

# **IMS System Hardware Users Guide**

April 21, 2015

Document Number: IMS-MAN-SYSTEM-HW-201410-GGv4



# Contents

1	Intro	oduction	1	6
2	IMS	Hardw	are Components	6
3	Sens	ors		8
4	netA	DC		8
	4.1	Front fa	aceplate	8
		4.1.1	User LEDS	9
		4.1.2	User Buttons	10
		4.1.3	Data Ports	10
	4.2	Bottom	faceplate	11
		4.2.1	Power Connectors	11
		4.2.2	Seismic Connectors	12
5	preA	MP		13
	5.1	Front fa	aceplate	13
		5.1.1	User LEDS	13
		5.1.2	Data Ports	14
	5.2	Bottom	faceplate	15
		5.2.1	Power Connectors	15
		5.2.2	Seismic Connectors	15
6 netSP(+)			16	
	6.1	Front fa	aceplate	16
		6.1.1	User LEDS	17
		6.1.2	User Buttons	19
		6.1.3	Data Ports	19
	6.2	Bottom	faceplate	21
		6.2.1	Power Connectors	21
		6.2.2	USB	22
7	GS+			22
	7.1	GS+ C	onnectors	22
	7.2	GS+ U	ser LED's	25



8	UPS	S	26
	8.1	Front faceplate	 26
		8.1.1 User LEDS	 27
	8.2	Bottom faceplate	 28
		8.2.1 Power Connectors	 28
9	GPS	S-Timer	28
	9.1	Front faceplate	 29
		9.1.1 User LEDS	 29
		9.1.2 User Buttons	 30
		9.1.3 NMEA Port	 30
		9.1.4 ATU Port	 31
	9.2	Bottom faceplate	 31
		9.2.1 Power Connectors	 31
		9.2.2 GPS Antenna	 32
	9.3	ATU Period	 32
10	Time	ne Distributor	33
	10.1	1 Front Faceplate	 33
		10.1.1 Power Connector	 33
		10.1.2 GPS Related Connectors	 33
		10.1.3 User LEDs	 34
		10.1.4 User DIP Switches	 35
		10.1.5 I/O Ports	 35
11	РТР	P Time Distributor	36
	11.1	1 Front Faceplate	 36
		11.1.1 Power Connector	 36
		11.1.2 GPS Antenna Connector	 37
		11.1.3 I/O Ports	 37
		11.1.4 User LEDs	 38
		11.1.5 User DIP Switches	 39
12	DSL	LAM and DSL modem	40
13	Syna	napse	40



institute of mine seismology

A	Logging into a netSP(+)	41
B	Configuring a netSP(+)'s network settings	42
С	Logging into a PTP Time Distributor	42
D	Configuring a PTP Time Distributor's network settings	43



# **List of Figures**

1	netADC front faceplate	9
2	netADC bottom faceplate.	11
3	preAMP front faceplate.	13
4	preAMP bottom faceplate.	15
5	netSP front faceplate.	17
6	netSP(+) bottom faceplate.	21
7	GS+ external connectors	23
8	GS+ external connector pinout details	24
9	Position and colour of the GS+'s internal LED's which are viewable through	
	the GS+'s semi-transparent cover.	25
10	the GS+'s semi-transparent cover	25 26
10 11	the GS+'s semi-transparent cover.	25 26 28
10 11 12	the GS+'s semi-transparent cover	25 26 28 29
10 11 12 13	the GS+'s semi-transparent cover.UPS front faceplate.UPS bottom faceplate.GPS-Timer front faceplate.GPS-Timer bottom faceplate.	25 26 28 29 31
10 11 12 13 14	the GS+'s semi-transparent cover.UPS front faceplate.UPS bottom faceplate.GPS-Timer front faceplate.GPS-Timer bottom faceplate.Time Distributor front faceplate.	<ol> <li>25</li> <li>26</li> <li>28</li> <li>29</li> <li>31</li> <li>33</li> </ol>

# List of Tables

1	Basic Seismic System Components.	6
3	Change record	45



# **1** Introduction

This guide provides an overview of the hardware components used in a typical IMS microseismic monitoring system. The basic concepts required for understanding each device's role in the system as well as how the system components interact are introduced. Reference information such as connector pin mappings and important specifications is also provided.

A typical IMS system consists of a number of hardware components or modules, mostly manufactured by IMS. Depending on the specific application and system configuration (especially relating to the system communications infrastructure), a number of third-party enabling components will be required, e.g. network switches, media converters, WiFi radios, etc. Most of these components are commercially available, off-the-shelf products, and are usually provided and administered by the customer or on-site IT department. Such devices are not covered in this document.

This document assumes that the infrastructure required for the operation of a reliable TCP/IP network, to which the IMS system has (preferably exclusive) access, exists and is fully operational.

# 2 IMS Hardware Components

A basic seismic monitoring system consists of seismic sensors, digitizers, (optional) waveform processors, communications hardware (including data and timing signal distribution) and a server. Table 1 divides the basic monitoring system into a number of different categories. A brief description of each category is given, and an example of some applicable IMS hardware is listed.

Sensor	Converts physical ground motion to an analogue, electrical signal.	IMS Geophone or Accelerometer, tri-axial or uni-axial in various packages (e.g. borehole, surface mount, etc.)	
Preamplifier	Amplifies analogue electrical signals	IMS preAMP	

Table 1: Basic Seismic System Components.



Digitizer Converts a sensor's analogue output signal into digital samples which can be used by a computer/digital processor.		IMS netADC (4 or 8 channels)	
Waveform Processor Performs the first stage of processing on digitized data, e.g. triggering, buffering and data transmission to the server.		IMS netSP/netSP+	
Integrated Digital SeismometerCombined Digitizer and Waveform Processor		IMS GS+ (previously ISS GS)	
Data Communication	Provides a means of long-range digital	IMS DSLAM and/or third party equipment.	
	communication between central server and end-point devices, e.g. netSP.	IMS DSL modem and/or third party equipment.	
Timing Signal Generation & Distribution	Provides a path and distribution system (and can optionally act as the source) for the time synchronisation signal (a.k.a. Analogue Time Update, or ATU).	IMS (GPS) Time Distributor, IMS PTP Time Distributor, and/or third party equipment.	
	Source of time synchronisation signal.	IMS GPS-Timer	
Server	Coordination, monitoring and control of the various seismic system hardware components, association of triggers into events and auto-processing of events.	IMS Synapse (Seismic Server Software)	IMS Synapse



# 3 Sensors

IMS manufactures a number of different types of sensors (e.g. geophones, accelerometers, FBA's, etc.), in a number of different packaging styles (e.g. borehole sonde, surface mount, removable borehole sonde, etc.). All sensors contain internal "*Smart Electronics*", which provide such information as sensor orientation and identification data. IMS netADC's are able to read this information, and feed it into the system to assist with configuration (see section 4).

All sensors use a common wiring colour coding scheme as documented in the following table for a three component sensor:

Sensor component	+ve	-ve
X	red	blue
У	yellow	green
Z	white	black
Smart Electronics	brown	violet

**Note**: single component sensors use the same cable, but only connect to the "z" and "Smart Electronics" pairs.

# 4 netADC

The netADC's primary function is to digitize sensor signals measured on its analogue inputs, and to send the digitized data to a waveform processor or seismic server node.

When the netADC powers up, it first scans its Smart Sensor inputs to see whether any IMS Smart Sensors are detected. Once this has completed (about 30 seconds after power up), the netADC uses the IMS WoE protocol to discover any IMS nodes on the Ethernet network that are available to accept digitized data from the netADC; this is called "*Discovery*" mode. The netADC reports any Smart Sensors it has detected during the scan, so that nodes have information about how many active sensor channels the netADC will digitize, and send in data for. Typical nodes which are able to accept digitized data from a netADC are a netSP, netSP+ or Synapse (seismic server software). Nodes will answer if they have sufficient spare capacity to accept data from this netADC (they may already be processing another netADC's data, and so may not have spare capacity to process this netADC's data). Once a node has been selected, the netADC is said to have "*Paired*" with the node, and the netADC will configure itself based on information received from the node (e.g. sampling rate, sensor/triggering settings, etc.).

The various connectors, user LED's and buttons of the netADC are detailed below.

# 4.1 Front faceplate





Figure 1: netADC front faceplate.

# 4.1.1 User LEDS

# Power

Solid Green	Internal electronics are	
	powered	
Flashes	netADC low level firmware	
Orange/Green	configuration (first few	
	seconds after power up)	

# **Pair Status**

Off	netADC low level firmware
	not configured
Blink Red	netADC initialising (reading
	Smart Sensors, etc.)
Blink Amber	"Discover" mode (looking
	for netSP's on network)
Blink Green	Initiated "pair" sequence
	with netSP
Solid Green	Successfully "paired"

# Sampling

Off	Not sampling
Blink Amber	Configuring ADC modules
Blink Green	Sampling data from analogue
	sensor interface



# ATU

Off	ATU has not been received
	since last reset
Solid Red	ATU has not been received in
	last two ATU periods
Solid Green	ATU OK

### WoE Tx/Rx

Blink Red	WoE message received
Blink Green	WoE message transmitted

### 4.1.2 User Buttons

#### Reset

• The reset button resets all the internal electronics of the netADC immediately.

### Test

• The test button is used for various factory tests.

# 4.1.3 Data Ports

### LAN

- One Ethernet (10/100Base-TX) port is provided for connecting the netADC to the local area network. This port has auto-MDIX (auto-crossover) functionality, so any standard, straight-through or crossover, Ethernet patch lead can be used to connect to the network.
- The LEDs integrated into the connector are used to represent the link status and activity on the medium and are interpreted as follows:

	ON	OFF	TOGGLE
Amber (LINK SPEED)	100 Mb/s	10 Mb/s or None	-
Green (LINK/ACTIVITY)	Link Up	No Link	Activity (Tx or Rx)

Note: When digitized data is continuously streaming from the netADC, there is so much data on the LAN port that the Green LED remains permanently in the off state (i.e. toggled "Link Up" state).



# ATU

• 3 wire RS-232 for input of time synchronization signal. Pin-outs of this table are as follows:

Pin no.	Signal
1	RxD
2	GND
3	N/C
4	N/C
5	N/C
6	N/C
7	N/C
8	N/C

# 4.2 Bottom faceplate



Figure 2: netADC bottom faceplate.

# 4.2.1 Power Connectors

# Input

- Input power should be between 12 and 15 V DC and should obey the polarity indicated on the input power port.
- A low impedance connection between chassis earth ( $\not\rightarrow$ ) and the local earthing system must be made. *This is extremely important to prevent equipment damage due to surges and EMI. If this connection is not made, the equipment warranty is voided.*



## Output

• For convenience, a 2-way output power port is provided, which simply provides an accessible connection to the input power port. This is useful if daisy chaining power between IMS devices using a single power source. Leave this port unconnected if not using this feature.

### 4.2.2 Seismic Connectors

The netADC is sold in 2 varieties: a 4- and 8-channel version. The sensor channels are grouped into banks of 4 channels, and referred to as "Seismic 1" and "Seismic 2" for the first and second banks respectively. Obviously a 4-channel netADC will only have 1 bank: Seismic 1.

### Analogue

• The analogue inputs to the netADC expect differential, balanced lines (e.g. geophone outputs) to be connected to each channel. As such, there is provision for 2 wires per channel - positive (+) and negative (-).

#### **Smart Sensor**

• The Smart Sensor inputs expect to be connected to the Smart Sensor pair of an IMS sensor, with the correct polarity. If IMS Smart Sensors are not to be used, then these connectors should be left unconnected.

**Note on Sensor Connections** In order to ensure that the system is able to auto-configure itself, it is important that the following conventions are followed when connecting sensors to the netADC:

- When connecting single component (uni-axial) sensors to a netADC, the Smart Sensor channel corresponding to the selected analogue channel should be used.
- When connecting three component (tri-axial) sensors to a netADC, the sensor components should always be connected to *consecutive* netADC analogue input channels on the *same bank* in the following order: x (red/blue sensor pair) on the first channel, followed by y (yellow/green sensor pair) on the second, and z (white/black sensor pair) on the third.
- Three component sensors should always have their Smart Sensor pair connected to the channel corresponding to the analogue **x** component.



# 5 preAMP

The preAMP's primary function is to amplify sensor signals before the signals are digitized by the netADC.

Similar to the eight channel netADC, the preAMP has eight differential channels, configured in two banks of four channels per bank. The banks are labeled "Seismic 1" and "Seismic 2". Each channel has an input and an output port, where the signal on the output is the amplified version of the signal connected to the input.

The user can select from four gain settings for each bank. The options available are programmed at the factory and printed on the unit. Gain options are also reported in software.

The amount of gain that is applied to each channel is configured per Seismic bank, which implies that all channels of Seismic 1 will have the same gain and all channels of Seismic 2 will have the same gain. Gain is configured through IMS Synapse.

# 5.1 Front faceplate



Figure 3: preAMP front faceplate.

# 5.1.1 User LEDS

Power

Solid Green	Internal electronics are
	powered
Flashes	Bootloader activated
Orange/Green	

# Gain S1

Off	Gain for bank Seismic 1 set
	to 0dB



Green	Gain for bank Seismic 1 set
	to gain option 1 <sup>1</sup>
Red	Gain for bank Seismic 1 set
	to gain option $2^1$
Amber	Gain for bank Seismic 1 set
	to gain option 3 <sup>1</sup>

### Gain S2

Off	Gain for bank Seismic 2 set
	to 0dB
Green	Gain for bank Seismic 2 set
	to gain option 1 <sup>1</sup>
Red	Gain for bank Seismic 2 set
	to gain option $2^1$
Amber	Gain for bank Seismic 2 set
	to gain option $3^1$

#### 5.1.2 Data Ports

### **Serial Port**

• This port provides a 3-wire RS-232 interface. All configuration and status reporting as well as updating firmware is performed via this port. The pin mappings are as follows<sup>2</sup>:

Pin no.	Signal
1	NC
2	GND
3	Isolated GND <sup>2</sup>
4	TxD
5	RxD
6	DCD
7	CTS
8	DTR

<sup>&</sup>lt;sup>1</sup>As configured at the factory.



 $<sup>^{2}</sup>$ To preserve the noise performance of the device, do not connect the isolated ground pin to any external signals. It is intended to be a "do not connect" pin.

# 5.2 Bottom faceplate



Figure 4: preAMP bottom faceplate.

# 5.2.1 Power Connectors

### Input

- Input power should be between 12 and 15 V DC and should obey the polarity indicated on the input power port.
- A low impedance connection between chassis earth ( ) and the local earthing system must be made. This is extremely important to prevent equipment damage due to surges and EMI. If this connection is not made, the equipment warranty is voided.

# Output

• For convenience, a 2-way output power port is provided, which simply provides an accessible connection to the input power port. This is useful if daisy chaining power between IMS devices using a single power source. Leave this port unconnected if not using this feature.

# 5.2.2 Seismic Connectors

The upper half of the seismic connectors serve as inputs and connects to sensor's analogue channels. The lower half of the seismic connectors output the amplified sensor signals and connects to netADC analogue input channels. The sensor channels are grouped into banks of 4 channels, and referred to as "Seismic 1" and "Seismic 2" for the first and second banks respectively.

### Analogue in

• The analogue inputs to the preAMP expect differential, balanced lines (e.g. geophone outputs) to be connected to each channel. As such, there is provision for 2 wires per channel: positive (+) and negative (-).



### Analogue out

• The analogue outputs from the preAMP are differential, balanced signals. As such, there is provision for 2 wires per channel: positive (+) and negative (-). The outputs are floating with 1500V isolation.

**Note on analogue connectors** For the system to be auto-configurable, sensors should be connected to seismic bank and channel numbers corresponding to that of the netADC.

For a uni-axial sensor, if the "smart" pair (purple and brown) is connected to Smart Sensor Seismic 1 channel 1 on netADC, then the analogue channel of the sensor must be connected to the preAMP seismic 1, channel 1 input. It then follows that the preAMP seismic 1, channel 1 analogue output must be connected to netADC seismic 1, channel 1 analogue input.

# 6 netSP(+)

The netSP(+)'s primary function is to collect digitized data from netADC's, and perform the first stage of processing on the digitized data. Typically, data is read from "paired" netADC's using the IMS WoE protocol, and triggering algorithms are applied to the data according to sensor information and user defined settings. Resulting "triggers" are reported to the seismic server (Synapse), and full waveforms are sent to Synapse based on an intelligent data prioritisation scheme where associated triggers are sent first, and then (if the communications bandwidth allows) non-associated triggers and finally un-triggered data is sent. If the communications bandwidth does not allow all the above data to be sent, then data is deleted in reverse order to which it was prioritized for sending.

When the netSP(+) powers up, it first boots its operating system and performs such administrative tasks as configuring its network interface and checking external disks for errors. Once this has completed (about 60 - 120 seconds after power up), the netSP(+) attempts to contact the network host called "synapse". netSP(+)'s network settings should be configured such that the netSP(+) is able to resolve the hostname "synapse" and the network should be configured such that there is a route between Synapse and netSP(+). Refer to appendix B for instructions on how to configure netSP(+)'s network settings.

After a connection to Synapse has been successfully established, the netSP(+) will listen for netADC's in "Discovery" mode.

The various connections, user LED's and buttons of the netSP(+) are detailed below.

# 6.1 Front faceplate







### 6.1.1 User LEDS

#### Power

Solid Green	Internal electronics are	
	powered	
Flashes	WoE switch bootloader is	
Orange/Green	waiting for a firmware	
	upgrade	

# LAN

• This LED indicates the status of the internal Ethernet connection between the netSP(+) and the WoE switch. The following table describes the LED states:

	ON	OFF	TOGGLE
Red (LINK SPEED)	100 Mb/s	10 Mb/s or None	-
Green (LINK/ACTIVITY)	Link Up	No Link	Activity (Tx or Rx)

Note: when both red and green LEDs are illuminated simultaneously, the resulting colour is orange/amber.

#### Status



		netSP(+) Status		
LED Colour	LED Flashing Frequency	Configuration Status	Connection to Server	Number of Paired netADC's
	0.5 Hz	Configured by Server	Connected	0
Green	1 Hz	Configured by Server	Connected	1
	2 Hz	Configured by Server	Connected	2
Orange	0.5 Hz	Self-configured	Not Connected	0
	1 Hz	Self-configured	Not Connected	1
	2 Hz	Self-configured	Not Connected	2
Red	0.25 Hz	Waiting for Configuration by Server	Not Connected	N/A
	0.5 Hz	Self-configured	Not Connected	0
	1 Hz	Self-configured	Not Connected	1
	2 Hz	Self-configured	Not Connected	2

USB

Flashing	External USB storage is
Green (1 Hz)	mounted and is writable
Flashing Red	External USB storage
(2 Hz)	detected, but not writable
Flashing Orange	No external USB storage
(0.5 Hz)	detected

NB: To avoid data corruption, never remove a USB device while it is mounted or data is being written to it, i.e. when the USB LED is flashing green.

**Unlabeled LED between Power and Status** This button flashes green at about 4-8 Hz to indicate that the netSP hardware has registered the **unlabeled** user button being pressed, and that a message indicating this will be delivered to the netSP software. Once this LED stops flashing, it means that the netSP software has acknowledged the button press and will take appropriate action.

**Unlabeled LED between LAN and USB** This button flashes green at about 4-8 Hz to indicate that the netSP hardware has registered the **USB** user button being pressed, and that a message indicating this will be delivered to the netSP software. Once this LED stops flashing, it means that the netSP software has acknowledged the button press and will take appropriate action. As a result of any actions taken by the netSP software the state of the USB LED may change, e.g. from flashing green (1 Hz) to flashing orange (0.5 Hz) to indicate that it is safe to remove the external USB storage device.



### 6.1.2 User Buttons

### Reset

• The reset button resets all the internal electronics of the netSP(+) immediately.

#### Test

• The test button is used for various factory tests, and to initiate the WoE switch bootloader.

### USB

• The USB button is used to request the safe removal of a connected and writable USB device. If a device is mounted and writable (see section 6.1.1) while pressing this button, a request is sent to the netSP software to stop writing to the device and unmount it (i.e. make it safe for removal). Once it is safe to remove, the USB LED should indicate that no USB device is detected (as described in section 6.1.1).

### 6.1.3 Data Ports

### NSIO

• The NSIO (Non-Seismic Input/Output) provides 7 channels which can be configured to be digital inputs, digital outputs or ADC inputs. Controlling of, and reading/writing from/to this port is managed through the Synapse interface. The pin mappings for this port are as follows:

Pin no.	Signal
1	NSIO channel 1
2	NSIO channel 2
3	NSIO channel 3
4	NSIO channel 4
5	NSIO channel 5
6	NSIO channel 6
7	NSIO channel 7
8	N/C

# Console/RS485

• The console/RS485 port provides 2 functions: it provides a 3-wire RS232 interface which the netSP(+) uses as its console port, and a 2-wire general purpose RS485 interface. Appendix A details how to login to the netSP(+) via the console port, and the RS485 port is read from/written to via the Synapse interface. The pin mappings for this port are as follows:



Pin no.	Signal
1	N/C
2	N/C
3	GND
4	TxD
5	RxD
6	N/C
7	RS485 A
8	RS485 B

### ATU

• The ATU port accepts an RS232 time synchronisation signal and distributes it to all 4 (LAN) ports of the WoE switch, using the IMS ATU-over-CAT5 mechanism. The netSP(+) can also be configured to generate ATU on this port. The pin mappings for this port are as follows:

Pin no.	Signal
1	RxD
2	GND
3	N/C
4	TxD
5	GND
6	N/C
7	N/C
8	N/C

### **Serial Port**

• This port provides a full 7-wire RS-232 interface with all modem control lines except ring indicator (RI), so it can be used to interface with an external serial modem. Of course it could also be used for any other task requiring a serial port. The pin mappings for this port are as follows:

Pin no.	Signal
1	DSR
2	RTS
3	GND
4	TxD
5	RxD
6	DCD
7	CTS
8	DTR



# LAN

- 4 LAN ports are provided and are connected to a 5 port internal WoE switch, the 5th port of which is internally connected to the netSP(+).
- All ports are Ethernet (10/100Base-TX) ports, and are used for connection to the network (providing a route to Synapse) and netADC's. All ports have auto-MDIX (auto-crossover) functionality, so any standard, straight-through or crossover, CAT5 Ethernet patch lead can be used to connect devices to these ports.
- The LEDs integrated into the connectors are used to represent the link status and activity on the medium and are interpreted as follows:

	ON	OFF	TOGGLE
Amber (LINK SPEED)	100 Mb/s	10 Mb/s or None	-
Green (LINK/ACTIVITY)	Link Up	No Link	Activity (Tx or Rx)

# 6.2 Bottom faceplate



Figure 6: netSP(+) bottom faceplate.

# 6.2.1 Power Connectors

### Input

- Input power should be between 12 and 15 V DC and should obey the polarity indicated on the input power port.
- A low impedance connection between chassis earth ( $\not\rightarrow$ ) and the local earthing system must be made. This is extremely important to prevent equipment damage due to surges and EMI. If this connection is not made, the equipment warranty is voided.



# Output

• For convenience, a 2-way output power port is provided, which simply provides an accessible connection to the input power port. This is useful if daisy chaining power between IMS devices using a single power source. Leave this port unconnected if not using this feature.

# 6.2.2 USB

• Standard female USB A-type receptacle for connection of external USB storage devices.

# 7 GS+

GS+ is based on the ISS Geophysical Seismometer (GS) hardware, but runs upgraded software to be able to run within the IMS Seismic System where telemetry, monitoring and control is supervised by IMS Synapse.

The GS+ performs the roles of a netSP and netADC unified into a single piece of hardware.

# 7.1 GS+ Connectors

The GS has ten external connectors, the function and position of each is detailed in figure 7.





	Connector	Name	Function
1	000000	Seismic 1	3 seismic sensor channels, smart sensor communication
2	BNC	GPS Antenna	External GPS antenna
3	(0.00) (0	Ethernet	Supports up to 100Mb/sec full-duplex Ethernet. Communication option.
4	000	External Slow 485	Satellite device communication and power
5	600	USB	External storage
6	000	Comms Downlink (L)	RS485 communication bus downlink
7	60	DC Power	DC power input and intelligent UPS communication <sup>4</sup> .
8	000	Comms Downlink (R)	RS485 communication bus downlink and debug port
9		Comms Uplink	Communications with central computer (RS232/485, FSK)
10	000000000000000000000000000000000000000	Seismic 2	3 seismic sensor channels, smart sensor communication

Figure 7: GS+ external connectors.

The pinout details of the connectors which mate with the external connectors of the GS+ are detailed in figure 8.



Seismic	Solder Side Cable	1 - X+ Red 2 - X- Blue 3 - Y+ Yello 4 - Y- Gree 5 - Z+ Whit 6 - Z- Black	10-ID Return         Orange           11-         12-           m         13-+12Vdc         Cyan           =         14- Gnd         Grey           t         15- Shield         Shield
	560	8 - ID Z Pwr Viole 9 - ID Z Pwr Pink	t 17- Slow485 (B) Green/Red 18-
Comms CC		RS485         RS23           1 - RS485         1 - TJ           2 - RS485         2 - R           3 - NC         3 - C'           4 - NC         4 - R           5 - NC         5 - DI           6 - NC         6 - DI           7 - NC         7 - R           8 - NC         8 - G	1         PSK data         1 - Blue           KD         1 - PSK data         2 - Yellow           TS         3 - NC         3 - Red           TS         3 - NC         3 - Red           TS         5 - NC         5 - Black           CD         5 - NC         6 - NC           TR         6 - NC         7 - Violet           Ind         8 - NC         8 - Green
Comms L/R		1 - RS485 Y 2 - RS485 E 3 - DEBUG Rx F 4 - DEBUG Tx C 5 - Shield	Yellow Blue Red Green
Xternal 485 & DC		1 - Ex485 (A) 2 - Ex485 (B) 3 - +12V/dc 4 - Ond	Yellow Blue Red Green
USB		1 - +5∀dc 2 - USB (A) 3 - USB (B) 4 - Gnd	Red Green White Black
Ethernet		RJ45 1 - Orange / White 2 - Orange 3 - Green / White 4 - Blue 5 - Blue / White 6 - Green 7 - Brown White 8 - Brown	Cable Solderside 7 1 5 3 3 3 4 2 2
UPS power		1 - ATU 2 - Gnd 3 - +12Vdc 4 - R5485 (A) 5 - R5485 (B)	White Black Red Yellow Blue
	Solder Side		

Figure 8: GS+ external connector pinout details.



# 7.2 GS+ User LED's

GS+ status indication LED's are mounted internally, and can be viewed through the GS+'s semi-transparent cover. The LED's may be difficult to see in daylight and are best viewed in low ambient light conditions. The details of these LED's are detailed in figure 9 and the following table.



Figure 9: Position and colour of the GS+'s internal LED's which are viewable through the GS+'s semi-transparent cover.



LED	Sub-	LED Status		
Colour	system	ON	FLASHING	OFF
All	Various	Done scanning SMART sensors, waiting for GS firmware to start	Scanning SMART sensors	Unused
Red	Run Status	Unused	Running/ Sampling	Not Running/ Sampling
Amber	Standalone	Networked	Standalone	Unused
Green	USB Storage	Unused	USB Storage Writable	No Writable USB Storage
Blue	UPS	Running on mains power	Running on battery power	No UPS detected
White	ATU	Previous ATU < 5 mins ago	Previous ATU < 10 mins ago	Previous ATU > 10 mins ago

# 8 UPS

The IMS Intelligent UPS acts as an AC/DC converter, converting universal (110/220 V) AC input to DC levels acceptable for powering other IMS equipment, e.g. netSP(+) and netADC. It also provides the ability to charge an external sealed lead acid battery and switch to battery power if the main AC input power source is removed.

Four DC output ports are available for powering a number of devices. Each output port is individually monitored for current drawn, and can be switched on or off remotely. Monitoring (e.g. reading current, AC input status, battery level, etc.) and control (e.g. switching off an output port) of the UPS is achieved using a serial link between the UPS serial port and the netSP(+). The user can issue commands or monitor the UPS status via the Synapse interface. The UPS can also warn the netSP(+) via the serial link of a power blackout, giving the netSP(+) sufficient time to backup any unsent data and gracefully shutdown.

The various connections, user LED's and buttons of the UPS are detailed below.

# 8.1 Front faceplate



Figure 10: UPS front faceplate.



# 8.1.1 User LEDS

#### Power

Solid Green	Internal electronics are
	powered
Flashes	Bootloader is waiting for a
Orange/Green	firmware upgrade

### AC Status

Solid Green	AC line power is present
Solid Red	AC line power is not present
	- running on battery

#### **Batt Status**

Solid Green	Battery is fully charged
Flashes	Battery is being charged
Green/Red	
Solid Red	Battery is critically low.

### **Serial Port**

• This port provides a 3-wire RS-232 interface for communicating with the netSP(+). The pin mapping is as follows:

Pin no.	Signal
1	N/C
2	N/C
3	GND
4	TxD
5	RxD
6	N/C
7	N/C
8	N/C

### **Output Switch**

• This switch is a mechanical override switch, which disconnects the DC output ports if moved to the off position.



# 8.2 Bottom faceplate



Figure 11: UPS bottom faceplate.

# 8.2.1 Power Connectors

# **DC Output**

- 4 DC output ports with polarity marked.
- 15.5 VDC output when AC input power is present, and battery voltage when AC input is not present.

# AC Input

- Universal IEC EN60320 C14 connector.
- Universal AC input: 90 260 VAC, 50 60 Hz.

# Battery

- Connection to external battery, which should be a 7 Ah, sealed lead acid battery.
- The third terminal on this connector (,, is for a low impedance connection between chassis earth and the local earthing system. *This is extremely important to prevent equipment damage due to surges and EMI. If this connection is not made, the equipment warranty is voided.*

# 9 GPS-Timer

The IMS GPS-Timer is used for generating the time synchronisation pulse (ATU) required by the IMS system. It also provides the RS232-level NMEA sentences and PPS (pulse per second) signal for synchronising computers to GPS time using NTP.

The various connections, user LED's and buttons of the GPS-Timer are detailed below.



# 9.1 Front faceplate



Figure 12: GPS-Timer front faceplate.

# 9.1.1 User LEDS

### Power

Solid Green	Internal electronics are
	powered.
Flashes	Bootloader is waiting for a
Orange/Green	firmware upgrade.

# ATU

• During normal operating mode, the ATU user LED behaves as follows:

Green	ATU pulse is being
	transmitted.

• When the GPS-Timer enters "*ATU Period Display*" or "*ATU Period Set*" mode this LED behaves as described in section 9.3.

### **3D** Fix

Green	GPS 3D-fix and time has
	been attained.
Red	Either a GPS 3D-fix, or valid
	time is yet to be attained.
Flashes	This LED flashes in either of
	the above cases to confirm
	that NMEA sentences are
	being successfully read from
	the GPS receiver.



### 9.1.2 User Buttons

### Reset

• The reset button resets all the internal electronics of the GPS-Timer immediately.

### **ATU Select**

• The "ATU Select" button is used for various factory tests, to initiate the bootloader and for setting/displaying the current ATU period setting - see section 9.3.

#### 9.1.3 NMEA Port

• This port outputs the RS-232 level NMEA sentences and PPS signal used for synchronising a computer's time to GPS. The pin mapping is as follows:

Pin no.	Signal
1	N/C
2	N/C
3	GND
4	TxD (NMEA)
5	N/C
6	PPS
7	N/C
8	N/C

• The LEDs on this port behave as follows:

Green	
	• On if GPS receiver is present.
	• Flashes off as PPS signal is transmitted.
Amber	Not used.



# 9.1.4 ATU Port

• This port outputs the RS-232 ATU signal, and provides a 3-wire RS-232 interface to the bootloader. The pin mappings are as follows:

Pin no.	Signal
1	TxD (ATU)
2	GND
3	TxD (BOOTLOADER)
4	RxD (BOOTLOADER )
5	GND
6	N/C
7	N/C
8	N/C

• The LEDs on this port behave as follows:

Green	On during transmission of
	ATU pulse.
Amber	Not used.

# 9.2 Bottom faceplate



Figure 13: GPS-Timer bottom faceplate.

# 9.2.1 Power Connectors

# Input

- Input power should be between 12 and 15 V DC and should obey the polarity indicated on the input power port.
- A low impedance connection between chassis earth ( $\stackrel{/}{\longrightarrow}$ ) and the local earthing system must be made. *This is extremely important to prevent equipment damage due to surges and EMI. If this connection is not made, the equipment warranty is voided.*



# Output

• For convenience, a 2-way output power port is provided, which simply provides an accessible connection to the input power port. This is useful if daisy chaining power between IMS devices using a single power source. Leave this port unconnected if not using this feature.

# 9.2.2 GPS Antenna

• Standard female SMA connector for connection of an external GPS antenna.

# 9.3 ATU Period

The GPS-Timer can be configured to generate an ATU pulse once per second, minute, 2 minutes or 5 minutes; this is referred to as the "ATU period". The pulse will be generated on the second (i.e. every second) or minute (i.e. at the end of the 59th second of every minute) boundary depending on the setting of the ATU period.

**To view the current ATU period** press the "ATU Select" button briefly to put the GPS-Timer into "*ATU Period Display*" mode - the ATU LED should light up red to acknowledge the button press. It will then blink red twice to indicate that the ATU period is about to be displayed, and then the LED will flash amber in a certain pattern before blinking red twice again, this time to indicate that it is done displaying the ATU period. The different ATU period settings are displayed by the amber LED flashing as follows:

ATU Period	Amber LED Pattern
1 second	1 quick flash (~2 Hz).
1 minute	1 slow flash (~1 Hz).
2 minutes	2 slow flashes (~1 Hz).
5 minutes	5 slow flashes (~1 Hz).

**To set the ATU period** keep the "ATU Select" button depressed (the ATU LED will burn solid red) until the ATU LED begins to flash, indicating that it is in "*ATU Period Set*" mode. In this mode the current ATU period will be displayed repeatedly using the same conventions as described above, i.e. 2 red blinks followed by amber flashes to indicate the ATU period, and then 2 red blinks. This will be repeated 10 times before returning to normal operating mode. If, at the end of any of the 10 cycles displaying the ATU period (i.e. after the last 2 red blinks of a cycle) the "ATU Select" button is depressed, the ATU period setting is changed to the next pre-defined setting according to the above table. So, to cycle through all ATU period settings, put the GPS-Timer into "*ATU Period Set*" mode by keeping the "ATU Select" button depressed. Without releasing the button, note the ATU period setting by observing the amber flashes of the ATU LED. At the end of each cycle, with the button still depressed, the ATU period setting will advance to the next value, and the new setting will be displayed. Release the "ATU Select" button when the ATU period is at the desired setting. To exit the "*ATU Period Set*" mode, the GPS-Timer can be reset or it will automatically exit after 10 cycles. The ATU period setting will be remembered until it is changed, even through power outages.



# **10** Time Distributor

The IMS Time Distributor is responsible for the fanning out of the system-wide timing synchronisation signal (also known as Analogue Time Update or ATU) at various points in the communications link. Fanning out of a signal means that a single input signal is copied to multiple outputs, where it can be redistributed. This is necessary in a typical IMS system because usually, to ensure accurate synchronisation, the timing source is generated at a single point, but needs to reach multiple locations where netADC's require the timing signal to synchronise their internal clocks.

Typically, Time Distributors are installed near multiple DSLAM's, where each DSLAM needs a timing signal input, but only one timing signal is available.

If the time distributor has been ordered with internal GPS module, then it is also able to act as the timing signal generator - i.e. as an ATU source.

# **10.1 Front Faceplate**



Figure 14: Time Distributor front faceplate.

# 10.1.1 Power Connector

# **AC Input**

- Universal IEC EN60320 C14 connector.
- Universal AC input: 90 260 VAC, 50 60 Hz.

### Fuse

• 5 x 20 mm glass fuse, 500 mA, time lag.

# 10.1.2 GPS Related Connectors

# ANT

• A female SMA connector is provided for GPS antenna connection.



## NMEA

• An RS232 output port which carries NMEA messages from the internal GPS module, as well as the PPS signal. The pin mapping of the connector is as follows:

Pin no.	Signal
1	N/C
2	N/C
3	GND
4	TxD
5	N/C
6	PPS
7	N/C
8	N/C

### 10.1.3 User LEDs

#### Power

Solid Green	Internal electronics are
	powered

### GPS

Solid Green	Internal GPS module present
Off	No internal GPS module

### 3D Fix

Solid Green	Internal GPS module present
	and 3D Fix has been obtained
Off	No internal GPS module/No
	3D Fix

### ATU

Solid Green	ATU is being generated
-------------	------------------------



# **10.1.4** User DIP Switches

Three user selectable DIP switches are provided, which control the ATU generation settings of the device. The switch position to ATU configuration mapping is detailed in the following table:

	DIP switch positions		itions	
ATU setting	1	2	3	Input Port
No ATU	UP	UP	UP	Fanned out to output ports
1 second	UP	UP	DOWN	Blocked
1 minute	UP	DOWN	UP	Blocked
2 minutes	UP	DOWN	DOWN	Blocked
5 minutes	DOWN	UP	UP	Blocked

Note: DIP switch positions not listed in the above table default to "No ATU".

# 10.1.5 I/O Ports

# Input

• An RS232 level input port which accepts a timing signal to be fanned out to the output ports (if the DIP switches are configured for "No ATU"). The pin mapping of this connector appears in the following table:

Pin no.	Signal
1	RxD
2	GND
3	N/C
4	N/C
5	GND
6	N/C
7	N/C
8	N/C

# Output

• Four RS232 level output ports which, if DIP switches are configured for "No ATU", provide the fanned-out input signal, or the generated ATU signal according to the DIP switch configuration. The pin mapping for these connectors is as follows:



Pin no.	Signal
1	TxD
2	GND
3	N/C
4	N/C
5	GND
6	N/C
7	N/C
8	N/C

# **11 PTP Time Distributor**

The IMS PTP Time Distributor is a timing signal (ATU) generator, providing sub-microsecond timing over Ethernet. It has built-in IEEE1588-2008 support, also known as Precision Time Protocol (PTP).

The PTP Time distributor is available in a grandmaster or slave option. The master option is equipped with a GPS module used for time synchronisation. By connecting a master to a local area network (LAN), up to twenty slave units can synchronise to the master across the LAN.

The PTP Time Distributor also serves as a Network Time Server (SNTP).

# **11.1 Front Faceplate**



Figure 15: PTP Time Distributor front faceplate - showing master option with GPS antenna connector.

# **11.1.1** Power Connector

### AC Input

- Universal IEC EN60320 C14 connector.
- Universal AC input: 90 260 VAC, 50 60 Hz.



### Fuse

• 5 x 20 mm glass fuse, 500 mA, time lag.

### 11.1.2 GPS Antenna Connector

• A female SMA connector is provided for GPS antenna connection.

### 11.1.3 I/O Ports

### NMEA

• An RS232 output port which carries NMEA messages from the internal PTP module, as well as the PPS signal. The pin mapping of the connector is as follows:

Pin no.	Signal
1	N/C
2	N/C
3	GND
4	TxD
5	N/C
6	PPS
7	N/C
8	N/C

### Console

• An RS232 level input/output port which provides a command line interface to the device for IP configuration and advanced use. The pin mapping of this connector is as follows:

Pin no.	Signal
1	N/C
2	N/C
3	GND
4	TxD
5	RxD
6	N/C
7	N/C
8	N/C



# ATU Out

• Four RS232 level output ports are available, which provide the generated ATU signal according to the DIP switch configuration. The pin mapping for these connectors is as follows:

Pin no.	Signal
1	TxD
2	GND
3	N/C
4	N/C
5	GND
6	N/C
7	N/C
8	N/C

# LAN

- An IEEE1588 LAN port with PTP timestamp engine is provided for connecting the PTP Time Distributor to the local area network backbone.
- A additional LAN port is provided for pass-through connectivity. When the PTP Time Distributor is connected in-line to an existing LAN connection, connect the downstream device to this port.
- All ports are Ethernet 10/100Base-TX ports. All ports have auto-MDIX (auto-crossover) functionality, so any standard, straight-through or crossover, CAT5 Ethernet patch lead can be used to connect devices to these ports.
- The LEDs integrated into the connectors are used to represent the link status and activity on the medium and are interpreted as follows:

	ON	OFF	TOGGLE
Amber (LINK SPEED)	100 Mb/s	10 Mb/s or None	-
Green (LINK/ACTIVITY)	Link Up	No Link	Activity (Tx or Rx)

# 11.1.4 User LEDs

Power

Solid Green	Internal electronics are
	powered



### Master

Solid Green	PTP master
Off	PTP slave
Flashing Green	Passive
Flashing Red	PTP state error

### PTP Sync

Solid Green	Synchronised to GPS (master	ATU will be generated
	mode) or PTP Master (slave	
	mode)	
Flash Green once	GPS (master mode) or PTP	ATU will be generated
per second for	master (slave mode) reached,	
half a second	establishing synchronisation	
Flash Amber	Lost time source, but clock	ATU will be generated
once per second	confidence as if synchronised	
for half a second	(Holdover state)	
Solid Red	Not synchronised	ATU will not be generated

### ATU

Flash Green on	ATU is being generated
Configured ATU	
boundary	
Flash red	ATU will not be generate
continuously	(Incorrect ATU setting
	selected on DIP switches)
Solid Red	ATU will not be generated
	(not synchronised to a time
	source)

### 11.1.5 User DIP Switches

Three user selectable DIP switches are provided, which control the ATU generation settings of the device as detailed in the following table:

	DIP switch positions			
ATU setting	1	2	3	
1 second	UP	UP	DOWN	
1 minute	UP	DOWN	UP	
2 minutes	UP	DOWN	DOWN	
5 minutes	DOWN	UP	UP	

Note: DIP switch positions not listed in the above table default to "No ATU".



# 12 DSLAM and DSL modem

Please refer to the separate DSLAM and DSL Modem Setup Guide for information on these devices.

# 13 Synapse

Please refer to the separate Synapse Getting Started Guide for information on Synapse.



# A Logging into a netSP(+)

There are two methods:

- 1. If the netSP(+) is connected to an IP network, or if one of the Ethernet (LAN) ports of the netSP(+) is available and accessible, use an SSH client (e.g. OpenSSH for Linux or PuTTY for Windows: www.putty.org) running on a PC which is able to access the netSP(+):
  - (a) Make sure the PC running the SSH client is configured with network settings compatible with that of the netSP(+), and is attached to the same network as the netSP(+), or has a route to the netSP(+); e.g. if necessary connect a straight through CAT5 Ethernet patch lead between one of the netSP(+) LAN ports and the Ethernet port of the PC running the SSH client. Ensure the netSP(+) is powered.
  - (b) Initiate an SSH connection to the netSP(+) by supplying the netSP(+)'s current IP address to the SSH client (you will need to wait for about two minutes after powering the netSP(+) before an SSH connection can be established).
  - (c) When asked for login details use username: root (contact IMS for password).
- 2. If you are not able to access the netSP(+) through an IP network, or directly through one of the the Ethernet (LAN) ports, and have access to a netSP(+) console cable, use a terminal emulator (e.g. Minicom for Linux or Hyperterminal or Teraterm for Windows: www.ayera.com/teraterm) to login via the console port:
  - (a) Configure your terminal emulator to use the correct port with the following settings:
    - baudrate: 115200
    - Data bits: 8
    - Parity: none
    - Stop bits: 1
    - Handshaking: none
  - (b) Connect the netSP(+) console cable between the serial port of the PC running the terminal emulator software and the netSP(+)'s serial port. Ensure the netSP(+) is powered.
  - (c) Monitor the output terminal emulator software and when prompted for login details, use username: root (contact IMS for password).



# **B** Configuring a netSP(+)'s network settings

Each netSP(+), unless specifically requested otherwise, is shipped with the following default, static network settings:

IP address	192.168.1.1
Netmask	255.255.255.0
Gateway	192.168.1.2

The netSP(+) is able to use different network settings to these defaults, including obtaining dynamic network settings from a DHCP server using an on-board DHCP client (udhcpc) to implement the Dynamic Host Configuration Protocol (see http://udhcp.busybox.net for udhcpc documentation).

Usually the IT department administering the network that the netSP(+) will connect to, will provide the networking parameters that the netSP(+) should use. If you need to choose your own network settings, e.g. because the netSP(+)'s are on an independent/isolated network, then please be sure to understand what you are doing. Networking settings are a field of their own and are beyond the scope of this document.

To change the network settings of a netSP(+), do the following:

- 1. Login to the netSP(+) using the methods of appendix A.
- 2. Once logged into the netSP(+), execute the interactive spipconf.sh script, and answer all questions the script asks using the desired network settings.
- 3. You will need to reboot the netSP(+) or restart the network for the settings to take effect.

# C Logging into a PTP Time Distributor

There are two methods:

- 1. If the PTP Time Distributor (TDU) is connected to an IP network, or if one of the Ethernet (LAN) ports of the PTP TDU is available and accessible, use a telnet client from on a PC which is able to access the PTP TDU:
  - (a) Make sure the PC running the telnet client is configured with network settings compatible with that of the PTP TDU, and is attached to the same network as the PTP TDU, or has a route to the PTP TDU; e.g. if necessary connect a straight through CAT5 Ethernet patch lead between the PTP TDU LAN port labeled "IEEE1588" and the Ethernet port of the PC running the telnet client. Ensure the PTP TDU is powered.



- (b) Initiate an telnet connection to the PTP TDU by supplying the PTP TDU's current IP address to the telnet client.
- (c) When asked for login details use username: root (contact IMS for password).
- 2. If you are not able to access the PTP TDU through an IP network, or directly through one of the the Ethernet (LAN) ports, and have access to a PTP TDU console cable, use a terminal emulator (e.g. Minicom for Linux or Hyperterminal, Putty or Teraterm for Windows: www.ayera.com/teraterm) to login via the console port:
  - (a) Configure your terminal emulator to use the correct port with the following settings:
    - baudrate: 115200
    - Data bits: 8
    - Parity: none
    - Stop bits: 1
    - Handshaking: none
  - (b) Connect the console cable between the serial port of the PC running the terminal emulator software and the PTP TDU's serial port. Ensure the PTP TDU is powered.
  - (c) Monitor the output terminal emulator software and when prompted for login details, use username: root (contact IMS for password).

# **D** Configuring a PTP Time Distributor's network settings

Each PTP Time Distributor, unless specifically requested otherwise, is shipped with the following default, static network settings:

IP address	192.168.1.10
Netmask	255.255.255.0
Gateway	192.168.1.1

The PTP Time Distributor (TDU) is able to use different network settings to these defaults, including obtaining dynamic network settings from a DHCP server.

Usually the IT department administering the network that the PTP TDU will connect to, will provide the networking parameters that the PTP TDU should use. If you need to choose your own network settings, e.g. because the PTP TDU's are on an independent/isolated network, then please be sure to understand what you are doing. Networking settings are a field of their own and are beyond the scope of this document.

To change the network settings of a PTP TDU, do the following:



- 1. Log in using the methods of appendix C.
- 2. Once logged into the PTP TDU, for static configuration execute the command

```
ipconfig -a <address> -m <netmask> -g <gateway> -c
```

substituting <address>, <netmask> and <gateway> as appropriate. The order of the parameters is important.

For dynamic configuration using DHCP, execute the command

ipconfig -d -c



Change Control Record				
Date	Author	Description	Revision	
2014/10/28 GG		Original document using correct IMS	s 0	
		document numbering system. The previous		
		document number was		
		IMS-SYSTEM-DOC-001.		
		Updated document formatting/layout.		
		Updated Table 1		
2014/11/28	DB	Added Section 11 PTP Time Distributor	1	
		Added Appendix C and D		
2014/12/01	GG	Updated images: TDU_GPS faceplate,	2	
		preAMP front & bottom faceplate		
2015/02/12	GG	Updated documentation relating to netSP(+)	3	
		user LED's and buttons		
2015/03/19	GG	Added GS+ documentation	4	

Table 3: Change record

