

OnCell 5004/5104 Series User's Manual

Second Edition, October 2009

www.moxa.com/product

MOXA®

© 2009 Moxa Inc. All rights reserved.
Reproduction without permission is prohibited.

OnCell 5004/5104 Series User's Manual

The software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

Copyright Notice

Copyright © 2009 Moxa Inc.
All rights reserved.
Reproduction without permission is prohibited.

Trademarks

MOXA is a registered trademark of Moxa Inc.
All other trademarks or registered marks in this manual belong to their respective manufacturers.

Disclaimer

Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.

Moxa provides this document “as is,” without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.

Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use or for any infringements on the rights of third parties that may result from its use.

This product may include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

Technical Support Contact Information

www.moxa.com/support

Moxa Americas:

Toll-free: 1-888-669-2872

Tel: +1-714-528-6777

Fax: +1-714-528-6778

Moxa China (Shanghai office):

Toll-free: 800-820-5036

Tel: +86-21-5258-9955

Fax: +86-10-6872-3958

Moxa Europe:

Tel: +49-89-3 70 03 99-0

Fax: +49-89-3 70 03 99-99

Moxa Asia-Pacific:

Tel: +886-2-8919-1230

Fax: +886-2-8919-1231

Table of Contents

Chapter 1	Introduction	1-1
	Overview	1-2
	Package Checklist.....	1-2
	Product Features	1-3
	Product Specifications	1-3
Chapter 2	Getting Started	2-1
	Panel Layout.....	2-2
	OnCell 5004 and OnCell 5004-HSDPA	2-2
	OnCell 5104 and OnCell 5104-HSDPA	2-3
	DIN-Rail, and Rack Mounting	2-4
	Wall or Cabinet Mounting.....	2-4
	DIN-Rail Mounting	2-4
	Connecting the Hardware	2-5
	SIM Card Installation	2-5
	Connecting the Power.....	2-5
	Connecting the I/O Port.....	2-5
	Connecting to the Network.....	2-6
	LED Indicators	2-6
	Reset Button	2-7
Chapter 3	Initial IP Address Configuration.....	3-1
	Static and Dynamic IP Addresses	3-2
	Factory Default IP Address.....	3-2
	Configuration Options	3-2
	OnCell Search Utility	3-2
	Web Console	3-2
	Telnet Console.....	3-2
	Serial Console.....	3-7
Chapter 4	Web Console Configuration	4-1
	Accessing the Web Console.....	4-2
	Web Console Navigation	4-3
	Basic Settings	4-3
	Device Settings	4-3
	Time Settings.....	4-4
	Network Settings	4-5
	LAN Settings	4-5
	LAN Port Configuration	4-6
	Cellular WAN Settings.....	4-7
	Ethernet WAN Settings	4-8
	DNS Settings	4-9
	DHCP Settings.....	4-11
	Auto IP Report.....	4-12
	Advanced Network Settings	4-12
	Firewall Settings	4-12
	WAN IP Filter	4-13
	Route Table	4-14
Chapter 5	System Management Settings	5-1

Misc. Network Settings	5-2
SNMP Agent Settings.....	5-2
DDNS Configuration	5-3
Auto Warning Settings.....	5-4
Event Settings.....	5-4
E-mail Alert	5-5
SNMP Trap.....	5-6
SMS Alert.....	5-7
Maintenance	5-7
Console Settings	5-7
PING Test.....	5-8
System Log Settings	5-8
Firmware Upgrade.....	5-9
Configuration Import/Export	5-9
Load Factory Defaults	5-10
Change Password.....	5-11
Certificate	5-12
Ethernet SSL Certificate Import	5-12
Certificate/Key Delete	5-12
System Monitoring	5-12
Network Connections	5-12
Network Statistics.....	5-13
Routing	5-13
DHCP Client List.....	5-14
Internet Sessions List.....	5-14
System Log	5-14
Dout State	5-15
Din and Power Status	5-15
Save Configuration.....	5-15
Restart.....	5-16
Restart System	5-16

Chapter 6 Introduction and Configuring OnCell Central Management Software6-1

Step 1: Server Settings.....	6-2
System Requirements	6-2
Installing OnCell Central Manager.....	6-3
Using OnCell Central Manager	6-7
Step 2: OnCell Device Web Console Settings	6-13
OnCell Central Settings	6-13
OnCell Central Server	6-14
Service Forwarding.....	6-14
Step 3: Host Settings and Management	6-15
OnCell Central Web Console	6-21
Server.....	6-21
Overview	6-22
Control Ports/User Ports Information.....	6-22
Account Settings.....	6-23
Device.....	6-23
All Devices	6-24
All User Ports	6-26
Service Forwarding.....	6-27
Firmware Upgrade.....	6-28

	Device's Settings and Maintenance.....	6-29
	Overview	6-30
	User Ports	6-30
	Service Forwarding.....	6-31
	Maintenance	6-32
	Logout	6-33
Chapter 7	OnCell Search Utility.....	7-1
	Installing Search Utility.....	7-2
	Configuring OnCell Search Utility.....	7-4
Appendix A	Default Settings	A-1

1

Introduction

The OnCell 5004/5104 cellular routers use a WAN connection to allow you to access your network from virtually anywhere within the operating range of your WAN network. There are currently four OnCell 5004/5104 models: The OnCell 5004, OnCell 5104, OnCell 5004-HSDPA, and OnCell 5104-HSDPA. The main differences between the models are the mechanical design, I/O support, and cellular technology support.

The following topics are covered in this chapter:

- Overview**
- Package Checklist**
- Product Features**
- Product Specifications**

Overview

The OnCell 5004/5104 are high-performance industrial grade cellular routers that allow up to 4 Ethernet-based devices to simultaneously use a single cellular data account for primary or backup network connectivity to remote sites and devices. Both the 5004 and 5104 series products provide the functionality of a cellular router, firewall, and switch in one device. The difference between the OnCell 5004 and OnCell 5104 is that the OnCell 5104 comes with a built-in relay output that can be configured to indicate the priority of events when notifying or warning engineers in the field, and the two digital inputs allow you to connect basic I/O devices, such as sensors, to the cellular network. The OnCell 5004 can be placed on a desktop or wall-mounted, whereas the OnCell 5104 has an IA design and can be attached to a DIN-Rail. Both products use 12 to 48 VDC power inputs with a screw-on connector for greater reliability, and the Ethernet port comes with 1.5 KV magnetic isolation protection to keep your system safe from unexpected electrical discharges.

Package Checklist

Each OnCell 5004/5104 cellular router is shipped in a separate box with standard accessories. In addition, several optional accessories can be ordered separately. When you receive your shipment, please check the contents of the box carefully, and notify your Moxa sales representative if any of the items are missing or appear to be damaged.

OnCell 5004/5104 cellular routers are shipped with the following items:

Standard Accessories

- Rubber SMA antenna
- Rubber stand (OnCell 5004 series only)
- Wallmount Kit (OnCell 5004 series only)
- Din-Rail Kit (OnCell 5104 series only)
- Terminal block (screw type)
- Document and Software CD
- Product warranty statement
- Quick Installation Guide

Optional Accessories

- DC Power Supply (screw-on)
- DC Power Supply (standard)
- Power Jack to Terminal Block Cable
- Antennas (impedance = 50 ohms):
 - ANT-CQB-AHSM-00-3m: Omni 0 dBi / 10 cm, magnetic SMA quad-band GSM/GPRS antenna, 3 m
 - ANT-CQB-AHSM-03-3m: Omni 3 dBi / 25 cm, magnetic SMA quad-band GSM/GPRS antenna, 3 m
 - ANT-CQB-AHSM-05-3m: Omni 5 dBi / 37cm, magnetic SMA quad-band GSM/GPRS antenna, 3 m
 - ANT-WCDMA-ASM-1.5: Omni 1.5 dBi, rubber SMA Five-band GSM/GPRS/UMTS/HSDPA antenna

Product Features

- Quad-band 900/1800, 850/1900 MHz GSM/GPRS
- Five-band 850/1900/2100 MHz GSM/GPRS/UMTS/HSDPA (OnCell 5004-HSDPA/5104-HSDPA only)
- Can connect up to 4 10/100BaseT(X) devices
- Redundant power (1 power jack; 1 terminal block) (OnCell 5004 series only)
- Industrial primary and backup wireless WAN connectivity
- 2 digital inputs and 1 relay output (OnCell 5104 series only)

Product Specifications

	OnCell 5004/5104	OnCell 5004/5104-HSDPA
Cellular Interface		
Standards	GSM/GPRS	GSM/GPRS/EDGE/UMTS/HSDPA
Quad-band Options	Quad-band 850/900/1800/1900 MHz	Tri-band 850/1900/2100 MHz Quad-band 850/900/1800/1900 MHz
GPRS Multi-slot	Class 10	
GPRS Terminal Device	Class B	
GRRS Coding Schemes	CS1 to CS4	
Tx Power	1 watt GSM1800/1900, 2 watt EGSM850/900	1 watt GSM1800, 2 watt GSM900, 0.25 watt UMTS/HSDPA, 0.5 watt EDGE900, 0.4 watt EDGE1800
WAN Interface		
Number of Ports	1	
Ethernet	10/100M (RJ45)	
1.5 KV Magnetic Isolation Protection	Yes	
LAN Interface		
Number of Ports	4	
Ethernet	10/100M (RJ45)	
1.5KV Magnetic Isolation Protection	Yes	
SIM Interface		
Number of SIMs	2	
SIM Control	3V	
I/O Interface		
Alarm Contacts & Digital Inputs	OnCell 5004 series: No I/O interface OnCell 5104 series: 1 Digital Output & 2 Digital Inputs	
Software		
Network Protocols	UDP/TCP, SNTP, ICMP, DDNS, DHCP/BOOTP, PPPoE, PPP, DNS, Relay, HTTPS, Telnet	

Router/Firewall	NAT, port forwarding, routing
Authentication	Local user-name and password
Security	IP filtering
Physical Characteristics	
Housing	Aluminum (IP30)
Weight	OnCell 5004 series: 505 ± 5 g OnCell 5104 series: 645 ± 5 g
Dimensions	OnCell 5004 series: 158 x 103 x 34 mm OnCell 5104 series: 160 x 103 x 50 mm
Environmental Limits	
Operating temperature	-30 to 55°C (-22 to 131°F), 5 to 95% RH
Storage Temperature	-40 to 75°C (-40 to 167°F)
Regulatory Approvals	
Safety	UL (UL60950)
Radio	FCC Part 22H, FCC Part 24E, EN301 489-1, EN301 489-7 EN301 511
EMC	CE: EN55022 Class A / EN55024, FCC: FCC part 15 subpart B, Class A, EN61000-4-2 (ESD) Level 4, EN61000-4-3 (RS) Level 3, EN61000-4-4 (EFT) Level 4, EN61000-4-5 (Surge) Level 3, EN61000-4-8 Level 3, EN61000-4-12 Level 3
Reliability	
Warranty	5 years (see www.moxa.com/warranty for details)

2

Getting Started


This chapter covers the hardware installation of the OnCell 5004/5104. Software installation is covered in the next chapter.

The following topics are covered in this chapter:


- ❑ **Panel Layout**
 - OnCell 5004 and OnCell 5004-HSDPA
 - OnCell 5104 and OnCell 5104-HSDPA
- ❑ **DIN-Rail, and Rack Mounting**
 - Wall or Cabinet Mounting
 - DIN-Rail Mounting
- ❑ **Connecting the Hardware**
 - SIM Card Installation
 - Connecting the Power
 - Connecting the I/O Port
 - Connecting to the Network
 - LED Indicators
 - Reset Button

Panel Layout

OnCell 5004 and OnCell 5004-HSDPA




Top View




Front View

Side View




Rear View


OnCell 5104 and OnCell 5104-HSDPA




Top View



Front View




Back View




Bottom View

Left Side





Right Side



DIN-Rail, and Rack Mounting


Wall or Cabinet Mounting

The OnCell 5004 and OnCell 5004-HSDPA device servers have built-in "ears" for attaching the device server to a wall or the inside of a cabinet. We suggest using two screws per ear to attach the device servers to a wall or the inside of a cabinet. The heads of the screws should be less than 6.0 mm in diameter, and the shafts should be less than 3.5 mm in diameter, as shown in the figure at the right.



DIN-Rail Mounting

DIN-rail attachments can be purchased separately to attach the OnCell 5104 and OnCell 5104-HSDPA to a DIN-Rail. When snapping the attachments to the DIN-Rail, make sure that the stiff metal springs are at the top.




Connecting the Hardware

This section describes how to connect the OnCell 5004/5104 cellular IP-modem to a host PC or Ethernet devices for first time testing purposes. We cover *SIM card Installation*, *Connecting the Power*, *Connecting the I/O Port*, *Connecting to the Network*, *LED Indicators*, and *Reset Button*.


SIM Card Installation

In order to protect the SIM card, the SIM card slot is located inside the OnCell 5004 and 5104 series' housing. You will need to unscrew and remove the outer SIM card cover before installing or removing the SIM card.

OnCell 5004 Series



OnCell 5104 Series



Connecting the Power

The dual power inputs that connect to the 4-pin power terminal block (2 terminals per power input) can be used to connect the OnCell 5104 to a variety of field power sources that support 12 to 48 VDC. The OnCell 5004 cellular routers have 1 power jack and 1 terminal block for connecting the power. After connecting the power wire to the OnCell's terminal block or power jack, the "PWR" LED will glow a solid green color to indicate that the system is ready.

Connecting the I/O Port

The OnCell 5104 has six terminals on the terminal block for the I/O ports, with 4 terminals used for each input, and 2 terminals used for the output.

Digital Input

Power input levels determine the ON/OFF states of the digital inputs:

- On: +13 to +30 V for state "1"
- Off: -30 to -3 V for state "0"

Digital Output: 1 relay output with current carrying capacity of 1 A @ 24 VDC.

Connecting to the Network

Connect one end of the Ethernet cable to the OnCell's 10/100M Ethernet port and the other end of the cable to the Ethernet network. If the cable is properly connected, the OnCell will indicate a valid connection to the Ethernet in the following way:

- The Ethernet LED glows a solid green when connected to a 100 Mbps Ethernet network.
- The Ethernet LED glows a solid orange when connected to a 10 Mbps Ethernet network.
- The Ethernet LED flashes when Ethernet packets are being transmitted or received.

LED Indicators

The following table explains the LED indicators on the front panel of the OnCell 5004-HSDPA/5104-HSDPA:

Type	Color	LED Function
PWR 1	Green	Activation of DC Power
	Off	Power is off, or power error
PWR 2	Green	Activation of DC Power
	Off	Power is off, or power error
2G	Amber	GPRS/EDGE is connected
	Off	GPRS/EDGE is disconnected
3G	Amber	UMTS/HSDPA is connected
	Off	UMTS/HSDPA is disconnected
SIM 1	Amber	Steady on: SIM 1 is inserted with correct PIN. Slowly Blinking (once per sec.): PIN code is wrong or no PIN code stored
	Off	SIM 1 is not connected
Ready	Green	Steady on: Software Ready Slowly Blinking (once per sec.): The OnCell has been located by the OnCell Search Utility
	Off	Power is off, or device is booting up.
Fault	Red	Steady on: Booting up, or IP fault Slowly Blinking (once per sec.): Cannot get an IP address from the DHCP server
	Off	Power is off, or normal with no error condition
LAN 1-4	Green	Steady on: LAN port is connected. Slowly Blinking (once per sec.): Data transmission
	Off	LAN port is disconnected, or device is booting up
Signal (3 LEDs)	Green	Indicates the signal level (at least 2 LEDs should be illuminated to guarantee proper data transmission)

Reset Button

Press and hold the **Reset** button for 5 sec to load factory defaults: Use a pointed object, such as a straightened paper clip or toothpick to press the reset button. This will cause the Ready LED to blink on and off. The factory defaults will be loaded once the Ready LED stops blinking (default LAN IP: 192.168.127.254).

Initial IP Address Configuration

When setting up the OnCell 5004/5104 for the first time, the first thing you should do is configure the IP address. This chapter introduces the different methods that can be used to do this.

The following topics are covered in this chapter:

- ❑ **Static and Dynamic IP Addresses**
- ❑ **Factory Default IP Address**
- ❑ **Configuration Options**
 - OnCell Search Utility
 - Web Console
 - Serial Console

Static and Dynamic IP Addresses

Determine whether your OnCell 5004/5104 needs to use a static IP address or dynamic IP address (either DHCP or BOOTP application).

- *If your OnCell 5004/5104 is used in a static IP environment*, you must assign a specific IP address using one of the tools described in this chapter.
- *If your OnCell 5004/5104 is used in a dynamic IP environment*, the IP address will be assigned automatically from over the network. In this case, set the IP configuration mode to DHCP or BOOTP.



ATTENTION

Consult your network administrator on how to reserve a fixed IP address for your OnCell 5004/5104 in the MAC-IP mapping table when using a DHCP Server or BOOTP Server. For most applications, you should assign a fixed IP address to your OnCell 5004/5104.

Factory Default IP Address

The OnCell 5004/5104 is configured with the following default private IP address:

192.168.127.254

Note that IP addresses that begin with “192.168” are referred to as private IP addresses. Devices configured with a private IP address are not directly accessible from a public network. For example, you would not be able to ping a device with a private IP address from an outside Internet connection. If your application requires sending data over a public network, such as the Internet, your OnCell 5004/5104 will need a valid public IP address, which can be leased from a local ISP.

Configuration Options

OnCell Search Utility

You may configure your OnCell 5004/5104 with the bundled OnCell Search Utility for Windows. Refer to *Chapter 7, OnCell Search Utility*, for details on how to install and use OnCell Search Utility.

Web Console

You may configure your OnCell 5004/5104 using a standard web browser. Refer to *Chapter 4, Using the Web Console*, for details on how to access and use the OnCell 5004/5104's web console.


Telnet Console

Depending on how your computer and network are configured, you may find it convenient to use network access to set up your OnCell 5004/5104's IP address. This can be done using Telnet.


**ATTENTION**

Figures in this section were taken from the OnCell 5004's and OnCell 5104's Telnet console.


1. From the Windows desktop, select **Start → Run**, and then type the following content in the **Run** window: **telnet 192.168.127.254**. If your IP address is different from the default setting, use your IP address instead. Click **OK**.




2. The console terminal type selection is displayed, as shown below. Enter **1** for **ansi/vt100**, and then press **ENTER** to continue.




- The following window will only appear if the OnCell 5004/5104 is password protected. Enter the console password if you are prompted to do so, and then press **ENTER**.




- Press **N** or use the arrow keys to select **Network**, and then press **ENTER**.



- Press **L** or use the arrow keys to select **LAN**, and then press **ENTER**.




- Use the arrow keys to move the cursor to **IP address**. Use the **DELETE**, **BACKSPACE**, or **SPACE** keys to erase the current IP address, and then type in the new IP address and press **ENTER**. Note that if you are using a dynamic IP configuration (BOOTP, DHCP, etc.), you will need to go to the **IP configuration field** and press **ENTER** to select the appropriate configuration.




- Press **ESC** twice to return to the previous page.

8. Press **A** or use the arrow keys to select **Save** and then press **ENTER**. Press **ENTER** again to confirm the save command.



9. Press **R** or use the arrow keys to select **Restart** and then press **ENTER**. Press **ENTER** again to restart the OnCell 5004/5104.




Serial Console

The OnCell 5004/5104 can be configured through the serial console, which works the same as the Telnet console but is accessed through the RS-232 console port rather than over the network.


The following instructions and screenshots show how to enter the serial console using PComm Terminal Emulator, which is available free of charge as part of the PComm Lite suite. You may use a different terminal emulator utility, although the actual screenshots and procedure may vary slightly from the following instructions.

Before running PComm Terminal Emulator, use an RJ45 to DB9-F (or RJ45 to DB25-F) cable to connect the OnCell 5004/5104's RS-232 console port to your PC's COM port (generally COM1 or COM2, depending on how your system is set up). After installing PComm Terminal Emulator, take the following steps to access the RS-232 console utility.


1. Turn off the OnCell 5004/5104's power, and then use a serial cable to connect the OnCell 5004/5104's serial console port to your computer's RS-232 serial port.
2. From the Windows desktop, select **Start → All Programs → PComm Lite → Terminal Emulator**.
3. The PComm Terminal Emulator window should appear. From the **Port Manager** menu, select **Open** (or click the **Open** icon).
4. The Property window opens automatically. Select the **Communication Parameter** tab, and then select the appropriate COM port for the connection (COM1 in this example). Configure the parameters to **115200** for Baud Rate, **8** for Data Bits, **None** for Parity, and **1** for Stop Bits.




- From the Property window's Terminal page, select **ANSI** or **VT100** for **Terminal Type** and then click **OK**.



- If the OnCell 5004/5104 has been set up for password protection, you will be prompted to enter the password. After you enter the password, or if password protection was not enabled, you will be prompted to select the terminal mode. Press **1** for **ansi/vt100** and then press **ENTER**.



- The main menu should appear. Once you are in the console, you may configure the IP address through the **Network** menu, just as with the Telnet console. Refer to steps 4 to 11 in the Telnet Console section to complete the initial IP configuration.



Web Console Configuration

In this chapter, we explain all aspects of the web-based console configuration utility. Moxa's easy-to-use management functions will help you set up your OnCell 5004/5104 and allow you to maintain your wireless network easily.

This chapter covers the following topics:

- ❑ **Accessing the Web Console**
- ❑ **Web Console Navigation**
 - Basic Settings
 - Device Settings
 - Time Settings
- ❑ **Network Settings**
 - LAN Settings
 - LAN Port Configuration
 - Cellular WAN Settings
 - Ethernet WAN Settings
 - DNS Settings
 - DHCP Settings
 - Auto IP Report
- ❑ **Advanced Network Settings**
 - Firewall Settings
 - WAN IP Filter
 - Route Table

Accessing the Web Console


Open your web browser and enter **192.168.127.254** in the website address line. This is the default IP address for the OnCell 5004/5104—if a new address has been assigned, enter the new address instead. Press **ENTER** to load the page.



ATTENTION

The examples and figures in this chapter use the OnCell 5004/5104 factory default IP address of 192.168.127.254. If you have assigned a different IP address to your OnCell 5004/5104, you will need to use that IP address. Refer to *Chapter 3, Initial IP Address Configuration*, for details on how to configure the IP address.

Enter the console password if prompted. The password will be transmitted with MD5 encryption over the Internet to ensure that the password cannot be easily intercepted by eavesdroppers.



The OnCell 5004/5104's web console will appear.

Welcome to OnCell 5004/5104-HSDPA Series	
Model name	OnCell 5004-HSDPA
Serial No.	50042
Firmware version	1.0 Build 09100510
LAN IP address	192.168.127.254
LAN MAC address	00:90:E8:00:00:AC
Cellular RSSI	0
Cellular WAN IP address	0.0.0.0
Cellular mode	N/A
Ethernet WAN IP address	192.168.126.254
Ethernet WAN MAC address	00:90:E8:00:00:AB
Ethernet WAN speed	No link
WAN preference	Cellular
Up time	0 days 00h:34m:45s

Web Console Navigation

The left panel of the OnCell 5004/5104's web console is the navigation panel, and contains an expandable menu tree for navigating among the various settings and categories. When you click on a menu item in the navigation panel, the main window will display the corresponding options for that item. Configuration changes can then be made in the main window. For example, if you click on **Basic Settings** in the navigation panel, the main window will show a page of basic settings that you can configure.

You must click on the **Submit** button to keep your configuration changes. The **Submit** button is located at the bottom of every page that has configurable settings. If you navigate to another page without clicking the Submit button, your settings will be lost.

Changes will not take effect until they are saved and the OnCell is restarted! You may complete this in one step by clicking on the Save/Restart option after you submit a change. If you need to make several changes before restarting, you may save your changes without restarting by selecting **Save Configuration** in the navigation panel. If you restart the OnCell without saving your configuration, the OnCell will discard all submitted changes.

Basic Settings

The **Basic Settings** screen can be accessed from the navigation panel.

Device Settings

Basic Settings

Device Settings

Device name

Device location

Time Settings

Time zone ▼

Local time (24-hour) / / : :

Time server

Device name: This is an optional text field for your own use; it does not affect the operation of the OnCell 5004/5104, and can be used to help differentiate one OnCell 5004/5104 device from another.

Device location: This is an optional text field for your own use; it does not affect the operation of the OnCell 5004/5104, and is useful for assigning or describing the location of an OnCell 5004/5104. If you need to manage multiple servers, you should use this field to indicate the precise physical location of each device.

Time Settings

The OnCell 5004/5104 has a built-in Real-Time Clock for time calibration functions. Functions such as Auto Warning Email or SNMP Trap can add real-time information to messages.

Before making any adjustments to the time, first select the correct time zone and submit the change. The console will display the real time according to the time zone. To modify the real time clock, click on **Modify** next to the **Local time** field. Once you submit the new time, the OnCell 5004/5104's firmware will modify the GMT time based on your time zone and local time settings.




ATTENTION

There is a risk of explosion if the real-time clock battery is replaced with the wrong type!

The OnCell 5004/5104's real time clock is powered by a lithium battery. We strongly recommend that you do not attempt to replace the lithium battery without help from a qualified Moxa support engineer. If you need to change the battery, please contact the Moxa RMA service team.

Time zone (default=GMT Greenwich Mean Time): This field shows the currently selected time zone and allows you to select a different time zone.

Local time: This field shows the time that you last opened or refreshed the browser. To set the local time for the OnCell 5004/5104, click on the Modify button, update the date and time, and then click on submit.



Time server: The OnCell 5004/5104 uses SNTP (RFC-1769) for auto time calibration. You may enter a time server IP address or domain name in this optional field. Once the OnCell 5004/5104 is configured with the correct time server address, it will request time information from the time server every 10 minutes.

Network Settings

LAN Settings

LAN Settings

Router IP Configuration
IP address
Netmask

LAN Port Configuration

Port	Enable	Speed	Flow Ctrl
1	Yes <input type="button" value="v"/>	Auto <input type="button" value="v"/>	Enable <input type="button" value="v"/>
2	Yes <input type="button" value="v"/>	Auto <input type="button" value="v"/>	Enable <input type="button" value="v"/>
3	Yes <input type="button" value="v"/>	Auto <input type="button" value="v"/>	Enable <input type="button" value="v"/>
4	Yes <input type="button" value="v"/>	Auto <input type="button" value="v"/>	Enable <input type="button" value="v"/>

You can access **LAN Settings** by expanding the **Network Settings** item in the navigation panel. Use the LAN Settings page to assign the OnCell 5004/5104's IP address, netmask, and other LAN Port configuration parameters.

Note: You must assign a valid IP address to your OnCell 5004/5104 before it will work in your network environment. Your network system administrator should provide you with a unique IP address and related settings for your network. First-time users can refer to Chapter 3, Initial IP Address Configuration, for more information.

IP Address (default=192.168.127.254): Enter the IP address that is assigned to your OnCell 5004/5104. All LAN ports on the OnCell 5004/5104 will share this IP address. An IP address is a number assigned to a network device (such as a computer) as a permanent address on the network. Computers use the IP address to identify and talk to each other over the network. Choose a proper IP address that is unique and valid for your network environment.

Netmask (default=255.255.255.0): Enter the subnet mask. A subnet mask represents all of the network hosts at one geographic location, in one building, or on the same local area network. When a packet is sent out over the network, the OnCell 5004/5104 will use the subnet mask to check whether the desired TCP/IP host specified in the packet is on the local network segment. If the address is on the same network segment as the OnCell 5004/5104, a connection is established directly from the OnCell 5004/5104. Otherwise, the connection is established through the given default gateway.

LAN Port Configuration

LAN Port Configuration settings are included to give the user control over Port Access, Port Transmission Speed, Flow Control, and Port Type (MDI or MDIX). An explanation of each configuration item is given below.

Enable (default=Yes):

Option	Description
Yes	Allows data transmission through the port.
No	Immediately shuts off port access.

Speed (default=Auto):

Option	Description
Auto	Allows the port to use the IEEE 802.3u protocol to negotiate with connected devices. The port and connected devices will determine the best speed for that connection.
10Mbps Half	Choose one of these fixed speed options if the opposing Ethernet device has trouble auto-negotiating for line speed.
10Mbps Full	
100Mbps Half	
100Mbps Full	

Flow Ctrl (default=Enable):

This setting enables or disables the flow control capability of this port when the “speed” setting is in “auto” mode. The final result will be determined by the “auto” process between the OnCell and connected device.

Option	Description
Enable	Enables the flow control capability of this port when in auto-nego mode.
Disable	Disables the flow control capability of this port when in auto-nego mode.

Cellular WAN Settings

Cellular WAN Settings

SIM1 Configuration

Please ensure inserting SIM card into right slot. **Below setup applies to SIM1 slot only.**

SIM1 PIN	<input type="text"/>
Band	<input type="text" value="Auto"/>
Username	<input type="text"/>
Password	<input type="text"/>
APN	<input type="text"/>
TCP/IP compression	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Link quality report	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
WAN preference	<input checked="" type="radio"/> Cellular <input type="radio"/> Ethernet
NAT service	<input checked="" type="radio"/> Enable <input type="radio"/> Disable

Warning: When plugging in GSM/GPRS/EDGE capable SIM card, please select related band to get the better performance!

From the left navigation panel, click **Network Settings** → **Cellular WAN Settings** to configure the SIM card Settings. The various configuration items are described below:

SIM1 PIN: This is a pin code that locks the SIM card until you enter the correct code. Use the pin to protect your account. The default code is set by the Service Provider. Note that a cell phone must be used to change the PIN.

Band (default=Auto): The GSM/GPRS/EDGE/UMTS/HSDPA band will be detected automatically.

Username: This is the user ID account.

Password: This is the user password.

APN: Before using the GPRS, an APN (Access Point Name) must be configured as a modem initialization command.

TCP/IP compression (default=Disable): Use this field to indicate whether the remote user's application requests compression.

Link quality report (the default is set to "Disable"): Set this field to "Enable" for the following:

- (1) Automatic disconnection if the link noise of the connection exceeds a user-defined threshold.
- (2) When the OnCell device does not receive data from the host within a 3 minute lapse, the OnCell will then ping the host up to 4 times. If all the pings fail, the OnCell will automatically reboot.

WAN Preference (default=Cellular): Select either cellular or Ethernet. Note that the WAN preference option on the Ethernet WAN settings page (see below) will be updated automatically.

Note: You need to select one of the two WAN preferences. If the line is disconnected, the router will not automatically switch to the other WAN preference.

NAT service (default=Enable): If you Enable NAT service, LAN-side applications will be able to link to WAN-side applications.

Ethernet WAN Settings

Ethernet WAN Settings

IP configuration	Static <input type="button" value="v"/>
IP address	192.168.126.254
Netmask	255.255.255.0
Gateway	<input type="text"/>
PPPoE user account	<input type="text"/>
PPPoE password	<input type="text"/>
WAN speed	Auto <input type="button" value="v"/>
WAN preference	<input checked="" type="radio"/> Cellular <input type="radio"/> Ethernet

You can access **Network Settings** → **Ethernet WAN Settings** by expanding the item in the navigation panel. Ethernet WAN Settings is where you assign the OnCell 5004/5104's IP address, netmask, Gateway, and other parameters for the Ethernet interface.

Note: You must assign a valid WAN IP address to your OnCell 5004/5104 before it will work in your network environment. Your network system administrator should provide you with a unique IP address and related settings for your network.

IP configuration (default=Static): You can choose from four possible IP configuration modes:

Mode	Description
Static	User-defined IP address, netmask, and gateway
DHCP	DHCP server-assigned IP address, netmask, gateway, and DNS
PPPoE	Your ISP will provide you with a username and password. This option is typically used for DSL services
DHCP/BOOTP	DHCP server-assigned IP address, netmask, gateway, and DNS, or BOOTP server-assigned IP address (if the DHCP server does not respond)
BOOTP	BOOTP server-assigned IP address

IP Address (default=192.168.126.254): Enter the WAN IP address that the OnCell 5004/5104 will use to connect to the internet.

Netmask (default=255.255.255.0): Enter the subnet mask. A subnet mask represents all of the network hosts at one geographic location, in one building, or on the same local area network. When a packet is sent out over the network, the OnCell 5004/5104 will use the subnet mask to check whether the desired TCP/IP host specified in the packet is on the local network segment. If the address is on the same network segment as the OnCell 5004/5104, a connection is established directly from the OnCell 5004/5104. Otherwise, the connection is established through the given default gateway.

Gateway: Enter the IP address of the gateway if applicable. A gateway is a network computer that acts as an entrance to another network. Usually, the computers that control traffic within the network or at the local Internet service provider are gateway nodes. The OnCell 5004/5104 needs to know the IP address of the default gateway computer in order to communicate with the hosts outside the local network environment. For correct gateway IP address information, consult the network administrator.

PPPoE user account: If your ISP uses a PPPoE connection, enter the user account name here. This option is typically used for DSL services.

PPPoE password: Enter your password.

WAN speed (default=Auto):

Option	Description
Auto	Allows the port to use the IEEE 802.3u protocol to negotiate with connected devices. The port and connected devices will determine the best speed for that connection.
10Mbps Half	Choose one of these fixed speed options if the opposing Ethernet device has trouble auto-negotiating for line speed.
10Mbps Full	
100Mbps Half	
100Mbps Full	

WAN Preference (default=Cellular): You must select either one of the WAN interface for data transmission. Note that the WAN preference option on the Cellular WAN settings page (see above) will be updated automatically.

Note: You need to select one of the two WAN preferences. If the line is disconnected, the router will not automatically switch to the other WAN preference.

DNS Settings

DNS Settings

User Configuration

DNS server 1

DNS server 2

From ISP

DNS server from C-WAN 0.0.0.0

DNS server from E-WAN 0.0.0.0

Submit

DNS server 1: This is an optional field since the DNS server automatically obtains the DNS server's IP address from C-WAN OR E-WAN. If your network has access to a DNS server, you may choose to enter the DNS server's IP address in this field. This allows the OnCell 5004/5104 to use domain names instead of IP addresses to access hosts.

The Domain Name System (DNS) is used to identify Internet domain names and to translate the names into IP addresses. A domain name is an alphanumeric name, such as www.moxa.com, that it is usually easier to remember than the numeric IP address. A DNS server is a host that translates this kind of text-based domain name into the actual IP address used to establish a TCP/IP connection.

When the user wants to visit a particular website, the user's computer sends the domain name (e.g., www.moxa.com) to a DNS server to request that website's numeric IP address. When the IP address is received from the DNS server, the user's computer uses that information to connect to the website's web server. The OnCell 5004/5104 plays the role of a DNS client, in the sense that it actively queries the DNS server for the IP address associated with a particular domain name. The following functions in the OnCell 5004/5104's web console support the use of domain names in place of IP addresses: Time Server, Destination IP Address (in TCP Client mode), Mail Server, SNMP Trap Server, and SMTP Server.

DNS server 2: This is an optional field. The IP address of another DNS server may be entered in this field for times when DNS server 1 is unavailable.

DNS server form C-WAN: Normally, the DNS server's IP address is automatically obtained through the cellular network. The OnCell will use the DNS server's C-WAN or E-WAN's IP address as its first priority.

DNS server form E-WAN: Normally, the DNS server's IP address is automatically obtain through the Ethernet network. The OnCell will use the DNS server's C-WAN or E-WAN's IP address as its first priority.

DHCP Settings

DHCP Service Settings

DHCP Server Configuration

DHCP server Enable Disable
DNS relay Enable Disable
Start IP address
Maximum dynamic users
Client lease time (1~10 days)
Static IP mapping Enable Disable

DHCP Static Mapping

No	<input type="checkbox"/> Active	IP Address	MAC Address
1	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
2	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
3	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
4	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
5	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
6	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
7	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
8	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>

DHCP (default=Enable): DHCP stands for Dynamic Host Control Protocol. When you enable the DHCP Server, it will automatically assign an IP address to the computers on the LAN/private network. Be sure to set your computers to be DHCP clients by setting their TCP/IP settings to "Obtain an IP Address Automatically." When you turn your computers on, they will automatically load the proper TCP/IP settings provided by the OnCell 5004/5104. The DHCP Server will automatically allocate an unused IP address from the IP address pool to the requesting computer. You must specify the starting and ending address of the IP address pool.

DNS relay (default=Enable): If enabled, your computers will use the router as a DNS server. If disabled, the DNS server information will be transferred from your ISP to your computers.

Start IP address: Enter the starting IP addresses for the DHCP server's IP assignment.

Note: If you assign static IP addresses to your computers or devices, make sure the IP addresses are outside of this range or you may have an IP conflict.

Client lease time: The length of time for the IP address lease. Enter the Lease time in days.

Static IP mapping: If enabled, the mapping list allows you to assign specific IP addresses to specific MAC addresses, provided the IP addresses are in the range specified under DHCP Server Configuration.

Auto IP Report

Auto IP Report Settings

Configuration

Auto IP report to host

Report to UDP port

Report period (1 - 65535 min)

Auto IP report to host: Reports generated by the Auto report function will be sent automatically to this IP address or host name.

Report to UDP port (default=63100): This is the UDP port number assignment for the serial port on the OnCell 5004/5104.

Report period (default=99): You can use this option to set the automatic report time.

Advanced Network Settings

Firewall Settings

Virtual Server Settings

Virtual Server Settings

Virtual Server Setup

Virtual server Enable Disable

No	<input type="checkbox"/> Activate	Protocol	Public Port	Internal IP	Internal Port
1	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>
2	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>
3	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>
4	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>
5	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>
6	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>
7	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>
8	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>

Virtual Server Settings (default=Disable): This function allows remote users to access the Host or FTP services via a public IP address, and automatically redirects them to local servers in the LAN (Local Area Network).

The OnCell firewall feature filters out unrecognized packets to protect your LAN network when computers networked with the OnCell are hidden from public view. If you wish, you can make some of the LAN computers accessible from the Internet by enabling Virtual Server. Depending on the requested service, the OnCell redirects the external service request to the appropriate server within the LAN network.

The OnCell is also capable of port-redirection, which means that traffic coming in to a particular port may be redirected to a different port on the server computer.

Public Port: The public port is the port seen from the Internet side.

Internal IP: Enter the IP address of the host on your local network that you want to link the incoming service to.

Internal Port: The internal port is the port being used by the application on the host within your local network.

WAN IP Filter

WAN IP Filter

WAN Filter Configuration

WAN IP filter Enable Disable

Filter type Accept Deny

No	<input type="checkbox"/> Activate	IP Address	Network Type	Netmask
1	<input type="checkbox"/>	<input type="text"/>	Host <input type="button" value="v"/>	<input type="text" value="255.255.255.255"/>
2	<input type="checkbox"/>	<input type="text"/>	Host <input type="button" value="v"/>	<input type="text" value="255.255.255.255"/>
3	<input type="checkbox"/>	<input type="text"/>	Host <input type="button" value="v"/>	<input type="text" value="255.255.255.255"/>
4	<input type="checkbox"/>	<input type="text"/>	Host <input type="button" value="v"/>	<input type="text" value="255.255.255.255"/>
5	<input type="checkbox"/>	<input type="text"/>	Host <input type="button" value="v"/>	<input type="text" value="255.255.255.255"/>
6	<input type="checkbox"/>	<input type="text"/>	Host <input type="button" value="v"/>	<input type="text" value="255.255.255.255"/>
7	<input type="checkbox"/>	<input type="text"/>	Host <input type="button" value="v"/>	<input type="text" value="255.255.255.255"/>
8	<input type="checkbox"/>	<input type="text"/>	Host <input type="button" value="v"/>	<input type="text" value="255.255.255.255"/>
9	<input type="checkbox"/>	<input type="text"/>	Host <input type="button" value="v"/>	<input type="text" value="255.255.255.255"/>
10	<input type="checkbox"/>	<input type="text"/>	Host <input type="button" value="v"/>	<input type="text" value="255.255.255.255"/>
11	<input type="checkbox"/>	<input type="text"/>	Host <input type="button" value="v"/>	<input type="text" value="255.255.255.255"/>
12	<input type="checkbox"/>	<input type="text"/>	Host <input type="button" value="v"/>	<input type="text" value="255.255.255.255"/>
13	<input type="checkbox"/>	<input type="text"/>	Host <input type="button" value="v"/>	<input type="text" value="255.255.255.255"/>

The OnCell 5004/5104 uses an IP address-based filtering method to control access to its Ethernet ports. The WAN IP Filter allows you to restrict network access to the OnCell 5004/5104. Access is controlled by IP address. When the WAN IP Filter list is enabled, a WAN's IP address must be listed in order to gain access to the OnCell 5004/5104. You may add a specific address or range of addresses by using a combination of IP address and netmask, as follows:

Filter Type: If you select Accept, the WAN IPs that you enter will be allowed to access the OnCell 5004/5104. If you select Deny, the WAN IPs that you enter will be denied access to the OnCell 5004/5104.

IP Address: This is the WAN IP address or cellular network address that you would like to filter.

Netmask type: Commonly used network classes are indicated below:

Network Type	Netmask
Host	255.255.255.255
Class A	255.0.0.0
Class B	255.255.0.0
Class C	255.255.255.0
User Define	---

Netmask: This is the destination network's netmask.

Route Table

You can access the **Route Table** by expanding **Advanced Network Settings** in the navigation panel. Use the route table to configure how the OnCell 5004/5104 will connect to an outside network.

Route Table

Route Configuration

Static route Enable Disable

No	<input type="checkbox"/> Activate	Gateway	Destination	Network Type	Netmask	Metric	Interface
1	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN
2	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN
3	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN
4	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN
5	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN
6	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN
7	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN
8	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN
9	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN
10	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN
11	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN
12	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN
13	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN
14	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN
15	<input type="checkbox"/>			Class C	255.255.255.0	15	LAN

You are allowed up to 16 entries in the route table. For each entry, you must provide the gateway, destination, netmask type, netmask, metric hops, and interface.

Gateway: This is the IP address of the next-hop router.

Destination: This is the host's IP address or the network address of the route's destination.

Netmask type: Commonly used network classes are indicated below:

Network Type	Netmask
Host	255.255.255.255
Class A	255.0.0.0
Class B	255.255.0.0
Class C	255.255.255.0
User Define	---

Netmask: This is the destination network's netmask.

Metric: You may use this optional field to enter the number of hops from the source to the destination. This allows the OnCell 5004/5104 to prioritize the routing of data packets if there is more than one router available to reach a given destination.

Interface: This is the network interface to which the packet must be sent.

System Management Settings

In this chapter, we describe the OnCell 5004/5104's system management settings. The same configuration options are also available through the Telnet and serial console.

This chapter covers the following topics:

- ❑ **Misc. Network Settings**
 - SNMP Agent Settings
 - DDNS Configuration
- ❑ **Auto Warning Settings**
 - Event Settings
 - E-mail Alert
 - SNMP Trap
 - SMS Alert
- ❑ **Maintenance**
 - Console Settings
 - PING Test
 - System Log Settings
 - Firmware Upgrade
 - Configuration Import/Export
 - Load Factory Defaults
 - Change Password
- ❑ **Certificate**
 - Ethernet SSL Certificate Import
 - Certificate/Key Delete
- ❑ **System Monitoring**
 - Network Connections
 - Network Statistics
 - Routing
 - DHCP Client List
 - Internet Sessions List
 - System Log
 - Dout State
 - Din and Power Status
- ❑ **Save Configuration**
- ❑ **Restart**
 - Restart System

Misc. Network Settings

SNMP Agent Settings

SNMP Agent

Configuration

SNMP	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Read community string	<input type="text" value="public"/>
Write community string	<input type="text" value="private"/>
Contact name	<input type="text"/>
Location	<input type="text"/>
SNMP agent version	<input checked="" type="checkbox"/> v1 <input checked="" type="checkbox"/> v2 <input checked="" type="checkbox"/> v3
Read only user name	<input type="text"/>
Read only authentication mode	Disable <input type="button" value="v"/>
Read only password	<input type="text"/>
Read only privacy mode	Disable <input type="button" value="v"/>
Read only privacy	<input type="text"/>
Read/write user name	<input type="text"/>
Read/write authentication mode	Disable <input type="button" value="v"/>
Read/write password	<input type="text"/>
Read/write privacy mode	Disable <input type="button" value="v"/>
Read/write privacy	<input type="text"/>

SNMP: To enable the SNMP Agent function, select the **Enable** option, and enter a community name (e.g., **public**).

Read community string (default=public): This is a text password that is used to weakly authenticate queries to agents of managed network devices.

Write community string (default=private): This is a text password that is used to weakly authenticate changes to agents of managed network devices.

Contact name: The optional SNMP contact information usually includes an emergency contact name and telephone or pager number.

Location: Use this optional field to specify the location string for SNMP agents such as the OnCell 5004/5104. This string is usually set to the street address where the OnCell 5004/5104 is physically located.

SNMP agent version: The OnCell 5004/5104 supports SNMP V1, V2, and V3.

Read-only and Read/Write Access Control

The following fields allow you to define user names, passwords, and authentication parameters for two levels of access: read-only and read/write. The name of the field will indicate which level of access it refers to. For example, **Read only** authentication mode allows you to configure the authentication mode for read-only access, whereas **Read/write** authentication mode allows you to configure the authentication mode for read/write access. For each level of access, you may configure the following:

User name: Use this optional field to identify the user name for the specified level of access.

Authentication mode (default=Disable): Use this field to select MD5 or SHA as the method of password encryption for the specified level of access, or to disable authentication

Privacy mode (default=Disable): Use this field to enable or disable DES_CBC data encryption for the specified level of access.

Password: Use this field to set the password for the specified level of access.

Privacy: Use this field to define the encryption key for the specified level of access.

DDNS Configuration

DDNS

Configuration

DDNS Enable Disable

Server address

Host name

Username

Password

DDNS (default=Enable): The Dynamic Domain Name System is a method of keeping a domain name linked to a changing IP Address. Check the box to enable DDNS.

Server address: Choose your DDNS provider from the drop down menu.

Host name: Enter the Host Name that you registered with your DDNS service provider.

Username: Enter the Username for your DDNS account.

Password: Enter the Password for your DDNS account.

Auto Warning Settings

Event Settings

Event Settings			
System Event			
Cold start	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> SMS
Warm start	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> SMS
Network Event			
Ethernet link down	<input type="checkbox"/> Dout	<input type="checkbox"/> SMS	
Config Event			
Console(web/text) login auth fail	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> SMS
IP changed	<input type="checkbox"/> Mail		<input type="checkbox"/> SMS
Password changed	<input type="checkbox"/> Mail		<input type="checkbox"/> SMS
Power Event			
Power 1 fail	<input type="checkbox"/> Mail	<input type="checkbox"/> Dout	<input type="checkbox"/> SMS
Power 2 fail	<input type="checkbox"/> Mail	<input type="checkbox"/> Dout	<input type="checkbox"/> SMS
Din Event			
Din 1 turn on (trigger)	<input type="checkbox"/> Mail	<input type="checkbox"/> Dout	<input type="checkbox"/> SMS
Din 1 turn off (trigger)	<input type="checkbox"/> Mail	<input type="checkbox"/> Dout	<input type="checkbox"/> SMS
Din 2 turn on (trigger)	<input type="checkbox"/> Mail	<input type="checkbox"/> Dout	<input type="checkbox"/> SMS
Din 2 turn off (trigger)	<input type="checkbox"/> Mail	<input type="checkbox"/> Dout	<input type="checkbox"/> SMS
Cellular Module Event			
Cell. module fail	<input type="checkbox"/> Mail	<input type="checkbox"/> Dout	
Cell. close temperature range	<input type="checkbox"/> Mail	<input type="checkbox"/> Dout	<input type="checkbox"/> SMS
Cell. over temperature range	<input type="checkbox"/> Mail	<input type="checkbox"/> Dout	<input type="checkbox"/> SMS

On the Event Settings page, you may configure how administrators are notified of certain system, network, configuration, power, Din, and cellular module events. Depending on the event, different options for automatic notification are available, as shown above. **Mail** refers to sending an e-mail to a specified address. **Trap** refers to sending an SNMP Trap. **Dout** is available on the network, power, Din, and cellular module event. **SMS** refers to sending a message to a specified phone number.

Note: If you select “enable for SMS,” the receiver will receive the message in the following format:

“**[modelName] alert (S/N: [serial number], LAN: [LAN IP], [LAN MAC Address]): (C-WAN/E-WAN/P-WAN: [WAN IP]): (yyyy-mm-dd hh:mm:ss) [message]**”

“C-WAN: x.x.x.x” indicates the cellular WAN IP address

“E-WAN: x.x.x.x” indicates the Ethernet WAN IP address and “P-WAN: x.x.x.x” indicates the preferred WAN IP address.

Cold start: This refers to starting the system from a power off state, or after upgrading the firmware

Warm start: This refers to restarting the OnCell 5004/5104 without turning the power off.

Ethernet link down: These settings configure the OnCell 5004/5104 to change the status of the relay output and SMS if the specified connection goes down.

Console (web/text) login authentication failure: This field refers to failed attempts to log in to a WEB/Console/Telnet/OnCell Central using a password.

IP changed: With this IP address change, the OnCell 5004/5104 will send an email or SMS warning after it reboots.

Password changed: With this option selected, the OnCell 5004/5104 will attempt to send an e-mail or SMS warning after it reboots with a new console password. If the OnCell 5004/5104 is unable to send an e-mail or SMS message to the mail server within 15 seconds, it will still reboot without sending the e-mail or SMS.

Power event: The OnCell 5004/5104 provides two DC power inputs for redundancy. If either power fails, the OnCell 5004/5104 will attempt to send an e-mail warning, relay output, or SMS.

Din event: When the status of digital input 1 or 2 is changed, the OnCell 5104 series will attempt to send an e-mail, trigger the digital output, or send an SMS.

Cell. module fail: When the cellular module fails to function, the OnCell 5004/5104 will attempt to send an e-mail, or trigger the digital output to inform users.

Cell. close temperature range: When the temperature on the cellular module inside the OnCell 5004/5104 is close to the upper or lower limit, the OnCell 5004/5104 will attempt to send an e-mail, trigger the digital output, or send an SMS message to inform users.

Cell. over temperature range: When the temperature on the cellular module inside the OnCell 5004/5104 is outside the normal temperature range, the OnCell 5004/5104 will attempt to send an e-mail, or trigger the digital output to inform users.

E-mail Alert

E-mail Alert

Mail Server Settings

Mail server (SMTP)

My server requires authentication

 User name

 Password

From e-mail address

To e-mail address 1

To e-mail address 2

To e-mail address 3

To e-mail address 4

The E-mail Alert settings determine how e-mail warnings are sent for system and serial port events. You may configure up to 4 e-mail addresses to receive automatic warnings.



ATTENTION

Consult your Network Administrator or ISP for the proper mail server settings. The Auto warning function may not work properly if it is not configured correctly. The OnCell 5004/5104's SMTP AUTH supports LOGIN, PLAIN, and CRAM-MD5 (RFC 2554).

Mail server: This field is for your mail server's domain name or IP address.

User name: This field is for your mail server's user name, if required.

Password: This field is for your mail server's password, if required.

From e-mail address: This is the e-mail address from which automatic e-mail warnings will be sent.

To e-mail address 1 to 4: This is the e-mail address or addresses to which the automatic e-mail warnings will be sent.

SNMP Trap

SNMP Trap

SNMP Trap

SNMP trap server IP or domain name	<input type="text"/>
Trap version	<input checked="" type="radio"/> v1 <input type="radio"/> v2
Trap community	<input type="text" value="alert"/>

SNMP trap server IP: Use this field to indicate the IP address to use for receiving SNMP traps.

Trap version (default=v1): Use this field to select the SNMP trap version.

Trap community (default=alert): Use this field to designate the SNMP trap community.

SMS Alert

SMS Alert

SMS Alert

To phone number 1

To phone number 2

To phone number 3

To phone number 4

Encode format ▼

To phone number 1 to 4: This is the phone number to which the automatic warnings message will be sent.

Encode format:

SMS Data Format	
Text ASCII (7 bits) (default)	7 bits text format (160 bytes per packet)
Binary	8 bits binary (140 bytes per packet)
Unicode	16 bits Unicode (UCS2) format (70 bytes per packet)

Maintenance

Console Settings

Console Settings

HTTP console Enable Disable

HTTPS console Enable Disable

Telnet console Enable Disable

SSH console Enable Disable

Reset button Always Enable Disable after 60 sec

On this screen, access to different OnCell 5004/5104 configuration console options (HTTP, HTTPS, Telnet, SSH) can be enabled or disabled. Refer to Change Password later in this chapter for more information on passwords.

Reset button (default=Always Enable): Select “Always Enable” to activate the reset button. Use the “Disable after 60 sec” option to avoid resetting the server when the reset button is pressed accidentally.

PING Test

Ping Test

Ping Destination

Destination

You can ping an IP address from the OnCell 5004/5104 web console in order to test the Ethernet connection. Enter the IP address or domain name in the **Destination** field to make sure the connection is OK.


System Log Settings



System Log Settings allows the administrator to customize which network events are logged by the OnCell 5004/5104. Events are grouped into five categories, known as event groups, and the administrator selects which groups to log under Local Log. The actual system events that would be logged for each system group are listed under summary. For example, if **System** was enabled, then System Cold Start events and System Warm Start events would be logged.

Group	Event
System	System Cold Start, System Warm Start, Power 1 DOWN, Power 2 DOWN, Cell. module awake/fail, Cell. module close/over temperature range
Network	DHCP/BOOTP/PPP/PPPoE Get IP/Renew, NTP, Mail Fail, NTP Connect Fail, IP Conflict, Network Link Down, Cell. module get/lost IP
Config	Login Fail, IP Changed, Password Changed, Config Changed, Firmware Upgrade, SSL Key Import, Config Import, Config Export
Input	Din 1 turn on, Din 1 turn off, Din 2 turn on, Din 2 turn off


Firmware Upgrade




The OnCell 5004/5104's firmware can be upgraded through the web console or the OnCell Search Utility. If you have made any changes to your configuration, remember to save the configuration first before upgrading the firmware. Please refer to Save Configuration later in this chapter for more information. Any unsaved changes will be discarded when the firmware is upgraded. To upgrade the firmware, simply enter the file name and click **Submit**. The latest firmware can be downloaded from www.moxa.com.

Configuration Import/Export

The OnCell 5004/5104 can share or back up its configuration by exporting all settings to a file.




To import a configuration, go to **System Management** → **Maintenance** → **Configuration Import**. Enter the configuration file path/name and click Submit. The OnCell 5004/5104's configuration settings will be updated according to the configuration file. If you also wish to import the IP configuration (i.e., the OnCell 5004/5104's IP address, netmask, gateway, etc.), make sure that **Import all configurations including IP configurations** is checked.




To export a configuration, go to **System Management** → **Maintenance** → **Configuration Export** and click **Download**. A standard download window will appear to allow you to download the configuration into a file and location of your choice.

Load Factory Defaults



This function will reset all of the OnCell 5004/5104's settings to the factory default values. All previous settings, including the console password will be lost. If you wish to keep the OnCell 5004/5104 IP address, netmask, and other IP settings, make sure **Keep IP settings** is checked before loading the factory defaults.

Change Password



For all changes to the OnCell 5004/5104's password protection settings, you will first need to enter the old password. Leave this blank if you are setting up password protection for the first time. To set up a new password or change the existing password, enter the password under both **New password** and **Confirm password**. To remove password protection, leave the **New password** and **Confirm password** boxes blank.




ATTENTION

If you forget the password, the **ONLY** way to configure the OnCell 5004/5104 is by using the reset button on the OnCell 5004/5104's casing to load the factory defaults.

Before you set a password for the first time, it is a good idea to export the configuration to a file when you have finished setting up your OnCell 5004/5104. Your configuration can then be easily imported back into the OnCell 5004/5104 if you need to reset the OnCell 5004/5104 due to a forgotten password or for other reasons. Please refer to the section on Configuration Import/Export earlier in this chapter for more details.

Certificate

Ethernet SSL Certificate Import



SSL certificate is used to ensure that the website you are accessing is the one you trust, and to encrypt the data transmitted between you and the website. The SSL certificate contains unique, authenticated information about the certificate owner. It is issued by a Certificate Authority (CA), such as VeriSign, that verifies the identity of the certificate owner.

The OnCell 5004/5104 will generate a new SSL certificate whenever a new IP is used. However, the SSL certificate is issued by the OnCell itself. If you would like to import an SSL certificate issued by a primary CA, you can do it from the “Ethernet SSL Certificate Import” page.

Certificate/Key Delete




You can delete an SSL certificate on this page. To do so, select the Delete option and then click on the Submit button.

System Monitoring

Network Connections

Go to **System Monitoring** under **Network Connections** to view network connection information.



Network Statistics

Go to System Monitoring under Network Statistics to view network statistics.

The screenshot shows the MOXA Network Statistics web interface. On the left is a navigation menu with categories like Main Menu, Overview, Basic Settings, Network Settings, Advanced Network Settings, System Management, and System Monitoring. The main content area is titled 'Network Statistics' and includes an 'Auto refresh' checkbox. Below this is a table of network statistics:

Protocol	Direction	Count	Sub-Category	Count	Sub-Category	Count
ETHERNET	Received	0		Sent		12
	Received	3168		Sent		6169
IP	RDiscard	0	StoRoute	0	SDiscard	0
	ErrHeader	0	ErrProto	0	ErrAddr	0
ICMP	Received	0		Sent		0
	REchoReq	0		SEchoReq		0
UDP	REchoReply	0		SEchoReply		0
	Received	91	ErrPorts	0	Sent	18
TCP	ErrHeader	0		Sent		6144
	Received	3070	ErrPorts	0	ReSent	1
	ErrHeader	0	Opens	34		
	CumEstab	2				

Routing

Go to System Monitoring under Routing to display the routing information.

The screenshot shows the MOXA Routing web interface. On the left is a navigation menu. The main content area is titled 'Routing' and includes an 'Auto refresh' checkbox. Below this is a table of current routing information:

Interface	Destination	Gateway/HA	Netmask	Metric	Flag	Use
LAN	192.168.127.0	192.168.127.254	255.255.255.0	1	U+	6319
WAN-E	192.168.126.0	192.168.126.254	255.255.255.0	1	D	9

Possible flags include:

U: route is up

D: route is down

G: use gateway


+: default gateway

T: static route


H: target is a host

DHCP Client List

The DHCP Client List shows all the clients that require and have successfully received IP assignments. You can click the **Refresh** button to refresh the list.




Internet Sessions List



The Internet Sessions page displays full details of active Internet sessions through your router. An Internet session is a conversation between a program or application on a LAN-side computer and a program or application on a WAN-side computer/device.

System Log

This option displays the system log. You may click **Select all** to select the entire log if you wish to copy and paste the contents into a text file.




Dout State

Dout State refers to the relay output status, which can be configured to change upon the occurrence of certain system events through **Auto Warning Settings** under **System Management**. Click **Dout State** under **System Monitoring** to display a list of events that may cause a change to the Dout state. If a configured alarm event occurs, the Dout state changes, and you can refer to this screen to determine the specific cause for the alarm. To reset the Dout state, click on Acknowledge Event.




Din and Power Status

Go to **Din and Power status** under **System Monitoring** to display the power and digital input information.



Save Configuration

Go to **Save Configuration** and then click **Save** to save your submitted configuration changes to the OnCell 5004/5104's flash memory. The configuration changes will be effective when the OnCell 5004/5104 is restarted. If you do not save your changes before restarting, they will be discarded.



Restart

Restart System

Go to **Restart System** under **Restart** and then click **Restart** to restart the OnCell 5004/5104. Ensure that you save all of your configuration changes before you restart the system or else these changes will be lost.




6

Introduction and Configuring OnCell Central Management Software

In this chapter, we introduce OnCell Central Management Software, and explain how to configure OnCell Central Management Software with the OnCell 5004/5104 web console, install and set the OnCell Central Driver Manager, and cover all of the equipment specifications.

This chapter covers the following topics:

- ❑ **Step 1: Server Settings**
 - System Requirements
 - Installing OnCell Central Manager
 - Using OnCell Central Manager
- ❑ **Step 2: OnCell Device Web Console Settings**
 - OnCell Central Settings
 - OnCell Central Server
- ❑ **Step 3: Host Settings and Management**



Step 1: Server Settings

System Requirements

Hardware Requirements

Please ensure that your host hardware meets the following minimum requirements:

- Pentium III or above
- 500 MHz CPU (1 GHz recommended)
- 256 Mb RAM (1 GB recommended)
- 300 MB disk space

Software Requirements

- OnCell Central Manager runs on a the following host systems:
 - Microsoft Windows 2000 Server
 - Microsoft Windows Server 2003
 - Microsoft Windows Server 2008
 - Internet Explorer 6.0 above is required.

Installation


Installing OnCell Central Manager software involves two main elements:

- If needed, installing Adobe Flash.
- Installing the OnCell Central Manager software.


Installing OnCell Central Manager

To install the OnCell Central Manager software, follow these steps. This procedure requires that you have administrative privileges. Insert the OnCell Installation CD into the OnCell Central Server.


1. Click the **INSTALL OnCell Central Manager** button in the OnCell Installation CD auto-run window to install the OnCell Central Manager. Once the installation program starts running, click **Yes** to proceed.
2. Click **Next** when the Welcome screen opens to proceed with the installation.




Click **Next** to install program files to the default directory, or click **Browse** to select an alternate location.




3. Click **Next** to install the program's shortcuts in the appropriate Start Menu folder.




4. Click **Next** to proceed with the installation. You will be prompted to select additional tasks.




5. Click **Next** to proceed with installation. Setup will display a summary of the installation options.



6. Click **Install** to begin installation. The setup window will report the installation progress. To change the installation settings, click **Back** and navigate to the previous screen.




7. Click **Finish** to complete the installation of the OnCell Central Manager.



Using OnCell Central Manager


After you install OnCell Central Manager, you can set up the OnCell 5004/5104's OnCell Central Settings for your PC host. Make sure the settings on your OnCell 5004/5104 match the settings for OnCell Central Manager.

1. Go to **Start → OnCell Central → OnCell Central** to start the OnCell Central mapping software.




You may need to install Adobe Flash before using this OnCell Central Server. The system will give you the link for installation automatically. Alternatively, you may find the Adobe Flash in the CD as well.

- 2. Click on **Tool** → **Control Ports Settings** to modify the port number.



To modify the new configuration of control ports, you can make all configuration changes here. The Control Ports Setting's information must match the web console's OnCell Central Server Settings. Please refer to Step 2, OnCell Device Web Console Settings, for control port information. Click **Save** if any modifications have been made.



3. Click on **Tool → User Ports Settings** to modify the port number. Click Save if any modifications have been made.

User Ports are used to connect the host and OnCell Central Server. The User Ports are assigned by the OnCell Central Server to each OnCell device sequentially within the specified port range.


Data port: Ports used to communicate with serial devices connected to the OnCell.

Command port: The TCP port for listening to SSDK commands from the host.


Service forwarding: Ports used to communicate with Ethernet devices connected to the OnCell.

Telnet port: The telnet port is the TCP listening port that allows the host to configure the OnCell via Telnet.


NOTE: Enabling **Remove registered ports** will remove the already assigned port numbers within the specified port range from the system.




- 4. If you need to import/add a long pre-defined device list to the OnCell Central Server, follow the next step, otherwise skip directly to **Step 9**.
- 5. To import the configuration from a text file, click on **Tool → Import OnCell User Ports/Service Forwarding**.




Browse to locate the configuration file (file format can be .txt for the following import format) and then click **Import** (same step as Import Service Forwarding).



- In order to view the information you have been imported or added, click on **View** (same step as Import Service Forwarding).




- To save **All** the configuration settings to an xml file format, select **Export DataBase** from the **OnCell Central** menu. You will then be able to import this configuration file to another host and use the same OnCell Central settings on the other host.



- 9. When all the configurations have been completed, return to the OnCell central main page. If your OnCell Central Server has two LAN cards, you may need to **select** the IP that needs to pass through the OnCell Connection and User Connection, and then click **Startup**.

For security reasons, we use 2 LAN cards for the server, one for the private IP domain in User Connection, and another for the public IP domain in OnCell Connection (OnCell Central must be accessible from the public IP domain).



Step 2: OnCell Device Web Console Settings

OnCell Central Settings

From the left navigation panel, click **Network Settings** → **OnCell Central Settings** → **OnCell Central Server** to configure the OnCell Central Settings. The configuration items are shown below:

OnCell Central Manager

Configuration

OnCell Central Manager Enable Disable

Manager IP

Auto reconnect period (10 - 1000 sec)

Control Port

Management information port

Management configuration port

Telnet port

OnCell Central Server

Configuration

Server (default=Disable): If you select Enable, the OnCell will be ready to connect to the OnCell Central Server

Server IP: Enter the IP address that will be assigned to your OnCell Central Server. The IP address must be in the **Public IP** domain.

Auto reconnect period (default=10 s): This field specifies the idle time setting for auto-reconnect.

Control Port

Management information port (default=63201): This port is used to transfer status information of the OnCell to the OnCell Central Server. The port number must match the OnCell Central Manager's port number configured in the OnCell Central Server. In order to prevent port conflicts with other applications, you can set the management information port to another port if needed.

Management configuration port (default=63202): This port is used to transfer configurations from the OnCell to the OnCell Central Server. The port number must match the OnCell Central Manager's port number configured in the OnCell Central Server. In order to prevent a port conflict with other applications, you can set the management information port to another port if needed.

Telnet port (default=63203): The Telnet port is the TCP port that is listening for Telnet connection from the host side. In order to prevent a TCP port conflict with other applications, you can set the Telnet port to another port if needed.

Service Forwarding

From the left navigation panel, click **Network Settings** → **OnCell Central Settings** → **Service Forwarding** to configure the OnCell Central Settings. The configuration items are shown below:

Service Forwarding

Service forwarding Enable Disable (This function is for OnCell Central Manager only.)

Service forwarding port

No	<input type="checkbox"/> Act.	Protocol	Eth. Device Name	Eth. Device IP	Port	Description
1	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
2	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
3	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
4	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
5	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
6	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
7	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
8	<input type="checkbox"/>	TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Service forwarding (default=Disable): If enabled, this option will establish the Ethernet device connection of the OnCell device to OnCell Central Server. Up to 8 Ethernet devices can be stored in the Service Forwarding Table.


Service forwarding port: Ports used to establish the Ethernet port connection of the OnCell device to OnCell Central Server.

Step 3: Host Settings and Management


Before you connect to OnCell Central's Web, you must install Adobe Flash, which you can download from Adobe Flash Web Site: <http://get.adobe.com/flashplayer/>

If you are using Microsoft Windows 2000 Server, Microsoft Windows 2008 Server, or Microsoft Windows Server 2003 platform, you may need to enable your ActiveX control on your platform. For other platform versions, refer directly to the Host Settings.


1. Start Internet Explorer and click on **Tool** → **Internet Options**.




2. Select **Security Settings**, select **Internet**, and then click **Custom Level**.




3. Enable **Download signed ActiveX controls**.




4. Enable **Run ActiveX controls and plug-ins**.




5. Enable **Script ActiveX controls marked safe for scripting** and then click **OK**.




6. Select **Trusted sites** under Security and then click on **Sites...**




7. Enter your IP address for your OnCell Central's web page, then click **Add**.




- 8. Click on **Custom Level...**




- 9. Enable **Download signed ActiveX controls**



10. Enable **Run ActiveX controls and plug-ins**



11. Enable **Script ActiveX controls marked safe for scripting** and then click **OK**




OnCell Central Web Console

1. Start the web browser.
2. In the **Address** input box, enter the OnCell Central's web IP address follow with the 8080 port (e.g., 192.168.127.111:8080). You should see the OnCell Central Manager Welcome page.
3. Enter the default username and password and then click **Login**.

Username: admin

Password: admin

4. The **OnCell Central** page will open:



From this page, you can change the view to one of the following options:

- **Server**
- **Device**
- **Logout**

Server


This section describes how to change the connection ports number for device and host in order to establish a connection with OnCell Central Server. If you would like to change your account settings, you can use the instructions in this section to do so.

Overview

The page shows which OnCell Central Manager version number you are using.



Control Ports/User Ports Information.




Control Ports Information.

Control ports are used to establish a connection between an OnCell device and the OnCell Central Server. This section shows all control port information that has already been configured.

User Ports info.

User ports are used to establish a connection between the host and the OnCell Central Server. This section shows all ranges of user ports that have been configured. See page 6-25 for an explanation of each user port.

Account Settings



The screenshot shows the Moxa OnCell Management Software interface. At the top, there is a green header with the Moxa logo and the website address www.moxa.com. Below the header, there is a navigation menu on the left with the following items: Overview, Control Ports/User Ports info., and Account Settings (which is highlighted in blue). The main content area is titled 'Account Settings' and contains two sections for user accounts: 'admin' and 'user'. Each section has three input fields: 'Old password:', 'New password:', and 'Confirm password:'. Below each set of fields is an 'Activate' button.

For all changes to the OnCell Central's admin and password protection settings, you will first need to enter the old password. To set up a new password or change the existing password, enter your desired password under both **New password** and **Confirm password**.

Device

This section describes ways in which you can monitor all of the device information that appears in the Device List.

If this is the first time that you have used OnCell Central, be aware that the list of groups in the left pane and the **Device List** will be empty, since you have not added any devices yet.

If you are managing hundreds of devices, the **Device List** can be very long, and searching the list to locate a particular device can be inconvenient and time-consuming. However, you can use the **All Devices**, **All User Ports**, and **Service Forwarding** tab to view a smaller amount of information, which makes monitoring much easier.

All Devices

This table describes **All Devices** that are connected to OnCell Central Server:


Device MAC	Device Name	Device Series	WAN IP	LAN IP	OP Mode	FW Vers	Last Connected
00:90:E8:15	OnCell_G3150-HSDPA	OnCell G3100	114.136.1	196.168.10	RealCOM	1.1	2009/10/
00:90:E8:15	OnCell_G3150_V2	OnCell G3100	114.136.5	192.168.12	Reverse Real	2.1	2009/10/
00:90:E8:14	OnCell_G3150_V2	OnCell G3100	117.98.12	192.168.1.5	RealCOM	2.1	2009/10/
00:90:E8:15	OnCell_G3110-HSDPA	OnCell G3100	114.137.1	192.168.12	TCP Client	1.1	2009/10/

Item	Description
Device MAC	Each Device has unique MAC ID that you can find on the device label or web/telnet/serial console
Device Name	Device's Name
WAN IP	Device's WAN IP address
LAN IP	Device's LAN IP address
OP mode	Device's operation mode (does not apply to the OnCell 5004 and 5104)
FW Version	Device's firmware version
Last Connected	Device's last connection date, month, time


Refresh: The device list is refreshed when this button is pressed. New online devices will be shown at the top of the list.

Auto Refresh (30 secs): If you checkmark this box, the new online device list will be updated every 30 seconds.

Group Edit. When you create groups of devices, you can efficiently apply device settings or perform maintenance tasks on multiple devices at the same time. To create a group, **click the right mouse button and select Group Edit.**



After creating the group, you can copy the devices under **All Devices** folder to create a new folder (e.g., South A).



Remove Device. To maintain the list, you can remove all offline devices. To activate this function, click the right mouse button and select **Remove Device**.

Note: If a device is removed from the **All Devices Folder** then the same device will be removed from all other new folders, too.

All User Ports


The **All User Ports** table displays the host's established connections to the OnCell Central Server, and its corresponding OnCell devices.

Device MAC	User Data Port	User Command Port	User Telnet Port
00:90:E8:19:C7:D9	50000 (Registered)	51025 (Registered)	0 (Closed)
00:90:E8:18:41:4E	50001 (Closed)	51024 (Closed)	0 (Closed)
00:90:E8:1A:DE:1E	50002 (Registered)	51026 (Registered)	0 (Closed)
00:90:E8:19:9E:48	0 (Closed)	0 (Closed)	60240 (Closed)

Item	Description
Device MAC	Each Device has a unique MAC ID that you can find on the device label or web/telnet/serial console.
User Data Port	The port number allows the host to establish a serial data connection to OnCell Central, which is mapped to the OnCell device (does not apply to the OnCell 5004 and 5104).
User Command Port	The port number allows the host to establish a command connection to OnCell Central, which is mapped to the OnCell device (does not apply to the OnCell 5004 and 5104).
User Telnet Port	The port number allows the host to establish a telnet connection to OnCell Central, which is mapped to the OnCell device.

Service Forwarding


The **Service Forwarding** table displays the host's established Ethernet connection to the OnCell Central Server, and the corresponding OnCell devices.



Item	Description
Status	Shows the status of the user's service ports. Closed: this mean the port is not connected Registered: this mean the OnCell is connected to OnCell Central Server. Connected: this mean the host side is connected to OnCell Central Server and is ready to use.
Device MAC	Each Device has a unique MAC ID that you can find on the device label or web/telnet/serial console.
Service Port	The port number allows the host to establish an Ethernet connection to the OnCell Central, which is mapped to the OnCell device.
Protocol	Protocol type for Service forwarding connection
LAN Device Name	Device's Name
LAN Device IP	Device's IP address
Port	This is the Ethernet device's local port number.
Description	Detailed description of the device.


Firmware Upgrade

The **Firmware Upgrade** table displays the firmware upgrade status of your devices.




Item	Description
Device Name	Device's name
Device MAC	Each device's unique MAC ID, which can be found on the device label
Device Model	Device's model
Firmware Support	Device's firmware version
Upgrade Status	Shows the status of the firmware upgrade: Success: this mean the firmware upgrade was successful Fail: this mean the firmware upgrade has failed Cancel: this mean the firmware upgrade was canceled
Upgrade Percentage	Displays the percentage of firmware that has been uploaded.

If you are the administrator, you have ability to use **Clear finished and cancelled upgrades** and **Cancel selected devices** icons on Firmware Upgrade page, and **Select All** and **Firmware Upgrade** on the All devices page.



Clear finished and cancelled upgrades: This button clears all firmware upgrades that have been finished and canceled.

Cancel selected devices: This button cancels the firmware upgrading process of the selected device(s).




Select All: This button makes it easy to select all of your devices for firmware upgrades.

Firmware Upgrade: This button will initiate a firmware upgrade for the devices you have selected.


Device's Settings and Maintenance

From the left navigation panel, click the All Device folder to list all devices, and then select the device that you want to monitor or reconfigure.




Overview

This page shows the OnCell's device information:




User Ports



Telnet Enable: If you click on the enable icon, Telnet will permit the the host to connect to the OnCell device. If no connections are made within 30sec, the port will just close.


Change User Port: If you do not want to use the system's assigned user ports, you may change the **User Data Port**, **User Command Port**, and **Telnet Port** here (does not apply to the OnCell 5004 and 5104).

Reset connection: Use this option to disconnect existing connections.



Note: If the data or command port is occupied, an error message will appear at the bottom of the window.

Service Forwarding



Item	Description
Status	Show the status of the User Service Port. Closed: Means the port is not connected. Registered: Mean the OnCell is connected to OnCell Central Server. Connected: Means the host side is connected to OnCell Central Server, and is ready to use.
Service Port	The port number allows the host to establish an Ethernet connection to OnCell Central, which maps to the OnCell device.
Protocol	Protocol type for Service forwarding connection
LAN Device Name	Device's Name
LAN Device IP	Device's IP address
Port	This is the Ethernet device's local port number.
Description	Detailed description of the device


Del selected record: Allows you to delete the device information under service forwarding that you have highlighted.

Reset connection: This is used to disconnect existing connections.

Maintenance


Configuration Export

To save all tconfigurations to an xml file, select **Configuration Export** and then click **Download**.




Configuration Import

Allows you to import this configuration file to another host and use the same OnCell Central settings in the other host.




Restart OnCell Device

Click **Restart** to restart the OnCell 5004/5104 device. Be sure that you save all of your configuration changes before you restart the system, or the changes will be lost.



Logout



7


OnCell Search Utility

This chapter covers the following topics:


- ❑ **Installing Search Utility**
- ❑ **Configuring OnCell Search Utility**

Installing Search Utility


1. Click the **INSTALL UTILITY** button in the OnCell Installation CD auto-run window to install OnCell Search Utility. Once the program starts running, click **Yes** to proceed.
2. Click **Next** when the Welcome screen opens to proceed with the installation.




3. Click **Next** to install program files to the default directory, or click **Browse** to select an alternate location.



4. Click **Next** to select additional tasks.




5. Click **Next** to proceed with the installation. The installer then displays a summary of the installation options.



6. Click **Install** to begin the installation. The setup window will report the progress of the installation. To change the installation settings, click **Back** and navigate to the previous screen.

- Click **Finish** to complete the installation of OnCell Search Utility.




Configuring OnCell Search Utility

The Broadcast Search function is used to locate all OnCell 5004/5104 servers that are connected to the same LAN as your computer. After locating an OnCell 5004/5104, you will be able to change its IP address.


Since the Broadcast Search function searches by MAC address and not IP address, all OnCell 5004/5104 servers connected to the LAN will be located, regardless of whether or not they are part of the same subnet as the host.

- Open OnCell Search Utility and then click the **Search** icon.




The Searching window indicates the progress of the search.


- When the search is complete, all OnCell 5004/5104 servers that were located will be displayed in the OnCell Search Utility window.




Click **Locate** to cause the selected device to beep.




To modify the configuration of the highlighted OnCell 5004/5104, click on the Console icon to open the web console. This will take you to the web console, where you can make all configuration changes. Please refer to Chapter 4, *Using the Web Console*, for information on how to use the web console.




3. Select **IP Address Report** for monitoring the status of the IP Address, and then click **Go**.



- To change the configuration of the IP Address Report, click on the **Settings** icon to open the IP Location Settings. The Local UDP listen Port number should match the web console Auto IP Report Settings' port number.



- Click the **Go** icon to complete the configuration. Refer to Chapter 4, *Using the Web Console*, for information on how to use the IP Address Report.



A

Default Settings

Setting Name	Default Name
Web Console Login	
Username	admin
Password	Keep <blank>
Network Settings	
LAN IP address	192.168.127.254
WAN IP address	192.168.126.254
Network	255.255.255.0
WAN Preference	Cellular
Cellular Settings	
SIM PIN	<blank>
NAT service	Enable
DHCP Service Settings	
DHCP Server	Enable
DNS relay	Enable
Virtual Server Settings	
Virtual Server	Disable
Route Table	
Static Route	Disable
WAN IP Filter Configuration	
WAN IP Filter	Disable