



Milesight

Video Management System Pro User Manual

Milesight Technology Co.,Ltd.

V3.08

Table of Contents

Chapter I Introduction.....	2
1.1 Milesight VMS Pro Introduction.....	2
1.2 Key Features.....	2
Chapter II Installation.....	3
2.1 Software Overview.....	3
2.2 System Operating Environment.....	3
2.3 Installation Guide.....	3
Chapter III Operations and Settings.....	7
3.1 How to Execute Milesight VMS Pro.....	7
3.2 Configuration.....	8
3.2.1 Camera Management.....	12
3.2.2 General Settings.....	15
3.2.3 Schedule.....	16
3.2.4 Motion Detection.....	18
3.2.5 Network.....	18
3.2.6 User Management.....	19
3.2.7 Log Management.....	20
3.3 Settings.....	20
3.4 File.....	22
3.5 Tools.....	23
3.5 Help.....	24
3.6 Toolbar.....	24
Chapter IV Live view.....	26
4.1 Camera Tree Window.....	26
4.2 Live toolbar.....	28
4.3 Live view workspace.....	28
4.4 PTZ control.....	29
Chapter V Playback.....	30
Chapter VI Map.....	34
6.1 Toolbar.....	34
6.2 Pop-up Menu.....	35
6.3 Add the hot.....	35
Chapter VII Milesight VMS Server.....	36
Chapter VIII Service.....	37

Chapter I Introduction

1.1 Milesight VMS Pro Introduction

Milesight VMS Pro (Video Management System) is one of the most innovative and most powerful video management software systems on the market and it will fulfill your highest requirements and expectations. The simple and intuitive design requires little training while providing easy access to live and recorded video, facility maps and alarms. The user who has the authority can configure all server and cameras settings from a central location. Utilize the left panel navigation tree structure to navigate the server and cameras as well as to access features like searching out the online server and cameras automatically, checking the information of the server and camera. Use Client/Server architecture, it is a future-proof network video solution for large projects and can manage unlimited network cameras via unlimited working servers in different locations. It's able to integrate with other cameras over ONVIF.

This manual describes how to use and manage “*Milesight VMS Pro*” in your network environment. Some knowledge of network environment would be beneficial to the readers. Should you require any technical assistance, please contact authorized service center.

1.2 Key Features

- ✧ Support 1/ 2/4/ 6/8/ 9/ 13/ 16/ 20/24/30/36/49/ 64 channels playing synchronously
- ✧ H.264/MPEG-4 /MJPEG video compression
- ✧ Client/Server architecture, support to add multiple-server
- ✧ Record locally or to network storage
- ✧ Customizable user access levels
- ✧ E-mail notification
- ✧ Support dual-stream
- ✧ 4-CH synchronized playback and up to 16-CH asynchronous playback
- ✧ Alarm or scheduled recording
- ✧ Integrated Motion-Detection from camera
- ✧ Multiple monitors support
- ✧ Human-oriented Milesight UI
- ✧ Support ONVIF
- ✧ Support D3D display mode

Chapter II Installation

2.1 Software Overview

An installation of “*Milesight VMS Pro*” has two components: Server software and Client software. “*Milesight VMS Server*” is the intelligence management system forward the RTSP stream, and the Client software is used to log in the server and provides the user interface for all tasks including monitoring, searching, reporting and configuration. “*Milesight VMS Client*” allows users in different locations to log into the server. If users have the right, they are able to change the system configuration.

2.2 System Operating Environment

OS: Windows XP/7/Vista/Server 2000/Server 2008

CPU: 2.4GHZ or faster

Memory: 2G MB or more

Graphic memory: 1G or more

Internet protocol: TCP/IP

2.3 Installation Guide

Run the Milesight VMS Pro installation file and install the programs on your computer by following the on-screen instructions. After finishing installation, you will find the programs on the start menu or on the desktop.

Step1: Select the preferred language for this installation.




Figure 2.1

Step2: Click "Next" to go on.




Figure 2.2

Step3: Read the information to know about Milesight VMS Pro and go on.




Figure 2.3

Step4: Choose the destination.




Figure 2.4

Step5: Here you need to install “Milesight VMS Client” and “Milesight VMS Server” to complete the installation.




Figure 2.5

Step6: Finish the installation.




Figure 2.6

Chapter III Operations and Settings

3.1 How to Execute Milesight VMS Pro

(1) Start “Milesight VMS Server” first

After installation, you can find it on “Go to” -> “Start All Programs”-> “Milesight VMS Pro” -> “Milesight VMS Server”, then all the cameras on the server will load automatically.

(2)Then, start “Milesight VMS Client”

After installation, you can find it on “Go to” -> “Start All Programs”-> “Milesight VMS Pro” -> “Milesight VMS Client”.

When you log in “Milesight VMS Client”, a window will pop up as below. Enter the Username, Password. The default user name and password is “*admin*” and “*password*”. You can also choose which language to be used for the Client. If the [\[Auto Login\]](#) is selected, “Milesight VMS Client” will log in without keying in the Username and Password next time.




Figure 3.1

After you click on the “Login” button, the window will pop up as follow. Please wait for a few seconds. After loading the cameras successfully, “Milesight VMS Client” will come into view.



Figure 3.2

After successful login, the window will pop as follow. It will search online server automatically, and the users can add servers according to their needs.




Figure 3.3

3.2 Configuration

Before using “*Milesight VMS Client*” for live view, you need to add the server first. Then you are able to add the cameras via different servers. Only after adding the server and cameras, can you use functions like live view, playback, E-map etc.

How to Add Server?

There are two ways to add servers via “*Milesight VMS Client*”: one way is searching online automatically, the other is adding manually. After adding successfully, you can see the name of the server under “*Default Group*”.

Right-click the “*Default Group*” and select “*Server Management*” option, the window will pop up as follow. Click on the “*Search Server*” button to search servers automatically, while click on the “*Add Server*” button to add manually. Details will be shown in the following figures.




Figure 3.4

1. Search Server

Click the button, the window will show as below. You can search servers automatically.




Figure 3.5

Item	Description
<i>Stop/Rescan</i>	When searching the servers, you can stop it and rescan by clicking again.
<i>Select All</i>	All the servers will be selected at a time.
<i>Clear All</i>	All the servers will be unchecked at a time.
<i>Set Password</i>	Enter the password at a time.
<i>OK</i>	Click [OK] button to confirm the settings.
<i>Cancel</i>	Exit quit.

2. Add Server

When the button is clicked, the window will show as below. You can add the server manually.



Figure 3.6

Item	Description
<i>Server Type</i>	Choose the VMS Server you use

<i>Name</i>	The name of server.
<i>Port</i>	The port of the server.
<i>User Name</i>	The user name of the server.
<i>IP</i>	IP address of the server.
<i>SQL port</i>	SQL port.
<i>Password</i>	Password of the server.
<i>Enable</i>	Enable or unable the server.

3. Edit Server

When the button is clicked, the window will show as below. Edit the information of the camera.



Figure 3.7

4. Delete Server

Remove the server from “*Milesight VMS Client*”.

5. Configure Server

Here you can do the settings for the server. Including *General Settings*, *Camera Management*, *Schedule Settings*, *Motion Detection*, *Network Settings*, *User Management*, *Log Management* and *Record File Management*.

For more details, please refer to the below content “How to Add IP Camera”.




Figure 3.8

How to Add IP Camera?

After adding the server successfully, you need to configure the server further, including searching cameras, adding them to the live view window, setting motion detection, setting recording schedule, etc. Adding, modifying, removing and SMTP for Server could be also set here. The details are as below.




Figure 3.9

When you click on the “[Config Server](#)” button, window pops up as below, including *General Settings*, *Camera Management*, *Schedule Settings*, *Motion Detection*, *Network Settings*, *User Management*, and *Log Management*.




Figure 3.10

3.2.1 Camera Management

Click *“Camera Management”* button, the pop-out window is as below.




Figure 3.11

1. Search Camera



Figure 3.12

Item	Description
<i>Stop/Rescan</i>	When searching the cameras, you can stop it and rescan by clicking again.
<i>Select All</i>	All the cameras will be selected at a time.
<i>Clear All</i>	All the cameras will be unchecked at a time.
<i>Set Password</i>	Enter the password at a time.
<i>OK</i>	Click [OK] button to confirm the settings.
<i>Cancel</i>	Exit quit.

Note: Before you register Milesight VMS Pro, you can only add up to 4 cameras. For more information, please refer to Chapter VII Milesight VMS Server.

2. Add Camera

When the button is clicked, the window will show as below. You can add the camera manually.

- 1) Through IP address you can add Milesight's cameras and other cameras supporting ONVIF.
- 2) Through RTSP stream you can add cameras supporting RTSP.

Note: Those options with * are required, including Name, IP, Port, User Name, Password.




Figure 3.13

3. Edit Camera

When the button is clicked, the window will show as below. Edit the information of the camera.




Figure 3.14

Click on “*Video Settings*” button, you can change the video parameters here.

Item	Description
<i>Video Stream</i>	Choose the main stream or 2 nd stream to play.
<i>Video Codec</i>	Including H.264, MPEG-4, MJPEG.
<i>Frame Size</i>	The resolution.
<i>Maximum Frame Rate</i>	Maximum refresh rate of frames
<i>Bit Rate</i>	Transmit bits of data per second




Figure 3.15

4. Delete Camera

Remove the camera from “Milesight CMS Client”.

5. Browsing Web

Browse the web of the camera.

6. Modify IP address

Modify the IP address.

3.2.2 General Settings

Click “General” button, the pop-out window is as below. Here you can set the Recording Path (support multiple disks at the same time), Server Name and Server Port. It’s also able to decide how long to schedule recording time length, to keep the recorded files and event/alarm log. At the same time, you can decide whether to delete these files automatically or not and when.




Figure 3.16

3.2.3 Schedule

Set the time schedule. When the button is clicked, the window will show as below.
Here you can choose the schedule to be an auto recording schedule or an alarm schedule.




Figure 3.17

Step1: Click “Add” button to add a new schedule as a time templet. You can draw the timeline for each day. Here you can choose the schedule to be an auto recording schedule or an alarm schedule. Make sure the [Enable] button is checked.




Figure 3.18

The schedule settings include:

Item	Description
Name	The schedule name.
Enable	Enable or disable the schedule.
Date from/Date to	Begin or stop to put in the schedule.
Record Type	Including alarm and continuous record
Trigger	Motion Detection from “Milesight VMS Client” or IPC itself.

Capture Image

Pre record

Post record

SMTP

Capture how many pictures per second when alarm is triggered.

Setting length of the pre-alarm recording file. Setting range: 0-9s.

Setting length of the post-alarm recording file. Setting range: 1-1800s.

Enable to use the SMTP.

Step3: Choose a type under the “*Record Type*”.

Note: If you choose the “*Alarm*” type as the record type, you can also do some settings including “*Trigger Condition*”, “*Action When Alarm is Triggered*”.




Figure 3.19

If you choose the “*Alarm*” type as the record type, the timeline is red. While if you choose the “*Record*” type as the record type, the timeline is blue.




Figure 3.20

Note: Left-click to draw the timeline and right-click to cancel again.

Step4: Select the cameras on the left camera list and move them to the right camera list.

Step5: Click [Apply] or [OK] to confirm the settings.

3.2.4 Motion Detection

Do the alarm settings here. When the button is clicked, the window will show as below.
Draw the areas where to be detected.




Figure 3.21

Step 1: Select the camera on the left tree which you want to set motion detection. Make sure the “*Enable*” button is checked. Draw certain areas by mouse.

Item	Description
<i>Select All</i>	Select all of the area to be detected
<i>Clear All</i>	Clear all of the area
<i>Level</i>	Different levels to trigger alarm
<i>Detection Interval</i>	How often to trigger alarm

Step 2: Select the cameras on the left camera list and move them to the right camera list.

Step 3: Click [\[Apply\]](#) or [\[OK\]](#) to confirm the settings.

3.2.5 Network

Here you can do the settings for SMTP. Click on the “*Network*” button and the window will pop up as below.




Figure 3.22

SMTP: Enter the SMTP server, port, SMTP sender, password and the SMTP receiver, then when the alarm is triggered, the server will send you an email to inform you what happened. Now we can support three kinds of encryption types (NO_SECURITY,USE_SSL,USE_TLS). If you are not sure, contact with the connection provider or the network administrator.

If you want to send a test email, click “Test”.

DDNS: Choose different types of provider, enter the Host name, User name and Password. The DDNS can translate constant hostnames into changing IP addresses. This is used to provide a persistent domain name for a resource that may change location on the network.

3.2.6 User Management

Users are managed in the User Management dialog box.

Users can be created, modified, and deleted from the User Management dialog box in “Milesight VMS Client”. Several properties of a user including User Name and Password can be changed here. When the button is clicked, it shows as below.

Note: Different users have different permissions to access the server.

User Type:

Administrator: Full access to do any settings.

Operator: Do anything except create a new user.

Viewer: Can’t change any settings but to view.




Figure 3.23

When the “Add” button is clicked, the window will show as below.




Figure 3.24

3.2.7 Log Management

When the button is clicked, the window will show as below. You can change the different log under the option, including “*Event Log*” and “*Alarm Log*”.




Figure 3.25

3.3 Settings

Local Settings

This part is mainly used for local settings. Select a disk to store the recorded files and images. You can also set how long to keep the operation logs and alarm logs here. (Mainly used in the local recording and snapshot)

Note: The default disk is the destination disk where you install “Milesight VMS Pro”.
When you click the “[Settings->Local Settings](#)” button, the window will show as below.




Figure 3.26

Better Image Quality

Better image quality uses YUV (traditional is RGB) display mode, which can make the whole effect of video image more clear.

Carousel Settings

Choose an interval between each other. After being set, the cameras in the live view mode will alternates with different cameras at a time within an interval.

Connect IPC Stream Directly

Decrease the load of the server when connecting IPC stream directly and the server needn't to forward the video stream.

Note: We do not recommend that you check this opinion on when several servers connecting with the same IPC at the same time.




Figure 3.27

Audio Alarm

Play audio when alarm is triggered. The *Live View* page will appear the alarm icon. 

Alarm action

Enable alarm pop up: Check on this option. If a camera is not on the live view channel, it also will pop up when alarm is triggered.

Windows always on top when alarm: Check on this option. If “*Milesight VMS Pro*” program was minimized, it’ll restore to the original size when alarm is triggered.

Change Password

Here you can change the password of “*Milesight VMS Client*”.

3.4 File

File->Lock

When you click the [\[Lock\]](#) button, the GPI page will be locked. Then click it again, the window will show as below.




Figure 3.28

You have to key in Username and Password to unlock it.

File->Exit

Username and Password are required when logging out “*Milesight VMS Client*”. And if the [\[Auto Login\]](#) is checked, “*Milesight VMS Client*” will log in without keying in the Username and Password next time.



Figure 3.29

3.5 Tools

Tool-> Multi Monitor

Now “Milesight VMS Client” support multiple monitors. When click on the “Multi Monitor” button, the window pops up as follow. “Milesight VMS Client” supports to use up to 4 monitors now. There are 3 modes you can choose to use in each monitor, including *Live Screen mode*, *Fullscreen mode* and *Alarm Screen mode*. What you need to do is to drag the cameras to the position of the monitor you want to show.

Live screen mode: For this mode, you can add any cameras which you want to show on the screen. Just drag the cameras and move it into the specified monitor.

Fullscreen mode: Click on the main console monitor, double click on the individual position of the camera, then the live video will be showed in full screen on the specified monitor.

Alarm screen mode: When the camera is triggered, the live video will play on the monitor. (Now this mode only supports to display 16 channels at the same time)




Figure 3.30

Tools->Log Management

Please refer to 3.2.7

Tools-> Change Language

Select the language for “Milesight VMS Client”.

3.5 Help

Help-> Online Help

Here you can feedback any questions to Milesight and seek any help from Milesight.

Help-> About Milesight VMS Pro

“Milesight VMS Client” information can be checked here.



Figure 3.31

3.6 Toolbar

Add short cut icons on toolbar as below.



Figure 3.32

Num	Item	Description
1	<i>Server Settings</i>	Please refer to 3.2.1 Server/Client Settings.
2	<i>Lock/Unlock</i>	Lock/Unlock “Milesight VMS Client”. For details, please refer to 3.3 File.
3	<i>Display/ Play toolbar</i>	Display or hide toolbar.
4	<i>Hide the PTZ</i>	Display or hide PTZ interface.
5	<i>Fullscreen</i>	You can view the live video in full screen mode. To return to the normal screen, press [Esc] button on the keyboard.
6	<i>Live view modes</i>	Support 1/ 2/4/ 6/8/ 9/ 13/ 16/ 20/24/30/36/49/ 64 channels playing synchronously.
7	<i>Synchronous Playback</i>	In the playback mode, choose to playback 4 cameras synchronously.
8	<i>Previous Page</i>	Switch to the previous group cameras when in carousel mode.

9	<i>Next Page</i>	Switch to the next group cameras when in carousel mode.
10	<i>Start/Stop Carousel</i>	Start or stop the carousel mode.

Chapter IV Live view

“Milesight VMS Client” software provides the user interface for all tasks including monitoring, searching, reporting and configuration. The interface is shown as below.




Figure 4.1

This part is mainly used for real-time video preview and polling mode setting. The first time “Milesight VMS Client” is started, you should add some cameras to it. You can add the cameras manually or by searching cameras. For details, please refer to [3.2.1 Camera Settings-> Add Camera](#) and [3.2.1 Camera Settings-> Search Camera](#). After adding the camera, you have to drag it to the live view window to display the video.

How to Connect the Camera

Step1: Select a camera in window 1.

Step2: Double-click on the camera or drag and drop the camera to the individual position. The camera is connected automatically and live video will show in the selected window.

Step3: Repeat step1 to 2 to connect other cameras.

Note: Please make sure the camera is available .

How to Disconnect the Camera

Step1: Select a camera in window 1.

Step2: Right click the camera. Select [\[Enable\]](#), the camera will be disconnected. If you want to connect again, click it again.

Step3: Repeat step 1 to 3 to disconnect other cameras.

4.1 Camera Tree Window

This part is to display the added camera. There are 3 types shown bellow.

(1) Right-click on the view list

Pop-up Menu:




New View
View Management

Create a new view to save the camera
Manage all the saved view

Figure 4.2

(2) Right-click on the group

Pop-up Menu:



Server Management
Server Online
Play All
Stop All

Manage the server.
Search out the online-server
Play all the live videos.
Stop all the live videos.

Figure 4.3

Note: The status of server like below means the server is out of connection.





Figure 4.4

(3) Right-click on the server

Pop-up Menu:




Config Server
Search Camera
Server Information
Enable
Enable All
Unable All
Play All
Stop All

Configure the server.
Search out the online-cameras.
Server information.
Enable/Unable the server.
Enable all the cameras under the server.
Unable all the cameras under the server.
Play all the live videos.
Stop all the live videos.

Figure 4.5

(4) Right-click on the camera

Pop-up Menu:



Camera Information
Browsing Web
Enable
Play
Stop

Please refer to [3.2.2 Camera Settings-> Edit Camera](#).
Please refer to [3.2.2 Camera Settings-> Browsing Web](#).
Connect or Disconnect the camera.
Start the live video.
Stop showing all the videos.

Figure 4.6

Item

Description

Item

Description



available



unusable



failed to connect



alarm status

Note: When the camera is failed to connect successfully for the first time, it will try to reconnect at an increasing intervals until it succeed. If it is failed to connect for a long time, drag it into the live view screen to play again. You can also click the camera and unable it, and then enable it again, it will connect successfully again.

4.2 Live Toolbar



Figure 4.7

Icon	Item	Description
	<i>Record</i>	Record manually. And this icon will turn into  .
	<i>Audio</i>	Play Audio or stop it. (Audio is unusable in the polling live view window)
	<i>Snapshot</i>	Take a snapshot when viewing.
	<i>Display</i>	Display.
	<i>Stop Display</i>	Stop showing the videos.
	<i>Zoom In</i>	Enable to zoom in a specific area of video image with mouse wheel.
	<i>Fullscreen</i>	You can view the live window in full screen mode. To return to the normal screen, press [Esc] button on the keyboard.

4.3 Live View Workspace

This part is used for displaying the live view. Right click the mouse, and the window will show as follow.




Figure 4.8

Pop-up Menu:

<i>Play</i>	Display.
<i>Stop</i>	Stop showing the videos.
<i>Remove</i>	Remove the camera from the live view window.
<i>Remove All</i>	Remove all cameras from the live view window.
<i>16:9</i>	The original screen size can adjust to 16:9.
<i>4:3</i>	The original screen size can adjust to 4:3.
<i>Resize</i>	Return to the original screen size.
<i>Mute</i>	Stop audio.
<i>Mute All</i>	Stop playing all the audios.
<i>Mute Other</i>	Stop playing other audios.
<i>Exit Fullscreen</i>	Return to the normal screen.
<i>Fullscreen</i>	You can view the live video in full screen mode.

4.4 PTZ control

This part is for the flexibility of remote pan/tilt/zoom through operator control. It is possible to zoom in on small distant objects with exceptional clarity. The user can easily track objects with high precision by using a mouse or joystick.




Figure 4.9

Item	Description
<i>Speed</i>	PTZ rotation speed control.
<i>Brightness</i>	A brighter scene appears if a higher level of brightness has been selected.
<i>Contrast</i>	The difference in color and light between different parts of an image.
<i>Saturation</i>	A vivid scene appears if a higher level of saturation has been selected.
<i>Default</i>	The default values of Brightness/Contrast/Saturation.

Chapter V Playback

In this part, you can search and play back the recorded files of a selected IP camera. When you click the [\[Playback\]](#) button, the window will show as below.




Figure 5.1

How to Replay the Recorded Files

Way 1: Asynchronous Playback

Step1: Select which camera to replay on the left, and then check it.

Step2: Select a date and the file type you want to search. The File Type includes: All / Manual / Motion / Schedule.

Step3: Click [\[Search\]](#) button.

Step4: Choose a playback mode, if it's asynchronous playback, 1/2/4/6/9/13/16 panes modes are able to use.

Note: Synchronous playback only supports for 4 panes mode.

Step5: Click the file on the list and it will begin to play the recorded files.

Play toolbar

Icon	Item	Description
	<i>Play</i>	Play the video.
	<i>Pause</i>	Pause the video.
	<i>Stop</i>	Stop the video.
	<i>Step forward</i>	Step forward the video.
	<i>Slow</i>	Slow down to catch details.
	<i>Fast</i>	Speed up to skip some details.
	<i>Mute</i>	Play or stop audio. (The default state is to play audio)
	<i>Zoom</i>	Enable to zoom in a specific area of video image with mouse wheel.
	<i>Capture</i>	Take a snapshot when playing the file.
	<i>Record</i>	Record the video.
	<i>Download</i>	Download the recorded files.



Color of Recorded Files on the List.



Red

Refers to those alarm type recorded files.



Blue

Refers to those scheduled recorded files.

Operative Skills

Timelines will help you find the correct videos when there are too many files on the list. It's easy to zoom out the area by scrolling the mouse wheel to find exactly the incident you are looking for. Take a file near 10:00 for example, when the position of mouse is between 08:00 and 10:00, then scroll up the mouse wheel, the position of this file will show as follow. Scroll down to turn back. You can hold down the left mouse and drag the mouse to left or to right (between the intervals from 00:00 to 24:00) to get the exact recorded files.

Begin:



Figure 5.2

Scroll up 1:



Figure 5.3

Scroll up 2:



Figure 5.4

Scroll up 3:



Figure 5.5

Scroll up 4:




Figure 5.6

Why 2: Synchronous Playback




Figure 5.7

Step1: Click on the “*Sync playback*” button.

Step2: Select the camera to replay on the left, and then check it.

Step3: Select a date and the file type you want to search. The File Type includes: All / Manual / Motion / Schedule.

Step4: Click [*Search*] button.

Step4: Click the file on the list and it will begin to play the recorded files.

Note: Synchronous playback only supports for 4 panes mode. If you want to change the camera to view, just right click on the window, choose the “*Remove*” option, and drag the different camera to the window.

Play toolbar



Icon	Item	Description
	<i>Play</i>	Begin to play the video.
	<i>Pause</i>	Pause to play the video.
	<i>Stop</i>	Stop playing the video.
	<i>Slow</i>	Slow down to catch details.
	<i>Fast</i>	Speed up to skip some details.
	<i>Zoom</i>	Enable to zoom in a specific area of video image with mouse wheel.
	<i>Download</i>	Download the recorded files.
	<i>Fullscreen</i>	Fullscreen

How to Export the Recorded Files

Here is for exporting the recorded files from “*Milesight VMS Client*”.

Over “*Milesight VMS Client*”, you can export the recorded files to your local PC. Choose the start time and the stop time for the recorded files, then select the file type, including *Alarm Type* and *Schedule Type*. Then choose a destination where save the files on your local PC. Right-click on the file list, select the “*Export*” option to export the recorded files.




Figure 5.8

How to Import the Recorded Files

Here is for importing the files which were exported to the local PC before to “Milesight VMS Client”.

Over “Milesight VMS Client”, you can import the exported files in your local PC to “Milesight VMS Client”. Click *Local File* and choose *Import*, find the destination of the exported files, choose what you want to import, then select the “Confirm” option to import the recorded files.




Figure 5.9

Chapter VI Map

In this part, you can add an electronic map and different cameras to the map. The display of map graphics in the Map window can be controlled. The size of the map can be selected, and the map can be moved in the window to show the area you want to view. Use the zoom in / zoom out buttons or with the mouse wheel to adjust the map size. Right-click on the map and choose the “Lock” option, this would prevent the accidental deletion of the map.

It is easy to navigate between different layers of maps, and to show the maps of cameras in various locations. Here you can add different maps for each server.

Note: Only on the layers of the server, can you drag the cameras to the server map.

When you click the [\[Map\]](#) button, the window will show as below.



Figure 6.1

6.1 Toolbar



Modify

When the [\[Modify\]](#) button is clicked, the window will show as below. Different image formats such as [bmp](#) / [gif](#) / [png](#) / [jpg](#) are supported.




Figure 6.2

Icon	Item	Description
	<i>Delete Map</i>	Remove the map from “Milesight VMS Client”.
	<i>Zoom In</i>	Enlarge the picture to see more details.
	<i>Zoom Out</i>	Zoom out the map.
	<i>Reset</i>	Return the map to its original size.
	<i>Delete Hot</i>	Remove the camera from the map.

6.2 Pop-Up Menu

Right-click the map (anywhere except the cameras). A menu will pop up as figure 6.3.

Lock If the map is locked, you can do nothing with the map but zoom in or zoom out.

Unlock You can do anything if the map is unlocked.




Figure 6.3

Right-click the camera. A menu will pop up as figure 6.4.

Delete Remove the camera from the map.

Play Live preview.




Figure 6.4

6.3 Add the Hot

Click the camera and drag it to the E-map, then it will be added successfully. After the camera has been added on the E-map, you can double click on the hot to play.



Figure 6.5

Chapter VII Milesight VMS Server

An installation of “*Milesight VMS Pro*” has two components: server software and client software. The Server functions as the intelligence management system forward the RTSP stream. After you

log on “*Milesight VMS Server*”, an icon will appear like this .

Right-Click on the icon, the window is shown as below.




Figure 7.1

Item	Description
<i>Stop/Start</i>	Stop/Start running “ <i>Milesight VMS Server</i> ”.
<i>Help</i>	Feedback any questions to Milesight.
<i>Online Help</i>	About the version information of “ <i>Milesight VMS Server</i> ”.
<i>About Us</i>	
<i>Run When Startup</i>	Run the program when computer startup.
<i>Register now</i>	Activate “ <i>Milesight VMS Pro</i> ”.
<i>Exit</i>	Exit “ <i>Milesight VMS Server</i> ”.




Figure 7.2

Note: Before activating “*Milesight VMS Pro*”, you can add up to 8 cameras. If you want to use more cameras, please contact with Milesight to activate “*Milesight VMS Pro*” via “*Milesight VMS Server*”.

Chapter VIII Service

Milesight Technology Co., Ltd provides customers with timely and comprehensive technical support services. End-users can contact your local dealer to obtain technical support. Distributors and resellers can contact directly with Milesight for technical support.

Technical Support Mailbox: support@milesight.com

Web: <http://www.milesight.com>

Online Problem Submission System: <http://www.milesight.com/service/feedback.asp>

Address: Room 202, No.23 Wanghai Road, 2nd Software Park, Xiamen, China

Zip Code: 361006

TEL: +86-592-5922772

FAX: +86-592-5922775

Milesight
More in Sight