
Multi-Input Field Unit User Manual



Multi-Input Field Unit Models WI-AI and WI-AV

Versions 1.56 or later



Important Information to the User



- Changes or modifications not expressly approved by Adaptive Instruments, LLC may void the user's authority to operate the equipment.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.
- This device is for mobile and fixed use only (not portable or body-worn). A separation distance of 20cm must be maintained at all times between the antenna and the body of the user and bodies of nearby persons.
- This device has been designed to operate with an antenna having a maximum gain of 9 dBd. Antenna having a higher gain is strictly prohibited per regulations of Industry Canada. The required antenna impedance is 50 ohms.
- To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (EIRP) is not more than that required for successful communication.
- The installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RF field in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's website www.hc-sc.gc.ca/rpb.



FCC Certification



- This product is a frequency hopping RF transceiver module for the 900MHz ISM band, designed to meet FCC 15.247, and is used in industrial control and monitoring applications.
- The antenna is factory installed and **MUST NOT** be removed or modified by user.

Accutech

A Division of Adaptive Instruments Corp.

577 Main Street · Hudson, MA 01749 USA

TEL: 800-879-6576 · 978-568-0500

FAX: 978-568-9085

Email: support@accutechinstruments.com

Web: www.accutechinstruments.com

Adaptive Instruments Corp. reserves the right to update or change this user guide at anytime. For the most recent version of the user guide, please check our website: www.accutechinstruments.com

© Adaptive Instruments Corp., 2005.

Printed in the USA

Table of Contents

Section 1: Introduction	1
1.1: Using This Manual	1
1.2: About the Device	2
1.3: Unpacking	2
1.4: Software Compatibility	2
Section 2: In a Hurry?	3
Section 3: Installation	4
3.1: Mechanical Installation	4
3.1.1: Field Unit Positioning	4
3.1.2: Simple RF Placement Procedure	5
3.2: Electrical Installation	7
3.2.1: Electrical Specifications	7
3.2.2: Wiring the Voltage/Current Input	7
3.2.3: Wiring the Input Switches	8
3.2.4: Wiring and Configuring the Output Switches	9
Section 4: General Configuration	10
4.1: Field Unit Displayed Messages	10
4.1.1: The Read-Only Sequence	10
4.2: Overall Configuration Menu Map	11
4.3: Setting the Field Unit Tag Name	11
4.4: Setting a User Password	12
4.5: Resetting All Field Unit Settings	12
Section 5: Configuring the RF Communications	13
5.1: RF Channel Selection	13
5.2: RF Baud Rate Selection	13
5.3: RF Identification Selection	14
Section 6: Configuring the Sampling and Transmission Rates	15
6.1: Selecting the Normal Transmission Rate	15
6.2: Selecting the Normal Sampling Rate	16
6.3: Selecting the Abnormal Transmission Rate	17
6.4: Selecting the Abnormal Sampling Rate	18
6.5: Setting the Smart Rate Threshold	19
6.6: Selecting the Normal Upper and Lower Values	20
6.7: Selecting Rates, Thresholds, and Deadbands via the Software	21
Section 7: Configuring the Process Variable	22
7.1: Selecting the Units of Measure	22
7.2: Setting a Measurement Offset	23
7.3: Trimming the Measurement	23
7.4: Entering a 22-Point Curve	23
Section 8: Maintaining the Field Unit	24
8.1: Changing the Battery	24
Section 9: Technical Specifications	25
Dimensioned Mechanical Drawing	26
Intrinsic Safety Control Drawing	27
Appendix A: Navigating the Menus	28
Appendix B: Displayed Message Definitions	29
Appendix C: Field Unit Menu Map	30

Table of Figures

3.1: Example of Incorrect Field Unit Positioning	4
3.2: Menu Map to RSSI Mode	5
3.3: Voltage/Current Input Wiring Diagram	7
3.4: Input Switch Wiring Diagram	8
3.5: Output Switch Wiring Diagram	9
3.6: Output Switch Configuration Using Wireless Instrumentation Manager	9
4.1: Field Unit Power-UP and Operations Sequence	10
4.2: The Read-Only Sequence	10
4.3: Overall Configuration Menu Map	11
4.4: Menu Map to Tag Name Setting	11
4.5: Menu Map to Password Setting	12
4.6: Password Setting Using Wireless Instrumentation Manager	12
5.1: Menu Map to RF Channel Setting	13
5.2: Menu Map to Baud Rate Setting	13
5.3: Menu Map to RF ID Setting	14
6.1: Menu Map to Normal Transmission Rate Setting	15
6.2: Incorrect Sampling Rate	16
6.3: Correct Sampling Rate	16
6.4: Menu Map to Normal Sampling Rate Setting	16
6.5: Example of Abnormal Transmission Rate Setting	17
6.6: Menu Map to Abnormal Transmission Rate Setting	17
6.7: Example of Abnormal Sampling Rate Setting	18
6.8: Menu Map to Field Abnormal Sampling Rate Setting	18
6.9: Smart Rate Configuration Using Wireless Instrumentation Manager	19
6.10: Normal Upper and Lower Value Example	20
6.11: Menu Map to Normal Upper and Lower Value Settings	20
6.12: Condition “Chatter” Without Time Deadband	20
6.13: Condition “Chatter” Elimination Due to Time Deadband	20
6.14: Sampling and Transmission Rate Selection Using the Software	21
6.15: Normal Upper and Lower Value Selection Using the Software	21
7.1: Menu Map to Units Setting	22
7.2: Units Selection Using Wireless Instrumentation Manager	22
7.3: Menu Map to Sensor Offset Setting	23
7.4: Menu Map to Trim Setting	23
7.5: Setting a 22-Point Curve Using Wireless Instrumentation Manager	23
Dimensioned Mechanical Drawing	26
Intrinsic Safety Control Drawing	27

Introduction

1.1: USING THIS MANUAL

This manual is designed to assist in installing, operating, and maintaining Accutech Model WI-AV and WI-AI Multi-Input Field Units. The manual is broken into sections as follows:

Section 2: In a Hurry?

This section summarizes what must be done in order to get the device installed, configured and in operation quickly. However, it does not provide detailed or how-to information to perform the tasks outlined.

Section 3: Installation

This section explains how to correctly wire the Voltage/Current loops, Input Switches, Output Switches and ground the Field Unit. Also covered in this section are mechanical installation considerations; such as Field Unit placement.

Section 4: General Configuration

In this section general configuration options such as password protection, and selecting a user password are discussed. Also covered, is the setting of a Field Unit tag name, resetting of all Field Unit settings, and a discussion of the various messages that are displayed on the Field Unit LCD.

Section 5: Configuring the RF Communications

This section covers the setup of the Field Unit RF Communications which allow the Field Unit to achieve communication with the Base Radio. Parameters discussed are the Field Unit RF ID, the RF channel setting and Baud Rate.

Section 6: Configuring the Sampling and Transmission Rates

This section aids the user in selecting the amount of time between each sample of the process, and the time between each transmission of this sample to the Base Radio. Also discussed is the use of setting an abnormal threshold in which sampling and transmission times may change during a period when the process variable is within the abnormal region.

Section 7: Configuring the Process Variable

This section helps the user in the selection of engineering units, as well as discussing the setting of a measurement offset and trimming the process measurement.

Section 8: Maintaining the Field Unit

This section explains how the Field Unit should be cared for once it has been placed into service. Changing the battery is also covered in this section.

Section 9: Technical Specifications

This section explains the technical specifications that are associated with this device such as power characteristics, accuracy, and operating characteristics.

1.2: ABOUT THE DEVICE

The Accutech Multi-Input Field Unit is a reliable Radio Frequency (RF) transceiver coupled with an dual-channel analog input sensor that can be used to monitor a variety of processes in hazardous and hard-to-reach areas. The time and expense of running wires often makes it difficult to measure parameters that have an economic impact on your plant operation, but the Multi-Input Field Unit allows you to quickly and accurately monitor those devices at fraction of the cost, which gives you bigger and faster returns on your instrumentation investments.

The Field Units communicate in a secure, digital protocol over a band of frequencies from 902MHz to 928MHz. This data communication technique has been the backbone of the military's secure communications protocols for many years. These devices require no wires, permits or licenses, and they are easily set up and installed right out of the box.

You can use this device for long term monitoring in remote locations, for short-term data gathering on process conditions, or to quickly test the economic viability of a new installation.

The purpose of this manual is to help you install and maintain your Accutech Multi-Input Field Unit. BEFORE setting up and installing the Field Unit please setup and configure the Base Radio.

1.3: UNPACKING

Remove the Packing List and check off the actual equipment received. If you have any questions on your shipment, please call your Accutech Representative. Upon receipt of shipment, inspect the container for any signs of damage in transit. Especially take note of any evidence of rough handling. Report any apparent damage immediately to the shipping agent.

Please note that sometimes units are assembled with accessories when shipped. Inspect the shipment carefully if you think that something is missing. This is rare, as we take considerable care to pack units for shipment, but it does sometimes happen. Please give us a call and we may be able to resolve this matter quickly over the phone.

NOTE




Please note that the carrier will not honor any claims for damage unless all shipping materials are saved for their examination. If damage is found during examining and removal of the contents, save the packing material and the carton.

1.4: SOFTWARE COMPATABILITY

Software for Accutech is revised periodically. Internal device software may contain portions that are not compatible with previous versions of the Wireless Instrumentation Manager software.

To ensure software compatibility, Wireless Instrumentation Manager software version 1.56.126 or later must be used. If you believe you are experiencing software compatibility issues please call Accutech Technical Support at (978) 568-0500 or email wireless@adaptiveinstruments.com.

In a Hurry?



This section summarizes what must be done in order to get the device installed, configured and in operation quickly. However, it does not provide detailed or how-to information to perform the tasks outlined.

1. Place the Field Unit in the desired location of operation.
 - Note:** Trimming of the measurement may be necessary before device can be placed in service. If trimming is required perform steps 1 and 7-16 prior to placing device in service.
1. Wire the analog input(s) as shown in top left figure.
2. Wire input switches as shown in middle left figure (optional).
3. Wire output switches as shown in bottom left figure (optional)
 - WARNING!** Wiring output switches voids intrinsic safety certification. Do NOT wire output switches if device will be used in an explosive environment.
5. Ground Field Unit via grounding screw provided in enclosure.
6. Close enclosure and secure enclosure via set screw
7. Turn on Field Unit by pressing ENTER and NEXT buttons simultaneously and holding until unit powers up.
8. Set RF CHAN setting equal to the Base Radio's RF Channel.
9. Set BAUD RT setting equal to the Base Radio's Baud Rate.
10. Set RF ID number to be a unique value between 1 and 50.
11. Select normal transmission rate.
12. Select normal sampling rate.
13. Select abnormal transmission rate.
14. Select abnormal sampling rate.
15. Set normal upper and lower values.
16. Select engineering measurement units.

If the "RF OFF" message is being displayed on the Field Unit LCD, perform the following:

- Set the Set RF CHAN setting equal to the Base Radio's RF Channel.

If a "NO RF" message is being displayed on the Field Unit LCD, check the following:

- Is the Field Unit set to the above listed configurations?
- Is the Base Radio on?
- Are the Field Unit and Base Radio set to the matching configurations? (See Section 5 of Field Unit and Base Radio User Manuals)
- Are the Base Radio and Field Units unable to communicate due to obstructions or distance? (See Field Unit Manual: Field Unit Placement section)
- Did you perform the Simple RF Placement Procedure? (See Field Unit Guide: A Simple RF Placement Procedure section)



Caution



If the Base Radio is not energized for more than 30 minutes, the Field Units should also be turned off to preserve battery life. Leaving the Field Units on when the Base Radio is not energized or out of range will cause the Field Units to transmit very frequently and drastically reduces their battery life.

Installation

3.1: Mechanical Installation

In this section mechanical installation instructions are discussed for the various setup capabilities of the Multi-Input Field Unit. The subsections are as follows:

3.1.1: Field Unit Positioning

3.1.2: A Simple RF Placement Procedure

The Accutech Multi-Input Field Unit is a rugged device, but it provide much better performance if installed with careful consideration, as noted in this manual. It may be utilized in any analog input measurement service so long as care is exercised to prevent exposing the sensing elements to excess stress or temperature. Installation practices have a lot to do with these service parameters and the life that you can expect from your Accutech Multi-Input Field Unit. The main considerations for installation are covered below.

Give careful consideration to the environment where you will be installing your instrument. Avoid installations that expose the device to excess temperature, high vibration, considerable shock, or exposure to dripping condensate or corrosive materials. Also avoid installing the device in an un-serviceable location.

Most often these problems can be avoided with some thought at the time of installation. The practices noted below are generally recommended, but they can only act as a guideline and cannot cover all possible variations. The final installation must be made at the discretion and approval of the user. You must be the judge of the actual installation.

Dimensioned mechanical drawings for aid in mechanical installation are located in Section 9: Technical Specifications

Correct positioning of the Field Unit will ensure the best performance of the device. When planning the positioning of the Field Units there are a few parameters that must be paid attention to:

- Ideally the top of the Field Unit will generally point in an upward fashion. The bottom of the Field Unit should NOT point directly at the Base Radio and the Field Unit LCD should point away from the Base Radio.
- All Field Units should maintain an approximate spacing of at least one foot apart from one another.
- The line of sight range between a Field Unit and Base Radio is 2000 feet at the 19.2K baud rate setting. Note that this range is reduced by the amount of RF Noise present, obstructions, and the material properties of the obstruction.
- Only place the Field Unit in ambient operating temperatures of -40°F to 185°F (-40°C to 85°C).

Warning

During installation do not apply force to the instrument housing or antenna. Use a proper wrench for all installations. Failure to use correct installation procedures can cause damage to the Base Radio.

3.1.1: Field Unit Positioning




Figure 3.1: Examples of Incorrect Field Unit Positioning

Figure 3.1, shown to the left, gives examples of incorrect setups according to the previously mentioned parameters.

Because there are so many setup possibilities we cannot cover them all. A correct setup would make sure that the above warnings are heeded, and that the Field Unit and Base Radio are capable of communication. The RF Placement Test section will help you to determine if you have a selected the correct installation points and orientations for your application.

3.1.2: A Simple RF Placement Procedure

Remember, proper placement of the Field Unit will optimize your RF communication range and capabilities. Perhaps the best test to perform before mechanically mounting the unit is a quick hand-held test.

To perform this test you should have a good idea of where the Base Radio will be placed (for more information see Section 3 of the Base Radio User Manual). Put the Base Radio in this area and power it up. Make sure that the Base Radio and Field Unit are on the same RF Channel and Baud Rate (See Section 5). You may also have to increment the number of Field Units with which the Base Radio is communicating (See the Base Radio User Manual Section 4.3).

Once both the Base Radio and Field Unit are set up to be on the same network, make sure communication is established by looking at the Field Unit LCD for the 'RF OK' message in the Read-Only Sequence (see Section 4.1.1).

After communications have been established, Field Unit should be placed in RSSI Diagnostic mode to determine the signal strength at the location of the equipment to be monitored. Placing the Field Unit in this mode is explained in the following section.

3.1.2.1: Field Unit RSSI Diagnostic

The Received Signal Strength Indicator (RSSI), located in the Field Unit's diagnostic menu, displays the RF signal strength in one of seven ranges. The signal strength is displayed on the LCD using a combination of '>' and '_' characters. Full signal strength is displayed as ">>>>>>>" while minimum signal strength is displayed as "> _ _ _ _ _". If the field unit is not communicating with the Base Radio (i.e. NO RF), all underscore characters will be displayed (" _ _ _ _ _").

The RSSI is measured every time the Field Unit receives a message from the Base Radio. The signal strength of the received message from the Base Radio is calculated during this time. The actual signal strength in dBm for each range is shown below:

>	>	>	>	>	>	>
Less than	Between	Between	Between	Between	Between	Greater than
-105 dBm	-105 dBm & -100 dBm	-100 dBm & -95 dBm	-95 dBm & -90 dBm	-90 dBm & -85 dBm	-85 dBm & -80 dBm	-80 dBm

To place the Field Unit in RSSI Diagnostic mode follow the menu map shown on the following page in Figure 3.2. Note that the RSSI menu is under the DIAGNSE menu and not the CONFIG menu.




Figure 3.2: Menu Map to RSSI Mode

3.1.2.1 Continued

Now that the Field Unit is in the RSSI mode, bring the Field Unit close to the equipment you wish to monitor. Look at the LCD; notice the '>' will constantly fluctuate. One should estimate an average value based on these fluctuations. While the ideal signal integrity is seven arrows, the suggested fluctuating arrow ranges for the different RF Baud Rate settings are listed below:

- 4.8K Baud – between 1 and 4 arrows
- 19.2K Baud – between 2 and 5 arrows
- 76.8K Baud – between 3 and 6 arrows

Once you have verified that you are receiving a signal, you should check to make sure the Field Unit is communicating properly with the Base Radio. To do so exit the RSSI by pressing ENTER, and then navigate to the EXIT? of the diagnostic menu and return to the Operations Sequence shown in Figure 1 on page 8. Once in the Operations Sequence, you will notice small arrows on the rightmost and leftmost regions of the LCD. These arrows indicate the sending and receiving of messages between the Base Radio and the Field Unit. If both arrows are moving up and down, and you do not see a NO RF message, then the position you have selected will be suitable for mounting the device.

NOTE

While using slower baud rate increases communication distance, it also requires more time to complete a communications cycle. This may not be suitable for your application.

If only one or neither of the arrows is moving, and you see a NO RF message, then you do not have satisfactory RF communication with the Base Radio. If your application allows, move the Field Unit to a different position and check again for communications. If your application only allows you to mount at this particular point, you may want to try a slower baud rate setting for an increased range (see note).

One final solution is to reposition the Base Radio. However, this may affect communications with previously installed Field Units, and if so, may require the use of a second Base Radio for your application. To select a better spot for the Base Radio, see section 3.1.1 of the Base Radio User Manual.

3.2.3: Wiring and Configuring the Output Switches

NOTE

The de-energized state of all digital output switches is **NORMALLY OPEN**. Consideration should be given, as in the event of power loss to the device, all switches will **OPEN**.



Warning



Wiring the output switch terminal, for any reason, will **void** the Intrinsic Safety rating for this Field Unit. If the device is to be used in an explosive environment or an environment where Intrinsic Safety is a requirement, then the output switch terminal block should be removed from the device to prevent accidental wiring.

To properly wire an output switch, follow the wiring diagram provided below. Please note that loop power **MUST** be supplied. The Multi-Input Field Unit has the capability of producing two output switches.

Warning: Wiring the output switch terminal, for any reason, will **void** the Intrinsic Safety rating for this Field Unit. If the device is to be used in an explosive environment or an environment where Intrinsic Safety is a requirement, then the output switch terminal block should be removed from the device to prevent accidental wiring.

The diagram shown in Figure 3.5 below refers to the circuit board found at the base of the Field Unit, within the enclosure. Before connecting wires to the terminal blocks, the wires should be routed into the back of the enclosure and threaded through the center of the circuit board.




Figure 3.5: Output Switch Wiring Diagram

To enable and configure each of the output switches, the user must go to the Field Unit Configuration Menu in the Wireless Instrumentation Manager software. For more details on how to access this menu see section 9.2 of the Wireless Instrumentation Manager User Manual.




Figure 3.6: Output Switch Configuration Using Wireless Instrumentation Manager

As in Figure 3.6, the Output Switches configuration tab will display a number of user options. Check the **Enable** check box to enable a switch. Select the input channel of the Field Unit which will be mapped to the output switch via the **Input Number** drop-down list. The **Threshold** value is the point at which the switch will open/close. The **Deadband** is the amount **BELOW** the threshold the process variable must fall before the switch will revert back to its original state. In the case of Figure 3.6, if the process variable is above 10 Volts the switch will open. The switch will not close again until the process variable drops below 8 Volts, which is the Threshold minus the Deadband.

General Configuration

This section discusses the generalities for configuring the Field Unit via the NEXT and ENTER buttons. The subsections are as follows:

- 4.1: Field Unit Displayed Messages
 - 4.1.1: The Read-Only Sequence
- 4.2: The Overall Configuration Menu Map
- 4.3: Setting a Field Unit Tag Name
- 4.4: Setting a User Password
- 4.5: Resetting All Field Unit Settings

4.1: Field Unit Displayed Messages

To turn the Field Unit on, press both the NEXT and ENTER buttons and hold them for a few seconds. Upon power up, the Field Unit will display the Power-Up Sequence, and then go into the Operations Sequence. These Sequences are shown in Figure 4.1 below:

NOTE

During configuration and testing, keep Field Units at least one foot apart and away from the Base Radio to ensure good communications.





Figure 4.1: Field Unit Power-UP and Operations LCD Sequences

4.1.1: The Read-Only Sequence

Once the Field Unit is in the Operations Sequence, a user may access the READ-ONLY Sequence without a password by simply pressing the ENTER button at any time. The Read-Only Sequence, as shown in Figure 4.2, displays extra information about the current settings of the Field Unit that are not seen during the Operations Sequence, but does not allow any changes to be made to these settings.



4.2: The Read-Only Sequence

4.4: Setting a User Password*

Each Field Unit has a password that will lock out undesired users from making changes to the Field Unit. Any user may still view some of the Base Radio settings by pressing the ENTER key during the Operations Sequence and viewing the Read-Only Sequence.

The password is a four-digit password. The factory default is 0000. If you wish to select a different password, follow the Field Unit Menu Map shown in Figure 4.5 to change it.




Figure 4.5: Menu Map to Password Setting




Figure 4.6: Password Setting Using Wireless Instrumentation Manager

If you have the Wireless Instrumentation Manager software this menu option will not be accessible via the Field Unit once the Field Unit detects that the software is being used (See Appendix A for more details). The password should be entered using the Wireless Instrumentation Manager software. To do so, enter the configuration menu (See Section 9.2 of the Wireless Instrumentation Manager User Manual). Once in the configuration menu click on the **General** tab to bring up the general information as shown in Figure 4.6.

The Field Unit password for this device can be set by entering a four-digit number in the **Field Unit Password** field. Once a password has been entered, click **OK** to save and download the password to the Field Unit.

Please note that the password only protects the Field Unit from unauthorized configuration via the NEXT and ENTER buttons. The Wireless Instrumentation Manager requires a user login password to gain access to all configuration parameters. However, user accounts are available and can be set with different access levels and restrictions (For more information on user accounts see the Wireless Instrumentation Manager User Manual Section 8.4).

4.5: Resetting All Field Unit Settings

To reset all Field Unit settings to their default state, the user must navigate to the DEFAULT menu option in the CONFIG menu via the keypad.

Once at the default menu option pressing the ENTER button will display 'RESET?' on the LCD; which asks if the user is sure he or she wants to reset the device to its default configuration. The user will then be prompted with 'NO' on the LCD. Pressing the ENTER button while 'NO' is being displayed will NOT reset the device. Pressing the NEXT button will display 'YES' on the LCD. If the user presses the ENTER button while 'YES' is being displayed the device will be reset.

* Indicates that Menu is Disabled if Wireless Instrumentation Manager is detected. (See Appendix A)

Configuring the RF Communications



Caution



If the Base Radio is not energized for more than 30 minutes, the Field Units should also be turned off to preserve battery life. Leaving the Field Units on when the Base Radio is not energized or out of range will cause the Field Units to transmit very frequently and drastically reduces their battery life.

5.1: RF Channel Selection

NOTE

The RF Channel defines a set of frequencies on which communication takes place between the Base Radio and the Field Unit. Each RF Channel has a different set of frequencies, thus allowing the user to have multiple different wireless networks co-existing throughout the same facility.

The RF Channel can be thought of as a set of walkie-talkies. If both walkie-talkies are on channel one they can communicate. If a walkie-talkie is on channel one and the other is on channel two, they cannot communicate. Likewise, if two walkie-talkies are on channel one and two other walkie-talkies are on channel two, the walkie-talkies on channel one cannot hear what is being transmitted by the walkie-talkies on channel two.

5.2: Baud Rate Selection

NOTE

If you change the baud rate of a Field Unit, you must also change the baud rate of the Base Radio and all other Field Units that are communicating with that Base Radio to match.

In order for the Field Unit and the Base Radio to communicate, they must be on the same RF Channel and must be transmitting at the same Baud Rate. While all Field Units and Base Radios are set to default configurations at the factory, if any configuration differences are present the Base Radio will not be able to communicate with the Field Units. The subsections are as follows:

- 5.1: RF Channel Setup
- 5.2: RF Baud Rate Setup
- 5.3: RF Identification Setup

All Base Radios and Field Units can be set to one of 16 different communication channels. The only Field Units recognized by a particular Base Radio are the units that are on the same RF Channel as that Base Radio. This allows the user to decide which Field Units communicate with each Base Radio.

Each Field Unit comes from the factory set to the RF OFF channel. This means the Field Unit will not communicate to any Base Radio. To set the Field Unit for communication first determine the channel that you wish to use. Then follow the Field Unit menu map shown below in Figure 5.1 to configure the RF Channel.



Figure 5.1: Menu Map to RF Channel Setting

Once you are in the RF Channel menu, you can increment it by pressing the next button. When selecting this value, do not choose an RF Channel that is currently being used by other Accutech Wireless Systems as this can cause communication problems.

The RF Baud Rate refers to the speed at which the Base Radio and Field Units communicate. There are three selectable settings with the fastest update times and ranges listed below:

- 4.8K– Rate of 4.8 Kbaud (Update every 20 seconds)
- Range of 3000ft (Line of Sight)
- 19.2K– Rate of 19.2 Kbaud (Update every 5 seconds)
- Range of 2000ft to 2500ft (Line of Sight)
- 76.8K– Rate of 76.8 Kbaud (Update every 1 second)
- Range of 500ft to 750ft (Line of Sight)

A faster RF Baud Rate allows the user to transmit more information in a given period of time, but it will also limit the Field Unit's range. If you need more distance out of your Field Units or are encountering difficulties by frequently losing communications, then select a slower baud rate.

Follow the Base Radio menu map shown in Figure 5.2 to configure the RF Baud Rate. The factory default is the 19.2K Baud Rate.




Figure 5.2: Menu Map to Baud Rate Setting

5.3: RF Identification Selection

Each Field Unit is identified by the Base Radio and software according to the RF Identification (ID) given to that particular unit. Two Field Units can NOT have the same ID and be on the same RF Channel (if you do not know the RF Channel see section 5.1). If the Field Unit is in the Operations Sequence, pressing the ENTER button displays the Read-Only Sequence on the LCD, which displays the ID of that unit like this: ID 3.

All Field Units in your system are set to a default ID number upon shipment. For example, if you have ordered a Base Radio and three Field Units, the Field Units will be configured to ID's 0, 0 and 0. You must set these units to three different IDs between 1 and 50. The Field Units in this example could be set to RF IDs 1, 2 and 3.

First determine the ID's you'd like to give each unit. Then follow the menu map shown in Figure 5.3 to configure the RF ID. The factory default is RF ID 0, which disables the RF communication of the unit.




Figure 5.3: Menu Map to RF ID Setting

Once you have selected the RF ID you wish to use for this particular Field Unit, save and exit the menus and return to the Operations Sequence.

The Field Unit should now be successfully configured to the Base Radio. To check this, press ENTER while the Field Unit is in the Operations Sequence for the Read-Only Sequence to be displayed. You may see an RF SYNC message displayed on the Field Unit LCD. This means that the Field Unit and Base Radio are attempting to synchronize communications. If this is successful the RF Status will display an RF OK message. If this is unsuccessful the RF Status will display a NO RF message.

Also notice the two small arrows on either side of the LCD; if they are fluctuating up and down, that indicates the Field Unit and Base Radio are successfully communicating. If only one or none of the arrows are moving then RF communication is unsuccessful.

Configuring the Sampling and Transmission Rates

The Multi-Input Field Unit is very versatile with many programmable features and can be used in numerous different applications. Because no two applications are the same, some configuration is required for each unit. This section will walk you through the initial configuration of these sample and transmit settings. The subsections are as follows:

- 6.1: Selecting the Normal Transmission Rate
- 6.2: Selecting the Normal Sampling Rate
- 6.3: Selecting the Abnormal Transmission Rate
- 6.4: Selecting the Abnormal Sampling Rate
- 6.5: Setting the Smart Rate Threshold
- 6.6: Selecting the Normal Upper and Lower Values
- 6.7: Selecting Rates, Thresholds, and Deadbands via the Software

6.1: Selecting the Normal Transmission Rate*

The Field Unit is in a “sleep” mode to save power during the operations sequence. This mode turns off most of the electronics on the unit, with the exception of the LCD, in order to preserve battery life. The Field Unit will then ‘wake up’ every **Normal Sampling Period** and take the necessary current/voltage readings. The Field Unit will then transmit these readings to the Base Radio on an interval determined by the **Normal Transmission Rate**.

Notice that the fastest update rate of the Normal Transmission Rate is dependent on the baud rate setting you selected earlier (see section 5.2). The transmission rates cannot update data faster than their communication speed allows. Thus, if you selected the 19.2K Baud Rate setting, your fastest transmission rate will be 5 seconds and no faster. The Field Unit automatically determines these settings and adjusts the menu options accordingly. A complete table of these parameters is shown in the table in the following section.

In order to properly set the Normal Transmission Rate, you must first determine how often you need updates from the Field Unit when the device being monitored is operating within what you consider to be normal operating conditions for that process variable. You have a selectable range of 1-5, 10, 15, 20, 40 seconds and 1 minute. Then, follow the menu map shown in Figure 6.1 to configure the Normal Transmission Rate. The factory default is 10 seconds.




Figure 6.1: Menu Map to Normal Transmission Rate Setting

Using Wireless Instrumentation Manager

If you have the Wireless Instrumentation Manager software this menu option will not be accessible via the Field Unit once the Field Unit detects that the software is being used (See Appendix A for more details). An explanation of how to select the Normal Transmission Rate using the Wireless Instrumentation Manager software can be found in section 6.7.

* Indicates that Menu is Disabled if Wireless Instrumentation Manager is detected. (See Appendix A)

6.2: Selecting the Normal Sampling Rate*

As previously mentioned, the Field Unit is in “sleep” mode to save power during the operations sequence. This mode turns off most of the electronics on the unit (with the exception of the LCD) in order to preserve battery life. The Field Unit will then ‘wake up’ for every **Normal Sampling Period** and take the necessary current/voltage readings.

Notice that the minimum speed of the Normal Sampling Rate is dependent on the Normal Transmission Rate setting you selected earlier (see section 6.1). The Sampling Rates cannot be set to a slower time interval than the time interval at which the Field Unit is required to transmit updates. Thus, if you selected the Normal Transmit Rate setting to be 10 Seconds the Normal Sampling Rate must be set to 10 Seconds or faster. A complete table of these parameters is shown below.

Baud Rate (communication range)	76.8K	19.2K	4.8K
(speed of updates)	500-750 feet	2000-2500 feet	3000 feet
Normal and Abnormal Transmit Rates	1 Second	5 Seconds	20 Seconds
Normal and Abnormal Sampling Rates	1 Second or Greater	5 Seconds or Greater	20 Seconds or Greater
	Equal to Transmit Rate or Less	Equal to Transmit Rate or Less	Equal to Transmit Rate or Less




Figure 6.2: Incorrect Sampling Rate

In order to properly set the Normal Sampling Rate, first determine how often updates are needed from the Field Unit when the device being monitored is operating normally. You have a selectable range of 1-30 seconds. Note, however, the more frequently the Field Unit wakes up to check the monitored device, the faster you will use up the battery life of the Field Unit.




Figure 6.3: Correct Sampling Rate

Figure 6.2 is an example of what happens when the Normal Sampling Rate is too slow for the device being sampled. Notice how the rise in the voltage level falls between two normal samples, and thus goes completely undetected.

Figure 6.3 is an example of what happens when the normal sampling rate is correctly set for the device that is being monitored. Notice how this setting makes it possible to sample the rise in the voltage level.

Once you have decided on the proper Normal Sampling Rate follow the Field Unit menu map shown in Figure 6.3 to select this setting. The factory default is 1 second.



Figure 6.4: Menu Map to Normal Sampling Rate Setting

Using Wireless Instrumentation Manager

If you have the Wireless Instrumentation Manager software this menu option will not be accessible via the Field Unit once the Field Unit detects that the software is being used (See Appendix A for more details). An explanation of how to select the Normal Sampling Rate using the Wireless Instrumentation Manager software can be found in section 6.7.

* Indicates that Menu is Disabled if Wireless Instrumentation Manager is detected. (See Appendix A)

6.3: Selecting the Abnormal Transmission Rate*

NOTE

If you do not need more or less frequent samples and updates from a Field Unit for a given application, then there is no need to complete this section. Simply set the Normal Transmission and Sampling Rates to the desired speeds, and make sure that the Normal Upper and Lower Values are configured to **Disabled**.




Figure 6.5: Example of Abnormal Transmission Rate Setting

The **Abnormal Transmission Rate** is identical to the Normal Transmission Rate with one exception. The Abnormal Transmission Rate only applies while the Field Unit is in an Abnormal condition (see Setting Normal Upper and Lower Values section 6.6). This allows you to increase or decrease the frequency of information you receive depending on the operating conditions of the device being monitored.

In order to properly set the Abnormal Transmission Rate, you must first determine how often the Field Unit needs to update its data about the device being monitored while in an Abnormal condition. You have a selectable range of 1-10, 15, 20, 40 seconds and 1 minute. Figure 6.5 is an example of how the device switches transmission rates from Normal Transmission Rate to Abnormal Transmission Rate. Note how the first abnormal transmission is sent immediately when the Normal Upper Value set point is exceeded. The next transmission will then follow this immediate transmission by 10 seconds (or whatever the Abnormal Transmission Rate is set to). The transmissions will continue at this interval until the process value drops below the Normal Upper Value set point.

Once the process value drops below this set point, another transmission is made to the Base Radio. The transmissions will then be made at the Normal Transmission Rate of one minute (or whatever the Normal Transmission Rate is set to) from the time of the last abnormal transmission.

The user should also note that the transmission time depends on the sampling rate, and when the process variable is sampled. If the Normal Sampling Rate is 30 seconds, then the process variable may be above the Normal Upper Value for up to 29 seconds before abnormal condition is detected. This means that the transmission could be as late as 29 seconds after the process variable exceeded the Normal Upper Value.

Once you have decided the proper time for the Abnormal Transmission Rate follow the Field Unit menu map shown in Figure 6.6.




Figure 6.6: Menu Map to Abnormal Transmission Rate Setting

Using Wireless Instrumentation Manager

If you have the Wireless Instrumentation Manager software this menu option will not be accessible via the Field Unit once the Field Unit detects that the software is being used (See Appendix A for more details). An explanation of how to select the Abnormal Transmission Rate using the Wireless Instrumentation Manager software can be found in section 6.7.

* Indicates that Menu is Disabled if Wireless Instrumentation Manager is detected. (See Appendix A)

6.4: Selecting the Abnormal Sampling Rate*

NOTE

If you do not need more or less frequent samples and updates from a Field Unit for a given application, then there is no need to complete this section. Simply set the Normal Transmission and Sampling Rates to the desired speeds, and make sure that the Normal Upper and Lower Values are configured to **Disabled**.




Figure 6.7: Example of Abnormal Sampling Rate Setting

The **Abnormal Sampling Rate** is identical to the Normal Sampling Rate with one exception. The Abnormal Sampling Rate only applies while the Field Unit is in an Abnormal condition (see Setting Normal Upper and Lower Values section 6.6). This allows you to increase or decrease the frequency of information you receive depending on the operating conditions of the device being monitored.

In order to properly set the Abnormal Sampling Rate, you must first determine how often the Field Unit needs to update its data while in an Abnormal condition. You have a selectable range of 1-10, 15, 20, 40 seconds and 1 minute. Figure 6.7 is an example of how the device switches sampling methods from Normal Sampling Rates to Abnormal Sampling Rates. Note how the first abnormal sample is taken a few seconds after the Normal Upper Value set point is exceeded. The next sample will then follow this sample by 5 seconds (or whatever the Abnormal Sampling Rate is set to). These samples will continue at this interval until the process value drops below the Normal Upper Value set point.

Once the process value drops below this set point the sampling rate will return to the Normal Sampling Rate. Also, the Abnormal Sampling must be equal to or faster than the Abnormal Transmission Rate.

The user should also note that the transmission time depends on the sample rate, and when the process variable is sampled. If the Normal Sampling Rate is 30 seconds, then the process variable may be above the Normal Upper Value for up to 29 seconds before abnormal condition is detected. This means that the transmission could be as late as 29 seconds after the process variable exceeded the Normal Upper Value.

Once you have decided the proper time for the Abnormal Sampling Rate follow the Field Unit menu map shown in Figure 6.8.




Figure 6.8: Menu Map to Abnormal Sampling Rate Setting

Using Wireless Instrumentation Manager

If you have the Wireless Instrumentation Manager software this menu option will not be accessible via the Field Unit once the Field Unit detects that the software is being used (See Appendix A for more details). An explanation of how to select the Abnormal Sampling Rate using the Wireless Instrumentation Manager software can be found in section 6.7.

* Indicates that Menu is Disabled if Wireless Instrumentation Manager is detected. (See Appendix A)

6.5: Setting the Smart Rate Threshold*

The Smart Rate is a feature used to trigger radio transmission of the measured data sooner than the normal or abnormal rate specified by the user. This feature is used to construct a more accurate graph of the measured process variable vs. time than is possible with the fixed transmission rates, while using less battery power.

To configure the Smart Rate Threshold follow the user menu to the SMART R menu and press the ENTER button. The user is then asked to enter the amount that the process variable must change since the last data sample to trigger a new transmission of the process variable.

If the process variable changes by more than the entered Smart Rate amount within the normal or abnormal sampling rate (whichever is active), then the process variable is transmitted immediately. The normal/abnormal transmit clock is then reset upon this transmission. If no Smart Rate amount exceeding change takes place in the next normal/abnormal sample then the next transmission will be the normal/abnormal transmit rate period.

The amount entered is in the same units as were selected by the user to be displayed on the Field Unit. If the measured process variable does not change by more than the entered Smart Rate amount within the time between the sampling rate (whichever is active), then the process variable is transmitted on the next transmit rate.

If changes in the process variable, which exceed the Smart Rate Amount, continue to occur, the process variable is transmitted repeatedly.

If you have the Wireless Instrumentation Manager software this menu option will not be accessible via the Field Unit once the Field Unit detects that the software is being used (See Appendix A for more details). The Smart Rate should be enabled using the Wireless Instrumentation Manager software. To do so, enter the configuration menu (See Section 9.2 of the Wireless Instrumentation Manager User Manual). Once in the configuration menu click on the **Sampling Rates** tab to bring up the sampling rate information as shown in Figure 6.9.

To enable the Smart Rate, click the check-box labeled **Enable SmartRate** for the correct input. The user will then be allowed to enter a “delta”, or amount changed, value which will trigger a transmission.

Once a value has been entered, click **OK** to save and download the configuration changes to the Field Unit.




Figure 6.9: Smart Rate Configuration Using Wireless Instrumentation Manager

* Indicates that Menu is Disabled if Wireless Instrumentation Manager is detected. (See Appendix A)

6.7: Selecting Rates, Thresholds, and Deadbands via the Software




Figure 6.14: Sample and Transmission Rate Selection Using the Software




Figure 6.15: Normal Upper and Lower Value Selection Using the Software

If you have the Wireless Instrumentation Manager software the Normal and Abnormal Sampling and Transmission menu options will not be accessible via the Field Unit once the Field Unit detects that the software is being used (See Appendix A for more details). These settings should be entered using the Wireless Instrumentation Manager software. To do so, enter the configuration menu (See Section 9.2 of the Wireless Instrumentation Manager User Manual). Once in the configuration menu click on the **Sampling Rates** tab to bring up the sampling rate information, as shown in Figure 6.10.

To select the Normal Transmission Rate, select one of the time periods from the drop box. Next, select an Abnormal Transmission Rate in the same manner. Note that the Normal and Abnormal Transmission Rate can be the same.

Once the transmission rates have been selected, the user should select the desired sampling rates. Note that the sampling rate must be equal to or faster than the associated transmit rate. For example, in Figure 6.10 the Normal Transmission Rate is set to 10 seconds and the Normal Sampling Rate is also set to 10 seconds. This is a valid configuration. Another example in Figure 6.10 is the Abnormal Transmission Rate being set to 3 seconds and the Abnormal Sampling Rate being set to 1 second.

If the user incorrectly enters the Transmission and Sampling Rates, a message will be displayed explaining this to the user. The user will not be allowed to leave this screen before the setting is corrected.

If you have the Wireless Instrumentation Manager software the Normal and Normal Upper and Lower Value menu options will not be accessible via the Field Unit once the Field Unit detects that the software is being used (See Appendix A for more details). These settings should be entered using the Wireless Instrumentation Manager software. To do so, enter the configuration menu (See Section 9.2 of the Wireless Instrumentation Manager User Manual). Once in the configuration menu click on the **Sampling Bands** tab to bring up the sampling band information as shown in Figure 6.11.

To set a limit to the normal condition, enable the limit by clicking on the **Use Input X Limit** check box. Then enter the value and time deadband for the limit (for more details see Section 6.6 of this manual).

Configuring the Process Variable

This section helps the user in the selection of engineering units, as well as discussing the setting of a measurement offset and trimming the process measurement. The subsections are as follows:

- 7.1: Selecting Units of Measure
- 7.2: Setting a Measurement Offset
- 7.3: Trimming the Measurement (Entering a 22-Point Curve)

7.1: Selecting Unit of Measure*

The Field Unit can be used in many different types of applications. To accommodate these various options, there are various engineering units that can be selected. Options include: Volts (WI-AV only) and Milliamps (WI-AI only).

Please note that the units selected apply to both Input 1 and Input 2. Each input may not use different units.

To select units of measurement, follow the Field Unit menu map shown in Figure 7.1. The factory default units is Volts/Milliamps.




Figure 7.1: Menu Map to Units Setting




Figure 7.2: Units Selection Using Wireless Instrumentation Manager

If you have the Wireless Instrumentation Manager software this menu option will not be accessible via the Field Unit once the Field Unit detects that the software is being used (See Appendix A for more details). The process variable units should be entered using the Wireless Instrumentation Manager software. To do so, enter the configuration menu (See Section 9.2 of the Wireless Instrumentation Manager User Manual). Once in the configuration menu click on the **General** tab to bring up the general information as shown in Figure 7.2.

To select the units, click the drop down box labeled **Input Units**. Select units you wish to use from the available list.

Once a valued has been entered, click **OK** to save and download the configuration changes to the Field Unit.

* Indicates that Menu is Disabled if Wireless Instrumentation Manager is detected. (See Appendix A)

7.2: Setting a Measurement Offset

For various applications, the user may wish to display an offset value rather than the actual value. To enter an offset, navigate to the OFFSET command, as shown in Figure 7.3, select the desired input to be offset. Then enter the offset to be added or subtracted from the actual measured value.




Figure 7.3: Menu Map to Offset Setting

7.3: Trimming the Measurement

The Field Unit interface allows the user to set a two point correction curve for the sensor. This process is often called “trimming” because the displayed value is trimmed up or down to reflect the actual value being applied.




Figure 7.5: Setting a 22-Point Curve Using Wireless Instrumentation Manager

7.4: Entering a 22-Point Curve

To set a trim point take the Field Unit offline and navigate to the TRIM menu, as shown in Figure 7.4, and select the input to be trimmed. Then select the point you wish to enter. After selecting the point, you will be asked if the Field Unit has been taken offline. Press the ENTER button if this is true. Next, you will be asked to enter a value. This should be a known reference value. Once you have entered the applied value, you will be prompted to apply the reference value to the sensor, and then confirm the value is being applied via a yes/no prompt.




Figure 7.4 Menu Map to Trim Setting

If you have the Wireless Instrumentation Manager software, a 22-point sensor offset curve may be entered for the Field Unit. To do so, enter the configuration menu (See Section 9.2 of the Wireless Instrumentation Manager User Manual). Once in the configuration menu click on the **Sensor Offset** tab to bring up the offset information as shown in Figure 7.5.

Maintaining the Field Unit

The Multi-Input Field Unit is extremely easy to maintain in that it requires no periodic calibration or system checks. The Field Unit has a self diagnostic which is constantly checking the internal system. If any errors are found they are reported via the LCD, Base Radio or the software. A simple yearly visual inspection for the following is all that is needed:

- Is the Field Unit still securely fastened to the equipment being monitored?
- Are there any visible corrossions, cracks or residue build-ups on the unit?
- Has anything about the application changed from the original intended use?

8.1: Changing the Battery



Warning



Explosions may result in death or serious injury. Do not remove the instrument cover or open wiring housing in explosive atmospheres when power and communications are on. Instead, remove the Field Unit from the hazardous location and then proceed to open the instrument cover and replace the battery.

The battery will need to be changed within one month of seeing a ‘LOW BAT’ message on either the Field Unit. This is a simple process:

1. Make sure you have the correct replacement battery:

TADIRAN™ Lithium Inorganic Battery (non-rechargeable)
Size “C” – 3.6Volts
#TL2200/S

2. Power down the Field Unit by pressing and holding both the NEXT and ENTER buttons for a few moments.
3. Remove the 4 set screws on the sides of the Field Unit housing with a standard screw driver.
4. Remove the housing and locate the battery. Warning! When removing the housing do not twist or bend the green flex cable! Doing so may cause the tether to improperly seat next to the antenna and greatly reduce operable RF distances. Do not allow the housing to flop around while hanging by the tether.
5. Remove the old battery and replace it with the new battery positive end first. (Note that the positive end of the battery clip is the end with the red wire).
6. Plug the green wire tether back in and replace the housing. Then, screw the housing back on, and power up the unit by pressing either of the buttons.
7. Properly dispose of used battery.

Technical Specifications

Analog Input Characteristics

- 10 Ohm impedance, analog (WI-AI)
- 100 kOhm impedance, analog (WI-AV)

Intrinsic Safety Entity Parameters for Analog Inputs

- V_{Max} = 30 VDC
- I_{Max} = 100 mA
- P_{Max} = 900 mW
- Maximum operating temperature = 85 °C
- Temperature Class T4

Input Switch Characteristics

- For simple device monitoring only (i.e., contact closures)
- Input switches share common ground

Output Switch Characteristics (Do not use in Intrinsic Safety required environments)

- V_{max} = 30 VDC
- I_{max} = 1 Amp
- Non-Isolated, output switches share common ground

Accuracy

- ± 0.1 % of Full-scale reading at reference conditions
- ± 0.01% of reading per °C for ambient temperature effect

RF Characteristics

- 902 MHz – 928 MHz Frequency Hopping Spread Spectrum, FCC certified ISM license-free band
- Up to 3000' range from Base Radio with clear line of sight;
- The RF module in each field unit is individually tested and calibrated over the full temperature range to ensure reliable wireless operation

Operating Temperature Range

- -40 °F to +185 °F (-40 °C to +85 °C) electronics
- -4 °F to +158 °F (-20 °C to +70 °C) display (full visibility)
- -40 °F to +185 °F (-40 °C to +85 °C) display (with reduced visibility)

Physical Characteristics

- Aluminum junction box
- GE Lexan® cover. V-0 rating and UV stable

Operating Vibration and Shock Characteristics

- Certified per IEC EN00068 2-6 (vibration) and 2-27 (shock)

Random Vibration Characteristics


- Certified to withstand 6 g's, 15 minutes per Axis from 9 – 500 Hz

Electromagnetic Compatibility (CE Compliance)

- Operates within specification in fields from 80 to 1,000 MHz with Field strengths to 30 V/m. Meets EN 50082-1 general immunity standard and EN 55011 compatibility emissions standard

Industrial Certification

- Rated for industrial use -40 °F to 185 °F (-40 °C to 85 °C)
- FM NEMA 4 weather-proof housing
- FM rated intrinsically safe for Class I/II/III, Division 1, Groups A,B,C,D,E,F&G; Class I/II/III, Division 2, Groups A,B,C,D,F&G



+

Dimensioned Mechanical Drawing

REV	ECO	APPROVED	DATE	DESCRIPTION
A	PR-213	JC	10/24/03	


REV	ECO	APPROVED	DATE	DESCRIPTION
A	PR-213	JC	10/24/03	

FM APPROVED INTRINSICALLY SAFE INSTALLATION CONTROL DRAWING

HAZARDOUS (CLASSIFIED) LOCATION

Class I, Zone 0, Group IIC
 Class II, Division 1, Groups A, B, C, and D
 Class II, Division 1, Groups E, F, and G
 Class III

UNCLASSIFIED LOCATION



Acutech WI-AI, WI-AV Entry Parameters:

UI (Vmax) = 30V
 II (Imax) = 100mA
 PI = 0.9W
 CI = 0
 LI = 0

- Notes:
- The Intrinsic Safety Entry permits the interconnection of two FM Approved intrinsically safe devices with entry parameters not specifically examined in combination as a system when:
 - Uo or Voc or Vi ≤ Vmax, Io or Isc or Ii ≤ Imax, Ca or Co ≥ Ci + Ccable, La or L ≤ Lc, R ≤ Rcad, Po ≤ Pi.
 - Dust-tight conduit seal must be used when installed in Class II and Class III environments.
 - Control equipment connected to the Associated Apparatus must not use or generate more than 250 Vrms or 100 Vdc.
 - Installation should be in accordance with ANSI/ISA-81.12.6 "Installation of Inherently Safe Systems for Hazardous (Classified) Locations" and the National Electrical Code® (ANSI/NFPA 70) Sections 504 and 506.
 - The configuration of associated Apparatus must be FM Approved under Entry Concept.
 - Associated Apparatus manufacturer's installation drawing must be followed when installing this equipment.
 - No revision to drawing without prior FM Approval.
 - RTD, TC, and Contact Input process connectors to a Simple Apparatus Only.
 - Acutech WI-RT-S, WI-TCS, WI-GP-S, WI-AP-S, WI-AM, WI-AM, WI-AP-I, WI-GP-I, WI-RT-I, and WI-TC-I MUST be installed to a bonded process.
 - Acutech WI-AI, WI-AV has an internal ground screw mounted in the enclosure and must be connected to IS ground.

NOTE: Devices connected to J3 must be of "Simple Apparatus" type.

Device	Terminal	Signal	Notes
WI-AM (Acoustic Monitor)	J1 (Terminal Board) Sensor Input		
	1	(CH+)	
	2	(CH-)	
	3	(EXC+)	
	4	(EXC-)	
	5	(CH2+)	
WI-GP-I, WI-AP-I (Pressure Sensor)	J3 (Terminal Board) Input Switches		
	1	(SW1+)	
	2	(SW1-)	
	3	(SW2+)	
	4	(SW2-)	
	5	(CH2-)	
WI-RT-I (RTD Temperature)	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
WI-RT-S (RTD Temperature)	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
WI-GP-S, WI-GP-S (Pressure Sensor)	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
WI-TCS (T/C Temperature)	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
WI-AI (Dual Input)	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		
	Integral Sensor - no external connections		

Drawn By	Date	Title	Scale	Size	Sheet
JC	10/24/03	Adaptive Instruments LLC	N/A	A	1 of 2
Checked By	Date				
PCN	10/24/03	I/S Installation Control Drawing - Wireless Sensors			
Released By	Date				
PCN	10/24/03				

Drawn By	Date	Title	Scale	Size	Sheet
JC	10/24/03	Adaptive Instruments LLC	N/A	A	1 of 2
Checked By	Date				
PCN	10/24/03	I/S Installation Control Drawing - Wireless Sensors			
Released By	Date				
PCN	10/24/03				

NOTICE: This drawing and specifications, herein are the proprietary property of Adaptive Instruments LLC and shall not be reproduced or in part as the basis for manufacture or sale without prior written permission from Adaptive Instruments LLC.

NOTICE: This drawing and specifications, herein are the proprietary property of Adaptive Instruments LLC and shall not be reproduced or in part as the basis for manufacture or sale without prior written permission from Adaptive Instruments LLC.

Navigating User Menus

Pressing either the NEXT or ENTER buttons located on the front of the Field Unit or Base Radio just below the Liquid Crystal Display (LCD) screen is all that is needed to navigate the respective menus. Pressing both of these buttons for one second will turn the unit on.

Pressing the NEXT button at any time while the Field Unit is cycling through the normal messages causes the Field Unit to enter the setup mode. The NEXT button is then used to step through menu options, and the ENTER button is used to enter a sub menu of what is displayed on the LCD at that time. If no button is pressed within a 30 second period the unit goes back to the normal display mode.

If you enter a sub menu that requires a numerical input, such as 001, the left most 0 will be blinking. This indicates that pressing the NEXT button will increment this value with each press from 0 to 9 and back to 0 again. Pressing the ENTER button will move to the next available value. If the last value is blinking, pressing ENTER will save the entered values and return from the sub menu.

If both the NEXT and ENTER buttons are depressed at once, a message on the LCD displaying OFF? will appear. If both buttons are released upon appearance of this message the user will be returned to the scrolling main screen. If both buttons are not released for the duration of the OFF? message the unit will power down and turn off. Note: If the unit is turned off while entering values in a sub menu, those values will NOT be saved.

* As shown throughout the document, this mark indicates that these menu options will automatically turn off if the Wireless Instrumentation Manager Software is used. All changes to these Field Unit menu options should be made through software instead. This is to prevent simultaneous changes from taking place. If you wish to discontinue use of the software and want these menus re-instated, you must contact your Accutech Sales Representative.

Field Unit Displayed Message Definitions

This section covers the various messages, displayed on the Field Unit LCD, that occur during operation of the device.

Operations Sequence

- **RF Link Status**
 - ⇒ RF OK – Field Unit and Base Radio are communicating properly
 - ⇒ RF SYNC - Field Unit and Base Radio are attempting to synchronize communications.
 - ⇒ RF OFF - Field Unit's RF Channel is set to RF OFF
 - ⇒ NO RF - Field Unit and Base Radio have no communications
- **Analog Input Level**
 - ⇒ -XX.XX – Currently measured Analog Input level

Error Messages

If an error is detected with the operation of the Field Unit a message will be displayed on the Field Unit LCD (a corresponding message may also appear on the Base Radio LCD).


There are few types of error messages, warning and fatal. Warning messages are displayed as part of the normal cycling message sequence. These are:

- **LOW BAT** - battery should be replaced as soon as possible
- **NO RF** - can not detect Base Radio
- **S FAULT** - there is an open sensor or excitation wire detected. Also if a sensor value goes above/below logical limits. The unit will display 9999.99 for measurement (sensor fault mode); but will continue sampling and recover if the problem desists.
- **OVERRNG** - the device is measuring a value above/below sensor dependent bound values. For example the Analog Input device will report over-range if measurement is above 100% range of the Analog Input sensor. If the measurement goes above 150% full range, the unit will go into Sensor Fault mode. In over-range mode, the measurement is continued to be displayed, with the "OVERRNG" message to remind the user that the specified range of the sensor and the calibrated range of the device is being exceeded.

Fatal error messages will replace the normal cycling message sequence and will flash. A fatal message indicates the Field Unit is no longer operating normally and requires repair. These are:

- **RF ERR** - fatal error within RF communications
- **SEN ERR** - fatal error within the sensor electronics
- **SYS ERR** - fatal error within the microprocessor system
- **RF CAL** - fatal error within the RF calibration system

Field Unit Menu Map



A B O U T U S

Accutech, a division of Adaptive Instruments Corp., is a leading edge, technology-driven developer, manufacturer and supplier of embedded microprocessor-based electronics. Based in Hudson, Massachusetts, Accutech is the most successful leading independent producer of wireless instrumentation on the market today.

Accutech customers include large national companies in the oil and gas, chemicals, pharmaceutical, food and beverage, primary materials processing, and energy industries. In addition to the wireless product line, Accutech also offers a traditional wired line of temperature, pressure and differential pressure instrumentation.

In the process control field, where quality is taken for granted and new technology is announced daily, we have deliberately concentrated our efforts on the development of instrumentation that makes business sense. The result is a product range that is rugged, secure, and reliable and works in even the most hazardous environments. We give companies the tools to reduce costs, save time, enhance safety, improve environmental performance and cut waste.

The next industrial revolution is right now. Let Accutech show you how to realize gains in operating efficiency.

Visit us at: www.accutechinstruments.com

Or call us at +1 800 879-6576

Specifications subject to change without notice. Printed in USA. Copyright 2005 Adaptive Instruments, Corp.

The logo for Accutech, featuring the word "Accutech" in a bold, white, sans-serif font set against a solid orange rectangular background.

A Division of Adaptive Instruments Corp.
577 Main Street · Hudson, MA 01749 U.S.A.
TEL: 800-879-6576 · 978-568-0500
FAX: 978-568-9085
Email: support@accutechinstruments.com
www.accutechinstruments.com

The logo for Wireless Instrumentation, featuring a stylized orange and white graphic of concentric arcs above the text "Wireless Instrumentation" in a bold, sans-serif font. Below this, the tagline "FOR INDUSTRIAL SENSORS" is written in a smaller, all-caps, sans-serif font.

**Wireless
Instrumentation**
FOR INDUSTRIAL SENSORS