

fluair
MV distribution
Factory-built assemblies
at your service

User Manual


F400 cubicle

Merlin Gerin

Modicon

Square D

Telemecanique

Schneider
 **Electric**

Contents

General description	3
Glossary	3
Cable incoming or outgoing cubicles	3
Bus coupler cubicles	4
Bus riser cubicles	5
Draw-out SF circuit-breakers	6
Draw-out bar bridge	6
Identification	7
How to read the information on the front side	7
Symbols	8
List of optional accessories available with the switchboard	8
Operating Instructions	9
How to extract the removable part	9
How to insert the removable part	11
How to plug in the removable part (front plate with black background)	13
How to draw out the removable part (front plate with black background)	14
How to close the MV cable earthing isolator (front plate with a yellow background)	15
How to open the MV cable earthing isolator (front plate with a yellow background)	16
How to operate the adjustable voltage transformers	18
Padlocking	20
Key-locking	22
Testing	24
"Power on" on the MV cables	24
Checking phase coincidence between two cubicles	24
Testing MV cables	24
Switchboard dielectric test	25
Testing the current transformers	25
Busbar earthing truck	26
Maintenance Instructions	28
Ordering parts	28
Preventive maintenance	28
Maintenance points	28
Access to top and bottom plug-in blocks	29
Access to the voltage transformers	31
Replacing the fuses of the adjustable voltage transformers	32
Replacing the VT position auxiliary contacts	33
Replacing the "power on" Led block	33
Replacing the earthing isolator position auxiliary contacts	34
Replacing the removable part position auxiliary contacts	35
Trouble-shooting	35



General description

Glossary

Abbreviations

LV : low voltage

MV : 36 kV voltage class

EI : earthing isolator

SF : range of SF6 circuit-breakers used
in F 400

VT : voltage transformer

NVC : no-voltage check

CT : current transformer or current sensor

Cable incoming or outgoing cubicles

Front side

A : LV compartment access door

B : removable part compartment access door


C : removable part position check view ports

D : removable part interlocking and operating plate

E : voltage indicators

F : earthing isolator interlocking and operating plate

G : removable part blocking



Left-hand view

1 : LV cable routing and connection compartment

2 : low voltage compartment

3 : busbar compartment

4 : MT and VT cable compartment


5 : removable part compartment

H : removable part

J : earthing isolator

K : earthing isolator operating mechanism

L : voltage transformer.




General Description

Bus coupler cubicles


Front side

- A : LV compartment access door
- B : removable part compartment access door
- C : view ports
- D : removable part interlocking and operating plate
- E : removable part interlocking plate



Left-hand view

- 1 : LV cable routing compartment
- 2 : low voltage compartment
- 3 : bottom busbar compartment
- 4 : top busbar compartment
- 5 : removable part compartment
- F : removable part interlocking mechanism
- G : removable part
- H : voltage transformer.




General Description

Bus riser cubicles


Front side

- A : LV compartment access door
- B : fixed bar bridge compartment access door
- C : view ports.



Left-hand view

- 1 : LV cable routing compartment
- 2 : LV compartment
- 3 : bottom busbar compartment
- 4 : top busbar compartment
- D : voltage transformer.





General Description

Draw-out SF circuit-breakers



SF1

CEI 1250 A standard





SF2

CEI 1250 A standard





SF2

CEI 2500 A standard




Draw-out bar bridge

1250 A and 2500 A



General Description

Identification




Functional unit:
A : cubicle name
B : nameplate
C : features, descriptions and serial number.

SF draw-out removable part
D : features, descriptions and serial number.

How to read the information on the front side


Removable part



1 : mechanical opening push-button
2 : removable part position selector
3 : removable part operating crank insertion opening

A : removable part mechanical position indicator
B : slot for the disconnecting truck lock (optional).

Earthing isolator, power on and plug-in disabling




A : power-on indicator block
B : earthing isolator position selector
C : slot for the earthing isolator lock
D : earthing isolator operating crank insertion opening
E : locking pull for plug-in disabling (plug-in disabling selector)
F : slot for the plug-in disabling lock

General Description

Symbols

Cubicle



Plug-in disabling position



Operating position



Earthing isolator open position



Earthing isolator open mechanical indicator



Earthing isolator closed position



Earthing isolator closed mechanical indicator



Padlockable position.


Removable part



Operating position



"Plugged-in" position



"Drawn-out" position




Insertion / extraction position

List of optional accessories available with the switchboard

- 1 busbar earthing truck (optional) (see MALT truck on page 26)
- 1 phase coincidence checking device (optional) (See on page 24).


Operating Instructions

How to extract the removable part




Operation

Warning: for cubicles with internal arc withstand option, loosen the six screws **A** before operating the handle





Open the access door to the removable part by pulling and then rotating the handle rightwards.



Unplug the LV auxiliary connection cord. Clip the cable on the circuit-breaker.

Warning: the threshold bar must be removed before extracting the removable part.



Press push-button 1.
 Hold it down to move selector 2 to position 
 Then extract the removable part by pulling the handles.



Pull out the removable part.

threshold bar

Operating Instructions


Closing the door after extracting the removable part

Warning: the following steps MUST be followed to allow the door to be closed.


Warning: put back the threshold bar.




Before closing the access door to the removable part, lower the panel.



Inside the door, pull locking part 1 or lift part 2.




The door closes but does not lock.



Close the door.

Operating Instructions


How to insert the removable part




Open the access door to the removable part by pulling and then rotating the handle rightwards.


Warning: Remove the threshold bar.


Insert the removable part in the cubicle.



Operating Instructions




To move selector 2 to position ,

press push-button 1.
Hold it down to move selector 2 to position .


Push the removable part into the cubicle until it is in abutment.

Then press push-button 1.



Hold it down to move selector 2 back to position .

Connect the LV auxiliary connection cord.

Warning: lift protection flap V of push-button 1.




Reassembling the threshold




- Insert the threshold bar A tilting it slightly, align slots B with threaded rods C then fit the threshold bar,
- position nuts D

Closing the door with the removable part in place


Warning: if closing is impossible, check the following points.




Before closing the access door to the removable part, lift the panel and check that it is properly latched at the top.



Lift rod 2, topple locking part 1 over and release rod 2.




The door closes but does not lock.




Close the door.

Operating Instructions

How to plug in the removable part (front plate with black background)



and



Initial statuses

Removable part


The removable part is drawn out. Operation should be allowed by means of the locks, if fitted.

The circuit-breaker LV auxiliaries are connected and the circuit-breaker compartment door is closed.


Earthing isolator


- selector 4 to 0 (earthing isolator open)
- locking pull to disable plug-in in unlocked position.

Operation




If the disconnecting switch is key-locked (optional): insert the key in **H**. Lower the protection flap of push-button 1.





Press push-button 1; hold it down to move selector 2 to .


Lift the protection flap of push-button 1.



Insert the crank in aperture 3. Plug in the removable part by rotating the crank clockwise until status change of position indicator **A** and locking of crank in rotation.




Move selector 2 to .



The removable part is plugged-in. If a circuit-breaker is used, the electrical operation for energizing the downstream part of the equipment is now possible.

Operating Instructions


How to draw out the removable part (front plate with black background)




Initial statuses:


- removable part in plugged-in position.


Operation




If the disconnecting switch is key-locked (optional): insert the key in **H**.
Lower the protection flap **V** of push-button 1.





Press push-button **1** (which triggers a circuit-breaker mechanical opening order).
Hold it down to move selector **2** to .
Lift protection flap **V** of push-button 1.



Insert the crank in aperture **3**.
Draw out the removable part by rotating the crank counter-clockwise until status change of position indicator **A**.



Move selector **2** to .




The removable part is drawn out.
The cubicle is in disconnected position.




Operating Instructions

How to close the MV cable earthing isolator (front plate with a yellow background)



Its function:


- in closed position, it short-circuits and earths MV cables, making it possible to work on cables in safe conditions.
- it can be closed only if the circuit-breaker is in drawn-out position or extracted from the cubicle.




Initial statuses:

- the removable part has been drawn out or extracted from the cubicle.

or



and




Earthing isolator.

Check that the Leds (L1, L2, L3) are off (no voltage).


The earthing isolator is open (4).

The locks if fitted (A and B) should allow operation.

Operation





Move selector 4 to  , pulling then rotating it clockwise.




Insert the crank in the operating shaft 5, rotate it clockwise until status change of position indicator E.

Operating Instructions




Move selector 4 to ; to do so, pull then rotate it clockwise.




The earthing isolator is in closed position.
MV cables are short-circuited and earthed.

How to open the MV cable earthing isolator (front plate with a yellow background)





Initial statuses:


- earthing isolator closed.
- If fitted, lock should allow operation.
Selector 4 to .

Operating Instructions


Operation





Move selector 4 to , pulling then rotating it counter-clockwise.



Insert the crank in the operating shaft 5, rotate it clockwise until status change of position indicator E.




Move selector 4 to  by pulling and then rotating it counter-clockwise.



The earthing isolator is in open position.


Operating Instructions

How to operate the adjustable voltage transformers




Voltage transformers are operated from the rear of the cubicle. They can be in the position: "**in operation**" (primary fuses and transformers connected to MV cables or switchboard busbars) or "**out of operation**" (primary fuses and voltage transformers disconnected).

Caution: for cubicles with internal arc withstand option, first remove the panel located at the rear of the cubicle.




"Out of operation" position
A : operating handle in the top position
B : lock
C : fuse ends apparent
D : fuse extraction slot.




"In operation" position
A : operating handle in the bottom position
B : padlock
E : fuse slot retractable closing flap in closed position
D : fuse extraction slot.

How to put the VTs in operation




Initial status:
 Handle **A** in top position, flap **E** open and fuse ends **C** apparent, indicate that the transformers are out of operation.




1 : Push the latch to the left.
2 : Pull the handle.

Operating Instructions




- 3 : Lower the handle.
- 4 : Block the assembly in position by pushing the latch to the right.
- 5 : Lock with a padlock




Handle **A** in bottom position and flap **E** closed, indicate that the transformers are in operation.


How to put the VTs out of operation




Initial status:
Handle **A** in bottom position and flap **E** closed, indicate that the transformers are in operation.



- 1 : Remove the padlock
- 2 : Pull the handle.
- 3 : Push the latch to the left.



- 3 : Lift the handle.
- 4 : Block the assembly in position by pushing the latch to the right.



Handle **A** in top position, flap **E** open and fuse **C** end apparent, indicate that the transformers are out of operation.

Operating Instructions


Padlocking

ø 6 to 8 mm padlock can be used

- on the plug-in disabling selector
- on the protection flap of the removable part mechanical opening push-button
- on the earthing isolator selector in open or closed position

- on the flap opening mechanisms inside the circuit-breaker compartment.
- on the adjustable voltage transformers operating mechanism.

Disabling the removable part plug-in




Fit 1 to 3 padlocks on plug-in disabling selector **D**, in following position




Disabling the mechanical opening order of a circuit-breaker in operation position

This device can also be used as an additional plug-in and draw-out disabling system.





Fit a padlock on the protection flap of mechanical opening push-button **1**.

Disabling the opening or closing of the MV cable earthing isolator




Earthing isolator open:

Fit 1 to 3 padlocks on selector **4** in position  to disable closing.




Earthing isolator closed:

Fit 1 to 3 padlocks on selector **4** in position  to disable opening.

This also disables the plug-in of a removable part.

Operating Instructions


Disabling the opening of a flap of the removable part compartment



Left-hand side

The plug-in blocks are accessed by manual opening of the bottom flap:

- on the busbar side, in an incoming/outgoing cubicle
- on the left-hand busbar side, in a circuit-breaker coupling cubicle.



Right-hand side


The plug-in blocks are accessed by manual opening of the bottom flap:

- on the MV cable side, in an incoming/outgoing cubicle
- on the right-hand busbar side, in a circuit-breaker coupling cubicle.

After the removable part has been extracted from the cubicle, the top or bottom flap can be locked by means of 1-2 or 3 padlocks.


- 1 : position the part (K and L)
- 2 : padlock.

Note: the two operating mechanisms are separate.



Left-hand side:


- F : padlocking
- G : bottom flap operating mechanism.




Right-hand side:

- H : padlocking
- J : top flap operating mechanism.

Disabling the putting in or out of operation of the voltage transformers



Fitting a padlock allows you to lock the handle in bottom position (transformers in operation).



Fitting a padlock allows you to lock the handle in top position (transformers out of operation).

Operating Instructions

Key-locking

Possible number of locks

This locking is optional.

- removable part in drawn-out position:

1 lock on the cubicle


- (2 NO) or (2 NC) or (1 NO and 1 NC) or (1 NO) or (1 NC) : on the earthing isolator.

NO: normally open

NC: normally closed

- disconnecting truck: 1 lock in "plugged-in" position on the removable part.

Disabling the plug-in of a removable part





Removable part in drawn-out position. Remove the key when the plug-in disabling selector is in following position



Draw-out is then impossible.

Disabling the draw-out of a removable part or of a disconnecting truck




Remove the key when selector 2 is in position .

Draw-out is then impossible.

Operating Instructions


Disabling the opening or closing of the earthing isolator

Earthing isolator closed



Remove the key(s) when selector 4 is in position **1**, opening is then impossible.


Earthing isolator open



Remove the key(s) when selector 4 is in position **2**, closing is then impossible.


Testing

"Power on" on the MV cables



As soon as the cables have been energized, the "power on" indicator Leds L1, L2 and L3 must come on.

Checking phase coincidence between two cubicles




Phase coincidence:
the tester lamp does not come on.

Phase unbalance:
the tester lamp comes on.

Testing MV cables

Voltage injection to MV cables



Check that power is off.
The "power on" indicator Leds are off.
Close the earthing isolator (see chapter titled **how to close the EI**).
It is recommended to lock it in this position.

- remove the closing plate from the cable compartment.

Open the earthing isolator (see chapter titled **how to open the EI**) then perform the tests.



At the end of the tests:

- close the earthing isolator
- remove accessories
- close cable compartment.
- Fasten the injection vises to the MV cable fastening terminal pads or to the lugs.

Testing

Switchboard dielectric test

This test can be performed in a single operation.
All circuit-breakers must be plugged-in and closed, with the cubicle doors open.
Furthermore, one of the outgoing cubicles must have its MV cable compartment open for the connection of the test cable.




Indicator **A** indicates the status of the circuit-breaker (O or I).

This preparation requires the manual disabling of interlocking to plug in the circuit-breakers, with the door open.

The sequence below must absolutely be followed.

Position the circuit-breaker in drawn-out position, with the door open.
Lift and lock the door locking rod by means of a 55 mm high U-shaped wedge.
Plug in the circuit-breaker.
Remove the wedge.



The manual closing of the circuit-breaker by pressing button "I" is then possible by means of its operating mechanism.

Testing the current transformers

Note: to perform this operation, refer to the various relevant chapters in this document.

Injection at primaries

An injection at the current transformer primaries is possible by access to the fixed plug-in blocks located in the circuit-breaker compartment.

Injection at secondaries

The tests and settings will be preferably performed by injection at secondaries, using the test and injection boxes provided in the LV compartment.

- 1 : Extract the removable part.
- 2 : Close the earthing isolator.
- 3 : Padlock the opening of the bottom flap providing access to the fixed blocks on the busbar side.
- 4 : Access the fixed blocks on the current transformer side through the top flap aperture.
- 5 : Fit the injection device between the fixed block (primary terminal P1) and the cubicle earth bar which is accessible in the circuit-breaker compartment.
Terminal P2 of the transformer is connected to the cubicle earth bars by means of the earthing isolator in closed position.

Caution: the connection accessory must not damage the fixed block coating.

Changing the winding ratios at the secondary.

Any change in the winding ratio is performed by access to a specific terminal board inside the low voltage compartment (see LV developed diagrams).

This operation is performed with the transformer primary de-energized and earthed by closing of the earthing isolator.

After testing

- 1 : Remove the injection device.
- 2 : Close the top flap.
- 3 : Remove the padlock locking the opening of the bottom flap.
- 4 : Open the earthing isolator.
- 5 : Insert the removable part.

Testing

Busbar earthing truck

The earthing of the busbars of Fluair 400 switchboards in version 2000 is provided by means of a circuit-breaker type truck positioned in one of the outgoing cubicles after draw-out.

All circuit-breakers in the switchboard can be extracted if necessary.

Busbar earthing truck F400 complies with the requirements of CEI129.

Technical features

Rated voltage = 36kV

I_{th} = i.e. 25kA - 3s

i.e. 31.5kA - 3s

"Power on" device: no


The MALT trucks are planned to be inserted in one of the switchboard cubicles 1250A for the main earthing of the busbars.

A double lock can be provided with separate operating mechanisms releasing cams that about the polarization block located on the cubicle floor.

Each double lock is then allocated to one of the ½ sets of cubicles (L-H or R-H) by means of a central key box.

Polarization of MALT trucks

The purpose of this optional device is to impose the draw-out of all circuit-breakers in a ½ set of cubicles and of the coupling before plugging in a busbar earthing truck



Testing

Recommendations for operating MALT trucks

The plug-in of a MALT truck is performed by means of the propulsion mechanism used for circuit-breakers (crank).

The closing-opening operations of the main contacts are performed manually by the operator, with the cubicle MV door open.

The MALT truck is used in the following conditions:

- possibility of plugging in the MALT truck with the cubicle MV door open or closed
- the MALT truck only operates the bottom flap of the plug-in bells
- the truck operates the plug-in/draw-out contacts of the cubicle
- the positioning of closing springs is performed manually by means of the lever
- opening-closing operations are controlled by means of the buttons located on the front panel of the truck
- the " O-C " buttons are padlockable separately
- the truck can be inserted with the earthing isolator (SMALT) closed or open
- the SMALT remains operable with the MALT truck plugged-in
- the MALT truck is equipped with a separation prohibiting access to energized parts when the truck is plugged-in

Once plugged in, the MALT truck is considered as potentially closed.

As a result, it does not have the following auxiliaries:

- auxiliary contacts indicating the status of the Mean Voltage main contacts
- electric control systems to ensure the remote opening-closing controls
- low voltage cord connecting the MALT truck to the cubicle LV compartment.

The " O - C " position mechanical indicator of HV contacts is:

- black for OPEN
- white for CLOSED

Maintenance Instructions

Ordering parts

When preparing the order, refer to this manual supplied with the system to define the equipment desired very precisely.

To order any equipment, you must indicate:

- type of cubicle
- manufacturing number (engraved on the identification plate located on the left-hand panel of the circuit-breaker compartment).

If possible, attach a diagram of this manual on which the part is conspicuous.

Preventive maintenance

Before performing any task, make sure of the strict compliance with operating and safety instructions.

Our equipment is designed to guarantee optimum operation provided that the maintenance instructions described in this manual are strictly adhered to.

Start each maintenance task with the thorough cleaning of the cubicle.

The use of pressurized solvent projection as a cleaning process is prohibited.

The main risks related to this process are as follows:

- De-lubrication of sliding rails and joints (life lubricated)

- Corrosion of unprotected parts
- Damage and deformation due to high pressure
- Overheating due to solvent on contact areas.
- Elimination of special protections.

Schneider Electric cannot guarantee the durability and reliability of the equipment subjected to this type of cleaning process even if followed with lubrication.

Maintenance points

Removable part

Extract the removable part (see chapter "how to extract the removable part").

Referring to its user manual, perform an overall check of the system.

- clean insulating parts
- apply a thin film of grease ("Klüber Amblygon TA 15/2") or equivalent to the plug-in clamps.

Caution: should clamps be damaged, the corresponding MV fixed block in the cubicle shall be inspected.

Warning: prior to any application, remove the old grease.

Removable part compartment

Extract the removable part.

Check and lubricate:

- pins and joints, mechanisms and sliding rails of flaps ("Klüber Isoflex Topas L152") or equivalent.
- the earthing plate ("Klüber Amblygon TA 15/2") or equivalent.
- the Smalt driving mechanism ("Klüber Isoflex Topas L152") or equivalent.
- behaviour at the LV wiring connection points.

Caution: for electric contacts, do not use grease ("Klüber Isoflex Topas L152") or equivalent.

Warning: prior to any application, remove the old grease.

Remove dust and clean the inside of the compartment and the plug-in insulating parts.

MV cable compartment

- check behaviour, condition and tightening of the connections of the main earth bar, earthing isolator braid and MV cables
- check the condition of the earthing isolator contacts and that it is operating correctly
- remove dust and clean the inside of the compartment, the cable ends and the insulating shields

- slightly lubricate the earthing isolator blades and blocks ("Klüber Amblygon TA 15/2") or equivalent.

Warning: prior to any application, remove the old grease.

Maintenance Instructions

Busbar compartment

- remove dust and clean the inside of the compartment and the insulators
- check the behaviour, condition and tightening of the busbars.


Tightening torque

The connections must be tightened by means of a torque wrench, complying with the following torques:

screw	torque in Nm
ø 6	13
ø 8	28
ø 10	50
ø 12	75
ø 14	120

Access to top and bottom plug-in blocks

Opening the flaps




Left-hand side.

A : bottom flap latch finger.

The plug-in blocks are accessed by manual opening of the bottom flap:

- on the busbar side, in an incoming/outgoing cubicle
- on the left-hand busbar side, in a circuit-breaker coupling cubicle.



Right-hand side

B : top flap latch finger.


The plug-in blocks are accessed by manual opening of the bottom flap:

- on the MV cable side, in an incoming/outgoing cubicle
- on the right-hand busbar side, in a circuit-breaker coupling cubicle.

Operating the bottom flap

Right-hand side:


Padlock the opening of the top flap (see paragraph titled "disabling the opening of a flap of the removable part compartment).




Left-hand side:

Using a screwdriver, release latch finger **A**.

Maintenance Instructions



Push to open the flap.




After maintenance, close the flap by lifting it manually until it locks, then remove the padlock locking the top flap.

Operating the top flap


Left-hand side:

Padlock the opening of the bottom flap (see paragraph titled "disabling the opening of a flap of the removable part compartment").




Right-hand side

Using a screwdriver, release latch finger B.



Holding latch finger B, in position, push the flap upwards.





After maintenance, lower the flap manually until it locks, then remove the padlock locking the bottom flap.

Maintenance Instructions

Access to the voltage transformers

Caution: this operation should preferably be performed with the cable head or busbars de-energized, according to the type of cubicle.

For cubicles with internal arc withstand option, earth the system then remove the shield.





Put the transformers out of operation (see paragraph "how to put VTs out of operation")

C : fuses.


D : adjustable voltage transformers.

Once the transformers are out of operation, release, without removing them, the 2 screws that secure cover F in order to lift it.




Remove the red flap located at the top of the compartment.

Slide it under cover F.




Padlock the red flap.



Remove the top of the compartment.


Maintenance Instructions




Access to voltage transformers and VT position auxiliary contacts is then possible. To put back into operation, proceed in the reverse order.

Replacing the fuses of the adjustable voltage transformers


Put the VTs out of operation (see paragraph "how to put VTs out of operation").





Release the two screws.




Rotate and remove the fuse.



Remove the fasteners and bayonet **A** from the fuse...




... and fit it on the new fuse.



Fully insert the fuse and rotate.

Maintenance Instructions




Lock the two screws to the recommended torque.
Put the VTs into operation (see paragraph "how to put VTs into operation").


Replacing the VT position auxiliary contacts

Removal

Note: to access the auxiliary contact block, refer to chapter "access to voltage transformers".



A : auxiliary contacts.




For the auxiliary contacts, separate the crank on the compartment side and remove the 4 mounting screws.

Fitting


Proceed in the reverse order.

Replacing the "power on" Led block

Removal




Extract the removable part from the cubicle. On the right-hand side of the circuit-breaker compartment, locate the earthing isolator control box.



Remove the 4 M6 screws on the earthing isolator control box side, to access auxiliary contacts. Remove protecting cover **A**.

Maintenance Instructions



Mark and disconnect the wiring connector.


Remove the fasteners and free the "power on" Led block.

Fitting


Proceed in the reverse order.

Replacing the earthing isolator position auxiliary contacts


Removal



Extract the removable part from the cubicle. On the right-hand side of the circuit-breaker compartment, locate the earthing isolator control box.



Remove the 4 M6 screws on the earthing isolator control box side, to access auxiliary contacts. Remove protecting cover **A**.



Mark and disconnect the auxiliary contact wiring.

Remove the 2 screws that secure the auxiliary contact support. Remove the assembly.


Fitting

Proceed in the reverse order.


Maintenance Instructions

Replacing the removable part position auxiliary contacts


Removal




Extract the removable part from the cubicle. Locate the assembly on the internal right-hand side of the circuit-breaker compartment.



Remove the three screws from the cover and the cover itself.



Mark and disconnect the wiring.



Remove the mounting screws and the contact unit assembly.

Fitting

Proceed in the reverse order.

Trouble-shooting

Symptoms	Faulty devices	Possible causes and solutions
Abnormal noise with power on (crackling, vibrations)	<ul style="list-style-type: none"> ■ insulators ■ metal components ■ upstream or downstream connection 	Damp or dirty <ul style="list-style-type: none"> ■ clean or dry them Incorrectly fastened <ul style="list-style-type: none"> ■ check fasteners Incorrect cubicle connection <ul style="list-style-type: none"> ■ check the connections
Excessive overheating at connection points	<ul style="list-style-type: none"> ■ connection 	Connections incorrectly tightened <ul style="list-style-type: none"> ■ retighten them, see tightening torque, contact surfaces ill adapted or damaged ■ change or clean them
Operation requiring abnormal effort		Anomaly resulting from deformation <ul style="list-style-type: none"> ■ adjust

Maintenance Instructions

Symptoms	Faulty devices	Possible causes and solutions
One of the "power on" Leds does not come on	■ Led	Abrupt handling, MV network overvoltage ■ change the "power on" block
	■ wiring	Faulty ■ check it (see wiring diagram)
	■ "power on" functional unit	Capacitor damaged ■ change the unit
	■ capacitor insulator	Insulator capacitor damaged ■ change insulator
Circuit-breaker does not close		Operation incomplete ■ refer to the removable part extraction chapter
	■ protection relay	Action of a protection ■ check the relay settings and remove the fault
	■ wiring	Faulty ■ check it by successive eliminations
	■ LV circuit-breaker	Faults on LV circuit ■ trouble-shooting by successive eliminations
	■ section switch	In "Out of operation" position ■ close it

Schneider Group service centers are available for:

engineering and technical assistance
start-up
training
preventive and corrective maintenance
adaptation work
spare parts


**Call your sales representative who will put you
in touch with your nearest Schneider Group Service Center,
or call directly Grenoble France on 33 (0)4 76 57 60 60**

Schneider Electric Industries SA

F-38050 Grenoble cedex 9
Tel. : +33 (0) 4 76 57 60 60
Fax : +33 (0) 1 47 51 80 20

<http://www.schneiderelectric.com>
RCS: Nanterre B 954 503 439

As a result of the development of specifications and designs, always ask for confirmation of the information given in this publication.

 This document has been printed on co-friendly paper.

Publication: Schneider Electric
Layout: Cabinet MARTINEZ SARL - NANTES
Printed by: Cabinet MARTINEZ SARL - NANTES