# **User Manual**

GOODWE DS SERIES

Ver 03

#### **Table of Contents**

1	Symbols1
2	Safety
3	Installation
	3.1 Mounting Instruction
	3.2 Unpacking
	3.3 Equipment Installation
	3.3.1 Selecting the installation location4
	3.3.2 Mounting Procedure
	3.4 Electrical Connection
	3.4.1 Connection to grid (AC side Connection)
	3.4.2 DC side connection10
	3.4.3 RS485 Communication
	3.4.4 ZigBee Communication
	3.4.5 WiFi Communication
	3.4.6 Communication with Solar-Log Device
	3.4.7 USB Communication
	3.5 Troubleshooting
4	System Operation
	4.1 Display
	4.2 Indicator Lights
	4.3 LCD Display
	4.4 Error messages60
5	Technical Parameters

	Table5.1 GW3600-DS, GW4200-DS, GW4600-DS, GW5000-DS	43
	Table5.2 GW3600D-DK/UK	47
6	Certificates	72
7	Warranty	72
	7.1 Warranty Period	72
	7.2 Warranty Card	72
	7.3 Warranty Conditions	72
	7.4 Scope of Warranty	73
8	Contact	74
N	ote:	

The images and diagrams in this manual are for guidance only. Please refer to the actual product.

## 1 Symbols

	Caution! - Failure to observe a warning indicated
	in this manual may result in injury.
$\triangle$	Danger of high voltage and electric shock!
	Danger of hot surface!
) X	Product should not be disposed as household waste.
<u>†</u> †	This side up; the package must always be transported, handled and stored in such a way that the arrows always point upwards.
5	Components of the product can be recycled.
<b>T</b>	Fragile; the package/product should be handled carefully and never be tipped over or slung.
6	No more than six (6) identical packages may be stacked on each other.
Ţ	Keep dry; the package/product must be protected from excessive humidity and must be stored under cover.
(6	CE Mark



Residual voltage exists in the inverter; before commencing any maintenance, at least 5 minutes must be allowed for the capacitor in the inverter to fully discharge. Units:



3.6-4.6KW

## 2 Safety

The DS series inverter of Jiangsu GoodWe Power Supply Technology Co. Ltd. (hereinafter referred to as GoodWe) strictly conforms to related safety rules in design and test. Safety regulations relevant to the location shall be followed during installation, commissioning, operation and maintenance. Improper operation may have a risk of electric shock or damage to equipment and property.

- Installation, maintenance and connection of inverters must be performed by qualified personnel, in compliance with local electrical standards, regulations and the requirements of local power authorities and/or companies.
- To avoid electric shock, DC input and AC output of the inverter must be terminated at least 5 minutes before performing any installation or maintenance.
- The temperature of some parts of the inverter may exceed 60°C

during operation. To avoid being burnt, do not touch the inverter during operation. Let it cool before touching it.

- Ensure children are kept away from inverters.
- Do not open the front cover of the inverter. Apart from performing work at the wiring terminal (as instructed in this manual), touching or changing components without authorization may cause injury to people, damage to inverters and annulment of the warranty.
- Static electricity may damage electronic components. Appropriate method must be adopted to prevent such damage to the inverter; otherwise the inverter may be damaged and the warranty annulled.
- Ensure the output voltage of the proposed PV array is lower than the maximum rated input voltage of the inverter; otherwise the inverter may be damaged and the warranty annulled.
- When the photovoltaic array is exposed to light, it supplies a d.c. voltage to the PCE.
- PV modules should have an IEC61730 class A rating. If the maximum AC mains operating voltage is higher than the PV array maximum system voltage, PV modules should have a maximum system voltage rating based upon the AC mains voltage.
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

- Completely isolate the equipment should : switch off the DC switch ,disconnect the DC terminal ,and disconnect the AC terminal or AC breaker.
- Not to enter other areas of the equipment when maintaining!
- Prohibit to insert or pull the AC and DC terminals when the inverter is electrified.

## **3 Installation**

#### **3.1 Mounting Instruction**

- A In order to achieve optimal performance, the ambient temperature should be lower than 45 °C.
- B For the convenience of checking the LCD display and possible maintenance activities, please install the inverter at eye level.
- C Inverters should NOT be installed near inflammable and explosive items. Any electro-magnetic equipment should be kept away from installation site.
- D Product label and warning symbol shall be clear to read after installation.

E Please avoiding direct sunlight, rain Exposure, snow lay up when installing.



图 3.1-1

#### 3.2 Unpacking

When you receive the GoodWe inverter, please check for external damage to the inverter and any accessories. Please also check that the following are included:

Inverter 1
Wall-mounted bracket 1
Lock Plate 1
Positive DC Plugs 2
Negative DC Plugs 2
AC Plug 1
USB Data Cable1
Expansion Bolts7
Screws for Lock Plate and RS485 Cover5

User Manual 1	
Warranty Card 1	L
Antenna(only for WiFi inverter) 1	



#### **3.3 Equipment Installation**

#### 3.3.1 Selecting the installation location

The following must be considered when selecting the best location for an inverter:

• The mount and installation method must be appropriate for the

inverter's weight and dimensions.

- The location must be well ventilated and sheltered from direct sunlight.
- The inverter must be installed vertical or with a backward tilt less than 15°. No sideways tilt is allowed. The connection area must point downwards.



Figure 3.3.1-1

To allow dissipation of heat, and for convenience of dismantling, clearances around the inverter must be at least:

Upward	300mm
Downward	500mm
Front	300mm
Both sides	200mm



Figure 3.3.1-2

#### 3.3.2 Mounting Procedure

**A** Use the wall-mounted bracket as a template and drill 7 holes in the wall, 10 mm in diameter and 80 mm deep.



Figure 3.3.2-1

**B** Fix the wall mounting bracket on the wall using the expansion

bolts in the accessories bag.

C Hold the inverter by the groove on the heat sink.



Figure 3.3.2-2

**D** Place the inverter on the wall-mounted bracket (as illustrated below).



Figure 3.3.2-3

Figure 3.3.2-4



Figure 3.3.2-5

**E** Insert the lock plate pegs into the two holes in the heat-sink, then fix the inverter with a padlock and screw M3x8.



#### **3.4 Electrical Connection**

Connections must be made in compliance with local regulations and the requirements of local power authorities/companies.

In accordance with VDE0126-1-1/A1, the inverter incorporates a Residual Current Monitoring Unit (RCMU) which monitors residual current from the solar module to the grid side of the inverter. The inverter can automatically differentiate between fault current and normal capacitive leakage currents.

It must be included a breaker or a fuse at the AC side, ac breaker's norminal voltage is 250Vac, the melting current is not larger than 32A.

The equipment should have a protective earthing attached to earth conductor.

#### 3.4.1 Connection to grid (AC side Connection)

- A Check the grid (utility) voltage and frequency at the connection point of the inverter. It should be 230VAC (or 220VAC), 50/60Hz, and single phase.
- **B** Disconnect the breaker or fuse between the PV inverter and the utility.
- **C** Connect the inverter to the grid as follows:
  - Switch off the AC breaker.
  - Disassemble the female connector of the AC wire connector and connect the AC wires to the connection socket as indicated.



Figure 3.4.1-1

Insert Line wire to Pin 1, Neutral wire to Pin 2 and Ground wire to Pin (



Figure 3.4.1-2

- Tighten the cables with a torque of 20kgf.cm (1.9 N.m).
- ► After fastening all screws, reassemble the female connector of the AC wire connector.
- Connect the female connector of the AC wire connector to the male connector on the inverter.
- **D** Specifications of the AC wires:



Figure 3.4.1-3

Depicted	Size
A External diameter of the wire	12mm-25mm
B Sectional area of conducting mater	ials Max.6mm <sup>2</sup>
C Length of bare wire	Approx.10mm

#### E AC output connection

Tighten the screw with a screw driver until the head of the screw is inside the connector. Otherwise the wire could be loose.



Figure 3.4.1-4

#### **3.4.2 DC side connection**

- A Make sure the maximum open circuit voltage (Voc) of each PV string does not exceed the inverter's input voltage Vmax under any condition.
- **B** Use Phoenix contact or Multi-contact connectors for the PV array terminals.
- C Connect the positive and negative terminals of the PV panel to

corresponding terminals on the inverter. The DC terminal on each inverter can bear 20A DC current.

#### **Phoenix Contact Connectors**

If using Phoenix contact connectors for the PV array terminals, install as follows:





Female side connector (PV+)

Male side connector (PV-)

Connectors must be installed as a pair, and each cable stripped and installed as shown below.



Figure 3.4.2-1



Figure 3.4.2-2

1. Insert the stripped PV conductor.



Figure 3.4.2-3

2. Press down on the spring and snap in.



Figure 3.4.2-4

3.Tighten the screw connection. Then the terminal can be connected to the inverter side



Figure 3.4.2-5

4. The connection can only be released using a screwdriver

## **Multi-Contact Connectors**

If using Multi-contact connectors for the PV array terminals, install as follows:



Female side connector (PV+)

Male side connector (PV-)

Connectors must be installed as a pair, and each cable stripped and installed as shown below.









Figure 3.4.2-6

Tighten the screw connection. Then the terminal can be connected

to the inverter side.





Compress the two snap-in springs by hand and release.

Where the inverter is equipped with a DC switch, ensure the switch is in the "OFF" position before connecting the inverter to PV panels. Switch to "ON" after completing the connection.

## ⚠

- Before connecting the PV panels, ensure the plug connectors have the correct polarity. Incorrect polarity could permanently damage the unit.
- Check the short-circuit current of the PV string. The total shortcircuit current must not exceed the inverter's maximum DC current.
- High voltage exists when the PV panel is exposed to the sun. Secure the terminal connection and, to avoid electric shock, do NOT touch any exposed components.
- ▶ PV array should not be connected to the grounding conductor .

The minimum array insulation resistance to ground that system designer or installer must meet when selecting the PV panel and system design, based on the minimum value that the design of the PV functional grounding in the inverter was based on. The minimum value of the total resistance 33.3kΩ that the system must meet. There is a risk of shock hazard if the total minimum resistance requirement is not met.

#### 3.4.3 RS485 Communication

An RS485 interface is used for multipoint communication. The EzLogger can monitor and communicate with 20 inverters at the same time; however the cable length should not exceed 800m. The diagram below shows a typical inverter connection through the RS485 interface.



Figure 3.4.3-1

The diagram below shows the inverter connections for multipoint

communication through the RS485 interface. "EzExplorer" software at the PC end allows 16 EzLoggers to be monitored simultaneously, in real time.



Figure 3.4.3-2

RS485 pins in the GoodWe DS series:

Pin1+7V	
Pin2+7V	
Pin3 RX_RS485B	Pin1> 8
Pin4GND	لىرىكا
Pin5GND	RJ45 SOCKET
Pin6RX_RS485A	
Pin7TX_RS485B	
Pin8TX_RS485A	

A Connection procedure:

- a. Remove the waterproof RS485 cover;
- **b.** Remove the screw cap of the cable gland;
- c. Remove the one-hole sealing ring;
- **d.** Put the RS485 cable through the components in this order: screw cap, one-hole sealing ring, gland body;
- e. Compress the crystal head and insert it into the corresponding interface;
- f. Fasten the waterproof RS485 cover;
- **g.** Fasten the screw cap of the cable gland.



Figure 3.4.3-3

**B** The RS485 cable has eight wires of different colors. Strip off the outside envelope to expose the eight wires, then straighten the end of each wire, and put them in order.



#### Figure 3.4.3-4

- **C** Ensure each pin of the crystal connection corresponds with the correct wire of the RS485 cable.
- **D** Plug the eight wires into their corresponding slots of the crystal connector, and then fasten them using a 485 wire crimper.
- **E** Connect the other end of the RS485 cable to the crystal connector according to procedures B, C and D
- **F** The inverter can communicate with an EzLogger through an RS485 cable. When the EzLogger is connected to a PC via an Ethernet or USB interface, the inverter can communicate with the PC directly.

#### **3.4.4 ZigBee Communication**

Only for ZigBee mode inverter.

Zigbee communication function is not compatible with the 485 communication function.

An EzBee is needed for wireless function. For installation and detailed information of the wireless function please refer to the EzBee User Manual.

A typical wireless connection for an inverter is shown below.



Figure 3.4.4-1

One Ezbee device can monitor up to 8 inverters. The diagram below shows the wireless connection for multiple inverters.



Figure 3.4.4-2

#### 3.4.5 WiFi Communication

You can browse GoodWe global PV stations monitoring website (<u>http://www.goodwe-power.com</u>) to get data. The information includes energy generated yearly, monthly and daily, the total income and CO2 savings, etc. At the same time you can browse information of other PV stations if the setting is "shared".

In order to achieve that you need to register in the website and create your PV station in advance.

A **WiFi** router device is essential for Internet connection. Be sure to keep the inverter in the area that WiFi signal could reach.

ONLY for the inverter with WiFi function:

Step1: Assemble the Antenna.



Figure 3.4.5-1

As the picture showed, assemble the antenna into the wireless plate.

#### Step2: Configuration of Inverter with WiFi

Please start up inverter before the configuration. And make sure the yellow Led light on the front cover is flickering. Otherwise please set the protocol to '.VS. WebServer' at first referring to 'PART E' of chapter 4.3 in page 49.

#### **Option I:** Via App (for smart phone/pad)

Please download 'SolarMan Tool' from google play or app store and install it on smart phone or Pad. Run it.

#### Below is for Anroid app:



A. Click 'Settings'



B. Choose 'GoodWe-HF'

GN Home	Language
Configure	Diagnosis



C. Press Configure Icon



E. Input 'GoodWe-HF',

#### D. Choose Enter Manually



F. Press Next

## (no password as default)



G. Choose WiFi network And Input password.



H. Linking...

- 3 🔚 🔜 10	:40
Select the router to be connected by data logger/inverter	8
Goodwe-YanFa	104
Goodwe-Wireless_Test	1
TP-LINK_6E224C	
sz-akbr	100
GoodWe-HF	10
Enter Manually	
? Unknown Result	
Unknown result for configuration of SN GoodWe-HF, please disgnose or try again	
Diagnose	
Try Again	



I. Repeat A & B, then Press

#### 'Diagnose'

S8	奈 🎇 🚮 💷 🎴 10:56
र 🔜 Diagnose	
Configuration succe 0 fault need to be handle	ssful.
Send report	Diagnose again
Connection status	^
Smartphone	
Inventer WiPi	Ronter
Scientific Server	Internet
Fault items(0)	~
Items to be optimized	(0) ~
All diagnosis result	~

K. OK or it will tell where there is problem

J. Waiting Diagnose for Result.

And below is for iOS app:



A. Click 'Setting'



B.Turn on Wi-Fi





C. Choose 'GoodWe-HF'



D: Run app and click Configure



E. Click 'I Know'

F. Press 'Refresh' Icon

Configure	-
	C
to connect to	
	÷
	¢.
YanFa	÷
	>
	to connect to YanFa





H. Input password



I. Linking






## K. Click 'I Know' and Waiting

#### L. Diagnosing...

iPod 🗢 9:04 🔳	iPod 🗢 9:04 🖃
Configure Diagnose	Configure Diagnose
Configuration successful.	Configuration successful.
Send report Diagnose again	Send report Diagnose again
Connection status	Connection status
	Inverter Data boger Router Router Router Router Internet
Invertor Data logger Router	Fault items (0)
	Items to be optimized (0)
	All diagnosis result

M. OK or it will tell where there is problem.

#### **Option II: Via Laptop**

You need a PC with WiFi to search WiFi network and choose "GoodWe-HF". Browse website <u>http://10.10.100.254</u> to set the configuration. A windows page will pop-up after you browse the website, please enter user name and password the same as "admin". In order to avoid the configuration of WiFi module is modified by others, it's recommended that you modify the password of WiFi firstly. To implement it please click "AP Interface Setting". You can find it in the left side of webpage as below.

	<b>₽</b> Х	English
Mode Selection	Working Mode Configuration	
AP Interface Setting	You may configure the Uart-WIFI module wifi mode and data transfor mode.	
STA Interface Setting     Application Setting     Device Management	AP Mode: Access Point STA Mode: Staton Mode Data Temperature Tode	
	Apply Cancel	

Figure 3.4.5-2

Then you can see a page as below, please change "Security Mode" to "WPA2-PSK" and change WPA Algorithms" to "AES". Then you can enter the password in "Pass Phrase" column.

Made Colorian	AP Interface Setting such as SSID, Securi	ty	
Node Selection	2		
AP Interface Setting	Wireless Network		
STA Interface Setting	Network Mode	llb/g/n mixed mode 🖌	
Application Setting	Network Name(SSID)	Goodwe-HF-RD-DS	
a la caracteria de la cara	BSSID	AC:CF:23:01:7A:B0	
Device Management	Frequency (Channel)	AutoSelect	
	Wireless Distribution System(WDS)	WDS Configuration	
	Abbra	Cancel	
	Goodwe HF-RD-DS		
	Security Mode VPA	12-PSK 🗸	
	WPA		
	WPA Algorithms	TKIP @ AES () TKIPAES	

Figure 3.4.5-3

Please don't change other settings.

NOTICE: Please do remember the password. Once you forget it and you want to access it, the only way is to reload the WiFi module (Refer to 4.3 Part E) and configure the WiFi module again. After change the password please click "Apply" button, you will get a page as below:





Click "STA Interface Setting" and you will get a page as Figure 3.4.5-5:

i Mode Selection	STA Interface Sett	ing	
AP Interface Setting     STA Interface Setting	You could configure STA interfa	ice parameters here.	
Application Setting	STA Interface Parameters		
Device Management	AP's SSID	GoodWe-Sample	Search
- 10	MAC Address (Optional)		
	Security Mode	WPA2PSK 🐱	
	Encryption Type	TKIP 🐱	
	Pass Phrase	*****	
	WAN Connection T DHCP Mode Hostname(Optional)	Apply Cancel ype: DHCP C GoodWe-HF	buto config) 🛩
		apply Cancel	

Figure 3.4.5-5

Click "Search..." button, you will get a list of WiFi network and choose the network of your WiFi router. "Security Mode" and "Encryption Type" will change the same as your router automaticly. Enter the password of your WiFi network in "Pass Phrase" column. Do not change the "MAC Address", "WAN Connection Type" and "Hostname", then click "Apply" button as shown in picture. You will get a page as below:



Figure 3.4.5-6

Click the 'Device Management', you will get a page as below:

	and the second statements of		
Mode Selection	Device Managen	nent	
AP Interface Setting	4.01.9		
STA Interface Setting	You may configure administ: firware.	rator account and password, load default setting or update	
Application Setting			- 22
Device Management	Adminstrator Settings		
	Account	adain	
	Password	adain	
		Apply Cancel	
		David (1)	
	Restart Module		
	Restart Module	Restart	
	Load Factory Defaults		
	count rectory contained		

Figure 3.4.5-7

Click the 'Restart' button, and several seconds later the configuration is completed. The page will not update automaticly, but you can see the wireless connection disconnect from WiFi module and connect to your local router.

#### **Step3: Registration**

After connect to your local router. Browse <u>http://www.goodwe-</u> <u>power.com</u>, and click the "Register" button. Select "End User" as user type, fill in the register table and the registration is completed.

#### **Step4: Create PV Station**

Fill in the table of the "New Station" web page according to the actual location of your station. In the "Maintain WiFi Inverter" column, enter the information of the inverter including S/N, Check Code, Type and Description, and click "Add" button. Then you

can browse the website.

If you have several WiFi type inverters in one PV station, you need to enter their information one by one.

ONLY for non-WiFi type inverter connected with EzLogger

#### Step1: Get EzLogger

Check the user manual of EzLogger. Follow the steps and ensure your inverters are connected with EzLogger.

#### Step2:

#### Registration

Browse http://www.goodwe-power.com, and click the "Register" button.

Select "End User" as user type, fill in the register table and the registration is completed.

## **Step3: Create PV Station**

Fill in the table of the "New Station" web page according to the actual location of your PV station. In the "Maintain EzLogger/EzMonitor" column, type the information of your EzLogger, including S/N and Check Code. Then click "Add" button. Type the information of your inverter such as S/N, Check Code, Type and Description and click "Add" button. If you got several non-WiFi type inverters for single PV station, you need to type the information of inverter one by one.

NOTICE: ONLY THE DATA FROM INVERTER WITH THOSE

INFORMATION ENTERED CORRECTLY IN THE WEBSITE CAN BE VIEWED.

## 3.4.6 Communication with Solar-Log Device

All GoodWe inverters can be monitored by Solar-Log200/500/1000.

Work steps

- Switch off the inverters and Solar-Log;
- Follow the steps in 3.4.3 connection procedure to install the RS485 interface in the inverters;
- Connect inverters to the Solar-Log;
- Connect the inverters to each other;

## CAUTION

Risk of damage to the Solar-Log!

The Solar-Log also has an RJ45 socket, which must never be connected to the RJ45 socket on the inverter!

ONLY connect Solar-Log via the RS485/422 B interface on the bottom of Solar-Log.



Figure 3.4.6-1

Figure RS485/422 B Terminal Block Connector

Connect the wires as shown in the following diagram:

G 1 I		11 1	DI 15 1 1 1
Solar-Log	terminal	block	RJ 45 socket of inverter
-			
connector			Pin
connector			1
Terminal			
Terminai			
1			Pin 6
4			Pin 3
Т			1 111 5
5	-		Din 9
3			Pin 8
	-		
6			Pin 7

• Insert the RJ45 plug into any RJ45 socket on the first inverter;

• If only one inverter is to be connected, terminate this;

• Insert the terminal block connector into the Solar-Log RS485/422 B socket;

Connecting the inverters to each other

- Connect using a network cable (patch cable);
- Where to connect: RJ45 socket on the outside of the inverter;

Procedure:

- Insert the RJ45 plug into any RJ45 socket on the first inverter;
- Insert the other end of the wire into any RJ45 socket on inverter 2;
- Connect the other inverters to each other in the same way;
- Terminate in the last inverter;

## Before operation, please read the instruction of Solar-Log!

## 3.4.7 USB Communication

USB communication function is available for all GoodWe inverters, Before use the function please install software 'EzExplorer' which can be downloaded from GoodWe website.

To connect the USB data cable, remove the USB socket cover and insert the USB cable as indicated.



Figure 3.4.7-1

## 3.5 Troubleshooting

In most situations, the inverter requires very little maintenance. However, if the inverter is not working properly, please try the following troubleshooting solutions before calling your local dealer.

Should a problem arise, the red (fault) LED indicator on the front panel will light up and the LCD screen will display the type of fault. The following table lists error messages and the solutions for associated faults.

Display	Possible actions
---------	------------------

System Fault	Isolation Failure	<ol> <li>Check the impedance between PV (+) &amp; PV (-) and make sure the PV inverter is earthed. The impedance value must be greater than 2MΩ.</li> <li>Contact the local service office for help if the</li> </ol>
	Ground I Failure	<ol> <li>Contact the rocal service office for help if the problem still exists.</li> <li>The ground current is too high.</li> <li>Unplug the inputs from the PV generator and check the peripheral AC system.</li> <li>When the problem is cleared, reconnect the PV panel and check the inverter status.</li> <li>Contact the local service office for help if the problem still exists</li> </ol>
	Vac Failure	<ol> <li>The PV Inverter will automatically restart within 5 minutes if the grid returns to normal.</li> <li>Make sure grid voltage conforms with the specification.</li> <li>Contact local service office for help if the problem still exists.</li> </ol>

	Fac Failure	<ol> <li>The PV Inverter will automatically restart within 5 minutes if the grid returns to normal.</li> <li>Make sure grid frequency is in conformity with the specification.</li> <li>Contact the local service office for help if the problem still exists.</li> </ol>
	Utility Loss	<ol> <li>Grid is not connected.</li> <li>Check grid connection cables.</li> <li>Check grid usability.</li> </ol>
Inverter fault	PV Over Voltage	<ol> <li>Check whether the PV open voltage is higher or too close to the maximum input voltage.</li> <li>If the problem still exists when the PV voltage is less than the maximum input voltage, contact the local service office for help.</li> </ol>
	Consistent Failure	<ol> <li>Disconnect PV (+) or PV (-) from the input and restart the PV Inverter.</li> <li>If the problem still exists, contact the local service office for help.</li> </ol>
	Over Temperature	<ol> <li>The internal temperature is higher than the normal value specified.</li> <li>Reduce the ambient temperature.</li> <li>Move the inverter to a cool place.</li> <li>If the problem still exists, contact the local service office for help.</li> </ol>

	Relay-Check	
	Failure	
	DC Injection	
	High	1. Disconnect all PV (+) or PV (-).
	EEPROM	2. Wait for a few seconds.
	R/W Failure	3. After the LCD switches off, reconnect and check
	SCI Failure	again.
	DC Bus High	4. If the message appears again, contact the local
	De Dus Ingli	service office for help.
	Ref 2.5V	
	Failure	
	GFCI Failure	
		1.Check the yellow led light on front cover is
		flickering or not; If not, 'Set Protocol' to '.VS.
		WebServer';
		2. Make sure the configuration was made step by step
WiFi		follow the guide. Otherwise, please configure the
Fault		WiFi properly.
		3. If you forget the password you set for WiFi module
		in inverter, and you want to access the WiFi module
		once again, you can use the button to reload WiFi
		module. Please refer to item E in 4.3
		4. Check if the WiFi router can access to internet or
		not.
		5. Make sure the inverter is not far away from the
		WiFi router than 10 meters. If yes, please locate the
		WiFi router closer to inverter.

▶ If there is no display on the panel, check the PV-input connections. If the voltage is higher than 125V, contact the local

service office for help.

When sunlight is insufficient, the PV Inverter may continuously start up and shut down automatically due to insufficient power generated by the PV panel. If the problem remains, please contact the local service office.

# **4** System Operation

## 4.1 Display



Figure 4.1-1

## 4.2 Indicator Lights

Yellow

## For Non-WiFi type

Light on indicates the inverter is electrified;

Light off indicates the inverter is not electrified.

## For WiFi type

Light flashes on 1sec off 1sec indicates the WiFi module doesn't connect to the WiFi network; Light flashed on 2.5sec off 2.5sec indicates the WiFi module connect to the WiFi network but cannot send data to Web Server; Always on indicates communication between Web Server is ok.

• Green

Light on indicates the inverter is feeding power;

Light off indicates the inverter is not generating power at the moment.

Slow flicking (1HZ) indicates the inverter is self-checking;

Fast flicking (5HZ) indicates the inverter has finished self-

checking and is ready for grid integration.

Red

Light on indicates abnormal conditions;

Light off indicates normal condition.

## 4.3 LCD Display

A A schematic of the display screen is shown below:



Figure 4.3-1

**B** Display area

The display area is divided into top, middle and bottom areas.

TOP AREA

• The top area displays the status information.

"Waiting" indicates the inverter is on standby for power generation;

"Checking 30S" indicates the inverter is self-checking, counting down and preparing for power generation (checking time is based on safety, and varies from country to country);

"Normal" indicates the inverter is generating power.

If any condition of the system is abnormal, the screen will display an error message; please then refer to Table 4.4-1.

▶ By pressing the key successively, the display in this top area of the screen will scroll through different information, such as

operation parameters and power generation status. More guidance on navigating through the menus is given in C to H below.

#### MIDDLE AREA, LEFT

- The electrical connections on the DC side and the AC side are represented by dashed and full lines.
- A flashing dashed line on DC side indicates the PV panel is feeding power to the inverter.
- Nothing showing on AC side means the grid is not available;
- A full line on the AC side means the grid is available, but the inverter is not generating power ;
- A flashing dashed line on the AC side indicates the inverter is feeding power to the grid network.

## MIDDLE AREA, RIGHT

In this area, a histogram is used to represent the hourly average power generation from 4 a.m. to 8 p.m. for the day. A full column for average power represents the nominal power of system.

#### BOTTOM AREA

The bottom area displays total power generation, daily power generation, power being generated at present, and time information, as described below.

Part	Description
E-TOTAL	Gross power generated from the first use of the inverter. The initial unit is "kWh"; when power generation exceeds 999.9kWh, the unit changes to "MWh".
E-DAY	Power generated for the day
POWER	Present power generation of the system
TIME	Current system time

About the settings of field adjustable setpoints shall be accessible from communications port.

#### C Key operation

There are 2 modes of key operation: Short press, Long press for two seconds (2S).

## **D** Key operation and LCD description

Key operation is mainly for language and time setting; however a variety of other information is also available through key operation.

The menu, shown in the LCD display area has two levels. Short and long key presses will take you between menus and through each menu, as shown below, in Fig. 4.3-2.



Figure 4.3-2

Items in the first level menu that have no second level are locked. For these items, when the key is pressed for two seconds, the LCD will display the word "Lock" followed by data relating to the first level menu item. The locked menu can only be unlocked under system mode switching, fault occurrence or key operation.

In all levels of menu, if no action is taken for 20 seconds, the backlight of the LCD display will switch off, the display will automatically revert to the first item of the first level menu, and any modifications made to the data will be stored into internal memory.

#### E Menu Introduction

#### Status display

#### **Inverter status**

When the PV panel is feeding power to the inverter, the screen shows the first-level menu.

The initial display is the first item of the first level menu, and the interface displays the current status of the system. It shows "Waiting" in the initial state; it shows "Normal" during power generation mode; if there is something wrong with the system, an error message is shown. Please then refer to Table 4.4-1.

# View PV voltage, PV current, grid voltage, current and frequency:

- Short press the key to enter the Vpv menu which displays the PV voltage in "V".
- Short press the key to enter the Ipv menu which displays the PV current in "A".
- Short press the key to enter the Vac menu which displays the

grid voltage in "V".

- Short press the key once more to enter the Iac menu which displays the grid current in "A".
- Short press the key once more to enter the Frequency menu which displays the grid frequency in "Hz".

## View Error code

Short press the key once more to enter the Error Code History menu.

Long press (2S) the key to enter the second level menu of error detection. The last three inverter error records will be shown by short pressing the key in this second level menu. The records include error codes (ECODEXX) and error times (e.g. 2011-03-16 15:30). Error codes and their related faults can be found in Table 4.4-2.

## View model name and software version:

- From the Error Code History item in the first level menu, short press the key once to see Model Name.
- Short press the key once more to enter the software version menu which shows the current software version used.

## Settings:

## Set language:

Short press the button to enter the Set Language menu. Long press (2S) the key to enter the second level menu. Short press to

browse the languages available. The inverter will store the chosen language after 20 seconds of no operation.

#### Set time:

- From the first level Set Language menu, short press the key to enter the Set Time menu.
- ► Long press (2S) the key to enter the second level menu. The initial display is "2000-00-00 00:00", in which the first four numbers represent the year (e.g. 2000~2099); the fifth and sixth numbers represent the month (e.g. 01~12); the seventh and the eighth numbers represent the date (e.g. 01~31). The remaining numbers represent the time.
- Short press to increase the number in current location, and long press to move the cursor to next position. The inverter will store the time after 20 seconds without any key operation, and the LCD will automatically return to the main menu and the backlight will switch off.

#### Set protocol:

The function is only used for service personnel, set wrong protocol could lead to communication failure.

From the first level Set Time menu, short press the key once to enters set protocol display menu. Press the key for 2S to enter the second level menu. The circulatory submenu including two protocols can be found. The protocol can be chosen by short pressing the key. The inverter will store the chosen protocol without any action within 20S and LCD display will automatically return to main menu when the backlight is off.

#### **Reset Zigbee ID:**

The function is only available for Zigbee model inverter. When the communication between inverter and EzBee is failed, please try to reset ZigBee ID.

Press the key until the LCD displays "Zigbee ID Reset", then Long press (2S) until the LCD displays "ID Resetting ...". Stop pressing and wait for the screen showing "ID Reset Successful" or "ID Reset Failed".

#### WiFi Reset & WiFi Reload

The two functions are only available for WiFi model inverters. WiFi reload function is used to change the WiFi configuration to default value. Please configure the WiFi again as 3.4.5 after using the function.

- Press the key until the LCD displays "WiFi Reset", then long press (2S) until the LCD displays "WiFi Resetting...". Stop pressing and wait for the screen showing "WiFi Reset Successful" or "WiFi Reset Failed".
- Press the key until the LCD displays "WiFi Reload", then long press (2S) until the LCD displays "WiFi Reloading...". Stop pressing and wait for the screen showing "WiFi Reload

Successful" or "WiFi Reload Failed".

#### **MPPT function for Shadow:**

The default setting for shadow optimizer is disabled.

Please enable shadow optimizer when there is shadow on PV panel. The function could help the system generate more power under shadow condition.

Please do not enable the function when there's no shadow on panel. Otherwise it could lead to generate less power

Press the key until enter Shadow Optimize menu. When it shows "Shadow Optimized Off", it means the MPPT function for shadow is switched off. Press the key 5s to enable the function. If it shows "Shadow Optimized On" it means the shadow optimizer is on. Press the key 5s to disable the function.

## 70% Rated power limit

The function could only be available for inverter in German. It could only be used by network operator. Otherwise it will cause the PV plant generated reduced.

Press the key until enter 70% rated power menu. If it shows "70% Rated Enable" it means the function to limit the inverter working under 70% rated output is switched off. Pressing key 5s will switch this function on. If it shows "Recover Rated Power" it means inverter is working under 70% of rated output power. Press key 5s will recover inverter to 100% of its rated output power.

- **F** Operation of Display when commissioning.
- ➤ When the input voltage reaches the inverter turn-on voltage, the LCD starts to work, the yellow light is on and the LCD displays "Waiting". More information will be displayed within a few seconds. If the inverter is connected to the grid, "Checking 30" will be displayed and a countdown will commence from 30 seconds. When it shows "00S" you will hear the relay triggered 4 times. The LCD will then display "Normal". The instant power output will be shown at the left bottom of the LCD.
- G Sound Control

Knock at the cover of the inverter, the first level menu can turn from one to another, One knock like one short press on the key. However, it is not possible to enter second-level menu.

- **H** Auto test (only for users in Italy)
- When the inverter is turned on, press the key beside the LCD panel; go to the list of "Auto Test", long press the key for 2 seconds will take you to "Auto Test Result". Long press the key for 2 seconds and the auto test history will show on the LCD.
- From "Auto Test Result", short press the key to go to "Auto Test Start". Long press (2S) the key for 2 seconds; the interface will show the grid voltage upper intervention thresholds: "Limit

V=276V T=100ms". After 3 seconds the auto test will start. Voltage intervention thresholds vary with a ramp of 0.05Vn/s. The LCD will show the upper limits and trip time after the upper intervention threshold is tripped.

Short press the key to test the grid voltage lower intervention thresholds; the LCD will show "LV=187.0V T=200ms". After 3 seconds the auto test will start. Follow the same steps to finish the upper and lower frequency tests. The frequency intervention thresholds vary with a ramp of 0.05Hz/s.

- During the test, the backlight is always on and the key can't execute any command. After finishing the last item, if 4 auto test items all pass, the inverter will exit the test mode and reconnect to the grid automatically. If the auto test shows a fault, the inverter can't be restored to operating condition until auto test passes.
- In each test item, the result will show as below:

Maximum voltage check

Threshold value

Lim V=276V T=100mS (The limit value will show before

starting each test, after 2s the test will start.)

Result

HV=273.0V T= 60ms Y

## PASS

Minimum voltage check

Threshold value Lim V=184V T=200mS Result LV=187.0V T=160ms Y

## PASS

Maximum frequency check

Threshold value

Lim F=51Hz T=100mS

Result

HF=50.97Hz T=160msN

FAIL (Example of fail)

Minimum frequency check

Threshold value

Lim F=49Hz T=100mS

Result

LF=49.03Hz T= 60ms Y

## PASS

• The test result will be stored in auto test results.

## 4.4 Error messages

An error message will be displayed on the LCD if a fault occurs.

Table 4.4-1 Description of Error Message

Error message	Description
Utility Loss	Grid disconnected
Fac Failure	Grid frequency no longer within permissible range
Consistent Failure	Machine parameter consistent fault
Device Failure	Device internal fault
PV Over Voltage	Overvoltage at DC input
Over Temperature	Overtemperature on the case
Isolation Failure	Ground insulation impedance is too low
Ground I Failure	Overhigh ground leakage current
Relay-Check Failure	Relay self-checking failure
DC Injection High	Overhigh DC injection
EEPROM R/W Failure	Memory chip failure
SCI Failure	Internal communication failure
DC Bus High	Overhigh BUS voltage
Ref 2.5V Failure	2.5V reference voltage failure
AC HCT Failure	Output current sensor failure
GFCI Failure	Detection circuit of ground leakage current failure
Vac Failure	Grid voltage no longer within permissible range

Second level menu error codes

Table 4.4-2Description of Error Code

Error	Description
Code	

01	Communication between microcontrollers is failing		
02	EEPROM cannot be read or written		
03	The master-frequency is out of tolerable range		
04	The slave-frequency is out of tolerable range		
05	NA		
06	NA		
07	Relay has failed		
08	NA		
09	Different value between Master and Slave for grid voltage		
10	Different value between Master and Slave for grid frequency		
11	NA		
12	Different value between Master and Slave for Fac, Uac		
13	The DC injection check for grid Current has failed		
14	Isolation resistance of PV-plant out of tolerable range		
15	Master-grid voltage measurement-value out of tolerable range		
16	Fan Lock		
17	Pv input voltage is over the tolerable maximum value		
18	NA		
19	Over temperature fault		
20	NA		
21	Dc bus fault		
22	Ground current is too high		
23	Grid voltage =0		
24	NA		
25	Device Fault		
26	Dc Bus voltage is too high.		

27	NA
28	Different value between Master and Slave for GFCI
29	Different value between Master and Slave for output DC current
30	The 2.5V DSP reference inside are abnormal
31	The DC output sensor is abnormal
32	The GFCI detecting circuit is abnormal

## **5** Technical Parameters

## Table5.1 GW3600-DS, GW4200-DS, GW4600-DS, GW5000-DS

Model Name	GW3600-DS	GW4200-DS	GW4600-DS	GW5000-DS
DC input data				
Max. PV-generator power [W]	3800	4600	5400	5400
Max. DC Voltage [V]	580	580	580	580
MPPT voltage range [V]	125~550	125~550	125~550	125~550
Turn on DC Voltage [V]	125	125	125	125
Turn off DC Voltage [V]	90	90	90	90
Max. DC work current [A]	2*10	2*15	2*15	2*15

Isc PV [A]	2*15	2*20	2*20	2*20
Max Inverter backfeed current to the array[A]	0	0	0	0
Number of DC connection	2	2	2	2
Number of MPP trackers	2	2	2	2
DC-connection	MC IV Connector			
Standby power consumption [W]	5	5	5	5
Night power consumption [W]	0	0	0	0
Output data				
Nominal AC power [W]	3600	4200	4600	4600
Max.AC power [W]	3600	4400	5100	5000
Max.output current[A]	18	21	25	25
Inrush current[A]	0	0	0	0
Max. output fault current[A]	35	35	43	43
Max output	35	35	43	43

overcurrent protection[A]				
Nominal AC output	50/60Hz; 230Vac			
AC output range	45~55Hz/55~65Hz; 180~270Vac			
THD(AC output current)	<2%			
Power factor	0.90leading0.90lagging			
AC Connector	Single phase with clamps			
Efficiency				
Max. efficiency	97.6%	97.8%	97.8%	97.8%
Euro efficiency	>96.5%	>97.4%	>97.4%	>97.4%
MPPT adaptation efficiency	>99.5%	>99.5%	>99.5%	>99.5%
Safety equipment				
DC reverse polarity protection	Integrated (with diode)			
Leakage current monitoring unit	Integrated			
AC short protection	Integrated			
DC switch- disconnector	Option			
Islanding protection	AFD			

Grid Monitoring Normative referen	According to VDE-AR-N 4105, AS4777.2/.3, RD1699, G83/1, G59/2, 62109-2, VDE0126-1-1+A1, EN50438, MEA, PEA	
EMC compliance	According to EN 61000-6-1,EN 61000-6-2,EN 61000-6- 3,EN 61000-6-4	
Safety compliance	According to IEC62109-1, AS3100	
General data		
Dimensions (WxHxD) [mm]	390*417*165	
Net Weight [kg]	20	
Environmental category	outdoor and indoor	
Mounting information	Wall bracket	
Ambient temperature range	-20~60°C (up 45°C derating)	
Relative humidity	0~95%	
Site altitude (max.)	2000m	
Wet locations classification	4K4H	
UV exposure rating	F1	

AC Overvoltage category (note2)	Ш
DC Overvoltage category	Π
IP protection type	IP65
AC Over voltage category	Category III
DC Over voltage category	Category II
Protective Class	Class 1
Topology	Transformerless
Cooling concept	Natural convection
Noise level	<25dB
Display	4" LCD
Data communication	USB 2.0; RS485 or WiFi
Standard warranty	5/10/15/20/25(optional)

## Table5.2 GW3600D-DK/UK

Model Name	GW3600D-DK/UK		
DC input data			
Max. PV-generator power [W]	4200		
Max. DC Voltage [V]	580		
MPPT voltage range [V]	125~550		
Turn on DC Voltage [V]	125		
Turn off DC Voltage [V]	90		
Max. DC work current [A]	2*10		
Max. PV array short current[A]	2*15		
Max Inverter backfeed current to the array[A]	0		
Number of DC connections	2		
Number of MPP trackers	2		
DC-connection	MC IV connector		
Turn on power [W]	<5		
Night Power [W]	0		
Output data			
Nominal AC power [W]	3600		
Max.AC power [W]	4000		

Max. output current[A]	16	
Inrush current[A]	0	
Max. output fault current[A]	35	
Max output overcurrent protection[A]	35	
Nominal AC output	50/60Hz; 230Vac	
AC output range	45~55Hz/55~65Hz; 180~270Vac	
THD(AC output current)	<2%	
Power factor	~1	
AC Connector	Single phase with clamps	
Efficiency		
Max. efficiency	97.6%	
Euro efficiency	>96.5%	
MPPT adaptation efficiency	>99.5%	
Safety equipment		
DC reverse polarity protection	Integrated (with diode)	
Leakage current monitoring unit	Integrated	
AC short protection	Integrated	
DC switch disconnector	Option	
Islanding protection	AFD	
Grid Monitoring	G83/1(For UK), VDE0126-1-1+A1 , EN 50438(For DK)	
Normative reference		
---------------------------------	---	
EMC- compliant according to	EN 61000-6-1, EN 61000-6-2, EN 61000-6-3, EN 61000-6-4	
Safety compliance	According to IEC62109-1	
General data		
Dimensions (WxHxD) [mm]	390*417*165	
Net Weight [kg]	18	
Environmental category	outdoor and indoor	
Mounting information	Wall bracket	
Ambient temperature range	-20~60°C (up 45°C derating)	
Relative humidity	0~95%	
Wet locations classification	4K4H	
UV exposure rating	F1	
AC Overvoltage category (note2)	III	
DC Overvoltage category	II	
Site altitude (max.)	2000m	
IP protection type	IP65	
AC Over voltage category	Category III	
DC Over voltage category	Category II	
Protective Class	Class 1	

Topology	Transformerless
Cooling concept	Natural convection
Noise level	<25dB
Display	4" LCD
Data communication	USB2.0; RS485 or WiFi
Standard warranty	5/10/15/20/25(optional)

Note: For equipment or circuits energized from the MAINS, four categories are considered:

• category IV applies to equipment permanently connected at the origin of an installation (upstream of the main distribution board). Examples are electricity meters, primaryovercurrent protection equipment and other equipment connected directly to outdooropen lines.Outdoor PCE connected downstream of the main distribution board is not considered OV category IV.

• category III applies to equipment permanently connected in fixed installations(downstream of, and including, the main distribution board). Examples are switchgear and other equipment in an industrial installation;

• category II applies to equipment not permanently connected to the fixed installation.Examples are appliances, portable tools and other plug-connected equipment;

• category I applies to equipment connected to a circuit where measures have been taken to reduce transient overvoltages to a low level.

## 6 Certificates



### 7 Warranty

#### 7.1 Warranty Period

GoodWe provides a standard warranty of 5 years for DS series products (warranty period begins from the date on purchase invoice). Additional provision will be subject to contract.

#### 7.2 Warranty Card

The warranty card and purchase invoice should be properly kept for the product warranty period. Meanwhile, the nameplate on products shall be kept clearly visible. Otherwise GoodWe may reject warranty service or only provide paid service.

#### 7.3 Warranty Conditions

According to the GoodWe product description and instructions, if a device becomes defective within the warranty period, and it is proved that further functional performance is impossible due to a problem with product quality, the device will be, as decided by GoodWe:

- A Returned to the factory for maintenance; or
- **B** Repaired onsite; or
- C Replaced (If the original model is no longer produced, GoodWe will provide a replacement device of equivalent value according to model and age.

### 7.4 Scope of Warranty

Warranty is not valid in the following situations:

- Products or fittings exceed warranty period (excluding and warranty extension agreement signed beforehand).
- Fault or damage is caused by improper operation or not following the user manual, product instructions or relevant safety regulations.
- Insufficient ventilation of the unit.
- Fault or damage due to improper installation, repair, change or removal by persons who are not authorized by GoodWe.
- Fault or damage due to unpredictable accidental factors, human errors or force majeure.
- Fault or damage unrelated to product quality.

# 8 Contact

If you have any enquiries or technical problems concerning a GoodWe DS series inverter, please contact our customer services.

Address: No.189 Kun Lun Shan Road, Suzhou New District, Jiangsu, China (Jiangsu GoodWe Power Supply Technology Co., Ltd.) Tel: + 86 512 6239 6771 Fax: + 86 512 6239 7972 E-mail: service@goodwe.com.cn Website: www.goodwe.com.cn