

INTELLIGENT  
PANEL  
METERS

Series

FEMIA ELECTRÓNICA

## Intelligent Panel Meters



TAS-1-IAC	AC Current
TAS-1-IDC	DC Current
TAS-1-VAC	AC Voltages
TAS-1-VDC	DC Voltages

USER'S MANUAL

## 1.1-INDEX

1.- Introduction	
1.1.- Index	2
1.2.- If this is the first time you work with a TAS-1 meter	3
1.3.- Frontal View and Rear View of the instrument	3
2.- Quick Reference Guide	
2.1.- Connections	4
2.2.- Programming Menu	4
3.- Configuration	
3.1.- Input Signal	5
3.2.- Direct Access	
3.2.1- Decimal Point Position	5
3.2.2- Adjusting the Low Indication	5
3.2.3- Adjusting the High Indication	5
3.2.4- Alarm Setpoints	5
3.2.5- Correcting a Low Input Signal	5
3.2.6- Correcting a High Input Signal	5
4.- Advanced Configuration	
4.1.- Input Signal for : DC Voltage	6
4.2.- Input Signal for : AC Voltage	6
4.3.- Input Signal for : DC Current	6
4.4.- Input Signal for : AC Current	6
4.5.- Alarm Configuration	6
4.6.- Manual Adjustment	7
4.7.- Dealing with Errors	7
4.8.- Advanced Indication	7
4.9.- Blocking the Keypad	7
4.10.- Resetting the system. Default values	7
4.11.- Messages and Errors	8
5.- Configuring with a PC	8
6.- Technical Specifications and Dimensions	9
7.- Available Options .- Installing and Configuring	10
7.1- Analog Output - TSAT Option Board	10
7.1.1- Connections	10
7.1.2- Technical Characteristics	10
7.1.3- Start-Up	10
7.1.4- Configuration	11
7.2- Installing the option boards	11
7.3- Modbus Output - R485M Option Board	12
7.3.1- Configuration	12
7.3.2- Accepted Functions	12
7.3.3- Register Map	12
7.3.4- Connections and Bus Terminator	13
7.3.5- Modbus frame structure-I	13
7.3.6- Character Structure	13
7.3.7- Modbus frame structure-II	13
7.4- Peak, Valley, Hold, Tare, Reset - TEK Option Board	14
7.4.1- Available Functions	14
7.4.2- Connections	14
7.4.3- Configuration	14
8.- CE Certificate / Warranty	15
9.- Safety Information	15

## 1.2- IF THIS IS THE FIRST TIME YOU WORK WITH A TAS-1 METER...

We strongly recommend you to read the following paragraphs. Following ideas need to be clearly understood in order to easily adjust and program the unit.

WHEN POWERING THE INSTRUMENT the meter displays a message indicating the configured signal input range (see page 4).

IF THE TAS-1 DETECTS A STRANGE SITUATION on the instrument status, or sensor break, etc, the instrument will show an error message (see page 8 «messages and errors»).

THE FRONTAL KEYPAD is composed of 5 function/key pads and 1 programming pad. The pads have two functions, acting both as number keys (when a number needs to be entered) and as direct access keys to the following functions :

- Key AL - Access to the ALARM setpoints
- Key HI - Value for the HIGH Indication
- Key LO - Value for the LOW Indication
- Key ADJ - Access to the automatic «on the field» offset correction and High Level Input Signal correction
- Key DP - Decimal Point Position
- Key PROG - Allows the introduction of the PROGRAMMING codes (4 digit codes, as shown on page 4). These codes, when validated, activate different input signal modes, and advanced configurations for alarms, indication, etc.

«TIME» MESSAGE .- If while introducing a programming code or while reconfiguring the unit parameters (such as the alarm setpoints or others) the user does not interact with the unit for a period of 5 seconds, the TAS-1 will show the message «TIME», cancel the ongoing changes, and roll-back to the previous configuration. This is a security function which disables the situation where a unit would be «hanged» for a long time waiting for the operator to finish a programming.

THE TAS-1 UNITS ARE FULLY CONFIGURABLE. The unit is 100% configurable from the frontal keypad. The programming software also allows an easy configuration from a PC (*PCConnection Cable needed*).

OPTIONS .- This manual includes description and operating instructions for the basic unit and the additional extra options accepted. These options include Relay Output Contacts, Analog Outputs, RS485 Outputs, Peak/Valley memory, etc. If your instrument does not include these options, they can easily be added.


SIGNAL INPUT RANGES .- To work with an input signal range not indicated in this manual, select the closest input signal range accepted, and change the input/indication parameters with the code 14 11 (see later in this manual). For example, to configure a 0/60 mV input coming from a 10 Amper shunt, we need to :

- 1.- select the 0/100 mV input signal range
- 2.- enter on code 14 11 for Editing Adjustments
- 3.- edit 0=0 and 60=10.000


If later on we need to change the 10.000 value for any other value we can do it directly with the keypad HI.

## 1.3- FRONTAL VIEW AND REAR VIEW

TAS-1 Frontal View




TAS-1 Rear View




Note .- The 2 relay outputs and the Optional Boards are OPTIONAL and are NOT INCLUDED with the basic unit.

## 2.1- CONNECTIONS

	<b>TAS-1-VDC</b>	<b>TAS-1-VAC</b>
	0/650 Vdc 0/100 Vdc 0/10 Vdc	0/650 Vac 0/100 Vac
	0/1 Vdc 0/100 mVdc 0/20 mVdc	0/1 Vac 0/100 mVac
	0/5 Adc 0/100 mAcd	0/5 Aac 0/100 mAac



## 2.2- PROGRAMMING MENU



**\* IMPORTANT:**  
Before validating a PASSWORD with the Keypad Blocking menu, remember the 5 digit number you are about to enter. The instrument will not accept any future order until the same 5 digit password is reintroduced.

## 3- CONFIGURATION

Section 3.1 shows how to enter a code to select an input signal range. All codes are indicated on page 4.

Examples in this page show how to configure a TAS-1-IAC unit with an input signal of 0/5 Aac and indication 0/2500.0. All other units and signal ranges follow the same procedures.

### 3.1- INPUT SIGNAL

The TAS-1 units have several built-in predefined input signal ranges, selectable with the help of codes (4 digit codes). On page 4 there is a list of all accessible ranges and the codes associated.


### 3.2- DIRECT ACCESS

The frontal keypad has several direct access buttons for a quick configuration of the instrument :

- Pad 1 (ADJ) - Correct the LOW or HIGH input levels
- Pad 2 (DP) - Decimal Point Position
- Pad 3 (LO) - Set for the LOW indication level
- Pad 4 (HI) - Set for the HIGH indication level
- Pad 5 (AL) - Alarms Setpoint

### CONFIGURING A 0/5 AAC INPUT SIGNAL RANGE (Code 11 41 ; as shown on table on page 4, for a TAS-1-AAC unit)

- 1- Press message «Prog» during 1 second blank screen
- 2- Input the code 11 41
- 3- Validate the code pressing
- 4- Message showing the selected range «5 A» during 1 second




#### 3.2.1- DECIMAL POINT POSITION

Activate the Decimal Point at position XXXX.X

- 1- Press DP
- 2- message «DP» during 1 second  
Press 2 to fix decimal point position 2  
(To fix at other positions, press 1,2,3,4 or 5)
- 3- Validate changes pressing

message «INPUT» shows the configuration has been accepted




#### 3.2.4- ALARM SETPOINTS

Fix the setpoint for Alarm1 at 10500

- 1-Press AL
- 2-Enter the number of the alarm we want to modify 1
- 3-Current value for Alarm1 setpoint is displayed. Modify it by pressing on 1,2,3,4,5 until we see 10500
- 4-Validate the changes pressing

message «INPUT» shows the configuration has been accepted




#### 3.2.2-ADJUSTING THE LOW INDICATION VALUE

For the low input level (0 Aac) we want to configure a low indication of 0000.0

- 1-Press Lo
- 2- Current value for the low indication is displayed. Modify it by pressing on 1,2,3,4,5 until we see 00000
- 3-Validate the changes pressing

message «INPUT» shows the configuration has been accepted




#### 3.2.5-CORRECTING THE LOW INPUT SIGNAL (OFFSEET)

Allows offset correction, by linking the current input signal on terminals to the Low Indication Value memorized.

- 1-Generate the low input level signal
- 2-Press Adjust  
The instrument asks «Hi» or «Lo» ?
- 3-Press Lo

4-Message «Cr Lo» shows the unit has corrected the low level value, linking the current input signal value to the low indication value memorized (LO keypad)




#### 3.2.3- ADJUSTING THE HIGH INDICATION VALUE

For the high input level (5 Aac) we want to configure a high indication of 2500.0

- 1-Press Hi
- 2- Current value for the high indication is displayed. Modify it by pressing on 1,2,3,4,5 until we see 25000
- 3-Validate the changes pressing

message «INPUT» shows the configuration has been accepted




#### 3.2.6-CORRECTING THE HIGH INPUT SIGNAL

Allows to link a current signal at the input terminals to the High Indication Value memorized on the HI keypad.

- 1-Generate the high input level signal
- 2-Press Adjust  
The instrument asks «Hi» or «Lo» ?
- 3-Press Hi

4-Message «Cr Hi» shows the unit has corrected the high level value, linking the current input signal to the high indication value memorized (HI keypad)



## 4-ADVANCED CONFIGURATION

### 4.1- INPUT SIGNAL : DC VOLTAGE

Codes : 11 XX

Input	Code	Message
0/650 Vdc	11 24	650U
0/100 Vdc	11 23	100U
0/10 Vdc	11 22	10U
0/1 Vdc	11 11	1U
0/100 mVdc	11 12	1000U
0/20 mVdc	11 13	200U

### 4.2- INPUT SIGNAL : AC VOLTAGE

Codes : 11 XX

Input	Code	Message
0/650 Vac	11 32	650RU
0/100 Vac	11 31	100RU
0/1 Vac	11 14	1RU
0/100 mVac	11 15	1000RU

### 4.3- INPUT SIGNAL : DC CURRENT

Codes : 11 XX

Input	Code	Message
0/5 Adc	11 35	5Ab
0/100 mAcd	11 33	1000Ab

### 4.4- INPUT SIGNAL : AC CURRENT

Codes : 11 XX

Input	Code	Message
0/5 Aac	11 41	5Aa
0/100 mAac	11 34	1000Aa

## 4.5- ALARM CONFIGURATION

Alarm Number	CODE	Menu
Alarm 1	13 11	Alarm Parameters
Alarm 2	13 12	Alarm Parameters
Alarm 3	13 13	Alarm Parameters
Alarm 4	13 14	Alarm Parameters
General	13 15	Hysteresis and SM

The alarm configuration menu list several parameters to which we must assign a value.

Numerical values are assigned with the number pads. Predefined values (such as ON/OFF) are selected by selecting available options with keys '1', '2' or '3'.

Validate with key 'J' in order to access next parameter.

#### Menu : Alarm Parameters

Parameters	Values	Description
RL 1	ON OFF	Alarm1 working Alarm1 not working
TYPE	RL HI RL LO	Alarm1 working as «maximum» Alarm1 working as «minimum»
RL - 1	88888	Setpoint for Alarm1 (expressed in display points)
HIST	88888	Hysteresis value (max. 255) (expressed in display points)
dL 1	88888	Delay on relay activation (expressed in seconds)
LED	dir INU	Led is active when alarm is active Led is active when alarm is inactive
TEXT	ON OFF	Alarm text active Alarm text inactive
STROG	88888	Text associated with alarm led

#### Menu : Hysteres and SM

Parameters	Values	Function
HIST	LEFT	Hysteresis is applied to the process of alarm deactivation*
	CENTER	Band alarm. Hysteresis is applied to the process of alarm activation and deactivation*
	RIGHT	Hysteresis is applied to the process of alarm activation.*
		*The hysteresis points are defined on parameter HYST for each alarm.
SMODE	ON	Security Mode activated on alarms acting as «minimum»**
	OFF	Security Mode deactivated
		**Output relay are inactive until the set point is reached for the first time.

## 4.6- MANUAL ADJUSTMENT

Code : 14 11      Function : *Edt*

Parameters	Values	Function
<i>In Lo</i>	number	<i>Input Low</i> - Low Input Signal
<i>dI Lo</i>	number	<i>Display Low</i> - Indication for Low Signal
<i>In Hi</i>	number	<i>Input High</i> - High Input signal
<i>dI Hi</i>	number	<i>Display High</i> - Indication for High Signal

Code 14 11 can be used both to modify adjustments and to visualize current values.

## 4.7- DEALING WITH ERRORS

Code : 14 14      Function : *onErr*

Parameters	Values	Function
<i>onErr</i>	<i>on</i>	Activates all alarms in case of error state *
	<i>off</i>	Deactivates all alarms in case of error state*

\* More information on «what is an error», on section 4.7 «Messages and errors»

## 4.8-ADVANCED CONFIGURATION

Code : 14 13      Function : *dISPL*

Parameters	Values	Function
<i>nuLL</i>	<i>on</i>	No zeros active to the left
	<i>off</i>	Zeros active to the left
<i>LRSt</i>	<i>on</i>	Fixes the least significant digit to zero
	<i>off</i>	Frees the least significant digit
<i>FiLt</i>	<i>FiL1</i>	Fast filter on the input signal : 0.25 Seg 98%
	<i>FiL2</i>	Medium filter on the input signal : 0.5 Seg 98%
	<i>FiL3</i>	Slow filter on the input signal: 1 Seg. 98%
<i>AdRn</i>	<i>rEAL</i>	Real time indication
	<i>AUErR</i>	Indication of mean values
<i>StEP</i>	<i>88888</i>	Time (between 1 and 255 seconds) to calculate mean values for mean indication

## 4.9- BLOCKING THE KEYPAD

Code : 14 15      Function : *PRSSUWord*

Parameters	Values	Function
<i>PRSSUWord</i>	<i>00000</i>	Blocks the frontal keypad Password is made of a numerical value of 5 digits

## 4.10-RESETTING THE SYSTEM. DEFAULT VALUES

Code : 14 22      Function : *dEFLonfr*

Resets the unit to the default manufacturing values. It is needed to reconfirm the action by pressing INTRO after the message *dEFLonfr*

### General Default Configuration

Acquisition Mode	Real									
STEP Value	10									
Zero Blanking	ON	Alarm 1	ON	1000	1	0	H	DIR	OFF	AL-1
Least Significant Digit to zero	OFF	Alarm 2	ON	1000	1	0	H	DIR	OFF	AL-2
Display Refresh	Filter 2 (0.5 seg.)	Alarm 3	ON	1000	1	0	H	DIR	OFF	AL-3
Password	deactivated	Alarm 4	ON	1000	1	0	H	DIR	OFF	AL-4
		Hysteresis						CENTER		
		Security Mode						ON		
		OnError						OFF		

### Default Configuration TAS-1-VDC

Input Signal	0/100 VDC
Lo - Low Level Indication	0
HI - High Level Indication	100.00
Decimal Point	0 0 0.0 0

### Configuration TAS-1-IDC

Input Signal	0/5 ADC
Lo - Low Level Indication	0
HI - High Level Indication	5.000
Decimal Point	0 0.0 0 0

### Default Configuration TAS-1-VAC

Input Signal	0/650 VAC
Lo - Low Level Indication	0
HI - High Level Indication	650.0
Decimal Point	0 0 0.0 0

### Configuration TAS-1-IAC

Input Signal	0/5 AAC
Lo - Low Level Indication	0
HI - High Level Indication	5.000
Decimal Point	0 0.0 0 0



## 4.11-MESSAGES AND ERRORS

Messages and errors are active when the instrument senses a «not normal» situation. The instrument identifies the type of «anormality» and informs with an error or with a message.

### Messages

«Messages» are associated with non-critical situations, those which only affect the measure temporary. The «message» remains active on display until the situation clears. The instrument recovers the normal working state when situation clears.

**LOW** The input signal is lower than selected range

**HIGH** The input signal is higher than selected range

**TIME** Security waiting time exceeded while in configuration mode. The instrument rolls-back to the previous configuration

**Error** Error when entering a data. Value not accepted. Reintroduce the value. (Typical case : The value assigned to hysteresis is higher than 255)

### Errors

«Errors» are associated with critical situations which disable the ability to measure the signal.

The «error» remains active on display until the situation disappears. At this time, the instrument recovers normal functionality.

«Errors» execute actions on alarms, activating or deactivating them depending on the status of variable OnErr (see page.11). Alarms recover their normal behaviour when the the error state clears.

**Error** Internal Error. Restart the instrument.  
\*\* It is possible that no action is performed on alarms if this error is affecting the internal EPROM

**NErr0** Mathematical Error 0  
Parameters introduced for the input signal are not coherent. (Typical case : the high level value is similar or very close to low level value, on input signal range or indication)

**NErr1** Mathematical Error 1: mathematical overflow.  
The unit is trying to process values higher than 32000 or lower than -32000.

**dError** Error on Display Indication  
Trying to display a value higher than 32000 or lower than -19999. Reduce HI and LO levels dividing by 10.

## 5- CONFIGURING WITH A PC

TAS-1 units allow configuration from a PC. You need software SW-TAS-1 and the cable PCConnector. Cable is connected to the rear side of the instrument (stereo jack) and to the 9-pin SUB-D PC Port. Software installs executable file TAS-1.exe

- 1.- Select com port. Press «START COMM»
- 2.- Configuration windows open

These windows contain all information on the unit. Meter and alarms are shown on the main window. Additional options are shown in the small window to the right.


To force a writing onto the device press WRITE\_D. Some changes already force a writing (such as changing the input signal), and ask for a confirmation.

To force a configuration reading of the instrument press READ\_D

To save/load configurations on your hard disk, use buttons SAVE\_F / READ\_F. Note that the options (right windows) have their own configuration file independent of the main instrument and so have their own «SAVE TO FILE» / «LOAD FROM FILE» buttons.

COM Selection  
«START COM» Button

«WRITE\_D» Button  
Forces writing configuration to the instrument



Options Configuration Window

Signal/Display adjustments

Input Signal Ranges



## 6- TECHNICAL SPECIFICATIONS

### INDICATION

Display	5 Digits, 7 Segments , Red Led High Brightness
Digit Height	14,2 mm. / 0,56"
Filter	Anti-reflexive.
Indication	From - 19999 to 32000
Refresh	5 /seg. (Filter selectable)

### A/D CONVERTER

Speed	14 Readings / Second
Accuracy	16 BIT + sign ( $\pm$ 65.000 points)
CMRR	> 130 dB

### POWER

Standard	230 Vac 50/60 Hz. Consumption 3,5W Max
Optional	115 Vac 50/60Hz. Consumption 3.8W Max
Optional	24 Vdc ( $\pm$ 10%) isolated. Consumption 4W Max
	Isolation 1000 Vdc (Primary - Secondary)
	Maximum consumption at 24 Vdc .- 265 mA
	Peak current at start-up <600mA

### ENVIRONMENTAL DATA

Working Temperature	0 ... + 50 °C
Storage Temperature	-20 ... + 85 °C
Humidity	0 ... 85%, non condensaded

### MECAHNICAL DATA

Dimensions	Standard 1/8 DIN 96 x 48 x 124 mm. (3,78" x 1.89" x 4,88")
Front	Protection IP65 (NEMA 4)
Weight	0,5 Kgs

### ALARMS AND RELAYS (OPTION AL2)

4 alarms on display. Alarms 1 and 2 can control Relays 1 y 2 (Option AL2)  
2 Relays ON/OFF 2 A. (non inductive), 250 Vac  
*Note .- AL2 option not mounted on standard units*

### ANALÓG OUTPUT

Technical data see page 10

### RS485 MODBUS OUTPUT

Technical data see page 12

### PEAK / VALLEY, ETC OPTION

Technical data see page 14

### UNIT TAS-1-VDC

Input Signal Ranges	0/650 Vdc, 0/100 Vdc, 0/10 Vdc 0/1Vdc, 0/100 mVdc, 0/20 mVdc
---------------------	---

*Note .- Although not mentioned above, the unit accepts any signal range between 0/20mV and 0/650Vdc, including 60mV, 100mV y150mV shunt signals. For these ranges. select the closest range and readjust with code 14 11*

Accuracy	0,1% from reading $\pm$ 1 point
Thermal Drift	$\pm$ 100 ppm/°C
Input impedance	1 MOhm for $V_{in}>1Vdc$ 5 MOhm for $V_{in}<1Vdc$
Effective Resolution	32.000 points

### UNIT TAS-1-IDC

Input Signal Ranges	0/5 Adc 0/100 mAcd
---------------------	-----------------------

*Note .- Although not mentioned above, the unit accepts any signal range between 0/100mA and 0/5 Adc. For these ranges. select the closest range and readjust with code 14 11*

Accuracy	0,1% of reading $\pm$ 1 point
Thermal Drift	$\pm$ 150 ppm/°C
Input impedance	0.02 Ohm for $I>100mA$ 1 Ohm for $I<100mA$
Effective Resolution	32.000 points

### UNIT TAS-1-VAC

Input Signal Ranges	0/650 Vac, 0/100 Vac 0/1 Vac, 0/100 mVac
---------------------	---

*Note .- Although not mentioned above, the unit accepts any signal range between 0/20mVac and 0/650Vac, including 60mV, 100mV y150mV shunt signals. For these ranges. select the closest range and readjust with code 14 11*

Accuracy	0,3% of reading $\pm$ 1 point
Thermal Drift	$\pm$ 150 ppm/°C
Input impedance	1 MOhm for $V_{in}>1Vdc$ 5 MOhm for $V_{in}<1Vdc$
Effective Resolution	32.000 points


### UNIT TAS-1-IAC

Input Signal Ranges	0/5 Aac 0/100 mAac
---------------------	-----------------------

*Note .- Although not mentioned above, the unit accepts any signal range between 0/100mAac and 0/5 Aac, including X/5 and X/1 Current Transformer signals. For these ranges. select the closest range and readjust with code 14 11*

Accuracy	0,3% of reading $\pm$ 1 point
Thermal Drift	$\pm$ 200 ppm/°C
Input impedance	0.02 Ohm for $I>100mA$ 1 Ohm for $I<100mA$
Effective Resolution	32.000 points

### SIZES AND PANEL CUT-OUT



## 7- AVAILABLE OPTIONS - INSTALLING AND CONFIGURING

### 7.1- ANALOG OUTPUT - TSAT OPTION BOARD

The TSAT board adds analog output capabilities to the TAS-1 instruments. Jumper selectable for voltage ( 0/10 Vdc) and for current (4/20mA and 0/20mA in modes SINK and SOURCE) adds a galvanic isolation of 2KVe<sub>ff</sub>.


The analog output adjustment is done via the frontal keypad. The analog output value is adjusted related to the display indication. This allows the intelligent use of the correction functions for offsets and fast readjustment of the TAS-1 series, meaning that when

readjusting the input/display readings, the analog output does not need to be readjusted most of the times.


in case of trouble with the input signal, such as loop break or sensor break, the analog output signal will exhibit always the same behaviour predefined by the operator on the menu.

#### 7.1.1- CONNECTIONS



**Voltage Output**   .- Terminal 12 (Negative)  
Terminal 13 (Positive)



**Current Output (Source = Active)**   .- Terminal 13 (Negative)  
Terminal 14 (Positive)



**Current Output (Sink=Pasive needs external power supply)**   .- Terminal 12 (Negative)  
Terminal 13 (Positive)




#### 7.1.2- TECHNICAL CHARACTERISTICS

Output Signals	0/10 Vdc, 0/20 mA and 4/20 mA (and others)
Resolution	12 bits
Accuracy	<0.1% FS
Ripple	<0.01% FS
Thermal Drift	100 ppm/°C
Pass Band	1.5 Hz (-3 dB)
Response Time	250 ms (99% of indication)
Isolation Levels	2KVe <sub>ff</sub> (50 Hz, 1 minute)


mA Output	RLmax	500 Ohms (Source Mode)
	Imax	21.5 mA aprox.
	SINK Output maximum 40Vdc on terminals	

Vdc Output	RL min	1 KOhm
	Vmax	11 Vdc aprox.

**Jumpers to the left.-  
Output in Vdc**



**Jumpers to the right.-  
Output in mA**



#### 7.1.3- START-UP

- 1.- Place jumpers on TSAT board for Vdc or mA output
- 2.- Plug the TSAT board on the bus pins (Expansion Bus) on board AL2 or EXP
- 3.- To configure the analog output you need to know the analog output signal and the related display indication

Note .- Analog output units are entered with 3 decimals, this is, in miliVolts and microAmperes.

4.- Make connections, power the unit and configure the board (see next page)

Input Signal	Indication	Analog Output
4 mA	0	0 Vdc (00000 miliVots)
20 mA	100.00	10 Vdc (10000 miliVolts)

## 7.1.4- CONFIGURING THE ANALOG OUTPUT

### Entering the Menu

Introduce the programming code «55 11»

Message «IC ANG» Analog Output board recognized  
 Message «MENU» Entering the programming menu  
 Message «4\_20» or «0 10» Shows the operating mode selected by jumpers (Vdc or mA)

### Adjusting the Analog Output

\*Note .- The values for the following 4 parameter are settable using keys 1,2,3,4,5

Parameter «d\_LO» (Display Low)  
 Display value associated with the low level analog output

Parameter «o\_LO» Output Low  
 Analog output value associated with the «d\_LO» value\*

Parameter «d\_HI» Display High  
 Display value associated with the high level analog output

Parameter «o\_HI» Output High  
 Analog output value associated with the «d\_HI» value\*


Note .- values for «d\_LO» and «d\_HI» are in microVolts or microAmperes

### Behaviour when Error

Parameter «OnErr» .- Behaviour of the analog output when an «error» occurs (section 4.11 describes «errors»)  
 «DIR» .- Analog Output rises up to Full Scale (11Vdc or 21mA aprox)  
 «INV» .- Analog Output sinks down to zero ( -0.5 Vdc or 0mA aprox)

### Exiting the Menu

Message «INPUT» Confirms that the parameters have been accepted  
 Message «ERROR» Informs that at least one of the values is not correct, and the whole configuration could not be applied. Repeat the process from the beginning.



## 7.2- INSTALLING THE OPTION BOARDS

The Option Boards are inserted onto the vertical pins of the Expansion Modules. These modules are AL2 or EXP.

Note .- Both AL2 and EXP are optional themselves and are not included in the standard units

The board has to be firmly inserted onto the vertical pins of the expansion module. Once inserted, reconnect the expansion module to the frontal of the instrument and insert the whole into the box.


The instrument automatically recognizes the presence of an inserted board.

Note1 : The expansion module is included with those instruments TAS-1 with the AL2 option built in or the EXP option. The AL2 or the EXP modules can be also added to those instruments who were acquired without any of these two options.

Note2 : The TEK board can share the expansion bus with the TSAT option of with the R485M option, or can be directly connected to the bus alone.

Nota3 : Boards TSAT for Analog Output and R485M for Modbus output can not be integrated simultaneously on the same instrument.

Option Board (Analog Output, Modbus or TEK)



## 7.3- MODBUS OUTPUT - R485M OPTION BOARD

The R485M board adds Modbus communication capabilities to the TAS-1 units, for retransmission of visualized data to a remote element. The board is isolated and is completely configurable from frontal keypad.

Protocols ModBus RTU and ModBus ASCII selectable  
 Bus RS485 Half Duplex (EIA-RS485) shielded twisted pair cable, in line, closed with terminator

### 7.3.1- CONFIGURATION


Introduce te programming code «55 11»  
 Message «IC 485» RS485 board recognized  
 Message «MENU» Entering the programming menu

Speed 2400, 4800, 9600, 19200, 38400 bauds  
 Addresses from 0 to 99  
 Distances 1200 meters per BUS segment  
 4800 meters with repeaters  
 Isolation 2 KV with input signal  
 3.5 KV with power signal

- Parameter «PROT» Protocol  
 Select Modbus ASCII or Modbus RTU
- Parameter «DIR» Address  
 Input instrument address
- Parameter «BAUDS» Speed in Bauds
- Parameter «n BIT» Number of Bits  
 Select 8 or 7 bits per character
- Parameter «t PAR» Parity  
 «Even» «Odd» «nPar»

Message «INPUT» .- confirms that the parameters have been accepted

Message «ERROR» .- informs that at least one of the values is not correct, and the whole configuration could not be applied. Repeat the process from the beginning.



### 7.3.2- ACCEPTED FUNCTIONS

04 Hex Registry read («Input Register» on the standard)

### 7.3.3- REGISTER MAP


00 00 Hex Display Value  
 Type : Integer  
 Value : from -32768 to 32767

00 01 Hex Decimal Point Position  
 Type : Integer  
 Value : 0, 1, 2, 3 or 4

Note1 : If there is no numeric value on display (but a text value), register 0000Hex offers value 32767 or -32768. And bit b0 of register 0002Hex show the display status.

0 = no decimal      2 = 2 digits decimal      4=4 digits decimal  
 1 = 1 digit decimal      3 = 3 digits decimal      5=5 digits decimal


00 02 Hex Status  
 Type : Integer  
 Word composed of 1+4 bits  
 b0=0 Value contained on register 00 00H is an indication (number)  
 b0=1 Value contained on register 00 00H is not an indication



Word b4,b3,b2,b1

- |              |           |           |               |               |             |
|--------------|-----------|-----------|---------------|---------------|-------------|
| 0.- Reserved | 3.- +Ovr  | 6.- Con   | 9.- MErr1     | 12.- Reserved | 15.- Others |
| 1.- Low      | 4.- DErr0 | 7.- Open  | 10.- Reserved | 13.- Reserved |             |
| 2.- -Ovr     | 5.- Brk   | 8.- MErr0 | 11.- Reserved | 14.- Reserved |             |

00 03 Hex Alarms  
 Type : Integer  
 b0=0 AL1 in OFF state      b2=0 AL3 in OFF state  
 b0=1 AL1 in ON state      b2=1 AL3 in ON state  
 b1=0 AL2 in OFF state      b3=0 AL4 in OFF state  
 b1=1 AL2 in ON state      b3=1 AL4 in ON state




Note2 : The length of all registers is 2 bytes, defined as LSB and MSB. MSB (Most Significant Byte) is the first to be transmitted. LSB (Least Significant Byte) is the second to be transmitted.


## 7.3.4- CONNECTIONS AND BUS TERMINATOR

Connections - Cables A and B as Standard Modbus


Terminal 14 B  
Terminal 13 A



Terminator - Place jumper if the BUS ends on this instrument



## 7.3.5- MODBUS FRAME STRUCTURE-I



Example for a Modbus-RTU frame - Start Character corresponds with instrument address and final character corresponds with the CRC Security Code  
In Modbus-ASCII Start and End characters are specific

T1 = Time between two characters  
T2 = Time between end of question and start of response  
T3 = Time between end of response and start of next question

	T2 MAX (RTU and ASCII)	T1 (min/max)	T3 (min/max)
38400	4.3 mSeg	RTU 0CT / 3CT ASCII 0CT / ---	RTU 3.5CT / -- ASCII --- / ---
19200	5.7 mSeg		
9600	9.2 mSeg		
4800	15.5 mSeg		
2400	27 mSeg		

## 7.3.6- CHARACTER STRUCTURE

Bit structure for the characters on protocols ModBus RTU and ModBus ASCII

	START	DATA	PARITY	STOP	TOTAL BITS
RTU	1	8	P	1	11
	1	8	I	1	11
	1	8	--	2	11
ASCII	1	7	P	1	10
	1	7	I	1	10
	1	7	--	2	10

## 7.3.7- MODBUS FRAME STRUCTURE-II

QUESTION : Communication MASTER and SLAVE

ADDRESS 1 CHARACTER  
FUNCTION 1 CHARACTER  
READING START REGISTER 2 CHARACTERS  
NUMBER OF REGISTERS TO READ X CHARACTERS  
CRC 2 CHARACTERS

Instrument Address  
Function 04H, register read  
Register 00 00H = Display Value  
02 = 2 registers (4 bytes)  
Control Checksum

RESPONSE : Communication SLAVE to MASTER

ADDRESS 1 CHARACTER  
FUNCTION 1 CHARACTER  
LENGTH 1 CHARACTER  
DATA X CHARACTERES  
CRC 2 CHARACTERS

Instrument Address  
Function 04H, register read  
Number of data characters following  
Response data\*  
Control Checksum

## 7.4- PEAK, VALLEY, HOLD, TARE, RESET- OPCIÓN TEK

The TEK option adds functions for PEAK/VALLEY memory, or remote TARE or remote HOLD to the instruments TAS-1. These functions are selectable and programmable from frontal keypad, and are activated connecting two external contacts to the rear


side terminals. Each contact has assigned one function (which can be changed) plus a third function associated to both contacts closing at the same time, to release a RESET for PEAK/VALLEY memory. Isolated option.

### 7.4.1- AVAILABLE FUNCTIONS

Functions	PEAK, VALLEY, HOLD, TARE, RESET
Terminals	2 Terminals for 2 Free Potential Contacts 1 Function for each contact
Contact1	PEAK or VALLEY or HOLD or TARE or RESET configurable from frontal keypad
Contact2	PEAK or VALLEY or HOLD configurable from frontal keypad
Contact12	RESET. This function is fixed and is activated when closing both contacts at same time.
Isolation	2KV to the input signal 3K5V to the power 230Vac and 115Vac 1KV to the power 24Vdc

### 7.4.2- CONNECTIONS

Terminal 12 .- COMMON  
Terminal 15 .- CONTACT1  
Terminal 16 .- CONTACT2



### 7.4.3- TEK CONFIGURATION

#### Entering the Menu

Introduce the programming code «14 23»  
Message «E INP»      TEK board recognized

#### Configuring the external contacts

Parameter «INP_1»	Contact 1 ON Active OFF Not Active
Parameter «FUN_T»	Function assigned to Contact1
Parameter «INP_2»	Contact 2 ON Active OFF Nor Active
Parameter «FUN_T»	Function assigned to Contact2
Parameter «RES12»	RESET12 Function «Reset» when connecting contacts 1 and 2 simultaneously ON Active OFF Nor Active

#### Exiting the Menu


Message «INPUT» .- confirms that the parameters have been accepted

Message «ERROR» .- informs that at least one of the values is not correct, and the whole configuration could not be applied. Repeat the process from the beginning.

#### Default Configuration

When entering code «14 22» to apply a unit reset, the TEK option is configured as follows :

	STATE	FUNCTION
CONTROL 1	OFF	HOLD
CONTROL 2	OFF	HOLD



## DECLARATION OF CONFORMITY CE

**Manufactured by :** FEMA ELECTRONICA, S.A.  
**Address :** P.I. Santiga  
 Altimira 14 (Talleres-14, Nave-2)  
 08210-Barberà del Vallès (Barcelona-Spain)

**Declares that the equipment complies with the following technical specifications.**

**Product :** TAS-1-TP, TAS-1-VDC, TAS-1-VAC, TAS-1-IDC,  
 TAS-1-IAC

**DIRECTIVES**

**EUROPEAN DIRECTIVE FOR LOW VOLTAGE D73/23/CEE AMENDED BY D93/68/CEE.**  
 Equipments powered from 50 to 1000 Vac. and/or from 75 to 1500 Vdc.

**EUROPEAN DIRECTIVE FOR PRODUCT SAFETY D92/59/CEE.**  
**ELECTROTECHNICAL REGULATION FOR LOW VOLTAGE (RBT) ITC 21, ITC 29, ITC 35.** For equipments with power supply lower than 50 Vac and/or 75 Vdc.

**EUROPEAN DIRECTIVE FOR ELECTROMAGNETIC COMPATIBILITY D89/336/ CEE AMENDED BY D93/68/CEE, ACCORDING TO RD1950/1995 (Dec.1st).**

**REGULATIONS**

**ELECTRICAL SECURITY:** EN 61010-1  
 EN 50082-2  
**SUCEPTIBILITY:** IEC 1000-4-2, EN 61000-4-2, IEC 801-2  
 ENV 50140, EN 61000-4-4, IEC 801-4 (level 3)  
 ENV 50141, IEC 801-3 (level 3)  
 ENV 50204 (level 3)

**EMISSION:** EN 50081-2.  
 EN 55011, EN 55014, EN 55022

**UNE 21352-76: CEI 359-71.**  
 Operating quality expressions for electronic equipments.  
**UNE 20652-80: CEI 284-68.**  
 Behaviour rules inherent to the handling of electronic equipments and other similar technics.

FEMA ELECTRONICA, S.A.  
 Barberà del Vallès, 2000

## WARRANTY.

FEMA ELECTRÓNICA, S.A. warrants this product free of manufacture defects for two years from the date of shipment.

This Warranty is VOID if the unit shows evidence of damages as a result of misapplication, accident, misuse or if the product has been tampered or repaired by personnel or companies without the official authorization of FEMA ELECTRÓNICA, S.A. This Warranty is VOID also for damages caused by defective or inappropriate applications.

During the warranty FEMA ELECTRONICA, S.A. will repair or replace at its own discretion the material which results to be faulty. Attach with the material a copy of the invoice and delivery note, with a description of the malfunction, and ship it free of charge and properly packed to your local distributor or to the following address

FEMA ELECTRONICA, S.A.  
 Altimira 14 (Talleres-14, Nave-2)  
 P.I. Santiga  
 P.O. Box 49  
 E 08210 BARBERÀ DEL VALLÈS  
 BARCELONA (SPAIN)

## LIMITATION OF LIABILITY

FEMA ELECTRONICA, S.A. shall not be responsible for any damage or loss to other equipment however caused, which may be experienced as a result of the installation or use of this product. FEMA ELECTRONICA, S.A. liability shall not exceed the purchase price paid of the product upon which liability is based. In no event shall FEMA ELECTRONICA, S.A. be liable for consequential, incidental or special damages.

## INSTALLATION

**PRECAUTIONS.-** Installation and use of this unit must be done by qualified operators. The unit has not AC (mains) switch, neither internal protection fuse, and it will be in operation as soon as power is connected. The installation must contain an external mains switch with protection fuse plus the necessary devices to protect the operator and the process when using the unit to control a machine or process where



injury to personnel or damage to equipment or process may occur as a result of failure of the unit.

External Protection Fuse to be added :  
 for 230 Vac : **80mA fuse TimeLag** as IEC 127/2  
 for 115 Vac : **125mA fuse TimeLag** as IEC 127/2

**SAFETY PRESCRIPTIONS.-** These instruments have been designed and tested according to EN-61010-1 rules and are delivered in good operational conditions. This user manual contains useful information for electrical connections. Do not make wiring signal changes or connections when power is applied to the unit. Make signal connections before power is applied and, if reconnection is required, disconnect the AC (mains) power before such wiring is attempted. Install the unit in a place with good ventilation to avoid excessive heating, and far from electrical noise sources or magnetic field generators such as power relays, electrical motors, speed controls etc...



The unit cannot be installed in open places. Do not use until the installation is finished.

**POWER SUPPLY.-** The power supply must be connected to the adequate terminals (see connection instructions). Characteristics of the power supply are showed on the characteristics label attached to the instrument. Please make sure the unit is correctly connected to a power supply of the correct voltage and frequency. Do not use other power supply otherwise permanent damage may be caused to the unit. Do not connect the unit to power sources heavily loaded or to circuits which power loads in cycle ON-OFF or to circuits which power inductive loads.

**WARNING.-** On units with DC power supply, be careful with the polarity indicated for each terminal.

**SIGNAL WIRING.-** Certain considerations must be given when installing the signal input wires. Long wires can act like an antenna and introduce electrical noise to the unit, therefore :

Do not install the signal input wires in the same conduct with power lines, heaters, solenoids, SCR controls etc...and always far from these elements.

When shielded wires are used, leave unconnected the shield on the indicator side and connect the other end of the shield to the ground terminal of the machine.

## SAFETY CONSIDERATIONS

**PRESCRIPTIONS.-** Before starting any operation of adjustment, replacement, maintenance or repair, the unit must be disconnected from any kind of power supply.



Keep the unit clean , to assure good functioning and performance. To prevent electrical or fire hazard, do not expose the unit to excessive moisture. Do not operate the unit in the presence of flammable gases or fumes, such as environment constitutes a definite safety hazard. The unit is designed to be mounted on a panel.

If the unit shows signs of damage, or is not able to show the expected measures, or has been stored in a bad conditions or a protection failure can occur, then do not attempt to operate and keep the unit out of service.

## IN CASE OF FIRE



- 1.- Disconnect the unit from the power supply.
- 2.- Give the alarm according to the local rules.
- 3.- Switch off all the air conditioning devices.
- 4.- Attack the fire with carbonic snow, do not use water in any case.

**WARNING :** In closed areas do not use systems with vaporized liquids.