

# User Manual

Revision 1.000  
English

## Modbus TCP Master / SNMP - Converter

(Order Code: HD67166-A1)

for Website information:

[www.adfweb.com?Product=HD67166](http://www.adfweb.com?Product=HD67166)

for Price information:

[www.adfweb.com?Price=HD67166-A1](http://www.adfweb.com?Price=HD67166-A1)

### Benefits and Main Features:

- ✚ Very easy to configure
- ✚ Electrical isolation
- ✚ Temperature range: -40°C/85°C (-40°F/185°F)



For others SNMP products, see also the following links:

#### Converter SNMP to

[www.adfweb.com?Product=HD67155](http://www.adfweb.com?Product=HD67155)  
[www.adfweb.com?Product=HD67156](http://www.adfweb.com?Product=HD67156)  
[www.adfweb.com?Product=HD67159](http://www.adfweb.com?Product=HD67159)  
[www.adfweb.com?Product=HD67160](http://www.adfweb.com?Product=HD67160)  
[www.adfweb.com?Product=HD67161](http://www.adfweb.com?Product=HD67161)  
[www.adfweb.com?Product=HD67162](http://www.adfweb.com?Product=HD67162)  
[www.adfweb.com?Product=HD67163](http://www.adfweb.com?Product=HD67163)  
[www.adfweb.com?Product=HD67164](http://www.adfweb.com?Product=HD67164)  
[www.adfweb.com?Product=HD67165](http://www.adfweb.com?Product=HD67165)  
[www.adfweb.com?Product=HD67167](http://www.adfweb.com?Product=HD67167)  
[www.adfweb.com?Product=HD67168](http://www.adfweb.com?Product=HD67168)  
[www.adfweb.com?Product=HD67169](http://www.adfweb.com?Product=HD67169)  
[www.adfweb.com?Product=HD67613](http://www.adfweb.com?Product=HD67613)  
[www.adfweb.com?Product=HD67693](http://www.adfweb.com?Product=HD67693)  
[www.adfweb.com?Product=HD67726](http://www.adfweb.com?Product=HD67726)

(CAN)  
 (CANopen)  
 (EtherNet/IP)  
 (DeviceNet Master)  
 (DeviceNet Slave)  
 (J1939)  
 (M-Bus Master)  
 (Modbus Master)  
 (Modbus Slave)  
 (Modbus TCP Slave)  
 (PROFIBUS Master)  
 (PROFIBUS Slave)  
 (PROFINET)  
 (BACnet Slave)  
 (BACnet Master)

Do you have an your customer protocol?

[www.adfweb.com?Product=HD67003](http://www.adfweb.com?Product=HD67003)

Do you need to choose a device? do you want help?

[www.adfweb.com?Cmd=helpme](http://www.adfweb.com?Cmd=helpme)



User Manual

## INDEX:

	Page
INDEX	2
UPDATED DOCUMENTATION	2
REVISION LIST	2
WARNING	2
TRADEMARKS	2
SECURITY ALERT	3
EXAMPLE OF CONNECTION	4
CONNECTION SCHEME	5
CHARACTERISTICS	6
CONFIGURATION	6
POWER SUPPLY	7
FUNCTION MODES	8
LEDS	9
ETHERNET	10
USE OF COMPOSITOR SW67166	11
NEW PROJECT / OPEN PROJECT	12
SOFTWARE OPTIONS	13
SET COMMUNICATION	14
SET ACCESS	15
UPDATE DEVICE	17
SNMP COMMUNICATION	19
MECHANICAL DIMENSIONS	21
ORDERING INFORMATIONS	22
ACCESSORIES	22
DISCLAIMER	23
OTHER REGULATIONS AND STANDARDS	23
WARRANTIES AND TECHNICAL SUPPORT	24
RETURN POLICY	24

## UPDATED DOCUMENTATION:

Dear customer, we thank you for your attention and we remind you that you need to check that the following document is:

- ✚ Updated
- ✚ Related to the product you own

To obtain the most recently updated document, note the “document code” that appears at the top right-hand corner of each page of this document.

With this “Document Code” go to web page [www.adfweb.com/download/](http://www.adfweb.com/download/) and search for the corresponding code on the page. Click on the proper “Document Code” and download the updates.

## REVISION LIST:

Revision	Date	Author	Chapter	Description
1.000	05/01/2015	Ff	All	First Release

## WARNING:

ADFweb.com reserves the right to change information in this manual about our product without warning.

ADFweb.com is not responsible for any error this manual may contain.

## TRADEMARKS:

All trademarks mentioned in this document belong to their respective owners.

**SECURITY ALERT:****GENERAL INFORMATION**

To ensure safe operation, the device must be operated according to the instructions in the manual. When using the device, legal and safety regulation are required for each individual application. The same applies also when using accessories.

**INTENDED USE**

Machines and systems must be designed so the faulty conditions do not lead to a dangerous situation for the operator (i.e. independent limit switches, mechanical interlocks, etc.).

**QUALIFIED PERSONNEL**

The device can be used only by qualified personnel, strictly in accordance with the specifications. Qualified personnel are persons who are familiar with the installation, assembly, commissioning and operation of this equipment and who have appropriate qualifications for their job.

**RESIDUAL RISKS**


The device is state-of-the-art and is safe. The instruments can represent a potential hazard if they are inappropriately installed and operated by untrained personnel. These instructions refer to residual risks with the following symbol:



This symbol indicates that non-observance of the safety instructions is a danger for people that could lead to serious injury or death and / or the possibility of damage.

**CE CONFORMITY**

The declaration is made by our company. You can send an email to [support@adfweb.com](mailto:support@adfweb.com) or give us a call if you need it.

**EXAMPLES OF CONNECTION:**

## CONNECTION SCHEME:




Figure 1: Connection scheme for HD67166-A1

**CHARACTERISTICS:**

The HD67166-A1 is a Modbus TCP Master / SNMP Converter.

It has the following characteristics:

- Up to 1024 bytes in reading and 1024 bytes in writing;
- Isolation between Power Supply - Ethernet.
- Two-directional information between Modbus TCP bus and SNMP bus;
- Mountable on 35mm Rail DIN;
- Wide power supply input range: 8...24V AC or 12...35V DC;
- Wide temperature range: -40°C / 85°C [-40°F / +185°F].



**CONFIGURATION:**

You need Compositor SW67166 software on your PC in order to perform the following:

- Define the parameter of SNMP line;
- Define the parameter of Modbus TCP line;
- Update the device.

## POWER SUPPLY:

The devices can be powered at 8...24V AC and 12...35V DC. For more details see the two tables below.



VAC 		VDC 	
Vmin	Vmax	Vmin	Vmax
8V	24V	12V	35V

Consumption at 24V DC:

Device	Consumption [W/VA]
HD67166-A1	3.5

**Caution: Do not reverse the polarity power**

**Connector1:**  
Power Supply port  
0V = Ground  
+V = Positive wire  
V AC: min 8V ; max 24V  
V DC: min 12V ; max 35V



HD67166-A1

**FUNCTION MODES:**

The device has got two function modes depending on the position of the 'Dip2 of Dip-Switch A':

- The first, with 'Dip2 of Dip-Switch A' at "OFF" position, is used for the normal working of the device.
- The second, with 'Dip2 of Dip-Switch A' at "ON" position, is used for uploading the Project and/or Firmware.

For the operations to follow for the updating, see 'UPDATE DEVICE' section.

According to the functioning mode, the LEDs will have specific functions, see 'LEDS' section.

**Warning:**


Dip1 of 'Dip-Switch A' must be at ON position to work even if the Ethernet cable is not inserted.



## LEDS:


The device has got six LEDs that are used to give information about the functioning status.  
The various meanings of the LEDs are described in the table below.

LED	Normal Mode	Boot Mode
1: ON [supply voltage ] (green)	<b>ON:</b> Device powered <b>OFF:</b> Device not powered	<b>ON:</b> Device powered <b>OFF:</b> Device not powered
2: Modbus comm. (green)	Blinks when Modbus data are received	<b>Blinks quickly:</b> Boot state <b>Blinks very slowly (~0.5Hz):</b> update in progress
3: Device state (green)	Blinks slowly (~1Hz)	<b>Blinks quickly:</b> Boot state <b>Blinks very slowly (~0.5Hz):</b> update in progress
4: Not used (green)	OFF	<b>Blinks quickly:</b> Boot state <b>Blinks very slowly (~0.5Hz):</b> update in progress
5: Ethernet1 Tx (green)	Blinks when is transmitting Ethernet frames	<b>Blinks quickly:</b> Boot state <b>Blinks very slowly (~0.5Hz):</b> update in progress
6: Ethernet2 Tx (green)	Blinks when is transmitting Ethernet frames	<b>Blinks quickly:</b> Boot state <b>Blinks very slowly (~0.5Hz):</b> update in progress



**ETHERNET:**

The SNMP connection, Modbus TCP connection and the updating of the converters must be made using Connector3 and/or Connector4 with at least a Category 5E cable. The maximum length of the cable should not exceed 100m. The cable has to conform to the T568 norms relative to connections in cat.5 up to 100 Mbps. To connect the device to an Hub/Switch is recommended the use of a straight cable, to connect the device to a PC/PLC/other is recommended the use of a cross cable.



**USE OF COMPOSITOR SW67166:**

To configure the Converter, use the available software that runs with Windows called SW67166. It is downloadable on the site [www.adfweb.com](http://www.adfweb.com) and its operation is described in this document. *(This manual is referenced to the last version of the software present on our web site)*. The software works with MSWindows (XP, Vista, Seven, 8; 32/64bit).

When launching the SW67166, the window below appears (Fig. 2).

**Note:**

It is necessary to have installed .Net Framework 4.





Figure 2: Main window for SW67166


**NEW CONFIGURATION / OPEN CONFIGURATION:**

The “**New Configuration**” button creates the folder which contains the entire device’s configuration.




A device’s configuration can also be imported or exported:


- To clone the configurations of a programmable “Modbus TCP Master / SNMP - Converter” in order to configure another device in the same manner, it is necessary to maintain the folder and all its contents;
- To clone a project in order to obtain a different version of the project, it is sufficient to duplicate the project folder with another name and open the new folder with the button “**Open Configuration**”.



## SOFTWARE OPTIONS:

By pressing the “**Settings**” () button there is the possibility to change the language of the software and check the updatings for the compositor.

In the section “Language” it is possible to change the language of the software.



In the section “Connection Options”, it is possible to check if there are some updatings of the software compositor in ADFweb.com website. Checking the option “**Check Software Update at Start of Program**”, the SW67166 check automatically if there are updatings when it is launched.

**SET COMMUNICATION:**

This section define the fundamental communication parameters of two buses, SNMP and Modbus TCP.

By Pressing the **"Set Communication"** button from the main window for SW67166 (Fig. 2) the window "Set Communication" appears (Fig. 3).

The window is divided in two sections, one for the SNMP and the other for the Modbus TCP Master.

The means of the fields for "SNMP" are:

- In the field **"IP ADDRESS"** insert the IP address that you want to give to the SNMP side;
- In the field **"SUBNET Mask"** insert the SubNet Mask of the SNMP side;
- In the field **"GATEWAY"** insert the default gateway that you want to use. This feature can be enabled or disabled pressing the Check Box field. This feature is used for going out of the net;
- In the field **"SNMP Name of Station"** is possible to assign a name to the SNMP node.

The means of the fields for the "Modbus TCP Slave" section are:

- In the field **"IP ADDRESS"** insert the IP address that you want to give to the Modbus TCP side;
- In the field **"SUBNET Mask"** insert the SubNet Mask of the Modbus TCP side;
- In the field **"GATEWAY"** insert the default gateway that you want to use. This feature can be enabled or disabled pressing the Check Box field. This feature is used for going out of the net;
- In the field **"TimeOut (ms)"** insert the maximum time that the device waits for the answer from the slave interrogated;
- In the field **"Cyclic Delay (ms)"** insert the delay between two Modbus TCP requests.

The screenshot shows the 'Set Communication' window for device SW67166. The window has a title bar with 'ADF WEB' and 'Set Communication'. The main content area is divided into two sections: 'SNMP' and 'Modbus TCP Master'. The 'SNMP' section contains fields for 'IP ADDRESS' (192.168.0.10), 'SUBNET Mask' (255.255.255.0), a 'GATEWAY' checkbox (unchecked), and a text field for 'SNMP Name of Station' (devicename1). The 'Modbus TCP Master' section contains fields for 'IP ADDRESS' (192.168.0.5), 'SUBNET Mask' (255.255.255.0), a 'GATEWAY' checkbox (unchecked), a 'TimeOut (ms)' field (1000), and a 'Cyclic Delay (ms)' field (100). At the bottom of the window are 'OK' and 'Cancel' buttons.

Figure 3: "Set Communication" window

## SET ACCESS:

By Pressing the **"Set Modbus Access"** button from the main window for SW67166 (Fig. 2) the window "Set Access" appears (Fig. 4).

The window is divided in two parts, the "Modbus Read" that contains the Modbus registers/status readable by the Converter and "Modbus Write" that contains the Modbus registers/status writeable by the Converter.

The meaning of the fields in the window are the follows:

- In the field **"Slave IP Address"** the address of the Modbus device you have to read/write is defined;
- In the field **"Port"** the port used for require the Modbus data is defined;
- In the field **"Slave ID"** is possible to insert the ID the address of the Modbus device you have to read/write;
- In the field **"Type"** insert the data type of the Register you would like to read/write. You can choose between the following:
  - Coil Status (R/W);
  - Input Status (R);
  - Holding Register (R/W);
  - Input Register (R);
- In the field **"Address"** the start address of the register/status to read/write is defined;
- In the field **"NPoint"** insert the number of consecutive registers/status to read/write;
- In the field **"Poll Time"** insert the time (expressed in milliseconds) used for read/write the register/status. If zero, the request isn't made;

**SW67166**  
Set Modbus TCP Master Access

Modbus Read | Modbus Write

N	Slave IP Address	Port	Slave ID	Type	Address	NPoint	Poll Time	Max Error	Position	Start Bit	Mnemonic
1	192.168.0.11	502	1	Holding Register	100	1	1000	0	0	0	
2	192.168.0.11	502	1	Input Register	100	1	1000	0	2	0	
3	192.168.0.11	502	1	Coil Status	200	10	5000	0	4	0	
4											
5											

OK Cancel Delete Row Insert Row

**SW67166**  
Set Modbus TCP Master Access

Modbus Read | Modbus Write

N	Slave IP Address	Port	Slave ID	Type	Address	NPoint	Poll Time	On Change	Max Error	Position	Start Bit	Mnemonic
1	192.168.0.11	502	1	Holding Register	100	2	1000	<input checked="" type="checkbox"/>	0	0	0	
2	192.168.0.11	502	1	Holding Register	123	4	1000	<input type="checkbox"/>	0	4	0	
3	192.168.0.11	502	2	Coil Status	200	1	5000	<input checked="" type="checkbox"/>	0	12	0	
4								<input type="checkbox"/>				
5								<input type="checkbox"/>				

OK Cancel Delete Row Insert Row

Figure 4: "Set Access" window

- In the field "**Max Error**" insert the number of consecutive errors that the Master waits before discard the row from the cycle of requests;
- By checking the field "**On Change**" the Modbus write request is made only if SNMP data are changed; otherwise is sent cyclically, using the "Poll Time". This feature is used only on "Modbus Write" section;
- In the field "**Position**" is possible to select the position where take/save the data from SNMP array;
- The field "**Start Bit**" is used for select from which Bit save the data (to use only when the "Type" is 'Coil Status' or 'Input Status' and the "NPoint" is more than one);
- In the field "**Mnemonic**" is possible to insert a description of the data inserted in the row.

**Note:**

If you want that the Modbus register/status is written only when data are changed, the "Poll Time" of the row must be 0.

**Note:**

If the field "On change" is checked and the "Poll Time" is different from 0, the converter sends the Write request cyclically and also when the data is changed.



**UPDATE DEVICE:**

By pressing the **"Update Device"** button, it is possible to load the created Configuration into the device; and also the Firmware, if necessary.

If you don't know the actual IP address of the device you have to use this procedure:

- Turn off the Device;
- Put Dip2 of 'Dip-Switch A' in ON position;
- Turn on the device
- Connect the Ethernet cable;
- Insert the IP **"192.168.2.205"**;
- Press the **"Ping"** button, "Device Found! must appear";
- Press the **"Next"** button;
- Select which operations you want to do;
- Press the **"Execute update firmware"** button to start the upload;
- When all the operations are "OK" turn off the Device;
- Put Dip2 of 'Dip-Switch A' in OFF position;
- Turn on the device.

At this point the configuration/firmware on the device is correctly updated.




Figure 5: "Update device" windows

If you know the actual IP address of the device, you have to use this procedure:

- Turn on the Device with the Ethernet cable inserted;
- Insert the actual IP of the Converter;
- Press the "**Ping**" button, must appear "Device Found!";
- Press the "**Next**" button;
- Select which operations you want to do;
- Press the "**Execute update firmware**" button to start the upload;
- When all the operations are "OK" the device automatically goes at Normal Mode.

At this point the configuration/firmware on the device is correctly update.



**Note:**

When you install a new version of the software, if it is the first time it is better you do the update of the Firmware in the HD67166-A1 device.



**Note:**

When you receive the device, for the first time, you also have to update the Firmware in the HD67166-A1 device.



**Warning:**

If Fig. 6 appears when you try to do the Update try these points before seeking assistance:

- Try to repeat the operations for the update;
- Try with another PC;
- Try to restart the PC;
- If you are using the program inside a Virtual Machine, try to use it in the main Operating System;
- If you are using Windows Seven or Vista or 8, make sure that you have the administrator privileges;
- Pay attention to the Firewall lock;
- Check the LAN settings.



In the case of HD67166-A1 you have to use the software "SW67166": [www.adfweb.com/download/filefold/SW67166.zip](http://www.adfweb.com/download/filefold/SW67166.zip).




Figure 6: "Protection" window

## SNMP COMMUNICATION

In order to read/write the data from/to Modbus TCP side, it is necessary to use specific SNMP commands in order to see the SNMP Input and write the SNMP Output.

### Reading Modbus TCP data from SNMP:

In order to read the data from the HD67166-A1 it is necessary to use the "snmpget" command. The Input array is contained to this internal directory: 1.3.6.1.4.1.33118.1.1.1.4.x.0, where 'x' is the number of data block. Each data block has a dimension of 128 bytes.

Example: you want to read informations of the data block 3. The structure of the command to send is:

snmpget -v1 -cprivate "IP Address of the converter" 1.3.6.1.4.1.33118.1.1.1.4.**3**.0



Figure 7a: MIB Tree Input

### Writing Modbus TCP data from SNMP:

In order to write the data to the HD67166-A1 it is necessary to use the "snmpset" command. The Output array is contained to this internal directory: 1.3.6.1.4.1.33118.1.1.1.4.x.0, where 'x' is the number of data block. Each data block has a dimension of 128 bytes.

Example: you want to write informations of the data block 3 with the data '0123456789' (ASCII). The structure of the command to send is:

snmpset -v1 -cprivate "IP Address of the converter" 1.3.6.1.4.1.33118.1.1.1.5.3.0 s "0123456789"





Figure 7b: MIB Tree Output

## MECHANICAL DIMENSIONS:




Housing: PVC  
Weight: 200g (Approx)

Figure 8: Mechanical dimensions scheme for HD67166-A1

## ORDERING INFORMATION:

The ordering part number is formed by a valid combination of the following:

### **HD67166 - A1**



Order Code: **HD67166-A1** - Modbus TCP Master / SNMP - Converter

## ACCESSORIES:

Order Code: **AC34001** - 35mm Rail DIN - Power Supply 220/240V AC 50/60Hz - 12 V AC

Order Code: **AC34002** - 35mm Rail DIN - Power Supply 110V AC 50/60Hz - 12 V AC

**DISCLAIMER:**

All technical content within this document can be modified without notice. The content of the document is a under continual renewal. For losses due to fire, earthquake, third party access or other accidents, or intentional or accidental abuse, misuse, or use under abnormal conditions repairs are charged to the user. ADFweb.com S.r.l. will not be liable for accidental loss of use or inability to use this product, such as loss of business income. ADFweb.com S.r.l. shall not be liable for consequences of improper use.

**OTHER REGULATIONS AND STANDARDS:****WEEE INFORMATION**

Disposal of old electrical and electronic equipment (as in the European Union and other European countries with separate collection systems).

■ This symbol on the product or on its packaging indicates that this product may not be treated as household rubbish. Instead, it should be taken to an applicable collection point for the recycling of electrical and electronic equipment. If the product is disposed correctly, you will help prevent potential negative environmental factors and impact of human health, which could otherwise be caused by inappropriate disposal. The recycling of materials will help to conserve natural resources. For more information about recycling this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

**RESTRICTION OF HAZARDOUS SUBSTANCES DIRECTIVE**

The device respects the 2002/95/EC Directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment (commonly referred to as Restriction of Hazardous Substances Directive or RoHS).

**CE MARKING**

The product conforms with the essential requirements of the applicable EC directives.

## WARRANTIES AND TECHNICAL SUPPORT:

For fast and easy technical support for your ADFweb.com SRL products, consult our internet support at [www.adfweb.com](http://www.adfweb.com). Otherwise contact us at the address [support@adfweb.com](mailto:support@adfweb.com)

## RETURN POLICY:

If while using your product you have any problem and you wish to exchange or repair it, please do the following:

- Obtain a Product Return Number (PRN) from our internet support at [www.adfweb.com](http://www.adfweb.com). Together with the request, you need to provide detailed information about the problem.
- Send the product to the address provided with the PRN, having prepaid the shipping costs (shipment costs billed to us will not be accepted).

If the product is within the warranty of twelve months, it will be repaired or exchanged and returned within three weeks. If the product is no longer under warranty, you will receive a repair estimate.



**ADFweb.com S.r.l.**  
Via Strada Nuova, 17  
IT-31010 Mareno di Piave  
TREVISO (Italy)  
Phone +39.0438.30.91.31  
Fax +39.0438.49.20.99  
[www.adfweb.com](http://www.adfweb.com)

