4CH MPEG4 DVR

USER MANUAL

Please read instructions thoroughly before operation and retain it for future reference.

The image shown above may differ from the actual product appearance.

IMPORTANT SAFEGUARD



CAUTION

RISK OF ELECTRIC SHOCK



CAUTION:

To reduce the risk of electric shock, do not expose this apparatus to rain or moisture. Only operate this apparatus from the type of power source indicated on the label. The company shall not be liable for any damages arising out of any improper use, even if we have been advised of the possibility of such damages.

Graphic Symbol Explanation

| Ý | The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons. |
|------|--|
| Â | This exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance. |
| RoHS | All lead-free products offered by the company comply with the requirements of the European law on the Restriction of Hazardous Substances (RoHS) directive, which means our manufacture processes and products are strictly "lead-free" and without the hazardous substances cited in the directive. |
| X | The crossed-out wheeled bin mark symbolizes that within the European Union the product must be collected separately at the product end-of-life. This applies to your product and any peripherals marked with this symbol. Do not dispose of these products as unsorted municipal waste. Contact your local dealer for procedures for recycling this equipment. |
| CE | This apparatus is manufactured to comply with the radio interference requirements. |

Disclaimer

We reserve the right to revise or remove any content in this manual at any time. We do not warrant or assume any legal liability or responsibility for the accuracy, completeness, or usefulness of this manual. For the actual display & operation, please refer to your DVR in hand. The content of this manual is subject to change without notice.

The product & company names mentioned herein may be the registered trademarks or tradenames of their respective owners.

MPEG4 Licensing

THIS PRODUCT IS LICENSED UNDER THE MPEG-4 VISUAL PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER FOR (i) ENCODING VIDEO IN COMPLIANCE WITH THE MPEG-4 VISUAL STANDARD ("MPEG-4 VIDEO") AND/OR (ii) DECODING MPEG-4 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED BY MPEG LA TO PROVIDE MPEG-4 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION INCLUDING THAT RELATING TO PROMOTIONAL INTERNAL AND COMMERCIAL USES AND LICENSING MAY BE OBTAINED FROM MPEG LA, LLC. SEE HTTP://WWW.MPEGLA.COM.

GPL Licensing



This product contains codes which are developed by Third-Party-Companies and which are subject to the GNU General Public License ("GPL") or the GNU Lesser Public License ("LGPL").

The GPL Code used in this product is released without warranty and is subject to the copyright of the corresponding author.

Further source codes which are subject to the GPL-licenses are available upon request.

We are pleased to provide our modifications to the Linux Kernel, as well as a few new commands, and some tools to get you into the code. The codes are provided on the FTP site, and please download them from the following site or you can refer to your distributor:

ftp://ftp.dvrtw.com.tw/GPL/AV071/

Version

TABLE OF CONTENTS

| 1. OVERVIEW | 1 |
|---|----|
| 1.1 Product Description | 1 |
| 1.2 Features | |
| 1.3 Specifications | 2 |
| 2. FRONT AND REAR PANELS | |
| 2.1 Front Panel | |
| 2.2 Rear Panel | 5 |
| 3. CONNECTIONS AND SETUP | 7 |
| 3.1 HDD Installation (Take Model 1 as an example) | 7 |
| 3.2 Camera Connection | 8 |
| 3.2.1 Camera Connection | 8 |
| 3.3 External Device Connections | 8 |
| 3.3.1 VGA Converter Connection (Optional) | |
| 3.3.2 IR Transmitter (Model 3, 4 & 5 only) | |
| 3.3.3 Speed Dome Camera | |
| 3.4 Power Setup | |
| 3.5 Date and Time Setting | |
| 3.6 Password Setting | 10 |
| 4. BASIC OPERATION | |
| 4.1 Live Page | 12 |
| 4.2 Recording | |
| 4.3 Playback | |
| 4.4 Key Lock and Unlock | |
| 4.5 Upgrade | |
| 4.6 Search | |
| 4.7 Audio Backup and Playback | |
| 5. MENU CONFIGURATION | |
| 6. QUICK START MENU | |
| 6.1 QUICK SEARCH | 17 |
| 6.2 RECORD | 17 |
| 6.2 TIMER | |
| 6.3 DATE | 19 |
| 7. ADVANCED MENU | |
| 7.1 CAMERA | 20 |
| 7.2 DETECTION | 21 |
| 7.3 REMOTE | |
| 7.4 DISPLAY | 23 |
| 7.5 ALERT | 23 |
| 7.6 SYSTEM | |
| 7.7 NETWORK | |
| 7.8 BACKUP (Model 3, 4 & 5 Only) | |
| 7.9 HDD INFO | |
| 7.10 EVENT SEARCH | |

| 7.11 EVENT LOG | |
|---|----|
| 8. REMOTE OPERATION | |
| 8.1 Supplied Licensed Software AP | 31 |
| 8.1.1 Installation & Network Connection | |
| 8.1.2 General AP Operation | |
| Record | |
| Playback | |
| Network Backup | |
| 8.1.3 AP Control Panel | |
| 8.1.4 AP Functions | |
| Address Book | |
| Miscellaneous Control | |
| Information | 51 |
| DVR Control | 51 |
| 8.2 IE Web Browser | 53 |
| 8.3 QuickTime Player | 55 |
| APPENDIX 1 PIN CONFIGURATION | |
| APPENDIX 2 COMPATIBLE USB FLASH DRIVE BRAND | |
| APPENDIX 3 COMPATIBLE HDD BRAND | |
| APPENDIX 4 TROUBLESHOOTING | |
| APPENDIX 5 RS485 PROTOCOL | 61 |

1. OVERVIEW

1.1 Product Description

This MPEG4 multiplex network DVR series combines remote surveillance, burglar prevention, and evidentiary recording features and is designed to become a simple DVR system with all necessary functions.

1.2 Features

MPEG4 Technology

- MPEG4 compression format providing crystal clear images with real time performance
- MPEG4 web transmitting for faster transmission and clearer images via network

Multiplex Operation

· Allows live display, record, playback, backup, and network operations at the same time

Free Upgrade to Advanced Functions

Allows you to upgrade DVR functions without any charges

Backup Device

- Network (for all models)
- USB flash drive (Model 3, 4 & 5)
- DVD writer (Model 5 only)

Remote Surveillance

 Supports remote surveillance up to 20 users simultaneously with licensed software AP, IE browser & Mozilla Firefox browser

Intelligent Motion Trigger Recording

- With the advanced functions of motion detection, scheduled motion detection recording (4 different adjustable factors for motion detection sensitivity) and quick search, customized security environments are achieved
- · Alarm trigger recording will send alerts with images to designated e-mails and the FTP address
- · Supports pre-alarm recording (8MB)

Covert Recording

· Blank screen replaces live displays to achieve covert recording

• A/V Support

- Model 1, 2, 3 & 4: Supports 1 audio-in, 1 audio-out to record sounds Model 5: Supports 2 audio-in & 1 audio-out to record sounds
- Supports VGA output to monitor

General

- Supports multi-language OSD
- · System auto recovery after power failure
- Supports PTZ camera operations through RS485 signals
- · Supports manual / timer / motion / alarm / network remote recording
- Supports TCP/IP, PPPoE, DHCP and DDNS network connection
- Supports IR remote control (for Model 3, 4 & 5 only)
- Supports SATA HDD (except for Model 1)

1.3 Specifications

| MODEL | MODEL 1 | MODEL 2 | MODEL 3 | MODEL 4 | MODEL 5 |
|--|---|---|---|--|--|
| Video System | | NTS | C / PAL (auto detec | tion) | |
| Video Compression Format | | | MPEG4 | | |
| Video Input (Composite video signal 1 Vp-p 75Ω BNC) | 4 Channels | | | | |
| Video Loop Out (Composite video signal 1 Vp-p 75Ω BNC) | | | 4 Channels | | |
| Video Output (Composite video signal 1 Vp-p 75Ω BNC) | | Main Monit | or Output / Call Mor | nitor Output | |
| Maximum Recording Rate | | • | | ×576 pixels with 25 IP 288 pixels with 100 IP | |
| Adjustable Recording Speed | | Frame: 30, 15, 7, 3 CIF: 120, 60, 30, 15 I | IPS <ntsc> / 25, PS <ntsc> / 100, 9</ntsc></ntsc> | | |
| Image Quality Setting | | Best, | High, Normal and E | Basic | |
| Hard Disk Storage (Supports over 1000GB HDD capacity, and HDDs are optional) | Supports HDD * 1 | | Supports S | ATA HDD * 1 | |
| HDD Quick Cleaning | Quick cle | an up the "index syste | em" of the recorded | files. 1000GB under 2 | seconds |
| Recording Mode | | Manual / T | imer / Motion / Alarn | n / Remote | |
| Refresh Rate | | 120 IPS | for NTSC / 100 IPS | for PAL | |
| Audio I/O | | 1 audio input, 1 au | dio output (Mono) | | 2 audio inputs, 1 audio output (Mono) |
| VGA Interface | | NO | | YE | ĒS |
| USB Interface | N | 0 | | Rear Panel x 1 | |
| SATA Interface | NO | | Y | ES | |
| Motion Detection Area | | 16 × 12 gri | ds per camera for a | ll channels | |
| Motion Detection Sensitivity | 4 | adjustable variables v | vith precise calculat | on for motion detectio | n |
| Pre-alarm Recording | | | Yes (8MB) | | |
| Backup Device | Network | | Network / U | SB flash drive | Network / USB flash drive / DVD writer |
| Web Transmitting Compression Format | | | MPEG4 | | |
| Ethernet | 1 | 0/100 Base-T. Suppor | t remote control and | l live view via Ethernel | |
| Web Interface | Si | upport licensed softwa | re AP, IE browser & | Mozilla Firefox brows | er |
| Remote Alarm Notification | I | E-mail images, and up | load images to FTP | site's specific account | |
| Network Protocol | | Support TCP/IP, | PPPoE, DHCP and | DDNS function | |
| PTZ control | | Sup | ports PELCO-D prot | ocol | |
| IR Remote Control | N | 0 | | YES | |
| Dwell Time (Sequential Channel Switch) | | Programma | able with adjustable | dwell time | |
| Alarm I/O | | | 4 inputs, 1 output | | |
| Digital Zoom | 2X digital zoom (live mode) | | | | |
| Key Lock | | | Yes | | |
| Video Loss Detection | | | Yes | | |
| Camera Title | Support up to 6 letters | | | | |
| Video Adjustable | | Hue / C | olor / Contrast / Brig | ghtness | |
| Date Display Format | | YY/MM/DD, | DD/MM/YY, MM/DD | /YY, and Off | |
| Power Source | | | DC 19V | | |
| Power Consumption | <42 W | | <64 W | | |
| Operating Temperature | 10 °C ~ 40°C (50°F~104°F) | | | | |
| Dimensions (mm) | 34.3(VV) X 59(H) X 22.3(L) 345(VV) X 68.3(H) X 225(L) | | 375(W) x 61(H) x 281(D) | | |
| System Recovery | System auto recovery after power failure | | | | |
| Optional Peripherals | | | Keyboard Controller | | |
| • | 1 | | * The specification | | |

The specifications are subject to change without notice.

2. FRONT AND REAR PANELS

2.1 Front Panel

1) LED Indication

The following LEDs will be on when:

HDD: HDD is reading or recording HDD Full: HDD is full. ALARM: Once the alarm is triggered TIMER: When timer recording is turned on PLAY: Under playing status REC: Under recording status

2) <u>MENU</u>

Press this button to enter / exit the DVR menu mode. In the sub-layer of the DVR menu, press this button to confirm the settings and go back to the upper layer.

3) <u>ENTER</u>

Confirm the password entering.

4) <u>REC</u>

Press this button to activate manual recording.

5) LIST or SEARCH

To quick search the recorded files by event list, press this button to show all types of the event lists. Select one of the event list and press "ENTER" button to playback the selected file.

MANUAL List the information of the manual-recorded files. The DVR will save one recorded file once any recording setting is changed.
SYSTEM List the information of the system-recorded files. The DVR system will save one recorded file every one hour.
MOTION List the information of the motion-trigger-recorded files.
ALARM List the information of the alarm-trigger-recorded files.
TIMER List the information of the timer-recorded files.

6) <u>SLOW</u>

Under the playback mode,

Press "SLOW" button to get 1/4X speed playback and press twice to get 1/8X speed playback.

7) <u>ZOOM</u>

In the live mode of the DVR, press this button to enlarge the image of the selected channel.

8) <u>田 / —</u>

Press " \boxplus " button to show the 4 channel display modes. Press "-" button to change the setting in the menu.

9) <u>SEQ /+</u>

Press "SEQ" button to activate the call monitor function, and press again to quit. Press "+" button to change the setting in the menu.

10) <u>Power</u>

Press this button long enough to turn on/off your DVR.

Note: Under the recording mode, please stop recording before turning off your DVR.

11) 1/2/3/4

Press one of these buttons to show the channel display of CH1 ~ CH4 on the monitor.

12) Or PLAY

Press this button to play the recorded video.

13) Pause / Stop / Rew / FF

Under the playback mode:


Press one of these button to pause / stop / rewind / fast-forward the playback file.

14) Up / Down / Left / Right

Press one of these direction buttons to move the cursor up/down/left/right. Under the DVR menu mode, these direction buttons can use for the following operation: Up / Down: Make the selection / Change the settings Left / Right: Make the selection

15)
$$\frac{\overset{\text{SLOW ZOOM}}{\bigcirc} \overset{\text{SLOW ZOOM}}{\bigcirc} \overset{\text{SLOW ZOOM}}{\bigcirc} \overset{\text{SLOW ZOOM}}{\bigcirc} (\text{Audio})}{\circ}$$

Press these two buttons at the same time to select live or playback sounds of the audio channels.




Press these two buttons at the same time to enter / exit the PTZ control mode. In the PTZ control mode \rightarrow Zoom in: Press "+" button ; Zoom out: Press "-" button Adjust PTZ angle: Press direction buttons to turn up/down/left/right

17) <u>"MENU" + "ENTER" (Key lock)</u>

Press these two buttons at the same time to lock keys on the DVR front panel.


2.2 Rear Panel

• Model 1 & 2




Model 3


•



• Model 4



Model 5



1) <u>75Ω / HI-IMPEDANCE</u>

When using LOOP function, please switch to HI-IMPEDANCE. Otherwise, please switch to 75Ω .

- 2) LOOP / INPUT (For channel 1~4)
 - LOOP: Video output connector.

INPUT: Connect to video sources, such as cameras.

Note: If you want to playback the video with audio, please connect an audio camera to INPUT 1 on the DVR rear panel.

3) <u>MONITOR</u>

Connect to MAIN monitor.

FRONT AND REAR PANELS

4) <u>CALL</u>

Connect to CALL monitor to show the channel display one by one. When any alarm is triggered, CALL monitor will show the image of the triggered channel for a period of time.

5) <u>AUDIO IN</u>

Connect to audio sources, such as cameras equipped with the audio function. When users start recording, the audio input will also be recorded.

6) AUDIO OUT

Connect to a monitor or speaker with 1 mono audio output.

7) USB (Model 3, 4 & 5 only)

To quickly backup or upgrade firmware/OSD, you can insert a compatible USB flash drive into this USB port. Before using the USB flash drive, please use your PC to format the USB flash drive as "FAT32" first.

Note: For the list of compatible USB flash drives, please refer to "APPENDIX 2 COMPATIBLE USB FLASH DRIVE BRAND" at page 57.

8) IR (Model 3, 4 & 5 only)

Connect the IR receiver for remote control.

9) EXTERNAL I/O

Insert the supplied 15PIN DSUB to this port for connecting external devices (external alarm, PTZ camera, etc).

For detailed I/O port PIN configuration, please refer to "APPENDIX 1 PIN CONFIGURATION" at page 56.

10) VGA (Model 4 & 5 only)

Connect to a LCD monitor directly.

11) <u>LAN</u>

Connect to Internet by LAN cable.

12) LINK ACT.

When your DVR is connected to the Internet, this LED will be on.

13) <u>DC 19V</u>

Connect to the supplied adapter.

3. CONNECTIONS AND SETUP


3.1 HDD Installation (Take Model 1 as an example)

The HDD must be installed before the DVR is turned on.

Step 1: Loose the screws on the upper cover and open the upper cover of the DVR.



STEP1-1: Remove Screws





STEP1-2: Remove DVR Upper Cover



STEP 2:Remove HDD Bracket

Step 3: Get a compatible SATA HDD, and connect it to the power connector and data bus connector (make sure to align the HDD precisely for pin connection).





STEP3: Connect to power connector & data bus connector

Step 4: Put the HDD to the DVR, and replace the HDD bracket back to the DVR base.





STEP4: Put the HDD and replace the bracket back

Step 5: Close the upper cover of the DVR, and fasten all the screws you loosened in Step 1.

3.2 Camera Connection

The cameras must be connected and power-supplied **<u>BEFORE</u>** the DVR is turned on. The DVR will automatically detect the video system of the connected camera(s) (NTSC / PAL), and switch itself to the correct system.

Note: For detailed DVR video input / output ports, please refer to "2.2 Rear Panel" at page 5. For detailed camera operation, please refer to its own manual.

Note: If you want to make a video backup with audio, please connect audio camera to the CH1 which support the audio function


3.2.1 Camera Connection

- Power connection: Connect the camera with indicated power supply.
- <u>Video cable connection:</u>
 Connect the camera video output to the DVR video input port with a coaxial cable or RCA line with BNC connector.
- 3) <u>RS485-A & RS485-B wires connection (For speed dome camera only)</u>: Solder the RS485-A (brown) and RS485-B (orange) wires of the PTZ camera to the corresponding pins on the solder side of the 15 PIN D-Sub connector. For details, please refer to "3.3.3 Speed Dome Camera" at page 9.
- <u>Camera Setup (For speed dome camera only)</u>:
 For detailed camera title, ID, protocol and baud rate setup, please refer to "<u>7.3 REMOTE</u>" at page 22.

3.3 External Device Connections

3.3.1 VGA Converter Connection (Optional)


This optional peripheral allows your DVR to have VGA output function. For the connection method, please refer to the following figure as an example (do not use gender changer). For detailed connection, please refer to your VGA converter manual.



3.3.2 IR Transmitter (Model 3, 4 & 5 only)

Please connect the IR receiver line to the IR port on the DVR rear panel. And make sure the IR function is


activated in the DVR menu (The default setting is on). Please refer to the following figure as an example.



3.3.3 Speed Dome Camera

You can connect the speed dome camera directly to DVR for pan / tilt / zoom control, but the available camera control is limited.

The following description is just an example. For connection details, please refer to your speed dome camera user manual.



STEP 1: Get a RJ11 line with the proper length to your connection.

Different RJ11 connector may have different wire layout, so the connection might be different. If you cannot control the DVR after connection, please reverse the RJ11 line connection with the DVR.

STEP 2: Remove one end of the insulating coating of the RJ11 line.

Remove one end of the insulating coating of the RJ11 line to find the RS485-A and the RS485-B wires, and remove the insulating coating to reveal the naked wires for further connection.

STEP 3: Twist the RS485-A and RS485-B wires of the RJ11 line and the speed dome camera together.

Twist the RS485-A (red) and RS485-B (green) wires of the RJ11 line to the RS485-A (brown) and RS485-B (orange) wires of the speed dome camera. To protect the naked wires, use the insulation tape to cover on the twisted wires.

STEP 4: Connect the other end of the RJ11 line to DVR.

Solder the RS485-A (red) and RS485-B (green) wires of the RJ11 line to the corresponding pins on the

solder side of the 15 PIN or 25 PIN D-Sub connector (as shown in the picture above).

STEP 5: Set the speed dome camera at the DVR side.

Go to the "REMOTE" menu to set the speed dome camera.

- a) Select the device to "PTZ".
- b) Set the ID to the value the same as the one set in the speed dome camera. The default ID of the camera is 000.
- c) Select the protocol based on the speed dome camera you're connecting.
- d) Set the baud rate to the value the same as the one set in the speed dome camera. The default baud rate of the camera is 2400.

| | | REMOTE | | | |
|--|--------|--------|----------|------|--|
| TITLE | DEVICE | ID | PROTOCOL | RATE | |
| CH1 | PTZ | 000 | NORMAL | 2400 | |
| CH2 | CAMERA | 000 | NORMAL | 2400 | |
| СНЗ | CAMERA | 000 | NORMAL | 2400 | |
| CH4 | CAMERA | 000 | NORMAL | 2400 | |
| PLEASE CONSULT YOUR INSTALLER FOR ADVANCE SETTING ↑↓ SELECT ← BACK → NEXT ← ENTER | | | | | |
| | | | | | |

3.4 Power Setup

This device should be operated only with the type of power source indicated on the manufacturer's label. Connect the indicated AC power cord to the power adapter, and plug into an electrical outlet. The power LED " \mathcal{U} " will be on as green. It takes approximately 10 to 15 seconds to boot the system.

Note: To ensure that your DVR works constantly and properly, it's recommended to use an UPS, Uninterruptible Power Supply, for continuously operation. (Optional)

3.5 Date and Time Setting

Before operating your DVR, please set the date and time on your DVR first.

Press the "MENU" button and enter the password to go to the menu list. The default admin password is 0000. Move to "DATE" and you can set the date / time / daylight saving in the "DATE" menu list.

Note: Please DO NOT change the date or time of your DVR after the recording function is activated. Otherwise, the recorded data will be disordered and you will not be able to find the recorded file to backup by time search. If users change the date or time accidentally when the recording function is activated, it's recommended to clear all HDD data, and start recording again.

Note: For the first time to use the DVR, please charge the DVR for at least 48 hours continuously after the date & time is set correctly.

3.6 Password Setting

Press the "MENU" button and enter the password to go to the menu list. Then, move to "ADVANCE" to enter the advanced setting menu.

In the "ADVANCE" menu, move to "SYSTEM". Select "PASSWORD" and press the "ENTER" button to enter the submenu to set the password (four digits). The default admin password is 0000.

| ADVANCE | | SYSTEM |
|--------------|---------------|-----------------------------|
| CAMERA | SERIAL TYPE | RS485 |
| DETECTION | BAUDRATE | 2400 |
| REMOTE | HOST ID | 0 |
| DISPLAY | PASSWORD | XXXX |
| ALERT | RESET DEFAULT | RESET |
| SYSTEM | CLEAR HDD | HDD-MASTER-1 |
| NETWORK | UPGRADE | START |
| BACKUP | AUTO KEYLOCK | NEVER |
| HDD INFO | LANGUAGE | ENGLISH |
| EVENT SEARCH | VIDEO FORMAT | NTSC |
| EVENT LOG | VERSION | 1236-1012-1033-1018-M3-6C1B |

4. BASIC OPERATION

4.1 Live Page

In this live page of the DVR, you can see the following icons:

| lcon | Function | lcon | Function | lcon | Function |
|------|--------------------------|-------------|---------------------------|----------|---------------|
| | Key lock | Q | Digital zoom mode | () () | Alarm |
| | Key unlock | € | Digital zoom unselected | Ŗ | Recording |
| | Live audio channel | 8 | Timer recording | 8 | Motion |
| | Playback audio channel | 6 74 | PTZ control mode | 1 | HDD overwrite |
| 0 | Audio channel unselected | . | Full screen sequence mode | | |

4.2 Recording

When the recording and the pre-alarm function are activated, this device will overwrite 8GB data from the oldest for continuous recording without notice.

1) Continuous Recording Icon

When the DVR is properly connected with camera, you can see the icon " 🗭 " (recording) on the monitor.

2) <u>Motion Recording Icon</u>

When the motion / alarm detection is activated, once motion or external alarm happens, you will see the icon " 🗞 " (motion) on the monitor.

3) <u>Timer Recording Icon</u>

When the timer record is activated, you will see the icon "O" (timer) on the monitor

Note: The audio source connected to the "Audio 1" will be recorded with the video of the "CH1".

4.3 Playback

Press the "PLAY" button on the DVR control panel, and the device will playback the latest recorded video.

Note: There must be at least 8192 images of recorded data for playback to work properly. If not, the device will stop playback. For example, if the IPS is set to 30, the recording time should be at least 205 seconds (8192 images / 40 IPS) for the playback to work properly.

1) Fast Forward / Fast Rewind

You can increase the speed for fast forward and rewind on this device. In the playback mode: Press "FF" once to get 4X speed forward and press twice to get 8X speed, etc. And the maximum speed is 32X. Press "REW" once to get 4X speed rewind and press twice to get 8X speed, etc. And the maximum speed is 32X.

Note: During playback, the image size of the recording (CIF) will be shown on the screen.

2) Pause / Image Jog

Press "PAUSE" button to pause the playback.

In the pause mode:

Press "▶" button once to get one frame forward.

Press "◀" button once to get one frame rewind.

3) <u>Stop</u>

Pressing "STOP" button under playback mode, the screen of this device will return to live monitoring mode.

4) Slow Playback

Press "SLOW" button to get 1/4X speed playback and press twice to get 1/8X speed playback.

5) Audio Playback

Use these two buttons to select the live or playback sound of the audio channels.

- 🔩 Live audio of the 1st audio channel 🖤 Playback audio of the 1st audio channel
 - Live audio of the 2nd audio channel (Model 5 only) 🖓 Playback audio of the 2nd audio channel (Model 5 only)

Note: If you want to make a video backup with audio, please connect your audio camera(s) to the channel(s) supporting the audio function first.

Model 1, 2, 3 & 4: Connect to CH1 / Model 5: Connect to CH1 & CH2.

4.4 Key Lock and Unlock

1) Key Lock On:

Press "MENU" + "ENTER" buttons at the same time on the DVR control panel to lock keys. Or set the time-out after which the key lock function is activated (NEVER / 30 SEC / 60 SEC / 120 SEC). Please refer to "7.6 SYSTEM" at page 24.

2) Key Lock Off:

Enter the DVR password to exit "Key Lock" mode.

Note: For the password setting, please refer to the section "3.6 Password Setting" at page 10.

4.5 Upgrade

Firmware / Multilanguage OSD Upgrade

1) Use USB flash drive to upgrade firmware or OSD:

Step 1. Format the USB memory device as FAT32 format first.

Step 2. Get the upgrade files from your distributor and save the upgrade files in your USB flash device (do not change the file name).

Step 3. In the "SYSTEM" menu, move to "UPGRADE" \rightarrow "START", and press "ENTER" button.

Step 4. Select "YES", and press "ENTER" button again to confirm upgrade.

- 2) Use the supplied software AP to remotely upgrade firmware or OSD:
 - Step 1. Save the upgrade files at your PC (do not change the file name), and log into the Video Viewer.
 - Step 2. Click " (Miscellaneous Control) to show the miscellaneous control panel. In the miscellaneous control panel, click " (Tools) on the miscellaneous control panel to enter the upgrade window.
 - Step 3. Enter the user name, password, IP address and port number of the DVR.
 - Step 4. Click "Firmware" or "Language" tab as needed, and click "Add" to select the firmware or OSD files to upgrade.

Note: For remote upgrade details, please see "Tools" at page 48.

4.6 Search

1) Search by List

Press "LIST" or "SEARCH" button on the DVR control panel to show the list for all types of the recorded files. Choose the list you want to view and press "ENTER" button to start playback.

| ALARM | List the information of the alarm-trigger-recorded files. |
|--------|---|
| MANUAL | List the information of the manual-recorded files. The DVR will save one recorded file once any recording setting is changed. |
| MOTION | List the information of the motion-trigger-recorded files. |
| SYSTEM | List the information of the system-recorded files. The DVR system will save one recorded file every one hour. |
| TIMER | List the information of the timer-recorded files. |

2) Quick Search by Time

Press the "MENU" button to enter the menu list, move to "QUICK SEARCH", and press "ENTER" button to enter the quick time search menu. You can search any specific events by time (Year / Month / Day / Hour / Min) and directly play the file you find.

4.7 Audio Backup and Playback

For audio backup, you need to connect your camera(s) to the correct channel(s) supporting audio recording first. For Model 1, 2, 3 & 4, the audio channel is CH1. For Model 5, the audio channels are CH1 & CH2. For detailed backup instructions, please refer to "7.8 BACKUP (Model 3, 4 & 5 Only)" at page 27.



To select live or playback sounds of the audio channels, press these two buttons on the DVR front panel at the same time. For detailed playback instructions, please refer to "4.3 Playback" at page 12. For detailed playback instructions at the remote side, please refer to "Playback" at page 33.

5. MENU CONFIGURATION

| | | DATE |
|---------------|--------------|--|
| | QUICK SEARCH | |
| | | SEARCH HDD |
| | | IMAGE SIZE |
| | | QUALITY |
| | | |
| | | EVENT REOCRD ENABLE TIMER RECORD ENABLE |
| | RECORD | MANUAL RECORD ENABLE |
| | | EVENT RECORD IPS |
| MAIN MENU | | TIMER RECORD IPS |
| | | PRE-ALARM RECORD |
| | | OVERWRITE |
| | | RECORD TIMER |
| | TIMER | DETECTION TIMER |
| | | DATE |
| | DATE | FORMAT |
| | | DAYLIGHT SAVING |
| | ADVANCE | - |
| ADVANCED MENU | | TITLE |
| | | BRIG |
| | | CONT |
| | CAMERA | SATU |
| | | HUE |
| | | COV. |
| | | REC |
| | | TITLE |
| | | DET |
| | | AREA |
| | DETECTION | LS |
| | BEIEGHON | SS |
| | | TS |
| | | RE |
| | | ALARM |
| | | TITLE |
| | DEMOTE | DEVICE |
| | REMOTE | ID |
| | | PROTOCOL RATE |
| | | DE-INTERLACE |
| | | FULL SCREEN DWELL DURATION (SEC) |
| | | CHANNEL TITLE |
| | DISPLAY | EVENT STATUS |
| | | DATE DISPLAY |
| | | VGA OUTPUT (For Model 4 & 5 only) |
| | | EXT. ALERT |
| | | INT. BUZZER |
| | | KEY BUZZER |
| | | VLOSS BUZZER |
| | ALERT | MOTION BUZZER |
| | | ALARM BUZZER |
| | | HDD BUZZER |
| | | ALARM DURATION (SEC) |
| | | HDD NEARLY FULL (GB) |
| | SYSTEM | SERIAL TYPE |
| | | BAUDRATE |
| | | HOST ID |
| | | PASSWORD |
| | | RESET DEFAULT |
| | | CLEAR HDD |

| | UPGRADE |
|-----------------------------|--------------------|
| | AUTO KEYLOCK (SEC) |
| | LANGUAGE |
| | VIDEO FORMAT |
| | VERSION |
| | NETWORK TYPE |
| | IP |
| | GATEWAY |
| NETWORK | NETMASK |
| | PRIMARY DNS |
| | SECONDARY DNS |
| | PORT |
| | START TIME |
| BACKUP | END TIME |
| ((For Model 3, 4 & 5 only)) | AVAILABLE SIZE |
| | HDD NUM |
| HDD INFO | HDD SIZE (GB) |
| | DATE |
| | CHANNEL |
| EVENT SEARCH | EVENT |
| | SEARCH HDD |
| | START |
| | EVENT |
| EVENT LOG | TIME |
| | COMMENT |
| | |

6. QUICK START MENU

Press the "MENU" button and enter the password to go to the quick-start menu list. The default admin password is 0000. Users can change the password later. Please refer to "SYSTEM" at page 24.

| ITEM | FUNCTION |
|----------|---|
| | Enter / exit the quick start menu |
| MENU | Under the sub-layer of the advanced setting menu, use this button to confirm the settings and go back to the upper layer. |
| ▲ ▼ | Make the selection / Change the setting |
| ↓ | Go to the upper layer or sub-layer / Make the selection |
| ENTER | Confirm the password entering |
| | Go to the sub-layer of the advanced menu |
| → NEXT | Move to this item and press the "ENTER" button to go the next page. |
| ← BACK | Move to this item and press "ENTER" button to go the previous page. |

6.1 QUICK SEARCH

In this menu list, you can search any specific events by time and directly play the file you find. Move to "QUICK SEARCH", and press "ENTER" button.

You will see a similar screen as the following:

| | | TIME SEARCH | | | |
|--------------|--------------------|------------------------|--------------|--|--|
| | DATE | 2007 / OCT / 10 | 21 : 30 : 00 | | |
| MENU | SEARCH HDD | | ALL HDD | | |
| QUICK SEARCH | START | | | | |
| RECORD | | | | | |
| TIMER | | | | | |
| DATE | | | | | |
| ADVANCE | PLEASE CONSULT YOU | R INSTALLER FOR ADVANC | E SETTING | | |
| | †↓ SELECT ← BACK | → NEXT ← ENTER | | | |

The submenu items are described below:

1) <u>DATE</u>

Select the specific time period (YEAR / MONTH / DAY / HOUR / MIN) that you want to search.

2) SEARCH HDD

Change to the HDD you want if there are more than 1 HDD in your DVR.

3) <u>START</u>

Move to "START" and press "ENTER" button to search and directly playback the recorded files.

6.2 RECORD

In this menu list, you can set record settings. Press "MENU" button on the front panel to enter the main menu list. The default admin password is **0000**. Enter the default password, and press "ENTER". Users can change the password later.

Move to "RECORD", and press " ENTER". The screen will show the following options:

| | RECORD | |
|--------------|---|---------|
| | IMAGE SIZE | FRAME |
| MENU | QUALITY | BEST |
| QUICK SEARCH | MANUAL RECORD ENABLE | ON |
| RECORD | EVENT RECORD ENABLE | ON |
| TIMER | TIMER RECORD ENABLE | ON |
| DATE | MANUAL RECORD IPS | 30 |
| ADVANCE | EVENT RECORD IPS | 30 |
| | TIMER RECORD IPS | 30 |
| | PRE-ALARM RECORD | ON |
| | OVERWRITE | ON |
| | | |
| | PLEASE CONSULT YOUR INSTALLER FOR ADVANCE | SETTING |
| | †↓ SELECT ← BACK → NEXT ← ENTER | |

The submenu items are described below:

1) IMAGE SIZE

select FRAME or CIF.

2) <u>QUALITY</u>

Select one of the 4 quality options: BEST, HIGH, NORMAL and BASIC.

3) MANUAL RECORD ENABLE

Start / stop the manual recording function.

4) <u>EVENT RECORD ENABLE</u>

Start / stop the event recording function. When this function is enabled, the recording will be triggered by any motion or external alarm.

5) TIMER RECORD ENABLE

Start / stop the timer recording function.

6) MANUAL RECORD IPS

Select the images per second for MANUAL RECORD.

7) EVENT RECORD IPS

Select the images per second for EVENT RECORD (Recording that is triggered by alarm or motion).

8) TIMER RECORD IPS

Select the images per second for TIMER RECORD (Recording that is activated according to the scheduled time.). The IPS options are as following:

| NTSC | | PAL | |
|-------|--------------------|-------|--------------------|
| FRAME | 30 / 15 / 7 / 3 | FRAME | 25 / 12 / 6 / 3 |
| CIF | 120 / 60 / 30 / 15 | CIF | 100 / 50 / 25 / 17 |

9) PRE-ALARM RECORD

Select to enable or disable the pre-alarm function (ON / OFF). When pre-alarm and event recording functions are both activated, the DVR will record 8MB data before any alarm / motion is triggered.

10) OVERWRITE

Select to overwrite previous recorded data in your HDD. When the HDD is full under O/W recording mode, this device will clear 8GB data from the oldest for continuous recording without notice.

6.2 TIMER

Press "MENU" button on the front panel to enter the main menu list. Move to "TIMER", and press "ENTER". Select to enable (ON) or disable (OFF) the recorder timer and / or detection timer functions.

| | TIMER |
|--------------|---|
| | RECORD TIMER OFF |
| MENU | DETECTION TIMER OFF |
| QUICK SEARCH | |
| RECORD | |
| TIMER | |
| DATE | PLEASE CONSULT YOUR INSTALLER FOR ADVANCE SETTING |
| ADVANCE | †↓ SELECT ← BACK → NEXT ← ENTER |
| | |

6.3 DATE

In this menu list, you can set up the system date and time for this device.

Note: When the recording function is activated, please **DO NOT** change the date or time on your DVR.

Press "MENU" button on the front panel to enter the main menu list. Move to "DATE", and press "ENTER". The screen will show the following options.

The submenu items are described below:

| MENU |
|--------------|
| QUICK SEARCH |
| RECORD |
| TIMER |
| DATE |
| ADVANCE |
| |

| | DATE |
|-------------------------|------------------------------|
| DATE | 2008 / FEB / 15 19 : 15 : 27 |
| FORMAT | Y/M/D |
| DAYLIGHT SAVING | OFF |
| PLEASE CONSULT YOUR INS | STALLER FOR ADVANCE SETTING |
| | |
| It↓ SELECT ← BACK → N | NEXI ← ENIER |
| | |

1) <u>DATE:</u>

Set the current date and time. The default order is "YEAR – MONTH – DATE HOUR : MIN : SEC".

2) <u>FORMAT</u>

Select one date format from the following 3 options: Y-M-D, M-D-Y, D-M-Y.

3) DAYLIGHT SAVING

Specify whether to use daylight-saving time (ON / OFF). If it's set to ON, press "ENTER" to go to its submenu for further settings. You will see a similar screen as following.

| DAYLIGHT SAVING | | | | | | |
|----------------------------------|-------------------|----------|--|--|--|--|
| START TIME | 1ST - SUN - MAR | 24:00:00 | | | | |
| END TIME | LAST - SUN - OCT | 24:00:00 | | | | |
| ADJUST | | 01:00 | | | | |
| | | | | | | |
| PLEASE CONSULT YOUR INSTALLER FC | R ADVANCE SETTING | ì | | | | |
| ↑↓ SELECT ← BACK → NEXT ← | ENTER | | | | | |

Set the start time and end time, and adjust the daylight saving time in hour. The above example means during the daylight-saving time period (starting from the 4th Sunday of March and ending on the 4th Sunday of October), the system time will plus one hour.

7. ADVANCED MENU

Press "MENU" button on the front panel to enter the main menu list. Move to "ADVANCE", and press "ENTER". The screen will show the following options.

| MENU |
|--------------|
| QUICK SEARCH |
| RECORD |
| TIMER |
| DATE |
| ADVANCE |

| ADVANCE |
|--------------|
| CAMERA |
| DETECTION |
| REMOTE |
| DISPLAY |
| ALERT |
| SYSTEM |
| NETWORK |
| BACKUP |
| HDD INFO |
| EVENT SEARCH |
| EVENT LOG |
| |

7.1 CAMERA

In this submenu, you can make advanced camera settings, such as changing the camera title, or adjust the brightness. Move to "CAMERA", and press "ENTER". You will see a similar screen as the following:

| ADVANCE | | | | CAMERA | ۱. | | |
|--------------|---------|---------|----------|----------|----------|---------|------|
| CAMERA | TITLE | BRIG | CONT | SATU | HUE | COV | REC |
| DETECTION | CH1 | 110 | 120 | 128 | 128 | NO | ON |
| DISPLAY | CH2 | 110 | 120 | 128 | 128 | NO | ON |
| REMOTE | CH3 | 110 | 120 | 128 | 128 | NO | OFF |
| ALERT | CH4 | 110 | 120 | 128 | 128 | NO | OFF |
| SYSTEM | | | | | | | |
| NETWORK | PLEASE | CONSULT | YOUR INS | TALLER F | FOR ADVA | NCE SET | TING |
| BACKUP | ↑↓ SELE | ECT + B | ACK → N | IEXT ⊷ | ENTER | | |
| HDD INFO | | | | | | | |
| EVENT SEARCH | | | | | | | |
| EVENT LOG | | | | | | | |

The submenu items are described below:

1) <u>TITLE</u>

You can change the default camera naming here. The default title is the channel number. Move to the camera title you want to change, and press "ENTER" to access the character selection screen. Assign a new name to the camera up to six characters (letters or symbols).

2) BRIG/CONT/SATU/HUE

You can adjust the brightness/contrast/saturation/hue of each channel here. The default value of BRIG is 110, and others are 128. The value is adjustable from 0 to 255.

3) <u>COV.</u>

Select if you want to mask the selected channel under recording (YES/NO). When this function is activated, the wording "COV." will be shown on the screen.

4) <u>REC</u>

Select if you want to enable recording for the selected channel (YES/NO). When this function is activated, the symbol ", will be shown on the channel screen.

7.2 DETECTION

In this submenu, you can set up detection-related functions: DETECTION SETUP and DETECTION TIMER. Move to "DETECTION", and press "ENTER". The screen will show the following options.

| ADVANCE | | | | DETEC | CTION | | | |
|--------------|--------|-------|----------|--------|--------|-------|--------|--------|
| CAMERA | TITLE | DET | AREA | LS | SS | TS | RE | ALARM |
| DETECTION | CH1 | ON | SETUP | 07 | 03 | 02 | 10 | OFF |
| REMOTE | CH2 | OFF | SETUP | 07 | 03 | 02 | 10 | N.C. |
| DISPLAY | CH3 | OFF | SETUP | 07 | 03 | 02 | 10 | N.O. |
| ALERT | CH4 | OFF | SETUP | 07 | 03 | 02 | 10 | OFF |
| SYSTEM | | | | | | | | |
| NETWORK | PLEASE | | ULT YOUR | INSTAL | LER FC | RADV | ANCE S | ETTING |
| BACKUP | ↑↓ SEL | ECT 🖣 | ⊢ BACK | → NEXT | r 4 | ENTER | | |
| HDD INFO | | | | | | | | |
| EVENT SEARCH | | | | | | | | |
| EVENT LOG | | | | | | | | |

The submenu items are described below:

1) <u>TITLE</u>

Show the camera title of each channel set in "CAMERA".

2) <u>DET</u>

Select if you want to activate the motion detection function for the selected channel (ON/OFF).

3) <u>AREA</u>

Press "ENTER" button to set the detection area. You will see similar screens as the following:

Pink blocks represent the area that is not being detected while the transparent blocks are the area under detection.



Transparent blocks are the area under detection.



Press "UP" / "DOWN" button to choose the height of the area.



Press "ENTER" button to confirm the start area.



You can also set up multi-detection area.



Press "LEFT" / "RIGHT" button to choose the width of the detection area.



When any movement is detected, you will see the grids are flashing.

4) <u>LS</u> (Level of Sensitivity)

"LS" is to set the sensitivity of comparing two different images. The smaller the value is, the higher sensitivity for motion detection. The highest sensitivity setting is 00, and the lowest sensitivity setting is 15. The default value is 07.

5) <u>SS</u> (Spatial Sensitivity)

"SS" is to set the sensitivity for detecting the size of one object (the number of the grids) on the screen. The smaller the value is, the higher sensitivity for motion detection.

The highest sensitivity setting is 00, and the lowest sensitivity setting is 15. The default setting is 03.

Note: The default setting of SS is 03, which means once an object is detected more than 3 grids, the system will get triggered. So the value of SS must be less than the number of grids that you set up for the motion detection area.

6) <u>TS</u> (Time of Sensitivity)

"TS" is to set the sensitivity regarding how long one object stays in the detection area and triggers the recording. The smaller the value is, the higher sensitivity for motion detection.

The highest sensitivity setting is 00, and the lowest sensitivity setting is 15. The default setting is 02.

7) <u>RE</u> (Reference)

"RE" is to set a reference for detection. The default value is 10, which means the DVR will compare the 1st image and the 10th image according to the sensitivity of LS, SS, TS simultaneously.

The bigger the value is, the higher sensitivity for motion detection. The highest sensitivity is 61.

8) <u>ALARM</u>

Select N.C. (Normally Closed) / N.O. (Normally open) / OFF for the alarm polarity. The default alarm value is OFF.

7.3 REMOTE

In this menu list, you can set up remote devices to work properly.

Move to "REMOTE", and press "ENTER". You will see a similar screen as the following:

| ADVANCE | |
|--------------|--|
| CAMERA | |
| DETECTION | |
| REMOTE | |
| DISPLAY | |
| ALERT | |
| SYSTEM | |
| NETWORK | |
| BACKUP | |
| HDD INFO | |
| EVENT SEARCH | |
| EVENT LOG | |

| | REMOTE | | | | | | | | |
|----------|------------|------------|---------------|---------|--|--|--|--|--|
| TITLE | DEVICE | ID | PROTOCOL | RATE | | | | | |
| CH1 | PTZ | 000 | P-D | 2400 | | | | | |
| CH2 | CAMERA | 000 | NORMAL | 2400 | | | | | |
| СНЗ | CAMERA | 000 | NORMAL | 2400 | | | | | |
| CH4 | CAMERA | 000 | NORMAL | 2400 | | | | | |
| | | | | | | | | | |
| PLEASE C | ONSULT YOU | R INSTALLE | R FOR ADVANCE | SETTING | | | | | |
| ↑↓ SELEC | T + BACK | → NEXT | ← ENTER | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

The submenu items are described below:

1) <u>TITLE</u>

Show the camera title of each channel set in "CAMERA".

2) <u>DEVICE</u>

Select the device type (CAMERA / PTZ) according to the connected camera for each channel.

3) <u>ID</u>

Set the ID number $(0 \sim 255)$ for a PTZ camera.

After connecting to a PTZ camera correctly, the default ID of the PTZ camera will be shown on the screen.

4) PROTOCOL

Select NORMAL (our protocol) or P-D (PELCO-D) protocol.

5) <u>RATE</u>

Set the baud rate of each channel (2400 / 4800 / 9600 / 19200 / 57600 / 115200). For the connected cameras, such as PTZ and speed dome cameras, etc., please make sure their baud rate setting is the same as the setting here.

7.4 DISPLAY

In this menu list, you can check and change some display settings.

Move to "DISPLAY", and press "ENTER". You will see a similar screen as the following:

| ADVANCE | DISPLAY | |
|--------------|--|------------|
| CAMERA | DE-INTERLACE | ON |
| DETECTION | FULL SCREEN DWELL DURATION (SEC) | 03 |
| REMOTE | CHANNEL TITLE | ON |
| DISPLAY | EVENT STATUS | ON |
| ALERT | DATE DISPLAY | ON |
| SYSTEM | VGA OUTPUT (For Model 4 & 5 only) | 1024 X 768 |
| NETWORK | | |
| BACKUP | PLEASE CONSULT YOUR INSTALLER FOR ADVANCE SE | TTING |
| HDD INFO | ↑↓ SELECT ← BACK → NEXT ← ENTER | |
| EVENT SEARCH | | |
| EVENT LOG | | |

The submenu items are described below:

1) <u>DE-INTERLACE</u>

Select to enable or disable "DE-INTERLACE" function (ON / OFF).

- FULL SCREEN DWELL DURATION (SEC) Set the full screen dwell duration time (3 / 5 / 10 / 15 seconds).
- <u>CHANNEL TITLE</u> Select to display the channel title or not (ON / OFF).
- 4) <u>EVENT STATUS</u>

Select to display the symbols of the event or not (ON / OFF).

5) DATE DISPLAY

Select to display the date or not (ON / OFF).

6) VGA OUTPUT (For Model 4 & 5 only)

Select the VGA output resolution. There are seven options for your choice: 800 x 600 / 1024 x 768 (default) / 1280 x 1024 / 1440 x 900 / 1400 x 1050 / 1680 x 1050 / 1600 x 1200

7.5 ALERT

In this menu list, you can set alerts for different kinds of situations, such as when HDD is full.

Move to "ALERT", and press "ENTER". You will see a similar screen as the following:

| ADVANCE | ALERT | | | |
|--------------|---|---|--|--|
| CAMERA | EXT. ALERT | ON | | |
| DETECTION | INT. BUZZER | ON | | |
| REMOTE | KEY BUZZER | ON | | |
| DISPLAY | VLOSS BUZZER | ON | | |
| ALERT | MOTION BUZZER | ON | | |
| SYSTEM | ALARM BUZZER | ON | | |
| NETWORK | HDD BUZZER | ON | | |
| BACKUP | ALARM DURATION (SEC) | 05 | | |
| HDD INFO | HDD NEARLY FULL (GB) | 05 | | |
| EVENT SEARCH | | | | |
| EVENT LOG | PLEASE CONSULT YOUR INSTALLER FOR ADVAN | PLEASE CONSULT YOUR INSTALLER FOR ADVANCE SETTING | | |
| | ↑↓ SELECT ← BACK → NEXT ← ENTER | | | |

The submenu items are described below:

1) <u>EXT. ALERT</u>

Select to enable or disable the sound when any external alarm is triggered (ON / OFF).

2) <u>INT. BUZZER</u>

Select to enable or disable the sound (ON / OFF) for all the internal buzzers: KEY BUZZER, VLOSS BUZZER, MOTION BUZZER, ALARM BUZZER, and HDD BUZZER.

Note: When this item is set to OFF, item 3) to item 7) will be disabled even though they are set to ON.

3) KEY BUZZER

Select to enable or disable the sound when pressing the buttons on the front panel (ON / OFF).

4) VLOSS BUZZER

Select to enable or disable the sound when video loss happened (ON / OFF).

5) MOTION BUZZER

Select to enable or disable the sound when any motion alarm is triggered (ON / OFF).

6) ALARM BUZZER

Select to enable or disable the sound when any internal alarm is triggered (ON / OFF).

7) HDD BUZZER

Select to enable or disable the sound (ON / OFF) when the HDD remaining capacity reaches to the value set in "HDD NEARLY FULL (GB)".

8) ALARM DURATION (SEC)

Press "UP" / "DOWN" to set the duration time of alarm recording in second (5 / 10 / 20 / 40).

9) HDD NEARLY FULL (GB)

If HDD BUZZER is enabled, press "UP" / "DOWN" to have a buzzer notification when the HDD available capacity is 5/10/15/20 GB left.

7.6 SYSTEM

In this menu list, you can check or change some system settings.

Move to "SYSTEM", and press "ENTER". You will see a similar screen as the following:

| ADVANCE | | SYSTEM | |
|--------------|---|-----------------------------|--|
| CAMERA | SERIAL TYPE | RS485 | |
| DETECTION | BAUDRATE | 2400 | |
| REMOTE | HOST ID | 0 | |
| DISPLAY | PASSWORD | XXXX | |
| ALERT | RESET DEFAULT | RESET | |
| SYSTEM | CLEAR HDD | HDD-MASTER-1 | |
| NETWORK | UPGRADE | START | |
| BACKUP | AUTO KEYLOCK | NEVER | |
| HDD INFO | LANGUAGE | ENGLISH | |
| EVENT SEARCH | VIDEO FORMAT | NTSC | |
| EVENT LOG | VERSION | 1236-1012-1033-1018-M3-6C1B | |
| | | | |
| | PLEASE CONSULT YOUR INSTALLER FOR ADVANCE SETTING | | |
| | ↑↓ SELECT ← BACK → NEXT ← ENTER | | |

The submenu items are described below:

1) <u>SERIAL TYPE</u>

Press "UP" / "DOWN" to set the serial type of the DVR (RS485 / RS232).

2) <u>BAUDRATE</u>

Press "UP" / "DOWN" to set the baud rate of the DVR (2400 / 9600 / 19200 / 57600 / 115200).

3) HOST ID

Press "UP" / "DOWN" to set the ID of the DVR (0 ~ 255).

4) PASSWORD

Press "ENTER" to reset the password for accessing the DVR system (ADMIN PASSWORD or GUEST PASSWORD). You can set the password up to 4 digits.

Note: Users who use guest password to access the DVR will be only allowed to view the live streaming video and sequence display, shift the channel display, and lock keys.

5) <u>RESET DEFAULT</u>

Press "ENTER" to reset all settings as default, and select "YES" to confirm or "NO" to cancel.

6) <u>CLEAR HDD</u>

Press "ENTER", and select "YES" to confirm to clear HDD or "NO" to cancel.

7) <u>UPGRADE</u>

Press "ENTER", and select "YES" to confirm upgrade or "NO" to cancel.

Note: To use this function, you need to have the upgrade file saved in a compatible USB flash drive, and insert it into the USB port at the front or rear panel.

Note: Do not disconnect the power of your DVR while the upgrade process is in progress, or the DVR functions may not work normally or be unable to use.

8) AUTO KEYLOCK

Set the time-out in second after which the key lock function is activated (Never / 10 / 30 / 60).

9) LANGUAGE (Support multi-language)

Press "ENTER" to select the language of the OSD.

10) VIDEO FORMAT

Here shows the information of the DVR video format (NTSC / PAL).

11) VERSION

Here shows the firmware version information.

7.7 NETWORK

In this menu list, you can set up the network.

Move to "NETWORK", and press "ENTER". You will see a similar screen as the following:

| ADVANCE | NET | NETWORK | | |
|--------------|---------------------------|--------------------------|--|--|
| CAMERA | NETWORK TYPE | STATIC | | |
| DETECTION | IP | 192 . 168 . 001 . 012 | | |
| REMOTE | GATEWAY | 192 . 168 . 001 . 254 | | |
| DISPLAY | NETMASK | 255 . 255 . 252 . 000 | | |
| ALERT | PRIMARY DNS | 168 . 095 . 001 . 001 | | |
| SYSTEM | SECONDARY DNS | 139 . 175 . 055 . 244 | | |
| NETWORK | PORT | 0080 | | |
| BACKUP | | | | |
| HDD INFO | PLEASE CONSULT YOUR INSTA | LLER FOR ADVANCE SETTING | | |
| EVENT SEARCH | ↑↓ SELECT ← BACK → NE> | KT ← ENTER | | |
| EVENT LOG | | | | |

The submenu items are described below:

• STATIC

1) <u>NETWORK TYPE</u>

Select the network type as STATIC and set all the information needed in the DVR.

2) NETWORK INFORMATION (IP / GATEWAY / NETMASK)

Key in all the network information obtained from your ISP (Internet Service Provider).

3) DNS (PRIMARY DNS / SECONDARY DNS)

Key in the IP address of the domain name server obtained from your ISP (Internet Service Provider).

4) <u>PORT</u>

The valid number ranges from 1 to 9999. The default value is 80. Typically, the TCP port used by HTTP is 80. However in some cases, it is better to change this port number for added flexibility or security. See the example below:

| STATIC | | |
|---|-----------------------|--|
| NETWORK TYPE | STATIC | |
| IP | 192 . 168 . 001 . 012 | |
| GATEWAY | 192 . 168 . 001 . 254 | |
| NETMASK | 255 . 255 . 252 . 000 | |
| PRIMARY DNS | 168 . 095 . 001 . 001 | |
| SECONDARY DNS | 139 . 175 . 055 . 244 | |
| PORT | 0080 | |
| | | |
| PLEASE CONSULT YOUR INSTALLER FOR ADVANCE SETTING | | |
| ↑↓ SELECT ← BACK → NEXT ← E | NTER | |
| | | |

• PPPOE

1) <u>NETWORK TYPE</u>

Select the network type as PPPOE.

2) USER NAME / PASSWORD

Set the "username" and "password" subscribed from your ISP supplier

3) DNS (PRIMARY DNS / SECONDARY DNS)

Key in the IP address of the domain name server obtained from your ISP (Internet Service Provider).

4) <u>PORT</u>

The valid number ranges from 1 to 9999. The default value is 80. Typically, the TCP port used by HTTP is 80. However in some cases, it is better to change this port number for added flexibility or security. See the example below:

| PPPOE | | | |
|--|-----------------------|--|--|
| NETWORK TYPE | PPPOE | | |
| USER NAME | EMPTY | | |
| PASSWORD | EMPTY | | |
| IP | 000 . 000 . 000 . 000 | | |
| GATEWAY | 000 . 000 . 000 . 000 | | |
| NETMASK | 000 . 000 . 000 . 000 | | |
| PRIMARY DNS | 168 . 095 . 001 . 001 | | |
| SECONDARY DNS | 139 . 175 . 055 . 244 | | |
| PORT | 0800 | | |
| PLEASE CONSULT YOUR INSTALLER FOR ADVANCE SETTING ↑↓ SELECT ← BACK → NEXT ← ENTER | | | |

Note: The PPPOE function needs to have one "username" and one "password" subscribed from one ISP supplier, and a "DDNS account" to correspond the dynamic IP address to a specific "Hostname".

DHCP

1) <u>NETWORK TYPE</u>

Select the network type as DHCP.

2) DNS (PRIMARY DNS / SECONDARY DNS)

Key in the IP address of the domain name server obtained from your ISP (Internet Service Provider).

3) <u>PORT</u>

The valid number ranges from 1 to 9999. The default value is 80. Typically, the TCP port used by HTTP is 80. However in some cases, it is better to change this port number for added flexibility or security.

See the example below:

| DHCP | | | |
|---|-----------------------|--|--|
| NETWORK TYPE | DHCP | | |
| IP | 000.000.000.000 | | |
| GATEWAY | 000.000.000.000 | | |
| NETMASK | 000.000.000.000 | | |
| PRIMARY DNS | 168 . 095 . 001 . 001 | | |
| SECONDARY DNS | 139 . 175 . 055 . 244 | | |
| PORT | 0080 | | |
| | | | |
| PLEASE CONSULT YOUR INSTALLER FOR ADVANCE SETTING | | | |
| ↑↓ SELECT ← BACK → NEXT ← ENTE | ER | | |
| | | | |

Note: This DHCP function needs to be supported by a router or a cable modem network with DHCP services, and a "DDNS account" to correspond the dynamic IP address to a specific "Hostname", for this function to work properly.

7.8 BACKUP (Model 3, 4 & 5 Only)

The backup file can be played directly in your PC via the supplied licensed **software AP**, or via other **media players** (ex: Windows Media Player or RealPlayer) after the file is converted to "**AVI**" format.

Note: Before making a video backup with audio, you need to check whether there's any audio camera connected to the channel which supports audio recording, and there's any recorded data for the channel.

BACKUP USB BACKUP

Move to "BACKUP", and press "ENTER". You will see the following options:

| ADVANCE |
|--------------|
| CAMERA |
| DETECTION |
| REMOTE |
| DISPLAY |
| ALERT |
| SYSTEM |
| NETWORK |
| BACKUP |
| HDD INFO |
| EVENT SEARCH |
| EVENT LOG |

1) USB BACKUP

Before making USB backup, please check if:

a) The USB flash drive is supported by your DVR. If not, the message "USB ERROR" will be shown on the screen.

For the list of the compatible USB flash drives, please refer to "APPENDIX 2 COMPATIBLE USB FLASH DRIVE BRAND" at page 57.

- b) The format of your USB flash drive is "FAT 32". If no, please format it to "FAT 32" in your PC.
- c) There is no data in the USB flash drive. If yes, it's recommended to clear all data in the USB flash drive before starting the backup.

Note: You can backup up to 2GB video data for one-time USB backup. To backup more data, please set the time & channel(s) you want, and start USB backup again.

Move to "BACKUP", and press "ENTER". You will see a similar screen as the following:

| BACKUP | | USB BACKUP | | | | |
|------------|----------------|------------|----|--------------|--------------|--|
| USB BACKUP | START TIME | | 20 | 06 – 12 – 01 | 21 : 35 : 00 | |
| | END TIME | | 20 | 06 – 12 – 01 | 21 : 45 : 00 | |
| | AVAILABLE SIZE | | | | 1.460 GB | |
| | CHANNEL | ☑ 01 | 02 | 03 | 04 | |
| | HDD NUM | | | HDC |)-MASTER-1 | |

The submenu items are described below:

START TIME

Select the start time of the backup.

• END TIME

Select the end time of the backup.

AVAILABLE SIZE

Display the available capacity in the inserted USB flash drive.

• <u>CHANNEL</u>

Select channels by pressing "ENTER" to change the symbol in front of the channel number.

Symbol " \square " means that this channel is selected to backup.

Symbol " \square " means that this channel is not selected to backup.

• HDD NUM

Press "ENTER" to select the HDD containing the data you need.

7.9 HDD INFO

In this menu list, you can view the remaining capacity of all the connected HDDs in this device. Move to "HDD INFO", and press "ENTER". You will see a similar screen as the following:

| ADVANCE | | HDD INFO | | | |
|--------------|---------------|---|-------------|---------------|--|
| CAMERA | HDD NUM | HDD SIZE (GB) | HDD NUM | HDD SIZE (GB) | |
| DETECTION | HDD-MASTER-1 | 368 | HDD-SLAVE-1 | NO HDD | |
| REMOTE | | | | | |
| DISPLAY | | | | | |
| ALERT | PLEASE CONSUL | PLEASE CONSULT YOUR INSTALLER FOR ADVANCE SETTING | | | |
| SYSTEM | †↓ SELECT ← E | ↑↓ SELECT ← BACK → NEXT ← ENTER | | | |
| NETWORK | | | | | |
| BACKUP | | | | | |
| HDD INFO | | | | | |
| EVENT SEARCH | | | | | |

7.10 EVENT SEARCH

EVENT LOG

In this menu list, you can search any event by motion or alarm.

Move to "EVENT SEARCH", and press "ENTER". You will see a similar screen as the following:

| ADVANCE |
|--------------|
| CAMERA |
| DETECTION |
| REMOTE |
| DISPLAY |
| ALERT |
| SYSTEM |
| NETWORK |
| BACKUP |
| HDD INFO |
| EVENT SEARCH |
| EVENT LOG |

| EVENT SEARCH | | | | |
|---|-----------------|----------|--|--|
| DATE | 2008 / JUN / 17 | 22:48:00 | | |
| CHANNEL | | 01 | | |
| EVENT | | MOTION | | |
| SEARCH HDD | | ALL HDD | | |
| START | | | | |
| | | | | |
| PLEASE CONSULT YOUR INSTALLER FOR ADVANCE SETTING | | | | |
| ↑↓ SELECT ← BACK → NEXT ← | ENTER | | | |
| | | | | |

The submenu items are described below:

1) <u>DATE</u>

Set the date and time you want to search for events.

2) <u>CHANNEL</u>

Press "UP" / "DOWN" to select the channel.

3) <u>EVENT</u>

Select the event type: MOTION or ALARM.

4) <u>SEARCH</u>

You can choose to search only the selected HDD (SELECTED) or all the connected HDDs (ALL HDD) by pressing "UP" / "DOWN".

After setting all search criteria, press "ENTER" to start search and directly play if any file is found.

Note: The file found will be played with the fast speed.

7.11 EVENT LOG

In this menu list, you can view all the event information (event type, time and channel) or clear all log records. Move to "EVENT LOG", and press "ENTER". You will see the following options:

| ADVANCE | | EVENT LOG | | | | |
|--------------|--------------------|--|----------|---------|--|--|
| CAMERA | EVENT | TIME | | COMMENT | | |
| DETECTION | | | | | | |
| REMOTE | POWER ON | 2007 / OCT / 10 | 20:27:49 | 16 | | |
| DISPLAY | VLOSS | 2007 / OCT / 10 | 20:05:05 | 06 | | |
| ALERT | VLOSS | 2007 / OCT / 10 | 20:00:11 | 09 | | |
| REMOTE | VLOSS | 2007 / OCT / 10 | 16:00:08 | 14 | | |
| SYSTEM | VLOSS | 2007 / OCT / 10 | 15:09:32 | 13 | | |
| NETWORK | VLOSS | 2007 / OCT / 10 | 11:00:08 | 12 | | |
| BACKUP | VLOSS | 2007 / OCT / 10 | 10:27:33 | 11 | | |
| HDD INFO | VLOSS | 2007 / OCT / 10 | 08:05:55 | 10 | | |
| EVENT SEARCH | RESET TO DEFAULT | 2007 / OCT / 10 | 08:05:26 | 09 | | |
| EVENT LOG | POWER ON | 2007 / OCT / 10 | 08:00:22 | 08 | | |
| | | | | | | |
| | PREV NEXT | - | | | | |
| | PLEASE CONSULT YOU | PLEASE CONSULT YOUR INSTALLER FOR ADVANCE SETTINGS | | | | |
| | †↓ SELECT ← BACK | → NEXT ← ENTE | ER | | | |

8. REMOTE OPERATION


You can also control the DVR remotely via the supplied licensed software AP (hereafter called the "AP"), IE web browser, and Apple's QuickTime player.

8.1 Supplied Licensed Software AP

8.1.1 Installation & Network Connection

1) Install the software

Step1: Place the supplied CD into your CD-ROM or DVD-ROM drive. The program will be automatically run.



Step2: Click "Licensed Software AP" to install Video Viewer, or click "Download Latest Version" under "Licensed Software AP" to download the latest version of Video Viewer from the Internet.

Step3: follow the on-screen instructions to finish the installation. When the installation is completed, a shortcut icon "" will be placed on your PC desktop.

2) Network Connection

- Local Connection (via LAN)
 - a) Connect the DVR to your PC via a RJ-45 network line. The default DVR IP address is "192.168.1.10", and the default user name and password are both "admin".
 - b) Set the PC's IP address as "192.168.1.XXX " (1~255, except 10) in order to make the PC and DVR under the same domain.
 - c) Double-click "???" icon on your PC desktop to enter the AP control panel. By defaults, the "Address Book" ([]]) panel will be displayed on the right side of the AP control panel.
 - d) Click "■11■" (Address Book) → "■11■" (Add) button to key in the default IP address, user name, password, and port number of the DVR you intend to connect.

OR

Click " \square (Search) \rightarrow " \square " (Refresh) to search the available IP address(es) of other DVR(s) under the same domain as your PC's IP address. The found address(es) will be listed, and can be added into the address book by clicking " \square " (Add into address book). For details, please see " \square " (Search) at page 35.

e) Double-click the IP address you just added into the address book to log in. When you're logged in, the

"Event" panel will be shown by defaults.

- Remote Connection (via Internet)
 - a) Double-click "???" icon on your PC desktop to enter the AP control panel. By defaults, the "Address Book" panel will be displayed on the right side of the AP control panel.
 - b) Click " (Address Book) → " (Add) button to key in the IP address, user name, password, and port number of the DVR you intend to connect.

The default DVR values are as follows:

| ltem | Default Value | | |
|------------|---------------|--|--|
| IP address | 192.168.1.10 | | |
| User name | admin | | |
| Password | admin | | |
| Port | 80 | | |

OR

Click " \square (Search) \rightarrow " \square (Refresh) to search the available IP address(es) of other DVR(s) under the same domain as your PC's IP address. The found address(es) will be listed, and can be added into the address book by clicking " \square (Add into address book). For details, please see " \square " (Search) at page 35.

c) Double-click the IP address you just added into the address book to log in. When you're logged in, the "Event" panel will be shown by defaults.

8.1.2 General AP Operation

Record

To record remotely at the same time when any event alarm is triggered at the DVR side, click "

| (Miscellaneous Control) \rightarrow " | (Record Setting) to go to the "Record Setting" page. |
|---|--|
| Record Setting | × |

| ecord On/ | | | | | nt Record Time | |
|-----------|--------------|-----------|-------------------|--------------------|----------------|--|
| Manual | Schedul | e 🔽 Motio | on 🗆 Alarm | Prev. | | Sec. |
| Hard Di | sk Overwrite | • | | Post | <u> </u> | Sec. |
| Record Ti | me Range | | | | | |
| Weekly | Custom | | Schedule | 💻 Alarm | Motion | |
| + - | | 0 1 2 3 | 4 5 6 7 8 | 9 10 11 12 13 14 | | |
| : | Sun | | ***************** | ****************** | | a de la calenda de |
| | /lon | | | | | |
| - | ſue | | | | | |
| ۷ | Ved | ********* | | | | entinetin |
| | ſhu | | | | | |
| | Fri | | | | | |
| | Sat | | | ****** | | |
| Record Pa | ath | | | | | |
| Drive | Total(MB) | Free (MB) | Reserve(MB) | Video Path | Picture Path | |
| V C: | 76308 | 46064 | 2048 | C:\tempvideo\ | C:\temppicture | 8 |
| E: | 78528 | 41019 | 2048 | EA | EA | |
| F: | 131061 | 85301 | 2048 | FA | FA | |
| | | | | | | |

In the "Record Setting" page, you can set the following items:

- Record type
- Hard disk overwriting
- Pre- / post-alarm record time
- Record time setting
- Record path

If "Manual" is checked, click " (Record) on the main control panel to start the manual recording immediately, and the recordings will be saved in the specified location. The red text indication "REC" will be shown at the top left corner of the image display view.

If "Motion" and / or "Alarm" are checked, the recording function will also be enabled at the remote side when any event is triggered at the DVR side, and the recordings will be saved in the specified location.

For details, please see "Record Setting" at page 38.

Playback

To play a recorded file recorded at your PC side, click " $\boxed{100}$ " (Miscellaneous Control) \rightarrow " $\boxed{1000}$ " (Status List), and select the "Record" tab or "Backup" tab. A list of all the recordings will be shown by defaults, and you can also sort out the logs you want to speed up the search time.

For details, please see "Status List" at page 50.

NOTE: You can't select a single channel for video playback. During the playback mode, you can only see the quad view.

| | lange Inge Unit On | e Day 🔻 | Prev. Ne | ×t Record Type - | ▽ A | larm |
|--------|-----------------------|-------------------|-------------------|----------------------------------|------------|---------|
| From: | 2008/ SEP. /23 | To: | 2008/ 九月 /23 | Motion | R B | RETR |
| lecord | Backup Event | | | | Qu | ery |
| Event | IP | Start Time | End Time | File Path | Reserve | Error 🔺 |
| User | 192.168.1.12 | 09/23/08 20:41:07 | 09/23/08 20:41:07 | C:\tempvideo\20080923204107_off: | | |
| User | 192.168.1.12 | 09/23/08 20:36:45 | 09/23/08 20:36:45 | C:\tempvideo\20080923203645_off: | | |
| User | 192.168.1.12 | 09/23/08 20:18:56 | 09/23/08 20:41:07 | C:\tempvideo\20080923201856_off: | | |
| User | 192.168.1.12 | 09/23/08 20:13:22 | 09/23/08 20:36:45 | C:\tempvideo\20080923201322_off: | | |
| Motion | 192.168.1.12 | 09/23/08 20:05:30 | 09/23/08 20:05:35 | C:\tempvideo\20080923200530_off: | | |
| Motion | 192.168.1.12 | 09/23/08 20:05:30 | 09/23/08 20:05:35 | C:\tempvideo\20080923194836_off: | | |
| Motion | 192.168.1.12 | 09/23/08 20:05:30 | 09/23/08 20:05:35 | C:\tempvideo\20080923195524_off: | | |
| User | 192.168.1.12 | 09/23/08 19:55:24 | 09/23/08 20:18:56 | C:\tempvideo\20080923195524_off: | | |
| User | 192.168.1.12 | 09/23/08 19:48:36 | 09/23/08 20:13:22 | C:\tempvideo\20080923194836_off: | | |
| User | 192.168.1.12 | 09/23/08 19:32:55 | 09/23/08 19:55:24 | C:\tempvideo\20080923193255_off: | | |
| User | 192.168.1.12 | 09/23/08 19:24:51 | 09/23/08 19:48:36 | C:\tempvideo\20080923192451_off: | | |
| User | 192.168.1.12 | 09/23/08 19:10:26 | 09/23/08 19:32:55 | C:\tempvideo\20080923191026_off: | | |
| User | 192.168.1.12 | 09/23/08 19:01:05 | 09/23/08 19:24:51 | C:\tempvideo\20080923190105_off: | | |
| User | 192.168.1.12 | 09/23/08 18:47:57 | 09/23/08 19:10:26 | C:\tempvideo\20080923184757_off: | | |
| Motion | 192.168.1.12 | 09/23/08 18:46:17 | 09/23/08 18:46:28 | C:\tempvideo\20080923183720_off: | | |
| Motion | 192.168.1.12 | 09/23/08 18:46:17 | 09/23/08 18:46:28 | C:\tempvideo\20080923182528_off: | | |
| Motion | 192.168.1.12 | 09/23/08 18:46:17 | 09/23/08 18:46:28 | C:\tempvideo\20080923184617_off: | | |
| User | 192.168.1.12 | 09/23/08 18:37:20 | 09/23/08 19:01:05 | C:\tempvideo\20080923183720_off: | | |
| Tota | l Records: | 133 Delete | Delete All | Play Repair | App | ply |

To immediately play a recording, select a log from the list, and click "Play" button, or double-click the selected log. Then, the playback control panel will be shown at the bottom of the main control panel similar to the following.



For the playback control panel details, please see "Playback Screen" at page 50.

Network Backup

Click "III" (Miscellaneous Control) \rightarrow "III" (Backup) to go into the "Download" page as follows, and you can

select a specific time range or event to make a video backup remotely. For details, please see "Backup" at page 37.

| IP Address: | 192.168.1.10 💌 | | Relo | ad | Prev. Pag | e Next Page |
|---|---------------------|----------|--------|--------|---------------------|---------------------|
| Port: | 80 | | | System | 🔽 Mar | ual 🗖 Alarm |
| User Name: | admin | | | limer | Mot | ion |
| | **** | | NO. | Event | CH | Time |
| Password: | ***** | | 1 | MOTION | 1 | 2008/08/28 20:53:28 |
| | | | 2 | MOTION | 1 | 2008/08/28 20:50:05 |
| HDD Number: | MASTER-1 - Refre | sh | 3 | MOTION | 1 | 2008/08/28 20:48:14 |
| | | | 4 | MOTION | 1 | 2008/08/28 20:47:53 |
| Channel: | 1 | | 5 | MOTION | 1 | 2008/08/28 20:46:20 |
| | | | 6 | MOTION | 1 | 2008/08/28 20:44:38 |
| Start Time: | 2008/08/28 20:42:31 | T | 7 | MOTION | 1 | 2008/08/28 20:44:03 |
| | | - | 8 | MOTION | 1 | 2008/08/28 20:43:20 |
| End Time: | 2008/08/28 21:42:31 | _ | 9 | MOTION | 1 | 2008/08/28 20:42:31 |
| chu thie. | 2008/08/28 21:42:31 | <u> </u> | 10 | MOTION | 1 | 2008/08/28 20:42:12 |
| | | | 11 | MOTION | 1 | 2008/08/28 20:41:54 |
| File Path: | c:\download\ | | 12 | MOTION | 1 | 2008/08/28 20:41:40 |
| | | | 13 | MOTION | 1 | 2008/08/28 20:41:19 |
| Simultaneous Planeous Planeous Planeous | | 14 | MOTION | 1 | 2008/08/28 20:40:27 | |
| onnancanovao i | | | 15 | MOTION | 1 | 2008/08/28 20:39:20 |
| | | | 16 | MOTION | 1 | 2008/08/28 20:14:49 |
| | | | 17 | MOTION | 1 | 2008/08/28 19:51:09 |
| | 1 | | 18 | MOTION | 1 | 2008/08/28 19:43:27 |
| Down | load Cancel | | 19 | MOTION | 1 | 2008/08/28 19:41:59 |

8.1.3 AP Control Panel

After setting up the network information, login user name and password, double-click "???" on the PC desktop to open and log into the AP control panel. You will see a screen similar to the following with 7 major sections:




| Button | Function | Description |
|------------|-----------------------|--|
| N/A | Image Display | The place where the images are displayed. For details, please see "8.1.4 AP Functions" at page 35. |
| - Harrison | Address Book | Click to show the predefined IP address(es). You can add, remove or search the IP address to log in the DVR remotely. Two sub-functions are available for this button: Address Book and Search. For details, please see "Address Book " at page 35. |
| | Miscellaneous Control | Click to show the main operation functions: audio volume control, color setting, backup, DVR setting, upgrade, and find event logs. For details, please see "Miscellaneous Control 1 ," at page 36. |
| 🚷 , 🔇 | Record | Click to start / stop the manual recording. |
| 1 | Snapshot | Click to take a snapshot of the current view. The snapshot will be saved in the path you specified in "Record Setting". Please refer to "Record Setting" at page 38 for details. |
| | Information | Click to show the current network connection details. For details, please see "Information use " at page 51. |

| Button | Function | Description |
|------------------|-------------------------|--|
| | DVR Control | Click to go to the DVR control panel to operate the DVR remotely. For details, please see "DVR Control "", at page 51. |
| | | If you want to switch among the live view, playback view and download view, click the blue tab "Live1", "Play1" or "Download" to make a switch. Live1: When you are logged in, this tab with the live view is displayed by |
| Live1 Play1 Dowr | Live / Playback / | defaults. |
| | Download Display Switch | Play1 : When a video clip is selected in "Status List" and played, this tab with the palyback view is displayed. |
| | | Download : When the downloaded video clip is selected in "Status List" and played, this tab with the downloaded video clip is displayed. |
| a l | Original Size | Click to return to original size of the monitoring view. |
| | Expand All Views | To see all views in the image display area if you have many views and do not want to switch each view by clicking the blue tab described above, click to choose a proper split view (1-cut / 4-cut / 6-cut / 9-cut / 13-cut / 16-cut) which best suits your needs. |
| | | The selected view will be indicated with a red frame around it. |
| x | Close | Click to close the current image display view. If the last image display view is closed, you will be logged out automatically. |
| 1 | Close All | Click to close all the image display views. |

8.1.4 AP Functions

Address Book

This view is displayed when the AP is activated for you to log in / out the DVR from the current address list, or search the available IP address as follows:



(Address Book)

Click to view the pre-defined DVR access details.

To log in, choose one IP address from the address list, and click the address twice; to log out, click the connected IP address twice.

Tip: You can also click "X" or "M" to log out.

You can also create new IP address information, or modify or remove the current IP address information.

| Button | Function | Description |
|--------|----------|--|
| | Add | Click to directly add one IP address for login. Key in the DVR access information needed, and click "Apply" and "Close". |
| | Edit | Select one current IP address from the address list, and click this button to modify the DVR access information as needed. |
| | Remove | Select one IP address from the address list, and click this button to delete it. |

REC

When the AP is connected to more than 1 device, and not all devices are necessary to enable the manual record function, check "REC" for the connected device(s), and its manual record function will be on.

Note: When the AP is connected to more than 1 device, click " will record the live views for all the connected devices. To enable the manual record function for the specific device(s), please set from this view.

> (Search)

Click to search and view the available IP address(es) for the DVR connection. You can choose one address to add into the address book, edit the details, or update the address list.

| Button | Function | Description |
|----------|--------------------------|---|
| | Add into address book | Select from the available IP address list, and click this button to add the selected address to the address book. |
| | Setting | Select from the available IP address list, and click this button to edit the setting. |
| S | Refresh | Click to update the available IP address list. |

Miscellaneous Control


Click " (Miscellaneous Control) on the AP control panel, and six functions are available as follows:



| Button | Function | Description |
|---------------------|----------------|--|
| I n I | Color Setting | Click this button to adjust the brightness / contrast / hue / saturation for a single channel or the whole channels. For details, please see "Color Setting" at page 36. |
| 45 | Backup | To make a video backup remotely, click this button, and you will go to the download setting page. For details, please see "Network Backup" at page 34. |
| 11 | Record Setting | Click to go to the detailed record setting. Please refer to "Record Setting" at page 38 for details. |
| -0 | Server Setting | Click to go into the detailed DVR setting. Please refer to "Server Setting" at page 38 for details. |
| * | Tools | Click to update the firmware version, multilingual OSD and boot display of your DVR remotely. Please refer to "Tools" at page 48 for details. |
| # - | Status List | Click to view all event and recording logs, search the desired log(s) by date, or playback the recording of the selected log. For details, please refer to "Status List" at page 50. |

> Color Setting

Click " to go into the "Color Setting" page, and you can adjust the brightness / contrast / hue / saturation for a single channel or all channels.



Choose the desired channel from the drop-down list, and click and drag the slider to make adjustment. Click " To apply the change to the selected channel, or " T T to apply to all channels.

To return to the default values, click " (Default), and click " return" to apply the change to the selected channel, or " return" to apply to all channels.

Note: You need to be a supervisor to operate this function. For details, please see "Account" at page 40.

> Backup

Click "Click "Click "Click" (Backup) to go into the "Backup" page, and you can select a specific time range or event to make a video backup remotely.

Note: You need to be a supervisor to operate this function. For details, please see "Account" at page 40.

Note: Before enabling the network backup function, make sure the DVR is not in the playback mode, or the DVR will stop playback.

| IP Address: | 192.168.1.10 💌 | | Relo | ad | Prev. Pag | e Next Page |
|-----------------------|---------------------|---|--------------|------------------|-----------|--|
| Port: | 80 | | | System | 🗹 Mar | nual 🗖 Alarm |
| User Name: | admin | | [] 1 | limer | Mot | ion |
| Deserved | ***** | | NO. | Event | CH | Time |
| Password: | 100000 | | 1 | MOTION | 1 | 2008/08/28 20:53:28 |
| | | | 2 | MOTION | 1 | 2008/08/28 20:50:05 |
| HDD Number: | MASTER-1 - Refresh | | 3 | MOTION | 1 | 2008/08/28 20:48:14 |
| | | _ | 4 | MOTION | 1 | 2008/08/28 20:47:53 |
| Channel: | 1 | | 5 | MOTION | 1 | 2008/08/28 20:46:20 |
| | | | 6 | MOTION | 1 | 2008/08/28 20:44:38 |
| Start Time: | 2008/08/28 20:42:31 | | 7 | MOTION | 1 | 2008/08/28 20:44:03 |
| | | | 8 | MOTION | 1 | 2008/08/28 20:43:20 |
| End Time: | 2008/08/28 21:42:31 | | 9 | MOTION | 1 | 2008/08/28 20:42:31 |
| Litu Time. | 2000/00/20 21:42:51 | | 10 | MOTION | 1 | 2008/08/28 20:42:12 |
| E1 D 11. | | | 11 12 | MOTION MOTION | 1 | 2008/08/28 20:41:54 2008/08/28 20:41:40 |
| File Path: | c:\download\ | | 12 | MOTION | 1 | 2008/08/28 20:41:40 |
| | | | 13 | MOTION | 1 | 2008/08/28 20:40:27 |
| Simultaneous Playback | | | 14 | MOTION | 1 | 2008/08/28 20:39:20 |
| | | | 16 | MOTION | 1 | 2008/08/28 20:14:49 |
| | | | 17 | MOTION | 1 | 2008/08/28 19:51:09 |
| | | | 18 | MOTION | 1 | 2008/08/28 19:43:27 |
| Down | oad Cancel | | 19 | MOTION | 1 | 2008/08/28 19:41:59 |

| Function | Description |
|--|--|
| IP Address / Port / User Name / Password | Check if the network connection information of the DVR within which contains the video data you need is correct. |
| HDD Number / Channel | Specify the hard disk (HDD Number) and channel number (Channel) within which have the video data you need. |
| Download by Time | Specify the time range within which has the video data you want in the "Start Time" and "End Time" columns. |
| Download by Event | Select an event log from the event list. This list shows all logs in the specified DVR from the latest to the earliest. To quickly find the events you need, check or uncheck the event type "System" / "Manual" / "Alarm" / "Motion", and select the log you want. To view the earlier or later logs that are not shown in the current page, click "Prev. Page" or "Next Page". To refresh the event list, click "Reload". |
| File Path | Assign the location where the backup files are saved. |
| Simultaneous Playback | To view the backup images simultaneously when the download process is in progress, select the checkbox "Simultaneous Playback". You will see the backup images while the images are being downloaded to the PC or notebook. |

| Function | Description |
|-------------------|--|
| | To simply backup images without previewing, deselect the checkbox "Simultaneous Playback". You will only see a message box indicating the total time needed, the current status and the saving location. |
| Download / Cancel | Click "Download" to start or "Cancel" to discard the video backup. |

Record Setting

Press " to go into the "Record Setting" page, and you can set the following items:

- Record type
- Hard disk overwriting
- Pre- / post-alarm record time
- · Record time setting
- Record path

| Manual | Schedule | e 🔽 Motion | on 🗆 Alarm | Prev. | <u> </u> | Sec. |
|-----------|-----------------|----------------|--------------------|------------------|----------------------|-------|
| Hard D | isk Overwrite | | | Post | | Sec. |
| Record Ti | me Range | | | | | |
| Neekly | Custom | | Schedule | 💻 Alarm | Motion | |
| | | 0 1 2 3 | | 9 10 11 12 13 14 | 15 16 17 18 19 20 21 | 22 23 |
| | Sun | | | | | |
| 1 | Vion | | | | | |
| | Tue | | | | | |
| | Wed | | | | | |
| | | | | | | |
| | Thu | | | | | |
| | Fri | ********** | ****************** | | | |
| | Sat | | | | | |
| Record Pa | ath | | | | | |
| Drive | Total(MB) | Free (MB) | Reserve(MB) | Video Path | Picture Path | |
| V C: | 76308 | 46064 | 2048 | C:\tempvideo\ | C:\temppicture\ | |
| E: F: | 78528 131061 | 41019 85301 | 2048 | EA EA | EA FA | |
| F. | 101001 | 00001 | 40-10 | 63 | Fa | |

Record type

In this section, you can select which type of the recording will be enabled. There are 4 options: Manual / Schedule / Motion / Alarm.

Hard disk overwriting

To overwrite the recorded data from the earliest to the latest when the hard disk is full, check "Hard Disk Overwrite" checkbox.

Pre- / post-alarm record time

Select the pre-/post-alarm recording time from 0 sec. to 60 sec.

Record time setting

There are two ways to set the record time: Weekly and Custom.

Weekly

Click "Weekly" tab, and you will see a weekly time table indicating the week days (Mon ~ Sun) and hours $(0 \sim 24)$, similar to the figure below:

| Record Time Range | |
|-------------------|---|
| Weekly Custom | 드 Schedule 🛛 🖿 Alarm 🛛 💻 Motion |
| + - | 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 |
| Sun | |
| Mon | |
| Tue | |
| Wed | |
| Thu | |
| Fri | |
| Sat | - |

X axis: 0 ~ 24 hours. Each time interval within a square is 15 minutes.

Y axis: Monday ~ Sunday.

Operation: You can set the record schedule for 3 record types as needed in this time table:

1st timeline -- Schedule record, indicated in yellow,

2nd timeline -- Alarm record, indicated in magenta, and

3rd timeline -- Motion record, indicated in cyan.

Click and hold the start time point, and drag to the end time point to set the record time range.

Custom

Click "Custom" tab, and you can set a more specific record time range for the 3 record types: Schedule,

| Motion, and Alarm. |
|--------------------|
| Record Time Range |

| ☐ Alarm | | Add D | elete Update |
|----------|---------|------------|--------------|
| | Туре | Start Time | End Time |
| | | | |
| ÷ • | | | |
| | | | |
| <u>.</u> | | | |
| | F Alarm | | |

How to add a new time setting:

- i. Check the record type you want to schedule the recording.
- ii. Set the start time (From) and end time (To).
- iii. Click "Add" to add the time range you just set into the schedule table. Before adding the time range, you will be prompted to confirm as follow:

| Information | × |
|--|-------------------------------|
| One item will be a | dded: |
| Type: Motion From: 2008/08/2 To: 2008/08/2 | 8 4:04:28 PM 8 10:04:28 PM |
| Are you sure? | |
| | |
| (OK] | Cancel |

iv. Check if the information shown is correct. Click "OK" if the information is correct. Click "Cancel" if the information is wrong.

How to modify / delete a current time setting:

| Veekly Custom | | | | | | | |
|---------------|--------------------------|------------|------------------|---------------------------------|---------|---------|--------------------------------------|
| 🗆 Schedule | Motion | 🗆 Alarm | [| Add | Dele | ete | Update |
| | | | Туре | Start Time | | | End Time |
| Fre | om: | | Motion Motion | 2008/08/28 4:04 2008/09/22 4:04 | | | 3/28 10:04:28 PM 3/22 10:04:28 PM |
| 2008/08/ | <mark>21</mark> 16:04:28 | ÷ • | Modoli | 2006/09/22 4:04 | .20 FP1 | 2000/03 | 922 10.04.20 FM |
| т | ō: | | | | | | |
| 2008/08/ | 22 22:04:28 | <u>+</u> • | | | | | |

- 1. Select the schedule setting you want to modify from the schedule table. The setting will be displayed in the left setting panel.
- 2. Modify the setting in the left setting panel, and click "Update".
- 3. You will be prompted to confirm the setting. Click "OK" if the information is correct. Click "Cancel" if the information is wrong.
- 4. To delete one schedule setting, select it, and click "Delete".

Record Path

Select and view the location for saving the recorded video and snapshot pictures.

To change the saving path for the recorded video clips or snapshots, check the drive you want, click the cell of "Video Path" or "Picture Path" twice, and select a new path for saving the video clips or snapshots.

Server Setting

Click **"** to view, set or modify the DVR setting. All the changes you make here will be applied to the connected DVR.

Note: You need to be a supervisor to operate this function. For details, please see "Account" at page 40.

General

In "General" and its sub-menus, "Log", "Account" and "OnLineUser", you can view and set some common settings, such as the turbo step, make account setting, check the information for all current on-line users, and search the server logs.

| 🔯 Server Setting : 192.16 | 68.1.12 | × |
|------------------------------|-------------------|-----------------------------|
| General | General | |
| Log Account OnLineUser | | |
| - Network | Firmware Version: | 1227-1012-1032-1018-M1-6C1B |
| FTP | MAC Address: | 00:0E:53:0D:9B:BD |
| MAIL Video | into Address. | 00.02.33.02.35.02 |
| ⊡ Dvr Camera | Title: | office |
| Device Detection | | |
| Record Record Timer | Turbo Step: | 1 |
| Alert Display | | |
| ОК | | |
| Cancel | | |
| Apply | | |
| | | |

In "General", you will see the following items:

| Item | Description | |
|--------------------------------------|--|--|
| Firmware Version | Firmware Version Display the current firmware version of your DVR. | |
| MAC Address Display the MAC address. | | |
| Turbo Step | Turbo Step Speed up the menu selection under the AP from 1 to 10. | |
| | Ex: If the value of the turbo step is set to 5, one mouse-click will function as 5 mouse-clicks when you click | |
| | one of the buttons 🚾 / 💟 / 🕅 in the DVR control panel. | |
| Title | Provide a title for this DVR. Only 15 characters are allowed. | |

Logs

Click "(Miscellaneous Control) \rightarrow """ (Server Setting) \rightarrow "General" \rightarrow "Log" to go into the

"Log" page. In the "Log" page, you can see all the logs for the network camera, such as "Power On", "Reset Default", "Net Login" and "SNTP Update" ... etc.

• To refresh the logs, click "Reload".

• To view the earlier or later logs that are not shown in the current page, click "Prev. Page" or "Next Page".

• To clear all the logs, click "Clean".


| Log | | | | | |
|--------------|--------------|------------|---------------------|----------|---|
| Account | Reload | Prev. Page | Next Page | Clear | n |
| - OnLineUser | Event | CH | Time | Message | - |
| DDNS | Remote Login | 0 | 2008/09/22 18:19:16 | admin | |
| FTP | Remote Login | ŏ | 2008/09/22 16:29:43 | admin | |
| MAIL | Key Unlock | ŏ | 2008/09/22 14:51:11 | | |
| Video | Power On | Ő | 2008/09/22 14:37:58 | | |
| Dvr | Video Loss | 4 | 2008/09/22 14:37:56 | | |
| Camera | Video Loss | 3 | 2008/09/22 14:37:56 | | |
| | Video Loss | 2 | 2008/09/22 14:37:55 | | |
| Device | Video Loss | 1 | 2008/09/22 14:37:54 | | |
| Detection | Power On | 0 | 2008/09/22 14:37:51 | | |
| Record | Power On | 0 | 2008/09/19 22:30:35 | | |
| Record Timer | Key Unlock | 0 | 2008/09/19 22:30:25 | | |
| Alert | Power On | 0 | 2008/09/19 22:23:43 | | |
| | POWER ON PRE | MOTE LOGIN | DDNS 🔽 PPP0 | E 🔽 DHCP | |
| | FTP FEMAIL | . | RESET DEFAULT | | |
| Cancel | SNTP UPDATE | | LOSS 🔽 HDD | | |

Account

In "General" \rightarrow "Account", you can create a new account for login, or delete or modify the existing account setting.

• To add an account, click "New", and fill in the following columns. Then, click "Apply" to save your setting and create a new account.

| 🔤 Server Setting : 192.16 | 8.1.12 | | | × |
|---------------------------|----------------------|--------------|------------------|------------|
| 🗐 General | General :: Account | | | |
| Log | | | | |
| - Account OnLineUser | User Name | User Level | Life Time | |
| - Network | admin | Supervisor | INFINITE | |
| DDNS | | - | | |
| FTP | | | | |
| MAIL Video | | | | |
| Dvr | | | | |
| Camera | | | | |
| Device | | | | |
| Detection Record | | | | |
| Record Timer | User Name: adr | nin Pa | ssword: | **** |
| Alert | | | | · |
| Display | User Level: Supervis | or 🔹 | Life Time: | INFINITE 🔻 |
| ОК | N | ew Delete | Apply | |
| Cancel | | | - 11- 2 | |
| | Max User(s): | 10 C Anonyme | ous Viewer Login | Update |
| Apply | | | Jus ficwer Login | opuuto |
| | | | | |



| Column Description | | | | |
|---|--|--|--|--|
| User Name Set a user name that will be used for remote login. The user name allows up to 10 characters. | | | | |
| Password Set the password that will be used for remote login. The password allows up to 8 characters. | | | | |
| User Level | Set the security level of an account to give the permission to control different AP functions. There are 4 user levels: Supervisor, Power User, Normal User and Guest. | | | |
| Life Time | Select how long this account is allowed to stay online (1 MIN / 5 MIN / 10 MIN / 1 HOUR / 1 DAY / INFINITE) | | | |

- To modify an existing account, select the account you want, change the setting, and click "Apply".
- To remove an existing account, select the account you want, and click "Delete".
- To save your changes, click "Apply".
- To define the maximum account creation number, key in the number in "Max User(s)" column from 1 to 20, and click "Update".

OnLineUser

In "General" \rightarrow "OnLineUser", you can check all the online user information. To update the user information, click "Refresh".

| 🔯 Server Setting : 192.16 | 58.1.12 | | | | × |
|---|-----------------------|------------|---------------|------------|---|
| ⊡ · General Log | General :: OnLineUser | | | | |
| | Online User Ir | formation: | | Refresh | |
| MAIL | User Name | User Level | IP Address | Media Type | |
| Video - Video - Device - Device - Detection - Record - Record Timer - Alert - Display OK | edmin | Supervisor | 192.168.1.196 | MPEG_AUDIO | |
| Cancel | | | | | |
| Apply | | | | | |

Network

In "Network" and its sub-menu, "DDNS", you can set the DVR network configuration. The network configuration allows the DVR to connect to the LAN or Internet.

| × |
|---|
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |

Select the network type you will be using for DVR connection. There are 3 network connection types: Static IP, PPPOE and DHCP.

Note: PPPOE and DHCP network connection types are required to apply the DDNS service to get a "Hostname" to correspond to a dynamic IP address. Please refer to "DDNS" at page 42 for details.

| Function | Description |
|--|--|
| Web Port | Typically, the default TCP port used by HTTP is 80. However, in some cases, it is better to change this port number for added flexibility or security. The valid web port number ranges from 1 to 9999. |
| Static IPComputers are communicated and recognized by their own unique IP addresses over the Intern provided by your ISP (Internet Service Provider) means the IP address of the computer is fixed. Key in the server IP address, gateway and network information provided by your ISP provider to IP network connection. | |
| PPPOE | PPPOE stands for Point-to-Point Protocol over Ethernet. Users can easily have the Internet service as long as they're ready for the following things: 1) Insert an Ethernet card into the PC. 2) Obtain the ADSL service via any ISP. 3) Obtain and install the PPPOE software CD. |
| | When everything is ready, choose the "PPPOE" IP type, and key in the user name and password provided by your ISP. Then, select "Network" \rightarrow "DDNS" to set DDNS settings. For detailed DDNS settings, please refer to "DDNS" at page 42. |
| DHCP | This DHCP function needs to be supported by a router or cable modem network with the DHCP service. Choose the "DHCP" IP type, and select "Network" \rightarrow "DDNS" to set DDNS settings. |
| | For detailed DDNS settings, please refer to "DDNS" at page 42. |

DDNS

You need to apply a DDNS account before setting PPPOE or DHCP connection. DDNS is a service for transforming the dynamic IP corresponding to a specific "host name". Go to a website which provide free DDNS services and apply a host name.

| 📴 Server Setting : 192.16 | 8.1.12 | | | × |
|---------------------------|-----------------|--------------|----------------------|---|
| General | Network :: DDNS | | | |
| Account OnLineUser | | DNS Server1: | 168 . 95 . 1 . 1 | |
| DDNS FTP | | DNS Server2: | 139 . 175 . 55 . 244 | |
| WAIL Video | | DDNS: | © On C Off | |
| Camera. Device | | System Name: | dyndns | |
| Detection Record | | User Name: | manager | |
| Record Timer Alert | | Password: | ***** | |
| OK | | Hostname: | manager.dyndns.org | |
| Cancel | | Verify Code: | | |
| Apply | | | | |

DDNS Apply:

- a). Go to a website which provide the free DDNS service, for example, http://www.dyndns.org.
- b). Create an account in DynDNS.
- c). After creating one account, users will receive a confirmation E-mail within a few minutes. To complete the registration, please follow the instructions received.

Users must complete these steps within 48 hours to complete the registration. If the confirmation

E-mail was not received within an hour, request "password reset" (http://www.dyndns.org/account/resetpass/).

- d). Use the DDNS username and password to log into the DynDNS.
- e). Create a host name:

After login, click "Account" \rightarrow "My Service" \rightarrow "Add Host Services" \rightarrow "Add Dynamic DNS Host". Enter and choose a host name, and click "Add Host". Then, your DDNS host name is created.

| | photostativevices/hostshill | Ditel | | 2 | · 24至 東雄 " Gaugh 🗹 |
|---|-----------------------------|----------|-------------------------------|-----------------|--|
| 🗑 Dyn 🛛 | ONS | | <u> </u> | | Legged is there Yashbadhuma Mellanibur - Salitair - Lea Cul |
| | About | Services | Account Supp | an News | |
| Account | Add Heat | Services | | | |
| y Services | Add Host | Services | | | |
| ccourt Upprades | | | Dynamic DNS ((Eld D) | Annie Date Mart | |
| Billiop Outbound | | | East Date (1) | | |
| ecursive DR2S | | Nev | v Dynamic DNS SM H | lost | |
| LA v Zones | | | i bynamie bite i | | |
| Add Zone Services | | | Hostname: | Youttestiania | dyndns.org |
| hy blands | | | IP Address: | 211.75.84.96 | dyndra org |
| LATHUR CARDAN | P | | Enable Wildcard: | P | dynchs ws |
| | | | | | - game-mar.org |
| Dynamic DNS Static DNS | | | Mail Exchanger (optional): | | game-server.cc |
| Add Host Services Dynamic DNS Static DNS WebHop MWrbHop | | | Mail Exchanger (optional): | 1 | setmyip com |
| Dynamic DNS Stelic DNS | | | Mail Exchanger (optional): | | |

FTP

Click "(Miscellaneous Control) \rightarrow """ (Server Setting) \rightarrow "Network" \rightarrow "FTP" to go into the

"FTP" page. Enter the detailed FTP information and press "Apply" to confirm. The information you set here will be applied when the function of FTP notification is enabled in the "Alert" menu.

| 📴 Server Setting : 192.16 | 8.1.12 | | × |
|---|----------------|-------------|---|
| General | Network :: FTP | | |
| Log Account OnLineUser Network | User Name: | manager | |
| DDNS FTP MAIL | Password: | ***** | |
| ⊡ Video ⊟ D∨r Camera | Port: | 21 | |
| Device Detection Record | Server: | 192.168.1.6 | |
| Record Timer Alert Display | Directory: | event | |
| ОК | | | |
| Cancel | | | |
| Apply | | | |

MAIL

Click " \square " (Miscellaneous Control) \rightarrow " \square " (Server Setting) \rightarrow "Network" \rightarrow "MAIL" to go into the

"MAIL" page. Enter the detailed E-mail information and press "Apply" to confirm. The information you set here will be applied when the function of E-mail notification is enabled in the "Alert" menu.

| 🔤 Server Setting : 192.16 | 58.1.12 | > |
|--|--|---|
| General Log Account OnLineUser Network DDNS FTP | Network :: MAIL Server: 192.168.1.6 Mail From: manager@tech.com | |
| - Video - Video - Dvr - Device - Detection - Record - Alert - Display | Verify Password Verify: © Yes © No User: manager Password: ****** Email Address Mail Account ceo@tech.com | |
| OK Cancel Apply | Add | |

| Function | Description | | | |
|--|---|--|--|--|
| Server | Enter the SMTP server address provided from your e-mail system supplier. | | | |
| Mail From Enter the entire mail address to ensure E-mails will not be blocked by SMTP. | | | | |
| Verify Password | Some mail servers are required to verify the password. Please enter the "user name" and "password". | | | |
| Email Address | Add the E-mail address(s) of the assigned recipient(s). | | | |

Note: Users can assign up to 4 mail accounts for E-mail notification.

Video

In "Video", you can set the video web transmission size and quality, and the frame rate for transmitting.

| 📴 Server Setting : 192.16 | 8.1.12 |
|--|----------------------|
| General Log Account OnLineUser | Video |
| Network DDNS FTP MAIL Video | JPEG: 4CIF 💌 HIGH 💌 |
| Dvr Camera Device Detection Record | MPEG: CIF 💌 NORMAL 💌 |
| Record Timer Alert Display | FrameRate: |
| 0K | |
| Cancel | |
| Apply | |

| Function | Description |
|-----------|---|
| JPEG | Choose the image size (4CIF / CIF) and picture quality (BEST / HIGH / NORMAL / BASIC) when the web transmission format is JPEG. |
| MPEG | Choose the image size (4CIF / CIF) and picture quality (BEST / HIGH / NORMAL / BASIC) when the web transmission format is MPEG. |
| FrameRate | Choose the frame rate for transmitting (FULL, 1/2, 1/3, 1/4, 1/5, 1/10, 1/15, 1/20, 1/25, 1/30). |

Dvr

In "Dvr" and its sub-menus, "Camera", "Device", "Detection", "Record", "Record Timer", "Alert" and "Display," you can set DVR general functions, such as the host ID, the record schedule, alerts, motion detection, and text or icon display, etc.

| Server Setting : 192.168 | 3.1.12 | × |
|--------------------------|--|---|
| General | Dvr | |
| Account OnLineUser | Host ID: 12 (0~254) | |
| - Network | | |
| DDNS | System Type: C NTSC @ PAL De-interlace: @ On C Off | |
| FTP MAIL | Daylight Saving | |
| - Video | © On C Off Adjust: 01:00 | |
| Camera. | Start: Aug. V First Week V Mon. V 06:00 | |
| - Detection | End: Oct. V Last Week V Mon. V 10.00 - | |
| Record Timer | | |
| Alert | Menu Operation | |
| Display | AutoKeyLock: 30 V Seconds | |
| OK | | |
| Cancel | Serial Port Type: RS485 V Baud Rate: 2400 V | |
| Annha | | |
| Apply | | |

| In "Dvr", you ca | n see the foll | owing items: |
|------------------|----------------|--------------|
|------------------|----------------|--------------|

| Function | Description | | | | | |
|--|--|--|--|--|--|--|
| System Type Display the current system type (NTSC / PAL). It's automatically detected. | | | | | | |
| De-interlace | elect to enable or disable the de-interlace function (ON / OFF). | | | | | |
| Daylight Saving | Specify whether to use daylight saving time (ON / OFF). If this function is enabled, set the time period (START / END), and adjust the daylight saving time in hours (ADJUST). | | | | | |
| Menu Operation | Select the time-out in seconds after which the DVR keys will be automatically locked when no one is operating the DVR for a period of time (0 / 30 / 60 / 120). The default value is 30. | | | | | |

| Function | Description |
|------------------|--|
| Serial Port Type | Display the serial type (RS485) used by this DVR. It's automatically detected. |
| Baud Rate | Set the baud rate of the DVR (2400 / 9600 / 19200 / 38400 / 57600). |

Camera

In "Dvr" \rightarrow "Camera", you can specify a channel to enable the recording function by selecting the check box "Record", choose to activate the "Covert Recording" function by selecting the check box "Cover", and rename the channel title which will be displayed in the live view screen by double-clicking the channel title.

| Server Setting : 192.16 - General | 3.1.12 Dvr :: Camera | _ | _ | _ | | |
|--------------------------------------|-------------------------|----|-------|-------|----------|--|
| Log | DVI Callicia | | | | | |
| Account | | | | | | |
| OnLineUser | | CH | Title | Cover | Record | |
| Network | | 1 | CH1 | | N | |
| DDNS | | 2 | CH2 | | N N | |
| FTP | | 3 | CH3 | | <u>v</u> | |
| MAIL | | 4 | CH4 | | | |
| - Video | | | | | | |
| 🖻 Dvr | | | | | | |
| Camera | | | | | | |
| Device | | | | | | |
| Detection | | | | | | |
| Record | | | | | | |
| Record Timer | | | | | | |
| Alert | | | | | | |
| Display | | | | | | |
| OK | | | | | | |
| Cancel | | | | | | |
| | | | | | | |

Device

Select the device type (CAMERA / PTZ) according to the connected cameras for each channel. Click "Edit" or double click the item to enter the setting box.

| Server Setting : 192.168.1.12 | | | | | | 2 | × | | |
|-------------------------------|----|--------|----|------------------|--------------|---|---|---------------------------|------------|
| General Dvr : | | | | | | | | | |
| - Log Account | | | | | | | | | |
| OnLineUser | CH | DEVICE | ID | PROTOCOL | RATE | | | | |
| Network | 1 | CAMERA | 0 | NORMAL | 2400 | | | | |
| DDNS | 2 | CAMERA | 0 | NORMAL | 2400 | | | | |
| MAIL | 3 | CAMERA | 0 | NORMAL NORMAL | 2400 2400 | | | | |
| Video | 4 | CAMERA | U | NORMAL | 2400 | | | 21 Edit Device Parameters | |
| - Dvr | | | | | | | | | |
| - Camera | | | _ | | | | | CH | 1 |
| Device Detection | | | | | | | | | |
| Record | | | | | | | | Device: | PTZ 🔻 |
| Record Timer | | | | | | | | ID: | 1 |
| - Alert | | | | | | | | ID. | P . |
| - Display | | | | | | | | Protocol: | NORMAL - |
| ОК | | | | | | | | | INOT GAUGE |
| | | | | | | | | Rate: | 2400 - |
| Cancel | | | | Edit | | | | | 1 |
| Apply | | | | cuit | | | | Apply | Return |

| Function | Description |
|----------|--|
| DEVICE | Choose either normal camera or PTZ camera. |
| ID | Set the ID number (0 ~ 255) of the connected PTZ camera. |
| PROTOCOL | Choose "NORMAL" or "P-D" protocol. It is recommended to select PELCO-D protocol for the |
| | connected PTZ camera of other brands. Please choose Normal if it's our own PTZ camera |
| RATE | Set the baud rate of each channel (2400 / 4800 / 9600 / 19200 / 38400 / 57600 / 115200). |

Detection

Select the desired channel, and click "Edit" to enter the motion detection sensitivity and area-setting page.

| | | 124 Edit Detection Persinetters |
|-------------------------------------|--|---|
| | | CH Detect LS SS TS RE Alarm 1 ON ▼ 7 3 2 10 OFF ▼ |
| Server Setting : 192.160.1.12 | 3 | 1 ON <u>v</u> 7 3 2 10 OFF <u>v</u> x [+]Select All [-[Clear All] |
| General Dvr :: Detect | | |
| - Account OnLineUser | CH DETECT LS SS TS RE ALARM | |
| DDNS FTP MAIL | 2 OPF 7 3 2 10 OPF 3 OPF 7 3 2 10 OPF 4 OPF 7 3 2 10 OPF | |
| -Vileo B-Dvr -Camera | | |
| - Device - Detection - Record | | |
| -Record Timer -Alert Display | | |
| ОК | | |
| Cancel Apply | Edit | Apply Return |
| 1999 | | |

Please see the description below for each function:

| Function | Description |
|------------------------------------|---|
| DETECT | Enable (ON) or disable (OFF) the function of "Motion Detection". |
| | If this function is enabled, you might need to set the motion detection sensitivity or simply keep the |
| | default values. For details, please see the description below. |
| Motion Detection | Set the detection sensitivity in 4 different adjustable parameters (LS / SS / TS / RE). |
| Sensitivity (LS / SS / TS / RE) | For details about each parameter, please refer to"7.2 DETECTION" at page 21. |
| Alarm | Select N.C. (normal closed) / N.O. (normal opened) / OFF for the alarm polarity. For N.C. / N.O. |
| | contact details, please refer to "APPENDIX 1 PIN CONFIGURATION" at page 56. |
| Motion Detection Setting Area | Set the motion detection area by selecting the area grids with your mouse. Pink grids represent the area that is not being detected while the transparent grids are the area under detection. You can set multiple areas under detection. |
| | Click " $-$ " (Clear All) to set the whole area undetected. |
| | Click "+" (Select All) to set the whole area under detection. |
| Apply / Return | To save the setting, click "Apply" and return to "Server Setting" window. |
| | To discard the setting, click "Return" to directly return to "Server Setting" window without saving. |

х

Record


In "Dvr" \rightarrow "Record", you will see the following items for DVR record settings.

| 📴 Server Setting : 192.16 | 88.1.10 |
|---|--|
| General Log Account OnLineUser DDNS FTP MAIL Video Dvr Camera | Dvr :: Record Image Size: CIF v Quality: BEST v Manual Record © Yes © No IPS: 120 v |
| Device Detection Record | Event Record |
| Record Timer Alert Display | Timer Record ⊙ Yes ◯ No IPS: 120 ▼ |
| 0K | |
| Cancel Apply | I Pre-Alarm Record Overwrite: ⓒ Yes C No |

| Function | Description |
|--|--|
| Image Size / Quality | Choose the image size (FRAME / FIELD / CIF) and quality (BEST / HIGH / NORMAL / BASIC). |
| Manual Record / Event Record / Timer Record | Select the record type that the DVR will take recording (Yes / No), and select the IPS setting for the selected record type. |
| Pre-Alarm Record | Check this option if you want to enable the pre-alarm recording function. |
| | When an alarm is triggered, the DVR will record 8MB video data before the alarm event is actually happened. |
| Overwrite | Select "Yes" to enable the HDD overwrite function when the HDD is full, or "No" to disable this function. |
| | When this function is on, and the recording and the pre-alarm function are activated, the DVR will overwrite 8GB data from the oldest for continuous recording without notice. |

Record Timer

In this menu list, you can set the record schedule for normal recording or motion recording.



Permit

Select this checkbox to allow the record timer setting to be applied to the connected DVR. If this checkbox is deselected, the setting will not be applied to the connected DVR even when you click "Apply" and "OK".

Routine / Motion

Click "Routine" tab to select the time range for continuous recording, or "Motion" tab to select the time range within which the recording will be on when any movement is detected.

Time Table

Find the day and time you want to enable the recording. Then, click to select the time interval(s). Each interval represents 30 minutes.

To enable the recording all the time, click "+"; to clear the record timer setting, click "-".

Alert

In "Alert", you can set the DVR to beep for notification when there's any alert happened. Check the buzzer option you want, and set how long the beep sound will be lasted.

| 📴 Server Setting : 192.16 | 8.1.12 | | × |
|-------------------------------|--------------------|----------|-------|
| General | Dvr :: Alert | | |
| Log Account | | | |
| OnLineUser | Ext Alert: | N | |
| - DDNS - FTP MAIL | Buzzer Enabled: | N | |
| Video Dvr | Motion Buzzer: | A | |
| Camera Device Detection | Alarm Buzzer: | N | |
| Record Record Timer | Video Loss Buzzer: | N | |
| Alert Display | Key Input Buzzer: | N | |
| ОК | Notified by: | 🔽 Email | E FTP |
| Cancel | Duration: | 5 - | |
| Apply | | - | |

| Function | Description |
|---|---|
| Ext Alert | Check this option to enable the external alert. |
| Buzzer Enabled | This option must be checked for "Motion Buzzer", "Alarm Buzzer", "Video Loss Buzzer" & "Key Input Buzzer" to take effects. |
| Motion Buzzer / Alarm Buzzer / Video Loss Buzzer / Key Input Buzzer | Check one of these 4 options, and you will hear the beep sound when any movement is detected / the alarm is triggered / video loss occurs / any DVR key is pressed. |
| Notified by | Select the notification method when any event occurs: Email or FTP. |
| Duration | Set the alert and buzzers to beep for 5 / 10 / 20 / 40 seconds. |

Display

In "Display", you can choose whether to display some text indication or icons, set the channel display switch time-out, set the DVR time remotely, and select the date format (Y-M-D / M-D-Y / D-M-Y).

| 🔯 Server Setting : 192.16 | 8.1.12 | × |
|---------------------------|-------------------------|-------------------------|
| 🖃 General | Dvr :: Display | |
| - Log - Account | | |
| - OnLineUser | Title: | <u>ष</u> |
| DDNS | | |
| FTP | Event: | <u>ष</u> |
| MAIL | | |
| - Video ⊡- Dvr | Quick Status: | N |
| - Camera | | |
| Device Detection | Full Sequence Duration: | 3 🔻 |
| Record | | |
| Record Timer | Quad Sequence Duration: | |
| Display | | |
| OK | Server Time: | 2008/08/23 16:24 |
| | | , |
| Cancel | Date Format: | ⊙ Y-M-D ⊂ M-D-Y ⊂ D-M-Y |
| Apply | | |
| | 1 | |

| Function | Description |
|------------------------|--|
| Title | Select to display the channel title in the live view. |
| Event | Select to display the event symbol in the live view. |
| Quick Status | Select to display the quick status in the live view. |
| Full Sequence Duration | Set the time-out in seconds (3 / 5 / 10 / 15) after which the channel display will be switched |
| | by one channel (Full Sequence Duration). |
| Server Time | Set the DVR time remotely. |
| Date Format | Choose the date display format appropriate to your location (Y-M-D, M-D-Y and D-M-Y). |

> Tools

Click " to upgrade the firmware version, multilingual OSD and boot display of your DVR (Update

Server).

Note: You need to be a supervisor to operate this function. For details, please see "Account" at page 40.

Update Server

3 update options are available for this function: Firmware, Language and Logo.

Before performing any update, finish the following settings first:

- 1) Choose the IP address of the DVR whose firmware needs to be updated from the drop-down list, or click "Search" to find.
- 2) Key in the user name, password and port number used to access your DVR remotely.
- 3) Select the update option (Firmware / Language / Logo) you want. For details, please see the description below.

| IP Address: 192.168.1.12 Search Port: 80 User Name: admin Password: ***** Firmware Language Logo Current version: 1227-1012-1032-1018-M1-6C1B | Jpdate Server Langua | ane |
|---|-----------------------|---------------------------------------|
| User Name: admin Password: ***** Firmware Language Logo Current version: 1227-1012-1032-1018-M1-6C1B G:\xml_4.bin G:\AppImg_4.bin | pulle berrer Langua | |
| Firmware Language Logo Current version: 1227-1012-1032-1018-M1-6C1B | IP Address: | 192.168.1.12 - Search Port: 80 |
| Current version: 1227-1012-1032-1018-M1-6C1B Add Remove G:\xml_4.bin G:\AppImg_4.bin | User Name: | admin Password: ***** |
| G:¦xml_4.bin G:¦AppImg_4.bin | Firmware Language | Logo |
| G:\xml_4.bin G:\AppImg_4.bin | Current version: 12 | 27-1012-1032-1018-M1-6C1B |
| G:\xml_4.bin G:\AppImg_4.bin | | Add Remove |
| Update Firmware | Compleming_4.011 | |
| | | |
| Configure File | | Update Firmware |
| System Backup: Backup | Configure File | Update Firmware |

Firmware

To upgrade your DVR firmware remotely, click "Firmware" tab, and follow the steps below:

- a). In the "Firmware" section, you will see the current firmware version. To upgrade the firmware version of your DVR, click "Add" to locate and select the firmware file. The file will be shown in the firmware list.
- b). If you want to backup your system before upgrading the firmware version of your DVR, select "System Backup" in the "Configure File" section, click "..." to specify the location for saving system backup, and click "Backup" to start the backup process.
- c). To start upgrading the DVR firmware, choose the file from the firmware list, and click "Update Firmware" to start the upgrade process.

Language

To update the DVR OSD language, click "Language" tab, and follow the steps below:

| Update Server Langı IP Address: User Name: | Jage 192.168.1.12 ▼ admin | Search Password: | Port: 80 |
|--|---------------------------------|---------------------|----------|
| Firmware Language | Logo | | |
| | | Add | Remove |
| G:\GlyphData_de | | | |
| <mark>G:\GlyphData de</mark> G:\StringInfo_de | | | |

- a). Get the language files you want to update from your distributor.
- b) Click "Add" to locate and select the files needed. The files will be shown in the list. If you add the wrong file, select it and click "Remove".
- c). To start updating the OSD language, choose the files from the list, and click "Update Language" to start the upgrade process.

• Logo

To replace the logo shown in the DVR boot display, click "Logo" tab, and follow the steps below:

| 🔤 Tools | | × |
|---------------------|------------------------------|----------|
| Update Server Langu | age | |
| IP Address: | 192.168.1.12 v Search | Port: 80 |
| User Name: | admin Password | j: ***** |
| Firmware Language | Logo | |
| | Add | Remove |
| G:\logo.bmp | | |
| | Update Logo | |
| | | |

a). Prepare a graphic file in the "BMP" format for replacement.

Note: Use the image software to set the image size to 320 * 240, and save the image as an 8-bit (64-color) image in the "BMP" format.

- b) Click "Add" to locate and select the graphic file. The file will be shown in the list. If you add the wrong file, select it and click "Remove".
- c). To start updating the logo, choose the file from the list, and click "Update Logo" to start the upgrade process.
- Language

This software is available in English / Chinese / French / German / Portuguese / Spanish / Japanese. Select a language from the drop-down list, and press "Apply". You will be prompted to restart the application for this change to take effect.

| 🔯 Tools | | | x |
|---------------|-----------|--------|---|
| Update Server | Language | | |
| | | | |
| | | | |
| | | | |
| | Language: | German | |
| | Languagor | | |
| | | | |
| | | | |
| | | Apply | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

Status List

Click "Click "to view all the event and record logs, or search for the specific log(s) by date or by record type.

There are three types of logs: Record, Backup and Event. To playback the recorded data for a specific record or backup log, select the log, and double-click to start the video playback.

| | nge Unit | One Day | | | Next | | User Motion | R F | ETB |
|--------|----------------|---------|---------------|------------------|-------------|---------------|----------------|---------|--------|
| From: | 2008/ SEP. /23 | ₹₹ | To: | 2008/九月 /23 | Ð | | Moton | I¶ ⊢ | ie i R |
| ecord | Backup Eve | nt | | | | | | Qu | ery |
| Event | IP | S | tart Time | End Time | | File Path | | Reserve | Error |
| User | 192.168.1.1 | 2 09/2: | 3/08 20:41:07 | 09/23/08 20:41:0 | 07 C:\tempv | (ideo\2008092 | 3204107_off: | | |
| User | 192.168.1.1 | 2 09/2: | 3/08 20:36:45 | 09/23/08 20:36:4 | 45 C:\tempv | /ideo\2008092 | 3203645_off: | | |
| User | 192.168.1.1 | 2 09/2: | 3/08 20:18:56 | 09/23/08 20:41:0 | 07 C:\tempv | /ideo\2008092 | 3201856_off: | | |
| User | 192.168.1.1 | 2 09/2: | 3/08 20:13:22 | 09/23/08 20:36:4 | 45 C:\tempv | /ideo\2008092 | 3201322_off: | | |
| Motion | 192.168.1.1 | 2 09/2: | 3/08 20:05:30 | 09/23/08 20:05:2 | 35 C:\tempv | /ideo\2008092 | 3200530_off: | | |
| Motion | 192.168.1.1 | 2 09/2: | 3/08 20:05:30 | 09/23/08 20:05: | 35 C:\tempv | /ideo\2008092 | 3194836_off: | | |
| Motion | 192.168.1.1 | 2 09/2: | 3/08 20:05:30 | 09/23/08 20:05:2 | 35 C:\tempv | /ideo\2008092 | 3195524_off: | | |
| User | 192.168.1.1 | 2 09/2: | 3/08 19:55:24 | 09/23/08 20:18: | 56 C:\tempy | /ideo\2008092 | 3195524_off: | | |
| User | 192.168.1.1 | 2 09/2: | 3/08 19:48:36 | 09/23/08 20:13:2 | 22 C:\tempv | /ideo\2008092 | 3194836_off: | | |
| User | 192.168.1.1 | 2 09/2: | 3/08 19:32:55 | 09/23/08 19:55:3 | 24 C:\tempv | /ideo\2008092 | 3193255_off: | | |
| User | 192.168.1.1 | | 3/08 19:24:51 | 09/23/08 19:48: | 36 C:\tempv | /ideo\2008092 | 3192451_off: | | |
| User | 192.168.1.1 | 2 09/2 | 3/08 19:10:26 | 09/23/08 19:32: | 55 C:\tempv | /ideo\2008092 | 3191026_off: | | |
| User | 192.168.1.1 | 2 09/2: | 3/08 19:01:05 | 09/23/08 19:24: | 51 C:\tempv | /ideo\2008092 | 3190105_off: | | |
| User | 192.168.1.1 | 2 09/2: | 3/08 18:47:57 | 09/23/08 19:10:3 | 26 C:\tempv | /ideo\2008092 | 3184757_off: | | |
| Motion | 192.168.1.1 | 2 09/2: | 3/08 18:46:17 | 09/23/08 18:46:2 | 28 C:\tempv | (ideo\2008092 | 3183720_off: | | |
| Motion | 192.168.1.1 | | 3/08 18:46:17 | 09/23/08 18:46:2 | | /ideo\2008092 | | | |
| Motion | 192.168.1.1 | 2 09/2: | 3/08 18:46:17 | 09/23/08 18:46:2 | 28 C:\tempv | /ideo\2008092 | 3184617_off: | | |
| User | 192.168.1.1 | 2 09/2: | 3/08 18:37:20 | 09/23/08 19:01:0 | 05 C:\temp\ | /ideo\2008092 | 3183720_off: | | |
| Tota | Becords: | 133 | Delete | Delete Al | 1 | Play | Repair | Ap | nlv 1 |

For detailed playback operation, please refer to "Playback" at page 50.

| Button | Description |
|---------------------|--|
| Time Range | To find the specific logs, set the time range (From / To), and the range unit here. |
| Record Type | Select the record type you want to search (User / Alarm / Motion / RETR). |
| Query | Click to start sorting the logs specified. |
| Delete / Delete All | Click "Delete" to remove the selected log(s), or click "Delete All" to clear the current log list. |
| | Tip: To select more logs all at once, press and hold the "Ctrl" key on your keyboard, |
| | and click to select the logs you want to remove. |
| Play | Click to play the selected record log. The playback panel will be shown for your further operation. For playback details, please see "Playback Screen" at page 50. |
| Repair | Click to fix the log with errors. |
| Close | Click "Close" to quit this window. |

Playback Screen

When you select and play the recorded data for a specific log in " \square " (Status List) \rightarrow "Record" or

"Backup", you will immediately go into the playback mode, and the following playback panel appears. For the function of each part on the panel, please refer to the following description.



| NO. | Function | Description |
|-----|-------------------------------------|---|
| 1 | Playback / Download Info Display | This area shows the detailed playback / download information, such as the file name, record date and time, and the speed, etc. |
| 2 | Playback Progress Bar | This area shows the playback progress and the progress percentage. |
| 3 | Playback Operation | This area is enabled only when the playback is started. (Rewind) / (Forward) / (Stop) / (Pause) / (Play) (Rewind / Forward Click once to get 2X fast rewind / forward, twice to get 4X, three times to get 8X, and four times to get 16X the highest. |
| 4 | De-Interlace | Click to reduce the vibration of the paused picture. |

Information

To view the current network connection details, click this button.

| IP Address: | 60.251.8.56 |
|----------------|---------------------|
| Transfer Type: | тср |
| Stream Format: | MPEG4 |
| AV Option: | Video |
| Bitrate: | 231(kbps) |
| FrameRate: | 6 |
| Resolution: | 4CIF |
| Quality: | HIGH |
| Server Time: | 2008-05-20 23:13:58 |
| Online Users: | 2 |
| Current Disk: | c: |
| | 35% |

DVR Control

When the AP is connected to the DVR, this DVR control panel will be enabled, and you can control the DVR remotely. For the function of each button, please refer to the following description.



| NO. | Function | Description |
|-----|------------------------|--|
| 1 | Channel | Click the channel No. (CH1 ~ CH16) to see the live view of the selected channel. |
| 2 | Selection | Click the view mode you want to see. There are 10 modes for your choice: |
| | | Select to display the quad view. |
| | | You can also click " " " or " " " to go to the previous / next channel of the selected channel. |
| 3 | Digital Zoom | Click in / out the selected channel image. |
| 4 | Full Sequence | Full Sequence Click to display each channel one by one, starting from CH1. When CH4 is displayed, it will start from CH1 again. To exit from this display mode, click any other channel display button. |
| 5 | Key Lock | Click lock the DVR key lock function. To unlock the DVR, key in your password, and click lock. |
| 6 | Search | Click " To enter the DVR full search menu. You can check all the logs here, and select one of them to payback. |
| 7 | Playback | (Stop) / 💷 (Pause) / 🥶 (Rewind) / 💽 (Play) / ဲ (Slow Playback) / 🍋 (Forward) |
| | | Rewind / Forward Click once to get 4X fast rewind / forward, twice to get 8X, three times to get 16X, and four times to get 32X the highest. Slow Playback Click once to get 4X slow playback and twice to get 8X slow playback. |
| 8 | Event | Click "E " to enter the DVR full search menu. |
| | | You can check all the logs here, and select one of them to payback. |
| 9 | Menu and Arrow Keys | Click "Omage" (Menu) to enter the menu / exit the menu mode. |
| | | Click the arrow keys to move the cursor and make the selection: |
| | | . Move the cursor up / down to select the previous / next menu or sub-menu function, or change the setting. |
| | | / Nove the cursor left / right to the previous / next sub-menu items. |
| 10 | Enter | Click "Click "Click "Click Click Cli |

8.2 IE Web Browser

You can view the live images only via IE web browser.

Note: The supported PC operation systems are Windows 2000 and Windows XP.

- Step 1: Key in the IP address used by your DVR in the URL address box, such as 60.121.46.236, and press Enter.
 You will be prompted to enter the user name and password to access the DVR.
 If the port number your DVR used is NOT 80, you need to key in the port number additionally. The format is *ipaddress:portnum*. For example, for IP address 60.121.46.236 and port No. 888, please key in "http://60.121.46.236:888" into the URL address box, and press "Enter".
- Step 2: Enter the user name and password, the same as the ones used at AP login, and press "OK". You will see a similar screen as the following when the login information is correct.



| Function | Description |
|----------------|--|
| Home | Press to go to the main page of the DVR |
| Config. | Press to go to the detailed DVR setting. |
| PTZ | Click to enter the PTZ mode. |
| | Press to enter the menu / exit the menu mode. |
| Menu and Arrow | Press the arrow keys to move the cursor and make the selection: |
| Keys | I where the cursor up / down to select the previous / next menu or sub-menu function, or change the setting. |
| | / D : Move the cursor left / right to the previous / next sub-menu items. |
| Event | Press 트 to enter the playback search settings screen. |
| Key Lock | Press 🙆 to enable the DVR key lock function. To unlock the DVR, key in your password, and press 🕒. |
| Enter | Press C to confirm the setting or enter your selection. |
| Digital Zoom | Press 2 to zoom in / out the selected channel image. |

| Function | Description |
|-----------------------------|---|
| Search | Press to enter the DVR full search menu. You can check all the logs here, and select one of them to payback. |
| Playback control buttons | (Stop) / (Play) / (Rewind) / (Forward) / (Pause) / (Slow Playback) <u>Rewind / Forward</u> Press once to get 4X fast rewind / forward, twice to get 8X, three times to get 16X, and four times to get 32X the highest. <u>Slow Playback</u> Press once to get 4X slow playback and twice to get 8X slow playback. |
| Single Channel Selection | Press the channel No. (CH1 ~ CH4) to see the live view of the selected channel. You can also press 🛨 or 🚍 to go to the previous / next channel of the selected channel. |
| Display Mode | Press 🖽 to show 4-cut display. |
| Snapshot | Press 🛅 to take a snapshot for the current view, and open another browser window to display the captured image. |
| Full Sequence | Full Sequence Image: Sequence Press to display each channel one by one, starting from CH1. When CH16 is displayed, it will start from CH1 again. To exit from this display mode, press any other channel display button. |
| Web Transmission | <u>MPEG4 / JPEG / QuickTime</u> QuickTime is Apple Inc.'s multimedia software. You need to have QuickTime installed in you operation system first. When "QuickTime" is selected, you will be promoted to enter the user name and password to access the server of the DVR. |
| Change Quality | BEST / HIGH / NORMAL / BASIC Press to change the image quality. |
| Change Resolution | <u>4 CIF / CIF</u> Press to change the image resolution (4CIF: 720*480 / CIF: 352*240) |

8.3 QuickTime Player

You can also use the QuickTime player to remotely log into the DVR and check the live view only.

- **Note:** QuickTime is Apple's multimedia software. You need to have QuickTime installed in you operation system first, and you can access the DVR to see the live view. If you have installed QuickTime, please skip Step 1.
- **Note:** The latest version of QuickTime is V6.4 at the time this manual goes to press, and the supported operation systems are Windows Vista / XP / 2000, and Apple Mac.
 - Step 1: Go to Apple's official website to download QuickTime. The website address is as follows: <u>http://www.apple.com/quicktime/win.html</u>
 - a). Click "Free Download" to go into the download page, and select to download the free player.
 - b). Leave your Email address, and click "Free Download Now" to download the latest QuickTime version.
 - c). When the download is completed, execute the "QuickTimeInstaller.exe" file, and follow the on-screen instructions to finish the installation procedure.
 - Step 2: Open your QuickTime player. Select "File" \rightarrow "Open URL in New Player...", and key in the URL address.



The URL format is **rtsp:**//**ipaddress:portnumber**/**live**/**mpeg4**. If the port number is 80, users don't need to key in the port number. For example, rtsp://192.168.1.10/live/mpeg4.

| Open URL | |
|--------------------------------|-----------|
| Enter an Internet URL to open: | |
| rtsp://192.168.1.10/live/mpeg4 | |
| | OK Cancel |

Step 3: A pop-up window will appear and prompt you to enter the authentication information. Key in the user name and password for accessing your DVR. The user name and password are the same as the ones you use to log into the AP.

If the information is correct, press "OK" to go on. If not, press "Cancel" to quit the accessing.


| QuickTime Internet Authentication | | | |
|--|-----------|---|--|
| Enter username for Server at 192.168.1.10: | | | |
| | | | |
| Userid: | | - | |
| Password: | | | |
| | Cancel OK | | |

Step 4: When the login is successful, you will see a similar screen as the following.



APPENDIX 1 PIN CONFIGURATION

PIN Connection Application



Siren: When the DVR is triggered by alarm or motion, the COM connects with NO and the siren with strobe starts wailing and

Magnetic Contact: When the magnetic contact is opened, the alarm will be triggered and the recording is on.

| PIN | FUNCTION | DESCRIPTION |
|---------|--------------------|---|
| 1 | PIN OFF | |
| 2 | PIN OFF | |
| 3 ~ 6 | ALARM INPUT | To connect the wire from ALARM INPUT (PIN 3 6) to GND (PIN 9) connector, DVR will start recording and the buzzer will be on. * "MENU -> ADVANCE -> DETECTION -> DETECTION SETUP -> ALARM" is set to "Low": When the alarm input signal is " Low ", the unit starts to record and buzzer. * "MENU -> ADVANCE -> DETECTION -> DETECTION SETUP -> ALARM" is set to "High": When the alarm input signal is " High ", the unit starts to record and buzzer. |
| 7 | EXTERNAL ALARM NC | Under the normal operation, COM connects with NC and disconnects from NO. But when any alarm is triggered, COM disconnects with NC and connects with NO. Attention: The voltage restriction is under DC24V 1A. |
| 8 | EXTERNAL ALARM NO. | Under the normal operation, COM disconnects with NO. But when any alarm is triggered, COM connects with NO. Attention: The voltage restriction is under DC24V 1A. |
| 9 | GND | Signal GND |
| 10 | RS485-B | DVR can be controlled remotely by the keyboard of PC by using RS-485 serial communication signals. |
| 11 | RS485-A | DVR can be controlled remotely by the keyboard of PC by using RS-485 serial communication signals. |
| 12 ~ 14 | PIN OFF | |
| 15 | EXTERNAL ALARM COM | Under the normal operation, COM disconnects with NO. But when any alarm is triggered, COM connects with NO. Attention: The voltage restriction is under DC24V 1A. |
| 16 ~ 17 | GND | Earth GND |

APPENDIX 2 COMPATIBLE USB FLASH DRIVE BRAND

Please upgrade the firmware of the DVR to the latest version to ensure the accuracy of the following table. If the USB flash drive is not supported by the DVR, the "USB ERROR" message will be shown on the screen.

Note: Please use your PC to format the USB flash drive as "FAT 32".

Note: You can backup up to 2GB video data for one-time USB backup. To backup more data, please set the time & channel(s) you want, and start USB backup again.

| MANUFACTURER | MODEL | CAPACITY | |
|--------------|------------------|----------|--|
| Apacer | AH320 | 2G | |
| | AH320A | 8G | |
| | AH220 | 1G | |
| | AH320 | 4G | |
| A-data | RB-18 | 1G | |
| Transcend | JFV35 | 4G | |
| | JFV30 | 8G | |
| Sony | Micro Vault Tiny | 1G | |
| Sandisk | Cruzer Micro | 2G | |
| | Cruzer Micro | 4G | |
| | Cruzer4-pk | 2G | |
| MSI | F200 | 4G | |
| PQI | U172P | 4G | |
| Netac | U208 | 1G | |

APPENDIX 3 COMPATIBLE HDD BRAND

Please upgrade the firmware of the DVR to the latest version to ensure the accuracy of the following table.

For SATA HDD

•

| MANUFACTURER | MODEL | CAPACITY | ROTATION | |
|--------------|-----------------|----------|----------|--|
| Seagate | ST3320613AS | 320GB | 7200 rpm | |
| | ST33500320AS | 500GB | 7200 rpm | |
| | ST3750330AS | 750GB | 7200 rpm | |
| | ST31000340AS | 1000GB | 7200 rpm | |
| Hitachi | HDT725032VLA360 | 320GB | 7200 rpm | |
| | HDS721010KLA330 | 1000GB | 7200 rpm | |
| | WD3200AAKS | 320GB | 7200 rpm | |
| WD | WD5000AACS | 500GB | 7200 rpm | |
| | WD6400AAKS | 640GB | 7200 rpm | |
| | WD7500AAKS | 750GB | 7200 rpm | |
| | WD10EACS | 1000GB | 7200 rpm | |
| Maxtor | STM3500320AS | 500GB | 7200 rpm | |
| | STM3750330AS | 750GB | 7200 rpm | |

• For IDE HDD

| MANUFACTURER | MODEL | CAPACITY | ROTATION |
|-----------------|-----------------------------------|----------|----------|
| НІТАСНІ | Deskstar 7K250, HDS722516VLAT20 | 160GB | 7200 rpm |
| | HDS722516VLAT80 | 160GB | 7200 rpm |
| | HDS722516DLAT80 | 160GB | 7200 rpm |
| | Deskstar 7K250, HDS722525VLAT80 | 250GB | 7200 rpm |
| | Deskstar 511DHT0021 | 500GB | 7200 rpm |
| | DiamondMax Plus 9, Model#6Y160L0 | 160GB | 7200 rpm |
| | DiamondMax 10 6L160R0 | 160GB | 7200 rpm |
| Maxtor | DiamondMax 10 6L200R0 | 200GB | 7200 rpm |
| | DiamondMax 10 6L200PO | 200GB | 7200 rpm |
| | MaxLine Plus II, Model#7Y250P0 | 250GB | 7200 rpm |
| | DiamondMax 10 6L250R0-3 | 250GB | 7200 rpm |
| | DiamondMax 10 HDMA6L300RO-3 | 300GB | 7200 rpm |
| | Barracuda 7200.7 Plus, ST3160023A | 160GB | 7200 rpm |
| | Barracuda 7200.8 ST3200826A | 200GB | 7200 rpm |
| | Barracuda 7200.8 ST3250826A | 250GB | 7200 rpm |
| Seagate | Barracuda 7200.8 ST3300831A/P | 300GB | 7200 rpm |
| | Barracuda 7200.8 ST3400832A/P | 400GB | 7200 rpm |
| | 7200.9 ST3200827A/P | 200GB | 7200 rpm |
| | 7200.10 ST3250620A/P | 250GB | 7200 rpm |
| | 7200.10 ST3320620A/P | 320GB | 7200 rpm |
| Western Digital | Caviar SE WD1600JB | 160GB | 7200 rpm |
| | Caviar WD2000BB-00DWA0 | 200GB | 7200 rpm |
| | Caviar SE WD2500JB | 250GB | 7200 rpm |
| | Cavir RE WD2500SB-01KBC0 | 250GB | 7200 rpm |

APPENDIX 4 TROUBLESHOOTING

Please refer to the table below for easy troubleshooting. The table describes some typical problems and also their solutions. Please check them before calling your DVR dealer.

• FAQ (Frequently ask question)

| Questions | Solutions | | |
|--|--|--|--|
| No power | Check power cord connection. | | |
| | Confirm that there is power supplied from the outlet. | | |
| DVR is not working when pressing any button | You might be under "Key Lock" mode. Press any key and enter the password to exit | | |
| | this mode. | | |
| HDD detection failed | Replace with another HDD for testing. | | |
| | Replace with another HDD cable for testing. | | |
| | Make sure HDD "Master", "Slave" mode is correctly set. | | |
| Can't detect your USB flash drive | Replace with another USB flash drive for testing. | | |
| | Format the USB flash drive as FAT32 format and try again. | | |
| No live video | Confirm the camera is power supplied. | | |
| | Check the setting of the camera lens. | | |
| | Check the monitor's video cable and connection. | | |
| | Check the camera's video cable and connection. | | |
| No recorded video | Check if the HDD is installed and connected properly. | | |
| | Check the "MANUAL RECORD ENABLE" is set to "ON", and the record function in | | |
| | the "CAMERA" menu is set to "ON" too. | | |
| Timer recording is not working | Check if "TIMER RECORD ENABLE" option is set to "ON" and the timer schedule | | |
| | has been arranged. | | |
| Motion detection recording is not working | Check if "EVENT RECORD ENABLE" option is set to "ON". | | |
| | Check the detection function "DET" is set to "ON". | | |
| | Check the detection area "AREA" has been setup. | | |
| Can't play the recorded data on my DVR | There must be at least 8192 images of recorded data for playback to work properly. | | |
| | If not, your DVR will stop the playback. | | |
| | For example, if the IPS is set to 30, the recording time should be at least 273 | | |
| | seconds (8192 images / 30 IPS) for the playback to work properly. | | |
| Can't backup the video with audio | Make sure the audio cameras are connected to the DVR channels which support the | | |
| | audio function (CH1, CH2, CH3 and CH4). | | |
| Can't view the DVR images over the network | Check the DVR firmware version. | | |
| with IE web browser | Please choose to allow the web browser ActiveX or applet in the pop-out message. | | |
| Failed to backup the recorded files of the DVR | You need to be a supervisor to operate this function. For details, please see | | |
| from remote PC side. | "Account" at page 40. | | |
| (For details, please see "Network Backup" at | t Check if the network connection information is correct (IP Address / Port / User | | |
| page 34.) | Name / Password). | | |
| | Specify the hard disk (HDD Number) and channel number (Channel) within which | | |
| | have the recorded data you need. | | |
| Failed to upgrade the firmware / OSD file | Check the USB flash drive is formatted to FAT32. | | |
| | Check the firmware / OSD file is correct. | | |
| Can't use the IR remote control | Check whether if the batteries are installed or not. | | |
| | Aim at the IR receiving zone and try again. | | |
| | Check the lock button on the DVR front panel is switched to the right position. | | |

APPENDIX 5 RS485 PROTOCOL

- Use PC keyboards to simulate DVR keypads.
- Data: REMOTE PROTOCOL uses 8 bit data, 1 start bit, 1 stop bit.

| | | \succ | | \searrow | |
|------------------|--------|---------|---------------------------|------------|---------------|
| | ↓ ↓ | | \downarrow \downarrow | | + |
| ACT (FFH) | C0H | | ID FUNCTIOI | N | STOP (7FH) |
| FUNCTION | CODE | ASCII | FUNCTION | CODE | ASCII |
| KEY_MENU | 0x4D | М | KEY_SET_CHANNEL | 0x6e | n |
| KEY_ENTER | 0x0D | ENTER | KEY_DWELL | 0x65 | e |
| KEY_PLUS | 0x6b | k | KEY_CH1 | 0x31 | 1 |
| KEY_MINUS | 0x6d | m | KEY_CH2 | 0x32 | 2 |
| KEY_UP | 0x55 | U | KEY_CH3 | 0x33 | 3 |
| KEY_DOWN | 0x4E | N | KEY_CH4 | 0x34 | 4 |
| KEY_LEFT | 0x4C | L | KEY_CH5 | 0x35 | 5 |
| KEY_RIGHT | 0x52 | R | KEY_CH6 | 0x36 | 6 |
| KEY_POWER | 0x57 | W | KEY_CH7 | 0x37 | 7 |
| KEY_REC | 0x72 | r | KEY_CH8 | 0x38 | 8 |
| KEY_PLAY | 0x50 | Р | KEY_CH9 | 0x39 | 9 |
| KEY_SLOW | 0x53 | S | KEY_CH10 | 0x41 | A |
| KEY_ZOOM | 0x5A | Z | KEY_CH11 | 0x42 | В |
| KEY_KEY LOCK | 0x4B | К | KEY_CH12 | 0x43 | С |
| KEY_AUDIO | 0x64 | d | KEY_CH13 | 0x44 | D |
| KEY_SEARCH | 0x73 | S | KEY_CH14 | 0x45 | E |
| KEY_PTZ_MODE | 0x70 | р | KEY_CH15 | 0x46 | F |
| KEY_PTZ_PRESET | 0x71 | q | KEY_CH16 | 0x47 | G |
| KEY_PTZ_ZOOM_IN | 0x69 | i | KEY_EJECT_DVD | 0x6a | j |
| KEY_PTZ_ZOOM_OUT | 0x66 | f | KEY_IRIS_NEAR | 0x67 | g |
| KEY_MODE | 0x6f | 0 | KEY_IRIS_FAR | 0x68 | h |
| KEY_4 CUT | 0x61 | а | KEY_PTZ_LIGHT | 0x6c | I |
| KEY_9 CUT | 0x62 | b | KEY_PTZ_WIPER | 0x77 | w |
| KEY_16 CUT | 0x63 | С | | | |