



S1000 User Manual

Installation
Configuration
Programming
Specifications

Important User Information

Limited Warranty

Hardware: Inico Technologies Ltd. (hereafter *Inico*) warrants that its products are free from defects in material and workmanship for a period of 1 year from the date of invoice from Inico or its appointed distributor. The obligations of Inico under this warranty are limited to replacing or repairing, at its option, any product which shall, in the applicable period, be returned to the Inico facility, transportation charges prepaid, and which after examination is determined, to the satisfaction of Inico, to be thus defective. Products may be returned by Buyer only after permission has been obtained from Inico.

Repaired or replacement Products provided under warranty are similarly warranted for a period of six (6) months from the date of shipment to Buyer or the remainder of the original warranty term, whichever is longer.

This warranty shall not apply to any such equipment which shall have been :

- damaged in shipment to or from Buyer,
- repaired or altered except by Inico,
- subject to improper installation, misuse, neglect, or accident.

This limited warranty is in lieu of all other warranties whether oral or written, expressed or implied.

Firmware: Inico warrants for a period of one (1) year from the date of invoice from Inico or its appointed distributor, as the case may be, that standard firmware Products, when used with Inico-specified hardware, will perform in accordance with published specifications prepared, approved, and issued by Inico. Inico makes no representation or warranty, express or implied, that the operation of the firmware Products will be uninterrupted or error free, or that the functions contained therein will meet or satisfy the Buyer's intended use or requirements. Firmware corrections are warranted for a period of three (3) months from the date of shipment to Buyer or the remainder of the original warranty term, whichever is longer.

Limited Liability

Inico's liability shall not exceed the price of the individual unit which is the basis of the claim. In no event shall Inico be liable for any loss of profits, loss of use of facilities or equipment or other indirect, incidental or consequential damages.

Safety Guidelines

Throughout this manual, when necessary, the following notes are used to make you aware of safety considerations.

**Warning**

Indicates a potentially hazardous situation which could lead to death or serious injury, property damage, and/or economic loss.

**Caution**

Indicates a potentially hazardous situation which could lead to minor or moderate injury, property damage, and/or economic loss.

Notice

Indicates a potential situation which could lead to undesirable results or performance.

Installation and Operation Warnings

**Warning**

Explosion hazard, do not install in potentially explosive atmospheres.

**Warning**

Only qualified personnel should be allowed to install and work on this equipment. Improper installation may lead to property damage, injury, or death.

**Warning**

This product can only function correctly and safely if it is transported, stored, set up, and installed correctly, and operated and maintained as recommended.

Table of contents

Important User Information.....	2
Limited Warranty.....	2
Limited Liability.....	2
Safety Guidelines.....	2
Installation and Operation Warnings.....	3
Table of contents.....	4
1 Product Overview.....	6
1.1 General Description.....	6
1.2 Features.....	6
1.3 Selection Chart.....	7
1.4 Expansion Modules.....	7
1.5 Web-based configuration and programming.....	8
1.6 Web-based HMI.....	8
1.7 Web Services.....	9
1.8 Built-in Apps.....	9
2 Install.....	11
2.1 Mount the Hardware.....	11
2.2 Connect Power, I/O and Communication Wiring.....	11
3 Initial Set Up.....	14
3.1 Access through Web Browser.....	14
3.2 Change IP address.....	14
3.3 Set time and date.....	15
3.4 Set user names and passwords.....	15
3.5 Run and Config start modes.....	16
3.6 Manual Start in Safe Mode.....	16
4 Configure I/O.....	18
4.1 Onboard I/O.....	18
4.2 Expansion I/O.....	20
4.3 Remote I/O.....	21
4.4 W1-Z Wireless I/O System.....	23
5 Program Logic Control.....	28
5.1 Define Global Variables.....	28
5.2 Define Retained Variables.....	29
5.3 Add ST programs.....	29
5.4 Build ST programs.....	29
5.5 ST Syntax.....	30
5.6 ST Built-in Functions.....	31
5.7 Tips and Advice.....	32
6 Program Web Services.....	34
6.1 Introduction to Web Services.....	34

6.2 Creating a new Web Service.....	34
6.3 SOAP Message configuration.....	35
6.4 Sending and receiving SOAP messages.....	37
6.5 WSDL support.....	38
7 Configure HMI Web Pages.....	39
7.1 HMI Values.....	39
7.2 HMI Parameters.....	39
7.3 HMI Alarms.....	40
7.4 HMI Graphics.....	43
7.5 HMI Charts.....	46
8 Send E-mail Reports.....	47
8.1 Create and E-mail Report app.....	47
8.2 Configure SMTP Mail Server Settings.....	47
8.3 Configure Destination and Subject.....	47
8.4 Configure Timed Send Settings.....	47
8.5 Configure the E-mail contents.....	48
9 Log data.....	49
9.1 Create a Value Logger app.....	49
9.2 Configure Timed Save Settings.....	49
9.3 Add data points to save.....	49
9.4 Download log to a PC.....	49
10 Technical Specifications.....	50
10.1 Electrical characteristics.....	50
10.2 Environmental characteristics.....	51
10.3 Mechanical characteristics.....	52
10.4 Pin Descriptions.....	52
10.5 Status Indicators.....	53
11 Expansion modules.....	55
11.1 DIO8, DIO16 – Digital I/O.....	55
11.2 E10 – Energy Analyzer.....	56
11.3 W1-Z – Wireless Module, Zigbee PRO.....	57
12 Compliance and Certifications.....	58
12.1 Electro-magnetic compatibility (EMC).....	58
12.2 Safety standards.....	58
12.3 Hazardous locations.....	58
12.4 IEC 61131-3 Compliance.....	58
13 Revision History.....	61

1 Product Overview

1.1 General Description

The S1000 is a programmable Remote Terminal Unit (Smart RTU) device which offers process control capabilities, as well as a Web-based Human-Machine Interface (HMI), support for Web Services, and many more features that are described in this manual.

The S1000 is designed to operate in typical industrial settings and is compatible with most industrial signal types and levels.

In addition to built-in I/O ports, the S1000 supports expansion modules, which offer additional I/O points as well as specialty functions such as wireless networking and energy monitoring.

1.2 Features

- 32-bit CPU
 - ARM RISC CPU running at 55MHz
 - 8MB flash memory for user programs and data storage
- Logic control using IEC61131-3 Structured Text
 - Web-based ST editor with syntax highlighting
 - Built-in compiler, now need to install tools
- Web-based HMI
 - User-configurable pages
 - Graphic component library: charts, circular and linear gauges, etc
 - Automatic data refresh
- Built-in apps
 - E-mail reports
 - Data logger
 - New apps released through firmware upgrades
- 10/100 Mbit Ethernet
 - Built-in Web server for configuration and monitoring
 - Web Services, compliant with DPWS specifications
 - Support for legacy Ethernet I/O, such as Modbus/TCP
- RS232 serial port
 - User-programmable protocols
 - Support for legacy I/O, such as Modbus/RTU
- CAN port (ISO11898 compliant)
 - Support for legacy I/O, such as DeviceNet or CANOpen
 - Support for specialty equipment, such as smart valves
- 9~36V DC digital inputs and outputs
 - 8 built-in digital inputs

- 8 built-in digital outputs
- 0-20mA, 4-20mA, 0-5V, 1-5V analogue inputs
 - 4 built in analogue inputs
 - Digital signal filtering
- 9~36V DC power supply
 - 1W typical power consumption
- USB 1.1 device port
 - Firmware upgrades with new features released periodically
- Plug-in terminal block connectors
- DIN rail mounting
- -40~85C temperature range
- EMC compliance for North America and Europe

1.3 Selection Chart

The S1000 is available in several configurations. The following chart summarizes the ordering codes and available I/O configurations.

Model	10/100 Mbit Ethernet	12 Mbit USB Port	I/O Expansion bus	8 Digital Inputs	8 Digital Outputs	4 Analog Inputs (4-20mA)	4 Analog Inputs (0-5V)	RS-232, Isolated	CAN bus, Isolated
S1000.B	✓	✓	✓						
S1000.D	✓	✓	✓	✓	✓				
S1000.A	✓	✓	✓			✓			
S1000.DA	✓	✓	✓	✓	✓	✓			
S1000.DAV	✓	✓	✓	✓	✓		✓		
S1000.S	✓	✓	✓					✓	
S1000.C	✓	✓	✓						✓
S1000.DS	✓	✓	✓	✓	✓			✓	
S1000.DC	✓	✓	✓	✓	✓				✓
S1000.DASC	✓	✓	✓	✓	✓	✓		✓	✓

1.4 Expansion Modules


To meet the requirements of a wide variety of applications, the S1000 can be outfitted with up to 4 expansion modules. The following table lists available expansion modules.

Expansion Modules	Type			
Digital I/O				
Input	8x In	16x In	32x In	
Output	8x Out	16x Out	32x Out	
Input/Output	8x In + 8x Out	16x In + 16x Out		
Analog I/O				

Input (0/4-20mA or 0/1-5V)	4x In (common)	4x In (isolated)	8x In (common)	8x In (Isolated)
Communication				
Wireless	W1-Z PRO	Zigbee		
Sensor I/O				
Energy	E10 Three-phase energy analyzer			
Temperature	T1 Thermocouple module		T2 - RTD module	
Other				


1.5 Web-based configuration and programming

The S1000 is fully configurable using a Web browser. All I/O, logic, HMI, Web Services, and other built-in apps are configured and programmed through the Web interface. The S1000 supports both Microsoft Internet Explorer and Mozilla Firefox Web browsers.




1.6 Web-based HMI

The S1000 offers a Web-based HMI engine. Users are able to develop custom HMI pages which can be used to monitor a process and to adjust parameters.



1.7 Web Services

The S1000 can be programmed to send and receive XML/SOAP messages, in order to integrate industrial processes to factory IT systems.



1.8 Built-in Apps

The HMI pages are part of a library of built-in apps which can be enabled and configured to enhance any S1000 system. Among the built-in apps are:

- E-mail reports

- Generates a report on data change, or at predefined time intervals or time of day
- E-mail is sent through a SMTP server using custom user name and password
- Customizable message subjects
- Data logger
 - Saves data on change, or at predefined time intervals or time of day
 - Data can be saved to a PC and edited with MS Excel as a spreadsheet, or using custom software
- Other apps are periodically released via firmware upgrades

2 Install

The S1000 is designed to be easy to install. It is outfitted with clips to easily snap onto standard 35mm DIN rail. All power and I/O connections are made through pluggable terminal blocks. This chapter provides a walk-through of the installation procedure, and provides guidelines for optimal performance.



Warning

Electric shock hazard, installation or service with the power applied can cause electric shock or damage the equipment. Always disconnect power before installing or servicing this product.

2.1 Mount the Hardware

Whether you purchased a stand-alone S1000 device, or an S1000 with expansion I/O modules, the product ships fully assembled and ready to install. The S1000 snaps onto standard 35mm DIN rail.

Notice

Separate the S1000 Devices from High Voltage and Electrical Noise sources. The S1000 has been designed and tested to withstand electromagnetic interference at levels found in industrial settings. However, it is good practice to install low-voltage logic-type devices away from high-voltage and rapidly switched loads, in order to assure optimal performance and extended service life.

Notice

Provide adequate clearance for cooling and wiring. The S1000 is cooled by natural convection air flow, therefore it is good practice to leave sufficient space between devices to allow adequate air flow. Likewise, it is good practice to allow adequate space to install and remove the pluggable terminal blocks used for I/O connections.

2.2 Connect Power, I/O and Communication Wiring

Connect DC power (9-30VDC) to the assigned terminal block. Connect all I/O terminals to the appropriate sensors and actuators. Connect all network and communication cables.

Notice


The S1000 is equipped with reverse polarity protection. However, please ensure the positive and negative terminals are connected correctly to avoid any hazard.

The following diagram and tables provide an overview of the I/O connections



Caution

Please refer to the technical specification section for detailed information on each I/O port. Failure to follow the specifications for each port could lead to malfunction and/or property damage.




2.2.1 Power supply

Pin	Description
+	9-36V
-	0V/Neutral

2.2.2 Digital inputs

Pin	Description
1-8	Input 1-8
C	Common

Digital Inputs may be configured in either sinking or sourcing configurations.



2.2.3 Digital outputs

Digital outputs operate in sourcing mode. They are equipped with diode protection for moderately-inductive loads. However, it is recommended that additional diodes are used for highly-inductive loads.

Pin	Description
1-8	Sourcing Output 1-8
+	10.5-45V
-	0V/Neutral

2.2.4 Analogue inputs

Analogue inputs are designed for 4-20mA sensors. However, the S1000 can be shipped with 0/1-5V inputs by special order.

Pin	Description
1-4	Input 1-4
-	0V/Neutral

2.2.5 Serial port

The serial port complies with RS232 specifications.

Pin	Description
-	0V/Neutral
Rx	Received data
Tx	Transmitted data

2.2.6 CAN port

The CAN port complies with ISO11898 specifications.

Pin	Description
-	CANL pin
+	CANH pin

2.2.7 LAN port

The LAN port provides IEEE 802.3 10/100Mbit communications (Ethernet). Connect preferably to an industrial-rated Ethernet switch. Connect to an office network only if appropriate noise-filtering is installed.

Notice

Network cables can carry significant amounts of electromagnetic noise if not properly installed. Always use industrial-rated switches, or install noise filtering devices if connections to office networks are made. Failure to filter out industrial noise can lead to unexpected operation of office devices.

3 Initial Set Up

3.1 Access through Web Browser

The S1000 is configured entirely through a Web interface. Devices are shipped with a pre-defined IP address, which is based on the serial number. The IP addresses are of the form:

192.168.xxx.yyy

where *xxx* is the first half of the serial number, and *yyy* is the second half of the serial number. For example, for a device with serial number 003-0045, the default IP address is 192.168.3.45.


In order to access the S1000 configuration Web pages, simply type the IP address in the browser address bar.

Notice

The computer used for configuring the S1000 must be in the same subnet as the device. A simple way to guarantee this is to use the following IP configuration:

IP Address: 192.168.0.1

Subnet mask: 255.255.0.0



3.2 Change IP address

In order to set a new IP address for an S1000 device, you must access **Configure** → **Network**. Simply enter the new IP address configuration and click on **Update**.

IP ADDRESS	
INTERFACE	IP CONFIGURATION
IEEE 802.3	IP Address: <input type="text" value="192.168.2.27"/>
	Subnet mask: <input type="text" value="255.255.0.0"/>
	Gateway address: <input type="text" value="192.168.0.1"/>
<input type="button" value="Update"/>	

Notice

Keep a record of the IP address used for each S1000 device. An invalid or lost IP address may lead to undesirable operation.

3.3 Set time and date

The S1000 allows automatic time and date updates using a NTP time server, or manual updates if no NTP server is available. Most modern Windows computers run a NTP server, which must be unblocked in any active firewalls. Likewise, most Linux computers can be configured to act as NTP servers. A list of public NTP servers is also available at .

In order to configure automatic time and date updates using an NTP server, you must access **Configuration** → **Network**. Simply enter the IP address of the time server and the local time zone, and click on **Update**.

If no NTP server is available, the date and time may be set manually through **Configure** → **Options**. Please note that this time and date is lost if the device loses power or is reset.

Date and Time

Adjust the date (dd/mm/yyyy) and time (hh:mm:ss).

Alternatively, the time and date may be set through logic programming using ST language. Please refer to the ST programming section of this manual. This method allows using high-accuracy external clocks, such as GPS devices.

3.4 Set user names and passwords

User names and passwords can be enabled in order to protect access to certain parts of the S1000 Web interface. The user configuration screen is available through **Configure** → **Users**. Setting allow to protect access to monitoring pages and configuration pages.

Notice

Keep a record of the user names and passwords that you enter. Failure to remember username/password combinations may lead to blocked devices. If you lose or forget your username and password and need to access the configuration screen, please contact Inico Technologies for assistance.

User list

Enable user authentication

Require user login to access monitoring interface?

- Yes
 No

Require user login to access configuration?

- Yes
 No

Active users

USERS	
USER NAME	
Admin	Edit Remove

3.5 Run and Config start modes

The S1000 can boot in three possible modes: Run, Config, and Safe Mode.

- Run: compiled ST logic programs and other apps are running, configuration interface disabled.
- Config: Configuration interface enabled, no programs or apps are running.
- Safe Mode: Configuration interface enabled, no programs or apps are running, device accessible through **192.168.0.10**. Non-critical components disabled.

In order to change the start mode, update the configuration in **Configure** → **Options**.

Configuration options

Boot mode

Select the boot mode for the controller:

- Run
 Config
 Safemode

In order to know in which mode the S1000 is running, you may observe the status LEDs visible through the clear front panel. The following table indicates the status indications.

Status	L1 (Blue)	L2 (Green)	L3 (Yellow)	L4 (Red)
Power ON	On	-	-	-
Running	On	On	Off	Off
Stopped - Configuration	On	Off	On	Off
Stopped - Safe mode	On	Off	On	On
Stopped - Error	On	Off	Off	On

3.6 Manual Start in Safe Mode

The S1000 offers the possibility to boot in “Safe Mode”, a special mode use for recovery from abnormal situations. When booting in Safe Mode, the IP Address is always **192.168.0.10**.

In order to enable Safe Mode and recover from an abnormal situation:

1. Disconnect power from the S1000.

2. Connect a USB cable to the S1000 port and to a PC port
3. Connect power to the S1000
4. Access the S1000 configuration interface using the **192.168.0.10** address.
5. Make any necessary configuration changes, such as IP address, or removing programs which are causing errors.

4 Configure I/O

The S1000 I/O system is configured entirely using the Web interface. Each I/O subsystem is referred to as an *I/O module*. S1000 devices are shipped with I/O modules pre-configured and ready to use. However, this section explains the entire process for adding I/O modules to the current configuration and how to set them up. All I/O modules can be added following **Configure** → **I/O** → **Add new I/O module**.



Warning

Adding or setting up I/O modules which are not present in the S1000 assembly, or configuring the wrong kind of I/O module, can cause to unexpected results and malfunction, and lead to equipment damage and injury.

4.1 Onboard I/O

This section explains how to add and set up the onboard I/O modules, which include the built-in digital inputs, digital outputs, analog inputs, and serial port*.

4.1.1 Digital Inputs

In order to use the onboard digital inputs, select **Add new I/O module** and then select **Digital inputs**. You may enter a *friendly name* which will help you identify this module.

Add I/O block

Onboard I/O

Module type:
 Friendly name:

Once added, select the module from the I/O Module list and enter aliases for the inputs which are in use. These aliases can then be used to read the value of the input from ST logic programs, or from other apps such as HMI pages or the data logger.

Configuration: IX0

Friendly name:

POINTS	
ADDRESS	ALIAS
%IX0.0	<input type="text" value="push_button1"/>
%IX0.1	<input type="text" value="push_button2"/>
%IX0.2	<input type="text" value="prox_sensor"/>
%IX0.3	<input type="text" value="limit_switch"/>
%IX0.4	<input type="text" value="run_signal"/>
%IX0.5	<input type="text" value="stop_signal"/>
%IX0.6	<input type="text"/>
%IX0.7	<input type="text"/>

4.1.2 Digital Outputs

Following the same procedure as for digital inputs, add an onboard digital outputs module, and then enter aliases for each of the outputs.

* Not available in all hardware configurations. See selection chart for details.

Add I/O block

Onboard I/O

Module type:
 Friendly name:

Configuration: QX0

Friendly name:

POINTS	
ADDRESS	ALIAS
%QX0.0	<input type="text" value="relay1"/>
%QX0.1	<input type="text" value="relay2"/>
%QX0.2	<input type="text" value="motor_fwd"/>
%QX0.3	<input type="text" value="motor_back"/>
%QX0.4	<input type="text" value="alarm_signal"/>
%QX0.5	<input type="text" value="stacklight_red"/>
%QX0.6	<input type="text" value="stacklight_yellow"/>
%QX0.7	<input type="text" value="stacklight_green"/>

4.1.3 Analog Inputs

Following the same procedure as for digital inputs, add an onboard analogue inputs module, and then enter aliases for each of the input.

Add I/O block

Onboard I/O

Module type:
 Friendly name:

In addition, configure:

- *Input type*: select 4-20mA, 0-20mA, 1-5V, or 0-5V inputs
- *Noise filter*: select a type of filter: 2nd or 4th order FIR, IIR filter, or no filter.
- *Min and Max scale*: values corresponding to the input limits (e.g. 4mA value and 20mA value).

Configuration: ID0

Friendly name:

Input type:
 Noise filter:

POINTS			
ADDRESS	ALIAS	SCALE MIN	SCALE MAX
%ID0.0	<input type="text" value="temperature_in"/>	<input type="text" value="0"/>	<input type="text" value="100"/>
%ID0.1	<input type="text" value="humidity_in"/>	<input type="text" value="0"/>	<input type="text" value="100"/>
%ID0.2	<input type="text" value="pressure_in_1"/>	<input type="text" value="900"/>	<input type="text" value="1100"/>
%ID0.3	<input type="text" value="pressure_in_2"/>	<input type="text" value="500"/>	<input type="text" value="5000"/>

4.1.4 Serial Port

Following the same procedure as for digital inputs, add an onboard RS-232 Serial Port module.

Add I/O block

Onboard I/O

Module type:
 Friendly name:



Caution

If the serial port will be used to access remote I/O, such as Modbus/RTU devices, do not add a serial port module to the configuration, or a resource conflict will occur. If a serial port is already added to the I/O configuration, remove it before adding Modbus/RTU or other serial I/O devices.

Once added, access the serial port configuration from the I/O list, and set the applicable parameters.

The Onboard serial port is always assigned the COM 0 address. Serial ports in expansion modules are assigned COM 1, COM 2, etc. Use address 0 when reading or writing data in ST logic programs.

Configuration: COM0

Friendly name:

PORT	
Port number:	COM0
Baud rate:	38400
Data bits:	8
Parity:	None
Stop bits:	1
TX/RX buffers size:	128

4.2 Expansion I/O

Expansion I/O modules are added in a similar way to onboard I/O modules.

Expansion I/O

Module type:
 Friendly name:

Each expansion module has an assigned slot ID which is needed to identify the module in the configuration screens.

Configuration: IX1

Friendly name:

Expansion slot:

POINTS	
ADDRESS	ALIAS
%IX1.0	<input type="text" value="exp_in_1"/>
%IX1.1	<input type="text" value="exp_in_2"/>
%IX1.2	<input type="text" value="exp_in_3"/>
%IX1.3	<input type="text" value="exp_in_4"/>
%IX1.4	<input type="text"/>
%IX1.5	<input type="text"/>

For details on the configuration of expansion I/O modules, refer to the user manuals of the respective products.

4.3 Remote I/O

The S1000 is compatible with a number of fieldbus protocols, and can therefore read and write I/O points on remote I/O devices.

4.3.1 Modbus/RTU

The S1000 is capable of acting as a Modbus/RTU master, reading and writing discrete and analog values for Modbus/RTU slaves. The Modbus/RTU protocol operates through the built-in RS-232 port. An external RS-232 to RS-485 converter may be necessary in some applications.



Caution

When using the Modbus/RTU capabilities, the serial port cannot be used by other subsystems of the S1000. The serial port must be removed from the I/O Module list, if it has been added. Failure to remove the serial port from the I/O Module list will result in a resource conflict and may lead to unexpected results.

The first step in configuring the S1000 as a Modbus/RTU master is to add a Modbus/RTU Scanner module.

Modbus I/O

Module type:
 Friendly name:

Once added, the Modbus Scanner must be configured. In addition to the standard serial port parameters, a *scan interval* must be specified. This interval specifies how often values on remote I/O are read and written.

Configuration: MBUS0

Friendly name:

MODBUS SERIAL PORT	
Port number:	COM0
Baud rate:	38400
Data bits:	8
Parity:	None
Stop bits:	1
MODBUS MASTER	
Scan interval:	1000 ms (suggested: 1000 ms)

Once a scanner has been added, Modbus register blocks can be added. This includes coils, discretes, registers, and holding registers.

Modbus I/O

Module type:
 Friendly name:

To configure a register block, select it from the I/O module list. Then, configure the slave address and register start address and quantity. Finally, type an alias for each point. The same process is used for all types of Modbus registers.

Configuration: IX2

Friendly name:

REMOTE REGISTERS	
Register type:	Discrete inputs
Slave address:	<input type="text" value="4"/> (Serial: 1-247, TCP: 0/255)
Register block start address:	<input type="text" value="1"/> (1-65536)
Register quantity:	<input type="text" value="8"/> (1-120)

POINTS	
ADDRESS	ALIAS
%IX2.0	<input type="text" value="discrete_4_1"/>
%IX2.1	<input type="text" value="discrete_4_2"/>
%IX2.2	<input type="text" value="discrete_4_3"/>
%IX2.3	<input type="text" value="discrete_4_4"/>
%IX2.4	<input type="text" value="discrete_4_5"/>
%IX2.5	<input type="text" value="discrete_4_6"/>
%IX2.6	<input type="text" value="discrete_4_7"/>
%IX2.7	<input type="text" value="discrete_4_8"/>

4.3.2 Modbus/TCP

The S1000 is capable of acting as a Modbus/TCP client, reading and writing discrete and analog values for Modbus/TCP servers. The Modbus/TCP protocol operates through the built-in Ethernet port.



Caution

The Modbus/TCP and Modbus/RTU functions cannot be used simultaneously. Using both systems will result in a resource conflict and may lead to unexpected results.

The first step in configuring the S1000 as a Modbus/TCP client is to add a Modbus/TCP Scanner module.

Modbus I/O

Module type:
 Friendly name:

Once added, the Modbus Scanner must be configured. In addition to the IP Address and TCP port parameters, a *scan interval* must be specified. This interval specifies how often values on remote I/O are read and written.

Configuration: MBUS1

Friendly name:

MODBUS TCP/IP PARAMETERS	
Modbus server IP address:	<input type="text" value="192.168.2.210"/> (e.g. 192.168.0.100)
Modbus server port:	<input type="text" value="502"/> (default: 502)
Scan interval:	<input type="text" value="1000"/> ms (suggested: 1000 ms)
Keep connection open:	<input type="text" value="Yes"/> (suggested: Yes)

4.3.3 DeviceNet

Please contact Inico Technologies for more information.

4.3.4 CANOpen

Please contact Inico Technologies for more information.

4.4 W1-Z Wireless I/O System

The S1000 can communicate through wireless networks, using appropriate expansion modules. One of these modules is the *W1-Z*, which supports wireless networks using the Zigbee PRO communication standard. Features of this system are:

- Zigbee PRO network
 - IEEE 802.15.4 radio
 - 250kbps data rate
 - 100m range per link
 - Mesh networking, multi-hop packet routing
 - Potentially 100s of devices in a network
- Support for digital and analog points
 - Up to 256 digital points per device
 - Up to 16 analog points per device, 16-bit resolution
- Smart data transfer
 - Update values on change (event-based system) or on timeout (scan-based system)
 - Configurable triggers

4.4.1 Devices a W1-Z Network

An S1000 device with a W1-Z module can take one of two roles: network coordinator, or endpoint+router. In addition, other Inico Wireless I/O devices can join the network as endpoint+router or as sleeping endpoints.

- **Network Coordinator:** there must be one and only one network coordinator device in every network. This devices coordinates other devices joining and leaving the network, and organizes the network structure. The network coordinator also acts as a bridge between wireless devices, and as a gateway between the wireless network and a wired network.
- **Endpoint+router:** all S1000 devices which are not the coordinator act as Endpoint+router nodes. The first role as endpoint is to provide read-only and read-write registers to the wireless network. In addition, these devices can act as routers in the mesh network, relaying messages from other devices to/from the coordinator.
- **Sleeping endpoint:** these are battery-powered sensors, which are able to go to sleep mode in order to conserve power. For a full list of available wireless sensors, please see the Inico catalog.

[TODO Diagram]

Data is always exchanged between an endpoint and the network coordinator. Sometimes the data relayed through router or endpoint+router devices.

Each endpoint is equipped with a set of registers, which hold digital or analog values. There are both read-only and write-only registers. Read-only registers are values that the coordinator can read but not change. Write-only registers are placeholders for values that the coordinator sends to the endpoint. The following table summarizes the types of registers available on endpoint devices:

Register Type	Digital	Analog
Read-only	Values are sent to coordinator on state change or timeout.	Values are sent to coordinator on configurable quantity change or timeout.
Write-only	Values are sent from coordinator to endpoint on change.	Values are sent from coordinator to endpoint on change.

4.4.2 W1-Z Coordinator

The first step in deploying a W1-Z network is to configure an S1000 to act as network coordinator. In order to do so, a W1-Z Coordinator module needs to be added.

Wireless

Module type:
 Friendly name:



Caution

When using the W1-Z module as a coordinator, all other I/O modules are disabled (except for the onboard serial port). Do not attempt to use I/O modules (such as digital I/O or analog inputs), as this will create a resource conflict and may lead to unexpected results. This limitation only applies to the coordinator device.

The next step is to configure the coordinator. Three parameters must be set:

- **Extended PAN ID:** The extended PAN ID is the unique identifier for the wireless network being created. It is a 64-bit identifier, which is encoded as 16 hexadecimal characters (0-9 and A-F). Choose an Extended PAN ID that is a unique number.
- **Short PAN ID:** The Short PAN ID is a short version of the extended PAN ID. After joining the network, devices use the Short PAN ID to save bandwidth. The Short PAN ID is a 16-bit number encoded as 4 hexadecimal characters. Choose an Extended PAN ID which is not in use within the area where the network will be deployed.
- **Radio Channel:** select one of 16 available radio channels. Select a radio channel which is not being used in the deployment area.

Configuration: WLESS0

Friendly name:

W1 COORDINATOR PARAMETERS		
Extended PAN ID:	<input type="text" value="1234567890ABCDEF"/>	(64-bit)
Short PAN ID:	<input type="text" value="9876"/>	(16-bit)
Radio Channel:	<input type="text" value="5"/>	



Caution

Using a duplicate PAN ID or reusing a radio channel may lead to unexpected results.

Notice

Remember to document the network parameters, as these will be needed when configuring other devices in the network.

After the coordinator module has been configured, the next step is to add remote registers to the configuration. Remote registers allow creating a local image of the registers in remote devices. There are four types of registers:

- **Read-only digital registers:** treated as digital inputs at the coordinator, values are received from the remote device.
- **Write-only digital registers:** treated as digital outputs at the coordinator, values are sent to the remote device.

- **Read-only analog registers:** treated as integer inputs at the coordinator, values are received from the remote device.
- **Write-only analog registers:** treated as integer outputs at the coordinator, values are sent to the remote device.

In order to add remote registers, add a new I/O module with the types of registers that shall be used.

Wireless

Module type:
 Friendly name:

Then, select the I/O module from the list and configure the remote endpoint address, and provide aliases to those points that shall be used.

Configuration: IX0

Friendly name:

W1 REMOTE REGISTER BLOCK	
Register type:	Read-only Digital (1-bit)
Remote endpoint address:	<input type="text" value="8"/> (1-65536)
Register quantity:	<input type="text" value="8"/>

POINTS	
ADDRESS	ALIAS
%IX0.0	<input type="text" value="node8_1"/>
%IX0.1	<input type="text" value="node8_2"/>
%IX0.2	<input type="text" value="node8_3"/>
%IX0.3	<input type="text" value="node8_4"/>
%IX0.4	<input type="text" value="node8_5"/>
%IX0.5	<input type="text" value="node8_6"/>
%IX0.6	<input type="text" value="node8_7"/>
%IX0.7	<input type="text" value="node8_8"/>

4.4.3 W1-Z Endpoint

In order to add an S1000 device to a wireless network, a W1-Z Endpoint module needs to be added.

Wireless

Module type:
 Friendly name:

Once added, the appropriate configuration parameters must be set. These include the Extended PAN ID, which must match the one used in the Network Coordinator, and a node address which will identify this S1000 unit in the wireless network.

In addition, *publish parameters* must be configured in order to control when read-only register values are sent/published to the coordinator:

- **Publish digital/analog values on change:** defines whether values are sent to the coordinator on change (event trigger).
- **Analog value change trigger:** the quantity of change required to trigger a change event for analog values.
- **Value publish interval:** defines a timeout after which the read-only values are published, in case no change events are triggered. Can be used for periodically sending values if change triggers are disabled.
- **Heartbeat interval:** defines the interval at which to publish a heartbeat, which contains status information.

Configuration: WLESS0Friendly name:

W1 ENDPOINT PARAMETERS	
Extended PAN ID:	<input type="text" value="1234567890ABCDEF"/> (64-bit)
Endpoint address:	<input type="text" value="8"/> (1-65536)
Radio Channel:	<input type="text" value="5"/>

W1 PUBLISH PARAMETERS	
Value publish interval:	<input type="text" value="0"/> minutes
	<input type="text" value="10"/> seconds
Publish digital values on change:	<input type="text" value="Yes"/>
Publish analog values on change:	<input type="text" value="Yes"/>
Analog value change trigger:	<input type="text" value="5"/>
Heartbeat interval:	<input type="text" value="1"/> minutes
	<input type="text" value="0"/> seconds

After the endpoint module is configured, it is time to add wireless registers to the configuration.

Wireless

Module type:

Friendly name:

Provide aliases to the registers which shall be used, in order to be able to access them from ST logic programs and other apps such as HMI pages.

Configuration: QX0Friendly name:

W1 ENDPOINT REGISTER BLOCK	
Register type:	Read-only Digital (1-bit)
Register quantity:	<input type="text" value="8"/>

POINTS	
ADDRESS	ALIAS
%QX0.0	<input type="text" value="ro_dig_1"/>
%QX0.1	<input type="text" value="ro_dig_2"/>
%QX0.2	<input type="text" value="ro_dig_3"/>
%QX0.3	<input type="text" value="ro_dig_4"/>
%QX0.4	<input type="text" value="ro_dig_5"/>
%QX0.5	<input type="text" value="ro_dig_6"/>
%QX0.6	<input type="text" value="ro_dig_7"/>
%QX0.7	<input type="text" value="ro_dig_8"/>

4.4.4 W1-Z Configurator

Most battery-powered wireless sensors in the Inico catalog do not have a Web-based configuration interface. In order to set their parameters, a special configuration network needs to be created. The configuration parameters are then sent via this wireless network to the sensor.

In order to set up a S1000 as a wireless sensor configurator, a Configurator module must be added.

Wireless

Module type:
 Friendly name:

This configurator node is a Network Coordinator with predefined network parameters, which all wireless sensors have pre-configured. The parameters can be viewed by selecting the Configurator module from the I/O Module list.

Configuration: WLESS0

Friendly name:

W1 REMOTE NODE CONFIGURATOR PARAMETERS

Extended PAN ID: (64-bit)
 Short PAN ID: (16-bit)
 Radio Channel:

Once the S1000 is started in Run mode, a configurator page will appear in the **Monitor** → **HMI Pages** list. This page will list wireless sensors which are currently connected to the configuration network, and allows sending network and publish parameters for when the sensor is started in Run mode.

Remote Wireless Node Configurator

CONNECTED NODES

SERIAL NUMBER	LINK	SIGNAL	BATTERY

Send configuration data

NETWORK PARAMETERS

Extended PAN ID: (64-bit)
 Endpoint address: (1-65536)
 Radio Channel:

DATA PUBLISH PARAMETERS

Value publish interval: minutes
 seconds
 Publish digital values on change:
 Publish analog values on change:
 Analog value change trigger:
 Heartbeat interval: minutes
 seconds

5 Program Logic Control

The S1000 can be programmed to perform logic control using the IEC61131-3 Structured Text (ST) language. This chapter specifies how to use this tool and provides some guidelines. The configuration of ST Logic Programs is available through the Web interface at **Configure** → **ST Logic**.

ST Logic

[Build](#)

VARIABLES	
Global variables	Edit
Retained variables	Edit

ST PROGRAMS	
NAME	
oil_values	Edit Remove
oil_alarms	Edit Remove
water_fill	Edit Remove
water_pumps	Edit Remove
water_valve	Edit Remove
water_alarms	Edit Remove

[Add new](#)

5.1 Define Global Variables

The first step is to define the variables that will be used in the logic programs. All programs share a set of global variables, local variables are not allowed. To access the global variables, follow the Edit link next to the Global Variables label.

Global Variables

```

1  VAR_GLOBAL
2
3  pos1setpoint : real := 2.0;
4  pos1low : real := 0.5;
5  pos1high : real := 3;
6  pos1current : real;
7  pos1alarm : string(4);
8
9  pos2setpoint : real := 2.0;
10 pos2low : real := 0.5;
11 pos2high : real := 3;
12 pos2current : real;
13 pos2alarm : string(4);
14
15 pos3setpoint : real := 2.0;
16 pos3low : real := 0.5;
17 pos3high : real := 3;
18 pos3current : real;

```

5.1.1 Variable declaration syntax

VAR Syntax	VAR Example
<pre> VAR_GLOBAL (identifier : type[(capacity)] [:= initial_value];)* END_VAR </pre>	<pre> VAR_GLOBAL myBooleanVar : BOOL; myOtherBooleanVar : BOOL := TRUE; myIntVar : INT; myOtherIntVar : INT := 123; myRealVar : REAL := 123.45; myStringVar : STRING(20) := 'Hello World!'; END_VAR </pre>

Notes:

1. Supported types are BOOL, INT, DINT, REAL, STRING
2. String variables **must** define a capacity
3. Integers can be declared as types INT or DINT (Double INT). Although INTs are standardized as 16-bit values, both INT and DINT are treated as 32-bit signed integers, due to the 32-bit architecture of the S1000.
4. Identifiers are case insensitive.

5.2 Define Retained Variables

The S1000 allows defining retained variables. In order to access the retained variable list, click on the Edit link next to the Retained Variables label. In order to add a retained variable, enter the alias of the variable and click on Add.

RETAINED VARIABLES		
ALIAS	TYPE	
pos1setpoint	real	Edit Remove
pos2setpoint	real	Edit Remove

Add retained variable

Variable alias:

Retained variables are not saved automatically, they must be saved by the user through the SAVE_RETAIN() function in ST logic.



Caution

Retained variables are saved to Flash memory. Flash memory has a maximum erase/write life of 100.000 cycles. Beyond this number of writes, results can be unexpected. Use the SAVE_RETAIN() function with caution in order not to exceed this maximum.

5.3 Add ST programs

ST Programs can be added by using the **Add New** button. Follow the Edit link in order to edit the program.

oil_values

```

1 PROGRAM oil_values
2
3 wait(2000);
4
5 pos1current := pos1current - 0.1 + RAND(21) / 100.0;
6 IF pos1current < 0.1 OR pos1current > 4.9 THEN pos1current := pos1setpoint; END_IF
7
8 pos2current := pos2current - 0.1 + RAND(21) / 100.0;
9 IF pos2current < 0.1 OR pos2current > 4.9 THEN pos2current := 0.4; END_IF
10
11 pos3current := pos3current - 0.1 + RAND(21) / 100.0;
12 IF pos3current < 0.1 OR pos3current > 4.9 THEN pos3current := pos3setpoint; END_IF

```

5.4 Build ST programs

Once that the programming work is completed, you must Build the programs (internal compilation). Use the Build button to compile all programs. If any errors are encountered during compilation, a descriptive message will be shown, together with a link to the corresponding program.

Build terminated with errors.

Program: oil_values.

Errors: 3

```

Line: 12 - Undefined identifier
Line: 12 - Type mismatch
Line: 12 - Type mismatch

```

5.5 ST Syntax

This section describes the syntax used in ST programs. For a more complete reference, please refer to the IEC 61131-3 standard.

5.5.1 Assignment statements

Example expression:

```
result := A + B - C;
```

Operands:

Operation	Symbol
Parenthization	(Expression)
Function evaluation	Identifier (argument list), e.g. ABS(X)
Exponentiation	**
Negation	-
Complement	NOT
Multiply	*
Divide	/
Modulo	MOD
Add	+
Subtract	-
Comparison	<, >, <=, >=
Equality	=
Inequality	<>
Boolean AND	& AND
Boolean exclusive OR	XOR
Boolean OR	OR

5.5.2 Conditional statements

IF Syntax	IF Example
<pre> IF condition THEN Statement_list; [ELSIF condition THEN Statement_list;] [ELSE Statement_list;] END_IF </pre>	<pre> D := B*B-4*A*C; IF D < 0.0 THEN NROOTS := 0; ELSIF D = 0.0 THEN NROOTS := 1; ELSE NROOTS := 2; END_IF; </pre>

5.5.3 Iteration statements

FOR Syntax	FOR Example
<pre> FOR var := init_value TO end_value [BY step] DO </pre>	<pre> FOR i := 1 TO 100 BY 2 DO </pre>

Statement_list; END_FOR;	j := i * 2; END_FOR
-----------------------------	------------------------

WHILE Syntax	WHILE Example
WHILE expression DO Statement_list; END_WHILE;	i := 1; WHILE i < 100 DO j := i + 2; END_WHILE;

REPEAT Syntax	REPEAT Example
REPEAT Statement_list; UNTIL expression END_REPEAT;	i := 1; REPEAT j := i + 2; UNTIL i >= 100 END_REPEAT;

5.5.4 Return statement

RETURN Syntax	RETURN Example
RETURN;	IF error = true THEN RETURN; END_IF

5.6 ST Built-in Functions

This section describes the supported ST functions, both standard functions and S1000-specific functions.

5.6.1 Flow control

WAIT (*milliseconds*) – suspends execution of the program for the specified number of milliseconds.

WAIT_UNTIL (*expression*) – suspends execution of the program until the expression becomes true.

5.6.2 Retained variables

SAVE_RETAIN () – saves the retained variables to flash memory.

5.6.3 Serial port

SERIAL_GETC (*port*) – returns the first byte from the *in_buffer* of the selected COM port, or -1 if buffer empty.

SERIAL_READ(*port, string, count*) – reads into *string* up to *count* bytes from the *in_buffer* of the selected COM port. Read data is appended, existing contents of *string* are not overwritten. Returns the number of bytes effectively read.

SERIAL_PUTC (*port, char*) - places a byte in the *out_buffer* of the selected COM port.

SERIAL_WRITE (*port, string*) – copies an entire string to the *out_buffer* of the selected COM port.

5.6.4 String manipulation

BOOL_TO_STR (*bool, string*) – converts the Boolean value to a string (“true” or “false”)

INT_TO_STR (*int, string*) – converts the Integer value to a string (e.g. “123”)

INT_TO_HEX (*int, string*) – converts the Integer value to a string in hexadecimal representation (e.g. “A528DF01”)

REAL_TO_STR (*real, string*) – converts the Real (float) value to a string (e.g. “123.45”)

STR_TO_BOOL (*string*) – returns the parsed value of the string as a Boolean.

STR_TO_INT (*string*) – returns the parsed value of the string as an Integer.

STR_TO_REAL (*string*) – returns the parsed value of the string as a Real (float).

STR_LEN (*string*) – returns the number of characters in the string.

STR_LEFT (*string1, string2, n*) – copies *n* characters from *string1* to *string2*, counting from the left.

STR_RIGHT (*string1, string2, n*) – copies *n* characters from *string1* to *string2*, counting from the right.

STR_MID (*string1, string2, start, n*) – copies *n* characters from *string1* to *string2*, counting from the character at index *start*.

STR_CONCAT (*string1, string2*) – appends *string1* to *string2*.

STR_FIND (*string1, string2*) – returns the index of the first occurrence of *string1* within *string2*, or -1 if not found.

STR_CHAR (*string, n*) – returns the character found at index *n*.

STR_PEND (*string, c*) – appends character *c* to *string*.

5.6.5 Date and time

DATETIME (*string*) – writes the current date and time to a string

TIME_MILLIS () – gets the number of milliseconds elapsed since logic execution started.

SET_TIME (*int, int, int, int*) – sets the current time, parameters are hh:mm:ss.mmm

SET_DATE (*int, int, int*) – sets the current time, parameters are yyyy/mm/dd

5.6.6 Web Services

WS_PUBLISH (*message*) – publishes the specified message to all subscribers.

WS_RESPOND (*message*) – responds to a received WS command with the specified message.

WS_SEND (*message, address*) – sends the specified message to address.

WS_GET_RESPONSE (*message*) – returns a response code according to the status of the message transmission following WS_SEND.

For more information on Web Services commands, please see the Web Services section.

5.7 Tips and Advice



Caution

Verify that your code is free of deadlocks, such as infinite loops. Deadlocks will cause the controller to freeze, which could lead to unexpected results leading to equipment damage and/or injury.

If a deadlock occurs, a watchdog timer will detect this condition and reset the controller.

Notice

When running ST programs for the first time, consider accessing the **Monitor** → **Statistics**

page in order to verify proper runtime parameters. Verify that there is sufficient memory to load all programs, and verify the execution time to ensure that there are no scan cycle overruns.

6 Program Web Services

This chapter explains how to set up the S1000 to use Web Services, which are used to easily integrate industrial processes to PC software applications.


6.1 Introduction to Web Services

Web Services are used to easily integrate S1000 controllers to PC-based monitoring and supervisory control applications. Data is exchanged through an Ethernet LAN in real time (<10 ms) using XML/SOAP format. Use Web Services to receive process data and display it in your monitoring solution, and to send process control and configuration data from your supervisory application.

Web Services is the technology endorsed by the major programming languages (Java, Microsoft .NET C# and Visual Basic) to integrate distributed applications. Using these languages, it is easy to send and receive data to/from S1000 units, without needing any special drivers installed.

The S1000 programming environment allows you to easily define new Web Services, link Web Services to ST programs, and send/receive messages from your logic code.

The Web Services use XML messages that conform to the SOAP standard, and also to the Devices Profile for Web Services (DPWS) specification. DPWS provides standardized mechanisms for small devices (such as an S1000) to publish its Web Services so that PC applications can discover the devices that available in the local network.



6.2 Creating a new Web Service

To create a new Web Service, enter the S1000 configuration interface and select the **Configure** → **Web Services** section. Use the **Add new** option to create a new Web Service. The new Web Service should appear in the list. Choose to **Edit** the new Web Service from the list.

Web Services

WEB SERVICES	
NAME	
my_service	Edit Remove
<input type="button" value="Add new"/>	

OPTIONS	
DPWS Version	1.0 (February 2006) <input type="button" value="v"/>
Device friendly name:	My S1000 #27
Device serial number:	002-0027
Response timeout:	2000 milliseconds
<input type="button" value="Save"/>	

The first step to configure is the **ServiceID** and the **Service Types**:

- **ServiceID (mandatory)**: this is the unique identifier for this Web Service. It is recommended to select an ID value that is meaningful and unique within the network. For example, choose an ID value of “Conveyor23” for the Web Service associated to the 23rd conveyor in an assembly line. White spaces are allowed in the Service ID, but strongly discouraged as some PC applications might have problems handling white spaces.
- **Service Types (optional)**: a list of types that describe this type of service, separated by spaces. Service types allow you to categorize Web Services, which is useful to organize and work with all the Web Services in a particular network. For example, choose a type of “Conveyor” for all Web Services associated to conveyors in an assembly line. Service types are optional, but strongly encouraged for medium to large systems where many Web Services are deployed.

Once you have entered the Service ID and optionally the service types, click on the **Save** button.

Web Service: my_service

Service ID:

Service types:

Messages

EVENTS	
ALIAS	ACTION
<input type="button" value="Add new"/>	

INPUT MESSAGES	
ALIAS	
<input type="button" value="Add new"/>	

OUTPUT MESSAGES	
ALIAS	
<input type="button" value="Add new"/>	

6.3 SOAP Message configuration

A Web Service provides an interface to an industrial process that is being monitored and/or controlled by an S1000 unit. As such, a Web Service is a collection of several incoming and outgoing XML messages. These messages are formatted according to the SOAP standard.

6.3.1 Message types

There are three types of messages that can be added to a Web Service:

- **Input messages:** these are messages that are sent from a PC application to the S1000. Typically, these messages will convey commands to execute a particular action, or can also be used to transfer configuration data. They can also be used to request data, such as the state of a process that is being executed or the value of a measured parameter. A response message (S1000→PC) can be configured, or left blank if not used.
- **Output:** these are messages that are sent from the S1000 to a PC application. As with input messages, they may or may not use a response message.
- **Event messages:** these are messages that are sent from the S1000 to one or more PC applications. Typically, these messages will report events such as the completion of a process, a significant change in a process parameter, or a fault/error/warning condition. In order to receive a copy of these messages, PC applications must *subscribe* to the S1000, so that an internal list of interested applications can be maintained. The number of subscribed applications for an event message can be zero, one, or many.

6.3.2 Input message configuration

To add an input message to a Web Service, click on the **Add new** button from the Input Message list. A blank message will be added to the list.

Three parameters need to be configured for an input message:

- **Alias (mandatory):** used as a reference to this message from ST logic. Duplicate aliases for different messages are not allowed.
- **Program name (mandatory):** the name of the ST program to be executed when this message is received. This must be a valid name from one of the saved ST programs.
- **Action (mandatory):** used to identify the type of this message. Different types of messages have a different Action parameter, but if the same message is re-used in different S1000 units, then the same action should be used each time. As a convention, the action parameter is a Web URL, e.g. *http://www.inicotech.com/soap/ConveyorStart*. This makes it easy to generate unique Actions for each type of message. Optionally, a Web Page can be loaded at the specified location in order to describe the message. This serves as a good reference for programmers.
- **Response Action (optional):** used to identify the type of the response message generated, if any. If no response message is to be generated, this field should be left blank.

INPUT MESSAGES			
ALIAS			
ConveyorStartMsg	ST Program:	conv_start_prog	
Remove	Request action:	http://www.inicotech.com/soap/ConveyorStart	Edit body
	Response action:	http://www.inicotech.com/soap/ConveyorStartResp	Edit body
		Save	
Add new			

6.3.3 Output message configuration

To add an output message to a Web Service, click on the **Add new** button from the Output Message list. A blank message will be added to the list.

Two parameters need to be configured for an output message:

- **Alias (mandatory):** used as a reference to this message from ST logic. Duplicate aliases for different messages are not allowed.
- **Action (mandatory):** used to identify the type of this message. The same rules as for an input message apply.
- **Response Action (optional):** used to identify the type of the response message to be received, if any. If no response is expected, this field should be left blank.

6.3.4 Event message configuration

To add an event message to a Web Service, click on the **Add new** button from the Event Message list. A blank message will be added to the list.

Two parameters need to be configured for an event message:

- **Alias (mandatory):** used as a reference to this message from ST logic. Duplicate aliases for different messages are not allowed.
- **Action (mandatory):** used to identify the type of this message. The same rules as for an input or output message apply.

6.3.5 XML configuration

Once that all input, output, and event messages have been added, it's time to specify the actual XML content of each message.

To generate or edit the XML data contained by each message, select the Edit option next to the corresponding message entry. An XML editor screen will be displayed.

Type in, or copy-and-paste from an existing file, the XML structure of the message. In order to make the value of an element or attribute variable, type the *alias of a string variable* as the value of the element or attribute, preceded by the '\$' character. If this is an input/command message, the received value of the element/attribute will be copied to the named variable. If this is an output/response or event message, the value of the variable will be used when the XML message is generated. Element and attribute values which are not of the '\$variable' form will be treated as constants.

Edit Message

```

1 <ConveyorStart convSpeed="$convSpeedValue">$convStartValue</ConveyorStart>
2
3
4
5
6
7

```

Notice

In this step, the SOAP Body contents are specified. The SOAP Headers are automatically set up by the S1000 according to WS-Addressing.

If the entered XML has an error, the entire SOAP message will be shown on the next edit. In this case, fix the Soap Body part to ensure XML compliance, and leave the SOAP Envelope and Header untouched.

6.4 Sending and receiving SOAP messages

6.4.1 Working with Input messages

For input messages, when the message is received, the named ST Program will be executed. If any variable data was sent with the message, it will be available from the string variables configured in the XML message structure.

In addition to executing any logic, the ST program must send back a response message, using the **WS_RESPOND(msg_alias)**. Even if no SOAP response is configured, a **WS_RESPOND(msg_alias)** should be used to send an empty response back. Any parameters for the response message must be set before calling **WS_RESPOND(msg_alias)**.

6.4.2 Sending output messages

If an output message is to be sent to a PC application, the command **WS_SEND(msg_alias, service_address)** can be used from any ST program. The message will be automatically sent to the specified service. In order to check when a response has been received, or to check if there were any

errors in the communication, the command **WS_GET_RESPONSE**(msg_alias) is used. The return codes for this command are:

- 0 – Response not received
- 1 – Response received OK
- 2 – SOAP Fault received
- 3 – Unexpected response type/action
- 4 – Malformed response, not valid XML
- 5 – Connection error, could not connect to destination web service
- 6 – Bad address, address not valid
- 7 – Out of memory error

6.4.3 Sending event messages

If an event message is to be sent to all subscribed PC applications, the command **WS_PUBLISH**(msg_alias) can be used from any ST program. A copy of the message will be automatically sent to every subscribed PC application. If no applications are subscribed, the event isn't sent through the network at all.

6.4.4 ST Command summary

The following two commands are used from ST programs to send XML/SOAP messages:

- **WS_RESPOND**(msg_alias): a response to an input/command message is generated and sent back. Any variable data should be set/copied to the corresponding string variables before this command is invoked.
- **WS_SEND**(msg_alias, destination_address): an output message is sent to destination_address. Any variable data should be set/copied to the corresponding string variables before this command is invoked.
- **WS_GET_RESPONSE**(msg_alias): Returns a response code according to the status of the output message transmission.
- **WS_PUBLISH**(msg_alias): an event message is generated and sent to every subscribed PC application. Any variable data should be set/copied to the corresponding string variables before this command is invoked.

6.5 WSDL support

In order to associate a WSDL to the Web Service, use the **Upload WSDL** utility.

WSDL



7 Configure HMI Web Pages

The S1000 is equipped with an HMI engine, which allows you to develop custom Web pages to display real-time process data. All HMI Pages are added by accessing **Configure** → **App Library** and clicking on **Add New Application**. Each HMI Page is treated as an individual app.

Notice

In order to enable proper rendering and real-time refresh of HMI Pages, please make sure that your browser has Javascript enabled.

7.1 HMI Values

HMI Values are used to display a list of variable and I/O point values, together with a description of the value. It is the simplest form of HMI pages. The values are updated automatically on screen. In order to add an HMI Values page, create a new app of the corresponding type.

Enter new application data

Application friendly name:
 Application type:

Once created, follow the edit link to set the page configuration, including a page title, refresh interval, and values to display.

Configuration: HMI Values

Data saved.

CONFIGURATION			
Page title:	<input type="text" value="Current Values"/>		
Refresh interval:	<input type="text" value="5s"/>		
VALUES			
ALIAS	TYPE	DESCRIPTION	
pos1current	real	Current Level, position #1	Edit Remove
pos2current	real	Current Level, position #2	Edit Remove

Add value

Variable alias:
 Value description:

When the S1000 is started in Run mode, the page will be available in the **Monitor** → **HMI section**.

Current Values

VALUES		
ALIAS	VALUE	DESCRIPTION
pos1current	0.00	Current Level, position #1
pos2current	0.00	Current Level, position #2

7.2 HMI Parameters

HMI Parameters are used to display a list of parameter values, which can be modified by an operator. In order to add an HMI Parameters page, create a new app of the corresponding type.

Enter new application data

Application friendly name:
 Application type:

Once created, follow the edit link to set the page configuration, including a page title, and values to display.

Configuration: Parameter Settings

Data saved.

CONFIGURATION			
Page title:	<input type="text" value="Parameter Settings"/>		

PARAMETERS			
ALIAS	TYPE	DESCRIPTION	
pos1setpoint	real	Position #1 Target level	Edit Remove

Add parameter

Variable alias:
 Parameter description:

When the S1000 is started in Run mode, the page will be available in the **Monitor** → **HMI section**. To change the value of a parameter, edit the applicable form field and click on **Apply**. You can also configure the variables used as parameters to be Retained Variables (see applicable section). If some of the parameters are set to be retained, you can click the **Save** button to retain the value. The value will be reloaded if the controller is reset or loses power.

Parameter Settings

PARAMETERS		
ALIAS	VALUE	DESCRIPTION
pos1setpoint (real)	<input type="text" value="2.00"/>	Position #1 Target level
pos2setpoint (real)	<input type="text" value="2.50"/>	Position #2 Target level

Retained values

Save retained values:

7.3 HMI Alarms

HMI Alarms are used to display a list of active alarms and warnings, when variables or I/O points exceed predefined limits. In order to add an HMI Alarms page, create a new app of the corresponding type.

Enter new application data

Application friendly name:
 Application type:

Once created, follow the edit link to set the page configuration, including a page title, refresh interval, and the values which will be used to generate alarms and warnings.

Configuration: Alarms

Data saved.

CONFIGURATION			
Page title:	<input type="text" value="Alarms"/>		
Refresh interval:	<input type="text" value="5s"/>		
ALARMS			
ALIAS	TYPE	CAPTION	
pos1current	real	Level out of range, position #1	Edit Remove

Add alarm

Point alias:

Alarm caption:

Once the alarm sources have been added, follow the Edit link in order to configure details for each alarm source. These are:

- **Point alias:** the alarm source, a variable or I/O point
- **Data type:** the data type for the source: boolean, integer, or real.
- **Caption:** a description for the alarm
- **Alarm level:** one of Alarm or Warning. Alarms require acknowledgment by an operator in order to be cleared, whereas Warnings represent less critical situations which do not require operator acknowledgment.
- **High limit:** the value above which an alarm or warning is triggered.
- **Low limit:** the value below which an alarm or warning is triggered.

Configuration: Alarms

Level out of range, position #1

LEVEL OUT OF RANGE, POSITION #1	
Source	Point alias: <input type="text" value="pos1current"/>
	Data type: <input type="text" value="Real"/>
Description	Caption: <input type="text" value="Level out of range, posit"/>
	Alarm level: <input type="text" value="Alarm"/>
Limits	High value: <input type="text" value="5.0"/>
	Low value: <input type="text" value="1.0"/>
<input type="button" value="Save"/>	

When the S1000 is started in Run mode, the page will be available in the **Monitor** → **HMI section**. If there are any active alarms or warnings, these will be shown with the following color codes:

- **White font with red background:** Alarm is active and unacknowledged.
- **Red font:** Alarm is active and has been acknowledged.
- **Magenta font:** Alarm is no longer active, but has not been acknowledged yet.
- **Blue font:** Warning is active and unacknowledged
- **Cyan font:** Warning is active and has been acknowledged.

The following capture shows an active alarm.

ALARMS				
CAPTION	CURRENT VALUE	TRIGGER VALUE	TRIGGER TIME	ACKNOWLEDGEMENT
Level out of range, position #2	0.71	0.94	12:23:04 05/05/2010	(Not Acknowledged)

In order to acknowledge the alarm, click anywhere on the alarm line. Enter an acknowledgment message and click on Acknowledge.

ALARMS				
CAPTION	CURRENT VALUE	TRIGGER VALUE	TRIGGER TIME	ACKNOWLEDGEMENT
Level out of range, position #2	0.79	0.94	12:23:04 05/05/2010	(Not Acknowledged)

Message:

Once acknowledged, the alarm will change state.

ALARMS				
CAPTION	CURRENT VALUE	TRIGGER VALUE	TRIGGER TIME	ACKNOWLEDGEMENT
Level out of range, position #2	0.85	0.94	12:23:04 05/05/2010	Level being corrected, ack by IvDe

If the alarm becomes inactive before it is acknowledged, it will be shown in magenta color. After it is acknowledged, it will disappear from the list.

ALARMS				
CAPTION	CURRENT VALUE	TRIGGER VALUE	TRIGGER TIME	ACKNOWLEDGEMENT
Level out of range, position #2	1.17	0.97	12:25:24 05/05/2010	(Not Acknowledged)

The following capture shows an active Warning.

ALARMS				
CAPTION	CURRENT VALUE	TRIGGER VALUE	TRIGGER TIME	ACKNOWLEDGEMENT
Level out of range, position #1	0.56	1.45	12:47:55 05/05/2010	(Not Acknowledged)

In order to acknowledge it, click on the Warning line and provide an acknowledgment message.

ALARMS				
CAPTION	CURRENT VALUE	TRIGGER VALUE	TRIGGER TIME	ACKNOWLEDGEMENT
Level out of range, position #1	0.41	1.45	12:47:55 05/05/2010	Level ok

Unacknowledged Warnings disappear from the list when they are no longer active, regardless of whether they have been acknowledged or not.


In addition to the active alarm and warning list, an Alarm Log is accessible through the HMI Pages list. The Log provides a record of the latest Alarm events, as well as any acknowledgment messages entered by operators.

Alarm Log

```
[INFO] Device power up.
[ALARM] Level out of range, position #2=0.97 at 12:25:24 05/05/2010
[ALARM] Level out of range, position #2=0.99 at 12:25:18 05/05/2010
[ACKNOWLEDGED] Level out of range, position #2 at 12:25:08 05/05/2010, Level being corrected, ack by IvDe
[ALARM] Level out of range, position #2=0.94 at 12:23:04 05/05/2010
[ACKNOWLEDGED] Level out of range, position #2 at 00:00:21 01/01/2000, Level corrected, ack by IvDe
[ALARM] Level out of range, position #2=0.21 at 00:00:10 01/01/2000
[INFO] Device power up.
[ACKNOWLEDGED] Level out of range, position #2 at 12:19:45 05/05/2010, Level corrected, ack by IvDe
[ALARM] Level out of range, position #2=0.32 at 00:00:10 01/01/2000
[INFO] Device power up.
[ACKNOWLEDGED] Level out of range, position #2 at 00:00:55 01/01/2000, Level corrected, ack by IvDe
[ACKNOWLEDGED] Level out of range, position #1 at 00:00:38 01/01/2000, Level corrected, ack by IvDe
[ALARM] Level out of range, position #2=0.00 at 00:00:10 01/01/2000
[ALARM] Level out of range, position #1=0.00 at 00:00:10 01/01/2000
[INFO] Device power up.
```

7.4 HMI Graphics

HMI Graphics allow user to create custom graphic HMI pages. These pages can contain graphic elements such as **circular and linear gauges**, **formatted text values**, and predefined (rectangle, oval) and **custom shapes**. **Animation effects** such as component rotation, translation, and color change are also possible.



7.4.1 Create an HMI Graphics Page

In order to add an HMI Graphics page, create a new app of the corresponding type.

Enter new application data

Application friendly name:

Application type:

Once created, follow the Edit link in order to configure the page. Start by setting basic parameters such as the page title, size, and background color, as well as the refresh rate.

CONFIGURATION	
Page title:	Water Station Quick View
Page width:	600
Page height:	400
Background color:	ffffff
Background gradient color:	eeeeee
Border width:	1
Border color:	888888
Refresh interval:	3s

7.4.2 Colors and gradients

Colors are specified using a long-form 6 hexadecimal characters (0-9 and A-F) or a short-form 3 hexadecimal characters. In the long form, there are two characters for each the red, green, and blue components, whereas the short form uses one character for each. Some example colors are:

- Red: FF0000 or F00
- Green: 00FF00 or 0F0
- Blue: 0000FF or 00F
- Yellow: FFFF00 or F00
- White: FFFFFFFF or FFF
- Grey: 888888 or 888
- Black: 000000 or 000

Some components allow you to define a gradient color. If used, the component will be rendered with the primary color fading into the gradient color. If you need a solid color, leave the gradient color blank.

7.4.3 Labels and Value text

A **Label** component allows you to display a fixed text at a specified location and with a specified format. The configuration fields for labels are:

- Component Id: an identifier for this component, useful when browsing a list of components.
- Text: the text to display in the HMI page.
- X and Y: the location of the text.
- Font, Font Size, Font Weight, and Font Color: the format of the text.

A **Value Text** component allows you to display the value of a variable or I/O point at a specified location and with a specified format. The configuration fields for value text components are:

- Component Id: an identifier for this component, useful when browsing a list of components.
- Alias: the alias of the variable or I/O point which is the source of the text value.
- Data type: the data type of the value source, one of boolean, integer, real or string.
- X and Y: the location of the text.
- Font, Font Size, Font Weight, and Font Color: the format of the text.

7.4.4 Shapes and Toggle Shapes

A **Shape** component allows you to display a fixed shape at a specified location. A shape can follow a predefined pattern, such as rectangle or ellipse, or follow a custom path specification. The configuration fields for shape components are:

- Component Id: an identifier for this component, useful when browsing a list of components.
- Shape: the type of shape to render, one of rectangle, ellipse, or custom.
- Stroke color and width: the display specifications for the edge of the shape.
- Fill color: the color to fill the shape, leave blank for no fill.
- Gradient color: leave blank for solid color, or specify a color to create a gradient effect.
- X and Y: the location of the shape.
- Width/path: the width of rectangles and ellipses, or path specification for custom shapes.
- Height: the height of rectangles and ellipses, ignored for custom shapes.

In order to specify a custom shape, a path must be specified using SVG format. The commands to draw lines are:

Command	Name	Parameters	Description
M (Absolute) m (relative)	moveto	(x y)+	Moves the pointer to a new location, without drawing (pen up).
L (Absolute) l (relative)	lineto	(x y)+	Draws a line from the current point to the specified point (pen down).
Z or z	closepath	(none)	Close the current path by drawing a straight line from the current point to the initial point.

For example, the following path generates a triangle shape:

```
l 50 100 l -100 0 z
```



For more information on SVG paths, including how to specify curves, visit <http://www.w3.org/TR/SVG/paths.html>.

A **Toggle Shape** component is very similar to a shape component, but allows two states which are controlled by a variable. This allows changing the colors of a shape, and also provide rotation and translation effects, controlled by a boolean value. The configuration fields for toggle shape components are the same as for shapes, with the following fields added:

- Alias: the alias of the variable used to control the render state of the shape.
- Stroke color and width (true): the display specifications for the edge of the shape when the control variable is true.
- Fill and gradient color (true): the fill specifications of the shape when the control variable is true.
- Rotation (true): specified in degrees, the angle to rotate the shape when the control variable is true. Leave blank or specify 0 for no rotation.
- Translation (true): specified as an (x y) pair, the number of pixels to translate the shape when the control variable is true. Leave blank for no translation. E.g. use 100 -50 to translate the shape 100 pixels to the right and 50 pixels up.

7.4.5 Gauges

A **Gauge** component is used to display the value of a variable or I/O point using a dial or meter. Circular, semi-circular, and linear gauges are available. The configuration fields for gauge components are:

- Component Id: an identifier for this component, useful when browsing a list of components.
- Alias: the alias of the variable or I/O point which is the source of the value.
- Data type: the data type of the value source, one of integer or real.
- X and Y: the location of the text.
- Min and max value: the limits to display on the gauge.
- Major and minor ticks: the intervals at which to render ticks. Major ticks are labeled, and minor ticks are unlabeled. A rule of thumb is to define Major ticks which are about 20-25% of the total range (max value – min value), and Minor ticks which are about 20-25% of the Major tick.
- Text: a caption for the gauge.
- Units: the units to display next to the value reading. Tip: for a degree sign, use the ° symbol.

- Shape: the shape of the gauge, one of circular, semi-circular, horizontal, or vertical.
- Border color and width: the specification of the gauge edge.
- Fill color and gradient: the specification of the gauge background.
- Needle color and width: the specification of the gauge needle for circular gauges, or the indicator for linear gauges.
- Needle cap fill color and gradient: the specification for the needle cap.
- X and Y: the location of the gauge.
- Width and height: the size of the gauge.
- Font, Font Size, Font Weight, and Font Color: the format of the text.

7.5 HMI Charts

HMI Charts allows creating custom trends, bar and pie charts, and other visual data representation.

[TODO document charts]

8 Send E-mail Reports

Within the S1000 App Library is the E-mail Reports app. This app allows you to send e-mail with a summary of variable and I/O point values. E-mail reports can be sent when a variable changes value (useful for sending alarm or warning messages), or at specified time intervals.

8.1 Create and E-mail Report app

To create an Email report app, follow instructions on the **Configure** → **App Library** → **Add New Application** page.

Enter new application data

Application friendly name:
 Application type:

8.2 Configure SMTP Mail Server Settings

The first step is to configure the SMTP server settings. You should obtain the information required in this section from your Email system administrator. The required information is:

- SMTP server IP address
- SMTP server port (the default value is 25)
- The account name and password

E-MAIL ACCOUNT	
SMTP server IP address:	<input type="text" value="123.45.67.89"/>
SMTP server port:	<input type="text" value="25"/> (default: 25)
Account name:	<input type="text" value="myusername"/>
Password:	<input type="password" value="••••••••"/>

8.3 Configure Destination and Subject

The next step is to enter the email addresses of the sender and recipient(s), as well as the email subject. Enter the names of the sender and recipient(s) in the double-quoted field ("Name"), and the email in between the comparison signs (<email@server.com>).

For the subject field, you can enter a fixed subject text, or you can point to a string variable using the '\$' symbol. In the latter case, the subject will be copied from the value of the specified variable.

E-MAIL FORMAT		
From:	<input type="text" value="S1000 002-0027"/>	<input type="text" value="myuser@emailserver.com"/>
To:	<input type="text" value="System Administrator"/>	<input type="text" value="admin@emailserver.com"/>
Cc:	<input type="text" value="Shift Manager"/>	<input type="text" value="shift.manager@emailserver.com"/>
Subject:	<input type="text" value="\$email_subject"/>	

8.4 Configure Timed Send Settings

You can configure the E-mail reports app to send an email at a specified time-of-day, or at specified time intervals. You may use both specifications, or neither (send emails on value changes, described later).

TIMED E-MAIL		
E-mail every (interval):	<input type="text" value=""/>	<input type="text" value=""/> h <input type="text" value=""/> m
E-mail at this time-of-day:	<input type="text" value="18"/>	<input type="text" value=""/> h <input type="text" value="00"/> m

8.5 Configure the E-mail contents

Use the alias of variables or I/O points to add values to the email body. You can edit each individual point to enable or disable it from appearing in the email body. For boolean, integer and real values, you can specify to send an email on a value change. Tip: You can use this method to control when an email is sent from within ST logic programs, by utilizing a boolean variable to trigger sending an email report.

POINT_ALIAS	
<i>Point definition</i>	
Alias:	<input type="text" value="pump1run"/>
Data type:	<input type="text" value="Boolean"/>
Enable:	<input checked="" type="radio"/> Yes <input type="radio"/> No
<i>Value change</i>	
E-mail on change:	<input checked="" type="radio"/> Yes <input type="radio"/> No

9 Log data

The **Value Logger** app allows you to keep a log of variable and I/O point values. Values are stored in the embedded flash memory.

Notice

The flash memory has a maximum guaranteed life of 100.000 write cycles. You must ensure through appropriate configuration that the log isn't written too often. Writing to the flash in excess of 100.000 cycles may lead to unpredictable results.

9.1 Create a Value Logger app

To create a Value Logger app, follow instructions on the **Configure** → **App Library** → **Add New Application** page.

Enter new application data

Application friendly name:
 Application type:

9.2 Configure Timed Save Settings

You can configure the Value Logger app to save values at a specified time-of-day, or at specified time intervals. You may use both specifications, or neither (save data on value changes, described later).

TIMED SAVE			
Save every (interval):	<input type="text" value="1"/>	h	<input type="text" value="30"/> m
Save at (time-of-day):	<input type="text" value="17"/>	h	<input type="text" value="00"/> m

9.3 Add data points to save

Enter the aliases of all variables and I/O points that you wish to save to flash. Whenever a save operation is triggered, whether due to a time trigger or a value change trigger, all values in the list are saved simultaneously.

You may edit each value source individually in order to specify whether it triggers a save operation on value change. This change may be a true/false change for boolean points, or a significant change in value for integers and reals (this means, if the value changes by more than a specified amount since the last save operation). In the example below, a save operation is triggered when the variable changes by more than 10.0 since the last save operation.

POINT_ALIAS	
<i>Point definition</i>	
Alias:	<input type="text" value="pos1current"/>
Data type:	<input type="text" value="Real"/>
Enable:	<input checked="" type="radio"/> Yes <input type="radio"/> No
<i>Value change</i>	
Save on change:	<input checked="" type="radio"/> Yes <input type="radio"/> No
Significant change value:	<input type="text" value="10.0"/>

9.4 Download log to a PC

The log is available for download from the `/logger/` path. For example, if the IP address of the device is 192.168.2.27, the log is available from `http://192.168.2.27/logger/`.

The log is in **TSV** format, or tab-separated values format. The file can be imported into MS Excel or similar software, utilizing the Tab character to separate columns.

10 Technical Specifications

10.1 Electrical characteristics

10.1.1 Power Supply

Parameter	Conditions	Min	Typ	Max	Units
Input					
Input Voltage		9	24	36	V
Input current	Full load, 24V supply			0.34	A
Power consumption	Typ: all onboard systems on, no expansion boards Max: theoretical fully loaded with expansion boards		1.5	8	W
Protection					
Output over-current			continuous		
Output short circuit			continuous		

10.1.2 Digital inputs

Parameter	Conditions	Min	Typ	Max	Units
Input					
Input impedance			3		K Ω
Input high		6		30	V
		1		10	mA
Input low		0		3	V
		0		0.2	mA
Isolation					
Isolation	1 minute	2500			V _{rms}

10.1.3 Digital outputs

Parameter	Conditions	Min	Typ	Max	Units
Operating supply					
Op supply voltage		10.5		45	V
Under+voltage shutdown		7		10.5	V
Supply current	All channels ON, Vcc '24V			12	mA
Outputs					
Output current				0.7	A
ON Resistance				150	m Ω
Protections					
Short circuit current	24V, R _{LOAD} = 10m Ω	0.7		1.7	A
Turn-off output clamp voltage	24V; I _{OUT} = 0.5A; L = 6mH	-33	-28	-23	V
Shut-down temperature	Internal case temperature	125			°C
Isolation					
Isolation	1 minute	2500			V _{rms}

10.1.4 Analogue inputs

Parameter	Conditions	Min	Typ	Max	Units
Inputs					
Impedance	0/4-20mA configuration		240		Ω
	0/1-5V configuration	1			M Ω
Voltage signal		0		5	V
Current signal	0/4-20mA configuration	0		20.8	mA
Accuracy					
Resolution			12		bits
Reference initial error				0.12	%
Reference temp coefficient			10		ppm/ $^{\circ}$ C
Shunt initial error				0.1	%
Shunt temp coefficient					ppm/ $^{\circ}$ C
Integral non+linearity				2	Msb
Isolation					
Isolation		1500			V _{rms}

10.1.5 Serial port

Parameter	Conditions	Min	Typ	Max	Units
Driver					
V _{OUT} High		5	5.4		V
V _{OUT} Low		-5	-5.4		V
Receiver					
V _{IN} High		2.7		25	V
V _{IN} Low		-2.7		-25	V
Protections					
Short circuit current			35	60	mA
Isolation					
Isolation		1500			V _{rms}

10.1.6 CAN port

Parameter	Conditions	Min	Typ	Max	Units
Driver					
V _{OUT} dominant	CANH	2.9	3.4	4.5	V
	CANL	0.8		1.75	V
V _{OUT} recessive		2	2.5	3	V
V _{OUT} standby		-0.1		0.1	V
Protections, maximum ratings					
Output current		-20		20	mA
Bus voltage	Recommended	-12		12	V
	Maximum	-27		40	V
Transient pulse		-200		200	V
Isolation					
Isolation		1500			V _{rms}

10.2 Environmental characteristics

Parameter	Conditions	Min	Typ	Max	Units
Temperature		-40		85	$^{\circ}$ C
Relative Humidity		10		90	%

10.3 Mechanical characteristics

10.3.1 Dimensions

120mm (H) x 101mm (W) x 22.5mm (D)

10.3.2 Mounting


Mounting on standard 35mm DIN Rail (IEC 60715).

10.3.3 Plug Connectors

Parameter	Conditions	Min	Typ	Max	Units
Pitch			3.81		mm
Wire gauge		28		14	AWG
Torque			1.7		Lb-in
Wire strip length			6		Mm
Screw			M2		

10.4 Pin Descriptions

10.4.1 Overview




10.4.2 Power supply

Pin	Description
+	9-36V
-	0V/Neutral


10.4.3 Digital inputs

Pin	Description
1-8	Input 1-8
C	Common

Sinking input configuration (PNP sensor)



Sourcing input configuration (NPN sensor)



10.4.4 Digital outputs

Pin	Description
1-8	Sourcing Output 1-8
+	10.5-45V
-	0V/Neutral

10.4.5 Analogue inputs

Pin	Description
1-4	Input 1-4
-	0V/Neutral


10.4.6 Serial port

Pin	Description
-	0V/Neutral
Rx	Received data
Tx	Transmitted data

10.4.7 CAN port

Pin	Description
-	CANL pin
+	CANH pin

10.5 Status Indicators



10.5.1 Runtime indicators

Four LEDs on the front-rightmost side indicate the current runtime status of the S1000. The following table summarizes the status conditions:

Status	L1 (Blue)	L2 (Green)	L3 (Yellow)	L4 (Red)
Power ON	On	-	-	-
Running	On	On	Off	Off
Stopped - Configuration	On	Off	On	Off

Stopped - Safe mode	On	Off	On	On
Stopped - Error	On	Off	Off	On

10.5.2 I/O indicators

Two rows of LEDs indicate the current state of digital inputs and digital outputs.


The leftmost row indicates the On/Off state of the digital outputs 1-8, from left to right, in white colour.

The center row indicates the On/Off state of the digital inputs 8-1, from left to right, in blue colour.

11 Expansion modules

11.1 DIO8, DIO16 – Digital I/O

The DIO8 and DIO16 expansion modules offer 8 and 16 expansion digital inputs and outputs, respectively. The electrical characteristics and wiring diagrams are equivalent to the digital I/O available in the base S1000. The following diagram illustrates the DIO8 and DIO16 configuration and layout. DIO8 offers only the elements in marked (A), while DIO16 include elements marked (A) and (B).



11.1.1 Electrical characteristics: Digital inputs

Parameter	Conditions	Min	Typ	Max	Units
Input					
Input impedance			3		K Ω
Input high		6		30	V
Input low		1		10	mA
Input low		0		3	V
Input low		0		0.2	mA
Isolation					
Isolation	1 minute	2500			V _{rms}

11.1.2 Electrical characteristics: Digital outputs

Parameter	Conditions	Min	Typ	Max	Units
Operating supply					
Op supply voltage		10.5		45	V
Under+voltage shutdown		7		10.5	V
Supply current	All channels ON, V _{cc} '24V			12	mA
Outputs					
Output current				0.7	A
ON Resistance				150	m Ω

Protections

Short circuit current	24V, $R_{LOAD} = 10m\Omega$	0.7	1.7	A
Turn-off output clamp voltage	24V; $I_{OUT} = 0.5A$; $L = 6mH$	-33	-28	-23
Shut-down temperature	Internal case temperature	125		$^{\circ}C$
Isolation				
Isolation	1 minute	2500		V_{rms}


11.2 E10 – Energy Analyzer

The E10 is an expansion module that allows analyzing 3-phase electrical power consumption. The features for the E10 energy analyzer are summarized below:

- 3-phase RMS Voltage (up to 600V)
- 3-phase RMS Current (using /5A transformers, other configurations available on special request)
- 3-phase Active, Reactive and Apparent Power (Watts)
- 3-phase Active, Reactive and Apparent Energy (Watt-hour)
- Line frequency measurement
- Calibration down to 0.1% error

11.2.1 Connection Diagram

The following figure illustrates the connection points for the E10 energy analyzer.



Pin	Description
Ia +, Ib +, Ic +	Current transformer positive terminal
Ia -, Ib -, Ic -	Current transformer negative terminal
Vn	Neutral
Va, Vb, Vc	Phase A, B and C voltage connection

**Warning**

Never disconnect a current transformer from the +/- terminals unless the primary side has been disengaged. Connecting a current transformer with the secondary side left open will cause arcing, and can cause injury and permanent damage to the equipment..

11.2.2 Electrical Characteristics

Parameter	Conditions	Min	Typ	Max	Units
Current terminals					
Nominal impedance			160		$m\Omega$
Current				5	A
Voltage terminals					
Phase voltage	AC, Phase to Neutral			600	V

11.3 W1-Z – Wireless Module, Zigbee PRO

The W1-Z module adds wireless networking to the S1000. It uses the ZigBee PRO protocol for communications. For more information on features and configuration, see the Wireless I/O section of this manual.

Parameter	Conditions	Min	Typ	Max	Units
Radio					
Frequency Band		2.4		2.48	MHz
Number of Channels			16		
Channel spacing			5		MHz
Data rate			250		Kbps
TX power		-17		3	dBm
RX sensitivity	PER = 1%			-101	dBm
Antenna terminal					
Antenna impedance	RP-SMA connector		50		Ω
Operating conditions					
Temp. Range	-40 to 85 operational with minor degradation of clock stability	-20		70	$^{\circ}\text{C}$
Rel. Humidity				80	%

11.3.1 FCC Certification

This product has been certified for use in the United States of America.

Contains FCC ID: U6TZIGBIT-B0

The enclosed device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (i.) this device may not cause harmful interference and (ii.) this device must accept any interference received, including interference that may cause undesired operation.

11.3.2 Industry Canada Certification

This product has been certified for use in Canada.

Certification number	IC: 7036A-ZIGBITB0
Manufacturer's Name	ZIGBIT
Model Name	ATZB-24-B0

11.3.3 CE Marking

This product has been certified for use in the European Union.

12 Compliance and Certifications

12.1 Electro-magnetic compatibility (EMC)

The S1000 complies with the following standards and codes:

- FCC Part 15.107 Class A Conducted emissions
- FCC Part 15.109 Class A Radiated emissions
- ICES-003 Issue 4 Class A Radiated and conducted emissions
- CISPR 22 : 2003 / EN 55022 : 1998 Class A Radiated and conducted emissions
- EN 61000-6-1 : 2001
 - EN 61000-4-2 ESD Direct
 - EN 61000-4-2 ESD indirect
 - EN 61000-4-3 Radiated Immunity
 - EN 61000-4-4 EFT
 - EN 61000-4-6 CS induced RF field
 - EN 61000-4-8 Power Freq. Magnetic field

12.2 Safety standards

This device is not yet certified for safety standards such as UL, CSA or TÜV. Please contact Inico Technologies for further information on safety certification.

12.3 Hazardous locations

This device is not yet certified for use in hazardous locations. Please contact Inico Technologies for further information on HazLoc certification.



Warning

Explosion hazard, do not install in potentially explosive atmospheres.

12.4 IEC 61131-3 Compliance

This system complies with the requirements of IEC 61131-3 for the following language features:

12.4.1 Common elements

Table number	Feature number	Feature description	Notes
1	1	Required character set	
1	2	Lower case characters	
1	4a	Dollar sign (\$)	
2	1	Identifiers using upper case and numbers	
2	2	Identifiers using upper and lower case, numbers, embedded underlines	
2	3	Identifiers using upper and lower case, numbers, leading or embedded underlines	
3	1	Comments	
4	1	Integer literals	
4	2	Real literals	

4	3	Real literals with exponents	
4	8	Boolean FALSE and TRUE	
5	1	String literals	
6	2	Dollar sign	
6	3	Single quote	
6	4	Line feed	
6	5	Newline	
6	6	Form feed	
6	7	Carriage return	
6	8	Tab	
10	1	BOOL (Boolean) data type	
10	3	INT (integer) data type	Implemented as 32-bit double int
10	4	DINT (double integer) data type	
10	10	REAL (floating point) data type	
10	16	STRING (variable-length character string) data type	
13		Default initial values: BOOL := FALSE; INT, DINT := 0; REAL := 0.0; STRING := "";	
16		VAR_GLOBAL global variable declarations	
17	5	Automatic memory allocation of symbolic variables	Multiple comma-separated identifiers not allowed
18	5	Initialization of symbolic variables	
22	1	Type conversion functions: BOOL_TO_STR, INT_TO_STR, INT_TO_HEX, REAL_TO_STR, STR_TO_BOOL, STR_TO_INT, STR_TO_REAL	See 5.6.4
23	1	ASB function	
23	2	SQRT function	
24	12	ADD arithmetic function	+ symbol
24	13	MUL arithmetic function	* symbol
24	14	SUB arithmetic function	- symbol
24	15	DIV arithmetic function	/ symbol
24	16	MOD arithmetic function	
24	17	EXPT arithmetic function	** symbol
26	5	AND bitwise Boolean function	
26	6	OR bitwise Boolean function	
26	7	XOR bitwise Boolean function	
26	8	NOT bitwise Boolean function	
28	5	GT comparison function	> symbol
28	6	GE comparison function	>= symbol
28	7	EQ comparison function	= symbol
28	8	LE comparison function	<= symbol
28	9	LT comparison function	< symbol
28	10	NE comparison function	<> symbol
29	1	LEN string function	Use STR_LEN keyword
29	2	LEFT string function	Use STR_LEFT keyword
29	3	RIGHT string function	Use STR_RIGHT keyword
29	4	MID string function	Use STR_MID keyword
29	5	CONCAT string function	Use STR_CONCAT keyword
29	9	FIND string function	Use STR_FIND keyword

12.4.2 ST language elements

Table number	Feature number	Feature description	Notes
55	1	Parenthization	
55	2	Function evaluation	
55	3	Exponentiation	
55	4	Negation	
55	5	Complement	
55	6	Multiply	

55	7	Divide
55	8	Modulo
55	9	Add
55	10	Subtract
55	11	Comparison
55	12	Equality
55	13	Inequality
55	14	Boolean AND (& symbol)
55	15	Boolean AND (AND symbol)
55	16	XOR
55	17	OR
56	1	Assignment statement
56	3	RETURN statement
56	4	IF statement
56	6	FOR statement
56	7	WHILE statement
56	8	REPEAT statement
56	10	Empty statement

12.4.3 Implementation-dependent parameters

The following table lists the parameters adopted by the S1000 implementation, as required by the IEC 61131-3 standard Annex D.

Clause	Parameter	Value
2.1.1	\$ or “currency” sign	\$
2.1.2	Maximum length of identifiers	39
2.1.5	Maximum comment length	Unlimited
2.4.2	Initial value of inputs	As per actual input scanner
2.4.3	Maximum number of variables per declaration	One
2.5.3	Program size limitation	Subject to available system memory
3.3.1	Maximum length of expressions	Unlimited
3.3.2	Maximum length of expressions	Unlimited
3.3.2.3	Maximum number of CASE selections	Not implemented
3.3.2.4	Value of control variable upon termination of FOR loop	Final value + Step

13 Revision History

Revision	Date	Comments
0.1	16-March-2009	First version.
1.0	29-May-2009	First release. Included indicator section.
1.1	09-Fe-2009	Added expansion IO modules: DIO16, E10
1.2	05-Ma-2010	Major edit, all sections modified.