




407 – 15216 North Bluff Road
White Rock, BC
Canada V4B 0A7
Phone: 604.424.9092

Toll Free: 1.877.352.9158
Fax: 1.877.453.0658
Email: info@microedgeinstruments.com
Web: www.microedgeinstruments.com

SiteView

Site-Log Data Logger Software



User's Manual

Microedge Instruments Inc.
407 – 15216 North Bluff Road
White Rock, BC, Canada, V4B 0A7
Toll Free: 1.877.352.9158
www.microedgeinstruments.com

ABOUT THIS MANUAL

This manual contains operational information for SiteView software.

Copyright © 2010, Microedge Instruments Inc.

Limits of Liability and Disclaimer of Warranty:

The manual contained in this document is furnished for informational use only and is subject to change without notice.

Microedge Instruments Inc. shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Copyright and Trademarks

This manual contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without prior written consent of Microedge Instruments Inc.

Microedge Instruments Inc., Site-Log, SiteView are the trademarks of Microedge Instruments Inc.

All other trademarks and registered trademarks are the property of their respective owners.

End User License Agreement

End User License Agreement is available for download on our website.

PLEASE DOWNLOAD AND READ THE SOFTWARE LICENSE AGREEMENT CAREFULLY BEFORE DOWNLOADING OR USING THE SOFTWARE.

Microedge Instruments Inc.

407 – 15216 North Bluff Road

White Rock, BC, Canada, V4B 0A7

Toll Free: 1.877.352.9158

Web-Site: www.microedgeinstruments.com

Email: info@microedgeinstruments.com

Revision 2.4 For SiteView 2.0, Jan, 2013

Table of Contents

ABOUT THIS MANUAL	1
LIMITS OF LIABILITY AND DISCLAIMER OF WARRANTY:	1
COPYRIGHT AND TRADEMARKS	1
END USER LICENSE AGREEMENT.....	1
CHAPTER 1 - INTRODUCTION	8
FEATURES	8
SYSTEM REQUIREMENTS.....	8
CHAPTER 2 - INSTALL SITEVIEW	9
INSTALL SITEVIEW	9
CONNECT DATA LOGGER.....	14
ACTIVATE SITEVIEW	17
CHAPTER 3 – PROTECT YOUR LOGGER	19
TYPES OF USER ACCOUNT AND PRIVILEGE	19
CREATE ACCOUNTS	19
CHAPTER 4 - COMMUNICATE WITH LOGGER	24
USB PORT CONNECTION	24
<i>Start Communication</i>	24
<i>Adjust USB Settings</i>	25
USB DEVICE SERVER CONNECTION	26
<i>Prepare USB Device Server:</i>	27
<i>Start Communication</i>	31
<i>Adjust Ethernet Settings</i>	33
SERIAL PORT CONNECTION.....	33
<i>Start Communication</i>	33
<i>Adjust Serial Port Settings</i>	35
SERIAL DEVICE SERVER CONNECTION (ETHERNET)	36
<i>Start Communication</i>	36
<i>Adjust Ethernet Settings</i>	39
MODEM CONNECTION.....	39
<i>Initialize Remote Modem</i>	40
<i>Initialize Local Modem</i>	42
<i>Start Communication</i>	43
CHAPTER 5 - VIEW STATUS OF LOGGER	44
WHAT IS THE STATUS OF LOGGER	44
GENERAL STATUS	45
ALARM AND EXCITATION STATUS	45
KNOW IF LOGGER OPERATE PROPERLY?	46
CHAPTER 6 - DOWNLOAD LOGGER DATA	47
CHOOSE FILENAME AND TIME SPAN	47

HOW DEFAULT FILENAME CREATED	49
PLOT DISPLAYING OPTIONS	50
CHAPTER 7 - CONFIGURE LOGGER.....	52
CLOCK OF DATA LOGGER	53
DECIDE WHEN TO START AND WHEN TO STOP LOGGING	53
DECIDE HOW OFTEN THE LOGGER SAMPLES SOURCES	54
DECIDE WHICH CHANNELS TO LOG ON	54
DECIDE HOW TO CONVERT TO PHYSICAL MEASUREMENT	54
<i>Role of Equation</i>	55
<i>Decide What Equation to Use</i>	55
MANAGE ALARM AND EXCITATION CONTROL.....	55
<i>Configure Channel Alarms</i>	55
<i>Decide what to do when in Alarm State</i>	56
<i>Configure Excitation Control</i>	56
ADD CUSTOM CHANNELS	57
QUICK WAY TO CALIBRATE LOGGER	57
<i>Understand Cali. Low & Cali. High</i>	57
<i>Calibrate Channel</i>	58
SAVE SETTINGS AND START NEW SESSION	58
CHAPTER 8 - REAL-TIME CHART VIEWING/RECORDING	59
DISPLAY REAL-TIME DIALOG	59
SAVE REAL-TIME DATA	60
CHANGE VIEWS PROPERTIES	61
CHAPTER 9 - CALIBRATE LOGGER	62
<i>On-Line Calibrate</i>	62
<i>Off-Line Calibrate</i>	67
CHAPTER 10 - RECEIVE ALARM NOTIFICATIONS.....	69
HOW SITEVIEW RECEIVE ALARMS	69
CONFIGURE PARAMETERS FOR RECEIVING ALARMS.....	69
ACTIONS WHEN ALARM RECEIVED	70
<i>Execute a program or play music:</i>	70
<i>Send out email:</i>	71
ALARM CENTRE.....	73
CHAPTER 11 - WORK WITH EQUATIONS	75
WHAT IS EQUATION	75
BUILT-IN EQUATIONS	75
<i>Equations for Temperature Channels</i>	75
<i>Equations for Relative Humidity Channel</i>	75
<i>Equations for Voltage Channels</i>	76
<i>Equations for Current Channels</i>	76
TEMPERATURE EQUATION FOR THERMISTOR	76
CUSTOM EQUATION	78

CREATE EQUATION	79
IMPORT/EXPORT EQUATIONS	81
APPLY EQUATION TO LOGGER	84
CREATE CUSTOM-LINE EQUATION	85
ADD CUSTOM-LINE EQUATION TO PLOT.....	86
CALL/INVOKE OTHER CUSTOM EQUATIONS	87
CHAPTER 12 - WORK WITH UNITS	89
WHAT IS UNIT.....	89
OPEN UNIT CATEGORY DIALOG.....	90
CREATE UNIT.....	91
IMPORT/EXPORT UNITS.....	92
USE UNIT	95
<i>Apply Unit Category in Equation</i>	<i>95</i>
<i>Change Unit.....</i>	<i>95</i>
<i>Change Unit in Plot.....</i>	<i>95</i>
CHAPTER 13 - WORK WITH SETTINGS & PLOT PREFERENCES.....	96
PLOT PREFERENCES	96
GLOBAL SETTINGS.....	97
CHAPTER 14 – UPGRADE SITEVIEW & FIRMWARE.....	99
UPGRADE SITEVIEW	99
UPGRADE FIRMWARE.....	99
CHAPTER 15 - WORK WITH PLOT	101
BASIC VIEWS	101
<i>Plot View.....</i>	<i>102</i>
<i>Tabular View.....</i>	<i>102</i>
<i>Statistics</i>	<i>103</i>
OPEN SITEVIEW FILES	103
<i>Open SiteView files</i>	<i>103</i>
<i>Merge SiteView files With Current Plot.....</i>	<i>104</i>
SAVE AND EXPORT PLOT	105
<i>Save the Change.....</i>	<i>105</i>
<i>Save a copy of SiteView File.....</i>	<i>105</i>
<i>Save As Image File.....</i>	<i>106</i>
<i>Save as Text File</i>	<i>108</i>
PRINT PLOT.....	109
CHANGE PLOT SETTINGS	111
<i>Change Axis Settings.....</i>	<i>111</i>
<i>Change Line Settings</i>	<i>111</i>
<i>Change Plot Title Settings</i>	<i>112</i>
<i>Change Legend Settings.....</i>	<i>112</i>
<i>Change Other Settings</i>	<i>113</i>
ZOOM PLOT.....	113
<i>Zoom-In.....</i>	<i>113</i>

Zoom-Out	115
Un-zoom-All	115
Time-Zoom	116
ADD CUSTOM CHANNELS	116
ADD CUSTOM LINES	117
ADD ANNOTATION AND COMMENT.....	118
Add an Annotation	118
Add a Comment.....	119
OTHER FEATURES OF PLOT	120
Use Context Menu.....	120
Copy Plot to Clipboard.....	122
Show Point Value	122
View Mouse-Point Values.....	123
Fast Draw Mode	123
Change View Layout.....	124
CHAPTER 16 - USER INTERFACE REFERENCES.....	125
MENU BAR.....	125
File	125
View.....	126
Tools.....	126
Help.....	127
TOOL BAR.....	128
COMMUNICATION BAR	129
USB	130
USB Device Server.....	131
Serial Port.....	134
Serial Device Server (Ethernet).....	136
LOGGER STATUS VIEW	138
Tool Bar Buttons.....	139
General	140
Alarm & Excitation.....	141
DOWNLOAD DIALOG.....	143
Filename & Browse	143
Start Time & End Time	144
LOGGER CONFIGURATION DIALOG	144
General Settings.....	144
Channel Settings	146
Alarm and Excitation Settings	147
REAL-TIME DIALOG.....	149
Tool Bar Buttons:.....	150
Other Settings.....	151
EQUATION DIALOG	153
Tool bar Buttons	154
Other Fields	155
New Equation Dialog.....	155
Import Equation Dialog.....	157

<i>Export Equations Dialog</i>	158
<i>Polynomial Equation Dialog</i>	160
CUSTOM LINE EQUATION DIALOG	162
UNIT CATEGORY DIALOG	163
<i>Tool bar buttons</i>	163
<i>Other Fields</i>	164
<i>Add New Unit Category Dialog</i>	165
<i>Export Units Dialog</i>	166
<i>Import Units Dialog</i>	167
PLOT PREFERENCE DIALOG	167
<i>Buttons</i>	168
<i>Other fields</i>	169
<i>New Plot Preference</i>	169
DIAGNOSTIC LOG PANEL	170
GLOBAL SETTING DIALOG	172
<i>General</i>	172
<i>Download</i>	173
<i>Diagnostic Log</i>	174
<i>Real-Time Log</i>	175
<i>Alarm</i>	176
<i>Modem</i>	178
<i>USB Device Server</i>	179
PLOT WINDOW	180
<i>Tool Bar Buttons</i>	180
<i>Menu Items</i>	182
<i>Select Time Span Dialog</i>	186
<i>Dataset View</i>	186
<i>Statistics</i>	187
<i>Axis</i>	187
<i>Line</i>	189
<i>Plot Title</i>	191
<i>Legend</i>	192
<i>Others</i>	193
ALARM CENTER	194
<i>Connections</i>	194
<i>Alarm Events</i>	194
<i>Log</i>	195
<i>Buttons</i>	195

CHAPTER 17 - EQUATION REFERENCES 196

C# LANGUAGE SOURCE CODE REFERENCES	196
<i>Basic data types</i>	196
<i>Basic Operators</i>	196
<i>Basic Math Methods</i>	200
ACCESSIBLE OBJECTS	201
EQUATION EXAMPLES	202
<i>Dew Point Temperature</i>	202

<i>Carbon Dioxide Transmitter (0 – 5000 PPM)</i>	202
<i>External Thermistor</i>	203
<i>Previous Hour Average</i>	203
APPENDIX	205
MODEM AT COMMAND SET	205

CHAPTER 1 - INTRODUCTION

Congratulations on using SiteView - the complete software package working closely with Site-Log and VersaLog series data loggers for device configuration, data downloading, plotting and analyzing.

Features

- ❑ Supports Serial Port, USB, Ethernet and Modem connections for easy local and remote access of data loggers.
- ❑ Allows downloading multiple data loggers simultaneously.
- ❑ Provides powerful custom equation functionality solving scientific and laboratory algorithm difficulties.
- ❑ Displays both tabular data and plot view. Zooming function provides detailed view of specific data section.
- ❑ Annotation/Comment highlights the important data points and sections.
- ❑ Custom channel and custom line allow adding more channels to the logger and plot lines to the plot view.
- ❑ Allows real-time chart and list views of the data logger, replacing paper chart recorder.
- ❑ Receives alarm notifications from data logger and takes actions like sending email, playing music etc.
- ❑ Access remote data loggers via LAN/Internet as if they were connected directly to the local computer.
- ❑ User Account Control to protect data loggers and important settings.

System Requirements

Computer:

CPU: 1.0 GHZ or above
Memory: 256M or above
Port: 1 USB port or 1 COM port
Hard Drive: 1GB or above

Operating System:

Window XP with SP2 or later, Windows Vista, Windows 7, 8

CHAPTER 2 - INSTALL SITEVIEW

NOTE: Before the installation, please make sure the product key is available.

Install SiteView

1. Configure for Windows 8 User:

Please skip this section if your operating system is NOT Windows 8!

For Windows 8 user, in order to install the USB Driver properly, the following steps must be followed before the installation of SiteView software:

- A. Mouse over the lower-right corner of the screen, then select Settings.
- B. Select Change PC Settings.
- C. Navigate to General and under Advanced Startup. Click Restart Now.
- D. Now Windows 8 will restart in the advanced menu options, click on Troubleshoot.
- E. Click on Advanced options.
- F. Click the Startup Settings option from the menu.
- G. The Startup Settings will allow you to change various Windows configuration options. Click Restart.
- H. Now Windows 8 will reboot. But instead of going to the Desktop it will start in the Startup Settings page. Choose option: 7) Disable driver signature enforcement by pressing F7 or the number 7. Then the windows will boot to the mode allowing the USB Driver to be installed.


Windows 8 is now ready for SiteView installation.

For on-screen step by step configuration please visit:


<http://www.microedgeinstruments.com/Win8Configurations.pdf>

2. Install SiteView and Data Logger USB Driver


Insert the included CD to the CD Drive. The installation should start to run automatically. Follow the on-screen instructions to complete the installation.



Click “Next >” button to proceed to the next page.




Please read the License Agreement carefully. If you accept the terms click “I Agree”, then click “Next >” button. Otherwise click “Cancel” to cancel the installation.




In this dialog select a destination folder where SiteView will be installed. We recommend you keep the default folder.

Once you are ready, click “Next >” button to proceed to the next page.




This confirmation page gives you the chance to modify previously selected options. Click “Next >” button to start the installation.




As SiteView is being installed the above dialog shows the installation progress by percentage.

Depending on the operating system, you may see the dialog similar to the one below displayed. Please select “Continue Anyway” or “Install this driver software anyway” to allow the software and the driver to be installed.



Once the installation is complete, the below dialog appears:



Click “Close” button to finish the installation and close the dialog.


Connect Data Logger

Connect the logger to the computer's USB port. Windows Vista and Windows 7, 8 will automatically recognize the data logger.


For Windows XP user, the following dialog window will appear:



Select "No, not this time" from options available and then Click "Next >" to proceed with the installation.



Select "Install the software automatically (Recommended)" as shown in the above figure and then click "Next >".




Select the item with Manufacturer of Microedge Instruments Inc and click "Next>" to proceed.


In the following message dialog, click "Continue Anyway" to continue with the installation:



The screen below will be displayed as Windows copies required driver files:



Windows should then display a message indicating the installation was successful:



Activate SiteView

After the installation SiteView needs to be activated by the Product Key you obtained when you bought SiteView.

If the above installation of SiteView was successful, SiteView can be launched by either one of the following:


Double click on SiteView icon on the desktop:




Or:

Using Windows Start Menu, select Start : All Programs: Microedge Instruments Inc.: SiteView.

Double click **SiteView** icon on the desktop, the following dialog appears:



Enter the Product Key, then click **Activate** button. If the Product Key is accepted the following confirmation dialog will appear:



Click **OK** button to finish the activation. From now you can start using SiteView.

CHAPTER 3 – PROTECT YOUR LOGGER

When SiteView is first installed there are no user account and password protections. We strongly recommend you to create user accounts as early as possible in order to protect your logger and system.


Types of User Account and Privilege

- | | |
|-----------------------|---|
| Administrator: | Change all fields of the system and configure data logger. Add, modify and delete other users. You can only have one Administrator account in the system. |
| Master: | Has the same privilege as Administrator except Master can not create, modify and delete other users. |
| Standard User: | Can view logger status, download data and view plots. Some system settings are not allowed to view. Can not change most of settings. |


Create Accounts

To enable User Account and create one or more users with SiteView system:

1. Display Global Settings dialog:



2. Click "User Account" tab then "Click Create Account" button to create an Administrator account:



3. Fill out the registration dialog and click "OK" button. Make note of your user ID, password and put them in a safe place.

User Registration


There is no user in the system. You need to create an administrator account first. Once you logged in, you can add other users.

Please choose a user ID carefully. The user ID can not be changed once it is created.

Login User ID:	Password: (>=5 characters/numbers)	Account Type:
		Administrator
First Name:	Confirm Password:	Admin:
		> View all fields.
Last Name:		> Change all settings.
		> Manage other users.
Compnay:		Master:
		> View all fields.
Email:		> Change most of settings.
		Standard User:
Confirm Email:		> View all fields.

Help OK Cancel

4. You may create other user accounts by clicking "Add New User" button after you have created the administrator account.



Global Settings

General | Download | Diagnostic Log | Real-Time Log | Alarm | Modem | USB Device Server | **User Account**

Administrator

Edit

UserID	First Name	Last Name	Company	Email Address	Account Type
admin	test	test	test	test@yahoo.com	Admin


User

Add New User | Delete Selected User | Edit Selected User

UserID	First Name	Last Name	Company	Email Address	Account Type
user1	user1	user1	test	test@yahoo.com	Master

Help | OK | Cancel

Once you have created users, on the next start of SiteView you are prompted with User Login dialog. Only valid users can log in to the system and start using SiteView:




User Login

Login User ID: Password:


Log Off | Log In | Cancel

You can also display the above dialog to log off the system if you want to prevent other people from using SiteView. To display the above dialog within SiteView, click Log in/off button:



Then click "Log Off" button on the above User Login dialog.

The system will automatically log off if you have not interact with the system for a period of time that you can set from General tab of Global Settings dialog:



Change "Log Off Timer" to a decent value.

CHAPTER 4 - COMMUNICATE WITH LOGGER

All Site-Log series data loggers come with an USB and an AUX ports. The USB port is for connecting directly to the computer. The AUX port is for connecting to a serial communication device like a Modem or a Serial Device Server when the logger needs to be accessed remotely.


NOTE: Please make sure SiteView and USB driver are installed correctly. Refer to Chapter 2 for details on the installation.

USB Port Connection

Start Communication

To communicate with the logger via USB port:


1. Connect accompanied USB cable from the logger to a computer's USB port.



2. Launch SiteView application by double clicking on SiteView icon on the desktop:



SiteView application starts running and the logger icon is showing in the USB tab page of the communication panel:




3. Double click the logger icon. If the communication is successful the logger's status page will appear.

Adjust USB Settings


Each time when you selected a USB icon under USB Port list, the settings for that port will be displayed under the properties section. You may change the settings based on the communication quality. For detailed explanation of each setting please refer to **User Interface References** chapter.

USB Device Server Connection

USB Device Server Connection is for the communications with data logger via USB Device Server over LAN/Internet . A USB Device Server can be a Site USB Device Server hardware or SiteView software with USB Device Service function enabled.



USB Device Server Connection with Site USB Device Server



USB Device Server Connection with Computer as Device Server

Prepare USB Device Server:


If the data logger is connected to a **Site USB Device Server** hardware, please refer to **Site USB Device Server Manual** for detailed instructions on installation, obtaining IP address, port number (default: 5678) and password (default: 12345).


If the data logger is connected to a computer and the computer will act as the USB Device Server:

1. Connect a data logger to the computer which will act as the Device Server.
2. Launch SiteView by double clicking on SiteView icon on the desktop:



3. Enable Device Service by opening Tools -> Global Settings -> USB Device Server menu item:





The factory default password is 12345.


Check **Enable USB Device Service** to enable the service.

Click **OK** button to close the dialog.


For security purpose, Windows system may display the following alert. You can just click Unblock to accept.



4. Obtain the IP address by opening USB Device Service -> Show Service Log:




The IP Address and port are listed in caption area of the following dialog:




Start Communication

To communicate with the USB Device Server:


1. Launch SiteView. Click USB Device Server tab in the Communication panel



2. Click **New** button to create a new Ethernet connection:
In the following pop-up dialog, enter the IP address and the port of the Site USB Device Server. Give a meaningful description of the connection, enter the password and click **OK** button to close the dialog.




3. Double click on the icon to start the communication. If the communication is successful the logger's icon will appear under the connection you just created. Double click on the logger icon the logger status page will appear.



Adjust Ethernet Settings

Each time when you selected an Ethernet icon under IP Address list, the settings for that address will be displayed under the properties section. You may change the settings based on the communication quality.




For detailed explanation of each setting please refer to **User Interface References** chapter.

Serial Port Connection

Start Communication

To communicate with the logger via Serial Port:


4. Connect one side of SL-RS232 Converter to the logger's AUX port, connect another side to one of the computer's COM port. If your computer does not have a COM port you may need to use a USB-Serial Converter.



5. Launch SiteView application by double clicking on SiteView icon on the desktop:



SiteView application starts running. Click **Serial Port** tab in the communication panel,



6. Double click on the correct COM port. If the communication is successful the logger's status page will be displayed.

Adjust Serial Port Settings


Each time when you selected a COM port icon under Serial Port list, the settings for that port will be displayed under the properties section. You may change the settings based on the communication quality. For detailed explanation of each setting please refer to **User Interface References** chapter.

Serial Device Server Connection (Ethernet)

Start Communication

To communicate with the logger via Ethernet Connection:


1. Connect the logger, the SL-RS232 Converter and the Device Server as illustrated below:



2. Locate the IP address of the Device Server:
The Device Server was pre-configured with the correct parameters. You can use Link Local and multicast DNS (also known as Bonjour) to locate the Device Server and its IP address.

Bonjour Browser can be downloaded from our website
at: www.microedgeinstruments.com/resourcedownload.php.

Once you run Bonjour Browser and select **Web Server(HTTP)** on the left hand side you will see a window similar to the following




Write down the IP address besides the SitePlayer Telnet.

3. Launch SiteView application by double clicking on SiteView icon on the desktop:



SiteView application starts running. Click **Ethernet** tab in the communication panel.



4. Click **New** button to create a new Ethernet connection:

In the following pop-up dialog, enter the IP address that you obtained from the preceding step. Give a meaningful description of the connection and click **OK** button to close the dialog.

If you use other brand Device Server you may need to adjust **Port** and **Packet Size** values accordingly in order to make a successful connection.

192.168.0.120

Description:
New remote site

IP Address
192.168.0.120

Port:
5678

Packet Size:
200 Bytes
(1 - 5000)

Timeout:
5000 Milliseconds
(100 - 10000)

Retry:
5 Times
(1 - 10)

Help OK Cancel

Notice a new connection icon was added to the list.


5. Double click on the icon to start the communication. If the communication is successful the logger's status page will appear.

Adjust Ethernet Settings


Each time when you selected an Ethernet icon under IP Address list, the settings for that address will be displayed under the properties section. You may change the settings based on the communication quality. For detailed explanation of each setting please refer to **User Interface References** chapter.

Modem Connection

When you use Modem to communicate with a logger, you need one local Modem to connect to the computer where SiteView is running, and another remote Modem to connect to the logger. The following figure illustrates the correct connection between a computer and a logger.



The Modem settings are under the Serial Port connection:



In order to make the connection, both local and remote Modems must be initialized correctly.


Initialize Remote Modem

If the remote Modem has not been initialized by SiteView, the Modem needs to be initialized. The default initialization string that works with US Robotics is:

AT&F&D0&K0&Q0\N1%C0S0=1S37=9M0&M0-V90=0E0&W

To initialize a remote Modem:

1. Connect the remote Modem to the computer.
2. Run SiteView, go to **Global Settings** -> **Modem** dialog.



3. Change the **Initialization String**.
4. Choose the correct COM port that is connected to the Modem.
5. Click **Initialize MODEM** button.
6. You should get the confirmation dialog if the initialization was successful.

The following table explains each command in **Default Initialization String**:

Command	Description
AT	Get the Modem's attention
&F	Return the configuration to the factory settings.
&D0	Control data terminal ready (DTR). &D0: Ignore DTR signal.
&K0	DTE/Modem Flow Control. &K0: Disable flow control
&Q0	Asynchronous/Synchronous mode select. &Q0: Select asynchronous operation in the Direct mode.
\N0	Operation Mode Control. \N0: Select normal speed buffering mode.

%C0	Compression Control %C0: Disable data compression.
S0= x	Read or write to S registers. S0 = 1: Auto answer after 1 ring. S37 = 9: Attempt to connect at 9600 bps speed.
M0	Control Speaker On/Off M0: Speaker is always off.
&M0	Communication Mode.
E0	Command Echo E0: Inhibit the echoing of commands.
&W	Store user profile.

NOTE: Different Modem may have different AT commands. The default initialization string is for US Robotics 33K Modem. Please refer to Appendix -> Modem AT Commands for details.


Initialize Local Modem

The local Modem gets initialized before SiteView tries to dial the number for the Modem connection.

The default initialization string that works with US Robotics 32K Modem is:

AT&F &D0 &K0 &Q0 \N1 %C0 S37=13 E0 &W

The default initialization string is located under each COM port bar:



You may change the string based on the Modem you are using.

Start Communication

To communicate with the logger via Modem:

1. Connect both Modems correctly.
2. Go to COM Port page and highlight the COM port that is connected to the local Modem.
3. Make sure **Is Modem** check box is checked. Make sure **Phone No.** text-box has the valid phone number the remote Modem is connected. Make sure **Modem Initialization** is correct.
4. Double click the COM port icon to start the communication. If the communication is successful the logger's status page will appear.

CHAPTER 5 - VIEW STATUS OF LOGGER

What is the Status of Logger

The status of a logger is a set of properties that are saved inside the logger. The properties are used by the logger and SiteView software. When SiteView communicates with the logger, it first retrieves all properties of the logger, parses them into meaningful information and populates them on the graphical user interface.

If the communications between SiteView and the logger was established successfully from the above chapter, the status of the logger appears in a tab page illustrated below:

Logger Status Tab Caption: LPV-1 (S/N: 0101010003F2) Plot: New Logger

Logger Status Page: General, Alarm and Excitation

Logger Status Tool Bar: Real-Time, Refresh, Download, Configure, Clear, Calibrate

Logger Status Sub Tab Pages: General, Alarm and Excitation

General Page Content:

- ☒ LED light when sampling
- Description:** New Logger
- Sampling Interval:** 5 Seconds
- Start Time:** 22/05/2011 1:17:30 AM
- End Time:** 22/05/2011 5:52:10 PM
- The logger was last configured at:** 22/05/2011 1:17:25 AM
- Logging Method:** Overwrite oldest data when memory full
- Total Memory:** 2095104 Readings 15 Days 3 Hours 44 Minutes
- User Selected Memory:** 2095104 Readings 15 Days 3 Hours 44 Minutes
- Used Memory:** 95496 Readings 16 Hours 34 Minutes 45 Seconds (4.6%)
- The logger is currently logging data**

Channels:

Channel #	Enable	Description	Equation	Cali. Low	Cali. High
0 [Thermistor]	☒	CH0	Temperature	0	0
1 [5V]	☒	CH1	VoltageDC	0	0
2 [5V]	☒	CH2	VoltageDC	0	0
3 [5V]	☒	CH3	VoltageDC	0	0
4 [5V]	☒	CH4	VoltageDC	0	0
5 [5V]	☒	CH5	VoltageDC	0	0
6 [5V]	☒	CH6	VoltageDC	0	0
7 [5V]	☒	CH7	VoltageDC	0	0

Right Panel:

- Firmware:** 2.2
- Board ID:** RHTB
- Battery Level:** 3.66V (100%)

The tab page caption shows the name and the serial number of the logger to identify this tab page.

The status page shows the general, the channel level, the alarm and excitation properties grouped in sub-tab pages.

The status page is for viewing purpose only. To edit and save the properties, please go to **Logger Configuration** dialog by clicking the **Configure** tool bar button.

Through the tool bar buttons you can finish other tasks described in the following chapters.

Please refer to **User Interface References** chapter for the detailed explanation of each field.

General Status

This page specifies the basic logger status information like start and end time, memory usage, logging mode etc.


Channel properties specify how many channels the logger has and each channel's information such as if the channel is enabled or disabled, the description and the applied equation etc.

Alarm and Excitation Status

This page specifies how the logger acts if there is an alarm: dial-out to a Modem and send out the alarm notifications or send out the alarm notification directly via the port, or ignore the alarm. It also shows how each channel affects the alarm conditions.

Excitation Control status is displayed in this page like Excitation Warm-up Delay and if the excitation control connects to the terminal pole.

Please refer to **Receive Alarm Notifications** chapter for detailed instructions on how to set up the alarm information properly and receive alarm notifications within SiteView.



LPV-1 (S/N: 0101010003F2)

Real-Time Refresh Download Configure Clear Calibrate

General Alarm and Excitation

Alarm Excitation Selection:
Disable any output to A1 and A2/E

Excitation Warm-up Delay:
Keep on

Alarm-On Delay: 1 Minute **Alarm-Off Delay:** 1 Minute

Alarm Sent-out Selection:
Disable alarm send out

Dial-out Number:

Temperature for Compensation: 25°C

Logger in No Alarm state

Channel Alarm Settings:

Channel #	Enabled	Low Alarm	High Alarm	Unit
0	☐	1171.95	-93.90	°C
1	☐	0	5490	mV
2	☐	0	5468	mV
3	☐	0	5474	mV
4	☐	0	5415	mV
5	☐	0	5501	mV
6	☐	0	5474	mV
7	☐	0	5473	mV

Know If Logger Operate Properly?

It is important to know that the logger is operating properly. What status can we use to tell if the logger has stopped logging data and is operating abnormally?

The first status you should look at is the blue bold section just above the Channel information:

The logger is currently logging data

This status tells you if the logger is logging data or has stopped. Other information it reports can be:

- 1. The logger has not started logging data. It will start at XXXX.**

The logger is in start-delay mode and is counting down the timer. Once the timer goes to zero the logger will start logging data.

If you set **Time to Start** field to a time in the future you will see the above status. If you want the logger to record data right after the logger is configured you can set this field to now or a time in the past.

- 2. The logger has stopped logging data and has been dormant for XXXX.**

If the logger is in dormant mode, it stops logging data and waits for SiteView to download the data.

Usually, this is because the **When Memory Full** field was set to **Stop Logging** when the logger was configured, and when the memory is full the logger will stop logging and in dormant mode.

If you want the logger to keep recording data you can set **When Memory Full** field to **Continue Logging**.

- 3. Data has rolled over and in FIFO mode**

If the logger is in First-In-First-Out mode, the logger keeps overwriting the oldest data with the new measured data.

If you are only interested in a specific time frame, you may need to set **When Memory Full** field to **Stop Logging**. In this case, the logger will stop logging when the time passed the **Time to End** parameter.

Another status you should focus is the battery level. If the on-board battery level is too low you will get the red warning sign indicating it's time to replace the battery.

CHAPTER 6 - DOWNLOAD LOGGER DATA


Downloading Logger Data is the process transferring the recorded measurements inside the logger to the computer and saving them in a file that SiteView can recognize – SiteView file (.svf).


If the logger is in normal sampling mode (sampling interval ≥ 5 seconds), the downloading process does not interrupt the logging operation. If the logger is in fast sampling mode (sampling interval is less than 5 seconds) logger will stop logging data from the time SiteView communicates with the logger.

SiteView can choose to download whole available data or only the interesting section for the specific period of time.

Choose Filename and Time Span

If you are already in logger status page, click **Download** button, **Download Logger** dialog window will appear:






Each time when **Download Logger** dialog appears a default filename is created based on the properties in **Global Setting** -> **Download** page and is loaded in the Filename field.

You may specify a different file name by clicking **Browse** to select a file name.

Once you have selected the file name to save and specified the start and end time, click **OK** button to start the downloading process. After the download the plot and the tabular data will appear:



How Default Filename Created

The **Download** page in **Global Settings** dialog specifies the properties regarding download.


Default Download Folder specifies the default folder to save all SiteView files.

Download File Prefix specifies a string added in front of the filename.

Download File Format specifies how to build the filename. The available selections are:

- Prefix + Serial Number + Date + Time
- Serial Number + Date + Time
- Serial Number
- Date + Time
- Prefix + Serial Number
- Prefix + Date + Time
- Prefix + Model + Serial Number + Time


For example, if you selected: **Prefix + Serial Number + Date + Time**, the logger serial number is **0101FF-065282**, and the prefix string is “**LAB01-**”, the system will generate the default file name looks like:



Plot Displaying Options

If you check **Display Plot After Download** in the above **Global Settings** dialog, the plot will be displayed after the download process. Otherwise, SiteView just saves the data and the plot will not show.

If you check **Load Plot in Separate Window** in **General** page of the above **Global Settings** dialog, the plot will be displayed in a separate window after the SiteView file is loaded. Otherwise the plot will be displayed within the current SiteView main frame.



CHAPTER 7 - CONFIGURE LOGGER

WARNING: By clicking OK or Apply buttons, all recorded data in the logger will be lost. If the data is important please ALWAYS download the data before configuring the logger.

Configuration of the logger is the procedure to change the properties of the logger and start a new session of logging.

If you are already in the Logger Status page, clicking on the **Configure** button will bring up the **Logger Configuration** dialog:



Logger Configuration S/N: 0101010003F2

General Alarm and Excitation

Alarm/Excitation Selection:
 Disable any output to A1 and A2/E

Excitation Warm-up Delay:
 keep on

Alarm-On Delay: 1 Minute **Alarm-Off Delay:** 1 Minute

☐ Notify Alarm via Modem **Dial-out Number:**

Temperature for Compensation: 25 °C

Channel Alarm Settings:

Channel #	Enabled	Low Alarm	High Alarm	Unit
0	☐	1171.95	-93.90	°C
1	☐	0	5490	mV
2	☐	0	5468	mV
3	☐	0	5474	mV
4	☐	0	5415	mV
5	☐	0	5501	mV
6	☐	0	5474	mV
7	☐	0	5473	mV

Channels: Custom Channel Actions: + - ↑ ↓

Channel #	Channel Type/Input Range	Enabled	Description	Equation	Cali. Low	Cali. High
0	Thermistor	☒	CH0	Temperature [Temperature]	0	0
1	5V	☒	CH1	VoltageDC [VoltageDC]	0	0
2	5V	☒	CH2	VoltageDC [VoltageDC]	0	0
3	5V	☒	CH3	VoltageDC [VoltageDC]	0	0
4	5V	☒	CH4	VoltageDC [VoltageDC]	0	0
5	5V	☒	CH5	VoltageDC [VoltageDC]	0	0
6	5V	☒	CH6	VoltageDC [VoltageDC]	0	0
7	5V	☒	CH7	VoltageDC [VoltageDC]	0	0

Buttons: Help Real-Time Apply OK Cancel

Clock of Data Logger

Each Site-Log data logger synchronizes its clock with the computer which is used to configure the data logger. If you have multiple computers used to configure data loggers please make sure all computers are synchronized with the same clock source. Or only one computer will be used to start new logging session.

Decide When To Start and When To Stop Logging

The new session can be started immediately after the logger is configured or start in the future by adjusting the **Time to Start** field.

If you want the logger to stop at a specific time:

1. Adjust **Time to End** field to a time later than **Time to Start** field.
2. Set **When Memory Full** to **Stop Logging**.

If you want the logger to stop logging after a specific period of time:

1. Adjust **Total Time Span** to desired period of time.
2. Set **When Memory Full** to **Stop Logging**.

If you want the logger to continue logging for a specific period of time:

1. Adjust **Time to End** field to the time later than **Time to Start** field. You will see **Total Time Span** fields updated with the new set of values. Or you can adjust **Total Time Span** to a desired period of time.
2. Set **When Memory Full** to **Continue Logging**.

If the start time is unknown and you want to activate the new session in the field:

1. Adjust **Time to Start** field to a time far beyond the estimated start time (for example, one year ahead) so the logger will be in start-delay mode.
2. Adjust **Total Time Span** to desired period of time.
3. Set **When Memory Full** to **Stop Logging** or **Continue Logging** based on your application.
4. When you decide to activate the session, press the activation button located on the logger until the LED starts to blink. Release the button.

NOTE: **The activation button is used for starting the session, not for stopping the session. Once the logger has started logging, the activation button is ignored.**

Decide How Often the Logger Samples Sources

When the logger is operating, the logger samples the source channels in a preset time interval (sampling interval). Most of Site-Log loggers can run as fast as sampling one channel every 20 milliseconds, or as slow as sampling all channels every 12 hours.

If the sampling interval is set 5 seconds or bigger, the logger will operate in normal sampling mode. In this mode, if the logger is logging data, the logger will continue operating while it is communicating with the host device.

If the sampling interval is set below 5 seconds, the logger will operate in fast sampling mode. In this mode, the logger needs the external power supply for the logging period and the communications with the logger will force the logger to stop logging.

TIPS: **The proper steps to configure the logger for fast sampling mode is:**

1. Adjust the sampling interval to 4 seconds or less.
2. Adjust **Time to Start** to the time when you want the logger to start logging.
3. Apply the external supply to the logger before the logger starts logging.

If the logger tries to start fast logging and the external power supply is not applied, the logger will stop. Then you have to reconfigure the logger.

Decide Which Channels To Log On

When the logger is operating, the logger measures the input of each **ENABLED** channel. Be sure to enable the channel if you want the channel be recorded.

If one channel's measurement relies on other channels' measurements (A custom equation may use other channels' measurements for the current channel's calculation), be sure to enable those dependent channels.

Some of the Site-Log loggers are featured with software programmable channels. The input range of those channels can be changed via SiteView. When the range is changed to better fit the actual input signal's range, better resolution and accuracy can be obtained.

For instance, changing the **Input Range** of a programmable voltage channel to 0 – 2 V will get better resolution if you know the input source's range will be within 0 – 2 V.

Decide How to Convert To Physical Measurement

When the logger saves the data the logger saves the data in digital format. SiteView converts the digital values to the physical measurements after the data is downloaded to the computer.

Role of Equation

SiteView does the data conversions by using equations. An equation is a software entity handling the conversion from one data format to another. SiteView contains the built-in equations for those predefined channel types and the customer-defined equations that can be applied to all channel types.

A custom-defined equation (custom equation) is a piece of script (C# source code) in the format of function implementing the data conversion.

When a channel is configured, an equation is applied to the channel. After SiteView has retrieved the logger status SiteView locates the equation entity by the equation name saved inside the logger. Once the equation entity is identified the equation entity will handle the data conversion.

Decide What Equation to Use

This depends on the physical measurement and the input source parameters. If you are using 0 – 10 VDC channel to record a voltage source, you can use a built-in equation “VoltageDC”. If you are recording a 0 – 10 VDC transducer as the source input, and the transducer has the measurement range of 0 – 5000 PPM CO₂, you need to write your custom equation like this:

```
public double CO2Equation(double Input)
{
    double output;
    output = 5000 * Input / 10 ;
    return output;
}
```

The above equation implements the relationship between the input voltage value and the output physical PPM value. A voltage is converted proportionally to a PPM value.

Please refer to **Work with Equations** chapter for detailed instructions on how to write a custom equation.

Manage Alarm and Excitation Control

Configure Channel Alarms

When the logger is recording data, it compares the current reading with Low/High Alarm values that is previously saved in the logger for each channel. If all the following conditions are met, the logger will be in Alarm state:

1. The current reading is beyond the Low/High Alarm values.
2. Alarm is enabled for that channel.
3. Alarm-On Delay's counter is counted down to zero.

In the figure illustrated below, you can check “Alarm Enabled” check-box if you want to enable the Alarm of the channel. And you can adjust “Low Alarm” and “High Alarm” values so that when the measurement is below “Low Alarm” or above “High Alarm” it will trigger the alarm.

Channel #	Enabled	Low Alarm	High Alarm	Unit
0	☒	1171.95	-93.90	°C
1	☐	0	5490	mV
2	☐	0	5468	mV
3	☐	0	5474	mV
4	☐	0	5415	mV
5	☐	0	5501	mV
6	☐	0	5474	mV
7	☐	0	5473	mV

Decide what to do when in Alarm State

If the logger is alarm state, the logger can energize Alarm1 and/or A2/E terminals in order to control the external devices like siren auto dialer etc. It can also report the alarm to SiteView via Modem dial-out.

At the left side of the above figure, you can change **Alarm/Excitation Selection** to decide which terminals the logger will work with when there is an alarm. You can also change **Notify Alarm via Modem** to decide if the logger will dial out the connected Modem to the remote Modem which is connected to the PC where SiteView is running.

Please refer to **Receive Alarm Notifications** chapter for detailed instructions on how to make the logger to report the alarm to SiteView.

Configure Excitation Control

Excitation output is used when you need to save the electric power of the device that provides the signal source to the data logger. When there is no local power available and a battery pack is used to power the transducer, excitation control greatly reduces power consumption by turning on the transducer only when it samples the data and turning off the transducer after the sampling.

A2/E on the terminal strips can be configured by for excitation purpose.

In order to enable A2/E, one of the following **Alarm/Excitation Selection** must be selected:

Excitation control to A2/E, both high and low alarm to Alarm1

Excitation control to A2/E, low alarm to Alarm1

Excitation control to A2/E, high alarm to Alarm1

Excitation Warm-up Delay is used to specify how much delay will be set after the excitation terminal is activated and before the logger is taking the sample. If the measurement source device needs certain time to stabilize the signal output you may need to set this parameter so the logger will wait certain time before it takes the sample.

Please refer to **User Interface References** for the detailed explanation of each field.

Add Custom Channels

A custom channel is a virtual channel that SiteView can add to a data logger. Because there is no physical measurement source for a custom channel, the logger can not save the channel's data in the logger's memory. Instead, the channel's data is parsed in SiteView.

A custom channel is useful when you need a new measurement in addition to the measurements of existing physical channels and the new measurement relates to those existing channels.

For example, if a logger has one temperature channel and one relative humidity channel, and you want to calculate the dew point from the temperature and the relative humidity measurements, a custom channel can be added to the logger for the new dew point measurement.

You can add maximum of eight custom channels to a logger.

Quick Way to Calibrate Logger

Although you can go through the procedure in **Calibrate Logger** chapter to calibrate a logger, you can also use **Logger Configuration** dialog to do a quick calibration for all channels of the logger.

Understand Cali. Low & Cali. High


These two fields specify the calibration values that are used for measurement adjustment.

Cali. Low value specifies the digital value that is over zero when the input value is the lowest value (for 0 – 5 VDC channel the lowest value is zero volt). For instance, if you apply zero volt input and the logger measured 100 as the digital value, then Cali. Low should be 100 digits. The equation entity will subtract this value when resolving the correct lowest digital value.

Cali. High value specifies the digital value that is over 65535 when the input value is the highest value (for 0 – 5VDC channel the high range is 5 volt). For instance, if you apply 5 volt voltage to the channel and the logger measured 65100 as the digital value. Then Cali. High is “- 435” (calculated from 65100 – 65535). The equation entity will subtract this value (-435) from the digital value when resolving the highest digital value.

The valid range for these two parameters is from -32768 to 32767 .

The following figure illustrates the relationship between an ideal data line and a measured data line and how Cali. Low and Cali. High correct the measured data line.



Calibrate Channel

Cali. Low and **Cali. High** parameters for each channel are editable in **Logger Configuration** dialog. You can simply change them and use real-time table to check if the parameters are changed correctly.

To calibrate a channel:

1. Click **Real-Time** button to enable **Real-Time** table. Notice the real-time readings are updated in **Reading** cells for all channels.
2. Check the difference between the reading you see and the reading it is supposed to be. Adjust **Cali. Low** and **Cali. High** parameters to make the readings as close as to the desired value.
3. If you are satisfied, click **Apply** button to save the parameters to the logger or click **OK** button to save the parameters and close the dialog.

Save Settings and Start New Session

Once you have finished making changes to the available settings, you can click **OK** button to save the settings to the logger. The logger will start to record data from the **Time to Start** field you have set.



Please refer to **User Interface References** for the detailed explanation of each field.

CHAPTER 8 - REAL-TIME CHART VIEWING/RECORDING

If the logger is in normal sampling mode (sampling interval is 5 seconds or bigger), SiteView can view the real-time measurements while the logger is still logging data. The real-time display shows the list of the latest real-time measurements of all enabled channels, and the trend chart of the real-time measurements for a given latest period of time.

Display Real-Time Dialog

The **Real-Time** dialog can be displayed by clicking on **Real-Time** tool bar button in the logger status page.




Save Real-Time Data

The real-time data can be saved in the pre-defined file and the tabular data can be viewed by clicking on **Dataset** button.



Real-Time Log page of **Global Settings** dialog specifies if, where and how the real-time data will be saved.



If you are real-time logging the data for more than a day, the real-time file can be split either daily or monthly.

You can specify the folder to save the real-time data file.

Change Views Properties

Both List and Chart views can be displayed or hidden by toggling **List View Visible** and **Chart View Visible** buttons. They can be displayed either vertically or horizontally by switching between **Vertical View** and **Horizontal View** buttons.

More properties can be edited by clicking on **Settings** button:

A dialog box titled 'Real-Time Settings' with a close button (X) in the top right corner. It contains three main sections: 'Line Properties', 'Axis Properties', and 'List Properties'.
Line Properties table:

Channel #	Visible	Width	Color
0	☒	3	Blue
1	☒	1	Red
2	☒	1	Green
3	☒	1	Yellow
4	☒	1	Brown
5	☒	1	Purple
6	☒	1	Pink
7	☒	1	Orange

Axis Properties table:

Name	Visible	Auto Scale	Min	Max
Celsius (°C)	☒	☒	0	50
MilliVolt (mV)	☒	☒	0	10

List Properties section:

- ☒ Channel Index Visible
- ☐ Channel Description Visible
- ☒ Apply Channel Color To List

At the bottom are three buttons: 'Help', 'OK', and 'Cancel'.

Line Properties table specifies if a line will be displayed, the width and the colour of the line.

Axis Properties table specifies if a Y-Axis will be displayed, how the Y-axis scales the reading: **Auto Scale** or **Manual Scale** on the given **Min** and **Max** range.

List Properties section specifies if the channel index and description will be displayed and if the line colour will be applied to the colour of the list text.


Click **OK** button to save the changes.

CHAPTER 9 - CALIBRATE LOGGER


SiteView software provides two-point calibration for most of the loggers. If the source signal like voltage or current can be connected to the logger while the logger is connecting to the computer, you can calibrate the logger on-line. If the source signal like a temperature or relative humidity is not available for on-line calibration, you can calibrate the logger off-line after the logger has recorded the low and high point data.

On-Line Calibrate

Click **Calibrate** button on the top of the logger status page in SiteView and choose **On-Line Calibrate** menu.



The following dialog appears:



Select the channel you want to calibrate on and click **OK** button. The following dialog appears:

Channel Calibration Wizard - Channel:1

Step 1: Low Point Calibration

Based on the equation the channel is using, the range of the channel is:

Millivolt(mV) To Millivolt(mV)

Please type in the low point value of the source input that is connected to the channel:

Input Low Reference Value

Millivolt(mV)

Click "Start Calibration" button to start the calibration. When you see the current reading is stable you can click "Stop Calibration" button to stop this procedure.

Current Reading Millivolt(mV)

Click "Next >>" button to proceed for High Point Calibration.

The above page allows you to calibrate the low point. Please adjust your input which connects to the channel terminal strip to a low point value closes enough to the lowest value of the channel. In the above example “0” is the lowest value.

Click **Start Calibration** button to start the low point calibration. After the click, **Start Calibration** button changed to **Stop Calibration**.

During the calibration process the current real-time value is showing in **Current Reading** field. If you think this value is stable you may click **Stop Calibration** button.

Click **Next** to proceed to the next page.

The image shows a software dialog box titled "Channel Calibration Wizard - Channel:1". It is at "Step 2: High Point Calibration". The dialog has a blue title bar with a close button. The main area is light beige. It contains text explaining the input range (0 to 5000 mV) and asks for a high point value. There is a text input field for the high point value. Below this, it says to click "Start Calibration" to begin and "Stop Calibration" to end. There is a button labeled "Start Calibration" and a "Current Reading" field. At the bottom, there are four buttons: "Help", "Previous", "Next >>", and "Cancel".

Channel Calibration Wizard - Channel:1

Step 2: High Point Calibration

Based on the equation the channel is using, the input range of the channel is:

MilliVolt(mV) To MilliVolt(mV)

Please type in the high point value of the source input that is connected to the channel:

Input High Reference Value

MilliVolt(mV)

Click "Start Calibration" button to start the calibration. When you see the current reading is stable you can click "Stop Calibration" button to stop this procedure.

Current Reading MilliVolt(mV)

Click "Next >>" button to proceed for the result.

The above page allows you to calibrate the high point. Please adjust your input which connects to the channel terminal strip to a high point value closes enough to the highest value of the channel. In the above example “50000” mV is the highest value.

Click **Start Calibration** button to start the high point calibration. After the click, **Start Calibration** button changed to **Stop Calibration**.

During the calibration process the current real-time value is showing in **Current Reading** field. If you think this value is stable you may click **Stop Calibration** button.

Click **Next>>** to proceed to the next page.

Channel Calibration Wizard - Channel:1

Step 3: Calibration Result

Given Parameters:

Channel Range	0 MillVolt(mV)	To	5000 MillVolt(mV)
Input Low Reference Value	0.00 MillVolt(mV)	Input High Reference Value	5000.00 MillVolt(mV)

Calculated Parameters

Measured Input Low Digit	40	Measured Input High Digit	59161
Calibration Low Value	40	Calibration High Value	-6374

Save Parameters to the logger

Help Previous Done Cancel

The above page shows all parameters you have input as well as the values the system have calculated. Two important values can be saved back to the logger by clicking **Save Parameters to the logger**. Those two parameters are: **Calibration Low Value** and **Calibration High Value**.

If you click **Save Parameters to the logger** button you will get the below warning dialog. Click Yes to confirm the saving process.

SiteView

New Calibration Parameters will be saved to the logger. All existing parameters in the logger will be lost. Continue?

Yes No

If the system saved the parameters back to the logger successfully, at the bottom side of the dialog **The calibration is finished!** will appear.

The calibration is finished!


You may click **Done** button to close the dialog.

On the logger status page the Cali. Low and Cali High values for this channel were updated with the new values.

The calibration is finished!

Off-Line Calibrate

Click **Calibrate** button on the top of the logger status page in SiteView and choose **Off-Line Calibrate** menu.



The following dialog appears:

Channel Calibration

Step 1. Retrieve reference and actual values:

1.1 Make sure the following channel configuration is correct:

Channel	Cali. Zero	Cali. Span	Equation	Range From	Range To	Unit
#1 (5V)	36	900	VoltageDC	0.00	5000.00	MilliVolt (mV)

1.2 Make sure the logger is logging data with the proper sampling interval. Adjust the source input to a value close to 'Range From' parameter in the above table. Take note of this input value as 'Low Referene' Value. Apply the source input to the designated channel for a period of time that can best reflect the accuracy of the source input.

1.3 Adjust the source input to a value close to 'Range To' parameter in the above table. Take note of this input value as 'High Referene' Value. Apply the source input to the designated channel for a period of time that can best reflect the accuracy of the source input.

1.4 Download the logger first. Open the downloaded file and zoom in to the time frames when the designated channel was applied by the source input. Write down the mean value in the first period of time as 'Real Low' Value and the mean value in the second period of time as 'Real High' Value.

Step 2. Calibrate channel:


2.1 Fill out the following fields with the parameters retrieved in step 1.

2.2 Click "Calibrate" button to calculate the calibration values and save them back to the logger.

Low Reference Value: mV Real Low Value: mV High Reference Value: mV Real High Value: mV

In Step 1, it instructs you how to configure the logger to record low and high point values and retrieve them in the downloaded file.

Once you have obtained those four parameters, enter them into their fields respectively. Click Calibrate button to calculate the final parameters and save them back to the logger. The following dialog appears:



Click Yes button to save the parameters.

The calibration is finished!

CHAPTER 10 - RECEIVE ALARM NOTIFICATIONS

How SiteView Receive Alarms

In order to receive any alarms, SiteView must have **Alarm Centre** opened. **Alarm Centre** can be displayed by clicking on **Alarm Centre** menu item under Tools menu.

There are two ways that a logger can report the alarm condition:

1. Via Modem Connection:

If the connection between the logger and the computer is Modem connection, and **Sent Out via Modem/Pager** was selected in **Alarm Sent-out Selection**, the logger will send out the alarm notification via Modem connection by dialling out the phone number and send out the alarm.

In this case, SiteView can receive alarms from any logger that can access the Modem connection.

2. Via Direct Connection:

If the connection between the logger and the computer is USB, Ethernet or direct Serial Port, SiteView will retrieve the alarm condition of the logger periodically. In this case, SiteView keeps the USB, Ethernet connection or the serial port open all the time.

Configure Parameters for Receiving Alarms

Before the logger was sent out to the field, the logger must be configured properly for alarm notification. The parameters can be configured are through **Logger Configuration** dialog.

Channel #	Enabled	Low Alarm	High Alarm	Unit
0	☒	20	25	°C
1	☐	0.00	0.00	mV
2	☐	0.00	0.00	mV
3	☐	0.00	0.00	mV
4	☐	0.00	0.00	mV
5	☐	0.00	0.00	mV
6	☐	0.00	0.00	mV
7	☐	0.00	0.00	mV

Configure Channels for Alarming

In Alarm & Excitation tab, there is **Channel Alarm Settings** table. If you want the alarm of the channel to be enabled you need to check **Alarm Enabled** field. The alarm thresholds can be set by **Low Alarm** and **High Alarm** fields. If the value is below the **Low Alarm** the channel is considered to be in **Low Alarm** state. If the value is beyond the **High Alarm** the channel is considered to be in **High Alarm** state.

Configure How to Send out Alarm

Notify Alarm via Modem checkbox specifies if the logger sends out an alarm notification via Modem.

To let the logger report the alarm via Modem dial-out, you select **Sent Out via Modem/Pager**.

Configure When to Send out Alarm

Alarm-On Delay specifies if the logger will wait for a period of time before it treats the alarm to be a true alarm. During this period of time, if the value goes below the alarm thresholds the alarm will be cleared.

Configure The Phone Number for Modem


If you have selected **Notify Alarm via Modem** checkbox, you need to provide the phone number the logger needs to dial for the Modem connection. The phone number should be the PSTN line connected to the Modem and the computer where SiteView is running.

Actions When Alarm Received

When SiteView received an alarm notification, it can run a program and/or send out email:

Execute a program or play music:

In order to run a program and / or play a music the following parameters must be set in **Global Setting -Alarm** tab page:




If you want to run a program or play a music, you need to check **Run Executable/Play Music** check-box and click **Browse (...)** button to select the file. You may click **Test** button to see if the selected file is valid.

Send out email:

If you want to send an alarm email you need to check **Send Email To:** check-box and fill out the email text-box with the recipient. You may click **Send out a Test Email** button to test if a test email can be sent to the recipient correctly.

You must configure the SMTP email account correctly before sending out any email. SMTP Configuration can be displayed by clicking **Configure SMTP Email Account** button.



SMTP Configuration

SMTP Server:
smtp.gmail.com

SMTP Port:
587

Username:
siteviewalarm

Password:
xxxxxxxxxx

Confirm Password:
xxxxxxxxxx

Use SiteView Alarm Account

Help OK Cancel

Please refer to **User Interface References** for the detailed explanation of each field.

Below is an example of Alarm Notification Email sent out by SiteView Alarm Center:

Alarm Notifications

Reported At: 3/13/2012 9:21:50 PM

Hello: This email was sent to you from **SiteView** indicating alarm states just changed with one or more registered data loggers in the system. Details are specified below:

Logger Channel Alarms:

Data Logger: New Logger					
Model	S/N	Interval	Configure Time	FIFO?	Other Info
LPTH-1	010601000099	5 seconds	3/10/2012 10:01:15 AM	Yes	Working properly

CH#	Description	Alarm State	Low Alarm	High Alarm
0	Office	Low Alarm	23.33 °C	24.00 °C
1	Lab with Temperature	High Alarm	1999.89 Ohm	7142.75 Ohm
7	CH7	No Alarm	0.00 Ohm	7200.34 Ohm


© 2011 Microedge Instruments Inc.

Alarm Centre

If all above settings are configured correctly, you must open **Alarm Centre** dialog to receive the alarm and take the specified actions.


To open **Alarm Centre**, you click on **Alarm Centre** menu item under **Tools** menu.

The following **Choose Connections** dialog appears. You need to select one ore more connections that will be used to communicate with the connected loggers.




If you have selected one or more connections and clicked **OK** button, the system will check if the loggers are connected to the computer for the non-Modem connections.

Upon the success, the **Alarm Center** dialog will appear.



If there is an alarm, a red-color row will be added to the Alarm Event List and the further action will be taken based on the settings you have already configured.

You may change the settings by clicking **Settings** button.



Please refer to **User Interface References** for the detailed explanation of each field.

CHAPTER 11 - WORK WITH EQUATIONS

What is Equation

Data logger records a channel input measurement in digital value, which does not represent the physical measurement. In order to do the correct conversion Equation is introduced.

Equation is a software functionality handling the conversion from one data format to another. SiteView uses equation name up to 16 characters to identify an equation. Each time when SiteView loads status of the logger it locates the equation by the equation name saved in the logger. If the equation is predefined (built-in equation), SiteView uses predefined function to convert the data. If the equation is customer defined (custom equation), SiteView loads the contents of the equation from the equation file and does the conversion.

Built-In Equations

The following tables contain all built-in equations:

Equations for Temperature Channels

Channel Type	Equation Name	Equation Description
Internal Thermistor		
	Temperature	Temperature
	Resistance	Resistance
External Thermistor		
	Temperature	Temperature
	Resistance	Resistance
Temperature	Temperature	Temperature
Thermocouple		
	ThermocoupleB ThermocoupleE ThermocoupleJ ThermocoupleK ThermocoupleN ThermocoupleR ThermocoupleS ThermocoupleT	Thermocouple Equations
	VoltageDC	Voltage DC

Equations for Relative Humidity Channel

Channel Type	Equation Name	Equation Description
Relative Humidity	RelativeHumidity	Relative Humidity

Equations for Voltage Channels

Channel Range	Equation Name	Equation Description
0-2 VDC	VoltageDC	Voltage DC
0-5 VDC	VoltageDC	Voltage DC
0-10 VDC	VoltageDC	Voltage DC
0-20 VDC	VoltageDC	Voltage DC
-5 to + 5 VDC	VoltageDC	Voltage DC
-2 to +2 VDC	VoltageDC	Voltage DC

Equations for Current Channels

Channel Range	Equation Name	Equation Description
4-20 mA	Current DC	Current DC
0-50 mA	CurrentDC	Current DC

If the physical measurement is same as the measurement that the built-in equation generates, you can pick the built-in equation when you configure the channel.

If built-in equations do not meet the requirement, you can create a custom equation.

Temperature Equation For Thermistor

A thermistor is a type of resistor whose resistance varies significantly with temperature. All Site-Log data loggers except LRHT-1/2 have on-board thermistor channel to record the ambient temperature. External thermistor channels of LPTH-1 are for user to connect nearly any type thermistors.

The Steinhart-Hart equation is widely used for thermistors for a wide range of temperatures with high precision:

$$T = \frac{1}{a + b \ln (R) + c \ln^3(R)} - 273.15$$

When you use 'Temperature' equation for an external thermistor channel, you need to specify a, b and c coefficients which you can get from the thermistor manufacturer.

#	Channel Type/Input Range	Enabled	Description	Equation	Cali. Low	Cali. High	Action
0	Thermistor	☐	CH0	Temperature	0	0	
1	External Thermistor	☒	CH1	Temperature	192	-176	Change Coefficients
2	External Thermistor	☒	CH2	Resistance	39	-11	
3	Resistance (8K)	☒	CH3	Resistance	10	11	
4	Resistance (8K)	☐	CH4	Resistance	0	0	
5	Resistance (8K)	☐	CH5	Resistance	0	0	
6	Resistance (8K)	☐	CH6	Resistance	0	0	
7	Resistance (8K)	☐	CH7	Resistance	0	0	

The above screenshot is part of Logger Configuration dialog. After you selected "Temperature" as the equation for channel #1 External Thermistor, "Change Coefficients" button will display in "Action" column to allow you change those a, b and c values:

Thermistor Coefficients

A thermistor is a type of resistor whose resistance varies significantly with temperature.

The Steinhart-Hart equation is widely used for thermistors for a wide range of temperatures with high precision:

$$T = \frac{1}{a + b \ln(R) + c \ln^3(R)} - 273.15$$

Where:

- T is temperature in Celsius
- a, b and c are called the Steinhart-Hart parameters also called temperature coefficients
- R is resistance in ohms

When you use 'Temperature' equation for any external thermistor channel of LPTH-1 logger, you need to specify a, b and c coefficients which you can get from the thermistor manufacturer.

If you know the thermistor part number you can also send us an email and we will calculate those coefficient values for you.

Please enter the following temperature coefficient values:

a:

0.001462721

b:

0.000239215

c:

9.7E-08

Help

OK

Cancel

After you changed those values and click "OK" button the above dialog will close. Then in the Logger Configuration Dialog once you applied the changes the equation will be transferred to the logger.

Custom Equation

A custom equation is a piece of script that user can create to implement the physical measurement conversion. SiteView uses .Net C# language as the script. The script or the source code is in the format of function call.

A function specifies the name of the function, the types and number of parameters it expects to receive, and its return type. The body of the function implements the conversion from one unit measurement to another. A simple custom equation looks like this:


```
public double CO2Equation(double Input)
{
    double output;
    output = (5000 / 10 ) * Input ;
    return output;
}
```

The above equation has the name “CO2Equation”. The name must be unique and with maximum of 16 characters.

The function has one parameter named **Input**. This value is read-only and it is the result of the caller function or the conversion from digital value to the unit measurement for that channel type if there is no caller function. In the latter case, **Input** refers to a value within the range of 0 – 10 volt for a 0 – 10 VDC channel type.

The function must return a value, which is the result of the conversion.

The above equation is illustrated below. It indicates that for the input range 0 – 10, the output is proportional to the range of 0 – 5000. For instance, A CO2 transducer has output of 0 – 10 VDC representing 0 – 5000 PPM of CO2. The transducer is connected to the 0 – 10 VDC channel of the logger. When the transducer outputs 0 Volt, the physical measurement should be 0 PPM of CO2. When the transducer outputs 10Volt, the physical measurement should be 5000 PPM of CO2. When you apply the above equation to the channel you should get the correct conversion.



$$\text{Output} = (5000 / 10) * \text{Input}$$

Create Equation

To create a custom equation:

- ❑ Click **Equation** button from Main tool bar.
- ❑ In the equation dialog, click **Create** button to create a new equation:

New Equation

Step 1: Input Equation Name:

CO2Equation

Equation Name must meet the following requirements:

1. Must be alphabetical characters and numbers.
2. Number (Nemeric characters) can not be at beginning.
3. Maximum length is 16.

Step 2: Input Equation Description:

CO2 Concentration

Give meaningful description about what the equation is for.

Step 3: Specify Input and Output Range:

Minimum Input Value: 0 Maximum Input Value: 5

Minimum Output Value: 0 Maximum Output Value: 5000

If the equation is linear equation you may fill out the input value pair and outpub value pair.

You may leave them blank if you know how to write your own

Minimum and Maximum Output Values refer to the output range.

You may leave them blank if you know how to write your own equation.

Step 4: Select Unit:

New Unit Category

If no unit meets your requirement you may create a new unit first and come back to this page later.

Help OK Cancel

In the pop-up dialog, enter the name and description of the equation.

If the equation is a linear equation, type in the Input Value pair and Output Value pair. In the above example, the correct parameters are:

Minimum Input Value = 0
Maximum Input Value = 10

Minimum Output Value = 0
Maximum Output Value = 5000

You need to choose a unit for the new equation. If this is a new unit you need to use **Unit Dialog** to create a unit prior to this dialog.

Click **OK** button to close the dialog and return to the Equation dialog.

The new equation is added to the equation list on the left-hand side and the contents of the equation are displayed on the right-hand side panel.


- ❑ Click **Apply** button to save the new created equation.

Import/Export Equations


Import/export equation function is used when a batch of equations need to be copied from one SiteView system in one computer to another SiteView system in another computer.

To export a series of equations:


- ❑ Click **Export** button.



In the pop-up Export Equations dialog, check each equation you want to export and click **Export** button.




- ❑ In the **Save As** dialog give a filename to save and click **Save** button to close file-save dialog.




The equations were exported to an equation package file, which can be imported to other SiteView system.

To import an equation package:


- ❑ Click **Import** button.



Browse for the equation package file and click **Open** button to choose the file and close the File-Open dialog.



The following Import Equation dialog appears:



- ❑ Check the equations you want to import from the left-hand side list and click **Import** button to import.
- ❑ Click **Close** button to close the Import Equation dialog.

Apply Equation to Logger

If you are in Logger Configuration dialog, when you click on the combo-list in the Equation column cell, all custom equations will be displayed in the list. Choose the one and click Apply button to save the equation information to the logger.

Channels: Custom Channel Actions:    

Channel #	Channel Type/Input Range	Enabled	Description	Equation
0	PT103J2 Thermistor		CH0	Temperature [Temperature]
1	20V		CH1	VoltageDC [VoltageDC]
2	20V		CH2	VoltageDC [VoltageDC]
3	5V		CH3	Digit [ADC Digit Value]
4	5V		CH4	Ave5Points [Average of Previous 5 Points]
5	5V		CH5	CO2Equation [this is a test equation]
6	5V		CH6	CO_200PPM [CO 200 PPM]
7	5V		CH7	DewPointAverage [Average DewPoint]
				DewPointEquation [Dew point of the air]
				ExtThermistor2 [Equation for an external thermistor]
				VoltageDC [VoltageDC]


Create Custom-Line Equation

A custom-line equation is used when you add a custom line to the plot. The value of the new line relates to the values of other existing lines on the plot. The relationship is specified in the custom-line equation.


A custom-line equation is similar to a standard custom equation. The only difference is a custom equation accesses **Lines** object instead of **Logger** and **Channels** objects.


To create a custom-line equation:

- Click **Custom-Line Equation** button from Main tool bar.



- In the Custom-Line Equation dialog, click **Create** button to create a new equation:





In the pop-up dialog, type in the name and click “OK” button.

The new equation is added to the equation list on the left-hand side and the contents of the equation are displayed on the right-hand side panel.


You may update the description of the equation and add your source code in the body of the equation.

- ❑ Click **Apply** button to save the new created equation.


Add Custom-Line Equation to Plot

If you have created a custom line equation, you can apply it to a new created line:

1. Open a SiteView file that you want to add a new custom line to.
2. Click on **Tools -> Add Custom Line** of the Plot View:



3. In the pop-up **Add Custom-Line** dialog pick the custom line equation you want to apply to the current plot and click **OK** button:




A new line was added to the plot.

Call/Invoke Other Custom Equations

If you have created a custom equation for certain measurement conversion and this conversion may be useful to other custom equations, then you can call/invoke this equation inside other equations.

All available custom equations are listed under **Available Objects** list:



For example, if you have created **DewPointEquation** to calculate the dew point value and **HourAverage** equation to calculate the previous hour average value, you can create a third equation to call these two equations for the previous hour average value of the dew point values like this:

```
//A custom equation for previous hour average of dew point.
public double HourAveDewPoint(double Input)
{
    double val = DewPointEquation(Input);
    val = HourAverage(val);
    return val;
}
```

CHAPTER 12 - WORK WITH UNITS

What is Unit

A Unit is a definite magnitude of a physical quantity, defined and adopted by convention and/or by law, that is used as a standard for measurement of the same physical quantity.

For example, Temperature is a physical quantity or a Unit Category. The Celsius is a unit of Temperature that represents a definite predetermined temperature. When we say 25 Celsius (or 25°C), we actually mean 25 times the definite predetermined temperature called "Celsius".

A unit category may have multiple units associated to it. For example, Fahrenheit and Kelvin are other two units under temperature category and their relationships are:

$$\text{Fahrenheit} = 1.8 * \text{Celsius} + 32$$

$$\text{Kelvin} = \text{Celsius} + 273$$

In the SiteView system, each unit category can have only one primary unit. In the above example, Celsius is defined as the primary unit. Only the primary unit has its slop = 1 and intercept = 0. All other units under the same unit category relate to the primary unit.

In SiteView system, each unit category can have one user selectable default unit. For example, if you are in the United States you may choose Fahrenheit as your default unit.

The following tables specify the SiteView built-in units for some unit category:

Temperature Category:

Unit	Slop	Intercept	
Celsius	1	0	
Fahrenheit	1.8	32	
Kelvin	1	273	

Voltage Category:

Unit	Slop	Intercept	
Volt	1	0	
Killovolt	0.001	0	
Millivolt	1000	0	
Microvolt	1000000	0	

Current Category:

Unit	Slop	Intercept	
Amp	1	0	
Milloamp	1000	0	

Microamp	1000000	0	
----------	---------	---	--


Relative Humidity Category:

Unit	Slop	Intercept	
RH	1	0	


Unit category is used by an equation. Without the unit, the measurement calculated by the equation does not have meaning.

Open Unit Category Dialog

Click **Unit Category** button on main tool bar:




The following **Unit Category** dialog appears:




Create Unit

To create a unit under existing unit category:

- ❑ Click **Add Unit** button in **Unit Category** dialog:



The following **Add New Unit** dialog appears:

A screenshot of a dialog box titled 'Add New Unit'. It contains several input fields: 'Name' (with 'New unit' entered), 'Symbol' (with 'New symbol' entered), 'Scale' (with '1' entered), 'Offset' (with '0' entered), 'Decimal Place' (a dropdown menu set to '0'), 'Min Scale' (with '0' entered), and 'Max Scale' (with '10' entered). At the bottom are 'OK' and 'Cancel' buttons.


- ❑ Fill out the fields in the above dialog and click “OK” button to close **Add New Unit** dialog.

To create a unit and unit category:

- ❑ Click **Add Unit Category** button in **Unit Category** dialog:



The following **Add New Unit Category** dialog appears:



The dialog box titled "Add New Unit Category" features a text input field for "Unit Category" containing "New Unit Category". To the right, a list titled "Reserved Unit Category Names" includes: Current DC, Digit, Energy, Power, Relative Humidity, Resistance, Temperature, and Voltage DC. Below these is a table for "Units" with columns: Name, Symbol, Slope, Intercept, Decimal Place, Min, and Max. The first row is "New unit" with values: New Symbol, 1, 0, 0, 0, 0, 10. A second row is partially visible with an asterisk in the Name column. At the bottom are "Help", "OK", and "Cancel" buttons.

	Name	Symbol	Slope	Intercept	Decimal Place	Min	Max
▶	New unit	New Symbol	1	0	0	0	10
*							

Add each unit under the new category and click **OK** button to close **Add New Unit Category** dialog.

Import/Export Units


To export unit package:

Click **Export Units** button in **Unit Category** dialog:



A horizontal row of buttons: "Add Unit Category", "Delete Unit Category", "Export Units" (circled in red), "Import Units", "Add Unit", and "Delete Unit".

The following **Export Units** dialog appears:




Check the units you want to export and click **Export** button to choose a file to save.

Click **Close** button to close **Export Units** dialog.


To import a unit package:

Click **Import Units** button in **Unit Category** dialog. The following Open dialog appears:



Browse for the unit package file in **Open** dialog.

The following **Import Unit** dialog appears:




Check units you want to import to and click **Import** button to add the units to the system.

Use Unit

Apply Unit Category in Equation

A unit category is used by an equation. When you create an equation you need to specify what unit category you want the equation to use. You choose the unit in Step 4 of **New Equation** dialog:



Change Unit

If you prefer other unit other than the existing default unit under Unit Category, you can change it in **Unit Category** dialog:

Unit Category List		Unit List								
Unit Category	Unit	Symbol	Slope	Intercept	Decimal Place	Default	Min	Max		
Temperature	Celsius	°C	1	0	2	☒	0	10		
Temperature	Fahrenheit	°F	1.8	32	0	☐	0	10		
Temperature	Kelvin	°K	1	273	0	☐	0	10		

In the above diagram, unit Celsius is the current default unit under Temperature category. You can change this setting by checking Default check box for Fahrenheit or Kelvin row.

Change Unit in Plot

If you prefer a different unit for a channel displayed in the plot, you can change this by selecting a different unit under Unit column in Axis Tab:


Dataset	Statistics	Axis	Line	Plot Title	Legend	Others
Description	Visible	Scale	Min Value	Max Value	Unit	
Temperature (°C)	☒	Auto	0	10	Celsius	
Relative Humidity (%)	☒	Auto	30	100	Relative Humidity	

CHAPTER 13 - WORK WITH SETTINGS & PLOT PREFERENCES


Plot Preferences

Plot Preferences are the properties regarding SiteView plot view. The default Plot Preferences are applied in a new created SiteView file.

All plot preferences are managed in **Plot Preferences** dialog opened by clicking **Plot Preferences** main tool bar button:



The following Plot Preferences appears:



You may add, delete and set default for the selected plot preferences item in the left-hand side list.


Any property you changed will reflect the changes in the Preview plot.

Click **OK** or **Apply** button to save the changes.


Global Settings

Global Settings are the properties categorized in groups that are used for the default settings in SiteView.

Global Settings are managed by **Global Settings** dialog opened by clicking **Global Settings** main menu item:



The following **Global Settings** dialog appears:



General section specifies the general properties like if Log Panel and Comm Panel are displayed in the main frame, how the tool bars and buttons are rendered etc.

Download section specifies the default download folder and the format of the default file name etc.

Diagnostic Log specifies if the log information will be saved to the file and the default folder for the log file.

Real-Time Log specifies if the real-time log will be saved to the file and the default file name format.

Alarm specifies when an alarm notification is received how SiteView acts on it.

Modem specifies how to initialize a Modem.

USB Device Server specifies the properties when SiteView enables USB Device Service.

User Account manages the user accounts.


Please refer to **Global Settings User Interface References** chapter for detailed explanation for each field.

CHAPTER 14 – UPGRADE SITEVIEW & FIRMWARE


SiteView 1.0.1 or above has a new feature to on-line upgrade SiteView and data logger firmware. Please do this periodically for the bug-fixing and updates.

Upgrade SiteView

- ❑ Click **Get Latest SiteView** menu item|:



- ❑ Click **Yes** in the following dialog:




- ❑ SiteView will check and install the latest updates.

Upgrade Firmware

If SiteView found the current firmware of the connected data logger is older than the firmware SiteView has, SiteView will show “Upgrade Firmware” button at the right side of the status form:



If you would like to upgrade the firmware click “Upgrade Firmware” button. The following dialog will show. If you decide to upgrade the firmware be sure to download the data first. Upgrading of the firmware will cause clearing of the data in the logger.




Click **Yes** button to upgrade the firmware.

CHAPTER 15 - WORK WITH PLOT

Chapter 14 - Work With Plot

After the data of the logger is downloaded into the computer, the data is saved in SiteView file (with “svf” as the file extension) and the data is presented in plot and tabular views by SiteView:




The top section is the plot view and the bottom section contains **Dataset**, **Statistics**, **Axis** settings, **Line** settings, **Plot Title** settings, **Legend** settings and **Others** settings.

Basic Views

The view of the plot contains Plot View, Tabular View and Statistics.

Plot View



The above plot view shows the downloaded data of a logger. X axis shows the date and time the data is within. Two Y axes show the measurement ranges with the units in the current time frame. Title of the plot is located at the top section. Below the Title is the Legend, then the actual plot. You can add curve annotations and labels in the plot area.

You can change the looks and feels by going through [Change plot settings](#) page.

Tabular View

Dataset/Plot Settings		 Apply	View Layout	 Horizontal View		
Dataset	Statistics	Axis	Line	Plot Title	Legend	Others
Time		CH0 [°C]		CH1 [%]		
13/10/2010 4:52:22 PM		22.62		44.20		
13/10/2010 4:52:27 PM		22.58		44.20		
13/10/2010 4:52:32 PM		22.62		44.30		
13/10/2010 4:52:37 PM		22.62		44.40		
13/10/2010 4:52:42 PM		22.62		44.53		
13/10/2010 4:52:47 PM		22.62		44.49		
13/10/2010 4:52:52 PM		22.66		44.46		

The above tabular view shows the downloaded data of the logger in the detailed tabular format. The first column shows the date and time when the measurement was taken, the following columns display the data values of all recorded channels.

Statistics

Plot statistics are a set of properties about the opened SiteView files and the current plot view. The statistics are under **Statistics** tab page:

Dataset	Statistics	Axis	Line	Plot Title	Legend	Others				
Statistics: [S/N: 0204104322]New Logger (C:\SiteViewFiles\SN0204104322-2010-10-13-17-12-47.svf)										
Logger Type		Sampling interval	Start	End	Duration	Data Points				
Site-Log LRHT-1		5 Seconds	13/10/2010 4:52:22 PM	13/10/2010 5:12:42 PM	0 Hours 20 Minutes 20 Seconds	490 Readings (245 Readings/Channel)				
Zoomed Section		Zoom Start	Zoom End	Duration	Data Points					
		13/10/2010 4:52:22 PM	13/10/2010 5:12:42 PM	0 Hours 20 Minutes 20 Seconds	490 Readings (245 Readings/Channel)					
Channels		Channel Type	Cali. Low	Cali. High	Min Value	Mean Value	Max Value	Span	Unit	Description
#0		Temperature	0	0	22.02	22.89	23.22	1.20	°C	CH0
#1		Relative Humidity	0	0	41.24	42.78	46.95	5.71	%	CH1


If you opened multiple files, each statistics information associated with its file is listed separately. Each statistics information starts with its file name. Then it specifies the logger type, sampling interval, logged time and total data points. If you have zoomed the plot, it specifies the properties for the zoomed view. At last it specifies the properties about each channel: channel type, calibration information, minimum, mean and maximum values etc.

Open SiteView Files


Open SiteView files

You can open one or more SiteView files into one plot view.

- ❑ Click **Open SiteView File** under **File** menu:




- ❑ Choose one or more SiteView files from the pop-up **Open** file dialog:



In order to choose multiple files, press **Ctrl** key while selecting the files.

Merge SiteView files With Current Plot

If you are already in a SiteView Plot View/Window, you can add another SiteView files to the existing plot by clicking **Add** menu item under **File** menu of the plot view:




Save and Export Plot


Save the Change

If you have made some changes to the plot view, you can save the plot back to the SiteView file:

- ❑ Click **Save** menu item under **File** menu of the plot view:




If the file was saved successfully, you will get the confirmation dialog like this:




Save a copy of SiteView File

- ❑ Click **Save As...** toolbar button:



- Edit a new file name in the pop-up **Save As** dialog and click **Save** button to save the file:




Save As Image File


The plot view can be saved to the following image file formats:

- Enhanced Metafile Format (EMF)
- Portable Network Graphics (PNG)
- Graphics Interchange Format (GIF)
- Joint Photographic Experts Group (JPEG)
- Tagged Image File Format (TIFF)
- Bitmat (BMP)

- Click **Save As Image File** menu item under **File** menu of the plot view:




- ❑ Enter the file name you want to save and select a image file format from **Save as type** list. Then click **Save** button to save the image:




Save as Text File

The logger and channel properties and the current tabular data can be saved in text file format. The file is TAB separated and can be opened by Note Pad, Excel or other text editing software.


- ❑ Click **Save As Text File** menu item under **File** menu of the plot view:



- ❑ Enter a file name to save in the **Save As** dialog:



If the file was saved successfully, you will get the confirmation dialog like this:




Print Plot


There are three sections that SiteView can print: The plot, the statistics and the dataset.

To print the plot:

1. Click **Print** button.
2. In the pop-up dialog, select the interesting sections:



3. Click **OK** button to display **Print** dialog:




4. Make changes of printer, orientation and other properties, click **Print** button to print out the plot.

Before printing you can set up page by clicking **Page Setup** button or preview the plot by clicking **Print Preview** button.

Change Plot Settings

NOTE After the changes are made, you must click Apply button to apply the changes to the current plot.



Change Axis Settings

A plot view contains one X Axis indicating the time frame of the current view and one or more Y Axis indicating the current line scales of the current view.

Each plot curve/line must associate to one X axis and one Y axis, if multiple lines share the same unit they will share the same Y axis.

A Y axis can be visible or hidden by toggling “Show” check box.

A Y axis can be in **Auto Scale** mode: the Y axis will automatically scale to the current range of the line. Or **Manual Scale** mode: the Y axis will use “Min Value” and “Max Value” as the scale.

The Y axis can use different unit under the same unit category. For example you can choose Fahrenheit or Celsius as the unit for a temperature axis.

Dataset/Plot Settings											View Layout		 Horizontal View	 Vertical View	 Special characters	
Dataset		Statistics		Axis	Line	Plot Title		Legend	Others							
Description	Visible	Scale	Min Value	Max Value	Unit	Decimal Place	Alarm Zoon Display Options		Low Alarm	Color	High Alarm	Color	Safe Zoon Color			
Temperature (°C)	☒	Auto	0	10	Celsius	2	Hide Both Alarm Zoons		1171.95	Blue	-122.07	Blue	Green			
Voltage DC (mV)	☒	Auto	0	10	MilliVolt	2	Hide Both Alarm Zoons		0.00	Red	0.00	Red	Green			

Change Line Settings

A line is the representation of the readings of a channel for the current time frame.

The line can be visible or hidden by toggling **Visible** check box.

The description of the line shows in the legend area of the plot.

You may change to a different equation to force the readings of the line to be recalculated based on the new equation.

Dataset/Plot Settings Apply View Layout Horizontal View Vertical View Special characters

Dataset Statistics Axis **Line** Plot Title Legend Others

Index	Visible	Description	Equation	Cali. Low	Cali. High	Width	Color	Style	Point Symbol	Symbol Size	Fill Below-Line	Fill Color	Action
0	☒	CH0	Temperature (Temperature)	0	0	1				7	☐		
1	☒	CH1	VoltageDC (VoltageDC)	0	0	1				7	☐		
2	☒	CH2	VoltageDC (VoltageDC)	0	0	1				7	☐		
3	☒	CH3	VoltageDC (VoltageDC)	0	0	1				7	☐		
4	☒	CH4	VoltageDC (VoltageDC)	0	0	1				7	☐		
5	☒	CH5	VoltageDC (VoltageDC)	0	0	1				7	☐		
6	☒	CH6	VoltageDC (VoltageDC)	0	0	1				7	☐		
7	☒	CH7	VoltageDC (VoltageDC)	0	0	1				7	☐		

Change Plot Title Settings

Plot Title is the text that is displayed on the top of the plot view. When the SiteView file was first created the description of the logger was chosen to be the plot title.

After the plot was loaded, text of the title, the font and the colour of the text can be changed via **Plot Title** tab page.

Dataset/Plot Settings		Apply	View Layout		Horizontal View	Vertical View	Special characters
Dataset	Statistics	Axis	Line	Plot Title	Legend	Others	
Text:		Workshop				☒ Visible	
Font:		Arial, 20.25, Bold					
Color:							

Change Legend Settings

Each plot view contains a legend shows each line's name/description. By default the descriptions of all channels were selected to be the legend when the SiteView file was first created.


You can change the legend's location, the font and the visibility by accessing **Legend** tab page:

Dataset/Plot Settings		Apply	View Layout		Horizontal View	Vertical View	Special characters
Dataset	Statistics	Axis	Line	Plot Title	Legend	Others	
Font:		Microsoft Sans Serif, 12				☒ Visible	
Location:		Top					

Change Other Settings

When a SiteView file was first created, the current default Plot Preferences entry was used to generate the properties of the plot view.

When you are in the plot view, those properties can be changed by access **Others** tab page:



Zoom Plot

Zooming of the plot is to adjust the scales of axes.

Zoom-In

Zoom-In is to focus on one section of the plot so it can be displayed in details.

There are two types of Zoom-In:


Box Zoom:

Zoom the plot to the enclosed area, which involves both X and Y axes' changing.

Scale Zoom:

Zoom the plot to the enclosed area, which only affects the time axis (X axis). The Y axis will be automatically adjusted based on the scale settings.


Switching between Box Zoom and Scale Zoom can be achieved by clicking on the tool bar buttons:




To Zoom In:

Press down the mouse at a spot of the plot, drag the mouse to make a rectangle, release the mouse. The plot will be zoomed into the enclosed area:


Before Scale Zoom:




After Scale Zoom:



Before Box Zoom:




After Box Zoom:



Zoom-Out

Zoom-Out is to restore the axes' scales to the previous view.

Click **Zoom Out** button to zoom out the view.



Un-zoom-All

Un-zoom All is to restore the axes' scales to the first view.



Click **Un-zoom All** button to zoom the plot to the first view.



Time-Zoom

Time-Zoom zooms the plot to the specific time frame.

Click **Time Zoom** button to display the time span selection dialog:



Pick the start and end time and click **OK** button to zoom the plot to the specified time span.


Add Custom Channels

A custom channel is a virtual channel that can be added to the plot. A custom channel is useful when you need a new measurement in addition to the measurements of existing physical channels and the new measurement relays to those existing channels.


For example, if a logger has one temperature channel and one relative humidity channel, and you want to calculate the dew point from the temperature and the relative humidity measurements, a custom channel can be added to the plot for the new dew point measurement.

To add a custom channel:

- ❑ Click **Add Custom Channel** menu item under **Tools** menu:



- ❑ Choose an equation in the **Add Custom Channel** dialog and click **OK** button:



Add Custom Lines


A custom Line is a line/curve that can be added to the plot and resolves its line values from the existing lines in the plot. For example, if there are two lines representing voltage and current readings, you can add the third line representing the power consumption for the current time frame.

To add a custom Line:

- ❑ Click **Add Custom Line** menu item under **Tools** menu:



- ❑ Choose an equation in **Add Custom Line** dialog and click **OK** button:




Add Annotation and Comment

An annotation is a note (label) that user can add to the plot area to explain an associated data point. A comment is a note (label) that user can add to the plot area to explain the plot. The difference between an annotation and a comment are:


1. An annotation goes with the data point. If the data point is zoomed off the plot area, the associated annotation will be off the plot area. Whereas a comment does not associate to any data point, it associates to the plot. Thus the location of a comment refers to the coordinates of the plot area.
2. An annotation has an arrow links the annotation to the data point. Whereas a comment does not have an arrow.

Add an Annotation


1. Move the mouse over a data point of a plot curve. Once the mouse pointer changed to hand icon, right click to display the context menu:



2. Click **Add Annotation** menu item. A default annotation was added to the plot area and was pointed to the highlighted data point:




3. The default text of the annotation contains the date and time and the value of the data point. The default colour of the text is the colour of the plot curve the data point belongs to. To change the properties of the annotation, double click on the annotation to display the Annotation Properties dialog:




Add a Comment

1. Move the mouse to the interesting place inside the plot area, right click to display the context menu:



2. Click **Add Comment** menu item. A default comment was added to the place where the mouse pointed.
3. The default colour of the text is the **Comment Colour** under **Plot Preferences**. To change the properties of the comment, double click on the comment to display the **Comment Properties** dialog:




Other Features of Plot

Use Context Menu

Context Menu is a pop-up menu displayed when the mouse is right clicked on the plot area. The number of enabled and visible menu items depends on the area and object the mouse is clicked on.


A right mouse click on a blank area will display the following context menu:



Note that **Zoom Out** and **Unzoom All** are disabled. This is because the plot's zoom is at the first level. If you have zoomed in once or more times, those two items will be enabled.

Add Comment item is displayed to allow adding a comment at the spot the mouse was just clicked at.


A right mouse click on a previously added comment will display the following context menu:




Property item is visible to allow displaying the **Comment Properties** dialog for editing the comment.

Delete Comment item is visible to allow deleting the comment.

A right mouse click on a data point of a curve will display the following menu:




Add Annotation item is visible to allow adding an annotation.



The default annotation will use the colour of the data point as its text and arrow colour, and the content of the label will be **[date and time] + [measurement value] + [measurement unit]**.

A right mouse click on the previously added annotation will display the following menu:




Property item is visible to allow displaying **Annotation Properties** dialog for editing the annotation.

Delete Annotation item is visible to allow deleting the annotation.


Copy Plot to Clipboard

The plot view can be copied to the clipboard by clicking on **Copy** button or **Copy** menu item:



Show Point Value

If you turn on **Show Point Value**, when the mouse is hovering on any data point on the plot the time and the value will be displayed in the tip box:



To toggle on/off **Show Point Value** property, click on **Show Point Value** button:



View Mouse-Point Values

When the mouse is moving on the plot area, the status bar of the plot window will display each line's value at the time stamp where the mouse is pointing at:


13/10/2010 2:25:52 PM [22.29 °C] [6.76 mV]

Fast Draw Mode

If the plot is in **Fast Draw Mode**, the plot will figure out the appropriate number of points to draw based on the current view port size. This will save dramatic drawing time if the plot contains big amount of data points.


Note: **In Fast Draw Mode, there is a chance where some spike data points may be missed out.**

To toggle on/off **Fast Draw Mode**, click on **Fast Draw Mode** menu item under **View** of the plot view.




Change View Layout

By default, the plot view is at the top and the dataset view is at the bottom side of the plot window. This is **Horizontal View Layout**. You can toggle between horizontal and vertical view layout by clicking on **Horizontal View** and **Vertical View** button:




CHAPTER 16 - USER INTERFACE REFERENCES

Menu Bar



File



Open SiteView File:

Click to open SiteView files and load them into the plot.

Open SiteView Database File:

Click to open SiteView Database files and load them into the plot. For detailed information about SiteView Database file please refer to the manual of logSync application or contact Microedge.

Open Equation:

Click to open an equation package file and import it to the system.

Open Unit:

Click to open a unit package file and import it to the system.

Open Diagnostic Log:

Click to open a diagnostic log file.


Recent Files:

Click to view and open a recent opened file.

Exit:

Click to close SiteView application.

View



Diagnostic Log Panel:

Toggle to show/hide the diagnostic log panel.


Comm Bar:

Toggle to show/hide the communication panel.

Log Plot in Separate Window:

Toggle to either display the plot in a separate window or display the window within the current main frame.

Tools



Unit Category:

Click to display **Unit Category** dialog for managing the units.

Equation:

Click to display **Equation** dialog for managing the equations.

Custom-Line Equation:

Click to display **Custom Line Equation** dialog for managing the custom line equations.

Plot Preferences:

Click to display **Plot Preferences** dialog for managing the plot preferences.

Global Settings:

Click to display **Global Settings** dialog for managing the global wise settings.

Special Characters:

Click to display **Special Characters** dialog for input of special characters.


Alarm Center:

Click to display **Alarm Center** dialog for receiving the alarm notifications.

Enable USB Device Service:

Click to enable USB Device Service. When enabled, other computers can access the data loggers connected to the USB ports of this computer.

Help



Contents:

Click to show the contents of the help:

Index:

Click to show the index of the help:


Get Latest SiteView:

Click to on-line check if there is a latest SiteView to upgrade.


About:

Click to show the **About** dialog of SiteView. **About** dialog shows the version of SiteView and company information.

You can also re-activate SiteView from **About** dialog.



Tool Bar



Tool Bar provides the shortcut for the respective menu items.

Unit Category:

Same as Unit Category menu item.

Equation:

Same as Equation menu item.

Custom-Line Equation:

Same as Custom-Line Equation menu item.

Plot Preferences:

Same as Plot Preferences menu item.

Special Characters:


Same as Special Characters menu item.

USB Device Service:

Pull down button to display USB Device Service related menu items:




Enable/Disable USB Device Service: click to enable/disable the service.
Show Service Log: click to show the service log dialog:



Log in/off:
Log in to the system or log off the system.

Communication Bar

Communication Bar handles the communications between SiteView and data loggers. SiteView supports USB, USB Device Server, Serial Port and Serial Device Server communications that are handled by their tab pages of the Communication Bar.



USB

This tab page handles the communications over USB ports of the computer. All Site-Log data logger have Plug-And-Play feature in that when the logger is plugged in one of the USB ports the logger icon will show in the USB Port list. If the logger is unplugged from the port the logger icon will be removed from the list.

Contact:

Click this button to start the communication with a data logger connected to a USB port of the computer. If the communication is successful, the logger status page will appear in the main frame.

Before clicking this button please make sure you have selected a logger icon in the list.

Scan:

Click this button to scan the USB bus for connected data loggers.

Property:

This section deals with the properties of the USB communications.

Timeout:

This field specifies how much time in millisecond SiteView waits before cancelling the communication.

Retry:


This field specifies how many times SiteView retry the communication when communication failed.

Packet Size:


This field specifies the size of a packet for download. The bigger the packet size is the faster the download is. In case the communication is poor you may lower the packet size.

Change Properties:

Click this button to open a dialog for editing the properties.

**USB Device Server**

This tab page handles the communications with a remote USB Device Server.



Contact:

Click this button to start the communication with a remote USB Device Server. The Server can be a Site USB Device Server hardware or another computer with USB Device Service enabled.. If the communication is successful, the logger icon will appear under the connection. To display the status page of the logger you can double click the logger icon or select the logger icon and click **Contact** again.

Property:

This section deals with the properties of the TCP.

IP Address:

This field specifies the IP address of the remote computer you want to communicate with.

Port:

This field specifies the port that the remote computer will use to receive the communication request.

Timeout:

This field specifies how much time in millisecond SiteView waits before cancelling the communication.

Retry:

This field specifies how many times SiteView retry the communication when communication failed.

Packet Size:

This field specifies the size of a packet for download. The bigger the packet size is the faster the download is. In case the communication is poor you may lower the packet size.

Password:

This field specifies the password that this computer will send to the remote computer for the client authorization.

Change Properties:

Click this button to open a dialog for editing the properties.

The screenshot shows a dialog box titled "192.168.0.102" with a close button (X) in the top right corner. The dialog contains the following fields and controls:

- Description:** A text box containing "laptop".
- IP Address:** A text box containing "192.168.0.102".
- Port:** A text box containing "5678" with a range "(1024 to 65535)" below it.
- Packet Size:** A text box containing "2000" with a range "(1 - 5000)" below it, followed by the label "Bytes".
- Timeout:** A text box containing "5000" with a range "(100 - 10000)" below it, followed by the label "Milliseconds".
- Retry:** A dropdown menu showing "5" with a range "(1 - 10)" below it, followed by the label "Times".
- Password:** A text box containing "xxxxxx" with a range "(4 - 10 characters or numbers)" below it.
- Confirm Password:** A text box containing "xxxxxx".

At the bottom of the dialog are three buttons: "Help", "OK", and "Cancel".

New:

Click this button to create a new connection icon.

Delete:


Click this button to delete the highlighted connection icon.

Close:

Click this button to disconnect the communications to the selected IP connection.

Serial Port

This tab page handles the communications over COM ports of the computer.



Contact:

Click this button to start the communication with a data logger connected to a COM port of the computer. If the communication is successful, the logger status page will appear in the main frame.

Before clicking this button, please make sure the logger is connected to the COM port you have highlighted.

Property:

This section deals with the properties of the COM Port communications.

Timeout:

This field specifies how much time in millisecond SiteView waits before cancelling the communication.

Retry:

This field specifies how many times SiteView retry the communication when communication failed.

Baud Rate:

This field specifies the communication speed over the selected COM port. The faster the baud rate is the faster the download is. In case of poor communications you may need to lower the baud rate.

Packet Size:

This field specifies the size of a packet for download. The bigger the packet size is the faster the download is. In case the communication is poor you may lower the packet size.

Is Modem Connected:

This check box specifies if the COM port is for Modem communication. Check this box if you are using the Modem.

Phone No.:


This field specifies the phone number SiteView will dial for the Modem communications.

Modem Init.:

This field specifies the initialization string SiteView will send to Modem before using it.

Change Properties:

Click this button to open a dialog for editing the properties.




Close:

Click this button to close the selected COM port.

Serial Device Server (Ethernet)

This tab page handles the communications over Ethernet.



Contact:

Click this button to start the communication with a data logger connected to the Device Server device that has the same IP address of the selected icon. If the communication is successful, the logger status page will appear in the main frame.

Property:

This section deals with the properties of the Ethernet port.

IP Address:

This field specifies the IP address of the remote serial device server.

Port:

This field specifies the port that the remote device server will use to receive the communication request.

Timeout:

This field specifies how much time in millisecond SiteView waits before cancelling the communication.

Retry:


This field specifies how many times SiteView retry the communication when communication failed.

Packet Size:

This field specifies the size of a packet for download. The bigger the packet size is the faster the download is. In case the communication is poor you may lower the packet size.

Change Properties:

Click this button to open a dialog for editing the properties.



The screenshot shows a dialog box titled '192.168.0.120' with a close button (X) in the top right corner. The dialog contains the following fields and controls:

- Description:** A text box containing 'Lab1'.
- IP Address:** A text box containing '192.168.0.120'.
- Port:** A text box containing '5678'.
- Packet Size:** A text box containing '200' followed by the label 'Bytes'.
- Timeout:** A text box containing '4000' followed by the label 'Milliseconds'.
- Retry:** A dropdown menu showing '3' followed by the label 'Times'.

At the bottom of the dialog are three buttons: 'Help', 'OK', and 'Cancel'.

New:

Click this button to create a new connection icon.

Delete:


Click this button to delete the highlighted connection icon.

Close:

Click this button to disconnect the communications to the selected IP connection.

Logger Status View

Logger Status View can be displayed by double clicking on the Connection Icon in Communication bar.



Tool Bar Buttons

Real-Time:

Click to display Real-Time dialog. Please refer to **Real-Time Dialog** for detailed explanation.

Refresh:

Click to communicate with the logger and update each field.

Download:

Click to start download the data of the logger. Refer to **Download Dialog** for detailed explanation.

Configure:


Click to configure the logger for new session. Refer to **Logger Configuration Dialog** for detailed explanation.

Clear:

Click to clear the logger and start a new session.

Calibrate:

Click to start on-line/off-line calibration of a channel:

**General**

This sub tab page displays the general properties of the logger.

LED Light When Sampling:

If this check box is checked the on-board LED is enabled.

Description:

This field specifies the description of the logger. The maximum characters for this field is 30.

Sampling Interval:

This field specifies the current sampling interval of the logger. Sampling interval is the time delay between two samples the logger is taking. Most Site-Log loggers have the interval from 20 milliseconds to 12 hours.

Start Time:

This field specifies the time when the logger took the first sample or in FIFO mode, the earliest sample time.

End Time:

This field specifies the time when the logger took the last sample. If the logger is still operating, the time refers to the last sample time before SiteView contacted the logger.

Logging Method:

This field specifies if the logger will continue recording data (FIFO) or stop recording data when the memory is full.

Total Memory:

This field specifies the total available on-board memory for logging.

User Selected Memory:

This field specifies the memory size that user have selected for logging. If the total memory is capable of logging for one year but you only need one month of data, you may select one month as the logging time span and. In this case the User Selected Memory will be smaller than the Total Memory and you always get one month of data from the logger.

The logger was last configured at:

This field specifies the last time when it was configured.

The logger is currently logging data:

This field specifies the current logging status of the logger.

Channel Level Properties:

Channel#:

This column specifies the channel index. Each channel of the logger is identified by the channel#.

Enabled:

This column specified if the channel is enabled or disabled. The logger will not log data for any disabled channel.

Description:

This column specified the description of the channel, maximum of 30 characters.

Equation:

This column specified the equation been used by the channel. Please refer to Logger Configuration Dialog for the detailed explanation.

Cali. Low / Cali. High:

These columns specify the calibration parameters the channel contains. Please refer to Logger Configuration Dialog for the detailed explanation.

Alarm & Excitation

This sub tab page displays the properties regarding the alarm and excitation. By clicking the “Alarm & Excitation” tab page caption, the following page will appear:

Channel #	Enabled	Low Alarm	High Alarm	Unit
0	☒	21.00	25.00	°C
1	☐	0.00	21964.14	mV
2	☐	0.00	21828.03	mV
3	☐	0.00	5484.63	mV
4	☐	0.00	5451.67	mV
5	☐	0.00	5466.24	mV
6	☐	0.00	5470.51	mV
7	☐	0.00	5470.89	mV

Please refer to Logger Configuration Dialog for the detailed explanation for each field.

Alarm/Excitation Selection

This field specifies how A1 and A2/E terminals are being controlled by alarm state and/or excitation settings.

Alarm Sent Out Selection

This field specifies how the alarm notification is been sent out when in alarm state.

Alarm-On Delay

This filed specifies a time delay before sending out alarm notification if there is an alarm. This applies to both terminal strips and the dial-out command which is sent out via communications port.

Alarm-Off Delay

This filed specifies a time delay from the alarm is off the threshold to the alarm is cleared.

Dial-out Number

This field specifies the telephone number to dial out if the “Alarm Send Out Selection” was set for MODEM.

Excitation Warm-up Delay

This field specify the warm-up delay from the time the excitation control is turned on to the time the logger starts to sample the current reading.

Channel Alarm Settings

This table specifies how each channel controls alarm state by:



Alarm Enabled: Specify if the channel is connected with the alarm state.
Low & High Alarm: Specify the alarm thresholds, if the reading is beyond these thresholds, the alarm is triggered.
Unit: Specify the unit of the alarm thresholds.

Channel Alarm Settings:

Channel #	Enabled	Low Alarm	High Alarm	Unit
0	☒	21.00	25.00	°C
1	☐	0.00	21964.14	mV
2	☐	0.00	21828.03	mV
3	☐	0.00	5484.63	mV
4	☐	0.00	5451.67	mV
5	☐	0.00	5466.24	mV
6	☐	0.00	5470.51	mV
7	☐	0.00	5470.89	mV

Download Dialog

The Download dialog can be displayed by clicking on **Download** tool bar button in the logger status page.



Filename & Browse

These fields specify the full file path the downloaded data will be saved into.

Clicking on “Browse” button will display “File Save” dialog where you can edit or choose a file name.

Start Time & End Time

These fields specify the desired start and end time for the data to download. You can use both scroll bar or the calendar control to change both start time and end time.

Logger Configuration Dialog

To display Logger Configuration Dialog:

1. Double click the Connection icon in Communication bar.
2. Click “Configure” button on the logger status page.

Logger Configuration S/N: 0101010003F2

General | Alarm and Excitation

Alarm/Excitation Selection:
Disable any output to A1 and A2/E

Excitation Warm-up Delay:
keep on

Alarm-On Delay: 1 Minute **Alarm-Off Delay:** 1 Minute

☐ Notify Alarm via Modem **Dial-out Number:**

Temperature for Compensation: 25 °C

Channel Alarm Settings:

Channel #	Enabled	Low Alarm	High Alarm	Unit
0	☐	1171.95	-93.90	°C
1	☐	0	5490	mV
2	☐	0	5468	mV
3	☐	0	5474	mV
4	☐	0	5415	mV
5	☐	0	5501	mV
6	☐	0	5474	mV
7	☐	0	5473	mV

Channels: Custom Channel Actions: + - ↑ ↓

Channel #	Channel Type/Input Range	Enabled	Description	Equation	Cali. Low	Cali. High
0	Thermistor	☒	CH0	Temperature [Temperature]	0	0
1	5V	☒	CH1	VoltageDC [VoltageDC]	0	0
2	5V	☒	CH2	VoltageDC [VoltageDC]	0	0
3	5V	☒	CH3	VoltageDC [VoltageDC]	0	0
4	5V	☒	CH4	VoltageDC [VoltageDC]	0	0
5	5V	☒	CH5	VoltageDC [VoltageDC]	0	0
6	5V	☒	CH6	VoltageDC [VoltageDC]	0	0
7	5V	☒	CH7	VoltageDC [VoltageDC]	0	0

Help Real-Time Apply OK Cancel

General Settings

Description:

Description specifies the information about the logging session with a maximum of 30 characters. It will be the default Title section of the plot in the plot view.

Sampling Interval:

This field specifies the time span the logger will wait between two measurements sampling. Valid settings are:

Sampling Interval for Fast Sampling Mode	Sampling Interval for Normal Sampling Mode
20, 30, ...90 milliseconds *	5 seconds to 9 seconds in 1-second increment
100, 200... 900 milliseconds *	10 seconds to 50 seconds in 10-second increment
1,2,3,4 seconds *	1 minute to 59 minutes with 1-minute increment
	1 hour to 12 hour with 1-hour increment

For LRHT-1/2 logger, the minimum sampling interval is one second.

If the sampling interval you set is 4 seconds or faster, the logger must be powered by an external power supply during the logging period of time.

Making changes to the Sampling Interval will affect Total Time Span fields.

On-Board LED

Check this field to enable the on-board status LED. If the LED is enabled it will flash each time when it samples data to indicate:

1. The logging is active if the LED is in green.
2. The logger is in alarm state if the LED is in red.
3. The battery will die soon if the LED is in amber.

If you do not need LED indication, please uncheck this field to increase the battery life.

When Memory Full

If you want the logger to stop logging when the memory is full select **Stop logging**. If you want the logger to continue logging and overwrite the oldest data with new data (FIFO), you choose **Continue logging**.

Time to Start & Time to End

These two fields specify the desired time the logger will start logging data and the time to stop logging data.

Making changes to the Time to End will affect Total Time Span fields mentioned later.

If you have selected the “Continue logging” field, when the memory is full, both start time and end time will move forward accordingly.

Total Time Span

These fields are an alternate way to specify the total logging time from the start time you specified above.

Changing on these fields will affect the Time to End field.

Memory Usage:

Specify the memory usage for the new setting.

If you change Time to Start and Time to End, Total Time Span will change accordingly.

Channel Settings

Enabled

Check this field to enable this channel for logging.

Channel Range

This field specifies the channel type and range the channel will use. The available settings for each channel depend on the logger type.

Description

This field specifies the information for the channel using a maximum of 30 characters.

Equation

This field specifies the equation used for the channel.

For the detailed instructions on how to create a custom equation please refer to the **Work with Equation** and **Equation References** chapters.

Cali. Low & Cali. High


These two fields specify the custom calibration values that are used for measurement adjustment.

Custom Channels:

A custom channel is a virtual channel that SiteView can add to a data logger. Because there is no physical measurement source for this kind of channel, the logger can not save the channel's data in the logger's memory. Instead, the channel's data is parsed in SiteView after the data is downloaded to the computer.

You can add maximum of eight custom channels to a logger.

The following tool bar buttons are used to manage the custom channels of the logger.



Click to add a custom channel.



Click to remove a selected custom channel.



Click to move up a selected custom channel.



Click to move down a selected custom channel.

Alarm and Excitation Settings

Channel #	Enabled	Low Alarm	High Alarm	Unit
0	☒	21.00	25.00	°C
1	☐	0.00	21964.14	mV
2	☐	0.00	21828.03	mV
3	☐	0.00	5484.63	mV
4	☐	0.00	5451.67	mV
5	☐	0.00	5466.24	mV
6	☐	0.00	5470.51	mV
7	☐	0.00	5470.89	mV

Alarm/Excitation Selection

This field specifies how A1 and A2/E terminals are being controlled by alarm state and/or excitation settings. Available settings are:

- Disable any output to A1 and A2/E
- High alarm to A2/E only
- Low alarm to A1 only
- High alarm to A2/E, low alarm to A1
- Both high and low alarm to A1
- Excitation control to A2/E
- Excitation control to A2/E, both high and low alarm to A1
- Excitation control to A2/E, low alarm to A1
- Excitation control to A2/E, high alarm to A1

Notify Alarm via Modem

This field specifies if the alarm notification is been sent out via Mode when in alarm state.


Alarm-On Delay

This filed specifies a time delay before sending out alarm notification if there is an alarm. This applies to both terminal strips and the dial-out command which is sent out via communications port.

- 1 minute
- 0 minute
- 1 minute
- 2 minutes
- 3 minutes
- 4 minutes
- 5 minutes
- 6 minutes
- 7 minutes


Alarm-Off Delay

This field specifies a time delay after the alarm is off the threshold before the alarm is cleared.

A dropdown menu titled "Alarm-Off Delay:" with a list of time intervals: 1 Minute, 2 Minutes, 3 Minutes, 4 Minutes, 5 Minutes, 6 Minutes, 7 Minutes, and 8 Minutes. The "1 Minute" option is currently selected and highlighted in blue.


Dial-out Number

This field specifies the telephone number to dial out if **Notify Alarm via Modem** is checked.

A text input field labeled "Dial-out Number:" with a rectangular box for entering a telephone number.

Excitation Warm-up Delay

Specify the warm-up delay between the time the excitation control is turned on and the time the logger starts to sample the current reading.

A dropdown menu titled "Excitation Warmup Delay:" with a list of time intervals: keep on, 10 seconds, 20 seconds, 30 seconds, 40 seconds, 50 seconds, 60 seconds, and 70 seconds. The "keep on" option is currently selected and highlighted in blue.

Available selections: 10 to 240 seconds in 10 seconds interval.

Channel Alarm Settings

This table specifies how each channel controls alarm state by:


Alarm Enabled:	Checking the checkbox adjacent to the selected channel determines if the channel is connected with the alarm state.
Low & High Alarm:	Entering values defines the alarm thresholds, if the reading is beyond these thresholds, the alarm is triggered.
Unit:	The unit for alarm thresholds.


Channel Alarm Settings:

Channel #	Enabled	Low Alarm	High Alarm	Unit
0	☒	21.00	25.00	°C
1	☐	0.00	21964.14	mV
2	☐	0.00	21828.03	mV
3	☐	0.00	5484.63	mV
4	☐	0.00	5451.67	mV
5	☐	0.00	5466.24	mV
6	☐	0.00	5470.51	mV
7	☐	0.00	5470.89	mV

Real-Time Dialog

Real-Time dialog can be displayed by clicking on **Real-Time** tool bar button in the logger status page.





Tool Bar Buttons:

List View Visible

Click to show/hide the list view panel.

Chart View Visible

Click to show/hide the chart view panel.

Vertical View


Click to display the chart and list views vertically.

Horizontal View

Click to display the chart and list views horizontally.

Time Span

This field allows changing the time span for the chart view. Available settings are:



Interval:

This field allows changing the sampling interval to communicate with the data logger and retrieve the readings. Available settings are from five seconds to one minute.


Dataset

Click to display the tabular view of the recorded measurements illustrated below:

Dataset								
Time	CH1 (°C)	CH2 (mV)	CH3 (mV)	CH4 (mV)	CH5 (mV)	CH6 (mV)	CH7 (mV)	CH8 (mV)
21/08/2010 9:57:45 PM	23.94	76.9055	76.9055	76.9055	76.9055	77.2107	77.2107	77.5158
21/08/2010 9:57:50 PM	23.93	76.2951	76.6003	76.2951	76.6003	76.6003	76.9055	76.9055
21/08/2010 9:57:55 PM	23.91	76.6003	76.6003	76.6003	76.6003	76.9055	77.5158	76.9055
21/08/2010 9:58:00 PM	23.90	76.6003	76.9055	76.2951	77.2107	77.2107	77.2107	77.2107
21/08/2010 9:58:05 PM	23.91	76.6003	76.6003	76.9055	77.2107	76.6003	75.9899	76.2951
21/08/2010 9:58:10 PM	23.92	76.9055	76.9055	77.2107	76.6003	76.9055	76.6003	76.9055
21/08/2010 9:58:15 PM	23.94	76.6003	76.2951	77.2107	77.2107	76.9055	76.6003	76.9055
21/08/2010 9:58:20 PM	23.93	77.2107	76.2951	76.2951	76.9055	76.9055	77.2107	77.2107
21/08/2010 9:58:25 PM	23.94	76.6003	76.2951	76.6003	77.2107	76.9055	76.9055	76.2951
21/08/2010 9:58:30 PM	23.94	76.2951	76.6003	76.9055	77.2107	77.5158	76.9055	77.2107
21/08/2010 9:58:35 PM	23.94	76.6003	76.2951	76.9055	76.9055	76.9055	76.6003	76.9055

Other Settings

Click **Settings** button to display more properties illustrated below:



Line Properties:

Channel#:

The column specifies the channel index.

Visible:

This column specifies if show the line in the plot.

Width:

This column specifies the width of the line in the plot.

Color:

This column specifies the color of the line in the plot.

Axis Properties:

Name:

This column specifies the name of the axis.

Visible:

This column specifies if the axis will be displayed.

Auto Scale:

This field specifies if the scale of the axis will be automatic or be scaled by the range specified in Min and Max columns.

Min:

This field specifies the minimum value of the scale if the axis is manual scaled.

Max:

This field specifies the maximum value of the scale if the axis is manual scaled.

List Properties:

Channel Index Visible:

This field specifies if the channel's index number will be displayed in the list view.

Channel Description Visible:


This field specifies if the channel's description will be displayed in the list view.


Apply Channel Color To List:

This field specifies if the channel's line color specified in Line Properties will be used for the text color of the list.

Equation Dialog

Equation dialog can be displayed by clicking on **Equation** main tool bar button:





Tool bar Buttons

Create:

Click to display New Equation dialog for creating a new custom equation.

Delete:

Click to delete a selected equation.

Import:

Click to display Import Equation dialog for importing equations.

Export:

Click to display Export Equation dialog for exporting equations.

Polynomial:

Click to display Polynomial Equation dialog for generating a polynomial equation statement.

Compile:

Click to compile the equation script and report the result.

Other Fields**Equations:**

Display the list of the available equations. Click on one item to display the contents of the equation on the right-hand side controls.

Name:

Display the name of the selected equation.

Description:

Display the description of the selected equation.

Unit:

Display the measurement unit category of the selected equation.

Equation Code:

Display the equation script of the selected equation.

Available Objects:

Display a list of the objects that can be invoked /accessed by the current equation.

Compile Result:

Display the result of the compilation.

OK button:

Click to save the changes and close the dialog.

Cancel button:

Click to close the dialog without saving the changes.

Apply button:

Click to apply the changes.

Help button:

Click to display the help.

New Equation Dialog

New Equation dialog is displayed by clicking on **Create** button.

New Equation

Step 1: Input Equation Name:

Equation Name must meet the following requirements:

1. Must be alphabetical characters and numbers.
2. Number (Nemeric characters) can not be at beginning.
3. Maximum length is 16.

Step 2: Input Equation Description:

Give meaningful description about what the equation is for.

Step 3: Specify Input and Output Range:

Minimum Input Value Maximum Input Value

Minimum Output Value Maximum Output Value

If the equation is linear equation you may fill out the input value pair and outpub value pair.

You may leave them blank if you know how to write your own Minimum and Maximum Output Values refer to the output range.

You may leave them blank if you know how to write your own equation.

Step 4: Select Unit:

If no unit meets your requirement you may create a new unit first and come back to this page later.

Equation Name:

Specify the name of the new equation.

Equation Description:

Specify the description of the new equation.

Minimum Input Value:

Specify the minimum channel input value. For 0 – 10 VDC channel, 0 is the minimum input value.

Maximum Input Value:

Specify the maximum channel input value: For 0 – 10 VDC channel, 10 is the maximum input value.

Minimum Output Value:

Specify the minimum equation output value when the minimum input value is applied.

Maximum Output Value:

Specify the maximum equation output value when the maximum input value is applied.

Unit:

Specify the measurement unit category the new equation will use.

OK button:

Close the dialog and add the default equation function in Equation Code text box.

Cancel button:


Close the dialog and cancel the action.

Help:

Display Help.

Import Equation Dialog

Import Equation dialog is displayed by clicking on **Import** button.



Equations:

Specify the available equations for importing. Check any item to include it in the importing equation list.

Name:

Specify the name of the selected equation.

Description:

Specify the description of the selected equation.

Type:

Specify the equation type.

File Version:

Specify the version of the equation file.

Unit:

Specify the unit category and all measurement units of the selected equation.

Contents:

Specify the equation script of the selected equation.

Close button:

Click to close the dialog without importing equations.

Import button:


Click to import the selected equations to the system.

Help button:

Click to display help.

Export Equations Dialog

This dialog is display by clicking on **Export** button.




Equations to Export:

List all equations. Check any item to include it in the exporting equation list.

Export button:

Click to export all selected equations to an equation pack file. You need to specify a filename in **Save As** dialog displayed after the click.



Close button:

Click to close the dialog without exporting equations.

Help button:

Click to display the help.

Polynomial Equation Dialog

This dialog is displayed by clicking on **Polynomial** button.

Polynomial Equation

Degree: 1 Decimal Place: 2 Make Equation Clear

Input	Output
312	0
372	206
1015	1030
1500	1150
2000	1400

Source Code

Help Copy the Code to Clipboard and Return Close

Degree:
Specify the degree the polynomial equation.

Decimal Place:
Specify the decimal place will be used to generate the equation.

Make Equation button:
Click to create the polynomial equation based on the input and output table.

Clear button:
Click to clear the table.

Close button:
Click to close the dialog.

Copy the Code to Clipboard and Return button:
Click to copy the generated code to the clipboard and close the dialog.

Help button:



Click to display the help.

Input & Output:

This table specifies a list of input and output values used to generate the polynomial equation.

Custom Line Equation Dialog



Custom Line Equation dialog can be display by clicking on **Custom Line Equation** main tool bar button.



Custom Line Equation dialog is similar with **Equation** dialog. Please refer to **Equation** dialog for the explanation of each field.

Unit Category Dialog

Unit Category dialog can be displayed by clicking on **Unit Category** main tool bar button.



Tool bar buttons

Add Unit Category:

Click to display Add New Unit Category dialog for adding a new unit category.

Delete Unit Category:

Click to delete a unit category and all its units.

Export Units:

Click to display Export Units dialog for exporting units.

Import Units:

Click to display Import Units dialog for importing units.

Add Unit:

Click to display Add Unit dialog for adding a unit to the selected unit category.

Delete Unit:

Click to delete a selected unit.

Other Fields**Unit Category List:**

A list of all available unit categories. Click on one item to display its contents at the right-hand side.

Unit List:

A list of all available units for the selected unit category.

Unit Category:

Specify what unit category the unit belongs to.

Unit:

Specify the name of the unit.

Symbol:

Specify the symbol for the selected unit.

Slope:

Specify the slope for the selected unit.

Intercept:

Specify the intercept for the selected unit.

Decimal Place:

Specify the decimal place for the selected unit.

Default:

Specify if the unit will be the default unit for the selected category.

Auto Scale

Specify if the Y axis for this unit in the plot will scale automatically or manually to the span of the following Min and Max parameters.

Min:

Specify the minimum value of the Y-axis if this unit is used by a plot and when the scale property is set to manual.

Max:

Specify the maximum value of the Y-Axis if this unit is used by a plot and when the scale property is set to manual.

Cancel button:

Click to close the dialog without saving the changes.

OK button:

Click to close the dialog and save the changes.

Apply button:

Click to save the changes.

Help button:

Click to display the help.

Add New Unit Category Dialog

Add New Unit Category dialog is display by clicking on Add Unit Category tool bar button.

Unit Category

New Unit Category

Reserved Unit Category Names

- Current AC
- Current DC
- Digit
- Energy
- Power
- Relative Humidity
- Resistance
- Strain
- Temperature
- Voltage DC
- New Unit Category

Units

	Name	Symbol	Slope	Intercept	Decimal Place	Auto Scale	Min	Max
▶	New unit	New Symbol	1	0	0	☒	0	10
*						☐		

Help OK Cancel

Unit Category:

Specify the name of the new unit category.

Units:

Specify the list of the new units under the new unit category.

Reserved Unit Category Names:

Specify the list of the existing category names. A new unit category name must be unique.

Cancel button:

Click to close the dialog without adding the new unit category.

OK button:


Click to close the dialog and add the new units.

Help button:

Click to display the help.

Export Units Dialog

Export Units dialog is displayed by clicking on **Export Units** tool bar button.



Units to Export:

A list of all unit categories. Check any item to include it in the exporting list.

Close button:

Click to close the dialog.

Export button:


Click to export the selected units to a unit pack file.

Help button:

Click to display the help.

Import Units Dialog

Import Units dialog is displayed by clicking on **Import Units** tool bar button.



Unit Categories:

A list of the unit categories contained in the unit pack file. Check any one to include it in the importing list.

Units:

A list of units under the selected unit category.

Close button:

Click to close the dialog.

Import button:



Click to import the selected unit categories to the system.

Help button:

Click to display the help.

Plot Preference Dialog

Plot Preference dialog can be displayed by clicking on Plot Preferences main tool bar button.



Buttons

Add:

Click to add a new plot preference.

Set as Default:

Click to set the selected item as the default preference.

Delete:

Click to delete the selected item.

Cancel:

Click to close the dialog without saving the changes.

OK:

Click to close the dialog and save the changes.

Help:

Click to display the help.

Other fields

Plot Preferences:

List of the available plot preferences. Click on any item to display its contents at the right-hand side.

Plot Panel Back Colour:

Specify the colours of plot panel and plot area colours and their colour gradient.

Plot Title:

Specify the properties of the plot title: contents, colour, visibility, and font.

Axis and Grid:

Specify the grid colour and visibility. Axis font and if Y-Axis does auto scale.

Legend:

Specify the location, font and visibility of the legend.

Plot Comment:

Specify the colour and font of the plot comment.

Channel Colour Order:


Specify the colour will be used for each channel number from 1 to 60.

Preview:

Display the plot reflects the current preferences.

New Plot Preference

This dialog is displayed by clicking on **Add** button.



Description:

Specify the description of the plot preference.

Derive From:

Specify which existing plot preference to derive the new one from.

Cancel button:

Click to close the dialog without add the plot preference.

OK button:


Click to close the dialog and add the new plot preference.

Help button:

Click to display the help.

Diagnostic Log Panel

Diagnostic Log View can be displayed by checking **View -> Diagnostic Log Panel** main menu item:



Log		
Time	Reporter	Log
2010/9/10 15:37:31	SiteView	SiteView started.

Time:

Specify the date and time the log item is added.

Reporter:


Specify who reports the log.

Log:

Specify the contents of the log item.

Global Setting Dialog

General



Load Plot In Separate Window:

This field specifies that when SiteView files are being opened, the plot will be loaded inside the main frame of SiteView or in a separate window.

Log Panel Visible:

This field specifies if the information log panel is displayed inside the main frame. Check this field to make it visible.

Comm Bar Visible:


This field specifies if the Communication bar is displayed inside the main frame. Check this field to make it visible.

Tool bar Button Display Style:

This field specifies how the tool bar buttons are displayed. Available selections are: "Image", "Image + Text" and "Text".

Tool bar and Menu bar Render Mode:

This field specifies how the tool bar and menu bar is displayed. Available selections are: “System” and “Professional”.

Download**Default Download Folder:**

This field specifies the default folder for the downloaded files. “Browse” /”...” button is used to change to a new folder.

Download File Prefix:

This field specifies the prefix of the formatted file name.

Download Filename Format:


This field specifies how the default file name will be formed when you download a logger. Available selections are:

Prefix + Serial Number + Date + Time
Serial Number + Date + Time
Serial Number
Date + Time
Prefix + Serial Number
Prefix + Date + Time

Display Plot After Download:

This field specifies if the plot will be displayed after the data is downloaded and saved to the SiteView file. Check this field to show the plot automatically after the download.


Diagnostic Log



Save Diagnostic Log to:

These fields specify if the diagnostic log will be saved to a file and the folder for the log. Browse or “...” button is used to browse for a new folder.

Real-Time Log



Save Real-time Log to File:

This field specifies if the real-time log will be saved to the file. The real-time log is a stream of real-time readings when you have “Real-Time” display opened.


Split Real-time File by:

This field specifies when the real-time log will be saved to a file, how the file been split. Available selections are “Daily” or “Monthly”.

Save Real-time File in:

This field specifies the folder to save the real-time log files. Browse or “...” button is used to change to a different folder.

Alarm



Run Executable/Play Music:

This field specifies, when an alarm notification is received, if run an executable file or play the music file specified in the give text box.

“...” button is used to choose a different file.

Test:

Click this button to test if the file is valid to run or play.

Send Email To:


The check box specifies, when an alarm notification is received, if an email will be sent out. The text box specifies the email address to send to.

Send out a Test Email:

Click this button to send out a test email to the email address specified.

Configure SMTP Email Account:

Click this button to display the SMTP configuration dialog illustrated as follows:

The image shows a Windows-style dialog box titled "SMTP Configuration" with a red close button in the top right corner. The dialog has a light beige background. It contains five text input fields: "SMTP Server:" with the text "smtp.gmail.com", "SMTP Port:" with the text "587", "Username:" with the text "siteviewalarm", "Password:" with masked text "xxxxxxxxxx", and "Confirm Password:" with masked text "xxxxxxxxxx". Below these fields is a button labeled "Use SiteView Alarm Account". At the bottom of the dialog are three buttons: "Help", "OK", and "Cancel".

In order to send out an email you need a SMTP email account. This dialog allows you to configure the account:

SMTP Server:

This text box specifies the SMTP server name.

User Name:

This text box specifies the user name to log on the SMTP server.

Password:

This text box specifies the password for the user name.


Confirm Password:

This text box specifies the confirmed password.

Alarm Center Event Row Colors:

These fields specify the text and background colors of the alarm row in the alarm center dialog.

Modem



Remote MODEM:

A MODEM connected to the logger is called the remote MODEM. In order to establish the MODEM connection the remote MODEM must be properly configured locally before it is used remotely.

Initialization String:

This text box is used to specify a series of AT commands used to initialize the MODEM.

Restore Default:

Click this button to restore to the factory default initialization string.

COM Port:

This combo-list specifies which COM Port the MODEM is connected for configuration.

Initialize MODEM:

Click this button to transfer the initialization string to the MODEM.

USB Device Server

The screenshot shows a 'Global Settings' dialog box with a blue title bar and a close button. It has several tabs: 'Download', 'Diagnostic Log', 'Real-Time Log', 'Alarm', 'Modem', and 'USB Device Server'. The 'USB Device Server' tab is selected. The main area contains red text explaining the settings: 'This page is for the settings when current SiteView acts as a USB Device Server. A remote SiteView can communicate with the data loggers connected to the USB ports of this computer if 'USB Device Server' dialog is opened.' Below this, there are three input fields: 'Network Port' with the value '56789', 'Password' with five dots, and 'Confirm Password' with five dots. To the right of these fields is red text: 'The port that the server is listening on. Value must be between 1024 and 65535' and 'Remote SiteView must match this password when it tries to establish the connection. Length of the password must be between 4 and 10.' At the bottom are three buttons: 'Help', 'OK', and 'Cancel'.

Global Settings

Download Diagnostic Log Real-Time Log Alarm Modem **USB Device Server**

This page is for the settings when current SiteView acts as a USB Device Server.
A remote SiteView can communicate with the data loggers connected to the USB ports of this computer if 'USB Device Server' dialog is opened.

Network Port: The port that the server is listening on. Value must be between 1024 and 65535

Password: Remote SiteView must match this password when it tries to establish the connection. Length of the password must be between 4 and 10.

Confirm Password:

Help OK Cancel

Network Port:

This text box specifies the network port that the SiteView on this computer will listen on. Client SiteView must match this port in order to establish the connection with this computer.

Password/Confirm Password:

This text box specifies the password that the client must match in order to establish the connection with this computer.

Plot Window

Tool Bar Buttons



Save As...:

Click to save the current plot as a different file.

Copy:

Click to copy the plot to the clipboard.


Print:

Click to print the plot.

Box Zoom/Scale Zoom:

Toggle them to set the current zoom to be box zoom or scale zoom.

If box zoom is selected, the zoom will be made on the mouse-enclosed area:



If scale zoom is selected, the time zoom will be based on the mouse-enclosed area and the Y-Axis scales will be based on the current axis's scale selections.



Time Zoom:

Click to display Select Time Span dialog for zooming on the specified time span.

Un-zoom All:


Click to restore the zoom back to the first level.

Zoom Out:


Click to restore the zoom back to the previous level.

Show Point Value:


Click to display the data point value when the mouse is hovering on it.



Menu Items



File:



Add:

Click to browse for one or more SiteView files to add to the current plot.

Save:

Click to save the current plot.

Save As...:

Click to save the current plot as a new file.

Save As Image File:

Click to save the current plot to an image file.

Save As Text File:

Click to save the current plot to a text file.

Page Setup:

Click to display Page Setup for editing page settings.


Print Preview:

Click to display Print Preview dialog for previewing the print.


Print:

Click to print the plot.

The first dialog allows selecting which sections to print:




The second dialog allows selecting printer and the printer properties:



Exit:

Click to close the plot.

View:



Show Point Value:

Toggle to show/hide the data point value when the mouse is hovering on the data point.

Fast Draw Mode:


Toggle to enable/disable Fast Draw Mode.

Horizontal View/Vertical View:

Click on them to switch between the horizontal and vertical view of the plot.

Copy:

Click to copy the plot onto the clipboard.

Zoom:**Box Zoom/Scale Zoom:**

Toggle to choose either box zoom or scale zoom for zooming.

Time Zoom:

Click to zoom the plot on the specified time span.

Un-zoom All:

Click to restore the zoom to the first level.

Zoom Out:

Click to restore to the previous zoom.

Tools:**Add Custom Channel:**


Click to add a custom channel to the plot.

Add Custom Line:

Click to add a custom line to the plot.

Select Time Span Dialog

This dialog is displayed by clicking on **Time Zoom** button.



Start Time:

Specify the start time for the zooming.

End Time:

Specify the end time for the zooming.

OK button:

Click to zoom the specified time span.

Cancel button:

Click to cancel the time zoom task.

Dataset View

Tabular data is displayed as the first tab page of the **Dataset /Plot Settings** tab:

Dataset/Plot Settings								
Apply		View Layout		Horizontal View		Vertical View		Special characters
Dataset	Statistics	Axis	Line	Plot Title	Legend	Others		
Time	CH0 [°C]	CH1 [mV]	CH2 [mV]	CH3 [mV]	CH4 [mV]	CH5 [mV]	CH6 [mV]	CH7 [mV]
13/10/2010 2:22:43 PM	21.98	0.00	0.00	6.18	6.10	3.05	3.05	3.05
13/10/2010 2:22:48 PM	21.98	0.00	0.00	6.18	3.05	6.10	3.05	0.00
13/10/2010 2:22:53 PM	21.98	0.00	0.00	6.18	6.10	6.10	0.00	3.05
13/10/2010 2:22:58 PM	21.99	0.00	0.00	6.18	6.10	6.10	3.05	3.05
13/10/2010 2:23:03 PM	21.99	0.00	0.00	3.05	3.05	3.05	3.05	3.05
13/10/2010 2:23:08 PM	21.99	0.00	0.00	6.18	6.10	3.05	3.05	0.00
13/10/2010 2:23:13 PM	21.99	0.00	0.00	6.18	6.10	6.10	3.05	0.00

Dataset:

Specify the date and time of the measurement.

Column 2 – X:

Specify each channel's measurement and the unit. The column head specifies the description and the unit of the channel.

Statistics

Statistics is displayed as the second tab page:

Dataset/Plot Settings									
	Apply	View Layout	Horizontal View	Vertical View	Special characters				
Dataset	Statistics	Axis	Line	Plot Title	Legend	Others			
Statistics: [S/N: 0101101203] New Logger [C:\SiteViewFiles\SN0101101203-2010-10-13-14-31-46.svf]									
Logger Type		Sampling interval	Start	End	Duration	Data Points			
Site-Log LPV-1		5 Seconds	13/10/2010 2:22:43 PM	13/10/2010 2:31:43 PM	0 Hours 9 Minutes 0 Seconds	872 Readings (109 Readings/Channel)			
Zoomed Section		Zoom Start	Zoom End	Duration	Data Points				
		13/10/2010 2:22:43 PM	13/10/2010 2:31:43 PM	0 Hours 9 Minutes 0 Seconds	872 Readings (109 Readings/Channel)				
Channels	Channel Type	Cali. Low	Cali. High	Min Value	Mean Value	Max Value	Span	Unit	Description
#0	Thermistor	0	0	21.98	22.11	22.24	0.26	°C	CH0
#1	20V	0	0	0.00	0.03	3.66	3.66	mV	CH1
#2	20V	0	0	0.00	0.00	0.00	0.00	mV	CH2
#3	5V	0	0	3.05	5.40	9.23	6.18	mV	CH3
#4	5V	0	0	3.05	5.55	9.23	6.18	mV	CH4
#5	5V	0	0	3.05	5.55	9.23	6.18	mV	CH5

The first row specifies the serial number, the description and the filename of the plot.

Statistics: [S/N: 0101101203] New Logger (C:\SiteViewFiles\SN0101101203-2010-10-13-14-31-46.svf)

The second and the third rows specify the logger type, sampling interval, start and end time and the logging duration, total data points per channel.

Logger Type	Sampling interval	Start	End	Duration	Data Points
Site-Log LPV-1	5 Seconds	13/10/2010 2:22:43 PM	13/10/2010 2:31:43 PM	0 Hours 9 Minutes 0 Seconds	872 Readings (109 Readings/Channel)

The fourth and the fifth rows specify the start and end time, duration and data points for the zoomed section:

Zoomed Section	Zoom Start	Zoom End	Duration	Data Points
	13/10/2010 2:22:43 PM	13/10/2010 2:31:43 PM	0 Hours 9 Minutes 0 Seconds	872 Readings (109 Readings/Channel)

Then the remaining rows specify the channel properties such as channel index, channel type, calibration information, minimum, maximum, mean and span values for the zoomed section, unit and description of the channel:

Channels	Channel Type	Cali. Low	Cali. High	Min Value	Mean Value	Max Value	Span	Unit	Description
#0	Thermistor	0	0	21.98	22.11	22.24	0.26	°C	CH0
#1	20V	0	0	0.00	0.03	3.66	3.66	mV	CH1
#2	20V	0	0	0.00	0.00	0.00	0.00	mV	CH2
#3	5V	0	0	3.05	5.40	9.23	6.18	mV	CH3
#4	5V	0	0	3.05	5.55	9.23	6.18	mV	CH4
#5	5V	0	0	3.05	5.86	9.23	6.18	mV	CH5
#6	5V	0	0	0.00	2.83	6.10	6.10	mV	CH6
#7	5V	0	0	0.00	2.80	6.10	6.10	mV	CH7

Axis

Axis View is displayed as the third tab page:

Dataset/Plot Settings		 Apply	View Layout	 Horizontal View	 Vertical View	 Special characters						
Dataset	Statistics	Axis	Line	Plot Title	Legend	Others						
Description	Visible	Scale	Min Value	Max Value	Unit	Decimal Place	Alarm Zoon Display Options	Low Alarm	Color	High Alarm	Color	Safe Zoon Color
Temperature (°C)	☒	Auto	0	10	Celsius	2	Hide Both Alarm Zoons	1171.95	Blue	-122.07	Blue	Green
Voltage DC (mV)	☒	Auto	0	10	MilliVolt	2	Hide Both Alarm Zoons	0.00	Red	0.00	Red	Green

Description:

Specifies the description of the axis.

Visible:

Specifies if this axis will be displayed or hidden.

Scale:

Specifies if the scale of the axis will be automatic or manual.

Min Value/Max Value:

Specifies the scale range of the axis if the Scale was set to manual.

Unit:

Specifies what unit will be applied to the axis.

Decimal Place:


Specifies how many decimal places will be used by the axis.

Alarm Zone Display Options:

Specifies how to display the alarm zoon and safe zone. Available options are:

Hide Both Alarm Zones
 Show Both Alarm Zones
 Show Low Alarm Zone
 Show High Alarm Zone
 Show Safe Zone

If Low Alarm = 25, High Alarm = 28, the following figure shows the safe zone between the low alarm and the high alarm:



Low Alarm:

Specifies the low alarm value.

Color:

Specifies the color for the low alarm zone.

High Alarm:

Specifies the high alarm value.

Color:

Specifies the color for the high alarm zone.

Safe Zoon Color:

Specifies the color for the safe zone.

Line

Line View is displayed as the fourth tab page:

Dataset/Plot Settings													
Dataset/Plot Settings			Apply	View Layout		Horizontal View	Vertical View	Special characters					
Dataset		Statistics	Axis	Line	Plot Title	Legend	Others						
Index	Visible	Description	Equation	Cali. Low	Cali. High	Width	Color	Style	Point Symbol	Symbol Size	Fill Below-Line	Fill Color	Action
0	☒	CH0	Temperature (Temperature)	0	0	1	Blue	—	None	7	☐	Blue	
1	☒	CH1	VoltageDC (VoltageDC)	0	0	1	Red	—	None	7	☐	Red	
2	☒	CH2	VoltageDC (VoltageDC)	0	0	1	Green	—	None	7	☐	Green	
3	☒	CH3	VoltageDC (VoltageDC)	0	0	1	Black	—	None	7	☐	Black	
4	☒	CH4	VoltageDC (VoltageDC)	0	0	1	Purple	—	None	7	☐	Purple	
5	☒	CH5	VoltageDC (VoltageDC)	0	0	1	Magenta	—	None	7	☐	Magenta	
6	☒	CH6	VoltageDC (VoltageDC)	0	0	1	Pink	—	None	7	☐	Pink	
7	☒	CH7	VoltageDC (VoltageDC)	0	0	1	Orange	—	None	7	☐	Orange	

Index:

Specifies the index of the plot line.

Visible:

Specifies if the line will be visible or hidden.

Description:

Specifies the description (shows in the legend) of the line.

Equation:

Specifies what equation the line will use for data conversion.

Cali. Low/Cali. High:

Specifies the calibration values will be used for data adjustment.

Width:

Specifies the width of the line.

Color:


Specifies the color of the line.

Style:

Specifies the style of the line.

Point Symbol:


Specifies what symbol will be used by the data point. An example of plus symbol looks like this:

**Symbol Size:**

Specifies the size of the point symbol.

Fill Below-Line:

Specifies if the section underneath the line will be filled with color:



Fill Color:

Specifies the color to fill the Below-Line section.

Action:

If you have added a custom line or custom channel, this field will have a **delete** button allows removing the custom line or channel.

Color	Style	Point Symbol	Action
		None	delete
		None	delete
		None	delete

Plot Title

Plot Title is displayed as the fifth tab page.

Dataset/Plot Settings
☒ Apply
View Layout
Horizontal View
Vertical View
Special

Dataset
Statistics
Axis
Line
Plot Title
Legend
Others

Text: ☒ Visible

Font:

Color:

Text:

Specifies the text of the title.

Font:

Specifies the font of the title.

Color:


Specifies the color of the title.

Visible:

Specifies if the title will be displayed or hidden.

Legend

Legend is displayed as the sixth tab page.



Font:

Specifies the font of the legend.

Location:

Specifies the location the legend will be sit. Available options are:


Top,
Left,
Right,
Bottom,
Inside Top-Left,
Inside Top-Right,
Inside Bottom-Left,
Inside Bottom-Right,
Float,
Top Center,
Bottom Center,
Top Flush Left,
Bottom Flush Left.

Visible:

Specifies if the legend will be displayed or hidden.

Others

Others is displayed as the last tab page:



Plot Pane:

Out Area Back Color:

Specifies the color of the plot pane.

Gradient: (Out Area)

Specifies if the color gradient will be applied to the out area color.

Plot Area Back Color:

Specifies the color of the plot area.

Gradient: (Plot Area)

Specifies if the color gradient will be applied to the plot area color.

Axis and Grid:

Grid Color:

Specifies the color of the grid.


Grid Visible:

Specifies if the grid will be displayed or hidden.

Axis Font:

Specifies the font for all axes.

Alarm Center



Connections

Specify which connections Alarm Center is monitoring on. You may check any entry to enable the connection or uncheck the entry to not receive alarm notification from that connection.

Alarm Events

Specify the received alarm events from monitored loggers.

Date/Time:

Specify the date and time when the alarm was reported.

Event:

Specify what event the logger reported: "Report Alarm" or "Alarm Cleared".

Channel:

Specify which channel has alarm.

Logger:

Specify the identification of the alarmed logger.

Sequence Number:

Specify the sequence number of the alarmed logger. When alarm state is changed the sequence number is increased.

Alarm State:

Specify the detailed information of the event for each channel.

Action:

Specify the action Alarm Center has taken upon the received event.

Log

Display the information Alarm Center interacts with other entities.

Buttons**Settings:**

Click to display Settings dialog for editing the settings.

Close:

Click to close Alarm Center dialog.

Stop Music:

Click to stop the music if the music is playing.

Help:

Click to display related Help.

CHAPTER 17 - EQUATION REFERENCES

C# Language Source Code References

Basic data types

Name	Description	Size (byte)
int	Signed Integral type	4
uint	Unsigned integral type	4
short	Signed short integral type (-32768 to + 32767)	2
ushort	Unsigned short integral type (0 to 65535)	2
long	Signed long integral type	8
ulong	Unsigned long integral type	8
double	64-bit floating point type	8
float	32-bit floating point type	4
String/string	A sequence of zero or more Unicode characters.	
Byte/byte	0 – 255 integral value	1
Char/char	Unicode character	2
Boolean/bool	Boolean type (true or false)	
enum	Enumeration type	
Object/object	Any type	

Basic Operators

Name	Description	Example
.	The dot operator (.) is used for member access. The dot operator specifies a member of a type or namespace	Class1.y = 1;
()	Parentheses specify the order of operations in an expression. Parentheses are used to specify casts, or type conversions	Y = (1 + 2) / 3; double value1 = 1.5; int value2 = (int) value1;
[]	Square brackets ([]) are used for arrays, indexers, and attributes. They can also be used with pointers.	Int [] array = new int[5];
++	The increment operator (++) increments its operand by 1. The increment operator can appear before or after its operand:	Int i = 0; I++;
--	The decrement operator (--) decrements its	Int I = 0;

	operand by 1.	i--;
new	Used to create objects and invoke constructors	Class1 c = new Class1();
+	The + operator can function as either a unary or a binary operator. Unary + operators are predefined for all numeric types. The result of a unary + operation on a numeric type is just the value of the operand. Binary + operators are predefined for numeric and string types. For numeric types, + computes the sum of its two operands. When one or both operands are of type string, + concatenates the string representations of the operands.	<pre>Int a; a = 5 + 5;</pre>
-	The - operator can function as either a unary or a binary operator.	<pre>Int a; a = 5 - 5;</pre>
!	The logical negation operator (!) is a unary operator that negates its operand. It is defined for bool and returns true if and only if its operand is false .	<pre>bool val = true; if(!val) { }</pre>
~	The ~ operator performs a bitwise complement operation on its operand, which has the effect of reversing each bit	<pre>byte a = 0x10; a = ~a;</pre>
&	The & operator can function as either a unary or a binary operator. The unary & operator returns the address of its operand. Binary & operators are predefined for the integral types and bool. For integral types, & computes the logical bitwise AND of its operands. For bool operands, & computes the logical AND of its operands; that is, the result is true if and only if both its operands are true.	<pre>byte a = 0x10; a = a & 0x01;</pre>
*	The multiplication operator (*), which computes the product of its operands. Also, the dereference operator, which allows reading and writing to a pointer.	<pre>int a = 1; a = 5 * 10;</pre>
/	The division operator (/) divides its first operand by its second. All numeric types have predefined division operators.	<pre>int a; a = 10 / 5;</pre>
%	The modulus operator (%) computes the remainder after dividing its first operand by its second. All numeric types have predefined modulus operators.	<pre>int a ; a = 10 % 5;</pre>
<<	The left-shift operator (<<) shifts its first operand left by the number of bits specified by its second operand.	<pre>int a = 10; a <<= 8;</pre>
>>	The right-shift operator (>>) shifts its first operand	<pre>int a = 10;</pre>

	right by the number of bits specified by its second operand.	<code>a >>= 1;</code>
<code><</code>	All numeric and enumeration types define a "less than" relational operator (<code><</code>) that returns true if the first operand is less than the second, false otherwise.	<code>int a = 1; if(a < 2) { }</code>
<code>></code>	All numeric and enumeration types define a "greater than" relational operator (<code>></code>) that returns true if the first operand is greater than the second, false otherwise.	<code>int a = 1; if(a > 2) { }</code>
<code><=</code>	All numeric and enumeration types define a "less than or equal" relational operator (<code><=</code>) that returns true if the first operand is less than or equal to the second, false otherwise.	<code>int a = 1; if(a <= 2) { }</code>
<code>>=</code>	All numeric and enumeration types define a "greater than or equal" relational operator, <code>>=</code> that returns true if the first operand is greater than or equal to the second, false otherwise.	<code>int a = 1; if(a >= 2) { }</code>
<code>==</code>	For predefined value types, the equality operator (<code>==</code>) returns true if the values of its operands are equal, false otherwise. For reference types other than string, <code>==</code> returns true if its two operands refer to the same object. For the string type, <code>==</code> compares the values of the strings.	<code>int a = 1; if(a == 2) { }</code>
<code>!=</code>	The inequality operator (<code>!=</code>) returns false if its operands are equal, true otherwise. Inequality operators are predefined for all types, including string and object. User-defined types can overload the <code>!=</code> operator.	<code>int a = 1; if(a != 2) { }</code>
<code>&</code>	The <code>&</code> operator can function as either a unary or a binary operator. Binary <code>&</code> operators are predefined for the integral types and bool . For integral types, <code>&</code> computes the logical bitwise AND of its operands. For bool operands, <code>&</code> computes the logical AND of its operands; that is, the result is true if and only if both its operands are true .	<code>int a = 1; a = a & 0x03;</code>
<code>^</code>	Binary <code>^</code> operators are predefined for the integral types and bool . For integral types, <code>^</code> computes the bitwise exclusive-OR of its operands. For bool operands, <code>^</code> computes the logical exclusive-or of its operands; that is, the result is true if and only if exactly one of its operands is true .	<code>byte a = 0xf8; a = a ^ 0x3f; (a = 0xc7)</code>

	Binary operators are predefined for the integral types and bool . For integral types, computes the bitwise OR of its operands. For bool operands, computes the logical OR of its operands; that is, the result is false if and only if both its operands are false .	byte a = 1; a = a 2; (a = 3)
&&	The conditional-AND operator (&&) performs a logical-AND of its bool operands, but only evaluates its second operand if necessary.	byte a = 1, b = 0; if(a == 1 && b == 0) { }
	The conditional-OR operator () performs a logical-OR of its bool operands, but only evaluates its second operand if necessary.	byte a = 1, b = 0; if(a == 1 b == 0) { }
=	The assignment operator (=) stores the value of its right-hand operand in the storage location, property, or indexer denoted by its left-hand operand and returns the value as its result. The operands must be of the same type (or the right-hand operand must be implicitly convertible to the type of the left-hand operand).	byte a = 1, b; b = a;
+=	The addition assignment operator.	int a = 1; a += 2; (a = 3)
-=	The subtraction assignment operator.	int a = 1; a -= 1; (a = 0)
*=	The binary multiplication assignment operator.	int a = 2; a *= 5; (a = 10)
/=	The division assignment operator.	int a = 20; a /= 5; (a = 4)
%=	The modulus assignment operator.	int a = 20; a %=2; (a = 0)
&=	The AND assignment operator.	byte a = 0x0f; a &= 0xf0; (a = 0)
=	The OR assignment operator.	byte a = 0x0f; a = 0xf0; (a = 0xff)

<code>^=</code>	The exclusive-OR assignment operator.	byte a = 0x0f; a ^= 0xf0; (a = 0xff)
<code><<=</code>	The left-shift assignment operator.	byte a = 0x0f; a <<= 4; (a = 0xf0)
<code>>>=</code>	The right-shift assignment operator.	byte a = 0x0f; a >>= 1; (a = 0x07)

Basic Math Methods

Name	Description	Example
Abs	Returns the absolute value of a specified number	int a = -10; a = Math.Abs(a);
Acos	Returns the angle whose cosine is the specified number.	
Asin	Return the angle whose sine in the specified number.	
Atan	Returns the angle whose tangent is the specified number.	
Cos	Returns the cosine of the specified angle.	
Exp	Return e raised to the specified power.	double a ; a = Math.Exp(1);
Floor	Returns the largest integer less than or equal to the specified number.	double a; a = Math.Floor(2);
Log	Returns the logarithm of a specified number.	double a; a = Math.Log(2);
Log10	Returns the base 10 logarithm of a specified number.	double a; a = Math.Log10(2);
Max	Returns the larger of two specified numbers.	int a = Math.Max(1,2);
Min	Returns the smaller of two numbers.	int a = Math.Min(1, 2);
Pow	Returns a specified number raised to the specified power.	double a = Math.Pow(10,2);
Round	Rounds a value to the nearest integer or specified number of decimal places.	
Sign	Returns a value indicating the sign of a number.	
Sin	Returns the sine of the specified angle.	
Sinh	Returns the hyperbolic sine of the specified number.	
Sqrt	Returns the square root of a specified	

	number.	
Tan	Returns the tangent of the specified angle.	
Tanh	Returns the hyperbolic tangent of the specified angle.	
Truncate	Calculates the integral part of a number.	

Accessible Objects

When you write a custom equation, the following objects can be accessed:

For Custom Equation:

Name	Description
this	Current logger object.
Channels	The collection of all channels.
Channels[x]	The channel object specified by the index x.
this.Channels	Same as Channels.
this.CurrentChannel	The current channel object.
this.Description	The description of the current logger object.
this.StartTime	The data start time in DateTime data type.
this.EndTime	The data end time in DateTime data type.
this.NumberOfSamples	The total number of samples the logger contain.
this.SampleInterval	The sampling interval in second the logger has.
this.SerialNumber	The serial number of the logger in string data type.
this.Channel[x].CaliLow	The low calibration value of the specified channel.
this.Channels[x].CaliHigh	The high calibration value of the specified channel.
this.Channels[x].ChannelHighScale	The high scale value of the specified channel.
this.Channels[x].ChannelLowScale	The low scale value of the specified channel.
this.Channels[x].ChannelType	The channel type of the specified channel.
this.Channels[x].Description	The description of the specified channel.
this.Channels[x].DigitValue	The digital value of the specified channel.
this.Channels[x].Enabled	If the specified channel is enabled or disabled.
this.Channels[x].Index	The index of the specified channel.
this.Channels[x].Measurement	The physical measurement of the specified channel.

For Custom-Line Equation:

Name	Description
this	Current logger object.
Lines	The collection of all lines.
Lines[x]	The line object specified by the index x.
this.Description	The description of the current logger object.
this.StartTime	The data start time in DateTime data type.
this.EndTime	The data end time in DateTime data type.
this.NumberOfSamples	The total number of samples the logger contain.

this.SampleInterval	The sampling interval in second the logger has.
this.Linesl[x].Value	The physical measurement of the specified line.

Equation Examples

Dew Point Temperature

The dew point temperature is the temperature at which the air can now longer hold all of its water vapour, and some of the water vapour must condense into liquid water.

Because dew point temperature can be derived from the relative humidity and the temperature readings, the following equation can be used for the dew point temperature measurement.

This equation is for Site-Log LRHT-1/2 data logger. In the Logger Configuration dialog, add a new custom channel to the logger and apply this equation to the channel.

```
// A custom equation for dew point temperature.
// Condition:
//     channel#0 of the logger must be for temperature.
//     channel#1 of the logger must be for relative humidity.
//     both channels must be enabled.
public double DewPointEquation(double Input)
{
    double logEx, dew_point, rh, temperature;
    temperature = Channels[0].Measurement;
    rh = Channels[1].Measurement;

    logEx = 0.66077 + 7.5 * temperature / (237.3 + temperature) +
(Math.Log10(rh) - 2);
    dew_point = (logEx - 0.66077) * 237.3 / (0.66077 + 7.5 - logEx);
    return dew_point;
}
```

Carbon Dioxide Transmitter (0 – 5000 PPM)

This equation is for a CO2 transmitter with the following specifications:

Measurement Range: 0– 5000 PPM of CO2
Output 0 – 10 VDC

This equation can be used on 0 – 10 VDC or 0 – 20 VDC channel.

```
//A custom equation for CO2 transmitter
// Transmitter specifications
//     Measurement Range: 0 - 5000 PPM
//     Output: 0 - 10 VDC
public double CO2Equation(double Input)
{
    double output;
    output = 5000 * Input / 10;
    return output;
}
```

External Thermistor

This equation can be used for any of the external channel of LRTH-1 data logger. The logger has seven external thermistor channels that can accommodate any kind of thermistors.

The key parameters in this equation are a, b and c coefficients that can be obtained from the thermistor manufacturer. You may change them based on the thermistor type you are using.

```
//A custom equation for thermistor temperature
public double ExtThermistor2(double Input)
{
    //digit value must be 65534
    double dig_range = 65535;
    //load resistor must be 10000 ohm
    double load_resistor = 10000;
    double a, b, c, lgr, Output = 0;
    //different thermistor will have different a, b, c values
    a = 0.001028444; ;
    b = 0.000239244;
    c = 0.000000156;

    Output = CurrentChannel.DigitValue;

    if (Input >= dig_range)
        Output = dig_range - 1;
    if (Input < 1)
        Output = 1;

    double Rt = load_resistor * Output / (dig_range - Output);

    lgr = Math.Log(Rt);

    Output = 1f / (a + b * lgr + c * lgr * lgr * lgr) - 273.15f;

    return Output;
}
```

Previous Hour Average

This equation can be used to calculate the averaged value for the previous hours. It can be easily modified for a day or other time frame averages.

```
DateTime CurrentTime;
bool FirstIn = true;
int HourIndex = 0;
double AverageValue = 0;
double SumValue = 0;
int PreviousHour = 0;
//Equation to calculate the average value of the previous hour
public double HourAverage(double Input)
{
    //first time get in this function, initialize some variables.
```

```


if (FirstIn)
{
    FirstIn = false;
    SumValue = Input;
    AverageValue = Input;
    PreviousHour = this.StartTime.Hour;
    CurrentTime = this.StartTime;
}
else
{
    CurrentTime = CurrentTime.AddSeconds(this.SampleInterval);
    if (CurrentTime.Hour != PreviousHour)
    {
        PreviousHour = CurrentTime.Hour;
        AverageValue = SumValue / HourIndex;
        SumValue = 0;
        HourIndex = 0;
    }

    SumValue += Input;
}

HourIndex++;
//Average value of the previous hour.
//Note: the first hours value is always the first reading
return AverageValue;
}

```

The following figure illustrates the result after the above equation is applied:



Note the red curve is the hour average of the black curve.

APPENDIX

Modem AT Command Set

The following table summarizes the basic AT command set for Hayes compatible dial-up modems. Defaults are shown in boldface.

Command	Function
AT	Attention - this precedes all commands except A/ and +++
A/	Execute previous command - does not require a <CR>
A	Causes the modem to go off hook. If a call is coming in, the modem will try to answer it. The procedure for answering a call is a short silence and then an answer tone. Sending a character to the modem during this procedure will abort the answer sequence. The amount of time the modem will wait for a carrier is programmable by modifying the S7 register.
B0	Select CCITT V.22 (1200 bps)
B1	Select Bell 212A (1200 bps)
B2	Select CCITT V23 - Originate mode will transmit data at 75 bps and receive data at 1200 bps. Answer mode will transmit data at 1200 bps and receive data at 75 bps. The command N0 (disable auto mode) must be selected.
D	D alone will take the modem off-hook and wait for a dial tone. (see X command for exceptions). The length of time to wait for a dial tone before dialing is programmable in register S6.
Dmn	ATDmn will dial a phone number where m is the modifier: L, W, ,, ;, @, or S. It will dial the telephone number n.
L	Dial last number
W	Wait for dial tone. If you have selected X0 or X1 (disable dial tone detection), then you can use this modifier to override that setting.
,	Pause during dial. This amount of time to pause is determined in register S8.
;	Return to command mode after dialing. It does not wait for carrier or hang up.
@	Wait for 5 seconds of silence. This is used to access systems that do not provide a dial tone.
!	Hook flash. Causes the modem to go on-hook for 0.5 seconds. This is used in PBX systems and for voice features like call waiting.
S=(0-9)	Dials a stored number. Up to ten numbers can be stored, and the addresses are from 0 to 9. To store a number into one of these addresses, use the &Z command.
E0	Commands issued to the modem are not echoed to the local terminal. This only matters in the command mode. It does not affect the modem's ability to send response codes.

E1	Commands are echoed to the local terminal.
H0	Force modem on-hook (hang-up)
H1	Force modem off-hook (to answer or dial).
I0	Return numeric product code
I1	Return hardware variation code
I2	Report internal code
I3	Report software revision number
I4	Report product feature listing
L0	Speaker volume zero
L1	Speaker volume low
L2	Speaker volume low
L3	Speaker volume low (Hardware currently limits volume adjustment to on/off)
M0	Speaker always off
M1	Speaker on until carrier detected
M2	Speaker always on
M3	Speaker on during answering only
N0	Disable auto-mode. This forces the modem to connect at the speed specified in register S37
N1	Enable auto-mode. The modem will answer at the highest available line speed and ignore any ATBn command.
O0	Return to data mode. If you have entered the command mode using the time independent escape sequence, this will put you back in data mode without going on-hook.
O1	Retrain the modem. If the line condition has changed since the original connection, retraining the modem will cause it to reconnect at the most efficient speed for the current line condition.
P	Pulse dialing allows the modem to work on telephone networks where one is not supported. Pulse and tone dialing cannot be mixed on the same command line.
Q0	Enable response to DTE.
Q1	Disable response to DTE. The modem does not respond to the terminal. Issuing a command will not produce a response (unless the command is something like ATZ, which will restore this setting to default).
Sn	Set default S-register. Any subsequent = or ? commands will modify the default S register.
Sn=m	Set register n to value m
Sn?	Return the value of register n
T	Tone dialing - Pulse and tone dialing can not be mixed on the same command line.
V0	Result codes will be sent in numeric form. (See the result code table)

V1	Result codes will be sent in work form. (See the result code table.)
W0	Report DTE speed only. After connection, there will be no message about what Error Correction or Data Compression protocol is in use.
W1	Report DCE speed, Error Correction/Data Compression protocol, and DTE speed
W2	Report DCE speed only
X0	Send OK, CONNECT, RING, NO CARRIER, ERROR and NO ANSWER. Busy and dial tone detection are disabled.
X1	Send X0 messages and CONNECT speed
X2	Send X1 messages and NO DIAL TONE.
X3	Send X2 messages and BUSY and RING BACK. Dial tone detection is disabled.
X4	Send all responses.
Y0	Disable long space disconnect.
Y1	Enable long space disconnect; with error correction, hang up after sending 1.6 second long space; without error correction, hang up after 4 second long space.
Z0	Reset modem to profile 0
Z1	Reset modem to profile 1
+++	This is the default escape sequence. Transfers the modem from data mode to command mode. Must be preceded by at least 1 second of no characters and followed by one second of no characters. O0 (ATO0 or ATO) returns the modem to data mode.
=n	Sets the value of the default S register.
&	Ampersand commands
&C0	Force data carrier detect (DCD) on
&C1	DCD follows remote carrier
&D0	DTR is assumed on
&D1	DTR drop causes modem to go back to command mode without disconnecting
&D2	DTR drop causes modem to hang up
&D3	DTR drop causes modem to initialize; &Y determines which profile is loaded.
&F	Load factory profile
&K0	Disable flow control
&K3	Enable RTS/CTS flow control
&K4	Enable XON/XOFF flow control
&K5	Enable transparent software flow control
&K6	Enable both RTS/CTS and XON/XOFF flow control
&P0	Selects 33%-67% make/break ratio at 10 pulses per second.
&P1	Selects 33%-67% make/break ration at 20 pulses per second
&P2	Selects 33%-61% make/break ration at 10 pulses per second

&P3	Selects 33%-61% make/break ration at 20 pulses per second
&S0	Force DSR on
&S1	DSR on at the start of handshaking and off after carrier loss
&T0	Terminate test
&V0	Display active profile
&V1	Display stored profiles
&V2	Display stored telephone numbers
&W0	Save active profile to profile 0
&W1	Save active profile to profile 1
&Y0	Use profile 0 on powerup
&Y1	Use profile 1 on powerup
&Zn=m	Save telephone number (up to 36 digits) into memory location n (0-9)
%	Percent commands
%A	Default is set to each country encoding law. For example, for USA %A is 0, for Germany %A is 1.
%A0	Mu-law encoding
%A1	A-law encoding
%C0	Disable data compression
%C1	Enable MNP5 compression
%C2	Enable V.42bis compression
%C3	Enable both V.42bis and MNP5
%E0	Disable auto-retrain
%E1	Enable auto-retrain
%E2	Enable auto-retrain and fallback
%E3	Enable auto-retrain and fast hang up
%L	Report received signal level in -dBm
%N0	Dynamic CPU loading disabled
%N1	Dynamic CPU loading not to exceed 10%
%N2	Dyanmic CPU loading not to exceed 20%
%N3	Dyanmic CPU loading not to exceed 30%
%N4	Dyanmic CPU loading not to exceed 40%
%N5	Dyanmic CPU loading not to exceed 50%
%N6	Dyanmic CPU loading not to exceed 60%
%N7	Dyanmic CPU loading not to exceed 70%
%N8	Dyanmic CPU loading not to exceed 80%

%N9	Dyanmic CPU loading not to exceed 90%
%Q	Report line signal quality
\	Backslash commands
\A0	64-character max MNP block size
\A1	128-character max. MNP block size
\A2	192-character max. MNP block size
\A3	256-character max. MNP block size
\Bn	In non-error correction mode, transmit break in 100 ms units (1-9 with default 3)
\G0	Disable XON/XOFF flow control (modem to modem)
\G1	Enable XON/XOFF flow control (modem to modem)
\Kn	Define break type
\L0	Use stream mode for MNP
\L1	Use interactive block mode for MNP
\N0	Normal mode; speed control without error correction
\N1	Plain mode; no speed control and no error correction
\N2	Reliable mode
\N3	Auto-reliable mode
\N4	LAPM error correction only
\N5	MNP error correction only
*	Asterisk commands
*Q0	Send the "CONNECT xxxx" result codes to the DTE when an invalid TIES escape sequence is detected after the "OK" response has already been sent
*Q1	Does NOT send the "CONNECT xxxx" result codes to the DTE when an invalid TIES escape sequence is detected after the "OK" response has already been sent
S Registers	
Reg. 0	Rings to auto-answer. Sets the number of rings required before the modem answers. 0 setting disable auto-answer. Range is 0-255 rings. Default is 0 for auto-answer disabled.
Reg. 1	Ring counter. Counts the number of rings before the modem answers. Range is 0-255 rings. Default is 0.
Reg. 2	Escape character. Defines the character used for the three-charracter escape code sequence. 0 setting disables the escape code character. Range is 0-127. Default is 43 (+)
Reg. 3	Carriage return character. Defines the character for carriage return. Range is 0-127. Default is 13 (carriage return).
Reg. 4	Line feed character. Defines the character for the line feed. Range is 0-127. Default is 10 (line feed).
Reg. 5	Backspace character. Defines the character for the backspace. Range is 0-127. Default is

	8 (backspace)
Reg. 6	Wait before dialing. Sets the length of time to pause after off-hook before dial. Range is 2-255 seconds. Default is 2 seconds.
Reg. 7	Wait for carrier after dialing. Sets the length of time that the modem waits for a carrier from the remote modem before hanging up. Range is 1-255 seconds. Default is 50 seconds.
Reg. 8	Pause time for dial delay. Sets the length of time to pause for the pause dial modifier ", ". Range is 0-255 seconds. Default is 2 seconds.
Reg. 9	Carrier detect response time. Defines the length of time a signal is detected and qualified as a carrier. Range is 1-255 tenths of a second. Default is 6 (0.6 seconds)
Reg. 10	Lost carrier hang up delay. Sets the length of time the modem waits before hanging up for a carrier loss. Range is 1-255 tenths of a seconds. Default is 14 (6 seconds ????)
Reg. 11	DTMF speed control. Sets the length of tone and the time between tones for the tone dialing. Range is 50-255 milliseconds. Default is 95 milliseconds.
Reg. 12	Escape Prompt Delay (EPD) timer. Sets the time from detection of the last character of the three character escape sequence until the "K" is returned to the DTE. Range is 0-255 fiftieths of a second. Default is 50 (1 second)
Reg. 13	Reserved
Reg. 14	Reserved
Reg. 15	Reserved
Reg. 16	Reserved
Reg. 17	Reserved
Reg. 18	Test timer. Sets the length of loopback test. Range is 0-255 seconds. Default is 0 (disable timer)
Reg. 19	Reserved
Reg. 20	Reserved
Reg. 21	Reserved
Reg. 22	Reserved
Reg. 23	Reserved
Reg. 24	Reserved
Reg. 25	Delay to DTR. Sets the length of time the modem ignores DTR before hanging up. Range is 0-255 hundredths of a seconds. Default is 5 (0.05 seconds)
Reg. 26	Reserved
Reg. 27	Reserved
Reg. 28	Reserved
Reg. 30	Disconnect inactivity timer. Sets the length of time allowed for inactivity before the connection is hung up. Range is 0-255 in minutes. Default is 0 (disabled)
Reg. 32	XON character. Sets the value of XON character. Range is 0-255. Default is 17

Reg. 33	XOFF character. Sets the value of XOFF character. Range is 0-255. Default is 19.
Reg. 34	56k data rate (bit-rate). Sets the maximum bit rate for 56K. Range is 0-32. Bit rate = $32000\text{bps} + S34 * 2000\text{bps}$. V.34 data rate (bit-rate). Sets the maximum bit rate for V.34. Range is 0-8 (2400 baud), 1-10 (3000 baud), 1-11 (3200 baud), 1-13 (3429 baud) Bit rate = $((S34)+1) * 2400\text{bps}$. Default is 13 (33600 bps)
Reg. 36	Reserved
Reg. 37	Line connection speed. 0-Attempt to connect at the highest speed. 3-Attempt to connect at 300 bps. 4-Attempt to connect at 1200 bps. 6-Attempt to connect at 2400 bps. 7-Attempt to connect at 4800 bps. 8-Attempt to connect at 7200 bps. 9-Attempt to connect at 9600 bps. 10-Attempt to connect at 12000 bps. 11-Attempt to connect at 14400 bps. 12-Attempt to connect at V.34. 13-Attempt to connect at 56K, Default is 0.
Reg. 38	Delay before forced hang-up. Sets the delay to hang up after the disconnecting command is received. Range is 0-255 seconds. Default is 20 seconds.