

Users manual



Ht60B

PID controller

1 Important

Ht60B is a temperature / process controller intended for the built-in to panel. The format of controller is 96 x 48 mm (1/8 DIN).

The scope of the controller:

- controlling of stp value,

The controller can be equipped with 1 input:

- temperature (thermocouples + rtd sensor -Pt100),
- process (0-20mA, 4-20mA, 0-5V, 1-5V, 0-10V),

2 outputs:

- control (heating control or cooling control),
- alarm (alarm or signalling of temperature exceeding)

and communication lines:

- RS-232, protocol MODBUS RTU,
- EIA-485, protocol MODBUS RTU.

The controller is easy to run and operate. The parameters set can be locked and thus preventing from deleting by a user.

User manual for the controller Ht60B is divided into the particular chapters. When you install and put it into operation we recommend proceeding in the following way:

If you are a final user, the controller is in the default setting by the supplier

If you are a final user, you will get the device in the customized setting and you can view and change only the parameters that you need for your own work on the controller.

If you are a new user of the device, focus on the following chapters:

- [Basic terms](#) here it is explained the key functions, displays, and so on....
- [Basic mode](#) the description of basic mode of controller.
- [User level](#), in this chapter you will find the information on the parameters accessible for a user and the information on the basic features of the controller.

If you are carrying out the complete installation and setting of the controller

In this case you proceed in accordance with the following chapters:

- [Installation](#), in this chapter it is described how to build in a controller into panel.
- [Principals of installation](#), we recommend you to observe the guidelines described in this chapter.
- [Wiring](#), the description for wiring of the controller.
- [Putting into operation](#), at first power-up you enter the initial menu in which you can configure and set the most important parameters of controller.

According to the procedure you will perform installation, wiring and basic setting of controller. You can find out more details on the scope of the controller and its operation in the following chapters.


For the users who have the controller completely set, we recommend to perform the setting of all the parameters in **service level**, menu **CONF**. Initial password for the entry to service level is set to **995**.

2 Basic Terms

To avoid problems in operation of device the user should be able to manage its operation, setting parameters, ...

Functions of indicators

On the front panel board you can see 2 displays, 2 control lights (LED diodes) for indicating a status of outputs. The device is set and configured via 3 key-buttons.



Function of key-buttons

The setting of parameters of the controller is performed via key-board. The function of each key-button is as follows:

-  key for setting and viewing of parameters of user, operation, configuration and service level. By pressing this key **you confirm the change in configured parameter** and the controller comes to another parameter.
-  key for decreasing a value of parameter. The value of parameter is either the figure or abbreviation composed of maximum 4 letters.
-  key for increasing a value of parameter.

2.1 Information and error messages

Information and error messages are only indicated in *basic mode*, see page [6](#).

Information messages, upper display

-  ... error of input sensor or input is not set.

Information messages, lower display

Information messages on lower display blink, they can be:

-  ... the controller is in manual operation, the output power is set by a user.
-  ... indication of ramp function.
-  ... starting autotuning of PID parameters for heating,  ,  , .
-  ... starting autotuning of PID parameters for cooling,  ,  , .


Error messages, lower display

If there is an error message indicated then the control outputs are switched OFF, the signal output is switched OFF, the alarm output is activated. The error messages blink on the lower display.

- **Err0** ... error in FLASH memory of program. Switch the controller OFF and ON again. If the problem persists, contact your supplier.
- **Err1** ... error in EEPROM memory for configuration and operation parameters. The troubleshooting error can be made by restarting of all parameters in *service level*. After restart it is necessary to set up all parameters again. This can be done only by an experienced user. If the trouble persists, contact your supplier.
- **Err3** ... error in A/D converter. It can be caused by electrical impulse at input, too low temperature and excessive humidity, Switch the controller OFF and ON again. If the problem persists, contact your supplier.


2.2 Overview of levels, menus

For the right function of the controller it is necessary to set up its parameters properly. For better understanding the parameters are sorted out to groups (levels and menus). Level is superior to menu, menu is a part of level (menu **out1**). The structure of sorting shows the following picture.



2.3 Basic mode

The controller is in **Basic mode** when powered up (the initial set-up must be performed, see page [23](#)). On upper display process value is shown, on lower display there is stp value.



- When in **manual operation** there is output power in % shown on lower display and heading **Man.**
- If there is any other heading on lower display, the controller is **not in basic mode**, parameters are set or viewed.
- Information and error messages are indicated only in **basic mode**.

Return to basic mode

- To return to **basic mode** press shortly the keys  .
- If there is no key pressed for 60 seconds, the controller itself returns to **basic mode**.

3 User level

User level is intended for the quick access to the most common parameters for a user.

To enter user level and to go through this level press the key .

To return from user level you must go through all the parameters or by pressing shortly the keys  .

You can configure freely the structure of user level:

- you can define which parameters will be in user level,
- you can define on which position these parameters will be placed,
- the parameters are displayed only in case that their showing has the meaning (e.g. the parameters of autotuning of the parameters for the control output are shown only in case that control output is set for PID controlling).

Overview of all the parameters and menus of user level

Display	Procedure
PCn1	Indicates the power in % of the control output 1.
A-M	Automatic – manual operation of the controller: • Auto, automatic operation is set. • Man, manual operation is set.
Aut	Starting / ending of autotuning/automatic setting of PID parameters: • oFF, autotuning /automatic setting of PID parameters are turned OFF. • on, starting of autotuning/automatic setting of PID parameters for heating or cooling (acc to the setting of the control output).
Pb1	Proportional band of the control output Range: 1 to 2499 °C.
It1	Integral value of the control output. Range: oFF , 0.1 to 99.9 minutes.
dE1	Derivative value of the control output. Range: oFF , 0.01 to 9.99 minutes.
hYS1	Hysteresis of the control output, this single parameter is set only for ON/OFF control. Range: 1 to 249 °C.
o2Lo	Low limit of signalling. Output is activated when process value is <i>lower</i> than the set signalling limit. Range: • -499 to o2hI °C.
o2hI	High limit of signalling. Output is activated when process value is <i>higher</i> than the set signalling limit. Range: • o2Lo to 2499 °C.

Setting of parameters and menus in user level

User level provides a user with the quickest access for viewing and setting of parameters. The list of the parameters that will be present and accessible for a user in user level, as well as their sequence, can be freely configured.

You will carry out the formation of user level in *configuration level*, menu **uSEr**.

Example how to create user menu:


You want to place on the 1st position in *user level* the parameter for starting autotuning **Aut**, on the 2nd high limit of alarm **o2hI**. Proceed as follows:

- Set the parameter **StP1** = **Aut**.
- Set the parameter **StP2** = **o2hI**.
- 3rd to 4th positions are not used, for parameters **StP3** and **StP4** set **no**.

You can view the result in *user level*


3.1 Controlling of stp value

When the controller maintains stp value, lower display shows stp value and upper display shows process value. Setting of stp value can be changed with the arrow-keys, the new stp value is edited after approx. 2 seconds from the last pressing of the key.



Ramp function

When the controller is powered up, rapid temperature changes appear. If this rapid increase in temperature is not wanted, you can control the ramp rate to stp value with the ramp function.




- Ramp function ensures the reaching stp value SP1 in the linear way.
- Ramp function is active only after the controller is turned on and it is ended by reaching stp value SP1.
- When ramp function is active, on lower display there is stp value SP1 and blinks **rAMP**.
- Ramp function is set in **configuration level**, menu **SYS**, parameter **rAMP** [°C/hour].
- If parameter **rAMP** = **OFF**, ramp function is switched OFF.

3.2 Automatic / manual operation of controller

Automatic operation of controlling requires the closed control loop. The user adjusts stp value and the controller regulates the output power that is supplied to system.

At **manual operation** the user adjusts the required output power.



Manual operation

Important:

- When in manual operation, the controller can not influence the output power that is set by a user. The behavior of the system is then fully under users control.
- When in manual operation, **Man** blinks on lower display.
- The controller remains in the chosen mode of operation even after the power interruption.
- In manual operation the zero output power is set after the power interruption.
- If the PID control is chosen, in manual operation the output power in percentage is set (0 – 100% for heating as well as for cooling)
- If ON/OFF switching is set, in manual operation the output power is set in 2 states (**OFF** ... the control output is switched OFF, **on** ... the control output is switched ON).

3.3 Parameters of the control output, PID controlling


The controller enables:

- PID controlling for heating,
- ON/OFF controlling for heating,
- PID controlling for cooling,
- ON/OFF controlling for cooling.

Heating, PID controlling

PID controlling for heating is set with the parameter **ot1** = **ht**. Parameter **ot1** finds itself in *configuration level*, menu **out1**.


In *operation level* you set PID parameters **Pb1**, **It1**, **dE1**.



Heating, ON/OFF switching

ON/OFF switching is set with the parameter **ot1** = **ht2**. Parameter **ot1** finds itself in *configuration level*, menu **out1**.


In *operation level* you set the hysteresis for ON/OFF switching, parameter **hys1**.



Cooling, PID controlling

PID controlling for cooling is set with the parameter **ot1** = **CL**. Parameter **ot1** finds itself in *configuration level*, menu **out1**.


In *operation level* you set PID parameters **Pb1**, **It1**, **dE1**.



Cooling, ON/OFF switching

ON/OFF switching for cooling is set with the parameter **ot1** = **CL2**. Parameter **ot1** finds itself in *configuration level*, menu **out1**.


In *operation level* you set the hysteresis for ON/OFF switching, parameter **hys1**.



3.4 Autotuning – automatic setting of PID parameters

The controller is fitted with the function that sets automatically PID parameters.

Autotuning of PID parameters can be started only when the controller maintains stp value SP1 (parameter **L-r** = **L**)



When in autotuning, on lower there are the following headings blinking:

- **Aut1** ... the controller adjusts parameters **Pb1**, **It1**, **dE1** for heating.
- **Aut2** ... the controller adjusts parameters **Pb1**, **It1**, **dE1** for cooling.


Procedure of starting autotuning:

- Autotuning you can start with parameter **Aut** = **on**. Parameter **Aut** you will find in *operation level*. The control output must be set for PID controlling.
- The controller explores the characteristics of system from switching ON/OFF on the output and determines optimal PID parameters. It can cause an overshoot.
- In the course of autotuning on lower display the information messages (**Aut1**, **Aut2**,) blink.
- After the autotuning is finished the parameters are edited and the information messages stop blinking. The controller is fitted with function for setting PID parameters for heating as well as for cooling.

4 Operation level

In operation level you can set parameters which are available to a user.

From basic mode to operation level you will get by pressing the keys   for 3 seconds. On lower display it appears **LEVL**, on upper display set **OPER** and confirm with the key . If **PASS** appears on lower display, the level is secured with the password. In this case set the right password with the arrow-keys and confirm with the key .




Menu of operation level

Display	Meaning
PCn1	Shows the actual power of the output 1 in %.
A-M	Automatic – manual operation of the controller: Auto, setting of automatic operation. Man, setting of manual operation.
Aut	Starting / turning OFF of autotuning of PID parameters: oFF, turning OFF of autotuning of PID parameters. on, starting of autotuning of PID parameters, heating or cooling (acc. to the setting of the control output).
Pb1	Proportional band of output 1. Range: 1 to 2499 °C.
It1	Integral value of output 1. Range: oFF , 0.1 to 99.9 minutes.
dE1	Derivative value of output 1. Range: oFF , 0.01 to 9.99 minutes.
hYS1	Hysteresis of output 1, this single parameter is set only for ON/OFF control. Range: 1 to 249 °C.
o2Lo	Low limit of signalling. Output is activated when process value is <i>lower</i> than the set signalling limit. Range: -499 to o2hI °C.
o2hI	High limit of signalling. Output is activated when process value is <i>higher</i> than the set signalling limit. Range: o2Lo to 2499 °C.

5 Configuration level

Configuration level is intended for the basic setting of the controller. In this level **the control output is turned OFF** and **alarm and signal outputs are deactivated**.

To enter configuration level from basic mode press both the keys   for 3 seconds. On lower display it appears **LEVL**, on upper display set with the arrow-keys **Conf** and confirm. If **PASS** appears on lower display, configuration level is secured with the password. In this case set the password via the arrow-keys and confirm again.



InP1, input setting

Display	Meaning
SEn1	Setting of input sensor ... thermal input: no ... input is not set. J ... thermocouple J, range -200 to 900°C. K ... thermocouple K, range -200 to 1360°C. t ... thermocouple T, range -200 to 400°C. n ... thermocouple N, range -200 to 1300°C. E ... thermocouple E, range -200 to 700°C. r ... thermocouple R, range 0 to 1760°C. S ... thermocouple S, range 0 to 1760°C. b ... thermocouple B, range 300 to 1820°C. C ... thermocouple C, range 0 to 2320°C. d ... thermocouple D, range 0 to 2320°C. rtd ... rtd sensor Pt100, range -200 to 800°C. Setting of input sensor ... process input: no ... input is not set. 0-20 ... 0 – 20 mA, range -499 to 2499 units. 4-20 ... 4 – 20 mA, range -499 to 2499 units. 0-5 ... 0 – 5 V, range -499 to 2499 units. 1-5 ... 1 – 5 V, range -499 to 2499 units. 0-10 ... 0 – 10 V, range -499 to 2499 units.
dEC1	Setting of decimal point for displaying – thermal input. 0 ... no decimal point. 0.0 ... 1 decimal point. Setting of decimal point for displaying ... process input: 0 ... no decimal point. 0.0 ... 1 decimal point. 0.00 ... 2 decimal points. 0.000 ... 3 decimal points.
CAL1	Correction of sensor. The set value is added to process value. Range: -999 to 999 °C.
rL 1	Together with the parameter rh 1 you also set the scale of displaying measured values for process input ranges. Range: -499 to rh 1.
rh 1	Together with the parameter rL 1 you also set the scale of displaying measured values for process input ranges. Range: rL 1 to 2499.

CoMM, communication line

Display	Meaning
CoMM	Setting of communication line: Mod ... the controller is set for the communication with PC, protocol MODBUS RTU.
bAud	Communication baudrate: 9.6 ... 9600 Bd. 19.2 ... 19200 Bd. 38.4 ... 38400 Bd. 57.6 ... 57600 Bd.
Addr	Address of the equipment. Range: 1 to 250.

out1, output 1

Display	Meaning
ot1	Function of the control output 1: ht ... heating control, PID controlling. ht2 ... heating control, ON/OFF switching. C1 ... cooling control, PID controlling. C12 ... cooling control, ON/OFF switching.
Ct1	Time cycle for switching of the output 1. Range: 1 to 200 seconds.

out2, output 2

Display	Meaning
ot2	Function of output 2: - oFF ... output 2 is turned OFF. - ALPr ... alarm output. - SGPr ... signalling output.
SI d2	The selection of active limits for alarm, signalling - both ... low and high limit is active. - hI ... high limit is active. - Lo ... low limit is active.

SYS, system parameters

Display	Meaning
SP1L	The limit of low range for stp value. Range: -499 to SP1h °C.
SP1h	The limit of high range for stp value. Range: SP1L to 2499 °C.
rAMP	Ramp rate to stp value SP1 when in controlling to stp value. If you set oFF, ramp function is turned OFF. Range: oFF, 1 to 999 °C/hour.
dErt	It makes the character of derivative value more accurate. The more value is set, the more derivative value is damped down. Range: 1.0 to 100.0 seconds.

uSEr, setting of user menu

Display	Meaning
StP1	Parameter that is placed on the 1st position of user menu: - no ... no parameter - PCn1 ... indicates power in % of output. - A-M ... automatic, manual operation. - Aut ... starting / ending of autotuning of PID parameters. - Pb1 ... proportional band of output 1. - It1 ... integral value of output 1. - dE1 ... derivative value of output 1. - hYS1 ... hysteresis of output 1 for ON/OFF switching. - o2Lo ... low limit of signalling for output 2. - o2hI ... high limit of signalling for output 2.
StP2 ... StP4	Parameter that is placed on 2nd to 4th position of user menu. The list is the same as in StP1.

PASS, passwords for the entry to higher levels of menu

Display	Meaning
P oP	Password for the entry to operation level. If it is set oFF, the entry is not secured with password. Range: oFF, 1 to 9999.
P Co	Password for the entry to configuration level. If it is set oFF, the entry is not secured with password. Range: oFF, 1 to 9999.
P SE	Password for the entry to service level. If it is set oFF, the entry is not secured with password. Range: oFF, 1 to 9999.

5.1 Measurement

The right selection, the installation, the wiring, the location of sensor in the equipment and the corresponding setting of parameters of the controller has the essential importance for the correct function. Parameters for the configuration of the measurement input are in *configuration level*, menu **InP1**.

Setting of input sensor

Set the corresponding input sensor in parameter **SEn1**. You will find the survey of input sensors in the chapter **Technical parameters**, see page 24.

You can set the position of decimal point by parameter **dEC1**. For thermal sensors it is possible to display without decimal point or with 1 decimal point.

Set the calibration of sensor with the parameter **CAL1**. The set value is added to process/measured value.

You can set the limit for set point value in *configuration level*, menu **SYS**, parameters **SP1L** and **SP1h**.

Important:

- Thermocouple and RTD inputs have the detection of improperly wired sensor. When the sensor is open or broken, the control output is turned OFF, the alarm output is activated.


Measuring range of process inputs

In *configuration level*, menu **InP1**, you can define the measuring range of the process inputs with parameters **rL 1**, **rh 1** and **dEC1**.

Example of setting process input:

You want the input signal 4 to 20 mA to be displayed in the range 6.0 to 24.0.

Set **dEC1** = 0.0, **rL 1** = 6.0 a **rh 1** = 24.0. The distribution between the values 6.0 and 24.0 will be linear.



5.2 Controlling, control output


You can select in the controller ON/OFF or PID controlling for heating as well as for cooling. If PID controlling is set, you can use the autotuning of PID parameters, see page 10.

The parameters for configuration of the control output 1 are in *configuration level*, menu **out1**.

ON/OFF controlling

ON/OFF control is selected by setting **ot1** = **ht2** (for heating) or **ot1** = **cl2** (for cooling).

It is used for less exacting application. It is not possible to achieve zero hysteresis value on principle. The process value rises and drops about set point value in the characteristic way.



PID controlling

PID control is selected by setting **ot1** = **ht** (for heating) or **ot1** = **cl** (for cooling). It provides the precise control. For the correct function of the controller, however, it is necessary to set properly PID parameters. Autotuning for setting of PID parameters is described on page 10.

PID parameters have the following meaning:

- **Pb1 proportional band** is set in measured units. It is the band about the set point value in which the controller keeps the temperature.
- **It1 integral factor**, in minutes. Integral factor compensates the loss of system. A **low** integral value causes a **fast** integrating action.
- **de1 derivative factor**, in minutes. Derivative responses to fast changes and tries to react against them. The **more** value is, the **more** derivative factor reacts.


The required power is (given in %) transferred to the output with so called pulse width modulation. In each time cycle (parameter **ct1**, you will find it in *configuration level*, menu **out1**) the control output is switched ON once and once OFF. The more the power is necessary, the wider the width of switching is. The output responses are illustrated in the third part of the drawing.

Example of pulse width modulation of the output:

- Time cycle is 10 seconds, the power requested is 30%. The output is ON for 3 seconds and OFF for 7 seconds.
- Time cycle is 10 seconds, the power requested is 5%. The output is ON for 0,5 second and OFF for 9,5 seconds.

Important:

- The duration of time cycle has the influence on the quality of control. The longer the cycle is, the less the quality of control is.
- If the electromechanical unit (relay, switching contactor) is used for the control output, the duration of time cycle must be set longer with regard to lifetime of switch.



5.3 Alarm, signalling output


The second output can be configured as alarm or signal one.

The parameters for configuration you will find in *configuration level*, menu **out2**, setting the limits **o2Lo** and **o2hI** you will find in *operation level* or in *user level*.

Setting of alarm or signal output

Function is set with the parameter **out2**:

- **ot2** = **oFF**, output is turned OFF,
- **ot2** = **ALPr**, alarm output, limits for alarm are set in the absolute values,
- **ot2** = **SGPr**, signal output, limits are set in the absolute values.



Active sides of alarm/signalling


With the parameter **sid2** you can choose which side is active for alarm or signalling:

- **sid2** = **both**, both sides (limits) are active.
- **sid2** = **hI**, only high side (limit) is active.
- **sid2** = **Lo**, only low side (limit) is active.

6 Service level

Service level is intended for service workers. In this level **the control output is switched OFF and alarm and signal output is deactivated.**

To get from basic mode to service level press the keys   for about 3 seconds. On lower display **LEVL** appears, on upper one set **SERV** and confirm. If **PASS** appears on lower display, level is secured with password. In this case set the correct password with arrow-keys and confirm again.



Display	Meaning
SoFt	Number of software version.
AMb1	Actual ambient temperature.
tC1	Measured voltage, thermocouple input 1. Range 60mV.
rtd1	Measured resistance, rtd input 1. Range 350 ohm.
I1	Measured current, current input 1. Range 20mA.
u1	Measured voltage, voltage 1. Range 10V.
ConF	By setting YES and confirming you enter the menu for setting all the parameters. This menu can be used e. g. in initial setting of the controller.
rSt?	Editing of initial parameters is the significant action to controller's setting. First it must be confirmed by 6x setting YES.
rSt?	
rSt?	
rSt?	
rSt?	
rSt?	

7 Table of parameters

Table of parameters for configuration level:

Sen1		SP1L	
dEC1		SP1h	
CAL1		rAMP	
rL 1		dErt	
rh 1			
CoMM		StP1	
bAud		StP2	
Addr		StP3	
		StP4	
ot1		P oP	
Ct1		P Co	
		P SE	
ot2			
SId2			

Table of parameters for operation level:

Pb1	
It1	
dE1	
hYS1	
o2Lo	
o2hI	

8 Installation

The controller is designed to be mounted to the panel cutout. Slide the controller into the cutout and fix it with 2 flanges that are supplied with the controller. The installation requires the access to the back of the panel.

Mounting dimensions

- Width x height x overall length: 48 x 96 x 107 mm (including terminal board).
- Behind panel length: 101 mm ((including terminal board).
- Cutout in the panel: 45 x 90 mm.
- The thickness of panel: 1,5 to 5 mm.

Mounting

- Make the panel cutout 45 x 90 mm.
- Slide the controller into the panel cutout.
- Insert the flanges for holding into the holes upward and downward or on both sides of the controller.
- Tighten the screws firmly on the flanges.

The controller is now installed, before wiring we recommend to read thoroughly the chapter on the possible sources of interference and principals for installation.

Wiring of the controller begins on page [21](#).

8.1 Principals for installation, the sources of interference

There are many possible sources of interference in environment of the controller. Among the most harmful sources of interference are the following:

- Equipment with inductive load, e.g. electromotors, winding of relays and breakers,
- Thyristors and other semiconductor equipment
- Welding devices.
- Wires carrying high currents.
- Fluorescent lightings and neon lights.

8.2 Reduction of interference influence

Making a design of system, try to observe these guidelines:

- All wires of power supply voltage and power wires carrying high currents must be lead separately from signal leads (e.g. thermocouple lead wire, communication lines). Minimum distance between these types of wires should not be smaller than 30 cm.
- If signal and power wires cross each other it is suitable for them to be crossed in right angle.
- From the beginning try to find the possible sources of interference and keep the wires away from them.
- Do not install relays and breakers very close to the controller.
- Do not use supply voltage for the controller also for supplying inductive and phase angle control equipment.
- Twisted and shielded wires should be used for signal leads. Shielding should be earthed several times.

When necessary the uninterruptible power sources (UPS) could be used.

9 Wiring


To avoid potential electric shock, use safety practices laid down by national standards when wiring and connecting this unit to a power source. Failure to do so could result in such damage, and / or injury. The wiring must be done only by the authorized person.

If there is any default of the device could cause damage, the equipment with the controller must be fitted with the independent protection unit (thermal cut-out).

Supply voltage


Before you connect the unit to a supply power source, check the level of supply voltage. The controller is intended for use in industrial or in laboratory equipment.

Category of overvoltage II, level of interference 2.




Measuring input (InP1)

Thermal inputs



Process inputs



Measuring input is not galvanic insulated from the ground of controller

Communication line (CoMM)

RS 232

T x D ← 4
R x D ← 5
Com ← 6


EIA 485

T-/R- ←
T+/R+ ←
Com ←



Communication line *is galvanic insulated* from the ground of controller

Connection of commun. line RS232 to PC




output 1 (control output ...out1)

SSD

dc voltage

max. 30mA
voltage open state:
9-12Vdc




SSD is *not isolated* from controllers ground

RELAY

Relay output

230Vac/5A
or
30Vdc/5A




RELAY output is *galvanically isolated* from the ground of the controller. For this output it is necessary to fix the wires in the way that in case of loosening the wire from the terminal the insulation would not be reduced between supply voltage and safety voltage.

output 2 (alarm, signal ... out2)

RELAY

Relay output

230Vac/5A
or
30Vdc/5A



RELAY output is *galvanically isolated* from the ground of the controller. For this output it is necessary to fix the wires in the way that in case of loosening the wire from the terminal the insulation would not be reduced between supply voltage and safety voltage.

10 Putting into operation

The initial set-up can be done only by the qualified and authorized person. The wrong set-up can cause serious damage.

When you power the controller up for the first time, you must enter the most necessary data to the controller for its problem-free operation:

- Type of sensor, position of decimal point
- Operational range of set point value
- Set-up for the control output

Guidelines

Let's suppose that the controller is installed in the panel and you have just power it up for the first time. Parameters of initial operation are the following:

- **sEn1**, set input sensor. The descriptions of this parameter see on page [13](#).
- **dEC1**, set the position of decimal point. The descriptions of this parameter see on page [15](#). This parameter is shown only for the process input.
- **rL 1**, **rh 1**, parameters for setting of the scale of displaying values for process inputs. These are not displayed for thermal inputs. The description of parameters is on page [15](#).
- **ot1**, setting of the control output. The descriptions of this parameter see on page [13](#).
- **SP1L**, set low limit of range of stp value. We recommend to leave 0.
- **SP1h**, set high limit of range of stp value. We recommend to set maximum working temperature of equipment. The operator can not set higher stp value than this value of parameter.
- Further information about input setting you will find on page [15](#), information about output setting on page [16](#).

Important:

- All the parameters that were set in the initial operation can be later changed in *configuration level*.

11 Technical parameters

The controller is intended for use in industrial or laboratory equipment, the category of pollution / over voltage II.

Controlling

- PID, PI, PD, P controlling, autotuning/automatic setting of PID parameters, controlling of heating or cooling.
- ON/OFF controlling, controlling of heating or cooling.

Alarm, signalling

- absolute alarm, signalling, high and low limits.

Controlling of stp value

- controlling to stp value, ramp function

Indicators and keys

- 2 four-digit displays, height of segments is 10 mm,
- 2 LED diodes for outputs,
- 3 keys, setting through the particular menus.

Sensors, inputs

Thermal input – thermocouple or rtd Pt100, detection of bad-wired/broken sensor:

- **no** ... no input is set,
- **J** ... thermocouple J, range -200 to 900°C,
- **K** ... thermocouple K, range -200 to 1360°C,
- **T** ... thermocouple T, range -200 to 400°C,
- **N** ... thermocouple N, range -200 to 1300°C,
- **E** ... thermocouple E, range -200 to 700°C,
- **R** ... thermocouple R, range 0 to 1760°C,
- **S** ... thermocouple S, range 0 to 1760°C,
- **B** ... thermocouple B, range 300 to 1820°C,
- **C** ... thermocouple C, range 0 to 2320°C,
- **D** ... thermocouple D, range 0 to 2320°C,
- **rtd** ... sensor Pt100, range -200 to 800°C, 2-wire or 3-wire connection, DIN curves.

Process input - current (input impedance 40 Ohms), voltage (10 kOhm), without the detection of broken sensor:

- **no** ... no input is set,
- **0-20** ... 0 – 20 mA, range -499 to 2499 units,
- **4-20** ... 4 – 20 mA, range -499 to 2499 units,
- **0-5** ... 0 – 5 V, range -499 to 2499 units,
- **1-5** ... 1 – 5 V, range -499 to 2499 units,
- **0-10** ... 0 – 10 V, range -499 to 2499 units.

Output 1

- SS driver, voltage 9 – 12 Vdc in ON state, max. 30 mA,
- Electromechanical relay, 230Vac/5A or 30Vss/5A, switching, no RC suppression unit.

Output 2

- Electromechanical relay, 230Vac/5A or 30Vdc/5A, switching, no RC suppression unit.

Communication line

- RS 232, galvanic insulated, protocol Modbus RTU,
- EIA 485, galvanic insulated, protocol Modbus RTU.

Accuracy of inputs

- $\pm 0,25\%$ of range (min. 600°C), ± 1 digit at 25°C $\pm 3^\circ\text{C}$ ambient temperature and at $\pm 10\%$ rated supply voltage
- temperature stability $\pm 0,1^\circ\text{C}/^\circ\text{C}$ in ambient
- voltage stability $\pm 0,01\%/ \%$ of change in supply voltage.

Supply voltage

- 230 VAC + / - 10%, 50 Hz, internal slow fuse T2 A/250 V
- input power max. 5 VA
- data stored in memory upon power failure

Operating environment

- 0 to 50 °C
- 0 to 90 % relative humidity, non-condensing

Shipping and storage

- -20 to 70 °C

Dimensions

- width x height x length 48 x 96 x 107 mm,
- depth behind panel surface 101 mm,
- cutout into the panel 45 x 90 mm, , the thickness of the panel 1,5 to 5 mm.

11.1 Warranty

The supplier provides 36-month warranty on defects in material and workmanship on this controller with the exception on defects caused by mechanical or electrical wearing out of the outputs. This warranty does not also apply to damage resulting from inappropriate transportation and storage, misuse, wrong wiring, ambient influences (especially effects of electrical overvoltage, electrical values and temperatures of inadmissible intensity, chemical materials, and mechanical damage) electrical or mechanical overloading of inputs and outputs.

11.2 Description of model

Ht60B – a b – c d – e f g

- **a: input**
T = thermal input
P = process input
- **b: communication line**
0 = none
X = communication line RS 232
A = communication line EIA 485
- **c: output 1 (ontrol)**
K = ss driver
R = electromechanical relay
- **d: output 2 (alarm, signalling)**
R = electromechanical relay
- **e, f, g: 0 0 0**

12 Index

1	Important.....	3
2	Basic Terms	4
2.1	Information and error messages	4
2.2	Overview of levels, menus	5
2.3	Basic mode.....	6
3	User level.....	7
3.1	Controlling of stp value.....	8
3.2	Automatic / manual operation of controller.....	9
3.3	Parameters of the control output, PID controlling.....	10
3.4	Autotuning – automatic setting of PID parameters.....	10
4	Operation level	11
5	Configuration level.....	12
5.1	Measurement.....	15
5.2	Controlling, control output.....	16
5.3	Alarm, signalling output.....	17
6	Service level	18
7	Table of parameters	19
8	Installation	20
8.1	Principals for installation, the sources of interference.....	20
8.2	Reduction of interference influence	20
9	Wiring	21
10	Putting into operation	23
11	Technical parameters.....	24
11.1	Warranty	25
11.2	Description of model	25
12	Index.....	26