KDA 864

Version 2.1i through 2.1q

User's Manual

UM113739



"Your Partners In Telecom Management Networks" 4955 East Yale Avenue

Fresno, CA 93727

Tel: (559) 454-1600 - Fax: (559) 454-1688

E-mail: sales@dpstele.com

Visit our Web Site at http://www.dpstele.com

Copyright 1999

Released 3/12/99

Revised 9/27/99

Change Notice

3/12/99: Updated to support version 2.1q. 9/27/99: Updated to support NEBS versions

Terms

Warranty	DPS Telecom products are warranted to be free from defects in material and workman- ship at the time of sale, but our obligation under this warranty is limited to the replace- ment of any hardware proved to be defective within one year from the date of delivery and the replacement of any software for ninety days from the date of delivery. If the prod- uct malfunctions during the warranty period, DPS Telecom will repair or replace it at our option at no charge to the purchaser other than the cost of shipping to and from DPS Telecom, which shall be the responsibility of purchaser. Before using, user shall deter- mine the suitability of the product for his intended use, and user assumes all risk and lia- bility whatsoever in connection therewith. This warranty is made in lieu of and excludes all other warranties, expressed or implied. The implied warranties of merchantability and fitness for particular use are specifically excluded. DPS Telecom shall not be liable for any other injury, loss or damage, whether direct or consequential, arising out of the use of or the inability to use the product, as specifically indicated in the Warranty Agreement provided with the Purchase Order.
Warranty Card	Purchaser shall fill in the requested information on the Product Warranty Card. The card provides information that helps DPS make product improvements as well as develop new products that better suit your needs.
Copyrights	All software and manuals are copyrighted by DPS Telecom. Said software and manuals may not, in whole or in part, without prior written consent from DPS, except as required by United States copyright laws, be reproduced, copied, transmitted or used to make a derivative work. All rights are reserved.
Trademark Acknow- ledgements	KDA 864, KDA-864, DPM, BSU, BAU, APM, AlphaMax 82A, T/MonXM, IAM, T/MonDR, T/MonEM, T/MonEM-ATT, T/MonD, T/MonE, T/Remote, T/Remote for Windows, W/Shell, T/Link, T/Access, T/AccessM, T/Config, T/Bos, T/E2, T/abs and T/Term are all registered trademarks of DPS, Inc.
-	MS-DOS is a registered trademark of Microsoft Corporation.
	WINDOWS and WINDOWS 95 are registered trademarks of Microsoft Corporation.
	Open View is a trademark of Hewlett-Packard.
Cautions	Observe electrostatic precautions when servicing this equipment. Observe polarity when connecting power to this unit.
	For intra-building connections, all interfaces must be connected through a shielded cable that is grounded at both ends.

Table of Contents

	General
	KDA 864 Description
	Model Numbers
	Specifications
	LED Display Status
	Speaker Switch (ACO)
	ACK Button / Front Panel Addressing Mode
Section 2-	KDA APPLICATIONS
	Network Topologies
	Expansion Cards
Section 3 -	Installation and Turn Up Procedure
	I Install Hardware 3-1
	III Install Software 3-A
	IV Provision Software 3.4
	V Download KDA 3-4
	VI Test KDA
	VII. Trouble Shooting 3.4
Section 1	Hardware Connections
Section 4 -	Craft Dart Connections 4.1
	Wire Wren Din Levents
	Connectorized KDA Back Danel
	Connectorized KDA Back Parlet
	Connectorized KDA (Hardware Options 1, 2 and 3)
	Logical Diagrams 47
	Logical Diagrams
	Logical Diagrams. 4-7 LAN Wiring 4-8 Sotallita Wiring 4-8
	Logical Diagrams. 4-7 LAN Wiring 4-8 Satellite Wiring. 4-8 Pridra Dasking Red (Option 07) 4.8
	Logical Diagrams. 4-7 LAN Wiring 4-8 Satellite Wiring. 4-8 Bridge Docking Pad (Option -07) 4-8 Docking Module Strapping 4-8
	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors4-9
	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NLA and NAC Expansion Cards4-13
Soction 5	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13
Section 5 -	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13T/kda51
Section 5 -	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13T/kda5-1Standards.5-1
Section 5 -	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13T/kda5-1Standards5-2Standard Field Editing5-2
Section 5 -	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13T/kda5-1Standards5-1Standard Field Editing5-2Screen Features.5-2Defent Dere5-2
Section 5 -	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13T/kda5-1Standards5-2Screen Features.5-2Default Box.5-2
Section 5 -	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13T/kda5-1Standards5-2Screen Features.5-2Default Box.5-2Installing Under MS-DOS5-3Stantart Field Edition5-3
Section 5 -	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13T/kda5-1Standards5-2Screen Features.5-2Default Box.5-2Installing Under MS-DOS5-3Start T/Config5-6
Section 5 -	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13T/kda5-1Standards5-2Screen Features.5-2Default Box.5-2Installing Under MS-DOS5-3Start T/Config5-6System Parameters5-6Main Marma5-7
Section 5 -	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13T/kda5-1Standards5-2Screen Features.5-2Default Box.5-2Installing Under MS-DOS5-3Start T/Config5-6System Parameters5-7Nuw Configuration5-7
Section 5 -	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13 T/kda 5-1Standards5-2Screen Features.5-2Default Box.5-2Installing Under MS-DOS5-3Start T/Config5-6System Parameters5-6Main Menu5-7New Configuration5-8Over Configuration5-8
Section 5 -	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13T/kda5-1Standards5-2Screen Features.5-2Default Box.5-2Installing Under MS-DOS5-3Start T/Config5-6System Parameters5-6Main Menu5-7New Configuration5-8Open Configuration5-8Open Configuration5-8
Section 5 -	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13T/kda5-1Standards5-2Screen Features.5-2Default Box.5-2Installing Under MS-DOS5-3Start T/Config5-6System Parameters5-6Main Menu5-7New Configuration5-8Open Configuration5-8Satellite Names5-8
Section 5 -	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13T/kda5-1Standards5-1Standards5-2Screen Features.5-2Default Box.5-2Installing Under MS-DOS5-3Start T/Config5-6System Parameters5-6Main Menu5-7New Configuration5-8Open Configuration5-8Satellite Names5-8Edit Configuration5-9E lit Circle D. Circle5-9
Section 5 -	Logical Diagrams.4-7LAN Wiring4-8Satellite Wiring.4-8Bridge Docking Pad (Option -07)4-8Docking Module Strapping.4-8Expansion Port Connectors.4-9NIA and NAC Expansion Cards4-13T/kda5-1Standards5-1Standards5-2Screen Features5-2Default Box5-2Installing Under MS-DOS5-3Start T/Config5-6System Parameters5-6Main Menu5-7New Configuration5-8Open Configuration5-8Satellite Names5-8Edit Configuration5-9Edit Site Definition5-9Edit Site Definition5-9

Section 5 - T/kda (Cont.)

	Edit Relays
	Edit Protocol
	Edit Expansion Cards
	Edit Advanced
	Connect Direct
	Connect Modem
	Reports
	Software Parameters
	Utilities
Section 6 - Tr	ouble Shooting
	Probe NvRAM
	Connect Direct Trouble Shooting Functions
	Spy LAN Traffic
	Spy Lan Commands
	Spy Satellite
	Set Triggers
Appendices	
	Appendix 1 - Customer Support
	Appendix 2 - Glossary of Technical Terms
	Appendix 3 - DCP/DCPF/DCPS Addresses
	on Front Panel LED's
	Appendix 4 - Alarm Mapping and Stacking Table
	Appendix 5 - KDA 864 Functional Schematic
	Appendix 6 - Modem Initialization Strings
Expansion C	ard Operation Guides
	4 Port TBOS Scanner
	8 Port TBOS Scanner
	8 Channel (B Rev.) and 16 Channel Analog Monitor
	LR24 Relay Card

EXP 832 Card

4 TBOS / 8 Analog

NIA Card

NOTE: This manual supports version 2.1i through 2.1q of the KDA 864. Later versions are supported as indicated in the change box on the cover page.

KDA 864 Remote Telemetry Unit, ver. 2.1q

Section 1 - General



Fig. 1.1 - KDA 864 in One Rack-Unit Housing with Open Expansion Slot

DPSs KDA 864 is a multi-protocol, downloadable alarm and control remote or network element that packs 8 control points and 64 alarm points into a single 19-inch housing. The KDA 864 reports alarms over dedicated or dial-up circuits to an interrogating alarm center, such as the DPS T/MonXM Workstation or the DPS IAM (Intelligent Alarm Mediator). Version 2.1i also reports over Ethernet to a DPS T/MonXM or IAM element manager or with SNMP protocol to an SNMP manager, such as Hewlett-Packard Open View. On-site personnel can see alarms on the front panel LEDs or have full interactive monitoring by connecting a personal computer to the front panel craft port.

Multi-Purpose Expansion Slot.

An expansion slot is included to add expansion cards for Analog and ASCII inputs, TBOS ports or latching control outputs. The expansion slot can also hold a UPS or Ethernet card. See Model Numbers section for details.

Ethernet reporting to T/MonXM or IAM

When equipped with a Network Interface Adaptor (NIA) in the expansion card slot (or in a separate chassis) the KDA can interface the T/MonXM or IAM element managers via Ethernet using TCP/IP-DCPX protocol.

SNMP via Ethernet TCP/IP

When equipped with a Network Interface Adapter (NIA) in the expansion card slot (or in a separate chassis) the KDA can interface an SNMP or TL-1 element manager via Ethernet TCP/IP using SNMP or TL-1 protocol. The KDA with an NIA card is an ideal solution to bring "legacy" alarms into today's Telecommunications Management Network (TMN) environment. Discrete points, control points, TBOS ports and analog points can all be interfaced to the manager through the KDA.

Daisy-Chain up to Four KDAs for 256 Alarms and 32 Controls

Using its Daisy-Chaining feature you can add up to three satellite KDAs to expand to 256 alarm points and 32 control points at a single location. Add its versatile interface and unique diagnostic features and you'll see why the KDA 864 is an ideal choice for network management applications.

Interface Docking Stations.

The KDA is equipped with two communication port interface docking stations. Optional interfaces include RS232, RS422/RS485, a 202 modem and a 212 "AT" type modem.

Optional Modem for Dial-Up Access.

Using the optional "AT" type 1200 Baud modem in the secondary docking station makes dial-up networks easy to set up. It also makes disaster recovery via a backup path possible. Choose from three modes of operation: primary, dial-up and primary with dial backup. In Primary Mode the primary port is equipped with a direct connect type interface. In Dial-Up Mode the secondary port is equipped with a dial-up interface. In Primary with Dial Backup Mode the primary port is equipped with a direct connect type interface

KDA can report to T/MonXM via LAN

KDA 864

Description

The KDA can now serve as an SNMP network element

Report Alarms over Dedicated or Dial-Up Lines. and the secondary port is equipped with a dial-up interface, allowing the dial-up capability to be used for backup if the primary line fails. You can order your KDA equipped with the proper interfaces for your network, then add or change docking modules as your network grows.

KDA Easily Configured with T/kda Software

Easy-to-use pull down menus combined with colorful status screens make configuring the KDA a snap. You can configure the KDA 864 locally via the craft port on the front panel or remotely via a dial-up modem (if equipped). Configuration is done with T/KDA software on a DOS-based personal computer (does not run under Windows) or through a T/MonXM WorkStation (version 2.2 or higher). Satellite units can be configured through the craft port of the base unit. Select data rate, protocol, address number, the form of alarm inputs and the form of control outputs. And, you can enter a 13-character description for each of the 64 alarm points. Protocols include DCP, DCPX, DCP1, DCPF, DCPS, SNMP and UDP. TRIP protocol is used with the dial-up modem.

Trouble Shooting Screens

T/KDA software is

KDA.

included with every

Extensive diagnostic tools in the T/KDA software make trouble shooting a breeze.

Opto-Isolated Alarm Inputs

The 64 discrete opto-isolated inputs allow the KDA to turn any basic contact closure or ground loop closure into an alarm. Fifty-six inputs are ground activated, 8 inputs have both sides of the opto-isolator brought to the connectors. Options are available with some alarm inputs configured for TTL interface (see Model Numbers section). One alarm input can be programmed to operate as an external alarm acknowledgment input.

Relay-Isolated Control Outputs

There are 8 "Form A" dry contact relay outputs for controls. Relays may be activated in a latching or momentary mode. *Latching is electrical, not magnetic, except in the case of the 'L' (magnetic latching) option or the LR-24 Relay expansion card.* One control output relay can be programmed to activate an external audible or visual alarm indicator whenever an alarm is detected.

KDA Operational Status Indicated on Front Panel LED's

High intensity LED status indicators provide a local display of KDA operation as well as alarm point status. An indicating fuse and a fuse alarm LED are conveniently located on the front panel. Fuse alarm output relay contacts close when the fuse blows. A DB9 connector for the configuration port is also on the front panel.

Connectorized Backplane Available

The KDA 864 features a fixed-mount housing with a plug-in P.C. board for all electronics and wire-wrap connectors on the back panel for all system connections. A connectorized panel is also available. In case of failure your system can be quickly restored by simply changing the board. And by keeping the configuration data on a floppy, you can configure a new board in no time by plugging a computer into the front panel craft port. The KDA 864 operates from AC or DC power sources. (See the Model Numbers section for details.)

Compatibility with Other DPS Network Management Elements

Compatibility allows you to choose the DPS alarm gathering unit that is right for your needs now and add modules as you need them.

Buzzer Option

The -11 KDA firmware option includes an internal buzzer that sounds for five seconds when any alarm point changes state. A jumper on the KDA's P.C. Board allows the buzzer to be defeated.

UPS Expansion card

An Uninterruptable Power Supply (UPS) card is now available for the KDA. It fits in the expansion card slot and provides up to 3 hours of battery power for the KDA. See the Model Numbers section for part number.

NEBS Tested Versions

Versions of the KDA are available that have been tested for compliance with Telcordia (formerly Bellcore) Network Equipment Building Standards (NEBS).

Medel	Model Number Breakdown	KDA864-B-01-04	- <u>02-00</u> -L
wodei	Basic Model Number —		Option
Numbers	Issue		Secondary Pad
	Fir	mware	Primary Pad
		L	— Model/Voltage

Table 1.A - Model Number Components (Basic Model Number: KDA 864 - 8 Controls, 64 Alarms)

	01		Standard KDA	10	Alpha paging, downloadable code*	
		02	KDA with TL1 Responder*	11	Standard KDA w/ buzzer	
Firmware Type		03	Time-Stamp (T-S) Version*	12	TelTrak (KDA 832-T8 only)*	
		05	Extended Temperature Range	13	Alpha paging, w/ACO, downloadable	
		06	Pulsecom Datalok Protocol*	14	TABS	
		07	E2A Protocol*	15	Datalok XM, Downloadable	
		08	T-S w/buzzer. Downloadable*	16	Datalok Native (DCP1, DCP1AR)	
		09	T-S w/buzzer. Downloadable from T/MonXM, w/ clear qual. times *			
		0	Wire Wrap pins	L	LAN Connectorized	
	lat	1	Connectorized, DB9 Exp.	LN	LAN Connectorized, NEBS compliant	
Model	Old Forem	2	Connectorized, Amphenol exp.	D	LAN Connectorized, dual power barrier (use with power option 8)	
		3	Connectorized, no Exp.	R	LAN, Wire-Wrap blocks w/ 2 pins/alm	
	at	4	Connectorized, DB9 Exp.	G	All alarms ground closure	
	ema	5	Connectorized, Amphenol exp.	В	Connect., Amph. exp., bi-polar inputs	
	Nev Fore	6	Connectorized, no exp.	А	Connect., Amph. exp. anal., ana/TBOS	
		7	Connect., Amph. exp., -48V bias pts 56-64	AN	Connect., Amph. exp., analog or ana- log/TBOS, NEBS compliant	
		8	Connect., J9=pts 1-48, J10=pts 49-64	E	RS422 dual hub, Analog expansion	
		9	Wire-Wrap blks w/2 pins per alm	С	LAN, Wire-Wrap blks w/2 pins per alm	
				Z	Dual 202 pad, no expansion	
		2	Negative 24 VDC	6	Positive 12 VDC	
Voltage		3	Positive 24 VDC	7	Negative 12 VDC	
4		4	Negative 48 VDC	8	Dual Feed -48VDC	
		5	Negative 24 and 48 VDC (wide range)			
		00	Not Equipped	10	RS485 drop and insert	
Drimony Dod		01	RS 232	11	RS232 opto isolated (low speed)	
Primary Pao		02	RS 422/485	15	DCP	
		03	202 Modem	16	RS485, soldered	
		04	TTL	17	202 modem w/-1db	
		05	Type 212 1200 Baud Modem	91	Dual RS422 or 212 modem	
		06 E2A		92	Dual RS485	
		07	RS232 dual hub (both pads)	93	Dual 202	
		08	DDS	94	Dual FSK	
		09	202 w/loopback (KDA 864-E2 only)	99	Double pad	
Secondary Pad		00	Not Equipped	14	9600 Baud modem	
		05	Type 212 1200 Baud Modem	20	DTMF Module	
		L	Latching Relays	T1B	8 TTL Inputs (+5 V Bias)	
Options		T1	8 TTL Inputs	OB	Points 57-64 biased to -48V	
		T2	16 TTL Inputs	C9	DB9 to DB9 cables	
		A5	90 degree prewired cables	AD	ACO switch on front panel	
		ТОВ	All TTL Inputs (+5 V Bias)	T3B	24 TTL Inputs (+5V bias)	
*Not supported	in this	manual		Р	Lightning package	
Example Model Numbers:			KDA 864-01-04-02-00: KDA 864, Sta RS422/485 P	andard Firm rimary Port	ware, Wire-Wrap, -48 VDC, , No Secondary Port	

	KDA 864-01-02-03-00-1	 KDA 864, Standard Firmware, Wire-Wrap, -24 VDC, 202 Modem Primary Port, No Secondary Port, Latching Relays
	KDA 864-05-01-02-05:	KDA 864, Extended Temp., Wire-Wrap, 120 VAC, No Primary Port, Dial-up Secondary Port
Expansion Cards:	D-PC-446-10A-00 D-PC-705-10B-00 D-PC-706-10A-00 D-PC-710-10A-00 D-PC-715-10A-00 D-PC-716-10A-00 D-PC-717-10A-00 D-PC-708-10A-00 D-PC-395-10A-00 D-PC-770-10A-00	24 Relay Assembly 8 Analog Inputs 16 Analog Inputs 4 Port TBOS Scanner 8 Port TBOS Scanner 7 Port Serial Card (3 ASCII and 4 TBOS ports) EXP 832 Card (adds 8 controls and 32 alarms) 8 Analog / 4 TBOS UPS Network Interface Adapter, SNMP, TL-1 or DCPX via Ethernet
Accessories:	D-PR-631-10A-00 D-PR-105-10A-00	Satellite Cable, Male-to-Male DB9, 1 ft. (for connectorized satellites) Wall-mount AC Adapter for 24 V KDA (voltage 2 or 3)
Specifications	Specifications for the the back of this manua	KDA 864 are shown below. (See individual Operation Guides in l for expansion card specifications.)
	Dimensions:	17.0"(W) X 12.0"(D) X 1.75"(H)
	Mounting: 5" projection mounti	Mounts in a 19" or 23" rack. Ears can be located for flush or ng. Can also be wall mounted.
	Power Input:	+24 DC option: +18 to +36 VDC, 200 MA @24 VDC.
		-24 DC option: -18 to 36 VDC, 200 MA @24 VDC.
		-48 DC option: -36 to -72 VDC, 130 MA @ 48 VDC.
	Fuse:	1/4 Amp
	Operating Temperatur	e Range: 0 Degrees to +60 Degrees Celsius. Option 05: -30 Degrees to +70 Degrees Celsius.
	Humidity:	0% to 95% non-condensing.
	Modem:	212 "AT" type 1200 Baud internal modem for dial facility 202 Type 1200 baud internal modem for dedicated facility
	202 Modem Receive I	Level: -43 dBm to -3 dBm.
	202 Modem Transmit	Level: -30 to -3 dBm (-13 dBm factory default)
	Protocols:	Modem uses TRIP (T /Mon R emote Interface P rotocol). Primary port supports DCP, DCPF, DCPS and TBOS.
	Comm Rates	300, 600, 1200, 2400, 4800 and 9600 Baud
	Relay Contacts (contro Initial Contact Resis Contact Material Max. Switching Pow Max. Switching Curr Max. Carrying Curr Electrical Life (1 A @ 30 VDC)	bls and fuse alarm): tance 50 milleohms Gold-Clad Silver ter 60 W, 125 VA tent 1 A ent 3 A 500,000 Operations
LED Display Status	Indicators on the front operational status. The	panel give maintenance personnel quick diagnostics of the KDA's LEDs that appear white when inactive are red/green multicolored.

1-4



Fig. 1-2 - KDA LED's Indicate Real-Time Status of Alarms and Controls

Table 1.B - LED Display Meaning

LED	COLOR	MEANING
FA	Solid Red	Fuse Alarm. Fuse is blown & fuse alarm relay is active.
COS	Pulse Red Solid Red Off	An Alarm input has changed state. No unacknowledged alarms (one or more standing). No standing alarms
LOD	Solid Red	Reserved for future use. (Intended to show a software download occurring.)
LOC	Solid Red	Craft port active and secondary port (212 modem) cut off.
CM1*	Pulse Red Pulse Green	Data received from primary port. Data transmitted from primary port.
CM2*	Pulse Red Flash Red Pulse Green	Data received from secondary port. Indicates tail end of ringing signal. Data transmitted from secondary port.
LIN*	Alt Green/Red Solid Green Pulse Green	Dialing out on modem. Online. T/Mon host dialed in. Online. KDA dialed T/Mon host.
A	Solid Green Solid Red	LED's 1-8 show active points 1-8. LED's 1-8 show active points 33-40.
В	Solid Green Solid Red	LED's 1-8 show active points 9-16. LED's 1-8 show active points 41-48.
С	Solid Green Solid Red	LED's 1-8 show active points 17-24. LED's 1-8 show active points 49-56.
D	Solid Green Solid Red	LED's 1-8 show active points 25-32. LED's 1-8 show active points 57-64.
CTL	Pulse Green Solid Green	Call Telemetry Login. A point set Auto-call. Unit will be calling in to report alarms. NVRAM unanswered (Needs a software download) or spy mode active via craft port.
1-8	Red Pulse Red Off	Standing alarm exists (acknowledged) Change-of-State (COS) alarm (Unacknowledged) No alarm Note: See alternate LED meanings in Table 1.D. .

*These LED's have alternate meaning if ACK button is held down. See Table 1.D.

Scanning Sequence:

The KDA will continuously display alarm status in the following sequence:

Table 1.C - LED Scanning Sequence

LED	COLOR	MEANING	COLOR	MEANING
А	Green	Alarm points 1-8	Red	Alarm points 33-40
В	Green	Alarm points 9-16	Red	Alarm points 41-48
С	Green	Alarm points 17-24	Red	Alarm points 49-56
D	Green	Alarm points 25-32	Red	Alarm points 57-64
All	OFF	Controls 1-8		

Alternate LED Meanings

Use Table 1.D for alternate meanings of the CM1, CM2 and LIN LED's when the ACK button is held down.

Table 1.D - Alternate LED Meanings when ACK Button is Held Down

LED	COLOR	MEANING
CM1*	Pulse Red Pulse Green	Data received from LAN port (expansion card). Data transmitted from LAN port.
CM2*	Pulse Red Pulse Green	Command Data received from LAN port (expansion card). Command Data transmitted from LAN port.
LIN*	Solid Red Solid Green Off	Primary Carrier Status. Rcv Carrier Detect. Primary Carrier Status. Xmt Carrier On. Primary Carrier Status. No Carrier.

Speaker Switch (ACO)

ACK Button/ Front Panel Addressing Mode

Silences audible alarm (Audible Cut Off). OFF disables the speaker, ON enables it. (Option AD only.)

Normal ACK Usage

Pressing the ACK button for a second will cause all alarms to be acknowledged. Any alarms that have been queued for dial out reporting will be removed from the queue (call will not be made). This affects only the local unit, not satellites. To acknowledge alarms in any satellite, the ack button on the satellite must be pressed.

Buzzer

When any alarm point changes state, the buzzer will sound for five seconds or until the ACK button is pressed, whichever is first. Removing jumper J10 on the P.C. Board defeats the buzzer.

Front Panel Address Change

There is a special front panel configuration mode that is available for KDAs that have been provisioned to be a DCP, DCPF or DCPS responder. This mode permits the address of the KDA to be changed without the use of a P.C. (Not applicable to an expansion card.)

1) Remove fuse.

2) Press and hold the ACK button while inserting the fuse.

3) The unit will come up with the 8 status LEDs displaying the current address in binary (see Appendix for address table).

4) Use the ACK button to select the desired address.

5) Wait 5 seconds and the KDA will return to normal operation mode.

HINT: When installing KDAs for future activation, each can be installed, downloaded and tested with address '0'. When the time comes for activation the addresses can be changed from the front panel using the above procedure.

NOTE: While in address programming mode the ABCD LEDs will be going through a pattern that indicates the amount of time since the last time the ACK button was pressed. This pattern generally starts out from the A led and progresses to the D led. When LED's A-D are all red, the address programming mode will terminate.

PRESS and RELEASE the ACK button to advance one address. The ACK button must be held in for at least one half second.

Section 2- KDA APPLICATIONS

Network Topologies

The KDA is ideal for the small locations where visibility is critical, and a large scale RTU is too much equipment. The KDA can provide complete coverage for a manned or unmanned site without the need for expensive main monitoring stations. The following applications illustrate the various KDA alarm network topologies.



Fig. 2.1 - Primary Operation Mode - Direct Connect RS232, RS422/485 or 202 Modem



Fig. 2.3 - Alternate Path or Primary with Dial-up Backup Operation Mode



FIG. 2.5 - KDA With NIA Card Reports to SNMP or TL-1 Manager on Ethernet TCP/IP



Fig. 2.2 - Dial-up Operation Mode uses 212 Modem



Fig. 2.4 - Daisy-Chained Application Provides up to 256 Alarms and 32 Controls at one site



FIG. 2.6 - KDA With NAC Card Reports to T/MonXM or IAM on Ethernet TCP/IP with DCPX protocol.

Expansion Cards

Seven expansion cards are currently available to fit in the expansion slot on the KDA. Expansion cards may be used in any KDA, except those in satellite applications. The expansion cards are briefly explained in the following paragraphs. Full details may be found in the individual operation guides at the back of this manual.

NOTE: KDA Version 2.1 and later allows expansion cards to be addressed independently of the base KDA. Earlier versions required expansion cards to be addressed consecutively with the host address.

Four and Eight Port TBOS Scanners

The TBOS scanners provide four or eight RS 422/485 ports for accessing TBOS serial alarm ports. Alarms are converted to DCPF protocol for transport to an IAM or T/MonXM WorkStation. The displays (up to eight) assigned to each four TBOS ports appear on a separate DCPF address at the KDA's interrogation port.



Fig. 2.7 - TBOS Scanner Adds 4 or 8 TBOS Interrogation Ports to KDA

Eight and 16 Channel Analog Monitors

The Analog Monitors provide eight or 16 analog voltage inputs for voltage or current-source transducers. The analog card converts readings to a DCPF representation of absolute value and evaluates each input for four threshold levels to generate alarms. The analog card alarms and values appear on a separate DCPF address at the KDA'a interrogation port.



Fig. 2.8 - Analog Monitor Card adds 8 or 16 Analog Channels to KDA

LR24 and SR24 Relay Cards

The LR24 Relay Card provides 24 magnetic-latching control points to give the KDA a total of 32 control point outputs. Relays maintain position in power outage and provide true position indication via a second set of contacts. The SR24 is similar, with non-latching relays. The relay card is operated via the KDA's interrogation port using DCPF protocol. The relay card control points appear on a separate DCPF address.



Fig. 2.9 - Add 24 more Latching Control Outputs with LR24 Relay Card

Seven Port Serial Card

The Seven Port Serial Card provides three RS 232 ASCII data ports for interactive communication with craft ports on external devices. ASCII data is converted to DCPF protocol for transport to an IAM or T/MonXM WorkStation. The ASCII data appears on a separate DCPF address at the KDA's interrogation port . In addition it provides four RS 422/485 ports for accessing serial alarm ports using TBOS protocol. Alarms are converted to DCPF protocol for transport to an IAM or T/MonXM WorkStation. The displays assigned to the TBOS ports appear on yet another DCPF address at the KDA's interrogation port . Each TBOS port can access a full eight displays (512 alarm points).



832 EXP Card

Fig. 2.10 - KDA Accesses ASCII Ports and TBOS with 7-Port Card

The EXP 832 card adds 32 alarm points and 8 control points to the KDA. Utilizing this card gives the KDA a very high density of 96 alarms and 16 controls in only one rack-unit of space. The expansion card uses a separate DCPF address from the host.



Fig. 2.11 - EXP 832 Card Enhances KDA Capacity by 50%

Uninterruptable Power Supply (UPS)

Provides up to 3 hours of backup power in case the office battery supply fails. Functions with 24 volt options only.



Fig. 2.12 - KDA UPS Card Fits in Expansion Card Slot

Network Interface Adapter (NIA)

DPS' Network Interface Adapter fits in the expansion card slot of a KDA864 to interface it directly to an Ethernet 10 Base-T network using SNMP, TL1 or TCP/IP-DCPX protocol.

A KDA remote equipped with the NIA card brings conventional discrete alarm and control points to your existing SNMP or TL-1 management system, using your already deployed 10 Base-T network. This is an ideal way to integrate "legacy" alarms into your network management system.

A KDA remote equipped with the NIA card using TCP/IP-DCPX protocol brings conventional discrete alarm and control points to your T/MonXM element manager, using your already deployed 10 Base-T network.



Fig. 2.13 - NIA Card in the KDA Expansion Card Slot Turns it Into an SNMP Network Element

Section 3 - Installation and Turn Up Procedure

I. Install Hardware

A. Mount KDA

The KDA fits in either a 19" or 23" rack. The mounting brackets on the side of the unit can be positioned for either 5" projection or flush mounting in a 19" rack or for 5-1/2" projection or 1/2" projection in a 23" rack. They may also be positioned for mounting against a wall.

1. Determine which mounting configuration is required and orient the mounting brackets as shown in Fig. 3.1.



Fig. 3.1 - Positioning Mounting Brackets on the KDA

2. Attach each bracket with two 6-32 screws (provided in hardware bag).

3. Place the KDA in the rack and align the mounting holes in the brackets with the holes in the rack rails. Secure each bracket with two 10-24 screws (provided in hardware bag). If mounting against a wall, orient the KDA so the front panel can be observed. Mark mounting holes on wall and attach KDA with bolts or hollow wall anchors.

Cautions

Observe electrostatic precautions when servicing this equipment.

Observe polarity when connecting power to this unit.

There are no user serviceable parts inside the enclosure.

For intra-building connections, all interfaces must be connected through a shielded cable that is grounded at both ends.

II. Wire KDA

A. W/W pin models

1. A wire wrap tool with a .060" mandrel is required.

2. Refer to the J1 and J2 pin layout drawings (Fig. 4.2 and Table 4.A and 4.B) in Section 4 -Hardware Connections for all wire wrap pin designations.

3. Identify and connect each alarm input lead. (Refer to Fig. 4.5, Logical Diagram of Optically Coupled Inputs in Section 4.)

4. Identify and connect each control output lead. (Refer to Fig. 4.6, Logical Diagram of the Controls in Section 4.)

5. If an expansion card is used, wire J3 for the appropriate card. (Refer to Table 4.E or the card operation guide.)

6. Connect Fuse Alarm contacts to alarm input, if required. (Refer to Fig. 4.7 in Section 4.)

7. Connect communications lines for #1 and #2 docking (if equipped) modules to appropriate pins. (Refer to Table 4.C and 4.D in Section 4.)

8. Slip black and red colored tubing over power input wires before wrapping them. Take care that polarity is properly oriented. Wrap power leads and push the tubing over the wire wrap pins to protect them from accidental shorting. Heat tubing to shrink it tight. (Tubing is provided in the software diskette bag.)

Observe polarity of power connections. "Battery" terminal is negative on -24 and -48 volt models. "Battery" terminal is positive on +24 volt models.

B. Connectorized models. Connectorized KDAs can be interfaced with pre wired connectorized cables or mating connectors can be wired on-site.

1. Refer to the Connectorized KDA Back Panel sub-section in Section 4 - Hardware Connections.

2. Refer to the J9 and J10 pin assignment tables (Tables 4.F and 4.G) for alarm input pin designations. Identify and connect each alarm input lead. (Refer to Fig. 4.5, Logical Diagram of Optically Coupled Inputs in Section 4.)

3. Refer to the J10 pin assignment table (Table 4.G) for control output pin designations. Identify and connect each control output lead. (Refer to Fig. 4.6, Logical Diagram of the Controls in Section 4.)

4. Refer to the J10 pin assignment table (Table 4.G) for fuse alarm output pin designations. Identify and connect Fuse Alarm contacts to alarm input, if required. (Refer to Fig. 4.7, fuse alarm schematic in the J2 pin layout drawing in Section 4.)

5. If an expansion card is used, wire connector per Table 4.O or 4.P or use the card operation guide.

6. Satellite applications only. Refer to the J11 and J12 pin assignment table (Tables 4.H or 4.L and 4.M) for satellite pin designations. Use DPS Satellite Cable part no. D-PR-631-10A-00. Connect communications lines for satellite KDAs to appropriate pins.

7. Connect communications lines for #1 docking pad (Table 4.I or 4.M in Section 4) and for #2 docking pad (if equipped) (Table 4.J or 4.N in Section 4) to appropriate pins.

8. Refer to the Power Block Screw Lugs table (Table 4.K) in Section 4 for power connections. Take care that polarity is properly oriented.

Observe polarity of power connections. "Battery" terminal is negative on -24 and -48 volt models. "Battery" terminal is positive on +24 volt models.

III. Install Software	A personal computer running DOS version 3.3 or later is required to run the T/KDA software. Refer to Section 5 - T/KDA for the installation procedure.
IV. Provision Software	Once T/KDA is installed and running, a configuration file must be created for the KDA. Refer to the applicable pages in Section 5 to perform the following steps (be sure to use F8 to save, where appropriate):
	 A. Start T/KDA 864 (page 5-7 & 5-8). B. Set Software Parameters (Configuration computer port settings) (page 5-32 & 33). C. Edit Alarm Points (page 5-9 & 5-10). D. Edit Relays (page 5-11). E. Edit Protocol. Refer to proper protocol table (page 5-12 through 14). F. Edit Expansion Ports, if an expansion card is equipped (page 5-15 through 19). Refer to appropriate operation guide at the back of this manual for additional information. G. Edit Advanced (page 5-20).
V. Download KDA	 A. Direct. Use the Direct Connect selection on the main menu if the PC is connected to the KDA via the craft port on the front panel. Follow the instructions in Section 5, page 5-21 & 5-22, Direct Connect for download. B. Modem. Use the Modem Connect selection on the main menu if the PC is connected
VI. Test KDA	 to the KDA via the dial-up modem port (docking pad #2) on the back of the unit. Follow the instructions in Section 5, page 5-30, Modem Connect for download. Testing is done via the same port used for downloading. Follow the instructions for Monitor Mode under the appropriate sub-section of Section 5, starting on page 5-23. Simulate alarms and operate control points. <i>NOTE: It may be desirable to temporarily disconnect certain critical equipment from</i>
VII. Trouble Shooting	<i>control outputs and substitute a continuity tester to verify relay operation.</i> In case of difficulty, refer to Section 6 - Trouble Shooting, for tips on using the analysis tools built into the T/KDA software.

Section 4 - Hardware Connections

The KDA has a craft port connector on the front panel for configuration and monitoring.

All power and network connections are made at the back of the unit.

With a standard KDA these connections are made directly to the wire wrap pins on the plug-in card edge connectors.

With a connectorized KDA network, connections are made to a variety of connectors on the back.

Power is connected to a screw-terminal barrier.

The following sub-sections define wiring and connector pinouts for the KDA.

Craft Port Connector

The Craft Port is a female RS232 DB9 connector used as a direct link into the KDA. The craft port is normally used to download the KDA configuration from T/KDA software.



Fig. 4.1 - Craft Port Pinout for Front Panel Connector

Wire Wrap Pin Layouts

The illustrations on these two pages show the pinouts for J1 and J2 wire wrap pins. These pins are located on the back of the KDA. If an expansion port card is included, see Table 4.E or the operation guides at the back of this manual for J3 pinouts.



Fig. 4.2 - Wire Wrap Pins are Accessible at Rear of KDA Chassis Table 4.A - J1 Wire Wrap Connector Pin Layout

Pin No.	Function						
1	ALM 1	2	ALM 2	29	ALM 29	30	ALM 30
3	ALM 3	4	ALM 4	31	ALM 31	32	ALM 32
5	ALM 5	6	ALM 6	33	ALM 33	34	ALM 34
7	ALM 7	8	ALM 8	35	ALM 35	36	ALM 36
9	ALM 9	10	ALM 10	37	ALM 37	38	ALM 38
11	ALM 11	12	ALM 12	39	ALM 39	40	ALM 40
13	ALM 13	14	ALM 14	41	ALM 41	42	ALM 42
15	ALM 15	16	ALM 16	43	ALM 43	44	ALM 44
17	ALM 17	18	ALM 18	45	ALM 45	46	ALM 46
19	ALM 19	20	ALM 20	47	ALM 47	48	ALM 48
21	ALM 21	22	ALM 22	49	ALM 49	50	ALM 50
23	ALM 23	24	ALM 24	51	ALM 51	52	ALM 52
25	ALM 25	26	ALM 26	53	ALM 53	54	ALM 54
27	ALM 27	28	ALM 28	55	ALM 55	56	ALM 56

Table 4.B - J2 Wire Wrap Connector Pin Layout

Pin No.	Function	Pin No.	Function	Pin No.	Function	Pin No.	Function
1	ALM 57B**	2	ALM 57A	29	CONTROL 7B	30	CONTROL 7A
3	ALM 58B	4	ALM 58A	31	CONTROL 8B	32	CONTROL 8A
5	ALM 59B	6	ALM 59A	33	CHASSIS GROUND	34	BIAS A, PTS 57-64
7	ALM 60B	8	ALM 60A	35	BIAS B, PTS 57-64	36	LAN CLK
9	ALM 61B	10	ALM 61A	37	#2 DOCKING	38	#2 DOCKING
11	ALM 62B	12	ALM 62A	39	#2 DOCKING	40	#2 DOCKING
13	ALM 63B	14	ALM 63A	41	#2 DOCKING	42	#2 DOCKING
15	ALM 64B	16	ALM 64A	43	LAN RX	44	LAN TX
17	CONTROL 1B	18	CONTROL 1A	45	FUSE ALARM	46	FUSE ALARM
19	CONTROL 2B	20	CONTROL 2A	47	RS 485	48	RS 485
21	CONTROL 3B	22	CONTROL 3A	49	#1 DOCKING	50	#1 DOCKING
23	CONTROL 4B	24	CONTROL 4A	51	#1 DOCKING	52	#1 DOCKING
25	CONTROL 5B	26	CONTROL 5A	53	#1 DOCKING	54	#1 DOCKING
27	CONTROL 6B	28	CONTROL 6A	55	BATTERY*	56	GROUND

*Negative polarity for -24 and -48 volt models. Positive polarity for +24 volt models. ** Input 57B provides +5VDC output on TTL models.

Table 4.C - #1 Docking Module with RS 232, RS 485 or 202 Modem

Pin No.	Op. 07, Bridging RS232 (Fig. 4.10)	RS 232	RS 485	202 Modem
49	TXD to next KDA	N/C	RX+	TX
50	RXD from next KDA	RTS	RX-	N/C
51	RXD from Network	TXD	TX+	TX
52	TXD to Network	RCV	TX-	N/C
53	Gnd	CTS	N/C	RX
54	N/C	GND	N/C	RX

Table 4.D - #2 Docking Module with 212 Modem

Pin No.	Function
37	N/C
38	N/C
39	N/C
40	N/C
41	RING
42	TIP

Table 4.E - J3 Wire Wrap Connector Pin-Outs for Expansion Cards

Pin No.	4/8 Prt TBOS	LR24 Relay	7 Port Serial	8/16 Anal.	EXP 832	Anal/ Tbos	Pin No.	4/8 Prt TBOS	LR24 Relay	7 Port Serial	8/16 Anal.	EXP 832	Anal/ Tbos
1	Rx+ P1	Ry 1A	Rxd Prt 1	-Ch 1	Ctrl 1A	-Ch 1	2	Rx- P1	Ry 1B		+Ch 1	Ctrl 1B	+Ch 1
3	Tx+ P1	Ry 2A		-Ch 2	Ctrl 2A	-Ch 2	4	Tx- P1	Ry 2B	Txd Prt 1	+Ch 2	Ctrl 2B	+Ch 2
5	Rx+ P2	Ry 3A		-Ch 3	Ctrl 3A	-Ch 3	6	Rx- P2	Ry 3B	Txd Prt 2	+Ch 3	Ctrl 3B	+Ch 3
7	Tx+ P2	Ry 4A	Rxd Prt 2	-Ch 4	Ctrl 4A	-Ch 4	8	Tx- P2	Ry 4B		+Ch 4	Ctrl 4B	+Ch 4
9	Rx+ P3	Ry 5A	Rxd Prt 3	-Ch 5	Ctrl 5A	-Ch 5	10	Rx- P3	Ry 5B		+Ch 5	Ctrl 5B	+Ch 5
11	Tx+ P3	Ry 6A	Txd Prt 3	-Ch 6	Ctrl 6A	-Ch 6	12	Tx- P3	Ry 6B		+Ch 6	Ctrl 6B	+Ch 6
13	Rx+ P4	Ry 7A		-Ch 7	Ctrl 7A	-Ch 7	14	Rx- P4	Ry 7B		+Ch 7	Ctrl 7B	+Ch 7
15	Tx+ P4	Ry 8A		-Ch 8	Ctrl 8A	-Ch 8	16	Tx- P4	Ry 8B		+Ch 8	Ctrl 8B	+Ch 8
17	Rx+ P5	Ry 9A	Rx+ Prt 4	-Ch 9	Alm 1		18	Rx- P5	Ry 9B	Rx- Prt 4	+Ch 9	Alm 2	
19	Tx+ P5	Ry 10A	Tx+ Prt 4	-Ch 10	Alm 3		20	Tx- P5	Ry 10B	Tx- Prt 4	+Ch 10	Alm 4	
21	Rx+ P6	Ry 11A	Rx+ Prt 5	-Ch 11	Alm 5		22	Rx- P6	Ry 11B	Rx- Prt 5	+Ch 11	Alm 6	
23	Tx+ P6	Ry 12A	Tx+ Prt 5	-Ch 12	Alm 7		24	Tx- P6	Ry 12B	Tx- Prt 5	+Ch 12	Alm 8	
25	Rx+ P7	Ry 13A	Rx+ Prt 6	-Ch 13	Alm 9		26	Rx- P7	Ry 13B	Rx- Prt 6	+Ch 13	Alm 10	
27	Tx+ P7	Ry 14A	Tx+ Prt 6	-Ch 14	Alm 11		28	Tx- P7	Ry 14B	Tx- Prt 6	+Ch 14	Alm 12	
29	Rx+ P8	Ry 15A	Rx+ Prt 7	-Ch 15	Alm 13	Rx+ P1	30	Rx- P8	Ry 15B	Rx- Prt 7	+Ch 15	Alm 14	Rx- P1
31	Tx+ P8	Ry 16A	Tx+ Prt 7	-Ch 16	Alm 15	Tx+ P1	32	Tx- P8	Ry 16B	Tx- Prt 7	+Ch 16	Alm 16	Tx- P1
33		Ry 17A			Alm 17	Rx+ P2	34		Ry 17B	Gd Prt 1		Alm 18	Rx- P2
35		Ry 18A			Alm 19	Tx+ P2	36		Ry 18B	Gd Prt 2		Alm 20	Tx- P2
37		Ry 19A			Alm 21	Rx+ P3	38		Ry 19B	Gd Prt 3		Alm 22	Rx- P3
39		Ry 20A			Alm 23	Tx+ P3	40		Ry 20B			Alm 24	Tx- P3
41		Ry 21A			Alm 25	Rx+ P4	42		Ry 21B			Alm 26	Rx- P4
43		Ry 22A			Alm 27	Tx+ P4	44		Ry 22B			Alm 28	Tx- P4
45		Ry 23A			Alm 29		46		Ry 23B			Alm 30	
47		Ry 24A			Alm 31		48		Ry 24B		GND	Alm 32	GND
49	LAN TX				50					LREQ			
51	LAN CK				52	LAN RX							
53			Fuse A	larm			54	Fuse Alarm					
55	Power Battery				56		Power Gr	nd		PwrGnd			

Connectorized KDA Back Panel

The following information applies when the connectorized back panel is equipped. Expansion port card connectors are detailed on pp. 4-9 through 4-11 or in the operation guides at the back of this manual.



Fig. 4.3 - Rear View of Connectorized KDA

1. The plug-in card connectors are reached via two 50-pin Amphenol connectors, up to three DB9 female connectors, one RJ 12 phone line jack, one DB 37 connector and a power terminal block.

2. Connector pin-outs are listed in Tables 4.F through 4.K.

Pin No.	Function						
1	ALM 2	26	ALM 1	14	ALM 28	39	ALM 27
2	ALM 4	27	ALM 3	15	ALM 30	40	ALM 29
3	ALM 6	28	ALM 5	16	ALM 32	41	ALM 31
4	ALM 8	29	ALM 7	17	ALM 34	42	ALM 33
5	ALM 10	30	ALM 9	18	ALM 36	43	ALM 35
6	ALM 12	31	ALM 11	19	ALM 38	44	ALM 37
7	ALM 14	32	ALM 13	20	ALM 40	45	ALM 39
8	ALM 16	33	ALM 15	21	ALM 42	46	ALM 41
9	ALM 18	34	ALM 17	22	ALM 44	47	ALM 43
10	ALM 20	35	ALM 19	23	ALM 46	48	ALM 45
11	ALM 22	36	ALM 21	24	ALM 48	49	ALM 47
12	ALM 24	37	ALM 23	25	ALM 50	50	ALM 49
13	ALM 26	38	ALM 25				

Table 4.F - J9 50 PIN AMPHENOL

Table 4.G - J10 50 PIN AMPHENOL

Pin No.	Function	Pin No.	Function	Pin No.	Function	Pin No.	Function
1	ALM 52	26	ALM 51	14	CTRL 3B	39	CTRL 3A
2	ALM 54	27	ALM 53	15	CTRL 4B	40	CTRL 4A
3	ALM 56	28	ALM 55	16	CTRL 5B	41	CTRL 5A
4	ALM 57B(-)	29	ALM 57A(+)	17	CTRL 6B	42	CTRL 6A
5	ALM 58B(-)	30	ALM 58A(+)	18	CTRL 7B	43	CTRL 7A
6	ALM 59B(-)	31	ALM 59A(+)	19	CTRL 8B	44	CTRL 8A
7	ALM 60B(-)	32	ALM 60A(+)	20	FUSE	45	FUSE
8	ALM 61B(-)	33	ALM 61A(+)	21	GND	46	GND
9	ALM 62B(-)	34	ALM 62A(+)	22	GND	47	GND
10	ALM 63B(-)	35	ALM 63A(+)	23	GND	48	GND
11	ALM 64B(-)	36	ALM 64A(+)	23	GND	49	GND
12	CTRL 1B	37	CTRL 1A	25	GND	50	GND
13	CTRL 2B	38	CTRL 2A				

Table 4.H - J11 and J12 Female DB9 Satellite Network Connectors (Ref Fig. 4.8)

J11 and J12 Pin No.	Satellite
1	RS 485
2	RS 485
3	SPARE
4	SPARE
5	GND
6	NC
7	NC
8	NC
9	NC

Table 4.I - J13 Female DB9 Pad 1 Connector (Primary)

J13 Pin No.	RS 232	202 Modem	RS 485
1	NC	NC	NC
2	TXD	TX(Ring/TR)	TX+ (Tip/TT)
3	RXD	NC	TX-(Ring/TR)
4	NC	TX (Tip/TT)	RX+ (T1/RT)
5	GND	RX (R1/RR)	NC
6	NC	NC	NC
7	CTS	RX (T1/RT)	NC
8	RTS	NC	RX-(R1/RR)
9	NC	NC	NC

Table 4.J - J14 RJ12 Pad 2 Connector (Secondary / Dial-up)

J14 Pin No.	212 Function
1	NC
2	NC
3	RING
4	TIP
5	NC
6	NC

Table 4.K - Power Block Screw Lugs

Lug No.	Function
1	BATT*
2	BATT GND
3	CHASSIS GND

*Negative polarity for -24 and -48 volt models. Positive polarity for +24 volt models.



Fig. 4.4 - Rear view of connectorized KDA, NEBS compliant version.

Connectorized KDA (Hardware Options 1, 2 and 3)

Connectors J9, J10 and the power block are the same as described on the previous pages. Use Table 4.F for J9, Table 4.G for J10 and Table 4.K for the power block. Use Fig. 4.4 and Tables 4.L through 4.N for J11, J12 and J13.



Fig. 4.5 - Rear View of Connectorized KDA (Hardware Options 1, 2 and 3)

Table 4.L - J11 (Network)

J11 Pin No.	Satellite	J11 Pin No.	Satellite
1	RS 485	4	SPARE
2	RS 485	5	GND
3	SPARE	6 - 9	N/C

Table 4.M - J12 Female DB9 (Pad 1)

J12 Pin No.	RS 232	202 Modem	RS 485
1	N/C	N/C	N/C
2	TXD	TX-(Ring/TR)	TX+ (Tip/TT)
3	RXD	N/C	TX-(Ring/TR)
4	DSR	TX+ (Tip/TT)	RX+ (T1/RT)
5	GND	RX- (R1/RR)	N/C
6	N/C	N/C	N/C
7	CTS	RX+ (T1/RT)	N/C
8	RTS	N/C	RX-(R1/RR)
9	N/C	N/C	N/C

J13 Pin No.	RS232 Function	J14 Pin No.	212 Function
1	N/C	1	N/C
2	RSVD	2	N/C
3	RSVD	3	RING
4	RSVD	4	TIP
5	TIP	5	N/C
6	N/C	6	N/C
7	RING		
8	RSVD		
9	N/C		

Logical Diagrams

The following illustrations show logical diagrams of the Controls and Inputs on the wire wrap blocks.

Shown in Fig. 4.5 are six ways of connecting the KDA inputs. Fig. 4.6 shows the details of the control outputs. Fig. 4.7 shows how to wire the fuse alarm.



Fig. 4.6 - Logical Diagram of Optically Coupled Inputs



Fig. 4.7 - Logical Diagram of the Controls





LAN Wiring

Data is communicated between an expansion card and the host KDA via a backplane LAN. NOTE: LAN wiring is factory

Expansion Card	KDA	
J3	J2	
50 52	36 38 40 42 44	
48 51	33 37 38 41 43	

installed when an expansion unit.

card is ordered with the host Fig. 4.9 - Three Wires Provide the LAN Between the Host KDA and its Associated Expansion Card

Satellite Wiring

Bridge

Fig. 4.9 shows the proper placement of the satellite cable between a "Master' (connectorized) KDA and one or more satellite units.

NOTE: Cabling applies to hardware option 4, 5 and 6. Options 1, 2 and 3 require a special "daisy chain" cable connected to J11 on each unit. Contact DPS Inside Sales for information.

Fig. 10 shows how to wire be-

tween two KDAs using the

bridge docking pad option

(-07).



Fig. 4.10 - Satellite Cable Placement

Second KDA Host KDA J2 J2 RXD TO NETWORK SERVER RXI

Docking Module and **Main Board** Strapping

Docking Pad

(Option -07)

Shunt J2 and J3 only if directed by DPS Tech Support. Open J10 to defeat the buzzer operation.

Fig. 11 - Wiring Between 2 KDAs using the Bridge Docking Pad Option (-07)



Fig. 4.12 - Set Docking Module Straps for Communication Interface Requirements

Expansion Port Connectors

Universal Panel

The KDA can be ordered with the expansion port wired to a "universal" panel with 8 female DB9 connectors. The universal panel is detailed in Fig. 4.12 and Table 4.O.

A 50-pin Amphenol connector is also available. See Fig. 4.13 and Table 4.P or the individual operation guides for details.

NOTE: Although the back panel connectors are "universal," the internal ground wiring done at the factory is different for the analog cards. Therefore, the type of expansion card to be used should be specified when the KDA is ordered. All cards are interchangeable, except for the analog cards.

Wiring for power, LAN and fuse alarm is factory installed at the wire wrap pins on the plug-in card edge connectors. The fuse alarm parallels that on the main KDA (see Fig. 4.7).



Fig. 4.13 - "Universal" DB 9 Expansion Card Connector Panel Can be Used for any Expansion Card

Connector	Pin No.	J3 (on	Expansion Card Type					
		Main KDA)	4 and 8 Port TBOS	LR-24 Relay Card	7-Port Serial Card	8 or 16 Channel Analog	EXP- 832	Analog/ TBOS
J1	1	3	Port 1 TX+	Relay 2		CH 2 -	Ctrl Pt 2A	CH 2 -
	2	1	Port 1 RX+	Relay 1	Port 1 RXD	CH 1 -	Ctrl Pt 1A	CH 1 -
	5	33		Relay 17			Alm Pt 17	
	6	4	Port 1 TX-	Relay 2	Port 1 TXD	CH 2 +	Ctrl Pt 2B	CH 2 +
	7	2	Port 1 RX-	Relay 1		CH 1 +	Ctrl Pt 1B	CH 1 +
	9	34		Relay 17	Port 1 GND		Alm Pt 18	
J2	1	7	Port 2 TX+	Relay 4	Port 2 RXD	CH 4 -	Ctrl Pt 4A	CH 4 -
	2	5	Port 2 RX+	Relay 3		CH 3 -	Ctrl Pt 3A	CH 3 -
	5	35		Relay 18			Alm Pt 19	
	6	8	Port 2 TX-	Relay 4		CH 4 +	Ctrl Pt 4B	CH 4 +
	7	6	Port 2 RX-	Relay 3	Port 2 TXD	CH 3 +	Ctrl Pt 3B	CH 3 +
	9	36		Relay 18	Port 2 GND		Alm Pt 20	

Table 4.O - Expansion Card "Universal" Panel Connector Pin-outs*

(Table continued on next page)

Connector	Pin No.	J3 (on	J3 (on Expansion Care				Card Type			
		KDA)	4 and 8 Port TBOS	LR-24 Relay Card	7-Port Serial Card	8 or 16 Channel Analog	EXP- 832	Analog/ TBOS		
J3	1	11	Port 3 TX+	Relay 6	Port 3 TXD	CH 6 -	Ctrl Pt 6A	CH 6 -		
	2	9	Port 3 RX+	Relay 5	Port 3 RXD	CH 5 -	Ctrl Pt 5A	CH 5 -		
	5	37		Relay 19			Alm Pt 21			
	6	12	Port 3 TX-	Relay 6		CH 6 +	Ctrl Pt 6B	CH 6 +		
	7	10	Port 3 RX-	Relay 5		CH 5 +	Ctrl Pt 5B	CH 5 +		
	9	38		Relay 19	Port 3 GND		Alm Pt 22			
J4	1	15	Port 4 TX+	Relay 8		CH 8 -	Ctrl Pt 8A	CH 8 -		
	2	13	Port 4 RX+	Relay 7		CH 7 -	Ctrl Pt 7A	CH 7 -		
	5	39		Relay 20			Alm Pt 23			
	6	16	Port 4 TX-	Relay 8		CH 8 +	Ctrl Pt 8B	CH 8 +		
	7	14	Port 4 RX-	Relay 7		CH 7 +	Ctrl Pt 7B	CH 7 +		
	9	40		Relay 20			Alm Pt 24			
J5	1	19	Port 5 TX+	Relay 10	Port 4 TX+	CH 10 -	Alm Pt 2	Port 1 TX+		
	2	17	Port 5 RX+	Relay 9	Port 4 RX+	CH 9 -	Alm Pt 1	Port 1 RX+		
	5	41		Relay 21			Alm Pt 25			
	6	20	Port 5 TX-	Relay 10	Port 4 TX-	CH 10 +	Alm Pt 4	Port 1 TX-		
	7	18	Port 5 RX-	Relay 9	Port 4 RX-	CH 9 +	Alm Pt 3	Port 1 RX-		
	9	42		Relay 21			Alm Pt 26			
J6	1	23	Port 6 TX+	Relay 12	Port 5 TX+	CH 12 -	Alm Pt 6	Port 2 TX+		
	2	21	Port 6 RX+	Relay 11	Port 5 RX+	CH 11 -	Alm Pt 5	Port 2 RX+		
	5	43		Relay 22			Alm Pt 27			
	6	24	Port 6 TX-	Relay 12	Port 5 TX-	CH 12 +	Alm Pt 8	Port 2 TX-		
	7	22	Port 6 RX-	Relay 11	Port 5 RX-	CH 11 +	Alm Pt 7	Port 2 RX-		
	9	44		Relay 22			Alm Pt 28			
J7	1	27	Port 7 TX+	Relay 14	Port 6 TX+	CH 14 -	Alm Pt 10	Port 3 TX+		
	2	25	Port 7 RX+	Relay 13	Port 6 RX+	CH 13 -	Alm Pt 9	Port 3 RX+		
	5	45		Relay 23			Alm Pt 29			
	6	28	Port 7 TX-	Relay 14	Port 6 TX-	CH 14 +	Alm Pt 12	Port 3 TX-		
	7	26	Port 7 RX-	Relay 13	Port 6 RX-	CH 13 +	Alm Pt 11	Port 3 RX-		
	9	46		Relay 23			Alm Pt 30			
J8	1	31	Port 8 TX+	Relay 16	Port 7 TX+	CH 16 -	Alm Pt 14	Port 4 TX+		
	2	29	Port 8 RX+	Relay 15	Port 7 RX+	CH 15 -	Alm Pt 13	Port 4 RX+		
	5	47		Relay 24			Alm Pt 31			
	6	32	Port 8 TX-	Relay 16	Port 7 TX-	CH 16 +	Alm Pt 16	Port 4 TX-		
	7	30	Port 8 RX-	Relay 15	Port 7 RX-	CH 15 +	Alm Pt 15	Port 4 RX-		
	9	48		Relay 24			Alm Pt 32			

*NOTE: Pins 3, 4 and 8 have no connections. They are left out of this table for clarity.



Fig. 4.14 - 50-Pin Amphenol Connector is Available for Expansion Cards

Expansion cards can also be ordered with a 50-pin Amphenol connector on the expansion panel. This connector is also a "universal" configuration like the DB 9 panel described above. Refer to Fig. 4.13 and Table P.

NOTE: Although the back panel connectors are "universal," the internal ground wiring done at the factory is different for the analog cards. Therefore, the type of expansion card to be used should be specified when the KDA is ordered. All cards are interchangeable, except for the analog cards.

Wiring for power, LAN and fuse alarm is factory installed at the wire wrap pins on the card edge connectors. The fuse alarm parallels that on the main KDA (see Fig. 4.7).

Amphenol Connector Pin Number	J3 (on Main KDA)	4 and 8 Port TBOS	LR-24 Relay Card	7-Port Serial Card	8 & 16 Channel Analog	EXP- 832	8 Analog/ 4 TBOS
1	2	RX- Port 1	Relay 1 Com.		CH 1 +	Ctrl Pt 1B	CH 1+
2	4	TX- Port 1	Relay 2 Com.	TXD Port 1	CH 2 +	Ctrl Pt 2B	CH 2+
3	6	RX- Port 2	Relay 3 Com.	TXD Port 2	CH 3 +	Ctrl Pt 3B	CH 3+
4	8	TX- Port 2	Relay 4 Com.		CH 4 +	Ctrl Pt 4B	CH 4+
5	10	RX- Port 3	Relay 5 Com.		CH 5 +	Ctrl Pt 5B	CH 5+
6	12	TX- Port 3	Relay 6 Com.		CH 6 +	Ctrl Pt 6B	CH 6+
7	14	RX- Port 4	Relay 7 Com.		CH 7 +	Ctrl Pt 7B	CH 7+
8	16	TX- Port 4	Relay 8 Com.		CH 8 +	Ctrl Pt 8B	CH 8+
9	18	RX- Port 5	Relay 9 Com.	RX- Port 4	CH 9 +	Alm Pt 2	
10	20	TX- Port 5	Relay 10 Com.	TX- Port 4	CH 10 +	Alm Pt 4	
11	22	RX- Port 6	Relay 11 Com.	RX- Port 5	CH 11 +	Alm Pt 6	
12	24	TX- Port 6	Relay 12 Com.	TX- Port 5	CH 12 +	Alm Pt 8	
13	26	RX- Port 7	Relay 13 Com.	RX- Port 6	CH 13 +	Alm Pt 10	
14	28	TX- Port 7	Relay 14 Com.	TX- Port 6	CH 14+	Alm Pt 12	
15	30	RX- Port 8	Relay 15 Com.	RX- Port 7	CH 15 +	Alm Pt 14	Port 1 RX-
16	32	TX- Port 8	Relay 16 Com.	TX- Port 7	CH 16 +	Alm Pt 16	Port 1 TX-
17	34		Relay 17 Com.	GND Port 1		Alm Pt 18	Port 2 RX-
18	36		Relay 18 Com.	GND Port 2		Alm Pt 20	Port 2 TX-
19	38		Relay 19 Com.	GND Port 3		Alm Pt 22	Port 3 RX-
20	40		Relay 20 Com.			Alm Pt 24	Port 3 TX-
21	42		Relay 21 Com.			Alm Pt 26	Port 4 RX-
22	44		Relay 22 Com.			Alm Pt 28	Port 4 TX-
23	46		Relay 23 Com.			Alm Pt 30	
24	48		Relay 24 Com.			Alm Pt 32	
25	54	Fuse Alarm	Fuse Alarm	Fuse Alarm	Fuse Alarm	Fuse Alarm	Fuse Alarm
			(Table cont	inued on next pag	ge.)		
26	1	RX+ Port 1	Relay 1 N. O.	RXD Port 1	CH 1 -	Ctrl Pt 1A	CH 1-

Table 4.P - Expansion Card Pin-Outs for Amphenol 50-Pin Connector

Amphenol Connector Pin Number	J3 (on Main KDA)	4 and 8 Port TBOS	LR-24 Relay Card	7-Port Serial Card	8 & 16 Channel Analog	EXP- 832	8 Analog/ 4 TBOS
27	3	TX+ Port 1	Relay 2 N. O.		CH 2 -	Ctrl Pt 2A	CH 2-
28	5	RX+ Port 2	Relay 3 N. O.		CH 3 -	Ctrl Pt 3A	CH 3-
29	7	TX+ Port 2	Relay 4 N. O.	RXD Port 2	CH 4 -	Ctrl Pt 4A	CH 4-
30	9	RX+ Port 3	Relay 5 N. O.	RXD Port 3	CH 5 -	Ctrl Pt 5A	CH 5-
31	11	TX+ Port 3	Relay 6 N. O.	TXD Port 3	CH 6 -	Ctrl Pt 6A	CH 6-
32	13	RX+ Port 4	Relay 7 N. O.		CH 7 -	Ctrl Pt 7A	CH 7-
33	15	TX+ Port 4	Relay 8 N. O.		CH 8 -	Ctrl Pt 8A	CH 8-
34	17	RX+ Port 5	Relay 9 N. O.	RX+ Port 4	CH 9 -	Alm Pt 1	
35	19	TX+ Port 5	Relay 10 N. O.	TX+ Port 4	CH 10 -	Alm Pt 3	
36	21	RX+ Port 6	Relay 11 N. O.	RX+ Port 5	CH 11 -	Alm Pt 5	
37	23	TX+ Port 6	Relay 12 N. O.	TX+ Port 5	CH 12 -	Alm Pt 7	
38	25	RX+ Port 7	Relay 13 N. O.	RX+ Port 6	CH 13 -	Alm Pt 9	
39	27	TX+ Port 7	Relay 14 N. O.	TX+ Port 6	CH 14 -	Alm Pt 11	
40	29	RX+ Port 8	Relay 15 N. O.	RX+ Port 7	CH 15 -	Alm Pt 13	Port 1 RX+
41	31	TX+ Port 8	Relay 16 N. O.	TX+ Port 7	CH 16 -	Alm Pt 15	Port 1 TX+
42	33		Relay 17 N. O.			Alm Pt 17	Port 2 RX+
43	35		Relay 18 N. O.			Alm Pt 19	Port 2 TX+
44	37		Relay 19 N. O.			Alm Pt 21	Port 3 RX+
45	39		Relay 20 N. O.			Alm Pt 23	Port 3 TX+
46	41		Relay 21 N. O.			Alm Pt 25	Port 4 RX+
47	43		Relay 22 N. O.			Alm Pt 27	Port 4 TX+
48	45		Relay 23 N. O.			Alm Pt 29	
49	47		Relay 24 N. O.			Alm Pt 31	
50	53	Fuse Alarm	Fuse Alarm	Fuse Alarm	Fuse Alarm	Fuse Alarm	Fuse Alarm

NIA and NAC expansion cards

The NIA card is used for applications requiring SNMP protocol over Ethernet. The NAC card is used for applications requiring communications with a T/MonXM or IAM element manager over Ethernet.

An RJ-45 connector for the Ethernet port is located on the KDA back panel, behind the expansion card slot. (See Fig. 4.14.) Table 4.Q gives the connector pin-outs.

Table 4.Q - Ethernet Connector Pin-outs

Function	RJ-45 (C1) Pin No.
TX+	1
TX-	2
RX+	3
RX-	6



Fig. 4.15 - RJ-45 Connector for Ethernet is Located Behind the Expansion Card Slot

This page intentionally left blank

Section 5 - T/KDA



This section describes how to use the T/KDA software to configure the KDA 864.

T/KDA software is an editor and loader used to configure the KDA 864. T/KDA may also be used to monitor the status of alarm inputs and operate control relays. This document supports versions 2.1i thru q. (To verify version press F9 from the Main Menu screen.)

NOTE: This software is designed to operate under DOS, not Windows (tm). However, it can be opened via an icon in Windows 3.1 or Windows 95, but it runs in DOS mode (see pp. 5-4 and 5-5).

Standards

Documentation Standards

" Valid responses and items needing special attention may be enclosed in "Double Quotes". Therefore, a "Y" or "N" means valid inputs are the letter Y or N, but the quotes are not entered.

<ENTER> Denotes the Enter or carriage return key on the computer's keyboard.

Software Standards

Highlight

The T/KDA software was designed to work in color mode. The program will highlight items as follows:

See Menu Item Hot Keys in Tables 5.A & 5.B. **1. Selected items** are displayed in dark background with a color foreground and the "short cut key" letter in color.

2. Unselected items are displayed in dark background color of the window with the "short cut key" letter in color. Pressing a short cut key activates that menu item.

F10 & Esc

In general, the **F10** key and the **Esc** key work interchangeably. The escape key will almost always lead back to the Main Menu. The following rules apply to the escape key:

1. When editing a group of fields, it will take you to the first field. If you are editing the first field, it will exit that mode.

2. When at a submenu, it will exit and return to the previous menu.

3. When at the Main Menu, it will position you to exit the program.

Up Arrow

The up arrow will usually do one of two things:

- 1. Select the previous field (edit modes).
- **2.** Select the preceding item (monitor modes).

WARNING ! Always exit the program cleanly. This means that you must execute the "Quit" function from the Main Menu. NEVER turn off the computer before exiting the program. Doing so could corrupt the data files!

Standard Field Editing

Fields are type checked. That is, if a valid entry for a certain field is alphabetic and a number is pressed, the user is alerted to the error by a beep.

When editing all files, the following editing functions are available:

Key	Function
<enter></enter>	Accepts the field or highlighted menu item.
Ctrl Z	Erases current line (zaps).
Ctrl R	Restores the original contents of the field prior to editing.
Back Arrow	Deletes the previous character.
Ctrl H	Lists the editing keys that are available.

 Table 5.A - Hot Keys Available in all Editing Functions

In most cases the following additional keys are also active:

Кеу	Function				
Left Arrow	Move <i>left</i> 1 character within field.				
Right Arrow	Move <i>right</i> 1 character within field.				
Ctrl-Home	Move to the <i>start</i> of the field.				
Ctrl-End	Move to the end of the field.				
Del	Delete the current character.				
Ins	Toggle <i>insert</i> mode. (Types over current position.)				
Ctrl-Left Arrow	Moves cursor <i>left</i> to previous word.				
Ctrl-Right Arrow	Moves cursor <i>right</i> to next word.				
Ctrl-K or Alt-K	Delete to end of line.				
Menu Item Hot Keys	Pressing the hot key (reversed-out letter in a menu item name) will activate the item if menu verification is OFF. (Table 5.C). If the menu verification is ON, type "Y" after pressing the hot key to activate.				

Table 5.B - Hot Keys Available in Most Editing Functions

Screen Features

Default Box

Some data fields in the T/KDA software allow you to call up the Default Box, by pressing Tab, to aid you in the selection process. The Default Box will display the valid selections for the current field that is being edited. You can select from the Default Box or type in the entry desired. To select from the Default Box use the keys below, then press the <ENTER> key:



Tab or Down Arrow: Moves the Select Bar one selection Down.

Shift-Tab or Up Arrow: Moves the Select Bar one selection Up.

Those fields that feature the Default Box are noted in the tables by the Tab key Icon.

Prompt Line

The prompt is the second line up from the bottom of the screen or, in some cases, the bottom line in a window. The prompt line lists field value ranges and parameters.

Function Key Line

The bottom line in a screen lists the active function or "hot" keys.

The top line in a screen lists the active file name.

Refer to Fig. 5.1 for an illustration of a typical screen with these features.



Fig. 5.1 - Example Screen Showing Default Box, Prompt Line and Function Key Line

Installing Under MS-DOS

The T/KDA software runs under a program called T/Config, which is included on the disk supplied with the KDA unit. If T/KDA is being run on a computer that already has T/Config installed, we recommend that you re-install it to be sure that you are using the latest version.

NOTE: If T/Config will be installed on a PC running Windows 3.1, go to p. 5-4. If it will be installed under Windows 95, go to p. 5-5.

To install T/Config, place the disk in the computer's A drive and type a:<ENTER>. Type tinstall <ENTER>. Follow the directions on the screen. This will install both the T/Config and the T/KDA programs. Return to step 3 in the Windows installation procedure or skip to Start T/Config on p. 5-6.

Installing Software Under Windows 3.1

This procedure will result in a T/Config icon on the Windows desktop. Double-clicking on the icon will automatically load T/Config. Proceed as follows:

1 Start your computer and go into Windows. With the Main application window displayed, double click on the MS-DOS prompt icon.



The MS-DOS screen will appear. The DOS prompt will show the letter of your hard drive, followed by "\windows>."

2	Proceed with a normal install, as outlined on p. 5-3.	
-		Eile Ontions Window Help
3	Return to the C drive (C: <enter>).</enter>	<u>rice</u> <u>opaons</u> <u>minuow</u> <u>n</u> cip
0	Type "Exit." The Windows Desktop will appear.	
	With the Program Manager window	
	displayed, click on File on the Menu bar.	File Manager Control Panel Print Manager PIF Editor Read Me MS-DOS Promot
T		
1	he File Menu will appear.	
	New	New Program Object
4	Click on New.	
•	<u> </u>	Program tem Cancel
Т	he New Program Object window will appear.	
5	Select the Program Group button and click OK .	
J		
Т	he Program Group Properties window will appear.	Program Group Properties
		Description: DPS OK
6	For the Description field type in "DPS."	Group File:
U	The Group field may be left blank.	
	Click OK .	<u>H</u> elp
		Notaty T/Graft/ Windows Unity Printer ATM Control T/Bernot
Т	he DPS window will appear.	Program Manager
7	Again click on File on the Menu bar.	File Options Window Help
1		
Т	he File menu will appear.	File Manager Control Panel Print Manager PIF Editor Read Me MS-DDS
	New	
0	Click on New Open En	
0	<u>Move</u> F7	New Program Object
Т	he New Program Object window will appear.	
-		Program Group
•	Select the Brearam Item button and click OK	Program Item Help
9	Select the Program item button and click OK .	
Т	be Program Item Properties window will appear	
1	ne i rogram tem i roperties window win appear.	Program Item Properties
4.0	For the Description field type in "T/Config"	Description: T/Config OK
10	For the Command Line field type in T/Conlig.	C:\TCONFIG\TCONFIG.EXE Cancel
	For the Working Directory field type in "C.\TCONFIG\TCONFIG	C:\TCONFIG
	Click Change Icon	Shortcut Key: None Change Icon.
		<u>Help</u>
А	window will appear	
indi	cating there is no icon	Change Joon
Indi	Click	
Π		Current Icon:
т	he Change Icon window will annear	
	Click Browco	
12		
Т	be Browse window will appear displaying the directory structure	
1	ne browse whitew win uppear, aisplaying the anothery structure.	File Name: Directories:
		tconfig.ico c:\tconfig
17	Highlight the C drive TCONFIG directory and TCONFIGIC) file
13	Click OK.	tooning.co
		tdpm.exe tdpm216.exe
Т	he DPS window will appear, displaying the T/Config icon.	tdpmem.exe tdpmt.exe
-		List Files of Type: Drives:
1 4	Go to Start T/Config on p. 5-6	Icon Files ± 🖃 c: ms-dos_6 ±
14		
Installing Software Under Windows 95

The following procedure will result in a T/Config icon on the Windows 95 desktop. Double-clicking on the icon will automatically perform the steps of going to DOS and loading T/KDA-TS. Proceed as follows: Start your computer and wait for the Windows 95 1 10 desktop to appear. Click the Start button, point to Programs and click 100 on the MS-DOS menu item. The MS-DOS screen will appear. The DOS prompt will show the letter of your hard drive, followed by "\windows>." 2 Proceed with a normal install, as outlined on p. 5-3. p 1 Type "Exit." 3 9/ The Windows 95 Desktop will again appear. Arrange Icons Line up Icons Move the cursor to an area of the Δ em you want to by clicking Brow screen with no icon and click the <u>U</u>ndo Delete right mouse button. mmand line: \\TCONFIG\TCONFIG.EXE New Folder Shortcul Properties The icon menu will appear. Sound Corel PHOTO-PAINT Point to New and click on Shortcut. Text Document 1 The Create Shortcut window will appear. Enter "C:\TCONFIG\TCONFIG.EXE" on the Command Line 6 Click on Next. Enter "T/Config" on the Name line ct an icon for the shortcut: Click on Next. Highlight the correct icon. Click on Finish. Se<u>n</u>d To Cat Сору The icon will appear on the desktop. Create Shortcut <u>D</u>elete Move the cursor over the icon and click the 7 Rename < <u>B</u>ack right button. From the menu that appears, click on "Properties." ram Font Memory Screen Misc Generat The T/Config Properties window will appear. 2AMENU) IB Click on the "Program" tab. 8 Click on the "Advanced" box. Cmd line S-DDS\E2AMENU.EX Working The Advanced Program Settings window will appear. Batch file Advanced Program Settings Shortcut key: None PIF name: C:\WINDOWS\DESKTOP\E2AM Choose "MS-DOS" mode. 9 . E Bun Normal win Ŕ Close MS-DOS mode If there is a check-mark in the box in front of "Warn before entering MS-DOS mode," Warn before entering MS-DOS mode Advanced... Change Icon... Ise current MS-DOS configuration click on the box to remove the check-mark. cify a new MS-DOS configuration OK. Cancel 10 Click on the "OK" box that appears ΞŢ at the bottom of the window until the desktop is again displayed. *NOTE: Upon exiting the program, the computer will reboot.* 10 Go to Start T/Config on p. 5-6.

ÓК

Cance

Start T/Config

To run the program from DOS, select the hard drive and the T/Config directory. Type TCONFIG <ENTER>.

To run the program from Windows 3.1 or Windows 95, double-click on the T/Config icon.

The T/Config menu will appear (Fig. 5.4).



in the TConfig Directory

System Parameters

	System Parameter	2′
Color Mode Screen Saver Menu Verification Modem Disconnect Ti	: Color CRT : 10 Minutes : YES mer: 10 Minutes	Color CRT Color LCD Mono LCD

<ENTER>.

The first time T/Config is started, select "System Parameters" from the T/Config menu

Enter system parameter values according to Table 5.C and Fig. 5-5.

Fig. 5.5 - Set System Parameters When Running T/Config for the First Time

Table 5.C - Field Names and Descriptions in the System Parameters Screen

Field Name	Description
Color Mode	Select type of display from the default box: Color CRT Color LCD Mono LCD
Screen Saver	Set time of no activity before screen saver starts. (1 to 30 minutes. Default = 10 minutes. Enter 0 to disable.)
Menu Verification	Pressing the short cut key (reversed-out letter in a menu item name) will activate the item if menu verification is NO. If the menu verification is YES, "Y" must be typed after pressing the short cut key to activate.
Modem Disconnect Timer	Connection time before automatic disconnect (applies to optional secondary pad dial-up modem only). (3 to 90 minutes. Enter 0 to disable.)

When the last field entry is made, the T/Config menu will again be displayed.

Start T/KDA

Highlight T/KDA -TS <ENTER>.

The first screen will request initials. Enter your initials then press <ENTER>.

T/kda LOGON

Please enter your initials : CDH

Fig. 5.6 - Enter Initials to Log On

Main Menu

The Main Menu appears in the upper left portion of the screen after logging in with user initials. An example of the Main Menu is illustrated in Fig. 5.7.

One line on the menu will always be selected. The selected line is the one that is highlighted. The selection may be changed in two ways:

The first method is to use the up and down arrows to change the highlighted selection. The menu "wraps around" from top to bottom and vice-versa. Once the desired option is highlighted press <ENTER> to select.

The second and fastest way of selecting an option is to type either the highlighted or reverse video uppercase letter or the corresponding number of that option (short cut key). For example, to select "Connect" from anywhere on the Main menu, simply type "C" and press <ENTER>.

Fig. 5.7 - Select T/KDA Functions at the Main Menu

The Short Cut Keys are highlighted letters/numbers.

 Table 5.D - Hot Keys Available in the Main Menu Screen.

Кеу	Description	
Left Arrow	Prev KDA. Loads the previous defined KDA database.	
Right Arrow	Next KDA. Loads the next already defined KDA database.	
F10/Esc	Exit. These keys move the highlight bar to the Quit option. At the Quit option, press <enter> to leave the T/KDA program.</enter>	

Important: All configuration data must be saved by using the F8 key in order to become effective. Using the F10 key will exit without saving.

5-7



New Configuration

The New Configuration item in the Main Menu is used to define a new KDA configuration file.

ſ	New Configuration		
	Name : YALE		
	Site Name : YFI OFFICE Comment : KDA AT AIR TERMINAL		
	Site Number : 1 Phome Number: 222-2222		

Fig. 5.8 - The New Configuration Window Shows No Default Box

If New Configuration is chosen, the fields will be blank. Fill them in according to Table 5.E. An example of the New Configuration window is shown in Fig. 5.8.

Field	Description
Name	Enter the KDA database name or delete an existing one from the default box.
Tab	
Site Name	Enter the site name.
Comment	Enter the database description or any other additional information for your use.
Site Number	An I.D. number used when reporting alarms to T/MonXM masters.
Phone Number	Enter the dial string used to contact the KDA unit on the secondary or dial port.

Table 5.E - Field Names and Descriptions in the Open KDA Window

The KDA system database Name and the Site Name appear at the top of the screen after they have been defined.

Open Configuration

NOTE: Several databases can exist in T/KDA.

If Open Configuration is chosen, the available configurations will be listed in a default box. When a configuration is chosen, the configuration name will appear on the line at the top of the screen. Configurations can also be chosen using the left and right cursor arrows.



Fig. 5.9 - Once Defined in the Protocol Screen, Satellite Names are Listed in the Open KDA Name Default Box

Satellite Names

If one or more satellite KDAs are associated with the base KDA, their Name must be the same as the base, with the number 1, 2 or 3 following. The Edit Protocol screen provides a field for defining the number of associated satellite KDAs. Once this number has been entered, the Satellite Names will automatically appear in the Open Configuration default box for the Name field (Fig. 5.9).

Edit Configuration

Select Edit Configuration from the Main Menu to display the Edit Configuration sub-Menu. (Fig. 5.10). The items in this sub menu are listed in the order they are used. Each item is described under the subheadings that follow.

New (Open Edit	onfiguration Configuration
Conn	Edit Site Definition
Conn	Edit Phones
Repo	Edit Alarms
Soft	Edit Pelays
Util	Edit Protocol
Quit	Edit Expansion Cards
	Edit Advanced
	Quit

Fig. 5.10 - Select Editing Items from the Edit Configuration Submenu

Edit Site Definition

Calls up a window similar to the New Con-

figuration window. Edit Site Name, Site Number, Phone Number and Comments fields. Refer to Fig. 5.8 and Table 5.E.

Edit Phones

S Calls up a window for entering the phone numbers the KDA should call to report alarms. Two numbers can be entered. Valid only if the KDA is equipped with a 212T dial modem.

Edit Alarm Points

The Edit Alarm Points option allows you to build descriptions and assign attributes for the 64 alarm points that are assigned to the KDA. Refer to Figs. 5.11 and 12 and to Tables 5.F and G.

	DESCRIPTION	ALARM POLARITY	alm Qual	QUAL UNITS
6	FRONT GATE	RVS	5	MIN
7	DOOR NO. 1	NRM	1	MIN
8	DOOR NO. 2	NRM	1	MIN
9	BEACON NO. 1	RVS	5	SEC
10	BEACON NO. 2	RUS	5	SEC
11	POWER	NRM	1	SEC
12	STBY PWR	RVS	1	SEC
13		NRM	0	SEC
		пкп	0	SEC

Fig. 5.11 - Enter Descriptions and Attributes for the 64 Alarm Points

Table 5.F - Field Names and Descriptions in the Edit Alarm Points Window

Field	Description	
DESCRIPTION	Used in Monitor Mode to describe each alarm point. Enter up to 13 characters.	
ALARM POLARITY	Indicates the polarity of the alarm point. "Normal" is normally open for a non-alarm condition and closed (Ground Closure) for an alarm. If Polarity is "Reversed," then normally closed is a non-alarm condition and open is an alarm. Valid entries are NRM and RVS.	
DIAL TYPE	Specifies whether, upon an alarm condition, the alarm point will immediately dial out to report the alarm, or whether it will hold the alarm until it is polled from the master. Valid entries are : DIAL - Dials upon alarm occurrence POLLED -Alarm held until polled <i>NOTE: This field is effective only if the KDA is equipped with a dial modem on the secondary port.</i>	
ALM QUAL	Length of time the alarm must exist before an alarm is activated. 0 to 106 units (see below).	
QUAL UNITS	Units assigned to the alarm qualification time. Units are assigned for groups of eight points. See F1 in Table 5.G.	

Table 5.G - Hot Keys Available in the Edit KDA Points Window

Кеу	Description
Up Arrow	Moves the cursor up one line.
Down Arrow	Moves the cursor down one line.
Pg Up	Moves the cursor up one page. (8 points)
Pg Dn	Moves the cursor down one page. (8 points)
Home	Select. Moves the cursor to the first 8 points.
End	Select. Moves the cursor to the last 8 points.
F1	Qual. Set a units multiplier for each set of 8 points (i.e., 1-8, 9-16, 17-24, 25-32, 33-40, 41-48, 49-56 and 57-64). The units multiplier can be 0.1 sec (100 milliseconds), 1 second or 1 minute. Each point is set for a value between 1 and 255. Thus, the range of times is from 0.1 to 25.5 seconds in 0.1 second increments, from 1 second to 255 seconds in 1 second increments and from 1 minute to 255 minutes in 1 minute increments. The maximum error for each range is equal to the multiplier value. See screen illustration in Fig. 5.11. Select 0.1 sec, sec or min from the default box.
F3	Delete Point. Deletes the definitions for the selected point. This option is only available from the Desc field.
F8	Save. Saves the point definitions.
F9	Displays on line help.
F10/Esc	First Field/Abort. Moves the cursor to the first field and then the Main Menu.

	— Edit Alarms ——	
Edit	Alarm Qualification	Units
Qual Units for Qual Units for	points 1- 8: MIN points 9-16: SEC points 17-24: SEC points 25-32: SEC points 33-40: SEC points 41-48: SEC points 49-56: SEC points 57-64: SEC	.1s Sec MIN

Fig. 5.12 - Set Alarm Qualification Units for Groups of 8 Alarm Points in the Edit Alarm Qualification Units Window

Edit Relays

The Edit Relays option allows you to build descriptions and assign momentary periods for the control points that are assigned to the KDA. Refer to Fig. 5.13 and to Table 5.H.



Fig. 5.13 - Enter Descriptions and Momentary Period for the Control Points

Table 5.H - Field Names and Descriptions in the Edit Relays Window

Field Name	Description	
Momentary Period (sec)	Time period the relays remain operated when a momentary command is sent. (0.1 to 25.5 sec- retary) The Momentary Period entered applies to all eight relays.	
Description	Used in Monitor Mode to describe each relay. Use up to 13 characters.	

Table 5.I - Hot Keys in the Edit Relays Window

Кеу	Description	
Up Arrow	Moves the cursor up one line.	
Down Arrow	Moves the cursor down one line.	
F8	Save. Saves the point definitions.	
F9	Displays on line help.	
F10/Esc	First Field/Abort. Moves the cursor to the first field and then the Main Menu.	

Edit Protocol

The Edit Protocol option allows you to specify the remote responder protocol type and characteristics. Whether the configuration is for a KDA with no satellites or for a base KDA with satellites, select the protocol that matches your network requirements. "None" would rarely be chosen. Refer to Fig. 5.14 and Table 5.J.

NOTE: Before configuring a satellite KDA the base unit must be defined. Satellite configurations will be automatically created if the shelf quantity is 1, 2 or 3. Satellites will be set for DSAT protocol. Fields in the Satellite Edit Protocol screens should not be changed.

Table 5.J - Field Names and Descriptions	in	the
Edit Protocol Window		

Field Name	Description
PRIMARY	Protocol used on the primary port. Select
PROTOCOL	from :
Tab	DCP1.
	DCPF,
	DCPS,
	SNMP,
	TBOS, (ver. 2.1q)
	UDP (for NAC card),
	NONE

Fig. 5.14 - Select Protocol in the Edit Protocol Window

DCP Family of Protocols

Control ID: 1		-
ID Description 1 GENERATOR 2 RLY 2	Status Opr Rls	
C)ontrols : O)pr R)ls	M)om (ESC) ? R	Ľ
Control ID: 1		L
ID Description 1 GENERATOR 2 RLY 2	Status Rls Rls	
C)ontrols : O)pr R)ls	M)om (ESC) ? M	L
Control ID: 2		L
ID Description 1 GENERATOR 2 RLY 2	Status R1s R1s	
C)ontrols : 0)pr R)ls	M)om (ESC) ? _	Ŀ

Fig. 5.15 - Edit Protocol Window, DCP Protocol Family

Table 5.K - Field Names and Descriptions in the Edit Protocol Window, DCP Protocol Family

Field Name	Description
Responder Baud	Data rate the primary port will use. Possible values are: OFF, 300 Baud, 600 Baud, 1200 Baud, 2400 Baud, 4800 Baud, 9600 Baud. Default = 1200.
Responder Parity	Parity that the primary port will use. Valid values are Even, Odd and None. Default = None
DCP Address	Address the KDA will respond to when polled. Valid addresses are 1-255. 0 = Disabled.
Connection Type	Physical interface module that is plugged into the docking bay. Valid interfaces are : RS232, T212 modem, T202 Modem (half duplex), RS485, RS422, T202F Modem (full duplex).
RTS Lead/Tail Times (ver. 2.1q)	RTS lead time, Range: 1 - 213 milleseconds [30], RTS tail time , Range 10 - 213 milleseconds [10].
Relay 8 Response to RTS (ver. 2.1q)	Defines how control point relay #8 should respond when RTS is asserted. Set for no response (NONE), activate (CLOSE) or deactivate (OPEN). Press TAB to select from default box.
Satellite Shelf Qty	Number of Satellite KDA*s (0, 1, 2, or 3)
Report Satellite Failure	Yes or No.
Periodic Full Updates	Yes or No. "Yes" causes remotes to generate a full alarm status report every 250 polls, as opposed to the normal report that gives only changes since the last report. "No" provides full status reports only when requested by the polling master.

SNMP Protocol

Use the screen shown in Fig. 5.16 and the field explanations in Table 5.L to provision the host KDA unit for the NIA card.



Table 5.L - Field Descriptions in the Edit Protocol Window, SNMP Protocol

Fig. 5.16 - Edit Protocol Window, SNMP Protocol

Field	Description
Unit IP Address	IP Address of this KDA. Range is 000.000.000.000 to 255.255.255.255.
Subnet IP Mask	Subnet IP Mask for this KDA. Range is 000.000.000.000 to 255.255.255.255.
Gateway IP Address (v.1.2q)	Gateway address for this KDA. Range is 000.000.000.000 to 255.255.255.255.
Unit Id	Assign an ID for this unit if there are other units on the net. Range is 1 to 255.
Trap Manager IP Address	IP Address for TRAP reporting. Range is 000.000.000.000 to 255.255.255.255.
Community Name - GET (v.1.2q)	Enter number or letters as assigned by network administrator.
Community Name - SET (v.1.2q)	Enter number or letters as assigned by network administrator.
Community Name - TRAP (v.1.2q)	Enter number or letters as assigned by network administrator.
Pass-through port: BAUD Rate (v.1.2q)	Data rate to use on the pass-through port (OFF, 300, 600, 1200, 2400, 4800, 9600, 14400, 19200, 28800, 38400, 57600, 115200)

Note: Be sure to obtain addressing information from network manager. An incorrect address can cause grave system problems.

TBOS Protocol (ver. 1.2q)	NetDog v1.0H-1 Configuration Eldit M)onitor P)ing mo(D)em N)Vram e(X)it ? M A)larms P)ing Info C)ontrols S)ystem (ESC) ? S ID Description Status 36 Lost Provisioning Clear 41 Modem not Responding Clear 42 No Dialtone Clear 43 SNMP trap not sent Alarm 44 Pager Que Overflow Clear 45 Notification Failed Clear Ollarme P)ing Info C)ontrols Shurtar (ESC) ?	
	nyidina rying into cyontrois system (Loc) : _	

Fig. 5.17 - Edit Protocol Window, TBOS Protocol

1.

Table 5.M - Field Names and Descriptions in the Edit Protocol Window, TBOS Protocol

Field Name	Description
Responder Baud	Data rate the primary port will use. Possible values are: OFF, 1200 Baud, 2400 Baud. [1200].
Responder Parity	Parity that the primary port will use. Valid values are Even, Odd and None. [ODD]
Connection Type	Physical interface module that is plugged into the docking bay. Valid interfaces are : RS232, T212 modem, T202 Modem (half duplex), RS485, RS422, T202F Modem (full duplex).
RTS Lead/Tail Times (ver. 2.1q)	RTS lead time, Range: 1 - 213 milleseconds [30], RTS tail time , Range 10 - 213 milleseconds [10].
Relay 8 Response to RTS (ver. 2.1q)	Defines how control point relay #8 should respond when RTS is asserted. Set for no response (NONE), activate (CLOSE) or deactivate (OPEN). Press TAB to select from default box.
Satellite Shelf Qty	Number of Satellite KDA*s (0, 1, 2, or 3)
Report Satellite Failure	Yes or No.

UDP Protocol

Select UDP Protocol when the KDA is to report via Ethernet TCP/IP to a T/MonXM or



Fig. 5.18 - Edit Protocol Window for UDP (to Transport Data via Ethernet TCP/IP to T/MonXM or IAM) IAM element manager using the NIA card in the KDA's expansion card slot.

Refer to Fig. 5.18 and Table 5.N to provision the host KDA unit for the NIA card.

Table 5.N - Field Descriptions in the Edit Protocol Window, TCP/IP Transport (UDP)

Description
IP Address of this KDA. Range is 000.000.000 to 255.255.255.255.
Subnet IP Mask for this KDA. Range is 000.000.000 to 255.255.255.255.
Gateway address for this KDA. Range is 000.000.000.000 to 255.255.255.255.
Assign an ID for this unit if there are other units on the net. Range is 1 to 255.
Data rate to use on the pass-through port (OFF, 300, 600, 1200, 2400, 4800, 9600, 14400, 19200, 28800, 38400, 57600, 115200)

Note: Obtain addressing information from network manager. An incorrect address can cause grave system problems.

DSAT Protocol (Satellites)

The screen in Fig. 5.19 appears only when a predefined satellite KDA is configured.



Table 5.0 - Field Names and Descriptions in theEdit Protocol Window, DSAT Protocol

Field Name	Description
SATELLITE SHELF QTY	Valid satellite shelf quantities are 0, 1, 2 and 3. Satellites will be listed in the Open Configuration menu after they have been entered here. Press F8 to save. If the satellite shelf quantity is 1, 2 or 3, a window explaining satellite addressing will appear (Fig. 5.15).

Fig. 5.19 - Edit Protocol Window for a Satellite KDA



Edit Expansion Cards

If the KDA is equipped with an expansion card, it is to be defined now. Configuration screens for the expansion cards are explained on the following pages or in the operation guides for the individual cards.

 Table 5.P - Field Names and Descriptions in the Edit Expansion Cards Window

Field	Description
Expansion Type	Press the Tab key to enter the default box and select from: None, 4 CHAN TBOS, 8 CHAN TBOS, Analog (8 Chan), Analog (16 Chan), LR-24, SR-24 8 Analog / 4 TBOS EXP-832 7 Port Serial. Use the appropriate procedure below to configure the expansion card. If None is selected, exit to the Edit Configuration sub-menu.
	Use the appropriate procedure below to configure the expansion card. If None is selected, exit to the Edit Configuration sub-menu.

4 CHAN TBOS

Refer to Fig. 5.21 and Table 5.Q.

8 CHAN TBOS

Refer to Fig. 5.21 and Table 5.Q.

8 Analog / 4 TBOS (TBOS Portion)

			—— Ed	it Expansion Cards	L
					L
ED	(PANSIUN T	YPE: 8 CH	IAN TBUS		L
					L
					L
					L
PC	IRT ENABL	ED BAUD	PARITY	POLL LIST	L
					L
1	YES	2400	ODD	1-8	L
2	YES	1200	ODD	1	L
3	NO	-	-	-	L
4	YES	2400	ODD	2,3	L
5	YES	1200	ODD	2,3	L
6	NO	-	-	-	L
2	YES	2400	ODD	2-5	L
8	NO.	-	-	-	L
		YES			
		NO			L
					ł.

After defining analog channels and while still in the Edit Expansion Ports Screen, press F5 to observe the TBOS Configuration window. Refer to Table 5.Q and Fig. 5.21 for a brief explanation of the fields in the configuration window.

When all channels have been defined, exit the Edit Expansion Ports mode by using F8 to save. To exit this mode without saving use F10.

Fig. 5.21 - Enter Field Values to Configure the 4 or 8 Port TBOS expansion cards or the TBOS Portion of an 8 Analog / 4 TBOS Expansion Card

 Table 5.Q - Field Names and Descriptions in the TBOS Expansion Card Configuration Window

Field	Description
Enabled	Only the ports that are currently connected to TBOS sources should be enabled. Press Tab to select from the default box. Yes to enable, No to disable. If port is disabled, cursor will skip to next column.
Baud	Select 1200 or 2400 from the default box.
Parity	Fixed at odd. Press <enter> to move to the next field.</enter>
Poll List	Enter numbers for the displays to be interrogated in the TBOS source. Leave out unavailable displays to save polling time and to prevent unnecessary failed display alarms. Separate numbers with commas or dashes. (Example: 1,3,5 or 2-6)



Fig. 5.22 A Version of the 8 Channel Analog Card Requires Manual Range Entry.

Fig. 5.23 - Enter Field Values to Configure the Analog Expansion Card

Analog (8 Chan)

This early version of the analog card lacks auto ranging. Refer to Fig. 5.22 and Table 5.R. You will have to enter a range.

Analog (8 B rev) and Analog (16 Chan)

These two cards are identical, except for the number of channels. Refer to Fig. 5.23 and Table R. Because of the auto ranging feature, you will not have to enter a range.

8 Analog / 4 TBOS

The 8 Analog / 4 TBOS card provides 8 channels of analog inputs and 4 TBOS ports. For a complete explanation of this card, see the individual operation guide. For the analog portion refer to Table 5.R and Fig. 5.23. See p. 5-15 for the TBOS portion.

Table 5.R - Field Names and Descriptions in the Analog Portion of the 8 Analog / 4 TBOS Expansion Card Configuration Window

Field Name		Description		
EXPANSION TYPE	Type of expansion card [Analog (8 CHAN), Analog (8 B rev), Analog (16 CHAN), 8 ANALOG / 4 TBOS]			
Thresholds Only	Y = Report thresholds only. N = Report thresholds and analog values (takes more time to report).			
Chn	Point number (fixed field).			
Description	Enter the point description	. Up to 14 characters.		
Rng	Range (8 Chan rev A only). Select a range that supports the values to be measured. Select positive or negative 0 to 6 VDC, 0 to 15 VDC, 0 to 32 VDC or 0 to 72 VDC.			
Dec Dig	Enter number of digits to d	isplay after decimal.		
Unt Lbl	Enter the Units label (VDC	, VAC, F, C, PSI, etc.). This is "native units."		
F1 - Analog Display Worksheet	Use the worksheet to calculate Offset and Scale values for each analog point. Enter Two Calibration Values from the Transducer Spec Sheet in the Worksheet Screen. This should be done before entering threshold values. Press F6 to set unity value for scale and offset.	Analog Display Worksheet Enter a pair of analog values and corresponding display units. The Display Scale and Display Offset used to convert voltage (or current) into display units is calculated automatically. Analog input type - Volts or Current (V/C) : C Current value 1: 4.00000 Unit value 1 : -45.000 MA Current value 2: 20.0000 Unit value 2 : 120.000 MA Calc Scale : 10.3125 Calc Offset: -86.250 Scale and Offset have been recalculated. Key through remaining entries on line to make changes effective. Fig. 5.24 - Enter Two Calibration Values from the Transducer Spec Sheet in the Worksheet Screen		
	Tal	ole continued on next page.		

Field Name	Description
MjOvr	Major over threshold. Enter the threshold value in "native units." NOTE: Bottom line in window will show the available range in "native" units and the value of the input voltage or current (in ma).
MnOvr	Minor over threshold. Enter the threshold value in "native units." NOTE: Bottom line in window will show the available range in "native" units and the value of the input voltage or current (in ma).
MnUdr	Minor under threshold. Enter the threshold value in "native units." NOTE: Bottom line in window will show the available range in "native" units and the value of the input voltage or current (in ma).
MjUdr	Major under threshold. Enter the threshold value in "native units." NOTE: Bottom line in window will show the available range in "native" units and the value of the input voltage or current (in ma).
Dial Ctrl	If the KDA is dial modem equipped, specify which threshold should cause it to dial the master. Choose from NONE, MJ (Major) or MJ/MN (Major and Minor). Use Tab to highlight choice, Press <enter> to select.</enter>
Dial on Clear	Dial master when voltage retreats past a threshold? (same as a cleared alarm) Y = Yes, N = No.
Qualify Period*	Qualification time period. Value is times the Qualify Resolution value (see next field). Prompt line gives ranges. HINT: For greatest qualification accuracy choose a resolution that will avoid low numbers. i.e.: 120 seconds gives better accuracy than 2 minutes.
Qualify Resolution*	Units and multiplier for qualification time period. Use tab to choose 0.1 sec, sec or min. < Enter>.

*Qualification periods apply only to dial-out reports. There is no delay on direct connect reports.

LR-24 or SR-24

EXPA	ISION TYPE: SR-24	Edit Expansion Cards
PNT	RELAY DESCRIPTION	MOMENTARY Period
1 2 3 4 5 6 7 8	XMTR A WEST XMTR B WEST XMTR A EAST XMTR B EAST	1.0 seconds 1.0 seconds 1.0 seconds 1.0 seconds 1.0 seconds 1.0 seconds 1.0 seconds 1.0 seconds 1.0 seconds 1.0 seconds

T		LR-	-24	1omenta:	ry Peri	iod	s=====	
Î T	Momentary Momentary Momentary Momentary	Period Period Period Period	for for for for	Points Points Points Points	1–6 7–12 13–18 19–24		1.0 1.0 1.0 1.0	(seconds) (seconds) (seconds) (seconds)
			-					

Fig. 5.25 - LR-24 and SR-24 Expansion Cards have the Fig. 5.26 - Set Momentary Control Period for Groups Same Fields of 6 Points

Enter information in fields per Fig. 5.25 and 26 and Table 5.S and T.

Table 5.S - Field Names and Descriptions in the Edit LR-24 / SR-24 Relay Expansion Card Windows

Field Name	Description
PNT	Fixed point number field.
RELAY DESCRIPTION	Name or description for the control point. Use up to 14 characters.
MOMENTARY PERIOD	Time the relay remains operated when a momentary command is sent. Default = 0.1 sec. Press F5 to edit.

Table 5.T - Hot Keys in the Edit LR-24 and Edit SR-24 Relay Expansion Card Windows

Кеу	Description
F3	Blank.
F5	Edit Momentary Period. The momentary operation period is set in groups of 6 points. Set each group for 0.1 to 25.5 sec. Groups are: Points 1-6, Points 7-12, Points 13-18, Points 19-24
F8	Save
F9	Help
F10/Esc	Exit

EXP 832

		— Edit Expa	unsion Ports	
EXPAN	ISTON TYPE: EXP-83 2	E×	cp Add 1: 4	
PNT	DESCRIPTION	POLL TYPE	DIAL TYPE	MOMENTARY PERIOD
1 2 3 4 5 6 7 8	FRONT DOOR TOWER LIGHT XMTR A XMTR B LOW BATT STBY PWR MUX CH 1-24 MUX CH 25-48	NRM RUS NRM NRM RUS NRM NRM	POLLED DIAL DIAL DIAL POLLED DIAL DIAL DIAL	

	SION TYPE: EXP-83	Z E	unsion Ports cp Add 1: 4	
	DESCRIPTION	POLL TYPE	DIAL TYPE	
32 C1 C2 C3 C4 C5 C5 C6 C7	LOCK DOOR UNLOCK DOOR START GEN SWITCH XMTR A SWITCH XMTR B	NRM	POLLED	10 3 3 3 3 3 3 3

Fig. 5.27 - Define Alarm Points at Upper Portion of Screen

Fig. 5.28 - Define Control Points at End of Screen

The first screen asks for the Type Card. Use the Tab key to highlight EXP-832 and press <ENTER>. (See Fig. 5.27)

Enter information for alarm and control points (see Figs 5.27 and 5.28 and Table 5.U.) Both alarm points and control points are defined in the same screen. Control points are listed after alarm point 32, beginning with C1. (Use down arrow key to reach the control point listings.)

Field	Description
Exp Add	Address for the EXP 832 (1-255). This address is independent of the host address. It must be a unique address on the T/MonXM or IAM DCPF interrogating port.
PNT	Fixed point # field. Alarms-32; Controls C1-C8.
DESCRIPTION	Point description (up to 13 characters).
POLL TYPE	Applies to alarms only. Indicates polarity of alarm point. "Normal" is normally open for nonalarm and closed (Grounded) for alarm. If Polarity is "Reversed," closed is nonalarm and open is alarm. (NRM and RVS)
DIAL TYPE	For alarms only. Specifies whether an alarm will cause the KDA to immediately dial out or whether it will hold the alarm until polled from the master. Valid Entries are : DIAL - Dials upon alarm occurrence POLLED - Alarm held until polled
MOMENTARY PERIOD	For Controls only. Period of time (in 10ths of a second), that the control point will remain activated when a momentary operate command is sent.

Table 5.U - Field Descriptions in the EXP-832 Screen

7 Port Serial

XPAN	SION TY	PE: 7	PORT SER	IAL Exp	Add 1: 3	Exp Add 2: 6
ORT	TYPE	BAUD	PARITY	WORD LEN	STOP BITS	POLL LIST
	ASCII ASCII ASCII	1200 2400 0FF	ODD ODD	8 8	2 2	

Fig. 5.29 - When Ports are Defined, Save with F8

The first screen after selecting Edit Expansion Ports asks for the type card. Use the tab key to highlight the type card (7 Port Serial) installed in the KDA and press <ENTER> to select it.

The next screen requires information to be entered for each ASCII and TBOS port.

Port Parameters

Refer to Fig. 5.29. The cursor will move to the the **BAUD** field for channel 1. Press <Tab> to list the available data rates. Notice that "**OFF**" is also a selection. Use the Tab key to highlight the desired selection and press <Enter>. The cursor will move to the next field. If OFF is selected, the cursor

will move down to the BAUD field for the next channel. Enter the information for each field per the Edit Parameters Table, below. For most fields, pressing the Tab key will display the available selections. When all ports have been defined, exit the Edit Expansion Ports mode by using **F8 to save**. Press F10 to exit without saving.

Field	Description
EXPANSION TYPE	Select ASCII (3 Chan).
CHAN	Displays what port you are setting.
TYPE	Displays protocol for the port. Ports 1-3 are ASCII. Ports 4-7 are TBOS.
BAUD	Set this to the baud rate of this port. Port 1: 300/600/1200/2400/4800/9600 Baud. Ports 2-7: 1200/2400 Baud.
PARITY	Set this to the Parity of this port. Odd/Even/None. Use odd for TBOS.
WORD LEN	7 or 8 Bits (ASCII ports only).
STOP BITS	1 or 2 (ASCII ports only).
POLL LIST	Set which displays (1-8) to poll for this TBOS port. To minimize scan time, only poll the displays that the TBOS device uses. (Ports 4-7 only)

Edit Advanced

Edit miscellaneous advanced parameters in the Edit Advanced window.

Edit f	Adu	anced
Calling Parameters Callout Delay Call Control	:	0:50 m:ss NORMAL
Alarm Parameters Use Alarm 1 for Local Ack Activate Relay 1 on COS		NO NO
Periodic Status Reporting Status Report Interval		0 hh:mm T212
Remote Unit Parameters Secondary Docking Module Secondary Baud Secondary Modem Init String		T212. 9600
Number of Rings		2

WARNING: Do not use E1, Q1 or V1 commands in the Secondary Modem Initialization String.

Fig. 5.30 - Set Local ACK and COS Relay Options in the Edit Advanced Window

Table 5.W - Field Names and Descriptions in the Edit Advanced Window

Field	Description
Calling Parameters	
Callout Delay	Delay between calls to pagers. 0 to 5 in 10 second increments.
Call Control	Normal: Call out for all dial-type alarms. Backup: Call only on communications failure.
Alarm Parameters	
Use Alarm 1 for local ACK Tab	Answering "YES" will assign Point 1 (first input point of the KDA) to be a local alarm acknowledg- ment input. When Point 1 is activated, all COS alarms will immediately be ACKed.
Activate Relay 1 on COS Tab	Answering "YES" will assign Relay 1 of the KDA to be designated as a COS alarm relay. This means that the relay will be closed when an alarm Change Of State occurs. Additional COSs will pulse the relay OFF for 100ms. The relay will release once all COSs have been acknowledged.
Periodic Status Reporting	
Status Report Interval	Time between dialed in status reports. 0 = Disables To enable, set for 00:10 to 42:30 in 10 minute intervals.
Remote Unit Parameters	
Secondary Docking Module	Physical docking module that is installed in the secondary docking pad. Select NONE, RS232 or T212 from the default box.
If 212 is selected, the followir	ng fields appear: (ver. 2.1q)
Secondary Baud	Data rate to use on the secondary port. Only selection is 1200 BAUD.
Secondary Modem Init. String	Remote modem initialization string. Enter 'F' to use factory default. WARNING: Do not use E1, Q1 or V1 commands in the string.
Number of Rings	Number of rings before the KDA answers an incoming call. Set for 1 to 15 times. Default = 2.

Table 5.X - Hot Keys Available in the Edit Advanced Window

Кеу	Description
Tab	Enter or select from default box.
F8	Saves the miscellaneous data and returns to the main menu.
F9	On line help.
F10/Esc	First Field/Abort. These keys move the cursor to the first field and then the Main Menu.

Connect Direct



Fig. 5.31 - Connect Direct Submenu lists Available Options The Connect Direct option allows you to communicate with the KDA via the CRAFT port. The Direct Connect menu options are explained in detail on the following pages.

NOTICE: All options on this menu, with the exception of Quit, require approximately 15 seconds to establish a communications link with the KDA.

Table 5.Y - Options in the Connect Direct Submenu

Option	Function
Inquire	Returns information regarding the KDA current configuration state.
Download	Sends the currently selected configuration to the KDA.
Upload	Retrieves the configuration that is loaded in the KDA.
Monitor	Monitors the status of the KDA in real time.
Spy Primary	Enters a protocol analyzer mode that shows primary port activity.
Spy Secondary	Enters a protocol analyzer mode that shows secondary port activity.
Quit	Returns to Main Menu.

Table 5.Z - Hot Keys Available in the Direct Connect Submenu

Кеу	Description
F1	Communication Parameters. This function directly accesses the communication setup screen, which is normally accessed from the Software Parameters/Communications Menu. This screen allows modification of the communication parameters. These parameters include such information as Com Port, Baud, and Parity.
F10/Esc	Exit. These keys move the highlight bar to the Quit option. At the Quit option, press <enter> to leave the Connect Modem screen.</enter>

Inquire



Inquire is a non-intrusive test to return such information as the firmware version and the person who last downloaded it. It also can be used as an integrity check to verify that the provisioning of the KDA matches that of the currently selected system. This information is displayed in a Remote Status Window.

Note: The status inquire is automatically performed at the start of either a download or an upload.

Fig. 5.32 - Inquire Shows Firmware and Provisioning Status

Table 5.AA - Field Names and Descriptions in theRemote Status (Inquire) Window

Field	Description
SITE NAME	Site name of the KDA.
COMMENT	Comment stored in KDA.
PRODUCT	Remote type and version.
LST MOD	The last date and time the database was modified and who modified it.
LST DWNLD	The last date/time the database was downloaded and who downloaded it.
DB STATUS	Indicates whether the currently selected system matches the KDA provisioning.

Direct Connect Download



Fig. 5.33 - Vertical Bars Denote Download Progress

The Direct Connect Download will download the currently selected configuration to the KDA. The configuration PC must be connected to the CRAFT port of the KDA.

Satellites - The initial configuration of satellites must be done at each satellite craft port. After the initial configuration, satellites can be downloaded through the base unit.

The download process begins when the "Download" option is selected from the menu. The T/KDA download window appears and the software establishes a communications link with the KDA. It will display the current status of the remote. The download window will then display vertical lines indicating the progress of the download. Short lines indicate

that the database in the KDA is identical to the database being downloaded. Longer lines indicate that the database in the KDA is different from the database being downloaded. When the download is complete, a box will appear in the bottom right hand portion of the screen indicating the success or failure of the download.

Press F10 or ESC at any time to abort the download.

The remote status window displays the information status as it was PRIOR to the download.

Important - Time is downloaded from the PC using the DOS time and date. Be sure the DOS time and date in the configuration PC are correct.





Direct Connect Upload

The Direct Connect Upload will transfer the configuration that is currently residing in the KDA to the PC. The configuration PC must be connected to the CRAFT port of the KDA. An upload may be performed if the configuration file is not available and you need to modify it. To change an item or two on the KDA without having to enter all the data from scratch, upload the configuration from the KDA, make the modifications to the file and then download the KDA.

Warning: Uploading data will OVERWRITE (destroy) the selected configuration. Select the correct configuration before starting an upload.

Press F10 or Esc to abort the upload.

The upload process begins when the "Upload" option is selected. The T/KDA upload window appears and the software establishes a communications link with the KDA. It will display the current status of the remote. Vertical lines indicate the progress of the upload. When the upload is complete, a box will appear in the bottom right hand portion of the screen indicating the success or failure of the process.

Hints:

The current database configuration should be maintained in only ONE location. Backups of your database are always a very good idea.

Uploads can be used as a way of getting a head start on a configuration that is similar to that of another remote.

Direct Connect Monitor

The Monitor option will continuously observe the status of all the alarms and control re-



Fig. 5.35 - Select System Before Entering Direct Connect Monitor

lays. This mode is also used to issue control commands and to tune 202 (docking module) modems. Direct Connect Monitoring requires a connection from the serial port of the PC to the CRAFT port of the KDA.

When "Monitor" is selected, the program will ask you to select the system you wish to monitor from a list that it displays on the screen. Selecting the proper system is important so that the correct point and control descriptions are used. The highlight bar can be moved by pressing the up and down arrow keys. Press <ENTER> to select target system. Once a system has been selected, it will become the "active" system as though it was chosen from the "Open T/KDA" option on the Main Menu.

Кеу	Key Description				
Up Arrow	Prev. Selects the previous point. Previous at Point 1 wraps to 64.				
Down Arrow	Next. Selects the next point. Next after Point 64 wraps back to 1.				
Right Arrow	Move right one colu	ımn.			
Left Arrow	Move left one colur	nn.			
		Hot Keys in the Alarm Status Window			
	Key	Description			
PgUp	F2	ACK point. Acknowledges last change of state of the selected alarm point.			
Highlights &	F3	ACK all points. Acknowledges all blinking COS alarm points.			
Activates the Alarm	F4	Toggle protocol analizer. Analyzer appears in the control portion of the screen.			
Status Window.	F5	Reset disconnect timer. A modem connection is terminated after a preset time (see Table 5.C). Time is indicated between the alarm and control windows. F5 restores timer to the preset time.			
	F6	TBOS. Monitor TBOS card, if equipped. See p. 5-26.			
	F7	Tune 202 modems. See p. 5-27.			
	F9	Display help screen relating to the alarm status window.			
	Alt-F6	Expansion card inf See p. 5-27.			
	Alt-F7	Monitor Satellites. See p. 5-29.			
	F10/Esc	Abort. Exits monitoring mode.			
		Hot Keys in the Control Status Window			
PaDn	Key	Description			
5	F1	Latch. Close the relay.*			
Highlights & Activates the	F2	Release. Open the relay.			
Control Status	F3	Momentary. Close the relay for a predetermined amount of time. (See Edit Relays.)			
Window.	F4	Toggle protocol analizer. Analyzer appears in the alarm portion of the screen.			
	F5	Reset disconnect timer (same as F5 in the Alarm Status Window).			
	F7	Tune 202 Modems. See p. 5-27.			
	F9	Display help screen relating to the control status window.			
	F10/Esc	Abort. Exits monitoring mode.			

 Table 5.AB - Hot Keys Available in the Direct Connect Monitor Mode

*NOTE: Except for option 'L and the LR-24 Relay expansion card, "Latch" is electrical, not magnetic. Relays will release if power is lost.

For Alarms: A=Alarm N=Normal

For Controls: L=Latched R=Released

Alarm/Control Legend

Blinking indicates that the point changed state and has not yet been acknowledged.

Alarms have memory which means that if an alarm comes and goes, the fact that the alarm cleared will not be reported until the alarm failure is acknowledged.

Controls do not have to be acknowledged and always report current status.

highlighted.

Acknowledging Alarms

The alarm status window must be the active window before any alarms acknowledgments can take place. The alarm window is active when the highlight bar is somewhere on the

> alarm status window. Another way of knowing you are on the alarm status window is by making sure line 25 starts with "F2ACK". If the controls window has the highlight bar, press PAGE UP to activate the alarm status window.

> To Acknowledge a point, move the highlight bar on the Alarm Status window using the up, down, left and right arrow keys to any point on the Alarm Status window. Press the F2 (ACK Point) function key to acknowledge the point

> To Acknowledge ALL points, press the F3 (ACK ALL Points) function key and all the points will be acknowl-

> edged. Acknowledging an alarm will remove the alarm

			1	
1	/kda Selected : D	ALLASS Site :	OPERATIONS CONTROL	NORTH
1		Alarm	Status —	· · · · · · · · · · · · · · · · · · ·
	1:A)BACK DOOR WST	17:\)	33:A)FRONT GATE	49:\)
	2:A)BACK DOOR NTH	18:)FRNT DOOR MNE	34:A)WEST GATE	50:DMAIN BNK - L1
	3:A)BACK DOOR STH	19:)FRNT DOOR SEC	35:\)	51:)MAIN BNK - L2
	4:A)BACK DOOR EST	20:)WINDOW W WALL	36:) TMP THRLD LOW	52:A)MAIN BNK - L3
	5:A)	21:A)WINDOW E WALL	37:A)TMP THRLD HGH	53:)
	6: <u>A</u>)	22:)	38:)	54:)PANIC ALARM 1
	7: DFIRE DET 214	23:A)BEACON LITE 1	39:A)PEOPLE ENTRY1	55:)PANIC ALARM 2
	8:)FIRE DET 215	24:A)BEACON LITE 2	40:A)PEOPLE ENTRY2	56:)PANIC ALARM 3
	9:)FIRE DET #324	25:A)BEACON LITE 3	41:A)PEOPLE ENTRY3	57:A)LOW LEV TNK 1
	10:)FIRE DET #444	26:)CHN BNK1 - L1	42:A)PEOPLE ENTRY4	58:A)LOW LEV TNK 2
	11:)FIRE DET #445	27:A)CHN BNK2 - L5	43: DPEOPLE ENTRY5	59:A)LOW LEV TNK 3
	12:)FIRE DET #446	28:A)CHN BNK3 - L1	44:)PEOPLE ENTRY6	60:)HGH LEV TNK 1
	13:)FIRE DET #447	29:)CHN BNK4 - L6	45:)PEOPLE ENTRY?	61:)HGH LEV TNK 2
	14:)POWER FAIL 1	30:)CHN BNK5	46:)	62:)HGH LEV TNK 3
	15:)POWER FAIL 2	31:)	47:)SEC VIOLATION	63:)
	16: DBCK POW FLE	32: 0	48:A)UN-AUTH CON	64: DEVACUATE ALRT
Î	ELAPSED: 0:00:46	ONLINE:D	PS.	
1	_	Control	Status ————	
	1:L)BCK-UP GEN ON	3:R)LOC FIRE DEPT	5:L)FILL TANK LEV	7:R)SOUND GEN ALM
	2:R)BCK-UP GEN OF	4:R)LOC POLICE	6:R)REL TANK LEV	8:L)SOUND EVAC
	2.40% F3.40% A11	FZ.Tupe Modem F9.H	eln Esc Abort	EDPS
		ri rano nouom ro na	STF 100 moor v	6010

Fig. 5.36 - Alarm and Control Status Can be Viewed on The Alarm Status Screen

Issuing Controls

Prior to issuing controls to the KDA, the Control status window (bottom portion of the monitoring screen) must be active. The control window is active if there is a highlight bar in the control status window and line 25 starts with "F1Latch". If the control status window is not active, it can be made active by pressing the PAGE DOWN key.

from the dial-out queue.

To set a control, move the highlight bar on the Point Status window — using the up, down, left and right arrow keys until the highlight bar goes over the description of the control you want to change.

To LATCH* a control point press F1.

To RELEASE a latched control point, press F2.

To operate a control point MOMENTARILY, press F3.

*NOTE: Except for option 'L' and the LR-24 Relay expansion card, "Latch" is electrical, not magnetic. Relays will release if power is lost.

		Monitor Ana	logs		000000000000000000000000000000000000000	1
Channe l	Description	Display	3-	Volts	Stat	แร
1	AA	4.28	NDC	4.276		
2	BB	2.36	YDC 🗌	2.361	MINOR	UNDER
3	CC	0.45	YDC 🗌	0.446	MINOR	OVER
4	DD	4.72	YDC -	4.722	MINOR	OVER
5	EE	2.81	YDC 🗌	2.807	MINOR	OVER
6	FF	0.89	YDC 🗌	0.892	MAJOR	UNDER
7	GG	5.17	YDC 🗌	5.168	MAJOR	UNDER
8	НН	3.25	YDC 🚽	3.253	MAJOR	UNDER
	0:00:07		D			

Fig. 5.37 - Analog Alarms are Viewed via TBOS Expansion Card



Fig. 5.38 - TBOS Alarms are Viewed via Analog Expansion Card

In the Monitor Mode press F6 to monitor an analog card or the **Analog** portion of the 8 Analog / 4 TBOS expansion card (if equipped). (Fig. 5.37)

Press F8 to monitor a TBOS card or the **TBOS** portion of the 8 Analog / 4 TBOS expansion card (if equipped). (Fig. 5.38) The screen displays the status of all displays on a given port. Points that are in alarm will be identified by their point number appearing on the line for their assigned display. Display failures are identified by color. A line at the top of the screen identifies the port being monitored.

This monitoring is carried out between the craft port and the expansion card "LAN." It is not dependent on the interrogating master performing a poll.

Field Name	Description
Monitor TBOS Port #	Number of the port being monitored. Press the desired number key to change.
DISP (number)	Alarm display assigned to the line. All 64 alarm points will be shown on the line. The display number will be solid green (solid on monochrome screens) if the display is respond- ing properly. The display number will be blinking red (blinking on monochrome screens) if the display is not responding properly. The display number will be solid yellow if the TBOS card is not present.
ELAPSED	Time passed since entering this mode.
ONLINE	Indicates data activity by moving - and > symbols.

Table 5.AC - Field Names and Descriptions in the Monitor TBOS Screen

Table 5.AD - Hot Keys Available in the Monitor TBOS Card Screen

Кеу	Description
1-4	Select Port. Press the desired number to change selected port.
F4	Analyzer. Toggles protocol analyzer. This function allows you to view the protocol analyzer win- dow. This protocol analyzer shows the communication activity between the KDA and the expan- sion card.
F10/Esc	Return to Monitor Mode.

Monitor LR-24 / SR-24 Relay Card

1:L)RELA	Y EXP	01	9:L)RELAY	EXP.	09	17:R)RELAY	EXP.	17
2:R)RELA	Y EXP	. 02	10:L)RELAY	EXP.	10	18:L)RELAY	EXP.	18
3:R)RELA	Y EXP	03	11:R)RELAY	EXP.	11	19:R)RELAY	EXP.	19
4:L)RELf	Y EXP	. 04	12:L)RELAY	EXP.	12	20:L)RELAY	EXP.	20
5:R)RELA	Y EXP	. 05	13:R)RELAY	EXP.	13	21:L)RELAY	EXP.	21
6:R)RELA	Y EXP	06	14:R)RELAY	EXP.	14	22:R)RELAY	EXP.	22
7:R)RELA	Y EXP	. 07	15:L)RELAY	EXP.	15	23:R)RELAY	EXP.	23
8:R)RELA	AY EXP	08	16:R)RELAY	EXP.	16	24:R)RELAY	EXP.	24
	0:00	46		D				

Fig. 5.39 - Monitor Relay Expansion Card Status

In the Monitor Mode press F6 to monitor the LR-24 or SR-24 Relay expansion card (if equipped). See Fig. 5.39.

Relays may be operated from this screen. To operate, highlight a point and press F1. To release, highlight the point and press F2. To operate a point for the momentary period, press F3.

Tuning Modems

If your KDA is equipped with a 202 Tone Modem docking pad interface, then it may need to be tuned to optimize signal quality. The receive level is automatically adjusted over a 20 dB range. A "pad" on the input can be set for an input range of -43 to -23 dB or for a range of -23 to -3 dB. (See page 4-8.) The 202 modem transmit level is SOFTWARE ADJUSTABLE and therefore does not require the unit to be opened. The modems are shipped from the factory with the transmit levels set at approximately -13 Dbm.

Tuning mode is entered by pressing F7 from either the Alarm or Control status screens.

Tuning procedures: (Refer to Table 5.AE.)

1) Put either a Level Meter or Scope across the transmit leads of the KDA 202 modem.

2) Place transmitter on HIGH TONE (F5)

3) Press F1-F4 keys to bring the transmit level to the desired range. If the level is far to low, use course up. If it is far to high, use course level down. Once the level approaches the proper range, use the F2 & F3 keys to fine tune it.

4) Once tuned, press F7 followed by F10 to return to the monitoring screen.

Кеу	Description
F1	Course (10 Step) LEVEL UP (hotter)
F2	Single step LEVEL UP (hotter)
F3	Single step LEVEL DOWN
F4	Course (10 Step) LEVEL DOWN
F5	Transmitter On - Xmit HIGH TONE (MARK)
F6	Transmitter On - Xmit LOW TONE (SPACE)
F7	Transmitter Off
F8	Transmitter On - Xmit HIGH / LOW square wave
F9	Display help screen relating to the control status window
F10/Esc	Returns to Control/Status screen

Table 5.AE - Hot Keys Available in the Tune 202 Modems Window

Warning: Do not tune modem above -2 Dbm as the wave forms become distorted.



In the Monitor Mode press Alt-F6 to see information about the expansion card. A window appears giving information about the expansion card. See the following table.

Fig. 5.40 - Expansion Card Information Screen Shows Firmware Version

Table 5.AF - Field Names and Descriptions in the Expansion Ca	ard
Information Window	

Field Name	Description
Function (number):	Function and firmware version of the expansion card processor(s). If the card has only one processor, no others will be listed. If the card has multiple processors, such as the 8 port TBOS card illustrated above, another function line will be displayed. If no card is installed, the Function line will state "Not Present."
ELAPSED	Time passed since entering this mode.
ONLINE	Indicates data activity by moving - and > symbols.

Table 5.AG - Hot Keys Available in the Expansion Card Information Window

Key	Description
F4	Analyzer. Toggles protocol analyzer. Allows you to view the protocol analyzer window. This protocol analyzer shows the communication activity between the KDA and the expansion card.
F10/Esc	Return to Monitor Mode.

Monitor Satellites

In the Monitor Mode press Alt-F7 to see alarm and control status information from the base and satellite KDAs. A screen appears giving a display similar to the Monitor TBOS Card display, except this one shows the status of control points as well as alarms. See the following table.

NOTE: This screen is accessible only from the base KDA, not from the satellites.

Table 5.AH - Field Names and Descriptions in the Monitor Satellite Screen

Field Name	Description
Base ALM	Base KDA alarm point status. All 64 alarm points are shown on the line. Points in alarm are iden- tified by their point number on the line.
Base CTL	Base KDA control point status. Points that are operated (relay in the ON state) are identified by their point number appearing on the line.
SAT #()ALM	Satellite (#) alarm point status. All 64 alarm points are shown on the line. Points in alarm are identified by their point number on the line.
SAT #()CTL	Satellite (#) KDA control point status. Points that are operated (relay in the ON state) are identi- fied by their point number appearing on the line.
ELAPSED	Time passed since entering this mode.
ONLINE	Indicates data activity by moving - and > symbol.



Fig. 5.41 - Monitor Satellites Shows Status of all Alarm and Control Points at the Base and Satellite KDAs

Spy Primary & Spy Secondary

Spy mode will show the communication activity that is present on KDA's primary or secondary port. By plugging in a laptop or other DOS computer at the Craft Port you can view the protocol in either ASCII or Hexadecimal. This allows

on-the-spot analysis of the communications between the KDA and the polling master to quickly isolate communication prob-

T/kda Selected : RAUL Open KDA Edit 1arm Points Edit 1arameters Edit 1iscellaneous Edit 1iscellaneous Edit 1iscellaneous Edit 1iscellaneous Edit 1iscellaneous Connect Direct Downlo Commect Modem Upload	Site : KDA HOST SYSTEM — Remote Status SITE NAME:KDA HOST SYSTEM COMMENT :THIS IS A TBOS 8 PORT TEST PRODUCT :KDA-864, Version: 2.86 LST MOD :Date(81/18/1995) Time(18:43:00) By(RGK) LST DUMLD:Date(81/18/1995) Time(18:44:00) By(RGK) DB STATUS:Current DB and remote MATCH
00 TSC T38 T00 T00 T00 T T37 T3B T00 T00 T00 T00 T3E T00 T00 T00 T00 T00 1 T00 T00 T00 T00 T00 T00 2 R58 T02 T00 T11 R03 R D00 T00 T00 T00 T11 R03 R	KDA Spy Primary ************************************
K38 102 100 111 R03 R02 T02 T08 T11 R03 R02 R6F 9 T00 T05 T02 T08 T00 T0 06 T30 R02 R03 R2D T02 T T33 T03 T00 T00 T00 T00 T06 T00 T00 T00 T00 T00	Nev 103 100 126 101 102 100 100 100 100 100 100 100 100
F1·Full Window F2·ASCII	AST DOWNLOAD: Date(01/18/1995) Time(10:44:00) By(RGK) Space Bar·Pause F8·File F9·Help F10/Esc·Abort

Fig. 5.42 - Spy Mode Shows Primary or Secondary Port Data Activity

Table 5.Al - Hot Keys	Available in	the Spy Modes
-----------------------	--------------	---------------

lems.

Кеу	Description
F1	Toggles full window view so that protocol can be viewed on the entire screen. This allows more of a transmission to be viewed at once as the screen scrolls by.
F2	Displays printable characters in ASCII, decimal or Hexadecimal formats. Press F2 repeatedly to step through the three selections. The line at the bottom of the screen shows the current mode next to F2.
SPACE BAR	Pauses & Restarts protocol analyzer mode.
F8	File. Captures protocol analyzer display to a file in the the TCONFIG directory. File name appears at lower right corner of analyzer window. In Spy Secondary the file name is TKDASSEC.000. The 000 increments to 001, 002, etc., each time F8 is executed. Deleting the files from the directory will return the counter to 000.
F9	Display help screen.
F10/Esc	Exit spy mode.

These spy modes only work in direct mode, which means you must be connected directly to the craft port.

Connect Modem

The Connect option allows you to communicate with the KDA via a 212 dial-up modem. All of the options in this section function much the same way as the options in the direct connect section with the most significant difference being that the communication link is over a modem.



Fig. 5.43 - Connect Modem Performs Connect Functions via Dial-up Port

In order to minimize redundancy, the Connect Modem Section will only cover the differences between the two types of connections.

1) The SPY PRIMARY & SPY SECONDARY menu options are not on the "Connect Modem" submenu because these modes are only available from the CRAFT port, which only works in direct mode.

2) The Download, Upload and Monitor commands will all use the PC serial configuration information from the MODEM section of the Communications System Parameters.

3) When any of the above three modes are activated, two modem dialog boxes will appear. The top box shows the type of dialing that is taking place and the phone number that is being dialed. The bottom box will show anything that was received from the modem. The purpose of these boxes is to show you the connection as it is being established. This especially comes in handy for tracking down the problem if you cannot establish a link with the remote. For example, the bottom box would say "NO DIAL TONE" if the phone line was not connect to your modem. Once the software observes the connect message, the dialog boxes will disappear and it would be as though you direct connected.

Note: It is perfectly normal to see the phone number that is in the top box appear in the bottom box since the modem is most likely set to echo all commands it receives.

Reports

The Reports option allows you to generate reports based on your KDA database definitions. Reports can be sent to the Screen, File or Printer. When the Reports option is selected, the System Reports screen appears. Enter the KDA Start (to start the report) and the KDA End (to end the report). Then select either Screen, File or Printer for the report output. If File is selected for the output, the user will be prompted for a filename to be used for the report. The file extension is automatically set to ".RPT". File reports are written using ASCII text and can be read from DOS and most word processors.



Fig. 5.44 - Select Range and Destination for Report

Software Parameters

The Software Parameters option allows you to define the configuration computer port parameters. These parameters are not downloaded to the KDA.



Fig. 5.45 - Set Configuration Computer Parameters



Fig. 5.46 - Set Port Parameters

cess is required.

See Communications Parameters and System Parameters subsections on the following pages for additional information.

Communication Parameters

Selecting Communication from the System Parameters menu screen will bring you to the T/KDA Parameters window and allow you to define the T/KDA parameters.

> The primary purpose of this section is to define which ports are to be used for direct connect and modem connect functions along with their respective communications parameters. Given the configuration shown on the left, if the user selected "Connect Direct" from the Master Menu the software would then use com 1 at 1200 baud. Under the same circumstances, selecting "Connect Modem" would use com port 1 and use Tone dialing whenever it places a call. It is possible for both Direct and modem modes to use the same com port for single com port systems. When this occurs you need to plug a modem in the com port whenever phone ac-

Table 5.AJ - Field Names and Descriptions in the Communications Parameters Window(Default values are underlined)

Field	Description
Com	Serial Communication port that will be used for this configuration line. Valid Com Ports are 1-4.
Baud	Communication rate that the PC will use when talking to the KDA. Valid Baud rates are 110, 150, 300, 600, <u>1200</u> , 2400, 4800, 9600, 19 (19200), 38 (38400). The maximum communications rate for the KDA is 1200 baud.
Stop Bits	Valid stop bits are <u>1 Stop Bit</u> and 2 Stop Bits.
Data Bits	Valid Data Bits values are 7 Bits and <u>8 Bits.</u>
Parity	Valid Parity values are Even, Odd, and None.
Max Time-out	The amount of time the configuration software will wait for an answer to a request before the command is sent again. Valid Time-out range values are 50-9999 milliseconds. 3000 (3 seconds) is the default.
Max Resend	The number of resends the configuration software will attempt before the current transaction is aborted due to a communication failure with the target device. Valid Maximum Resend range values are 1-100. Default = 20
Send Delay	The delay time (in seconds) before each frame is sent to the remote. Normally this should always be zero except for special circumstances where a command lag time is required. Valid Send Delay range values are 0-999. Default = 0
Dial Type	The dialing method that the configuration software will use when it places a call. This field is not appli- cable for direct connect devices. Valid entries are Tone or Pulse.

This configuration screen can also be accessed from the direct & modem connect sub- menus by pressing F1.

If the Modem configuration line is used, there must be a modem present on the specified port before a modem connection can be established.

Table 5.AK - Hot Keys	Available in the	Communication	Parameters Window
-----------------------	------------------	---------------	-------------------

Кеу	Description
F8	Save. Saves the T/KDA Parameters definitions.
F9	Help Screen
F10/Esc	First Field/Abort. These keys move the cursor to the first field and then to the Main Menu.

System Parameters

Selecting Parameters from the Software Parameters menu will bring you to the Parameters window and allow you to define the Modem Initialization String, the Report Path and printer page length.

See Appendix 6 for a table of common modem initialization strings.

Software Parameters MODEM INITIALIZATION STRING #1: AT S7=120 E1 V1 M1 Q0 X4..... MODEM INITIALIZATION STRING #2: AT REPORT PATH : C:\TCONFIG3 PRINTER PAGE LENGTH : 60

Fig. 5.47 - Set Modem Initialization String, Report Path and Printer Page Length

Table 5.AL - Fields Names and Descriptions in the System Parameters Window

Field	Description
Modem Initialization String (#1 and #2)	The Modem Initialization String is for the modem in the configuration computer. The Modem Initializa- tion String default is a universal string which works with most modems. If your computer has a "smart" modem, you will need to turn off flow control, compression and error correction. These commands will be found in the manual for your modem. Initialization strings for some modems are listed in Appendix 6 at the back of this manual. If you have difficulty getting your modem to operate properly, contact DPS technical support for assistance. <i>NOTE: String #2 line is used only if String #1 line is not long enough.</i>
Report Path	The path (drive and directory) to which all report files generated are stored. Default is C:\TCONFIG
Printer Page Length	Enter number of lines on page for reports sent to printer. (Avoids blank or partly printed second pages when a laser printer is used.)

Utilities

The Utilities option allows you to rebuild database key index files and copy or delete the currently selected T/KDA database.

Copy Configuration



The Copy Configuration function lets you copy the contents of an existing configuration into a new or existing file, replacing all data in the existing file.

Before selecting the Utilities function make sure the name of the file to be copied to (destination) appears in the title bar line at the top of the screen. (Use right and left cursor keys to find it.) If the destination file name is new, it won't appear unless it has been defined in the Open Configuration function. (Go to Open and specify the new file name and other file information, then return to the Utilities function.)

Select Utility FunctionSelect Utilities, then Copy Configuration. The Copy Configuration box will appear.
Enter the COPY FROM (source) file name or select from the default box and pressFig. 5.48 - Select Utility Function<ENTER>. A red box will prompt you with a warning message:

CURRENT CONFIGURATION WILL BE OVERWRITTEN Copy (Y/N)?

Type "N" to abort or "Y" to proceed. The source file data will be copied to the destination file name. The source file will remain undisturbed. Edit the new file as needed.

Delete Configuration

The Delete Configuration option deletes the currently selected KDA configuration from the T/KDA database. When selecting this option, T/KDA will prompt you with a warning message:

CURRENT KDA CONFIGURATION WILL BE DELETED Delete (Y/N)?

Answering "Y" (Yes) will delete the currently selected configuration (listed on the title bar at the top of the screen). Replying "N" (No) will abort the deletion process.

!!Warning!! Use this option only if you are positive that you will never need the currently selected KDA configuration. This option will completely erase all references to the selected configuration.

Rebuild Key Files

The Rebuild Key Files option rebuilds the System index file. This option is used to rebuild and index file if the data file and the index file get out of synchronization. The Rebuild Key Files process deletes the "out-of-sync" index file and uses the data file to create a new index file.

TURN POWER OFF
ONLY AT THE DOS
PROMPTThis option is most often used in the event of catastrophe with T/KDA's index files and/or
when recommended by DPS tech support. This option should not be used unless there is a
problem. The most common need for a key rebuild is a power failure while T/KDA is ac-
cessing the disk, therefore be careful to always exit the program cleanly.

		Terminal	
COM Port Baud Parity Word Length Stop Bits	om Port : 1 : 1200 : NONE : 8 : 1	Settings	

When Terminal is selected in the Utilities menu, the Com Port Settings window appears. Use this function to set up the computer's serial port for any general purpose terminal application other than configuring the KDA. The settings in this window do not affect the settings in Software Parameters. See Table 5.AM.

Fig. 49 - Set Terminal Parameters for ASCII Functions

Table 5.AM -	Field	Descriptions	in the	Com	Port	Settings	Window
				-			

Field	Description
Com Port	Select number for computer*s serial port (1-4).
Baud	Data rate of serial port. Type in numbers or use Tab key to select from default box. (110, 150, 300, 600, 1200, 2400, 4800, 9600, 19.2K or 38K Baud)
Parity	Parity of serial port. Type in or use Tab key to select from default box. (Even, None or Odd)
Word Length	Word length on serial port. Type in value (7 or 8)
Stop Bits	Number of stop bits for serial port. Type in value (1 or 2).

Quit

The Quit option will quit this section of the program and return you to the Main Menu. To do this, move the highlight bar using the up and down arrow keys or press "Q" to move to the Quit option on the Utilities menu and press <ENTER>.

This page intentionally left blank

Section 6 - Trouble Shooting

These advanced diagnostics are normally used under direction of DPS Tech Support Several aids to trouble shooting are available, in addition to those presented in the T/KDA section. These are screens for viewing protocol between the various sections of a KDA remote. They can be accessed only by entering the following statement at the DOS prompt (before starting T/KDA):

SET PROBE=BYTE <Enter>

NOTE: This statement is case sensitive.

After entering this statement, start T/KDA in the normal fashion.

The following additional functions will be available from the menus:

From the Main Menu:

Probe NvRAM - View contents of Non-volatile RAM.



Fig. 6.1 - Probe Nvram is an Additional Function

From the Connect Direct Menu:

Spy LAN Traffic - View protocol between Host KDA and Expansion card.

Spy LAN Commands - View expansion card status.

Spy Satellite - View protocol between base KDA and Satellites.

Set Triggers - Specify data stream to trigger spy function.

Ykda Selected : Open kda 864 edit Alarm point edit Parameters edit Miscellaneo edit Expansion Connect modem Reports Software parame Utilities probe Nuram Quit	RAUL s us Download Upload Monitor Inquire spy Primary spy Seconda spy Lan tra spy Lan tra spy satElli spy satElli	Site : y my ffic Is te	TBOS		
	set Trigger Quit	rs			
(DPS logged on)	LAST	MODIFIED:	Date(06/30/1995)	Time(04:04:39)	By(DPS)
F1.Communication	LAST	F10/Esc : F	Date(06/26/1995)	Time(10:35:45)	ByCRGRJ

Fig. 6.2 - Additional Spy Functions are in the Connect Direct Menu

Probe NvRAM

The Probe NvRAM function is a powerful diagnostic tool that allows examination of the contents of the Non-volatile RAM in the KDA. In general, the use of this section is limited to those occasions when a DPS technical support person requests its use during trouble shooting sessions via phone or on-site.

								$= \mathbf{P}_1$	robe	e Nu	, RA							1	
SctlAdd	c B	B 54	4 42	2 41	53	00	00	00	00	00	00	00	00	00	00	00	. TBOS		Caution: Function kevs F4 and F5 can alter th
00000	3 0	9 90	0 0	3 00	00	00	00	00	00	00	00	00	10	00	00	00			
																			KDA configuration and place it in undetermine
edit Par		ters																	
]	states.
01000	1 B	B 54	4 42	2 4 H	' 53	00	00	00	00	00	00	00	00	00	00	00	. TBOS		
	0	0 00	0 0	<u>a 0</u> 6) 00	00	00	00	00	00	00	00	10	00	00	00			
1:002	3 6	6 35	5 3	5 35	5 2D	35	32	35	32	00	00	00	00	00	00	00	£555-5252		
	0	0	0 0	3 00	00	00	00	00	00	00	00	00	00	00	00	00			
210046	3 6	A 35	5 3	5 35	5 2D	31	32	33	34	00	00	00	00	00	00	00	j555-1234		
	0	0 0	0 0	<u>a 0</u> 6) 00	00	00	00	00	00	00	00	00	00	00	00			
310066	4 B	98:	1 00) ØE	00	00	00	00	00	БQ	00	00	00	00	00	00			
	0	9 96	0 03	2 C4	01	. 00	۵F	01	00	05	00	00	03	07	00	00			
410086	4 F	F Fl	F FI	F FI	' FF	FF	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}			
	F.	FFI	F FI	F FF	FF	FF	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}			
5100A6	4 F	0 10	9 19	F FI	FF	FF	FF	FF	\mathbf{FF}	\mathbf{FF}	FF	\mathbf{FF}	FΓ	\mathbf{FF}	\mathbf{FF}	FF			
	F.	5 151	5 151	F FF	FF	\mathbf{FF}	\mathbf{FF}	FF	\mathbf{FF}										
610000	1 3	C Ø:	1 C4	i FI	00	00	00	00	00	00	00	00	00	00	00	00	<		
	0	0 0	0 0	<u>a 0</u> 6	00 (00	00	00	00	00	00	00	00	00	00	00			
7100E	4 3	C Ø:	1 C4	i FI	00	00	00	00	00	00	00	00	00	00	00	00	<		
	0	0 0	0 0	9 00) 00	00	00	00	00	00	00	00	00	00	00	00			
					L	AST	DO	WNL	DAD	Da	ate	(06/	26	199	5)	Tir	ne(10:35:45	By (RGK)	
F1 Edit 1	Byte	s l	: Z - I	ła i	lir	FЗ	• Rd	Mo	d I	4	lt 1	Dir	F	∍₩t	Mo	nd	F9 Help Es	scExit	

Fig. 6.3 - Probe Nvram shows Contents of non-volatile RAM

Table 6.A - Hot Keys Available in the Probe NvRAM Screen

Key	Description
F1	Edit Bytes. Toggles between editing the section and editing the 32 bytes of the current section/address. Any changes that are made to the bytes of the current section will revert back to its original contents once a new section is selected.
F2	Rd Dir. Read 8 sections worth of bytes (256 bytes) from the NvRAM on the connected remote, beginning with the currently selected section number. (Direct Connect)
F3	Rd Mod. Same as F2, via modem connect.
F4	Wt Dir. Write the 32 bytes of the current section to the proper address in the NvRAM on the remote. The first byte of each section will be the check-sum (2s complement) of the next 31 bytes. This check-sum byte will continuously change to reflect any changes detected in the next 31 bytes. This check-sum byte cannot be edited. Any changes that were made to these bytes will be written to the NvRAM via Direct Connect.
F5	Wt Mod. Same as F4, but via Modem Connect.
F9	Help
F10/Esc	Exit screen and return to main menu.

Connect Direct The Connect Direct menu displays four additional functions when SET PROBE=BYTE is invoked. They include:

Connect Direct Trouble Shooting Functions

Spy Lan Traffic

Spy LAN Commands

Spy Satellite

Set Triggers

These functions are detailed on the following pages.

NOTE: While using these screens, refer to the protocol explanations in Appendix 4.

The spy screens all display Remote Status in the upper right portion of the screen when in the half window mode. the following table explains the fields in this window.

Site : TBOS

Remote Status SITE NAME:TBOS COMMENT : PRODUCT :KDA-864, Version: 2.1B LST MOD :Date(07/ 4/1995) Time(21:47:00) By(CDH) LST DWNLD:Date(07/ 4/1995) Time(21:48:00) By(CDH) DB STATUS:Current DB and remote are DIFFERENT



Field	Description
SITE NAME	Site name of the KDA
COMMENT	Comment stored in KDA
PRODUCT	Remote type and version
LST MOD	The last date and time the database was modified, and who modified it.
LST DWNLD	The last date/time the database was downloaded, and who downloaded it.
DB STATUS	Indicates whether the currently selected data base matches the KDA provisioning.

Table 6 B -	Field Names	and Description	s in the F	Remote Status	Window
	· I ICIU NaIIICS		5 III (IIC I	VEINULE Status	W

The Spy LAN Traffic function allows examination of the protocol between a host KDA and its associated expansion card when being polled from the T/MonXM master.

mation on the protocol.

The host data is preceded by "T" and the expansion card response is preceded by "R". In addition, the responses

LAN protocol is DCPF. Refer to Appendix 4 for infor-

are highlighted with a light background.

Spy LAN Traffic

Vkda Selected :	RAUL	Site : TBOS
Open kda 864 edit Alarm points edit Parameters edit Miscellaneou edit Expansion Connect Diffect Connect modem	s IS Downlo Upload	Remote Status SITE NAME:TBOS COMMENT : PRODUCT :KDA-864, Version: 2.1B LST MOD :Date(07/ 4/1995) Time(21:47:00) By(CDH) LST DWNLD:Date(07/ 4/1995) Time(21:48:00) By(CDH) DB STATUS:Current DB and remote are DIFFERENT
Register 02 T06 T69 R00 RF R03 R02 RF R00 RF R03 R04 R03 R04 R04	YF R02 R RFF R01 R06 R5E T40 T0 T0 YF R08 R R01 T01 T02 R00 R04 T00 R04 T00 T0 YF R02 R R04 T00 YF R02 R R R YF R02 R R R YF R02 R R R YF R02 R R R R YF R02 R <t< td=""><td>- KDA 864 Spy LAN Traffic 66 R69 T00 TFF T03 T40 T01 T02 T00 T01 T55 R00 RFF R00 R04 R55 R00 RFF R02 R00 R04 R33 T00 TFF T03 T66 T00 TFF T01 T40 T01 T02 T00 T01 T19 T00 TFF T03 T0 7 T02 T00 T01 T61 R00 RFF R02 R02 R58 R00 RFF R07 R 00 R04 R09 T00 TFF T02 T06 T69 R00 RFF R01 R00 R64 R33 T00 TFF T03 T06 T5E R00 RFF R03 R06 R5E T00 TF T19 T00 TFF T01 T06 T38 T00 TFF T02 T40 T07 T02 T 02 R58 R00 RFF R07 R00 R04 R2E R00 RFF R08 R00 R04 R00 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T0 R04 R00 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T0 R04 R00 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T0</td></t<>	- KDA 864 Spy LAN Traffic 66 R69 T00 TFF T03 T40 T01 T02 T00 T01 T55 R00 RFF R00 R04 R55 R00 RFF R02 R00 R04 R33 T00 TFF T03 T66 T00 TFF T01 T40 T01 T02 T00 T01 T19 T00 TFF T03 T0 7 T02 T00 T01 T61 R00 RFF R02 R02 R58 R00 RFF R07 R 00 R04 R09 T00 TFF T02 T06 T69 R00 RFF R01 R00 R64 R33 T00 TFF T03 T06 T5E R00 RFF R03 R06 R5E T00 TF T19 T00 TFF T01 T06 T38 T00 TFF T02 T40 T07 T02 T 02 R58 R00 RFF R07 R00 R04 R2E R00 RFF R08 R00 R04 R00 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T0 R04 R00 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T0 R04 R00 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T01 R04 R04 RFF R02 R06 R69 T00 TFF T03 T40 T01 T02 T00 T0
€ PAUSED ★ F1·Full	L Window	AST DOWNLOAD: Date(07/ 4/1995) Time(21:48:29) By(CDH F2:HEX Space Bar Besume F9:Help F10/Esc Abort

Fig. 6.5 - Spy LAN Traffic shows Protocol between Host and Expansion Card

Table 6.C - Hot Keys Available in the Spy Lan Traffic Screen

Key	Description
F1	Full Window. Toggles full/half screens.
F2	HEX. Displays printable characters in ASCII, decimal or Hexadecimal formats. Press F2 repeatedly to step through the three selections.
Space Bar	Pause. Pauses and restarts analyzer mode.
F8	File. Captures protocol analyzer display to a file in the TCONFIG di- rectory. File name appears at lower right corner of analyzer window. In Spy LAN Traffic the file name is TKDASTRF.000. The 000 incre- ments to 001, 002, etc. each time F8 is executed. Deleting the files from the directory will return the counter to 000.
F9	Help. Display help screen for the current function.
F10/Esc	Abort. Exit monitoring.

Spy LAN Commands

The Spy LAN Commands function allows examination of the status of the expansion card. This function queries the expansion card with two basic questions:



Card

Are you there?

Are you configured?

The query and response can be observed. The host data is preceded by "T" and the expansion card response is preceded by "R". In addition, the responses are highlighted with a light background.

See Table 6.D.
Key	Description					
F1	Full Window. Toggles full/half screens.					
F2	HEX. Displays printable characters in ASCII, decimal or Hexadecim formats. Press F2 repeatedly to step through the three selections.					
Space Bar	Pause. Pauses and restarts analyzer mode.					
F8	File. Captures protocol analyzer display to a file in the TCONFIG di- rectory. File name appears at lower right corner of analyzer window. In Spy LAN Commands the file name is TKDASCMD.000. The 000 in- crements to 001, 002, etc. each time F8 is executed. Deleting the files from the directory will return the counter to 000.					
F9	Help. Display help screen for the current function.					
F10/Esc	Abort. Exit monitoring.					

Table 6.D - Hot Keys Available in the Spy Lan Commands Screen

Spy Satellite

The Spy Satellite function allows examination of the protocol between a base KDA and its associated satellite units.

∕kda Selected : RAU	JL Site : TBOS
	Remote Status
Open kda 864	SITE NAME: TBOS
edit Alarm points	COMMENT :
edit Parameters	PRODUCT :KDA-864, Version: 2.1B
edit Miscellaneous	LST MOD :Date(07/ 4/1995) Time(21:47:00) Bu(CDH)
edit Expansion	LST_DWNLD:Date(07/ 4/1995) Time(21:48:00) Bu(CDH)
CONNECT DIRECT DOM	mlo DB STATUS: Current DB and remote are DIFFERENT
Connect modem []]	
Reports Mon	vito
nopor ta non	KDA 864 Smu Satellite
TAR TEE TAS BER TAR	TEE TAA DIA TAA TEE TAB DES TAA TEE TAA DIA TAA TEE TA
A DIVE TOO TEE TOP DI	$\frac{1}{1}$
FE TAO UND TOO TEE T	
TOO TEE TOP UNG TOO	TEE TAO DIVE TOO TEE TAA DINI TOO TEE TAD DIVE TOO TEE TAO
TOO IFF THE MAG TOO	
RFB 100 IFF IHH RFB	
F THE NOT TOO TFF TH	AS KED TOO TEE THA KED TOO TEE THB KEB TOO TEE THS TOO T
FF TAA RIG TUU TFF T	AB REB TOO THE TAY REP TOO THE TAA REB TOO THE TAB REP
TUU TFF TA9 RCU TUU	TFF TAA RIG TOU TFF TAB RIG TOU TFF TA9 RUI TOU TFF TAA
RFE TOO TFF TAB RFC	TOO TFF TAS RIF TOO TFF TAA RIF TOO TFF TAB REC TOO TF
F TA9_RFF_T00 TFF TA	ha <u>rec</u> too tFF tab <u>rep</u> too tFF ta9 too tFF taa <u>reb</u> too t
FF TAB RFE	
)
	LAST DOWNLOAD: Date(07/ 4/1995) Time(21:48:29) By(CDH)
PAUSED * F1 Full Wi	ndow F2 HEX Space Bar Resume F9 Help F10/Esc Abort

Fig. 6.7 - Spy Satellite shows Protocol between Host and Satellite KDA's

The query and response can be observed. The host data is preceded by "T" and the satellite unit responses are preceded by "R". In addition, the responses are highlighted with a light background.

Table 6.E - Hot Keys	Available in the Spy	Satellite Screen
----------------------	----------------------	------------------

Кеу	Description
F1	Full Window. Toggles full/half screens.
F2	HEX. Displays printable characters in ASCII, decimal or Hexadecimal formats. Press F2 repeatedly to step through the three selections.
Space Bar	Pause. Pauses and restarts analyzer mode.
F8	File. Captures protocol analyzer display to a file in the TCONFIG di- rectory. File name appears at lower right corner of analyzer window. In Spy Satellite the file name is TKDASEXP.000. The 000 increments to 001, 002, etc. each time F8 is executed. Deleting the files from the directory will return the counter to 000.
F9	Help. Display help screen for the current function.
F10/Esc	Abort. Exit monitoring.

Set Triggers

This function allows specifying a particular protocol pattern that will trigger a screen display during any of the spy modes. This is particularly useful when data rates are so high that ob-

Open kd Spy Mode Trigger Information	
edit Al	
edit Mi PREFILL AMOUNT : 50	
edit Ex MATCH PATTERN : 00 FF 01 40 03 02	
Connect SAMPLE DEPTH : 115	
Reports	
Softwar Utiliti	
probe N	
Quit The number of butes to conture after trigger	
SET TRIGGERS	
(DPS logged on) LAST MODIFIED: Date(06/30/1995) Time(04:04:39) By	(DPS)
uprevious field F8.Save F10/Esc.First Field	.KGRJ

Fig. 6.8 - Set Triggers shows a protocol segment "Snap-Shot"

serving the protocol becomes difficult. With a trigger set the screen will display a "snap-shot" of the protocol which can be easily observed for evaluation. The trigger can also have a set amount of data displayed prior to and following the trigger itself.

Select Set Triggers from the Connect Direct menu and fill in the fields according to the following table. When the Enter key is pressed after the last field is filled in the trigger will be effective for any spy mode selected, until the trigger mode is disabled.

Field Name	Description
Trigger Mode	"Y" enable the trigger mode during spy functions. "N" disables.
Prefill Amount	Number of Bytes preceding trigger point. (0 to 99).
Match Pattern	HEX Byte match (00-FF or "—" for "don't care").
Sample Depth	Number of Bytes to capture after trigger. (0 to 999)

Table 6.F - Field Names and Descriptions in the Set Triggers Screen

NOTE: The Trigger mode is effective for the spy primary and spy secondary functions also, even though those functions are features of the normal connect direct menu.

Section 6 - Trouble Shooting

These advanced diagnostics are normally used under direction of DPS Tech Support Several aids to trouble shooting are available, in addition to those presented in the T/KDA section. These are screens for viewing protocol between the various sections of a KDA remote. They can be accessed only by entering the following statement at the DOS prompt (before starting T/KDA):

SET PROBE=BYTE <Enter>

NOTE: This statement is case sensitive.

After entering this statement, start T/KDA in the normal fashion.

The following additional functions will be available from the menus:

From the Main Menu:

Probe NvRAM - View contents of Non-volatile RAM.



Fig. 6.1 - Probe Nvram is an Additional Function

From the Connect Direct Menu:

Spy LAN Traffic - View protocol between Host KDA and Expansion card.

Spy LAN Commands - View expansion card status.

Spy Satellite - View protocol between base KDA and Satellites.

Set Triggers - Specify data stream to trigger spy function.

Vkda Selected Open kda 864 edit Alarn point dit Parameters edit Miscellaned edit Expansion Connect modem Reports Software parame Utilities probe Nuram Quit	RAUL s Download Upload Monitor Inquire spy Primary spy Seconda spy Lan tra spy Lan tra spy Lan Cho spy satElli set Trigger	Site : Any Mffic Is ite	TBOS		
	set Trigger Quit	*S			
(DPS logged on)	LAST	MODIFIED:	Date(06/30/1995)	Time(04:04:39)	By(DPS)
F1. Communication	LAST	DOWNLOAD:	Date(06/26/1995)	Time(10:35:45)	By(RGK)

Fig. 6.2 - Additional Spy Functions are in the Connect Direct Menu

Probe NvRAM

The Probe NvRAM function is a powerful diagnostic tool that allows examination of the contents of the Non-volatile RAM in the KDA. In general, the use of this section is limited to those occasions when a DPS technical support person requests its use during trouble shooting sessions via phone or on-site.

									$= \mathbf{P}$	robe	e Nu	, RA								
SctlAdd	r B	38 5	54	42	4F	53	00	00	00	00	00	00	00	00	00	00	00	. TBOS		Caution: Function keys F4 and F5 can alter the
010000	8 8	10 8	90	00	00	00	00	00	00	00	00	00	00	10	00	00	00			
																				KDA configuration and place it in undetermined
edit Par	rame	eter																		
																				states.
01000	9 B	38 5	54	42	4F	53	00	00	00	00	00	00	00	00	00	00	00	. TBOS		
	Ø	90 0	00	00	00	00	00	00	00	00	00	00	00	10	00	00	00			
1:002	06	6 3	35	35	35	ZD	35	32	35	32	00	00	00	00	00	00	00	£555-52	52	
	E	90 8	90	00	00	00	00	00	00	00	00	00	00	00	00	00	00			
210046	06	SA 3	35	35	35	ZD	31	32	33	34	00	00	00	00	00	00	00	j555-12	34	
	e	90 8	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00			
310066	9 B	39 8	81	00	00	00	00	00	00	00	БQ	00	00	00	00	00	00			
	E	90 8	90	02	C4	01	00	ØF	01	00	05	00	00	03	07	00	00			
410086	2 F	FF I	FF	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}			
	F	FI	FF	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}			
5100A6	9 F	F I	0 Q	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	FF	\mathbf{FF}	\mathbf{FF}	FF	\mathbf{FF}	FF	FF	FΓ	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}			
	F	FI	515	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}	\mathbf{FF}			
610000	9 B	BC 6	01	C4	\mathbf{FF}	00	00	00	00	00	00	00	00	00	00	00	00	<		
	e	90 6	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00			
7100E	9 3	BC 6	91	C4	\mathbf{FF}	00	00	00	00	00	00	00	00	00	00	00	00	<		
	E	90 8	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00			
	_				_	L	AST	DO	WNL	JAD	Da	ate	(06,	26	199	5)	Tir	ne(10:35:	45) By(RGK)	
F1 Edit 1	Byte	s	F_2	2 · Ra	l D	ir	FЗ	• Rd	Mo		4	lt 1	lir	F	,⊎t	Mo	bd	F9 Help	Esc Exit	

Fig. 6.3 - Probe Nvram shows Contents of non-volatile RAM

Table 6.A - Hot Keys Available in the Probe NvRAM Screen

Key	Description
F1	Edit Bytes. Toggles between editing the section and editing the 32 bytes of the current section/address. Any changes that are made to the bytes of the current section will revert back to its original contents once a new section is selected.
F2	Rd Dir. Read 8 sections worth of bytes (256 bytes) from the NvRAM on the connected remote, beginning with the currently selected section number. (Direct Connect)
F3	Rd Mod. Same as F2, via modem connect.
F4	Wt Dir. Write the 32 bytes of the current section to the proper address in the NvRAM on the remote. The first byte of each section will be the check-sum (2s complement) of the next 31 bytes. This check-sum byte will continuously change to reflect any changes detected in the next 31 bytes. This check-sum byte cannot be edited. Any changes that were made to these bytes will be written to the NvRAM via Direct Connect.
F5	Wt Mod. Same as F4, but via Modem Connect.
F9	Help
F10/Esc	Exit screen and return to main menu.

Connect Direct The Connect Direct menu displays four additional functions when SET PROBE=BYTE is invoked. They include:

Connect Direct Trouble Shooting Functions

Spy Lan Traffic

Spy LAN Commands

Spy Satellite

Set Triggers

These functions are detailed on the following pages.

NOTE: While using these screens, refer to the protocol explanations in Appendix 4.

The spy screens all display Remote Status in the upper right portion of the screen when in the half window mode. the following table explains the fields in this window.

Site : TBOS

Remote Status SITE NAME:TBOS COMMENT : PRODUCT :KDA-864, Version: 2.1B LST MOD :Date(07/ 4/1995) Time(21:47:00) By(CDH) LST DWNLD:Date(07/ 4/1995) Time(21:48:00) By(CDH) DB STATUS:Current DB and remote are DIFFERENT



Field	Description
SITE NAME	Site name of the KDA
COMMENT	Comment stored in KDA
PRODUCT	Remote type and version
LST MOD	The last date and time the database was modified, and who modified it.
LST DWNLD	The last date/time the database was downloaded, and who downloaded it.
DB STATUS	Indicates whether the currently selected data base matches the KDA provisioning.

Table 6 B -	Field Names	and Descriptions	in the R	Remote Status	Window
	i ieiu naines	and Descriptions			WITTUOW

The Spy LAN Traffic function allows examination of the protocol between a host KDA and its associated expansion card when being polled from the T/MonXM master.

mation on the protocol.

The host data is preceded by "T" and the expansion card response is preceded by "R". In addition, the responses

LAN protocol is DCPF. Refer to Appendix 4 for infor-

are highlighted with a light background.

Spy LAN Traffic

I∕kda Selected : R	AUL Site: TBOS
Open kda 864 edit Alarm points edit Parameters edit Miscellaneous edit Expansion Connect modem U Parameter M	Remote Status SITE NAME:TBOS COMMENT : PRODUCT :KDA-864, Version: 2.1B LST MOD :Date(87/ 4/1995) Time(21:47:80) By(CDH) LST DWNLD:Date(87/ 4/1995) Time(21:48:80) By(CDH) DB STATUS:Current DB and remote are DIFFERENT pload
Reg Dirts T 02 T06 T69 R00 RFF R03 R02 R66 R00 RF T5E R00 RFF R03 R 08 R04 R2E R00 RFF 700 T61 T61 T62 R0 R09 T01 T61 R00 RFF T55 R00 RFF R42 T0	KDA 864 Spy LAN Traffic R02 R06 R69 T00 TFF T03 T40 T01 T55 R00 RFF R02 R06 R69 R02 R00 R04 R33 T00 TFF T03 T06 26 R5E T00 T61 T40 T01 T02 T00 T01 T55 R00 RFF 26 R5E T00 T61 T40 T01 T02 T00 T01 T5 R00 RFF R02 R02 R56 R00 RFF R03 R06 R64 R03 R07 R R08 R04 R04 R03 T00 TFF R02 R04 R64 R03 R04 <
← PAUSED ★ F1·Full	LAST DOWNLOAD: Date(07/ 4/1995) Time(21:48:29) By(CDH Window F2:HEX Space Bar:Resume F9:Help F10/Esc:Abort

Fig. 6.5 - Spy LAN Traffic shows Protocol between Host and Expansion Card

Table 6.C - Hot Keys Available in the Spy Lan Traffic Screen

Key	Description
F1	Full Window. Toggles full/half screens.
F2	HEX. Displays printable characters in ASCII, decimal or Hexadecimal formats. Press F2 repeatedly to step through the three selections.
Space Bar	Pause. Pauses and restarts analyzer mode.
F8	File. Captures protocol analyzer display to a file in the TCONFIG di- rectory. File name appears at lower right corner of analyzer window. In Spy LAN Traffic the file name is TKDASTRF.000. The 000 incre- ments to 001, 002, etc. each time F8 is executed. Deleting the files from the directory will return the counter to 000.
F9	Help. Display help screen for the current function.
F10/Esc	Abort. Exit monitoring.

Spy LAN Commands

The Spy LAN Commands function allows examination of the status of the expansion card. This function queries the expansion card with two basic questions:



Card

Are you there?

Are you configured?

The query and response can be observed. The host data is preceded by "T" and the expansion card response is preceded by "R". In addition, the responses are highlighted with a light background.

See Table 6.D.

Key	Description
F1	Full Window. Toggles full/half screens.
F2	HEX. Displays printable characters in ASCII, decimal or Hexadecimal formats. Press F2 repeatedly to step through the three selections.
Space Bar	Pause. Pauses and restarts analyzer mode.
F8	File. Captures protocol analyzer display to a file in the TCONFIG di- rectory. File name appears at lower right corner of analyzer window. In Spy LAN Commands the file name is TKDASCMD.000. The 000 in- crements to 001, 002, etc. each time F8 is executed. Deleting the files from the directory will return the counter to 000.
F9	Help. Display help screen for the current function.
F10/Esc	Abort. Exit monitoring.

Table 6.D - Hot Keys Available in the Spy Lan Commands Screen

Spy Satellite

The Spy Satellite function allows examination of the protocol between a base KDA and its associated satellite units.

∕kda Selected : RAU	JL Site : TBOS						
	Remote Status						
Open kda 864	SITE NAME: TBOS						
edit Alarm points	COMMENT :						
edit Parameters	PRODUCT :KDA-864, Version: 2.1B						
edit Miscellaneous	LST MOD :Date(07/ 4/1995) Time(21:47:00) Bu(CDH)						
edit Expansion	LST_DWNLD:Date(07/ 4/1995) Time(21:48:00) Bu(CDH)						
CONNECT DIRECT DOM	mlo DB STATUS: Current DB and remote are DIFFERENT						
Connect modem []]							
Reports Mon	vito						
	KDA 864 Smu Satellite						
TAR TEE TAS BER TAR	TEE TAA DIA TAA TEE TAB DES TAA TEE TAA DIA TAA TEE TA						
A DIVE TOO TEE TOP DI	$\frac{1}{1}$						
FE TAO UND TOO TEE T							
TOO TEE TOP UNG TOO	TEE TAO DIVE TOO TEE TAA DINI TOO TEE TAD DIVE TOO TEE TAO						
TOO IFF THE MAG TOO							
RFB 100 IFF IHH RFB							
F THE NOT TOO TFF TH	AS KED TOO TEE THA KED TOO TEE THB KEB TOO TEE THS TOO T						
FF TAA RIG TUU TFF T	AB REB TOO THE TAY REP TOO THE TAA REB TOO THE TAB REP						
TUU TFF TA9 RCU TUU	TFF TAA RIG TOU TFF TAB RIG TOU TFF TA9 RUI TOU TFF TAA						
RFE TOO TFF TAB RFC TOO TFF TA9 RFF TOO TFF TAA RFE TOO TFF TAB RFC TOO TF							
F TA9 RFF T00 TFF TAA RFC T00 TFF TAB RFE T00 TFF TA9 T00 TFF TAA RF8 T00 T							
FF TAB RFE							
)						
	LAST DOWNLOAD: Date(07/ 4/1995) Time(21:48:29) By(CDH)						
PAUSED * F1 Full Wi	ndow F2 HEX Space Bar Resume F9 Help F10/Esc Abort						

Fig. 6.7 - Spy Satellite shows Protocol between Host and Satellite KDA's

The query and response can be observed. The host data is preceded by "T" and the satellite unit responses are preceded by "R". In addition, the responses are highlighted with a light background.

Table 6.E - Hot Keys	Available in the Spy	Satellite Screen
----------------------	----------------------	------------------

Кеу	Description
F1	Full Window. Toggles full/half screens.
F2	HEX. Displays printable characters in ASCII, decimal or Hexadecimal formats. Press F2 repeatedly to step through the three selections.
Space Bar	Pause. Pauses and restarts analyzer mode.
F8	File. Captures protocol analyzer display to a file in the TCONFIG di- rectory. File name appears at lower right corner of analyzer window. In Spy Satellite the file name is TKDASEXP.000. The 000 increments to 001, 002, etc. each time F8 is executed. Deleting the files from the directory will return the counter to 000.
F9	Help. Display help screen for the current function.
F10/Esc	Abort. Exit monitoring.

Set Triggers

This function allows specifying a particular protocol pattern that will trigger a screen display during any of the spy modes. This is particularly useful when data rates are so high that ob-

Open kd Spy Mode Trigger Information	
edit Al	
edit Mi PREFILL AMOUNT : 50	
edit Ex MATCH PATTERN : 00 FF 01 40 03 02	
Connect SAMPLE DEPTH : 115	
Reports	
Softwar Utiliti	
probe N	
Quit The number of butes to conture after trigger	
SET TRIGGERS	
(DPS logged on) LAST MODIFIED: Date(06/30/1995) Time(04:04:39) By	(DPS)
uprevious field F8.Save F10/Esc.First Field	.KGRJ

Fig. 6.8 - Set Triggers shows a protocol segment "Snap-Shot"

serving the protocol becomes difficult. With a trigger set the screen will display a "snap-shot" of the protocol which can be easily observed for evaluation. The trigger can also have a set amount of data displayed prior to and following the trigger itself.

Select Set Triggers from the Connect Direct menu and fill in the fields according to the following table. When the Enter key is pressed after the last field is filled in the trigger will be effective for any spy mode selected, until the trigger mode is disabled.

Field Name Description						
Trigger Mode	"Y" enable the trigger mode during spy functions. "N" disables.					
Prefill Amount	Number of Bytes preceding trigger point. (0 to 99).					
Match Pattern	HEX Byte match (00-FF or "—" for "don't care").					
Sample Depth	Number of Bytes to capture after trigger. (0 to 999)					

Table 6.F - Field Names and Descriptions in the Set Triggers Screen

NOTE: The Trigger mode is effective for the spy primary and spy secondary functions also, even though those functions are features of the normal connect direct menu.

Appendix 1

Supporting DPS Inc. products after the sale continues to be an important concern to us. We endeavor to write our user manuals in an easy to understand manner. However, we realize problems come up and you need a person to talk to. Our telephone support personnel help you solve your problems in a courteous and efficient manner.

Customer Phone Support

DPS Inc. products are backed by Customer Support representatives who offer you timely, courteous service. If you've tried to work out your problem and need a friendly voice to help you, follow these steps:

1. Prepare Relevant Information.

In order to reduce the time it takes to answer your questions, you should have the following information readily available. If you do not have all of this information when you call, our Customer Support representatives can assist you in gathering this information. Please write the information down for easy access.

User Manual. Original (Master) DPS program diskettes (If you need to uninstall the program). Product Version Number. Serial Number (Located on the Original Diskettes, or displayed in software). Computer Information Computer Brand Name and Type/Model Contents of AUTOEXEC.BAT and CONFIG.SYS file Version of DOS RAM Memory and memory manager used

- 2. Please be at your computer when you call DPS Customer Support. In that way, we can more efficiently help you when you call.
- 3. Call during Customer Support hours. Customer Support hours are Monday through Friday, from 9 a.m. to 5 p.m. Pacific Standard Time.

Registration Cards

Thank you for sending in your registration cards. Registration cards help us stay in contact with you. They help us keep you up-to-date with important product information and make our contact with you more personal and productive.

Appendix 2

Alarm Levels - Alarm Levels are indicators that correspond to a specified alarm. Alarm Levels range from "A" to "D", with "A" as the highest priority, often designated "critical."

Alarm Point - A single discrete alarm input that requires a discrete (usually on-to-off or off-to-on) change in current flow or voltage to indicate a change of alarm condition from normal to alarm state. Assigned to a point number in a display and address. Usually reported to master as a single bit in a data stream.

Alternate Path - A backup route to the master via dial facility. The alternate path will be selected by the remote unit when communications via the primary path fail.

ASCII - The abbreviation for American Standard Code for Information Exchange. ASCII is a generic DOS text file. Most word processors can read ASCII text.

Battery - Facility DC power. Normally supplied from a battery plant inside the office. Polarity is normally negative (positive ground) in a telecom facility.

Baud - The data transmission rate that the Com Port uses to talk to the equipment. Common data rates include: 1200, 2400, 4800, 9600, 19200 (19) and 38400 (38).

BIOS - Basic Input/Output Operating System. This is the network of components that gives a computer the ability to operate with external devices and programs.

Change Of State - This is the condition of a point when it is in transition from one state to another. Change of State is abbreviated as COS.

Config. Sys File - The CONFIG.SYS file is an ASCII text file that allows the user to configure certain aspects of the operating system. Aspects that can be configured include: the number of internal disk buffers allocated, the number of files that can be open at one time, the formats for date and time, and the name and location of the executable command processor file.

Connectorized Unit provides quick-mate type connectors on the rear panel, as opposed to the more permanent wire-wrap connectorized units can shorten time for installation and replacement.

Control Point - Relay isolated output that is controlled by command from the master. Normally-open (SPST) dry contacts are commonly used.

Com Port - Abbreviation for Communication Port.

Communication Port - Serial interfaces that can be used for additional devices such as modems. Abbreviated as Com Port and normally referred to as COM1 & COM2.

COS - This is the abbreviation for Change Of State.

Craft Port - Serial port for connection of a computer or ASCII terminal to test and modify configuration of the remote.

CTS - This is the abbreviation for Clear To Send.

Database - A file containing records of organized and related information.

Dial String - A combined set of numeric and special characters used as the pager or modem dial number. The Dial String is the phone number and special characters that the KDA will use to dial out to master.

Displays - Displays contain 64 points of data.

Docking Module - Small plug-in circuit assembly that provides the electrical interface for a communications port. Available interfaces are RS232, RS422/485, 202 Modem (fro dedicated line) and 212 Modem (for dial line).

DOS Path - This is the DOS search path used to find specified directories on specified drives.

Download - The act of transferring a configuration file from a computer to the KDA. Can be done remotely via the dial port (modem), if equipped, or locally via the craft port.

DTMF - The abbreviation for Dual Tone Multi-Frequency. This is a common touch tone telephone.

Expansion Card - Accessory card that fits into a slot at the right side of the KDA chassis. Adds additional functions to the KDA, such as Analog Channels, TBOS Ports, Control Points, Discrete Alarm Points and ASCII Serial Ports.

Hexadecimal - A numbering system having a range from "0" to "F".

Interface - The electrical standard used by a data transmission port (RS232, RS422, RS485, 202 Modem, RJ11 etc.)

LED - The abbreviation for Light Emitting Diode. The LED is used as an indicator of activity.

Live Alarms - Live Alarms are indicated by a display of the number of standing alarms on the system.

Modem - The abbreviation for Modulator/Demodulator. Modems are used to transfer data over telephone lines.

Optically Isolated - Electrical interface, such as a discrete alarm point input, that isolates the external circuitry from the internal circuitry of the KDA with an optical coupler. Optical Isolation reduces the possibility of electrical mis-match or interference between the KDA and the alarm sources.

Point - The smallest unit on the line that can be monitored. It is therefore an alarm in itself.

Polarity - The polarity of a point can be either Normal (NRM) or Reverse (RVS). Normal polarity is current flow in a closed circuit for an alarm.

Primary Pad - Location of the docking module for the primary communications port. The Primary communications port will be used by the KDA to report all alarms, unless it is unequipped. If the Primary port fails to communicate properly, the KDA will switch to the secondary pad, if equipped. (see Docking Module)

Protocol Analyzer - A diagnostics mode in which the absolute hex bytes (hexadecimal), going to and from a particular channel, are displayed.

@SUBHEAD II = Qualification Time - The Qualification Time is the amount of time an alarm must stand in an "alarm state" before the KDA will perform an action.

Rebuild Key Files - This function rebuilds index key files that are associated with the data files.

RTS The abbreviation for Request To Send.

RTU - Remote Telemetry Unit. An RTU is a device that gathers alarm inputs and communicates them to a master alarm station.

Satellite - Additional KDA units at the same location and communicating with the master through a "base" KDA. Up to three satellites can be associated with a base KDA. Using satellites expands the use of a remote address, allowing greater system capacity.

Secondary Pad - Location of the docking module for the secondary communications port. The Primary communications port will be used by the KDA to report all alarms, unless it is unequipped. If the Primary port fails to communicate properly, the KDA will switch to the Secondary pad. The Secondary pad is normally the location of the dial-up modem, if equipped. (see Docking Module)

Stop Bits - The trailing bit(s) in a byte of data that indicate the end of a transmitted byte in RS232 communications.

String - A combined set of characters.

TBOS - Telemetry-Byte-Oriented-Serial protocol. A well-established alarm system protocol used by many telco-oriented manufacturers. Normally embedded in switches, channel banks and other equipment with many alarm points. TBOS normally uses an RS422 serial port. A port has a capacity of 512 alarm points, divided into 8 "displays" of 64 points each.

Timeout - A timeout action indicates a time limit was exceeded.

T/MonXM - DPS interrogating master.

T/KDA - Configuration software for the KDA.

Toggle - A process of switching back and forth from one mode to another. The enabling and disabling of switches and settings.

Traffic - Activity on the line or channel.

Upload - The act of transferring a configuration file from the KDA to a computer using T/KDA software. Can be done remotely via the dial port (modem), if equipped, or locally via the craft port.

Window - Depending on the context, the term window can refer to an alarm monitoring widow or to a special mode window.

Wire-Wrap - Wire connection points using a steel post that the connecting wire is wrapped around using a special tool. Wire-wrap is a fast and compact method of making lots of connections. It is commonly used on the KDA for all inputs and outputs, except on connectorized units. (See Connectorized.)

Word Length - A communication port attribute that indicates how many bits are in a byte. Typically is 8.

Appendix 3

DCP/DCPF/DCPS Addresses on Front Panel LEDs

NOTE: Address 000 is not used.

Addr	LED							
	1	2	3	4	5	6	7	8
001	ON	OFF						
002	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF
003	ON	ON	OFF	OFF	OFF	OFF	OFF	OFF
004	OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF
005	ON	OFF	ON	OFF	OFF	OFF	OFF	OFF
006	OFF	ON	ON	OFF	OFF	OFF	OFF	OFF
007	ON	ON	ON	OFF	OFF	OFF	OFF	OFF
008	OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF
009	ON	OFF	OFF	ON	OFF	OFF	OFF	OFF
010	OFF	ON	OFF	ON	OFF	OFF	OFF	OFF
011	ON	ON	OFF	ON	OFF	OFF	OFF	OFF
012	OFF	OFF	ON	ON	OFF	OFF	OFF	OFF
013	ON	OFF	ON	ON	OFF	OFF	OFF	OFF
014	OFF	ON	ON	ON	OFF	OFF	OFF	OFF
015	ON	ON	ON	ON	OFF	OFF	OFF	OFF
016	OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF
017	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF
018	OFF	ON	OFF	OFF	ON	OFF	OFF	OFF
019	ON	ON	OFF	OFF	ON	OFF	OFF	OFF
020	OFF	OFF	ON	OFF	ON	OFF	OFF	OFF
021	ON	OFF	ON	OFF	ON	OFF	OFF	OFF
022	OFF	ON	ON	OFF	ON	OFF	OFF	OFF
023	ON	ON	ON	OFF	ON	OFF	OFF	OFF
024	OFF	OFF	OFF	ON	ON	OFF	OFF	OFF
025	ON	OFF	OFF	ON	ON	OFF	OFF	OFF
026	OFF	ON	OFF	ON	ON	OFF	OFF	OFF
027	ON	ON	OFF	ON	ON	OFF	OFF	OFF
028	OFF	OFF	ON	ON	ON	OFF	OFF	OFF
029	OFF	OFF	ON	ON	ON	OFF	OFF	OFF
030	OFF	ON	ON	ON	ON	OFF	OFF	OFF
031	OFE	OFF						
032	ON	OFF	OFF	OFF	OFF	ON	OFF	OFF
033	OFF	ON	OFF	OFF	OFF	ON	OFF	OFF
034	ON	ON	OFF	OFF	OFF	ON	OFF	OFF
035	OFF	OFF	ON	OFF	OFF	ON	OFF	OFF
037	ON	OFF	ON	OFF	OFF	ON	OFF	OFF
038	OFF	ON	ON	OFF	OFF	ON	OFF	OFF
039	ON	ON	ON	OFF	OFF	ON	OFF	OFF
040	OFF	OFF	OFF	ON	OFF	ON	OFF	OFF
041	ON	OFF	OFF	ON	OFF	ON	OFF	OFF
042	OFF	ON	OFF	ON	OFF	ON	OFF	OFF
043	ON	ON	OFF	ON	OFF	ON	OFF	OFF
044	OFF	OFF	ON	ON	OFF	ON	OFF	OFF
045	ON	OFF	ON	ON	OFF	ON	OFF	OFF
046	OFF	ON	ON	ON	OFF	ON	OFF	OFF
047	ON	ON	ON	ON	OFF	ON	OFF	OFF
048	OFF	OFF	OFF	OFF	ON	ON	OFF	OFF
049	ON	OFF	OFF	OFF	ON	ON	OFF	OFF
050	OFF	ON	OFF	OFF	ON	ON	OFF	OFF
051	ON	ON	OFF	OFF	ON	ON	OFF	OFF
052	OFF	OFF	ON	OFF	ON	ON	OFF	OFF
053	ON	OFF	ON	OFF	ON	ON	OFF	OFF
054	OFF	ON	ON	OFF	ON	ON	OFF	OFF
055	ON	ON	ON	OFF	ON	ON	OFF	OFF
056	OFF	OFF	OFF	ON	ON	ON	OFF	OFF
057	ON	OFF	OFF	ON	ON	ON	OFF	OFF

Addr	LED							
	1	2	3	4	5	6	7	8
058	OFF	ON	OFF	ON	ON	ON	OFF	OFF
059	ON	ON	OFF	ON	ON	ON	OFF	OFF
060	OFF	OFF	ON	ON	ON	ON	OFF	OFF
061	ON	OFF	ON	ON	ON	ON	OFF	OFF
062	OFF	ON	ON	ON	ON	ON	OFF	OFF
063	ON	ON	ON	ON	ON	NO	OFF	OFF
064	OFF	OFF	OFF	OFF	OFF	OFF	ON	OFF
065	ON	OFF	OFF	OFF	OFF	OFF	ON	OFF
066	OFF	ON	OFF	OFF	OFF	OFF	ON	OFF
067	ON	ON	OFF	OFF	OFF	OFF	ON	OFF
068	OFF	OFF	ON	OFF	OFF	OFF	ON	OFF
069	ON	OFF	ON	OFF	OFF	OFF	ON	OFF
070	OFF	ON	ON	OFF	OFF	OFF	ON	OFF
071	ON	ON	ON	OFF	OFF	OFF	ON	OFF
072	OFF	OFF	OFF	ON	OFF	OFF	ON	OFF
073	ON	OFF	OFF	ON	OFF	OFF	ON	OFF
074	OFF	ON	OFF	ON	OFF	OFF	ON	OFF
075	ON	ON	OFF	ON	OFF	OFF	ON	OFF
076	OFF	OFF	ON	ON	OFF	OFF	ON	OFF
077	ON	OFF	ON	ON	OFF	OFF	ON	OFF
078	OFF	ON	ON	ON	OFF	OFF	ON	OFF
079	ON	ON	ON	ON	OFF	OFF	ON	OFF
080	OFF	OFF	OFF	OFF	ON	OFF	ON	OFF
081	ON	OFF	OFF	OFF	ON	OFF	ON	OFF
082	OFF	ON	OFF	OFF	ON	OFF	ON	OFF
083	ON	ON	OFF	OFF	ON	OFF	ON	OFF
084	OFF	OFF	ON	OFF	ON	OFF	ON	OFF
085	ON	OFF	ON	OFF	ON	OFF	ON	OFF
086	OFF	ON	ON	OFF	ON	OFF	ON	OFF
087	ON	ON	ON	OFF	ON	OFF	ON	OFF
088	OFF	OFF	OFF	ON	ON	OFF	ON	OFF
089	ON	OFF	OFF	ON	ON	OFF	ON	OFF
090	OFF	ON	OFF	ON	ON	OFF	ON	OFF
091	ON	ON	OFF	ON	ON	OFF	ON	OFF
092	OFF	OFF	ON	ON	ON	OFF	ON	OFF
093	ON	OFF	ON	ON	ON	OFF	ON	OFF
094	OFF	ON	ON	ON	ON	OFF	ON	OFF
095	ON	ON	ON	ON	ON	OFF	ON	OFF
096	OFF	OFF	OFF	OFF	OFF	ON	ON	OFF
097	ON	OFF	OFF	OFF	OFF	ON	ON	OFF
098	OFF	ON	OFF	OFF	OFF	ON	ON	OFF
100	OFF	OFF	OFF	OFF	OFF	ON	ON	OFF
100	OFF	OFF	ON	OFF	OFF	ON	ON	OFF
101	OFF	OFF	ON	OFF	OFF	ON	ON	OFF
102	OFF	ON	ON	OFF	OFF	ON	ON	OFF
103	OFF	OFF	OFE	OFF	OFF	ON	ON	OFF
104	OFF	OFF	OFF	ON	OFF	ON	ON	OFF
105	OFF	OFF	OFF	ON	OFF	ON	ON	OFF
100	OFF	ON	OFF	ON	OFF	ON	ON	OFF
107	OFF	OFF	ON	ON	OFF	ON	ON	OFF
100	ON	OFF	ON	ON	OFF	ON	ON	OFF
1109	OFF	ON	ON	ON	OFF	ON	ON	OFF
111	ON	ON	ON	ON	OFF	ON	ON	OFF
112	OFF	OFF	OFF	OFF	ON	ON	ON	OFF
112	ON	OFF	OFF	OFF	ON	ON	ON	OFF
114	OFF	ON	OFF	OFF	ON	ON	ON	OFF
115	ON	ON	OFF	OFF	ON	ON	ON	OFF

A-4 - DCP/DCPF/DCPS Addresses on Front Panel LEDs

Addr	LED	LED	LED	LED	LED	LED	LED	LED	Addr	LED	LED	LED	LED	LED	LED	LED	LED
	1	2	3	4	5	6	7	8		1	2	3	4	5	6	7	8
116	OFF	OFF	ON	OFF	ON	ON	ON	OFF	176	OFF	OFF	OFF	OFF	ON	ON	OFF	ON
117	ON	OFF	ON	OFF	ON	ON	ON	OFF	177	ON	OFF	OFF	OFF	ON	ON	OFF	ON
118	OFF	ON	ON	OFF	ON	ON	ON	OFF	178	OFF	ON	OFF	OFF	ON	ON	OFF	ON
119	ON	ON	ON	OFF	ON	ON	ON	OFF	179	ON	ON	OFF	OFF	ON	ON	OFF	ON
120	OFF	OFF	OFF	ON	ON	ON	ON	OFF	180	OFF	OFF	ON	OFF	ON	ON	OFF	ON
121	ON	OFF	OFF	ON	ON	ON	ON	OFF	181	ON	OFF	ON	OFF	ON	ON	OFF	ON
122	OFF	ON	OFF	ON	ON	NO	ON	OFF	182	OFF	ON	ON	OFF	ON	ON	OFF	ON
123	ON	ON	OFF	ON	ON	ON	ON	OFF	183	ON	ON	ON	OFF	ON	ON	OFF	ON
124	OFF	OFF	ON	ON	ON	ON	ON	OFF	184	OFF	OFF	OFF	ON	ON	ON	OFF	ON
125	ON	OFF	ON	ON	ON	ON	ON	OFF	185	ON	OFF	OFF	ON	ON	ON	OFF	ON
126	OFF	ON	ON	ON	ON	ON	ON	OFF	186	OFF	ON	OFF	ON	ON	ON	OFF	ON
127	ON	ON	ON	ON	ON	ON	ON	OFF	187	ON	ON	OFF	ON	ON	ON	OFF	ON
128	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	188	OFF	OFF	ON	ON	ON	ON	OFF	ON
129	ON	OFF	OFF	OFF	OFF	OFF	OFF	ON	189	ON	OFF	ON	ON	ON	ON	OFF	ON
130	OFF	ON	OFF	OFF	OFF	OFF	OFF	ON	190	OFF	ON	ON	ON	ON	ON	OFF	ON
131	ON	ON	OFF	OFF	OFF	OFF	OFF	ON	191	ON	ON	ON	ON	ON	ON	OFF	ON
132	OFF	OFF	ON	OFF	OFF	OFF	OFF	ON	192	OFF	OFF	OFF	OFF	OFF	OFF	ON	ON
133	ON	OFF	ON	OFF	OFF	OFF	OFF	ON	193	ON	OFF	OFF	OFF	OFF	OFF	ON	ON
134	OFF	ON	ON	OFF	OFF	OFF	OFF	ON	194	OFF	ON	OFF	OFF	OFF	OFF	ON	ON
135	ON	ON	ON	OFF	OFF	OFF	OFF	ON	195	ON	ON	OFF	OFF	OFF	OFF	ON	ON
136	OFF	OFF	OFF	ON	OFF	OFF	OFF	ON	196	OFF	OFF	ON	OFF	OFF	OFF	ON	ON
137	ON	OFF	OFF	ON	OFF	OFF	OFF	ON	197	ON	OFF	ON	OFF	OFF	OFF	ON	ON
138	OFF	ON	OFF	ON	OFF	OFF	OFF	ON	198	OFF	ON	ON	OFF	OFF	OFF	ON	ON
139	ON	ON	OFF	ON	OFF	OFF	OFF	ON	199	ON	ON	ON	OFF	OFF	OFF	ON	ON
140	OFF	OFF	ON	ON	OFF	OFF	OFF	ON	200	OFF	OFF	OFF	ON	OFF	OFF	ON	ON
141	ON	OFF	ON	ON	OFF	OFF	OFF	ON	201	ON	OFF	OFF	ON	OFF	OFF	ON	ON
142	OFF	ON	ON	ON	OFF	OFF	OFF	ON	202	OFF	ON	OFF	ON	OFF	OFF	ON	ON
143	ON	ON	ON	ON	OFF	OFF	OFF	ON	203	ON	ON	OFF	ON	OFF	OFF	ON	ON
144	OFF	OFF	OFF	OFF	ON	OFF	OFF	ON	204	OFF	OFF	ON	ON	OFF	OFF	ON	ON
145	ON	OFF	OFF	OFF	ON	OFF	OFF	ON	205	ON	OFF	ON	ON	OFF	OFF	ON	ON
146	OFF	ON	OFF	OFF	ON	OFF	OFF	ON	206	OFF	ON	ON	ON	OFF	OFF	ON	ON
147	ON	ON	OFF	OFF	ON	OFF	OFF	ON	207	ON	ON	ON	ON	OFF	OFF	ON	ON
148	OFF	OFF	ON	OFF	ON	OFF	OFF	ON	208	OFF	OFF	OFF	OFF	ON	OFF	ON	ON
149	ON	OFF	ON	OFF	ON	OFF	OFF	ON	209	ON	OFF	OFF	OFF	ON	OFF	ON	ON
150	OFF	ON	ON	OFF	ON	OFF	OFF	ON	210	OFF	ON	OFF	OFF	ON	OFF	ON	ON
151	ON	ON	ON	OFF	ON	OFF	OFF	ON	211	ON	ON	OFF	OFF	ON	OFF	ON	ON
152	OFF	OFF	OFF	ON	ON	OFF	OFF	ON	212	OFF	OFF	ON	OFF	ON	OFF	ON	ON
153	ON	OFF	OFF	ON	ON	OFF	OFF	ON	213	ON	OFF	ON	OFF	ON	OFF	ON	ON
154	OFF	ON	OFF	ON	ON	OFF	OFF	ON	214	OFF	ON	ON	OFF	ON	OFF	ON	ON
155	ON	ON	OFF	ON	ON	OFF	OFF	ON	215	ON	ON	ON	OFF	ON	OFF	ON	ON
156	OFF	OFF	ON	ON	ON	OFF	OFF	ON	216	OFF	OFF	OFF	ON	ON	OFF	ON	ON
157	ON	OFF	ON	ON	ON	OFF	OFF	ON	217	ON	OFF	OFF	ON	ON	OFF	ON	ON
158	OFF	ON	ON	ON	ON	OFF	OFF	ON	218	OFF	ON	OFF	ON	ON	OFF	ON	ON
159	ON	ON	ON	ON	ON	OFF	OFF	ON	219	ON	ON	OFF	ON	ON	OFF	ON	ON
160	OFF	OFF	OFF	OFF	OFF	ON	OFF	ON	220	OFF	OFF	ON	ON	ON	OFF	ON	ON
161	ON	OFF	OFF	OFF	OFF	ON	OFF	ON	221	ON	OFF	ON	ON	ON	OFF	ON	ON
162	OFF	ON	OFF	OFF	OFF	ON	OFF	ON		OFF	ON	ON	ON	ON	OFF	ON	ON
163	ON	ON	OFF	OFF	OFF	ON	OFF	ON	223	ON	ON	ON	ON	ON	OFF	ON	ON
164	OFF	OFF	ON	OFF	OFF	ON	OFF	ON	224	OFF	OFF	OFF	OFF	OFF	ON	ON	ON
165	UN OFF	OFF	ON	OFF	OFF	UN OV	OFF	UN OV	225	OFF	OFF	OFF	OFF	OFF	UN ON	ON	ON
166	OFF	UN ON	ON	OFF	OFF	ON	OFF	UN OV	226	OFF	UN OV	OFF	OFF	OFF	ON	ON	ON
167	UN OFF	UN OFF	UN OFF	OFF	OFF	ON	OFF	ON	227	OFF	UN OFF	OFF	OFF	OFF	ON	ON	ON
168	OFF	OFF	OFF	UN OV	OFF	ON	OFF	ON ON	228	OFF	OFF	ON	OFF	OFF	ON	ON	ON
169	UN	OFF	OFF	ON	OFF	ON	OFF	UN OV	229	OFF	OFF	ON	OFF	OFF	ON	ON	UN ON
170	OFF	ON	OFF	ON	OFF	ON	OFF	ON	230	OFF	ON	ON	OFF	OFF	ON	ON	ON
1/1	UN	UN	OFF	ON	OFF	ON	OFF	UN OV	231	OFF	UN	OFF	OFF	OFF	ON	ON	UN ON
172	OFF	OFF		ON	OFF	ON	OFF	ON		OFF	OFF	OFF	ON	OFF	ON	ON	ON
1/3	OFF	OFF	ON	ON	OFF	ON	OFF	ON		OFF	OFF	OFF	ON	OFF	ON	ON	ON
1/4	ON	ON	ON	ON	OFF		OFF	ON	234	OFF	ON	OFF	ON	OFF	ON	ON	ON
1/3	UN	UN	UN	UN	UFF		UFF	UN	235	UN	UN	OFF	UN	UFF	UN	UN	UN

A-5 - DCP/DCPF/DCPS Addresses on Front Panel LEDs

Addr	LED							
	1	2	3	4	5	6	1	ð
236	OFF	OFF	ON	ON	OFF	ON	ON	ON
237	ON	OFF	ON	ON	OFF	ON	ON	ON
238	OFF	ON	ON	ON	OFF	ON	ON	ON
239	ON	ON	ON	ON	OFF	ON	ON	ON
240	OFF	OFF	OFF	OFF	ON	ON	ON	ON
241	ON	OFF	OFF	OFF	ON	ON	ON	ON
242	OFF	ON	OFF	OFF	ON	ON	ON	ON
243	ON	ON	OFF	OFF	ON	ON	ON	ON
244	OFF	OFF	ON	OFF	ON	ON	ON	ON
245	ON	OFF	ON	OFF	ON	ON	ON	ON
246	OFF	ON	ON	OFF	ON	ON	ON	ON
247	ON	ON	ON	OFF	ON	ON	ON	ON
248	OFF	OFF	OFF	ON	ON	ON	ON	ON
249	ON	OFF	OFF	ON	ON	ON	ON	ON
250	OFF	ON	OFF	ON	ON	ON	ON	ON
251	ON	ON	OFF	ON	ON	ON	ON	ON
252	OFF	OFF	ON	ON	ON	ON	ON	ON
253	ON	OFF	ON	ON	ON	ON	ON	ON
254	OFF	ON						
255	ON							

Alarm Mapping

Alarm mapping is the way data is formatted for transmission between network elements. Mapping is different for each protocol. The tables and illustrations in this appendix attempt to provide enough information to allow you to read and interpret the information in protocol analyzer windows.

Alarm Data

The alarm protocols common to DPS network elements use an eight-bit character as the basic unit of alarm data. This character can encode eight alarm points and can also be represented in the protocol by two hexadecimal numbers. Four characters comprise one-half of a 64 point display. One character also is all that is required for up to 256 addresses. Other uses of the character in most protocols include operation codes, line numbers and framing.

Alarm Point Encoding

The following illustration shows eight switches, simulating eight alarm inputs. A closed switch represents an alarm, which produces a '1' bit. An open switch represents no alarm, which produces a '0' bit. The resulting character is shown in Binary Coded Decimal, Decimal and Hexadecimal formats.

In determining Hexadecimal numbers, the eight-bit character is divided into two 4-bit "nibbles" and each nib-



ble is converted to hexadecimal.

Use Table A to convert BCD to Hexadecimal.

Alarm Mapping and Stacking Table

Table A - BCD-to-Decimal-to-Hexadecimal Conversion Chart

BCD	Nibble 2 Decimal	Nibble 1 Decimal	Hexadeci- mal
0000	0	0	0
0001	16	1	1
0010	32	2	2
0011	48	3	3
0100	64	4	4
0101	80	5	5
0110	96	6	6
0111	112	7	7
1000	128	8	8
1001	144	9	9
1010	160	10	А
1011	176	11	В
1100	192	12	С
1101	208	13	D
1110	224	14	Е
1111	240	15	F

The following table presents some examples of BCD-to decimal and hexadecimal.

 Table B - Examples of

 BCD-to-Decimal-to-Hexadecimal Conversions

BCD Nibble 2				BCD Nibble 1			Hex.	Dec.	
2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰		
128	64	32	16	8	4	2	1		
0	0	0	0	0	0	0	0	00	0
0	0	0	0	0	0	0	1	01	1
1	1	0	0	0	1	0	0	C4	196
0	1	1	1	1	1	1	1	7F	127
0	0	1	0	1	1	0	0	2C	44
1	0	1	0	1	0	1	0	AA	170

DCPF Protocol

NOTE: In the following discussion only protocol analyzer presentations in hexadecimal will be used.

An example of a protocol analyzer window showing DCPF protocol is illustrated below.

7
7
i
l
1

The protocol consists of transmitted data ('T' prefix) and received data (no prefix). Three word structures are used, an *inquiry*, a *response preamble* and a *response line*. The T prefix always precedes data being transmitted from the device being analyzed. (i.e.: At a T/MonXM WorkStation 'T' precedes the data being transmitted by the Work-Station to a remote.) Some protocol analyzers also use an 'R' in front of received data.

Inquiry: [FRAME] [ADDRESS] [OP CODE] [BCH]

Example: **T00 TFF T01 T40 T03 T02 T00 T01 T17** ("T" in front of each character indicates that this inquiry originates from the point where protocol is being analyzed, which is the T/MonXM WorkStation.)

Frame: T00 TFF Always the same

Address: T01 One character

Op Code: **T40 T03 T02 T00 T01** Up to 5 characters. (See table)

BCH: T17 One character error check code

Table C - Operation Codes

Op Code	Description	
02	Upset Polling. Returns only the lines that have data	
	that has changed since the last transmission	
03	Full Update. Returns all lines.	
06	Data Acknowledge.	
00 01	00 01 End of Op Code. Always the same.	
Other codes are used for group polling and control point operation.		

Response Preamble: [FRAME] [ADDRESS] [Number of LINES of Data to Follow] [BCH]

Example: **00 FF 01 02 01**

Frame: 00 FF Address: 01 One character Lines: 02 One character BCH: 01 One character error check code.

Response Line: [FRAME] [LINE No.] [DATA Character 1] [DATA 2] [DATA 3] [DATA 4] [BCH]

Example: 00 FF 03 40 00 01 80 20 3A

Frame: 00 FF

Line No.: 03 One character (Decimal 3) (BCD 0000 0011)

Data 1: **40** One Character (Decimal 68) (BCD 0100 0100)

Data 2: 00 01 One Character (Decimal 0) (BCD 0000 0000)

Data 3: **80** One Character (Decimal 128) (BCD 1000 0000) Data 4: **20** One Character (Decimal 32) (BCD 0010 0000)

BCH: **3A** One character error check code

(Decimal 58) (BCD 0011 1010). Note that the above shows half of a display with points 3,

7, 24, and 30 in alarm.

DCP Protocol

DCP Protocol is like DCPF, without the framing bits.

DCPS Protocol

DCPS Protocol is like DCPF, without the framing bits.

Stacking Table

Table D and E list the displays required to transmit the alarm and control data from KDA 864's for DCPF protocol. The table lists satellite groupings, but single KDA's are the same as satellite no. 0. Use this table for mapping when programming the T/MonXM (Master) Software.

DeviceProductPointOddessOppointSundardIbser KoldControl 1-24N331-3In SourceControl 1-24N331-3In SourceControl 1-24N331-3In SourceControl 1-24N1-341-24In SourcePort 1. Displays 1.8M*9-16.1-24In SourcePort 1. Displays 1.8M*1-241-24In SourcePort 1. Displays 1.8M*1-241-24Port 1. Displays 1.8M*1-241-241-24In Displays 1.8M*1-241-241-24Port 1. Displays 1.8M*1-241-241-24Port 1. Displays 1.8M*1-241-241-24Port 1. Displays 1.8M*9-161-241-24Port 1. Displays 1.8M*1-241-241-24Port 1. Displays 1.8M*1-241-241-24Port 1		Remote		T/MonXM			
Sindard Bare KOA 864 Altrms 1-64 N 1 1-64 Cortorls 1: 3 N 33 1: 8. IR-23 Relay Exp. in In Base Cortorls 1: 24 M* 1 1: 24 4:Port TBOS Expension In Base Port 1, Displays 1: 3 M* 9: 61.6 1: 64 in each display 8:Port TBOS Expension In Base Port 1, Displays 1: 3 M* 1: 64 1: 64 in each display 9:Port 2, Displays 1: 3 M* 0: 65.7 See nable E 1: 64 in each display 9:Port 2, Displays 1: 3 M* 0: 65.7 See nable E 1: 64 in each display 9:Port 2, Displays 1: 3 M* 0: 65.7 See nable E 1: 64 in each display 9:Port 3, Displays 1: 4 1: 8 1: 64 in each display 1: 65.7 See nable E 9:Port 3, Displays 1: 8 1: 8 0: 65.7 See nable E 1: 64 in each display 9:Port 3, Displays 1: 8 1: 8 0: 7: 24 1: 64 1: 64 1: 64 10: 7, Displays 1: 8 1: 8 0: 7: 24 1: 64 1: 64 1: 64	Device	Product	Points	Address	Display	Point	
Re-24 Rely Exp. in bac Control 1-3 N 33 1-8 4-Port IDS Expansion in Base Port 1. Diplys 1-8 M* 1 1-24 4-Port IDS Expansion in Base Port 1. Diplys 1-8 M* 9-16. 1-64 7607 Diplys 1-8 M* 9-16. 1-64 1-64 1-64 7607 Diplys 1-8 M* 9-16. 1-64	Standard	Base KDA 864	Alarms 1-64	N	1	1-64	
R=24 Rely Esp. in Base Control 1-24 M* 1 1-24 4-Port TROS Fepanison in Base Port 1, Displays 1.8 M* 1.8 1-64 in each display 97 041, Displays 1.8 M* 97.0 See table E See table E 1005 Device Fahrue M* 0.5232 See table E See table E 1005 Device Fahrue M* 0.63 See table E Total in cach display 1015 Displays 1.8 M* 0.724 Fort TROS Partice Data Port 2, Displays 1.8 M* 0.724 1015 Displays 1.8 M* 0.724 Fort 3, Displays 1.8 1.64 In cach display 1015 Displays 1.8 1.* 1.8 1.64 in each display 1015 Displays 1.8 1.* 1.8 1.64 in each display 1015 Displays 1.8 1.* 1.8 1.64 in each display 1016 Displays 1.8 1.* 1.8 1.64 in each display 1101 Displays 1.8 1.* 1.8 1.64 in each display 1102 Displays 1.8 1.*			Controls 1-8	N	33	1-8	
4-Port TROS Fayansio in Base Port 1, Displays 1-8 M* 1-8 1-64 in each display Port 3, Displays 1-8 M* 1724 Port 3, Displays 1-8 M* 25-22 TBOS Porces Failure M* 65 Soc table F. Port 1, Displays 1-8 M* 1-64 1-64 Port 2, Displays 1-8 M* 1-64 1-64 Port 2, Displays 1-8 M* 1-64 1-64 Port 2, Displays 1-8 M* 1-64 1-64 Port 3, Displays 1-8 M* 1-64 1-64 Port 7, Displays 1-8 L* 1-72 1-64 Port 7, Displays 1-8 L* 1-72 1-64 Port 7, Displays 1-8 L* 1-72 1-72 Port 7, Displays 1-8 L* 1-72 1-72 Port 7, Displays 1-8 L* 1-84 1-84 LR-24 in sat. 1 Control 1-8 N 3.0 1-64 ROD 864 Satcillic 1 Control 1-24 N 6 1-84 LR-24 in sat. 2 </td <td></td> <td>LR-24 Relay Exp. in base</td> <td>Control 1-24</td> <td>M*</td> <td>1</td> <td>1-24</td>		LR-24 Relay Exp. in base	Control 1-24	M*	1	1-24	
In Base Port 2, Dipplay 1-8 M4 9-16 Port 3, Dipplay 1-8 M4 17-24 Port 3, Dipplay 1-8 M4 25-32 8-Port TROS Expansion in Base Port 1, Dipplay 1-8 M4 1-54 Port 3, Dipplay 1-8 M4 1-64 1-64 Port 4, Dipplay 1-8 M4 0-16 1-64 Port 3, Dipplay 1-8 M4 0-16 1-64 1-64 Port 3, Dipplay 1-8 M4 0-16 1-64		4-Port TBOS Expansion	Port 1, Displays 1-8	M*	1-8	1-64 in each display	
Port 3, Display 1-8 M4 17-24 Hord 3, Display 1-8 M4 65 See table E 1005 Povice Failure M4 65 See table E in Base Port 1, Dinglay 1-8 M4 9-16 1-64 in cach display in Base Port 2, Dinglay 1-8 M4 9-16 1-64 in cach display Port 6, Dinglay 1-8 M4 17-24 1-64 in cach display 1-64 in cach display Port 7, Dinglay 1-8 M4 1-64 1-64 in cach display 1-64 in cach display Port 6, Dinglay 1-8 M4 9-16 1-64 in cach display 1-64 in cach display Port 7, Dinglay 1-8 L* 9-16 1-84 1-64 in cach display Port 7, Dinglay 1-8 L* 9-16 1-84 1-84 Port 7, Dinglay 1-8 N 34 1-8 L*2-4 in st1 Alarm 1-64 N 3 1-84 L*2-4 in st1 Control 1-24 N 6 1-84 L*2-4 in st1 Control 1-24 N 6 1-84 <t< td=""><td></td><td>in Base</td><td>Port 2, Displays 1-8</td><td>M*</td><td>9-16</td><td></td></t<>		in Base	Port 2, Displays 1-8	M*	9-16		
Port 4, Displays 1-8 M* 25-32 B-Port TROS Expansion in Rase Port 1, Displays 1-8 M* 1-8 1-64 in cach display Port 3, Displays 1-8 M* 9-16 Port 3, Displays 1-8 M* 17.2 1000 Sevice Failure M* 65 See table E Port 3, Displays 1-8 M* 17.4 10-80 1-64 in cach display Port 3, Displays 1-8 M* 65 See table E 1-64 Port 3, Displays 1-8 L* 9-16 1-64 1-64 Port 6, Displays 1-8 L* 1-24 1-64 1-64 Port 7, Displays 1-8 L* 1-24 1-64 1-64 Port 7, Displays 1-8 L* 1-24 1-64			Port 3, Displays 1-8	M*	17-24		
Image Image <th< td=""><td></td><td></td><td>Port 4, Displays 1-8</td><td>M*</td><td>25-32</td><td></td></th<>			Port 4, Displays 1-8	M*	25-32		
8-Port TROS Expansion In Base Port 1, Displays 1-8 M* 1-8 1-64 in each display Port 2, Displays 1-8 M* 9-16 17-24 Port 3, Displays 1-8 M* 17-24 Port 4, Displays 1-8 M* 65 See table E Port 6, Displays 1-8 L* 1-8 1-64 in each display Port 7, Displays 1-8 L* 1-72-24 1-64 in each display Port 7, Displays 1-8 L* 1-72-24 1-64 in each display Port 7, Displays 1-8 L* 1-72-24 1-64 in each display Port 7, Displays 1-8 L* 1-8 1-8 ROA 864 Satellite 1 Alarms 1-64 N 2 1-64 Control 1-24 N 6 1-24 1-8 ROA 864 Satellite 2 Alarms 1-64 N 4 1-64 Control 1-24 N 6 1-24 1-8 ROA 864 Satellite 3 Control 1-24 N 7 1-24 ROA 64 Satellite 3 Control 1-24 N 7 1-24 <td></td> <td></td> <td>TBOS Device Failure</td> <td>M*</td> <td>65</td> <td>See table E</td>			TBOS Device Failure	M*	65	See table E	
in Base Part 2, Displays 1-8 M* 9-16 Port 3, Displays 1-8 M* 17.24 Port 4, Displays 1-8 M* 65 Port 5, Displays 1-8 L* 9-16 Port 7, Displays 1-8 L* 9-16 LR-24 in stt 1 Control 1-24 N 3 LR-24 in stt 2 Cortrol 1-24 N 4 Channel 1 M* 1 1-64 Channel 2 M* 2 2 Port 6, Disclat 1-8 N 3		8-Port TBOS Expansion	Port 1, Displays 1-8	M*	1-8	1-64 in each display	
Port 3. Displays 1-8 M* 17-24 Port 3. Displays 1-8 M* 25-32 TBOB Device Failure M* 65 Port 5. Displays 1-8 1-8 1-64 in each display Port 7. Displays 1-8 1-8 1-64 Port 7. Displays 1-8 1-8 1-64 Port 8. Displays 1-8 1-8 1-64 Port 7. Displays 1-8 1-8 1-64 Port 8. Displays 1-8 1-8 1-64 Controls 1-8 N 34 1-8 I.R-24 in sat. 1 Controls 1-8 N 35 1-8 I.R-24 in sat. 2 Control 1-24 N 6 1-24 KDA 864 Satellite 3 Alarms 1-64 N 4 1-64 Controls 1-8 N 36 1-8 1-8 I.R-24 in sat. 3 Controls 1-8 N 36 1-8 I.R-24 in sat. 3 Controls 1-8 N 36 1-8 I.R-24 in sat. 3 Controls 1-8 N 32 3 Maj Uhr Channe		in Base	Port 2, Displays 1-8	M*	9-16	-	
Image: stand standing large			Port 3, Displays 1-8	M*	17-24	-	
Image: second			Port 4, Displays 1-8	M*	25-32		
8 Channel Analog Expansion Card Perior (5) Displays 1-8 1.* 9-16 1007 (5) Displays 1-8 1.* 1.* 1007 (5) Displays 1-8 1.* 1.* 1100 (1100) Alarms 1-64 N 2 1100 (1100) 1.8 N 3.4 1100 (1100) 1.8 N 3.5 1100 (1100) 1.8 N 3.5 1100 (1100) 1.8 N 3.6 1100 (1100) 1.4 N 1.24 1100 (1100) 1.4 N 3.8 1100 (1100) 1.4 1.4			TBOS Device Failure	M*	65	See table E	
Image: Part ()			Port 5, Displays 1-8	<u>L*</u>	1-8	1-64 in each display	
Perf () Description ()			Port 6, Displays 1-8	L*	9-16	-	
Prof. 8, Dsplays 1-8 C.* 25-52 TBOS Device Failure L* 65 Sec table E IBOS Device Failure N 34 1-8 LR-24 in sat. 1 Controls 1-8 N 34 1-8 LR-24 in sat. 1 Controls 1-8 N 35 1-24 KDA 864 Satellite 2 Alarms 1-64 N 3 1-64 Controls 1-8 N 35 1-8 1-8 LR-24 in sat. 2 Control 1-24 N 6 1-24 KDA 864 Satellite 3 Alarms 1-64 N 4 1-64 LR-24 in sat. 3 Control 1-24 N 7 1-24 KDA 864 Satellite 3 Alarms 1-64 N 4 1-64 Roman 1 M* 3 1-64 1-64 1-64 KDA 864 Satellite 2 Control 1-24 N 7 1-24 1-64 1-64 1-64 1-64 1-64 1-8 1-8 1-8 1-64 1-8 1-64 1-64 1-8			Port 7, Displays 1-8	L*	17-24	-	
IBOS Device Failure L* 65 See table E KDA 864 Satellite 1 Alarms 1-64 N 2 1-64 IR-24 in sat.1 Controls 1-8 N 34 1-8 IR-24 in sat.1 Control 1-24 N 5 1-24 KDA 864 Satellite 2 Alarms 1-64 N 3 1-64 IR-24 in sat.2 Control 1-24 N 6 1-24 KDA 864 Satellite 3 Alarms 1-64 N 4 1-64 Control 1-24 N 6 1-24 1 KDA 864 Satellite 3 Alarms 1-64 N 4 1-64 Control 1-24 N 7 1-24 1 1 KDA 864 Satellite 3 Control 1-24 N 7 1-24 1 <td< td=""><td></td><td></td><td>Port 8, Displays 1-8</td><td>L*</td><td>25-32</td><td>0</td></td<>			Port 8, Displays 1-8	L*	25-32	0	
KDA 80F stelline 1 Alarms 1-64 N 2 1-64 LR-24 in sat. 1 Controls 1-8 N 34 1-8 LR-24 in sat. 1 Controls 1-8 N 33 1-64 KDA 80F stellite 2 Alarms 1-64 N 3 1-64 KDA 80F stellite 3 Alarms 1-64 N 6 1-24 KDA 80F stellite 3 Alarms 1-64 N 6 1-24 KDA 80F stellite 3 Alarms 1-64 N 6 1-24 KDA 80F stellite 3 Alarms 1-64 N 6 1-24 KDA 80F stellite 3 Alarms 1-64 N 7 1-24 KDA 80F stellite 3 Alarms 1-64 N 7 1-24 KDA 80F stellite 3 Channel 1 M* 1 1= Min Udr S Channel Analog Expansion Card Channel 3 M* 3 3 = Maj Ubr Channel 5 M* 3 3 = Maj Ubr 4 = Maj Or 5 is (no alarms to map) Channel 6 M* 1 1			TBOS Device Failure	L*	65	See table E	
IR-24 in sat. 1 Controls 1-8 N 54 1-8 KDA 864 Satellite 2 Alarms 1-64 N 3 1-64 KDA 864 Satellite 2 Controls 1-8 N 35 1-8 LR-24 in sat. 2 Controls 1-8 N 6 1-24 KDA 864 Satellite 3 Alarms 1-64 N 4 1-64 KDA 864 Satellite 3 Controls 1-8 N 36 1-8 LR-24 in sat. 3 Controls 1-8 N 36 1-8 LR-24 in sat. 3 Controls 1-8 N 36 1-24 generation of the set of		KDA 864 Satellite I	Alarms 1-64	N	2	1-64	
LRC4 in Sal. 1 Control 1-24 N 3 1-24 KDA 864 Satellite 2 Alarms 1-64 N 3 1-64 Controls 1-8 N 66 1-24 KDA 864 Satellite 3 Alarms 1-64 N 6 1-24 KDA 864 Satellite 3 Alarms 1-64 N 4 1-64 KDA 864 Satellite 3 Alarms 1-64 N 4 1-64 Controls 1-8 N 36 1-8 1 B Channel Analog Expansion Card Control 1-24 N 7 1-24 S Channel Analog Expansion Card Channel 1 M* 1 1 = Min Udr Channel 5 M* 3 3 3 = Maj Unr Channel 6 M* 6 6 1-24 Channel 7 M* 3 3 3 = Maj Unr Channel 5 M* 3 3 3 3 Channel 6 M* 6 3 3 3 3 Channel 7 M* 3		LD 24	Controls 1-8	N	54	1-8	
KDA 80% satisfile 2 Autims 1-94 N 3 1-94 Controls 1-8 N 35 1-8 LR-24 in sat. 2 Control 1-24 N 6 1-24 KDA 806 Satellite 3 Alarms 1-64 N 4 1-64 Control 1-24 N 6 1-24 KDA 806 Satellite 3 Alarms 1-64 N 4 1-64 Channel 1 M* 1 1-8 1-24 S Channel Analog Expansion Card Channel 1 M* 1 1= Min Udr Channel 6 M* 3 3= Maj Ovr 3= Maj Ovr Channel 1 M* 4 4 Maj Ovr Channel 5 M* 3 3= Maj Ovr Channel 6 M* 6 6 6 Channel 7 M* 7 1 4= Maj Ovr Channel 8 M* 3 3= Maj Udr 4= Maj Ovr Channel 1 M* 1 1= Min Udr 2 1 Channel		LR-24 in sat. 1	Control 1-24	N	2	1-24	
IR-24 in sat. 2 Control 1-24 N 6.3 1-8 KDA 864 Satellite 3 Alarms 1-64 N 4 1-64 KDA 864 Satellite 3 Controls 1-8 N 36 1-8 Record and the state of the s		KDA 804 Satellite 2	Alarms 1-04	N	25	1-04	
LR-24 in Saf. 2 Controls 1-24 N 0 1-24 KDA 864 Satellite 3 Alarms 1-64 N 4 1-64 B Channel Analog Expansion Card Version A or B Channel 1 M* 1 1 = Min Udr S Channel Analog Expansion Card Version A or B Channel 1 M* 2 3 = Maj Uar Channel 2 M* 3 Maj Uar 3 = Maj Uar 4 = Maj Ovr Channel 1 M* 4 4 5-53 5-32 = Absolute value 5-32 = Absolute value Channel 1 M* 6 6 6 6 6 Channel 1 M* 7 1 2 Min Ovr 3 = Maj Uar Channel 1 M* 6 6 6 6 6 6 7 2 Min Ovr 3 = Maj Uar 5 32 = Absolute value bits (no alarms to map) 6 6 6 6 6 6 6 6 6 6 6 6 6 6 7		IP 24 in set 2	Control 1 24	N	55	1-0	
KDA solution Addition 1-04 N 4 1-04 Controls 1-8 N 36 1-8 Remain Analog Expansion Card Version A or B Channel 1 M* 1 1 = 24 Min Udr Channel 1 M* 1 1 = 400 Yersion A or B Channel 2 M* 2 2 = Min Ovr S Channel Analog Expansion Card Channel 4 M* 3 4 = Maj Ovr 5-32 = Absolute value 5-32 = Abso		UK-24 III Sal. 2	Alarma 1.64	N	6	1-24	
Image: LR-24 in sat. 3 Control 1-24 N 7 1-24 8 Channel Analog Expansion Card Version A or B Channel 1 M* 1 = Min Udr 2 min Udr Channel 1 M* 1 = Min Udr 2 = Min Udr 2 min Udr Channel 3 M* 3 = Maj Ubr 4 = Maj Ovr 3 Channel Analog Expansion Card Channel 6 M* 6 - Min Udr 2 = Min Ovr 16 Channel Analog Expansion Card Channel 1 M* 1 = Min Udr 2 = Min Ovr 16 Channel Analog Expansion Card Channel 1 M* 1 = Min Udr 2 = Min Ovr 16 Channel Analog Expansion Card Channel 1 M* 1 = Min Udr 2 = Min Ovr 16 Channel Analog Expansion Card Channel 2 M* 3 3 = Maj Udr 3 = Maj Udr 16 Channel Analog Expansion Card Channel 2 M* 3 5 - 32 = Absolute value bits (no alarms to map) 5 - 32 = Absolute value bits (no alarms to map) 5 - 32 = Absolute value bits (no alarms to map) 5 - 32 = Absolute value bits (no alarms to map) 5 - 32 = Abso		KDA 804 Satellite 5	Controls 1.8	N	36	1.8	
B Channel Analog Expansion Card Version A or B Channel 1 M* 1 I = Min Udr 8 Channel 2 M* 2 Min Udr 2 = Min Ovr 3 = Maj Unr 1 Channel 3 M* 3 Maj Unr 4 = Maj Ovr 3 = Maj Unr 1 Channel 4 M* 4 5 5-32 = Absolute value 5-32 = Absolute value bits (no alarms to map) 16 Channel Analog Expansion Card Channel 1 M* 7 5-32 = Absolute value bits (no alarms to map) 16 Channel Analog Expansion Card Channel 1 M* 8 1 = Min Udr 2 = Min Ovr 3 Maj Unr Channel 3 M* 3 4 4 = Maj Ovr 16 Channel Analog Expansion Card Channel 1 M* 1 1 = Min Udr 2 = Min Ovr 3 Maj Udr Channel 3 M* 3 4 4 = Maj Ovr 5-32 = Absolute value Channel 4 M* 4 4 = Maj Ovr 5-32 = Absolute value 5-32 = Absolute value Channel 10 M*		IR-24 in sat 3	Control 1-24	N	7	1-8	
O Channel J M* 1 2 = Min Ovr pansion Card Channel 2 M* 3 Channel 3 M* 3	8 Channel Analog Fx-	Version A or B	Channel 1	M*	1	1 = Min I I dr	
Channel 3 M* 3 4 maj Ovr Channel 4 M* 4 4 maj Ovr Channel 5 M* 5 5:32 = Absolute value bits (no alarms to map) Channel 7 M* 6 5:32 = Absolute value bits (no alarms to map) Channel 7 M* 7 5:32 = Absolute value bits (no alarms to map) Channel 7 M* 1 1 1 Channel 2 M* 2 2 Min Ovr Channel 3 M* 3 4 maj Ovr 3 = Maj Unr Channel 7 M* 7 1 1 1 1 Channel 2 M* 3 4 3 4 maj Ovr 3 = Maj Unr 3 3 3 1 3 1 1 1 1 1 1 1 1 1 1 3 3 3 3 3 3 3 3 3 3 3 3 3 5 3 3 5 3 3	pansion Card	Version A or D	Channel 2	M*	2	2 = Min Ovr	
Image: Channel 4 M* 4 Channel 5 M* 5.32 = Absolute value bits (no alarms to map) Channel 6 M* 6 Channel 7 M* 7 Channel 8 M* 8 16 Channel Analog Expansion Card Channel 1 M* 1 Channel 3 M* 3 4 = Maj Our Channel 7 M* 7 5.32 = Absolute value Channel 8 M* 8 1 1 Channel 1 M* 1 2 Min Our Channel 3 M* 3 4 = Maj Our Channel 6 M* 2 Min Our Channel 7 M* 2 Min Our Channel 7 M* 4 Maj Our Channel 9 M* 9 - Channel 10 M* 10 - Channel 11 M* 11 - Channel 13 M* 13 - Channel 15 M* 16			Channel 3	M*	3	3 = Maj Unr	
Barbon Section Channel 5 M* 5 5-32 = Absolute value Channel 5 M* 6 6 bits (no alarms to map) Channel 7 M* 7 6 6 6 Channel 8 M* 8 7 6 7 6 I 6 Channel Analog Expansion Card Channel 1 M* 1 1 1 1 1 1 0 7 3 Main Orr 3 4 Maj Udr 2 3 Maj Udr 4 Maj Udr 4 4 Maj Udr 4 4 Maj Udr 4 4 Maj Udr 5 32 = Absolute value 5 5 5 5 5 5 5 5 5 5 5 5 32 = Absolute value 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 6 5 5 6 5			Channel 4	M*	4	4 = Maj Ovr	
Channel 6 M* 6 Channel 7 M* 7 Channel 8 M* 8 16 Channel Analog Expansion Card Channel 1 M* 1 Channel 1 M* 1 1=Min Udr 2=Min Ovr Ghannel 3 M* 3 4=Maj Ovr 3=Maj Udr Channel 4 M* 4 4=Maj Ovr 5-32 = Absolute value Channel 5 M* 5 5 5-32 = Absolute value Channel 6 M* 6 6 6 Channel 7 M* 7 5-32 = Absolute value 5 Channel 8 M* 8 6 6 Channel 10 M* 10 6 16 Channel 11 M* 11 6 16 Channel 13 M* 13 13 14 Channel 14 M* 14 16 16 TBOS / ASCII Channel 16 M* 16 1-64 in each display Expansion C			Channel 5	M*	5	5-32 = Absolute value	
Channel 7 M* 7 Channel 8 M* 8 16 Channel Analog Expansion Card Channel 1 M* 1 Channel 1 M* 1 2 = Min Ovr Channel 2 M* 3 4 Channel 3 M* 3 4 = Maj Ovr Channel 6 M* 6 4 = Maj Ovr Channel 6 M* 6 5:32 = Absolute value Channel 7 M* 7 6-Annel 6 Channel 7 M* 7 6-Annel 7 Channel 7 M* 9 6-Annel 7 Channel 10 M* 10 5-32 = Absolute value Channel 11 M* 11 6-Annel 7 Channel 12 M* 12 6-Annel 13 Channel 11 M* 13 6-Annel 13 Channel 15 M* 15 6-Annel 15 Channel 15 M* 16 6-Annel 15 (7 Port Seria) TBOS Port 5 L* 1-64 in each display <			Channel 6	M*	6	ons (no alarms to map)	
Ide Channel Analog Expansion Card Channel 1 M* 8 16 Channel Analog Expansion Card Channel 1 M* 1 1 = Min Udr 2 = Min Ovr 3 = Maj Udr 4 = Maj Ovr 3 = Maj Udr 4 = Maj Ovr 5 = 32 = Absolute value 5 = 52 = Absolute value <t< td=""><td></td><td></td><td>Channel 7</td><td>M*</td><td>7</td><td></td></t<>			Channel 7	M*	7		
16 Channel Analog Expansion Card Channel 1 M* 1 2 = Min Our 16 Channel 12 M* 3 4 = Maj Udr 2 = Min Ovr 16 Channel 3 M* 3 4 = Maj Udr 4 = Maj Ovr 16 Channel 5 M* 5 3 = Maj Udr 4 = Maj Ovr 16 Channel 5 M* 6 5 5-32 = Absolute value bits (no alarms to map) 16 Channel 6 M* 6 6 6-32 5-32 = Absolute value bits (no alarms to map) 16 Channel 16 M* 9 M* 9 6-16 6-16 11 M* 10 16 16 6-16 6-16 11 M* 11 13 16 6-16 6-16 12 M* 13 16 16 6-16 6-16 16 16 M* 16 M* 16 16 16 16 17 Port Serial) TBOS Port 5 L* 1-8 1-64 in each display 17 Port Serial) TBOS			Channel 8	M*	8		
Channel 2 M* 2 2 = Min Ovr Channel 3 M* 3 4 = Maj Udr Channel 4 M* 4 3 Channel 5 M* 5 3 = Maj Udr Channel 6 M* 6 5.32 = Absolute value Channel 7 M* 7 5.32 = Absolute value Channel 8 M* 8 6 Channel 9 M* 9 6 Channel 10 M* 10 6 Channel 11 M* 11 6 Channel 12 M* 12 6 Channel 13 M* 13 6 Channel 15 M* 15 6 Channel 16 M* 16 16 TBOS / ASCII ASCII Ports 1, 2, 3 M* 1 (7 Port Serial) TBOS Port 4 L* 1-8 Expansion Card TBOS Port 5 L* 9-16 TBOS Port 7 L* 25-32 TBOS Port 7	16 Channel Analo	og Expansion Card	Channel 1	M*	1	1 = Min Udr	
Channel 3 M* 3 3 = Maj Udr Channel 4 M* 4 4 = Maj Ovr Channel 5 M* 5 5-32 Absolute value Channel 6 M* 6 6 5-32 Absolute value Channel 6 M* 7 6 6 6 6 Channel 7 M* 7 7 6 6 6 6 6 6 6 6 6 6 6 7 6 7 6 6 16 7 6 6 16 1			Channel 2	M*	2	2 = Min Ovr	
Channel 4 M* 4 4 = Maj OV Channel 5 M* 5 5-32 = Absolute value bits (no alarms to map) Channel 6 M* 6 6 Channel 7 M* 7 6 Channel 8 M* 8 6 Channel 9 M* 9 6 Channel 10 M* 10 6 Channel 12 M* 11 6 Channel 12 M* 12 6 Channel 13 M* 13 13 Channel 14 M* 14 6 Channel 15 M* 15 16 TBOS / ASCII Channel 16 M* 16 TBOS Port Serial) TBOS Port 4 L* 1-8 TBOS Port 5 L* 9-16 1-64 in each display TBOS Port 6 L* 17-24 1-64 in each display TBOS Port 7 L* 25-32 See Table F.			Channel 3	M*	3	3 = Maj Udr	
Channel 5 M* 5 552 Absolute value Channel 6 M* 6 10 10 10 10 10 10 10 10 10 10 10 10 11			Channel 4	M*	4	4 = Maj OVr 5-32 = A bsolute value	
Channel 6 M* 6 Channel 7 M* 7 Channel 8 M* 8 Channel 9 M* 9 Channel 10 M* 10 Channel 11 M* 11 Channel 12 M* 12 Channel 13 M* 13 Channel 14 M* 14 Channel 15 M* 16 TBOS / ASCII Channel 16 M* 16 (7 Port Serial) TBOS Port 4 L* 1-8 Expansion Card TBOS Port 5 L* 9-16 TBOS Port 7 L* 25-32 See Table F			Channel 5	M*	5	bits (no alarms to map)	
Channel 7 M* 7 Channel 8 M* 8 Channel 9 M* 9 Channel 10 M* 10 Channel 11 M* 11 Channel 12 M* 12 Channel 13 M* 13 Channel 14 M* 14 Channel 15 M* 16 TBOS / ASCII ASCII Ports 1, 2, 3 M* (7 Port Serial) TBOS Port 4 L* 1-64 in each display Expansion Card TBOS Port 5 L* 9-16 TBOS Port 7 L* 17-24 TBOS Port 7 L* 25-32 TBOS Device Failure L* 65			Channel 6	M*	6		
Channel 8 M* 8 Channel 9 M* 9 Channel 10 M* 10 Channel 11 M* 11 Channel 12 M* 12 Channel 13 M* 13 Channel 14 M* 14 Channel 15 M* 15 Channel 16 M* 16 TBOS / ASCII ASCII Ports 1, 2, 3 M* (7 Port Serial) TBOS Port 4 L* 1-8 Expansion Card TBOS Port 5 L* 9-16 TBOS Port 6 L* 17-24 TBOS Port 7 L* 25-32			Channel 7	M*	7	-	
$\frac{\begin{array}{ c c c c c c } \hline Channel 9 & M^* & 9 \\ \hline Channel 10 & M^* & 10 \\ \hline Channel 10 & M^* & 10 \\ \hline Channel 11 & M^* & 11 \\ \hline Channel 12 & M^* & 12 \\ \hline Channel 12 & M^* & 12 \\ \hline Channel 13 & M^* & 13 \\ \hline Channel 14 & M^* & 14 \\ \hline Channel 15 & M^* & 15 \\ \hline Channel 16 & M^* & 16 \\ \hline TBOS / ASCII \\ (7 Port Serial) \\ Expansion Card & TBOS Port 4 & L^* & 1-8 \\ \hline TBOS Port 5 & L^* & 9-16 \\ \hline TBOS Port 6 & L^* & 17-24 \\ \hline TBOS Port 7 & L^* & 25-32 \\ \hline TBOS Device Failure & L^* & 65 \\ \hline \end{array}$			Channel 8	M*	8	-	
$\begin{tabular}{ c c c c c c c } \hline Channel 10 & M^* & 10 \\ \hline Channel 11 & M^* & 11 \\ \hline Channel 12 & M^* & 12 \\ \hline Channel 12 & M^* & 12 \\ \hline Channel 13 & M^* & 13 \\ \hline Channel 14 & M^* & 14 \\ \hline Channel 15 & M^* & 15 \\ \hline Channel 16 & M^* & 16 \\ \hline TBOS / ASCII \\ (7 Port Serial) \\ Expansion Card & TBOS Port 4 & L^* & 1-8 \\ \hline TBOS Port 5 & L^* & 9-16 \\ \hline TBOS Port 6 & L^* & 17-24 \\ \hline TBOS Port 7 & L^* & 25-32 \\ \hline TBOS Device Failure & L^* & 65 \\ \hline \end{tabular}$			Channel 9	M*	9	-	
Channel 11 M* 11 Channel 12 M* 12 Channel 13 M* 13 Channel 14 M* 14 Channel 15 M* 15 Channel 16 M* 16 TBOS / ASCII (7 Port Serial) Expansion Card TBOS Port 4 L* 1-8 TBOS Port 5 L* 9-16 1-64 in each display TBOS Port 6 L* 17-24 1-64 in each display TBOS Port 7 L* 25-32 See Table F.			Channel 10	M*	10	-	
Channel 12 M* 12 Channel 13 M* 13 Channel 13 M* 13 Channel 14 M* 14 Channel 15 M* 15 Channel 16 M* 16 TBOS / ASCII (7 Port Serial) Expansion Card ASCII Ports 1, 2, 3 M* TBOS Port 4 L* 1-8 TBOS Port 5 L* 9-16 TBOS Port 6 L* 17-24 TBOS Port 7 L* 25-32 TBOS Device Failure L* 65			Channel 11	M*	11	-	
$\begin{tabular}{ c c c c c c c c c c c c c c c c c c c$			Channel 12	M*	12	-	
$\begin{tabular}{ c c c c c c } \hline & & & & & & & & & & & & & & & & & & $			Channel 13	M*	13	-	
$\begin{tabular}{ c c c c c c c } \hline Channel 15 & M^* & 15 \\ \hline Channel 16 & M^* & 16 \\ \hline TBOS / ASCII \\ (7 Port Serial) \\ Expansion Card & TBOS Port 4 & L^* & 1-8 \\ \hline TBOS Port 5 & L^* & 9-16 \\ \hline TBOS Port 6 & L^* & 17-24 \\ \hline TBOS Port 7 & L^* & 25-32 \\ \hline TBOS Device Failure & L^* & 65 & See Table F. \\ \hline \end{array}$			Channel 14	M*	14	-	
TBOS / ASCII Cnannel 10 M* 16 TBOS / ASCII ASCII Ports 1, 2, 3 M* 16 (7 Port Serial) TBOS Port 4 L* 1-8 Expansion Card TBOS Port 5 L* 9-16 TBOS Port 6 L* 17-24 TBOS Port 7 L* 25-32 TBOS Device Failure L* 65 See Table F			Channel 15	M*	15	-	
(7 Port Serial) Expansion CardTBOS Port 4L*1-81-64 in each displayTBOS Port 5L*9-16TBOS Port 6L*17-24TBOS Port 7L*25-32TBOS Device FailureL*65	TROS / ASCII		A SCII Ports 1 2 2	IVI* M*	10		
Expansion Card TBOS Port 4 L* 1-5 1-64 in each display TBOS Port 5 L* 9-16 17-24 17-24 17-24 TBOS Port 7 L* 25-32 18-64 in each display 18-64 in each display TBOS Port 7 L* 65 See Table F.	(7 Port Serial)		TROS Dort 4	IVI" T *	1.0	1.64 in each display	
TBOS Port 5 L* 9-10 TBOS Port 6 L* 17-24 TBOS Port 7 L* 25-32 TBOS Device Failure L* 65 See Table F	Expansion Card		TBOS Port 5	L. I.*	0_16	1-04 in each display	
TBOS Force L 1/24 TBOS Port 7 L* 25-32 TBOS Device Failure L* 65 See Table F			TBOS Fort 6	L [*	17_24	-	
TBOSTORY L 2552 TBOSTORY L* 65 See Table F.			TBOS Fort 7	L [*	25_32	-	
			TBOS Device Failure	L*	65	See Table E	

Table E - TBOS Device Failures

	TBOS Display at Remote		T/Mon Alarm Point that Denotes TBOS Display Failure		
Device	TBOS Port	Displays	T/Mon Address	Display	Point**
	1	1 -8			1 -8
4-Port Expansion in	2	1 - 8	M*	65	9 - 16
KDA 864 Base	3	1 - 8			17 - 24
	4	1 - 8			25 - 32
	1	1 -8			1 - 8
	2	1 - 8	M*	65	9 - 16
	3	1 - 8			17 - 24
8-Port Expansion in	4	1 - 8			25 - 32
KDA 804 Dase	5	1 - 8			1 - 8
	6	1 - 8	L*	65	9 - 16
	7	1 - 8			17 - 24
	8	1 - 8			25 - 32
TBOS / ASCII Expansion	4	1 - 8			1 - 8
	5	1 - 8	L*	65	9 - 16
	6	1 - 8			17 - 24
	7	1 - 8			25 - 32

*When using KDA versions earlier than 2.1, M = N+1 and L = N+2. In version 2.1 and later, M and L can be any address not already assigned to another device.

**Failure of TBOS Port 2, Display 1 is reported at Point 1; port 1, Display 2 at Point 2;....;Port 2 Display 1 at Point 9; Port 2, Display 2 at Point 10, etc.

Display	Point	Meaning
33	25	Failure in Satellite 1
	26	Failure in Satellite 2
	27	Failure in Satellite 3
	31	Failure in Expansion Card
	32	Failure in Expansion Card, Address #2 (8-Port TBOS card only)

Table F - Base KDA 864 Device Failure Alarms

TBOS Protocol

Alarms received on ports that are set for TBOS are reported directly as received, display-for-display and point-for-point. A port defined as TBOS accepts a maximum of 8 displays (512 points).

If your computer uses one of these modems, be sure to put the corresponding initialization string into the Software Parameters / System Parameters section (page 5-21).

The Table A lists some initialization strings for commonly used modems.

0	2		
Table	A - Modem	Initialization	Strings

Modem Model	Initialization String
AlphaMax Factory Default	AT S7=120 E1 V1 M1 Q0 X4
A.T.&T. Paradyne PCMCIA 3760/62/63/64	AT V1 X4 Q0 SR41=3\Q0\N1
Best Data Products, Inc. Model 9624FQ	AT E1 V1 L3 M1 Q0 S7=120 X4 &Q0 &D &C
Compaq 14.4 laptop	AT S7=120 E1 V1 M1 Q0 X4 \N1%C0\Q0
Hayes Accura	AT S7=120 E1 V1 M1 Q0 X4 &Q0
	or AT&Q0
Intel 14/14E	ATB5S7=120E1V1Q0X4\G\V\N%C-J
Intel Satisfaction (400 and 400E)	ATS7=120E1V1M1QX4\N\Q%C0%E-J&Q
Megahertz PCMCIA CC3144	AT &Q5 S37=5 N0 &K0 %C0 &Q0
Paradigm 14400	ATS7=120E1\G1%B1200%C0\N1
US Robotics Sportster 14400	ATS7=120E1V1M0Q0X4&A0&H0&M0&N2
US Robotics Courier (33.6 / 28.8 Kbps)	AT Z

The following is an example of a common modem problem due an initialization string error:

With the modem's audible monitor enabled, you can hear the modem dial and the response tone from the KDA when it answers. But instead of a "connect" message you get a "no carrier" message. This is generally caused by a high speed modem taking too long to negotiate speed and protocol. Check the modem initialization string in Table A. If your modem is not listed in Table A, consult your modem manual. **Be sure that flow control, compression and error correction are off.** If difficulty persists, contact DPS Customer Support. Please have your modem manual handy.