

Edge Access



2201 Rack Chassis User Manual



CAUTION!


This product may contain a laser diode operating at a wavelength of 1300 nm - 1600 nm. Use of optical instruments (e.g., collimating optics) with this product may increase eye hazard. Use of controls or adjustments, or performing procedures other than those specified herein may result in hazardous radiation exposure.

Under normal conditions, the radiation levels emitted by this product are under Class 1 limits in 21 CFR Chapter 1, Subchapter J.

ATTENCION!

Cet équipement peut avoir une diode laser émettant à des longueurs d'onde allant de 1300nm à 1600nm. L'utilisation d'instruments optiques (par exemple : un collimateur optique) avec cet équipement peut s'avérer dangereuse pour les yeux. Procéder à des contrôles, des ajustements ou toute procédure autre que celles décrites ci-après peut provoquer une exposition dangereuse à des radiations.

Sous des conditions normales, le niveau des radiations émises par cet équipement est en dessous des limites prescrites dans CFR21, chapitre 1, sous chapitre J.



NOTICE!

This device contains static sensitive components. It should be handled only with proper ElectroStatic Discharge (ESD) grounding procedures.

NOTE!

Cet équipement contient des composants sensibles aux décharges électro-statiques. Il doit absolument être manipulé en respectant les règles de mise à la terre afin de prévenir de telles décharges.

NOTICE

Canoga Perkins has prepared this users manual for use by customers and Canoga Perkins personnel as a guide for the proper installation, operation and/or maintenance of Canoga Perkins equipment. The drawings, specifications and information contained in this document are the property of Canoga Perkins and any unauthorized use or disclosure of such drawings, specifications and information is prohibited.

Canoga Perkins reserves the right to change or update the contents of this manual and to change the specifications of its products at any time without prior notification. Every effort has been made to keep the information in this document current and accurate as of the date of publication or revision. However, no guarantee is given or implied that the document is error free or that is accurate with regard to any specification.

Canoga Perkins Corporation
20600 Prairie Street
Chatsworth, California 91311-6008
Business Phone: (818) 718-6300
(Monday - Friday 7 a.m. - 5 p.m. Pacific Time)
FAX: (818) 718-6312 (24 hrs.)
Web Site: www.canoga.com
Email: fiber@canoga.com

Copyright © 1994 - 2005 Canoga Perkins Corporation
All Rights Reserved

EdgeAccess®
2201 Rack Chassis
User Manual

Product Number 6910040
Rev. K 01/2008

EdgeAccess and Canoga Perkins are registered trademarks of Canoga Perkins Corp.
To reference Technical Advisories and Product Release Notes, go to Canoga Perkins'
website: <http://www.canoga.com>

Table of Contents

Chapter 1 Overview	1-1
Chapter 2 Installing and Troubleshooting the Chassis	2-1
Installing the Chassis	2-1
Troubleshooting the Power Supply(s)	2-3
Chapter 3 Specifications	3-1
Appendix A Warranty Information	A-1

List of Figures

Figure 1. 2201 Rack Chassis	1-1
Figure 2. 2201 Rear Panel	2-2

List of Tables

Table 1. Power Supply Cable Pinout.....	2-3
---	-----

Chapter 1 Overview

The 2201 Rack Chassis houses and supplies power to Canoga Perkins fiber optic modem modules in the 2200 series, including the 2240, 2262, 2270, and 2290. Although the chassis is not managed, it supports up to 10 fiber optic modems.



Figure 1. 2201 Rack Chassis

The 2201 supports one or two AC and/or DC power supplies in the chassis. The power monitor board includes an LED for each power supply; if a supply fails, the LED for that supply lights red and an alarm buzzes. For specifications for the power supplies, see Chapter 3. Figure 1 shows the 2201 with the power monitor board.

The chassis includes alarm output terminals at the rear panel. Use the ALRMC and ALRM terminals to connect to an external device that can receive alarm information. If an alarm condition occurs in the chassis power supply, notification is sent to the external device.

The front panel includes one pushbutton for alarm acknowledgement, which turns off the buzzer, and two LEDs that light red if the primary or secondary power fails.

Chapter 2

Installing and Troubleshooting the Chassis

This section describes how to set up and install the chassis.

Installing the Chassis

Before setting up the chassis, make sure these items are available:

- Chassis with application modules
- Power cables; 14 or 16 gauge wire for DC power
- Contact wires for the Alarm (optional)

Caution: *Equipment intended only for installation in a RESTRICTED ACCESS LOCATION accessible only to electrically skilled persons and electrically instructed persons with the proper authorization.*

Follow these steps to install the chassis:

1. Plan the installation, considering these characteristics:
 - Place the chassis within 7 ft. (2.134 m) of the power source.
 - Plan to use one or more of these locations for the connection to Earth Ground:
 - The grounding prong on the AC power cord
 - The ground of the DC terminal strip
 - The mounting hardware for the rack, if the rack is tied to Earth Ground
 - Place the chassis adjacent to other Canoga Perkins or related equipment.
2. Unpack the chassis, cables, and modems, and inspect all parts for damage and compare them with the packing list. Set the packaging aside in case you need to return the equipment.
3. On the power monitor board in the slot next to the power supply(s), check the switch and jumpers:
 - a. Set Power Switch to A for one power supply or to A+B for two power supplies.
 - b. Install a jumper at W1 to isolate the Signal and Chassis grounds or at W2 to connect the grounds, then check that a jumper is installed at W4.
4. On the Power Distribution board located inside the back panel; install a jumper at W1 if you will connect a normally-closed alarm or at W2 if you will connect a normally-open alarm.
5. Remove the front cover for the power supply, then slide the power supply(s) into the front of the chassis. Install the primary (A) supply in the lower bay and the secondary (B) supply in the upper bay. Secure each retaining screw finger-tight and then re-install the power supply cover.
6. Plug each power supply output cable into its connector on the power distribution board; plug the primary (A) supply into the lower connector and the secondary (B) supply into the upper connector.

7. Slide the power monitor board into the slot next to the power supply(s) and firmly seat it in the power distribution board, then push in the retainer latches at the front.
8. Mount the chassis in a standard 19-inch relay rack or in a 23-inch rack. The chassis ships with mounting brackets for a standard 19-inch relay rack.
 - For a 19-inch rack, position the chassis in the rack and secure the brackets to the rack with four screws.
 - For a 23-inch rack, secure the optional 23-inch extender brackets with four screws, then position the chassis in the rack and secure the brackets to the rack with four screws.
9. At ALRM and ALRMC (common or ground) at the rear panel, connect a device to receive alarm information; see Figure **Error! Reference source not found.**



Figure 2. 2201 Rear Panel

10. To connect power to the power supply(s), follow these steps:
 - For an AC supply, plug the power cord into the socket at the rear, then plug the cord into the power source.
 - For a DC supply, loosen the screws for the GND and BV terminals at the rear, then slide the wires under the square washers, and tighten the screws. See Figure 2. Connect the power cables according to the power source:
 - For -48 V or -24V input, connect +V to GND
connect -V to BV
 - For +48 V or +24V input, connect +V to BV
connect -V to GND

Note: To turn off the power, unplug the AC power cord or turn off the DC supply.

11. Insert the modems into the chassis; for details, see the user manual for each modem.
12. Turn on the chassis power supply(s). The LEDs on all modules may blink during the power-on sequence, then the PWR LEDs light steady.
13. To configure each modem in the chassis, see the user manual for that modem.

Troubleshooting the Power Supply(s)

If the Power LED on the power monitor board lights red and the alarm buzzer sounds, it indicates a problem with the power supply. Press the alarm reset switch to silence the alarm, then make these checks:

- If the Power Monitor board indicates a fault, but the Power LEDs on all modems are lit, check that the A/A+B switch on the Power Monitor board is set correctly for one (A) or two (A+B) power supplies.
- Unplug the cable for the failing power supply and check the voltage between ground on pins 1, 9, or 10 and supply on pins 3, 4, 5, 6, 7, or 8; see Table 1. For an AC supply, 9 VAC is normal. For a DC supply, +9 or -9 VDC is normal.
- Check the voltage between pins 3 and 4, 5 and 6, or 7 and 8; see Table 1. For an AC supply, normal voltage is 18 VAC. For a DC supply, normal voltage is 18 VDC.
- If all voltages are faulty, unplug the power cord for the faulty supply and check the main fuse for that power supply.
- If voltages are faulty on only one pair of pins, unplug the power cord for the faulty supply and check the secondary fuses, located inside the power supply; one fuse for each group of slots. If needed, you can move a modem from a faulty slot to an empty slot. For more information, see Table 1.
- If a fuse blows after you replace it, it can indicate a fault on a modem on that output circuit. To isolate a modem, swap each modem on that output circuit to slots on the other output circuits. If a different fuse blows, the fault is on that modem; replace it. For more information, see Table 1.

Table 1. Power Supply Cable Pinout

Pin Number	Function
1	Return
2	Key
3, 4	Power for slots 1, 2, and 3
5, 6	Power for slots 4, 5, and 6
7, 8	Power for slots 7, 8, 9, and 10
9, 10	Return

Chapter 3

Specifications

Chassis dimensions	8.8" H x 19" W x 12.8 D" (223.5 mm x 482.6 mm x 325.1 mm)
Weight	
Chassis (empty)	7.7 lbs. (3.49 kg)
AC power supply	9.0 lbs. (4.08 kg)
DC power supply	3.0 lbs. (1.36 kg)
Power supply monitor board	0.5 lbs. (0.23 kg)
Power	
Redundancy	Optional (AC/AC, DC/DC or AC/DC)
AC power supply	115 VAC +10% 47 to 63 Hz, 2.2 A Max. 230 VAC +10% 47 to 63 Hz, 1.1 A Max.; optional Heat dissipation, max: 825 BTU/hr
DC power supply	+/-48 VDC, 5 A Max. Heat dissipation, max: 825 BTU/hr
Environment	
Operating temperature	0 to 50° C
Humidity	10 to 95% (non-condensing)

Appendix A

Warranty Information

Current Warranty information is available on-line in the Client Login Area of the Canoga Perkins web site (www.canoga.com) or by contacting Technical Support at 800-360-6642 (voice) or fiber@canoga.com (email).



CANOGA PERKINS CORPORATION

20600 Prairie Street

Chatsworth, California 91311-6008 USA

Phone: (818) 718-6300 FAX: (818) 718-6312

Web Site: www.canoga.com

Email: fiber@canoga.com