


MV Electrical network management MV substation control unit

Merlin Gerin **Easergy** Range
T200

Modbus II Communication User's manual



Contents

| | |
|--|-----------|
| GENERAL | 4 |
| Application | 4 |
| Advantages | 4 |
| Functions | 4 |
| Select before execute | 4 |
| Report by exception | 4 |
| Protocol analyser | 4 |
| Events | 4 |
| GENERAL | 5 |
| CONNECTION TO A TRANSMISSION NETWORK | 6 |
| Space available for a transmission interface | 6 |
| Connection to a transmission interface | 6 |
| COMMUNICATION MODULE | 8 |
| Communication module configuration | 9 |
| Comms parameters | 10 |
| Alarm parameters | 17 |
| MODBUS analyser | 18 |
| Equipment states | 19 |
| Front panel indications | 20 |
| Normal operation | 20 |
| Diagnosis using front panel indicators and time-stamped events | 21 |
| Replacing the Serial line module | 22 |
| MODBUS DATA ADDRESSES AND ENCODING | 23 |
| General | 23 |
| Identification / configuration zone | 25 |
| Time synchronization zone | 25 |
| Test zone | 26 |
| Event zone | 26 |
| TC / TSD / TSS zone | 28 |
| Telemetry zone | 30 |
| Diagnostic counter reading | 31 |
| Example of exchanges with MODBUS | 32 |
| Report by exception with a modem | 33 |
| Report by exception without any modem | 34 |
| Select before execute | 34 |
| APPENDIX | 35 |
| MODBUS protocol | 35 |
| Read N bits: functions n°1 and 2 | 37 |
| Read N words: functions n°3 and 4 | 37 |
| Write a bit: function n°5 | 38 |
| Write a word: function n°6 | 38 |
| Read diagnostic counters: function n°8 | 39 |
| Write N consecutive words: function n°16 | 40 |
| CRC 16 calculation algorithm | 41 |
| Write CRC 16 calculation in C language | 41 |
| Communication exchange table T200 - 16 ways | 42 |
| Communication exchange table T200 - 4 ways | 43 |
| Communication exchange table T200 P | 44 |
| RS 485 network | 45 |

The T200-MOD2 communication board allows the connection of T200 to a telecontrol system by using a MODBUS protocol . It includes advanced telecommunication function and manages PSTN type of transmission modems.

Application

Permanent and non permanent serial link with a telecontrol center by using MODBUS protocol.

Advantages

- type of transmission modem : PSTN, Radio, GSM, etc .
- Advanced telecommunication functions
- Configuration by PC computer
- Built-in protocol analyser

Functions

Select before execute

- All control order needs a double transmission:
- A Select then an Execute order
- A control order is executed after reception of a healthy double transmission
- Delay between select and execute is limited to 20s

Report by exception

Each alarm may be configured to be sent spontaneously to the telecontrol centre when it changes of state.

The modem is activated through HAYES frames and after PSTN link is established with the telecontrol centre, a MODBUS protocol is initiated.

In case of use with a permanent link transmission(private line, optical fibre) or radio, a special MODBUS message is sent to the telecontrol centre which then initiates a Master/Slave MODBUS protocol exchange. The T200-MOD2 board manages the collision detection.

Protocol analyser

The communication board includes a protocol analyser functionality (including a MODBUS frame translation) available from the PC computer connected to the communication board

This analyser allows the display of the frames which are exchanged with the telecontrol system.

Events

The communication board memorises up to the last 200 events. Each change of states is time tagged with an accuracy of 20ms.

Accessible data

- **Writing of digital data**
 - Immediate AC supply OFF
- Transmission of remote control commands to MV switches.
 - Delayed AC supply OFF
 - Equipment fault,
 - Charger fault
 - Battery fault
- Transmission of the remote control command to reset fault currents stored.
 - Switchgear supply OFF.
- **Reading of digital data**
 - Position of switches (SW1 to SW16),
 - Remote indications:
 - Status of SW1 to 16,
 - Phase and earth fault currents of ways 1 to 16,
 - Digital inputs 1 to 24,
 - Local / Remote control operating mode,
 - **Reading of measurements**
 - 16 phase currents (1 per way).
 - **Diagnosis**
 - reading of MODBUS diagnostic counters.
 - **Other functions**
 - time synchronization function,
 - identification / configuration function.
 - management of up to 16 ways (4 ways by CPU)
 - possibility to add an other MODBUS equipment (SEPAM, PM300/600)


Characteristics

| | |
|-----------------------|---|
| type of transmission | asynchronous serial |
| protocol | MODBUS slave |
| speed | 300, 600, 1200, 2400, 4800, 9600, 19200 bauds |
| data format | 1 start bit, 8 data bits with no parity, 1 stop bit |
| electrical interface | RS232 |
| type of connector | 9 pin SUB-D, female |
| T200 amount on a line | 4080 |

Connection to a transmission network

Space available for a transmission interface

The top right section of the equipment contains a space available for a transmission interface (Modem, optical fibre, ...). A support structure mounted on sliding rails offers multiple possibilities for adding such a unit.



Connection to a transmission interface

Power supply :

The interface may be connected to the "Telecomms supply" terminals.


■ Output Voltage :

12 Vdc (10.8 to 14.8 Vdc)

■ Output Current :

See T200 user's manual.

The output is protected by a 4A time lag fuse located on the right side of the rack.




Connection to a transmission network

Serial I/O Port


The RS232 serial line is available on a 9 pins SUB-D female plug, located on the right side of the rack. (only with using a RS232 modem on card "Comms").

■ Signals :


- CD : Carrier Detect
- RD : Receive Data.
- TD : Transmit Data.
- DTR : Data Terminal Ready
- DSR : Data Set Ready
- RTS : Request To Send.
- CTS : Clear To Send
- RI : Ring Indicator



MODEM connection



Without use of CTS, DCD, DSR




With use of CTS, DCD, DSR

Radio Port


The RADIO connection is available on a 9 pins SUB-D female plug, located on the right side of the rack. (only with using a Radio modem on card "Comms") :

■ Signals :

- PTT : Press To Talk.
- TX : Transmission signal.
- SQ : Squelch.
- RX : Reception signal.
- N.U. : Not used.




RADIO connection



Communication module

Communication using MODBUS protocol takes place via a "COMMS" module.

The module is installed in the rack (position 3) of a "standard" T200 enclosure (on the left side of the Power supply module).



Communication module

Communication module configuration

The communication parameters are configured by using the "T200 Configuration and diagnostic" software.

- Plug a computer to the **COMMS** module.
- The computer being under DOS control, insert the the "T200 Configuration and diagnostic" disquette and enter **A:MG** then **ENTER**. The main menu is displayed.

The use of the software is described into the T200 user's manual.

The main menu configures the protocol, the RTU address and the type of transmission.

It allows also the access to:

- Communication parameters
- Alarmes configuration
- MODBUS frame analyser
- Modem status

T200 Comms Card MODBUS
PROM v4.05

PARAMETERS SETUP
MODBUS address : **100**
MODBUS sub-address : **0**
Modem type : **Direct RS 232**
Comms parameters

CPU Modules installed 1: **yes** 2: **yes** 3: **no** 4: **yes**
Alarm parameters **CPU 1 CPU 2 CPU 3 CPU 4**
Select before execute TC : **no**

SAVE CONFIGURATION : **OK**
Cancel

DIAGNOSTIC
Equipment states MODBUS analyser

- **MODBUS address :**
from **1 to 255**

- **MODBUS sub-address :**
This sub address allows a number of T200 on a MODBUS line greater than 255 by addressing several T200 on the same MODBUS address.

from **0 to 15**

- **CPU Modules installed:**
Yes : indicate that CPU1 (..CPU4) is present
No : indicate that CPU1 (..CPU4) is not present

- **Modem type :**
Hayes : use of a HAYES compatible modem.
Direct RS 232: permanent link
GSM : use of a GSM with AT commands.
Radio : use of a radio with analog input.

- **Select before execute :**
Yes : Controls are received with the "Select Before excetute" mode
No : Controls are received with the standard mode.

Communication module

Comms parameters

1- Modem : Hayes

| Comms parameters | |
|--|-------------------------|
| Modem : Hayes | |
| Host baud rate | : 9600 baud |
| Dialing type | : Pulse |
| Host telephone number (main) | : ???????? |
| Host telephone number (standby) | : ???????? |
| Dial-up delay time | - first attempt : 1s |
| (0s = random value) | - second attempt : 1 mn |
| | - third attempt : 2 mn |
| Modem init : &B1E0Q0V1&C1&D2X4S0=2S2=255 | |
| Factory modem init | |
| ESCAPE=Exit | |

■ Host baud rate :

Transmission speed with the telecontrol center.

200, 300, 600, 1200, 2400, 4800, 9600 or 19200 baud.

■ Dialing type :

Dialling up system.

Tone or Pulse.

■ Host tel number (main) :

Telephone number of the host computer system, used to send the alarms to the telecontrol center.

15 figures maximum.

The telephone number can generally include the following dialling options (Depend on external modem):

, (coma) : wait 2 seconds

/ (slash) : wait 125 milliseconds

W : Wait a second tone before carry on the dialling. Only for a modem that need to to dial a number to get an external line.

@ : Wait a 5s silence on the line before dialling the remaining part of the number.

■ Host tel number (standby) :

Backup telephone number used in case of trouble with the main telephone number.

15 figures maximum.

The dialing option are the same as as for the main phone number.

■ Dial up delay time :

Delay to transmit an alarm configured with "delayed" option.

- **first attempt** : configurable from **0 to 1 mn, by step of 1 s**. A "0" value configures a random delay between 0 and 1 mn, which is compulsory to avoid that all equipments call at the same time the telecontrol center.
- **second attempt** : configurable from **0 to 5 mn, by step of 1 mn**. A "0" value configures a random delay between 0 and 5 mn.
- **third attempt** : configurable from **0 to 10 mn, by step of 1 mn**. A "0" value configures a random delay between 0 and 10 mn.

Nota : The 2nd and 3rd emission are only used by the equipment if the preceding emission didn't success in sending the frame.

■ Modem init :

Hayes modem initialisation frame.

40 characters maximum.

Nota : **NEVER PLACE the AT frame at the beginning of initialisation frame.** T200 will send it automatically to the modem, before the configured frame.

■ Factory modem init :

This option allows the configuration of the "**modem init**" frame with U.S. Robotics type(Plant configuration). This frame is valid for most of the modems.

Plant initialised frame :

&B1 : Serial port speed constant (compulsory). The modem communicates with T200 at the configured speed (menu "comms parameter").

E0 : Echo disabled

Q0 : Display the resulting codes (Compulsory).

V1 : resulting code as word format (Compulsory).

&C1 : Normal use of DCD

&D2: Normal use of DTR

X4 : Activation of resulting code X4

S0=2 Automatic answer after two rings (Compulsory for European norm).

S2=255 Disable escape code +++ (Compulsory because the transmission frame is binary coded).

2- Modem : GSM

| <u>Comms parameters</u> | |
|------------------------------------|-------------------------|
| Modem : GSM | |
| Host baud rate : | 9600 baud |
| PIN code : | 0000 |
| Modbus parameters | |
| Alarm message enabled : | no |
| Host telephone number (main) : | ???????? |
| Host telephone number (standby) : | ???????? |
| Dial-up delay time | - first attempt : 1s |
| (0s = random value) | - second attempt : 1 mn |
| | - third attempt : 2 mn |
| Short message system : SMS | |
| Short message system enabled : | no |
| SMS service center phone number : | +33689004000 |
| SMS user phone number : | ???????? |
| ESCAPE=Exit | |

■ Host baud rate :

Transmission speed with the telecontrol center.

Must be fixed at 9600 baud with GSM modem.

■ PIN code :

Setting of the PIN code into the SIM card (default value is 000).
In case of wrong PIN code, "**GSM SIM card failure**" appears in the screen "**Equipment states**".

Be care : After 3 wrong settings of the PIN code, the SIM card is unavailable. To return to available status, a mobile phone must be use (T200 can not do it).

Please, consult the user guide of the SIM Card to return to an available status.

■ Alarm message enabled :

Yes : If a change of state of alarms and switch position occurs, a special MODBUS message is send to the telecontrol centre which then initiates a Master/Slave MODBUS protocol exchange.

No : T200 do not send an alarm message.

Nota : Please note that it is possible to have either an alarm on the control center and with a short message on a mobile . The short message is send at first.

■ Host tel number (main) :

Telephone number of the host computer system, used to send the alarms to the telecontrol center.

15 figures maximum.

■ Host tel number (standby) :

Backup telephone number used in case of trouble with the main telephone number.

15 figures maximum.

■ Dial up delay time :

Delay to transmit an alarm configured with "delayed" option.

- **first attempt** : configurable from **0 to 1 mn, by step of 1 s**. A "0" value configures a random delay between 0 and 1 mn, which is compulsory to avoid that all equipments call at the same time the telecontrol center.
- **second attempt** : configurable from **0 to 5 mn, by step of 1 mn**. A "0" value configures a random delay between 0 and 5 mn.
- **third attempt** : configurable from **0 to 10 mn, by step of 1 mn**. A "0" value configures a random delay between 0 and 10 mn.

Nota : The 2nd and 3rd emission are only used by the equipment if the preceding emission didn't success in sending the frame.

■ Short message system enabled :

Yes : When an alarm is detected, a short message is send to a mobile.

No : The short message system is disabled.

Nota : Please note that it is possible to have either an alarm on the control center and with a short message on a mobile . The short message is send at first.

■ SMS service center phone number:

Setting of the phone number of the server of the SMS.

Please consult the user guide of the SIM card in which this phone number is given.

Nota : Please note that is is possible to set the phone number in internationnal format. The following format +33 6can be used in all countries.

■ SMS user phone number:

Setting the phone number of the mobile in wich you wish to receive the short message.

Nota : Please note that is is possible to set the phone number in internationnal format. The following format +33 6can be used in all countries.

3- Modem : Radio

| <u>Comms parameters</u> | |
|------------------------------------|--------------------------------|
| Modem : Radio 600/1200 baud | |
| Host baud rate : 1200 baud | |
| RTS to message delay : 10ms | |
| Handle CTS (Squelch) : no | |
| Alarm message enabled : no | |
| Alarm delay time | - first attempt : 1s |
| (0s = random value) | - second attempt : 1 mn |
| | - third attempt : 2 mn |
| ESCAPE=Exit | |

■ Host baud rate :

Transmission speed with the telecontrol center.

600 or 1200 baud.

■ RTS to message delay :

It's the delay T200 will wait after RTS before sending the message value – depend of the radio..

Value is from **0** to **500ms** default value is 100ms.

■ Handle CTS (Squelch) :

Squelch, if it exist on the radio, allows T200 to have information about the status of the network (busy or not busy).

If the radio network is very noisy, it can be better to unabled this option.

■ Alarm message enabled :

Yes : if a the change of state of alarms and switch position occurs, a special MODBUS message is sent to the telecontrol centre which then initiates a Master/Slave MODBUS protocol exchange

No : T200 do not send an alarm message.

■ Alarm delay time :

Delay to transmit an alarm configured with "delayed" option.

- **first attempt** : configurable from **0 to 1 mn, by step of 1 s**. A "0" value configures a random delay between 0 and 1 mn, which is compulsory to avoid that all equipments call at the same time the telecontrol center.
- **second attempt** : configurable from **0 to 5 mn, by step of 1 mn**. A "0" value configures a random dely between 0 and 5 mn.
- **third attempt** : configurable from **0 to 10 mn, by step of 1 mn**. A "0" value configures a random dely between 0 and 10 mn.

Nota : The 2nd and 3rd emission are only used by the equipment if the preceding emission didn't success in sending the frame.

4- Modem : Phone line

| <u>Comms parameters</u> | |
|-------------------------------|------------------------|
| Identified modem : Phone line | |
| Host baud rate | : 300 baud |
| Dialing type | : Tone |
| Host tel number (main) | : ?????????? |
| Host tel number (standby) | : ?????????? |
| Dial up delay time | - first attempt : 1s |
| (0s = random value) | - second attempt : 1mn |
| | - third attempt : 2mn |
| ESCAPE=Exit | |

■ Host baud rate :

Transmission speed with the telecontrol center.

Configurable with **300, 600 or 1200 baud**.

■ Dialing type :

Type of dialing using for alarm transmission to telecontrol center.

Configurable with **Tone** or **Pulse** (default value : Tone).

■ Host tel number (main) :

Telephone number of the host computer system, used to send the alarms to the telecontrol center.

15 figures maximum.

■ Host tel number (standby) :

Backup telephone number used in case of trouble with the main telephone number.

15 figures maximum.

■ Dial up delay time :

Delay to transmit an alarm configured with "delayed" option.

- **first attempt** : configurable from **0 to 1 mn, by step of 1 s**. (Default value : 1s).

A "0" value configures a random delay between 0 and 1 mn, which is compulsory to avoid that all equipments call at the same time the telecontrol center.

- **second attempt** : configurable from **0 to 5 mn, by step of 1 mn**. (Default value : 1mn).

A "0" value configures a random delay between 0 and 5 mn.

- **third attempt** : configurable from **0 to 10 mn, by step of 1 mn**. (Default value : 2mn).

A "0" value configures a random delay between 0 and 10 mn.

Nota : The 2nd and 3rd emission are only used by the equipment if the preceding emission didn't success in sending the frame.

5- Modem : Direct RS 232

| <u>Comms parameters</u> | |
|-----------------------------------|---|
| Modem : Direct RS232 | |
| Host baud rate | : 9600 baud |
| RTS delay | : 20 ms (Only if handle CTS = no) |
| Handle CTS | : yes |
| Handle DCD | : yes |
| Handle DSR | : yes |
| Alarm message enabled : no | |
| ESCAPE=Exit | |

■ Host baud rate :

Transmission speed with the telecontrol center.

200, 300, 600, 1200, 2400, 4800, 9600 ou 19200 bauds.

■ RTS delay :

Waiting time between RTS activation and frame emission. This parameter is to be used only if Handle CTS = 0.

Configurable from **0 to 500ms by step of 10 ms**

■ Handle CTS :

Yes : T200 uses a normal RST/CTS handshake: The RTS delay is not taken into account.

No : T200 uses the RTS delay

■ Handle DCD :

Yes : T200 uses DCD signal.

No : T200 do not use DCD signal.

■ Handle DSR :

Yes : T200 uses DSR signal.

No : T200 do not use DSR signal.

■ Alarm message enabled :

Yes : if a the change of state of alarms and switch position occurs, a special MODBUS message is sent to the telecontrol centre which then initiates a Master/Slave MODBUS protocol exchange

No : T200 do not send an alarm message.

Communication module

Alarm parameters

The "Alarm Parameters" menu allows the configuration of each status to be in alarm mode for each CPU.

| Alarm Parameters CPU1 | |
|--------------------------------------|-------------------------------------|
| SWITCH ALARM | |
| Switch 1 : no | Switch 2 : yes |
| Switch 3 : yes | Switch 4 : no |
| SINGLE STATE REMOTE INDICATION ALARM | |
| Status SW1 : no | Presence HT SW1 : yes |
| Status SW2 : no | Presence HT SW2 : yes |
| Status SW3 : no | Presence HT SW3 : yes |
| Status SW4 : no | Presence HT SW4 : yes |
| Phase fault SW1 : no | Local : no |
| Earth fault SW1 A : no | Immediate AC supply OFF : no |
| Earth fault SW1 B : no | Delayed AC supply OFF : no |
| Phase fault SW2 : no | Digital input 1 : yes |
| Earth fault SW2 A : no | Digital input 2 : yes |
| Earth fault SW2 B : no | Digital input 3 : yes |
| Phase fault SW3 : no | Digital input 4 : yes |
| Earth fault SW3 A : no | Digital input 5 : yes |
| Earth fault SW3 B : no | Digital input 6 : yes |
| Phase fault SW4 : no | Charger/FPI fault : no |
| Earth fault SW4 A : no | Battery fault : no |
| Earth fault SW4 B : no | SW supply OFF : no |
| ESCAPE=Exit | |

Each status could be configure as: Remark :

no : The T200 do not send an alarm in case of change of state of this status.

Yes : T200 send a message to the telecontrol center, after the "dial up delay time" at each change of state of the status.

The above screen shows all the available status in the T200. Depending on the T200 type (1 or 4 ways , internal FPI or external FPI), some status should not exist and consequently are not displayed on the screen.

| Alarm Parameters CPU2 | |
|--------------------------------------|-------------------------------|
| SWITCH ALARM | |
| Switch 5 : no | Switch 6 : yes |
| Switch 7 : yes | Switch 8 : no |
| SINGLE STATE REMOTE INDICATION ALARM | |
| Status SW5 : no | Presence HT SW5 : yes |
| Status SW6 : no | Presence HT SW6 : yes |
| Status SW7 : no | Presence HT SW7 : yes |
| Status SW8 : no | Presence HT SW8 : yes |
| Phase fault SW5 : no | |
| Earth fault SW5 A : no | |
| Earth fault SW5 B : no | |
| Phase fault SW6 : no | Digital input 7 : yes |
| Earth fault SW6 A : no | Digital input 8 : yes |
| Earth fault SW6 B : no | Digital input 9 : yes |
| Phase fault SW7 : no | Digital input 10 : yes |
| Earth fault SW7 A : no | Digital input 11 : yes |
| Earth fault SW7 B : no | Digital input 12 : yes |
| Phase fault SW8 : no | |
| Earth fault SW8 A : no | |
| Earth fault SW8 B : no | |
| ESCAPE=Exit | |

The alarm parameters menus of CPU2, CPU3 and CPU4 allow the same configuration as CPU1 except the parameters which are global to the equipment.

Communication module

MODBUS analyser

The equipment includes a protocol analyser function(with a modbus frame specific decoding) . This function is accessible from the MODBUS analyser” menu on the PC connected to the COMMS card configuration plug.

Warning : The CPU includes also a MODBUS analyser allowing the display of MODBUS internal exchange between CPU and COMMS modules.

| MODBUS analyser | | | | |
|---|-----------|----|--|--|
| ESCAPE=Exit, SPACE=Pause, C=Clear, F=Toggle filtering | | | | |
| 34:56.67 | read ts | < | 01 03 00 34 00 08 05 C2 | |
| 34:56.67 | READ TS | >> | 01 03 10 00 08 00 00 00 04 00 00 00 00 00 80 00 00 00 00 F8 B1 | |
| 34:57.05 | read tm | < | 01 03 00 40 00 05 84 1D | |
| 34:57.05 | READ TM | >> | 01 03 0A 00 00 00 00 00 00 00 00 00 00 00 24 B6 | |
| 34:57.27 | read date | < | 01 03 00 02 00 04 E5 C9 | |
| 34:57.27 | READ DATE | >> | 01 03 08 00 60 0A 19 10 22 DF B6 95 F5 | |
| Pause... | | | | |

Use:


- The "SPACE" key is used to stop scrolling, thereby facilitating analysis of the frames received.
- The "C" key clears the screen.
- The "F" key changes the filtering method.
 - ☐ Display all received frames
 - ☐ Display only frames destined to this T200.
- The "ESCAPE" key is used to exit the analyser function.

Display:

- The first column gives the time of the message in minutes, seconds and 100ths of seconds.
- The second column indicates the type of frame. Upper case characters are used for frames transmitted by the T200. This is confirmed by the double chevron '>>' in column 3. On the other hand, all the lower case characters pertain to frames received by the remote control station (confirmed by a single chevron '<' in column 3).
- The last column displays the frame in hexadecimal form. The "+" and '*' signs may precede the display of the frame:
 - ☐ The '+' sign indicates frames not intended for the equipment,
 - ☐ The '*' sign indicates an erroneous frame (incomplete frame, faulty construction, ...).

Communication module

Equipment states



This menu shows the modem status (A selected information is displayed as bold)

■ Alarm processing ...

An alarm is in processing or in repeat mode.

■ CPU-MODBUS comms failure:

T200 doesn't recognise the CPU1 or CPU2 or CPU3 or CPU4; It is either not connected either the CPU is not valid.

■ Modem not identified :

T200 doesn't recognise the modem; It is either not connected either the initialisation frame is not valid.


■ Number blacklisted :

(Only with Hayes modem).

At least one of the telephone number doesn't work after some trials. (Generaly 6; this function is managed by the modem itself).

Communication module

Front panel indications



Normal operation

During normal operation the COMMS card display is as follow:

- ☐ TD and RD communication LEDs OFF
- ☐ ON is energized
- ☐ Fault LED is OFF

Communication module

Diagnosis using front panel indicators and time-stamped events

T200 includes time stamped facilities in order to help in the diagnostic. The events are memorized into the CPU module.

The Time stamped events can be read locally from a lap top PC computer connected to the CPU configuration plug and equipped with the software : **"T200 Configuration and Diagnostic"**.

- Connect the Lap top to the CPU card.
- The PC being powered, and under Dos control, insert the disquette **"T200 Configuration and Diagnostic"** into the driver and press **A:MG** then **ENTER** (Capital letter either not). The main menu is displayed.

For information on the use of the configuration software package, refer to the chapter entitled "Commissioning" in the T200 user's manual.

| Event | Possible cause | Solution |
|---|--|---|
| The "ON" LED on the COMMS card is OFF. | Equipment is not powered | Power the equipment |
| | Control unit supply fuse is burnt | Change the fuse on the Power supply unit. Fuse : 5x20mm, 0.8A semi time lag. |
| | Comms card failure. | Change the Comms card. |
| The "FAULT" LED on the COMMS card is steady ON. | The modem connected to the T200 is not recognised or doesn't work properly | Connect a correct modem |
| | At least one of the telephone number doesn't answer. | Check: <ul style="list-style-type: none">- The phone numbers- The complete chain of use- The modem standard options (generally setup by switches on the modem). Reset the Hayes modem and the T200. |
| The "FAULT" LED on the COMMS card is flashing ON. | The comms card software is in fault | Press "General RESET" button on the Power supply unit. If the led doesn't turn OFF some seconds later, change the comms card. |
| The "Equipment fault" LED on the "Control panel" module is ON. and presence of MODBUS comms failure event | Comms card failure. | Change the Comms card. |

Communication module

Replacing the Serial line module

Removing the module

- a) switch off the control unit,
 - Switch Off the AC supply
 - Disconnect the batteries
- b) unscrew the two module locking screws and extract it from its location.

Installing the module

- a) install the new board and lock it to its slot,
- b) switch the control unit on again.

IMPORTANT: Do not forget to configure the module; refer to the sections entitled "configuration of access mode" and "configuration of communication parameters"

MODBUS data addresses and encoding

General

Addressing


A MODBUS master can access 255 storage spaces of 64K words (255 MODBUS addresses).

To increase the addressing capability, each storage space is divided into 16 parts (256 words each).

Each part represents the storage space of a T200.

This makes it possible to dialogue with 16 T200s, with the same MODBUS address which increase the addressing capability to 4 080 T200 (255 x 16) in the same MODBUS network.

In the documentation which follows, the term "**sub-address**" (0 to 15) is used to refer to the storage position of the T200 in a MODBUS address.



MODBUS data addresses and encoding

Transmission

- asynchronous, 300 to 19200 bauds
- 1 start bit, 8 data bits, 1 stop bit, no parity
- maximum response time < 30ms.

Reply messages

- Upon receipt of a request recognized by the equipment (read or write), transmission of the data corresponding to the MODBUS specifications.
- Upon receipt of a request not recognized by the equipment, transmission of an exception message (type 1, 2 or 3 only).

Read zone

- The number of words read may not exceed the size of the checked zone.
- Some zones may only be accessed as a whole.

Remarks

- The bit by bit write and read functions are not used in the T200 application.
- Values followed by the letter "h" are in hexadecimal form (e.g. 0003h).
- In the charts describing the data exchanged between the master and the T200, the hatched strips in the "authorized function" columns indicate the zones that are accessible as a whole.

Terminology

- TCD: remote control (encoded in 2 bits)
- TSD: two-state remote indication (encoded in 2 bits)
- TSS: single-state remote indication (encoded in 1 bit)
- TM: telemetering (encoded in 16 bits)

Control orders

The control orders could be received with the "Select Before Execute" mode. This mode is configurable from the main configuration menu of communication card.

MODBUS data addresses and encoding

Identification / configuration zone

| | word address 0000h to 0001h | access mode | authorized function |
|------------------|--------------------------------|-------------|---------------------|
| Software version | 0000h | read | 3,4 |
| Status | 0001h | read/write | 3,4,6 |

■ Bit 0 of status indicates:

- 0 = "Scale conversion" telemetering mode.
- 1 = "Raw data" telemetering mode.

The T200 preset mode is "Scale conversion".

■ Bit 15 of status indicates:


- 0 = No events loss
 - 1 = Loss of events
- This bit is set when the event file is full. The event "event loss" is then placed in the file. As long as this event is in the file, no other event can be memorized. This bit is reset when the file is empty. This change of state doesn't initiate an event.

Time synchronization zone

This zone contains the internal date and time of the equipment for time-stamping of events.

The zone may only be read or written as a whole.

| binary date | word address 0002h to 0005h | access mode | authorized function |
|---------------|--------------------------------|-------------|---------------------|
| year | 0002h | read/write | 3,4,16 |
| month+day | 0003h | read/write | 3,4 |
| hours+minutes | 0004h | read/write | 3,4 |
| milliseconds | 0005h | read/write | 3,4 |



MODBUS data addresses and encoding

Test zone

The test zone contains 9 words that can be read or written. It is preset to zero status and is available to users to facilitate final adjustment tests.

The contents of the zone do not have any effect on the T200 functions.

| Test zone | word address | access mode | authorized function |
|-----------|----------------|-------------|---------------------|
| 9 words | 0006h to 000Eh | read/write | 1,2,3,4,5,6,16 |

Event zone

This zone contains the time stamp events.

| Event zone | word address | access mode | authorized function |
|---------------|----------------|-------------|---------------------|
| exchange word | 000Fh | read/write | 3,4,6,16 |
| event 1 | 0010h to 0017h | read | 3,4 |
| event 2 | 0018h to 001Fh | read | 3,4 |
| event 3 | 0020h to 0027h | read | 3,4 |
| event 4 | 0028h to 002Fh | read | 3,4 |

Only the exchange word may be written.
It is possible to read the exchange zone as a whole or the exchange word only.

The exchange word is used to manage a specific protocol to be sure not to lose events as a result of a MODBUS communication problem; the event table is numbered for that purpose.

The exchange word comprises 2 bytes:

- Most significant byte = exchange number which identifies each event frame. It is preset to zero when the T200 is switched on; when it reaches its maximum value (FFh), it automatically goes back to 0. The T200 numbers the exchanges and the master acknowledges the numbering.

- Least significant byte = number of valid events in the event zone (maximum 4).

MODBUS data addresses and encoding

Encoding of events

Each event is encoded with 4 words related to the event, followed by 4 words containing the event time-stamping data:

- word1: 0800h /2048
- word2: event bit address
 - 001Fh /31: Event loss bit (set only on appearance)
 - 0340h to 036Fh / 832 to 879: TSD 1 to 24
 - 0370h to 0375h /880 to 885 : code CR
 - 0380h to 03BFh / 896 to 959: TSS 1 to 64
- word3: 0
- word4: 0 = 0 to 1 change of state
1 = 1 to 0 change of state
- words 5 to 8: time-stamping with same format as date zone.

Acknowledgment of events

To inform the T200 that it has correctly received the frame it has read, the master must :

□ writes the number of the last exchange it has received in the "exchange number" byte

□ resets the "number of events" byte of the exchange word to zero.

After acknowledgment, the T200 erases the events that have already been transmitted and replaces them by new ones when applicable.

Remark: until the exchange word written by the master becomes "X,0" (with X = number of the previous exchange that the master wishes to acknowledge), the exchange word in the table remains at "X, number of previous events".

If the number is equal to zero, the master is not required to acknowledge a message with no event.

MODBUS data addresses and encoding

TC / TSD / TSS zone

| TCD / TSD / TSS | word address | access mode | function authorized |
|-----------------|--------------------|-------------|---------------------|
| TCD 1-8 | 0030h | write | 1,2,3,4,5,6 |
| TCD 9-16 | 0031h | write | 1,2,3,4,5,6 |
| TCD 17-24 | 0032h | write | 1,2,3,4,5,6 |
| reserved | 0033h | write | 1,2 |
| TSD 1-8 | 0034h | read | 1,2,3,4 |
| TSD 9-16 | 0035h | read | 1,2,3,4 |
| TSD 17-24 | 0036h | read | 1,2,3,4 |
| CR | 0037h | read | 1,2,3,4,5,6 |
| TSS 1-16 | 0038h | read | 1,2,3,4 |
| TSS 17-32 | 0039h | read | 1,2,3,4 |
| TSS 33-48 | 003Ah | read | 1,2,3,4 |
| TSS 49-64 | 003Bh | read | 1,2,3,4 |
| TSS 65-80 | 003Ch | read | 1,2,3,4 |
| TSS 81-96 | 003Dh | read | 1,2,3,4 |
| TSS 97-112 | 003 ^E h | read | 1,2,3,4 |
| TSS 113-128 | 003Fh | read | 1,2,3,4 |

Each TCD word is encoded as follows:

| | | | | | | | |
|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|
| TCD8 c o | TCD7 c o | TCD6 c o | TCD5 c o | TCD4 c o | TCD3 c o | TCD2 c o | TCD1 c o |
| b15 | | | b8 | b7 | | | b0 |

A remote control TCD is encoded in 2 bits:

- 01 = open order
- 10 = closing order

The TCDs are assigned as follows:

- TCD1..16 : Switch 1..16.
- TCD18: reset of fault current detectors by a closing order.
- TCD21..24: Automatism ON/OFF of CPU1, CPU2, CPU3, CPU4

Remote control orders are performed by writing a TCD word. Only one remote control order at a time may be requested. The order type is the status complementary to the TSD status (only one bit should be included in the word written). It is only accepted if the T200 is not already processing a remote control order.

The control order zone (TCD) may be read with bit and word read function code. As it contains no information the data is 0.

The CR code (result code) gives information on the processing of the remote control order carried out by the T200:

- bit 0: Remote control in progress.
- bit 1: Fault concerning the initial remote control order
- bit 2: Serious fault detected during internal check.
- bit 3: External fault; the switch has not reached the desired status within the time allotted.
- bit 4: Remote control not executed due to Station in Local mode or other disabling condition.
- bit 5: Failure to execute for an unknown reason.

Each change of state of one of this bit will produce a MODBUS event.

The telecontrol center system may reset this codes by writing a 0 to the relevant address.

MODBUS data addresses and encoding

Each TSD word is encoded as follows:

| TSD8 | | TSD7 | | TSD6 | | TSD5 | | TSD4 | | TSD3 | | TSD2 | | TSD1 | |
|------|---|------|---|------|---|------|---|------|---|------|---|------|---|------|---|
| C | O | C | O | C | O | C | O | C | O | C | O | C | O | C | O |
| b15 | | | | b8 | | | | b7 | | | | b0 | | | |

A TSD is encoded in 2 bits, F,O

The TSDs are assigned as follows:

- 01 = switch open.
- 10 = switch closed.
- 00 or 11 = undetermined.

- TSD1: Switch 1.
- TSD2: Switch 2.
- TSD3: Switch 3.
- TSD4: Switch 4.

For automatism only :

- 11 = automatism locked by internal problem
- 00 = automatism locked by external TSS

- TSD18: Corresponds to fault current detector reset order. The status is set to 01.

Each TSS word is encoded as follows:

| TSS16 | TSS15 | TSS14 | TSS13 | TSS12 | TSS11 | TSS10 | TSS9 | TSS8 | TSS7 | TSS6 | TSS5 | TSS4 | TSS3 | TSS2 | TSS1 |
|-------|-------|-------|-------|-------|-------|-------|------|------|------|------|------|------|------|------|------|
| b15 | | | | b8 | | | | b7 | | | | b0 | | | |

CPU 1 (4 ways)

| Single remote indications | Word bit |
|-----------------------------|----------|
| TSS1 : Phase fault SW 1. | 38h 0 |
| TSS2 : Earth fault A SW 1. | 38h 1 |
| TSS3 : Phase fault SW 2. | 38h 2 |
| TSS4 : Earth fault A SW 2. | 38h 3 |
| TSS5 : Phase fault SW 3. | 38h 4 |
| TSS6 : Earth fault A SW 3. | 38h 5 |
| TSS7 : Phase fault SW 4. | 38h 6 |
| TSS8 : Earth fault A SW 4. | 38h 7 |
| TSS9 : Earth switch SW 1. | 38h 8 |
| TSS10 : Earth switch SW 2. | 38h 9 |
| TSS11 : Earth switch SW 3. | 38h 10 |
| TSS12 : Earth switch SW 4. | 38h 11 |
| TSS13 : Earth fault B SW 1. | 38h 12 |
| TSS14 : Earth fault B SW 2. | 38h 13 |
| TSS15 : Earth fault B SW 3. | 38h 14 |
| TSS16 : Earth fault B SW 4. | 38h 15 |
| TSS17 : Digital input 1. | 39h 0 |
| TSS18 : Digital input 2. | 39h 1 |
| TSS19 : Volt. presence SW1 | 39h 2 |
| TSS20 : Volt. presence SW2 | 39h 3 |
| TSS21 : Volt. presence SW3 | 39h 4 |
| TSS22 : Volt. presence SW4 | 39h 5 |
| TSS23 : Local. | 39h 6 |
| TSS24 : Im. AC sup OFF. | 39h 7 |
| TSS25 : Digital input 3. | 39h 8 |
| TSS26 : Charger fault. | 39h 9 |
| TSS27 : Battery fault. | 39h 10 |
| TSS28 : SW. supply OFF. | 39h 11 |
| TSS29 : Del. AC sup. OFF. | 39h 12 |
| TSS30 : Digital input 4. | 39h 13 |
| TSS31 : Digital input 5. | 39h 14 |
| TSS32 : Digital input 6. | 39h 15 |

optionnal CPU2 (8 ways)

| Single remote indications | Word bit |
|---------------------------|----------|
| TSS33 :Phase fault SW 5 | 3Ah 0 |
| TSS34 :Earth fault A SW 5 | 3Ah 1 |
| TSS35 :Phase fault SW 6 | 3Ah 2 |
| TSS36 :Earth fault A SW 6 | 3Ah 3 |
| TSS37 :Phase fault SW 7 | 3Ah 4 |
| TSS38 :Earth fault A SW 7 | 3Ah 5 |
| TSS39 :Phase fault SW 8 | 3Ah 6 |
| TSS40 :Earth fault A SW 8 | 3Ah 7 |
| TSS41 :Earth switch SW 5 | 3Ah 8 |
| TSS42 :Earth switch SW 6 | 3Ah 9 |
| TSS43 :Earth switch SW 7 | 3Ah 10 |
| TSS44 :Earth switch SW 8 | 3Ah 11 |
| TSS45 :Earth fault B SW 5 | 3Ah 12 |
| TSS46 :Earth fault B SW 6 | 3Ah 13 |
| TSS47 :Earth fault B SW 7 | 3Ah 14 |
| TSS48 :Earth fault B SW 8 | 3Ah 15 |
| TSS49 :Digital input 7 | 3Bh 0 |
| TSS50 :Digital input 8 | 3Bh 1 |
| TSS51 :Volt. Presence SW5 | 3Bh 2 |
| TSS52 :Volt. Presence SW6 | 3Bh 3 |
| TSS53 :Volt. Presence SW7 | 3Bh 4 |
| TSS54 :Volt. Presence SW8 | 3Bh 5 |
| TSS55 :Reserved | 3Bh 6 |
| TSS56 :Reserved | 3Bh 7 |
| TSS57 :Digital input 9 | 3Bh 8 |
| TSS58 :Reserved | 3Bh 9 |
| TSS59 :Reserved | 3Bh 10 |
| TSS60 :Reserved | 3Bh 11 |
| TSS61 :Reserved | 3Bh 12 |
| TSS62 :Digital input 10 | 3Bh 13 |
| TSS63 :Digital input 11 | 3Bh 14 |
| TSS64 :Digital input 12 | 3Bh 15 |

optionnal CPU3 (12 ways)

| Single remote indications | Word bit |
|----------------------------|----------|
| TSS65 :Phase fault SW 9 | 3Ch 0 |
| TSS66 :Earth fault A SW 9 | 3Ch 1 |
| TSS67 :Phase fault SW 10 | 3Ch 2 |
| TSS68 :Earth fault A SW 10 | 3Ch 3 |
| TSS69 :Phase fault SW 11 | 3Ch 4 |
| TSS70 :Earth fault A SW 11 | 3Ch 5 |
| TSS71 :Phase fault SW 12 | 3Ch 6 |
| TSS72 :Earth fault A SW 12 | 3Ch 7 |
| TSS73 :Earth switch SW 9 | 3Ch 8 |
| TSS74 :Earth switch SW 10 | 3Ch 9 |
| TSS75 :Earth switch SW 11 | 3Ch 10 |
| TSS76 :Earth switch SW 12 | 3Ch 11 |
| TSS77 :Earth fault B SW 10 | 3Ch 12 |
| TSS78 :Earth fault B SW 11 | 3Ch 13 |
| TSS79 :Earth fault B SW 12 | 3Ch 14 |
| TSS80 :Earth fault B SW 13 | 3Ch 15 |
| TSS81 :Digital input 13 | 3Dh 0 |
| TSS82 :Digital input 14 | 3Dh 1 |
| TSS83 :Volt. presence SW9 | 3Dh 2 |
| TSS84 :Volt. presence SW10 | 3Dh 3 |
| TSS85 :Volt. presence SW11 | 3Dh 4 |
| TSS86 :Volt. presence SW12 | 3Dh 5 |
| TSS87 :Reserved | 3Dh 6 |
| TSS88 :Reserved | 3Dh 7 |
| TSS89 :Digital input 15 | 3Dh 8 |
| TSS90 :Reserved | 3Dh 9 |
| TSS91 :Reserved | 3Dh 10 |
| TSS92 :Reserved | 3Dh 11 |
| TSS93 :Reserved | 3Dh 12 |
| TSS94 :Digital input 16 | 3Dh 13 |
| TSS95 :Digital input 17 | 3Dh 14 |
| TSS96 :Digital input 18 | 3Dh 15 |

optionnal CPU4 (16 ways)

| Single remote indications | Word bit |
|-----------------------------|----------|
| TSS97 :Phase fault SW 13 | 3Eh 0 |
| TSS98 :Earth fault A SW 13 | 3Eh 1 |
| TSS99 :Phase fault SW 14 | 3Eh 2 |
| TSS100 :Earth fault A SW 14 | 3Eh 3 |
| TSS101 :Phase fault SW 15 | 3Eh 4 |
| TSS102 :Earth fault A SW 15 | 3Eh 5 |
| TSS103 :Phase fault SW 16 | 3Eh 6 |
| TSS104 :Earth fault A SW 16 | 3Eh 7 |
| TSS105 :Earth switch SW 13 | 3Eh 8 |
| TSS106 :Earth switch SW 14 | 3Eh 9 |
| TSS107 :Earth switch SW 15 | 3Eh 10 |
| TSS108 :Earth switch SW 16 | 3Eh 11 |
| TSS109 :Earth fault B SW 13 | 3Eh 12 |
| TSS110 :Earth fault B SW 14 | 3Eh 13 |
| TSS111 :Earth fault B SW 15 | 3Eh 14 |
| TSS112 :Earth fault B SW 16 | 3Eh 15 |
| TSS113 :Digital input 19 | 3Fh 0 |
| TSS114 :Digital input 20 | 3Fh 1 |
| TSS115 :Volt.presence SW13 | 3Fh 2 |
| TSS116 :Volt.presence SW14 | 3Fh 3 |
| TSS117 :Volt.presence SW15 | 3Fh 4 |
| TSS118 :Volt.presence SW16 | 3Fh 5 |
| TSS119 :Reserved | 3Fh 6 |
| TSS120 :Reserved | 3Fh 7 |
| TSS121 :Digital input 21 | 3Fh 8 |
| TSS122 :Reserved | 3Fh 9 |
| TSS123 :Reserved | 3Fh 10 |
| TSS124 :Reserved | 3Fh 11 |
| TSS125 :Reserved | 3Fh 12 |
| TSS126 :Digital input 22 | 3Fh 13 |
| TSS127 :Digital input 23 | 3Fh 14 |
| TSS128 :Digital input 24 | 3Fh 15 |

MODBUS data addresses and encoding

Telemetry zone

| 32 TM | Word address | | access mode | function authorized |
|----------------------|---------------|---------|-------------|---------------------|
| | Hexa. | decimal | | |
| Phase current way 1 | 0040h | 64 | read | 3,4 |
| Phase current way 2 | 0041h | 65 | read | 3,4 |
| Phase current way 3 | 0042h | 66 | read | 3,4 |
| Phase current way 4 | 0043h | 67 | read | 3,4 |
| Phase current way 5 | 0044h | 68 | read | 3,4 |
| Phase current way 6 | 0045h | 69 | read | 3,4 |
| Phase current way 7 | 0046h | 70 | read | 3,4 |
| Phase current way 8 | 0047h | 71 | read | 3,4 |
| Phase current way 9 | 0048h | 72 | read | 3,4 |
| Phase current way 10 | 0049h | 73 | read | 3,4 |
| Phase current way 11 | 004Ah | 74 | read | 3,4 |
| Phase current way 12 | 004Bh | 75 | read | 3,4 |
| Phase current way 13 | 004Ch | 76 | read | 3,4 |
| Phase current way 14 | 004Dh | 77 | read | 3,4 |
| Phase current way 15 | 004Eh | 78 | read | 3,4 |
| Phase current way 16 | 004Fh | 79 | read | 3,4 |
| TM reserved | 0050h à 005Fh | 80 à 95 | read | 3,4 |

Each TM value is a signed value encoded in 2's complement 16-bit word.

Depending on the calibration mode configured (in the identification zone), the value should be interpreted as follows:

"Raw data" mode: This is a value over +/-32767. For current metering, it is always positive and reaches +32767 as the maximum value. To find out the current value, it is necessary to convert :

$$I = A * val + B.$$

Example: for a full scale at 400 Amps, a TM value read as 8192 (2000h) corresponds to $8192 * 400 / 32767 + 0 = 100 \text{ A}$.

"Scale conversion" mode: This is the direct value of what is measured.

Example: if the equipment measures 387 Amps, the value of the TM read will be +387.

In both operating modes, invalid or non-declared measurements are encoded with the value 8000h (-32768).

MODBUS data addresses and encoding

Diagnostic counter reading

The sub-function codes recognized by the T200 are:

- 0000h: T200 returns an echo of the request.

- 000Ah: diagnostic count reset.

- 000Bh: reading of the number of frames received with no CRC errors (CPT1).


- 000Ch: reading of the number of frames received with CRC errors (CPT2).

- 000Dh: reading of the number of exception replies (CPT3).

- 000Eh: reading of the number of frames addressed to the station (CPT4).

- 000Fh: reading of broadcast requests received (CPT5).

The most significant bit of the sub-function code should be assigned with the sub-address of the T200 to be accessed.



MODBUS data addresses and encoding

Report by exception with a modem

When an indication configured as an alarm changes of state, T200 initiates an alarm cycle by dialling-up the main phone number after the "dial-up delay time / first attempt".

Two cases can occur:

1 - The telecontrol center system doesn't answer:

T200 dial-up again the "main" phone number after the "dial-up delay time / second attempt" and eventually try again after the "dial-up delay time / third attempt".

If the 3 attempts fail, T200 starts again a new sequence with the "standby" phone number.

2 - The telecontrol center system answer :

The telecontrol center system send a broadcast message (Slave address = 0) and the function code = 0.

T200 send back an exception message with its address, function code 0 with most significant bit set to 1 and the exception code filled with the sub-address.

The telecontrol center system can then initiate a standard MODBUS Master/Slave communication.

Example of an alarm followed by TS reading (Address=1, sub-address=4) (Frame displayed with the MODBUS analyser function of the COMMS card)

```
98/06/12 11:17:06.20 Alarm 1, delay = 1s...
98/06/12 11:17:07.22 Call in progress... "122"
98/06/12 11:17:30.48 Connected, calling mode "CONNECT 9600"
98/06/12 11:17:33.80 address      <  00 00 01 B0
98/06/12 11:17:33.80 ADDRESS     >> 01 80 04 40 03
98/06/12 11:17:44.74 read  ts    <  01 03 04 34 00 08 04 F2
98/06/12 11:17:44.74 READ  TS    >> 01 03 10 00 9A 00 00 00 04 00
                                     00 00 00 00 40 00 00 00 00 EA CD
```

MODBUS data addresses and encoding

Report by exception without any modem

This function allows T200 to report an alarm to the master when :

- The link between T200 / Master is multipoint (permanent link, radio, optical fiber ...).
- The Master doesn't poll T200 all the time.

In this case configuration of T200 in the comms parameter menu is :

Modem : **Direct**

Alarm message enabled : **yes**

Then T200 can report an alarm by exception (modification of status, fault detection ...)

- T200 transmits spontaneously an exception.

| | | | |
|--------------|--------|-------------|--------|
| Slave number | 00h | Sub-address | CRC16 |
| 1 byte | 1 byte | 1 byte | 2 byte |

- The master then must read tables and events from the T200 which transmits spontaneously an exception.
- If the master doesn't reply by a reading of table, T200 has no transmits again the exception message after 1, 2, 5, 10, 10, ... minutes.
- T200 transmits this exception with a collision avoidance mechanism .

Select before execute

This function allows to send first a select message before the control message.

- First writing message : Select.
- Second writing message : "Execute".

Case of "Writing bit" (function n°5) :

- Message "Select" : bit = "0".
- Message "Execute " : bit = "1".

Case of "Writing word" (function n°6) :

- Message "Select" : the word consists of all the bit = "1". Except the bit of the control which is set to "0".
- Message "Execute " : normal control proceedings : the word consists of all the bit = "0". Except the bit of the control which is set to "1".

The control is operate by the equipment only after reception of Select and Execute.

The Execute must be received less than 20 seconds after the Select.

In case of failure, an exception reply (03 = incorrect data) is replied to the master.

MODBUS protocol

MODBUS is a master - slave protocol.

It is used to read or write one or more words (16 bits), as well as diagnostic counters.

Functions available:

- **1**: read n output bits.
- **2**: read n input bits.
- **3**: read n output words.
- **4**: read n input words.
- **5**: write a bit.
- **6**: write a word.
- **8**: read diagnostic counters.
- **16**: write several words.

Exchanges are carried out at the master's initiative and comprise a request from the master followed by the reply from the slave. The master's requests are addressed to a slave identified by its number in the first byte of the frame or else addressed to all the slaves (broadcast).

Broadcast commands are necessarily write commands. No reply is transmitted by the slaves.

Structure of frames exchanged

All the frames exchanged (request and reply) have the same structure:

| | | | |
|--------------|---------------|-----------|---------------------|
| Slave number | function code | data zone | check zone CRC16 |
|--------------|---------------|-----------|---------------------|

Each message or frame contains 4 types of information:

- **slave number (1 byte)**: it specifies the receiving equipment (0 to FFh). If it is equal to zero, the request concerns all the slaves (broadcast) and there is no reply message.
- **function code (1 byte)**: it is used to select a command (read, write...) and check that the reply is correct.
- **data zone (n bytes)**: it contains the parameters linked to the function.
- **check zone (2 bytes)**: it is used to detect transmission errors.

Please note that words (2 bytes = 16 bits) are always written as high-order bits to low-order bits, with the exception of the CRC16 which is written as least significant bit, most significant bit.

Synchronization of exchanges

Any character that is received after a silence of more than 3 characters is considered as the beginning of a frame. A silence in the line equal to at least 3 characters should be respected between two frames.

Example: at 9600 bauds, the time is equal to approximately 3 milliseconds.

Checking of messages received by the slave

When the slave receives a frame, it checks the following, in order: CRC16, slave number, function code and function parameters.

- If the CRC16 or the slave number are incorrect, the slave does not reply.
- If the CRC16 and the slave number are correct, but the function code or parameters are not valid, the slave transmits an exception reply.
- If the CRC16, slave number, function code and parameters are correct, the slave replies to the master's request.

Exception reply transmitted by the slave

| | | | |
|-----------------|--|---|---------|
| Slave number | function code received with MSB set to 1 | Exception code 01 unknown function code 02 incorrect address 03 incorrect data | CRC16 |
| 1 byte | 1 byte | 1 byte | 2 bytes |

Appendix

Read N bits: functions n°1 and 2

Function 1: read output bits.

Function 2: read input bits.

Request

| Slave number | 1 or 2 | address of 1st bit (MSB+LSB) | number of bits | CRC16 |
|--------------|--------|------------------------------|----------------|---------|
| 1 byte | 1 byte | 2 bytes | 2 bytes | 2 bytes |

Reply

| Slave number | 1 or 2 | number of bytes read | 1st byte read | | last byte read | CRC16 |
|--------------|--------|----------------------|---------------|---------|----------------|---------|
| 1 byte | 1 byte | 1 byte | 2 bytes | N bytes | 2 bytes | 2 bytes |

Example

Reading of 16 bits, bit address 300h of slave n°1, sub-address 2

Request: 01 01 23 00 00 10 36 42

Reply: 01 01 02 00 00 B9 FC

Read N words: functions n°3 and 4

The number of words to be read should be less than or equal to 125.

Function 3: read output words.

Function 4: read input words.

Request

| Slave number | 3 or 4 | address of 1st word (MSB+LSB) | number of words (MSB+LSB) | CRC16 |
|--------------|--------|-------------------------------|---------------------------|---------|
| 1 byte | 1 byte | 2 bytes | 2 bytes | 2 bytes |

Reply

| Slave number | 3 or 4 | number of bytes read | 1st word read (MSB+LSB) | | last word read (MSB+LSB) | CRC16 |
|--------------|--------|----------------------|-------------------------|--|--------------------------|---------|
| 1 byte | 1 byte | 2 bytes | 2 bytes | | 2 bytes | 2 bytes |

Example

Reading of words 40h to 43h of slave n°1, offset 0

Request: 01 03 00 40 00 04 45 DD

Reply: 01 03 08 00 00 80 00 80 00 80 00 C2 17

Appendix

Write a bit: function n°5

Request

| | | | | | |
|--------------|--------|--------------------------|-----------|--------|---------|
| Slave number | 5 | address of bit (MSB+LSB) | bit value | 0 | CRC16 |
| 1 byte | 1 byte | 2 bytes | 1 byte | 1 byte | 2 bytes |

Reply

The reply is an echo of the request indicating that the slave has acknowledged the value contained in the request.

| | | | | | |
|--------------|--------|--------------------------|-----------|--------|---------|
| Slave number | 5 | address of bit (MSB+LSB) | bit value | 0 | CRC16 |
| 1 byte | 1 byte | 2 bytes | 1 byte | 1 byte | 2 bytes |

Example

Writing of bit to 1, bit address 301h of slave n°1, sub-address n°2

Request: 01 05 23 01 FF 00 D6 7E

Reply: 01 05 23 01 FF 00 D6 7E

Write a word: function n°6

Request

| | | | | |
|--------------|--------|---------------------------|-------------------------|---------|
| Slave number | 6 | address of word (MSB+LSB) | value of word (MSB+LSB) | CRC16 |
| 1 byte | 1 byte | 2 bytes | 2 bytes | 2 bytes |

Reply

The reply is an echo of the request indicating that the slave has acknowledged the value contained in the request.

| | | | | |
|--------------|--------|---------------------------|-------------------------|---------|
| Slave number | 6 | address of word (MSB+LSB) | value of word (MSB+LSB) | CRC16 |
| 1 byte | 1 byte | 2 bytes | 2 bytes | 2 bytes |

Example

Writing of word 30h of slave n°1, offset 0 at the value 0001h

Request: 01 06 00 30 00 01 48 05

Reply: 01 06 00 30 00 01 48 05

Appendix

Read diagnostic counters: function n°8

Each slave is assigned diagnostic counters. There are 5 counters in all per slave. The counters are 16-bit words. When they reach FFFFh, they go back to 0000h. When a request is sent by the master, the most significant byte in the sub-function code is assigned by the T200 equipment offset to access and the data are at 0000h.

When the slave sends a reply, the data contain the value of the counter concerned.

Request / reply

| | | | | |
|--------------|--------|-----------------------------|----------------|---------|
| Slave number | 8 | sub-function code (MSB+LSB) | data (MSB+LSB) | CRC16 |
| 1 byte | 1 byte | 2 bytes | 2 bytes | 2 bytes |

| | sub-function code | data |
|---|-------------------|------|
| the slave should send the echo of the request | xx00 | XXXX |
| resetting of diagnostic counters | xx0A | 0000 |
| reading of total number: | | |
| of frames received with no CRC errors (CPT1) | xx0B | XXXX |
| of frames received with CRC errors (CPT2) | xx0C | XXXX |
| of the number of exception replies (CPT3) | xx0D | XXXX |
| of frames addressed to the station (CPT4) (excluding broadcast) | xx0E | XXXX |
| of broadcast requests received and correctly executed (CPT5) | xx0F | XXXX |

Sub-function n°0 is used to test transmission. The slave sends back the echo of the data received.

Examples

Resetting of counters for slave n°1, offset 0

Request: 01 08 00 0A 00 00 C0 09

Reply: 01 08 00 0A 00 00 C0 09

Reading of broadcast requests received (CPT5) for slave n°1, offset 3 (300h in storage space)

Request: 01 08 03 0F 00 00 D0 4C

Reply: 01 08 03 0F 00 05 10 4F

Appendix

Write N consecutive words: function n°16

The number of words to be written is between 1 and 123 and the number of bytes is between 2 and 246.

Words are written in increasing order of addresses.

Request

| Slave number | 10h | address of 1st word to write | number of words to write | number of bytes to write | values of words to write | CRC16 |
|--------------|--------|------------------------------|--------------------------|--------------------------|--------------------------|---------|
| 1 byte | 1 byte | 2 bytes | 2 bytes | 1 byte | N bytes | 2 bytes |

Reply

| Slave number | 10h | address of 1st word written (MSB+LSB) | number of words written (MSB+LSB) | CRC16 |
|--------------|--------|---------------------------------------|-----------------------------------|---------|
| 1 byte | 1 byte | 2 bytes | 2 bytes | 2 bytes |

Example


Writing of words 0302h to 0305h of slave n°1, sub-address 3 (addresses 02h to 05h) with the values 0060h, 0A10h, 0B33h, 1662h

Request: 01 10 03 02 00 04 08 00 60 0A 10 0B 33 16 62 96 B3

Reply: 01 10 03 02 00 04 60 4E

Appendix

CRC 16 calculation algorithm



n = number of bits of data
poly= CRC16=1010 0000 0000 0001 calculation polynomial

Write CRC 16 calculation in C language

Calculates and gives the CRC16 in the "buf" zone with length "len".

- *buf: pointer of buffer on which the calculations are performed.
- len: length of buffer.

```
unsigned crc16(char *buf, int len)
{
#define POLY 0xA001
    char i;
    unsigned crc;

    for (crc = 0xFFFF; len != 0; len --)
    {
        crc ^= *buf ++;
        for (i = 0; i < 8; i ++)
        {
            if (crc & 0x0001)
                crc = (crc >> 1) ^ POLY;
            else
                crc >>= 1;
        }
    }
    return (crc);
}
```

Communication exchange table T200 - 16 ways

| Single remote indications | Word bit | Single remote indications | Word bit | Single remote indications | Word bit | Single remote indications | Word bit |
|----------------------------|----------|---------------------------|----------|----------------------------|----------|-----------------------------|----------|
| TSS1 : Phase fault SW 1. | 38h 0 | TSS33 :Phase fault SW 5 | 3Ah 0 | TSS65 :Phase fault SW 9 | 3Ch 0 | TSS97 :Phase fault SW 13 | 3Eh 0 |
| TSS2 : Earth fault A SW 1. | 38h 1 | TSS34 :Earth fault A SW 5 | 3Ah 1 | TSS66 :Earth fault A SW 9 | 3Ch 1 | TSS98 :Earth fault A SW 13 | 3Eh 1 |
| TSS3 : Phase fault SW 2. | 38h 2 | TSS35 :Phase fault SW 6 | 3Ah 2 | TSS67 :Phase fault SW 10 | 3Ch 2 | TSS99 :Phase fault SW 14 | 3Eh 2 |
| TSS4 : Earth fault A SW 2. | 38h 3 | TSS36 :Earth fault A SW 6 | 3Ah 3 | TSS68 :Earth fault A SW 10 | 3Ch 3 | TSS100:Earth fault A SW 14 | 3Eh 3 |
| TSS5 : Phase fault SW 3. | 38h 4 | TSS37 :Phase fault SW 7 | 3Ah 4 | TSS69 :Phase fault SW 11 | 3Ch 4 | TSS101: Phase fault SW 15 | 3Eh 4 |
| TSS6 : Earth fault A SW 3. | 38h 5 | TSS38 :Earth fault A SW 7 | 3Ah 5 | TSS70 :Earth fault A SW 11 | 3Ch 5 | TSS102 :Earth fault A SW 15 | 3Eh 5 |
| TSS7 : Phase fault SW 4. | 38h 6 | TSS39 :Phase fault SW 8 | 3Ah 6 | TSS71 :Phase fault SW 12 | 3Ch 6 | TSS103: Phase fault SW 16 | 3Eh 6 |
| TSS8 : Earth fault A SW 4. | 38h 7 | TSS40 :Earth fault A SW 8 | 3Ah 7 | TSS72 :Earth fault A SW 12 | 3Ch 7 | TSS104 :Earth fault A SW 16 | 3Eh 7 |
| TSS9 : Earth switch SW 1. | 38h 8 | TSS41 :Earth switch SW 5 | 3Ah 8 | TSS73 :Earth switch SW 9 | 3Ch 8 | TSS105 :Earth switch SW 13 | 3Eh 8 |
| TSS10 :Earth switch SW 2. | 38h 9 | TSS42 :Earth switch SW 6 | 3Ah 9 | TSS74 :Earth switch SW 10 | 3Ch 9 | TSS106:Earth switch SW 14 | 3Eh 9 |
| TSS11 :Earth switch SW 3. | 38h 10 | TSS43 :Earth switch SW 7 | 3Ah 10 | TSS75 :Earth switch SW 11 | 3Ch 10 | TSS107:Earth switch SW 15 | 3Eh 10 |
| TSS12 :Earth switch SW 4. | 38h 11 | TSS44 :Earth switch SW 8 | 3Ah 11 | TSS76 :Earth switch SW 12 | 3Ch 11 | TSS108:Earth switch SW 16 | 3Eh 11 |
| TSS13 :Earth fault B SW 1. | 38h 12 | TSS45 :Earth fault B SW 5 | 3Ah 12 | TSS77 :Earth fault B SW 10 | 3Ch 12 | TSS109:Earth fault B SW 13 | 3Eh 12 |
| TSS14 :Earth fault B SW 2. | 38h 13 | TSS46 :Earth fault B SW 6 | 3Ah 13 | TSS78 :Earth fault B SW 11 | 3Ch 13 | TSS110:Earth fault B SW 14 | 3Eh 13 |
| TSS15 :Earth fault B SW 3. | 38h 14 | TSS47 :Earth fault B SW 7 | 3Ah 14 | TSS79 :Earth fault B SW 12 | 3Ch 14 | TSS111:Earth fault B SW 15 | 3Eh 14 |
| TSS16 :Earth fault B SW 4. | 38h 15 | TSS48 :Earth fault B SW 8 | 3Ah 15 | TSS80 :Earth fault B SW 13 | 3Ch 15 | TSS112:Earth fault B SW 15 | 3Eh 15 |
| TSS17 :Digital input 1. | 39h 0 | TSS49 :Digital input 7 | 3Bh 0 | TSS81 :Digital input 13 | 3Dh 0 | TSS113:Digital input 19 | 3Fh 0 |
| TSS18 :Digital input 2. | 39h 1 | TSS50 :Digital input 8 | 3Bh 1 | TSS82 :Digital input 14 | 3Dh 1 | TSS114:Digital input 20 | 3Fh 1 |
| TSS19 :Volt. presence SW1 | 39h 2 | TSS51 :Volt. Presence SW5 | 3Bh 2 | TSS83 :Volt. presence SW9 | 3Dh 2 | TSS115:Volt.presence SW13 | 3Fh 2 |
| TSS20 :Volt. presence SW2 | 39h 3 | TSS52 :Volt. Presence SW6 | 3Bh 3 | TSS84 :Volt. presence SW10 | 3Dh 3 | TSS116:Volt.presence SW14 | 3Fh 3 |
| TSS21 :Volt. presence SW3 | 39h 4 | TSS53 :Volt. Presence SW7 | 3Bh 4 | TSS85 :Volt. presence SW11 | 3Dh 4 | TSS117:Volt.presence SW15 | 3Fh 4 |
| TSS22 :Volt. presence SW4 | 39h 5 | TSS54 :Volt. Presence SW8 | 3Bh 5 | TSS86 :Volt. presence SW12 | 3Dh 5 | TSS118:Volt.presence SW16 | 3Fh 5 |
| TSS23 :Local. | 39h 6 | TSS55 :Reserved | 3Bh 6 | TSS87 :Reserved | 3Dh 6 | TSS119:Reserved | 3Fh 6 |
| TSS24 :Im. AC sup OFF. | 39h 7 | TSS56 :Reserved | 3Bh 7 | TSS88 :Reserved | 3Dh 7 | TSS120:Reserved | 3Fh 7 |
| TSS25 :Digital input 3. | 39h 8 | TSS57 :Digital input 9 | 3Bh 8 | TSS89 :Digital input 15 | 3Dh 8 | TSS121:Digital input 21 | 3Fh 8 |
| TSS26 :Charger fault. | 39h 9 | TSS58 :Reserved | 3Bh 9 | TSS90 :Reserved | 3Dh 9 | TSS122:Reserved | 3Fh 9 |
| TSS27 :Battery fault. | 39h 10 | TSS59 :Reserved | 3Bh 10 | TSS91 :Reserved | 3Dh 10 | TSS123:Reserved | 3Fh 10 |
| TSS28 :SW. supply OFF. | 39h 11 | TSS60 :Reserved | 3Bh 11 | TSS92 :Reserved | 3Dh 11 | TSS124:Reserved | 3Fh 11 |
| TSS29 :Del. AC sup. OFF. | 39h 12 | TSS61 :Reserved | 3Bh 12 | TSS93 :Reserved | 3Dh 12 | TSS125:Reserved | 3Fh 12 |
| TSS30 :Digital input 4. | 39h 13 | TSS62 :Digital input 10 | 3Bh 13 | TSS94 :Digital input 16 | 3Dh 13 | TSS126:Digital input 22 | 3Fh 13 |
| TSS31 :Digital input 5. | 39h 14 | TSS63 :Digital input 11 | 3Bh 14 | TSS95 :Digital input 17 | 3Dh 14 | TSS127:Digital input 23 | 3Fh 14 |
| TSS32 :Digital input 6. | 39h 15 | TSS64 :Digital input 12 | 3Bh 15 | TSS96 :Digital input 18 | 3Dh 15 | TSS128:Digital input 24 | 3Fh 15 |

| Single remote indications | Word bit | Double remote indications | Word bit | Double remote control | word | Other | word |
|-----------------------------|----------|---------------------------|----------|-----------------------|--------|-----------------------|---------|
| CR0Remote ctrl in progress | 37h 0 | TSDD1 :Switch 1 open | 34h 0 | TCD1 :Switch 1 open | 30h 0 | Version | 00h |
| CR1Remote control fault | 37h 1 | Switch 1 close | 34h 1 | Switch 1 close | 30h 1 | Status | 01h |
| CR2Internal fault (serious) | 37h 2 | TSDD2 :Switch 2 open | 34h 2 | TCD2 :Switch 2 open | 30h 2 | Clock synchronisation | 02h-05h |
| CR3SW posit. not reached | 37h 3 | Switch 2 close | 34h 3 | Switch 2 close | 30h 3 | Test area | 06h-0Eh |
| CR4T200 in Local | 37h 4 | TSDD3 :Switch 3 open | 34h 4 | TCD3 :Switch 3 open | 30h 4 | | |
| CR5Fail for unknown reason | 37h 5 | Switch 3 close | 34h 5 | Switch 3 close | 30h 5 | | |
| | | TSDD4 :Switch 4 open | 34h 6 | TCD4 :Switch 4 open | 30h 6 | | |
| | | Switch 4 close | 34h 7 | Switch 4 close | 30h 7 | | |
| | | TSDD5 :Switch 5 open | 34h 8 | TCD5 :Switch 5 open | 30h 8 | | |
| | | Switch 5 close | 34h 9 | Switch 5 close | 30h 9 | | |
| | | TSDD6 :Switch 6 open | 34h 10 | TCD6 :Switch 6 open | 30h 10 | | |
| | | Switch 6 close | 34h 11 | Switch 6 close | 30h 11 | | |
| | | TSDD7 :Switch 7 open | 34h 12 | TCD7 :Switch 7 open | 30h 12 | | |
| | | Switch 7 close | 34h 13 | Switch 7 close | 30h 13 | | |
| | | TSDD8 :Switch 8 open | 34h 14 | TCD8 :Switch 8 open | 30h 14 | | |
| | | Switch 8 close | 34h 15 | Switch 8 close | 30h 15 | | |
| | | TSDD9 :Switch 9 open | 35h 0 | TCD9 :Switch 9 open | 31h 0 | | |
| | | Switch 9 close | 35h 1 | Switch 9 close | 31h 1 | | |
| | | TSDD10:Switch 10 open | 35h 2 | TCD10:Switch 10 open | 31h 2 | | |
| | | Switch 10 close | 35h 3 | Switch 10 close | 31h 3 | | |
| | | TSDD11:Switch 11 open | 35h 4 | TCD11:Switch 11 open | 31h 4 | | |
| | | Switch 11 close | 35h 5 | Switch 11 close | 31h 5 | | |
| | | TSDD12:Switch 12open | 35h 6 | TCD12:Switch 12open | 31h 6 | | |
| | | Switch 12 close | 35h 7 | Switch 12 close | 31h 7 | | |
| | | TSDD13:Switch 13 open | 35h 8 | TCD13:Switch 13 open | 31h 8 | | |
| | | Switch 13 close | 35h 9 | Switch 13 close | 31h 9 | | |
| | | TSDD14:Switch 14 open | 35h 10 | TCD14:Switch 14 open | 31h 10 | | |
| | | Switch 14 close | 35h 11 | Switch 14 close | 31h 11 | | |
| | | TSDD15:Switch 15 open | 35h 12 | TCD15:Switch 15 open | 31h 12 | | |
| | | Switch 15 close | 35h 13 | Switch 15 close | 31h 13 | | |
| | | TSDD16:Switch 16 open | 35h 14 | TCD16:Switch 16 open | 31h 14 | | |
| | | Switch 16 close | 35h 15 | Switch 16 close | 31h 15 | | |
| | | TSDD 18 : Reserved (1) | 36h 2 | TCD 18 : Reset FPI | 32h 2 | | |
| | | Reserved (0) | 36h 3 | Reserved | 32h 3 | | |

| Measure | Word | Automatism (TSD) | Word bit |
|-------------------------|------|-----------------------|----------|
| Phase current switch 1 | 40h | TSDD21 :Auto CPU1 OFF | 36h 8 |
| Phase current switch 2 | 41h | :Auto CPU1 ON | 36h 9 |
| Phase current switch 3 | 42h | TSDD22 :Auto CPU2 OFF | 36h 10 |
| Phase current switch 4 | 43h | :Auto CPU2 ON | 36h 11 |
| Phase current switch 5 | 44h | TSDD23 :Auto CPU3 OFF | 36h 12 |
| Phase current switch 6 | 45h | :Auto CPU3 ON | 36h 13 |
| Phase current switch 7 | 46h | TSDD24 :Auto CPU4 OFF | 36h 14 |
| Phase current switch 8 | 47h | :Auto CPU4 ON | 36h 15 |
| Phase current switch 9 | 48h | | |
| Phase current switch 10 | 49h | | |
| Phase current switch 11 | 4Ah | | |
| Phase current switch 12 | 4Bh | | |
| Phase current switch 13 | 4Ch | | |
| Phase current switch 14 | 4Dh | | |
| Phase current switch 15 | 4Eh | | |
| Phase current switch 16 | 4Fh | | |

| Events (*) | Word | Automatism (TCD) | Word bit |
|---------------|---------|----------------------|----------|
| Exchange word | 0Fh | TCD21 :Auto CPU1 OFF | 32h 8 |
| Event 1 | 10h-17h | :Auto CPU1 ON | 32h 9 |
| Event 2 | 18h-1Fh | TCD22 :Auto CPU2 OFF | 32h 10 |
| Event 3 | 20h-27h | :Auto CPU2 ON | 32h 11 |
| Event 4 | 28h-2Fh | TCD23 :Auto CPU3 OFF | 32h 12 |
| | | :Auto CPU3 ON | 32h 13 |
| | | TCD24 :Auto CPU4 OFF | 32h 14 |
| | | :Auto CPU4 ON | 32h 15 |

(*) The 200 events stored in memory are read through a 4 events buffer

Communication exchange table T200 - 4 ways

| Double remote indications | | wor | bit |
|---------------------------|---------------------|-----|-----|
| TSD1 : | Switch 1 open | 34h | 0 |
| | Switch 1 closed | 34h | 1 |
| TSD2 : | Switch 2 open | 34h | 2 |
| | Switch 2 closed | 34h | 3 |
| TSD3 : | Switch 3 open | 34h | 4 |
| | Switch 3 closed | 34h | 5 |
| TSD4 : | Switch 4 open | 34h | 6 |
| | Switch 4 closed | 34h | 7 |
| TSD 18 : | Reserved: value = 1 | 36h | 2 |
| | Reserved: value = 0 | 36h | 3 |

| Single remote indications | | | |
|---------------------------|-------------------------------|-----|----|
| CR0 : | Remote control in progress | 37h | 0 |
| CR1 : | Remote control fault | 37h | 1 |
| CR2 : | Internal fault (serious) | 37h | 2 |
| CR3 : | Switch position not reached | 37h | 3 |
| CR4 : | Failure due to T200 in local | 37h | 4 |
| CR5 : | Failure due to unknown reason | 37h | 5 |
| TSS1 : | Phase fault SW 1. | 38h | 0 |
| TSS2 : | Earth fault A SW 1. | 38h | 1 |
| TSS3 : | Phase fault SW 2. | 38h | 2 |
| TSS4 : | Earth fault A SW 2. | 38h | 3 |
| TSS5 : | Phase fault SW 3. | 38h | 4 |
| TSS6 : | Earth fault A SW 3. | 38h | 5 |
| TSS7 : | Phase fault SW 4. | 38h | 6 |
| TSS8 : | Earth fault A SW 4. | 38h | 7 |
| TSS9 : | Earth switch SW 1. | 38h | 8 |
| TSS10 : | Earth switch SW 2. | 38h | 9 |
| TSS11 : | Earth switch SW 3. | 38h | 10 |
| TSS12 : | Earth switch SW 4. | 38h | 11 |
| TSS13 : | Earth fault B SW 1. | 38h | 12 |
| TSS14 : | Earth fault B SW 2. | 38h | 13 |
| TSS15 : | Earth fault B SW 3. | 38h | 14 |
| TSS16 : | Earth fault B SW 4. | 38h | 15 |
| TSS17 : | Digital input 1. | 39h | 0 |
| TSS18 : | Digital input 2. | 39h | 1 |
| TSS19 : | Volt. Presence SW1 | 39h | 2 |
| TSS20 : | Volt. Presence SW2 | 39h | 3 |
| TSS21 : | Volt. Presence SW3 | 39h | 4 |
| TSS22 : | Volt. Presence SW4 | 39h | 5 |
| TSS23 : | Local. | 39h | 6 |
| TSS24 : | Immediate AC supply OFF. | 39h | 7 |
| TSS25 : | Digital input 3. | 39h | 8 |
| TSS26 : | Charger fault. | 39h | 9 |
| TSS27 : | Battery fault. | 39h | 10 |
| TSS28 : | Switchgear supply OFF. | 39h | 11 |
| TSS29 : | Delayed AC supply OFF. | 39h | 12 |
| TSS30 : | Digital input 4. | 39h | 13 |
| TSS31 : | Digital input 5. | 39h | 14 |
| TSS32 : | Digital input 6. | 39h | 15 |

| Double remote control | | word | bit |
|-----------------------|----------------------------------|------|-----|
| TCD1 : | opening Switch 1 | 30h | 0 |
| | closing Switch 1 | 30h | 1 |
| TCD2 : | opening Switch 2 | 30h | 2 |
| | closing Switch 2 | 30h | 3 |
| TCD3 : | opening Switch 3 | 30h | 4 |
| | closing Switch 3 | 30h | 5 |
| TCD4 : | opening Switch 4 | 30h | 6 |
| | closing Switch 4 | 30h | 7 |
| TCD18 : | Fault detector reset (value = 0) | 32h | 2 |
| | Fault detector reset (value = 1) | 32h | 3 |

| Remote measurements | |
|-------------------------|-----|
| Phase current channel 1 | 40h |
| Phase current channel 2 | 41h |
| Phase current channel 3 | 42h |
| Phase current channel 4 | 43h |

| Events | |
|---------------|------------|
| Exchange word | 0Fh |
| Event 1 | 10h to 17h |
| Event 2 | 18h to 1Fh |
| Event 3 | 20h to 27h |
| Event 4 | 28h to 2Fh |

| Miscellaneous | |
|-----------------------|------------|
| Version | 00h |
| Status | 01h |
| Clock synchronisation | 02h to 05h |
| Test zone | 06h to 0Eh |

| Automatism (TSD) | |
|----------------------|-------|
| TSD21 :Auto CPU1 OFF | 36h 8 |
| :Auto CPU1 ON | 36h 9 |

| Automatism (TCD) | |
|----------------------|-------|
| TCD21 :Auto CPU1 OFF | 32h 8 |
| :Auto CPU1 ON | 32h 9 |

Communication exchange table T200 P

| Double remote indications | | wor | bit |
|---------------------------|---------------------|-----|-----|
| TSD1 : | Switch open | 34h | 0 |
| | Switch closed | 34h | 1 |
| | | 34h | 2 |
| | | 34h | 3 |
| | | 34h | 4 |
| | | 34h | 5 |
| TSD4 : | automatism OFF | 34h | 6 |
| | Automatism ON | 34h | 7 |
| TSD 18 : | Reserved: value = 1 | 36h | 2 |
| | Reserved: value = 0 | 36h | 3 |

| Single remote indications | | | |
|---------------------------|-------------------------------|-----|----|
| CR0 : | Remote control in progress | 37h | 0 |
| CR1 : | Remote control fault | 37h | 1 |
| CR2 : | Internal fault (serious) | 37h | 2 |
| CR3 : | Switch position not reached | 37h | 3 |
| CR4 : | Failure due to T200 in local | 37h | 4 |
| CR5 : | Failure due to unknown reason | 37h | 5 |
| TSS1 : | Phase fault SW 1. | 38h | 0 |
| TSS2 : | Earth fault A SW 1. | 38h | 1 |
| | | 38h | 2 |
| | | 38h | 3 |
| | | 38h | 4 |
| | | 38h | 5 |
| | | 38h | 6 |
| | | 38h | 7 |
| | | 38h | 8 |
| | | 38h | 9 |
| | | 38h | 10 |
| | | 38h | 11 |
| | | 38h | 12 |
| | | 38h | 13 |
| | | 38h | 14 |
| | | 38h | 15 |
| TSS17 : | Digital input 1. | 39h | 0 |
| TSS18 : | Digital input 2. | 39h | 1 |
| TSS19 : | Digital input 3. | 39h | 2 |
| | | 39h | 3 |
| | | 39h | 4 |
| | | 39h | 5 |
| TSS23 : | Local. | 39h | 6 |
| TSS24 : | Immediate AC supply OFF. | 39h | 7 |
| | | 39h | 8 |
| TSS26 : | Charger fault. | 39h | 9 |
| TSS27 : | Battery fault. | 39h | 10 |
| TSS28 : | Switchgear supply OFF. | 39h | 11 |
| TSS29 : | Delayed AC supply OFF. | 39h | 12 |
| TSS30 : | Operated | 39h | 13 |
| | | 39h | 14 |
| | | 39h | 15 |

| Double remote control | | word | bit |
|-----------------------|----------------------------------|------|-----|
| TCD1 : | opening Switch 1 | 30h | 0 |
| | closing Switch 1 | 30h | 1 |
| | | 30h | 2 |
| | | 30h | 3 |
| | | 30h | 4 |
| | | 30h | 5 |
| TCD4 : | automatism OFF | 30h | 6 |
| | Automatism ON | 30h | 7 |
| TCD18 : | Fault detector reset (value = 0) | 32h | 2 |
| | Fault detector reset (value = 1) | 32h | 3 |

| Remote measurements | | |
|------------------------|--|-----|
| Phase current | | 40h |
| Measurement of voltage | | 41h |
| | | 42h |
| | | 43h |


| Events | | |
|---------------|--|------------|
| Exchange word | | 0Fh |
| Event 1 | | 10h to 17h |
| Event 2 | | 18h to 1Fh |
| Event 3 | | 20h to 27h |
| Event 4 | | 28h to 2Fh |

| Miscellaneous | | |
|-----------------------|--|------------|
| Version | | 00h |
| Status | | 01h |
| Clock synchronisation | | 02h to 05h |
| Test zone | | 06h to 0Eh |

RS 485 network

A optional board (Réf 0600) is available with RS 485 type in compliance with the EIA RS 485 standard.

Connexion to RS485 transmission network Connection au réseau de transmission RS485 Conexión a una red de transmisión RS485



N-0600 Ed.1

Operating problems

In case of problems, it is advisable to connect the devices to the RS 485 network one by one.

Make sure that the master sends frames to the equipment concerned.

Points to be checked

Check:

- the distributed voltage V+ (12V),
- the polarization is in one location only,
- the impedance matching is set up at the ends and only at the ends of the RS 485 network,
- the cable use is the one advised,
- the L+ or L- lines are not earthed,
- **the earthing of all the cabled shielding.**

Use an oscilloscope to check the form of the signals:

Transmit voltage

Level 0 +1.5V to +5V

Level 1 -1.5V to -5V

reception voltage threshold

Level 0 >+0.2V

Level 1 <-0.2V

Schneider Electric SA

N0484-9GB Edition : 02/2004

Postal address
F-38050 Grenoble Cedex 9
Tel.: +33 (0)4 76 57 60 60
Telex: merge 320842 F
<http://www.schneider-electric.com>

Rcs nanterre B 954 503 439

As standards, specifications and designs change from time to time, please ask for confirmation of the information given in this publication.

Published by: Schneider Electric SA
Design and layout by: PIPET
Printed by: Hewlett Packard