

**EJX Series
HART Communication Type**

IM 01C25T01-01E

CONTENTS

| | |
|--|------------|
| 1. INTRODUCTION | 1-1 |
| Regarding This Manual | 1-1 |
| 1.1 Safe Use of This Product | 1-2 |
| 1.2 Warranty | 1-2 |
| 1.3 ATEX Documentation | 1-3 |
| 1.4 Matching of Communicator DD and Instrument DD | 1-4 |
| 2. CONDITIONS OF COMMUNICATION LINE | 2-1 |
| 2.1 Interconnection Between DPharp and the HART Communicator | 2-1 |
| 2.2 Communication Line Requirements | 2-1 |
| 2.3 Power Supply Voltage and Load Resistance | 2-1 |
| 3. OPERATION | 3-1 |
| 3.1 Basic Operation of the 275 HART Communicator | 3-1 |
| 3.1.1 Keys and Functions | 3-1 |
| 3.1.2 Display | 3-2 |
| 3.1.3 Calling Up Menu Addresses | 3-2 |
| 3.1.4 Entering, Setting, and Sending Data | 3-3 |
| 3.2 Parameter Usage and Selection | 3-4 |
| 3.3 Menu Tree | 3-5 |
| 3.4 Basic Setup | 3-6 |
| 3.4.1 Tag and Device Information | 3-6 |
| 3.4.2 Unit | 3-6 |
| 3.4.3 Range Change | 3-7 |
| (1) Keypad input | 3-7 |
| (2) Apply values | 3-8 |
| 3.4.4 Output Mode | 3-9 |
| 3.4.5 Damping Time Constant Setup | 3-9 |
| 3.4.6 Output Signal Low Cut Mode Setup | 3-10 |
| 3.4.7 Impulse Line Connection Orientation Setup | 3-10 |
| 3.5 Detailed Setup | 3-11 |
| 3.5.1 Bi-directional Flow Measurement | 3-11 |
| 3.5.2 Integral Indicator Display Mode | 3-11 |
| 3.5.3 Integral Indicator Scale Setup | 3-12 |
| 3.5.4 Unit for Displayed Temperature | 3-14 |
| 3.5.5 Unit for Displayed Static Pressure | 3-14 |
| 3.5.6 Test Output | 3-15 |
| 3.5.7 Sensor Trim | 3-16 |
| (1) Zero Trim | 3-16 |
| (2) Full Sensor Trim | 3-17 |
| a. Auto Sensor Trim | 3-17 |
| b. Manual Sensor Trim | 3-17 |
| (3) Sensor Trim for Static Pressure | 3-18 |
| (4) Reset Trim Adjustment to Factory Setting | 3-18 |
| 3.5.8 Trim Analog Output | 3-18 |
| 3.5.9 Burst Mode | 3-20 |
| 3.5.10 Multidrop Mode | 3-21 |
| 3.5.11 External Switch Mode | 3-22 |

| | |
|--|------------|
| 3.5.12 CPU Failure Burnout Direction and Hardware Write Protect | 3-22 |
| 3.5.13 Software Write Protect | 3-23 |
| (1) Setting Password | 3-23 |
| (2) Entering Password to Enable the Parameter Changes | 3-23 |
| (3) Releasing Password | 3-23 |
| (4) Software Seal | 3-24 |
| 3.5.14 Signal Characterizer | 3-24 |
| 3.5.15 Process Alarm | 3-25 |
| 3.5.16 Status Output (option code AL) | 3-26 |
| 3.5.17 Capillary Fill Fluid Density Compensation | 3-27 |
| 4. SELF-DIAGNOSTICS | 4-1 |
| 4.1 Self-Diagnostics | 4-1 |
| 4.1.1 Identify Problems by Using the Communicator | 4-1 |
| 4.1.2 Checking with Integral Indicator | 4-1 |
| 4.2 Alarms and Countermeasures | 4-2 |
| 5. PARAMETER SUMMARY | 5-1 |
| APPENDIX 1. SAFETY INSTRUMENTED SYSTEMS INSTALLATION | A-1 |
| REVISION RECORD | |

1. INTRODUCTION

Thank you for purchasing the DPharp EJX electronic pressure transmitter.

EJX pressure transmitters are precisely calibrated at the factory before shipment. To ensure both safety and efficiency, please read this manual carefully before operating the instrument.

This manual describes the HART protocol communication functions of the EJX series and explains how to set the parameters for EJX series pressure transmitters using the 275 HART Communicator. For information on the installation, wiring, and maintenance of EJX series pressure transmitters, please refer to the user's manual of each model.



WARNING

When using the EJX in a Safety Instrumented Systems (SIS) application, refer to Appendix 1 in this manual. The instructions and procedures in the appendix must be strictly followed in order to maintain the designed safety integrity of the transmitter.

■ Regarding This Manual

- This manual should be provided on to the end user.
- The contents of this manual are subject to change without prior notice.
- All rights reserved. No part of this manual may be reproduced in any form without Yokogawa's written permission.
- Yokogawa makes no warranty of any kind with regard to this manual, including, but not limited to, implied warranty of merchantability and fitness for a particular purpose.
- If any question arises or errors are found, or if any information is missing from this manual, please inform the nearest Yokogawa sales office.
- The specifications covered by this manual are limited to those for the standard type under the specified model number break-down and do not cover custom-made instruments.

- Please note that changes in the specifications, construction, or component parts of the instrument may not immediately be reflected in this manual at the time of change, provided that postponement of revisions will not cause difficulty to the user from a functional or performance standpoint.
- The following safety symbols are used in this manual:



WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



IMPORTANT

Indicates that operating the hardware or software in this manner may damage it or lead to system failure.



NOTE

Draws attention to information essential for understanding the operation and features.

1.1 Safe Use of This Product

For the safety of the operator and to protect the instrument and the system, please be sure to follow this manual's safety instructions when handling this instrument. If these instructions are not heeded, the protection provided by this instrument may be impaired. In this case, Yokogawa cannot guarantee that the instrument can be safely operated. Please pay special attention to the following points:

(a) Installation

- This instrument may only be installed by an engineer or technician who has an expert knowledge of this device. Operators are not allowed to carry out installation unless they meet this condition.
- With high process temperatures, care must be taken not to burn yourself by touching the instrument or its casing.
- Never loosen the process connector nuts when the instrument is installed in a process. This can lead to a sudden, explosive release of process fluids.
- When draining condensate from the pressure detector section, take appropriate precautions to prevent the inhalation of harmful vapors and the contact of toxic process fluids with the skin or eyes.
- When removing the instrument from a hazardous process, avoid contact with the process fluid and the interior of the meter.
- All installation shall comply with local installation requirements and the local electrical code.

(b) Wiring

- The instrument must be installed by an engineer or technician who has an expert knowledge of this instrument. Operators are not permitted to carry out wiring unless they meet this condition.
- Before connecting the power cables, please confirm that there is no current flowing through the cables and that the power supply to the instrument is switched off.

(c) Operation

- Wait 10 min. after the power is turned off before opening the covers.

(d) Maintenance

- Please carry out only the maintenance procedures described in this manual. If you require further assistance, please contact the nearest Yokogawa office.
- Care should be taken to prevent the build up of dust or other materials on the display glass and the name plate. To clean these surfaces, use a soft, dry cloth.

(e) Modification

- Yokogawa will not be liable for malfunctions or damage resulting from any modification made to this instrument by the customer.

1.2 Warranty

- The warranty shall cover the period noted on the quotation presented to the purchaser at the time of purchase. Problems occurring during the warranty period shall basically be repaired free of charge.
- If any problems are experienced with this instrument, the customer should contact the Yokogawa representative from which this instrument was purchased or the nearest Yokogawa office.
- If a problem arises with this instrument, please inform us of the nature of the problem and the circumstances under which it developed, including the model specification and serial number. Any diagrams, data and other information you can include in your communication will also be helpful.
- The party responsible for the cost of fixing the problem shall be determined by Yokogawa following an investigation conducted by Yokogawa.
- The Purchaser shall bear the responsibility for repair costs, even during the warranty period, if the malfunction is due to:
 - Improper and/or inadequate maintenance by the purchaser.
 - Malfunction or damage due to a failure to handle, use, or store the instrument in accordance with the design specifications.
 - Use of the product in question in a location not conforming to the standards specified by Yokogawa, or due to improper maintenance of the installation location.
 - Failure or damage due to modification or repair by any party except Yokogawa or an approved representative of Yokogawa.
 - Malfunction or damage from improper relocation of the product in question after delivery.
 - Reason of force majeure such as fires, earthquakes, storms/floods, thunder/lightening, or other natural disasters, or disturbances, riots, warfare, or radioactive contamination.

1.3 ATEX Documentation

This section is only applicable to the countries in the European Union.

GB

All instruction manuals for ATEX Ex related products are available in English, German and French. Should you require Ex related instructions in your local language, you are to contact your nearest Yokogawa office or representative.

DK

Alle brugervejledninger for produkter relateret til ATEX Ex er tilgængelige på engelsk, tysk og fransk. Skulle De ønske yderligere oplysninger om håndtering af Ex produkter på eget sprog, kan De rette henvendelse herom til den nærmeste Yokogawa afdeling eller forhandler.

I

Tutti i manuali operativi di prodotti ATEX contrassegnati con Ex sono disponibili in inglese, tedesco e francese. Se si desidera ricevere i manuali operativi di prodotti Ex in lingua locale, mettersi in contatto con l'ufficio Yokogawa più vicino o con un rappresentante.

E

Todos los manuales de instrucciones para los productos antiexplosivos de ATEX están disponibles en inglés, alemán y francés. Si desea solicitar las instrucciones de estos artículos antiexplosivos en su idioma local, deberá ponerse en contacto con la oficina o el representante de Yokogawa más cercano.

NL

Alle handleidingen voor producten die te maken hebben met ATEX explosiebeveiliging (Ex) zijn verkrijgbaar in het Engels, Duits en Frans. Neem, indien u aanwijzingen op het gebied van explosiebeveiliging nodig hebt in uw eigen taal, contact op met de dichtstbijzijnde vestiging van Yokogawa of met een vertegenwoordiger.

SF

Kaikkien ATEX Ex -tyyppisten tuotteiden käyttöohjeet ovat saatavilla englannin-, saksan- ja ranskankielisinä. Mikäli tarvitsette Ex -tyyppisten tuotteiden ohjeita omalla paikallisella kielellänne, ottakaa yhteyttä lähimpään Yokogawa-toimistoon tai -edustajaan.

P

Todos os manuais de instruções referentes aos produtos Ex da ATEX estão disponíveis em Inglês, Alemão e Francês. Se necessitar de instruções na sua língua relacionadas com produtos Ex, deverá entrar em contacto com a delegação mais próxima ou com um representante da Yokogawa.

F

Tous les manuels d'instruction des produits ATEX Ex sont disponibles en langue anglaise, allemande et française. Si vous nécessitez des instructions relatives aux produits Ex dans votre langue, veuillez bien contacter votre représentant Yokogawa le plus proche.

D

Alle Betriebsanleitungen für ATEX Ex bezogene Produkte stehen in den Sprachen Englisch, Deutsch und Französisch zur Verfügung. Sollten Sie die Betriebsanleitungen für Ex-Produkte in Ihrer Landessprache benötigen, setzen Sie sich bitte mit Ihrem örtlichen Yokogawa-Vertreter in Verbindung.

S

Alla instruktionsböcker för ATEX Ex (explosionssäkra) produkter är tillgängliga på engelska, tyska och franska. Om Ni behöver instruktioner för dessa explosionssäkra produkter på annat språk, skall Ni kontakta närmaste Yokogawakontor eller representant.

GR

Όλα τα εγχειρίδια λειτουργίας των προϊόντων με ATEX Ex διατίθενται στα Αγγλικά, Γερμανικά και Γαλλικά. Σε περίπτωση που χρειάζεστε οδηγίες σχετικά με Ex στην τοπική γλώσσα παρακαλούμε επικοινωνήστε με το πλησιέστερο γραφείο της Yokogawa ή αντιπρόσωπο της.

1.4 Matching of Communicator DD and Instrument DD




CAUTION

Before using the 275 HART Communicator, make that the device description(DD) installed in the communicator matches that of the instrument that is being set up. To check the DD of the instrument and the HART communicator, follow the steps below. If the correct DD is not installed in the communicator, you must upgrade the DD at an authorized facility. For communication tools other than the 275 HART Communicator, contact the vendor for upgrade information.

1. Checking the DD of the instrument
 - 1) Connect the communicator to the instrument that is being set up.
 - 2) Call **Device setup** and press [→].
 - 3) Call **Review** and press [→].
 - 4) Press [NEXT] or [PREV] to display **Fld dev rev** to show the DD of the instrument.

[Example]




The instrument DD version is 1.

F0101.EPS

2. Checking the DD of the 275 HART Communicator
 - 1) Turn on only the communicator.
 - 2) Call **Utility** from the main menu and press [→].
 - 3) Call **Simulation** and press [→].
 - 4) Select **YOKOGAWA** from the list of manufacturers by pressing [↓] and press [→].
 - 5) Select the model name of the instrument(i.e. EJX) by pressing [↓] and press [→] to show the DD of the communicator.

[Example]



Version 1.

The communicator DD supports Version 1.

F0102.EPS

2. CONDITIONS OF COMMUNICATION LINE

The HART communication signal is superimposed onto the 4 to 20 mA DC analog signal. Since the modulated wave is a communication signal, superimposing it on the normal signal will, from basic principles, cause no error in the DC component of the analog signal. Thus, monitoring can be performed via the 275 HART Communicator while the transmitter is on-line.

2.1 Interconnection Between DPharp and the HART Communicator

The HART communicator can interface with the transmitter from the control room, the transmitter site, or any other wiring termination point in the loop, provided there is a minimum of 250 Ω between the connection and the power supply. To communicate, it must be connected in parallel with the transmitter; the connections are non-polarized. Figure 2.1 illustrates the wiring connections for direct interface at the transmitter site for the DPharp. The HART communicator can be used for remote access from any terminal strip as well.




Figure 2.1 Connecting the HART Communicator

2.2 Communication Line Requirements

Specifications for communication line:

Supply voltage (general use type): 16.6 to 42 V DC

Load resistance: 250 to 600 Ω (including cable resistance)

Minimum cable size: 24 AWG, (0.51 mm diameter)

Cable type: single pair shielded or multiple pair with overall shield

Maximum twisted-pair length: 10,000 ft (3,048 m)

Maximum multiple twisted-pair length: 5,000 ft (1,524 m)

Use the following formula to determine cable length for a specific application:

$$L = \frac{65 \times 10^6}{(R \times C)} - \frac{(C_f + 10,000)}{C}$$

Where: L = length in feet or meters

R = resistance in ohms, current sense resistance plus barrier resistance

C = cable capacitance in pF/ft, or pF/m

C_f = maximum shunt capacitance of field devices in pF

2.3 Power Supply Voltage and Load Resistance

When configuring the loop, make sure that the external load resistance is within the range in the figure below.

(Note) With an intrinsically safe transmitter, external load resistance includes safety barrier resistance.





Figure 2.3 Relationship between Power Supply Voltage and External Load Resistance

3. OPERATION

3.1 Basic Operation of the 275 HART Communicator

3.1.1 Keys and Functions



F0301.EPS

Figure 3.1.1 HART Communicator

3.1.2 Display

The HART communicator searches for a transmitter on the 4 to 20mA loop when it is turned on. When the HART communicator is connected to the transmitter, the **Online** menu (Top menu) is started automatically and the following display appears. If no transmitter is found, select the **Online** menu.




Figure 3.1.2 Display

- <a> appears and flashes during communication between the HART communicator and the transmitter. At Burst mode, appears.
- The item selected from the previous menu.
- <c> The available items in the menu of .
- <d> or appears when the item is scrolled out of the display.
- <e> Function labels corresponding to specific function keys are displayed. These labels indicate the currently available choices.

Function Key Labels

| F1 | F2 | F3 | F4 |
|--|---|---|--|
| HELP access on-line help | ON/OFF activates or deactivates a binary variable | ABORT terminate current task | OK acknowledge information on screen |
| RETRY try to re-establish communication | DEL delete current character or Hot Key Menu item | ESC leave value unchanged | ENTER accept user-entered data |
| EXIT leave the current menu | SEND send data to device, or mark data to send | QUIT terminate session because of a communication error | NEXT leave the current menu |
| YES answer to yes/no question | PGUP move up one help screen | PGDN move down one help screen | NO answer to yes/no question |
| ALL include current Hot Key item on Hot Key Menu for all devices | PREV go to previous message in a list of messages | NEXT go to next message in the list of messages | SKIP do not mark variable to be sent in off-line configuration |
| SAVE save information to communicator | EDIT edit a variable value | HOME go to the top menu in the device description | ONE include Hot Key item for one device |
| SEND send data to device, or mark data to send | ADD add current item to Hot Key Menu | BACK go back to menu from which HOME was pressed | |

F0303.EPS

3.1.3 Calling Up Menu Addresses

Subsection 3.3 Menu Tree shows the configuration of all menu items available with the HART communicator. The desired item can be displayed with ease by understanding the menu configuration.

When the HART communicator is connected to the transmitter, the **Online** menu will be displayed after the power is turned on. Call up the desired item as follows:

Key operation






There are two choices to select the desired menu item.

- Use the or key to select the desired item, and then press the key.
- Press the number displayed for the desired item.

To return to the previous display, press the key. If **ABORT**, **ESC** and **EXIT** are displayed, press the desired function key.

Example: Call up the **Tag** to change the tag number.

Check to see where **Tag** is located in the menu configuration. Then, call up the **Tag** on the display according to the menu tree (See section 3.3 Menu Tree).

| Display | Operation |
|---|--|
| <div style="border: 1px solid black; padding: 5px;"> <p>1</p> <p>EJX:YOKOGAWA Online 1 Device setup 2 Pres 3 AO 4 LRV 5 URV</p> </div> |  <p>Display 1 appears when the HART Communicator is turned on. Select Device setup.</p> |
| <div style="border: 1px solid black; padding: 5px;"> <p>2</p> <p>EJX:YOKOGAWA Device setup 1 Process Variables 2 Diag/Service 3 Basic Setup 4 Detailed Setup 5 Review HOME</p> </div> |  <p>Select Basic setup.</p> |
| <div style="border: 1px solid black; padding: 5px;"> <p>3</p> <p>EJX:YOKOGAWA Basic Setup 1 Tag YOKOGAWA 2 Unit kPa 3 Re-range 4 Device information 5 Xfer fnctn Linear HELP SAVE HOME</p> </div> |  <p>Select Tag.</p> |
| <div style="border: 1px solid black; padding: 5px;"> <p>4</p> <p>EJX:YOKOGAWA Tag YOKOGAWA YOKOGAWA HELP DEL ESC ENTER</p> </div> | <p>The display for the Tag setting appears. See 3.1.4 for data entry.</p> |
| <div style="border: 1px solid black; padding: 5px;"> <p>5</p> <p>EJX:YOKOGAWA Tag YOKOGAWA F11-1A HELP DEL ESC ENTER</p> </div> |  <p>(ENTER) After entering the data, set the HART communicator with the data entered by pressing ENTER (F4).</p> |
| <div style="border: 1px solid black; padding: 5px;"> <p>6</p> <p>EJX:YOKOGAWA Basic setup 1 Tag 2 Unit 3 Re-range 4 Device information 5 Xfer fnctn HELP SEND HOME</p> </div> |  <p>(SEND) Send the data to the transmitter by pressing SEND (F2).</p> |
| <div style="border: 1px solid black; padding: 5px;"> <p>7</p> <p>EJX:F11-1A Basic Setup 1 Tag 2 Unit 3 Re-range 4 Device information 5 Xfer fnctn HELP HOME</p> </div> | <p>* ♥ flashes during communication. When SEND disappears, the transmission is complete.</p> |

F0304.EPS

3.1.4 Entering, Setting, and Sending Data

Data entered using the keys is set in the HART communicator by pressing **ENTER (F4)**. Then, by pressing **SEND (F2)**, the data is sent to the transmitter. Note that the data is not set in the transmitter if **SEND (F2)** is not pressed. As all the data that has been set in the HART communicator is held in memory unless the power is turned off, all the data can be sent to the transmitter at once.

Operation

Entering data on the **Tag** setting display.

Example: To change from Tag **YOKOGAWA** to **F11-1A**.











Call up the **Tag** setting display.

1. Device setup
↓
3. Basic setup
↓
1. Tag

EJX:YOKOGAWA
Tag
YOKOGAWA
YOKOGAWA
HELP DEL ESC ENTER

F0305.EPS

When the setting display shown above, enter the data as follows:

| Character to be entered | Operation | Display |
|-------------------------|---|-----------------|
| F |   | F O K O G A W A |
| I |   | F I K O G A W A |
| 1 |  | F I 1 O G A W A |
| - |  | F I 1 - G A W A |
| 1 |  | F I 1 - 1 A W A |
| A |   | F I 1 - 1 A W A |
| Deletes characters. |  | F I 1 - 1 A |

F0306.EPS

3.2 Parameter Usage and Selection

Before setting a parameter, please see the following table for a summary of how and when each parameter is used.



IMPORTANT


After setting and sending data with the HART communicator, wait 30 seconds before turning off the transmitter. If it is turned off too soon, the settings will not be stored in the transmitter.

Table 3.2.1 Parameter Usage and Selection

| Item | | HART communicator | Description | Page |
|-------------------------------------|---|--|--|---------|
| Memory | | Tag | Tag number, up to 8 characters | P. 3-6 |
| | | Descriptor | Up to 16 characters | |
| | | Message | Up to 32 characters | |
| | | Date | xx/yy/zz | |
| Transmitter | Unit | Unit | Sets a pressure unit for the measured pressure | P. 3-6 |
| | Range | LRV/URV | Sets the calibration range by the keypad | P. 3-7 |
| | | Apply values | Range for 4 to 20 mA DC signal is set with actual input applied | P. 3-8 |
| | Output mode | Xfer fnctn | Sets mode for output signal to "linear mode" (proportional to input differential pressure) or to "Square root mode" (proportional to flow) | P. 3-9 |
| | Damping time constant | Pres Damp | Adjust the output response speed for the input pressure of differential pressure | P. 3-10 |
| | Output signal low cut mode | Low Cut | Used mainly to stabilize output near 0 if output signal is the square root mode. Two modes are available: forcing output to 0% for input below a specific value, or changing to proportional output for input below a specific value | |
| | | Low cut mode | Linear or Zero | |
| | Bi-directional flow measurement mode | Bi-dir mode | Used to measure bi-directional flows | P. 3-11 |
| | Unit for displayed temperature | Temp Unit | Sets a temperature unit displayed on HART communicator | P. 3-14 |
| | Unit for displayed static pressure | SP Unit | Sets a pressure unit for the static pressure displayed on HART communicator | |
| Impulse line connection orientation | H/L Swap | Used where installation conditions make it imperative to connect high pressure side impulse line to low pressure side of transmitter | P. 3-10 | |
| Display | Integral indicator display mode | Disp Pres % fnctn | Sets mode for integral indicator to "linear mode" (proportional to input differential pressure) or to "Square root mode" (proportional to flow) | P. 3-11 |
| | | Disp select | Sets the following 5 types of integral indicator scale ranges and unit: input pressure, % of range, user set scale, input static pressure, % of static pressure range, and alternating among any four of the above | P. 3-12 |
| | Integral indicator scale | Engr disp range | Sets Engr Unit/Modify Engr Unit/Engr LRV/Engr URV/Engr point/Engr exp | P. 3-13 |
| | Burst mode | Burst option | Selection of the data to be sent continuously (PV, % range/current, or Process vars/crnt) | P. 3-20 |
| | | Burst mode | ON/OFF switching of burst mode | |
| Process alarm | Process Alerts | Used for alarm generation on the integral indicator | P. 3-25 | |
| HART output | Multidrop mode | Poll addr | Sets the polling address (1 to 15) | P. 3-21 |
| | | Polling | ON/OFF switching of multidrop mode | |
| Monitoring | | Pres and Pres % | Pressure variable and % output variable | — |
| | | AO | 4 to 20 mA output variable | |
| | | Snsr temp | Sensor temperature | |
| | | SP and SP % | Static pressure variable and % static pressure variable | |
| | | Engr Disp/exp/Unit | Displays the output of user setting engineering information | |
| Maintenance | Test output | Loop test | Used for loop checks. Output can be set freely from -2.5% to 110% in 1% steps | P. 3-15 |
| | Self-diagnostics | Self test and Status | Check using the self-test and status command. If an error is detected, the corresponding message is displayed | P. 4-1 |
| | Output when CPU error has occurred | AO Alm typ | Display the status of 4 to 20 mA DC output when a failure occurs | P. 3-22 |
| | External volume switch | Ext SW | Display/set the external volume protect/permit for LRV (URV) setting | |
| | Software write protect | Write protect | Displays the permit/protect status of setting changes depending on communications | P. 3-23 |
| | | Enable wrt 10min | Write protect status is released for 10 minutes when the password is entered | |
| New password | | Sets a new password | | |
| Adjustment | Zeroing | Zero trim | Sets the current input value to 0 kPa | P. 3-16 |
| | Sensor trim | Pres and SP sensor trim | Adjust the measured differential pressure and static pressure variables | |
| | Analog output trim | D/A trim, Scaled D/A trim | Adjust the output value at the points of 4 mA and 20 mA | P. 3-18 |
| | Signal characterizer | S.C. menu | Used for compensate the output for the non-linear application | P. 3-24 |
| | Capillary fill fluid density compensation | T.Z. Cmp mode | Compensates the zero shift by the ambient temperature effect on the capillary tubes. | P. 3-27 |

T0301.EPS

3.3 Menu Tree



F0307.EPS

3.4 Basic Setup

3.4.1 Tag and Device Information

To change the Tag No., see section 3.1.4 Entering, Setting, and Sending Data.

Up to 8 characters can be set with **Tag**. The maximum number of characters to be set for other items is as shown below.

| Item | Number of characters |
|------------|----------------------|
| Tag | 8 |
| Descriptor | 16 |
| Message | 32 |
| Date | 2/2/2 |

T0302.EPS

(1) Tag

1. Device setup
↓
3. Basic setup
↓
1. Tag

EJX:YOKOGAWA
Tag
YOKOGAWA
YOKOGAWA

HELP DEL ESC ENTER

(2) Descriptor

1. Device setup
↓
3. Basic setup
↓
4. Device information
↓
2. Descriptor

EJX:YOKOGAWA
Descriptor

HELP DEL ESC ENTER

(3) Message

1. Device setup
↓
3. Basic setup
↓
4. Device information
↓
3. Message

EJX:YOKOGAWA
Message

HELP DEL ESC ENTER

(4) Date

1. Device setup
↓
3. Basic setup
↓
4. Device information
↓
4. Date

EJX:YOKOGAWA
Date
//**
//**

HELP ESC ENTER

F0308.EPS

3.4.2 Unit

The unit parameter is set at the factory before shipment if specified at the time of order. Follow the procedure below to change the unit parameter.

Example: To change the unit from mmH₂O to inH₂O

1. Device setup
↓
3. Basic setup
↓
2. Unit

1
EJX:YOKOGAWA
Unit
mmH2O
MPa
inH2O
mmH2O
ftH2O

HELP ESC ENTER

↑

F4

(ENTER)

Select the desired unit and press **ENTER (F4)**.

2
EJX:YOKOGAWA
Basic setup
1 Tag YOKOGAWA
2 Unit mmH2O
3 Re-range
4 Device information
5 Xfer fnctn Linear

HELP SEND HOME

F2

(SEND)

Press **SEND (F2)** to send the new unit to the transmitter memory.

3
EJX:YOKOGAWA
Basic setup
1 Tag YOKOGAWA
2 Unit mmH2O
3 Re-range
4 Device information
5 Xfer fnctn Linear

HELP SAVE HOME

Check that **SEND** becomes **SAVE**.

F0309.EPS

Note that the Yokogawa default setting for the standard temperature is 4°C (39.2°F). For the units of mmH₂O, inH₂O, and ftH₂O, the pressure varies according to the standard temperature definition. Select the appropriate unit with @68degF when a standard temperature of 20°C (68°F) is required.

Available pressure units are shown below.

| | | |
|---------------------------|--------------------|--------------------|
| inH ₂ O@68degF | mbar | MPa |
| inHg | g/cm ² | inH ₂ O |
| ftH ₂ O@68degF | kg/cm ² | mmH ₂ O |
| mmH ₂ O@68degF | Pa | ftH ₂ O |
| mmHg | kPa | hPa |
| psi | torr | |
| bar | atm | |

FX0301.EPS

3.4.3 Range Change

The range values are factory-set as specified by the customer. To change the range, follow the steps below.

(1) Keypad input — LRV and URV

- The measurement span is determined by the upper and lower range values. In this method, the upper and lower range values can be set independently, and the span changes according to the range limit values sent to the transmitter.

Example: To change the range from **0 to 2500 mmH₂O** to **500 to 3500 mmH₂O**

Call up the **Keypad input** display.

1. Device setup
3. Basic setup
3. Re-range
1. Keypad input

1

```
EJX:YOKOGAWA
Keypad input
1 LRV 0.0 mmH2O
2 URV 2500.0 mmH2O
3 Unit -10197.2 mmH2O
4 LSL -10197.2 mmH2O
5 USL 10197.2 mmH2O
HELP SAVE HOME
```

To change the Lower Range Value, select the **LRV** item.

2

```
EJX:YOKOGAWA
LRV
0.0 mmH2O
0.0
HELP DEL ESC ENTER
```

'5 0 0'
(F4)
(ENTER)
Enter **500**, and press **ENTER (F4)**.

3

```
EJX:YOKOGAWA
Keypad input
1 LRV 500.0 mmH2O
2 URV 2500.0 mmH2O
3 Unit -10197.2 mmH2O
4 LSL -10197.2 mmH2O
5 USL 10197.2 mmH2O
HELP SEND HOME
```

To change the Upper Range Value, select the **URV** item.

4

```
EJX:YOKOGAWA
URV
2500.0 mmH2O
2500.0
HELP DEL ESC ENTER
```

'3 5 0 0'
(F4)
(ENTER)
Enter **3500**, and press **ENTER (F4)**.

5

```
EJX:YOKOGAWA
Keypad input
1 LRV 500.0 mmH2O
2 URV 3500.0 mmH2O
3 Unit -10197.2 mmH2O
4 LSL -10197.2 mmH2O
5 USL 10197.2 mmH2O
HELP SEND HOME
```

(F2)
(SEND)
Press **SEND (F2)** to send the changed data to the transmitter. Check that **SEND** disappears.

F0310.EPS



NOTE

The calibration range can be set as $LRV > URV$ under the following conditions, reversing the 4 to 20 mA output signal.

$$LSL \leq LRV \leq USL$$

$$LSL \leq URV \leq USL$$

$$|URV - LRV| \geq \text{Min. Span}$$

(2) Apply values — changing the ranges while applying an actual input

- This feature allows the lower and upper range values to be setup automatically with the actual input applied. If the upper and lower range values are set, URV and LRV are changed at the same time.

Example: To change the range from **0 to 2500 mmH₂O** to **500 to 3000 mmH₂O**

Call up the **Apply values** display.

1. Device setup
3. Basic setup
3. Re-range
2. Apply values

1

EJX:YOKOGAWA
 WARN-Loop should be removed from automatic control

F4
(OK)

ABORT OK

Press **OK (F4)**.

2

EJX:YOKOGAWA
 Set the:

1 4mA
 2 20mA
 3 Exit

F4
(ENTER)

ABORT ENTER

To set the lower range value, select **4mA** and press **ENTER (F4)**.

3

EJX:YOKOGAWA
 Apply new 4ma input

F4
(OK)

ABORT OK

Apply the pressure of 500mmH₂O. After obtaining a stable pressure, press **OK (F4)**.

4

EJX:YOKOGAWA
 Current applied
 process value: 500.01 mmH₂O

1 Set as 4mA value
 2 Read new value
 3 Leave as found

F4
(ENTER)

ABORT ENTER

The LRV to be changed is 500.01 mmH₂O.

- Selecting item 1 sets LRV to 500.01 mmH₂O.
- Selecting item 2 reads LRV again.

To set LRV = 500.01, select item 1 and press **ENTER (F4)**.

5

EJX:YOKOGAWA
 Set the:

1 4mA
 2 20mA
 3 Exit

↓ ×2
 F4
(ENTER)

ABORT ENTER

Select **Exit** and press **ENTER (F4)**. Check the value after completing the range change with **URV** and **LRV**.

* The span is maintained the same as when changing LRV with **Apply values**. In this case, if LRV is changed from 0 to 500, URV is changed automatically to 3000.

F0311.EPS

- The measurement span is determined by the upper and lower range values. Changing the lower range value causes the upper range value to change automatically, keeping the span constant. If a change in the lower range value causes the upper range value to exceed the measuring limit of the transmitter, an error message appears and the transmitter holds the output signal right before the error occurred. Enter the correct values within the range of the sensor limits.
- Note that changing the upper range value does not cause the lower range value to change. Thus, changing the upper range value also changes the span.

3.4.4 Output Mode

The mode setting for the output signal and the integral indicator can be performed independently.

The output mode for the output signal is set as specified in the order when the instrument is shipped. Follow the procedure below to change the mode.

Example: To change the mode from **Linear** to **Sq root**.

Call up the **Xfer fncn** display.

1. Device setup
 3. Basic setup
 5. Xfer fncn

1

```

EJX:YOKOGAWA
Xfer function
Linear
Sq root
  
```

ESC ENTER (ENTER)

F4 (ENTER)

F2 (SEND)

[1] Select **Sq root**, and press **ENTER (F4)**.
 [2] Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0312.EPS

3.4.5 Damping Time Constant Setup

The damping time constant is set as specified in the order when the instrument is shipped. Follow the procedure below to change the damping time constant. The damping time constant for the amplifier assembly can be set here. The damping time constant for the entire transmitter is the sum of the values for the amplifier assembly and the capsule assembly.

Any number from 0.00 to 100.00 can be set for the damping time constant. Note that setting the quick response parameter ON enables you to set the time constant between 0.00 and 0.49 seconds.

Example: To change from **2.0** seconds to **0.5** seconds

Call up the **Pres Damp** display.

1. Device setup
 3. Basic setup
 6. Pres Damp

1

```

EJX:YOKOGAWA
Pres Damp
2.00 sec
0.5
  
```

HELPE DEL ESC ENTER (ENTER)

F4 (ENTER)

Enter **0.5** and press **ENTER (F4)**.

2

```

EJX:YOKOGAWA
Basic Setup
3 Re-range
4 Device information
5 Xfer fncfn
6 Pres Damp 0.50 sec
7 Low cut 10.00 %
  
```

HELPE SEND HOME (SEND)

F2 (SEND)

Press **SEND (F2)** to send the data to the transmitter.

Call up the **Quick resp** display to set the value to less than 0.5 seconds.

1. Device setup
 4. Detailed setup
 2. Signal condition
 Quick resp

1

```

EJX:YOKOGAWA
Quick resp
Off
On
  
```

ESC ENTER (ENTER)

F4 (ENTER)

Select **On** and press **ENTER (F4)**.

2

```

EJX:YOKOGAWA
Signal condition
7 Low cut mode
8 H/L Swap Normal
9 Bi-dir mode Off
Quick Resp On
T.Z. Cmp menu
  
```

HELPE SEND HOME (SEND)

F2 (SEND)

Press **SEND (F2)** to send the data to the transmitter.

F0313.EPS

3.4.6 Output Signal Low Cut Mode Setup


Low cut mode can be used to stabilize the output signal near the zero point.

The low cut point can be set in a range from 0 to 20%, the direct ratio corresponding to the output signal of 4 to 20 mA. (Hysteresis: ±10% of the cut point)

Either **LINEAR** or **ZERO** can be selected as the low cut mode. Unless otherwise specified, the cut mode is set to LINEAR at the factory.

Note that when the output modes of the output signal and the display are selected as **Sq root** and **Linear** accordingly, the low cut function is not available for the display value.

Example: To set the low cut range to 20% and the cut mode to ZERO in the **Sq root** output mode, proceed as follows:



For low cut in linear mode → For low cut in zero mode

F0314.EPS

Figure 3.4.6 Low Cut Mode

1. Device setup
3. Basic setup
7. Low Cut and 8. Low cut mode

1

```
EJX:YOKOGAWA
Low cut
10.00 %
10.00
```

F4 (ENTER)

Call up **Low cut**, and set to 20%.

2

```
EJX:YOKOGAWA
Low cut mode
Linear
Zero
```

↓ F4 (ENTER)

Select the **Low cut mode**, and set to **Zero**.

3

```
EJX:YOKOGAWA
Basic Setup
4 Device information
5 Xfer fnctn Linear
6 Pres Damp 0.50 sec
7 Low cut 20.00 %
8 Low cut mode Zero
```

← F2 (SEND)

Press **SEND (F2)** to send the date, then check to confirm that **SEND** disappears.

F0315.EPS

3.4.7 Impulse Line Connection Orientation Setup

This function reverses the impulse line orientation. Follow the procedure below to make this change.

Example: Assign the high pressure impulse line connection to the L side of the transmitter.

1. Device setup

3. Basic setup

9. H/L Swap

1

```
EJX:YOKOGAWA
H/L Swap
Normal
Reverse
```

↓ F4 (ENTER)

ESC ENTER

Call up the **H/L Swap** Display. Select **Reverse**, and press **ENTER (F4)**.

2

```
EJX:YOKOGAWA
Basic setup
5 Xfer fnctn Linear
6 Pres Damp 0.50 sec
7 Low cut 20.00 %
8 Low cut mode Zero
9 H/L Swap Reverse
```

← F2 (SEND)

HELP SEND HOME

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0316.EPS

3.5 Detailed Setup

3.5.1 Bi-directional Flow Measurement

(a) **Bi-dir mode** enables selection of 50% output at an input of 0 mmH₂O.

Example: If measurement range is 0 to 3000mmH₂O (LRV = 0 mmH₂O, URV = 3000 mmH₂O)

1. Device setup

4. Detailed setup

2. Signal condition

9. Bi-dir mode

1

```

EJX:YOKOGAWA
Bi-dir mode
Off
off
on
HELP ESC ENTER
            
```

↓
F4
(ENTER)

Call up the **Bi-dir mode** display. Select **on**, and press **ENTER (F4)**.

2

```

EJX:YOKOGAWA
Signal condition
5 Pres Damp 0.50 sec
6 Low cut 20.00 %
7 Low cut mode Zero
8 H/L swap Reverse
9 Bi-dir mode On
HELP SEND HOME
            
```

↓
F2
(SEND)


Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

Note: The measurement range changes to -3000 to 0 to 3000 mmH₂O, corresponding the output of 0% to 50% to 100%. Note that LRV and URV values are not changed.


F0317.EPS

(b) Combining **Bi-dir mode** with **Xfer fnctn** provides a square root output computed independently for 0% to 50% output and for 50% to 100% output.

● Output mode "LINEAR"



● Output mode "SQUARE ROOT"



F0318.EPS

3.5.2 Integral Indicator Display Mode

The mode setting for the output signal and the integral indicator can be performed independently.

The output mode for the integral indicator is set as specified in the order when the instrument is shipped. Follow the procedure below to change the mode.

Example: Change from **Linear** to **Sq root**.

1. Device setup

4. Detailed setup

4. Display condition

2. P disp condition

1. Disp Pres % fnctn

1

```

EJX:YOKOGAWA
Disp Pres % fnctn
Linear
Linear
Sq root
HELP ESC ENTER
            
```

↓
F4
(ENTER)

Call up the **Disp Pres % fnctn** Display. Select **Sq root**, and press **ENTER (F4)**.

2

```

EJX:YOKOGAWA
P disp condition
1 Disp Pres % fnctn
2 Disp Pres % Reso
3 Pres disp point 2
HELP SEND HOME
            
```

↓
F2
(SEND)






Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0319.EPS

If the instrument is equipped with an integral indicator and the transfer function is sq root, "√" is displayed on the integral indicator.

3.5.3 Integral Indicator Scale Setup

The following five displays are available for integral indicators: input pressure, % of range, user set scale, input static pressure*1, and % of static pressure range*1. A cycle of up to four displays can be shown by assigning variables to the parameters at **Disp select**.

| Available displays | Description and related parameters |
|--|---|
| Input pressure (PRES)  | Indicates values of input pressure with the indication limits –99999 to 99999. PRES 456 kPa |
| % of range (PRES %)  | Indicates input pressure in –2.5 to 110% range depending on the set range (LRV and URV). PRES % 45.6 % |
| User set scale (ENGR. PRES)  | Indicates values depending on the engineering range (Engr LRV and Engr URV) with the unit (Engr Unit). Engr LRV 0.0 Engr URV 45.0 Engr exp ×100 Engr Unit m3/min Engr point 1 |
| Input static pressure (SP)*1  | Indicates input static pressure with the indication limits –99999 to 99999. Reference pressure is factory-set in absolute. SP 4.000 MPa |
| % of static pressure range (SP %)*1  | Indicates input static pressure in –10 to 110% range depending on the set range (SP LRV and SP URV). SP % 52.6 % |

*1: Available for differential pressure transmitter.

See (a.) through (d.) for the setting procedures.

T0303.EPS

a. Display Selection

At **Disp select**, select the variable that the parameter **Disp Out 1** will display on the integral indicator.

Example: Change from **PRES %** to **PRES** for the display.

1. Device setup
 ↓
 4. Detailed setup
 ↓
 4. Display condition
 ↓
 1. Disp select
 ↓
 1. Disp Out 1

1

```

EJX:YOKOGAWA
Disp Out 1
PRES %
PRES %
ENGR. PRES
SP
SP %
  
```

↑ (ENTER)
 F4 (ENTER)

Call up the **Disp Out 1** display. Select **PRES**, and press **ENTER (F4)**.

2

```

EJX:YOKOGAWA
Disp select
Disp Out 1 PRES
2 Disp Out 2 Not Used
3 Disp Out 3 Not Used
4 Disp Out 4 Not Used
  
```

← (SEND)
 F2 (SEND)

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0320.EPS

b. Cyclic Display

In addition to the display set at **Disp Out 1**, displays can be set at **Disp Out 2**, **Disp Out 3**, and **Disp Out 4** for cyclic display in the order of the parameter number.

c. Setting Static Pressure Scale

Static pressure can be displayed as a measured input or as a percentage, independent from the 4-20 mA output signal for measured pressure or differential pressure. The **SP setup** parameters under **SP sensor** allow the setting of the range, unit, and damping time constant for the static pressure as well as the pressure management range for PV.

Note that either the high or low pressure side of the capsule can be selected to monitor the static pressure by means of the **H/L Select** parameter under **SP setup**.

d. User Setting of Engineering Unit and Scale

Enter disp range parameters allow the engineering unit and scale to be displayed. At **Set Engr Unit**, the following engineering units can be selected from a list. Alternately, up to eight alphanumeric characters, spaces or slashes (/) can be input on the keypad at **Modify Engr Unit**; only the first six are displayed on the integral indicator.

Select the unit from the **Set Engr Unit** list.

| | | |
|-------|---------|---------|
| kPa | ftH2O | NI/min |
| MPa | gf/cm2 | Nm3/h |
| mbar | kgf/cm2 | Nm3/min |
| bar | kg/cm2G | ACFH |
| psi | kg/cm2A | ACFM |
| psia | atm | SCFH |
| mmH2O | kg/h | SCFM |
| mmHg | t/h | GPH |
| mmHgA | m3/h | GPM |
| mmAq | m3/min | m |
| mmWG | l/h | mm |
| Torr | l/min | in |
| inH2O | kl/h | ft |
| inHg | kl/min | kg/m3 |
| inHgA | NI/h | g/cm3 |

FX0302.EPS

Follow the procedure below to set your own unit.

Example: Set the engineering unit as **M/h**.

1. Device setup
4. Detailed setup
4. Display condition
4. Engr disp range
7. Modify Engr Unit

1

Call up the **Modify Engr Unit**. Set **M/H**, and press **ENTER (F4)**.

2

Enter a space instead of a character to display the character in lowercase, and press **ENTER (F4)**.

F0321.EPS

Note that following symbols are not available:

% & < > . * : + -

The integral indicator shows “-- -- -- -- --” when these are entered.

Engr LRV and **Engr URV** are used to set the lower and upper range values for the engineering unit display. When the instrument is shipped, these are set as specified in the order.

Example: Set lower range value (LRV) to **-50** and upper range value (URV) to **50**.

1. Device setup
4. Detailed setup
4. Display condition
4. Engr disp range
1. Engr LRV and 2. Engr URV

1

Call up the **Engr LRV** Display. Set **-50**, and press **ENTER (F4)**.

2

Press **V W X 2** to select engr disp URV.

3

Set **50**, and press **ENTER (F4)**.

4

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0322.EPS

3.5.4 Unit for Displayed Temperature

When the instrument is shipped, the temperature units are set to **C** (Centigrade). Follow the procedure below to change this setting.

When this parameter is set, it also changes the temperature unit for **Snsr temp** at **Process variables** and **Amp temp** at **Temp sensor**.

Example: Change the unit for the temperature display from degC to degF.

1. Device setup
4. Detailed setup
1. Sensors
3. Temp sensor
3. Temp Unit

1

```

EJX:YOKOGAWA
Temp Unit
degC
degC
degF
Kelvin
    
```

↓ (ENTER)

F4 (ENTER)

Select **degF** (Fahrenheit), and Press **ENTER (F4)**.

2

```

EJX:YOKOGAWA
Temp sensor
1 Snsr temp      23 degC
2 Amp temp       23 degC
3 Temp Unit      degF
    
```

↓ (SEND)

F2 (SEND)

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0323.EPS

3.5.5 Unit for Displayed Static Pressure

Follow the procedure to change the static pressure unit.

Changing this parameter also changes the unit for the static pressure display.

Example: Change the static pressure unit from mmH₂O to kPa.

1. Device setup
4. Detailed setup
1. Sensors
2. SP sensor
3. SP Unit

1

```

EJX:YOKOGAWA
SP Unit
mmH2O
kg/cm2
Pa
kPa
torr
    
```

↓ (ENTER)

F4 (ENTER)

Select **kPa** and Press **ENTER (F4)**.

2

```

EJX:YOKOGAWA
SP sensor
1 SP              0 mmH2O
2 SP %            0.0 %
3 SP Unit         kPa
4 A/G Select
5 SP H/L Select  High
    
```

↓ (SEND)

F2 (SEND)

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0324.EPS

3.5.6 Test Output

This feature can be used to output a fixed current for loop checks. The available range for test output depends on the settings for the **AO lower limit** and **AO upper limit** parameters, whose limit is from 3.6 mA (-2.5%) to 21.6 mA (110%) .

Example: To output 12 mA (50%)

1. Device setup
2. Diag/Service
2. Loop test

1

EJX:YOKOGAWA
 WARN-loop should be removed from automatic control
 ABORT OK

F4
(OK)

Set the control loop in manual mode, and press **OK (F4)**.

2

EJX:YOKOGAWA
 Choose analog output level
 1 4mA
 2 20mA
 3 Other
 4 End
 ABORT ENTER

↓ ×2
F4
(ENTER)

Select **Other**, and press **ENTER (F4)**.
 Supplementary explanation.

1. 4 mA: Outputs a 4 mA current signal
2. 20 mA: Outputs a 20 mA current signal
3. Other: Sets a desired output using the alphanumeric keys
4. End: Exits

3

EJX:YOKOGAWA
 Output
 12
 HELP DEL ABORT ENTER

'1 2'
F4
(ENTER)

Enter **12**, and press **ENTER (F4)**.
 A fixed current of 12 mA is output.

4

EJX:YOKOGAWA
 Fld dev output is fixed at 12.000 mA
 ABORT OK

F4
(OK)

Press **OK (F4)**.

5

EJX:YOKOGAWA
 Choose analog output level
 1 4mA
 2 20mA
 3 Other
 4 End
 ABORT ENTER

↓ ×3
F4
(ENTER)

To finish the loop test, select **End**, and press **ENTER (F4)**.

6

EJX:YOKOGAWA
 NOTE-loop may be returned to automatic control
 OK

F4
(OK)

Press **OK (F4)**.



CAUTION

Test output continues for approximately 10 minutes, then is released automatically. Even if the HART communicator power supply is turned off or the communication cable is disconnected, test output will continue for approximately 10 minutes.

3.5.7 Sensor Trim

Each DPharp EJX series transmitter is factory characterized. Factory characterization is the process of comparing a known pressure input with the output of each transmitter sensor module over the entire pressure and temperature operating range. During the characterization process, this comparison information is stored in the transmitter EEPROM. In operation, the transmitter uses this factory-stored curve to produce a process variable output (PV), in engineering units, dependent on the pressure input.

The sensor trim procedure allows you to adjust for local conditions, changing how the transmitter calculates process variables. There are two ways to trim the sensor: a zero trim and a full sensor trim. A zero trim is a one-point adjustment typically used to compensate for mounting position effects or zero shifts caused by static pressure. A full sensor trim is a two-point process, in which two accurate end-point pressures are applied (equal to or greater than the range values), and all output is linearized between them.

(1) Zero Trim

a. Zeroing—Pres Zero trim

Pres Zero trim carries out the zero adjustment and automatically sets the applied “0” input values to the output value of “0,” keeping the span constant. Use this setting when the LRV is known to be 0 mmH₂O.

1. Device setup
2. Diag/Service
3. Calibration
3. Pres Sensor trim
1. Pres Zero trim

1

EJX:YOKOGAWA
 WARN-LOOP should be removed from automatic control

(OK)

Press **OK (F4)**.

2

EJX:YOKOGAWA
 WARN-This will affect sensor calibration

(OK)

Press **OK (F4)**.

3

EJX:YOKOGAWA
 Apply 0 input to sensor


(OK)

A pressure of 0 mmH₂O is applied. Press **OK (F4)** after the pressure has become stable.

F0326.EPS

b. Level Adjustment—Auto, lower Pt

This zero adjustment calibrates the transmitter output corresponding to the actual tank level. To perform this adjustment, first use a glass gauge or the like to determine the actual tank level, then enter the correct data as shown below.



F0327.EPS

1. Device setup
2. Diag/Service
3. Calibration
3. Pres sensor trim
2. Pres Trim

1

EJX:YOKOGAWA
 Select trim mode
 1 Off
 2 Auto, Lower Pt
 3 Auto, Upper Pt
 4 Manual, Lower Pt
 5 Manual, Upper Pt

(ENTER)

Select the **Auto, Lower Pt**, and press **ENTER (F4)**.

2

EJX:YOKOGAWA
 Pres for trim 1383.0
 Auto, Lower Pt
 0.000000
 1350

'1350'

 (ENTER)

Enter the value of the actual level (1350 mmH₂O), and press **ENTER (F4)**.

F0328.EPS

c. Using External Zero-adjustment Screw

This method permits zero adjustment without the HART communicator. Use a slotted screwdriver to turn the zero-adjustment screw. See the hardware manual for details.

Note that the parameter of **Ext SW** must be **Enabled** to perform this adjustment. See section 3.5.11 for the setting procedure.

(2) Full Sensor Trim—Auto Trim and Manual Trim

Full sensor trim is carried out with a series of the procedure of **Auto, Lower Pt** and **Auto, Upper Pt**. Also, you can manually perform the trimming procedure in **Manual, Lower Pt** and **Manual, Upper Pt**.

The full sensor trim is a two-point adjustment, and the lower point adjustment should always be performed before the upper point adjustment in order to maintain the pitch between the zero and 100% points within the calibration range.

In the manual method, the reference pressure should also be applied to the transmitter at both lower and upper point of trim ends. Without the reference pressure, **P LTD** and **P UTD** may not represent the correct value of adjustment point for each.

a. Auto Sensor Trim

Example: For the range of 1000 to 3000 mmH₂O

1. Device setup
2. Diag/Service
3. Calibration
3. Pres sensor trim
2. Pres Trim

1

EJX:YOKOGAWA
 Select trim mode
 1 Off
 2 Auto, Lower Pt
 3 Auto, Upper Pt
 4 Manual, Lower Pt
 5 Manual, Upper Pt
 ABORT ENTER

(ENTER)

Select **Auto, Lower Pt**, and press **ENTER (F4)**.

2

EJX:YOKOGAWA
 Pres for trim 994.0
 Auto, Lower Pt
 1000.000000
 1000
 DEL ABORT ENTER

'1000'

 (ENTER)

Apply a standard pressure of 1000 mmH₂O to the transmitter. After obtaining a stable pressure, press **ENTER (F4)**.

3

EJX:YOKOGAWA
 Select trim mode
 1 Off
 2 Auto, Lower Pt
 3 Auto, Upper Pt
 4 Manual, Lower Pt
 5 Manual, Upper Pt
 ABORT ENTER

x2

 (ENTER)

Select **Auto, Upper Pt**, and press **ENTER (F4)**.

4

EJX:YOKOGAWA
 Pres for trim 3015.0
 Auto, Upper Pt
 3000.000000
 3000
 DEL ABORT ENTER

'3000'

 (ENTER)

Apply a standard pressure of 3000 mmH₂O to the transmitter. After obtaining a stable pressure, press **ENTER (F4)**.

b. Manual Sensor Trim

Example: For the range of 1000 to 3000 mmH₂O
P LTD = -4.0 mmH₂O
P UTD = -3.0 mmH₂O

1. Device setup
2. Diag/Service
3. Calibration
3. Pres sensor trim
2. Pres Trim

1

EJX:YOKOGAWA
 Select trim mode
 1 Off
 2 Auto, Lower Pt
 3 Auto, Upper Pt
 4 Manual, Lower Pt
 5 Manual, Upper Pt
 ABORT ENTER

x3

 (ENTER)

Select **Manual, Lower Pt**, and press **ENTER (F4)**.

Suppose that a standard pressure of 1000 mmH₂O is applied and the value of the Pres for Trim in **2** is 994.0. Correct for this output error of 6 mmH₂O by adding 6 mmH₂O to **P LTD**.

$$-4.0 + 6.0 = +2.0$$

2

EJX:YOKOGAWA
 Pres for trim 994.0
 Manual, Lower Pt
 -4.000000
 2
 DEL ABORT ENTER

'2'

 (ENTER)

Enter the correction value of 2. Then press **ENTER (F4)**.

3

EJX:YOKOGAWA
 Select trim mode
 1 Off
 2 Auto, Lower Pt
 3 Auto, Upper Pt
 4 Manual, Lower Pt
 5 Manual, Upper Pt
 ABORT ENTER

x4

 (ENTER)

Select **Manual, Upper Pt**, and press **ENTER (F4)**.

Suppose that a standard pressure of 3000 mmH₂O is applied and the value of the Pres for Trim in **4** is 3015.0. Firstly, obtain the slope error for the span as follows;

$$\text{Slope Error} = \frac{\text{Applied Pressure Value} - \text{Value of Pres for Trim}}{\text{Applied Pressure Value}} \times (\text{URV} - \text{LRV})$$

$$= \frac{3000 - 3015}{3000} \times (3000 - 1000) = -10$$

Then correct for this slope error of -10 by adding -10 to **P UTD**.

$$-3.0 + (-10.0) = -13.0$$

4

EJX:YOKOGAWA
 Pres for trim 3015.0
 Manual, Upper Pt
 -3.000000
 -13
 DEL ABORT ENTER

'-13'

 (ENTER)

Enter the correction value of -13. Then press **ENTER (F4)**.

F0348.EPS

(3) Sensor Trim for Static Pressure

For the EJX differential transmitters, zeroing and full sensor trim of the static pressure is performed in the same way as with the primary process variable (PV). Note that the static pressure sensor trim should be done only after trimming the PV.

(4) Reset Trim Adjustment to Factory Setting

The **Clear P snsr trim** and **Clear SP snsr trim** commands can reset the trim adjustment to the initial calibrated values that were set. The amount of the adjustment by the external zero-adjustment screw is returned to the initial setting as well.

3.5.8 Trim Analog Output

Fine current output adjustment is carried out with **D/A trim** or **Scaled D/A trim**.

• D/A Trim

D/A trim is to be carried out if the calibration digital ammeter does not exactly read 4.000 mA and 20.000 mA with an output signal of 0% and 100%.

• Scaled D/A Trim

Scaled D/A trim is to be carried out if the output is adjusted using a voltmeter or a meter whose scale is 0 to 100%.

Example 1: For an adjustment using an ammeter ($\pm 1\mu\text{A}$ is measurable)

1. Device setup
 2. Diag/Service
 3. Calibration
 2. Analog output trim
 1. D/A trim

1

```
EJX:YOKOGAWA
Analog output trim
1 D/A trim
2 Scaled D/A trim
3 Clear D/A trim
HELP SAVE HOME
```

Select the **D/A trim** item.

2

```
EJX:YOKOGAWA
WARN-Loop should be
removed from
automatic control
ABORT OK
```

Press **OK (F4)**.

3

```
EJX:YOKOGAWA
Connect reference
meter
ABORT OK
```

Connect the ammeter ($\pm 1\mu\text{A}$ is measurable), and press **OK (F4)**.

4

```
EJX:YOKOGAWA
Setting fld dev
output to 4mA
ABORT OK
```

Press **OK (F4)**, and the transmitter outputs a 0% output signal.

5

```
EJX:YOKOGAWA
Enter meter value
4.000
4.115
HELP DEL ESC ENTER
```

'4 . 1 1 5'
 (ENTER)

Ammeter reading: 4.115

Enter the read value **4.115** of the ammeter, and press **ENTER (F4)**. (The output of the transmitter changes.)

F0330.EPS

6

```
EJX:YOKOGAWA
Fld dev output 4.000
mA equal to reference
meter?
1 Yes
2 No
```

(ENTER)

Ammeter reading: 4.000

If the reading on the ammeter is 4.000 mA, select **YES** and press **ENTER (F4)**.
If the reading is not 4.000 mA, select item 2. **NO**. Repeat steps **4** and **5** until the ammeter reads 4.000 mA.

7

```
EJX:YOKOGAWA
Setting fld dev
output to 20mA
```

(OK)

Press **OK (F4)**, and the transmitter outputs a 100% output signal.

8

```
EJX:YOKOGAWA
Enter meter value
20.000
19.050
```

(ENTER)

Ammeter reading: 19.050

Carry out the same procedures as those described under **4** and **5**.

9

```
EJX:YOKOGAWA
Fld dev output 20.000
mA equal to reference
meter?
1 Yes
2 No
```

(ENTER)

Ammeter reading: 20.000

Returning fld dev to original output appears.

10

```
EJX:YOKOGAWA
NOTE-Loop may be
returned to automatic
control
```

(OK)

Press **OK (F4)**.

F0331.EPS

Example 2: To adjust using a voltmeter

1. Device setup
2 Diag/Service
3. Calibration
2. Analog output trim
2. Scaled D/A trim

1

```
EJX:YOKOGAWA
Analog output trim
1 D/A trim
2 Scaled D/A trim
3 Clear D/A trim
```

Select the **Scaled D/A trim** item.

2

```
EJX:YOKOGAWA
WARN-Loop should be
removed from
automatic control
```

Press **OK (F4)**.

3

```
EJX:YOKOGAWA
Trim will be scaled
from 4.000 to 20.000
1 Proceed
2 Change
```

Select **Change**, and press **ENTER (F4)**.
When item 3. **Proceed** is selected, **D/A trim** must be carried out.

4

```
EJX:YOKOGAWA
Set scale- Lo output
value
4.000000
1
```

Enter the value read on the meter when the signal is 4 mA. In this case, Enter the value of the voltage across a 250 Ω resistor (1 V), and press **ENTER (F4)**.

5

```
EJX:YOKOGAWA
Set scale- Hi output
value
20.000000
5
```

Enter the value read on the meter when the signal is 20 mA. Then, enter **5**, and press **ENTER (F4)**.

6

```
EJX:YOKOGAWA
Trim will be scaled
from 1.000 to 5.000
1 Proceed
2 Change
```

Select **Proceed** and press **ENTER (F4)**.

7

```
EJX:YOKOGAWA
Connect reference
meter
```

Connect the voltmeter, and press **OK (F4)**.

8

```
EJX:YOKOGAWA
Setting fld dev
output to 4mA
```

Press **OK (F4)**. A 0% output signal is output.

F0332.EPS

9

```
EJX:YOKOGAWA
Enter meter value
1.000000
1.010
```

'1 . 0 1'

[F4]

(ENTER)

Voltmeter reading: 1.010

Enter the reading of the voltmeter (1.010), and press **ENTER (F4)**. (The output of the transmitter changes.)

10

```
EJX:YOKOGAWA
Scaled output: 1.000
equal readout
device?
1 Yes
2 No
```

[F4]

(ENTER)

Voltmeter reading: 1.000

If the reading on the voltmeter is 1.000, select **Yes** and press **ENTER (F4)**.
If the reading is not 1.000, select **No**. Repeat steps **8** and **9** until the voltmeter reads 1.000 V.

11

```
EJX:YOKOGAWA
Setting fld dev
output to 20mA
```

[F4]

(OK)

Press **OK (F4)**. A 100% output signal is output.

12

```
EJX:YOKOGAWA
Enter meter value
5.000000
5.210
```

'5 . 2 1'

[F4]

(ENTER)

Voltmeter reading: 5.210

Enter the reading of the voltmeter (5.210), and press **ENTER (F4)**.

13

```
EJX:YOKOGAWA
Scaled output: 5.000
equal readout
device?
1 Yes
2 No
```

[F4]

(ENTER)

Voltmeter reading: 5.000

Select **Yes** and press **ENTER (F4)**.

"Returning fld dev to original output"

14

```
EJX:YOKOGAWA
NOTE-Loop may be
returned to automatic
control
```

[F4]

(OK)

Press **OK (F4)**.

F0333.EPS

3.5.9 Burst Mode

When the burst mode is set on, the transmitter continuously sends stored data. Either the pressure value, % range/current value, or current/process variables can be selected and sent. The data is sent approximately three times per second as a digital signal when the transmitter is set in burst mode. When data is being sent in burst mode, other operations can be performed with the HART communicator.

Setting of Burst Mode

1. Device setup
4. Detailed setup
3. Output condition
3. HART output
3. Burst mode and 4. Burst option

1

```
EJX:
Burst option
Pv
Pv
% range/current
Process vars/crnt
```

[F4]

(ENTER)

Call up the **Burst option**, and set the data to be sent.

- PV: Primary variable (Pressure value)
- % range/current: Output in % and mA
- Process vars/crnt: Output in mA and process variables (pressure value, static pressure value, and sensor temp value)

2

```
EJX:
Burst mode
Off
On
Off
```

[Up Arrow]

[F4]

(ENTER)

Call up the **Burst mode** and set to **On**.

3

```
EJX:
HART output
1 Poll addr 0
2 Num req preams 5
3 Burst mode On
4 Burst opiton Pv
```

[F2]

(SEND)

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0334.EPS

To release Burst Mode, call up the **Burst mode** display and set it to **Off**.

3.5.10 Multidrop Mode

“Multidropping” transmitters refers to the connection of several transmitters to a single communications transmission line. Up to 15 transmitters can be connected when set in the multidrop mode. To activate multidrop communication, the transmitter address must be changed to a number from 1 to 15. This change deactivates the 4 to 20 mA analog output, sending it to 4 mA. The alarm current is also disabled.

Setting of Multidrop Mode

1. Device setup
4. Detailed Setup
3. Output condition
3. HART Output
1. Poll addr

```
EJX:
Poll addr
  0
  1
```

HELP DEL ESC ENTER



Call up the **Poll addr** and set the polling address. (a number from 1 to 15)
 And press **SEND (F2)** to send the data.

• Then make sure the communicator setting is as follows.

2. Online
4. Utility
1. Configure Communication
1. Polling

```
HART Communicator
Polling
Ask Before Polling
Always Poll
Digital Poll
Poll Using Tag
```

HELP ESC ENTER

(ENTER)

Confirm that **Always Poll**, **Ask Before Polling**, or **Digital Poll** is specified, and press **ENTER (F4)**.

F0335.EPS



NOTE

1. When the polling option is set as **Never Poll** or **Poll Using Tag**, the online menus cannot be called up and displayed. Be sure to select a polling option such as **Ask Before Polling**.
2. When the same polling address is set for two or more transmitters in multidrop mode, communication with these transmitters is disabled.

Example: Communication when set in multidrop mode

1

```
HART Communicator
Online
1 EJX110A-1
2 EJX110A-2
3 EJX110A-3
```

(1) The HART communicator searches for a transmitter that is set in multidrop mode when it is turned on.
 When the HART communicator is connected to the transmitter, the polling address and the tag will be displayed (display **1**).

2

```
EJX:EJX110A-1:
Online
1 Device setup
2 Pres 0.0 mmH2O
3 AO 4.000 mA
4 LRV 0.0 mmH2O
5 URV 3500.0 mmH2O
```

(2) Select the desired transmitter. After that, normal communication to the selected transmitter is possible. However, the communication speed will be slow (display **2**).

3

```
HART Communicator
1 Offline
2 Online
3 Frequency Device
4 Utility
```

(3) To communicate with another transmitter, turn off the power once and then turn on it again, or call up display **3** and select **Online**.

(4) Display **1** will appear. Select the desired transmitter.

F0336.EPS

To release multidrop mode, follow the procedure below.

1. Call up the **Poll addr** display and set the address to 0.
2. Call up the **Polling** display and set **Ask Before Polling**.

3.5.11 External Switch Mode

Follow the procedure below to enable or inhibit zero point adjustment by means of the zero-adjustment screw on the transmitter.

This is set to **Enabled** when the instrument is shipped.

Example: Set the mode to inhibit zero adjustment by means of the external zero-adjustment screw.

1. Device setup
4. Detailed setup
5. Device information
1. Field device info
9. Ext SW

1

| | |
|--|--|
| EJX: Ext SW Enabled Disabled Enabled | <div style="border: 1px solid black; width: 20px; height: 20px; margin: 0 auto; display: flex; align-items: center; justify-content: center;">↑</div> <div style="border: 1px solid black; width: 20px; height: 20px; margin: 2px auto; display: flex; align-items: center; justify-content: center;">F4</div> |
| ESC ENTER | (ENTER) |

Select **Disabled** and press **ENTER (F4)**.

2


| | |
|---|--|
| EJX: Field device info 5 Model 1 6 Model 2 7 Model 3 8 Write Protect No 9 Ext SW Disabled HELP SEND HOME | <div style="border: 1px solid black; width: 20px; height: 20px; margin: 0 auto; display: flex; align-items: center; justify-content: center;">F2</div> |
| SEND | (SEND) |

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0337.EPS

3.5.12 CPU Failure Burnout Direction and Hardware Write Protect

There are two slide switches on the CPU assembly board. One sets the burnout direction at CPU failure, and the other sets a write protection function which disables parameter changes through the use of a handheld terminal or some other communication method.



| Burnout direction switch (BO) | | | | | | | | | | | | | | |
|-----------------------------------|--|-----|--|---|---|--|---|--|---|--|---|---|--|---|
| Burnout Direction Switch Position | <table border="1" style="width: 50%; border-collapse: collapse;"> <tr> <td style="text-align: center;">H</td> <td style="text-align: center;"> </td> <td style="text-align: center;">L</td> </tr> <tr> <td style="text-align: center;">E</td> <td style="text-align: center;"> </td> <td style="text-align: center;">D</td> </tr> </table> | H | | L | E | | D | <table border="1" style="width: 50%; border-collapse: collapse;"> <tr> <td style="text-align: center;">H</td> <td style="text-align: center;"> </td> <td style="text-align: center;">L</td> </tr> <tr> <td style="text-align: center;">E</td> <td style="text-align: center;"> </td> <td style="text-align: center;">D</td> </tr> </table> | H | | L | E | | D |
| H | | L | | | | | | | | | | | | |
| E | | D | | | | | | | | | | | | |
| H | | L | | | | | | | | | | | | |
| E | | D | | | | | | | | | | | | |
| Burnout Direction | HIGH | LOW | | | | | | | | | | | | |

| Hardware write protection switch (WR) | | | | | | | | | | | | | | |
|---------------------------------------|--|-------------------------|--|---|---|--|---|--|---|--|---|---|--|---|
| Write Protection Switch Position | <table border="1" style="width: 50%; border-collapse: collapse;"> <tr> <td style="text-align: center;">H</td> <td style="text-align: center;"> </td> <td style="text-align: center;">L</td> </tr> <tr> <td style="text-align: center;">E</td> <td style="text-align: center;"> </td> <td style="text-align: center;">D</td> </tr> </table> | H | | L | E | | D | <table border="1" style="width: 50%; border-collapse: collapse;"> <tr> <td style="text-align: center;">H</td> <td style="text-align: center;"> </td> <td style="text-align: center;">L</td> </tr> <tr> <td style="text-align: center;">E</td> <td style="text-align: center;"> </td> <td style="text-align: center;">D</td> </tr> </table> | H | | L | E | | D |
| H | | L | | | | | | | | | | | | |
| E | | D | | | | | | | | | | | | |
| H | | L | | | | | | | | | | | | |
| E | | D | | | | | | | | | | | | |
| Write Protection | NO (Write enabled) | YES (Write disabled) | | | | | | | | | | | | |

F0340.EPS

The parameter of **AO alm typ** parameter displays the status of 4-20 mA DC output if a CPU failure occurs. In case of a failure, communication is disabled.

Standard specifications

The burnout direction switch is set to HIGH. If a failure occurs, the transmitter outputs a 110% or higher signal.

Option code /C1

The burnout direction switch is set to LOW. If a failure occurs, a -5% or lower output is generated.

Example: Confirming the burnout direction at the CPU failure.

1. Device setup
4. Detailed setup
3. Output condition
2. Analog output
5. AO alm typ

| | |
|--|---|
| EJX: Analog output 1 Loop test 2 D/A trim 3 Scaled D/A trim 4 Clear D/A trim 5 AO alm typ High HELP SAVE HOME | <div style="border: 1px solid black; width: 20px; height: 20px; margin: 0 auto; display: flex; align-items: center; justify-content: center;">←</div> |
|--|---|

F0341.EPS

3.5.13 Software Write Protect

EJX configured data is saved by using a write protect function. The write protect status is set to “Yes” when 8 alphanumeric characters are entered in the **New password** field and transferred to the transmitter. When write protect is set to “Yes,” the transmitter does not accept parameter changes. When the same eight alphanumeric string entered in the **New password** field is also entered in the **Enable wrt 10min** field and transferred to the transmitter, it will be possible to change transmitter parameters during a 10 minute period.

To change the transmitter from the write protect “Yes” status back to Write protect “No” status, use **Enable wrt 10min** to first release the write protect function and then enter eight spaces in the **New password** field.

The software write protection does not affect the function of external zero adjustment screw.

To disable the external zero adjustment screw, select Disabled in the Ext SW field before activating the software write protection. Refer to subsection 3.5.11.

(1) Setting Password

Example: Set the password to 1 2 3 4 _ _ _ _ .

1

EJX:
Hot key
1 keypad input
2 Wrt protect menu

←

SEND

Press **Hot key**.
Select **Wrt protect menu**.

2

EJX:
Wrt protect menu
1 Write Protect No
2 Enable wrt 10min
3 New password
4 Software seal Keep

←

HELP SEND

Select **New password**.

3

EJX:
Enter new password to change state of write protect:
1234

F4

(ENTER)

HELP DEL ABORT ENTER

Set **1 2 3 4 _ _ _ _** and press **ENTER (F4)**.

S T U V W X Y Z / J K L F2 x4
1 2 3 4 (DEL)

4

EJX:
Re-enter new password withing 30 seconds:
1234
1234

F4

(ENTER)

HELP DEL ABORT ENTER

Set the new password again, and press **ENTER (F4)**.

F0338.EPS

5

EJX:
It changed the state of protection related password.

OK

F4
(OK)
Press **OK (F4)**.
Write Protect status changes from **NO** to **YES**.

F0355.EPS

(2) Entering Password to Enable the Parameter Changes

Example: Enter the password of 1 2 3 4 _ _ _ _ .

1

EJX:
Hot key
1 keypad input
2 Wrt protect menu

←

SEND

Press **Hot key**.
Select **Wrt protect menu**.

2

EJX:
Wrt protect menu
1 Write Protect No
2 Enable wrt 10min
3 New password
4 Software seal Keep

←

HELP SEND

Select **Enable wrt 10min**.

3

EJX:
Enter current password to enable to write for 10 minutes:
1234

F4
(ENTER)

HELP DEL ABORT ENTER

Set **1 2 3 4 _ _ _ _** and press **ENTER (F4)**.

S T U V W X Y Z / J K L F2 x4
1 2 3 4 (DEL)

4

EJX:
Released the write protection for 10 minutes.

F4
(OK)

ABORT OK

Press **ENTER (F4)**.

5

EJX:
If you wish to release completely, you have to change password to all of spaces.

F4
(OK)

OK

Press **OK (F4)**, and the write protect is released for 10 minutes.

F0339.EPS

(3) Releasing Password

To release the password completely, enter spaces in the **New password** field while the write protect function is released.

(4) Software Seal

When you lose the password that has been registered, it is possible to release the **Write Protect** mode by using the general use password: "YOKOGAWA."

When the password is used, the status shown in the parameter of **Software seal** is changed from "KEEP" to "BREAK." The status returns to "KEEP" by entering a newly set password at **Enable wrt 10min.**


3.5.14 Signal Characterizer

This function is used to compensate the output for non-linear applications. The characterized values are applied to the 4-20 mA output. For the measured pressure, a maximum of nine coordinates can be specified between 0-100%. Perform the coordinate settings while the **S.C.** at **S.C. menu** parameter is **Disabled**.

To apply the settings to the output, set the **S.C.** parameter to **Enabled**.

Note that the EJX rejects the activation of the function by AL. 60 with the following transmitter's status:

- When the specified coordinates of x and y are not incremental as the input increases.
- When the output mode of the output signal is set as **Sq root**; at the same time, the low cut mode is set to **Linear**.



F0342.EPS

Example: Set the number of coordinates on the line graph to 5.

1. Device setup
 ↓
 4. Detailed setup
 ↓
 2. Signal condition
 ↓
 S.C. menu
 ↓
 2. Num of points

1

```
EJX:
Num of points
0
5
```

5'

F4 (ENTER)

Enter 5 and press **ENTER (F4)**.

F0343.EPS

2

```
EJX:
S.C. menu
1 S.C. Disabled
2 Num of points 5
3 point setting
4 X Start 0.00 %
5 Y Start 0.00 %
HELP SEND HOME
```

F2 (SEND)

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0356.EPS

Example: Set the first coordinates (X1, Y1) as (12, 14) in %.

1. Device setup
 ↓
 4. Detailed setup
 ↓
 2. Signal condition
 ↓
 S.C. menu
 ↓
 3. Point setting

1

```
EJX:
Select one
1 List
2 Edit all points
3 Edit one point
4 Exit
ABORT ENTER
```

↓ x2
 F4 (ENTER)

Select **Edit one point**, and press **ENTER (F4)**.

2

```
EJX:
Specify S.C. point to
set value
1
1
```

F4 (ENTER)

Press **ENTER (F4)**.

3

```
EJX:
X1
10.00 %
12
```

F4 (ENTER)

Enter 12 and press **ENTER (F4)**.

4

```
EJX:
Y1
10.00 %
14
```

F4 (ENTER)

Enter 14 and press **ENTER (F4)**.

F0344.EPS

Example: Set the signal characterizer to **Enabled**.

1. Device setup
 ↓
 4. Detailed setup
 ↓
 2. Signal condition
 ↓
 S.C. menu
 ↓
 1. S.C.

1

```

EJX:
S.C
Disabled
Disabled
Enabled
HELP DEL ESC ENTER
    
```

(ENTER)

Select **Enabled**, and press **ENTER (F4)**.

2

```

EJX:
S.C. menu
1 S.C. Enabled
2 Num of points 5
3 Point setting
4 X Start 0.00 %
5 Y Start 0.00 %
HELP SEND HOME
    
```

(SEND)

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0345.EPS

3.5.15 Process Alarm

The function is used to display the alarm codes when the input pressure exceeds the specified value within the calibration range. The same is available for the input static pressure and the capsule temperature on the pressure sensor. Refer to table 4.2.1 Alarm Message Summary for the specific alarm code to be generated.

Example: Set the alert mode from **OFF** to **Hi. AI Detect** for the input pressure.

1. Device setup
 ↓
 4. Detailed setup
 ↓
 3. Output condition
 ↓
 4. Process Alerts
 ↓
 1. Pres Alert mode

1

```

EJX:
Pres Alert mode
Off
Off
Hi. AI Detect
Lo. AI Detect
Hi/Lo. AI Detect
ESC ENTER
    
```

(ENTER)

Select **Hi. AI Detect**, and press **ENTER (F4)**.

2

```

EJX:
Process Alerts
1 Pres Alert mode
2 Config Pres Alerts
3 SP Alert Mode off
4 Config SP Alerts
5 Temp Alert Mode
HELP SEND HOME
    
```

(SEND)

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0346.EPS

Example: Set the higher alert value of 75 for alarm generation.

1. Device setup
 ↓
 4. Detailed setup
 ↓
 3. Output condition
 ↓
 4. Process Alerts
 ↓
 2. Config Pres Alerts
 ↓
 1. Hi Alert Val

1

```

EJX:
Hi Alert Val
75 100.000 kPa
HELP DEL ESC ENTER
    
```

(ENTER)

Enter 75, and press **ENTER (F4)**.

2

```

EJX:
Config Pres Alerts
1 Hi Alert Val
2 Lo Alert Val
3 LSL -100.000 kPa
4 USL 100.000 kPa
HELP SEND HOME
    
```

(SEND)

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0347.EPS

3.5.16 Status Output (option code AL)

This feature is used for a transistor output (open collector) of an on/off signal according to the status of high and low alarm limits, which are user-configurable values as shown in 3.5.15 Process Alarm. The status output can be assigned as any combination of the high or low limits of the input pressure, input static pressure, or capsule temperature.

 **NOTE**

No status output signal has been defined for a CPU failure or hardware error. Use a 4-20 mA signal to indicate a transmitter's failure.

Example: Set the status output to output an off signal when the input pressure exceeds 75 kPa with the alert mode of Hi. Al Detect.

1. Device setup
4. Detailed setup
3. Output condition
4. Process Alerts
7. DO Config
2. DO Select and 3. DO Signal type

1

```

EJX:
DO Select
Pres
Off
Pres
SP
Temp
    
```

(ENTER)

Select **Pres**, and press **ENTER (F4)**.

2

```

EJX:
DO Config
1 Digital Output Off
2 DO Select Pres
3 DO Signal type
4 DO Test
    
```

(SEND)

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

3

```

EJX:
DO Signal type
ON WHEN AL. DETECT
OFF WHEN AL. DETECT
    
```

(ENTER)

Select **OFF WHEN AL. DETECT**, and press **ENTER (F4)**.

4

```

EJX:
DO Config
1 Digital Output Off
2 DO Select Pres
3 DO Signal type
4 DO Test
    
```


(SEND)

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.


F0349.EPS

Example: Status output operation of **ON WHEN AL. DETECT**

● Status output for higher alert value



● Status output for lower alert value



F0350.EPS

3.5.17 Capillary Fill Fluid Density Compensation

For transmitters with diaphragm seals, this function is used to compensate the zero shift caused by the ambient temperature effect on the capillary tubes.

The following equation indicates the relationship between the calculated output value and the compensating constant K (%/°C) with the measured ambient temperature at the capsule module.

$$\text{Compensated output} = \text{output} + K \times T_{\text{amb}}$$

(1) Temperature Compensation Mode Setup

When using this function, set **T.Z. Cmp mode** to *ON* to enable or *OFF* to disable. To set to *ON*, follow the procedure below.

Example: Set the temperature compensation mode to **ON**.

1. Device setup
4. Detailed setup
2. Signal condition
T.Z. Cmp menu
1. T.Z. Cmp mode

1

EJX:
T.Z. Cmp mode
Off
Off
On

[F4]
(ENTER)

Select **On**, and press **ENTER (F4)**.

2

EJX:
T.Z. Cmp menu
T.Z. Cmp mode On
2 Temp Zero

[F2]
(SEND)

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0351.EPS

(2) Zero Shift Compensation Setup

Obtain the K compensating value from the equation (a) below, and enter the value to **Temp Zero**.

$$K = - \frac{h \times B}{\text{Span}} \times 100 \dots \dots \dots (a)$$

where,

B: Constant value of fill fluid (See Table A.)


span: |URV-LRV|

h: Distance from high pressure side to low pressure side (m)


EJX118A: Distance from high side of diaphragm seal to low side of diaphragm seal.

EJX438A: Distance from diaphragm seal (high side) to position of transmitter (low side).

● EJX118A



● EJX438A



Note: When the transmitter is positioned lower than the diaphragm seal part, the value of "h" must have a negative sign (-).

F0353.EPS

Example: Enter K value obtained from the equation (a). A value having up to 3 decimal places may be specified.

When h = +3 m, Fill fluid code A, span = 15 kPa,
 $K = -(+3) \times 0.00745 \div 15 \times 100 = -0.149$

1. Device setup
4. Detailed setup
2. Signal condition
T.Z. Cmp menu
2. Temp Zero

1

EJX:
Temp Zero
0.000 %/degC
=0.149

[F4]
(ENTER)

Enter **-0.149** and press **ENTER (F4)**.

2

EJX:
T.Z. Cmp menu
1 T.Z. Cmp mode On
2 Temp Zero

[F2]
(SEND)

Press **SEND (F2)** to send the data to the transmitter, then check to confirm that **SEND** disappears.

F0354.EPS

Note 1: The function is performed using a built-in temperature sensor in the transmitter body. The temperature deviation between the transmitter body and capillaries should be minimized to achieve optimal performance of the function.

Note 2: When the span changes, reenter the newly obtained value of K to **Temp Zero**.

Table A. Constant value [B] of fill fluid

| | Fill fluid code | A, C | B | D | E |
|--------------------|---------------------|----------|----------|----------|----------|
| Constant value [B] | mmH ₂ O | 0.76 | 0.87 | 1.45 | 0.75 |
| | kgf/cm ² | 0.000076 | 0.000087 | 0.000145 | 0.000075 |
| | kPa | 0.00745 | 0.00853 | 0.01422 | 0.00736 |
| | mBar | 0.07453 | 0.08532 | 0.14220 | 0.07355 |
| | atm | 0.000074 | 0.000084 | 0.000140 | 0.000073 |
| | inH ₂ O | 0.02992 | 0.03425 | 0.05709 | 0.02953 |
| | psi | 0.00108 | 0.00124 | 0.00206 | 0.00167 |
| | mmHg | 0.05592 | 0.06401 | 0.10669 | 0.05518 |

T0304.EPS

Note 3: Select the unit of constant value of [B] from the actual unit used for the transmitter in operation.

4. SELF-DIAGNOSTICS

4.1 Self-Diagnostics

4.1.1 Identify Problems by Using the Communicator

The HART communicator can be used to run self-diagnostics on a transmitter and check for incorrect data settings.

The **Self test** and **Status** commands are available for self-diagnostics. When **Self test** is run, the integral indicator shows an error code and alarm message if the transmitter detects any illegal parameter settings and functional faults. See table 4.2.1 Alarm Message Summary for probable causes and countermeasures. If the specific diagnostic item is known for the check, you can directly call up the item by using the **Status** command. See table 4.2.1 to determine the status group.

The HART communicator diagnoses every command you make. When a faulty command or keypad input is performed, an error message appears. See table 4.2.2 HART Communicator Error Messages for the details.

Diagnostic by “self test”

1. Device setup
 ↓
 2. Diag/Service
 ↓
 1. Test device
 ↓
 2. Self test

1

EJX:
 Test device
 1 Status
 2 Self test

←

HELP SAVE HOME

Call up **Test device**, and select **Self test**.

2

EJX:
 Self test OK

If no error is detected, **Self test OK** is displayed.
 If there is an error, an error message appears.

ABORT OK

F0401.EPS

Diagnostic by “status”

1. Device setup
 ↓
 2. Diag/Service
 ↓
 1. Test device
 ↓
 1. Status
 ↓
 6. Status group 6

1

EJX:
 Status
 2 Status group 2
 3 Status group 3
 4 Status group 4
 5 Status group 5
 6 Status group 6

←

HELP SAVE HOME

Call up **Status**, and select **Status group 6**.

2

EJX:
 Status group 6
 Illegal P LRV On
 Illegal P URV Off
 Illegal P SPAN Off
 P SPAN trim err Off
 P ZERO trim err Off

EXIT

If there is no error, the result of diagnostics is indicated as **Off**. If **On** is indicated, a countermeasure for that error is necessary.

F0402.EPS

4.1.2 Checking with Integral Indicator



NOTE

If an error is detected by running self-diagnostics, an error number is displayed on the integral indicator. If there is more than one error, the error number changes at three-second intervals. See table 4.2.1 regarding the alarm codes.



F0403.EPS

Figure 4.1.2 Integral Indicator

4.2 Alarms and Countermeasures

Table 4.2.1 Alarm Message Summary

| Integral indicator | HART communicator display | Cause | Output operation during error | Countermeasure | Status group |
|--------------------|------------------------------------|--|--|---|--------------|
| AL. 01 CAP. ERR | P sensor error | Sensor problem. | Outputs the signal (High or Low) set with burnout direction switch. [status output: undefined] | Replace capsule when error keep appearing error even after restart. | 1 |
| | CT sensor error | Capsule temperature sensor problem. | | Replace capsule. | |
| | Cap EEPROM error | Capsule EEPROM problem. | | | |
| AL. 02 AMP. ERR | AT sensor error | Amplifier temperature sensor problem. | | Replace amplifier. | 2 |
| | Amp EEPROM error | Amplifier EEPROM problem. | | | |
| | CPU board error | Amplifier problem. | | | |
| — | No device ID | No device ID is found. | Continues to operate and output. | | 2 |
| AL. 10 PRESS | P outside limit | Input is outside measurement range limit of capsule. | Outputs AO upper limit or AO lower limit. | Check input or replace capsule when necessary. | 3 |
| AL. 11 ST. PRSS | SP outside limit | Static pressure exceeds limit. | Continues to operate and output. | | |
| AL. 12 CAP. TMP | CT outside limit | Capsule temperature is outside range (–50 to 130°C). | | Use heat insulation or make lagging to keep temperature within range. | |
| AL. 13 AMP. TMP | AT outside limit | Amplifier temperature is outside range (–50 to 95°C). | | | |
| AL. 30 RANGE | P over range | Output is outside upper or lower range limit value. | Outputs AO upper limit or AO lower limit. | Check input and range setting, and change them as needed. | 4 |
| AL. 31 SP. RNG | SP over range | Static pressure exceeds specified range. | Continues to operate and output. | | 5 |
| AL. 35 P. HI | P high alarm | Input pressure exceeds specified threshold. | | Check input. | |
| AL. 36 P. LO | P low alarm | | | | |
| AL. 37 SP. HI | SP high alarm | Input static pressure exceeds specified threshold. | | | |
| AL. 38 SP. LOW | SP low alarm | | | | |
| AL. 39 TMP. HI | CT high alarm | Detected temperature exceeds specified threshold. | | Check capsule temperature. | |
| AL. 40 TMP. LO | CT low alarm | | | | |
| AL. 50 P. LRV | Illegal P LRV | Specified value is outside of setting range. | Holds output immediately before error occurred. | Check settings and change them as needed. | 6 |
| AL. 51 P. URV | Illegal P URV | | | | |
| AL. 52 P. SPN | Illegal P SPAN | | | | |
| AL. 53 P. ADJ | P SPAN trim err P ZERO trim err | | | | |
| AL. 54 SP. RNG | Illegal SP LRV | | Continues to operate and output holding static pressure in %. | Check settings and change them as needed. | 7 |
| | Illegal SP URV | | | | |
| | Illegal SP SPAN | | | | |
| AL. 55 SP. ADJ | SP SPAN trim err | | Continues to operate and output. | Adjust settings and change them as needed. | 7 |
| | SP ZERO trim err | | | | |
| AL. 60 SC. CFG | SC config error | Specified values or settings do not meet the conditions. | Continues to operate and output without signal characterizing. | Check settings and change them as needed. | — |
| AL. 79 OV. DISP | — | Displayed value exceeds limit. | Continues to operate and output. | | — |

T0401.EPS

Table 4.2.2 HART Communicator Error Messages

| Error message | Probable cause | Countermeasure |
|--|--|---|
| Invalid selection | — | Change the setting. |
| Value was too high | Set value is too high. | |
| Value was too low | Set value is too low. | |
| Too few data bytes received | — | — |
| In write protect mode | Operation is set in the Write Protect mode. | — |
| Lower range value too high | LRV set point is too high. | Change the range. |
| Lower range value too low | LRV set point is too low. | |
| Upper range value too high | URV set point is too high. | |
| Upper range value too low | URV set point is too low. | |
| Span too small | Set span is too small. | |
| Applied process too high | Applied pressure is too high. | Adjust the applied pressure. |
| Applied process too low | Applied pressure is too low. | |
| New lower range value pushed upper range value over upper sensor limit | The shift of URV according to the new LRV setting exceeds USL. | Change the URV setting within the range of USL. |
| Excess correction attempted | Amount of correction is too much. | Adjust the amount. |
| Lowercase conversion not succeeded | Characters are not convertible. e.g. % | Correct the setting. |
| Not in fixed current mode | The fixed current mode is desired but not set in that mode. | Set in the fixed current mode. |
| In multidrop mode | Operation is set in the multi-drop mode. | — |
| Not write protect mode | Operation is set without a password. | — |
| Lower range value and upper range value out of limits | Set value is outside lower or upper range limit. | Change the setting. |

T0402.EPS

5. PARAMETER SUMMARY

| Function | Label | Item | Contents | Default value | Handling | Fast key sequences |
|-------------------------------|--------------------------------------|---|---|--------------------------|------------------|--------------------|
| Analog output | AO alm typ | Analog output alarm type | High or Low | | R | 1, 4, 3, 2, 5 |
| | AO lower limit | Lower limit of analog output | 3.6000 to 21.6000 mA | 3.6000 mA | W | 1, 4, 3, 2, 7 |
| | AO upper limit | Upper limit of analog output | 3.6000 to 21.6000 mA | 21.6000 mA | W | 1, 4, 3, 2, 8 |
| | Auto recover | Auto-recover from hardware error | Off or On | On | W | 1, 4, 3, 2, 6 |
| Analog output trim | Clear D/A trim | Reset analog output trim | | | M | 1, 2, 3, 2, 3 |
| | D/A trim | Analog output trim with ammeter | | | M | 1, 2, 3, 2, 1 |
| | Scaled D/A trim | Analog output trim with voltmeter | | | M | 1, 2, 3, 2, 2 |
| Bi-directional mode | Bi-dir mode | Bi-directional mode | Off or On | Off | W | 1, 4, 2, 9 |
| Burst mode | Burst mode | Burst mode | Off or On | Off | W | 1, 4, 3, 3, 3 |
| Burst operation option | Burst option | Burst option | PV, % range/current, or Process vars/cmt | | W | 1, 4, 3, 3, 4 |
| Damping | Pres Damp | Damping time constant at amplifier | 0.00 to 100.00 sec | As specified or 2.00 sec | W | 1, 3, 6 |
| | Quick resp | Quick response | On or Off | Off | W | 1, 4, 2, ↓ |
| Date | Date | Date | ****/** | | W | 1, 3, 4, 1 |
| Descriptor | Descriptor | Descriptor | 16 alphanumerics | As specified | W | 1, 3, 4, 2 |
| Device information | Dev id | Device ID | | | R | 1, 4, 5, 1, ↓, 6 |
| | Distributor | Yokogawa | | | R | 1, 4, 5, 1, ↓, 7 |
| | Drain vent matl | Drain and vent plug material | | | W | 1, 4, 5, 2, 5 |
| | Extra No. | Customization number | | | R | 1, 4, 5, 1, ↓, 4 |
| | Ext SW | External zeroing permission | Disabled or Enabled | Enabled | W | 1, 4, 5, 1, 9 |
| | Fill fluid | Fill fluid | | | W | 1, 4, 5, 2, 2 |
| | Final asbly num | Final assembly number | | | W | 1, 4, 5, 1, ↓, 5 |
| | Fld dev rev | Field device revision | | | R | 1, 4, 5, 1, ↓, 2 |
| | Gasket matl | Gasket material | | | W | 1, 4, 5, 2, 3 |
| | Isoltr matl | Capsule material | | | W | 1, 4, 5, 2, 1 |
| | LSL | Lower sensor limit | | | R | 1, 3, 3, 1, 4 |
| | Mfr Date | Manufactured date | | | R | 1, 4, 5, 1, ↓, 3 |
| | Min Span | Minimum span | | | R | 1, 3, 3, 1, 6 |
| | Model 1 | Memo field for MS code 1 | 16 alphanumerics | | W | 1, 4, 5, 1, 5 |
| | Model 2 | Memo field for MS code 2 | 16 alphanumerics | | W | 1, 4, 5, 1, 6 |
| | Model 3 | Memo field for MS code 3 | 16 alphanumerics | | W | 1, 4, 5, 1, 7 |
| | Num of RS | Number of remote seal | | | W | 1, 4, 5, 2, 9 |
| | Process Conn matl | Process connection material | | | W | 1, 4, 5, 2, 4 |
| | Process Conn size | Process connection size | | | W | 1, 4, 5, 2, 8 |
| | Process Conn type | Process connection type | | | W | 1, 4, 5, 2, 6 |
| RS fill fluid | Fill fluid of remote seal | | | W | 1, 4, 5, 2, ↓ | |
| RS Isoltr matl | Remote seal material | | | W | 1, 4, 5, 2, 7 | |
| RS type | Remote seal type | | | W | 1, 4, 5, 2, ↓ | |
| Serial No. | Serial number | | | R | 1, 4, 5, 1, ↓, 2 | |
| Software rev | Software revision | | | R | 1, 4, 5, 1, ↓, 3 | |
| Style No. | Style number | Style number of product | | R | 1, 4, 5, 1, ↓, 1 | |
| Universal rev | Universal revision | | | R | 1, 4, 5, 1, ↓, 1 | |
| USL | Upper sensor limit | | | R | 1, 3, 3, 1, 5 | |
| Display setup | Bar indicator | Bar indicator | Off or On | On | W | 1, 4, 4, 5 |
| | Disp Out 1 | LCD output 1 | Pres, Pres %, Engr Pres, SP, or SP % | Pres % | W | 1, 4, 4, 1, 1 |
| | Disp Out 2 | LCD output 2 | Pres, Pres %, Engr Pres, SP, SP %, or Not used | Not used | W | 1, 4, 4, 1, 2 |
| | Disp Out 3 | LCD output 3 | Pres, Pres %, Engr Pres, SP, SP %, or Not used | Not used | W | 1, 4, 4, 1, 3 |
| | Disp Out 4 | LCD output 4 | Pres, Pres %, Engr Pres, SP, SP %, or Not used | Not used | W | 1, 4, 4, 1, 4 |
| | Disp Pres % fnctn | % display mode | Linear or Sq root | As specified or Linear | W | 1, 4, 4, 2, 1 |
| | Disp Pres % Reso | % display resolution | Normal or High resolution | Normal | W | 1, 4, 4, 2, 2 |
| | Engr exp | Exponents | ---, ×10, ×100, or ×1000 | As specified or --- | W | 1, 4, 4, 4, 3 |
| | Engr LRV | User set lower range value | -32000 to 32000, unit specified in Set Engr Unit | As specified | W | 1, 4, 4, 4, 1 |
| | Engr point | Decimal place for user set | 0 to 4 | 2 | W | 1, 4, 4, 4, 5 |
| | Engr URV | User set upper range value | -32000 to 32000, unit specified in Set Engr Unit | As specified | W | 1, 4, 4, 4, 2 |
| | Modify Engr Unit | User set engineering unit | | As specified | M | 1, 4, 4, 4, 7 |
| Pres disp point | Decimal place for pressure | 0 to 4 | 2 | W | 1, 4, 4, 2, 3 | |
| Set Engr Unit | Engineering unit select | See section 3.5.3d | | M | 1, 4, 4, 4, 6 | |
| SP disp point | Decimal place for static pressure | 0 to 4 | 2 | WD | 1, 4, 4, 3, 1 | |
| Error log | Error log Clear | Clear error records | | | M | 1, 2, 4, 2 |
| | Error log view | Error records | Log1 (latest) to log4 | | M | 1, 2, 4, 1 |
| Loop test | Loop test | Test output setting | Within AO lower and upper limits | | M | 1, 2, 2 |
| Low cut | Low cut | Low cut | 0.00 to 20.00% | 10.00% | W | 1, 3, 7 |
| | Low cut mode | Low cut mode | Linear or Zero | Linear | W | 1, 3, 8 |
| Message | Message | Message | 32 alphanumerics | As specified | W | 1, 3, 4, 3 |
| Number of requested preambles | Num req preams | Number of requested preambles | | | R | 1, 4, 3, 3, 2 |
| Piping orientation | H/L Swap | Impulse piping accessing direction | Normal or Reverse | Normal | WD | 1, 3, 9 |
| Poll address | Poll addr | Poll address for multidrop use | 0 to 15 | 0 | W | 1, 4, 3, 3, 1 |
| Process Alert | Digital Output | Display of contact output | Off or On | Off | RA | 1, 4, 3, 4, 7, 1 |
| | DO Select | Contact output select | Off, P Alarm, SP Alarm, P or SP Alarm | Off | WA | 1, 4, 3, 4, 7, 2 |
| | DO Signal type | Signal type select | On When AI Detect or Off When AI Detect | On When AI Detect | WA | 1, 4, 3, 4, 7, 3 |
| | DO Test | Test output contact | Off, On, or Exit | MA | 1, 4, 3, 4, 7, 4 | |
| | Hi Alert Val | High side alert value of pressure | LSL-10% to USL+10% minus 5% hysteresis | W | 1, 4, 3, 4, 2, 1 | |
| | Lo Alert Val | Low side alert value of pressure | LSL-10% to USL+10% plus 5% hysteresis | W | 1, 4, 3, 4, 2, 2 | |
| | Pres Alert mode | Alert mode for pressure | Off, Hi AI Detect, Lo AI Detect, or Hi/Lo AI Detect | Off | WD | 1, 4, 3, 4, 1 |
| | SP Alert mode | Alert mode for static pressure | Off, Hi AI Detect, Lo AI Detect, or Hi/Lo AI Detect | Off | WD | 1, 4, 3, 4, 3 |
| | SP Hi Alert Val | High side alert value of static pressure | SP LSL-10% to SP USL+10% minus 5% hysteresis | WD | 1, 4, 3, 4, 4, 1 | |
| | SP Lo Alert Val | Low side alert value of static pressure | SP LSL-10% to SP USL+10% plus 5% hysteresis | WD | 1, 4, 3, 4, 4, 2 | |
| Temp Alert mode | Alert mode for temperature | Off, Hi AI Detect, Lo AI Detect, or Hi/Lo AI Detect | Off | W | 1, 4, 3, 4, 5 | |
| Temp Hi Alert Val | High side alert value of temperature | -50 to 130 | 120 degC | W | 1, 4, 3, 4, 6, 1 | |
| Temp Lo Alert Val | Low side alert value of temperature | -50 to 130 | -40 degC | W | 1, 4, 3, 4, 6, 2 | |

*1: Handling: R=Read only, W=Read & Write, M=Method, A=Applicable for option code AL, D=Applicable for differential pressure transmitters. Do not change these parameters for pressure transmitters.

T0501.EPS

5. PARAMETER SUMMARY

| Function | Label | Item | Contents | Default value | Handling | Fast key sequences |
|--------------------------|--------------------|---|--|------------------------|---------------|------------------------|
| Process variables | AO | Analog output current | 3.6000 to 21.6000 mA | | R | 1, 1, 3 |
| | Engr Disp | User scaled value | -32000 to 32000, unit specified in Set Engr Unit | | R | 1, 1, 7 |
| | Engr Unit | User set engineering unit | Unit specified in Set Engr Unit | | R | 1, 1, 9 |
| | Pres | Measured pressure | -32000 to 32000, unit specified in Unit | | R | 1, 1, 1 |
| | Pres % | Measured pressure in % | -2.50 to 110.00% | | R | 1, 1, 2 |
| | Snsr temp | Capsule temperature | Unit specified in Temp Unit | | R | 1, 1, 6 |
| SP | SP | Measured static pressure | -32000 to 32000, unit specified in SP Unit | | RD | 1, 1, 4 |
| | SP % | Measured static pressure in % | -10.0 to 110.00% | | RD | 1, 1, 5 |
| Rerange | Apply values | Rerange for measured pressure | 4 mA, 20 mA, or Exit | | M | 1, 3, 3, 2 |
| | LRV | Lower range value | -32000 to 32000 within measurement range | As specified | W | 1, 3, 3, 1, 1 |
| | URV | Upper range value | -32000 to 32000 within measurement range | As specified | W | 1, 3, 3, 1, 2 |
| Self test | Self test | Self-diagnostics | See Chapter 4 | | M | 1, 2, 1, 2 |
| Sensor trim | Clear P snsr trim | Reset pressure trim to factory setting | | | M | 1, 2, 3, 3, 5, 3 |
| | Clear SP snsr trim | Reset SP trim to factory setting | | | MD | 1, 2, 3, 4, 4, 3 |
| | P LTD | Lower pressure trim deviation | | | R | 1, 2, 3, 3, 5, 1 |
| | P LTP | Lower temperature trim point | | | R | 1, 2, 3, 3, 3 |
| | P.UTD | Upper pressure trim deviation | | | R | 1, 2, 3, 3, 5, 2 |
| | P UTP | Upper temperature trim point | | | R | 1, 2, 3, 3, 4 |
| | Pres trim | Pressure trim | | | M | 1, 2, 3, 3, 2 |
| | Pres Zero trim | Zeroing | | | M | 1, 2, 3, 3, 1 |
| | SP LTD | Lower SP trim deviation | | | RD | 1, 2, 3, 4, 4, 1 |
| | SP LTP | Lower SP trim point | | | RD | 1, 2, 3, 4, 2 |
| | SP UTD | Upper SP trim deviation | | | RD | 1, 2, 3, 4, 4, 2 |
| | SP UTP | Upper SP trim point | | | RD | 1, 2, 3, 4, 3 |
| | Static Pres trim | Static pressure trim | | | MD | 1, 2, 3, 4, 1 |
| | Trim Date | Trim information | ***j** | | W | 1, 2, 3, 5, 2 |
| Trim Desc | Trim information | 16 alphanumerics | | W | 1, 2, 3, 5, 4 | |
| Trim Loc | Trim information | 8 alphanumerics | | W | 1, 2, 3, 5, 3 | |
| Trim Who | Trim information | 8 alphanumerics | | W | 1, 2, 3, 5, 1 | |
| Signal characterizer | Num of points | Number of coordinates | 0 to 9 | 9 | W | 1, 4, 2, ↓, 2 |
| | Point setting | Coordinates editor | | | M | 1, 4, 2, ↓, 3 |
| | S.C. | Signal characterizer permission | Disabled or Enabled | Disabled | W | 1, 4, 2, ↓, 1 |
| | X End | End point of X | 100.00% | | R | 1, 4, 2, ↓, 6 |
| | X Start | Start point of X | 0.00% | | R | 1, 4, 2, ↓, 4 |
| | Y End | End point of Y | 100.00% | | R | 1, 4, 2, ↓, 7 |
| | Y Start | Start point of Y | 0.00% | | R | 1, 4, 2, ↓, 5 |
| Static pressure setup | A/G Select | Gauge/abs select for static pressure | Gauge or Absolute | Absolute | WD | 1, 4, 1, 2, 7, 4, 1 |
| | Atm. Pres value | Conversion coefficient | | 101.3 kPa | WD | 1, 4, 1, 2, 7, 4, 2 |
| | SP H/L Select | H/L select for static pressure | High or Low | High | WD | 1, 4, 1, 2, 7, 5 |
| | SP Apply values | Rerange for static pressure | "0%, 100%, or Exit" | | MD | 1, 4, 1, 2, 7, 1, 2 |
| | SP Damp | Damping time constant for SP | 0.00 to 100.00 sec | 2.00 sec | WD | 1, 4, 1, 2, 7, 3 |
| | SP LRV | Lower range value for static pressure | -32000 to 32000 within measurement range | 0.0 MPa | WD | 1, 4, 1, 2, 7, 1, 1, 1 |
| | SP LSL | Lower sensor limit for static pressure | | | RD | 1, 4, 1, 2, 7, 1, 1, 4 |
| | SP Min Span | Minimum span for static pressure | | | RD | 1, 4, 1, 2, 7, 1, 1, 6 |
| | SP URV | Upper range value for static pressure*2 | -32000 to 32000 within measurement range | | WD | 1, 4, 1, 2, 7, 1, 1, 2 |
| | SP USL | Upper sensor limit for static pressure | | | RD | 1, 4, 1, 2, 7, 1, 1, 5 |
| Status | Status group 1 | Device status information for hardware | | | R | 1, 2, 1, 1, 1 |
| | Status group 2 | Device status information for hardware | | | R | 1, 2, 1, 1, 2 |
| | Status group 3 | Device status information for process | | | R | 1, 2, 1, 1, 3 |
| | Status group 4 | Device status information for process | | | R | 1, 2, 1, 1, 4 |
| | Status group 5 | Device status information for process | | | R | 1, 2, 1, 1, 5 |
| | Status group 6 | Device status information for settings | | | R | 1, 2, 1, 1, 6 |
| | Status group 7 | Device status information for settings | | | R | 1, 2, 1, 1, 7 |
| Tag | Tag | Tag number | 8 alphanumerics | As specified | W | 1, 3, 1 |
| Temperature compensation | T.Z. Cmp mode | Temperature compensation mode | Off or On | Off | W | 1, 4, 2, ↓, 1 |
| | Temp Zero | Zero shift compensation | -99.999 to 99.999%/degC | 0.000%/degC | W | 1, 4, 2, ↓, 2 |
| Temperature sensor | Amp temp | Amplifier temperature | | | R | 1, 4, 1, 3, 2 |
| | Snsr temp | Capsule temperature | | | R | 1, 4, 1, 3, 1 |
| | Temp Unit | Temperature setting unit | degC, degF, or Kelvin | degC | W | 1, 4, 1, 3, 3 |
| Test key | Test Key | Special maintenance parameter | | | M | 1, 4, 6 |
| Transfer function | Xfer frctn | Output mode | Linear or Sq root | As specified or Linear | W | 1, 3, 5 |
| Unit | Unit | Measurement range unit | See section 3.4.2 | As specified or kPa | W | 1, 3, 2 |
| | SP Unit | Static pressure unit | See section 3.5.5 | MPa | WD | 1, 4, 1, 2, 3 |
| Write protect menu | Enable wrt 10min | Write protect release | 8 alphanumerics | | M | Hot key, 2, 2 |
| | New password | User set password for write protect | 8 alphanumerics | | M | Hot key, 2, 3 |
| | Software seal | Software seal | Keep or Break | Keep | R | Hot key, 2, 4 |
| | Write protect | Write protect indicator | Yes or No | No | R | Hot key, 2, 1 |

T0502.EPS

*1: Handling: **R**=Read only, **W**=Read & Write, **M**=Method, **A**=Applicable for option code AL, **D**=Applicable for differential pressure transmitters. Do not change these parameters for pressure transmitters.

*2: The default value shows MWP (Maximum working pressure) of the capsule.

Since the working pressure limit varies according to the Model, refer to the General Specifications section in each user's manual.

APPENDIX 1. SAFETY INSTRUMENTED SYSTEMS INSTALLATION



WARNING

The contents of this appendix are cited from exida.com safety manual on the EJX series pressure transmitters specifically observed for the safety transmitter purpose. When using the EJX for Safety Instrumented Systems (SIS) application, the instructions and procedures in this section must be strictly followed in order to preserve the transmitter for that safety level.

A1.1 Scope and Purpose

This section provides an overview of the user responsibilities for installation and operation of the EJX in order to maintain the designed safety level for Safety Instrumented Systems (SIS) applications. Items that will be addressed are proof testing, repair and replacement of the transmitter, reliability data, lifetime, environmental and application limits, and parameter settings.

A1.2 Using the EJX for an SIS Application

A1.2.1 Safety Accuracy

The EJX has a specified safety accuracy of 2%. This means that the internal component failures are listed in the device failure rate if they will cause an error of 2% or greater.

A1.2.2 Diagnostic Response Time

The EJX will report an internal failure within 5 seconds of the fault occurrence.

A1.2.3 Setup

During installation the transmitter must be setup with engineering units parameters. This is typically done with a handheld terminal. These parameters must be verified during the installation to insure that the correct parameters are in the transmitter. Engineering range parameters can be verified by reading these parameters from the optional local display or by checking actual calibration of the transmitter.

The calibration of the transmitter must be performed after parameters are set.

A1.2.4 Required Parameter Settings

The following parameters need to be set in order to maintain the designed safety integrity.

Table A1.2.4 Required Parameter Settings

| Item | Description |
|--------------------------|--|
| Burnout direction switch | To specify if the output should go 21.6 mA or higher or 3.6 mA or lower upon detection of an internal failure. |
| Write protection switch | The write function should be disabled. |

TA0101.EPS

A1.2.5 Proof Testing

The objective of proof testing is to detect failures within the transmitter that are not detected by the diagnostics of the transmitter. Of main concern are undetected failures that prevent the safety instrumented function from performing its intended function. See table A1.2.5 for proof testing method.

The frequency of the proof tests (or the proof test interval) is to be determined in the reliability calculations for the safety instrumented functions for which the EJX is applied. The actual proof tests must be performed more frequently or as frequently as specified in the calculation in order to maintain required safety integrity of the safety instrumented function.

The following tests need to be specifically executed when a proof test is performed. The results of the proof test need to be documented and this documentation should be part of a plant safety management system. Failures that are detected should be reported to Yokogawa.

The personnel performing the proof test of the transmitter should be trained in SIS operations including bypass procedures, EJX transmitter maintenance, and company management of change procedures.

Table A1.2.5 Proof Testing

| Testing method | Tools required | Expected outcome | Remarks |
|---|---|--------------------------|--|
| Functional test: 1. Follow all Management of Change procedures to bypass logic solvers if necessary. 2. Execute HART/BRAIN command to send value to high alarm (21.5 mA) and verify that current has reached this level. 3. Execute HART/BRAIN command to send value to low alarm (3.6 mA) and verify that current has reached this level. 4. Restore logic solvers operation and verify. | <ul style="list-style-type: none"> • Handheld terminal | Proof Test Coverage =52% | The output needs to be monitored to assure that the transmitter communicates the correct signal. |
| Perform three point calibration along with the functional test listed above. | <ul style="list-style-type: none"> • Handheld terminal • Calibrated pressure source | Proof Test Coverage =99% | |

TA0102.EPS

A1.2.6 Repair and Replacement

If repair is to be performed with the process online the EJX will need to be bypassed during the repair. The user should setup appropriate bypass procedures.

In the unlikely event that the EJX has a failure, the failures that are detected should be reported to Yokogawa.

When replacing the EJX, the procedure in the installation manual should be followed.

The personnel performing the repair or replacement of the EJX should have a sufficient skill level.

A1.2.7 Startup Time

The EJX generates a valid signal within 1 second of power-on startup.

A1.2.8 Firmware Update

In case firmware updates are required, they will be performed at factory. The replacement responsibilities are then in place. The user will not be required to perform any firmware updates.

A1.2.9 Reliability Data

A detailed Failure Mode, Effects, and Diagnostics Analysis (FMEDA) report is available from Yokogawa with all failure rates and failure modes.

The EJX is certified up to SIL2 for use in a simplex (1oo1) configuration, depending on the PFDavg calculation of the entire Safety Instrumented Function.

The development process of the EJX is certified up to SIL3, allowing redundant use of the transmitter up to this Safety Integrity Level, depending the PFDavg calculation of the entire Safety Instrumented Function.

When using the transmitter in a redundant configuration, the use of a common cause factor (β -factor) of 2% is suggested. (However, if the redundant transmitters share an impulse line or if clogging of the separate impulse lines is likely, a common cause factor of 10% is suggested.)

Note that the failure rates of the impulse lines need to be accounted for in the PFDavg calculation.

A1.2.10 Lifetime Limits

The expected lifetime of the EJX is 50 years. The reliability data listed the FMEDA report is only valid for this period. The failure rates of the EJX may increase sometime after this period. Reliability calculations based on the data listed in the FMEDA report for EJX lifetimes beyond 50 years may yield results that are too optimistic, i.e. the calculated Safety Integrity Level will not be achieved.

A1.2.11 Environmental Limits

The environmental limits of the EJX are specified in the user’s manual IM 01C25.

A1.2.12 Application Limits

The application limits of the EJX are specified in the user’s manual IM 01C25. If the transmitter is used outside of the application limits, the reliability data listed in A1.2.9 becomes invalid.

A1.3 Definitions and Abbreviations

A1.3.1 Definitions

| | |
|-------------------|---|
| Safety | Freedom from unacceptable risk of harm |
| Functional Safety | The ability of a system to carry out the actions necessary to achieve or to maintain a defined safe state for the equipment/ machinery/plant/apparatus under control of the system |
| Basic Safety | The equipment must be designed and manufactured such that it protects against risk of damage to persons by electrical shock and other hazards and against resulting fire and explosion. The protection must be effective under all conditions of the nominal operation and under single fault condition |
| Verification | The demonstration for each phase of the life-cycle that the (output) deliverables of the phase meet the objectives and requirements specified by the inputs to the phase. The verification is usually executed by analysis and/or testing |
| Validation | The demonstration that the safety-related system(s) or the combination of safety-related system(s) and external risk reduction facilities meet, in all respects, the Safety Requirements Specification. The validation is usually executed by testing |

Safety Assessment The investigation to arrive at a judgment -based on evidence- of the safety achieved by safety-related systems

Further definitions of terms used for safety techniques and measures and the description of safety related systems are given in IEC 61508-4.

A1.3.2 Abbreviations

| | |
|-------|---|
| FMEDA | Failure Mode, Effects and Diagnostic Analysis |
| SIF | Safety Instrumented Function |
| SIL | Safety Integrity Level |
| SIS | Safety Instrumented System |
| SLC | Safety Lifecycle |

REVISION RECORD

Title: EJX Series HART Communication Type
Manual No.: IM 01C25T01-01E

| Edition | Date | Page | Revised Item |
|---------|-----------|-----------|---|
| 1st | Mar. 2004 | – | New publication |
| 2nd | Apr. 2004 | – 3-26 | Revise words and phrases 3.5.16 • Add section 3.5.16 Status Output |
| 3rd | Oct. 2004 | 3-27 | 3.5.17 • Add section 3.5.17 Capillary fill fluid density compensation |
| | | | |