

ECM2 Control Platform Ethernet Control Module™ User Manual AS01023G-01



Controls Product Group
134 W. Rio Robles Drive
San Jose, CA 95134

Main: 408.750.0300
Fax: 408.750.2990

Copyright

This manual and the software described therein are copyrighted with all rights reserved. Under copyright laws, this manual and software may not be copied, in whole or part, without the prior written consent of MKS Instruments. The same proprietary and copyright notices must be affixed to any permitted copies as were affixed to the original. This exception does not allow copies to be made for others whether or not sold, but all of the materials purchased may be sold, given, or loaned to another person. Under the law, copying includes translating into another language or format.

© MKS Instruments - Controls Product Group, 2012

134 W. Rio Robles Drive
San Jose, CA 95134

Export Regulation

MKS Products provided subject to the US Export Regulations. Diversion or transfer contrary to U.S. law is prohibited.

Preface

About this manual

This manual is designed to serve as a guideline for the installation, setup, operation and basic maintenance of the ECM2 Control Platform. The information contained within this manual, including product specifications, is subject to change without notice. Observe all safety precautions and use appropriate procedures when handling the ECM2 product and its related software.

Technology protected by U.S. patent numbers 7,620,516 and 6,993,404.

Table of Contents

Revision History	5
1 General Information	6
1.1 CONVENTIONS USED IN THIS USER MANUAL	6
2 Hardware Description & Setup	7
2.1 HARDWARE DESCRIPTION	7
2.2 PHYSICAL SPECIFICATIONS	7
2.3 TOP VIEW	12
2.4 CONNECTORS	12
2.4.1 <i>Power Connectors</i>	12
2.4.2 <i>IO Connectors</i>	13
2.4.3 <i>Interlock-IN Connectors</i>	21
2.4.4 <i>Interlock-OUT Connectors</i>	23
2.4.5 <i>Other Connectors</i>	25
2.5 LCD	26
2.6 LED's	26
2.7 SWITCHES	27
2.8 DIAGNOSTIC CONSOLE SERIAL	29
2.8.1 <i>Connecting via a Diagnostic Console Serial</i>	29
2.8.2 <i>RS232 Serial Communication Ports</i>	30
3 Quick Start	32
3.1 NETWORK CONFIGURATION	32
3.2 CONNECTING TO A COMPUTER VIA TCP/IP AND OVER THE CONSOLE PORT AND PREPARING TO BOOT THE ECM2	32
3.2.1 <i>LCD Power Start up Sequence</i>	32
3.3 CHANGING THE IP ADDRESS FOR THE UNIT	36
3.3.1 <i>IEC Start Up Rotary Switch Setting</i>	37
3.4 SETTING THE UNIT DATE	38
3.5 SETTING THE UNIT TIME	39
3.6 TROUBLESHOOTING NETWORK CONFIGURATION	40
4 DeviceNet Master Capabilities	41
4.1 FIRST-TIME SETUP OF DEVICENET NETWORKS OR ADDING ADDITIONAL DEVICENET NETWORKS	41
4.1.1 <i>Deleting the DeviceNet config file</i>	42
4.2 DEVICENET MASTER DIAGNOSTICS AND INFORMATION	42
4.3 DEVICENET MASTER DETECTION MECHANISM	42
4.4 SCANNING THE DEVICENET NETWORK NODES	43
4.5 IO MAPPING FOR SLAVE/NODE DEVICES	43
5 IEC61131-3 Compliant Programming Interface	45
5.1 SOFTWARE REQUIREMENTS	45
5.1.1 <i>Configuration</i>	52
5.1.2 <i>IEC LED status</i>	52
6 Tutorial - Creating a Multiprog Project	54
6.1 WRITING IEC CODE AND COMPILING AND DOWNLOADING TO UNIT	68
6.1.1 <i>Compiling</i>	73
6.1.2 <i>KW Multiprog Project Control and Download</i>	76
6.1.3 <i>MKS Firmware Library</i>	81

7	Programmable Interlocks	86
7.1	OVERVIEW	86
7.2	MAIN FEATURES	86
7.3	OPERATION DESCRIPTION	86
7.3.1	<i>Prog/Debug Mode</i>	87
7.3.2	<i>Operational Mode</i>	88
7.3.3	<i>Debounce on the Inputs</i>	88
7.4	INTERLOCK STATUS BIT MAP TABLE	90
7.5	INTERLOCK OUTPUT LOGIC	92
7.6	VISIM TOOL FOR INTERLOCK OUTPUT LOGIC COMMISSIONING	92
7.6.1	<i>Installation</i>	93
7.7	TUTORIAL – CREATING A LOGIC FILE USING VISIM	95
7.7.1	<i>Create New File</i>	95
7.7.2	<i>I/O Map File</i>	95
7.7.3	<i>Edit the Visio File</i>	95
7.7.4	<i>Draw The Logic</i>	96
7.7.5	<i>Assign Inputs and Output</i>	97
7.7.6	<i>Generate CSV (Coma-Separated Value) File</i>	100
7.7.7	<i>Logic example</i>	103
7.7.8	<i>The Default CSV File</i>	103
7.7.9	<i>Simulate the Design</i>	103
7.8	LOGIC STRUCTURE	105
7.8.1	<i>Combined AND/OR Logic Term</i>	105
7.8.2	<i>Latch Structure</i>	106
7.8.3	<i>Download the Logic to ECM2</i>	107
7.8.1	<i>Troubleshooting</i>	110
7.9	MAINTENANCE AND SAFETY	110
7.9.1	<i>System Periodic Test/Monitoring</i>	110
7.9.2	<i>Self-Test</i>	110
7.9.3	<i>User Relay Diagnostic Test</i>	111
7.9.4	<i>Proof Test</i>	111
8	WARRANTY	115
	Appendix A: Troubleshooting	116
	Appendix B: Available Shell Commands	118
	AVAILABLE COMMANDS BY OS DESIGN:	121

Revision History

Revision	Description of changes	Date
0.9	First Release	03/27/2012
1.0	Final Release, with "Arrow First Release" image	04/20/2012
1.5	Update per SW release 1.5	06/21/2012

Revision method:
Rev X.Y

X = 'major revision' - Any change that affects functional safety shall affect this numeral and will require re-assessment by the certification body

Y = 'minor' revision' - Any change that does not affect functional safety should be recorded by this numeral which will not require re-assessment by the certification body

1 General Information

The ECM2 is a control platform that provides an integrated solution with I/O, interlock, and signal distribution/conditioning in a compact, low cost package. The unit can be implemented as a complete control platform for a single location or tool or for a complete manufacturing line. The ECM2 can be used to manage all required tool control needs: handles detailed execution tasks using common programming languages including C and IEC-61131-3 (such as ladder logic, structure text, sequential function chart....) to run certified programmable safety interlocks.

There are multiple control and data monitoring interfaces for the ECM2:

- Modbus/TCP (supported in the future)
- DeviceNet™ Slave (supported in the future) as well as Master(s) via external module(s)
- EtherCAT™ Slave and Master. (supported in the future)
- Profibus™ DP (supported in the future)

1.1 Conventions used in this User Manual



Warning The **WARNING** sign denotes a hazard to personnel. It calls attention to a procedure, practice, condition, or the like, which, if not correctly performed or adhered to, could result in injury to personnel.



Caution The **CAUTION** sign highlights information that is important to the safe operation of the ECM2, or to the integrity of your files. .



Note The **NOTE** sign denotes important information. It calls attention to a procedure, practice, condition, or the like, which is essential to highlight.

On screen buttons or menu items appear in bold and italics.

Example: Click ***OK*** to save the settings.

Keyboard keys appear in brackets.

Example: [ENTER] and [CTRL]

Pages with additional information about a specific topic are cross-referenced within the text.

Example: (See page xxx)

2 Hardware Description & Setup

This section describes the ECM2 hardware setup and the interface with the Ethernet network, Modbus/TCP, Profibus™, DeviceNet™, EtherCAT™.

2.1 Hardware Description

The ECM2 provides the following interfaces.

- I/O Capability
 - Digital (210) or up to 354 with expansion cards
 - Analog In (32 differential)
 - Analog Out (16 single-ended with offset)
 - 48 interlock digital inputs (24V) + 1 Watch Dog Input (TTL).
 - Support 32 Interlock functions.
 - 4 Serial Ports (RS232) (1 dedicated Serial Monitor, 3 Serial)
- KW Multiprog software with IEC61131-3 compliant development environment for IEC programming capabilities
- LCD for IP address display
- Network Status LEDs
- IP Address Switches



This user manual is based on general market configuration and SW at the time of this writing. Customer's specific configuration, layout, IO counts and functional features might differ. Please contact MKS for specific feature and information on customized ECM2 products.

2.2 Physical Specifications

Criteria	Specifications
Dimensions	2U(h) x 13"(w) x 10"(d)
Ethernet Connector	100 BaseT auto-software switched
RS-232 Connector	TXD, RXD; DB9 connector
Material chassis	Plate/chromate
Material front	Paint black
Cooling	Internal Fan

Environmental Specifications

Criteria	Specifications
Operating Temperature	0 to +45°C
Storage	-40 to +85°C
Humidity	5 to 95% non-condensing
Altitude	Up to 2000 meters
MTBF minimum	>10 years @ 80% confidence level (87K Hours @ 80% confidence level)

Communication Protocol Specifications

Protocols Supported	Master	Slave
Modbus/TCP	Coming soon	Coming soon
DeviceNet™	Yes	Coming soon
EtherCAT™	Coming soon	Coming Soon
Profibus	Coming soon	Coming soon

Power Input Specifications

General		
Main Power Supply Power Consumption	18VDC – 30VDC Typical – 1.2Amp Max – 10Amp	
Power Supply Analog Power Consumption	±15V @ ±1% Max – 6.7Amp	Internally limited.

Fuse Status Detection and Power Measurements

Fuse detection		
	4 Fuses: 1. 24V_PWR_1 2. 24V_PWR_2 3. 24V_PWR_3 4. 24V_FUSED	Can be expanded to up to 48 by different distribution board design. Fuses are reported as pass or fail to the application software.
Fuse detection Thresholds	17V for the 24V powers 12.5V for 15V powers.	Fuses are resettable. A power down of 5 minutes is required.
Powers measurements		
	1. 24V_Main 2. +15V 3. -15V	High and low limits for each power are configurable via application software. Power measurements are reported to the application SOFTWARE and compared against the predefined limits.
Power measurements resolution	10 bits	

Input/Output Specifications

Digital Input		
Number of Inputs	210 up to 354 with expansion board	shared with outputs, each functions as I/O
Sink Input Current Input Low Voltage range(ON) Input High Voltage range(OFF)	Max -2.2mA at $V_{in}=0V$ Min 0V to Max 9.2V Min 9.9V to Max 24V	
Source Input Current Input High Voltage range(ON) Input Low Voltage range(OFF)	Max 2.35mA at $V_{in}=24V$ Min 12.5V to Max 24V Min 0V to Max 11.7V	
Debounce filter	0 msec to 999 msec	1 msec resolution,
Isolation	2.5KVrms	
DI refresh rate	1msec	
Digital Output		
Number of Outputs	210, up to 354 with expansion boards	shared with inputs, each functions as I/O
Output Type	Open collector	Pull up value – 10K
Output Drive Current	200 mA per output, maximum 750 mA per 6 outputs	Sinked/sourced from 24VDC
Sink: Output High Voltage Output Low Voltage	Min 23.7V @ 0.16mA Max 0.3V @200mA	Pull up value-10K

ECM2 User Manual Rev. 1.5

Source: Output High Voltage Output Low Voltage	Min 23.7V @ 200mA Max 0V @ 0μA	Pull down value-10K
Isolation	2.5KVrms	
Max update rate	1msec	
EMC Protections	± 2kv (Immunity to EFT/Burst)	EN60490-1 EN61000-4-2
Current Protection: Each channel	~1.5A	DO driver internal Current limit.
Total	~10A	Current limit circuit
Polarity	Sink / Source , HW selectable per 16 IOs for DIO 0-185, per 2 IOs for DIO186-207, per 1 IO for DIO208,209.	

Analog Input		
Number of Inputs Differential	32	
Resolution ±10V	16 Bit	
Accuracy Differential ±10V	0.05 % FS (10V)	For 0.05% periodic calibration is needed
Input DC resistance	0.4MΩ (Diff) 0.2M (Single ended)	Pull Down Res
-3db filter frequency	0.76kHz	Calculated as $f = 1/2\pi RC$
EMC Protections	Clamping diodes to ± 15V	
Isolation	No Isolation	Same Net, different planes For Analog and Digital part

Analog Output		
Number of Outputs Single-ended with offset	16	
Resolution Range $\pm 10V$	16 Bit	
Accuracy Range $\pm 10V$	0.03 % (3mv) FS (10V) (required 0.1%)	
Output Drive Current	10mA per output, (Capacitive load max 1nF)	
EMC Protection	$\pm 2kv$ (Immunity to EFT/Burst)	EN60490-1 EN61000-4-2
Isolation	No Isolation	

Programmable Interlocks		
Certification	SIL3	Redundant PLD design, Implement 1 out of 2 programmable logic architecture
Inputs	48 1 (for watchdog function)	Active high or low contact inputs, jumper selectable in groups of 12
Output Relays	32 dry contact type N.O.	32 are monitored
Output current		
Standard Output	2A	Software monitored
High power	16A	
Modes of operation	Run / Prog	Run- normal operation mode. Prog - Load the Interlock Logic and Access special FPGA registers for debug

2.3 Top view




Figure 2-1 Top View of AS01023G-01

2.4 Connectors

2.4.1 Power Connectors

ECM2 is powered by a single 24VDC source. I/O is internally powered.

Table 2-1 Power Pinouts and Fuse Ratings

J1 -1	J1-2	J1-3	Current limit protection circuit
+24V	Chassis GND	GND	10Amp

Mating connector for power connector

Mftg PN	Manufacturer	Description
350689-1	AMP/Tyco	Socket crimping type
350766-1	AMP/Tyco	3 circuit plug

2.4.2 IO Connectors

2.4.2.1 Combo (Mixed) Input/Output 37 Pin D-SUB Connector

The analog interface provides 16 single-ended with offset outputs and 32 differential analog inputs (or 64 single-ended analog inputs).

NOTE: Currently ECM2 only supports differential analog inputs. Single-ended analog outputs from user can be connected to the differential input on ECM2 using the same differential pair




Figure 2-2 Analog Inputs




Figure 2-3 Analog Outputs

Table 2-2 Analog Voltage 2's complement Conversion for 16 bits A/D

Analog Value(V)	DEC	HEX
+10	32767	0x7FFF
+9	29491	0x7333
+8	26214	0x6666
+7	22937	0x5999
+6	19660	0x4CCC
+5	16383	0x3FFF
+4	13107	0x3333

+3	9830	0x2666
+2	6553	0x1999
+1	3276	0x0CCC
0	0	0x0000
-1	62259	0xF333
-2	58982	0XE666
-3	55705	0XD999
-4	52428	0xC CCC
-5	49152	0xC000
-6	45875	0xB333
-7	42598	0xA666
-8	39321	0x9999
-9	36044	0x8CCC
-10	32768	0x8000

Table 2-3 - 37 Pin D-SUB Combo I/O Legend

AI	Analog Input
AO	Analog Output
DIO	Digital Input Output
AGND	Analog Ground
AGND_E	External Analog Ground
GND	Ground

Notes:

For differential analog inputs:

AI0, AI2, AI4....AI62 = AI_Positive

AI1, AI3, AI5....AI63 = AI_Negative

Same pair order must be used for differential: AI0/AI1, AI2/AI3.....AI62/AI63




Figure 2-4 Combo Connector Pinouts
Connectors: J8, J9, J10, J11, J12

Table 2-4 – COMBO (MIXED) I/O - DSUB 37 Pin Assignments

Connector:	J8	J9	J10	J11	J12
Pin #					
1	+15V DC	+15V DC	+15V DC	+15V DC	+15V DC
2	AO1-	AO5-	AO9-	AGND_E	AGND_E
3	AO1+	AO5+	AO9+	AGND_E	AGND_E
4	AO0-	AO4-	AO8-	AO12-	AO14-
5	AO0+	AO4+	AO8+	AO12+	AO14+
6	AGND_E	AGND_E	AGND_E	AGND_E	AGND_E
7	AGND	AGND	AGND	AGND	AGND
8	AI5	AI17	AI29	AI41	AI55
9	AI4	AI16	AI28	AI40	AI54
10	AGND	AGND	AGND	AGND	AGND
11	AI3	AI15	AI27	AI39	AI53
12	AI2	AI14	AI26	AI38	AI52
13	AI1	AI13	AI25	AI37	AI51
14	AI0	AI12	AI24	AI36	AI50
15	24_GND	24_GND	24_GND	24_GND	24_GND
16	DIO184	DIO190	DIO196	DIO202	NC
17	DIO183	DIO189	DIO195	DIO201	DIO207
18	DIO182	DIO188	DIO194	DIO200	DIO206
19	24VDC	24VDC	24VDC	24VDC	24VDC
20	-15V DC	-15V DC	-15V DC	-15V DC	-15V DC
21	AO3-	AO7-	AO11-	AO13-	AO15-
22	AO3+	AO7+	AO11+	AO13+	AO15+
23	AO2-	AO6-	AO10-	AI49	AI63
24	AO2+	AO6+	AO10+	AI48	AI62
25	AGND	AGND	AGND	AGND	AGND
26	AI11	AI23	AI35	AI47	AI61
27	AI10	AI22	AI34	AI46	AI60
28	AI9	AI21	AI33	AI45	AI59
29	AGND	AGND	AGND	AGND	AGND
30	AI8	AI20	AI32	AI44	AI58
31	AI7	AI19	AI31	AI43	AI57
32	AI6	AI18	AI30	AI42	AI56
33	24_GND	24_GND	24_GND	24_GND	24_GND
34	DIO187	DIO193	DIO199	DIO205	NC
35	DIO186	DIO192	DIO198	DIO204	DIO209
36	DIO185	DIO191	DIO197	DIO203	DIO208
37	24VDC	24VDC	24VDC	24VDC	24VDC

2.4.2.2 Digital Input/Output

Connectors J13-J19 provide 210 digital I/O points. DIO 0-108 are direct IO. DIO 109-209 are only enabled through completion of an interlock chain. DIOs through expansion board 210-354 are also always enabled (direct IO) Any IO point can be used as either an input or an output. DIDO points can be used as output in conjunction with interlocked logic. If the interlock string for that DO driver is not satisfied, the DO point will not operate and stay off.

NOTE: Interlock outputs 0-16 each enables DIDO driver 17-31 (six DIDOs per driver). If the interlock logic is not satisfied, the DIDO associated for that driver will not be enabled.




Figure 2-5 High level Interconnect for DIDO and Interlock




Figure 2-6 Combo Connector Pinouts
Connectors: J13, J14, J15, J16, J17, J18, J19

Table 2-5 - Digital I/O Legend

DIO	Digital Input Output
24_GND	Ground
24VDC	+ 24 Volts DC

Table 2-6 - Digital I/O - DSUB 37 Pinout Summary

Connector:	J13	J14	J15	J16	J17	J18	J19
Pin#							
1	24VDC	24VDC	24VDC	24VDC	24VDC	24VDC	24VDC
2	24_GND	24_GND	24_GND	24_GND	24_GND	24_GND	24_GND
3	DIO12	DIO38	DIO64	DIO90	DIO116	DIO142	DIO168
4	DIO11	DIO37	DIO63	DIO89	DIO115	DIO141	DIO167
5	DIO10	DIO36	DIO62	DIO88	DIO114	DIO140	DIO166
6	DIO9	DIO35	DIO61	DIO87	DIO113	DIO139	DIO165
7	24_GND	24_GND	24_GND	24_GND	24_GND	24_GND	24_GND
8	DIO8	DIO34	DIO60	DIO86	DIO112	DIO138	DIO164
9	DIO7	DIO33	DIO59	DIO85	DIO111	DIO137	DIO163
10	DIO6	DIO32	DIO58	DIO84	DIO110	DIO136	DIO162
11	24_GND	24_GND	24_GND	24_GND	24_GND	24_GND	24_GND
12	DIO5	DIO31	DIO57	DIO83	DIO109	DIO135	DIO161
13	DIO4	DIO30	DIO56	DIO82	DIO108	DIO134	DIO160
14	DIO3	DIO29	DIO55	DIO81	DIO107	DIO133	DIO159
15	24_GND	24_GND	24_GND	24_GND	24_GND	24_GND	24_GND
16	DIO2	DIO28	DIO54	DIO80	DIO106	DIO132	DIO158
17	DIO1	DIO27	DIO53	DIO79	DIO105	DIO131	DIO157
18	DIO0	DIO26	DIO52	DIO78	DIO104	DIO130	DIO156
19	24VDC	24VDC	24VDC	24VDC	24VDC	24VDC	24VDC
20	24VDC	24VDC	24VDC	24VDC	24VDC	24VDC	24VDC
21	DIO25	DIO51	DIO77	DIO103	DIO129	DIO155	DIO181
22	DIO24	DIO50	DIO76	DIO102	DIO128	DIO154	DIO180
23	DIO23	DIO49	DIO75	DIO101	DIO127	DIO153	DIO179
24	DIO22	DIO48	DIO74	DIO100	DIO126	DIO152	DIO178
25	24_GND	24_GND	24_GND	24_GND	24_GND	24_GND	24_GND
26	DIO21	DIO47	DIO73	DIO99	DIO125	DIO151	DIO177
27	DIO20	DIO46	DIO72	DIO98	DIO124	DIO150	DIO176
28	DIO19	DIO45	DIO71	DIO97	DIO123	DIO149	DIO175
29	24_GND	24_GND	24_GND	24_GND	24_GND	24_GND	24_GND
30	DIO18	DIO44	DIO70	DIO96	DIO122	DIO148	DIO174
31	DIO17	DIO43	DIO69	DIO95	DIO121	DIO147	DIO173
32	DIO16	DIO42	DIO68	DIO94	DIO120	DIO146	DIO172
33	24_GND	24_GND	24_GND	24_GND	24_GND	24_GND	24_GND
34	DIO15	DIO41	DIO67	DIO93	DIO119	DIO145	DIO171
35	DIO14	DIO40	DIO84	DIO92	DIO118	DIO144	DIO170
36	DIO13	DIO39	DIO65	DIO91	DIO117	DIO143	DIO169
37	24VDC	24VDC	24VDC	24VDC	24VDC	24VDC	24VDC

Table 2-7 – Digital Expansion I/O – Female DSUB 50 Pinout Summary

Connector J20				Connector J21			
Pin#		Pin#		Pin#		Pin#	
1	24VDC	26	EXP_DIO35	1	24VDC	26	EXP_DIO54
2	24_GND	27	24_GND	2	24_GND	27	24_GND
3	EXP_DIO0	28	EXP_DIO34	3	24VDC	28	EXP_DIO55
4	EXP_DIO1	29	EXP_DIO33	4	EXP_DIO37	29	EXP_DIO56
5	EXP_DIO2	30	EXP_DIO32	5	EXP_DIO38	30	EXP_DIO57
6	EXP_DIO3	31	EXP_DIO31	6	EXP_DIO39	31	EXP_DIO58
7	EXP_DIO4	32	EXP_DIO30	7	EXP_DIO40	32	EXP_DIO59
8	24_GND	33	24_GND	8	24_GND	33	24_GND
9	EXP_DIO5	34	24VDC	9	EXP_DIO41	34	24VDC
10	EXP_DIO6	35	24VDC	10	EXP_DIO42	35	EXP_DIO60
11	EXP_DIO29	36	EXP_DIO28	11	EXP_DIO36	36	EXP_DIO61
12	EXP_DIO7	37	EXP_DIO27	12	EXP_DIO43	37	EXP_DIO62
13	EXP_DIO8	38	EXP_DIO26	13	EXP_DIO44	38	EXP_DIO63
14	24_GND	39	24_GND	14	24_GND	39	24_GND
15	EXP_DIO9	40	EXP_DIO25	15	EXP_DIO45	40	EXP_DIO64
16	EXP_DIO10	41	EXP_DIO24	16	EXP_DIO46	41	EXP_DIO65
17	EXP_DIO11	42	EXP_DIO23	17	EXP_DIO47	42	EXP_DIO66
18	EXP_DIO18	43	EXP_DIO22	18	EXP_DIO71	43	EXP_DIO67
19	EXP_DIO12	44	EXP_DIO21	19	EXP_DIO48	44	EXP_DIO68
20	24_GND	45	24_GND	20	24_GND	45	24_GND
21	EXP_DIO13	46	EXP_DIO20	21	EXP_DIO49	46	EXP_DIO69
22	EXP_DIO14	47	EXP_DIO19	22	EXP_DIO50	47	EXP_DIO70
23	EXP_DIO15	48	24VDC	23	EXP_DIO51	48	24VDC
24	EXP_DIO16	49	24VDC	24	EXP_DIO52	49	24VDC
25	EXP_DIO17	50	24_GND	25	EXP_DIO53	50	24_GND

2.4.2.2.1 Digital Input Interface Example

The individual outputs will support up to a 200 mA load per channel. Each output is thermally protected against short-circuiting and includes under voltage protection.

Outputs default to the OFF condition during power up and processor reset conditions. The figures below show the output and output with relay circuitry.

For AS01023G-01, digital I/O is configured as sourcing (active high). Other ECM2 part numbers or configurations, digital I/O can be configured as either sinking or sourcing by the factory.




Figure 2-7 Equivalent circuit Digital input

Below is an example of how to use the digital input interface for both the sinking and sourcing hardware configurations. The digital I/O circuitry is powered from an external +24-volt power source via the I/O connector.




Figure 2-8 Sourcing Input




Figure 2-9 Sinking Input

2.4.2.2.2 Digital Output Interface Example

The individual outputs will support up to a 200 mA load per channel. Each output is thermally protected against short-circuiting and includes under voltage protection.

Outputs default to the OFF condition during power up and processor reset conditions. The figures below show the output and output with relay circuitry.

For AS01023G-01, digital I/O is configured as sourcing (active high). Other ECM2 part numbers or configurations, digital I/O can be configured as either sinking or sourcing by the factory.




Figure 2-10 Digital Output

Below is an example of how to interface with the digital outputs for both the sinking and sourcing hardware configurations. The digital I/O circuitry is again powered from an external +24-volt power source via the I/O connector.




Figure 2-11 Sinking Output




Figure 2-12 Sourcing Output

2.4.3 Interlock-IN Connectors

Up to 48 physical interlocks Inputs are available via connectors J22, J23, and J24. The pin assignments are shown below.




Figure 2-13 Interlock IN Connector Pinouts
Connector J22, J23, J24

Table 2-8 - Interlock IN - Legend

IN_ILK	Interlock Input
24_GND	24VGround

Table 2-9 - INTERLOCK – IN - DSUB 37 Pinouts Summary

Connector:	J22	J23	J24
Pin			
1	24VDC	24VDC	24VDC
2	24_GND	24_GND	24_GND
3	IN_ILK7	IN_ILK23	IN_ILK39
4	24_GND	24_GND	24_GND
5	IN_ILK6	IN_ILK22	IN_ILK38
6	24_GND	24_GND	24_GND
7	IN_ILK5	IN_ILK21	IN_ILK37
8	24_GND	24_GND	24_GND
9	IN_ILK4	IN_ILK20	IN_ILK36
10	24_GND	24_GND	24_GND
11	24_GND	24_GND	24_GND
12	IN_ILK3	IN_ILK19	IN_ILK35
13	24_GND	24_GND	24_GND
14	IN_ILK2	IN_ILK18	IN_ILK34
15	24_GND	24_GND	24_GND
16	IN_ILK1	IN_ILK17	IN_ILK33
17	24_GND	24_GND	24_GND
18	IN_ILK0	IN_ILK16	IN_ILK32
19	24_GND	24_GND	24_GND
20	24VDC	24VDC	24VDC
21	IN_ILK8	IN_ILK24	IN_ILK40
22	24_GND	IN_ILK24_RTN	24_GND
23	IN_ILK9	IN_ILK25	IN_ILK41
24	24_GND	IN_ILK25_RTN	24_GND
25	IN_ILK10	IN_ILK26	IN_ILK42
26	24_GND	IN_ILK26_RTN	24_GND
27	IN_ILK11	IN_ILK27	IN_ILK43
28	24_GND	IN_ILK27_RTN	24_GND
29	24_GND	24_GND	24_GND
30	IN_ILK12	IN_ILK28	IN_ILK44
31	24_GND	IN_ILK28_RTN	24_GND
32	IN_ILK13	IN_ILK29	IN_ILK45
33	24_GND	IN_ILK29_RTN	24_GND
34	IN_ILK14	IN_ILK30	IN_ILK46
35	24_GND	IN_ILK30_RTN	24_GND
36	IN_ILK15	IN_ILK31	IN_ILK47
37	24_GND	IN_ILK31_RTN	24_GND

2.4.4 Interlock-OUT Connectors




Figure 2-14 Interlock OUT Connector Pinouts
Connector J25, J26

Table 2-10 - Interlock OUT - Legend

ILK_NC	Interlock Normally Close
ILK_NO	Interlock Normally Open
GND	Ground

Table 2-11 - Interlock – OUT - DSUB 37 Pinout Summary

Connector:	J25	J26
Pin		
1	24VDC	24VDC
2	24_GND	24_GND
3	ILK_NC7	ILK_NC23
4	ILK_NO7	ILK_NO23
5	ILK_NC6	ILK_NC22
6	ILK_NO6	ILK_NO22
7	ILK_NC5	ILK_NC21
8	ILK_NO5	ILK_NO21
9	ILK_NC4	ILK_NC20
10	ILK_NO4	ILK_NO20
11	24_GND	24_GND
12	ILK_NC3	ILK_NC19
13	ILK_NO3	ILK_NO19
14	ILK_NC2	ILK_NC18
15	ILK_NO2	ILK_NO18
16	ILK_NC1	ILK_NC17
17	ILK_NO1	ILK_NO17
18	ILK_NC0	ILK_NC16
19	ILK_NO0	ILK_NO16
20	24VDC	ILK_NC24
21	ILK_NC8	ILK_NO24
22	ILK_NO8	ILK_NC25
23	ILK_NC9	ILK_NO25
24	ILK_NO9	ILK_NC26
25	ILK_NC10	ILK_NO26
26	ILK_NO10	ILK_NC27
27	ILK_NC11	ILK_NO27
28	ILK_NO11	ILK_NC28
29	24_GND	ILK_NO28
30	ILK_NC12	ILK_NC29
31	ILK_NO12	ILK_NO29
32	ILK_NC13	ILK_NC30
33	ILK_NO13	ILK_NO30
34	ILK_NC14	ILK_NC31
35	ILK_NO14	ILK_NC31
36	ILK_NC15	ILK_NO31
37	ILK_NO15	ILK_NO31

2.4.5 Other Connectors

Please note that not all versions of the ECM2 include all connectors. Your version may be customized and may not include all of the described features.

2.4.5.1 Profibus Connector

A 9-pin D-Sub female connector is used for the Profibus Interface. The pin assignments are as the following:




Figure 2-15 9-Pin D-Sub

Table 2-12 - Profibus female DB9 Connector pinout

PIN	FUNCTION
1	NC
2	NC
3	B-line (RS485-)
4	RTS
5	GND (Iso.)
6	+5 (Iso.)
7	NC
8	A-line (RS485+)
9	NC

2.4.5.2 EtherCat

EtherCat uses standard RJ45 connectors with the following pin assignments. The same pin assignments exist on both U16 (In) and U17 (Out)


Table 2-13 – EtherCat RJ45 Connector pinout

PIN	ECAT IN U16	ECAT OUT U17
1	ECAT_IN_TX+	ECAT_OUT_TX+
2	ECAT_IN_TX-	ECAT_OUT_TX-
3	ECAT_IN_RX+	ECAT_OUT_RX+
4	NC	NC
5	NC	NC
6	ECAT_IN_RX-	ECAT_OUT_RX-
7	NC	NC
8	NC	NC

2.4.5.3 Ethernet Ports

There are two Ethernet ports. Currently, only one is enabled and active (U19).

2.4.5.4 DeviceNet Connector



DeviceNet Connector
(female 5-pin micro connector)

PIN	SIGNAL
1	SHIELD
2	V+
3	V-
4	CAN H
5	CAN L

Figure 2-16 DeviceNet Connector

The ECM2 has a Euro micro 5-pin female connector for the DeviceNet Interface.

2.5 LCD

After boot up sequence (see 3.2.1 for more information), the LCD screen will show the ECM2 unit IP address. An example is shown below:




Figure 2-17 The ECM2 LCD Screen, after boot

2.6 LED's

The LED's are used to communicate status of the IEC run-time engine.

Table 2-14 The ECM2 LED Status

IEC61131-3 State	Health LED	If there is an error
On	Solid Amber	N/A
Stop	Blinking Amber	Solid Red
Running	Solid Green	Blinking Red
Halt	Blinking Green	Blinking Red

2.7 Switches

Table 2-15 Switch 3 (Right-Most Switch) Setting refers to the right most rotary switch shown with an arrow in the picture below on the ECM2 front panel. This dictates how the IEC program boot project (if already existing) will be started at system boot up.



The 'boot project' is the IEC code that will be executed upon boot of the ECM2.




Figure 2-18 Front Panel Image of Reset button and 3 Switches



Note: the use of "IP Address" is not applicable to the functions of these switches. Currently, these switches are not used for IP Address setting.

Table 2-15 Switch 3 (Right-Most Switch) Setting

Switch value	Function	Description
0	IEC Boot project will not start.	IEC program will not be executed by the system and will wait for Multiprog command. For the next step, please refer to section 6.
1	Cold Boot	IEC starts with boot project

		with initial data. For the next step, please refer to section 6.
2	Warm Boot	IEC starts boot project with retained value from the previous execution. For the next step, please refer to section 6.
3-9	IEC Not Active	IEC will not be running. Multiprog cannot be connected to ECM2. In this scenario, the ECM2 can be programmed via C or other languages. For the next step, please refer to the Arrow SDK document. *

* available at: <http://www.mksinst.com/product/product.aspx?ProductID=1155>

2.8 Diagnostic Console Serial

The ECM2 has an available RS-232 serial diagnostics interface. The serial port is used to send all legally required copyright messages, current version information and hardware configuration information during the unit's power-up sequence to a display.

Table 2-16 - Diagnostic Serial Port Connector Pin-Out (DB-9 Female Connector)

Pin	RS232 Function
1	NC
2	TXD
3	RXD
4	NC
5	SGND
6	NC
7	NC
8	NC
9	NC

2.8.1 Connecting via a Diagnostic Console Serial


Connect your computer to the diagnostics port (DB9) using a standard straight-through cable.

User can now communicate via the diagnostics port of the unit using a terminal program such as Microsoft® HyperTerminal or TeraTerm Pro. The serial connection parameters are listed in Table 2-17e. The screenshot in Figure 2-19 shows examples of the messages output on the Console Serial port.

Table 2-17 - Serial Connection Parameters

Parameter	Value
Baud rate	115200
Data bits	8
Parity	None
Stop bits	1
Flow Control	None

The screenshot below shows examples of the messages output on the Console Serial port:



```
File Edit Setup Control Window Help
INFO:OALLogSetZones: dpCurSettings.ulZoneMask: 0xb
DEMInit: silicon rev = 0x20
BoardID = 0x0.
SUCCESS: LOCALBUSMap.
OALIoCtlHalInitRTC(2006/1/1 12:0:0.000)
Check Arrow FPGA revision: 0x0002
Check LBX FPGA revision: 0x2115
Check DIO FPGA revision: 0x0311
Check AIO FPGA revision: 0x8903
192.168.1.4
    OTG : Load HCD
    OTG : Unload HCD
    OTG : Load UFN
MKS Instruments embedded CLR Version 2.2.0.20250 - Mode 0.
MKS ECM2 PLC Digital IO Driver successfully loaded
MKS ECM2 PLC Analog IO Driver successfully loaded
MKS ECM2 PLC Interlock IO Driver successfully loaded
MKS ECM2 Firmware Library successfully loaded
MKS DNET Driver successfully loaded
Failed to initialized retain data
.Creating Exit Thread
Successfully created Exit Thread
Stdin not accessible.
1/9/2006 4:21:41 PM - On...
```

Figure 2-19 Console Serial Port, Sample Screenshot

This information available through the console serial port is valuable when troubleshooting-with the aid of MKS applications engineering.

2.8.2 RS232 Serial Communication Ports

In addition to the dedicated RS232 console port, the ECM2 supplies three additional RS232 communication ports.

J31 will be wired to the same console serial port for diagnostic.

J28, J29 are additional serial ports that can be accessed over IEC61131 interface. Please see Multiprog chapter for the serial port function block on how to access these ports through IEC programming.

J30 is not currently enabled and cannot be used.




Figure 2-20 RS-232 - DB9 Connector Pinouts J28, J29, J30, J31

Table 2-18 – RS-232 Connector Pinout Summary

Pin	RS232 Function
1	DCD – Data Carrier Detect
2	RXD – Receive Data
3	TXD – Transmit Data
4	DTR – Data Terminal Ready
5	GND – Ground
6	DSR – Data Set Ready
7	RTS – Request to Send
8	CTS – Clear to Send
9	RI – Ring Indicator

3 Quick Start

3.1 Network Configuration

The ECM2 network settings are factory configured as shown in Table 3-1:

Table 3-1 Default Ethernet setting

Parameter	Setting
IP-Address	192.168.1.3
Subnet mask	255.255.255.0
Default Gateway	None

3.2 Connecting to a computer via TCP/IP and over the Console Port and Preparing to boot the ECM2

- The following are required:
 - Laptop or PC (including TeraTerm Pro or equivalent, and Multiprog Express/Pro)
 - Ethernet cable connected directly, or over a Hub, to the ECM2
 - Optionally, a Serial port cable
- Attach the Ethernet cable between the unit (U19) and your computer, or use a HUB to build a small network. Your computer must be on the same subnet as the ECM2.

NOTE: Currently only the U19 port is enabled for Ethernet access. Ethernet port U18 is not enabled.

- To start with Multiprog Pro or Multiprog Express (IEC61131-3), refer to chapter 5.
- Power the ECM2 by supplying +24 volts to the power connector (P2). If troubleshooting requires viewing the boot status messages over the Console port, refer to instructions in section 2.8.
 - Analog +/-15 volts for Analog modules and 24V for Digital IO are supplied internally. No additional power is required for the unit.

3.2.1 LCD Power Start up Sequence

The front LCD panel goes through a status sequence during boot. Depending on the network setting, some LCD screen displays and unit status might differ due to initialization. The expected display and unit status based on LCD display are shown below:

First Power Up, LCD display will display a default screen with double vertical lines as seen below




Figure 3-1 Initial LCD View on boot

ECM2 software booting sequence will indicate the booting start as shown below



Figure 3-2 LCD View during boot sequence

Then ECM2 will check network setting. The following image may flash quickly or not at all if the IP address is configured for static IP address



Figure 3-3 LCD View during boot sequence

3.2.1.1 With Static IP Address

As default, the unit is configured with the static IP address 192.168.1.3. If network configuration remains as static, no Ethernet cable connection is required for unit to be complete IP detection mechanism as part of boot sequence. A screen such as that shown below with static IP address will be displayed indicating that the unit completed the boot sequence and is ready.



Figure 3-4 LCD screen showing IP address

3.2.1.2 With DHCP network setting

If the ECM2 network setting is configured to DHCP, an Ethernet cable connected to a switch or network capable of assigning an IP address for a node on the network is required. ECM2 will continue to query for IP address and remain in wait mode until an IP address is assigned to it. The screen shown below with continuously scrolling dots will continue until an IP address is assigned.



Figure 3-5 LCD screen during DHCP IP assignment

Once an IP address is assigned and detected, the ECM2 displays its IP address as shown in the next figure indicating that the boot up is complete and the unit is ready. (Note that the IP address in the figures is only given as an example and your IP address may be different).



Figure 3-6 LCD screen after DHCP IP assignment

3.2.1.3 Resetting the Unit and Possible Boot error

During a re-boot, the unit software may fail to start in some cases. This is typically due to a power glitch caused by a quick power toggle. When power cycling the unit, please ensure you allow for at least 10 seconds between shutting the unit off, and power restoration. If the power is toggled too quickly, the ECM2 will enter a fault mode and the LCD will display a static block as shown below.



Figure 3-7 LCD screen during boot error

If a fault state such as that shown above is observed, power the ECM2 off completely off by removing the power connector to the ECM2 or shut down main 24V DC power source, wait for 10 seconds and power the ECM2 back up.

Alternatively, the “Reset” button found on the front panel of the unit can be used for proper power cycling



Figure 3-8 Reset button on front panel of the ECM2


To properly reboot the ECM2, press and hold the Reset button until the 3.3V LED turns amber. Release the reset button, and wait approximately 10 seconds for the boot messages to appear on the LCD screen.

3.3 Changing the IP address for the unit


Follow the steps below to change the IP address from the default value.

Note: Changing the IP address of the unit is not required as the unit can operate with the default setting of 192.168.1.3.

1. Open a telnet session to the default unit IP address. NOTE: your PC has to have the same subnet as the ECM2 to do this. (To launch telnet, in Windows, click Start, then Run, then type "telnet" and hit Enter).
2. Then, type 'Open 192.168.1.3' or the IP address shown on the LCD screen if different.
3. At the command prompt, type "ipsetup" and press ENTER key, the following screen will appear

A screenshot of a Windows Telnet window titled 'Telnet 10.202.3.152'. The window shows a command-line interface with the following text: 'Welcome to the Windows CE Telnet Service on Arrow', 'Pocket CMD v 6.00', '\> ipsetup', 'Current IP Address configuration: DHCP', 'Enter Desired Configuration.', and 'Enable DHCP <1 - Yes, 0 - No>:'. The background of the terminal is black with white text.**Figure 3-9 Telnet view during IP address change**

4. Type "1" to enable DHCP, or "0" to specify a static IP address. Then follow the prompts for IP address settings.



```

Telnet 10.202.3.152
Welcome to the Windows CE Telnet Service on Arrow
Pocket CMD v 6.00
> ipsetup
Current IP Address configuration: DHCP
Enter Desired Configuration.
Enable DHCP (1 - Yes, 0 - No): 1
Saving...
Success.
Reset to enable new configuration.
> ipsetup
Current IP Address configuration: DHCP
Enter Desired Configuration.
Enable DHCP (1 - Yes, 0 - No): 0
Enter IP Address: 192.168.1.150
Enter Net Mask: 255.255.255.0
Saving...
Success.
Reset to enable new configuration.
>
    
```

Figure 3-10 Telnet view after successful IP address change

5. Reset (power toggle) the unit for change to take effect. Be careful to toggle the power with sufficient wait time as described in section 3.2.1.3.

Note the reset will disconnect your Telnet session.

3.3.1 IEC Start Up Rotary Switch Setting

The following table refers to the right most rotary switch on the ECM2 front panel. This dictates how the IEC program boot project (if already in existence) will be started at system boot up.



The 'boot project' is the IEC code that will be executed upon boot of the ECM2.




Figure 3-11 Front Panel Image of Reset button and 3 Switches

Table 3-2 Switch 3 (Right-Most Switch) Setting


Switch value	Function	Description
0	IEC Boot project will not start.	IEC program will not be executed by the system and will wait for Multiprog command. For the next step, please refer to section 5.
1	Cold Boot	IEC starts with boot project with initial data. For the next step, please refer to section 5.
2	Warm Boot	IEC starts boot project with retained value from the previous execution. For the next step, please refer to section 5.
3-9	IEC Not Active	IEC will not be running. Multiprog cannot be connected to ECM2. For the next step, please refer to the Arrow SDK document. *

* available at: <http://www.mksinst.com/product/product.aspx?ProductID=1155>

3.4 Setting the Unit Date

Telnet to the unit, by typing “telnet” and the unit IP address in the Windows/Start/Run field.

When the telnet session opens, type “date” followed by Enter. Type the date and hit Enter.




```
Telnet 10.202.2.187
Welcome to the Windows CE Telnet Service on Arrow
Pocket CMD v 6.00
\> date
The current date is: Sunday, January 01, 2006
Enter the new date (mm-dd-[yy]yy): 04-20-2012
```

Figure 3-12 Telnet view during date change

3.5 Setting the Unit Time

Telnet to the unit, by typing “telnet” and the unit IP address in the Windows/Start/Run field.

When the telnet session opens, type “time” followed by Enter. Then type in the time (using a 24hour clock format) and hit Enter.



```
Telnet 10.202.2.187
Welcome to the Windows CE Telnet Service on Arrow
Pocket CMD v 6.00
\> time
The current time is: 1:22:13 PM
Enter the new time (hh:mm:ss): 13:22:13
\>
```

Figure 3-13 Telnet view during time change

3.6 Troubleshooting Network configuration

- Make sure your PC or laptop has the same subnet as the ECM2
- Ensure that all Ethernet cable connections are inserted correctly and ethernet cable is in U19 Ethernet port on ECM2.
- From your PC command prompt, issue a “ping 192.168.1.3” (or to the IP address shown on the LCD screen) and see if ECM2 replies. If there is no reply, please check your network configuration, cable connection, PC IP address setting and whether the correct NIC card is used.
- Refer to the LCD screen on the unit front for the unit IP address.

4 DeviceNet Master Capabilities

If the ECM2 is used as a DeviceNet master, it can control up to 16 completely separate DeviceNet networks with a maximum of 63 devices per network using separate Brad Ethernet DeviceNet modules. Note, as DeviceNet nodes and networks are added, the IO latency of the process code may be affected.




Figure 4-1 DeviceNet Master with two Brad Modules.

4.1 First-Time Setup of DeviceNet networks or Adding Additional DeviceNet Networks

To setup the DeviceNet network (or networks if more than one is available), a scan command must be performed in the ECM2 telnet session as described below. If additional DeviceNet networks are added, this step must be repeated.

Note: One network is added at a time. Connect the DeviceNet module to the network in the order you wish the networks to appear.

For the first network, telnet to the unit, by typing “telnet” and the unit IP address in the Windows/Start/Run field.

When the telnet session opens, type “ednbrowse” followed by Enter. This command will allow the ECM2 to scan the network the module.




Figure 4-2 Telnet view during browse for DeviceNet networks

Repeat the above steps for additional networks.

4.1.1 Deleting the DeviceNet config file

To remove the DeviceNet network (or networks if multiple are connected,): in the telnet session, type “dir” and Enter. Then, type “del dnrapiproxy.cfg” and Enter. This will reset the ECM2 to a state in which no DeviceNet networks are connected. New DeviceNet networks can be added at this, or later time.

4.2 DeviceNet Master Diagnostics and Information

For additional information and diagnostics of the Master modules, please see Molex documentation.

4.3 DeviceNet Master Detection Mechanism

Currently, ECM2 only supports the Molex/Brad Ethernet DeviceNet Masters. Source: www.molex.com.

Table 4-1 Molex Part Numbers

Molex PN	Manufacturing PN	Description
SST-EDN-1	112034-0021	SST Remote DeviceNet Scanner, Ethernet remote connection, Din Rail mounting, IP30

DRL-280P	112036-0037	Direct-Link® Series 200 Unmanaged Ethernet Switch, 8-Port RJ45, IP30
----------	-------------	--

Brad Ethernet DeviceNet Masters, if connected, will be detected automatically upon unit power up if connected. Since the detection mechanism is based on the Brad MAC address, the scanned detection order of the networks is not deterministic for the purpose of master index mapping for IEC application. However, this order can be changed if needed.

4.4 Scanning the DeviceNet network nodes

For diagnostic purposes, and to confirm DeviceNet Mac ID address settings, type “dnbrowse”, this will scan the networks for all available DeviceNet slave devices.

Type “dnbrowse” in the telnet session and press Enter. Type “all” and Enter if you wish to have all networks scanned.

Note: Card names are case sensitive, but ‘all’ is not.
 Note: This step may take a few minutes to complete.




Figure 4-3 Telnet view during scanning for DeviceNet network nodes

4.5 IO Mapping for Slave/Node Devices

All devices on each network are mapped as a single continuous block of memory per DeviceNet MacID address. To illustrate an example is given in the table below:

Table 4-2 IO Mapping Example

DeviceNet Network	Node	Input/Output Size (also known as Produce/Consume)*
1	Slave1, MacID=2	5/5 bytes
1	Slave2, MacID=3	10/6 bytes
1	Slave3, MacID=6	7/12 bytes
2	Slave1, MacID=22	2/5 bytes
2	Slave2, MacID=3	10/10 bytes
2	Slave9, MacID=2	5/7 bytes
...		

With the above example, the input for network 1 will be 22 bytes, and output will be 23.

Table 4-3 IO Mapping Example, summary of network requirements

DeviceNet Network	Input	Output
1	22 bytes	23 bytes
2	17 bytes	22 bytes

Continuing with the above example, the memory mapping of the DeviceNet slave IO nodes will be as follows:

Table 4-4 IO Memory mapping in ECM2

DeviceNet Network	DeviceNet Network MacID	Input Byte	Output Byte
1	2	%IB00-%IB04 **	%QB00-%QB04**
1	3	%IB05-%IB14	%QB05-%QB10
1	6	%IB15-%IB21	%QB11-%QB22
2	2	%IB100-%IB104***	%QB200-%QB206
2	3	%IB105-%IB114	%QB207-%QB216
2	22	%IB115-%IB117	%QB217-%QB221

* As defined by the perspective of the ECM2.

** Assumes starting address is x00. This can be set at any available byte address.

*** Each additional network memory mapping is not required to be continuous to the previous network(s). In this example, the memory assignments are not continuous.

5 IEC61131-3 Compliant Programming Interface

The ECM2 is implemented with Multiprog KW-Software run time engine for IEC61131-3 compliant Programmable Logic Controller (PLC) programming capabilities including all five IEC supported languages:

- Ladder Diagram (LD)
- Function Block Diagram (FDB)
- Instruction List (IL)
- Sequential Function Chart (SFC)
- Structured Text (ST)

According to KW-Software, Multiprog Express/Pro Development platform allows full GUI and editor fully compliant with IEC61131-3 development interface and PLCOpen XML format (see <http://www.plcopen.org/> for more information) import of structure text from other PLCs.

5.1 Software Requirements

MKS provides three installation packages that include the following SW

- 1) Multiprog Pro version 5.35 or later, with the option to install eCLR and MKS ECM2 drivers.
- 2) Multiprog Express version 5.35 or later, with the option to install ECLR and MKS ECM2 drivers.
- 3) eCLR and MKS ECM2 drivers. Use this option if you already have the Multiprog Pro or Multiprog Express software installed on your laptop or PC.

These installation files are available in the “Documents and Downloads” section of the MKS Instruments ECM2 website at:

<http://www.mksinst.com/product/product.aspx?ProductID=1155>

Note: Multiprog Pro is available for purchase from MKS Instruments. Please contact your local sales representative for pricing and availability information. Multiprog Express is available free of charge via download.

The installation for Multiprog Express and Multiprog Pro are similar. Installation on Windows XP and Windows 7 are both supported, though the installation screens may appear slightly different. For reference purposes, the installation of the “ECM2_MULTIPROG_Express_Setup.exe” on a WindowsXP computer is shown below.

Start by double-clicking on the “ECM2_MULTIPROG_Express_Setup.exe” file.

NOTE: there are options to select installation packages; however installation must be done in the exact order listed in the installation, i.e. the user cannot install eCLR ARM before installing Multiprog.

Click Install on the following dialogue box:




Figure 5-1 ECM2 Multiprog installation screen

Upon completion of the installation, you should see the following dialogue box:



Figure 5-2 ECM2 Multiprog installation completed

Select OK to continue. Next, you should see the following screen. Select Next to continue.




Figure 5-3 eCLR setup screen

On the following screen, please review and accept the license terms by clicking **Next**.

After accepting the terms and conditions, the following dialogue box will appear. Select **Next** or select another Multiprog location.



Figure 5-4 eCLR setup screen

Select **Next** to obtain support for Visual Studio C#:




Figure 5-5 eCLR setup screen, support for Visual Studio

Finally, select **Install** on the following screen:



Figure 5-6 eCLR ready to install screen view

Following the completion of the installation, select **Finish**. After clicking **Finish**, select **Next** on the following screen:




Figure 5-7 eCLR for ECM2 setup

On the following dialogue box, confirm that the location for installation is correct, and select ***Install***.




Figure 5-8 eCLR installation screen, select install location

Once installation has completed, select **Finish**. At this point, you will be asked to reboot your computer to finish the installation.




Figure 5-9 eCLR installation screen, reboot for completed installation

After the installation program has completed, a new folder, called KW-Software, will be available in “Programs” under the Windows, Start menu.

To create a project in Multiprog, refer to section 6.

5.1.1 Configuration

- 1) The user development laptop/PC should contain the following items:
 - a. TeraTerm (available at: <http://www.ayera.com/teraterm/>)
 - b. Telnet (available on all Windows PC's)
 - c. MKS provided installed packages as described in section 5.1.

5.1.2 IEC LED status

The health LED status would indicate what status and state the IEC engine is in.

Table 5-1 The ECM2 LED Status

IEC61131-3 State	Health LED	If there is an error
On	Solid Amber	N/A
Stop	Blinking Amber	Solid Red
Running	Solid Green	Blinking Red
Halt	Blinking Green	Blinking Red

6 Tutorial - Creating a Multiprog Project

Open Multiprog Pro application software; go to File->New Project. Select Project Wizard and follow the steps below

1. Create a project name. The example below uses FirstProject as project name.




Figure 6-1 Creating a project name

2. Select the desired IEC language for the Program Organization Unit (POU) and name. The example uses MyPOU, and Ladder logic as the desired language.




Figure 6-2 Selecting the name and language

3. Create configuration name and select “eCLR_ECM2” as Type. Note, for Multiprog Express, this step is skipped.




Figure 6-3 eCLR configuration

4. Create a resource name and select eCLR_ECM2 as the type.




Figure 6-4 Creating a resource name

5. Create Task name and use default for Type.




Figure 6-5 Creating a task name

6. Click **Finish** when prompted .




Figure 6-6 Reviewing the project description

7. Right click on MyResource->Settings.




Figure 6-7 Opening resource settings

- Choose TCP/IP for communication Type and enter the unit IP address of the ECM2 (displayed in the ECM2 LCD window) in the Parameter window, and select eCLR 3.0 (Core 3.0.0) for Version Build settings, then click OK.




Figure 6-8 Identifying the ECM2 unit IP address in Multiprog

9. Double-click on the IO Configuration item in the explorer tree (on the left side of the screen). A pop-up window for device IO configuration will appear.




Figure 6-9 Starting IO configuration in Multiprog

10. Delete the default entries (there may only be one) in the IO group list (on INPUT tab) as well as the default out (on OUTPUT tab). New IO groups can be created with appropriate name for each project. Follow the steps below to create IO groups.
 - a. On the INPUT tab, click Add to create an Input IO group. A new window will pop up as shown below. Create the IO group name and select the task created for this project (Task1).




Figure 6-10 Setting Digital Inputs as example for adding an IO Group

- b. In the Board IO module window, high-light ECM2 then click Driver Parameter .
- c. A window will pop up for user to select the type of IO: digital, analog or Programmable Interlock as shown below. Select the desired I/O type, and the first IO byte that the user wants to access. The text below the window shows the maximum number of bytes if I/O group 1-8 is selected. For example if first DI group is 9-16 is selected, the first 8 DI cannot be accessed by user and total length will be reduced by one byte.




Figure 6-11 Selecting the driver and group

11. Similar mapping can be done for other I/O groups.




Figure 6-12 Maximum analog inputs size is 64 bytes




Figure 6-13 Different Options to map Programmable Interlock Inputs




Figure 6-14 Maximum analog Outputs size is 32 bytes




Figure 6-15 Maximum Programmable Clear Debounce Status size is 1 bytes

12. Details for the Input and Output settings are as follows:

Input/Output	Driver	Function	Comments
Input	Analog	0-31	Each AI is setup as a differential input. 2 bytes are used per analog input. For pin mapping, see Error! Reference source not found.
	Digital	1-210	Each bit will correspond to a physical DIO point. For pin mapping, see Error! Reference source not found. Note in Error! Reference source not found. there is an offset and 0-209 in that table matches 1-210 in the Multiprog software.
	Programmable Interlock	Status	2 bytes. Gives the status of the Interlock board. Refer to 7.4 for more information.
		Inputs	Reads the state of the physical inputs on the interlock board. Note 64 bits are on the ECM2 but only the first 48 bits are available. Bit 65 is used for the watchdog. For pin mapping, see Error! Reference source not found.

		Outputs	Reads the status of the result of the interlock logic.
		Relay Feedback	Reads the status of the physical relay. Meaning: what is occurring on the interlock output pins.
		Debounce Status	Reads the presence of a debounce error for each input. Each interlock input is a single bit, with value 0 equals no error, and value 1 equals error. Refer to Error! Reference source not found. for more information.
Output	Analog	0-15	Each AO is setup as a differential output. 2 bytes are used per analog output. For pin mapping, see Error! Reference source not found.
	Output	1-210	Each bit will correspond to a physical DIO point. For pin mapping, see Error! Reference source not found. . Note in Error! Reference source not found. there is an offset and 0-209 in that table matches 1-210 in the Multiprog software.
	Programmable Interlock	Clear Debounce Status	Allows clearing the debounce error. Bit value of 1 clears all debounce statuses. Note the debounce status cannot be cleared one at a time.

Table 6-1 Input/Output Mapping Definitions Table

13. If DeviceNet slave devices are available on the DeviceNet network, follow the steps below to configure mapping for each device. The example in the figure below adds a slave with 10 byte inputs
- Click "**Add IO Group**" as in step 10 above.
 - Create a name and select the task associated with the IO. The example below create an IO group for a DeviceNet slave on Network 1 with 10 input bytes, a scan rate of 50ms, and a reconnect time out of 50ms.
 - Make sure the length in the logical address area matches that which you enter for the Driver Parameters below.




Figure 6-16 Example of setting DeviceNet IO group

- d. Click on the **MKS DeviceNet** then click on **Driver Parameters**




Figure 6-17 Setting DeviceNet driver parameters

6.1.1 ECM2 IO Mapping detail


- Process Input Image (PII) and Process Output Image (PIQ) are mapped directly to ECM2 physical I/Os, i.e. the actual I/O point on the ECM2 physical connectors

1. Which area ?
 2. When, attached to which task ?
 3. Which hardware, which driver ?

I/O Group	Board / I/O Module	Range	Task	Comment
PB Inputs Grp	Hilscher CIF	%B11 .. %B11	T_200ms	PB Inputs
IO_Config_Out_1	INTERBUS G4	%Q80 .. %Q83	T_200ms	IBS 24 DO




1. User has to create IO Group Name and assign the Task associated with this IO group.
2. Start address (can be any address within range of 32 bit addressing), overlapped is NOT allowed within process image and will create errors.
3. PII and PIQ have totally separate addressing range.
4. Length: total number of bytes based on the first IO group selected and how many IO point user want to map to the specific group




6.1.1.1 Digital Input Mapping

1. Click on Add if user wants to create a new IO group



2. Create a meaning full name for the IO group: ECM2_DI for ECM2 digital inputs was used as example.
3. Select the Task associated with the IO mapping
4. Select by task for refresh and Driver for Device (other options are not supported)
5. Highlighted ECM2 as driver option and click on Driver parameters for further configuration
6. Start address can be any address where the combination of start address and length is not overlapping with other already mapped IO groups.
7. Length will be explained in later slide



Properties

Name: ECM_DI

Task: Task1

Logical address: <default>
Task2
Task1

Start address: Task1

Length: 27

End address: %IB 26

Data configuration

Retain

Refresh

by task
 manual

Device

Driver
 Memory

Board / IO Module:

ECM2
Hilscher CIF
INTERBUS G4
MKS DeviceNet
Modbus/TCP
User defined Input



Comment: ECM2 Digital Input

OK
Cancel
Description...
Driver Parameter...

8. Choose the driver you want to map and select the first physical IO group where your mapping first start.
9. The total number of bytes available for logical memory for all 210 Digital Inputs of ECM2 is 27 bytes.


10. Each logical byte is mapped to 8 digital inputs, each bit in a byte represent a physical digital input of ECM2

- Example 1: If user only wishes to map the first 16 digital inputs (1-16) to this group, select DI Group 1-8 then click OK. Starting address could be anything not used before (within available 32 bits addressing allocation) and length will be 2 bytes.



11. In the example 1 above, the logical address will be mapped to physical IO of the ECM2 as follow:


Byte Address	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
0	DI8	DI7	DI6	DI5	DI4	DI3	DI2	DI1
1	DI16	DI15	DI14	DI13	DI12	DI11	DI10	DI9
2								
3								
4								
5								
6								
7								
8								
9								



ECM2 Physical Digital Inputs 1-16

12. Example 2 for digital input 17-48 mapping: starting address is 8, length is 4 bytes. The logical address will be mapped to physical IO of the ECM2 as follow:

Byte Address	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
0	DI8	DI7	DI6	DI5	DI4	DI3	DI2	DI1
1	DI16	DI15	DI14	DI13	DI12	DI11	DI10	DI9
2								
3								
4								
5								
6								
7								
8	DI24	DI23	DI22	DI21	DI20	DI19	DI18	DI17
9	DI32	DI31	DI30	DI29	DI28	DI27	DI26	DI25
10	DI40	DI39	DI38	DI37	DI36	DI35	DI34	DI33
11	DI48	DI47	DI46	DI45	DI44	DI43	DI42	DI41
12								




ECM2 Physical Digital Inputs 17-48

6.1.1.2 Analog Mapping

1. Currently, analog inputs are differential
2. A pair of pins forms one differential analog input
3. For example: AI0- and AI0+ (from AI0 and AI1 pair) forms differential analog input 1 (as based 1 reference from the mapping)
4. Each analog requires two bytes of data (single-ended or differential does not change the number of bytes needed for data representation)

- This example maps only one analog input (AI0) to the group called ECM_AI, starting at an address 20, and length of 2 bytes



Starting Address at 20

Length is 2 bytes

Process Input Image

AI0 (+) JB (pin14)

AI0 (-) JB (pin13)

Byte Address	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
0	DI8	DI7	DI6	DI5	DI4	DI3	DI2	DI1
1	DI16	DI15	DI14	DI13	DI12	DI11	DI10	DI9
:								
8	DI24	DI23	DI22	DI21	DI20	DI19	DI18	DI17
9	DI32	DI31	DI30	DI29	DI28	DI27	DI26	DI25
10	DI40	DI39	DI38	DI37	DI36	DI35	DI34	DI33
11	DI48	DI47	DI46	DI45	DI44	DI43	DI42	DI41
:								
20	Analog Input 0 LSB							
21	Analog Input 0 MSB							
22								
23								

6.2 Writing IEC code and compiling and downloading to unit

IEC coding will be created in the MyPOU (as created by user when the project is created). After the IEC code is completed, it needs to be compiled and downloaded to the ECM2.

For full reference of using Multiprog, please refer to the KW-Software documentation.

6.2.1 Compiling

There are several ways to compile the project once you have finished editing. The corresponding menu items are provided in the 'Build' submenu. Additionally each command is available as a toolbar icon.




Figure 6-18 Compiling the Multiprog code

- **'Make'** - Standard mode for compiling the project once you have finished editing. The menu item can be used to compile all worksheets which have been edited. These worksheets are marked with an asterisk in the project tree. After using 'Make' the specific code is generated and the project is ready for downloading to the PLC.
- **'Patch POU'** - This command is used to compile only modifications, which have been made e.g. after debugging a project. The changes are automatically downloaded to the PLC while the IEC keeps on running, i.e. the program execution on the PLC is not aborted. So you can view changes immediately after switching the corresponding worksheet into online mode. While patching a POU it is not necessary to stop the program execution on the PLC.

Alternatively send and apply program modifications to the target using the '**Download changes**' feature.

- '**Compile worksheet**' - This menu item is used to compile a single worksheet after editing it. Choosing this menu item means, that syntax errors within the current code body worksheet and the related variable worksheet are going to be detected by the compiler. All detected errors and warnings are displayed in the message window. By double clicking on an error or warning you can open the related worksheet, where the error was detected.

No code is generated when Using 'Compile Worksheet'!

When closing or saving a worksheet, the system automatically compiles this worksheet. Additionally the variables worksheet is compiled.

This automatic compilation makes each user defined function or function block available in the **Edit Wizard** immediately after saving the corresponding worksheet.

- '**Rebuild Project**' - This menu item is used to compile the whole project for the first time or if a user library has been changed. It should only be used, if 'Make' generates compiler errors, if you have unzipped your project without the front end code or if changes have been made in an announced user library.
Using 'Rebuild Project' all worksheets are going to be compiled and linked. Detected errors and warnings are displayed in the message window. After the syntax checking the IEC code as well as the PLC specific code is generated automatically. The project is then ready for downloading to the PLC.

Automatic cross references update before compilation:

The 'Build' tab of the 'Options' dialog (menu item 'Extras > Options...') provides the checkbox 'Update cross references before compilation'. After marking this option, the cross reference list is automatically updated prior to compiling the project using the commands 'Make' or 'Rebuild Project'. The progress of this update operation is displayed in the 'Build' tab of the message window.

Excluding resources from compilation:

If your project contains several resources, you can exclude individual resources when making or rebuilding the project or when patching POUs. For that purpose right-click on the resource node to be excluded (in the subtree 'Physical Hardware') and select 'Exclude' from the context menu.

The context menu item of the affected resource is now checked and the resource node icon as well as all included elements are put in parenthesis as shown in the following example:

To re-include an excluded resource into the compilation process, select the context menu item 'Exclude' again (the item is then shown unmarked).

KW-Soft Multiprog help file has lots of information on creating PLC code and compiling.




Figure 6-19 Locating the Multiprog help contents

The KW-Soft Multiprog Help File provides information on creating PLC code and compiling. For additional information on programming in Multiprog, refer to the KW website on Multiprog project at: <http://www.kw-software.com/com/service/2680.jsp>

6.2.2 KW Multiprog Project Control and Download

Once a project is compiled using 'Make' or 'Rebuild Project', it must be downloaded to the target simulation(s) or to the connected PLC(s).

The system recognizes, whether the program must be downloaded to only one or to several available target resources. Depending on the number of resources in the subtree 'Physical Hardware', different dialogs can be used for downloading as shown in the following figure:

On the left side, only one resource is available. Therefore, clicking the 'Project Control' icon directly calls the resource control dialog (1). Clicking 'Download' in the control dialog opens the 'Download' dialog (2).

On the right side, 2 resources are included in the project. Therefore, clicking the 'Project Control' icon on the toolbar opens the 'Project

Control' dialog (3). In this dialog, all selected and connected PLCs can be controlled together. Clicking the 'Control' button opens the resource control dialog for the selected resource (4), thus enabling the individual PLC control.




Figure 6-20 Opening the Multiprog Project Control dialog box

Control Dialog box




Figure 6-21 The Multiprog Project Control dialog




Figure 6-22 Multiple Resource control in Multiprog

Additionally you have the possibility to download changes (without stopping the program execution on the PLC), to download the project source or a file of any type individually to each connected resource, in order to store it or for any other future usage.

Table 6-2 Dialog Element table and description

Dialog element	Meaning
----------------	---------

Dialog element	Meaning
resources list	<p>This selection list contains all resources which are defined in the subtree 'Physical Hardware'. Each available resource is represented as one line in the selection list.</p> <p>The list consists of several columns:</p> <p>Resource: indicates the resource name.</p> <p>Configuration: indicates the name of the configuration to which the resource belongs.</p> <p>Status: indicates the state of this PLC or simulation. The status 'Offline' means, that no communication connection is established between the dialog and the resource.</p> <p>Please refer to the note below this table.</p> <p>Info: shows a short information about the current PLC state or the progress of operations (e.g. project download).</p>
Online 'Connect' 'Disconnect'	<p>The dialog 'Project control' always starts offline, except a communication channel already is established to a particular resource, because at least one related worksheet is opened in online mode.</p> <p>Please refer to the note below this table.</p> <p>Using the commands in the dialog area 'Online' you can control the connections between the dialog 'Project control' and the resources.</p> <p>Both buttons in this area relate to each resource selected in the resources list.</p> <p>Connect: The system tries to establish the connection to each PLC IEC or simulation marked in the resource selection list.</p> <p>Disconnect: The system terminates the connection to each PLC or simulation selected in the resources list.</p> <p>If you are disconnecting a particular resource by clicking this button, this only affects the communication connection between the dialog 'Project control' and this resource. Worksheets in online mode of the same resource are not switched offline by this operation! (See note below this table.)</p> <p>The state of each selected resource is displayed in the selection list column 'Status' after executing the command.</p>
Select all	Marks all resources in the resources list.
Download 'Project' 'More...'	<p>Using the buttons in the dialog area 'Download' you can initiate the download procedure. Both buttons in this area relate to each resource selected in the resources list.</p> <p>Precondition for starting a download is that the connection to a resource has already been established (using the 'Connect' button).</p> <p>A button appears inactive (i.e. grey) if you have selected a resource in the resources list, for which the command relating to the grey button cannot be executed at this moment. A possible reason may be that one of the selected resources is in the TIMEOUT state or the connection has not been established properly. In this case you have to deselect the affected resource in order to activate the button for the remaining resources which are ready for the download.</p> <p>'Project': After clicking this button, the system sends the whole project to each selected and connected simulation or PLC. The download progress is indicated as a percentage value in the column 'Info' of the resources list.</p> <p>'More...': This button calls the 'Download' dialog, which is used to initiate further operations for all selected resources. Click here for a description of this dialog.</p> <p>Both buttons in the area 'Download' remain inactive (grey) while the download is in progress for at least one resource.</p>
Control 'Cold'	Using the buttons in the dialog area 'Control' you can control all selected resources, i.e. an invoked command is executed for all resources marked in the selection list.

Dialog element	Meaning
'Warm' 'Hot' 'Stop' 'Reset' 'Control...'	<p>A button appears inactive (i.e. grey) if only one of the selected resources is not able to execute the related command. A possible reason may be, that one of the selected resources is in the TIMEOUT state or the download has not been finished successfully. In this case you have to deselect the affected resource in order to activate the button for the remaining resources which are ready to execute the command.</p> <p>If, for example, one resource is in 'Run' state and the others in the 'Stop' state, the 'Cold' button remains active. In this case, the start command is downloaded only to those resources which are in the 'Stop' state.</p> <p>'Cold': executes a cold start on all selected resources. During a cold start all data are initialized. 'Warm': executes a warm start on all selected resources. During a warm start only non-retentive data are initialized. 'Hot': executes a hot start on all selected resources. During a hot start no data are initialized.</p> <p>The hot start can be disabled by checking the checkbox 'Disable Hotstart' on the 'Debug' tab in the 'Options' dialog. After changing this option, the resource control dialog must be closed in order to apply the changed setting.</p> <p>'Stop': stops the program execution on all selected PLCs or simulations. 'Reset': resets all selected PLCs or simulations. 'Control...': Calls the control dialog for each selected resource. If breakpoints are set for one resource, the related control dialog 'Resource_name' displays the buttons 'Step', 'Trace', etc. automatically.</p>
Close	<p>closes the dialog 'Project control'. The communication path between the dialog and the connected resources are terminated. When re-opening the dialog, the communication status 'Offline' is displayed for each resource and you have to re-connect the desired resources in order to control them using the dialog 'Project control'. Please refer to the note below this table.</p>

NOTE: Communication channels between the system and a resource:

Each time you access a PLC (in order to download a program, control the PLC using the buttons 'Cold', 'Stop' etc., or switch a worksheet into online mode) the system establishes a communication connection to the requested PLC. In the dialog 'Project control' this is done using the button 'Connect'. In the control dialog 'Resource_name' and when switching a worksheet into online mode, it is performed automatically. When closing the dialog 'Project control' or the control dialog 'Resource_name' or switching an online worksheet back into offline mode, the communication connection is terminated.

For that reason the connection between dialog and PLC is already established if you are calling the dialog 'Project control' while a worksheet is in online mode.

This does **not** mean, that the resource state changes, because the program execution on the PLC is still executed, although the communication path between the programming system and the resource has been canceled.

6.2.3 MKS Firmware Library

This includes the function blocks for the additional serial ports and the switches and LEDs. Follow the steps below to insert and use the serial ports and LED from your IEC program.

1. On your Multiprog project, right-click on **Libraries->Insert->FW Library** as shown below




Table 6-3 Inserting the ECM2 firmware library

2. On your Multiprog project, right-click on **Libraries->Insert->FW Library** then select the path for the libraries as shown below. Normally, this is the default path.




Table 6-4 Locating the installed firmware library

3. Then select ECM2.FWL and click Include. This allows access to the built-in function block for the serial ports.

NOTE: Only two ports are enabled:

- Port 1: J28
- Port 2: J29




Table 6-5 Selecting the firmware library

4. To use the serial ports in your PLC, it is necessary to open and use the handle to read and/or write. The screen below shows how to open and use the handle to read the port with the file handle thru ladder logic language.
 - a. The blocks can be located via the right-side drop-down labeled “**Group**”. This is the list of built-in functions that were just added in the steps above. Select ECM2 for the blocks specific to the ECM2.




Figure 6-23 Example of serial port function blocks

The configuration parameters for your COM ports are shown below. These are based on the built-in function blocks above:

6.2.3.1 ECM_RS232_OPEN block

Table 6-6 Parameters of the RS232 Open block

Parameter	Data type	Description
EXECUTE	BOOL	Open serial port to read if a rising edge is detected.
PortNum	USINT	1 = Serial port J28 2 = Serial port J29
Baud	UDINT	300= 300 Baud. 9600 = 9600 baud Up to 115200 Serial baud support: 300, 600, 1200, 2400, 4800, 9600, 14400, 19200, 38400, 57600, 115200
Bits	USINT	7 = 7 data bits 8 = 8 data bits

Parity	USINT	0: No parity. 1: odd 2: even 3: mark 4: Space
Stop	USINT	0: 1 stop bit. 1: 1 ½ stop bits. 2: 2 stop bits
BufferSz	UINT	HW buffer size. Limit to 1KB HW buffer. New data will be discarded when buffer is full.
Done	BOOL	0: The function block was not executed. 1: The function block was executed.
Handle	UINT	File handle of the file from which should be read.
Error	BOOL	0: No error occurs while opening/creating the file. 1: error occurs while opening/creating the file.
ErrorID	DWORD	Windows last error code on opening the port.

6.2.3.2 ECM_RS232_READ and WRITE block

Table 6-7 Parameters of the RS232 Read and Write block

Parameter	Data type	Description
EXECUTE	BOOL	Read serial data from buffer if a rising edge is detected.
Handle	DWORD	File handle of the file from which should be read.
MaxLength	UDINT	Number of characters to be read.
Buffer	Any	Data buffer for the data to be read. This should be an array.
Done	BOOL	0: The function block was not executed. 1: The function block was executed.
LengthAvailable	UDINT	Number of read characters.
BufferSz	UINT	HW buffer size. Limit to 1KB HW buffer. New data will be discarded when buffer is full.
Error	BOOL	0: No error occurs while opening/creating the file. 1: error occurs while opening/creating the file.
ErrorID	DWORD	Windows last error code on reading data.

7 Programmable Interlocks

7.1 Overview

Interlock is a safety function that protects a system from hazardous states. It disables the operation of external devices if a pre-defined state of input conditions is not met. Programmability enables the user to define interlock functions without having to rewire the board each time. The design concept is based on one common design code that processes a user file.

Section 7 details the safety features and show how to program an Interlock on the ECM2 programmable Interlock module.

No logic file is loaded on the ECM2 unit as shipped from the factory.

7.2 Main Features

1. Implement 1oo2 programmable logic architecture.
2. Meets SIL-3 reference: IEC61508 (SIRA FSP 08005)
3. Based on single form factor boards.
4. The interlock logic file is downloaded via FTP.
5. Self-Diagnostic.
6. Programmable De-bounce on inputs.
7. 48 interlock digital inputs (24V) + 1 Watch Dog Input (TTL).
8. 32 real output functions (1-32)
9. 24V, 3.3V input Power protection against: Over Voltage (OV), Under Voltage (UV), and Over Current (OC).



This product is only intended to be used within the 61508 'overall lifecycle'.

7.3 Operation Description

There are two modes of operation:

1. Prog/Debug
2. Operational

In the Prog/Debug mode the following functions are available:

1. Load the Interlock Logic (IL) and the Product Data EEPROM.
2. Read the content of the EEPROM.

In Operational mode the access is limited to few registers for monitoring:

- Status register.
- Inputs register.

Outputs register.

A mechanical **rotary switch** is used for mode selection. It is designated in Figure 7.1. Operational mode is set with the rotary switch pointing to '0'. Prog/Debug mode is set with the rotary switch pointing to '9'. Other positions of the rotary switch are not defined. The switch is not easily accessible to avoid unintentional change. Prog/Debug will set the outputs to off regardless of the IL functions. Further control on the outputs is possible via the debug registers as described in HW support for Debug.




Figure 7-1 Locating the programmable interlock board switches



Moving the switch from Prog/Debug to Operational mode will take effect any time. The other direction, from Operational mode to Prog/Debug will take effect only after system reset or recycle of the board power.

7.3.1 Prog/Debug Mode

The user must set the switch to Prog/Debug and turn the power off and on. This will set the outputs to their off position for each channel. The user can program the interlock logic via FTP (File Transfer Protocol). The configuration file includes an integrity check value.

7.3.2 Operational Mode

When the unit is set to Operational mode, it will perform an integrity check on the data (based on CRC). If no errors are detected, the outputs will be set to follow the IL functions

7.3.3 Debounce on the Inputs

A debounce mechanism is applied on the inputs (Except Watch Dog Input). The input signal must be stable during a predefined period of time in order to be resample and used by the IL. This period of time is a parameter set by the user in the DEB_DELAY 3 bit field of the Status Control register as follows:

Table 7-1 – Interlock Inputs Debounce Values

DEB_DELAY Value (3 bit)	Period of time for which the input signal must be stable in order to be sampled in. Otherwise previous signal value is kept.
0	125 us
1	250 us
2	375 us
3	500 us
4	625 us
5	750 us
6	875 us
7	1000 us

Default value for the debounce delay DEB_DELAY is 0 which is 125uS

7.3.3.1 Set Debounce for Interlock Inputs

Follow the instruction steps below to set the debounce for the interlock inputs.

1. Open a telnet session to the unit IP address.
2. Change directory to Windows by typing “cd Windows”




Figure 7-2 Telnet view for setting debounce

- To set the debounce value at 750uS, at command prompt, type "PrgIntlk SETDB 5". User should get a similar screen to below confirming the new debounce values




Figure 7-3 Completing the setup of debounce

7.4 Interlock Status Bit Map Table

Position	Field Name	Value after reset	Access	Meaning
0	RDONE	0	R	A '1' indicates completion of IL and DP load from EEPROM into the FPGA.
1	ILRST	0	R	IL EEPROM Read Status 0 – OK. 1 – Error.
2	DPRST	0	R	DP EEPROM Read Status: 0 – OK. 1 – Error.
3	ILV	0	R	Interlock Logic Valid: 1 – IL EEPROM revision matches PD EEPROM (P/N). 0 - No match, or the ILK is in programming mode.
4	FORC	0	R	FPGA Outputs to Relay Compare: 0 – No match between the FPGA and Relay. 1 – Match.
5	NAL	0	R	FPGA Neighbor Not Alive bit. 1 – The neighbor FPGA is alive. 0 - The neighbor FPGA is not alive. (see Self Test section).
6	SWMOD	X	R	Position of the Switch Mode for the user Interface SW. 1 – Operational mode 0 – Prog/debug mode
7	RLY_24V_EN	X	R	Status of FW code verifier which is used to enable the 24V to the relays. 1 – FW is ok, 24V is enabled. 0 – FW doesn't match, 24V is disabled.
8	OUTSEL	0	R/W	Select the source for Output: 1 – The Output ON/OFF Register is selected for output. The output value will be according to that register. 0 – The IL function is selected for output. Effective in Prog/Debug mode only. In Oper mode the IL function is selected for the output at the end of FPGA init process regardless of this bit state.
9	INSEL	0	R/W	Select the source for the Input: 0 – The actual input (Opto out) is selected.

				1 – The Input Emulation Register is selected.
10-12	DEB_DELAY	0	R/W	Defines the debounce time period. See section: Debounce on Inputs.
13	Global Reset	0	R/W	Resets the entire FPGA, active high.
14	24V_MONITOR	X	R	Status of 24V voltage monitoring 0- The 24V level out of correct range of operation. 1- The 24V level within the correct range of operation.
15	ILOAD	0	W/R	Used in Prog/Debug mode: Writing a '1' will launch the process of loading the IL file from the EEPROM into the FPGA with check. The '1' is latched. At the end of the process the FPGA will clear this bit. Any access in other mode has no effect. Before each new launch the process of loading, after the first launch, needed to be issued Global reset via bit "Global Reset" in CSR register.

Meaning of Status bits (examples):

RDONE	ILRST	DPRST	ILV	FORC	NAL	Output State	Meaning
1	0	0	1	1	1	Enabled	This is operational normal run state: The FPGA had successfully loaded the IL and DP files, IL file match PD P/N, IL output matches Relay state, and second FPGA is alive.
1	1	0	0	0	X	Disabled	An example of an error: FGPA had completed the read of IL file but with error. The ILV and FORC will remain 0 and the output will be disabled.
0	0	0	0	0	0	Disabled	The FPGA didn't complete the read of IL and DP files. Within time period of ... after power up or ILOAD command, it is normal. Beyond this time period it's an error.
1	0	0	0	0	0	Disabled	Files IL and PD had been loaded successfully but no match of IL with PD P/N.

7.5 Interlock Output Logic

Each Interlock output logic can have up to a combination of eight **AND** gates that all feed into an **OR** gate. Each **AND** gate can be any combination of the available interlock inputs or output feedback channel.




Figure 7-4 Non-Inverted Interlock Output Logic

The interlock output can also be inverted. Figure 7-5 shows the inverted Interlock output logic.




Figure 7-5 Inverted Interlock Output

7.6 ViSim Tool for Interlock Output Logic Commissioning

The ViSim is a GUI tool based on MS Office VISIO with underlying Visual Basic code. The tool enables the user to build interlock logic by interconnecting relays and I/O symbols, simulate the design, and generate a 'csv' file. This file can then be loaded into the Prog Interlock platform via FTP.

7.6.1 Installation

7.6.1.1 Requirements

The following applications need to be installed.

1. MS Office Excel 2007 or 2010.

NOTE: Other versions of MS Office Excel are not supported at this time of writing.


2. MS Office Visio 2007 or 2010.
3. In some cases, registration of the below Dynamic Libraries are needed in order to make ViSim works with Visio

C:\Windows\system32\scrrun.dll

C:\Program Files\Common Files\Microsoft Shared\DAO\dao350.dll

C:\Program Files\Common Files\Microsoft Shared\DAO\dao360.dll

To register the above dll, at window Start->Run type regsvr32 "path to dll location". An example of the first dll registration with regsvr32 is shown below



A message similar like below will indicate that dll registration is successful. If not, please check syntax and location of the dll.



7.6.1.2 Installation

1. Copy the ViSim folder into your local drive. This folder is available via download from the MKS website at:

<http://www.mksinst.com/product/product.aspx?ProductID=1227>

[Visim Logic MS-Visio **sample files** \(referenced in the Visim User Guide\)](#)

2. Change the security level for macros to 'Low' as follows:

- Open blank Visio document.
- On the menu bar: **File->Options->Trust Center**.
- Once in the Trust Center, click on **Macro Settings**, and select the radio button labeled "**Enable all macros**". Then, check the box labeled "Trust access to the VBA project object model".

Note If you check a higher security option the macros will be blocked

•



Note You may need to restart the Visio for the changes to take effect after changing security option.

7.7 Tutorial – Creating a Logic file using ViSim

This section details the process of design, simulation and generation of the cvs file through the use of example.

7.7.1 Create New File:

Open the ViSim folder and double-click on 'ViSim Drawing Template.vsd'. This file is a template with underlying VB code. 'Save As' this file into the same folder with your selected name.

7.7.2 I/O Map File:

Before drawing the logic, you need to have an Excel file with the I/O definition. By default the tool will refer to the following file:

.....\ViSim\work\IO_MAP.xlsx

The file contains two sheets, the first for the inputs, second for the outputs. Use default labeling of the first sheet as "In" and the second sheet as "Out".

The sheet structure is shown below: The first column contains the input user name (or signal name), and the second column contains the index of this input in the Programmable Interlock. The third column contains the location of this input on the Distribution board. Use a similar structure for the second sheet.

7.7.3 Edit the Visio File:

Open the ViSim folder and double click on 'ViSim Master.vsd'. This file is a template with underlying VB code. 'Save As' this file into the same folder with your selected name. You may notice the new tab item 'Add-Ins' on the ribbon and a new sub-item labeled 'Interlock'.





Figure 7-6 Locating the Add-Ins tab on the MS-Visio ribbon

Following any modification of the IO_MAP file, run the 'Validate IO_MAP file' in the 'Interlock' menu. This function checks the file for the following errors:

1. Illegal sheet names
2. In or Out indexes out of range (in < 0 or in > 64, out < 0 or out > 65) or illegal chars.
3. Duplicate indexes.
4. Duplicate Descriptions.

The tool will not let you edit and compile a design without validated IO_MAP file.



	A	B	C
	User		
1	Input name	DIN#	User Pin#
2	GAS1-OP	1	J1-23
3	GAS2-OP	2	J1-24
4	OVR-TMP	3	J1-15
5	DOOR1	4	J2-4
6	DOOR2	5	J2-5
7	VALV1	6	J3-14
8	VALV2	7	J3-15
9	VALV3	8	J3-18
10	IN-9	9	J3-19
11	IN-10	10	J3-20

Figure 7-7 Example of IO Map Excel Spreadsheet file.

7.7.4 Draw The Logic:

If you have anything already drawn on the page, just select and delete.

From the 'Drawing' stencil on the left of the page, drag two 'INPUT' one RELAY and one OUTPUT symbols and drop them on the page. Drag the LINE symbol and drop it on the page. Then stretch the edges of the line

by using the mouse with the left click button held down and tie them to the symbol pins as shown in the following figure. You'll need to drag the LINE three times.




Figure 7-8 Simple one AND gate logic example with ViSim

7.7.5 Assign Inputs and Output.

Place the mouse pointer close to the INPUT symbol, until a small menu item appears as shown in Figure 7-9.




Figure 7-9 Selecting Input using drop down menu in ViSim

NOTE: If the input symbols are spaced too closely together, the input menu may not be easily accessible using the mouse to cover the input symbol. The user can change input signal by selecting the input symbol with ribbon tab->Add-Ins->Interlock->Edit I/O as shown in [Figure 7-10](#)~~Figure 7-10~~.




Figure 7-10 Selecting Input using drop down menu in ViSim

Click on this menu item and then click again on the 'Edit Pin #' sub item.

You will get a form as shown in Figure 7-11. The data within this form is taken from the IO_MAP.xlsx file. Click on any one of the items in the list, and then click the 'Assign' button. The form will be closed and the selected data will appear on the INPUT symbol. Do the same for the second INPUT symbol and the OUTPUT symbol.

At this point the I/O is assigned to the input and output symbols.




Figure 7-11 IO selection from spreadsheet IO file

7.7.6 Generate CSV (Coma-Separated Value) File.

Click on the Visio tool bar icon as shown in Figure 7-12.
The created file is:

...\ViSim\work\intlkcfg_user.csv




Figure 7-12 Generating CSV file from Visio ViSim Tool.

This will activate the netlist generator and the csv file generator. At the end of the netlist generation a message 'Connections Complete' will appear, then a message 'csv File creation completed' will appear. Press OK to both messages.

At this point, the following should appear on the Visio page. Note that the symbols are designated, and also note that the small red circles around the pins disappeared to indicate the connection has been made.




Figure 7-13 Complete interlock sample design ready for simulation

Note: All input symbols used in interlock design must be assigned a signal name. Leaving a connected input symbol with “no name” will result in an error. The error path will be highlighted with red wire to the un-assigned input signal as shown in Figure 7-14




Figure 7-14 Complete interlock sample design ready for simulation

7.7.7 Logic example

The example above will generate the below logic in Figure 7-15 Equivalent Logic for the simple example above.:

$$OUT1 = IN4 \text{ and } IN5$$



Figure 7-15 Equivalent Logic for the simple example above.

7.7.8 The Default CSV File:

The file created is: ...\\ViSim\\work\\intlcfg_user.csv

Figure 7-16 shows the logic definition section in this file, in which one AND term is composed of the inputs 4 and 5. This AND term is assigned to output 1.

114		64	Input 64			
115		65	Watchdog			
116	IN	O1	O2	O3	O4	
117		4	A1	-	-	-
118		5	A1	-	-	-
119	OUTFB	O2	O3	O4	O5	
120	OUTNUM					
121						
122						

Figure 7-16 CSV file generated by ViSim Tool for example above

7.7.9 Simulate the Design

Turn the inputs ON and OFF by moving the mouse pointer as shown in Figure 7-17 to activate the drop down menu.




Figure 7-17 Button to toggle inputs for simulation.

Then click ON or OFF to simulate the output




Figure 7-18 Toggle an input ON or OFF to simulate programmable logic design

Figure 7-19 shows the result when both inputs are ON:




Figure 7-19 Result of simulation when logic is TRUE and activates the output.

To reset the simulator click on the tool bar icon as shown below:



Figure 7-20 Reset simulation condition on ViSim tool.

7.8 Logic Structure

7.8.1 Combined AND/OR Logic Term

Relays can be connected to form various logic structures. The following example shows a combination of AND and OR terms.




Figure 7-21 More complex logic structure

The logic term represented by this structure would be:

$$\text{Out1} = (1 \text{ and } 2 \text{ or } 3 \text{ and } 4) \text{ and } 5 \text{ and } 6 \text{ and } (7 \text{ and } 9 \text{ or } 8 \text{ and } 10)$$




Figure 7-22 Equivalent logic gate for figure 14



Note

The logic above depicts the equivalent logic equation for interlock logic condition, not the actual TTL gate level for timing analysis purposes.

The resulting 'csv' is shown on the right.

Note that the tool uses other free outputs (actual or virtual in this case O2 and O3) to form the logic parts and feed them back to output 1.

114	64	Input 64			
115	65	Watchdog			
116	IN	O1	O2	O3	O4
117	1	-	-	A1	-
118	2	-	-	A1	-
119	3	-	-	A2	-
120	4	-	-	A2	-
121	5	A1	-	-	-
122	6	A1	-	-	-
123	7	-	A1	-	-
124	8	-	A2	-	-
125	9	-	A1	-	-
126	10	-	A2	-	-
127	OUTFB	O2	O3	O4	O5
128	2	A1	-	-	-
129	3	A1	-	-	-
130	OUTNUM				
131					

Figure 7-23 ViSim generated CSV file for more complex logic design above

7.8.2 Latch Structure

The following structure realizes a latch function. Given that the upper AND term (1 * 2 * 5 * 6) is true, when the inputs 3 and 4 (the latch condition) turns ON, the relay U5 will be energized for a short period as dictated by the capacitor, and then due to the feedback on U5 (pin 4 to pin3) the relay will be kept energized. Once the upper condition turns false, the relay U5 will be de-energized.




Figure 7-24 Example of Latch and Clear Interlock design

The example in Figure 7-24 is translated into the csv file shown on the right:

The latch condition is assigned to AND term #1 (A1). The latched function is assigned to A3. The clear condition is the same latched function inverted by using a free output (in this case O2) and then fed back to O1 as term #2.

115	65 Watchdog			
116	IN	O1	O2	O3
117	1	A3	A1	-
118	2	A3	A1	-
119	3	A1	-	-
120	4	A1	-	-
121	5	A3	A1	-
122	6	A3	A1	-
123	9	-	-	-
124	10	-	-	-
125	OUTFB	O2	O3	O4
126		2	A2	-
127	OUTNUM	A1->L	INV	
128		A2->C		
129				

Figure 7-25 CSV file with Latch condition

7.8.3 Download the Logic to ECM2

Once the interlock logic is simulated successfully and csv file is generated, following the below step to download the logic file in csv format to the ECM2 and program it to EEPROM

1. NOTE: Make sure the rotary switch for interlock is switched to program mode (switch pointing to 9 position then power toggle the unit) for the EEPROM program to take effect.

2. Open a command window from your PC where you create the Visio Interlock file. Change directory to where the csv file resides.
 - (a) This should be in the same Visim folder with the Visio file under work directory, for example if you put the Visim folder in the root C:\ directory, the generated csv file will be in C:\ visim\work
 - (b) The generated csv file name is fixed as **intlkcfg_user.csv**. Make sure to rename existing intlkcfg_user.csv file to a different name for archive before generating a new logic csv file. Existing **intlkcfg_user.csv** will be overwritten.
3. From the same command window in step 1, Open an FTP session to the ECM2 unit by typing “ftp 192.168.1.3”
4. Enter anonymous/anonymous for user name and password, respectively when prompted for.
5. Type “put intlkcfg_user.csv”
6. When FTP transfer completes, close the FTP window.
7. Open a telnet session to the ECM2 unit. You can open a command window and type “telnet 192.168.1.3”
8. Change directory to Windows by typing on the command prompt “cd Windows”
9. Type “PrgIntlk SETIL \Temp\intlkcfg_user.csv”. If unit is already in program mode, user should see a screen similar to the below

```
Telnet 10.202.3.152
Writing IL to EEPROM1.....
Writing IL to EEPROM1 Ok.
EEPROM 2:

Opening \Temp\intlckfg_user.csv..DONE.
Parsing CSV file..

IN 1, 01 = A1
IN 2, 01 = A1
IN 2, 03 = A3
IN 2, 05 = A1
IN 3, 04 = A1
IN 4, 03 = A3
IN 4, 04 = A1
IN 4, 05 = A1
IN 5, 02 = A1
IN 6, 02 = A1
IN 7, 04 = A2
IN 8, 04 = A2
IN 9, 02 = A1
IN 10, 01 = A1
IN 10, 02 = A1
IN 11, 02 = A1
IN 12, 02 = A1
IN 13, 03 = A3
IN 13, 05 = A1
IN 14, 03 = A3
IN 14, 05 = A1
IN 15, 03 = A3
IN 15, 05 = A1
IN 16, 03 = A1
IN 17, 03 = A1
IN 18, 03 = A1
OUTFB 4, 02 = A1
OUTFB 5, 03 = A2
OUTNUM3, INU=0, A1->L=1, A2->C=1
OUTNUM5, INU=1, A1->L=0, A2->C=0

Creating binary image from CSV..
Retrieving Product Name from Registry for IL Header..
Could not acquire access to key HKEY_LOCAL_MACHINE\ProductCfg\ProductName.


Writing IL to EEPROM2.....
Writing IL to EEPROM2 Ok.
Write IL Completed Successfully!

*****

Cleaning up on exit...
Closing handle to Interlock Device Driver...OK.

Application Exit Complete.
\Windows>
```

10. Make sure the rotary switch for interlock is switched to program mode (switch pointing to 9 position then power toggle the unit) for the EEPROM program to take effect.



```

Telnet 10.202.3.152
>>>>>>
> cd Windows
\Windows> PrgIntlk.exe SETIL BOTH ..\Temp\intlckfg_user.csv

PrgIntlk <Revision:1.002, Build Date: Mar 16 2012 18:24:30>
Opening handle to Interlock Device Driver...OK.
*****
That function is not accesible while Interlock is in RUN mode!
*****

Cleaning up on exit...
Closing handle to Interlock Device Driver...OK.

Application Exit Complete.
\Windows>

```

7.8.1 Troubleshooting

1. After opening the IO_MAP excel file no sheets are visible.

Resolution: In the menu bar select 'View' and then 'Unhide'. Select the IO_MAP workbook and then press 'OK'.

2. For Visio 2010 version, if you have an error popped up saying ActiveX Cannot Create Object with error code 429. Please refer to section 7.5.1.1 for dll registration of Microsoft Dynamic Libraries.

7.9 Maintenance and Safety

7.9.1 System Periodic Test/Monitoring

User must periodically monitor the internal status bits of the Prog Ilk over the network for any indication of failure. The monitoring system will alarm in the case of a failure, alerting the user that the tool's safety process requirement and specification indicate a need to replace the unit.

7.9.2 Self-Test

A periodic test of the HW can decrease probability of failure. In our case, since there is a redundant architecture (1oo2), after a channel failure, a functioning channel still remains to provide the time necessary to replace the board. The self-test is based on two functions: Channels Output Comparison, and Mutual Alive Sign.

7.9.3 User Relay Diagnostic Test

The programmable Interlock has self-diagnostics features that can diagnose internal circuit failures while in operational mode. This is achieved through the 1oo2 topology of the design.

Each output channel has two Relays connected serially such that if one fails to open (safe state) the other will back up.

These Relays are not diagnosed by the design for a case of contact fail to open. They need be tested once a year in order to comply with the SIL-3.

This test is supported by a dedicated circuit that is part of the Programmable Interlock design and requires human activation.

7.9.4 Proof Test

Proof Test Interval: Every 12 Months.



For certain industries, the maintenance of IEC61508 SIL3 certification requires that this proof test be performed yearly.

7.9.4.1 Proof Test Definition

The periodic test should include short circuit test on output relays, transistor switch test, and input connector short circuit test.

7.9.4.2 User Test Procedure

1. Turn off the power to the unit.
2. Disconnect all DI/O cables from connector's panel.
3. Remove the cover on the side panel as illustrated in the following figure (Layout of I/O connector for illustration purpose only, they may differ between systems).

Figure 7-26 Removing the interlock board side panel



Image is for illustration purpose only. Actual layout might be slightly different than 3D model rendering.

IMPORTANT: Keep side panel cover on during normal operation and affix temper proof sticker to detect unauthorized access to switches.




Figure 7-27 Cover layout for DIP switches access (for illustration purposes only).

4. Set DIP SWITCH position of all 64 switches to ON position (upper position).




Figure 7-28 DIP positions (for illustration purpose only)



Image is for illustration purpose only.

5. Rotate the ROTARY SWITCH to position 9. This will set the unit into test mode.
6. Turn the power on.
7. Verify TEST STATE LED is green.
8. To start the test, move the TEST SWITCH to its left position then back to right immediately. The TEST STATE LED will start blinking to indicate test is running. It may take few seconds for the test to complete. You should hear the relays clicking while test is running.
9. On test completion the both LEDs will be turned green to indicate pass, any red LED indicates failure.



Warning In case TEST RESULT LED is turned Red do not use the unit.

Unit need to be repaired.

10. Rotate the ROTARY SWITCH to 0 position and make sure the TEST STATE LED is turned off.
11. Turn the power off.
12. Move the DIP SWITCHES back to their lower position.
13. Assemble the cover.
14. Connect the DI/O cabled back to the connector's panel.
15. Unit is ready for use.

7.9.4.3 Input Connector Short Circuit Test.

Set each of the inputs, one at a time to ON and read the FPGA input register. The read should result with only one bit set with respect to the input.

8 WARRANTY

Please refer to MKS Website below for warranty term and legal disclaimer

<http://www.mksinst.com/about/warranties.aspx>

<http://www.mksinst.com/about/legal.aspx>

Appendix A: Troubleshooting

Boot:

<ul style="list-style-type: none"> LCD displays “ECM2: Booting” for over 1 min 	<ul style="list-style-type: none"> Make sure power supply provides enough amperes for ECM2 Unplug power. Wait for a few seconds and plug back power.
<ul style="list-style-type: none"> <u>LCD displays “ECM2: Loading” for over 1min</u> 	<ul style="list-style-type: none"> <u>Unit is waiting for network interface to be plugged in.</u> <u>Unit’s IP address might be set as DHCP and it’s waiting for an assigned IP address. Make sure your PC is not set as static with different subnet mask and your network must be able to assign IP address automatically.</u>

Network:

<ul style="list-style-type: none"> User cannot telnet or FTP to the unit 	<ul style="list-style-type: none"> Make sure PC IP address is set to the same subnet as unit IP. Make sure Ethernet cable is plugged to U19 (NOTE: U18 is not enabled) Make sure no other device on the network is set with the same IP address as host or ECM2 Make sure unit complete booting and unit IP address is displayed on the front panel LCD.
---	--

Visio or Visim:

<ul style="list-style-type: none"> Visio 2010 returns an error popped up saying ActiveX Cannot Create Object with error code 429 	<ul style="list-style-type: none"> Please refer to section 7.5.1.1 to Register dao360.dll and runsrv.dll using regsrv32 NOTE: Refer to Microsoft knowledge database for helpful solution to Visio related issue.
<ul style="list-style-type: none"> After opening the IO_MAP excel file no sheets are visible. 	<ul style="list-style-type: none"> In the Visio menu bar select ‘View’ and then ‘Unhide’. Select the IO_MAP

	workbook and then press 'OK'.
--	-------------------------------

IEC61131-3:


<ul style="list-style-type: none"> Project Control Dialog does not seem to response with a pop up control 	<ul style="list-style-type: none"> Make sure the Project resource setting matched the unit IP address.
<ul style="list-style-type: none"> Project error or warning with wrong resource 	<ul style="list-style-type: none"> Make sure the project resource for PLC type select eCLR_ECM2 as PLC/Processor type.
<ul style="list-style-type: none"> Multiprog cannot connect to unit after all have been confirmed 	<ul style="list-style-type: none"> Make sure IEC rotary switch is not on position 3 or higher.

Appendix B: Available Shell Commands

ednbrowse

This command will allow the ECM2 to scan the DeviceNet network module, create the dnrapiproxy.cfg file at the root directory. The same command can be repeated for each additional dnet master module. The order of the DNET network is based on order of when the command was executed. If the order of the network was not as desired, the file dnrapiproxy.cfg can be deleted and the process can be started from beginning with the master modules in desired order.

Below figure shows the command was executed when there is one dnet network master module as network 1. Second added network with same command will append EDN2 to the dnrapiproxy.cfg file, and so on.

A screenshot of a Telnet window titled 'Telnet 10.202.2.187'. The window shows a terminal session with the following text:

```
Pocket CMD v 6.00
\> ednbrowse
Molex Incorporated
DeviceNet Remote Scanner Browser
Version 1.3.8.0

Configuration file does not exist \dnrapiproxy.cfg
Updates to the configuration file:
-----
Unchanged 0 cards
Deleted 0 existing cards
Found new cards:
-----
[EDN1] - new
eth_network="00:0B:17:10:75:2B"
eth_address="00:A0:91:60:02:A2"
Added 1 new card
\>
```


dnbrowse

This command scans the networks for all available DeviceNet slave devices.

Type “dnbrowse” in the telnet session and press Enter. Type “all” and Enter if you wish to have all networks scanned.

Note: card names are case sensitive, but ‘all’ is not.

Note: this step may take a few minutes to complete.


A screenshot of a Telnet window titled 'Telnet 10.202.2.187'. The window shows a command prompt where the user has entered 'dnbrowse'. The output of the command is as follows:

```
\> dnbrowse
MKS DeviceNet Command Line Scanner Version 1.0.0.1 for Arrow
Card1: EDN1
please input the Card Name <case sensitive> to use, or all to scan all masters.
all

Attempting to open EDN1...Success.
Card EDN1 is online!
Card EDN1 started scanning!
Card EDN1 added all devices!
Scanning for slaves...
MACID 60 found...AS00121-01
Vendor 664, Product 121
2 produced, 4 consumed
DNET Master EDN1: found 1 slaves, total size 4 produced, 2 consumed.
Found 1 slaves.
Card EDN1 stopped scanning successfully
Card EDN1 no more device active
Card EDN1 taken offline successfully
Waiting for IO to be active...
Waiting for IO to be active...
Slave (Card EDN1, MACID=60) - IO Active.
Starting...
\>
```

ipsetup:

This command allows user to change the IP address of the ECM2. Type "ipsetup" and press ENTER key, follow option prompt for unit IP address change. Unit has to be power cycled for the change to take effect.

A screenshot of a Windows Telnet window titled "Telnet 10.202.3.152". The window shows a terminal session with the following text:

```
Welcome to the Windows CE Telnet Service on Arrow
Pocket CMD v 6.00
\> ipsetup
Current IP Address configuration: DHCP
Enter Desired Configuration.
Enable DHCP <1 - Yes, 0 - No>:
```


plc

This command starts the execution of the PLC program if existed. If rotary switch is set on 1, this command will be executed automatically when ECM is booted up. This command is only on AS01023G-01

prgintlk

This command is for interlock program and debug. Type “prgintlk” without any option then press enter key will display synopsis and available option for the command.

version

This command will return the following features for the unit:

- a. Product Name
- b. Part Number
- c. Serial Number
- d. Product Version
- e. Product HW Version
- f. User Manual
- g. Test Fixture Part Number
- h. Test Fixture Version
- i. Manufacturing Date
- j. Product Install Date

dniotest

Test the IO connection for DeviceNet slaves.

- Scans for and adds all detected slaves for all EDN cards configured on the ECM2.
- Opens an IO polled connection and increments each byte by 1 every 100ms.
- Runs forever until the user quits by entering 'q' in the command window.

Available commands by OS design:

date

This command will return the current setting date on the ECM2

time

This command will return the current time on the ECM2