


BOMANN®

User Manual

 **FREEZER**

GS 184 NoFrost



Please read this manual carefully and keep for future reference!

TABLE OF CONTENT

OVERVIEW	2
DISPOSAL OF USED DEVICES	2
IMPORTANT USE AND SAFETY INSTRUCTIONS	3
General safety precautions	3
Risk of injury	3
Coolant	3
Intended use	3
Unpacking	3
PRODUT DESCRIPTION	4
Delivery scope	4
Specifications	4
INSTALLATION	5
Location	5
Electrical connection	5
REVERSE THE DOOR OPENING	6
STARTUP / OPERATION	7
Prior to first use	7
Turning on / control panel & settings	7
Storing food	8
Defrosting	9
Operating noise	9
Turning off	9
TIPS FOR SAVING ENERGY	10
MAINTENANCE AND CLEANING	10
Cleaning and care	10
Repairs	10
What if . . . Troubleshooting	10

OVERVIEW



Please read this user manual thoroughly before first time operation. It includes important information with regard to installation, operation and maintenance of the device. Improper use may cause hazardous situations, especially for children.

Keep this manual for future reference. Pass it on to any future owner of this product. In case of any doubt regarding questions or topics which are not extensively described in this manual, please contact your distributor or a specialist.

DISPOSAL OF USED DEVICES



This product is marked in accordance with the European waste regulation 2002 / 96 / EC - WEEE

It regulates the proper disposal of the product. Environmentally friendly disposal will prevent possible negative consequences to health caused by improper disposal.

This symbol on the product or its packaging indicates that this product must not be disposed of with the regular household waste. The user has to return the product to a collection point for the recycling of electric and electronic equipment.

The disposal must comply with the local regulations in place.

For further information please contact your local authorities or waste collection service.

Disable waste equipment before disposal:

- Disconnect the mains plug from the wall socket.
- Disconnect the plug from the mains cable.
- Remove or disable any existing spring or latch locks.

This will prevent children from locking themselves (risk of suffocation!) or from getting into perilous situations. Children might not understand the risks that arise from handling household devices. Therefore, observe children and make sure they do not play with the device.

IMPORTANT USE AND SAFETY INSTRUCTIONS

General safety precautions

All safety information in this user manual are marked with a warning symbol. They indicate possible dangers precociously. It is imperative to read and follow these information.

- Do not touch the plug at the mains cable with wet or moist hands when connecting or disconnecting. Risk of death by electric shock!
- In case of emergency, unplug the device immediately.
- Hold the plug when disconnecting the mains cable; do not pull the cable.
- Disconnect the plug before cleaning or servicing.
- Regularly check the device and cable for signs of damage. Do not continue to operate the device in case of damage.
- A damaged mains cable must be replaced by the manufacturer or a technician and without any delay. Do not use the device with a damaged cable or plug.
- Do not repair the device by yourself. Please contact authorized personnel. In order to avoid hazards. A damaged mains cable must be replaced with an equivalent cable by the manufacturer or qualified specialist.
- Except for cleaning and maintenance work described in this manual, no other alterations of this device must be executed.
- Do not place vases or other containers filled with liquids on the device.

Risk of injury!

- So that you can disconnect the appliance quickly in event of an emergency, do not use extension cables.
- This device may not be operated by children or persons with physical, sensory or mental abilities or lack of experience and knowledge, unless they are supervised or guided.
- Children should be supervised to ensure that they do not play with the device.
- Transport the unit never with content.

WARNUNG

- Packaging materials (e.g. plastic bags, polystyrene) are dangerous for children. Risk of suffocation! Keep packaging materials out of reach of children.
- Containers with flammable gases or liquids can leak due to cold ambient temperatures. Risk of explosion! Do not store combustible materials such as aerosol cans or refill cartridges for lighters in your device.

Coolant

CAUTION

The coolant circuit of this device contains the refrigerant Isobutane (R600a), a natural gas that is flammable and of high environmental compatibility. Make sure no part of the Coolant circuit gets damaged during transport and installation of the device.

If the coolant circuit is damaged:

- it is imperative to avoid any open flames or ignition source.
- thoroughly air the room in which the device is installed.

Intended use

- This device is intended for private use. It is suitable for freezing food.
- The manufacturer is not reliable for any damage resulting from improper or other then intended use.
- For safety reasons, alterations or modifications of the device are prohibited.
- Please keep in mind that the manufacturer is not reliable for any damage resulting from commercial or any other use then freezing food.

Unpacking

The packaging must be undamaged. Check the device for any possible transport damage. Do not install a damaged device. In case of damage, please contact your distributor.

⚠ ATTENTION

Remove the separate polystyrene part (transport protection) between the rear of the device and condenser – metal grid (if available).

Packaging material

The packaging for transportation of the device and individual parts is produced of recyclable materials.

- corrugated cardboard / paperboard (mainly of waste paper)
- form part of PS (foamed, CFC-free polystyrene)
- Films and bags of PE (polyethylene)
- Strapping strips of PP (polypropylene)


⚠ IMPORTANT

Make sure you dispose of packaging materials environmentally friendly.

Removing the transport protection

The device and parts of the interior are protected for transport. Remove all adhesive tapes from the right and left side of the door. You may remove adhesive residue with a cleaning solvent. Also remove any adhesive tapes and packaging materials from the inside of the device.

PRODUCT DESCRIPTION



- 1 Control panel / adjustable thermostat
- 2 Freezing flap
- 3-6 Freezing drawers
- 7 Adjustable feet
- 8 Inner door with sealing

Delivery scope

5 Freezing drawers, 1 freezing flap, ice-cube tray, user manual

Specifications

BOMANN Model No.	GS 184
Energy efficiency class ⁽¹⁾	A+
Category, Type	Freezer, free-standing
Climate class ⁽²⁾	N/ST
Gross/net capacity, total	213/176 litre
Freezing capacity in 24h	15 kg
Storage time by power failure	10 h
Energy consumption ⁽³⁾	0,733 kWh/24h – 267 kWh/year
Connection voltage	220-240 V, 50 Hz
Connection power	100 W
Operating noise	45 dB(A)
Unit Sizes H x W x D	168,7 x 55,4 x 55,1 cm
Depth with open doors	108,0 cm
Gross / net weight	60,5 / 55,0 kg
Coolant	R600a (35g)

- (1) A+++= economical - G= less economical
(2) Climate class SN (Subnormal): ambient temperature of +10 °C up to +32 °C
Climate class N (Normal): ambient temperature of +16 °C up to +32 °C
Climate class ST (Subtropics): ambient temperature of +16 °C up to +38 °C
Climate class T (Tropics): ambient temperature of +16 °C up to +43 °C
(3) The actual energy consumption depends on the use and installation of the device.

All device-specific data of the energy label have been determined by the manufacturer under laboratory conditions in accordance with pan-European standardized measuring methods. These are regulated by ISO EN 15502. The actual energy consumption depends on the usage and might therefore also be above the values determined by the manufacturer under standard conditions.

An expert knows these relations and will execute the tests with special measurement instruments in accordance with the regulations in place.

MANUFACTURER DATA

Product is subject to changes and improvements.

INSTALLATION

Location

Sufficient ventilation around the device is necessary in order for the heat to dissipate properly and to guarantee efficient cooling operation at low power consumption. For this purpose, leave sufficient space around the device.

- Minimum clearance of 7,5 cm between rear side and wall,
- at least 10 cm on both sides and 10 cm on top of the device.
- Leave proper space in front of the device in order to open the door at an angle of 160°.




IMPORTANT

- Do not expose the device to direct sunlight.
- Do not place near heaters, next to a stove or any other heat sources.
- Do not use the device outdoors.
- Only install at a location with an ambient temperature suitable for the climate class of the device.
For information on the climate class, please refer to chapter "Specifications" or to the rating label located in the interior or on the rear side of the device.
- Avoid installation at locations with high humidity (e.g. outdoors, bathroom), as metal parts would be susceptible to corrosion under such circumstances.
- Do not place the device near volatile or combustible materials (e.g. gas, fuel, alcohol, paint, etc.) and in rooms which may have poor air circulation (e.g. garages).
- Only place on a steady and safe surface.
- If the device is not horizontally leveled, adjust the feet accordingly.

Assembling the door handle

Attach the door handle by removing the cover caps from the side of the door and tighten the handle with the included screws in the below holes.



Electrical connection

The kind of current (AC) and the voltage must be conform with the data of the rating label, located inside or outside on the back of the unit. In case of heavy voltage fluctuations, it is recommended to use an automatic alternating current regulator.

The plug, together with the grounding conductor, must fit into the wall socket. The mains plug must be freely accessible.

Mains cable

- Do not extend or roll up the cable during operation.
- Also, the cable must not be near the compressor on the rear side, since latter one gets hot during operation. In case of any contact, the isolation would be damaged resulting in electric leakage.
- The use of extension cables is not recommended.

- Do not connect the device to the mains with wet hands.
- Install the device for the wall socket to be freely accessible.


REVERSE THE DOOR OPENING

If required, the door opening can be moved from the right (supplied condition) to the left side.


WARNING

When replacing the door stop, the device must be disconnected from the power supply. Always unplug the device first.


1. Use a flat bladed screw driver to remove the screw covers at the device top cover. Unscrew the below screws and remove the device cover.




2. Put the blind cap of the top cover at the opposite side.




3. Dismount the upper door hinge by unscrewing the screws.
Open the door a little, take the door carefully from the lower door hinge. Put the blind cap of the device door B at the opposite side A and place it on a padded surface to prevent it from scratches.



4. Tilt the device slightly backwards and block it in this position.
Unscrew both feet and remove the door hinge incl. hinge pin and the separate screw-in foot bracket by unscrewing the screws.




5. Loose the hinge pin from the door hinge and put it to the other side of the hinge.
Afterwards you screw on the door hinge at the opposite side of the device and fix the separate screw-in foot bracket for the foot at the corresponding other side too. Screw both feet on again.



Replace the device upright.

Insert the door on the hinge pin of the lower door hinge and fix the door to the property position.

- Attach the upper door hinge by using the screws at the opposite side, after you unscrewed the hinge pin and screwed it on at the other side of the door hinge again.



Put the in point 1 removed device cover on again, tight the screws and clip the cover caps on.

- Affix the door handle at the opposite side by loosening the screws of the handle, take the cover caps from the door and screw on the handle at the below holes. Put the cover caps on the exposed holes at the other side.



Check if the door is arranged vertical as well as horizontal, so that a smooth opening and closing of the door is ensured.

STARTUP / OPERATION

Prior to first use

⚠ ATTENTION

After transport, the device should be left standing for 4 hours in order for the oil to be collected in the compressor. Nonobservance could cause damage to the compressor and hence result in failure of the device. This would void your warranty claim.

- Clean the interior of the device including all accessory parts located inside.

Connect the device to the mains supply

⚠ IMPORTANT


- The device must be earthed properly. For this purpose the plug of the mains cable has been fitted with the intended lead.
- Contact an electrician if the plug does not fit in the wall socket.
- In case you disconnect the device or in case of power failure: Wait for 5 minutes before restarting the device.

Turning on

Turn on the device by connecting the plug to a wall socket. At the temperature control, located on the control panel at the device front, you can adjust the desired temperature. Please also refer to the chapter "Control panel settings".

Control panel & settings

The control panel that controls the temperature inside the freezer compartment is located inside:



Adjustable thermostat

Setting Cold (min): lowest setting (warmest inside temperature)

Setting Colder (max): highest setting (coldest inside temperature)

Function buttons

Alarm : to stop alarm sound
Super Freeze: to activate or de-activate super freeze function

Control lamps:

Alarm: indicator light for temperature
Power: indicator light for Power
Super: indicator light for Super Freeze

Turning the temperature control clockwise will lower the inside temperature. Please keep in mind that the temperature changes with the ambient temperature (of the location), with the frequency of opening the door and the amount of food in the device.

During initial operation, turn the temperature control to the highest setting first, until the device has reached the desired operating temperature. Afterwards it is recommended to turn the control back to a medium setting; correcting the temperature at a later point would then be easier.

Caution for turning! Please avoid regulating range exceed the position from "Cold" to "Colder".

Important! Normally we advise you select setting of mid, if you want the temperature warmer or colder please turn the knob to cold or colder setting accordingly.

When you turn the knob to lower which can lead to the more energy-saving. Otherwise, it would result the high energy-consuming.

Important! High ambient temperatures (e.g. on hot summer days) and a cold setting on the temperature regulator (position Colder) can cause the compressor to run continuously!

Reason: when the ambient temperature is high, the compressor must run continuously to maintain the low temperature in the appliance.

Super Freeze (Button)

If you need the temperature inside the freezer to drop quickly, please press this button and indicator of super will be on. The unit runs in **Super Freezer**.

If you need the appliance to stop the mode of **Super Freeze**, please repress the Super Freeze (button), the indicator of super shuts off.

Attention! The freezer will automatically quit super freeze mode after 24 hours, at the same time, super indicator will shut off.

Alarm for Freezer

If the power of appliance has been cut for a long time or stopped for any reason, and the inside temperature has reached the higher degree ($\geq -10^{\circ}\text{C}$) then it is working. When temperature $\geq -10^{\circ}\text{C}$, the indicator light begins to flash, and at the same time, the alarm sounds 3 times per 10 seconds. After 2 minutes, the alarm will automatically stop, and the excessive temperature indicator will be on without flash. When temperature $< -10^{\circ}\text{C}$, excessive temperature indicator shuts off.

Alarm Button

During the alarm of freezer, press button, the alarm sound is stopped and the excessive temperature indicator is on but no flashing.

Storing food

The  freezer allows you to store frozen food at a temperature of -18°C or below (from a middle temperature control setting) for several months, to produce ice cubes and to freeze fresh good.

The temperature of the device is automatically controlled by the temperature control.

Due to external influences such as room temperature, placements, frequency of opening the door and the amount of food the temperature in the freezer can be influenced.

Freezing

- 24 hours before freezing we recommend to push the button Super Freeze and to keep this setting even after freezing for a few hours. The device is not compromised if the Super Freeze will not revert to a medium operating control after the freezing process, but for economic reasons you should possibly avoid it.
- Place fresh food to be frozen in the upper compartment. In order for that to be always possible, frozen food items need to be rearranged frequently.
- Fresh food should be frozen as fast as possible to the core. Therefore during freezing operation, the temperature of fresh food should be lowered as fast as possible in order to keep formation of ice crystals as little as possible and not to damage the food structure.
- If the freezing process is too slow, ice crystals build up and the food quality might get affected.

- Even frozen food should be stored in the lower compartments, in order to keep the upper compartment available for fresh food.
- Frozen food should be kept in contact with the bottom of the compartment.
- Keep a space between the single items for air circulation.

Storing frozen food

- Packed frozen merchandise should be stored in a 4-star-freezer compartment in accordance with the manufacturer's data. Make sure the food items do not defrost after purchase and to store them as fast as possible in the freezer.
- It is possible to store food for longer periods of time, up to three months. This period might vary, so please observe the storage information on the packaging of the merchandise.



IMPORTANT

Make sure that the temperature in the freezer does not rise above -18°C.

Moreover the device should be defrosted regularly. A thick layer of ice on the wall deteriorates the cooling effect and the power consumption increases.

Safety precautions

- Do not store sizzling drinks in this device, such as mineral water, beer, sparkling wine, coke etc. (risk of explosion).
- Once products have been defrosted halfway or completely, they should be consumed as soon as possible and should not be frozen again, except they have been processed to a ready meal.
- In case of power failure, do not open the door. If the failure does not take longer than 10 hours, the food will not be affected.
- Do not store bottles or cans. These can break when the contents freeze – or even explode, if they contain carbonated drinks.
- Do not eat food that is still frozen. Do not allow children to eat ice cream directly from the freezer. The cold can cause injuries in the oral cavity.
- Touching metal parts inside the device can cause symptoms similar to burns if the skin is very sensitive.
- Do not touch frozen food with moist or wet hands; they could freeze to the items.
- For safety reasons, the freezer compartments feature a stopper. But they can also be removed completely by pulling them upwards and then removing them. Reattach in reverse order.

Defrosting

Because of automatically “NoFrost-System” the freezer keeps free from ice inside. The defrost procedure isn't necessary.

Operating noise

	TYPE OF SOUND	CAUSE/ SOLUTION
NORMAL NOISE	Mumbling	Caused by the compressor during its operation. This is stronger when it turns on or off.
	Liquid sounds	Caused by the circulation of the refrigerant in the device.
	Click sounds	The temperature control turns the compressor on or off.
	Disturbing noises	Vibration of the shelves or cooling coils – check if those are securely fastened.

Turning off

Disconnect the plug or unscrew the fuse in order to turn off the device.

If the device will not be operated for a longer period of time:

- Remove the entire food from the device.
- Disconnect the plug or turn off / unscrew the fuse.
- Thoroughly clean the device (refer to chapter of “Cleaning and Care”).
- Keep the door open in order to prevent bad odors.

TIPS FOR ENERGY SAVING

- Disconnect the plug if you do not use the device.
- Do not install the device near stoves, heaters or other heat sources. In case of higher ambient temperatures, the compressor will run more frequently and longer.
- Ensure sufficient ventilation at the bottom and rear side of the device.
Never block any ventilation openings.
- Allow warm dishes to cool down before putting them in the device.
- Do not open the door longer than necessary.
- Avoid opening all freezer compartments at the same time.
- Make sure that the temperature in the freezer does not rise above -18°C.
- The device should be defrosted regularly.
- Always keep the condenser – metal grid on the rear side (if existing) – clean.
- Make sure the door sealing is in good order for the door to close properly.

MAINTENANCE AND CLEANING

Cleaning and care

For hygienic reasons, clean the interior and accessory parts regularly.



WARNING

- Always disconnect the plug or turn off/ unscrew the fuse before cleaning. Pull the plug and not the cable.
- Does not use steam cleaners for cleaning the device; moisture could enter electrical components. Risk of electric shock! Hot steam could damage the plastic parts. The device must be dry before restarting operation.
- Essential oils and organic solvents, such as the juice of lemon or orange skin, butanoic acid or cleaning agents containing acetic acid can damage plastic parts. Prevent contact of any part with such substances. Do not use abrasive cleaning agents.

Pls. do as follows:

- Remove all food and keep covered at a cool location.
- Use warm water and a mild detergent for cleaning the interior (including rear side and bottom).
- After thorough drying, restart operation.
- Clean the condenser - metal grid on the rear side (if existing) once a year, using a soft brush or vacuum cleaner.



WARNING

Do not bend the cooling coils.
Do not use arenaceous abrasives.

Repairs



WARNING

Servicing of electric devices must be conducted by qualified experts only. Incorrect or improper repairs constitute a risk for the user and will void the warranty!

What if . . . Troubleshooting

The design of the device ensures a trouble-free operation as well as a long life cycle. Nevertheless, if any defect occurs during operation, please check if it is caused by improper operation.

The following problems can be solved by you by checking for the possible cause.

PROBLEM	POSSIBLE CAUSE	SOLUTION
The device is not working properly or at all	Is the plug securely connected to the mains? Has the safety mechanism of the wall socket been triggered? Is the temperature control properly set? Is the place unqualified?	Connect the plug properly to the socket, turn on the fuse, and contact a technician if necessary. Check the settings. Check the ambient temperature.

	Do food items or shelves and/or drawers prevent the door from closing properly? Is the ventilation of the device hedged?	Arrange the food or shelves and/or drawers properly. Clear the ventilation slits, install the device freely
Loud noise during operation	Does the device not stand vertical or horizontal?	Adjust the feet accordingly. Liquid flow sounds in the cooling circuit are normal.
Water on the bottom	Is the temperature control set properly?	Check the temperature settings.
The food is too warm	Temperature is not properly adjusted. Door was open for an extended period. A large quantity of warm food was placed in the appliances within last 24 hours. The appliance is near a heat source.	Please lock in the section "Control panel & settings." Open door only as long as necessary. Turn the temperature regulation to a colder setting temporarily. Please lock in section "Installation, location".
Appliance cools too much	Temperature set is too cold.	Turn the temperature regulator to a warmer setting temporarily.

Note. On days of high humidity, condensation might occur on the outer surface of the device. This is no malfunction; you may simply wipe the water off.

If a problem still persists after following the steps above, please contact your distributor or a technician.

Are you interested in other Bomann products? Please visit our website:

www.bomann.de