

i-View User Guide

Ishida Scale Network Utility Software

i-View Version 1.24a
June 2005

ISHIDA CO., LTD



Copyright © 2001-2005 Ishida Co. Ltd., Japan
Copyright © 2001-2005 Interface Translation Ltd., New Zealand

No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, without permission in writing from Ishida Co. Ltd.

Microsoft Windows is a registered trademark of Microsoft Corporation.
Motorola is a registered trademark of Motorola Corporation.



Revision History

Date	Program Version	Page	Description
4th July 2003	1.21	5	Updated system requirements section
16th July 2003	1.22	19	Updated configuration dialog image and explanation to show cassette and test mode settings
6th Sept. 2003	1.22	19	Revised configuration dialog explanation because test mode page changed to "Misc. Settings".
6th Sept. 2003	1.22	17	Added note about faulty head dot display
25th Nov. 2003	1.22b	23	Added note about "Clear RAM & Setup on Scale" button.
15th July 2004	1.24	7, 9, 10, 13, 16, 19, 21, 24, 26	Added dealer mode and SR-2000 support.
30th June 2005	1.24a	10, 13, 15, 18, 20, 23, 28	Added WM-4000 and BC-4000 support



Contents

1. Introduction	5
How to Use This Manual	5
2. Installation	6
2.1 System Requirements	6
2.2 Installing i-View	6
2.3 Uninstalling i-View	6
2.4 Dealer Mode	7
3. Getting Started	8
3.1 Configuring i-View	8
3.1.1 Copy Configuration from Other Ishida Software	8
3.1.2 Configuring the Scale Network	9
3.1.4 Event Log Setup	11
4. Scale Status	13
4.1 Meaning of Scale Data	13
4.2 Scale Screen Operation	16
4.2.1 Refreshing the Displayed Data	16
4.2.2 Show Status Log	16
4.2.3 Remote Diagnostics	18
4.2.4 Scale Configuration Data	20
4.2.5 Export Status Information	22
5. Error Log	23
5.1 Displayed Error Information	23
5.2 Export Error Log	23
6. Backup & Restore	25
6.1 Backup & Restore Data	25
6.2 Backing Up a Scale	25
6.2 Restoring Data to a Scale	26
7. Scale Program Update	28
7.1 Get Program from Scale	28
7.2 Update Program on a Single Scale	29
7.3 Update Program on All Scales	30
8. Service Journal	31
9. Event Log	33
10. i-View Setup	34
10.1 Event Log Setup	34
10.2 Error Definitions	34
10.3 Configuration Data Setup	34
10.4 ROM Switch Fields	36

1. Introduction

i-View is a utility program for managing a network of Ishida scales.

The principal functions of the software are as follows

- Connect to the scales via the store network (using TCP/IP)
- Displays the operation status of each scale. This includes:
 - Current scale operation mode
 - Error information
- Displays the scale error log (number of times each type of error detected by scale)
- Backup and restore of scale data
- Backup and updating of the scale firmware
- Generate logs recording scale activity
- Display and update scale remote diagnostic and configuration data

The aim of this software is to provide the system administrator at the store with a PC-based tool for monitoring and managing the Ishida scales connected to the store LAN. This includes backing up scale data and performing firmware updates.

How to Use This Manual

If you are about to install i-View.

⇒ See Chapter 2 *Installation*

If you are a new user wishing to familiarize yourself with the software.

⇒ See Chapter 3 *Getting Started*

If you wish to learn how to use a specific feature.

⇒ Lookup the feature in the *Contents* and find the relevant chapter.

2. Installation

2.1 System Requirements

i-View requires a Windows 98 or higher personal computer with a LAN connection. The software should also run successfully on Windows 95, but this has not been confirmed.

A screen resolution of at least 800x600 is recommended.

A floppy disk or CD-ROM is recommended for installation.

Operation on Windows XP has been verified for i-View version 1.21.

2.2 Installing i-View

1. Startup Windows, then run SETUP.EXE from the installation floppy disk or CD-ROM. Follow the instructions that appear on the screen.
2. The installation installs an icon on the desktop and a shortcut in the Windows Start menu. To run i-View, double click on the i-View icon or select **Start** → **Programs** → **Ishida** → **i-View**.
3. Refer to section 3.1 *Configuring i-View* for details on how to configure i-View for your store.

2.3 Uninstalling i-View

Select **Start** → **Settings** → **Control Panel** to open Control panel, then double click on **Add/Remove Programs**. Follow the instructions to remove i-View from your hard disk.

2.4 Dealer Mode

To be able to access the various advanced setup commands in the **Setup** menu, i-View must be run in dealer mode, which is specified by the -d command line switch. This is set automatically if you install using the dealer mode installation. To set the command line switch manually, right-click on the shortcut you use to start i-View from the desktop or Windows Start menu, then open the **Properties** dialog. Add -d after the i-View EXE file name.

For example, if i-View is installed in the *C:\Program Files\shida\i-View* folder, the command line should now read:

"C:\Program Files\shida\i-View\i-View.exe -d"

3. Getting Started

This section provides a brief overview of the i-View software for users running the software for the first time.

If you have just installed i-View and need to configure the software for your store, read section [3.1 Configuring i-View](#) below.

If i-View has already been configured, proceed directly to section [3.2 Using i-View](#).

3.1 Configuring i-View

This section describes how to configure i-View for your store. However, if you have an existing, configured copy of the Ishida ScaleLink Pro or i-Label software packages already installed on your PC, you can load the LAN configuration (IP addresses of each scale, etc.) from the setup files of these packages. The operation is described below.

If you do not have an existing Ishida software package, proceed to [3.1.2 Configuring the Scale Network](#).

3.1.1 Copy Configuration from Other Ishida Software

1. Run ScaleLink Pro or i-Label and select **Save Site Setup** from the **Setup** menu. Specify a file name and save the setup information.
2. Start i-View and select **Load Setup** from the **Setup** menu. Select the file you saved in step 1 and click the **Open** button.
3. This loads the scale LAN configuration (IP addresses of each scale, etc.). In i-View, select **Scale Comms** from the **Setup** menu and check that all scales have been configured correctly. If there are any problems, refer to [3.1.2 Configuring the Scale Network](#) below.




NOTE Note that i-View only supports AstraXT/AC-4000 series scales. Any 3000-series or older equipment on your network will not have been loaded into the i-View setup.

4. This completes configuration of the scale network parameters. Proceed to [3.1.3 Error Definitions](#) and [3.1.4 Event Log Setup](#).


3.1.2 Configuring the Scale Network

Use the following procedure to configure i-View for your store.


1. Start i-View and select **Scale Comms** from the **Setup** menu.
2. This opens the following Communication Links dialog listing the available scales. If you have just installed i-View, this list will be empty.



3. Click the **Add** button to add a communication link. This displays a dialog like that shown below. (The format may change as new models are added.) Select the scale type, then enter the IP address of the scale.



4. Click **OK**. This displays a dialog like the one below. Set any parameters that need changing, then click the **OK** button to save the settings. Repeat this procedure for each scale on your network.




The meanings of each field in this dialog are as follows:

- Link Name:** Enter a name to identify the scale in the i-View screens. Defaults to the scale IP address.
- Scale Type:** Specifies the scale model.
- Enable Link:** Specifies whether to enable these network settings. Set this off if you wish to save network settings for a scale that is not currently connected to the network.
- Comms Log ON:** Set this on to save a log of data transfer between the PC and scale. If you set logging on, specify the name of a text file in which to save the log. Use the **Change File** button if you wish to change the currently selected file. Saving a communications log provides useful information for troubleshooting scale problems. It is recommended that logging be set on.
- Port No.:** The TCP/IP socket port number for communications with the scale. This is currently fixed at 50021 for the AstraXT, 50031 for the AC-4000XT, 4031 for the AC-4000, and 6051 for the SR-2000, 5041 for the WM-4000, and 7061 for the BC-4000.
- IP Address:** The IP address for the scale. An IP address is typically assigned to the scale when the scale is installed. Refer to the scale Service Manual for details on how to set the IP address on the scale.
- Connection Timeout:** Specifies how long i-View waits for a scale to respond when making the initial connection to a scale. The recommended value is 10 seconds.

3.1.4 Event Log Setup

Select **Event Log** from the **Setup** menu to display the following dialog.




The meanings of each field in this dialog are as follows:

- Enable Event Log:** Specifies whether or not to save an event log.
- Keep Log for:** Specifies how long to save the event log. If zero is specified, the event log is cleared each time i-View starts. Up to 365.
- Event Log File:** Use the **Select** button to specify the file in which to save the event log.

3.2 Using i-View

If i-View is correctly configured, a screen similar to that shown below should appear after you start the program.




The table below gives a general overview of the main operations for using i-View. The detailed operation of each screen is described later in this manual.

- Tab Bar** Click on the tab bar buttons to display the different i-View screens
- Scale List** Each i-View screen lists the scales configured in the system. The scales may be displayed in list format (as shown above) or as icons. Use the Icon View and List View commands in the View menu to switch between display modes. In both cases, the scale icon indicates the current scale status (which is also listed in the **Status** column in list view mode).
- Operation Buttons** Some i-View screens have buttons for performing specific operations. In most cases, the operation is performed for the scale currently selected in the scale list.

4. Scale Status

The following screen appears when you start i-View.



4.1 Meaning of Scale Data

This screen displays the current status of each scale in the network. The meaning of each column is as follows.



1. The displayed scale status is valid for the time when i-View last accessed the scale. See 4.2.1 Refreshing the Displayed Data for details of how i-View refreshes the displayed scale information.

2. The SR-2000 and WM-4000 does not support error data or detailed status information. The error fields remain blank for SR-2000 and WM-4000 scales.

Scale Displays the scale name specified in the i-View setup. (See 3.1.2 *Configuring the Scale Network*)











ID Displays the scale link number. This number is used within i-View only to identify the scale.

Status Displays the current operation status of the scale. The meaning of each status is as follows.

- 1 **Normal Mode** The scale is turned on, connected to the network, and ready for use.
- 2 **Busy** Indicates that the scale was in use (calling up a PLU, weighing or printing a label) when i-View last refreshed the scale information.
- 3 **Not Connected** The scale does not respond to communication via the network. Typically, this means the scale is turned off or disconnected from the network.

4 Registration Mode	Indicates that the scale has been set to registration mode (P) by manual operation at the scale. (By pressing 9000 followed by the MODE key on the scale's keyboard.)
5 Setup Mode	Indicates that the scale has been set to setup mode (B) by manual operation at the scale. (By pressing 6000 followed by the MODE key on the scale's keyboard.)
6 Subtraction Mode	Indicates that the scale has been set to setup mode (D) by manual operation at the scale. (By pressing 7000 followed by the MODE key on the scale's keyboard.)
7 Total Mode	Indicates that the scale has been set to total mode (F) by manual operation at the scale. (By pressing 8000 followed by the MODE key on the scale's keyboard.)
8 Sub-Total Mode	Indicates that the scale has been set to sub-total mode by manual operation at the scale. (Activated by a preset key on the scale's keyboard.)
9 Test Mode	Indicates that the scale has been set to test mode (C) by manual operation at the scale. (By pressing the RESET key + any other key on the scale's keyboard.)
# Errors	Displays the total number of errors logged in the scale error log screen.
Last Error	Displays the date of the most recent error reported from the scale.
Error	Displays the most recent error reported from the scale. A detailed list of scale errors is shown in the error log screen.

The scale icon also changes depending on the mode, as follows (other icons may be added in the future for new scale models):


Icon	Modes
	AstraXT/SR-2000 : Normal mode, Busy
	AstraXT/SR-2000 : Not connected
	AstraXT/SR-2000 : Disabled
	AstraXT : Registration ~ Test mode
	AstraXT : Print head faulty
	AC-4000 : Normal mode, Busy
	AC-4000 : Not connected
	AC-4000 : Disabled
	AC-4000 : Registration ~ Test mode
	AC-4000 : Print head faulty

4.2 Scale Screen Operation

The following operations are available from the scale screen.

4.2.1 Refreshing the Displayed Data

The following fields at the bottom of the screen control how i-View refreshes the displayed scale data.




If “**Auto-refresh status every ...**” is set ON, the scale status is automatically refreshed at the specified interval. Click on the up and down arrows if you wish to modify the refresh interval. The interval can be up to 600 seconds. The other parameters, however, are only refreshed when i-View starts or when you click the **Refresh** button.

Clicking the **Refresh** button updates all displayed information, regardless of whether auto-refreshing is on or off.

4.2.2 Show Status Log

Click the **Show Status Log** button at the bottom right of the screen to open a dialog showing a log of scale status changes for the scale currently selected in the list. An example is shown below.



The meaning of each column is as follows.

Date/Time The date and time at which the status change occurred.

Duration The time since the previous status change. That is, the length of time the scale remained in the “**Old Status**”.

Old Status The scale status prior to the status change.

New Status The scale status after the status change.

Click the **Refresh** button to refresh the display with any status changes since the dialog was opened.

Click the **Export** button to output the log of status changes to a text file.

Click the **Clear Log** button to clear the entire log.

The figure below shows a sample output.

```
Scale Status Log

2001/07/18 14:00 Normal Mode -> Setup Mode Duration
(HH:MM:SS) = 00:00:24
2001/07/18 13:59 Total Mode -> Normal Mode Duration
(HH:MM:SS) = 00:00:13
2001/07/18 13:59 Normal Mode -> Total Mode Duration
(HH:MM:SS) = 02:05:44
2001/07/18 11:53 Start i-View -> Normal Mode
```

4.2.3 Remote Diagnostics

Click the **Remote Diagnostics** button at the bottom right of the screen to retrieve the thermal head data and other diagnostic information from the scale currently selected in the list. If successful, a dialog opens displaying the retrieved data.


If i-View is unable to retrieve the remote diagnostics data, an error message appears describing the problem and the remote diagnostics dialog does not appear.

The figure below shows an example of the data for an AC-4000. If necessary, you can edit the print head and label settings and send these back to one or more scales. To edit the data, select the [Edit Data] check box.



Remote diagnostics is not supported for SR-2000 and WM-4000 scales.

NOTE



Scale: ID = 2 : AC-4000 #2

Model	AC-4000	Memory Size	918KB
Program Version	SimScale	Free Memory	918KB

Diagnostic Data

Edit Data

Head resistance	645	Label length	60.0 mm
Print distance	3.4 km	Label sensor distance	60.0 mm
Print density (1=Light, 9=Dark)	3	No. of burnt out head dots	0
Label sensor check	85	(0 = All OK, 1 to 448 = Faulty dots)	

Send to Scale... Dump to File... Refresh Close

If the scale supports the function to retrieve faulty head dot data, and if faulty dots are present on the print head, a graphic showing the location of the faulty dots appears at the bottom of the dialog, together with a list of faulty dot positions.

The meaning of each field is as follows.

Scale	The ID and name of the scale from which the diagnostic data was retrieved.
Model	The scale model (AstraXT or AC-4000)
Program Version	The version of the program running on the scale
Memory Size	The total amount of memory on the scale (in kilobytes)
Free Memory	The amount of memory currently available (in kilobytes)
Head Resistance	The head resistance value (0 to 999)
Print Distance	The print head usage expressed as a distance (km).
Print Density	A number (1 to 9) representing the print density (1 = light, 9 = dark). The default is 5.
Label Sensor Check	Displays the value of the label sensor when the scale data was last refreshed
Label Length	Label length + inter-label gap. The maximum label length is 242.5mm for the AC-4000 and 175mm for the AstraXT.
Label Sensor Distance	0 to 99.9mm
No. of burned out head dots	0 indicates that all head dots are OK, 1 to 448 indicates the number of burned out head dots. This is not available for AstraXT series scales.

Operations

The operation of each dialog button is as follows.

Send to Scale	Click this button to send the displayed data to one or more scales. The button only becomes enabled when the [Edit Data] check box is selected.
Dump to File	Saves the remote diagnostic data in a text file. You can use this to printout a hardcopy.
Refresh	Refreshes the displayed data by reading from the scale.
Close	Closes the dialog.

4.2.4 Scale Configuration Data


The scale configuration function reads the configuration data from the currently selected scale and displays on the screen. This feature is not available on some AstraXT scales.

The scale configuration function is password protected. Clicking the **Scale Config Data** button at the bottom right of the main screen opens a password dialog. After you enter the password, i-View reads the data from the scale and opens a dialog similar to the one shown below.



The SR-2000 and WM-4000 does not support configuration data maintenance.

NOTE



The meaning of each tab is as follows.

ROM Switch Settings	All the ROM Switches that have been set up in the ROM Switch Fields dialog should be listed here, with their respective value read from the scale. If there are too many to fit on one screen, they may be split over two tabs.
Setup Mode Settings #1	Lists some of the setup mode settings and their values
Setup Mode Settings #2	Lists the remainder of the setup mode settings and their values
Registration Mode Settings (B09)	Lists the registration mode (B09-Pxx) settings and their values
PLU File Selection (B08)	Lists the PLU File Selection (B08-xx) settings and their values
TCP/IP Settings	Lists the TCP/IP related settings and their values. These values cannot be changed by i-View.
Misc. Settings	Displays various test mode settings including the AC-4000 model number and daylight saving time settings. This page only appears for AC-4000 scales.
Cassette Settings	Lists the label format and related settings for each cassette.

Operations

The operation of the controls on each page is as follows.

Edit Data	Selecting Edit Data allows you to edit the data in each of the fields on the current page. However, fields that are not applicable to your model of scale remain disabled. Changes are not sent to the scale unless you click Send to scale .
Load Data	Loads the configuration data from a configuration data file. This loads a complete set of configuration data, not just the data on the current page. Changes are not sent to the scale unless you press Send to scale
Save Data	Saves the configuration data to a configuration data file for backup purposes. This saves a complete set of configuration data, not just the data on the current page.
Reset Values	This button resets all configuration data back to the original values loaded from the scale or configuration file. Any changes you have made are overwritten.
Send to Scale	Sends the updated configuration data to selected scales. This sends a complete set of configuration data, not just the data in the current page. Note: After sending settings to the scale, always reset the scale to ensure that the new settings are updated on the scale. To prevent misoperation, some scale settings are not updated immediately.
Dump to File	Outputs a hard copy of the configuration data to a text file. Clicking Dump to File opens a Save dialog to specify the file name.
Close	Closes the dialog. Any changes that have not been sent to the scale or saved in a file are discarded.

4.2.5 Export Status Information

Select **Export** from the **File** menu to save the above status information for each scale to a text file.

The figure below shows a sample output.

```
Scale Status

Scale : Bakery #1 (ID=1) : Status = Normal Mode
Memory Size = 949KB, Free Memory = 863KB
Print Head Dist. = 0.000km, Prog. Version = AG001C-A

Scale : Bakery #2 (ID=2) : Status = Not Connected
Memory Size = 0KB, Free Memory = 0KB
Print Head Dist. = 0.000km, Prog. Version =
```


5. Error Log

Clicking the **Error Log** tab displays the following screen. The right side of the screen displays a list of the errors logged by the scale selected on the left.



The SR-2000 and WM-4000 does not support the error log function.

NOTE



5.1 Displayed Error Information

The meaning of each column is as follows.

Error No. The scale error code.

Description A brief description of the error. The description for each error code is specified as part of the i-View setup. See 3.1.3 *Error Definitions* for details.

Errors The number of times the error has been detected by the scale since the last time the error totals were cleared on the scale.

Last Error The date of the most recent instance of the error.

Click on **Clear Error Log...** to clear the contents of the error log on i-View and on the scale.

5.2 Export Error Log

Select **Export** from the **File** menu to save the above error log information for the selected scale to a text file.

The figure below shows a sample output.


Scale Error Log

Scale:Bakery #2 (ID=2)

Error No.	Description	# Errors	Last Error
02	Commodity name is too long	06	2001/07/06
04	Extra message 1 is too long	12	2001/07/06
08	Out of labels/Label feed error	24	2001/07/06

6. Backup & Restore

Clicking the **Backup & Restore** tab displays the following screen. The right side of the screen displays backup and restore information for the scale selected on the left.



6.1 Backup & Restore Data

Backing up the scale using i-View reads the following data from the scale as saves in a backup file (*.abk). The actual data depends on the scale model.

PLUs	Campaigns
Store Name/Address	Operator Name
Extra Messages	Batch Label Printing Data
Free Messages	Nutrition (if scale supports nutrition)
Coupon Message	PLU Production Data
Preset Keys	Hourly Production Data
Scrolling Messages	Operator Production Data
Label Formats	Operator Production Data (Unit Price Overwrite)
Logo(Image) Data	Thermal Head Configuration
Field Titles	Error Log
	Scale Configuration

6.2 Backing Up a Scale

Use the following procedure to backup a scale

1. Select the scale from the icons on the left side of the screen. This displays details of the most recent backup for that scale on the right side of the screen.
2. Click the **Backup Scale** button. This opens a file Save As dialog to specify the file in which to save the scale data. Select a file and click the **Save** button.

3. i-View starts receiving data from the scale. A dialog appears displaying the progress of data transfer. The transfer may take some time, depending on the volume of data on the scale. A confirmation message appears when data transfer finishes and a summary of the received data is displayed. This completes the backup.

If any error occurs during communications with the scale, an error message will appear describing the problem. In this case the backup will not be performed.

Click the **View Summary** button if you wish to view a summary of the contents of the most recent backup.

6.2 Restoring Data to a Scale

Use the following procedure to restore data to a scale


1. Select the scale from the icons on the left side of the screen. The **Backup File** field at the bottom right of the screen displays the currently selected backup file (typically, the most recent backup for that scale).

Click the **Select** button if you wish to select a different file to restore to the scale.

Click the **View Summary** button if you wish to view a summary of the backup file contents.

Click the **Clear RAM & Setup on Scale** button if you wish to clear the scale before restoring the data.

2. Click the **Restore Scale** button. This opens the following dialog for specifying which data to copy back to the scale. Unsupported data types are greyed out.



Restore Scale Data

Restore Mode

- Standard restore or scale-to-scale copy
- Special full restore (e.g. after replacing scale main circuit board)
- Custom (Select restore data below)

Data to restore

<input checked="" type="checkbox"/> PLUs	<input checked="" type="checkbox"/> Free Message #1	<input checked="" type="checkbox"/> Labels	<input type="checkbox"/> Batch Production
<input checked="" type="checkbox"/> Store Name/Address	<input checked="" type="checkbox"/> Free Message #2	<input checked="" type="checkbox"/> Logos	<input type="checkbox"/> Thermal Head Data
<input checked="" type="checkbox"/> Extra Messages	<input checked="" type="checkbox"/> Free Message #3	<input type="checkbox"/> Field Titles	<input type="checkbox"/> Error Log
<input checked="" type="checkbox"/> Extra Messages #2	<input checked="" type="checkbox"/> Free Message #4	<input type="checkbox"/> Batch Print	<input type="checkbox"/> Scale Configuration
<input checked="" type="checkbox"/> Extra Messages #3	<input checked="" type="checkbox"/> Free Message #5	<input type="checkbox"/> PLU Production	
<input checked="" type="checkbox"/> Coupons	<input checked="" type="checkbox"/> Free Message Name	<input type="checkbox"/> Hourly Production	
<input checked="" type="checkbox"/> Preset Keys	<input checked="" type="checkbox"/> Operators	<input type="checkbox"/> Department Production	
<input checked="" type="checkbox"/> Campaigns	<input checked="" type="checkbox"/> Nutrition	<input type="checkbox"/> Group Production	
<input checked="" type="checkbox"/> Advertising Messages	<input checked="" type="checkbox"/> Department	<input type="checkbox"/> Operator Production	
<input checked="" type="checkbox"/> Pop Messages	<input checked="" type="checkbox"/> Group	<input type="checkbox"/> Operator Prod. (U/P Overwrite)	

OK Cancel

3. Click on one of the **Restore Mode** buttons to specify the type of restore to perform. The options are:

Standard restore or scale-to-scale copy

Use this option when you wish to restore the PLU and other scale operational data only. This only restores the data types indicated by a check mark in the lower half of the screen. This option omits data that is time-dependent (such as production data which would be out of date) or specific to an individual scale (such as the thermal head configuration).

Special full restore

Use this option if you wish to restore all data to the scale. This option is typically used to restore a scale that has lost all its data due to a fault or other reason. For example, if the main circuit board has been replaced.

Custom

Use this option if you wish to specify yourself which data to restore. In this case, select the restore data using the check boxes in the lower half of the dialog.

4. Click the **OK** button to start data transfer to the scale. A dialog appears displaying the progress of data transfer. The transfer may take some time, depending on the volume of data to be sent. A confirmation message appears when data transfer finishes. This completes restoration of scale data.

If any error occurs during communications with the scale (if the scale is not in "Normal Mode", for example), an error message will appear describing the problem. In this case the scale data will not be restored.


7. Scale Program Update

Clicking the **Scale Program Update** tab displays the following screen. The right side of the screen displays the program version information (**Current Program ID**) for the scale selected on the left.



The SR-2000 and WM-4000 does not support scale program updating.

NOTE



NOTE

When updating the program on the scale, it is very important that the correct program file is sent to the scale. Sending an incorrect file to the scale may cause the scale to malfunction. This will make the program update function unavailable and therefore you will be unable to use i-View to send the correct file. Be very careful when updating the scale program.

7.1 Get Program from Scale

Use the following procedure to backup the scale application program. The received program will be in binary format.

1. Select the scale on the left side of the screen. This displays the scale name and current program ID at the top right of the screen.
2. Click the **Get Prog. from Scale** button. This opens a file Save As dialog to specify the file in which to save the scale program. Select a file and click the **Save** button.
3. i-View starts receiving the program from the scale. A dialog appears displaying the progress of data transfer. A confirmation message appears when data transfer finishes. This completes backing up of the scale program.

If any error occurs during communications with the scale (if the scale is not in "Normal Mode", for example), an error message will appear describing the problem. In this case the program backup will not be performed.

7.2 Update Program on a Single Scale


Use the following procedure to update the application on a specified scale. Typically, the updated program file will have been provided by your Ishida dealer. Take great care to send the correct file to the scale as an incorrect file may cause the scale to malfunction.

1. Select the scale on the left side of the screen. This displays the scale name and current program ID at the top right of the screen.
2. Click the **Update Prog. on Scale** button. This opens a File Open dialog to specify the new program file to update on the scale. Two different file formats are supported.

Motorola format (*.MOT) Motorola format was used to distributing scale application files in the past. i-View converts Motorola files to binary format internally before sending to the scales.

Binary (*.BIN) Scale application files are typically provided in binary format. Also, programs received from the scale using **Get Prog. from Scale** are in this format..

3. Select the correct file and click the **Open** button. The following confirmation dialog appears.



4. If everything is OK, click the **OK** button to start sending the program to the scale. A dialog appears displaying the progress of data transfer. A confirmation message appears when data transfer finishes. This completes updating of the scale program.
If any error occurs during communications with the scale (if the scale is not in "Normal Mode", for example), an error message will appear describing the problem. In this case the program will not be updated on the scale.
5. Typically, the scale will reset automatically after receiving the new program, but some older versions of the scale firmware require that you reset the scale manually before the new program takes effect.
i-View waits for approximately 30 seconds after sending the program completes to allow the scale to reset, then refreshes the scale data via the comms link. The new program version number should appear in the **Prog. Version** column on the left side of the screen and a service journal entry is generated automatically to record the program update.

7.3 Update Program on All Scales

This updates the application on all currently connected scales. The operation is the same as described in 7.2 *Update Program on a Single Scale* above except that you use the **Update Prog on All Scales** button.



NOTE

When updating the program file on all scales, it is very important to check that the program you are sending is correct for **all** scales. Sending an incorrect file to a scale may cause the scale to malfunction. This will make the program update function unavailable and therefore you will be unable to use i-View to send the correct file. Be very careful when updating the scale program.


An error message appears if communications with any scale is unsuccessful. In this case, the program is not updated on that scale (but is updated on all other scales). After performing a program update for all scales, i-View waits for approximately 30 seconds to allow the scale to reset, then refreshes the scale data via the comms link. The new program version number should appear in the **Prog. Version** column on the left side of the screen and a service journal entry is generated automatically for each scale to record the program update. Check that the program version IDs for each scale have been updated correctly.

8. Service Journal

The purpose of the service journal is to record the service history for each scale.


Typically, the service person will use i-View to enter details of any service visits to each scale.

i-View also generates service journal entries automatically to record whenever a new firmware program is sent to the scale using the *Scale Program Update* function.



The procedure for using the service journal is as follows:


1. Select the scale on the left side of the screen. This displays the service journal for that scale on the right of the screen.
2. Click the **Add Journal Entry** button to add a new journal entry. This opens the dialog shown below for you to enter the details of the service visit.



3. If you wish to make a copy of the journal entry, click the **Export Journal** button at the bottom right of the screen to display the following dialog. This provides a range of options for outputting the service journal to a file.

Select the desired options, then click OK.

i-View asks whether you wish to view the resulting file in Windows Notepad. If you need to printout the file, click **Yes**, then select **Print** from the **File** menu in Notepad.



The dialog box, titled "Service Journal Export Settings", contains the following options:

- Export for which scales?**
 - Selected scale only
 - All scales
- Export format**
 - Report format
 - CSV format (for Excel)
- Date range**
 - Specify a date range
 - From: 2001/09/14
 - To: 2002/09/14

Buttons: OK, Cancel

9. Event Log

The event log records a list of all significant events that occur in the i-View program. This includes the following:

- Scale status changes (e.g. Normal <-> Setup mode)
- Backup and restore operations
- Program backup and update operations

The event log can be turned on or off and the length of time log data is maintained can be specified. See section 3.1.4 *Event Log Setup* for details.

To view the event log, select **View Event Log** from the **View** menu. This runs Windows Notepad and opens the event log file. Use Notepad to view or printout the log.

The figure below shows a sample output.

```
2001/07/18 11:26:31|G Starting i-View
2001/07/18 11:52:56|G Loaded setup file D:\Dev\Slp3\Slp3Test.sit
2001/07/18 11:53:57|S Scale "Bakery #1" (ID=1) : Status change Start
i-View -> Normal Mode
2001/07/18 11:53:57|S Scale "Bakery #2" (ID=2) : Status change Start
i-View -> Not Connected
2001/07/18 15:34:23|B Backed up scale "Bakery #1" (ID=1) to file:
C:\Program Files\Ishida\i-View\BakeryBackup.abk
2001/07/18 15:52:45|B Backed up scale "Bakery #1" (ID=1) to file:
C:\Program Files\Ishida\i-View\BakeryBackup.abk
2001/07/18 15:58:53|S Scale "Bakery #1" (ID=1) : Status change
Normal Mode -> Busy
2001/07/18 16:18:12|B Restored backup to scale "Bakery #1" (ID=1)
from file: C:\Program Files\Ishida\i-View\BakeryBackup.abk
2001/07/18 16:18:13|S Scale "Bakery #1" (ID=1) : Status change Busy
-> Normal Mode
2001/07/18 20:37:09|B Read program from scale "Bakery #1" (ID=1) and
saved in file: C:\Program Files\Ishida\i-View\IVPROG1.BIN
2001/07/18 20:53:39|B Updated program on scale "Bakery #1" (ID=1)
from file: C:\Program Files\Ishida\i-View\IVPROG1.BIN
```

10. i-View Setup

i-View has a number of setup data items that modify operation to suit the particular models of scale you are using. Typically, the i-View installation will install the correct setup for your site. Alternatively, you may select **Load Setup** from the **Setup** menu to load the settings from a file supplied by Ishida.

The following sections describe the setup information in detail. However, normal users should not need to modify the settings themselves.



NOTE

The main setup functions are only available if i-View is run in dealer mode. See 2.4 *Dealer Mode* for details.

10.1 Event Log Setup


See section 3.1.4 *Event Log Setup* in 3. *Getting Started*.

10.2 Error Definitions

The scale error log stores errors as two-digit codes. The error definitions specify the meaning of each scale error code.

To edit the error definitions, select **Error Definitions** from the **Setup** menu to display the following dialog. A password is required to access this dialog.


Use the **Add**, **Edit**, or **Delete** button to edit the definitions.



10.3 Configuration Data Setup

This specifies the meaning of the scale-specific data contained in the AC-4000 scale configuration.

To edit the setup, select **Configuration Data Setup** from the **Setup** menu to display the following dialog. A password is required to access this dialog.



The image shows a 'Configuration Data Setup Dialog' window with the following fields and controls:

- Country:** A drop-down menu currently showing 'New Zealand'.
- Use Nutrition?:** An unchecked checkbox.
- Unit Types:** A list box containing '01 Piece', '02 Pack', '03 Bag', '04 Box', and '05 Pieces'. To its right are 'Add', 'Edit', and 'Delete' buttons.
- Bar Code Types:** A list box containing '01 NON-PLU13', '02 NON-PLU8', '03 PLU13', and '04 PLU8'. To its right are 'Add', 'Edit', and 'Delete' buttons.
- Pos Code Types:** A list box containing '01 F2C5CPP4CP', '02 F2C5CPP4CP', '03 F2C6P4CP', '04 F1C6CPP4CD', '05 F2C5P5CD', '06 F1C6P5CD', '07 F2C4CPP5CD', and '08 F2C6W4CD'. To its right are 'Add', 'Edit', and 'Delete' buttons.
- Bar Code ITF Types:** A list box containing '01 F2C5P5w5', '02 F2C5P5Q5', '03 F2C5U', and '04 Auto'. To its right are 'Add', 'Edit', and 'Delete' buttons.
- Buttons:** 'OK' and 'Cancel' buttons are located at the bottom center.

The meanings of each field in this dialog are as follows:

Country Select your country from this drop-down list for region-specific settings.

Use Nutrition Select this if you use nutrition information.

Unit Types This is the list of currently defined unit types and their values.

Bar Code Types This is the list of currently defined Bar Code types and their values.

Pos Code Types This is the list of currently defined Pos Code types and their values.

Bar Code ITF Types This is the list of currently defined Bar Code ITF types and their values.


The operation of each of the code type boxes is the same. Click **Add**, **Edit** or **Delete** to edit the definitions. If you are adding a new type, you will need to specify a name and a value for the type.

Click **OK** to close this dialog and save any changes.


10.4 ROM Switch Fields

The scale configuration data includes a set of 64 “ROM switches” which control scale operation. The meaning of each ROM switch varies between scale models and countries. The ROM switch fields setup is used to define the meaning of each ROM switch.

To edit the field definitions, select **ROM Switch Fields** from the **Setup** menu to display the following dialog. A password is required to access this dialog.



Click on **Add**, **Edit** or **Delete** to edit the fields. When you click on **Add** or **Edit**, a dialog similar to the one below appears.



The meanings of each field in this dialog are as follows:

Name	The name of the ROM Switch field
Field Type	The ROM Switch Type, from “ROM Switch 0” to “ROM Switch 63”
Display?	Select this if you want the field to be displayed on the ROM Switch Settings screen
Display Width	The number of digits that should be displayed. Must be at least 1.
Digits after Dec. Pt.	The number of digits after the decimal point
Display in Hex Format?	Determines whether the value is displayed in Hexadecimal on the ROM Switch Settings screen
Maximum	Select the maximum value that should be allowed to be input.
Minimum	Select the minimum value that should be allowed to be input.
Default Value	Select the default value for this ROM Switch.
Field Values	These values are preset values that can be selected for the ROM Switch. Click Add , Edit or Delete to edit this list. If there are values in this list then these values are the only ones which will be available on the ROM Switch Settings screen. If this list is empty then any value can be entered.

Click on **OK** to save changes to the field, or **Cancel** to cancel any changes. Then click **OK** on the “Field Definitions” dialog to save changes to the field definitions list.