

# **LIGHTNING**

**MODELS EV1P25 thru EV1P75 MANUAL**

A large, stylized graphic of a lightning bolt or swirl, rendered in a light blue color, positioned behind the word 'INSTRUCTIONS'.

## **INSTRUCTIONS**

**INSTALLATION**

---

**OPERATION**

---

**MAINTENANCE**

Book No. 1563



# INSTRUCTION MANUAL MODELS EV1P25 thru EV1P75 TABLE OF CONTENTS MANUAL 1563

TITLE	PAGE
SAFETY CHECK LIST .....	IT-2144
DIMENSION DRAWING .....	DS-P-70
ASSEMBLY DRAWING .....	L-17094
“EV” SERIES BUNG ADAPTER .....	DS-P-72
GENERAL INSTRUCTIONS “EV” SERIES MIXER DIRECT DRIVE .....	IT-3694
INITIAL INSPECTION, SHIPPING ARRANGEMENT .....	SECTION-1
MIXER INSTALLATION .....	SECTION-2
SHAFT AND IMPELLER INSTALLATION .....	SECTION-3
SHAFT REMOVAL .....	SECTION-4
MIXER OPERATION .....	SECTION-5
LUBRICATION .....	SECTION-6
DISASSEMBLY INSTRUCTIONS .....	SECTION-7
ASSEMBLY INSTRUCTIONS .....	SECTION-8
AIR MOTOR REQUIREMENTS .....	SECTION-9
AIR MOTOR LUBRICATION .....	SECTION-10
MODEL NO. 2 AND 4 AIR MOTOR DRIVE ASSEMBLY .....	L-17617
NON-LUBRICATED AIR MOTOR INSTRUCTIONS .....	IT-3710
AIR MOTOR REQUIREMENTS .....	SECTION-1
USE OF AIR MOTOR IN HAZARDOUS ATMOSPHERE .....	SECTION-2
ELECTRIC MOTOR INSTRUCTIONS .....	IT-2588
INITIAL INSPECTION .....	SECTION-1
MOTOR MAINTENANCE AND STORAGE .....	SECTION-2
OPERATING INSTRUCTIONS <b>LIGHTNIN</b> VARI-MIX DRIVE (VM SERIES) .....	IT-5252
(WITH <u>BALDOR</u> MOTOR)	
GENERAL .....	SECTION-1
SPECIFICATIONS .....	SECTION-2
INSTALLATION & OPERATION .....	SECTION-3



# INSTRUCTION MANUAL MODELS EV1P25 thru EV1P75 TABLE OF CONTENTS MANUAL 1563

TITLE	PAGE
OPERATING INSTRUCTIONS <i>LIGHTNIN</i> VARI-MIX DRIVE (VM SERIES) .....	IT-2023
(WITH <u>RELIANCE</u> MOTOR)	
GENERAL .....	SECTION-1
SPECIFICATIONS .....	SECTION-2
INSTALLATION & OPERATION .....	SECTION-3
RECOMMENDED SPARE PARTS EV "P" SERIES DIRECT .....	IT-3711
<i>LIGHTNIN</i> <sup>R</sup> U.S. SALES OFFICE DIRECTORY .....	IT-3839

IT-5203

6-27-03


## SAFETY CHECK LIST

### IMPORTANT

All *LIGHTNIN* Mixers and Aerators are provided with properly designed lifting devices and safety covers to avoid potential injury and/or equipment damage. The following SAFETY CHECK LIST should be THOROUGHLY REVIEWED AND ADHERED TO before operating or performing maintenance on the mixer. FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN SERIOUS INJURY.

1. Use only the lifting device provided on your unit to install the mixer. Use shouldered eyebolts and tighten securely to handle component parts. We strongly recommend that the hoist rings be of safety swivel type with 360° rotational capability.
2. DO NOT connect the motor to the power source until all components are assembled, the mixer is installed, and all hardware is tightened to the proper torque which is specified in the operation and maintenance manuals supplied by *LIGHTNIN*.
3. DO NOT operate shaft sealing devices at temperatures or pressures higher than those specified in the manual or on the nameplates.
4. DO NOT service the mixer until you have followed your "Control of Hazardous Energy Sources" (lockout, tagout procedure) as required by OSHA 29 CFR Part 1910.
5. DO NOT touch rotating mixer parts.
6. DO NOT operate mixer for service other than its intended use.
7. DO NOT make any field changes or modifications (horsepower, output speed, shaft lengths, impellers, etc.) without reviewing the changes with your *LIGHTNIN* Sales Representative or the *LIGHTNIN* Customer Service Department.
8. DO NOT install an aftermarket Variable Frequency Drive without first consulting your *LIGHTNIN* Sales Representative or the *LIGHTNIN* Customer Service Department to determine the compatibility of the existing motor with the Variable Frequency Drive.
9. DO NOT operate mixer until you have checked the following items:
  - A. Make sure the mixer is properly grounded.
  - B. Ensure all protective guards and covers are installed.
  - C. Ensure all detachable components are securely coupled to the mixer.
  - D. Thoroughly REVIEW and ADHERE TO the mixer operating instructions supplied by *LIGHTNIN*.
  - E. Ensure the mixer output shaft rotates freely by hand.
  - F. Ensure all personnel and equipment are clear of rotating parts.
  - G. Ensure all external connections (electrical, hydraulic, pneumatic, etc.) have been completed in accordance with all applicable codes and regulations.
10. DO NOT enter the mixing vessel UNLESS:
  - A. The mixer power supply is locked out (follow Item number 4).
  - B. The mixer shaft is firmly attached to the mixer drive or the shaft is supported securely from below.
  - C. You have followed applicable confined space regulations.





231	MIXER SHAFT		
123	ROTATIONAL INSERT	61	FLAT WASHER (4)
122	HEX LOCKNUT	60	SOCKET HEAD CAP SCREW (4)
121	FLAT WASHER	59	RETAINING RING
120	HEX HEAD CAP SCREW	58	HEX SOCKET SET SCREW - NYLOK
119	RETAINING RING	45	BALL BEARING
118	CUP WASHER	44	RETAINING RING
116	CLAMP SCREW	42	OIL SEAL
115	TANK CLAMP	41	BALL BEARING
101	MOTOR	40	LANYARD
72	HEX WRENCH	39	EXPANSION PLUG
65	MOTOR COUPLING INSERT	36	HOUSING
64	MOTOR COUPLING HALF	35	DRIVE QUILL
63	MOTOR COUPLING HALF	22	GASKET
ITEM	PART NAME	ITEM	PART NAME



CERTIFIED

© LIGHTNIN  
1996


ALL EQUIPMENT DESIGN AND APPLICATION DATA SHOWN HEREIN AND RELATED KNOW-HOW IS CONFIDENTIAL AND THE PROPERTY OF THE LIGHTNIN GROUP OF COMPANIES. NO USE OR DISCLOSURE THEREOF MAY BE MADE WITHOUT OUR WRITTEN PERMISSION.

**LIGHTNIN**®

MIXERS AND AERATORS

ASSEMBLY DRAWING

**EV "P" SERIES MIXER  
DIRECT DRIVE  
BEARING HOUSING ASSEMBLY**



CERTIFIED

ALL DIMENSIONS IN INCHES.

© LIGHTNIN  
1996

ALL EQUIPMENT DESIGN AND APPLICATION DATA SHOWN HEREIN AND RELATED KNOW-HOW IS CONFIDENTIAL AND THE PROPERTY OF THE LIGHTNIN GROUP OF COMPANIES. NO USE OR DISCLOSURE THEREOF MAY BE MADE WITHOUT OUR WRITTEN PERMISSION.

**LIGHTNIN**

MIXERS AND AERATORS  
DIMENSION DRAWING

**"EV" SERIES MIXER  
BUNG ADAPTER**

231	MIXER SHAFT
153	LOCKWASHER
152	HEX NUT
151	PLAIN WASHER
150	HX HD CAP SCREW
123	INSERT
122	LOCK NUT
121	PLAIN WASHER
120	HX HD CAP SCREW
53	MOUNTING PLATE
36	HOUSING
3	BUNG ADAPTER
ITEM	PART NAME

Certified By \_\_\_\_\_ Date \_\_\_\_\_

DRAWING NO. DS-P-72A



# GENERAL INSTRUCTIONS "EV" SERIES MIXERS DIRECT DRIVE

## SECTION 1 – INITIAL INSPECTION, SHIPPING ARRANGEMENTS

1. 1 Check the shipping crates and your **LIGHTNIN** equipment for possible shipping damage. Report any damage immediately to the carrier and our factory.
1. 2 The mixer and impellers are packed together. The mixer shaft, if over 48 inches long, is packed in a separate container.
1. 3 Do not remove any protective coatings or wrappings until the mixer is ready to be put into service. If the mixer is to be stored, store only in an indoor, clean, dry location with controlled temperatures of 15° C to 40° C (59° F to 104° F).

## SECTION 2 – MIXER INSTALLATION

2. 1 Refer to Installation drawing for:
  - a. Proper mixer mounting and location.
  - b. Proper minimum impeller off-bottom and relative spacing for dual impeller applications.
2. 2 Lock-out power before positioning mixer, and review safety instructions before starting mixer.
2. 3 The clamp and beamplate are cast offset at recommended 20° horizontal plane and adjustable 0–10° in the vertical plane. Clamp and beamplate are also available with zero degree offset in the horizontal plane and adjustable 0–10° in the vertical plane. Refer to Table 1 for recommended angular positions.




Table 1 – Mixer positioning

### 2. 4 BOLT TIGHTENING TORQUE RECOMMENDATIONS

- a. Inadequately or improperly tightened hardware can loosen due to vibration or the reactions imposed by fluid forces. This can result in reduced equipment service life or damage and failure.

b. Recommended torques for tightening the bolts and screws on your **LIGHTNIN** mixer are listed with assembly instructions. Use of a torque wrench is recommended to ensure compliance with torque recommendations.

c. The amount of torque required to maintain a tight connection can vary considerable for bolts of the same size under different operating conditions. Variations such as basic joint design, compression factors, type and strength of base and hardware material, surface finish of mating parts and lubrication are only some of the factors that influence the tightness of bolted connections for given torque values.

d. All bolts should be coated with oil, grease, or an anti-seize compound whenever possible. The threads and bearing face of bolt heads and/or nuts should be lubricated.

e. **ALL BOLTS SHOULD BE RETIGHTENED AFTER THE UNIT HAS BEEN RUN UNDER LOAD FOR TWO (2) WEEKS, AND AT EACH SCHEDULED SHUT-DOWN THEREAFTER.**

f. Unless otherwise specified, it is recommended that metric commercial standard class 8.8 bolts and screws, and class 8 nuts be used for all bolted connections. For inch hardware use GR5.

### SECTION 3 – SHAFT AND IMPELLER INSTALLATION

3. 1 Install the impeller(s) on the mixer shaft (231) by tightening the set screws in the impeller hub. Refer to the installation drawing for recommended dual impeller spacing if two impellers are supplied. Refer to Impeller Assembly drawing for general impeller orientation.

3. 2 Clean the mixer shaft (231) end and drive quill (51) thoroughly.

3. 3 Orient the drive quill so that the set screw (58) aligns with the hole in the bearing housing (36). Align quill shaft by inserting lower shaft (231) into quill and rotate quill manually.

3. 4 Grasp mixer shaft approximately 20 inches below the shaft top and insert the mixer shaft completely into the drive quill, until it contacts the top of the quill bore. Align flat on shaft with set screw (58). Tighten set screw (58).




Figure 1 – Shaft Installation

#### 3. 5 DRIVE QUILL ORIENTATION

a. **NORMAL LIGHT CONDITIONS** – Rotate the drive quill until the set screw (58) aligns with the access hole in the housing (36). Rotate drive quill by inserting lower shaft into drive quill and rotating by hand.

b. **LOW LIGHT CONDITIONS** – If the mixer shaft is being installed in low light conditions, the drive quill can be oriented by feel. Insert lower shaft into drive quill and rotate the drive quill (35) by hand until the set screw (58) can be felt with the hex wrench through the access opening.

3. 6 With the drive quill oriented, insert the 7/32" hex key (72) provided into the housing opening and tighten the set screw (58) to (15–30 ft–lbs). **DO NOT IMPACT THE WRENCH OR USE AN EXTENSION.**
3. 7 Check for free movement of all components by rotating the mixer shaft.

## SECTION 4 – SHAFT REMOVAL

**CAUTION: THE UPPER PORTION OF THE MIXER SHAFT (231) MAY BE HOT TO THE TOUCH. ONCE REMOVED FROM THE DRIVE QUILL (35), DO NOT GRASP THE UPPER 20" OF THE MIXER SHAFT.**

It is recommended that the mixer be removed from the tank before shaft or shaft and impeller are removed.

- a. Make sure all electrical power is disconnected.
- b. Grasp impeller by hand (or shaft with a strap wrench) and rotate mixer shaft (231) until the drive quill set screw (58) aligns with the access hole in the housing (36). See Caution above.
- c. With hex key (72) loosen set screw (58) and back out two (2) turns. See Figure 2.
- d. Remove mixer shaft from quill. See Caution above.




Figure 2 – Shaft Removal

## SECTION 5 – MIXER OPERATION

5. 1 This **LIGHTNIN** mixer is designed for continuous operation and normally needs no additional maintenance.

**CAUTION: IT IS NOT RECOMMENDED TO OPERATE THE MIXER WITH EXTREME VORTEXING OR SURGING OF THE LIQUID BEING MIXED.**

5. 2 At the end of two weeks service, check all hardware for tightness.

**WARNING: AT THE END OF THE MIXING CYCLE, IT IS GOOD PRACTICE TO TURN OFF THE MIXER BEFORE THE TANK HAS BEEN DRAINED TO A LEVEL WHICH WILL RESULT IN EXCESSIVE SPLASHING. THIS MAY RESULT IN SHAFT DAMAGE.**

---

## SECTION 6 – LUBRICATION

All mixer bearings are the sealed type and are pre-packed with lubricant. Relubrication of these bearings is not necessary.

## SECTION 7 – DISASSEMBLY INSTRUCTIONS

**WARNING: DISCONNECT MOTOR LEADS OR OTHERWISE LOCK-OUT POWER SUPPLY BEFORE SERVICING THE MIXER. EYE PROTECTION MUST BE WORN.**

7. 1 This mixer is precision manufactured and assembled to provide long trouble free service when properly maintained. If it becomes necessary to disassemble the unit, careful precise reassembly is necessary.

7. 2 Refer to the assembly drawings for location of parts.

7. 3 Equipment that will be required to service the mixer, in addition to standard mechanics tools is, a rubber mallet, retaining ring pliers, metric and "inch" allen wrenches, arbor press and torque wrench.

7. 4 When disassembling the mixer, clean external surfaces adjacent to prevent dirt from entering the housings.

7. 5 It is recommended that oil seals and gaskets be replaced when the mixer is disassembled.

### 7. 6 SEAL REPLACEMENT

Inspect oil seals and gaskets for nicks, gouges and deformities. When replacing seals:

- a. Coat the lips of seals with bearing grease.
- b. Install oil seal with lip facing up as shown in Figure 3.
- c. Coat the section of shaft sealing surface with oil.

### 7. 7 BEARING REPLACEMENT

- a. Old bearings can be removed with a puller or an arbor press.
- b. New bearings can be pressed on the shafts. Be careful to apply load only to the inner race.
- c. Make sure the bearings are tightly seated against the shaft or housing shoulders with no clearance.

### 7. 8 SHAFT REMOVAL

Loosen set screw (58) and remove mixer shaft (231) as outlined in Section 4.

### 7. 9 MOTOR REMOVAL

- a. Remove the mixer from the tank and remove the mixer shaft (231) as outlined in Section 4.
- b. Tip the mixer upside down on a workbench.
- c. Remove the four socket head cap screws (60) holding the bearing housing (36) to the motor (101).
- d. Lift the bearing housing off the motor. It may be necessary to tap the bearing housing GENTLY with a rubber mallet to get the bearing housing to separate from the motor.
- e. Remove motor coupling half (63) and insert (65) from motor shaft.

### 7. 10 BEARING MODULE DISASSEMBLY

- a. Remove the oil seal (42) from the drive quill (35). This oil seal will be damaged and a new oil seal must be installed when reassembled.
- b. Remove retaining ring (44).
- c. Remove upper retaining ring (59).
- d. Place the bearing housing upright in a press, and press out the drive quill (35) and lower bearing (41).

- e. Remove lower retaining ring (59) and bearing (41) from the drive quill (35).
- f. Remove upper bearing (41) from housing (36).
- g. Inspect bearing (41) for excessive wear. Replace if necessary.

## SECTION 8 – ASSEMBLY INSTRUCTIONS

### 8.1 QUILL ASSEMBLY

Insert the set screw (58) into the drive quill (35) until it is flush with the bore of the quill.

### 8.2 BEARING MODULE ASSEMBLY

- a. Press the lower bearing (41) onto the drive quill (35) bearing journal. The bearing must seat against the drive quill shaft shoulder with no visible gap.
- b. Install the lower external retaining ring (59).
- c. Press the drive quill assembly into the bearing housing (36) from the bottom until the bearing seats on the housing shoulder.
- d. Install lower retaining ring (44).
- e. Press oil seal (42) in place with the seal cavity facing as shown in Figure 3. Make sure the oil seal has the internal spring removed. This is a non-lubricated seal, and will run hot and have a shortened life if the spring is not removed.
- f. Turn the bearing housing over, support the assembly on the quill shaft (35) and install the upper bearing (45) by pressing it into the bearing housing and onto the quill shaft.
- g. Install the upper retaining ring (59).
- h. Support the bearing housing assembly in an upright position and press the drive quill downward until the bearing (41) shoulders on the retaining ring (59). This will relieve any locked in axial load on the bearing created during assembly.




Figure 3– Oil Seal Installation

### 8.3 FINAL ASSEMBLY (Refer to assembly drawing L-17094).

- a. Install gasket (22) around the bearing housing (36).
- b. Assemble mixer coupling hub (64) to the quill shaft (35), until it seats against the upper retaining ring (59). Tighten the mixer hub set screw to 5 ft-lbs. Install the insert (65) on the mixer hub.
- c. With the motor upside down on a workbench, assemble the motor coupling hub (63) to the motor shaft as shown in Figure 4. Align motor coupling hub keyway 180° opposite motor output shaft keyway. Motor coupling hub set screw is tightened against motor output shaft (key is not used in the assembly). Tighten the motor hub set screw to 5 ft-lbs.




Figure 4 – Motor Coupling Hub Installation

- d. Align coupling hubs and assemble the bearing housing to the motor, using care so as not to damage the flexible element (65) or the gasket (22).
- e. Bolt the bearing housing (36) to the motor (101), using socket head cap screws (60) and washers (61). Alternately tighten the hardware to 9 ft–lbs to ensure that all components are drawn evenly together.
- f. Install mixer shaft (231) as outlined in Section 3.

### SECTION 9 – AIR MOTOR REQUIREMENTS

Be sure your compressor has capacity for both pressure and the proper cubic feet per minute air displacement. Wet air, and low pressure will cause sticking of the motor, requiring hand starting. It is important to use an air filter and moisture trap near the motor for removal of foreign matter. Maximum recommended operating pressure is 100 P.S.I.

AIR PRESSURE / AIR CONSUMPTION GUIDE  
FOR AIR MOTOR DRIVEN MIXER  
(AIR MOTOR OPERATING AT 1800 RPM)

H.P.	GAST MOTOR #	SHAFT RPM	PRESSURE CONSUMPTION REQUIRED	
			* (PSIG)	** (CFM FREE AIR)
1/3	#2	1800	60	15
1/3	#2	360	60	15
1	#4	1800	85	30
1	#4	360	85	30

\* Live pressure should be approximately 1–1/2 times the operating pressure of the air motor. The full line pressure will then be available for overloads and startup.

\*\* CFM free air refers to air at atmospheric conditions measured at the inlet of the compressor.

Table 2

### SECTION 10 – AIR MOTOR LUBRICATION


10. 1 Use only a high detergent lubricant of the recommended viscosity. Recommended oils are shown in Table 3.

10. 2 For continuous duty or high speed operation, it is recommended that an automatic lubricating device in the air line be provided to feed 1 to 3 drops per minute to the motor. If required request optional air–line lubricator (part # 151030psp).


10. 3 For manual oiling, remove the oil cap at the top of the motor, and add one squirt of oil at the end of each 8 hours of operation.

RECOMMENDED LUBRICANT	AMBIENT TEMPERATURE	GRADE OF OIL
GAST AD 220 (SAE #10) OR A HIGH DETERGENT AUTOMOTIVE ENGINE OIL DESIGNED FOR ANY ONE OR MORE OF THE FOLLOWING API SERVICE RATINGS SB, SC, SD, SE, CB, CC, CD.	BELOW 32° F	DILUTE SAE #10 OIL WITH 25% KEROSENE
	32° F TO 100° F	SAE #10 OIL
A HIGH DETERGENT AUTOMOTIVE ENGINE OIL DESIGNATED FOR ANY ONE OR MORE OF THE FOLLOWING API SERVICE RATINGS – SB, SC, CD, CE, CB, CC, CD.	101° F TO 200° F	SAE #20 OIL

Table 3 – Motor Lubrication



**SECTION THRU ROTOR HOUSING**



WHEN ORDERING PARTS, SPECIFY:  
MOTOR SERIAL NO., ITEM NO. AND  
DRAWING NO.

332	PRESSURE RELIEF VALVE
329	GASKET
328	FLANGE
327	FILLISTER HEAD MACHINE SCREW
326	FILLISTER HEAD MACHINE SCREW
324	MUFFLER
323	END CAP ASSEMBLY
322	BEARING RETAINER
319	O-RING
317	FILLISTER HEAD MACHINE SCREW
316	ROTOR & DRIVE SHAFT ASSY
315	GASKET
314	DOWEL PIN
313	SHAFT SEAL
312	UPPER BALL BEARING
311	GASKET
310	BALL BEARING
309	ROTOR VANE (4 REQ'D)
308	UPPER BEARING HOUSING
307	LOWER BEARING HOUSING
306	ROTOR HOUSING
110	PIPE NIPPLE
109	NEEDLE VALVE
ITEM	PART NAME



CERTIFIED

© LIGHTNIN  
2001

ALL EQUIPMENT DESIGN AND APPLICATION DATA SHOWN  
HEREIN AND RELATED KNOW-HOW IS **CONFIDENTIAL** AND  
THE PROPERTY OF THE LIGHTNIN GROUP OF COMPANIES.  
NO USE OR DISCLOSURE THEREOF MAY BE MADE WITHOUT  
OUR WRITTEN PERMISSION.

**LIGHTNIN**

MIXERS AND AERATORS  
ASSEMBLY DRAWING

**MODEL NO. 2 AND 4  
AIR MOTOR DRIVE**

(1) FURNISHED ON 2 SIZE DIRECT DRIVE UNITS ONLY.



## NON-LUBRICATED AIR MOTOR INSTRUCTIONS

**WARNING: MOTOR CANNOT EXCEED 1800 RPM.**

**WARNING:** To prevent explosive hazard, DO NOT drive this air motor with combustible gases. Injury and/or property damage can result.

**WARNING:** DO NOT USE KEROSENE OR OTHER COMBUSTIBLE SOLVENTS.

**WARNING:** EYE PROTECTION IS REQUIRED. Keep face away from exhaust port, and DO NOT flush unit with any flammable solvent.

**WARNING:** Foreign material exiting the air motor can be hazardous.

**CAUTION:** Do not drive the air motor in excess of recommended speeds.

### SECTION 1 – AIR MOTOR REQUIREMENTS

- 1.1 In order to insure maximum performance and life from this motor, it is essential that the following points be observed.
- 1.2 Be sure your compressor has capacity for both pressure and the proper dm<sup>3</sup>/s (CFM) air displacement. Wet air, and low pressure will cause sticking of the motor. It is important to use an air filter and moisture trap in the air line ahead of the motor for removal of foreign matter.
- 1.3 Maximum operating pressure is 550 kPa (80 PSI).
- 1.4 This motor may be operated at any altitude, provided adequate air line lubrication is supplied. Being totally enclosed, it can be used in any environment within the temperature limits of  $-7^{\circ}\text{C}$  to  $+80^{\circ}\text{C}$  ( $+20^{\circ}\text{F}$  to  $+175^{\circ}\text{F}$ ).
- 1.5 The speed of the air motor increases as the load is reduced. Shaft vibration may occur while operating under light load, such as running in air. If excessive vibration occurs, adjust the speed up or down with the air valve until the vibration diminishes. Running the motor at no load and excessive speeds can also cause excessive internal heat build-up. Loss of internal clearances and rapid motor damage will result.
- 1.6 Motor may be run continuously at speeds up to the rated running conditions shown in the performance data sheets. These sheets give the output power – torque based on running conditions with the actual pressure measured at the motor inlet ports.
- 1.7 Before final connection to the motor, blow out the air lines to remove any loose scale, swarf or abrasive dust which may be present.
- 1.8 A muffler is supplied with the motor. Do not operate the air motor with the exhaust port either unguarded or without a muffler. When the muffler is installed, ensure that condensation cannot run back into the motor port.
- 1.9 The air supply must be clean and relatively dry. Excessive moisture in the air line can cause rust formation in the motor and might also cause ice to form in the muffler. An air line filter should be fitted in the air supply line and located before the first control valve of the system.
- 1.10 For short length pipe runs, (for example up to 1800mm / six feet), the supply lines should be the same size as the inlet and exhaust ports, and larger for longer runs.
- 1.11 Refer to Table 1 for air pressure / air consumption guide for air driven motors.

	H.P.	SPEED CODE (1)	REQUIRED PRESSURE CONSUMPTION (2) (3)			
			kPa	PSIG	dm <sup>3</sup> /s FREE AIR	CFM FREE AIR
	1/4	EV1	415	60	7	14
	1/3	EV5				
	1/2	EV6	415	60	17	35
	3/4					

(1) SPEED CODE / MIXER OUTPUT RPM  
 EV1 = 1725  
 EV5 = 350  
 EV6 = 280

(2) LINE PRESSURE SHOULD BE APPROXIMATELY 1.5 TIMES THE OPERATING PRESSURE OF THE AIR MOTOR. THE FULL LINE PRESSURE WILL THEN BE AVAILABLE FOR OVERLOADS AND STARTUP.

(3) dm<sup>3</sup>/s (CFM) FREE AIR REFERS TO AIR AT ATMOSPHERIC CONDITIONS, MEASURED AT THE INLET OF THE COMPRESSOR.

**TABLE 1 – Air Pressure/ Air Consumption Guide (Air Motor Operating at 1725 RPM)**

1.12 Air line filtration for lubricated service:

- a . Use 64 micron filter or better.
- b . The air line filter should be drained regularly and the element examined for signs of clogging.

1.13 Air motor lubrication requirements:

The air motor will operate with or without lubrication, and generally speaking, performance will improve with lubrication.

1.14 SERVICING

If the motor is sluggish or inefficient, flush it with solvent (refer to Table 2 for recommended solvents). To flush a unit, disconnect air line and muffler and add several teaspoons of solvent directly into the motor. Rotate the shaft by hand in both directions for a few minutes, reconnect the air line, and SLOWLY apply pressure until there is no trace of solvent in the exhaust air. FLUSH UNIT IN A WELL VENTILATED AREA. Relubricate the motor with a squirt of oil in the chamber. If the vanes need replacing, or foreign materials are present in the motor chamber, an experienced mechanic may remove the end plate opposite the drive shaft end. DO NOT PRY WITH A SCREWDRIVER. It will dent the surface of the plate and body, causing leaks. A puller tool should be used which will remove the end plate while maintaining the position of the shaft. New vanes should have the edge with the corners cut on an angle facing towards the bottom of the vane slot.

MANUFACTURER	PRODUCT
GAST	FLUSHING SOLVENT #AH255 or AH255A
W.W. GRAINGER, INC.	DEM-KOTE 2X726
LOCTITE CORP.	LOCTITE SAFETY SOLVENT
PENETONE CORP.	INHIBISOL SAFETY SOLVENT
DOW CHEMICAL	CHLOROTHANE

**TABLE 2 – Recommended Flushing Solvent**

## SECTION 2 – USE OF AIR MOTORS IN HAZARDOUS ATMOSPHERES

- 2.1 At the present time, there are no known standards governing the operation of air motors in hazardous atmospheres. However, there are several points regarding the safety of air motors.
- 2.2 An air motor is not a source of electric sparks. However, it is possible that an article which is not part of the air motor (e.g., wrenches, hammers, etc.) could create a spark by sharply impacting a cast iron or aluminum case or the steel shaft of the air motor. Note that electric motor enclosures for both Class I and II hazardous locations can be made of iron, steel, copper, bronze or aluminum.
- 2.3 An air motor housing is not designed to contain an internal explosion as is an explosion-proof electric motor. The only possible internal source of ignition in an air motor is a contact between the stationary housing components and the rotating elements that might create a spark. The likelihood of this occurring is reduced by the fact that the contact must be made at precisely the same time as a flammable or explosive gas is introduced into the air motor in a sufficient quantity to achieve a flammable or explosive mixture, while overcoming the positive pressure of the driving gas. In other words, although highly improbable, an internal explosion in an air motor is possible.
- 2.4 An air motor is designed to be operated by compressed air, the expansion of which in normal operation creates a cooling effect. As a result, the temperature of the air motor will not exceed the higher of the temperatures of the surrounding atmosphere or the air delivered to the inlet.
- 2.5 **LIGHTNIN**<sup>®</sup> does not guarantee the safety of every application, but to ensure the safe operation of an air motor in your application, always follow the product directions and consult your **LIGHTNIN**<sup>®</sup> representative.

# ELECTRIC MOTOR INSTRUCTIONS

## SECTION 1 – INITIAL INSPECTION

- 1.1 Care is taken at the factory to assure that the motor arrives at its destination in first class condition. If there is evidence of rough handling or damage in shipment, file a claim at once with the carrier and notify our factory.

Examine the outside of the motor carefully for damage, with particular attention to the conduit box, fans and covers. Check nameplate for correct speed, kilowatt, voltage, hertz and phase for conformance with power supply. See Section 1.3 for warning on explosion-proof motors.

1.2 GENERAL DATA:

- a .Single phase totally enclosed motors are wired at our factory for correct rotation.
- b .All three phase and explosion-proof motors must be field wired for proper rotation. If rotation does not agree with nameplate, reverse any two line leads.
- c .Dual voltage motors must be wired for the desired voltage. Refer to the connection diagrams provided on the motor nameplate, inside the conduit box cover or in this manual.
- d .Refer to Section 2 for motor maintenance and storage instructions.

1.3 WARNING

- **EXPLOSION-PROOF MOTORS** – These motors are constructed to comply with the U.L. Label Service Procedure manual. When repairing and reassembling a motor that has an Underwriter's Label, it is imperative that the unit be reinspected and;

- a .All original fits and tolerances must be maintained
- b .All plugs and hardware to be securely fastened
- c .Any part replacements, including hardware, be accurate duplicates of the originals

**REPAIR WORK ON EXPLOSION-PROOF MOTORS CAN ONLY BE DONE BY THE ORIGINAL MANUFACTURER. VIOLATIONS OF ANY OF THE ABOVE ITEMS WILL INVALIDATE THE SIGNIFICANCE OF THE U.L. LABEL.**

- **EXPLOSION-PROOF MOTORS ARE EQUIPPED WITH AN INTERNAL CIRCUIT INTERRUPTING DEVICE WHICH TRIPS WHEN OVER HEATING OCCURS. THIS THERMAL PROTECTION CIRCUIT WILL RESET AUTOMATICALLY WHEN UNIT COOLS.**
- If the thermal protector continues to trip, some abnormal condition exists. This condition must be corrected before motor will operate normally.
- **ALWAYS DISCONNECT POWER LINE BEFORE SERVICING ANY PART OF THE MIXER.** Unexpected motor start-up may occur after the thermal protection circuit trips.

- 1.4 After unpacking and inspection to see that all parts are in good condition, turn the shaft by hand to be sure there are no obstructions to free rotation. Equipment which has been in storage should be tested prior to being put into service.

- a .It is best to check the insulation resistance of the stator winding with a megohmmeter. If resistance is lower than one megaohm, consult **LIGHTNIN**<sup>®</sup>.
- b .Motors are shipped from the factory with sealed, shielded bearings properly packed with grease and ready to operate. Bearings are not regreaseable.

- 1.5 WIRING – Examine the nameplate data to see that it agrees with the power circuit to which the motor is to be connected. The motor is guaranteed to operate successfully with frequency not more than 5% and voltage not more than 10% above or below the nameplate data, or combined variation of voltage and frequency of not more than 10% above or below nameplate data. Efficiency, power factor and current may vary from nameplate data.
- 1.6 Connect the motor leads to a power source that matches the line voltage and wiring diagram specified on the motor nameplate.
- 1.7 Check impeller shaft rotation by jogging the motor until it is determined that rotation is correct.
- 1.8 **CAUTION**

Repeated trial starts can overheat the motor (particularly for across-the-line starting). If repeated trial starts are made, allow sufficient time between trials to permit heat to dissipate from the windings or rotor to prevent overheating. Starting currents are several times running currents, and heating varies as the square of the current. Do not exceed 12 starts per hour.
- 1.9 **WARNING**

The frames and other metal exteriors of motors should be grounded to limit their potential to ground in the event of accidental connection or contact between live electrical parts and the metal exteriors. All motors should be grounded through the conduit box. Explosion-proof motors have an integral ground lead for grounding.
- 1.10 **WARNING**

Before starting motor, remove all unused shaft keys and loose rotating parts to prevent them from flying off.
- 1.11 Start motor and operate at minimum load prior to filling the tank or basin. Look for any unusual condition.

The motor should run smoothly with little noise. If the motor should fail to start and produces a decided hum, it may be that the load is too great for the motor or that it has been connected improperly. Shut down immediately and investigate for trouble.

## SECTION 2 – MOTOR MAINTENANCE AND STORAGE

Electric motors or other prime movers are not prepared by **LIGHTNIN**<sup>®</sup> for indoor storage beyond 12 months in a dry ambient atmosphere with controlled temperatures, or 6 months in a dry ambient atmosphere with no temperature control. **OUTDOOR STORAGE OF ELECTRIC MOTORS IS NOT RECOMMENDED BY ANY MOTOR MANUFACTURER.** For information on storage periods beyond those shown, consult **LIGHTNIN**<sup>®</sup>.

- 2.1 To insure continued reliable operation of electric motors, the following basic rule applies: **KEEP THE MOTOR CLEAN AND DRY.** Motors should be inspected, and output shaft rotated, at a minimum of 6 month intervals with increased frequency as needed depending upon the type of motor and the service.
- 2.2 Terminal connections and assembly hardware may loosen from vibration during service and should be tightened.
- 2.3 Insulation resistance should be checked at operative temperature and humidity conditions to determine possible deterioration of insulation due to excessive moisture or extremes in operating environment. If wide variations are detected, motors should be reconditioned.
- 2.4 LUBRICATION - The ball bearing has deep grooved, double shielded sealed bearings with sufficient lubricant packed into the bearings by the manufacturer for “life lubrication”. The initial lubricant is supplemented by a supply packed into larger reservoirs in the end shield at time of assembly. No grease fittings are provided, as the initial lubrication is adequate for up to 10 years of operation under normal conditions.
- 2.5 **STORAGE REQUIREMENTS FOR MOTORS** – These extended storage requirements must be followed to allow the submission of a valid warranty claim.

- a .The motors, if not mounted, are to be stored in the original containers in a clean, dry, protected warehouse.
- b .The storage area is to be free from any vibration and from extremes in temperature.
- c .Windings to be megged at the time equipment is put in storage. At the time of removal from storage, the resistance reading must not have dropped more than 50% from the initial reading. Any drop below this point, consult **LIGHTNIN**<sup>®</sup>.
- d .All external parts and motors subjected to corrosion should be protected by a corrosive resistant coating.

# OPERATING INSTRUCTIONS FOR *LIGHTNIN*® VARI-MIX DRIVE (VM SERIES)

## 1/3 & 3/4 FRACTIONAL HORSEPOWER TOTALLY ENCLOSED 50 & 60 CYCLE MOTORS ONLY

### SECTION 1 - GENERAL


- 1.1 This supplement pertains to specifications and operation of the *LIGHTNIN* "Vari-Mix" motor and control only. For complete mixer installation, operation and maintenance, refer to the instruction manual furnished with the unit.
- 1.2 The motor and control are not watertight and should not be exposed to rain, snow or water sprays. Outdoor use is not recommended unless protection from rain and snow is provided. Maximum ambient temperature is not to exceed 100° F.

### SECTION 2 - SPECIFICATIONS

- 2.1 A.C. line voltage must be within the allowable limits shown in the table. If the performance of the unit is not satisfactory, measure the line voltage. Maximum voltages shown in the table are peak voltages and should not be exceeded. Step up transformers can be obtained from local electrical supply houses if proper line voltages cannot be maintained.

**LINE VOLTAGE LIMITS**

MOTOR HERTZ (CYCLES)	NOMINAL LINE VOLTAGE	ALLOWABLE LINE VOLTAGE VARIATION
50 & 60	115 230	120V TO 109V 242V TO 219V



**2.2 Power Connections:**

To insure extended motor and mixer life and satisfactory performance, the precautionary measures noted should be followed.

- a. DO NOT connect the drive to an AC line that also services heavy motors, starters and contactors. These devices produce transients that can damage the operator control station. Transient voltages can be eliminated by using isolation transformers.
- b. Do not over voltage (5% maximum above nameplate voltage) drive on the AC side.

- c. It is recommended that a switch (not provided by **LIGHTNIN**) be installed in the line between the power source and the control station. On 3/4 HP motors, the windings are at full voltage even though the speed control is in the off position. The line switch should be turned off or line plug disconnected if the unit is not operated for periods of one hour or more.
  - d. DO NOT attempt to reverse the drive by means of an external switch.
  - e. If the unit is to be serviced, disconnect the line to the power source. Turning the speed control to the off position does not isolate the motor or control.
- 2.3 Mixer Shaft Nominal Speed Ranges:  
Direct drive models - 100 to 1750 RPM  
Gear drive models - 20 to 350 RPM  
Exact speed range depends on AC voltage.

### SECTION 3 - INSTALLATION & OPERATION

- 3.1 A power supply cord is furnished by **LIGHTNIN**. All motors are wired for the correct shaft rotation.
- 3.2 Before starting the unit:
- a. Make sure the mixer is properly located with relation to tank centerlines and angular requirements or offsets shown in the instruction booklet.
  - b. Fill the mixing vessel so that the liquid level is at least two impeller diameters above the lower impeller.
  - c. **IMPORTANT:** Before applying AC power to the operator's control station, make sure the speed control dial is in the off position. Switching on the AC line with the speed control dial in the on position can cause control failure.
- 3.3 To start the unit:
- a. Plug the drive into the correct power source as noted in Section 2.1.
  - b. Turn the speed control dial in a clockwise direction to the desired speed. The lighted switch indicates power is on.
  - c. To select a new speed, adjust the speed control dial.
- 3.4 To stop the drive, turn the rocker switch off. Leaving the control dial on without the motor shaft turning will cause motor damage.
- 3.5 115V MODELS HAVE A 4A BUSSMAN or LITTLEFUSE 312004 rectifier fuse located in the external fuse receptacle which protects the control electronics from overload. If the unit does not operate, check the fuse and replace if necessary.
- 3.6 230 volt models have an A5 fuse and an additional 10A fuse to protect the board components. If the unit does not operate, check the fuses and replace them if necessary.
- 3.7 Precautions during operation:
- a. While operating fixed mounting type units in air or during draw-off, the following maximum speeds are not to be exceeded:
    - All Direct Drive Models - 400 Impeller RPM Max.
    - All Gear Drive Models - 500 Motor RPM or 100 Impeller RPM Max.
  - b. XD or XJ Series - Clamp mounted portable mixer shafts may vibrate at certain speeds. If the shaft vibration is excessive, adjust the speed up or down until the vibration diminishes.
  - c. DO NOT operate under the following adverse conditions unless the control station is protected:
    - 1. Open outdoor service without protection from rain and snow.
    - 2. Ambient temperatures over 100° F.
    - 3. Hot, humid atmospheres such as steam vapors.



# OPERATING INSTRUCTIONS LIGHTNIN® VARI-MIX DRIVE (VM SERIES)

**1/3 & 3/4 FRACTIONAL HORSEPOWER TOTALLY ENCLOSED  
50 & 60 CYCLE MOTORS ONLY**

## SECTION 1 – GENERAL


- 1.1 This supplement pertains to specifications and operation of the **LIGHTNIN**® "Vari-Mix" motor and control only. For complete mixer installation, operation and maintenance, refer to the instruction manual furnished with the unit.
- 1.2 The motor and control are not watertight and should not be exposed to rain, snow or water sprays. Outdoor use is not recommended unless protection from rain and snow is provided. Maximum ambient temperature is not to exceed 100° F.

## SECTION 2 – SPECIFICATIONS

- 2.1 A.C. line voltage must be within the allowable limits shown in the table. If the performance of the unit is not satisfactory, measure the line voltage. Maximum voltages shown in the table are peak voltages and should not be exceeded. Step up transformers can be obtained from local electrical supply houses if proper line voltages cannot be maintained.

**LINE VOLTAGE LIMITS**

MOTOR HERTZ (CYCLES)	NOMINAL LINE VOLTAGE	ALLOWABLE LINE VOLTAGE VARIATION
50 & 60	115 230	120V TO 109V 242V TO 219V



Control Station  
Fuse Specifications (115V ONLY)  
BUSS TRON KAA 10 Rectifier Fuse  
(LIGHTNIN Part No. 120245)  
DO NOT Substitute

### 2.2 Power Connections:

To insure extended motor and mixer life and satisfactory performance, the precautionary measures noted should be followed.

- a . DO NOT connect the drive to an AC line that also services heavy motors, starters and contactors. These devices produce transients that can damage the operator control station. Transient voltages can be eliminated by using isolation transformers.
- b . Do not over voltage (5% maximum above nameplate voltage) drive on the AC side.
- c . It is recommended that a switch (not provided by **LIGHTNIN**<sup>®</sup>) be installed in the line between the power source and the control station. On 3/4 HP motors, the windings are at full voltage even though the speed control is in the off position. The line switch should be turned off or line plug disconnected if the unit is not operated for periods of one hour or more.
- d . DO NOT attempt to reverse the drive by means of an external switch.
- e . If the unit is to serviced, disconnect the line to the power source. Turning the speed control to the off position does not isolate the motor or control.

### 2.3 Mixer Shaft Nominal Speed Ranges:

Direct drive models – 100 to 1750 RPM

Gear drive models – 20 to 350 RPM

Exact speed range depends on AC voltage.


## SECTION 3 – INSTALLATION & OPERATION

- 3.1 An 8 foot power supply cord is furnished by **LIGHTNIN**<sup>®</sup>. All motors are wired for the correct shaft rotation.
- 3.2 Before starting the unit:
  - a . Make sure the mixer is properly located with relation to tank centerlines and angular requirements or offsets shown in the instruction booklet.
  - b . Fill the mixing vessel so that the liquid level is at least two impeller diameters above the lower impeller.
  - c . **IMPORTANT:** Before applying AC power to the operator's control station, make sure the speed control dial is in the off position. Switching on the AC line with the speed control dial in the on position can cause control failure.
- 3.3 To start the unit:
  - a . Plug the drive into the correct power source as noted in Section 2.1.
  - b . Turn the speed control dial in a clockwise direction to the desired speed. The pilot light indicates the switch is on.
  - c . To select a new speed, adjust the speed control dial.
- 3.4 To stop the drive, turn the speed control full counterclockwise to the off position unit a click is heard and the pilot light goes out. Leaving the control dial on without the motor shaft turning will cause motor damage.
- 3.5 If the pilot light flashes, the motor is overheated. Stop the drive or reduce speed and allow to cool. Should the pilot light continue to flash, check for overload conditions and/or measure line voltage.
- 3.6 115V MODELS HAVE A BUSS TRON KAA10 rectifier fuse located in the external fuse receptacle which protects the control electronics from overload. If the unit does not operate, check the fuse and replace if necessary. **NOTE:** Only BUSS TRON KAA10 fuses are to be used. There are no substitutes. These fuses are available from our factory as **LIGHTNIN**<sup>®</sup> Part Number 120245.

3.7 230 volt models have an ABC10 fuse. If the unit does not operate, check the fuse and replace if necessary.


3.8 Precautions during operation:

- a . While operating fixed mounting type units in air or during draw-off, the following maximum speeds are not to be exceeded:
  - All Direct Drive Models – 400 Impeller RPM Max.
  - All Gear Drive Models – 500 Motor RPM or 100 Impeller RPM Max.
- b . XD or XJ Series – Clamp mounted portable mixer shafts may vibrate at certain speeds. If the shaft vibration is excessive, adjust the speed up or down until the vibration diminishes.
- c . DO NOT operate under the following adverse conditions unless the control station is protected:
  - 1 . Open outdoor service without protection from rain and snow.
  - 2 . Ambient temperatures over 100° F.
  - 3 . Hot, humid atmospheres such as steam vapors.



**115V**  
VARI-MIX WIRING DIAGRAM

**CAUTION:**  
WHEN SERVICING,  
DISCONNECT UNIT  
FROM POWER  
SOURCE



**230V**  
VARI-MIX WIRING DIAGRAM

**CAUTION:**  
WHEN SERVICING,  
DISCONNECT UNIT  
FROM POWER  
SOURCE

**MIXER PARTS UNIT SIZE: EV "P" SERIES DIRECT DRIVE**

**For service and repair, call 1-888-MIX BEST (1-888-649-2378)**

ITEM NO.	IDENT. CODE ◆	DESCRIPTION	QTY.	PART NO.	PRICE (EACH)	SHIPMENT (WEEKS)
NOTE: See mixer nameplate or spec. sheet for unit size & ratio. See Assembly Drawing for item no. identifier						
		DRAWING: L-17094				
3		BUNG ADAPTER	1	271787PSP		
22*		GASKET	1	271795PSP		
35		DRIVE QUILL - 3/4"	1	271781316		
		DRIVE QUILL - 5/8"	1	271754316		
36		HOUSING	1	271838ALF		
39*		EXPANSION PLUG	1	271868PSP		
40		LANYARD	1	271869PSP		
41*		BALL BEARING	1	290151PSP		
42*		OIL SEAL	1	290701PSP		
44*		RETAINING RING	1	270822PSP		
45*		BALL BEARING	1	290158PSP		
53		MOUNTING PLATE @ 0 DEG.	1	272099ALM		
		MOUNTING PLATE @ 20 DEG.	1	272098ALM		
58		SET SCREW - NYLOK	1	271757STL		
59*		RETAINING RING	2	291592PSP		
60		SOCKET HEAD CAP SCREW	4	271778GR5		
61		FLAT WASHER	4	112005316		
63		COUPLING HALF	1	292267PSP		
64		COUPLING HALF	1	292269PSP		
65		COUPLING INSERT	1	292256PSP		
72		HEX WRENCH	1	127210BPF		
101		MOTOR	Contact <b>LIGHTNIN</b> Representative			
102		COUPLING	1	292248PSP		
115		TANK CLAMP @ 0 DEG.	1	271782ALM		
		TANK CLAMP @ 20 DEG.	1	271755ALM		
116		CLAMP SCREW	1	105413CPR		
118		CUP WASHER	1	112409CPS		
119		RETAINING RING	1	205445PSP		
120		HEX HEAD CAP SCREW	1	100147316		
121		FLAT WASHER	1	112009316		
122		HEX LOCKNUT	1	107407PSP		
123*		ROTATION INSERT	1	291619PSP		

◆ **IDENTITY CODE:**

Blank code denotes common parts

\* Recommended spare parts



**FOR PROMPT SERVICE, CALL YOUR *LIGHTNIN* SALES ENGINEER**  
He can save you time and money, and provide you with mixers and aerators guaranteed to do the job.  
***LIGHTNIN*® U.S. SALES OFFICE DIRECTORY**

**ALABAMA, BESSMER**

The Himic Company  
1121 Greenwood Crossings Court  
Bessemer, AL 35022  
Phone: 205-48-3113  
800-828-8167  
Fax: 205-481-3118

**ARIZONA, PHOENIX**

Quadra  
2803 E Chambers Street  
Phoenix, AZ 85040-3736  
Phone: 602-323-2370  
Fax: 602-305-6485

**CALIFORNIA, CARLSBAD**

(Municipal Only)  
The Coombs-Hopkins Company  
5411 Avenida Ecinas  
Suite 250  
Carlsbad, CA 92008  
Phone: 760-931-0555  
Fax: 760-931-9115

**CALIFORNIA, LOS ANGELES**

Leonard Enginereed Products  
11354 Burbank Blvd  
P O Box 868  
No. Hollywood, CA 91603-0868  
Phone: 818-760-4100  
Fax: 818-760-3254

**CALIFORNIA, SAN FRANCISCO**

Milton S. Frank Co., Inc.  
180 A Mason Circle  
Concord, CA 94520  
Phone: 925-609-1400  
Fax: 925-609-1406

**COLARADO, GOLDEN**

Centennial Equipment  
15760 W. 6th Avenue  
Golden, CO 80401  
Phone: 303-278-8400  
Fax: 303-278-1822

**FLORIDA, CLEARWATER**

Arroyo Process Equip. Inc.  
13750 Automobile Blvd  
Clearwater, FL 33762  
Phone: 727-573-5294  
FL only: 800-445-2630  
Fax: 727-573-0217

**FLORIDA, JACKSONVILLE**

Arroyo Process Equip. Inc.  
1105 North Lane Ave  
Jacksonville, FL 32254  
Phone: 904-783-6000  
FL only: 800-342-0436  
Fax: 904-781-0522

**FLORIDA, MULBERRY**

Arroyo Process Equip. Inc.  
1351 State Road 60 West  
Mulberry, FL 33860-8571  
Phone: 863-425-1145  
Fax: 863-425-2936

**FLORIDA, SEBRING**

(Municipal Only)  
Envirosales of Florida Inc.  
1101 U. S. 27 South  
Sebring, FL 33870-2171  
Phone: 863-314-0616  
Fax: 863-314-0617

**GEORGIA, ATLANTA**

GPM Inc.  
1000 Holcomb Wood Parkway  
Suite 418  
Roswell, GA 30076  
Phone: 770-998-1956  
Fax: 770-998-0119

**ILLINOIS, CHICAGO**

Mills-Winfield Engineering Sales,  
Inc.  
2004 Bloomingdale Road  
Glendale Heights, IL 60139  
Phone: 630-924-1208  
Fax: 630-924-1380

**INDIANA, INDIANAPOLIS**

Canaley Process Equip. Co.  
120 N. Rangeline Road  
Carmel, IN 46032  
Phone: 317-846-6104  
Fax: 317-844-5869

**IOWA, CEDAR RAPIDS**

J W Moore Process Equip. Co  
710 32nd Ave. S.W.  
Cedar Rapids, IA 52404  
Phone: 319-362-7273  
Fax: 319-362-8204

**LOUISIANA, BATON ROUGE**

(Municipal Only)  
Environmental Technical Sales  
Inc.  
7731 Office Park Blvd  
Baton Rouge, LA 70809  
Phone: 225-295-1200  
Fax: 225-295-1800

**LOUISIANA, BATON ROUGE**

Ford-Gelatt & Associates, Inc.  
18359 Petroleum Avenue  
Baton Rouge, LA 70809  
Phone: 225-752-0267  
Fax: 225-751-3016

**MASSACHUSETTS, BOSTON**

(Municipal Only)  
New England Environmental  
Equipment, Inc.  
One DeAngelo Drive  
Bedford, MA 01730  
Phone: 781-275-1001  
Fax: 781-275-1002

**MASSACHUSETTS, BOSTON**

M. A. Olson Co., Inc  
414 Old Boston Rod  
Topsfield, MA 01983  
Phone: 978-887-2384  
Fax: 978-887-3234

**MICHIGAN, DETROIT**

Mattoon & Lee Equipment, Inc.  
23943 Industrial Park Drive  
Farmington, MI 48335  
Phone: 248-478-4070  
Fax: 248-478-4074

**MINNESOTA, MINNEAPOLIS**

Trident Process, Inc.  
Valley Office Park  
10800 Lybndale Ave. So.  
Bloomington, MN 55420  
Phone: 952-881-7271  
Fax: 952-881-4219

**MISSOURI, KANSAS CITY**

Technical Equipment Co., Inc.  
810-A N.W. Main Street  
Lee's Summit, MO 64086-9353  
Phone: 816-525-1350  
Fax: 816-525-3844

**MISSOURI, ST. LOUIS**

Hagedorn & Gannon Co., Inc.  
550 Axminister Drive  
Fenton, MO 63026-2904  
Phone: 636-349-3370  
Fax: 636-349-3460

**MISSOURI, INDEPENDENCE**

(Municipal Only)  
Fluid Equipment Company, Inc.  
4224 N.E. Port Ste. 100  
Lee's Summit, MO 64064-1773  
Phone: 816-795-8511  
Fax: 816-795-8926

**MISSOURI, FENTON**

(Municipal Only)  
VanDevanter Engineering  
1617 Manufacturers Drive  
Fenton, MO 63026  
Phone: 636-343-8880  
Fax: 636-343-1720

**NEW JERSEY / NYC**

Process Equipment Sales &  
Service, Inc.  
11 Melanie Lane, Unit 2  
East Hanover, NJ 07936-1101  
Phone: 973-884-4111  
800-526-2209  
Fax: 973-884-4551

**NEW YORK, ROCHESTER**

Siewert Equipment Co.  
175 Akron Street  
Rochester, NY 14609  
Phone: 585-482-9640  
Fax: 585-482-4149

**N. CAROLINA, CHARLOTTE**

Robert E Mason Company  
1726 N. Graham Street  
P O Box 33424  
Charlotte, NC 28233  
Phone: 704-334-3700  
Fax: 704-375-6104

**FOR PROMPT SERVICE, CALL YOUR *LIGHTNIN* SALES ENGINEER**

He can save you time and money, and provide you with mixers and aerators guaranteed to do the job.

***LIGHTNIN*® U.S. SALES OFFICE DIRECTORY (continued)**

**N. CAROLINA, CHARLOTTE**

(Municipal Only)  
Heyward Inc.  
2101 Cambridge Beltway Dr.  
Suite A  
Charlotte, NC 28273  
Phone: 704-583-2305  
Fax: 704-583-2900

**NEBRASKA, OMAHA**

(Municipal Only)  
Mellen & Associates Inc  
2304 South 24th Street  
Omaha, NE 68108  
Phone: 402-345-4566  
Fax: 402-345-6557

**OHIO, CINCINNATI**

Surkamp & Rowe, Inc.  
4757 Cornell Road  
Cincinnati, Ohio 45241-2432  
Phone: 513-489-2850  
Fax: 513-489-2854

**OHIO, CLEVELAND**

David Industrial Sales, Inc.  
3763 Brecksville Road  
P O Box 483  
Richfield, OH 44286  
Phone: 330-659-3157 (Richfield)  
419-874-1359 (Toledo)  
Fax: 330-659-4871 (Richfield)  
419-872-7450 (Toledo)

**OKLAHOMA, TULSA**

Vanco Engineering Company  
7033 East 40th Street  
Tulsa, OK 74145-4523  
Phone: 918-627-1920  
Fax: 918-627-6742

**PENNSYLVANIA, PHILADELPHIA**

Harrington-Robb Co.  
41 Twosome Drive, Unit #4  
Moorestown, NJ 08057  
Phone: 856-642-9605  
Fax: 856-642-9606

**PENNSYLVANIA, PITTSBURGH**

PCF Sales Corporation  
Suite 195 Twin Towers  
4955 Steubenville Pike  
Pittsburgh, PA 15205  
Phone: 412-788-6800  
Fax: 412-788-6808

**TENNESSEE, CHATTANOOGA**

Rodgers-Turner & Assoc. Inc.  
5751 Uptain Road  
Suite 105, Uptain Bldg 37411-5671  
P O Box 8266  
Chattanooga, TN 37414  
Phone: 423-894-2958  
Fax: 423-899-6874

**TENNESSEE, MEMPHIS**

Clements & Associates  
P O Box 24757  
Bartlett, TN 28184-0757  
Phone: 901-382-8700  
Fax: 901-377-9061

**TEXAS, DALLAS**

Rodgers Equipment Co., Inc.  
11882 Greenville Ave., Suite 130  
P O Box 744125 (Zipcode 75374)  
Dallas, TX 75243  
Phone: 972-238-1919  
Fax: 972-238-1995

**TEXAS, HOUSTON**

Hstik-Baymont, Inc.  
2525 West Bellfort, Suite 200  
P O Box 26657  
Houston, TX 77207-6657  
Phone: 713-661-1177  
Fax: 713-661-3681

**TEXAS, TOMBALL**

(Municipal Only)  
Hartwell Environmental Corp  
22115 Hufsmith Kohrville Road  
Tomball, TX 77375  
Phone: 281-351-8501  
Fax: 281-351-8323

**UTAH, SALT LAKE CITY**

Nibley & Company  
1333 East 3300 So  
Salt Lake City, UT 84106  
Phone: 801-487-8200  
Fax: 801-487-5222

**VIRGINIA, RICHMOND**

Engineering Equipment Co., Inc.  
711 Moorefield Park Dr.  
P O Box 35076, Suite L  
Richmond, VA 23235-0076  
Phone: 804-323-6100  
Fax: 804-323-7400

**WASHINGTON, SEATTLE**

Whitney Equipment Co. Inc.  
21222 30th Drive SE, Suite 110  
Bothell, WA 98021  
Phone: 425-486-9499  
Fax: 425-485-7409

**WASHINGTON, VANCOUVER**

Whitney Equipment Co. Inc.  
7017 NE Hwy 99, S-216  
Vancouver, WA 98665  
Phone: 360-694-9175  
Fax: 360-695-2389

**W. VIRGINIA, PARKERSBURG**

G&W Industrial Sales, Inc.  
915 Emerson Avenue  
Parkersburg, WV 26104  
Phone: 304-422-4755  
Fax: 304-422-4751

**WISCONSIN, MILWAUKEE**

Adam-Zeman LLC  
6577 North Sidney Place  
Wilwaukee, WI 53209  
Phone: 262-781-4500  
Fax: 262-781-4515



**FOR PROMPT SERVICE, CALL YOUR LIGHTNIN SALES ENGINEER**

He can save you time and money, and provide you with mixers and aerators guaranteed to do the job.

**LIGHTNIN® INTERNATIONAL SALES OFFICE DIRECTORY****ALGIERS**

See France

**ARGENTINA**

Tecointer, S.A.  
Tucuman 255  
1049 Buenos Aires  
Phone: 54-11-4311-7882  
Fax: 54-11-4311-1969

**ARUBA**

See Venezuela, Ortiz &amp; Mejia

**AUSTRALIA**

Lightnin Mixers Pty Ltd  
Unit 5, Block C, 391 Park Road  
Regents Park Estate  
Regents Park N.S.W. 2143  
Sydney, Australia  
Phone: 61-2-9645-2999  
Fax: 61-2-9645-2433

**MAILING ADDRESS**

P O Box 200  
Regents Park N.S.W. 2143

Lightnin Sales & Service Centre  
63 Kurnall Road  
Welshpool, WA 6106  
Phone: 61-8-9458-9700  
Fax: 61-8-9458-9766

**Victoria**

Lightnin Mixers Pty Ltd  
13 Healy Road  
Dandenong South  
Victoria 3175  
Phone: 61-3-9768-2111  
Fax: 61-3-9768-2188

**AUSTRIA**

See United Kingdom

**BAHAMAS**

See U.S. Sales Office Directory  
Arroyo Process Equipment

**BELGIUM**

Mervers NV  
Samberstraat 57-2060  
Antwerpen Belgium 2630  
Phone: 32-3-2339649  
Fax: 32-3-2329501

**BELIZE**

See U.S. Sales Office Directory  
Arroyo Process Equipment

**BOLIVIA**

See United States, Rochester

**BONAIRE**

See Venezuela, Ortiz &amp; Mejia

**BURMA**

See Singapore, Lightnin Pte.Ltd

**BRAZIL**

Equiprom  
Av. Afonso Pena, 3111-SALA 1011  
Bairro Funcionarios CEP 30130-008  
Belo Horizonte, MG-Brasil

**CANADA**

**Toronto, Ontario**  
T. D. Rooke Associates Ltd  
21 Vulcan Street  
Etobicoke, Ontario  
M9W 1L3  
Phone: 416-248-0555  
Fax: 416-248-8163

**Montreal, Quebec**

Nortec S.G.S. Inc  
Suite 230  
3300 Cavendish Boulevard  
Montreal, Quebec  
H4B 2M8  
Phone: 514-487-1055  
Fax: 514-487-0058

**Amherst, Nova Scotia**

Marathon Fluid Systems  
P O Box 672 (Mailing Address)  
Amherst, Nova Scotia B4H 4B8  
194 Halifax Street (Ship Address)  
Moncton, New Brunswick  
E1C 9S2  
Phone: 506-860-7867  
Fax: 506-867-8826

**Vancouver, Brit. Col.**

Black & Baird Ltd  
1641 Welch Street  
North Vancouver, BC  
V7P 3G9  
Phone: 604-986-1640  
Fax: 604-986-1675

**Winnipeg, Manitoba**

Nothart Eng. Sales Ltd.  
C-1420 Clarence Ave  
Winnipeg, Manitoba  
R3T 1T6  
Phone: 204-452-6411  
Fax: 204-477-1089

**Calgary, Alberta**

Zazula Process Equip. Ltd  
1526 10th Avenue S.W  
Calgary Alberta T3C 0J5  
Phone: 403-244-0751  
Fax: 403-245-5808

**CHILE**

BAFCO Procesos S.A.  
Panamericana Norte 18.900  
(Km.19)  
Lampa Santiago, Chile  
Phone: 56-2-738-7373  
Fax: 56-2-738-7198

**CHINA**

Lightnin China Mixers Ltd HQ  
1189 Li An Road  
Minhang District  
Shanghai 201100, China  
Phone: 86-21-5495-5616  
Fax: 86-21-5495-5626

**Beijing Regional Office**

Room 102-103, Haowei Building  
No. 25 Beitapingzhuang Road  
Haidian District  
Beijing 100088, P.R. China

**CHINA (continued)**

**Chengdu Regional Office**  
Block G, 27/F, Vancouver Plaza  
Third Section West,  
Yiuan Avenue  
Chengdu 610072, China  
Phone: 86-21-771-2350  
Fax: 86-21-773-2056

**Guangzhou Regional Office**

Room 602, 132 Yau district  
Dongpudama Road Tian He  
Guangzhou 510660, China  
Phone: 86-20-8231-7797  
Fax: 86-20-8231-7799

**COLUMBIA**

HEP (Herman Escobar Posada  
Representaciones Ltda)  
Carrera 11A N93-94, OF.201  
Santafe De Bogota, D.C.  
Columbia, S.A.  
Phone: 57-1-621-9711  
Fax: 57-1-621-9860

**COSTA RICA**

See U.S. Sales Office Directory  
Arroyo Process Equipment

**CURAZAO**

See Venezuela, Ortiz &amp; Mejia

**DENMARK**

AxFlow A/S  
Solvang 6  
3450 Allerod  
Denmark  
Phone: 45-7010-3550  
Fax: 45-7010-3555

**DOMINICAN REPUBLIC**

See Puerto Rico  
Coneco de Puerto Rico

**ECUADOR**

ETECO Del Ecuador SA  
Empresaa Tecnica y Comercial  
Av. 9 de Octubre y Av. Patria  
P O Box 1717-589  
Quito, Ecuador  
Phone: 593-225-61177  
Fax: 593-229-07406

**EGYPT**

Engineer for Tech Representatives  
122 El Gala street  
P O Box 2456  
Cairo, Egypt  
Phone: 20-2-574-5373  
Fax: 20-2-579-5326

**ENGLAND**

See United Kingdom

**EL SALVADOR**

See U.S. Sales Office Directory  
Arroyo Process Equipment

**FIGI**

See Lightnin Mixers Pty Ltd  
Sydney, Australia

**FINLAND**

Oy Jarlas AB  
Mettisvaarantie 7 A 2  
FIN-97420  
Lohiniva  
Finland  
Phone: 358-16-766761  
Fax: 358-16-766762

**FRANCE**

Bran+Luebbe Sarl  
87 Rue Des Poiriers  
Parc Sainte Apolline  
BP 72  
78372 Plaisir Cedex  
France  
Phone: 33-1-30-68-4141  
Fax: 33-1-30-68-4100

**FRENCH GUIANA**

See United States, Rochester

**GERMANY**

Turbo Misch-und Verfahrenstechnik  
Vertriebs-und Service GmBH  
Im Westfeld 8  
29336 Nienhagen  
Phone: 49-5144-9898  
Fax: 49-5144-4807

J. W. Stevens

P O Box 1508  
D-61366 Friedrichsdorf  
Germany  
Phone: 49-6172-71861  
Fax: 49-6172-71685

**GREECE**

Aero-Dynamics Ltd  
8 km National Rd Athens-Lamia 18  
Gaitenaki Street 14342-N  
Philadelfia P O Box 8415  
Athens 10010, Greece  
Phone: 30-1-252-0065  
30-1-252-0988  
30-1-252-6207  
Fax: 30-1-252-6207

**GUATEMALA**

See U.S. Sales Office Directory  
Arroyo Process Equipment

**GUYANA**

See United States, Rochester

**HOLLAND**

See Belgium - Mervers NV

**HONDURAS**

See U.S. Sales Office Directory  
Arroyo Process Equipment

**INDIA**

Rathi Lightnin Mixers PVT Ltd  
1162/2 Shivajinagar  
Behind Observatory  
Poona 411 005  
India  
Phone: 91-20-55-35384  
91-20-55-325215  
Fax: 91-20-553-3229

**LIGHTNIN**

135 Mt. Read Blvd.  
P.O. Box 1370  
Rochester, New York 14603

**LIGHTNIN**

DATE: 6-9-03

IT-3839L  
Page 3 of 5

**FOR PROMPT SERVICE, CALL YOUR LIGHTNIN SALES ENGINEER**

He can save you time and money, and provide you with mixers and aerators guaranteed to do the job.

**LIGHTNIN® INTERNATIONAL SALES OFFICE DIRECTORY (continued)****INDONESIA**

Guna Pertini Cemerlang  
Komplek Perkantoran  
Centre Blok A, J1 Pala  
No. 1, -D Cinere Jakarta  
Selatan, 16514 Indonesia  
Phone: 62-21-754-3889  
Fax: 62-21-754-3881

**IRAN**

Aramrange Engineering Corporation  
P O Box 15875-6418  
Tehran, Iran  
Phone: 98-21-875-5413  
Fax: 98-21-875-7521

**IRELAND, REPUBLIC & NORTHERN**

App & Company  
Blackhall, Dunboyne  
Co. Meath.  
Ireland  
Phone: 353-1-825-3000  
Fax: 353-1-825-3070

**ISRAEL**

Lightnin Israel Ltd  
P O Box 28  
#1 Hamasger Office 101  
43 100 Raanana, Hasharon, Israel  
Phone: 972-9-741-1333  
Fax: 972-9-741-1951

**ITALY**

Lightnin Italia SRI  
Via Delle Tuberosa No. 14  
10146, Milano, Italy  
Phone: 39-02-484-63432  
Fax: 39-02-484-01926

**JAMAICA**

See West Indies, Lewis & Co.

**JAPAN**

See United States, Rochester

**KOREA**

World Bridge Industrial Co. Ltd.  
459-26, Majo-ri  
Hasung-Myun.,  
Kimpro City Kyungki-do, Korea  
Phone: 82-341-988-0700  
Fax: 82-341-988-0701

**KUWAIT**

Al Moaef Trading Co  
P O Box 4675  
Hawalli, 32077  
Hawalli, Kuwait  
Phone: 965-4839911  
Fax: 965-481-5498

**LUXEMBURG**

See Belgium, Mervers, NV

**MALAYSIA**

Arachem (M) Sdn Bhd  
85A Jalan ss 21/60  
Damansara Utama  
47400 Petaling Jaya  
Malaysia  
Phone: 02-03-719-6668  
Fax: 02-03-719-66723

**MEXICO**

Lightnin Mexico  
Mitla #442  
Colonia Vertiz Narvarte  
Mexico DF CP 03600  
Phone: 52-55-2595-1630  
Fax: 52-55-2595-1635

**NEW CALEDONIA**

See Lightnin Mixers Pty Ltd  
Sydney, Australia

**NEW GUINEA**

See Lightnin Mixers Pty Ltd  
Sydney, Australia

**NEW ZEALAND**

Foster & Associates LMI Ltd  
3 Gloucester Park Road  
Onehunga N.Z.  
P O Box 11280  
Auckland, 1005 N.Z.  
Phone: 64-9-622-18358  
Fax: 64-9-622-1836

**NICARAGUA**

See U.S. Sales Office Directory  
Arroyo Process Equipment

**NORTH AFRICA**

See United Kingdom

**NORTH ANTILLES**

See Venezuela, Ortiz & Mejia

**NORWAY**

Maskin as Argo  
Blakstadmarka 26  
1370 Asker Norway  
Phone: 47-6698-7550  
Fax: 47-6698-7580

**PANAMA**

See U.S. Sales Office Directory  
Arroyo Process Equipment

**PARAGUAY**

See United States Rochester

**PERU**

ABL Corporation  
Los Tilos 124, Salamanca de  
Monterrico  
Lima-3, Peru  
Phone: 51-1-437-6796  
51-1-437-4765  
51-1-435-5982  
Fax: 51-1-435-0312

**PHILIPPINES**

Charles Searby Trading  
Penthouse B, Windsor Towers  
163 Legaspi Street  
Legaspi Villiage  
Makati City 1200, Philippines  
Phone: 63-2-8127739  
Fax: 63-2-8106751

**PORTUGAL**

Rebel  
Rua Joaquim  
Antonia de Aguilar 45 3 Dt  
P-1000 Lisboa  
Portugal  
Phone: 351-21-384-1040  
Fax: 351-21-384-1049

**PUERTO RICO**

Coneco de Puerto Rico  
P O Box 1150  
San Juan, Puerto Rioc  
00922-1500  
Phone: 787-276-6969  
Fax: 787-276-6951

**SAUDI ARABIA**

Salah & Abdulazia  
Abahsain Co. Ltd  
P O Box 209  
Al Khobar 31952  
Saudi Arabia  
Phone: 966-3-8984045  
Fax: 966-3-8990114

P O box 1300

Jeddah 21381

Phone: 966-2-6820944

Fax: 966-2-6833124

P O Box 42127

Riyadh 11541

Phone: 966-1-4742538

Fax: 966-1-4762660

P O Box 690

Al-Bahr Yanbu

Phone: 966-4-3224200

Fax: 966-4-3227877

**SCOTLAND**

Clyde Associates Engineers  
Block 5, 76 Beardmore Way  
Clydebank Industrial Estate  
Clydebank G81 4HT  
Phone: 44-141-954-1331  
Fax: 44-141-951-3460

**SINGAPORE**

Lightnin Pte Ltd  
5 Pioneer Sector Walk  
Singapore 627896  
Phone: 65-6264-4366  
Fax: 65-6265-9133

**Jakarta Representative Office**

Geolung Aria, 3rd Floor  
51 Gorgolargdia Lama No. 40  
Menteng, Jakarta Pusat  
Indonesia  
Phone: 65-6392-4980  
Fax: 65-6392-4981

**SOUTH AFRICA**

Lightnin Africa  
P O Box 542  
Bergvlei  
2012 Transvaal  
Phone: 27-11-608-0477  
Fax: 27-11-608-0503

Lightnin Africa

Durham Kwazulu Natal

P O Box 684

New Germany 3620

South Africa

Phone: 27-31-701-5563

Fax: 27-31-702-8735

Lightnin Africa

P O Box 3278

Cape Town 8000

South Africa

Phone: 27-21-221228

Fax: 27-21-221230

**SURINAME**

See United States Rochester

**SWEDEN**

Bergius Trading AB  
Box 4091, S-181 04 Lidingo  
Larsbergstorget 5  
Stockholm Sweden  
Phone: 46-8-731-5800  
Fax: 46-8-797-2993

**SWITZERLAND**

Alfa Laval GM  
Flow Division  
Industriestrasse 31  
Postfach 31  
CH-8305 Dietlikon, Switzerland  
Phone: 41-1-807-1440  
Fax: 41-1-807-1442

LIGHTNIN

**LIGHTNIN**

135 Mt. Read Blvd.  
P.O. Box 1370  
Rochester, New York 14603

DATE: 6-9-03

IT-3839L  
Page 4 of 5

**FOR PROMPT SERVICE, CALL YOUR *LIGHTNIN* SALES ENGINEER**  
He can save you time and money, and provide you with mixers and aerators guaranteed to do the job.  
***LIGHTNIN*® INTERNATIONAL SALES OFFICE DIRECTORY (continued)**

**TAIWAN**

ProMix Technique Inc  
5f-2, No. 191, Fu-Hsing North Road  
Taipei, Taiwan ROC  
Phone: 886-2-2719-8559  
Fax: 886-2-2719-8556

**THAILAND**

R.J.C. Associates Co. Ltd  
96 Samsen Road  
Bangkok 10200  
Phone: 66-2-281-5540  
66-2-282-5249  
Fax: 66-2-281-0615

**TOBAGO & TRINIDAD**

See United States Rochester

**UNITED ARB EMIRATES**

Systems & Equipment  
P O Box 45381, Hamdan Street  
Abu Dhabi U.A.E.  
Phone: 97-12-741296  
Fax: 97-12-741297

**UNITED KINGDOM**

Bran+Luebbe Limited  
Ironstone Way  
Brixworth, Northampton  
England NN99UD  
Phone: 44-1604-88-0751  
Fax: 44-1604-88-0145

**URUGUAY**

See United States Rochester

**VENEZUELA**

Ortiz & Mejia C.A.  
Av. Nueva Granada con Av. La.  
Linea/Torre A, Local 1  
Caracas 1040, Venezuela  
Phone: 58-2-632-4733  
Fax: 58-2-632-1732

**VIETNAM**

See Singapore, Lightnin Pte Ltd

**WEST INDIES**

Lewis & Company  
P O Box 725  
Mandeville, Manchester, Jamaica  
West Indies  
Phone: 876-962-0640  
Fax: 876-962-8749

***LIGHTNIN***  
*LIGHTNIN*  
135 Mt. Read Blvd.  
P.O. Box 1370  
Rochester, New York 14603

DATE: 6-9-03

IT-3839L  
Page 5 of 5

# LIGHTNIN

## REPAIR & SERVICE GUIDE

### LIGHTNIN Process Equipment Services (LPES): The fastest route to uptime.

**Expertise:** LPES technicians are the backbone of our dedicated service organization. They're uniquely qualified to keep your LIGHTNIN mixers running right.

**Lightnin Certified Technicians:** All LPES technicians are certified via training courses to ensure that the work they do meets the highest standards for consistency and reliability.

**Genuine LIGHTNIN Parts:** All LPES repairs follow original design specs and use only factory-authorized replacement parts.

**Full LIGHTNIN Factory Warranty:** We're so confident we'll do the job right that all LPES repair and service work is covered by a full factory warranty. What we repair, we guarantee – 100%.

**Repair Services:** LIGHTNIN provides quick, reliable repair services – using only certified technicians and factory-authorized replacement parts – on gearboxes, mechanical seals (seal cartridge and seal assembly), steady bearings, machine assemblies, impellers, shafts and all portable units. This service can be provided either at your site or at a LIGHTNIN Service Center location. All work is backed by LIGHTNIN's full warranty on all parts and service.

**Exchange Services:** By eliminating repair time, LIGHTNIN Exchange Services offer the fastest way to get up and running when a breakdown occurs. LPES keeps selected speed reducers, portable units and mixer subassemblies in stock – and available for immediate exchange – at regional service centers. Simply call and we will configure the appropriate assembly and ship it to you within 24 hours. Then send the damaged assembly back to us within 30 days – to ensure you receive a discounted price.

**Equipment Upgrade Services:** Preventive maintenance is your best defense against costly unplanned downtime and repairs associated with old or obsolete equipment. The full range of LPES upgrade services give you a convenient and cost-efficient way to address problems before they happen by converting older equipment to the latest, most reliable LIGHTNIN designs.

**Additional LPES Services:** In addition to minimizing downtime and repair costs when equipment failure occurs, LPES offers a comprehensive range of services for maximizing productivity through every stage of the equipment life cycle.

- Installation and Start-up
- Maintenance and Repair
- Asset Management

## LIGHTNIN Process Equipment Services Warranty

When repairs to your LIGHTNIN mixer are needed, we guarantee the results for one full year. This exclusive warranty covers all parts and labor. Talk to your LIGHTNIN sales representative for more information.

### Call:

**The LIGHTNIN Experts**  
When your need is urgent and after normal business hours call our 24-hour response team hotline at 1-888-MIX-BEST (U.S. and Canada). Your request will be promptly processed and directed to your nearest LPES team member. For more information visit our website at:  
[www.lightninmixers.com](http://www.lightninmixers.com).

## Factory Service Center Locations

Chicago, Illinois  
Houston, Texas  
Mulberry, Florida  
Reading, Pennsylvania  
Rochester, New York  
San Francisco, California  
Wytheville, Virginia

## Authorized Service Center Locations

Baton Rouge, Louisiana  
Concord, Ontario, Canada  
East Hanover, New Jersey  
Macon, Pooler, Roswell,  
Georgia