



SPARC Enterprise T5440 Server

Site Planning Guide



C120-H029-02EN



SPARC Enterprise™ T5440 Server Site Planning Guide

Copyright © 2009 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

FUJITSU LIMITED provided technical input and review on portions of this material.

Sun Microsystems, Inc. and Fujitsu Limited each own or control intellectual property rights relating to products and technology described in this document, and such products, technology and this document are protected by copyright laws, patents and other intellectual property laws and international treaties. The intellectual property rights of Sun Microsystems, Inc. and Fujitsu Limited in such products, technology and this document include, without limitation, one or more of the United States patents listed at <http://www.sun.com/patents> and one or more additional patents or patent applications in the United States or other countries.

This document and the product and technology to which it pertains are distributed under licenses restricting their use, copying, distribution, and decompilation. No part of such product or technology, or of this document, may be reproduced in any form by any means without prior written authorization of Fujitsu Limited and Sun Microsystems, Inc., and their applicable licensors, if any. The furnishing of this document to you does not give you any rights or licenses, express or implied, with respect to the product or technology to which it pertains, and this document does not contain or represent any commitment of any kind on the part of Fujitsu Limited or Sun Microsystems, Inc., or any affiliate of either of them.

This document and the product and technology described in this document may incorporate third-party intellectual property copyrighted by and/or licensed from suppliers to Fujitsu Limited and/or Sun Microsystems, Inc., including software and font technology.

Per the terms of the GPL or LGPL, a copy of the source code governed by the GPL or LGPL, as applicable, is available upon request by the End User. Please contact Fujitsu Limited or Sun Microsystems, Inc.

This distribution may include materials developed by third parties.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and in other countries, exclusively licensed through X/Open Company, Ltd.

Sun™, Sun Microsystems™, the Sun logo®, Java™, Netra™, Solaris™, Sun StorageTek™, docs.sun.com™, OpenBoot™, SunVTS™, Sun Fire™, SunSolve™, CoolThreads™, and J2EE™, are trademarks or registered trademarks of Sun Microsystems, Inc. or its subsidiaries in the U.S. and other countries.

Fujitsu and the Fujitsu logo are registered trademarks of Fujitsu Limited.

All SPARC trademarks are used under license and are registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon architecture developed by Sun Microsystems, Inc.

SPARC64 is a trademark of SPARC International, Inc., used under license by Fujitsu Microelectronics, Inc. and Fujitsu Limited.

SSH is a registered trademark of SSH Communications Security in the United States and in certain other jurisdictions.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

United States Government Rights - Commercial use. U.S. Government users are subject to the standard government user license agreements of Sun Microsystems, Inc. and Fujitsu Limited and the applicable provisions of the FAR and its supplements.

Disclaimer: The only warranties granted by Fujitsu Limited, Sun Microsystems, Inc. or any affiliate of either of them in connection with this document or any product or technology described herein are those expressly set forth in the license agreement pursuant to which the product or technology is provided.

EXCEPT AS EXPRESSLY SET FORTH IN SUCH AGREEMENT, FUJITSU LIMITED, SUN MICROSYSTEMS, INC. AND THEIR AFFILIATES MAKE NO REPRESENTATIONS OR WARRANTIES OF ANY KIND (EXPRESS OR IMPLIED) REGARDING SUCH PRODUCT OR TECHNOLOGY OR THIS DOCUMENT, WHICH ARE ALL PROVIDED AS IS, AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Unless otherwise expressly set forth in such agreement, to the extent allowed by applicable law, in no event shall Fujitsu Limited, Sun Microsystems, Inc. or any of their affiliates have any liability to any third party under any legal theory for any loss of revenues or profits, loss of use or data, or business interruptions, or for any indirect, special, incidental or consequential damages, even if advised of the possibility of such damages.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright © 2009 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, Etats-Unis. Tous droits réservés.

Entrée et revue tecnical fournies par FUJITSU LIMITED sur des parties de ce matériel.

Sun Microsystems, Inc. et Fujitsu Limited détiennent et contrôlent toutes deux des droits de propriété intellectuelle relatifs aux produits et technologies décrits dans ce document. De même, ces produits, technologies et ce document sont protégés par des lois sur le copyright, des brevets, d'autres lois sur la propriété intellectuelle et des traités internationaux. Les droits de propriété intellectuelle de Sun Microsystems, Inc. et Fujitsu Limited concernant ces produits, ces technologies et ce document comprennent, sans que cette liste soit exhaustive, un ou plusieurs des brevets déposés aux États-Unis et indiqués à l'adresse <http://www.sun.com/patents> de même qu'un ou plusieurs brevets ou applications brevetées supplémentaires aux États-Unis et dans d'autres pays.

Ce document, le produit et les technologies afférents sont exclusivement distribués avec des licences qui en restreignent l'utilisation, la copie, la distribution et la décompilation. Aucune partie de ce produit, de ces technologies ou de ce document ne peut être reproduite sous quelque forme que ce soit, par quelque moyen que ce soit, sans l'autorisation écrite préalable de Fujitsu Limited et de Sun Microsystems, Inc., et de leurs éventuels bailleurs de licence. Ce document, bien qu'il vous ait été fourni, ne vous confère aucun droit et aucune licence, expresses ou tacites, concernant le produit ou la technologie auxquels il se rapporte. Par ailleurs, il ne contient ni ne représente aucun engagement, de quelque type que ce soit, de la part de Fujitsu Limited ou de Sun Microsystems, Inc., ou des sociétés affiliées.

Ce document, et le produit et les technologies qu'il décrit, peuvent inclure des droits de propriété intellectuelle de parties tierces protégés par copyright et/ou cédés sous licence par des fournisseurs à Fujitsu Limited et/ou Sun Microsystems, Inc., y compris des logiciels et des technologies relatives aux polices de caractères.

Par limites du GPL ou du LGPL, une copie du code source régi par le GPL ou LGPL, comme applicable, est sur demande vers la fin utilisateur disponible; veuillez contacter Fujitsu Limited ou Sun Microsystems, Inc.

Cette distribution peut comprendre des composants développés par des tierces parties.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun™, Sun Microsystems™, le logo Sun®, Java™, Netra™, Solaris™, Sun StorageTek™, docs.sun.com™, OpenBoot™, SunVTSTM, Sun Fire™, SunSolve™, CoolThreads™, et J2EE™ sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc., ou ses filiales aux Etats-Unis et dans d'autres pays.

Fujitsu et le logo Fujitsu sont des marques déposées de Fujitsu Limited.

Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

SPARC64 est une marques déposée de SPARC International, Inc., utilisée sous le permis par Fujitsu Microelectronics, Inc. et Fujitsu Limited.

SSH est une marque déposée registre de SSH Communications Security aux Etats-Unis et dans certaines autres juridictions.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une license non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui, en outre, se conforment aux licences écrites de Sun.

Droits du gouvernement américain - logiciel commercial. Les utilisateurs du gouvernement américain sont soumis aux contrats de licence standard de Sun Microsystems, Inc. et de Fujitsu Limited ainsi qu'aux clauses applicables stipulées dans le FAR et ses suppléments.

Avis de non-responsabilité: les seules garanties octroyées par Fujitsu Limited, Sun Microsystems, Inc. ou toute société affiliée de l'une ou l'autre entité en rapport avec ce document ou tout produit ou toute technologie décrit(e) dans les présentes correspondent aux garanties expressément stipulées dans le contrat de licence régissant le produit ou la technologie fourni(e).

SAUF MENTION CONTRAIRE EXPRESSÉMENT STIPULÉE DANS CE CONTRAT, FUJITSU LIMITED, SUN MICROSYSTEMS, INC. ET LES SOCIÉTÉS AFFILIÉES REJETENT TOUTE PRÉSENTATION OU TOUTE GARANTIE, QUELLE QU'EN SOIT LA NATURE (EXPRESSE OU IMPLICITE) CONCERNANT CE PRODUIT, CETTE TECHNOLOGIE OU CE DOCUMENT, LESQUELS SONT FOURNIS EN L'ÉTAT. EN OUTRE, TOUTES LES CONDITIONS, PRÉSENTATIONS ET GARANTIES EXPRESSES OU TACITES, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE À LA QUALITÉ MARCHANDE, A L'APTITUDE À UNE UTILISATION PARTICULIÈRE OU À L'ABSENCE DE CONTREFAÇON, SONT EXCLUES, DANS LA MESURE AUTORISÉE PAR LA LOI APPLICABLE.

Sauf mention contraire expressément stipulée dans ce contrat, dans la mesure autorisée par la loi applicable, en aucun cas Fujitsu Limited, Sun Microsystems, Inc. ou l'une de leurs filiales ne sauraient être tenues responsables envers une quelconque partie tierce, sous quelque théorie juridique que ce soit, de tout manque à gagner ou de perte de profit, de problèmes d'utilisation ou de perte de données, ou d'interruptions d'activités, ou de tout dommage indirect, spécial, secondaire ou consécutif, même si ces entités ont été préalablement informées d'une telle éventualité.

LA DOCUMENTATION EST FOURNIE "EN L'ETAT" ET TOUTES AUTRES CONDITIONS, DECLARATIONS ET GARANTIES EXPRESSES OU TACITES SONT FORMELLEMENT EXCLUES, DANS LA MESURE AUTORISÉE PAR LA LOI APPLICABLE, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE A LA QUALITE MARCHANDE, A L'APTITUDE A UNE UTILISATION PARTICULIERE OU A L'ABSENCE DE CONTREFACON.

Contents

Preface vii

SPARC Enterprise T5440

Site Planning Guide 1

Physical Specifications 2

Minimum Clearance for Service Access 2

Environmental Specifications 3

Power Source Requirements 4

 Calculating Maximum Input Current 5

 Acoustic Noise Emissions 5

 Agency Compliance Specifications 6

 Operating Environment Requirements 6

 Electrical Power 6

 Ambient Temperature 7

 Ambient Relative Humidity 7

 Airflow Considerations 7

Index 9

Preface

This manual provides the specifications and site requirements you need when planning the installation of the SPARC Enterprise™ T5440 server.

For Safe Operation

This manual contains important information regarding the use and handling of this product. Read this manual thoroughly. Use the product according to the instructions and information available in this manual. Keep this manual handy for further reference.

Fujitsu makes every effort to prevent users and bystanders from being injured or from suffering damage to their property. Use the product according to this manual.

Related Documentation

The latest versions of all the SPARC Enterprise Series manuals are available at the following Web sites:

Global Site

(<http://www.fujitsu.com/sparcenterprise/manual/>)

Japanese Site

(<http://primeserver.fujitsu.com/sparcenterprise/manual/>)

| Title | Description | Manual Code |
|---|--|-------------|
| <i>SPARC Enterprise T5440 Server Getting Started Guide</i> | Minimum steps to power on and boot the server for the first time | C120-E504 |
| <i>SPARC Enterprise T5440 Server Product Notes</i> | Information about the latest product updates and issues | C120-E508 |
| <i>Important Safety Information for Hardware Systems</i> | Safety information that is common to all SPARC Enterprise series servers | C120-E391 |
| <i>SPARC Enterprise T5440 Server Safety and Compliance Guide</i> | Safety and compliance information that is specific to the server | C120-E509 |
| <i>SPARC Enterprise/PRIMEQUEST Common Installation Planning Manual</i> | Requirements and concepts of installation and facility planning for the setup of SPARC Enterprise and PRIMEQUEST | C120-H007 |
| <i>SPARC Enterprise T5440 Server Site Planning Guide</i> | Server specifications for site planning | C120-H029 |
| <i>SPARC Enterprise T5440 Server Installation and Setup Guide</i> | Detailed rackmounting, cabling, power on, and configuring information | C120-E510 |
| <i>SPARC Enterprise T5440 Server Service Manual</i> | How to run diagnostics to troubleshoot the server, and how to remove and replace parts in the server | C120-E512 |
| <i>SPARC Enterprise T5440 Server Administration Guide</i> | How to perform administrative tasks that are specific to the server | C120-E511 |
| <i>Integrated Lights Out Manager 2.0 User's Guide</i> | Information that is common to all platforms managed by Integrated Lights Out Manager (ILOM) 2.0 | C120-E474 |
| <i>Integrated Lights Out Manager 2.0 Supplement for SPARC Enterprise T5440 Server</i> | How to use the ILOM 2.0 software on the server | C120-E513 |

| Title | Description | Manual Code |
|---|---|-------------|
| <i>Integrated Lights Out Manager 3.0 Concepts Guide</i> | Information that describes ILOM 3.0 features and functionality | C120-E573 |
| <i>Integrated Lights Out Manager 3.0 Getting Started Guide</i> | Information and procedures for network connection, logging in to ILOM 3.0 for the first time, and configuring a user account or a directory service | C120-E576 |
| <i>Integrated Lights Out Manager 3.0 Web Interface Procedures Guide</i> | Information and procedures for accessing ILOM 3.0 functions using the ILOM web interface | C120-E574 |
| <i>Integrated Lights Out Manager 3.0 CLI Procedures Guide</i> | Information and procedures for accessing ILOM 3.0 functions using the ILOM CLI | C120-E575 |
| <i>Integrated Lights Out Manager 3.0 SNMP and IPMI Procedure Guide</i> | Information and procedures for accessing ILOM 3.0 functions using SNMP or IPMI management hosts | C120-E579 |
| <i>Integrated Lights Out Manager 3.x Feature Updates and Release Notes</i> | Enhancements that have been made to ILOM firmware since the ILOM 3.0 release | C120-E600 |
| <i>Integrated Lights Out Manager 3.0 Supplement for SPARC Enterprise T5440 Server</i> | How to use the ILOM 3.0 software on the server | C120-E587 |
| <i>External I/O Expansion Unit Installation and Service Manual</i> | Procedures for installing the External I/O Expansion Unit on the SPARC Enterprise T5120/T5140/T5220/T5240/T5440 servers | C120-E543 |
| <i>External I/O Expansion Unit Product Notes</i> | Important and late-breaking information about the External I/O Expansion Unit | C120-E544 |

Note – Product Notes are available on the website only. Please check for the recent update on your product.

Fujitsu Welcomes Your Comments

If you have any comments or requests regarding this document, or if you find any unclear statements in the document, please state your points specifically on the form at the following URL.

For Users in U.S.A., Canada, and Mexico:

(<https://download.computers.us.fujitsu.com/>)

For Users in Other Countries:

(http://www.fujitsu.com/global/contact/computing/sparce_index.html)

SPARC Enterprise T5440 Site Planning Guide

This guide provides SPARC Enterprise™ T5440 server specifications and site requirements that you can use to plan and prepare your site.

For safety and compliance information, refer to the *SPARC Enterprise T5440 Server Safety and Compliance Guide* and the documentation that came with your server.

| Topic | Links |
|--|--|
| Physical dimensions of the server | “Physical Specifications” on page 2 |
| Space required to access the server | “Minimum Clearance for Service Access” on page 2 |
| Operating and non-operating environmental specifications | “Environmental Specifications” on page 3 |
| Requirements for electrical and cooling infrastructure | “Power Source Requirements” on page 4 |
| Acoustic emissions | “Acoustic Noise Emissions” on page 5 |
| Safety and regulatory compliance information | “Agency Compliance Specifications” on page 6 |
| Environmental considerations for installation | “Operating Environment Requirements” on page 6 |

Physical Specifications

TABLE: Physical Specifications for the SPARC Enterprise T5440 Server

| Description | U.S. | Metric |
|---|---------------|--------|
| Width | 17.5 in. | 445 mm |
| Depth | 24.9 in. | 633 mm |
| Height | 6.92 in. (4U) | 176 mm |
| Weight, approximate (without PCI cards and rackmounts) | 88 lb | 40 kg |

Related Information

- “Environmental Specifications” on page 3
- “Power Source Requirements” on page 4

Minimum Clearance for Service Access

TABLE: Minimum Needed Clearances

| Description | Specification |
|----------------------------|----------------|
| Clearance, front of system | 36 in. (91 cm) |
| Clearance, rear of system | 36 in. (91 cm) |

Related Information

- *SPARC Enterprise T5440 Server Installation Guide*
- *SPARC Enterprise T5440 Server Service Manual*

Environmental Specifications

TABLE: Environmental Specifications for the SPARC Enterprise T5440 Server

| Specification | Operating | Nonoperating |
|--------------------------|--|---|
| Temperature | <ul style="list-style-type: none">Sea level to 2953 ft. (900m): 41°F to 95°F (5°C to 35°C)Above 2953 ft. (900m): Decrease the maximum allowable temperature by 1.6°F/1000 ft (1°C/300m) | -40°F to 149°F (-40°C to 65°C) IEC 60068-2-1 Test Ab and 60068-2-2 Test Bb |
| Relative Humidity | 10 to 90% RH, 27°C maximum wet bulb (noncondensing) IEC 60068-2-56 Test Cb | 93% RH, 35°C maximum wet bulb (noncondensing) IEC 60068-2-56 Test Cb |
| Altitude | 10,000 ft. (3,000m) | 40,000 ft. (12,000m) |
| Vibration | IEC 60068-2-13 Test M, and 60068-2-41 Test Z/BM IEC 60068-2-6 Test Fc | IEC 60068-2-13 Test M IEC 60068-2-6 Test Fc |
| Shock | 3 Gs, 11 ms half-sine IEC 60068-2-27 Test Ea | <ul style="list-style-type: none">Roll-off: 1-inch roll-off free fall, front to back rolling directionsThreshold: 25 mm threshold height at 0.75 m/s impact velocity |

ETE-1010-02 Rev A

Related Information

- “Physical Specifications” on page 2
- “Power Source Requirements” on page 4

Power Source Requirements

The SPARC Enterprise T5440 server has four autoranging power supplies. To ensure redundant operation of the power supplies, connect the power cords to at least two separate AC circuits.

Use the specifications in [TABLE: SPARC Enterprise T5440 Power Specifications on page 4](#) only as a planning guide. For more precise power values, make power measurements on your specific server configuration using your planned workload.

TABLE: SPARC Enterprise T5440 Power Specifications

| Description | Specification |
|---|---|
| General Specifications | |
| Operating input voltage range | 100 - 240 VAC, 50 - 60 Hz (VAC tolerance +/- 10%) |
| Maximum operating input current at 100 VAC* | 27.00 A |
| Maximum operating input current at 200 VAC | 13.25 A |
| Maximum operating input power at 100 VAC | 2700 W |
| Maximum heat dissipation | 9212.8 BTU/hour or 9720 KJ/hour |
| Maximum standby power | 70 W |
| Maximum Server Configuration Specifications | |
| Under Nominal Temperature and Voltage Conditions | |
| 4 CMP, 1.6 GHz, 32 cores (8 cores each), 64 x 4 GByte 800mhz FB-DIMMs, 4 HDDs, 8 PCIe cards | |
| Idle AC input power | 1671 W |
| Peak AC input power running SpecJBB | 2213 W |
| Minimum Server Configuration Specifications | |
| Under Nominal Temperature and Voltage Conditions | |
| 2 CMP, 1.2 GHz, 16 cores (8 cores each), 8 x 2 GByte FB-DIMMs, no HDDs, no I/O cards | |
| Idle AC input power | 495 W |
| Peak AC input power running SpecJBB | 590 W |

* See [TABLE: Maximum Operating Input Current Calculations on page 5](#)

Related Information

- “Calculating Maximum Input Current” on page 5
- “Electrical Power” on page 6
- *SPARC Enterprise T5440 Server Service Manual*

Calculating Maximum Input Current

The maximum operating current values are based on P/V using the equations in [TABLE: Maximum Operating Input Current Calculations on page 5](#).

TABLE: Maximum Operating Input Current Calculations

| Range | Equation | Example |
|-------------|------------------------|--|
| [90-120 V] | $P = 3316 - 6.87 * V$ | I = 22.0 A @ 115V, or 11.0 A per line cord with two power supplies active. |
| [200-240 V] | $P = 2447 + 0.375 * V$ | I = 12.0 A @ 210V, or 6.0 A per line cord with two power supplies active. |

Related Information

- “Power Source Requirements” on page 4
-

Acoustic Noise Emissions

Declared noise emissions for the SPARC Enterprise T5440 server is in accordance with ISO 9296 standards. See [TABLE: SPARC Enterprise T5440 Noise Emissions on page 5](#).

TABLE: SPARC Enterprise T5440 Noise Emissions

| Description | Operating at idle | Operating at maximum power |
|---|-------------------|----------------------------|
| Sound power level, LwAd (1 B = 10 dB) | 7.4 B | 8.9 B |
| Sound Pressure Level, LpAm (bystander positions) | 63 dB | 80 dB |

Agency Compliance Specifications

Refer to the *SPARC Enterprise T5440 Server Safety and Compliance Guide* for a full list of agency compliance specifications.

Operating Environment Requirements

Your environmental control system must provide intake air for the server that complies with the limits specified in “[Environmental Specifications](#)” on page 3.

To avoid overheating, *do not* direct warmed air:

- Toward the front air intake of the server
- Toward the server access panels

Note – When you receive your server, place it in the environment where you will install it. Leave the server in its shipping crate at its final destination for 24 hours. This resting period prevents thermal shock and condensation.

The servers have been tested to meet all functional requirements when operating in the operating environmental limits presented in “[Environmental Specifications](#)” on page 3. Operating computer equipment in extremes of temperature or humidity increases the failure rate of hardware components. To minimize the chance of component failure, use the server within the optimal temperature and humidity ranges.

Electrical Power

Good practice is to connect each power supply to a separate circuit. This redundancy enables the system to remain operational if one of the circuits fails. Consult your local electrical codes for any additional requirements.

Ambient Temperature

An ambient temperature range of 21°C (69.8°F) to 23°C (73.4°F) is optimal for server reliability. At 22°C (71.6°F) it is easy to maintain safe relative humidity levels. Operating in this temperature range provides a buffer if the environmental support systems fail.

Ambient Relative Humidity

Ambient relative humidity levels between 45% and 50% are the most suitable for data processing operations in order to:

- Prevent corrosion
- Provide an operating time buffer in the event of environmental control system failure
- Help avoid failures caused by the intermittent interference from static discharges that occur when relative humidity is too low

Electrostatic discharge (ESD) is easily generated and less easily dissipated in areas where the relative humidity is below 35%. ESD becomes critical when levels drop below 30%.

Airflow Considerations

- Ensure unobstructed airflow through the chassis.
- Ensure that inlet air enters at the front of the server and exits from the back.
- Ensure that ventilation openings, such as cabinet doors, for both the inlet and exhaust of the server provide a minimum open area of 460 cm² (71.3 in.²) each. This ventilation equates to a 60% open area perforation pattern across the front and rear area of the server. You must evaluate the impact of other open area characteristics that are more restrictive.
- Allow a minimum of 5 mm (0.2 in.) clearance at the front of the system and 80 mm (3.1 in.) at the rear of the server when mounted. These clearance values are based on the inlet and exhaust impedance (available open area). These values also assume a uniform distribution of the open area across the inlet and exhaust areas. Use greater clearance values to improve cooling performance.

Note – The combination of inlet and exhaust restrictions such as cabinet doors, and the spacing of the server from the doors can affect the cooling performance of the server. You must evaluate the effect of these criteria.

- Take care to prevent recirculation of exhaust air within a rack or cabinet.
- Manage cables to minimize interfering with the server exhaust vent.

Index

A

- acoustic noise emissions, 5
- agency compliance specifications, 6
- airflow considerations, 7
- airflow requirements, 7

E

- electrical power best practices, 6
- environmental specifications, 3

H

- humidity, ambient relative, 7

I

- installation site requirements, 1

O

- operating environment requirements, 6

P

- power source requirements, 4

S

- service access clearance, minimum, 2

T

- temperature, ambient, 7

V

- ventilation requirements, 7

FUJITSU