

FLUKE®

Biomedical

Victoreen 470A

Panoramic Survey Meter

Operators Manual

**Fluke Biomedical
Radiation Management Services**

6045 Cochran Road
Cleveland, Ohio 44139
440.498.2564

www.flukebiomedical.com/rms

Table of Contents

Section 1:	Introduction	1-1
1.1	Product Description	1-1
1.2	Specifications.....	1-1
1.3	Procedures, Warnings, and Cautions	1-3
Section 2:	Installation	2-1
2.1	Unpacking.....	2-1
2.2	Power Requirements	2-1
2.3	Precautions.....	2-2
2.4	Routine Cleaning	2-2
2.5	Storage	2-3
Section 3:	Operation	3-1
3.1	Function	3-1
3.2	Controls	3-1
3.2.1	Range Switch	3-1
3.2.2	Function Switch	3-1
3.2.3	Zero Set.....	3-1
3.2.4	Zero Adjust	3-1
3.2.5	Calibration Potentiometer and 22 ½ V Battery Switch	3-1
3.3	Operating Procedure (Turn-On Sequence).....	3-2
3.4	Operational Tests	3-2
Section 4:	Theory of Operation	4-1
4.1	General Theory.....	4-1
Section 5:	Adjustment and Maintenance	5-1
5.1	Calibration.....	5-1
5.1.1	Energy Dependence.....	5-1
5.1.2	Temperature and Pressure.....	5-1
5.1.3	Angular Dependence.....	5-1
5.1.4	Source Distance	5-1
5.1.5	Calibration Procedure.....	5-1
5.2	Troubleshooting	5-2
5.2.1	Test Procedure	5-2
Appendix A:	Replacement Parts	A-1
A.1	List of Electrical Replacement Parts	A-1

(Blank Page)

Section 1

Introduction

1.1 Product Description

The 470A is unparalleled in health physics surveys instrumentation. The latest solid-state IC technology has been utilized to miniaturize circuitry, reduce weight and increase reliability. Accuracy and convenience have also been carefully considered to assure the best possible indication of true radiation exposure. An extremely rugged high impact molded plastic case provides easy decontamination.

The 470A is ideal in numerous applications including:

- Background studies
- General health physics surveys
- Radiochemical lab checks
- Surveying nuclear power plants
- Monitoring x-ray and radiotherapy facilities
- Fuel processing plants
- Research labs
- Certain NDT applications

1.2 Specifications

Range	Rate: 0-3, 10, 30, 100, 300, 1000 mR/h and R/h Integrate: 0-3, 10, 30, 100, 300, 1000 mR
Radiation Detected	Alpha, beta, gamma and x-ray
Detector	Unsealed air ionization chamber
Material	Expanded polystyrene/275 cc vol
Wall Thickness	17 mg/cm ²
Cyclac Equilibrium Sleeve/Cap	500 mg/cm ² thick
Readout Meter	3.125 in (7.9 cm) scale, taut band movement
Controls	External: Function Switch (R/h, mR/h, mR integrate) Range Switch (Off, Battery Check, 1000, 300, 100, 30, 10, 3) Zero Set Zero Adjust Internal: Calibration Adjustment High Voltage Check Switch Coarse Zero Adjust Potentiometer

Energy Response	$\pm 15\%$ from 8.0 keV to 300 keV-bare $\pm 10\%$ from 40 keV to 2 MeV-Covered
Response Time	8 sec on 3 mR/h range 3 sec on 10 mR/h range 2 sec on 30 mR/h range 1.5 sec on 100 mR/h and 300 mR/h range
Switching Transients	Less than 8 seconds on Function & Set Zero
Batteries	Two 1.5 V "D" cells and four 22.5 V No. 505 Eveready
Battery Life	"D" cells 150 hr 22.5 V shelf life
Zero Adjust	Can be properly adjusted in a radiation field
Warm-up Time	Less than one minute
Environmental Effects	Temperature Range: -20° to $+120^{\circ}\text{F}$ (-29° to $+49^{\circ}\text{C}$) Humidity Range: 0 to 95%, non-condensing Geotropism: negligible
Response to Other Radiation	Minimum energy to penetrate chamber: Alpha: 8 MeV Beta: 120 KeV
Zero Drift with Temperature	6% per 10°C on 3 mR/h and 3 R/h range 2% per 10°C on 10 mR/h and 10 R/h range 0.6% per 10°C on 30 mR/h range and 30 R/h range Can be completely eliminated by rezeroing
Collection Efficiency	See Figure 1-1
Dimensions	11 in long (27.9 cm) 4 $\frac{3}{4}$ in wide (12.1 cm) 9 $\frac{1}{2}$ in high (24.1 cm)
Weight	Less than 4 lb




Figure 1-1. Collection Efficiency Graph

1.3 Procedures, Warnings, and Cautions

The equipment described in this manual is intended to be used for the detection and measurement of ionizing radiation. It should be used only by persons who have been trained in the proper interpretation of its readings and the appropriate safety procedures to be followed in the presence of radiation.

Although the equipment described in this manual is designed and manufactured in compliance with all applicable safety standards, certain hazards are inherent in the use of electronic and radiometric equipment.

WARNINGS and **CAUTIONS** are presented throughout this document to alert the user to potentially hazardous situations. A **WARNING** is a precautionary message preceding an operation that has the potential to cause personal injury or death. A **CAUTION** is a precautionary message preceding an operation that has the potential to cause permanent damage to the equipment and/or loss of data. Failure to comply with **WARNINGS** and **CAUTIONS** is at the user's own risk and is sufficient cause to terminate the warranty agreement between Fluke Biomedical, Radiation Management Services and the customer.

Adequate warnings are included in this manual and on the product itself to cover hazards that may be encountered in normal use and servicing of this equipment. No other procedures are warranted by Fluke Biomedical. It shall be the owner's or user's responsibility to see to it that the procedures described here are meticulously followed, and especially that **WARNINGS** and **CAUTIONS** are heeded. Failure on the part of the owner or user in any way to follow the prescribed procedures shall absolve Fluke Biomedical and its agents from any resulting liability.

Indicated battery and other operational tests must be performed prior to each use to assure that the instrument is functioning properly. If applicable, failure to conduct periodic performance tests in accordance with ANSI N323-1978, paragraphs 4.6 and 5.4, and to keep records thereof in accordance with paragraph 4.5 of the same standard, could result in erroneous readings of potential danger. ANSI N323-1978 becomes, by this reference, a part of this operating procedure.

(Blank page)

Section 2 Installation

2.1 Unpacking

When unpacking the 470A, check for any in-shipment damage.

2.2 Power Requirements

Two 1 ½ volt and four 22 ½ volt batteries are supplied with each instrument. Before installing the batteries be sure the Range Switch is in the OFF position. The “D” cells are installed in the handle by removing the two side retaining screws that permit removal of the cap. The batteries are inserted and the cap rep placed. Be sure to observe battery polarity. When replacing the cap be sure the contact spring is properly oriented. See Figure 2-2.

To install the 22 ½ volt batteries, remove the five screws that hold the front of the instrument to the body and pull the front forward. The battery holder is mounted to the front instrument assembly. Install the 22 ½ volt batteries observing the proper polarity. (When mounting the front assembly to the body, dress the interconnecting cable in a manner that will not cause interference.) Replace the five mounting screws. See Figure 2-2.

The 22 ½ volt batteries provide chamber collection voltage and do not experience significant current drain. Battery life is equal to shelf life that should be in excess of one year.

The BATT position on the Range Switch will check the condition of the D cells only, which must read in the green area of the meter. Since the 22 ½ volt batteries will last for shelf life, they require only infrequent checking. Checking may be accomplished by snapping out the logo plate located below the meter and actuating a microswitch located on the left hand side of the opening. When the switch is actuated, the meter will read about 95% of full scale. Note the reading for future reference to establish battery condition. The batteries should be replaced when they have dropped about 5% below their initial reading. This check must be performed with the Range Switch in the OFF position. See Figure 2-1.

The purpose of the collecting voltage is to supply the electrostatic field that sweeps the ions created in the chamber to the walls and center electrode, where they constitute the current which is measured by the electronics. This should be accomplished with as little recombination of these ions as possible. The voltage necessary for a certain ion collecting efficiency varies as the square root of the radiation intensity for a particular chamber geometry. Thus, since the chamber is 90% saturated at 1000 R/h at 90 volts, it requires only about 50 volts to produce 90% saturation at 300 R/h, full scale on the next range. Hence, the instrument is still quite useful, especially on the mR/h range, even if the collecting voltage has dropped to as much as half its original level. The reason for noting the reading of collecting voltage and replacing these batteries if the reading drops by about 5% is that such a decrease is a reasonable indication of the battery shelf life.




Figure 2-1. View of instrument with the logo plate removed. (Showing Battery Test Micro Switch, Control, and Coarse Zero Potentiometer)

2.3 Precautions

If the ion chamber is broken or contaminated with radioactive material, the chamber must be replaced. Contact Fluke Biomedical for servicing.

2.4 Routine Cleaning

CAUTION

Do not immerse the 470A Panoramic Survey Meter. The unit is not waterproof. Liquid could damage the circuits. The unit should be kept clean and free from dirt and contamination. The unit may be cleaned by wiping with a damp cloth using any commercially available cleaning or decontaminating agent.

2.5 Storage

In areas where the humidity is exceptionally high, Ion Chamber instruments may become saturated with moisture causing them to fail. To avoid this occurrence, store instruments in a typical dry box with either a 100-watt light bulb or renewable dessiccant packet. Smaller instruments can be stored in polyethylene

bags with dessiccant packet.




Figure 2-2. Batteries, Cap, and Contact Spring Replacement

(Blank page)

Section 3

Operation

3.1 Function

The 470A is an ionization chamber meter used to detect alpha, beta, gamma and x-ray radiation. It measures total exposure rate from 3 mR/h full scale for gamma and x-ray energies from 8.0 keV to 2 MeV.

3.2 Controls

The 470A has four front panel controls. See the following sections for details.

3.2.1 Range Switch

The Range Switch has eight positions. It can turn the instrument OFF, check the battery voltage, or set the sensitivity at 1000, 300, 100, 30, 10 or 3.

3.2.2 Function Switch

The Function Switch determines whether the 470A measures R/h, mR/h or integrates mR.

3.2.3 Zero Set

The Zero Set button is actuated whenever the instrument must be zeroed or operated in the Integrate Mode.

3.2.4 Zero Adjust

Since the instrument is susceptible to zero drift after initial turn on or when subjected to environmental extremes, zeroing is provided and may be accomplished in high radiation fields.

Depress the Zero Set button and adjust the Zero Adjust control on the instrument until the meter reads zero. Release the Zero Set button and the instrument is ready for operation. The zeroing procedure should be followed before performing integration.

3.2.5 Calibration Potentiometer and 22 ½ V Battery Test Switch

A calibration adjusting potentiometer, a coarse zero potentiometer, and a collecting voltage battery test switch are located under the logo plate directly under the meter, see Figure 2-1. This logo may be snapped out for access to these controls. The calibration potentiometer is factory adjusted and should be readjusted only with a calibrated radiation source.

In the event that the instrument cannot be zeroed with the external zero control as in Section 3.2.4, readjustment of the coarse zero control may be necessary. This is done by setting the external zero control to the middle of its range, turning the instrument to one of its operating ranges, depressing the Zero Set button and adjusting the coarse zero potentiometer till the indicating meter reads zero. The external zero control will then have ample range in each direction.

3.3 Operating Procedure (Turn-On Sequence)

Turn the Range Switch from OFF to BATT and make sure the meter is in the BATT. O.K. green region. Then turn the Range Switch to 1000. Push the Zero Set button and adjust zero as described in the previous paragraph. Turn the Function Switch to mR/h. As the ion chamber bias voltage rises to -90 volts, the instrument will read upscale. This lasts for less than one minute after the instrument is turned on.

After one minute, turn the range Switch to 3 mR/h. The instrument should now read background radiation. The 470A is now ready to make measurements.

After warm-up, the Mode and Range may be selected with the Function Switch.

3.4 Operational Tests

First the 470A must pass the turn-on procedure. Then place a small radiation source nearby so the 470A reads about 1 mR/h. Turn the Range Switch to the 10 mR/h and to the 30 mR/h range, the meter reading should decrease on each range change to always indicate about 1 mR/h. If the 470A fails the turn-on or operational tests, turn to Section 5.2, Troubleshooting.

The Operational Check Source on the end cap of the chamber equilibrium sleeve can be used for the first of these tests. The Check Source consists of less than 0.01 microcuries of depleted uranium, and will produce a reading of between 0.6 and 1.5 mR/h when the source is placed on top of or in front of the bare chamber.

Section 4 Theory of Operation

4.1 General Theory

When the ion chamber is exposed to radiation the internal air volume becomes ionized. A dc potential applied between the outer shell and center electrode separates the newly formed ion pairs before they can recombine and collects them. The ions, upon reaching the electrodes, are restored to neutral gas atoms through the process of taking on (or giving up) electrons. This causes a direct current flow in the external circuit. The ion chamber can be considered a constant current generator whose output current is directly proportional to the rate of internal air ionization or exposure rate. These currents are extremely small however, and special electrometer circuitry is required to measure them.

An operational, current-amplifier configuration is employed in this instrument, see Figure 4-1. The large amount of negative feedback causes the output voltage to be a function of input current and feedback element value, rather than amplifier gain or other variables. A MOSFET electrometer is used for the operational amplifier. The feedback element is either a high megohm resistor or a capacitor.

Precision film resistors, elected by the Range Switch, determine the amount of dc voltage gain, and hence, the full scale sensitivity of the instrument. A variable resistor is employed to calibrate accurately the meter deflection to a known exposure rate radiation field.




Figure 4-1. Operational Amplifier (current amplifier configuration)




Figure 4-2. Energy Response Correction Curve

This instrument is calculated in International Roentgens corrected to 0° Centigrade when used at 22° Centigrade and 760 mm mercury (Hg) barometric pressure. For temperatures other than 22° Centigrade and pressures other than 760 mm Hg, multiply the scale reading by the factor obtained from Table 4-1.

Table 4-1. Air Density Correction

Pressure		Temperature of °C															
In.	Mm.	60.8 16	64.4 18	68.0 20	71.6 22	75.2 24	78.8 26	82.4 28	86.0 30	89.6 32	93.2 34	96.8 36	100.4 38	104 40			
19.68	500	1.489	1.499	1.509	1.520	1.530	1.541	1.551	1.561	1.571	1.582	1.592	1.602	1.613			
20.08	510	1.460	1.469	1.479	1.490	1.499	1.510	1.520	1.530	1.540	1.551	1.561	1.571	1.581			
20.47	520	1.431	1.441	1.451	1.461	1.471	1.481	1.491	1.500	1.510	1.520	1.530	1.540	1.550			
20.87	530	1.405	1.414	1.424	1.434	1.444	1.453	1.463	1.473	1.482	1.492	1.502	1.512	1.521			
21.26	540	1.378	1.388	1.397	1.407	1.416	1.426	1.435	1.445	1.454	1.464	1.474	1.483	1.493			
21.65	550	1.354	1.363	1.373	1.382	1.391	1.401	1.410	1.419	1.429	1.438	1.448	1.457	1.466			
22.05	560	1.329	1.338	1.348	1.357	1.366	1.375	1.384	1.393	1.403	1.412	1.421	1.431	1.439			
22.44	570	1.306	1.315	1.324	1.333	1.342	1.351	1.360	1.369	1.378	1.387	1.396	1.405	1.414			
22.83	580	1.283	1.292	1.301	1.310	1.319	1.328	1.337	1.345	1.354	1.363	1.372	1.381	1.389			
23.23	590	1.262	1.270	1.279	1.288	1.297	1.305	1.314	1.323	1.331	1.340	1.349	1.358	1.366			
23.62	600	1.241	1.249	1.258	1.267	1.275	1.284	1.293	1.301	1.309	1.318	1.327	1.336	1.344			
24.02	610	1.220	1.229	1.237	1.246	1.254	1.263	1.271	1.279	1.288	1.297	1.305	1.314	1.322			
24.41	620	1.200	1.208	1.217	1.225	1.233	1.242	1.249	1.258	1.266	1.275	1.283	1.292	1.299			
24.80	630	1.181	1.189	1.198	1.206	1.214	1.222	1.230	1.239	1.247	1.256	1.263	1.271	1.279			
25.20	640	1.164	1.171	1.180	1.188	1.196	1.204	1.212	1.220	1.228	1.236	1.244	1.252	1.260			
25.59	650	1.145	1.153	1.161	1.169	1.177	1.185	1.193	1.201	1.208	1.216	1.224	1.232	1.240			
25.98	660	1.127	1.135	1.143	1.151	1.159	1.167	1.174	1.182	1.189	1.198	1.206	1.213	1.221			
26.38	670	1.111	1.119	1.126	1.134	1.142	1.149	1.157	1.165	1.172	1.180	1.188	1.195	1.203			
26.77	680	1.095	1.103	1.110	1.118	1.125	1.133	1.141	1.148	1.156	1.163	1.171	1.179	1.186			
27.16	690	1.078	1.086	1.093	1.101	1.108	1.116	1.123	1.131	1.138	1.146	1.153	1.161	1.168			
27.56	700	1.064	1.071	1.079	1.086	1.093	1.101	1.108	1.115	1.123	1.130	1.137	1.145	1.152			
27.95	710	1.048	1.053	1.063	1.070	1.077	1.084	1.092	1.098	1.106	1.113	1.121	1.128	1.135			
28.35	720	1.033	1.041	1.048	1.055	1.062	1.069	1.076	1.083	1.091	1.098	1.105	1.112	1.119			
28.54	725	1.027	1.034	1.041	1.048	1.055	1.062	1.069	1.076	1.083	1.091	1.098	1.105	1.112			
28.74	730	1.019	1.027	1.034	1.041	1.048	1.055	1.062	1.069	1.076	1.083	1.090	1.097	1.105			
28.94	735	1.013	1.019	1.027	1.034	1.041	1.048	1.055	1.062	1.069	1.076	1.083	1.090	1.097			
29.13	740	1.006	1.013	1.020	1.027	1.034	1.041	1.048	1.055	1.062	1.069	1.075	1.083	1.089			
29.33	745	0.999	1.006	1.013	1.020	1.027	1.034	1.041	1.048	1.054	1.061	1.068	1.075	1.082			
29.53	750	0.992	0.999	1.006	1.013	1.020	1.027	1.033	1.040	1.047	1.054	1.061	1.068	1.075			
29.72	755	0.986	0.993	1.000	1.007	1.014	1.021	1.027	1.034	1.041	1.048	1.055	1.062	1.068			
29.92	760	0.980	0.986	0.993	1.000	1.007	1.014	1.020	1.027	1.034	1.041	1.047	1.054	1.061			
30.12	765	0.972	0.979	0.986	0.993	0.999	1.006	1.013	1.020	1.026	1.033	1.040	1.047	1.054			
31.31	770	0.967	0.973	0.980	0.987	0.994	1.000	1.007	1.014	1.020	1.027	1.034	1.041	1.047			
30.51	775	0.961	0.968	0.974	0.981	0.987	0.994	1.001	1.007	1.014	1.020	1.027	1.034	1.041			
30.71	780	0.954	0.961	0.967	0.974	0.980	0.987	0.994	1.000	1.007	1.014	1.020	1.027	1.033			
30.90	785	0.948	0.955	0.961	0.968	0.974	0.981	0.988	0.994	1.001	1.007	1.014	1.021	1.027			
31.10	790	0.942	0.949	0.955	0.962	0.968	0.975	0.981	0.988	0.994	1.001	1.008	1.014	1.021			




Figure 4-3. Source Distance




Figure 4-4.470A Angular Dependence

(Blank page)

Section 5

Adjustments and Maintenance

5.1 Calibration

The 470A is calibrated at the factory. When field recalibration is performed, four correction factors must be remembered.

5.1.1 Energy Dependence

Any ion chamber has a certain energy dependence. That is, holding the exposure rate constant, the chamber responds differently to different energy photons. The 470A has been calibrated at an effective energy of 662 keV from ^{137}Cs . The response is fairly energy dependent in the low-energy region. For accurate usage at middle and high energy regions, the Energy Response Correction Curve must be used, see Figure 4-2.

5.1.2 Temperature and Pressure

Air, at standard temperature and pressure, is the ionized medium in the exposure rate definition. The density of the air determines directly the ionization rate with all other factors held constant. The density is, in turn, a function of barometric pressure and Kelvin temperature. Since the ion chamber is not sealed, a small correction must be made for temperatures and barometric pressures different from those during calibration. 0 Standard temperature, 0°C, is rarely encountered in practice. The 470A is calibrated and corrected to 22°C and 760 mmHg. For different temperatures and pressures, correction factors will be found on the Air Density Correction Table 4-1.

5.1.3 Angular Dependence

The shape, wall material, center electrode design, and Position of the ionization chamber of the 470A results in an instrument response relatively independent of the direction of the incident radiation. Figure 4-4 gives the relative angular response of the 470A with the equilibrium cap on and off respectively, at 1.3 MeV (^{60}Co), and 120 keV and 40 keV effective.

5.1.4 Source Distance

If a point Source or a collimated beam is used, the 470A chamber must be far enough from the source so the entire ion chamber is uniformly exposed. In practice this means any point source should be at least 1 meter from the ion chamber. The center of volume of the chamber is 5.7 cm from the end. See Figure 4-3.

5.1.5 Calibration Procedure

1. Set the 470A to the 1 R/h range. Zero the 470A.
2. Pull out the logo plate and look down through the opening at the circuit board. The calibration potentiometer, R7, is the lower one on the right side. See Figure 2-1.
3. Subject the ion chamber to a Low R field and adjust the pot for the correct reading. Use the equilibrium cap if the effective energy of the source is over 100 keV. Be sure to correct for temperature, pressure, and energy response.

5.2 Troubleshooting

For reference, see exploded view in Figure 5-1.

5.2.1 Test Procedure

If the 470A does not pass its turn-on procedure and operational tests, then the following troubleshooting steps will check the batteries and main circuit board. If these parts test all right, but the 470A still does not work, contact Fluke Biomedical.

CAUTION

Do NOT attempt to repair the preamplifier.
Tampering with it could void the warranty.

To test the 470A follow these steps exactly:

1. Turn the 470A OFF and wait one minute.
2. Remove the two D cells from the handle.
3. Remove the 3 control knobs.
4. Remove the 5 screws from the preamplifier bulkhead and pull the preamplifier, bulkhead and ion chamber assembly from the rest of the instrument.
5. Slide out the meter and circuit board assembly and place the three portions of the instrument (case and handle, meter and circuit board, and preamplifier and ion chamber), still connected together, on a non-conducting surface.

CAUTION

Do not open or try to test the preamplifier! The circuitry is easily damaged.




Figure 5-1. Exploded View of the 470A

6. Replace the two "D" cells and control knobs to make the instrument operable.
7. Turn ON the 470A carefully. Some of the circuitry is at -90 volts. Wait 2 minutes. Place in the 0-3 R/h.
8. Measure the three supply voltages; +8.2 + 5%, -6.2 + 5% and regulated battery voltage. The +8.2 volts and -6.2 volts are most conveniently measured between ground (the transformer T1 case) and the front and rear end terminals, respectively, of the Zero Adjust potentiometer R19. The regulated battery voltage is the voltage across C9 and should measure between 2.2 and 2.3 volts.
9. If these voltages are correct, check the voltages across R11 and R12. These should both be about 1.5 volts and equal. Refer to Figure 5-2, Circuit Board Assembly, and Figure 5-3, Schematic Circuit Diagram, for further continuity and voltage checks. If the difficulty seems to lie in the preamplifier, return the instrument to Fluke Biomedical.
10. After testing, turn the 470A OFF and wait 2 minutes. Remove the two "D" cells from the handle, and reassemble the instrument in the reverse order of disassembly.




Figure 5-2. Circuit Board Assembly




Figure 5-3. Schematic Circuit Diagram

(Blank page)

Appendix A Replacement Parts

A.1 List of Electrical Replacement Parts

Symbol Designation	Part Number	Description	Qty
C1, C3	21-758	Capacitor: 10 μ F, 20 V	2
C6	21-924	Capacitor: 20 μ F, 50 V	1
C8	21-2055	Capacitor: .0082 MFD, 100 V	1
C9	21-2056	Capacitor: 50 μ F, 6 V	1
CR2, CR5	52-91	Diode: 1N4005	2
CR3	52-149	Diode: Zener 1N5237B	1
CR4	52-181	Diode: Zener 1N5234B	1
CR6, CR7, CR8	52-219	Diode: Zener 1N914B	3
Qi	23-61	Transistor: 2N3638	1
Q2	23-62	Transistor: 2N3642	1
Ri	185-3553	Resistor: 100 k Ω , 1/4 W, 1%	1
R2	185-3674	Resistor: 28.7 k Ω , 1/4 W, 1%	1
R3	185-3559	Resistor: 10 k Ω , 1/4 W, 1%	1
R4	185-3675	Resistor: 2.87 k Ω , 1/4 W, 1%	1
R5	185-3557	Resistor: 1 k Ω , 1/4 W, 1%	1
R6	185-2452	Resistor: 422 Ω , 1/4 W, 1%	1
R7	22-1026	Potentiometer: 50 k Ω , Calibrate	1
R8	185-1432	Resistor: 27 k Ω , 1/4 W, 5%	1
R9	185-3452	Resistor: 3.9 M Ω , 1/4 W, 5%	1
RiO	185-1431	Resistor: 3.9 k Ω , 1/4 W, 5%	1
Rii, R12	185-1464	Resistor: 18 k Ω , 1/4 W, 5%	2
R13	185-3482	Resistor: 470 k Ω , 1/4 W, 5%	1
R14	22-315	Potentiometer: 100 k Ω , Zero	1
R15	185-3547	Resistor: 62 k Ω , 1/4 W, 5%	1
R17	185-3404	Resistor: 220 k Ω , 1/4 W, 5%	1
R18	185-2416	Resistor: 6.8 k Ω , 1/4 W, 5%	1
R19	22-289	Potentiometer: 5 k Ω	1
R20	185-2414	Resistor: 3.3 k Ω , 1/4 W, 5%	1
R22, R25	185-1460	Resistor: 560 k Ω , 1/4 W, 5%	2
R23, R16	185-2466	Resistor: 22 k Ω , 1/4 W, 5%	2
R24	185-2444	Resistor: 120 Ω , 1/4 W, 5%	1
Symbol Designation	Part Number	Description	Qty.

R35	185-1454	Resistor: 2.2 k Ω , ¼ W, 5%	1
R36	185-1442	Resistor: 2 M Ω , ¼ W, 5%	1
S1	470-106	Switch, Function	1
S2	470-107	Switch, Range	1
S3	11-111	Switch, Auto Zero	1
S5	11-112	Switch	1
Ti	14-88	Transformer	1
U1	63-26	Integrated Circuit CA3086	1
U2	63-9	Integrated Circuit IT56164	1
	470-58	Housing	1
	470-131	Housing Front Cover and Pre-Amp Assembly	1
	470-53	Equilibrium Cover Processed	1
	470-10	Equilibrium Cover Cap	1
	470-118	Bipod	1
	470-125	Bipod Boot	2
	470-114	Handle Cap Assembly	1
	470-116	Handle	1
	470-67	Wrist Strap	1
	470-117	Bipod Spring	1
	470-121	Leaf Spring	1
	470-120	Spring Retainer	1
	470-122	Cap Spring Contacter	1
	470-92	Check Source	1
	9-62	Knob: Range and Function	2
	9-70	Knob: Zero	1
	53-2	Switch Boot	1
	470-26	Meter Lens	1
	11-111-1	Switch Cap	1
	470-156	Battery Box Assembly	2
	470-41	Ion Chamber	1
	11-95	Switch	2
	16-4	Battery 1.5 V "D" Cell	2
	470-133	Meter	1
	16-31	Battery 22 ½ V #505 Eveready	4

NOTE

Component values used in this instrument may not agree exactly with those indicated in the parts list or circuit diagram. For purposes of replacement either the value as installed or that indicated in the manual may be used. When ordering parts from the factory use the part number in the parts list.

**Fluke Biomedical
Radiation Management Services**

6045 Cochran Road
Cleveland, Ohio 44139
440.498.2564

www.flukebiomedical.com/rms