## SONY.



**Operating Instructions** 

© 2003 Sony Corporation



4-094-605-12

### **Owner's Record**


The model and serial numbers are located at the rear of the projection TV, below the Sony logo, on the sticker, and also on the TV box (white label). Record these numbers in the spaces provided below. Refer to them whenever you call upon your Sony dealer regarding this product.

Model No.

Serial No.

#### WARNING

To prevent fire or shock hazard, do not expose the projection TV to rain or moisture.





This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

#### CAUTION

To prevent electric shock, do not use this polarized AC plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure.

#### CAUTION

When using TV games, computers, and similar products with your projection TV, or viewing a TV station whose logo always stays on the screen, keep the brightness and picture functions at low settings. If a fixed (non-moving) pattern such as a station logo is left on the screen for long periods of time, especially at a high brightness or picture setting, the image can be permanently imprinted onto the screen. These types of imprints are not covered by your warranty.

#### **Note on Caption Vision**

This television receiver provides display of television closed captioning in accordance with §15.119 of the FCC rules.

#### Note on convergence adjustment

Before you use your projection TV, make sure to adjust convergence. For details, see "Adjusting the Convergence Automatically – FLASH FOCUS™ –" on page 33.

#### Note to CATV system installer

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

Use of this television receiver for other than private viewing of programs broadcast on UHF, VHF, transmitted by cable companies or satellite for the use of the general public may require authorization from the broadcaster/cable company and/or program owner.

#### **NOTIFICATION**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- □ Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved in this manual could void your warranty and your authority to operate this equipment.

#### CAUTION

## How to reduce the risk of "Image Retention" on your Projection TV

Bright, stationary images such as TV station logos displayed on your TV can cause permanent damage to your TV, resulting in retention of the image in the picture.

Please take the following steps to reduce the risk of causing image retention:

View a variety of program sources or programming material.

Image retention can occur when bright stationary images such as TV station logos are viewed. Changing the program material viewed reduces the possibility that a single image will become imprinted on the picture tubes in your TV.

When viewing programs with stationary images, adjust the picture setting to reduce the "Picture" and "Brightness" levels. Image retention is accelerated by higher "Brightness" and higher "Picture" settings.

Please refer to your instruction manual for instructions on adjusting picture settings.

This will help you reduce the risk of causing image retention.

#### IMAGE RETENTION IS NOT COVERED BY YOUR WARRANTY

This document is for the remote control RM-Y909. MODELS: KP-46WT510, KP-51WS510, KP-57WS510, and KP-65WS510.

Please keep this notice with the instruction manual.

#### Safety

- Operate the projection TV only on 120 V AC.
- □ The plug is designed, for safety purposes, to fit into the wall outlet only one way. If you are unable to insert the plug fully into the outlet, contact your dealer.

- If any liquid or solid object should fall inside the cabinet, unplug the projection TV immediately and have it checked by qualified service personnel before operating it further.
- □ If you will not be using the projection TV for several days, disconnect the power by pulling the plug itself. Never pull on the cord.

For details concerning safety precautions, see "IMPORTANT SAFEGUARDS" on page 3.

#### Installing

- □ To prevent internal heat buildup, do not block the ventilation openings.
- Do not install the projection TV in a hot or humid place, or in a place subject to excessive dust or mechanical vibration.
- Avoid operating the projection TV at temperatures below 5°C (41°F).
- If the projection TV is transported directly from a cold to a warm location, or if the room temperature changes suddenly, the picture may be blurred or show poor color due to moisture condensation. In this case, please wait a few hours to let the moisture evaporate before turning on the projection TV.
- □ To obtain the best picture, do not expose the screen to direct illumination or direct sunlight. It is recommended to use spot lighting directed down from the ceiling or to cover the windows that face the screen with opaque drapery. It is desirable to install the projection TV in a room where the floor and walls are not of a reflective material.



As an ENERGY STAR<sup>®</sup> Partner, Sony Corporation has determined that this product meets the ENERGY STAR<sup>®</sup> guidelines for energy efficiency.

#### **Trademark Information**

TruSurround, SRS and ()\* symbol are trademarks of SRS Labs, Inc. TruSurround technology is incorporated under license from SRS Labs, Inc.

BBE and BBE Symbol are trademarks of BBE Sound, Inc. and are licensed by BBE Sound, Inc. under U.S. Patent No. 4,638,258 and 4,482,866.

Steady Sound, Digital Reality Creation, Caption Vision, CineMotion, Memory Stick, and Twin View are registered trademarks of Sony Corporation. ClearEdge VM and HD Detailer are trademarks of Sony Corporation.

## **IMPORTANT SAFEGUARDS**

For your protection, please read these instructions completely, and keep this manual for future reference.

Carefully observe and comply with all warnings, cautions and instructions placed on the set or described in the operating instructions or service manual.

#### WARNING

To guard against injury, the following basic safety precautions should be observed in the installation, use and servicing of the set.

#### Use

#### **Power Sources**

This set should be operated only from the type of power source indicated on the serial/model plate. If you are not sure of the type of electrical power supplied to your home, consult your dealer or



local power company. For those sets designed to operate from battery power, refer to the operating instructions.

#### **Grounding or Polarization**

This set is equipped with a polarized AC power cord plug (a plug having one blade wider than the other), or with a three-wire grounding type plug (a plug having a third pin for grounding). Follow the instructions below:

## For the set with a polarized AC power cord plug

This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If



the plug still fails to fit, contact your electrician to have a suitable outlet installed. Do not defeat the safety purpose of the polarized plug by forcing it in.

## For the set with a three-wire grounding type AC plug

This plug will only fit into a groundingtype power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to have a suitable outlet



installed. Do not defeat the safety purpose of the grounding plug.

#### Overloading

Do not overload wall outlets, extension cords or convenience receptacles beyond their capacity, since this can result in fire or electric shock.

Always turn the set off when it is not being used. When the set is left unattended and unused for long periods of time, unplug it from the wall outlet as a precaution against the

possibility of an internal malfunction that could create a fire hazard.

If a snapping or popping sound from a TV set is continuous or frequent while the TV is operating, unplug the TV and consult your dealer or service technician. It is normal for some TV sets to make occasional snapping or popping sounds, particularly when being turned on or off.



Never push objects of any kind into the set through the cabinet slots as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the set.



#### **Attachments**

Do not use attachments not recommended by the manufacturer, as they may cause hazards.



#### Cleaning

Clean the cabinet of the projection TV with a dry soft cloth. To remove dust from the screen, wipe it gently with a soft of cloth. Stubborn stains may be removed with a cloth slightly dampened with



solution of mild soap and warm water. Never use strong solvents such as thinner or benzine for cleaning.

If the picture becomes dark after using the projection TV for a long period of time, it may be necessary to clean the inside of the projection TV. Consult qualified service personnel.



#### Installation

#### Water and Moisture

Do not use power-line operated sets near water — for example, near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, etc.



#### **Accessories**

Do not place the set on an unstable cart, stand, table or shelf. The set may fall, causing serious injury to a child or an adult and serious damage to the set. Use only a cart or stand recommended by Sony for the specific model of TV. No part of the TV set should overhang any edge of the TV cart or stand; any overhanging edge is a safety hazard. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.

#### Ventilation

The slots and openings in the cabinet and in the back or bottom are provided for necessary ventilation. To ensure reliable operation of the set, and to protect it from overheating, these slots and openings must never be blocked or covered.

- Never cover the slots and openings with a cloth or other materials.
- Never block the slots and openings by placing the set on a bed, sofa, rug or other similar surface.



- Never place the set in a confined space, such as a bookcase or built-in cabinet, unless proper ventilation is provided.
- Do not place the set near or over a radiator or heat register, or where it is exposed to direct sunlight.



Do not allow anything to rest on or roll over the power cord, and do not place the set where the power cord is subject to wear or abuse.



#### Antennas

#### **Outdoor Antenna Grounding**


If an outdoor antenna is installed, follow the precautions below. An outdoor antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can come in contact with such power lines or circuits.

WHEN INSTALLING AN OUTDOOR ANTENNA SYSTEM, EXTREME CARE SHOULD BE TAKEN TO KEEP FROM CONTACTING SUCH POWER LINES OR CIRCUITS AS CONTACT WITH THEM IS ALMOST INVARIABLY FATAL.

Be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges.

Section 810 of the National Electrical Code (NEC) in USA and Section 54 of the Canadian Electrical Code in Canada provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

## Antenna Grounding According to the National Electrical Code, ANSI/NFPA 70



### Lightning


For added protection for this television receiver during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna. This will prevent damage to the receiver due to lightning and power-line surges.

#### **Service**

#### **Damage Requiring Service**

Unplug the set from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power cord or plug is damaged or frayed.
- □ If liquid has been spilled into the set.



- □ If the set has been exposed to rain or water.
- If the set has been subject to excessive shock by being dropped, or the cabinet has been damaged.
- If the set does not operate normally when following the operating instructions.
   Adjust only those controls that are specified in the operating instructions.
   Improper adjustment of other controls may result in damage and will often require extensive work by a

qualified technician to restore the set to normal operation.

When the set exhibits a distinct change in performance, it indicates a need for service.

#### Servicing

Do not attempt to service the set by yourself since opening the cabinet may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.



#### **Replacement Parts**

When replacement parts are required, be sure the service technician certifies in writing that he has used replacement parts specified by the manufacturer that have the same characteristics as the original parts.

Unauthorized substitutions may result in fire, electric shock or other hazards.

### Safety Check

Upon completion of any service or repairs to the set, ask the service technician to perform routine safety checks (as specified by the manufacturer) to determine that the set is in safe operating condition, and to so certify. When the set reaches the end of its useful life, improper disposal could result in a picture tube implosion. Ask a qualified service technician to dispose of the set.



### For Safety

## Be careful when moving the projection TV

When you place the projection TV in position, be careful not to drop it on your foot or fingers.



Watch your footing while installing the projection TV.

## Carry the projection TV in the specified manner

If you carry the projection TV in a manner other than the specified manner and without the specified number of persons, it may drop and a serious injury may be



caused. Be sure to follow the instructions mentioned below.

- Carry the projection TV with the specified number of persons. (see page 11)
- Do not carry the projection TV holding the speaker grill.
- □ Hold the projection TV tightly when carrying it.
- Model KP-65WS510 has handles that you can use to carry the unit.

# **Contents**

### Introducing the Sony Projection TV Using the Menus

Presenting the Sony Projection TV	8
Using this manual	9

# Installing and Connecting the Projection TV

Contents10
Inserting Batteries into the Remote Control10
Carrying Your Projection TV11
Installing the Projection TV11
Connector Types12
Projection TV Controls and Connectors13
Basic Connections (Connecting Cable TV or
Antenna)16
Connecting a VCR and Cable19
Connecting a VCR and Cable Box20
Connecting Two VCRs for Tape Editing22
Connecting a Satellite Receiver23
Connecting a Satellite Receiver with a VCR24
Connecting an Audio Receiver25
Connecting a DVD Player with Component
Video Connectors26
Connecting a DVD Player with A/V Connectors 27
Connecting a Digital TV Receiver28
Connecting a Camcorder29
Connecting an AV Receiver
Using the CONTROL S Feature
Setting Up the Projection TV Automatically32
Adjusting the Convergence Automatically - FLASH
FOCUS <sup>TM</sup> –
Adjusting the Convergence Manually34

### Using the Features

Using the Remote Control	36
Watching the TV	39
Watching the Digital TV	41
Using Favorite Channels	42
Using Twin View <sup>TM</sup>	43
Using the Freeze Function	46
Using Scrolling Channel Index	47
Using Wide Mode	49
Using Favorite Channels Using Twin View <sup>TM</sup> Using the Freeze Function Using Scrolling Channel Index	42 43 46 46

Overview	
Using the Video Menu	51
Using the Audio Menu	53
Using the Channel Menu	
Using the Wide Menu	
Using the Timer Menu	
Using the Setup Menu	60

### Other Information

Programming the Remote Control	70
Operating Other Components with Your Pr	ojection
TV Remote Control	73
Troubleshooting	75
Specifications	78
Index	

## Introducing the Sony Projection TV

### Presenting the Sony Projection TV

Thank you for purchasing the Sony Projection TV. This manual is for models KP-46WT510, KP-51WS510, KP-57WS510, and KP-65WS510. KP-51WS510 is used for illustration purposes, unless indicated otherwise.

#### Features

Some of the features that you will enjoy with your new projection TV include:

- Hi Scan 1080<sup>™</sup>: Enables you to receive the 1080i, 720p, 480p and 480i digital TV formats. By using the VIDEO 5/6/7 IN jacks, you can connect a DTV (digital television) receiver to view DTV programs.
- DRC<sup>™</sup> Multi-Function: Unlike conventional line doublers, the DRC feature doubles vertical and horizontal lines, resulting in four times the density for quality sources such as DVD, Satellite and Digital camcorder.
- CineMotion<sup>™</sup>: Reverse 3-2 pulldown processing provides optimal picture quality for film-based sources (media originally shot in 24 frames per second).
- Twin View<sup>™</sup>: Using Multi-Image Driver (MID-X), Twin View allows you to watch two programs side by side with the ability to zoom in on one picture and listen to the program in the selected window. You can watch pictures from two different sources (1080i, 720p, 480p or 480i) simultaneously.
- Steady Sound<sup>™</sup>: Equalizes volume levels so there is consistent output between programs and commercials.
- Parental Control: V-Chip technology allows parents to block unsuitable programming for younger viewers.
- Component Video Inputs: Offers the best video quality for DVD (480p, 480i) and Digital Set-top box (1080i, 720p, 480p, 480i) connections.
- S-VIDEO Inputs: Provides a high-quality image for connected equipment.
- **Favorite Channel Preview:** Preview up to eight favorite channels without leaving the current channel.
- Scrolling Channel Index: Allows you to view and choose channels from scrolling pictures without leaving the current channel.

#### Introducing the Sony Projection TV

- □ Wide Screen Mode: Allows you to watch 4:3 normal broadcasts in wide screen mode (16:9 aspect ratio).
- **Auto Wide:** Allows you to select the wide screen mode automatically.
- □ Flash Focus<sup>™</sup>: Allows you to adjust convergence automatically.
- Manual Convergence: Allows you to manually adjust the convergence of specific areas of the screen.
- Digital Visual Interface (DVI): Can accommodate a copyprotected digital connection (HDCP\*) to other devices (such as digital set-top boxes) that have compatible interfaces. The DVI-HDTV input terminal is compliant with the EIA-861 standard and is not intended for use with personal computers.

### Using this manual

We recommend that you carefully review the contents of the following three sections in the order shown to ensure that you fully understand the operation of your new projection TV.

1 Installing and Connecting the Projection TV

This section guides you through your initial setup. It shows you how to install your projection TV, to connect your new components and to connect the antenna and cable.

**2** Using the Features

This section shows you how to begin using your new projection TV. It also shows you how to use your remote control functions.

**3** Using the menus

This section teaches you how to access on-screen menus and adjust your projection TV settings.

Instructions in this manual are written for the remote control. Similar controls are also found on the projection TV console.

#### \* High-bandwidth Digital Content Protection


# Installing and Connecting the Projection TV

### **Contents**

The box contains your new projection TV, a remote control and two AA batteries. No peripheral cables are included. If you intend to add additional equipment to your projection TV, please check the hookup instructions for your desired setup before you begin. You may need to purchase cables and/ or splitters to complete the hookup properly.

### Inserting Batteries into the Remote Control

Insert two size AA (R6) batteries (supplied) by matching the + and - on the batteries to the diagram inside the battery compartment.




- Remove the batteries to avoid damage from possible battery leakage whenever you anticipate that the remote control will not be used for an extended period.
- Handle the remote control with care. Avoid dropping it, getting it wet, or placing it in direct sunlight, near a heater, or where the humidity is high.
- Your remote control can be programmed to operate most video equipment. (See "Programming the Remote Control" on page 70.)


## **Carrying Your Projection TV**

Carrying the projection TV requires four (4) or more people.


The projection TV has been equipped with casters for easy movement on a hard surface. Please move your projection TV using the casters. (KP-51WS510, KP-57WS510, and KP-65WS510 only)



## Installing the Projection TV



**Recommended viewing area (Vertical)** 




Recommended viewing area (Horizontal)

Installing and Connecting the Projection TV

### **Connector Types**

You may find it necessary to use some of the following connector types during set up.

#### **Coaxial cable**



#### S Video cable

High quality video cable for enhanced picture quality

#### Audio/Video cable

Video - Yellow Audio (Left) - White Audio (Right) - Red

Some DVD Players are equipped with the following three video connectors:

Y - Green P<sub>B</sub> (C<sub>B</sub>, C<sub>b</sub> or B–Y) - Blue P<sub>R</sub> (C<sub>R</sub>, C<sub>r</sub> or R–Y) - Red

#### **CONTROL S cable**

CONTROL S connections are exclusive to Sony products and allow greater control of all Sony equipment.

■ The second se

#### **DVI cable**

DVI connection for a high-bandwidth copy-protected signal





Push into connection.


### **Projection TV Controls and Connectors**

Front Panel Menu Controls

The front panel menu controls allow access to the on-screen menus without the use of a remote control. Pressing MENU brings up the on-screen menus. The arrow buttons move the on-screen cursor in the menus and by pressing the Select button (--) selects the menu item.








Connection	Description
1 DVI-HDTV VIDEO AUDIO R/L (VIDEO 7 IN)	Can accommodate a copy-protected digital connection (HDCP <sup>*</sup> ) to other devices (such as digital set-top boxes) that have compatible interfaces. The DVI-HDTV input terminal is compliant with the EIA-861 standard, and is not intended for use with personal computers. See the instruction manual that came with your equipment for details about connecting and using it with the TV.
2 AUX	Allows you to view local and cable channels if your cable provider does not feature local channels. You can switch between local and cable channels easily by pressing ANT on the remote control. Devices connected to the AUX input cannot be viewed in Twin View.
3 TO CONVERTER	This is a VHF/UHF OUT jack that lets you set up your projection TV to switch between scrambled channels (through a cable box) and normal cable channels (CATV). Use this jack instead of a splitter to get better picture quality when switching between scrambled and unscrambled cable channels.
4 VHF/UHF	Connects to your VHF/UHF antenna or cable.
5 S VIDEO (Rear and front)	Connects to the S VIDEO OUT jack of your VCR or other S VIDEO-equipped video component. Provides better picture quality than the VHF/UHF jacks or the Video IN jack.
6 VIDEO (L/R)/AUDIO (Rear and front)	Connects to the audio and video OUT jacks on your VCR or other video component. A fourth video input (VIDEO 2) is located on the front panel of the projection TV.
7 Y/P <sub>B</sub> /P <sub>R</sub> (L/R)/AUDIO	Connects to your DVD player's or Digital Set-top box's component video (Y, PB, PR) and audio (L/R) jacks.
8 TV OUT	Outputs the signal that the TV is tuned to (regardless of the picture displayed on the screen).
9 AUDIO OUT (VAR/FIX) L (MONO)/R	Connects to the left and right audio inputs of your audio or video component.
10 CONTROL S IN/OUT	To control other Sony equipment with the projection TV's remote control, connect the CONTROL S IN jack of the equipment to the CONTROL S OUT jack on the projection TV with the CONTROL S cable.
	To control the projection TV with a remote control for another Sony product, connect the CONTROL S OUT jack of the equipment to the CONTROL S IN jack on the projection TV with the CONTROL S cable.
* Ligh handwidth	Digital Contant Protection

\* High-bandwidth Digital Content Protection.

Installing and Connecting the Projection TV


Installing and Connecting the Projection TV

### **Basic Connections (Connecting Cable TV or Antenna)**



#### Cable and Antenna

If your cable provider does not feature local channels, you may find this setup convenient.



Select CABLE or antenna (ANT) mode by pressing ANT on the remote control.

To receive channels with an antenna, you need to turn your Cable to Off (see page 55) and perform the Auto Program function (see page 56).

### Cable Box Connections

#### **Cable Box and Cable**

This is the preferred basic cable TV hookup to use if:


- □ Your cable TV company scrambles some channels, but not all of them (pay channels vs. regular cable channels) and you need to use a cable box, and
- □ You want to enjoy the Twin View feature.

With this setup you can:

- □ Use the projection TV remote control to change channels using your cable box when the signal is scrambled.
- □ Use the projection TV remote control to change channels using your projection TV when the signal is not scrambled. (Your projection TV's tuner provides a better signal than the cable box.)
- Use the Twin View feature. (When all channels are routed through your cable box, only one channel is sent to the projection TV, so you can not use the Twin View or Channel Index features for your cable box.)

DIGITAL CABLE BOX USERS: Do not use this connection. The TO CONVERTER jack is not compatible with digital cable boxes.

- Connect the Cable TV cable to the projection TV's VHF/UHF jack.
- 2 Using a coaxial cable, connect the projection TV's TO CONVERTER jack to the cable box's IN jack. The projection TV's internal converter allows you to switch between unscrambled signals coming straight into the projection TV and scrambled signals coming in through the cable box, eliminating the need for an external splitter.
- **3** Using a coaxial cable, connect the cable box's OUT jack to the projection TV's AUX jack.



Pressing ANT on the remote control switches between the channels coming in through the cable box (scrambled) and those coming directly to the TV (unscrambled).


#### Cable Box Only

Use this hookup if:

- □ You subscribe to a cable TV system that uses scrambled or encoded signals requiring a cable box to view all channels, and
- You do not intend to hook up any other audio or video equipment to your projection TV.

When all channels are routed through your cable box, only one unscrambled channel is sent to the projection TV, so you cannot use the Twin View feature. If some channels are scrambled, but others are not, consider using the hookup on page 17 instead.

- 1 Connect the coaxial connector from your cable service to the cable box's IN jack.
- **2** Using a coaxial cable, connect the cable box's OUT jack to the TV's VHF/UHF jack.



Also, set Cable to On in the Channel menu (see page 55).

- Your Sony remote control can be programmed to operate your cable box (see "Programming the Remote Control" on page 70).
- To change channels using the cable box, set your projection TV to channel 3 or 4 depending on the cable box channel output. If you will be controlling all channel selection through your cable box, consider using the Channel Fix feature to set your projection TV to channel 3 or 4 (see page 56).

If you have a digital cable box, you cannot use this connection because the TO CONVERTER jack is not compatible with digital cable boxes.

Setting the Channel Fix feature in the Channel menu (see "Using the Channel Menu" on page 55), ensures that you do not accidentally switch the channels using your projection TV.


### Connecting a VCR and Cable

Use this hookup if:

• You have cable TV that does not require a cable box.

Disconnect all power sources before making any connections.

- Connect the cable TV cable to the VCR's IN jack.
- **2** Using a coaxial cable, connect the VCR's OUT jack to the projection TV's VHF/UHF jack.
- 3 Using AUDIO and S VIDEO cables, connect the VCR's Audio and S Video OUT jacks to the projection TV's AUDIO and S VIDEO IN jacks.



If your VCR is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.

### Connecting a VCR and Cable Box

Use this hookup if:

- Your cable TV company scrambles some channels, but not all of them (pay channels vs. regular cable channels) and you need to use a cable box, and
- □ You want to enjoy the Twin View feature.


With this setup you can:

- Use the projection TV remote control to change channels on your cable box when the signal is scrambled. To program your Sony remote control to operate your cable box, see "Programming the Remote Control" on page 70.
- Use the projection TV remote control to change channels using your projection TV when the signal is not scrambled. Your projection TV's tuner provides a better signal than the cable box.
- Use the Twin View feature. (When all channels are routed through your cable box, only one signal is sent to the projection TV, so you cannot use the Twin View feature.)

Disconnect all power sources before making any connections.

- **1** Connect the Cable TV cable to the projection TV's VHF/UHF jack.
- 2 Using a coaxial cable, connect the TV's TO CONVERTER jack to the cable box's IN jack. The projection TV's internal converter allows you to switch between unscrambled signals coming straight into the projection TV and scrambled signals coming in through the cable box, eliminating the need for an external splitter.
- DIGITAL CABLE BOX USERS: If you are connecting a digital cable box, you will need a special bi-directional splitter that is designed to work with your digital cable box. Contact your cable provider for details.
- **3** Using a coaxial cable, connect the cable box's OUT jack to the VCR's IN jack.
- 4 Using AUDIO and S VIDEO cables, connect the VCR's AUDIO and S VIDEO OUT jacks to the projection TV's AUDIO and S VIDEO IN jacks.
- 5 Using a coaxial cable, connect the VCR's OUT jack to the projection TV's AUX jack.

To view scrambled channels, press ANT to switch to the AUX input. Change channels using your cable box.



**Rear of projection TV** 


- If your VCR is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.
- You will not be able to change channels on the VCR. Set your projection TV and VCR to channel 3 or 4, depending on your cable box.
- Pressing ANT on the remote control switches between the channels coming in through the cable box (scrambled) and those coming directly to the projection TV (unscrambled).
- If you are connecting a digital cable box, you will need a special bi-directional splitter designed to work with your cable box.

### Connecting Two VCRs for Tape Editing

If you connect two VCRs, you can record from one VCR to the other while using your projection TV to monitor what is being recorded.

Disconnect all power sources before making any connections.

- Using AUDIO and VIDEO cables, connect the playback VCR's AUDIO and VIDEO OUT jacks to the recording VCR's Audio and Video IN jacks.
- 2 Using AUDIO and VIDEO cables, connect the recording VCR's AUDIO and Video OUT jacks to the projection TV's AUDIO and VIDEO IN jacks.



VMC-810S/820S (not supplied)


- To perform tape editing, set the projection TV to the video input intended for playback by pressing TV/VIDEO on the remote control.
- You may need to change the video input on your VCR. Consult your VCR's operating manual for instructions.
- If both VCRs have an S VIDEO jack, you can use the S VIDEO connection instead of the yellow video cable on a combined A/V cable. To use an S VIDEO cable, connect the VIDEO OUT jack of the playback VCR to the VIDEO IN jack of the recording VCR. Since S VIDEO does not provide audio, you must still connect audio cables to provide sound.
- You cannot record signals from equipment connected to the Y, P<sub>B</sub>, P<sub>R</sub> input.

### Connecting a Satellite Receiver

**Rear of projection TV** 

Disconnect all power sources before making any connections.

- 1 Connect the satellite antenna cable to the satellite receiver's SATELLITE IN jack.
- 2 Using AUDIO and S VIDEO cables, connect the satellite receiver's AUDIO and S VIDEO OUT jacks to the projection TV's AUDIO and S VIDEO IN jacks.
- Connect a coaxial cable from your cable or antenna to the projection TV's VHF/UHF jack.
- If your satellite receiver is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.




#### YC-15V/30V (not supplied)

### Connecting a Satellite Receiver with a VCR

Disconnect all power sources before making any connections.

- 1 Connect the satellite antenna cable to the satellite receiver's SATELLITE IN jack.
- **2** Connect the CATV cable to the VCR's VHF/UHF IN jack.
- **3** Using a coaxial cable, connect the VCR's OUT jack to the projection TV's VHF/UHF jack.
- 4 Using AUDIO and S VIDEO cables, connect the satellite receiver's AUDIO and S VIDEO OUT jacks to the VCR's AUDIO and S VIDEO IN jacks.
- **5** Using AUDIO and S VIDEO cables, connect the VCR's AUDIO and S VIDEO OUT jacks to the TV's AUDIO and S VIDEO IN jacks.



Be sure your VCR's video input is set correctly. Consult your VCR's operating manual for instructions.


Lise TV/VIDEO to select

- VIDEO 1 to watch satellite TV or the VCR (your VCR must be turned on).
- VHF/UHF to watch cable TV.
- If your VCR or satellite receiver is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.

### **Connecting an Audio Receiver**

#### Disconnect all power sources before making any connections.

Using audio cables, connect the projection TV's AUDIO OUT (VAR/FIX) jacks to the audio receiver's audio LINE IN jacks.



Installing and Connecting the Projection TV


### *Connecting a DVD Player with Component Video Connectors*

This is the preferred hookup to use if:

□ Your DVD player has component (Y, B-Y, R-Y) jacks.

Disconnect all power sources before making any connections.

- Using three separate component video cables, connect the DVD player's Y, B-Y and R-Y jacks to the Y, PB and PR jacks on the projection TV. Use the VIDEO IN 5 or 6 connections.
  - The Y, B-Y and R-Y jacks on your DVD player are sometimes labeled Y, CB and CR, or Y, PB and PR. If so, connect the cables to like colors.
- 2 Using an audio cable, connect the DVD player's Audio OUT jacks to the projection TV's AUDIO IN jacks. Be sure to use the same row of inputs that you used for the video connection (VIDEO IN 5 or 6).




### Connecting a DVD Player with A/V Connectors

Use this hookup if:

- □ Your DVD player does not have component (Y, PB, PR) jacks.
- If your DVD player has video component output connectors: for best picture quality use the connection described on page 26.

#### Disconnect all power sources before making any connections.

- 1 Using audio cables, connect the DVD player's Audio OUT jacks to the projection TV's AUDIO IN jacks.
- **2** Using an S VIDEO cable, connect the DVD player's S VIDEO jack to the projection TV's S VIDEO jack.



- Use TV/VIDEO on the remote control to switch between the VCR, DVD player and cable TV inputs.
- If your VCR is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.

Installing and Connecting the Projection TV


### **Connecting a Digital TV Receiver**

Be sure to read the Set-top box manual.

Some Digital TV Receivers are equipped with a DVI connection. Refer to your Digital TV Receiver manual for setup instructions using this connection.

#### Disconnect all power sources before making any connections.

- Using three separate component video cables, connect the Digital TV Set-top box's Y, PB and PR jacks to the projection TV.
  - The Y, PB and PR jacks do not provide audio, so audio cables must be connected to provide sound.
  - Component video connection is necessary to view 480p, 720p, and 1080i formats. You may also use the S VIDEO or Composite Video connections, however, component video (Y, PB, PR) will provide the best picture quality for all format types.
- 2 Using an audio cable, connect the Digital TV Set-top box's Audio OUT jacks to the projection TV's AUDIO IN jacks.



#### **RK-74A** (not supplied)


- You cannot record the signal from any equipment connected into the Y, PB and PR connectors.
- This projection TV is not compatible with digital TV receivers configured with RGB or VGA output connectors.
- The DVI connection is compliant with the EIA-861 standard and is not intended for use with personal computers.

### **Connecting a Camcorder**

For easy connection of the camcorder, the projection TV has front Audio and Video inputs (shown below). However, if you prefer, you can also connect the camcorder to the projection TV's rear Audio and Video IN jacks.

Using AUDIO and S VIDEO cables, connect the camcorder's Audio and S VIDEO OUT jacks to the projection TV's AUDIO and S VIDEO IN jacks.

- If you have a mono camcorder, connect its left audio output to the projection TV's AUDIO L (MONO) jack.
- If your camcorder is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.




### **Connecting an AV Receiver**

You can connect an AV receiver using both composite video and S VIDEO. If both are connected, then the TV will detect and display an S VIDEO signal. To take advantage of this feature, connect your receiver with Video 1. For greater control of all audio and video equipment, connect an AV receiver.

Change "Video Label" for the VIDEO 1 input to "Receiver" (see page 61).


Disconnect all power sources before making any connections.

- 1 Connect the coaxial cable from the incoming cable connection or antenna to IN on the VCR.
- **2** Using a coaxial cable, connect OUT on the VCR to VHF/UHF on the projection TV.
- **3** Using a VIDEO cable, connect VIDEO of VIDEO 1 IN on the projection TV to MONITOR OUT on the AV receiver.
- 4 Using an AUDIO/VIDEO cable, connect TV OUT on the projection TV to AUDIO/VIDEO 2 IN on the AV receiver.
- 5 Using an AUDIO/VIDEO cable, connect the video equipment to the AV receiver.
- **6** Select the Setup menu and set "Video Label" to "Receiver" to fix your TV's input to AV receiver (see "Video Label" on page 61).



### Using the CONTROL S Feature

CONTROL S allows you to control your projection TV system and other Sony equipment with one remote control. In addition to allowing you to control multiple devices with one remote control, the CONTROL S feature allows you to always point your remote control at your projection TV, instead of having to point it at the other equipment, which might be hidden or out of direct line of sight.




### Setting Up the Projection TV Automatically

After you finish connecting your projection TV, you can run Auto Setup to set up your channels. The Auto Setup screen appears when you turn your projection TV on for the first time after installing it. If you do not want to set up the channels at this time, you can do it later by using the Auto Program feature in the Channel menu (see page 56).

The Auto Setup feature does not apply for installations that use a cable box for all channel selection.

### Using Auto Setup

- **1** Press POWER on the front panel of your projection TV or on the remote control to turn on the projection TV.
- **2** Press the TV (FUNCTION) button on your remote control. Red light will briefly appear.
- Press CH+ on your projection TV to run Auto Setup, or press CH− to exit. If you use the channel buttons on your remote control, be sure to use the main set of buttons (<sup>H</sup>/<sub>(+)</sub>).



You can run Auto Program by selecting it in the Channel menu, as described on page 56.


### Adjusting the Convergence Automatically – FLASH FOCUS™ –

The projection tube image appears on the screen in three colors (red, green and blue). If they do not converge, the color is poor and the picture blurs.

Before you use your projection TV, be sure to adjust the convergence.


The FLASH FOCUS feature allows you to adjust the convergence automatically.

It is recommended to perform FLASH FOCUS about 30 minutes after the projection TV is first turned on.



- **1** Receive a TV or cable TV program.
- **2** Press FLASH FOCUS.

The cross pattern shown below appears and FLASH FOCUS begins to work. The adjustment is completed when the cross pattern becomes white and you are returned to the program you were watching.



- You cannot perform any other functions until FLASH FOCUS has completed its cycle.
- If you perform any other operation while FLASH FOCUS is in progress, FLASH FOCUS operation is canceled.
- Unshielded speakers or other metallic objects can cause picture distortion if placed close to the projection TV.
- If you would like to manually perform additional fine adjustments, see page 34.

# Adjusting the Convergence Manually

The Manual Convergence feature gives you more control over the TV's picture than the Flash Focus feature, allowing you to fine-tune the color alignment of each section of the TV screen.

- Before using Manual Convergence, you must first perform Flash Focus (as described on page 33).
- 🖾 Use the joystick of your remote control to perform the steps below.

the **P**ress MENU to display the Menu.

- Move the joystick  $\blacklozenge$  or  $\blacklozenge$  to highlight the Setup icon and press  $\bigoplus$ .
- Move the joystick to highlight Convergence and press 💮.

A pattern of white crosses appears, with a yellow around one of the crosses. Aligned crosses (which do not need adjustment) look white and have little or no red or blue showing. Crosses that are not aligned show red or blue shades beyond their edges.

+++	+ +	+ +	+++	+ +	+ +	++
+	+	+	+	+	+	+
+	+	+	[+-]	+	+	+
+	+	+	+	+	+	+
+	+	+	+	+	+	+
Full/Normal Move1↓→ ←		S	elect: 🕀	En	d: menu	

- You can scroll up and down through the 9 x 7 field of crosses to manually converge all portions of the screen.
- 4 Using the joystick, move the **b** to surround a cross that you want to adjust. Press (). The **b** changes to red.
- 5 If the cross that you selected has red edges, move the joystick until the red image is replaced with a white cross. Once you have finished this (or the cross does not have red edges), press (+). The \_ \_ \_ changes to blue.
- If the cross you selected has blue edges, move the joystick until the blue image is replaced with a white cross. Once you have finished this, press
   . The \_ \_ \_ changes to yellow again.
- 7 Repeat steps 4 to 6 to adjust other crosses. When finished, press MENU to exit the manual convergence screen and the Setup menu.

For details on using the Setup Menu, see page 60.


Notes on Adjusting the Convergence Manually

- □ For best results, stand about 3 to 5 feet back from the picture when adjusting the convergence. Begin with the crosses in the center area of the screen and, once those are adjusted, move to the crosses on the edges of the screen.
- You can make separate adjustments to each wide mode: Full/Normal, Zoom, Wide Zoom, and 1080i high-definition input. The cross pattern settings appear different in each wide mode, but the adjustment procedure is the same. Press the WIDE MODE button on the remote to toggle through the wide mode screens.

# Using the Remote Control

The following table describes the buttons on the remote control that are for more advanced functions.

# **Button Descriptions**




Outside Panel	
Button	Description
1 MUTING	Press to mute the sound. Press again or press VOL + to restore the sound.
2 SLEEP	Press repeatedly until the projection TV displays the time in minutes (15, 30, 45, 60, or 90) that you want the projection TV to remain on before shutting off automatically. Cancel by pressing until Sleep Off appears or turning the power off. While the Sleep feature is set, press once to view the remaining time.
3 ANT	Changes between the VHF/UHF input and the AUX input.
4 DISPLAY	Press once to display the current time and channel label (if set) and channel number. Press again to turn Display off. See page 59 for details on setting the time.
5 JUMP	Press to jump back and forth between two channels. The projection TV alternates between the current channel and the last channel that was selected.
6 FREEZE	Freezes the window picture. Press again to restore the picture.
7 INDEX	Press to enter the Scrolling Channel Index mode. You can view and select from all receivable channels scrolling on the screen without leaving the current one.
8	The joystick allows for movement of the on-screen cursor. Pressing down on the center of the joystick selects the item.
9 VOL +/-	Adjusts the volume.
10 PIC MODE	Press repeatedly to step through the available video picture modes: Vivid, Standard, Movie and Pro. Also available in the Video menu. For details, see "Selecting Video Options" on page 51.
11 FAVORITES	Displays the Favorite Channels list. For details, see "Using Favorite Channels" on page 42.
12 RESET	Press when in a menu to reset the settings to the factory defaults.

ANT DISPLAY TV/DEO	14
	16
FREEZE INDEX WENU CH	—17 —18
PIC MODE FAVORITES CINEMOTION	20
WIDE MODE	21
SONY RM4-Y909	

Button	Description
13 POWER buttons (GREEN)	Turn on and off the projection TV and other audio/video equipment you have programmed into the remote control. For instructions, see "Programming the Remote Control" on page 70.
14 FUNCTION buttons	Select the equipment (TV, SAT/CABLE) that you want to operate. The indicator lights up momentarily when pushed to show which device the remote control is operating.
15 TV/VIDEO	Cycles through the video equipment connected to your projection TV's video inputs: TV, VIDEO 1, VIDEO 2, VIDEO 3, VIDEO 4, VIDEO 5, VIDEO 6 and VIDEO 7.
16 0 – 9 and ENTER	Press <b>0</b> - <b>9</b> to select a channel, the channel changes after 2 seconds. Press ENTER to select immediately.
17 🕕	Turns on/off Twin View. For details, see "Using Twin View <sup>TM</sup> " on page 43.
GUIDE	Displays the program guide of your satellite.
18 MENU	Press to display the projection TV on-screen menu. Press again to exit from the menu.
19 CH +/-	Scan through channels.
20 DRC/ CINEMOTION	Press repeatedly to step through the available high- resolution picture modes: Interlaced, Progressive and CineMotion. For details, see "Using the Video Menu" on page 51.
21 WIDE MODE	Press to step through the wide screen modes: Wide Zoom, Normal, Full and Zoom. For details, see "Using Wide Mode" on page 49.

To scan rapidly through the channels, press and hold down CH+ or CH–.

### Using the Features




Ins	side Panel	
	Button	Description
1	SYSTEM OFF	Press to turn off the projection TV and all equipment connected with S-Link.
2		Play
3		Rewind
4	REC	Record
5		Stop
6	DVD MENU	Displays the DVD menu.
7	MTS/SAP	Press to scroll through the Multi-channel TV Sound (MTS) options: Stereo, Auto SAP, and Mono.
8	CODE SET	Used for programming the remote control to operate non- Sony video equipment. For details, see "Programming the Remote Control" on page 70.
9	POWER	Press to turn on the DVD/VCR player you have programmed into the remote control. For instructions, see "Programming the Remote Control" on page 70.
10	▶	Fast-forward
11	AV1 AV2 AV3 DVD	Use to switch control for connected video equipment. You can program one video source for each switch position. For details, see "Programming the Remote Control" on page 70.
12	11	Pause (Press again to resume normal playback)
13	MENU	Displays the Video equipment menu.
14	$\uparrow$ , $\clubsuit$ , $\Leftarrow$ , $\Rightarrow$ , and ENTER	Use to operate the DVD menu.
15	٩	Press to select an audio option: Steady Sound On or Off.

# Watching the TV

Many TV features can be accessed directly through the remote control. The following will explain the function of some of the buttons found on your remote control.

# Buttons for Projection TV Operations



## **1 TV (FUNCTION)**

Activates the remote control for use with the projection TV.

## 2 ANT— (AUX input)

Press to change between the VHF/UHF input and the AUX input.

## **3 TV (POWER)**

Turns the projection TV on and off. If a video input indication (e.g., VIDEO 1, VIDEO 2) appears on the screen, press TV/VIDEO or CH +/ – until a channel number appears.

## 4 0-9 and ENTER

Use for direct channel selection. Press 0-9 to select a channel (for example, to select channel 10, press 1 and 0). The channel will change after 2 seconds, or you can press ENTER for immediate selection.

## 5 CH +/-

Press to scan through the channels (+ up or – down).

## 6 VOL +/-

Press to adjust the volume (+ up or – down).

## 7 JUMP

Press to alternate or jump back and forth between two channels. The projection TV will jump between the current channel and the last channel selected.

## 8 MUTING

Press to mute the sound. "MUTING" will appear on the screen and will dim three seconds later. To restore the sound, press again or press VOL +.

## 9 FREEZE — (yellow labeled button)


This is useful when you need to copy down information that appears on the TV's screen (see "Using the Freeze Function" on page 46).

## 10 SLEEP

Press repeatedly until the projection TV displays the approximate time in minutes (15, 30, 45, 60, or 90) that you want the projection TV to remain on before shutting off automatically.

Cancel by pressing SLEEP until "Sleep Off" appears or turning the power off.

### **Using the Features**



## **11 DISPLAY**

Press to display the channel number, current time and channel label (if set).

To turn the display off, press DISPLAY again.

## **12 TV/VIDEO**

Press repeatedly to scroll through available video inputs: TV, VIDEO 1, VIDEO 2, VIDEO 3, VIDEO 4, VIDEO 5 VIDEO 6, and VIDEO 7.

If you select Skip as a Video Label in the Setup menu, your projection TV will skip the video input you selected (see "Video Label" on page 61).

### 13 MTS/SAP

Press to scroll through the Multi-channel TV Sound (MTS) options (see "MTS" on page 53).

### **14 PIC MODE**

Press PIC MODE repeatedly to directly choose one of four different video modes that best suits the program you are watching.

Vivid: Select for enhanced picture contrast and sharpness.

Standard: Select to display a standard picture for normal viewing environments.

Movie: Select to display a finely detailed picture for low light environments.

Pro (Professional): Select to display a picture with minimum enhancements.

When you select each mode, you can also adjust the picture quality (such as Brightness, Color, etc.) to suit your taste. For details, see "Mode" on page 51.

# Watching the Digital TV

When you have connected the DTV receiver, you can enjoy digital TV programs. This projection TV is capable of receiving 1080i, 720p, 480p and 480i digital TV formats (note that 720p is displayed as 480p).

### To view a digital TV program

- Connect the DTV receiver to VIDEO 5, 6 or 7 IN on the projection TV. (for details, see page 28)
- **2** Press TV/VIDEO to select VIDEO 5, 6 or 7.
- **3** Select a digital channel on the DTV receiver. For details, see the Operating Manual of the DTV receiver.
- 4 Adjust the volume of the projection TV as necessary.

# **Using Favorite Channels**

The Favorite Channel feature lets you select programs from a list of favorite channels that you preset.

To display a list of your favorite channels:

- Your Favorite Channel options can be set automatically or manually. The factory setting for Favorite Channel is Auto. When Favorite Channel is set to Auto, the last eight channels selected with 0-9 buttons will be set as Favorite Channel options. If you want to input your own selections as Favorite Channel settings, see "Favorite Channel" on page 55.
- **1** Press FAVORITES.

The Favorite Channel options appear.



2 Move the joystick up or down to highlight the channel you want to watch. The program of that channel appears in the preview window. Press ↔ to select.

# Using Twin View™

Activating Twin

**Pictures** 

Twin View enables you to watch two programs at the same time. You can also change the size of both the left and right pictures.

### To display twin pictures

1 Make sure your projection TV is tuned to a working channel.

2 Press 🕕.



To cancel twin pictures
□ Press ① again (or press ↔).

## Activating the Picture

Although two pictures appear on the screen at the same time, only one picture is active. For an active picture, you can:

- Change channels.
- Adjust the volume.
- Switch the input sources from VHF/UHF to cable by pressing ANT or TV/VIDEO to switch the video input.
   When the picture on the right is activated, the input sources cannot be

switched to VIDEO 5, 6, 7, or AUX by pressing ANT.Change the picture size (see page 45).

### To activate the right picture

□ Move the joystick to the right.



To activate the left pictureMove the joystick to the left.

Factors Affecting Twin View:

- If you use a cable box to view all channels, the same channel appears in both windows because the cable box unscrambles only one channel at a time.
- If you use a cable box, you can view the cable box output in one window and view a different source (such as a VCR or DVD player) in the second window by using the TV/VIDEO button.
- Sources connected to the AUX, VIDEO 5, VIDEO 6, and VIDEO 7 inputs display in the left window, but not the right.
- If you are viewing a 4:3 source and a 16:9 enhanced source (such as a DVD) side by side, the 4:3 source appears larger.
- Twin View does not display channels that are blocked by Parental settings (page 62).
- At The active picture is highlighted in cyan.

# Changing the Picture Size

The zoom feature lets you change the size of the left and right pictures.

### To enlarge the left picture (reduce the right)

1 Move the joystick left to activate the left picture (if not already activated).

2 Move the joystick up to enlarge the picture and move the joystick down to reduce the picture.









### To enlarge the right picture (reduce the left)

- Move the joystick right to activate the right picture (if not already activated).
- 2 Move the joystick up to enlarge the picture and move the joystick down to reduce the picture.

Using the Features

When you adjust the twin screen sizes, the projection TV memorizes the change. The next time you use the Twin View function, the memorized sizes appear.

# Using the Freeze Function

The FREEZE button allows you to temporarily capture a program's picture. You can use this feature to write down information such as phone numbers, recipes, etc.

### To use the Freeze function

- 1 When the program information you want to capture is displayed, press FREEZE.
- 2 The projection TV switches to Twin View mode and displays the "frozen" picture on the right, while the current program continues on the left.



**3** To cancel and return to normal viewing, press FREEZE.

In Freeze feature is not available if you are already in Twin View™ or Index mode.

# Using Scrolling Channel Index


Scrolling Channel Index allows you to view and select from all receivable channels scrolling on the screen without leaving the current channel.

Scrolling Channel Index will not function when Parental Lock is activated.

### To use the Scrolling Channel Index function


1 Press 🗇 .

The current channel will be reduced in size and displayed on the left in normal motion picture format. The first channel is briefly displayed on the bottom-right side of the screen, then frozen. It scrolls up and the next channel appears on the bottom-right, and the process is repeated with the other channels.




2 Move the joystick up and down so that the channel you wish to view is displayed in the cyan frame, and press (-).

To return to scrolling, move the joystick up and down again.



**3** To enlarge the selected channel into the left frame, press (+) again. The selected channel will be displayed in normal motion picture, and the sound also switches to this channel.



To change the direction of scrolling, move the joystick up or down once.

To increase scrolling speed, hold the joystick up or down.

### **Using the Features**

**4** Press **□**.

The selected channel will be enlarged for normal viewing.



### To cancel Scrolling Channel Index

Press 🗇 again to resume normal viewing.

- Sound will only be heard from the center picture.
- If one of the pictures received through Scrolling Channel Index is snowy, the entire screen may become unstable. In this case, skip the snowy channel. (see "Channel Skip/Add" on page 56)
- If you leave the Scrolling Channel Index screen displayed for an hour without any additional operation, Scrolling Channel Index is canceled and the normal picture reappears.
- The Scrolling Channel Index cannot be used in combination with set-top boxes, DBS receivers, or cable boxes.
- Scrolling Index feature does not function if you use a cable box to view all channels.

# Using Wide Mode

ϔ You can also access the Wide Mode settings in the Screen menu. For details, see page 57.

Wide Screen mode lets you watch 4:3 normal broadcasts in several Wide Screen modes (16:9 aspect ratio).

- M When viewing high-definition programs broadcast in 720p/1080i, it is not possible to change between Wide Screen modes.
- Press WIDE MODE repeatedly to toggle through the following Wide Mode settings.



### Description

screen.

Wide Zoom enlarges the center portion of the 4:3 picture proportionately; however, only the left and right edges of the screen are stretched to fill the 16:9 screen. The picture has a normal appearance, as much as possible.

Normal returns the 4:3 picture to its original size. Bars are visible at left and right sides to fill the 16:9



Using the Features





Wide Zoom

Normal



Full Mode stretches the entire 4:3 picture horizontally only, to fill the 16:9 screen. The picture has an elongated appearance.







Full


Zoom

Zoom Mode enlarges the entire 4:3 picture proportionately to fill the 16:9 screen. Useful for watching Letterbox movies.



When you change channels or inputs, the Wide Mode settings revert to the 4:3 Default setting in the Screen menu. To retain the current Wide Mode setting as channels and inputs are changed, set 4:3 Default to Off. For details, see page 57.

# **Overview**



### Opening and choosing a menu:

- **1** Press MENU to display the menu screen.
- **2** Move the joystick to the desired menu icon and press  $\bigoplus$  to select it.
- 3
  - Use the joystick to scroll through the features.
  - See the specific menu page for instructions on moving through the menu.

The menu gives you access to the following features:

# Menu Icon Description Video Allows you to It also allows It also allows

Allows you to make adjustments to your picture settings. 51 It also allows you to customize the Picture Mode based on the type of program you are viewing.

Page



Offers enhanced audio options such as listening to second 53 audio programming (SAP), or customizing the Effect of the sound on your projection TV.



Press MENU again.

### To end one menu session and move to another:

Press the joystick  $\leftarrow$  to return to the menu icons. Move the joystick  $\leftarrow$  or  $\rightarrow$  to choose the next menu icon and press (+) to select it.



Allows you to set up a Favorite Channel list, run the Auto 55 Program function, and more.

_		
	Wide	
	<b>₽</b> <sup>•</sup> Ъ	

Allows you to set the wide screen mode, adjust the 57 vertical center in wide mode, and set the 4:3 Default mode.



Lets you set the clock on your projection TV and allows 59 you to program your projection TV for scheduled viewing using the Timers.



Provides several options for setting up your channels, 60 labeling your Video inputs, and selecting the language of the on-screen menus.

# 50



# **Using the Video Menu**

### To select the Video Menu

- Press MENU.
- 2 Move the joystick to the Video icon icon and press .
- **3** Use the joystick to scroll through the features.
- 4 Press ⊕ to select a feature. That feature's adjustment appears.



- **5** Use the joystick to make the desired adjustments.
- **6** Press 🕀 to select/set.
- 7 Press MENU to exit the menu screen.

# To restore the factory default settings for Picture, Brightness, Color, Hue, Sharpness and Color Temp

Press **RESET** on the remote control when in the Video menu.

# Selecting Video Options

To quickly and easily change from one Video Mode to another, use the PIC MODE on the remote control. The Video menu includes the following options.

Option	<b>Description</b>		
Mode Customized	Vivid	Select for enhanced picture contrast and sharpness.	
picture	Standard	Recommended for Normal viewing conditions.	
viewing	Movie	Select for soft, film like, picture.	
	Pro	Select for professional monitor like appearance.	
		alter the Video menu settings (Picture, Brightness, .) for each Mode.	
Picture	Adjust to increase picture contrast and deepen the color or decrease picture contrast and soften the color.		
Brightness	Adjust to brighten or darken the picture.		
Color	Adjust to increase or decrease color intensity.		
Hue	Adjust to increase or decrease the green tones.		
Sharpness	Adjust to shar	pen or soften the picture.	
Color Temp	Choose from three color temperatures:		
White	Cool	Select to give the white colors a blue tint.	
intensity adjustment	Neutral	Select to give the white colors a neutral tint.	
	Warm	Select to give the white colors a red tint (NTSC-Standard).	

Description	
-	resolution picture with 4x density, for high quality VD player, Satellite receiver).
Interlaced	Recommended for moving pictures.
Progressive	Recommended for still images and text.
CineMotion	Recommended for 24 frame-per-second films.
	Creates a high- sources (i.e., D Interlaced Progressive



# Using the Audio Menu

### To select the Audio Menu

- Press MENU.
- 2 Move the joystick to the Audio icon and press .
- **3** Use the joystick to scroll through the options.
- 4 Press ⊕ to select an option. That option's settings appear.



- **5** Use the joystick to scroll through the settings.
- **6** Press  $\bigoplus$  to select the desired setting.
- **7** Press MENU to exit the menu screen.

### To restore the factory default settings for Treble, Bass and Balance

Press **RESET** on the remote control when in the Audio menu.

## Selecting Audio Options

The Audio menu includes the following options:

Option	<b>Description</b>	
Treble	Adjust to increase or decrease higher-pitched sounds.	
Bass	Adjust to increa	ase or decrease lower-pitched sounds.
Balance	Adjust to emph	asize left or right speaker balance.
Steady Sound	On	Select to stabilize the volume.
	Off	Select to turn off Steady Sound.
Effect	TruSurround	Select for surround sound (for stereo programs only).
	Simulated	Adds a surround-like effect to mono programs.
	Off	Normal stereo or mono reception.
MTS Enjoy stereo,	Stereo	Select for stereo reception when viewing a program broadcast in stereo.
bilingual and mono programs	Auto-SAP	Select to automatically switch the projection TV to second audio programs when a signal is received. (If no SAP signal is present, the projection TV remains in Stereo mode.)
	Mono	Select for mono reception. (Use to reduce noise during weak stereo broadcasts.)

Option	Description	
Speaker	On	Select to turn on the projection TV speakers.
	Off	Select to turn off the projection TV speakers and listen to the projection TV's sound only through your external audio system speakers.
Audio Out Easy control of volume adjustments	Variable	The projection TV's speakers are turned off, but the volume output from your audio system can still be controlled by the projection TV's remote control.
	Fixed	The projection TV's speakers are turned off and the volume, bass and treble output of the projection TV is fixed. Use your audio receiver's volume control to adjust the volume through your audio system.

#### Using the Channel Menu Channel Ch **To select the Channel Menu** 1 Press MENU. Audio Channel Wide Timer **2** Move the joystick to the $\mathbb{D}_{X}$ THE THE **(-)** Channel icon and press Favorite Channel: Cable:On Channel Fix:Off Auto Program Channel Skip/Add Channel Label Channel:Auto **3** Use the joystick to scroll through the features. Move:**↑↓→←** Select:⊛ End:? **4** Press $\bigoplus$ to select a feature. That feature's options appear. **5** Use the joystick to scroll through the options. **6** Press $\bigoplus$ to select the desired option. 7 Press MENU to exit the menu screen. Selecting Channel The Channel menu includes the following options: Options

Option	Description	
Favorite Channel	Auto	Select if you want Favorite Channel options to be set automatically to the last eight channels selected with the 0-9 buttons.
	Manual	<ul> <li>Select if you want to input your own selections as Favorite Channel options.</li> <li>Press (+) to select a favorite channel number.</li> </ul>
		2 Use the joystick to scroll through the channels until you find the channel you want to add to your favorites.
		<b>3</b> Press 🕀 to select it.
Cable	On	Select if you are receiving cable channels with a CATV cable.
	Off	Select if you are using an antenna.
	You shoul setting.	d run Auto Program after changing the Cable


Option	Description		
Channel Fix Useful when you have a cable box or satellite receiver connected	2-6	"Fix" your projection TV's channel setting to 3 or 4 and use the cable box, VCR or satellite receiver to change channels. Select one of these settings if you have connected the device to the VHF/UHF jack.	
	AUX 2-6	Same as 2-6, except you select one of these settings if you have connected the device to the AUX jack. (see page 15)	
	Video 1	Use when connecting a cable box to control external video sources. TV output should be connected through the cable box.	
Auto Program	Automatically programs the projection TV for all receivable channels.		
Channel	Removes and a	dds viewable channels.	
Skip/Add		ystick to scroll through the channels until you annel you want to skip/add.	
	<b>2</b> Press (+) to select it.		
	<b>3</b> Press the je "Skip."	oystick up or down to toggle between "Add" and	
	4 Press 🕞 t	to select.	
Channel Label	Label up to 20 d	channels with their station call letters.	



# Using the Wide Menu

### To select the Wide menu

- Press MENU.
- 2 Use the joystick to move to the Wide icon the and press ⊕.
- 3 Move the joystick to scroll through the features.
- Press (1) to select a feature. That feature's options appear.



- **5** Use the joystick to scroll through the options.
- **6** Press  $\bigoplus$  to select the desired option.
- **7** Press MENU to exit the menu screen.

The Wide menu includes the following options:

# Selecting Wide Options

To change from one Wide Mode to another, use the WIDE MODE button on the remote control.

Wide Mode is unavailable while in Twin View, Index or Freeze mode.

The 4:3 Default functions only when the projection TV receives 480i signals.

Option	Description	
Wide Mode Select a Wide Mode to use for	Wide Zoom	Select to enlarge the 4:3 picture, while the upper and lower parts of the picture are condensed to fit the wide screen.
4:3 sources.	Normal	Select to return the 4:3 picture to normal mode.
	Full	Select to enlarge the 4:3 picture horizontally only, to fill the wide screen.
	Zoom	Select to enlarge the 4:3 picture horizontally and vertically to an equal aspect ratio that fills the wide screen.
4:3 Default Select the default Screen Mode to	Wide Zoom	Select to enlarge the 4:3 picture, while the upper and lower parts of the picture are condensed to fit the wide screen.
use for 4:3 sources.	Normal	Select to return the 4:3 picture to normal mode.
	Full	Select to enlarge the 4:3 picture horizontally only, to fill the wide screen.
	Zoom	Select to enlarge the 4:3 picture horizontally and vertically to an equal aspect ratio that fills the wide screen.
	Off	Select to continue using the current Wide Mode setting when the channel or input is changed.

If 4:3 Default is set to anything but Off, the Wide Mode setting changes only for the current channel. When you change channels (or inputs), Wide Mode is automatically replaced with the 4:3 Default setting. To retain the current Wide Mode setting as channels and inputs are changed, set 4:3 Default to Off.

Option	Description
Vertical Center	Allows you to move the position of the picture up and down in the window. (Available only in Wide Zoom and Zoom modes.)
	Move the joystick up or down to choose a position and press $$ .

Some wide-screen programs (particularly certain theatrical releases) will be shown in aspect ratios that require the display of black bands at the top and bottom of your 16:9 screen. For more details, check the documentation that came with your DVD, or contact your content provider.



# Using the Timer Menu

**(**...).

first.

3

4

### To select the Timer menu Press MENU. Timer **2** Move the joystick to the 秋同日 $(\mathbf{I})$ Timer icon $\square$ and press $\bigcirc$ . 1:0ff 2:0ff Current Time Daylight Saving:Off To set the Current Time Use the joystick to select Move: ★↓→↓ Select:⊙ End: (NEND) "Current Time", then press 2 If it is currently Daylight Saving Time, be sure to set the mode to "On" Use the joystick to enter the correct time, then press (-). Press MENU to exit the menu screen. To set the Timer

Before setting the timer, be sure to set your projection TV's clock to the current time and Daylight Saving Mode.

- 1 Move the joystick to "Timer 1" or "Timer 2", then press (-).
- **2** Use the joystick to enter your day, time, channel, and timer duration preferences; then, press (-) to select each one.
- 3 Press MENU to exit the menu screen.

## To reset the Clock or Timers

Press RESET on the remote control after selecting that option in the Timer menu.

Option	<b>Description</b>	
Timer 1 Timer 2	Program	Select to set the Timer by day, time, duration, and channel.
	Off	Select to turn off the Timer. (Your previous settings will be saved.)
Current Time	Set the current	time.
Daylight Saving	On	Select in the Spring to adjust the time during Daylight Saving Time.
	Off	Select in the Fall to adjust the time at the end of Daylight Saving Time.

Selecting Timer Options

The Timer menu includes the following options:

Setup

# Using the Setup Menu

### To select the Setup Menu

- Press MENU.
- 2 Move the joystick to the Setup icon  $\bigotimes$  and press  $\bigoplus$ .
- **3** Use the joystick to scroll through the features.
- 4 Press (1) to select a feature. That feature's options appear.



- **5** Use the joystick to scroll through the options.
- **6** Press to select the desired option.
- **7** Press MENU to exit the menu screen.

# Selecting Setup Options

The Setup menu includes the following options:

-		
Option	Description	
Parental Control	• •	ne TV to block programs according to g levels. For details about setting, see uu" on page 62.
Caption Vision	-	om three closed caption modes (for dcast with closed captioning).
	Off	Turns off Caption Vision.
	CC1, CC2, CC3, CC4	Displays a printed version of the dialog or sound effects of a program. (Should be set to CC1 for most programs.)
	Text1, Text2, Text3, Text4	Displays network/station information presented using either half or the whole screen (if available). For closed captioning, set to CC1.
	XDS (Extended Data Service)	Displays a network name, program name, program length, and time of the show if the broadcaster offers this service.

Option	Description	
Video Label	to the projection TV VIDEO. When in the the joystick to highling select it. Use the joyst to select the composed jacks on the back of y	he audio/video components you connected so you can identify them when using TV/ e Setup menu's Video Label feature, use ght an input to label, then press (+) to stick to scroll through the labels. Press (+) ent you connected to each of the input your projection TV. Select "Skip" if you do at connected to a particular set of input
	VIDEO 1	Receiver, VHS, DVD, Satellite, Cable Box, 8 mm, DTV, LD, Beta, Skip
	VIDEO 2/3/4	VHS, DVD, Satellite, Cable Box, 8 mm, DTV, LD, Beta, Skip
	VIDEO 5/6/7	DVD, Satellite, Cable Box, DTV, HD, Skip
	If you select "Skip", when you press TV/\	your projection TV skips this connection /IDEO.
	you are able to c TV input will sta	set the Video Label for Video 1 to "Receiver", shange channels with the remote, and the y on Video 1. Refer to "Connecting an AV ge 30 for more details.
Language	Select to display all o choice: English, Esp	on-screen menus in your language of pañol, Français.

## Using the Parent Menu

The Parent menu allows you to set up the TV to block programs according to their content and rating levels.

These ratings are assigned by a federal rating board. Not all programs are rated. Using the Parental Lock blocks programs with a specific rating, but it does not block an entire channel.

🖉 Scrolling Channel Index will not function when Parental Lock is activated.

### To select the rating

First, set a password, then select the country you reside in (U.S.A. or Canada) and your desired rating.

- Press MENU.
- Move the joystick to the Setup icon 🛅 and press 🕀.



**3** Make sure that "Parental Control" is selected, and press 🕀.



- **4** Use the 0-9 buttons on the remote control to enter your four-digit password.
- **5** Confirm your password by entering it again. Your password is stored and the Parent menu options appear.
  - You need the password entered here for any future access into the Parent menu. If you lose your password, see "Lost password" on page 76.

🖉 If you want to change the password, see page 64.

**6** Make sure that "Country" is selected, and press  $\bigoplus$ .



7 Move the joystick up or down to select U.S.A. or Canada according to the country you reside in, and press (-).




8 Move the joystick down to select "Parental Lock", and press (+).



9 Move the joystick up or down to select a desired rating, and press  $\oplus$ .

If you select Child, Youth, Young Adult or Custom, the Parental Control is activated automatically.



If you want to select the ratings from Custom, see "Using Custom Rating Options" on page 65.

**10** Press MENU to exit the menu screen.

a the Parental deline rating system, should select Child, th, or Young Adult to o simplify the rating ection. To set more rictive ratings, selectParental Lock Off <i>Turn ratings on/</i> off and select a rating systemOff Child Turn ratings on/ Off and select aVoutl To set more rictive ratings, selectYoutl	<ul> <li>US: TV-Y, TV-G, G</li> <li>Canada: TV-Y, C, G</li> </ul>		
should select Child, th, or Young Adult to o simplify the rating ction. To set more rictive ratings, select tom.Turn ratings on/ off and select a rating systemTurn ratings on/ off and select a rating systemChild Child rating systemYouth tom.	<ul> <li>Maximum ratings permitted are:</li> <li>US: TV-Y, TV-G, G</li> <li>Canada: TV-Y, C, G</li> <li>Maximum ratings permitted are:</li> <li>US: TV-PG, PG</li> <li>Canada: TV-PG, PG, 8 ans+</li> </ul>		
h, or Young Adult to off and select a Child simplify the rating ction. To set more rictive ratings, select Youth tom.	<ul> <li>US: TV-Y, TV-G, G</li> <li>Canada: TV-Y, C, G</li> <li>Maximum ratings permitted are:         <ul> <li>US: TV-PG, PG</li> <li>Canada: TV-PG, PG, 8 ans+</li> </ul> </li> </ul>		
simplify the rating rating system ction. To set more ictive ratings, select Youth com.	<ul> <li>Canada: TV-Y, C, G</li> <li>Maximum ratings permitted are:</li> <li>US: TV-PG, PG</li> <li>Canada: TV-PG, PG, 8 ans+</li> </ul>		
ction. To set more ictive ratings, select Youth om.	h Maximum ratings permitted are: US: TV-PG, PG Canada: TV-PG, PG, 8 ans+		
om.	<ul> <li>US: TV-PG, PG</li> <li>Canada: TV-PG, PG, 8 ans+</li> </ul>		
	Canada: TV-PG, PG, 8 ans+		
Youn			
Youn	ng Adult Maximum ratings permitted are:		
	US: TV-14, PG-13		
	Canada: TV-14, 14+, 13 ans+		
or descriptions of Cust	om Select to set ratings manually.		
, Youth, and Young	US: See page 68 for details.		
ratings, see	Canada: See page 69 for details.		
s 68 and 69. Change For c Password	For changing your password. (see below)		

### To change the password

- 1 Select Change Password option when in the Parent menu using the joystick, and press (...).
- **2** Enter a new four-digit password using the 0-9 buttons.
- **3** Confirm the new password by entering it again.
- 4 Press MENU to exit the menu screen.

## Viewing Blocked Programs

You can view a blocked program by entering the password.

- 1 Press ENTER when tuned to a blocked program.
- **2** Enter your password using the 0-9 buttons.

Parental Control will be canceled temporarily until you turn your projection TV off.

Ϋ́ιf with Guid you s Youth help selec restri Cust

Ϋ́F Child Adult page The Parent menu includes the following options.


# Using Custom Rating Options

If you want to select the ratings to be blocked from Custom, follow the procedure below.

- Perform the steps 1 to 8 in "To select the rating" on page 62 to display the Parental Lock options.
- **2** Move the joystick up or down to select "Custom," and press 🕀.




3 Make sure that "Movie Ratings" is selected, and press ⊕.



4 Move the joystick up or down to select the rating to be blocked, and press ⊕.

The  $\bigcirc$  indicator automatically appears beside the selected rating and all "higher" ratings, indicating that the programs that match the ratings will be blocked.




To unblock a rating, select it by moving the joystick up or down, then press (+). The indicator (-) changes into "-" and all "lower" ratings are unblocked.

Move the joystick left, then down, to select "TV Rating" or "Program," and press (+).




**6** The "TV Rating" setting menu appears.



Move the joystick up or down to select the rating to be blocked, and press (+).


The 🖞 indicator automatically appears beside the selected rating and all "higher" ratings, indicating that the programs that match the ratings will be blocked.



To unblock a rating, select it by moving the joystick up or down, then press (+). The indicator (-) changes into "-" and all "lower" ratings are unblocked.

Some TV ratings have additional content ratings called "extenders." The extenders are defined as follows: D (sexually suggestive Dialog), FV (Fantasy Violence), L (Coarse Language), S (Sexual situations) and V (Violence). By setting the extenders, you can define additional viewing limits. All of the extenders included in the selected ratings will be blocked. If you wish to allow any of them to be viewed, go to step 8.

8 Move the joystick left or right to select the extender to be viewed, and press (-).



"-" appears beside the selected extender, indicating that the programs that match the extender can be viewed.

If you press  $\bigoplus$  again, a is displayed to show that the programs that match the extender will be blocked again.

**9** Repeat step 8 for other extenders.

All programs that match the ratings you select and higher, except for the extenders that were canceled, will be blocked.

**10** Press MENU to exit the menu screen.

### **US custom rating options**

If you selected U.S.A. as the country of residence on page 62, the Custom Rating Menu includes the following options. (If you selected Canada, see page 69.)

	Option	Descrip	tion
	Movie Rating	G	All children and General Audience.
naximum		PG	Parental Guidance suggested.
lity, the		PG-13	Parental Guidance for children under 13.
igs should		R	Restricted viewing, parental guidance is suggested for children under 17.
		NC-17 and X	No one 17 and under allowed.
e to block grams,	TV Rating	Age-Bas	sed Options
e that the	Block programs	TV-Y	All children.
ams may	by their rating,	TV-Y7	Directed to older children.
ergency itical	content or both	TV-G	General Audience.
ts, news,		TV-PG	Parental Guidance suggested.
,		TV-14	Parents Strongly cautioned.
s, religious		TV-MA	Mature Audience only.
veather.		Content	-Based Options
		FV	Fantasy Violence.
		D	Suggestive Dialogue.
		L	Strong Language.
		S	Sexual situations.
		V	Violence.
	Unrated	Block	Blocks all programs and movies that are broadcast
	Block programs		without a rating.
	or movies that	Allow	Allows programs and movies that are broadcast
	are broadcast		without a rating.
	without a rating		

The content ratings will increase depending on the level of the age-based rating. For example, a program with a TV-PG V (Violence) rating may contain moderate violence, while a TV-14 V (Violence) rating may contain more intense violence.

To ensure maximum blocking capability, the age-based ratings should be blocked.

If you choose to block unrated TV programs, please be aware that the following programs may be blocked: emergency broadcasts, political programs, sports, news, public service announcements, religious programs and weather.

## **Canadian custom rating options**

If you selected Canada as the country of residence on page 62, the Custom Rating Menu includes the following options. (If you selected U.S.A., see page 68.)

Option	Description	
English Rating	С	All children.
	C8+	Children 8 years and older.
	G	General programming.
	PG	Parental Guidance.
	14+	Viewers 14 and older.
	18+	Adult programming.
French Rating	G	General programming.
	8 ans+	Not recommended for young children.
	13 ans+	Not recommended for ages under 13.
	16 ans+	Not recommended for ages under 16.
	18 ans+	Programming restricted to adults.
JSA Rating	See "TV Rating" on page 68 for details.	

# **Programming the Remote Control**

The remote control is preset to operate Sony brand video equipment.

Sony Equipment	Switch Position on Remote Control	Programmable Code Number
Beta, ED Beta VCRs	AV1	303
8 mm VCR	AV2	302
VHS VCR	AV3	301
DVD Player	DVD	751

If you have video equipment other than Sony brand that you want to control with the projection TV's remote control, use the following procedures to program the remote control.

The equipment must have infrared (IR) remote capability in order to be used with the remote control.


From the "Manufacturer's Codes" listed on page 72, select the three-digit code number for the manufacturer's code for your component. If more than one code number is listed, start with the number listed first. Use the code number to complete the following procedure.


### To program a cable box or a satellite receiver

- 1 Open the panel of the remote control.
- **2** Press CODE SET inside the panel.
- **3** Close the panel and press SAT/CABLE (FUNCTON).
- 4 Enter the three-digit manufacturer's code number using the 0-9 buttons.
- **5** Press ENTER.


6

To check if the code number works, aim the projection TV's remote control at the component and press the green POWER button that corresponds with that component. If it responds, the programming is completed. If not, try using the other codes listed for that manufacturer.





#### 



### To program video equipment

- 1 Open the panel of the remote control.
- **2** Move the slide switch to the desired component type.
- **3** Press CODE SET inside the panel.

You must perform step 4 within 10 seconds of step 3, or you must start again from step 3.

- 4 Close the panel and enter the three-digit manufacturer's code number using the 0-9 buttons.
- **5** Press ENTER.
- **5** To check if the code number works, aim the projection TV's remote control at the component, open the panel, and press the green POWER button. If it responds, the programming is completed. If not, try using the other codes listed for that manufacturer.

### Tips

- □ If more than one code number is listed, try entering them one by one until you come to the correct code for your component.
- □ If you enter a new code number, the code number you previously entered at that setting is erased.
- In some rare cases, you may not be able to operate your component with the Sony remote control. In this case, use the component's own remote control unit.

### Manufacturer's Codes

### VCRs

VChS	
Manufacturer	Code
Sony	301
Admiral (M. Ward)	327
Aiwa	338, 344
Audio Dynamic	314, 337
Broksonic	319, 317
Canon	309, 308
Citizen	332
Craig	302, 332
Criterion	315
Curtis Mathes	304, 338, 309
Daewoo	341, 312, 309
DBX	314, 336, 337
Dimensia	304
Emerson	319, 320, 316, 317, 318, 341
Fisher	330, 335
Funai	338
General Electric	329, 304, 309
Go Video	322, 339, 340
Goldstar	332
Hitachi	306, 304, 305, 338
Instant Replay	309, 308
JC Penney	309, 305, 304, 330, 314, 336, 337
JVC	314, 336, 337, 345, 346, 347
Kenwood	314, 336, 332, 337
LXI (Sears)	332, 305, 330, 335, 338
Magnavox	308, 309, 310
Marantz	314, 336, 337
Marta	332
Memorex	309, 335

Manufacturer	Code
Minolta	305, 304
Mitsubishi/	323, 324, 325,
MGA	326
Multitech	325, 338, 321
NEC	314, 336, 337
Olympic	309, 308
Optimus	327
Panasonic	308, 309, 306, 307
Pentax	305, 304
Philco	308, 309
Philips	308, 309, 310
Pioneer	308
Quasar	308, 309, 306
RCA/	304, 305, 308,
PROSCAN	309, 311, 312,
	313, 310, 329
Realistic	309, 330, 328,
<u> </u>	335, 324, 338
Sansui	314
Samsung	322, 313, 321
Sanyo	330, 335
Scott	312, 313, 321, 335, 323, 324,
	325, 326 325, 326
Sharp	327, 328
Shintom	315
Signature 2000	338, 327
(M. Ward)	000,027
SV2000	338
Sylvania	308, 309, 338,
	310
Symphonic	338
Tashiro	332
Tatung	314, 336, 337
Teac	314, 336, 338,
	337
Technics	309, 308
Toshiba	312, 311

Manufacturer	Code
Wards	327, 328, 335,
	331, 332
Yamaha	314, 330, 336,
	337
Zenith	331

### **DVD Players**

Manufacturer	Code	
Sony	751	
Panasonic	753	
Pioneer	752	
RCA	755	
Toshiba	754	

### **Cable Boxes**

Manufacturer	Code
Hamlin/Regal	222, 223, 224,
	225, 226
Jerrold/G.I./	201, 202, 203,
Motorola	204, 205, 206,
	207, 208, 218
Oak	227, 228, 229
Panasonic	219, 220, 221
Pioneer	214, 215
Scientific	209, 210, 211
Atlanta	
Tocom	216, 217
Zenith	212, 213

## **Satellite Receivers**

Code
801
802
805
804
803
802, 808
806, 807

# **Operating Other Components with Your Projection TV Remote Control**

# **Operating a VCR**

Open the panel and move the slide switch to the AV input you coded for this device.

To Do This	Press
Turn on/off	green POWER button (inside the panel)
Change channels	CH +/-
Record	► and REC simultaneously
Play	
Stop	
Fast forward	<b>&gt;&gt;</b>
Rewind the tape	44
Pause	(press again to resume normal playback)
Search the picture	▶ or ◀◀ during playback
forward or backward	(release to resume normal playback)
Change input mode	Slide switch

## *Operating a DVD Player*

Open the panel and move the slide switch to the DVD input you coded for this device.

To Do This	Press
Turn on/off	green POWER button (inside the panel)
Play	
Stop	
Pause	II (press again to resume normal playback)
Step through different tracks of an audio disc	►► to step forward or ◄◄ to step backward
Step through different chapters of a video disc	CH+ to step forward or CH- to step backward
Display the DVD menu	DVD MENU
Display the menu (Setup)	MENU
Operate the DVD menu	<b>↑</b> , <b>↓</b> , <b>←</b> , <b>→</b> , ENTER

# *Operating a Cable Box*

To Do This	Press
Turn on/off	SAT/CABLE (POWER)
Select Cable Box	SAT/CABLE (FUNCTION)
Select a channel	0-9 buttons, ENTER
Change channels	CH +/-
Back to previous channel	JUMP

# *Operating a Satellite Receiver*

To Do This	Press
Turn on/off	SAT/CABLE (POWER)
Select Satellite Receiver	SAT/CABLE (FUNCTION)
Select a channel	0-9 buttons, ENTER
Change channels	CH +/-
Back to previous channel	JUMP
Display channel number	DISPLAY
Display DBS guide	GUIDE
Display DBS menu	MENU
Move highlight (cursor)	Joystick or arrows
Select item	$(\dot{\tau})$

# Troubleshooting

If, after reading these operating instructions, you have additional questions related to the use of your Sony television, please call our Customer Information Services Center at 1-800-222-SONY (7669) (U.S. residents only) or (416) 499-SONY (7669) (Canadian residents only).

Problem	Possible Remedies
No picture (screen not lit), no sound	<ul> <li>Make sure the projection TV's power cord is connected securely to the wall outlet</li> <li>Push the power button on the front of the projection TV.</li> <li>Check to see if the TV/VIDEO setting is correct: when watching TV, set to TV, and when watching connected equipment, set to VIDEO 1, 2, 3, 4, 5, 6 or 7.</li> <li>Try another channel. It could be station trouble.</li> <li>The Parental Control feature is activated (see "Using the Parent Menu" on page 62).</li> <li>If your projection TV does not turn on, and a red light keeps flashing, your</li> </ul>
	projection TV may need service. Call your local Sony Service Center.
Remote control does not operate	<ul> <li>Batteries could be weak. Replace the batteries.</li> <li>Press TV (FUNCTION) when operating your projection TV.</li> <li>Make sure the projection TV's power cord is connected securely to the wall outlet</li> <li>Locate the projection TV at least 3-4 feet away from fluorescent lights.</li> <li>Check the orientation of the batteries.</li> </ul>
Dark, poor or no picture (screen lit), good sound	<ul> <li>Adjust the Picture setting in the Video menu (see page 51).</li> <li>Adjust the Brightness setting in the Video menu (see page 51).</li> <li>Check antenna/cable connections.</li> <li>Adjust the convergence again using FLASH FOCUS (see "Adjusting the Convergence Automatically – FLASH FOCUS™ –" on page 33).</li> </ul>
Good picture, no sound	<ul> <li>Press MUTING so that "MUTING" disappears from the screen (see page 36).</li> <li>Make sure Speaker is set to On in the Audio menu (see page 54).</li> <li>Check the MTS setting in the Audio menu (see "MTS" on page 53).</li> </ul>
Cannot receive digital channels (when a DTV receiver is connected)	<ul> <li>Check the connections between the DTV receiver and the projection TV (see page 28).</li> <li>Check your local listings to find out if you can receive digital broadcasts in your area.</li> </ul>
Cannot receive upper channels (UHF) when using an antenna	<ul> <li>Change Cable to Off (see page 55).</li> <li>Use Auto Program in the Channel menu to add receivable channels that are not presently in TV memory (see page 56).</li> </ul>
No color	Adjust the Color settings in the Video menu (see page 51).
Only snow and noise appear on the screen	<ul> <li>Check the Cable setting in the Channel menu (see "Cable" on page 55).</li> <li>Check the antenna/cable connections.</li> <li>Make sure the channel is broadcasting programs.</li> <li>Press ANT to change the input mode (see page 39).</li> </ul>
Dotted lines or stripes	<ul> <li>Adjust the antenna.</li> <li>Move the projection TV away from noise sources such as cars, neon signs, or hair dryers.</li> </ul>

Problem	Possible Remedies
Projection TV is fixed to one channel	Use Auto Program in the Channel menu to add receivable channels that are not presently in TV memory (see page 56).
	Check your Channel Fix settings (see page 56).
Double images or ghosts	Use a highly directional outdoor antenna or a cable (when the problem is caused by reflections from nearby mountains or tall buildings).
Cannot operate menu	<ul> <li>If the item you want to choose appears in gray, you cannot select it.</li> <li>Turn the projection TV's power off and on again.</li> </ul>
Cannot receive any channels when using cable TV	<ul> <li>Use Auto Program in the Channel menu to add receivable channels that are not presently in TV memory (see page 56).</li> <li>Check your cable settings.</li> <li>Make sure Cable is set to On in the Channel menu (see page 55).</li> </ul>
Cannot gain enough volume when using a cable box	Increase the volume of the cable box using the cable box's remote control. Then press TV (FUNCTION) and adjust the projection TV's volume.
The TV does not display all available cable channels	<ul> <li>Make sure Cable is set to On in the Channel menu (see "Cable" on page 55).</li> <li>Use Auto Program in the Channel menu to add receivable TV channels that are not presently in TV memory (see page 56).</li> </ul>
Cannot receive channels	Use Auto Program in the Channel menu to add receivable TV channels that are
Unable to select a channel	not presently in TV memory (see page 56).
Lost password	<ul> <li>In the password screen (see page 62), enter the following master password: 4357. The master password clears your previous password; it cannot be used to temporarily unblock channels.</li> </ul>
Cannot change channels with the remote control	<ul> <li>Be sure you have not inadvertently switched your projection TV from channel 3 or 4 setting if you are using another device to change channels.</li> <li>If you are using another device to control channels, be sure the "function" button for that device has been pressed, or the slide switch is set correctly. For example, if you are using your cable to control channels, be sure to press SAT/CABLE.</li> </ul>
Cannot cycle through the other video equipment connected to the projection TV	Be sure the Video Label feature has not been set to Skip (see page 61).
There is a black box on the screen	You have selected a text option in the Setup menu and no text is available. (see page 60 to reset Setup selections) To turn this feature off, select Off in the Caption Vision option. If you were trying to get closed captioning, select CC1 instead of Text 1-4.
There is no twin picture or it is just static	<ul> <li>Be sure your twin picture is set to a video source/channel that has a program airing.</li> <li>You may be tuned to a video input with nothing connected to it. Try cycling through your video inputs using TV/VIDEO.</li> <li>Twin View is not set to receive a signal from the AUX input. If you have connected a VCR, DVD player or satellite receiver to the AUX input on the projection TV, it will not show in the second picture.</li> </ul>

Problem	Pos	Possible Remedies		
You get the same program in the window picture as in the main picture		Both may be set to the same channel. Try changing channels in either the main picture or the window picture. You may be running all your channels through a cable box. The cable box will only unscramble one signal at a time, so you cannot use the Twin View feature. If possible, run a direct cable to your projection TV's VHF/UHF input (this will only work if your cable system provides an unscrambled signal.)		
You cannot get anything but TV channels in your second picture		Be sure the video label has not been set to skip your video inputs. See the Setup menu on page 60.		
Favorite Channel does not display your choices		Verify that Favorite Channel is set to Manual in the Channel menu (see "Favorite Channel" on page 55).		
Some video sources do not appear when you press TV/ VIDEO		Ensure that Video Label is not set to SKIP (see "Video Label" on page 61).		
Digital cable box does not work		Be sure that you have not connected the digital cable box to the TV's TO CONVERTER jack. This jack is not compatible with digital cable boxes. If you are connecting a VCR and digital cable box, you must use a special bi- directional splitter that is designed to work with your digital cable box. Contact your cable provider for details.		

# **Specifications**

Projection System	3 picture tubes, 3 lenses, horizontal in-line system			
Picture Tube	7-inch high-brightness monochrome tubes (6.3 raster size), with optical			
	coupling and liquid cooling system			
Projection Lenses	High performance, large			
	diameter hybrid lens F1.1			
Antenna	75 ohm external terminal for VHF/UHF			
Television System	NTSC, American TV Standard			
Screen Size (measured diagonally)	46 inches (116.84 cm) (KP-46WT510)			
	51 inches (129.54 cm) (KP-51WS510)			
	57 inches (144.78 cm) (KP-57WS510)			
	65 inches (165 cm) (KP-	65WS510)		
Channel Coverage				
VHF	2-13			
UHF	14-69			
CATV	1-125			
Power Requirements	120V, 60 Hz			
Number of Inputs / Outputs				
DVI-HDTV		1 terminal, 3.3V T.M.D.S., 50 ohms		
		The DVI input terminal is compliant with the		
		EIA-861 standard and is not intended for use		
		with personal computers.		
Video (IN)	4	1 Vp-p, 75 ohms unbalanced, sync negative		
S Video (IN)	3	Y: 1 Vp-p, 75 ohms unbalanced, sync negative		
		C: 0.286 Vp-p (Burst signal), 75 ohms		
Audio (IN)	6	500 mVrms (100% modulation)		
		Impedance: 47 kiloohms		
AUDIO (VAR/FIX)	1	500 mVrms at the maximum volume setting		
		(Variable)		
		500 mVrms (Fixed)		
		Impedance (output): 1 kiloohm		
TV Out	1	Video: 1 Vp-p 75 ohms unbalanced, Sync		
		negative		
		Audio: 500 mVrms (100% modulation)		
		Impedance (output): 1 kiloohm		
CONTROL S (IN/OUT)	1	minijacks		
Component Video Input	$2(Y, P_B, P_R)$	Y: 1.0 Vp-p, 75 ohms unbalanced, sync		
Lomponone : nuco mpar	- (-, - B, - K)	negative		
		P <sub>B</sub> : 0.7 Vp-p, 75 ohms		
		P <sub>B</sub> : 0.7 Vp-p, 75 ohms		
RF Inputs	2	R. 0.7 v p-p, 75 onnis		
Converter	1			
Speaker Output	$20 \text{ W} \times 2$			

(Continued)

Dimensions $(W \times H \times D)$	$42^{3}/4 \times 40 \times 24$ inches (1,086 × 1,017 × 609 mm) (KP-46WT510)		
	$47 \times 53^{1/8} \times 25^{5/8}$ inches (1,194 × 1,350 × 650 mm) (KP-51WS510)		
	$52 \frac{1}{4} \times 54 \frac{1}{4} \times 27 \frac{1}{4}$ inches (1,326 × 1,377 × 690 mm) (KP-57WS510)		
	$60^{3}/4 \times 57^{3}/4 \times 29^{1}/2$ inches (1,542 × 1,466 × 750 mm) (KP-65WS510)		
Mass	135 lb (61.3 kg) (KP-46WT510)		
	172 lb (78.2 kg) (KP-51WS510)		
	195 lb (88.6 kg) (KP-57WS510)		
	300 lb (136 kg) (KP-65WS510)		
Power Consumption			
In Use	230 W		
In Standby	Under 1 W		
Supplied Accessories			
Remote Control	RM-Y909		
AA (R6) Batteries	2 supplied for remote control		
Optional Accessories			
AV Cable	VMC-810/820/830 HG		
Audio Cable	RKC-515HG		
Control S Cable	RK-G69HG		
Component Video Cable	VMC-10/30 HG		
AV Receiver	STR-V555ES or equivalent		
TV Stand	SU-46WT5		

Design and specifications are subject to change without notice.

# Index

# A

Activating a Twin View screen Adding channels to the channel list Adjusting audio, Steady Sound ANT button Antenna, connecting Audio menu **50**, Audio receiver, connecting Audio/Video cable Auto Program (channel setup) **32**, AV receiver, connecting to TV OUT **15**,

## В

Balance, adjusting Bass, adjusting Batteries, inserting in remote Bilingual audio Brightness, adjusting

# C

Cable connecting 16-18 setting ON/OFF 55 with VCR, connecting 19-20 Cable box connecting with VCR 20 using with TV remote control 74 Camcorder, connecting 29 Caption Vision 60 CATV. See cable. Channel list, adding channels 56 Channel menu 50, 55 Channel Skip/Add 56 Channels Auto Program 56 creating labels 56 setting up 32 CineMotion, DRC 37, 52 Closed caption modes 60 CODE SET button 38 Color temperature, adjusting 51 Color, adjusting 51 Connecting Audio receiver 25 AV receiver 30 Cable box 16–21 Cable or antenna **16** Camcorder 29 Digital TV Receiver 28 DVD player 26, 27 Satellite receiver 23, 24 VCR 20-22, 24 Connector Types 12

Contents of box **10** CONTROL S 31 Convergence, adjusting automatically 33 Convergence, adjusting manually **33** Π Daylight saving 59 Digital Reality Creation 52 Digital TV connecting 28 watching **41** Digital TV program 41 Digital TV receiver, connecting 28 DISPLAY button 36 Display, turning off 36 DRC (Digital Reality Creation) Mode, described 8 DRC/ CINEMOTION button 37 DVD MENU button 38 DVD player using with TV remote control 73 with A/V connectors, connecting 27 with component video connectors, connecting 26

# E

Effect OFF **53** Simulated TruSurround Enlarging pictures, in Twin View Extended Data Service

## F

Favorite Channel auto 55 described 8 manual 55 setting up 55 using 42 FAVORITES button 36 Features 8 Flash Focus described 9 performing 33 FREEZE button 36 Freeze, using 39, 46 Front Panel Controls 13 FUNCTION buttons (WHITE) 37 н Hookups **16–31** Hue, adjusting 51 Inputs, labeling **61** Installation of the projection TV 16-31

JUMP button 36

(Continued)

# 80

### Jump, using 39

# L

Label channels 56 video inputs 61

### М

MENU button 37 Menus Audio 50, 53 Channel 50, 55 Setup 50, 60 Timer 50, 59 Video 50, 51 Wide 50, 57 MODE Movie 40, 51 Pro 40, 51 Standard 40, 51 Vivid 40, 51 MTS/SAP button 40 MTS/SAP, using 53 Muting, using 39

## Ρ

Parental control, described 8 Password, changing 64 PIC MODE button 36 Picture contrast, adjusting **51** Picture size, adjusting in Twin View 45 POWER button 38 POWER buttons (GREEN) 37 Presetting channels 32, 56 Problems, troubleshooting 75

# R

Ratings setting 62-67 viewing blocked programs 64 Rear panel controls and connections 14, 15 Remote control buttons inside panel 38 Function of buttons 39, 40 inserting batteries 10 programming 70-72 Remote control, operating other components with Cable box 74 DVD player 73 Satellite receiver 74 VCR 73 Removing channels from the channel list 56 RESET button 36 Resetting Audio options 53 Timer options 59 Video options 51

# S

S Video cable 12 SAT/CABLE function button 37 SAT/CABLE power button 37 Satellite receiver connecting 23 using with TV remote control 74 Setting up channels 32, 56 Setup menu 50, 60 Sharpness, adjusting 51 SLEEP button 36 Sleep, using 39 Specifications 78-79 Steady Sound adjusting 53 described 8 Surround sound **53** SYSTEM OFF button 38

# Т

Time set current 59 set daylight saving 59 Timer menu 50, 59 Timer setting 59 Treble, adjusting 53 Troubleshooting 75–77 TV function button 37 TV power button **37** TV/VIDEO button 37 Twin View<sup>TM</sup> activating a picture 43 described 8 using 43

#### V VCR

connecting two, for tape editing 22 using with TV remote control 73 with cable box, connecting 20 with cable, connecting 19 with satellite receiver, connecting 24 Video inputs, labeling 61 Video menu 50, 51 Video Modes, selecting 51 Viewing area, recommended 11 VOL +/- button 36, 39 Z Zoom feature, with Twin View 45

http://www.world.sony.com/