

Quackenbush®

136SC-B-118 SELF-COLLETING DRILLS



Houston Operation
7007 Pinemont
Houston, TX 77040

Recoules Operation
Zone industrielle - B.P. 28
Avenue Maurice Chevalier
77831 Ozoir-la-Ferriere Cedex France


Safety Recommendations

For your safety and the safety of others, read and understand the safety recommendations and operating instructions before operating any drill motor.

Always wear protective equipment:



For additional information on eye protection, read the latest edition of ANSI Z87.1, Occupational and Educational Eye and Face Protection. This standard is available from the American National Standards Institute, Inc., 11 West 42nd Street, New York, N.Y. 10036.



Hearing protection is recommended in high noise areas (above 85dBA). Close proximity of additional tools, reflective surfaces, process noises, etc., can contribute substantially to the sound level experienced by the operator.




Follow good machine shop practices. Rotating shafts and moving components entangle and entrap, and may result in serious injuries. Never wear long hair, loose-fitting clothes, gloves, ties, or jewelry when working with or near a drill of any type.

Quackenbush drills are designed to operate on 90psig (6.2 bar) maximum air pressure using the proper hose. Excessive air pressure increases the loads and stresses on tool parts and drills, and may result in breakage. The installation of a filter-regulator-lubricator in the air supply line ahead of the tool is highly recommended.

CAUTION

- Before the tool is connected to the air supply, the throttle should be checked for proper operation (i.e., throttle valve moves freely and returns to closed position).
- Before removing a tool from service or changing drill bits, make sure the air line is shut off and drained of air. This will prevent the tool from operating if the throttle is accidentally engaged.
- Cutting tools used with these drill motors are sharp. Handle them carefully to avoid injury.
- The collet and mandrel must be inserted into a properly sized pre-drilled hole before starting the tool. An improperly sized pre-drilled hole prevents the mandrel from engaging the collet and could result in slippage of the tool. An improperly selected collet and mandrel can also result in slippage of the tool.



Drilling or other use of this tool may produce hazardous fumes and/or dust. To avoid adverse health effects utilize adequate ventilation and/or a respirator. Read the material safety data sheet of any cutting fluids or materials involved in the drilling process.


CAUTION

Some non-ferrous metal chips (or dusts) are combustible. Examples: Aluminum, magnesium, Titanium, and Zirconium. See the material safety data sheets for combustibility of materials drilled. Never collect spark generating material with combustible material. Examples: Collecting both steel and aluminum or steel and titanium.



Quackenbush drills are often used with lubricant or cooling systems which must be properly maintained to avoid leakage. Failure to do so can result in serious injuries from slipping on oily surfaces.

Safety Recommendations




Due to the number and variety of tooling applications, the user's methods engineering departments, ect., must consider any hazards that may be associated with each specific application of this product and provide adequate operator protection from inadvertent contact with any moving components. The clamping and feed mechanisms of self-colleting drill motors are exposed for visibility and can move when the air supply is connected or disconnected. To avoid injury, keep fingers and hands away from these areas when handling or operating this tool.



Some individuals are susceptible to disorders of the hands and arms when exposed to vibration and/or tasks which involve repetitive work motions. Those individuals predisposed to vascular or circulatory problems may be particularly susceptible. Cumulative trauma disorders such as carpal tunnel syndrome and tendinitis can be caused or aggravated by repetitious, forceful exertions of the hands and arms. These disorders develop gradually over periods of weeks, months, and years. Tasks should be performed in such a manner that the wrists are maintained in a neutral position, which is not flexed, hyperextended, or turned side to side. Stressful postures should be avoided and can be controlled through tool selection and work location.

Any tool operator should be aware of the following warning signs and symptoms so that a problem can be addressed before it becomes a debilitating injury. Any user suffering from prolonged symptoms of tingling, numbness, blanching of fingers, clumsiness or weakened grip, inability to hold objects, nocturnal pain in the hand, or any other disorder of the shoulders, arms, wrists, or fingers should notify their employer so that a review of what steps might be taken to prevent further occurrences. These steps might include but are not limited to, repositioning the workpiece or redesigning the workstation, reassigning tool users to other jobs, rotating jobs, changing worker pace, and/or changing the type of tool used so as to minimize stress on the operator. Some tasks may require more than one type of tool to obtain the optimum operator/ tool/ task relationship.




The following recommendations will help reduce or moderate the effects of repetitive work motions. The operator of any drill should:

- Use a minimum hand grip force consistent with proper control and safe operation
- Keep body and hands warm and dry
- Avoid anything that inhibits blood circulation
 - Smoking Tobacco
 - Cold Temperatures
 - Certain Drugs
- Avoid awkward postures
- Keep wrists as straight as possible
- Interrupt work, activities, or rotate jobs to provide periods free from repetitive work motions.


Index

Safety Recommendations	2-3	136SC-B Q-Matic Drill Assy and Parts List	26-31
Safety Labels	4	400 RPM Gear Set Assembly	32
Index	5	950 RPM Gear Set Assembly	32
Major Tool Components	5	2100 RPM Gear Set Assembly	32
Introduction and General Information	6	3100 RPM Gear Set Assembly	32
Air and Hydraulic System Diagrams	7-10	6000 RPM Gear Set Assembly	32
Backhead Disassembly	11	7800 RPM Gear Set Assembly	33
Spindle Adjustment Disassembly	12	11500 RPM Gear Set Assembly	33
Quill and Pressure Foot Removal	14-15	22500 RPM Gear Set Assembly	33
Feed Clamp Disassembly	15-18		
Dwell Valve Disassembly	18	Accessories	
Disassembly of Feed Rate Adjustment Valve	19	Template Boss	34
Unclamp Check Valve Disassembly	20	Jig Collet Foot Attachment	34
Retract and Dwell Valve Disassembly	21	High Curvature Pad	34
Hydraulic Fluid Reservoir Disassembly	22	Booster Pump Assembly	35
Trigger Disassembly	23	Mist Lubricator Assembly	35-38
Pilot Valve Disassembly	24	Trouble Shooting	39
Filling and Bleeding the Hydraulic System	25	NDSJC Jig Collet Foot Kit	40
Tool Adjustments	25	DSJC Jig Collet Foot Kit	41
		Maintenance Kit	42
		Piping Layout for Compressed Air Lines	43

Major Tool Components



Specials Tools



Introduction and General Information

The 136SC-B-118 is an air operated, hydraulically controlled tool that automatically clamps to the material, drills and countersinks close tolerance holes in one operation. This drill will produce high quality holes in aluminum, steel, titanium and petroleum hybrid materials primarily found in the aircraft/aerospace industries. This drill motor has been designed using state-of-the-art technology that provides maximum power, minimum weight and the highest degree of accuracy for demanding hole preparation requirements.

Technical Data

Feed Stroke: Feed stroke of the 136SC-B-118 is 1.18 inches to drill and countersink in 1 inch stacked material. The feed stroke is unaffected by the collet stroke.

Collet Stroke: The 136SC-B-118 will clamp throughout its .56 inch stroke. Collet stroke is unaffected by feed stroke. **Spindle Adjustment:** The spindle adjustment of .312 inch allows for drill length variations. See Spindle Adjustment information.

Countersink Depth Control: A micrometer adjustment provides for countersink stop repeatability within .001 inch.

Cutter Sizes: The 136SC-B-118 will accommodate .312 diameter drills without countersink and .250 diameter drills with .505 countersink diameter.

Feed Rate: An adjustable drill feed rate mechanism enables the 136SC-B-118 to drill from 5 seconds per inch to 1 minute per inch. See Feed Rate Adjustment information.

Cutter to Collet Spacing: The cutter to collet distance is adjustable between .500 inch minimum to 2.75 inch maximum.

Coolant: The 136SC-B-118 has a drill point coolant port in the pressure foot. A coolant mist lubricator is available (See Accessories).

Air Motor: The air motor develops .88 horsepower when supplied with air at 90 p.s.i.

Air Consumption: Air consumption of the 136SC-B-118 is 35 c.f.m. at 90 p.s.i. dynamic.

Weight: Tool weight with the steel pressure foot is 7.0 pounds.

Spindle Speeds: Eight geared spindle speeds are available: 400, 950, 2100, 3100, 6000, 7800, 11500, and 22500 RPM. Any gear set can be used with the 136SC-B-118 tool.

Trigger Lock: A trigger lock is provided which allows the tool to be locked in the "Operate" position. With the lock activated, the tool will run through the clamp, feed and retract cycles, but it will not unclamp or stop the motor until the trigger lock is manually released.

Tool Start-Up

The 136SC-B-118 drill is shipped from the factory equipped to the customer's specifications: spindle RPM, spindle to accommodate cutter type desired, pressure foot type, collet guide to accommodate collet desired and optional booster pump (if required).


After unpacking, examine the customer-specified equipment on this tool to verify type and speed of components.

Attach air line to 3/8-18 NPT inlet bushing. If quick disconnect fittings are used, 3/8 in. ID are minimum. The 136SC-B-118 drill requires a supply of clean 90-100 PSI air. Air consumption is 35 CFM at 90 PSI. The use of the in-line lubricator will provide the proper lubrication for the air motor and will significantly increase the tool life expectancy. Because O-rings are extensively used to seal systems within the tool, the elimination of foreign particles and other contaminants will reduce the possibility of damage to these parts. Always inspect O-rings for damage or wear and replace as required. The use of silicone O-ring lubricant is strongly recommended during reassembly. The addition of oil in the air line will also increase motor and valve life as well as the life of the O-rings.


136SC-B-118 DRILL MOTOR SPECIFICATIONS

WEIGHT	7.0 LBS. MAX. W/ALUMINUM FOOT
AIR CONSUMPTION	35 C.F.M. @ 90 P.S.I. DYNAMIC
HORSE POWER	APPROX. .88 @ 90 P.S.I.
O/A LENGTH	10.12 IN. MAX WITH SPINDLE ADJUST AT FULL EXTENSION
STROKE	1.18 IN. (DRILL & C/SINK 1 IN. STACK)
COLLET STROKE	.56 IN. (NO LOSS OF FEED STROKE)
COUNTERSINK	COUNTERSINK STOP REPEATS WITHIN .001 IN.
FEED RATE	MIN. 5 SEC. PER INCH, MAX 1 MIN. PER INCH
SPINDLE SPEEDS	400, 950, 2100, 3100, 6000, 7800, 11,500 & 22,500 RPM
DRILLING THRUST	130 LBS. MAX. (UNREGULATED AIR)
CLAMP FORCE	230 LBS. START CLAMP FORCE (UNREGULATED AIR)
SPINDLE ADJUSTMENT	.312 IN. ADJUSTMENT TO ALLOW FOR DRILL LENGTH VARIATIONS
MAX. DRILL SIZES	.312 (NO C/SINK), .250(.505 C/SINK DIA.)
COLLET FOOT SPACING	.500 IN. MIN.-2.75 IN. MAX.
SPINDLE	.375 IN. DIA. W/1/4-28 THR'D FOR I.D. THREAD TYPE DRILLS OR 1/4-28 MALE THD. DRILLS
COOLANT	AIR BLAST PORT & DRILL POINT PORT IN TEMPLATE STD., COOLANT MIST LUBRICATOR AVAILABLE.


1. DIAGRAM OF AIR AND HYDRAULIC SYSTEMS IN STANDBY CONDITION. Trigger released, compressed air attached, collet unclamped, cutter fully retracted, air motor stopped.



2. DIAGRAM OF AIR AND HYDRAULIC SYSTEMS AT FULL COLLET STROKE AND START OF CUTTER FEED. Trigger depressed, pilot and unclamp check valves shift, air motor starts, collet first clamps fully, then cutter starts feeding and continues to feed until pre-set depth has been reached. (See Figure 3).



3. DIAGRAM OF AIR AND HYDRAULIC SYSTEMS AT PRE-SET CUTTER DEPTH AND START OF RETRACT. Trigger depressed, air motor running, collet clamped, cutter continues feeding until depth control adjustment covers retract and dwell port, shifting retract and dwell valve, initiating rapid cutter retract.



4. DIAGRAM OF AIR AND HYDRAULIC SYSTEMS AT COMPLETION OF RETRACT STROKE. Trigger depressed, collet clamped, air motor running.

NOTE: Release trigger causes shifting of pilot, clamp-unclamp and retract valves, collet unclamps and air motor stops (See Figure 1).




FIGURE 4

I. Backhead Disassembly

WARNING: Disconnect air-supply before servicing.
Clamp mechanism moves when connecting or removing air supply.
Keep hands and fingers away from clamping and feed mechanism.



1. Remove four 1/4"-20 cap screws.



2. Pull backhead with spindle attached straight out of tool.

NOTE: Four O-rings in recessed cavities should remain in place in backhead mating surface.

II. Air Motor Disassembly

WARNING: Disconnect air-supply before servicing.
Clamp mechanism moves when connecting or removing air supply.
Keep hands and fingers away from clamping and feed mechanism.



1. Remove planet gear assembly and internal gear.



2. Remove two button head screws which hold exhaust cover in place, then remove the muffer plates and muffer pads.



3. Compress and remove beveled retaining ring. Beveled edge faces out.



4. Tap housing gently on surface to remove air motor. The complete motor includes rotor with blades, cylinder, and front and rear bearing plates.

NOTE: Exhaust slots on cylinder should be indexed approx. 180° from muffler)

III. Spindle Adjustment Disassembly

WARNING: Disconnect air-supply before servicing.
Clamp mechanism moves when connecting or removing air supply.
Keep hands and fingers away from clamping and feed mechanism.

NOTE: Spindle adjustment disassembly is necessary only to service bearings and to change spindles. Otherwise, the backhead assembly can be removed intact to service other internal assemblies, such as the air motor.



1. Use suitable spanner wrench to unscrew bearing retaining nut.



2. Use Allen wrench to loosen and remove tapered locking screw in rear housing.



3. Unscrew spindle adjustment nut and remove nut with spindle.



4. Tap spindle adjustment nut to remove spindle and duplex ball bearings.
5. Unscrew bearing lock nut and bearing lock nut washer.
6. To remove spindle gear, remove retaining ring and slide gear off spindle.

NOTE: To reassemble, 1st duplex ball bearing must seat firmly on spindle shoulder. Add 2nd ball bearing back-to-back with part number on bearings facing away from each other. Then add bearing lock washer and bearing lock nut. Tighten until inner race seats solid. Screw in bearing adjustment nut and bearing retaining nut and tighten until nut seats solid.

NOTE: Bearing lock nut and bearing retaining nut must be seated solidly to prevent end play in spindle and cutter.

IV. Quill & Pressure Foot Removal

WARNING: Disconnect air-supply before servicing. Clamp mechanism moves when connecting or removing air supply. Keep hands and fingers away from clamping and feed mechanism.



1. Remove Pressure foot nut with appropriate spanner wrench or with Special Pressure foot nut tool (Part No. 623515).



2. Unscrew depth stop from quill.


V. How To Change Quills

WARNING: Disconnect air-supply before servicing. Clamp mechanism moves when connecting or removing air supply. Keep hands and fingers away from clamping and feed mechanism.



1. Follow Quill and Pressure Foot disassembly instructions.

NOTE: If tool is equipped with template boss, remove socket cap screw and remove template boss.



2. Remove Foot & Quill by pulling foot forward from tool housing & feed sleeve.




Remove depth stop with tool #623647.

VI. Feed Clamp Disassembly


WARNING: Disconnect air-supply before servicing.
Clamp mechanism moves when connecting or removing air supply.
Keep hands and fingers away from clamping and feed mechanism.

1. Follow instructions in Step 4 above to remove quill and pressure foot.
2. Remove retainer ring 845733 and clevis linkage pin 625696.
3. Remove lift lever pin 623509 and remove bushing assembly 621519.






4. Unscrew pull rod bushing 625698.




4a. With air supply disconnected, Push in on pull rod 625697 and remove lift finger 625700.



5. Remove bleed port screw from side of tool. Remove $\frac{1}{8}$ " steel ball from bleed port with small magnet. Bleed hydraulic fluid by pulling and pushing feed sleeve. Fluid will run out of opening.



6. Insert rod through end of feed sleeve and push to remove rear bulkhead with clamp/ unclamp piston and collet spring assembly.
NOTE: Examine O-ring on rear bulkhead and replace if damaged.



7. Compress front bulkhead retaining ring, then pull on 2 screws inserted in front bleed port holes and remove front bulkhead.

NOTE: During reassembly, retaining ring grooves should be liberally packed with O-ring lubricant to prevent damage to inner O-rings while slipping past grooves on sleeve. While compressing retaining ring, tap front bulkhead flush with front of handle.



9. To remove feed piston, carefully apply short air blast to side bleed hole while holding feed sleeve. Drain remaining hydraulic fluid from cavity.




8. Expand and remove retaining ring on feed sleeve.




10. Expand and remove retaining ring from feed sleeve.



11. Feed sleeve and rear feed piston are removed by applying pressure on feed sleeve toward rear of tool.



12. Compress and remove large retaining ring located at the rear of the tool from large diameter bore of cavity. Be careful not to score or scratch inner bore.



13. Screw threaded end of special Bulkhead Removal Tool (Part No. 623520) into threaded hole in air/hydraulic bulkhead and pull to remove from rear of tool.

NOTE: The O-rings on the outer diameter of the air/hydraulic bulkhead must pass by two retaining ring grooves. Before reinserting the bulkhead, pack the retaining ring grooves with O-ring lubricant to prevent O-ring damage.

NOTE: A small orifice on the right side of the tool housing is provided to check the condition of the O-rings on the air/hydraulic bulkhead. Air seepage indicates a damaged O-ring on the air side; hydraulic fluid seepage indicates O-ring damage on the fluid side.

NOTE: One large retaining ring will remain in the inner bore. It should not be necessary to remove this ring.

VII. Dwell Valve Disassembly

WARNING: Disconnect air-supply before servicing.
Clamp mechanism moves when connecting or removing air supply.
Keep hands and fingers away from clamping and feed mechanism.



1. Remove needle valve from housing with Allen wrench.

VIII. Disassembly of Feed Rate Adjustment Valve

WARNING:

Disconnect air-supply before servicing.

Clamp mechanism moves when connecting or removing air supply.
Keep hands and fingers away from clamping and feed mechanism.



1. Remove valve retainer and spring.



2. Remove feed control valve assembly with threaded rod (7/16-20).



3. Remove pipe plug from rear of feed adjust boss and push forward to remove filter and O-ring.

IX. Unclamp Check Valve Disassembly

WARNING: Disconnect air-supply before servicing.
Clamp mechanism moves when connecting or removing air supply.
Keep hands and fingers away from clamping and feed mechanism.



1. Remove retaining ring and valve retaining plug. Remove plug using 4-40 screw if necessary.



2. Lift spool and spring out of cavity and place in clean area.




3. Carefully insert soft metal hook into hole in valve sleeve and lift out with pliers applied to wire. Be careful not to score or scratch the inside diameter of the sleeve. Carefully inspect O-rings for damage and replace if necessary.

X. Retract and Dwell Valve Disassembly

WARNING: Disconnect air-supply before servicing.
Clamp mechanism moves when connecting or removing air supply.
Keep hands and fingers away from clamping and feed mechanism.




1. Remove retaining ring on valve retaining plug. Remove valve retaining plug using 4-40 screw if necessary.



2. Lift out latching spool.



3. Remove retract and dwell valve spool and spring.



4. Carefully insert soft metal hook into hole in sleeve and lift out with pliers applied to the wire. Be careful not to score or scratch the inside diameter of the sleeve. Carefully inspect O-rings for damage and replace if necessary.

NOTE: Valve spool-to-sleeve is a hand-lapped fit. Exercise extreme caution against scratching and scoring when handling. Always place components in a clean, dry area.


5. When reassembling, apply O-ring lubricant liberally to prevent damage to O-rings as they are pushed past ports on the inside cavity.

NOTE: Spring on end of spool should be retained in hole in end of spool with grease during reassembly.

XI. Hydraulic Fluid Reservoir Disassembly

WARNING: Disconnect air-supply before servicing.

Clamp mechanism moves when connecting or removing air supply.
Keep hands and fingers away from clamping and feed mechanism.



1. Unscrew hex head reservoir plug.



2. Remove set screw



3. With suitable driver, drive out oil indicator guide, piston and rod assembly through the rear of the housing. Caution: Do not score or scratch inside of bore with driver.




4. When reassembling, the oil indicator guide must be inserted from the rear of the tool, and the indicator piston and rod assembly must be inserted from the front of the tool as shown. Failure to follow reassembly instructions will result in damaged O-rings.

NOTE: Inspect O-rings for damage and replace if necessary.

XII. Trigger Disassembly

WARNING: Disconnect air-supply before servicing.
Clamp mechanism moves when connecting or removing air supply.
Keep hands and fingers away from clamping and feed mechanism.



1. Use special Trigger Lock Assembly Tool (Part No. 623015) to remove trigger lock by unscrewing from handle.



2. Loosen and remove set screw in trigger and remove trigger.



3. Remove the retaining ring from the trigger bore.



4. Lift out trigger spool and sleeve.
5. Remove spring from trigger cavity.

XIII. Pilot Valve Disassembly

WARNING: Disconnect air-supply before servicing.
Clamp mechanism moves when connecting or removing air supply.
Keep hands and fingers away from clamping and feed mechanism.



1. Remove inlet bushing.



2. Remove spring and spacer.



3 Insert long 8-32 screw into tapped hole provided in base of pilot spool and lift out.
NOTE: Be careful not to bend pilot spool when removing or inserting. A bent spool will cause the tool to malfunction and will require spool replacement.

Filling & Bleeding the Hydraulic System

The 136-118 drill hydraulic system will periodically require filling and/or bleeding. If the oil level indicator is near the "Add Fluid" mark, replenish the system using Mobil D.T.E. light or equivalent hydraulic fluid.

FILLING


Connect the hydraulic fluid source to the tool using filler fitting number 622871 or the new 624235/624942 filler assembly. The fluid supply pressure should be 100-150 P.S.I. so the tool's internal check valve can be opened. Start the hydraulic fluid source and fill the tool until the oil level indicator shows full. Bleeding the tool should not be necessary if air has not been introduced into the system. Disconnect the tool from the fluid source and return to service.

BLEEDING

Remove the 10-32 set screw and the .125 diameter steel ball from the bleed port. This bleed port is located on the lower left hand side of the main housing (see section C-C items 59 and 101 for more detail). Open feed control valve to the fastest setting. This allows the fluid to flow unrestricted. Set the depth stop to the longest stroke. This must be done to completely bleed the air from the hydraulic fluid. Attach the filler fitting 622871 or the new 624235/624942 filler assembly to the hydraulic fill fitting. Thread the return stem part number 624235 into the 10-32 bleed port and hand tighten. Attach air line to tool and turn on air supply. Turn on hydraulic pump to circulate fluid. With the hydraulic

WARNING: Disconnect air-supply before servicing. Clamp mechanism moves when connecting or removing air supply. Keep hands and fingers away from clamping and feed mechanism.

fluid circulating through the tool, depress the trigger and cycle the tool several times to remove any air from within the tool. Visually check the clear return line for any air bubbles. When no bubbles are seen disconnect the air supply. Turn off the hydraulic supply and remove the filler fitting and return stem from the tool. Reinstall the .125 diameter steel ball and 10-32 set screw into the bleed port and tighten. Test the tool for proper feed control before returning to service.



Tool Adjustments

WARNING: Disconnect air-supply before servicing. Clamp mechanism moves when connecting or removing air supply. Keep hands and fingers away from clamping and feed mechanism.

Spindle Stroke Adjustment

Loosen spindle adjustment lock, then turn spindle adjustment knob. Right hand rotation advances cutter forward; left hand rotation returns cutter. Correct cutter point position is flush with face of template boss. When cutter is properly adjusted, lightly tighten spindle adjustment lock to hold adjustment.

Micrometer Depth Adjustment

Loosen set screws, and rotate depth adjustment nut. Clockwise rotation increases depth; counterclockwise decreases depth. Graduations scribed on barrel are in .001" increments. When proper depth is achieved, lightly tighten set screws.

Feed Rate Adjustment

With appropriate tool, turning feed rate adjustment counterclockwise, increases feed rate. Turning the screw clockwise decreases feed rate. Feed rate can be measured by using the following formula:

$$\frac{60 \text{ seconds}}{\text{Time} = \text{Feed Rate} \times \text{Spindle Speed (rpm)}}$$

$$\text{Time} = \frac{60 \text{ seconds}}{\text{Feed Rate} \times \text{Spindle Speed (rpm)}}$$

Dwell Adjustment

Insert appropriate size hex wrench into dwell adjustment valve opening. Rotate wrench clockwise until valve seats lightly. Rotate valve counterclockwise 1/4 turn to obtain base setting.

Note: If adjustment valve is opened too far, drill motor will not cycle, and feed cycle cannot be obtained. To correct, turn valve clockwise to seat valve and set according to instructions above.

If valve is closed too far, retract cycle cannot be obtained. To correct, turn valve counterclockwise and set according to instructions.


Closing valve increases countersink dwell time; opening valve decreases countersink dwell time.


Tail Pad Adjustment

The purpose of the tail pad is to compensate for slight surface curvature of the workpiece being drilled and to assure that the hole being drilled is perpendicular to the surface.


To adjust to a flat plane for drilling flat surfaces, use a straight edge between the tail pad and face of template boss and adjust the tail pad until the straight edge is flush with the face of the template boss.

An optional tail pad is available for high curvature surfaces. (See Accessories for additional information.)







SECTION A-A




SECTION B-B




SECTION C-C




SECTION D-D






ITEM NO.	Q'TY REQ'D	CODE NO.	DESCRIPTION	ITEM NO.	Q'TY REQ'D	CODE NO.	DESCRIPTION	ITEM NO.	Q'TY REQ'D	CODE NO.	DESCRIPTION	ITEM NO.	Q'TY REQ'D	CODE NO.	DESCRIPTION
1	1	621646	ASS'Y,GEAR SET, 400 RPM	33	2	622777	PLUG VALVE RETAINING	77	2	622353	SPRING,COMPRESSION	134	4	847710	D-RING
1	1	621647	ASS'Y,GEAR SET, 950 RPM	34	1	622757	ASS'Y,RETRACT/DWELL VALVE	78	1	622616	SPRING,COMPRESSION	135	1	863454	D-RING
1	1	621648	ASS'Y,GEAR SET, 2100 RPM	35	1	622620	ASS'Y,UNCLAMP CHECK VALVE	79	1	623588	SPRING,COMPRESSION	136	3	622143	D-RING
1	1	621649	ASS'Y,GEAR SET, 3100 RPM	36	1	623042	ASS'Y,FEED CONTROL VALVE	80	1	623793	SPRING,COMPRESSION	137	5	615947	D-RING
1	1	621650	ASS'Y,GEAR SET, 6000 RPM	37	1	623071	FILTER	82	1	625696	CLEVIS PINLINKAGE	138	3	849931	D-RING
1	1	621651	ASS'Y,GEAR SET, 7800 RPM	38	1	623691	SLEEVE & SPDDL,TRIGGER	83	1	623041	INSERT,BODY	139	2	617290	D-RING
1	1	621652	ASS'Y,GEAR SET, 11500 RPM	39	1	623589	PINCOVER	84	1	864271	RING,RETAINING,INTERNAL	140	1	864737	D-RING
1	1	621653	ASS'Y,GEAR SET, 22500 RPM	40	1	622329	ASS'Y,PILOT VALVE	86	2	622376	RING,RETAINING,INTERNAL	141	3	844303	D-RING
2	1	625844	PRESSURE FOOT,R-L	41	1	622279	SPACER,PISTON VALVE	87	3	622065	RING,RETAINING,INTERNAL	142	1	847272	D-RING
2	1	625845	PRESSURE FOOT,L-R	42	1	622280	SHAF,PISTON	89	1	623594	RING,RETAINING,INTERNAL	143	1	869465	SPRING
3	1	621658	ASS'Y SPINDLE SET	43	1	622284	BUSHING,INLET	90	4	843179	RING,RETAINING,INTERNAL	144	1	622781	MUFFLER
				44	1	623880	BUSHING,CLAMP	91	1	812231	RING,RETAINING,EXTERNAL				ITEMS NOT SHOWN
4	1	623539-623566	GUIDE,COLLET 1230-2595 DIA.	45	1	623881	NUT,CLAMP	92	1	622615	RING,RETAINING,EXTERNAL				
5	1	623587	HANDLE	46	1	623611	ROTOR	94	1	869148	RING,RETAINING,EXTERNAL		1	202901	WARNING LABEL (BACKHEAD)
7	1	621519	ASS'Y,BUSHING	47	1	623508	SPACER	95	1	623595	RING,RETAINING,EXTERNAL		1	202902	WARNING LABEL (PRES. FOOT)
8	1	623613	BACKHEAD	48	1	869451	CYLINDER	96	1	843434	PLUGPIPE		1	202903	WARNING LABEL (BACKHEAD)
9	1	622073	TRIGGER	49	4	869788	BLADE ROTOR	97	1	844892	PLUGPIPE				OTHER ITEMS
10	1	623571	HOLDER,COLLET	50	1	843446	BEARING,BALL,REAR	100	1	622054	SCREW,SOCKET SET				
11	1	625646	SPRING,PLUNGER (OLD 6-32)	51	1	869445	BEARING,BALL,FRONT	101	1	843518	SCREW,SOCKET SET				
11	1	625646	SPRING,PLUNGER (OLD 6-32)	52	1	863654	PLATE,REAR BEARING	102	1	622642	SCREW,SOCKET SET		1	623222	FITTING,ADAPTER 1/8NPT
11	1	622354	SPRING,PLUNGER (NEW 8-32)	53	1	869585	PLATE,FRONT BEARING	103	1	623084	SCREW,SOCKET SET		1	882209	FITTING,ELBOW 1/8NPT
12	1	622250	PAD,PRESSURE FOOT	54	1	622761	COVER,EXHAUST	105	1	619684	SCREW,ORIFICE			624043	TUBING, 1/4 X .06 X 10' LG.
13	1	623514	NUT,PRESSURE FOOT	55	2	622760	PAD,MUFFLER	106	3	622053	SCREW,BUTTON HEAD CAP			624044	TUBING, 1/4 X .06 X 6' LG.
14	1	623512	CLIP,COLLET GUIDE	56	1	623869	MUFFLER	107	1	812963	SCREW,BUTTON HEAD CAP			624045	TUBING, 1/4 X .04 X 2-1/2"
15	1	623509	PIN,LIFT LEVER	58	1	622026	VALVE,NEEDLE	109	6	623597	SCREW,SOCKET SET			624054	TUBING, 1/8 X .04 X 6' LG.
16	1	625697	PULL ROD,CLAMP-UNCLAMP	59	1	844265	BALL,STEEL (1/8 DIA.)	110	1	619656	SCREW,FLAT HEAD				
17	1	625701	SLEEVE,FEED	60	1	622762	GUIDE,JOIL LEVEL INDICATOR	112	1	622384	SCREW,HEX SOCKET CAP				
18	1	623522	BULKHEAD,FRONT	61	1	622308	PISTON,JOIL LEVEL INDICATOR	113	4	844407	SCREW,HEX SOCKET CAP				
19	1	623519	BULKHEAD,AIR/HYDRAULIC	62	1	622763	ROD,JOIL LEVEL INDICATOR	114	1	623596	SCREW,HEX SOCKET CAP				
20	1	623521	BULKHEAD,REAR	63	1	622764	SPACER,JOIL LEVEL INDICATOR	115	1	845733	RING,RETAINING,EXTERNAL				
21	2	623523	PISTON,FEED	64	1	622765	PLUG,RESERVOIR	117	1	883731	SCREW,HEX SOCKET CAP				
22	1	623518	PISTON,CLAMP-UNCLAMP	65	1	622870	FITTING,HYDRAULIC	118	2	622059	SCREW,BUTTON HEAD CAP				
23	1	623525	NUT,BEARING RETAINER	66	1	625699	LINKAGE,CLEVIS	119	1	612625	WASHER,FLAT				
24	1	623527	NUT,SPINDLE ADJUST	67	1	625700	LIFT FINGER	120	1	622387	WASHER,FLAT				
25	1	623591	BEARING,BALL (COUPLEX PAIR)	68	1	623040	SCREW,FEED RATE ADJUST	121	1	623598	WASHER,FLAT				
26	1	623592	NUT,BEARING LOCK	69	1	625698	BUSHING,PULL ROD	126	3	844301	D-RING				
27	1	623593	WASHER,BEARING LOCK	70	1	622617	PIN,TRIGGER LOCK	127	1	844305	D-RING				
28	1	623648	NUT,DEPTH CONTROL	71	1	622618	BUSHING,TRIGGER LOCK	128	2	844306	D-RING				
29	1	623590	COVER,DEPTH CONTROL	72	1	621439	COVER,ASSY	129	1	844308	D-RING				
30	1	623646	STOP,DEPTH	73	1	623039	BODY,FEED ADJUST	130	4	844312	D-RING				
31	1	623573-623586	TEMPLATE BOSS	74	1	623076	SPRING,COMPRESSION	131	3	863009	D-RING				
				75	1	622088	SPRING,COMPRESSION	132	4	844307	D-RING				
32	1	623517	SHAFT,CLAMP-UNCLAMP	76	1	622351	SPRING,COMPRESSION	133	16	615645	D-RING				

400 RPM GEAR SET ASS'Y (621646 REF.)




147	3	623538	WASHER,FLAT
146	3	869254	GEAR,IDLER,1-ST RED.
144	1	623572	BEARING
123	2	812231	RING,RETAINING
122	2	622134	KEY,WOODRUFF
116	1	623507	CARRIER,PLANET
108	1	623536	GEAR,INTERNAL
93	1	623535	GEAR,SPINDLE
85	1	623504	GEAR,REDUCTION
81	1	847095	BEARING,BALL
ITEM NO.	Q'TY REQ'D	CODE NO.	DESCRIPTION

950 RPM GEAR SET ASS'Y (621647 REF.)




148	1	869645	GEAR,PINION
147	3	623538	WASHER,FLAT
145	3	869637	GEAR,IDLER,1-ST RED.
144	1	623572	BEARING
123	2	812231	RING,RETAINING
122	2	622134	KEY,WOODRUFF
116	1	623506	CARRIER,PLANET
115	1	623537	GEAR,INTERNAL
93	1	623535	GEAR,SPINDLE
85	1	623504	GEAR,REDUCTION
81	1	847095	BEARING,BALL
ITEM NO.	Q'TY REQ'D	CODE NO.	DESCRIPTION

2100 RPM GEAR SET ASS'Y (621648 REF.)




148	1	869645	GEAR,PINION
147	3	623538	WASHER,FLAT
145	3	869637	GEAR,IDLER,1-ST RED.
144	1	623572	BEARING
123	2	812231	RING,RETAINING
122	3	622134	KEY,WOODRUFF
116	1	623506	CARRIER,PLANET
115	1	623537	GEAR,INTERNAL
98	1	623534	GEAR,SPINDLE
88	1	623505	SHAFT,GEAR
81	1	847095	BEARING,BALL
57	1	623529	GEAR,REDUCTION
ITEM NO.	Q'TY REQ'D	CODE NO.	DESCRIPTION

3100 RPM GEAR SET ASS'Y (621649 REF.)




148	1	869645	GEAR,PINION
147	3	623538	WASHER,FLAT
145	3	869637	GEAR,IDLER,1-ST RED.
144	1	623572	BEARING
124	1	623530	GEAR,REDUCTION
123	2	812231	RING,RETAINING
122	3	622134	KEY,WOODRUFF
116	1	623506	CARRIER,PLANET
115	1	623537	GEAR,INTERNAL
99	1	623533	GEAR,SPINDLE
88	1	623505	SHAFT,GEAR
81	1	847095	BEARING,BALL
ITEM NO.	Q'TY REQ'D	CODE NO.	DESCRIPTION

6000 RPM GEAR SET ASS'Y
(621650 REF.)




148	1	869645	GEAR,PINION
147	3	623538	WASHER,FLAT
145	3	869637	GEAR,IDLER,1-ST RED.
144	1	623572	BEARING
125	1	623531	GEAR,REDUCTION
123	2	812231	RING,RETAINER
122	3	622134	KEY,WOODRUFF
116	1	623506	CARRIER,PLANET
115	1	623537	GEAR,INTERNAL
104	1	623532	GEAR,SPINDLE
88	1	623505	SHAFT,GEAR
81	1	847095	BEARING,BALL
ITEM NO.	Q'TY REQ'D	CODE NO.	DESCRIPTION

7800 RPM GEAR SET ASS'Y
(621651 REF.)




143	1	623612	SHAFT,GEAR
123	2	812231	RING,RETAINING
122	2	622134	KEY,WOODRUFF
98	1	623534	GEAR,SPINDLE
81	1	847095	BEARING,BALL
57	1	623529	GEAR,REDUCTION
ITEM NO.	Q'TY REQ'D	CODE NO.	DESCRIPTION

11500 RPM GEAR SET ASS'Y
(621652 REF.)



143	1	623612	SHAFT,GEAR
124	1	623530	GEAR,REDUCTION
123	2	812231	RING,RETAINING
122	2	622134	KEY,WOODRUFF
99	1	623533	GEAR,SPINDLE
81	1	847095	BEARING,BALL
ITEM NO.	Q'TY REQ'D	CODE NO.	DESCRIPTION

22500 RPM GEAR SET ASS'Y
(621653 REF.)



143	1	623612	SHAFT,GEAR
125	1	623531	GEAR,REDUCTION
123	2	812231	RING,RETAINING
122	2	622134	KEY,WOODRUFF
104	1	623532	GEAR,SPINDLE
81	1	847095	BEARING,BALL
ITEM NO.	Q'TY REQ'D	CODE NO.	DESCRIPTION

Accessories

Template Boss




APPLICATION		TEMPLATE BOSS CODE NO.
B TEMPLATE HOLE DIA.	A CUTTER DIA.	
.434	.271	623573
.434	.286	623574
.434	.317	623575
.497	.271	623576
.497	.286	623577
.497	.317	623578
.497	.349	623579
.497	.380	623580
.622	.317	623581
.622	.349	623582
.622	.380	623583
.622	.411	623584
.622	.489	623585
.622	.505	623586

(TEMPLATE BOSS LENGTH IS .150.) C

(TO FIT HOLE IN TEMPLATE) B

(TO FIT C'SINK DIA. ON CUTTER) A



Jig Collet Foot Attachments

Depth Sensing Jig Collet Foot (Pictured)

Depth sensing jig collet foot is used for accurately drilling and countersinking hole layouts utilizing a simple fixture plate. The cutter passes centrally through the drillmotor collet to produce holes concentric with the fixture plate holes. The depth sensing sleeve will drill and accurately countersink with fixture-to-workpiece variations of up to .125". Coolant and air blast port is fitted to the foot.

User must specify template hole and drill-countersink size as well as drill-countersink configuration.

Non Depth Sensing Jig Collet Foot

Non-depth sensing jig collet foot is similar to the above foot without depth sensing capability. This foot is used for straight drilling applications where "rough" depth sensing only is required. This foot grips straight shank drills utilizing an "O-W" type collet (not supplied).

User must specify template hole and drill size.


High Curvature Pad Assembly

A high curvature pad (Part No.621522) is available for use in place of the standard pressure foot pad. The high curvature pad enables the drill to be used on surfaces with a greater curvature than the standard pad is capable of handling.



Accessories

Booster Pump Assembly




ITEM NO.	NO. REQ'D.	CODE NUMBER	DESCRIPTION
1	1	621500	ASSY, BODY
2	1	621501	ASSY, END PLATE (HIGH PRESS.)
3	1	622660	END PLATE (LOW PRESS.)
4	1	622792	GASKET, END PLATE
5	1	622662	VALVE, PRESS. RELIEF
6	1	622663	PISTON, PRESS. RELIEF
7	2	622664	VALVE, CHECK
8	1	622665	VALVE, SHUTTLE
9	1	622666	PISTON
10	1	622652	SPRING, COMPRESSION
11	1	622653	SPRING, COMPRESSION
12	3	844304	O-RING
13	1	625112	GASKET
14	2	622654	O-RING
15	1	844308	O-RING
16	1	844315	O-RING
17	2	847710	O-RING
18	10	863337	SCREW
19	3	617245	SCREW
20	1	622845	RETAINER RING
21	3	844303	O-RING



For increased clamping force or feed pressure, an optional Booster Pump (621482) is available. The pump provides extra clamp and feed pressures when drilling Titanium or taper drilling applications. The Booster Pump assembly will increase both clamp and feed forces by a factor of 2.5. The pump is easily installed on the Q-Matic Drill by replacing the cover supplied with the tool with the Booster Pump using the three screws supplied with the pump.

Mist Lubricator Assembly

The mist lubricator assemblies are available to introduce coolant and an air blast to the cutter. The lubricator is actuated by air from the accessory air tap on the motor side and only functions when the motor is running. The following three pages show the three different types available. The mist lubricators and mounting brackets can be purchased as complete subassemblies using these numbers: Manual fill small capacity - 631878, Pressure fill small capacity - 631879, Pressure fill large capacity - 631880. The reservoirs and individual parts can be ordered using numbers listed on drawings.



Note: $\frac{x}{x}$ Upper number is item.
 $\frac{x}{x}$ Lower number is quantity required.

631802 PRESSURE FILL LARGE CAPACITY


ITEM	PART NO.	PART NAME	QTY.
1	203568	RING, O	1
2	622026	VALVE, NEEDLE	1
3	622881	RING, O	1
4	624903	NUT, JAM HEX	1
5	624905	FITTING	2
6	624914	PISTON	1
7	625015	S-CAP	1
8	629086	COVER, LARGE CAPACITY	1
9	629093	WIRE, RETAINING	1
10	629090	CYLINDER, LARGE CAPACITY	1
11	629148	SPRING, WAVE	1
12	629095	CAP, MOUNT (PRESSURE FILL)	1
13	631586	FILTER ASSEMBLY	1
14	631756	END CAP ASSEMBLY (LARGE)	1
15	844301	RING, O	1
16	844307	RING, O	1
17	869025	RING, O	2

631801 PRESSURE FILL SMALL CAPACITY

ITEM	PART NO.	PART NAME	QTY.
1	203568	RING, O	1
2	622026	VALVE, NEEDLE	1
3	622881	RING, O	1
4	624903	NUT, JAM HEX	1
5	624905	FITTING	2
6	624914	PISTON	1
7	625015	S-CAP	1
8	629097	COVER, SMALL CAPACITY	1
9	629093	WIRE, RETAINING	1
10	629094	CYLINDER, SMALL CAPACITY	1
11	629148	SPRING, WAVE	1
12	629095	CAP, MOUNT (PRESSURE FILL)	1
13	631586	FILTER ASSEMBLY	1
14	631757	END CAP ASSEMBLY (SMALL)	1
15	844301	RING, O	1
16	844307	RING, O	1
17	869025	RING, O	2

PRESSURE FILL MIST LUBRICATOR

MANUAL FILL MIST LUBRICATOR




Note: $\frac{x}{x}$ Upper number is item.
 $\frac{x}{x}$ Lower number is quantity required.

631799 MANUAL FILL LARGE CAPACITY

ITEM	PART NO.	PART NAME	QTY.
1	622026	VALVE, NEEDLE	1
2	622881	RING, \square	1
3	623422	KNOB	1
4	624902	NUT, JAM HEX	1
5	624903	NUT, JAM HEX	1
6	624905	FITTING	2
7	625015	S-CAP	1
8	629086	COVER, LARGE CAPACITY	1
9	629093	WIRE, RETAINING	1
10	629088	CAP, MOUNT (PUMP FILL)	1
11	629148	SPRING, WAVE	1
12	629090	CYLINDER, LARGE CAPACITY	1
13	631586	FILTER ASSEMBLY	1
14	631756	END CAP ASSEMBLY (LARGE)	1
15	631759	PISTON ROD ASSY (LARGE)	1
16	844301	RING, \square	1
17	844306	RING, \square	1
18	844307	RING, \square	1
19	869025	RING, \square	2

631800 MANUAL FILL SMALL CAPACITY

ITEM	PART NO.	PART NAME	QTY.
1	622026	VALVE, NEEDLE	1
2	622881	RING, \square	1
3	623422	KNOB	1
4	624902	NUT, JAM HEX	1
5	624903	NUT, JAM HEX	1
6	624905	FITTING	2
7	625015	S-CAP	1
8	629097	COVER, SMALL CAPACITY	1
9	629093	WIRE, RETAINING	1
10	629088	CAP, MOUNT (PUMP FILL)	1
11	629148	SPRING, WAVE	1
12	629094	CYLINDER, SMALL CAPACITY	1
13	631586	FILTER ASSEMBLY	1
14	631757	END CAP ASSEMBLY (SMALL)	1
15	631758	PISTON ROD ASSY (SMALL)	1
16	844301	RING, \square	1
17	844306	RING, \square	1
18	844307	RING, \square	1
19	869025	RING, \square	2



ITEM	PART NO.	PART NAME	QTY.
1	631800	RESERVOIR, LUBRICATOR (MFSC)	1
1	631801	RESERVOIR, LUBRICATOR (PFSC)	1
1	631802	RESERVOIR, LUBRICATOR (PFLC)	1
2	625469	CHECK VALVE	1
3	627357	ELBOW	1
4	624911	FITTING	2
5	624906	FITTING, MALE PUSH-IN	2
6	624121	GASKET	1
7	624910	NYLON TUBING	2
8	629092	PLATE, MOUNTING	1
9	865123	SCREW, SHC	2


MIST LUBRICATORS & MOUNTS COMPLETE SUBASSEMBLIES:
MFSC - 631878, PFSC - 631879, PFLC - 631880.

136SC-B-118 MIST LUBRICATOR MOUNTING

TROUBLE SHOOTING

SYMPTOM	REASON	SOLUTION
Air motor and/or clamp and feed functions do not start when trigger is depressed.	Trigger or pilot valves clogged with foreign matter.	Remove trigger and pilot valves (separately) and inspect for rust or debris. Inspect O-rings and replace if necessary.
Air motor does not run when trigger is depressed, but feed and clamp functions properly.	Gears damaged or jammed with debris.	With air line disconnected check for free spindle rotation with hex key wrench in end of spindle. Remove backhead, clean and inspect gears for damage.
	Foreign matter in motor inlet.	Remove motor and clean debris from motor inlet.
	Broken rotor blades, rotor or gear bearings.	Remove motor and inspect rotor blades and bearings. Replace if necessary.
Air motor "idles" when trigger valve is released.	Pilot valve or retract and dwell valve sticky (not fully reset), or bad O-ring.	Remove and check valves for debris and free movement of spool. Inspect O-rings, lubricate and reassemble.
	Leaking O-ring on air motor rear bearing support.	Remove and inspect O-rings. Replace if necessary and reassemble.
Motor runs, but clamp & feed functions do not start.	Unclamp check valve doesn't shift when trigger is depressed.	Remove unclamp check valve and inspect for debris, free movement and damaged O-rings. Lubricate and reassemble.
Motor runs, clamps but doesn't feed.	Feed control valve "closed"	Back off feed control valve counter-clockwise until feed commences.
	Debris in the hydraulic system.	Remove bleed port and bleed hydraulic system until fluid is clear.
Lunge during feed or variation in feed rate.	Air in hydraulic system.	Back feed control valve two turns from seat, and bleed as above.
	Persistent air in hydraulic system.	Remove hydraulic reservoir piston and check or replace O-rings.
Tool doesn't retract at end of feed stroke.	Dwell valve seated too tightly.	Back dwell valve off from seat 1/8 turn to 1-1/2 turn.
	Retract and dwell valve doesn't shift.	Remove retract and dwell valve and inspect for debris, free movement and damaged O-rings. Lubricate and reassemble.
	Depth control adjusted out of the max. range of the tool.	Readjust depth control nut within the feed stroke of the tool (ref.: 1.10 max. stroke).
Tool retracts shortly after trigger depressed.	Dwell valve opened too far off of seat.	Turn dwell valve clockwise (should be 1/8 to 1-1/2 turns of seat).
Tool "pulses" on retract (rapid "feed retract-feed retract").	Damaged O-rings on retract and dwell valve.	Remove retract and dwell valve, inspect O-rings and replace as necessary. Lubricate and reassemble.

136SC-B-118 NON-DEPTH SENSING JIG COLLET FOOT KIT FOR .500- 631400, .625-631401, .750-631402 & .875-631403



ITEM NO.	QTY.	CODE NO.	DESCRIPTION
1	1	624568	COLLET .500 STRAIGHT
1	1	624569	COLLET .625 STRAIGHT
1	1	623436	COLLET .750 STRAIGHT
1	1	623437	COLLET .875 STRAIGHT
2	1	Specified by Customer	MANDREL ASSEMBLY
3	1	625357	COLLET SPRING .500
3	1	625390	COLLET SPRING .625
3	1	625358	COLLET SPRING .750
3	1	623452	COLLET SPRING .875
4	1	625963	LIFT FINGER .500
4	1	625964	LIFT FINGER .625
4	1	625965	LIFT FINGER .750
4	1	625966	LIFT FINGER .875
5	1	625159	HEX NUT .500
5	1	625160	HEX NUT .625
5	1	625161	HEX NUT .750
5	1	625162	HEX NUT .875
6	1	625176	.500 - NOSE. .375 - .500 GRIP RANGE
6	1	625177	.500 - NOSE. .625 - 1.000 GRIP RANGE
6	1	625178	.625 - NOSE. .375 - .500 GRIP RANGE
6	1	625179	.625 - NOSE. .625 - 1.000 GRIP RANGE
6	1	625180	.750 - NOSE. .375 - .500 GRIP RANGE
6	1	625181	.750 - NOSE. .625 - 1.000 GRIP RANGE
6	1	625182	.875 - NOSE. .375 - .500 GRIP RANGE
6	1	625183	.875 - NOSE. .625 - 1.000 GRIP RANGE
7	1	627033	FOOT BODY
8	1	621645	QUILL ASSEMBLY
9	1	627032	SPINDLE
10	1	832128	DOWEL PIN
11	1	624531	PRESSURE FOOT NUT
12	1	627035	PULL ROD
13	1	624533	FEED SLEEVE
14	4	622774	SCREW. SOCKET HEAD
15	1	844308	"O"-RING
16	1	623223	PLUG
17	1	624905	HOSE FITTING WITH GASKET
18	8	622063	SCREW. BUTTON HEAD
19	1	Specified by Customer	ERICKSON COLLET
20	1	863888	COLLET CHUCK
21	1	627030	HAND GUARD
22	1	627031	HAND GUARD
23	1	627029	CUP RETAINER
24	1	627028	RETAINER RING
25	1	622922	HEX NUT

MAINTENANCE KIT - 621953

PART NO.	NAME OF PART	QTY.
382370	TOOL BOX	1
622849	ASSEMBLY TOOL	1
623014	ASSEMBLY TOOL, PRESS. FOOT NUT	1
623015	ASSEMBLY TOOL, TRIGGER LOCK	1
623334	ASSEMBLY TOOL, PRESSURE HYDRAULIC & FRONT ENCLOSURE	1
623515	ASSEMBLY TOOL, PRESSURE FOOT NUT	1
623520	ASSEMBLY TOOL, BULKHEAD REMOVAL	1
623647	ASSEMBLY TOOL, DEPTH STOP	1
632424	REMOVAL TOOL, VALVE	1
624759	SLIDE HAMMER PULLER	1
624760	ASSEMBLY FIXTURE	1
624761	WRENCH, SPINDLE BEARING LOCKNUT	1
624762	BEARING INSTALLER	1
624763	REMOVAL TOOL, FEED CONTROL VALVE	1
624764	REMOVAL TOOL, PILOT VALVE	1
624765	ARBOR PRESS FIXTURE	1
624766	VALVE INSTALLATION TOOL	1
624767	WRENCH, FEED CONTROL VALVE	1
624768	TEE WRENCH, FOOT BODY	1

[illegible]



CooperTools
7007 Pinemont
Houston, Texas 77040
Phone: (713) 462-4521
Fax: (713) 460-7008
www.cooperindustries.com