



# UNI-LIFT 5000 NT

# UNI-LIFT 5000 NT Plus

Automotive lift date: 04/2001

Manual date: 29.06.2001

Version: Optional with SPID



Operating instruction and documentation

Serial number: .....

Retailer address/ phone



# Nussbaum

Nußbaum Hebetchnik GmbH & Co.KG//Korker Straße 24//D-77694 Kehl-Bodersweier//Tel: +49(0)7853/8990  
Fax: +49(0)7853/8787//E-mail: info@nussbaum-lifts.de//http://www.nussbaum-lifts.de

## Table of contents

Foreword.....	3
Record of installation .....	5
Record of handing over .....	6
1.Introduction .....	7
1.1 Installation and check of the automotive lift .....	7
1.2 Information of Warning .....	7
2.Master document of the automotive lift .....	8
2.1 Lift–manufacturer .....	8
2.2 Application .....	8
2.3 Changes at the construction.....	8
2.4 Displacement of the automotive-lift.....	9
2.5 Declaration of conformity .....	10
3.Technical information .....	11
3.1 Technical ratings .....	11
3.2 Safety devices .....	11
3.3 Data sheet .....	12
3.4 Foundation diagram drawing.....	14
3.5 Hydraulic diagram drawing (without wheel free lift).....	18
3.6 Hydraulic diagram drawing (with wheel free lift).....	20
3.8 Electrical diagram drawing (with wheel free lift) .....	28
3.10 Pneumatic diagram drawing SPID .....	35
4. Safety regulations .....	36
5. Operating instructions .....	36
5.1 Lifting the vehicle.....	36
5.2 Lowering the vehicle .....	37
5.3 Equalisation of the platforms.....	38
6. Troubleshooting .....	40
6.1 Driving on an obstacle.....	40
6.2 Emergency lowering of the main lift/ wheel free lift .....	40
7. Inspection and Maintenance of Nussbaum lifts .....	42
7.1 Maintenance plan of the lift.....	42
7.2 Cleaning of the automotive lift.....	43
8. Security check .....	44
9.Installation and Initiation .....	45
9.1 Regulations for the installation.....	45
9.2 Erection and doweling of the lift .....	45
9.3 Deaerate the hydraulic system (main lift).....	46
9.4 Initiation .....	47
9.5 Changing the installation place .....	48
First security check before installation.....	51
Regular security check.....	52
Extraordinary security check.....	60

## Foreword

Nußbaum-Lifts are a result of long-standing experiences.

The high quality and the superior concept guarantee them reliability, a long lift time and the economic business. To avoid unnecessary damages and dangers, read the operating instruction attentive and observe the contents. Another or the described purpose going out use is not valid when not as agreed. This is valid particularly for climb and go.

*Company Nußbaum is not liable for damages arising from this. The user carries the risk alonely.*

### For the use belonged:

- to observe all the notice in the operating instruction and
- the following of the inspection and maintenance work and the prescribed tests.
- The instruction for use have to be observed by all persons working with the lift.
- Especially the chapter "Safety/accident Prevention" has to be observed.
- In addition to the safety remarks of the instructions for use the regulations and instructions being valid at the place of operation have to be considered.

### Obligations of the operator:

The operator is obliged to allow only those persons complying to the following requirement to work at the unit

- being well acquainted with the basic regulations concerning labour safety and accident prevention and being trained to operate the unit.
- having read and understood the chapter concerning safety and warning instructions and confirmed that by their signature.

### Dangers when operating with the lift:

The Nußbaum-Lifts are designed and built according to technical standard and the approved regulations for technical security. Yet, danger for body and life of the operator may turn up when using the lift inexpertly.

### The lift must only be operated :

- for its appropriate use
- in unobjectionable condition concerning technical security.

## Organising requirements

- The instructions for use are constantly to be kept at the place of operation being at hand at any time.
- In addition to the instructions for use rules pertaining to other regulations i.e. accident prevention and environmental rules are to be observed and directed.
- Safety- and danger alert operation of personal is occasionally and by observing the instructions for use to be controlled.
- As far as required and ordered by regulations personal protective equipment is to be used
- All safety- and danger-hints at the lift are to be observed!
- Spare parts must comply with technical requirements laid down by the manufacturer. This is only warranted with original parts.  
Consider time intervals given or fixed in instructions for use for repeated tests/inspections.

## Maintenanceworks, remedy of faults and disposal

- Fixed Adjusting-, maintenance- and inspectionworks and time intervals including Details for exchange of parts/part components as mentioned in the instructions for use are to be adhered.  
These works must only be carried out by expert personal.
- After maintenance- and repair works loose screw connections must always be firmly tightened!

## Guarantee and liability

- Our „General conditions of selling and delivering“ are in force.  
There will be no guarantee or liability for injuries of persons or things if these injuries are caused by one or by some of the following reasons.
- Inappropriate use of the lift
- Inappropriate installation, initiation, operation and maintenance of the lift.
- Use of the lift while one or several security devices do not work or do not work correctly or are not installed correctly.
- Not to follow the regulations of the operating instruction concerning transport, storing, installation, initiation, operation and maintenance of the lift.
- Changes of the construction of the lift without asking the producer.
- Changes of important adjustments of the lift (e.g. driving elements, power rating, motor speed, etc)
- Wrong or incorrect maintenance.
- Catastrophes, acts of God or external reasons.



## Record of handing over

The automotive lift UNI 5000 NT / PLUS with the  
serial number:..... was installed on:.....  
at the firm:..... at:.....  
the safety was checked and the lift was started.

The persons below were introduced after the installation of the automotive lift. The  
introduction was carried out from an erector of the lift-manufacturer or from a franchised  
dealer (competent person).

.....  
date name signature

.....  
date name signature

.....  
date name signature

.....  
date name signature

.....  
date name signature

.....  
date name signature

.....  
date name of competent signature of the competent

Your customer service:.....

## 1. Introduction

The document **”Operating Instruction and Documentation”** contains important information about installation, operation and maintenance of the lift.

To furnish proof of the **installation of the automotive lift** the form **”Record of Installation”** must be signed and returned to the manufacturer.

To furnish proof of the singular, regular and extraordinary check this documentation contains forms. The forms should be used to document the checks. They should not be removed from this documentation.

Every **change of the construction** and **displacement** of the automotive lift has to be registered in the **”Master document”** of the lift.

### 1.1 Installation and check of the automotive lift

Only specialist staff is allowed to do work concerning safety and to do the safety checks of the lift. They are called experts and competent persons in this document.

Experts are persons (for example self-employed engineers, experts) which have received instruction and have experience to check and to test automotive lifts. They know the relevant regulations concerning both labour and accidents prevention.

Competent persons are persons who have acquired adequate knowledge and experience with automotive lifts. They took part in training from the lift-manufacturer (servicing technicians of the manufacturer or dealer are competent)

### 1.2 Information of Warning

To show danger and to show important information the three symbols below are used. Pay attention to those passages, which are marked with these symbols



***Danger! This sign indicates danger to life. Inexpert handling of the described operation may be dangerous to life.***



***Caution! This sign cautions against possible damage to the automotive lift or other material defects in case of inexpert handling .***



***Attention! This sign indicates an important function or another important note.***

## 2. Master document of the automotive lift

### 2.1 Lift–manufacturer

Otto Nußbaum Hebetchnik GmbH & Co. KG  
Korker Straße 24  
D-77694 Kehl-Bodersweier

### 2.2 Application

The automotive lift UNI-LIFT 5000 NT / Plus / Spid is a lifting mechanism for lifting motor vehicles with a laden weight of up to 5000 kg. The max. load distribution is 2:1 in or against drive-on direction.

The wheel free lift is a lifting mechanism for lifting motor vehicles with a laden weight of up to 3500 kg. The max. load distribution is 2:1 in or against drive-on direction.

The lift is equipped with a detector (called SPID) which is able to detect play in the axes and on single wheel suspensions. The detection is possible up to an axle load of 2300 kg. The automotive lift is only designed for servicing vehicles. It is not allowed to carry persons with the lift. It is not allowed to climb on the lift or on the vehicle. It's not allowed to install the standard-automotive lift in a hazardous location or washing bays.

After changes of the construction after essential maintenance work on carrying parts and after changing the installation place, an expert has to check the lift and to confirm its correctness and security.

### 2.3 Changes at the construction

#### Changes at the construction, expert checking, resumption of work

(date, kind of change, signature of the expert)

.....  
.....  
.....

name, address of the expert

.....  
place, date

.....  
signature of the expert



## 2.4 Displacement of the automotive-lift

### Displacement of the automotive-lift, expert checking, resumption of work

(date, kind of change, signature of the expert)

.....  
.....  
.....

name, address of the expert

.....  
place, date

.....  
signature of the expert

## 2.5 Declaration of conformity

# Nussbaum



**Konformitätserklärung**

Declaration of Conformity

Déclaration de conformité

Declaración de conformidad

Dichiarazione di conformità

gemäß Maschinenrichtlinie 98/37/EG Anhang II.



**OTTO NUBBAUM GmbH & Co. KG**

Korker Str. 24

D - 77694 Kehl-Bodersweier

Hiermit erklären wir, daß die Hebebühne, Modell ...  
Hereby we declare that the lift model ...  
Déclare par la presente que le pont elevateur modèle ...  
Por la presente declara, que el elevador modelo ...  
Con la presente dichiariamo che il ponte sollevatore modello ...

**Typ: UNILIFT 5000 NT Plus**

Seriennummer: \_\_\_\_\_

in Übereinstimmung mit den folgenden EG – Richtlinien und harmonisierten Normen gefertigt wurde  
was manufactured in conformity with EC directives and the harmonized norms  
fabriqué en conformité avec les directives européennes suivantes et selon les normes harmonisées en vigueur.  
producido de acuerdo a las siguientes reglas de la Comunidad Europea y normas armonizadas.  
è stato costruito in conformità con le direttive CE e le relative norme armonizzate

98/37EG	Maschinenrichtlinie
EN 1493: 1998	Fahrzeug- Hebebühnen
EN 60204:1992	Sicherheit von Maschinen – Elektrische Antriebe

Prüfinstitut – Certification institute  
Organisme certificateur – Ente certificatore

**CE 0044 (RWTÜV)**

Kehl- Bodersweier, 13.09.2004

  
Otto Nussbaum GmbH & Co. KG  
Korker Straße 24  
77694 Kehl-Bodersweier  
Tel. 0 78 53 / 899-0

## 3. Technical information


### 3.1 Technical ratings

capacity automotive lift	5000 kg
capacity wheel free lift	3500 kg
load distribution	max. 2:1 in or against drive-on direction
Lifting time (main lift)	approx. 30 sec. with load
Lowering time (main lift)	approx. 30 sec. with load
Lifting time (wheel free lift)	approx. 5 sec. with load
Lowering time (wheel free lift)	approx. 12 sec. with load
capacity detector „SPID“	max. axle load 2300 kg
Line voltage	3 x 400 Volt , 50Hz
Power rating	3 kW
Motor speed	3000 rot./min.
Pump capacity	3 cm <sup>2</sup>
Hydraulic pressure	ca. 270 bar
pressure relief valve	ca. 300 bar
Oil tank	approx. 14 Litre
Sound level	≤ 75 dB(A)
Connection by customer	3~/N+PE, 400V, 50 Hz (standard version) with fuse T16A (Pay attention to the voltage of your state)


### 3.2 Safety devices


1. Pressure relief valve  
Overprint-safety of the hydraulic system
2. Holding valve  
safety device against unintentional lowering
3. Lockable main switch  
safety device against unauthorised operation
4. Feet protection  
safety device against bruises in the area of the feet
5. Two independent cylinders  
(each side master- and slave-cylinder)  
safety device against unintentional lowering
6. Seat valves at the cylinders of the wheel free lift  
safety device against unintentional lowering of the wheel free lift
7. CE-STOP  
safety device against squeeze

## 3.3 Data sheet



Rodstand max. 4550





**Technische Daten:**

- Tragfähigkeit : 5 000 kg
- Auffahrhöhe : 195 mm
- Hubhöhe max. : 1 920 mm
- Hubzeit : ca. 31 sec
- Senkzeit : ca. 19 sec
- Motorleistung : 3 kW

(\*) 850 mm ohne Achsheber oder mit Achsheber Laser Jack  
950 mm mit Achsheber Jack 2000 oder mit Jack 2500

Mass- und Konstruktionsänderungen vorbehalten!

UNI-Lift 5000 NT Masstab 1:40	6032 EINBAU
20.06.02 // M.G.	

**NUSSBAUM**  
**HEBETECHNIK**  
TEL. 07883/899-0 FAX 07883/8787  
www.nussbaum-lifts.de  
77694 KEHL - BODERSWEIER

Technische Daten:

- : 5000 kg
- : 3 500 kg
- : 195 mm
- : 1 920 mm
- : ca. 31 sec
- : ca. 19 sec
- : 3 kW


(\*) 850 mm ohne Achsheber oder mit Achsheber Laser Jack  
950 mm mit Achsheber Jack 2000 oder mit Jack 2500

Mess- und Konstruktionsänderungen vorbehalten!


<b>UNI-Lift 5000 PLUS NT</b> Masstab 1:40	
20.06.02 // M.G.	6033 EINBAU

**NUSSBAUM**  
**HEBETECHNIK**  
 TEL. 07833/699-0 FAX 07833/9787  
 www.nussbaum-rlz.de  
 77684 KEHL-BODERSWEIER

### 3.4 Foundation diagram drawing



**Nussbaum**  
**HEBETECHNIK**  
TEL 07853/899-0 FAX 07853/8787  
KREIBITZBOURNE 11.1.16  
77694 KEHL-BODERSWEILER



\* ohne Achsheber oder mit Achsheber Laser Jack  
 \*\* mit Achsheber Jack 2000 oder Jack 2500  
 \* without Jack or with Laser Jack  
 \*\* with Jack 2000 or Jack 2500


ACHTUNG: GILT NUR FUER DIE SERIENAUSFUEHRUNG MIT STELLPLATTEN UND BEIDSEITIGEN AUFFAHRKLAPPEN.


ANSTELLE DES LEITUNGSKANALS KANN AUCH EIN LEERROHR dm 100 VERLEGT WERDEN.

BAUSEITS IST FOLGENDES ANZUBRINGEN: NETZANSCHLUSS 3 /N+PE. 400V. 50Hz. KABELLAENGE CA. 2m  
 WASSERABFLUSS IN DER VERTIEFUNG

Wir weisen in unseren Fundamentplaenen auf die Mindestanforderungen des Fundamentes hin, jedoch der Zustand der oertlichen Gegebenheiten (z.B. Untergrund) obliegt nicht in unserer Verantwortung. Ggf. muss ein Architekt oder Statiker hinzugezogen werden.

Änderungen vorbehalten!

Fundamentplan UNI-LIFT 5000 CLT/NT Komplettfundament für Jack // Schienenlänge 5000 mm Kabelkanäle unterflur Auffahrschiene bodeneben		 TEL 07853/899-0 FAX 07853/8787 FERTIGUNGSTECHNIK + MASCHINENBAU D-77694 Kehl-Bodersweier
13-03-02 M.G	6010 EINBAU	



**ACHTUNG: GILT NUR FÜR DIE SERIENAUSFÜHRUNG MIT STELLPLATTEN UND BEIDSEITIGEN AUFFAHRKLAPPEN.**  
ANSTELLE DES LEITUNGSKANALS KANN AUCH EIN LEERROHR  
dm 100 VERLEGT WERDEN.


BAUSEITS IST FOLGENDES ANZUBRINGEN: NETZANSCHLUSS 3 /N+PE, 400V, 50Hz, KABELLAENGE CA. 2m  
WASSERABFLUSS IN DER VERTIEFUNG

Wir weisen in unseren Fundamentplänen auf die Mindestanforderungen des Fundamentes hin jedoch der Zustand der örtlichen Gegebenheiten (z.B. Untergrund) obliegt nicht in unserer Verantwortung. Ggf. Mu\_ ein Architekt oder Statiker hinzugezogen werden.

Aenderungen vorbehalten!

Fundamentplan UNI-LIFT 5000 CLT/NT Oberkante Auffahrschiene bodeneben Schienenlaenge 5000 mm		 TEL 07853/899-0 FAX 07853/8787 www.nussbaum-lifts.de 77694 KEHL-BODERSWEIER
13.03.02 M.G.	EINBAU 6008	





Achtung: Gilt nur für die Serienausführung mit Stellplatten und beidseitigen Auffahrklappen. Anstelle des Leitungskanals kann auch ein Leerröhr dn 100 verlegt werden.  
Bauseits: ausreichende Stromversorgung und Absicherung bis zu Bedienaggregat  
Wasserabfluss in der Vertiefung empfohlen


Valid for the inground of the lift with drive-on ramps at each end of the rails.

By customer: At the location of the power unit the following has to be prepared:  
208 - 240 volt, 60 Hz, single phase,  
wateroutlet


Wir weisen in unseren Plänen auf die Mindestanforderung des Fundamentes hin, jedoch der Zustand der örtlichen Gegebenheiten (z.B. Untergrund) obliegt nicht unserer Verantwortung. Im Bedarfsfall ist ein Architekt, Statiker hinzuzuziehen.

We point out the minimum requirement of the foundation in our plans. The condition of the local realities (for example: ground under the foundation) does not lie our responsibility. If necessary an architect must be consulted.

Anderungen vorbehalten/ Subject to alterations!

UNI-LIFT 5000 CLT/NT		 TEL 07853/899-0 FAX 07853/8787 www.nussbaum-lifts.de 77694 KEHL-BODERSWEIER
Grube für Achsheber Schiene bodeneben Schielenlänge 5500mm	pit for Jack rail flush with floor rail length 5500mm	
30.09.03 // M.G.	2291-2 EINBAU	

## 3.5 Hydraulic diagram drawing (without wheel free lift)




Stand 04-01  
H-Plan UNI NT 04-01.jpg

## Hydraulic parts list

Nr.	description	order number
0.1	oil tank	
0.2	motor	990445
0.3	gear pump	9750510112304
0.4	sub oil filter	980012
0.5	oil level gauge	980098
RV1	holding valve	980480
RV2	holding valve	980480
DBV	pressure control valve	155211
V1	double seat valve (manual unlocking)	980853
V2	double seat valve (manual unlocking)	980853
V3	seat valve (manual unlocking)	980338
DR	regulating valve Ø 0,8	
Me1	measuring connection	155470
Me2	measuring connection	155470
KU1	ball valve	980513
KU2	ball valve	980513
K1	master cylinder 1	pair of cylinders complete 050UNI02200K
F1	slave cylinder 1	
K2	master cylinder 2	pair of cylinders complete 050UNI02200K
F2	slave cylinder 2	

## 3.6 Hydraulic diagram drawing (with wheel free lift)

UNI-Lift NT plus  
99 550 00 00 5  
SN: 158936



11.04.01


H-Plan UNI NT NT Plus 04-01.jpg

## Hydraulic parts list

Nr.	description	order number
0.6	oil tank	
0.7	sub oil motor	990445
0.8	gear pump	9750510112304
0.9	oil filter	980012
0.10	oil level gauge	980098
RV	holding valve	980480
DBV	pressure control valve	155211
V1	double seat valve (manual unlocking)	980853
V2	double seat valve (manual unlocking)	980853
V3	double seat valve (manual unlocking)	980853
V4	double seat valve (manual unlocking)	980853
V5	double seat valve (manual unlocking)	980853
V6	double seat valve (manual unlocking)	980338
DR	regulating valve Ø 0,8	
M1	measuring connection	155470
KU1	ball valve	980513
KU2	ball valve	980513
KU3	ball valve	980513
KU4	ball valve	980513
K1	master cylinder 1	pair of cylinders complete 050UNI02200K
F1	slave cylinder 1	
K2	master cylinder 2	pair of cylinders complete 050UNI02200K
F2	slave cylinder 2	
K3	master cylinder wheel free lift	
K4	master cylinder wheel free lift	
F2.1	slave cylinder wheel free lift	
F1.1	slave cylinder wheel free lift	

## 3.7 Electrical diagram drawing (without wheel free lift)

0	1	2	3	4	5	6	7	8	9
---	---	---	---	---	---	---	---	---	---



**Nussbaum Hebechnik**  
 GmbH & Co. KG  
 Korker Straße 24  
 D-77694 Kehl Bodersweier  
 Tel.: +49(0)7853/899-0

# SCHALTPLAN

OBJEKT : Unilift NT  
ANLAGE :  
KUNDE :  
SCHALTPLANNR: Unilift NT 09/02/001

**1.) Schaltpläne und Schaltunterlagen**  
Die Schaltpläne werden von uns nach bestem Wissen angefertigt. Für bestellte Schaltpläne und Schaltunterlagen wird eine Frist von uns nach freier Einschätzung angegeben. Diese Fristen werden durch Änderungen oder Änderungen der Schaltpläne verlängert. Dies wird von uns nur nach den vom Auftraggeber überlassenen Unterlagen des Herstellers ausgeführt.

**2.) Funktionsprüfung der Schaltanlagen**  
Schaltpläne wie Schaltunterlagen werden für die richtige Funktion des Schaltkreises geprüft. Die Prüfung lässt sich jedoch nicht für alle Funktionen durchführen. Die Funktion der Schaltpläne wird von uns nach freier Einschätzung geprüft. Die Funktion der Schaltpläne wird von uns nach freier Einschätzung geprüft. Die Funktion der Schaltpläne wird von uns nach freier Einschätzung geprüft.

**3.) Sicherheitsprüfung und Schutzmaßnahmen**  
Die Schaltpläne werden unter Beachtung der geltenden Regeln der Technik nach dem Stand der Technik erstellt. Die Schaltpläne werden von uns nach freier Einschätzung erstellt. Die Schaltpläne werden von uns nach freier Einschätzung erstellt. Die Schaltpläne werden von uns nach freier Einschätzung erstellt.

Diese Schaltpläne sind unser geistiges Eigentum. Sie dürfen ohne unsere Genehmigung weder vervielfältigt noch Dritten weitergegeben werden.


Ursprung	Datum	Nr.	Bezeichnung	Erst.	Erst.	Erst.	Erst.


2












Datum		Nussbaum Hebe-technik Bech & Co. KG	
Bsp. BDE		0-7859 Mel - Hebe-technik	
Bsp. 30.09.2002		Tel. +49 0 7859 3833 Fax. +49 0 7859 3837	
Name		Ers. f.	
Bsp.		Ers. d.	
Steuerung		Unlift NT	
Bl. 5		Bl. 6 Bl.	



## 3.8 Electrical diagram drawing (with wheel free lift)

0	1	2	3	4	5	6	7	8	9
---	---	---	---	---	---	---	---	---	---



# SCHALTPLAN

**Nussbaum Hebetchnik**  
 GmbH & Co. KG  
 Korcker Straße 24  
 D-77694 Kehl Bodersweiler  
 Tel.: +49(0)7853/899-0

<p><b>OBJEKT</b> : Unilift NT Plus</p> <p><b>ANLAGE</b> :</p> <p><b>KUNDE</b> :</p> <p><b>SCHALTPLANNR:</b> Unilift NT Plus 12/02/001</p>	<p><b>3.) Sicherheitsprüfung und Schutzmaßnahmen</b></p> <p>Der Schaltschrank wurde unter Beachtung der angekannten Regeln der Technik nach VDE0100/011 sowie der Unfallverhütungsvorschrift VGB/C2 (elektrische Anlagen und Betriebsmittel) gefertigt bzw. errichtet und überprüft.</p> <ol style="list-style-type: none"> <li>1. Spannungsprüfung und/oder Isolationsprüfung des Schaltschrankes nach VDE0100/5.73.</li> <li>2. Prüfung der Wirksamkeit der angeordneten Schutzmaßnahmen nach VDE0100/5.73.</li> <li>3. Funktionsprüfung und Stückprüfung nach VDE910/11.87.</li> </ol> <p>Alle Schutzmaßnahmen wurden getroffen: VDE0100/5.73, Par. 4.</p> <p>3. Schutz bei indirektem Berühren nach VDE0100/5.73, Par. 5.</p>
---	---

<p>Erdung nach örtlichen Vorschriften</p> <p>Vor Inbetriebnahme prüfen, ob Motorstrom mit Motorschutzrelais übereinstimmt. Alle Klemmstellen auf Ordnungsgemäße Verbindung und alle Kontaktschrauben auf festen Sitz prüfen</p> <p>Vor Inbetriebnahme Verdrahtung und Steuerung auf richtige Funktion überprüfen. Keine Inbetriebnahme von unbefugter Seite vornehmen lassen. Änderungen vorbehalten</p>	<p><b>1.) Schaltpläne und Schaltunterlagen</b></p> <p>Die Schaltpläne werden von uns nach bestem Wissen angefertigt. Für bestellte Schaltpläne und Schaltunterlagen wird von uns keine Gewähr für die Richtigkeit dieser Unterlagen übernommen. Dies trifft insbesondere für Schaltungen zu, die von uns nach fremden Plänen angefertigt werden. Diese werden von uns nur nach den vom Auftraggeber überlassenen Unterlagen des Herstellers ausgeführt.</p>
--	---


<p>Schaltpläne sind keine Fertigungszeichnungen. Bei der Prüfung des Schaltschrankes im Werk können Fehler wie Fehler, Thermoschalter und Motoren nicht einbezogen werden. Auch bei sorgfältiger Prüfung lassen sich deshalb Funktions- und Schaltungsfehler nicht immer vermeiden. Die Verantwortung für die Richtigkeit der Schaltpläne liegt bei der Inbetriebnahme. Bei Inbetriebnahme ohne Mitzeichnung unseres Service wird deshalb keine Haftung übernommen. Bei Inbetriebnahme ohne Mitzeichnung unseres Service wird deshalb keine Haftung übernommen. Nach einer Inbetriebnahme ohne Mitzeichnung unseres Service kann es zu Schäden kommen, die nicht durch unsere Serviceleistungen abgedeckt werden können. Bei Schäden, die nicht durch unsere Serviceleistungen abgedeckt werden können, übernehmen wir keine Haftung. Bei Schäden, die nicht durch unsere Serviceleistungen abgedeckt werden können, übernehmen wir keine Haftung.</p>	<p><b>2.) Funktionsprüfung der Schaltanlagen</b></p> <p>Schaltpläne sind keine Fertigungszeichnungen. Bei der Prüfung des Schaltschrankes im Werk können Fehler wie Fehler, Thermoschalter und Motoren nicht einbezogen werden. Auch bei sorgfältiger Prüfung lassen sich deshalb Funktions- und Schaltungsfehler nicht immer vermeiden. Die Verantwortung für die Richtigkeit der Schaltpläne liegt bei der Inbetriebnahme. Bei Inbetriebnahme ohne Mitzeichnung unseres Service wird deshalb keine Haftung übernommen. Bei Inbetriebnahme ohne Mitzeichnung unseres Service wird deshalb keine Haftung übernommen. Nach einer Inbetriebnahme ohne Mitzeichnung unseres Service kann es zu Schäden kommen, die nicht durch unsere Serviceleistungen abgedeckt werden können. Bei Schäden, die nicht durch unsere Serviceleistungen abgedeckt werden können, übernehmen wir keine Haftung. Bei Schäden, die nicht durch unsere Serviceleistungen abgedeckt werden können, übernehmen wir keine Haftung.</p>
--	---


<p>Diese Pläne sind auf einem CAD-System erstellt worden</p> <p>Um die Pläne immer auf dem aktuellen Stand zu halten, bitten wir Änderungen nur durch uns vornehmen zu lassen.</p>	<p>Diese Schaltpläne sind unser geistiges Eigentum. Sie dürfen ohne unsere Genehmigung weder vervielfältigt noch Dritten weitergegeben werden!</p>
--	--

<p><b>Datum</b></p> <p><b>Bearb. BOE</b></p> <p><b>Gepr. 15.04.2004</b></p>	<p><b>Nussbaum Hebetchnik GmbH &amp; Co. KG</b>          Bodersweiler Straße 24          77694 Kehl          Tel.: +49(0)7853/899-0 Fax: +49(0)7853/899-1</p>	<p>Unilift NT Plus</p>
<p><b>Ursprf.</b></p>	<p><b>Ers. f.</b></p>	<p><b>Ers. d.</b></p>
<p><b>Handlung Datum</b></p>	<p><b>Deckblatt</b></p>	<p>Bl. 1 7 Bl.</p>















Nussbaum Hebe-technik GmbH & Co. KG  
a -/resh (ent) - Werk/center  
tel.: 09181/33388-0 fax: 09181/33388-10

Unilift NT Plus		Fotozellen	
Ers. f.		Ers. d.	
Ursprr.		7 B1.	



## 3.10 Pneumatic diagram drawing SPID



Nr:	Description	order number
0.1	pneumatic connection min. 8 bar	
0.2	4/2 way valve (pneumatic)	airtec M06510-HN
0.3	4/2 way valve (pneumatic)	airtec M06510-HN
0.4	4/2 way valve (pneumatic)	airtec M06510-HN
0.5	4/2 way valve (pneumatic)	airtec M06510-HN
1.0	double-effect cylinder	1260500100 master side
1.1	double-effect cylinder	1260500100 master side
2.0	double-effect cylinder	1260500100 slave side
2.1	double-effect cylinder	1260500100 slave side

## 4. Safety regulations

If you use the automotive lift, the German following regulations are to be considered: BGG945: Examine of automotive-lifts; BGR260 Using automotive-lifts; (VBG14).

**Especially the following regulations are very important:**

- The laden weight of the lifted vehicle mustn't be more than 5000 kg for the automotive lift, 3500 kg for the wheel free lift.
- The maximal axle load must not be more than 2300 kg for the SPID.
- The automotive lift must be lowered completely, before the vehicle is driving, in the provided direction, on the lift.
- During working with the lift the operating instruction has to be followed.
- At vehicles with low sub-ground clearance or with optional equipment (sport equipment) or sport-vehicles, it is to be tested previously whether damages can appear.
- Only trained personnel over the age of 18 years old are to operate this lift.
- Position the polymer supports as described of the vehicle manufacturer under the vehicle. (Version with wheel free lift)
- The correct position of the polymer pads has to be checked after the vehicle has been lifted a little bit.
- It's not allowed to stay under the lifted or lowered vehicle (except for the operator).
- Check the center of gravity of the vehicle if heavy parts are removed. (Version with wheel free lift)
- It's not allowed to transport passengers on the lift or in the vehicle.
- It's not allowed to climb onto the lift or onto a lifted vehicle.
- The automotive lift must be checked from an expert after changes in construction or after repairing carrying pads.
- It's not allowed to start with operations at the lift before the main switch is switched off.
- During lifting or lowering the vehicle it must be observed from the operator.
- It's not allowed to install the standard-automotive lift in hazardous location or in washing bays.


## 5. Operating instructions



*The Safety Regulations must be observed during working with the automotive lift. Read the safety regulations in chapter 4 carefully before working with the lift!*

### 5.1 Lifting the vehicle

- Drive vehicle over the lift, longitudinal axes on line of the lift.

 (Wheel free lift): If necessary use the ramps to secure the safeness of the vehicle.

- Block the vehicle against rolling, put into gear.
- Check the dangerous places of the lift and be sure that there are no objects or people in the immediate area of the lift or on the lift.
- Switch on the control system; main switch on position "1" (see pic.1)
- Choose between main lift/ wheel free lift (see pic.1, 4)
- (wheel free lift) Position the polymer supports under the pick-up points which are described by the vehicle manufacturer. Do not lay them on edge! The vehicle might fall down!
- Raise the lift. Press the button „lifting“.
- (wheel free lift): Stop the lifting when the wheels are free to check the safe position of the vehicle on the polymer pads.
- Lift the vehicle on the working height. Press the button „lifting“ .



*pic. 1: operation unit*

*1 main switch*

*2 button „lifting“*

*3 button „lowering“*

*4 reversing switch main lift/wheel free lift*

## 5.2 Lowering the vehicle

- Check the dangerous places of the lift and be sure that there are no objects or people in the immediate area of the lift or on the lift.
- Choose between main lift/ wheel free lift (see pic.1, 4)
- Lower the vehicle to the working height or until the platform reaches the lowest point; press the button „lowering“ .
- Observe the complete process.
- Before the lift reaches the lowest position, it stops (approx. 150 mm).  
Let off the „lowering“. Control the dangerous places. Press the button again. You hear an acoustic signal until the lift reaches the lowest position.
- When the lift is in its lowest position, remove the polymer supports (wheel free lift)
- Drive the vehicle out of the lift if the lift (main lift) is in the lowest position.

## 5.3 Equalisation of the platforms

Because there are two independent hydraulic systems, differences between the two rails should normally not appear when you operate the lift correctly.

Check possible mistakes before you equalize the two platforms (for instance a leakage of the hydraulic system or another external mistake)



***Equalize the rails only without load!***

***Before an equalisation you have to remove any kind of load of the lift!***

An equalisation could be necessary when one side isn't let down completely into the lowest position or if the loads of the two rails are very different of each other, for example.

### **Correct equalisation:**

**Situation:** One rail is higher than the other.


**preparations/measures:**

- Lower the lift as far as possible into the lowest position. Press button „lowering“.



pic. 2: ball valves for the equalisation of the lift.

- Remove the covers of the operation unit (back side)
- Pull ball valve KU1 and press button „lowering“. One rail lowers. Put button and ball valve in normal (original) position again.  
Pull ball valve KU2 and press button „lowering“. The second rail lowers also. Put button and ball valve in normal position again.
- Repeat this process for the wheel free lift with the ball valves KU3 and KU4.
- Lift the rails 1500 mm.
- Check now the position of the cylinder levers. All four cylinder levers have to sit close to the limit stops of the scissors. (compare to pic 3)



pic. 3  
cylinder levers (circle)  
2 x each side of the lift

- If the cylinder levers do not sit absolutely close to the limit stops then the rails have to be equalised still one time with the ball valves, according to the following description.

- **Equalisation of the main lift:**

Choose the main lift at the reversing switch (see pic.1, 4)

Press button „lifting“ and pull the ball valve KU1. Observe if the cylinder levers move to the limit stops. If no cylinder lever moves, put KU1 in his original position. Pull ball valve KU2 and press button „lifting“.

- **Equalisation of the wheel free lift:**

Choose the wheel free lift (“RFH”) at the reversing switch (see pic.1, 4)

Lift the wheel free lift in the highest position. Check the rails for torsion.

Pull ball valve KU3 and press button „lowering“.

Observe the rails if one of them lowers. If no rail lowers, put KU3 in his original position and pull ball valve KU4. Push button „lowering“. The torsion should have disappeared.

If the rails have different heights, push the button „lowering“ until the rails of the wheel free lift have reached their lowest position. Hold the button „lowering“ pushed and pull the ball valves KU3 and KU4 until both rails are on the same level.

- Put the ball valves in their original position again.

## 6. Troubleshooting

If the lift does not work properly, the reason for this might be quite simple. Please check the lift for the potential reasons mentioned on the following pages. If the cause of trouble cannot be found, please call the technical service.

### **Problem: Motor does not start!**

#### **possible causes:**

- no power supply
- main switch is not engaged
- fuse defect
- the feed line is cut
- thermal switch in the motor is active

#### **solution:**

- let the power supply check
- put main switch on
- check fuse and replace it if necessary
- repair it
- let it cool down

### **Problem: Motor starts, lift does not lifting!**

#### **possible causes:**

- The vehicle is too heavy
- Level of the oil is too low
- leakage of the hydraulic system
- gear pump does not work

#### **solution:**

- unload it
- fill oil in
- repair the system
- call your service partner

### **Problem: The lift does not lower!**

#### **possible causes:**

- The lift is standing on a obstacle
- hydraulic valve defect
- fuse defect
- Button „lowering“ not pushed
- Seat valves cannot be unlocked

#### **solution:**

- Push button „lifting“
- call your service partner
- check fuse and replace it if necessary
- Push the correct button!
- emergency lowering

## 6.1 Driving on an obstacle

If the lift drives on an obstacle, the hydraulic system has got no more pressure and the lift stops. To remove the obstacle the lift has to rails have to be lifted a little. Therefore push button „lifting“ until the obstacle can be removed.

## 6.2 Emergency lowering of the main lift/ wheel free lift



*A emergency lowering is an intervention into the control of the lift and can be done only by experienced expert.*

*The emergency lowering must be carried in this order. Otherwise a malfunction can lead it to damages or lead to danger for body and lives.*






**Every kind of external leakage must be removed. This is necessary particular before an emergency lowering.**

Reasons which provoke an emergency lowering are e.g. disturbances of the valves or a breakdown of the power supply.

1. Disconnect the lift from the power supply before starting the emergency lowering.
2. Open the covers of the aggregate. You have to be able to reach the seat valves of the hydraulic bloc. (pic. 4)
3. Check the dangerous places of the lift and be sure that there are no objects or people in the immediate area of the lift or on the lift.
4. Emergency lowering of the main lift: press simultaneously the valves V1, V2.
5. Emergency lowering of the wheel free lift: press simultaneously the valves V3, V4.
6. The lowering starts immediately. If there is any danger, let off the valves and stop the emergency lowering!!



pic. 4

*Valves with buttons for emergency lowering*

7. Lower the lift or the wheel free lift in his lowest position.
8. Observe the complete process.
9. Change the defect parts of the lift, before you initiate the lift again, if it is necessary. Therefore call your service partner.



**Switch off the main switch and lock it. Do not work with the lift until the faulty parts are exchanged.**

## 7. Inspection and Maintenance of Nussbaum lifts



*Before a maintenance, all preparations are to enforce that with maintenance-working and repair-working at the lift no danger for body and lives and for damages of objects exists.*

A regular service has to be performed in regular distances of 3 months through the operator in accordance with following service manual.

If the lift is used very often the intervals of cleaning have to be shortened. Observe the function of the lift while you use it. If there is disturbance or leakage call your service partner.

### 7.1 Maintenance plan of the lift

- Clean the piston rods of the hydraulic cylinders from sand and dirt.
- Grease the piston rods with a high capacity lipid (approx. 5 g of S2 DIN51503 KE2G of the Renolit Company).
- Clean and lubricate the moving parts of the lift (hinge bolts, sliding pieces, sliding surfaces) grease with a multipurpose lipid (example: Auto Top 2000 LTD. Agip).
- Grease the lubricate nipples with a multipurpose lipid. (example: Auto Top 2000 LTD. Agip).
- Check the colour if necessary make a repair.
- Check the hydraulic hoses
- Check the hydraulics-hoses for leakage.
- Check the oil level. Fill in a clean, high quality oil (32 cst) in the oil tank.
- The hydraulic oil has to be changed at least once a year. To change the oil, lower the lift into the lowest position. Empty the tank and replaced clean oil, approx. 14 litres are needed. A high quality hydraulic oil is recommended, it should be 32 cst. (e.g. HLP 32 LTD. OEST Company)

Use a ATF-Suffix hydraulic-oil (OEST Company ) if the ambient temperature is under 5 degree centigrade. After the fill up, the hydraulic oil must be between the upper and low marking of the oil level gauge.

- After § 52-3 of the VBG 14 german regulation, exchange the hydraulic hoses if its necessary, but latest after 6 years.
- Check the welding of the lift.
- Check the safety devices of the lift.
- Check the Polymer supports and replace them if its necessary.
- Check the turning moment of the screws.

Turning moment for screws  
property class 8.8

	0,10*	0,15**	0,20***
M8	20	25	30
M10	40	50	60
M12	69	87	105
M16	170	220	260
M20	340	430	520
M24	590	740	890

property class 10.9

	0,10*	0,15**	0,20***
M8	30	37	44
M10	59	73	87
M12	100	125	151
M16	250	315	380
M20	490	615	740
M24	840	1050	1250

Drehmomenttabelle 8.8-10.9 E

- \* sliding friction 0,10 for very good surfaces, lubricated
- \*\* sliding friction 0,15 for good surfaces, lubricated oder dry
- \*\*\* sliding friction 0,20 surface black or phosphatized, dry



- The valves (cartridges) have to be tightened with approx. 30 – 35 Nm in regular intervals. (see attachment)  
With intensive utilization of the lifting platform, the maintenance interval has to be curtailed.
- Before the cartridges with the demanded turning moment can be tightened, the coils have to be removed through releasing the black turn-lock fastener.

## 7.2 Cleaning of the automotive lift

A regular and appropriate maintenance serves the preservation of the lift.

It can be a prerequisite for claims at possible corrosion.

The best protection for the lift is the regular cleaning of dirt of all manner.

- Including this:

- de-icing salt
- sand, pebble stone, natural soil
- industrial dust of all manner
- water ; also in connection with other environmental influences
- aggressive deposit of all manner
- constant humidity by insufficient ventilation

### How often must the lift be cleaned ?

This is dependent on the use, of the working with the lift, of the cleanness of the workshop and location of the lift. The degree of the dirt is dependent on the season, of the weather conditions and the ventilation of the workshop. Under bad circumstances it is necessary to clean the lift every week, but a cleaning every month can suffice.


Clean the lift and the floor with a non-aggressive and non-abrasive detergent. Use gentle detergent to clean the parts. Use an standard washing-up liquid and lukewarm water.


- Do not use for cleaning a steam jet cleaning
- Remove all dirt careful with a sponge if necessary with a brush.
- Pay attention that are no remains of the washing-up liquids on the lift after cleaning.
- Do not use aggressive means for cleaning the workshop floor and the automotive lift.
- A permanent contact with every kind of liquid is forbidden.
- Dry the lift after the cleaning with a cloth. Do not use any high pressure device for cleaning the lift!

## 8. Security check

The security check is necessary to guarantee the safety of the lifting during use. It has to be performed in the following cases:


1. Before the initial operation, after the first installation  
**Use the form “First security check before initiation”**
2. In regular intervals after the initial operation, at least annually.  
**Use the form “Regular security check at least annually”**
3. Every time the construction of that particular lift has been changed.  
**Use the form “Extraordinary security check”**

 *The first and the regular security check must be performed by a competent person. It is recommended to service the lift at this occasion.*

 *After the construction of the lift has been changed (changing the lifting height or capacity for example) and after serious maintenance works (welding on carrying parts) an extraordinary security check must be performed by an expert.*

This manual contains form with a schedule for the security checks. Please us the adequate form for the security checks. The form should remain in this manual after they have been filled out. In the following there is a short description about special safety devices.

## 9. Installation and Initiation



### 9.1 Regulations for the installation

- The installation of the lift is performed by trained technicians of the manufacturer or its distribution partner. If the operator can provide trained mechanics, he can install the lift by himself. The installation has to be done according to this regulation.
- The standard lift must not be installed in hazardous locations or washing areas.
- Before installation a sufficient foundation must be proved or constructed.  
An even installation place has to be provided. The foundations must be based in a frost resistance depth, both outside and indoors, where you must reckon with frost.
- An electrical supply 3~/N+PE, 400 V, 50 Hz has to be provided. The supply line must be protected with T16A (VDE0100 German regulation). The minimum diameter amounts to 2,5 mm<sup>2</sup>.
- All cable ducts have to be equipped with protective coverings to prevent accidents.

### 9.2 Erection and doweling of the lift

- Install the lift according to the data sheet and the foundation plan.
- Install the operating unit at its designed place. Connect the power supply.
- Connect the hydraulic. All hoses are marked.
- Fill in the hydraulic oil, approx. 14 litres are needed. A high quality hydraulic oil is recommended, it should be 32 cst. (e.g. HLP 32 LTD. OEST Company) After the fill up, the hydraulic oil must be between the upper and low marking of the oil level gauge.
- Push button „lifting“ until the vent screws (on the top of the slave cylinders, see pic. 5) can be reached. Execute a deaerate according to chapter 9.6, if necessary.
- Adjust the lift: first one base plate, than the second base plate. If there is an uneven floor even it with metal sheets. A continuous contact between the floor and the base plate must be guaranteed to avoid hollow spaces. Dowel the lift:  
**Nussbaum Company demands LIEBIG safety dowels (german dowel manufacturer) or equivalent dowels of other manufacturer but: observe their regulations.**

Before doweling check the concrete floor (with quality B25!) if the concrete floor goes to the top edge of the floor. For an existing concrete floor the dowels have to be

chosen according to pic. 8. If floor tiles are on the concrete floor, the dowels have to be chosen according pic. 9. Its important for the trouble-free working that the base plate are clean and the guides of the sliding block are clean and greased.

Check the adjustment of the base plates and dowel the lift: Bore the holes to fix the dowels through the borings of the base plates. Clean the holes with pressure air. Put in the safety dowels.

- Dowel the aggregate in the floor.
- Tighten the Liebig-dowels with the dynamometric key ( $M = 80Nm$ ).



***Each dowel must be tightened with the demanded torque. Otherwise the normal and secure function of the lift can not guaranteed.***

***Observe the regulations of the other dowel-manufacturer.***

- Raise and lower the lift several times with load. Check the torque of the dowels and check the hydraulic hoses tightness.
- Equalize the lift, if this is necessary.
- Mount the covers: Do not damage the cables.

### 9.3 Deaerate the hydraulic system (main lift)

- The correct power supply, the correct hydraulic oil and the closeness of the hydraulic system have to be controlled after the installation of the lift.

By connecting the hydraulic hoses, air might enter the hydraulic system and provoke problems of ganging. In consequence a deaerating is necessary.

Check again the correct installation of the hydraulic hoses!

**Effects**, which make a deaerating necessary are e.g. a sudden lifting out of the lowest position or unequal rails.

Correct deaerating:


**There have to be 14 litres of hydraulic oil filled in the oil tank.**

- Choose the main lift at the reversing switch (see pic.1, 4)
- Open the vent screws on the top of the slave cylinders (see pic. 5) a little bit.

***Do not open them completely.***

- Push button „lifting“. The air streams out of the borings on the slave cylinders.

Keep the screws open until only hydraulic oil comes out of the borings. Close the vent screws afterwards.



pic. 5

pos. X = vent screw on the top of the slave cylinders



***If you do not close the vent screws, trouble and disturbances of the lift will occur!***

- Push button „lifting“ and drive the lift into the highest position. Repeat the procedure of deaerating, if necessary.
- Check if the vent screws are closed
- Push button „lowering“ and drive the lift into the lowest position. (While you lower the lift it is possible that the oil-air mix makes sounds)
- Lift the rails on 1500 mm without load. Check up the holding time.
- Check again if the cylinder levers: All four cylinder levers have to sit close to the limit stops of the scissors. (compare to pic 3). Repeat the procedure of point 5.3 if necessary.

## 9.4 Initiation



***Before the initiation a security check must be performed. Therefore use form: First security check.***

If the lift is installed by a competent person, he will perform this security check. If the operator installs the lift by himself, he has to instruct a competent person to perform the security check.

The competent confirms the faultless function of the lift in the installation record and form for the security check and allows the lift to be used.



***Please send the filled installation record to the manufacturer after the installation.***

## 9.5 Changing the installation place

If the place of installation shall be changed, the new place has to be prepared in according to the regulations of the first installation. The changing should be performed in accordance with the following points:

- Raise the lift on approx. 1000 mm.
- Remove the cover of the hydraulic tubes.
- Loose the dowels.
- Lower the lift in the lowest position.
- Loose the plug of the power supply.
- If necessary loose the hydraulic hoses only on the operating unit.
- If necessary use blind plugs to close the hoses.
- Disconnect the power supply.
- Transport the lift to its new place.
- Install the lift in accordance with chapter 9 “ Installation and Initiation”.
- Equalize and deaerate the lift!



*Use new dowels, the used dowels can not be used anymore.*



*A security check must be performed before reinitiation by a competent person. Use form “Regular security check”*



**Pic. 8: choice of the dowel length without floor pavement or tile surface**




Table to pic. 8

Liebig-dowels

Dowel type		B20/75	B20/100
Drilling depth	a	115	140
Min. anchorage depth	b	85	85
Thickness of concrete	c	180	180
Diameter of bore	d	20	20
Thickness of the lift-pieces	e	0-40	40-65
Number of dowels		16	16
Starting torque		according to dowel manufacturer	

**Pic 9: choice of the dowel lengths ( without floor pavement or tile surface)**





Table to pic. 9

Liebig-dowels

Type of dowels		B20/100	B20/125	B20/135	B20/175
Drilling depth	a	140	165	175	215
Min. anchorage depth	b	85	85	85	85
Thickness of concrete	c	180	180	180	180
Diameter of bore	d	20	20	20	20
Thickness of the lift-piece	e	40-65	65-90	90-100	100-140
Number of dowel		16	16	16	16
Turning moment		according to dowel manufacturer			

## First security check before installation

 Filling out and leave in this manual

kind of check	all right	defect missing	veri- fication	remark
Short operating instruction.....				
Type plate.....				
Warning designation.....				
Function button "lifting/lowering".....				
Function lever „main lift/wheel free lift“.....				
Condition / function ramps.....				
Function play-detector.....				
Condition/Function pocket-lamp.....				
Security of the bolts.....				
Condition bolts and bearing.....				
Condition sliding blocks.....				
Condition colour.....				
Construction (deformation, cracking).....				
Torque moment of the dowel.....				
Turning moment of the screws.....				
Condition operating unit.....				
Condition piston rod.....				
Condition of the covers.....				
Closeness of the hydraulic system.....				
Level of hydraulic oil .....				
Condition hydraulic hoses .....				
Condition electrical wires.....				
Function test with vehicle.....				
Function test wheel free lift with vehicle.....				
Condition Polymer supports.....				
Condition welding.....				
Function CE-Stop.....				
<b>( mark here applicable, in case of verification mark in addition to the first mark!)</b>				

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

Initiation not permitted, verification necessary

Initiation possible, repair failures until.....

No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator


If failures must be repaired:

Failures repaired at: .....

(Use another form for verification!)

.....  
signature of the operator

## Regular security check

 Filling out and leave in this manual

kind of check	all right	defect missing	veri- fication	remark
Short operating instruction.....				
Type plate.....				
Warning designation.....				
Function button "lifting/lowering".....				
Function lever „main lift/wheel free lift“.....				
Condition / Function ramp.....				
Function play-detector.....				
Condition/Function pocket-lamp.....				
Security of the bolts.....				
Condition bolts and bearing.....				
Condition sliding blocks.....				
Condition colour.....				
Construction (deformation, cracking).....				
Torque moment of the dowel.....				
Turning moment of the screws.....				
Condition operating unit.....				
Condition piston rod.....				
Condition of the cover.....				
Closeness of the hydraulic system.....				
Level of hydraulic oil .....				
Condition hydraulic hoses .....				
Condition electrical wires.....				
Function test with vehicle.....				
Function test wheel free lift with vehicle.....				
Condition Polymer supports.....				
Condition welding.....				
Function CE-Stop.....				

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....  
(Use another form for verification!)

.....  
signature of the operator

## Regular security check

 Filling out and leave in this manual

kind of check	all right	defect missing	veri- fication	remark
Short operating instruction.....				
Type plate.....				
Warning designation.....				
Function button "lifting/lowering".....				
Function lever „main lift/wheel free lift“.....				
Condition / Function ramp.....				
Function play-detector.....				
Condition/Function pocket-lamp.....				
Security of the bolts.....				
Condition bolts and bearing.....				
Condition sliding blocks.....				
Condition colour.....				
Construction (deformation, cracking).....				
Torque moment of the dowel.....				
Turning moment of the screws.....				
Condition operating unit.....				
Condition piston rod.....				
Condition of the cover.....				
Closeness of the hydraulic system.....				
Level of hydraulic oil .....				
Condition hydraulic hoses .....				
Condition electrical wires.....				
Function test with vehicle.....				
Function test wheel free lift with vehicle.....				
Condition Polymer supports.....				
Condition welding.....				
Function CE-Stop.....				

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

Initiation not permitted, verification necessary

Initiation possible, repair failures until.....

No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

(Use another form for verification!)

.....

signature of the operator

## Regular security check

 Filling out and leave in this manual

kind of check	all right	defect missing	veri- fication	remark
Short operating instruction.....				
Type plate.....				
Warning designation.....				
Function button "lifting/lowering".....				
Function lever „main lift/wheel free lift“.....				
Condition / Function ramp.....				
Function play-detector.....				
Condition/Function pocket-lamp.....				
Security of the bolts.....				
Condition bolts and bearing.....				
Condition sliding blocks.....				
Condition colour.....				
Construction (deformation, cracking).....				
Torque moment of the dowel.....				
Turning moment of the screws.....				
Condition operating unit.....				
Condition piston rod.....				
Condition of the cover.....				
Closeness of the hydraulic system.....				
Level of hydraulic oil .....				
Condition hydraulic hoses .....				
Condition electrical wires.....				
Function test with vehicle.....				
Function test wheel free lift with vehicle.....				
Condition Polymer supports.....				
Condition welding.....				
Function CE-Stop.....				

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

Initiation not permitted, verification necessary

Initiation possible, repair failures until.....

No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

(Use another form for verification!)

.....

signature of the operator

## Regular security check

 Filling out and leave in this manual

kind of check	all right	defect missing	veri- fication	remark
Short operating instruction.....				
Type plate.....				
Warning designation.....				
Function button "lifting/lowering".....				
Function lever „main lift/wheel free lift“.....				
Condition / Function ramp.....				
Function play-detector.....				
Condition/Function pocket-lamp.....				
Security of the bolts.....				
Condition bolts and bearing.....				
Condition sliding blocks.....				
Condition colour.....				
Construction (deformation, cracking).....				
Torque moment of the dowel.....				
Turning moment of the screws.....				
Condition operating unit.....				
Condition piston rod.....				
Condition of the cover.....				
Closeness of the hydraulic system.....				
Level of hydraulic oil .....				
Condition hydraulic hoses .....				
Condition electrical wires.....				
Function test with vehicle.....				
Function test wheel free lift with vehicle.....				
Condition Polymer supports.....				
Condition welding.....				
Function CE-Stop.....				

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

Initiation not permitted, verification necessary

Initiation possible, repair failures until.....

No failings, Initiation possible

.....

signature of the expert

.....

signature of the operator

If failures must be repaired:

Failures repaired at: .....

(Use another form for verification!)

.....

signature of the operator

## Regular security check

 Filling out and leave in this manual

kind of check	all right	defect missing	veri- fication	remark
Short operating instruction.....				
Type plate.....				
Warning designation.....				
Function button "lifting/lowering".....				
Function lever „main lift/wheel free lift“.....				
Condition / Function ramp.....				
Function play-detector.....				
Condition/Function pocket-lamp.....				
Security of the bolts.....				
Condition bolts and bearing.....				
Condition sliding blocks.....				
Condition colour.....				
Construction (deformation, cracking).....				
Torque moment of the dowel.....				
Turning moment of the screws.....				
Condition operating unit.....				
Condition piston rod.....				
Condition of the cover.....				
Closeness of the hydraulic system.....				
Level of hydraulic oil .....				
Condition hydraulic hoses .....				
Condition electrical wires.....				
Function test with vehicle.....				
Function test wheel free lift with vehicle.....				
Condition Polymer supports.....				
Condition welding.....				
Function CE-Stop.....				

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

Initiation not permitted, verification necessary

Initiation possible, repair failures until.....

No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

(Use another form for verification!)

.....

signature of the operator



## Regular security check

 Filling out and leave in this manual

kind of check	all right	defect missing	veri- fication	remark
Short operating instruction.....				
Type plate.....				
Warning designation.....				
Function button "lifting/lowering".....				
Function lever „main lift/wheel free lift“.....				
Condition / Function ramp.....				
Function play-detector.....				
Condition/Function pocket-lamp.....				
Security of the bolts.....				
Condition bolts and bearing.....				
Condition sliding blocks.....				
Condition colour.....				
Construction (deformation, cracking).....				
Torque moment of the dowel.....				
Turning moment of the screws.....				
Condition operating unit.....				
Condition piston rod.....				
Condition of the cover.....				
Closeness of the hydraulic system.....				
Level of hydraulic oil .....				
Condition hydraulic hoses .....				
Condition electrical wires.....				
Function test with vehicle.....				
Function test wheel free lift with vehicle.....				
Condition Polymer supports.....				
Condition welding.....				
Function CE-Stop.....				

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

Initiation not permitted, verification necessary

Initiation possible, repair failures until.....

No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

(Use another form for verification!)

.....

signature of the operator

## Regular security check

 Filling out and leave in this manual

kind of check	all right	defect missing	veri- fication	remark
Short operating instruction.....				
Type plate.....				
Warning designation.....				
Function button "lifting/lowering".....				
Function lever „main lift/wheel free lift“.....				
Condition / Function ramp.....				
Function play-detector.....				
Condition/Function pocket-lamp.....				
Security of the bolts.....				
Condition bolts and bearing.....				
Condition sliding blocks.....				
Condition colour.....				
Construction (deformation, cracking).....				
Torque moment of the dowel.....				
Turning moment of the screws.....				
Condition operating unit.....				
Condition piston rod.....				
Condition of the cover.....				
Closeness of the hydraulic system.....				
Level of hydraulic oil .....				
Condition hydraulic hoses .....				
Condition electrical wires.....				
Function test with vehicle.....				
Function test wheel free lift with vehicle.....				
Condition Polymer supports.....				
Condition welding.....				
Function CE-Stop.....				
<b>( mark here applicable, in case of verification mark in addition to the first mark!)</b>				

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

Initiation not permitted, verification necessary

Initiation possible, repair failures until.....

No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

(Use another form for verification!)

.....

signature of the operator

## Regular security check

 Filling out and leave in this manual

kind of check	all right	defect missing	veri- fication	remark
Short operating instruction.....				
Type plate.....				
Warning designation.....				
Function button "lifting/lowering".....				
Function lever „main lift/wheel free lift“.....				
Condition / Function ramp.....				
Function play-detector.....				
Condition/Function pocket-lamp.....				
Security of the bolts.....				
Condition bolts and bearing.....				
Condition sliding blocks.....				
Condition colour.....				
Construction (deformation, cracking).....				
Torque moment of the dowel.....				
Turning moment of the screws.....				
Condition operating unit.....				
Condition piston rod.....				
Condition of the cover.....				
Closeness of the hydraulic system.....				
Level of hydraulic oil .....				
Condition hydraulic hoses .....				
Condition electrical wires.....				
Function test with vehicle.....				
Function test wheel free lift with vehicle.....				
Condition Polymer supports.....				
Condition welding.....				
Function CE-Stop.....				
<b>( mark here applicable, in case of verification mark in addition to the first mark!)</b>				

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

Initiation not permitted, verification necessary

Initiation possible, repair failures until.....

No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:


Failures repaired at: .....

(Use another form for verification!)

.....

signature of the operator

## Extraordinary security check

 Filling out and leave in this manual

kind of check	all right	defect missing	veri- fication	remark
Short operating instruction.....				
Type plate.....				
Warning designation.....				
Function button "lifting/lowering".....				
Function lever „main lift/wheel free lift“.....				
Condition / Function ramp.....				
Function play-detector.....				
Condition/Function pocket-lamp.....				
Security of the bolts.....				
Condition bolts and bearing.....				
Condition sliding blocks.....				
Condition colour.....				
Construction (deformation, cracking).....				
Torque moment of the dowel.....				
Turning moment of the screws.....				
Condition operating unit.....				
Condition piston rod.....				
Condition of the cover.....				
Closeness of the hydraulic system.....				
Level of hydraulic oil .....				
Condition hydraulic hoses .....				
Condition electrical wires.....				
Function test with vehicle.....				
Function test wheel free lift with vehicle.....				
Condition Polymer supports.....				
Condition welding.....				
Function CE-Stop.....				

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....  
(Use another form for verification!)

.....  
signature of the operator