

CHAPTER 5

BFH SERIES


INTRODUCTION

The BFH/Optima Series system is a wheel balancing machine equipped with three optical scanners. Two scanners capture images of the wheel rim profiles (inner and outer), so that the co-ordinates of optimum positions for application of the balancing weights can be calculated automatically and without user inputs. The scanners are also used to obtain geometrical data about rim deformations, deviation of the rim edges from its axis of rotation (Rim Runout). The third scanner provides geometrical data about tire deformations, deviation of the tire from its axis of rotation (Tire Runout). Such data is used for advanced diagnosis of the wheel as well as to provide the user with indications on how to proceed in order to minimize the effects of such deformations.



THEORY OF OPERATION

The BFH/Optima Series system is based on distance measuring devices (range finders) based on the principle of LASER triangulation. This device comprises a LASER source, a lens and a linear optical image sensor (a CCD – charge coupled device). The beam of coherent light emitted by the LASER source hits the object whose distance is to be measured. The beam of light is diffused (scattered) in a plurality of light rays from the surface of the object and the rays are concentrated by the lens in a spot on the sensitive surface of the linear optical image sensor. The position of the spot on the sensor is determined by a digital analysis of the electrical signal produced by the sensor.



The distance between the object and the LASER source may be calculated. In practice, a calibration procedure is performed and a polynomial interpolation of a suitable degree is used. Specifically, the BFH/Optima system implements cubic spline interpolation with shape preserving characteristics.

The complete process is as follows:

1. Laser power – exposure time settling. The system is able to set the optimum values of laser power and CCD exposure time according to the ambient light, amount of reflected light, and reflectivity of objects.
2. Background subtraction. Two successive readings are taken: in the first the laser source is off, in the second is on. Complete sensor readouts are kept in the computer's memory. The difference of the acquired data provide an image of the CCD sensor without effects due to ambient light.
3. Detecting the position of the light peak on the linear optical image sensor.
4. Calculating the distance to the object by means of polynomial interpolation.



Profiling


In the BFH/Optima Series system, the distance measuring devices (range finders) are rotated in a plurality of known positions by a stepper motor, so that they constitute optical scanners. The scanners, detecting the distances from a known position of a plurality of points on the object to be explored (the wheel rim) allows the spatial co-ordinates of each point detected to be obtained.

For each scanner, the complete process is as follows:

1. Measuring the distance to the point hit.
2. Saving the distance measured at point 1 and the position of the distance measuring device at point 1.
3. Moving the laser range finder to the next known position.
4. Repeating steps 1 – 4 until the scan is complete.



Based on these co-ordinates, it is possible to identify positions on the rim profile which are useful, and even in a certain sense optimum, for the application of balancing counterweights. The co-ordinates of these positions are calculated automatically and without contact.



The complete weight position detection process is as follows:

1. Scan rim contour to determine typical rim parameters
2. Compare current rim pattern with a set of stored rim patterns
3. Select the best match stored rim pattern
4. Pick pre-established weight locations associated with the best match pre-established rim pattern
5. Calculate weight amount and display
6. Allow the user to modify suggested weight location by moving the laser pointer
7. "Learn" from experience



Rim Runout Measurement - Rim- Tire Matching / Optimization

It is known that the vibrations produced by a motor vehicle wheel as it turns are caused, by the following:

1. Uneven distribution of weights on the tire
2. Uneven distribution of weights on the rim
3. Geometrical deformation of the tire
4. Geometrical deformation of the rim
5. Uneven tire elasticity (variation in stiffness)

The BFH/Optima system allows the identification of geometrical deformations in the rim, that is to say, deviation of the rim axis from its axis of rotation:

Radial and Lateral Runout.

The scanner devices are rotated to a known position so that the LASER beam hits the surface of the rim at a predetermined point. The rim is rotated about the wheel balancer shaft and a plurality of distance measurements are taken at known rim angles of rotation. The operation is repeated for at least one other known distance measuring device position. On the basis of the data gathered in this way, a calculation process defines the eccentricity (Radial Runout) and angle (Lateral Runout) of the rim axis relative to the axis of rotation. This data can be used to provide the user an indication of the quality of the rim examined. It is also used to provide the user with indications on how to position the tire relative to the rim in order minimize the effects of such deformations.



In fact, the system allows the measurement of geometrical data relative to tire deformations, deviation of the tire axis from its axis of rotation. The distance measuring device is moved by rotation and translation to a known position so that the LASER beam hits the surface of the tire at a predetermined point. The wheel is rotated about the wheel balancer axis and a plurality of distance measurements are taken at known wheel angles of rotation. On the basis of the data gathered in this way, a calculation process defines the eccentricity – Radial Runout – of the wheel axis relative to the axis of rotation. A calculation process defines the eccentricity of the tire only, based on the measurements taken respectively on the rim and on the entire wheel by means of vector subtraction.

This data, together with the data about the imbalance and the data about the rim geometrical deformations, allows a complete wheel diagnosis and provides the user with more accurate indications. Moreover, a suitable optimization algorithm provides indications on how to position the tire relative to the rim in order to minimize the concurrent effects of such deformations in accordance with appropriate criteria. Typically, the tire is rotated with respect to the rim opposing the peak (maximum) of the tire radial runout with the minimum of the rim radial runout, thus minimizing the radial runout of the assembled wheel.

BFH/OPTIMA SERIES MAJOR COMPONENTS

This section identifies the major components for the BFH/Optima Series balancer. All descriptions and AC/DC theory of other components can be found in earlier chapters of this service manual.

CAMERA PROCESSOR BOARD

The Camera Processor board is the liason between the three Scanner / CCD assemblies and the Main Processor PCB inside the Ebox.

J6/7/8/9

Pin #	Direction	Name	Description
1	Digital Out	Q3	Stepper Motor Phase B
2,5	Power Out	Un	Common Power Supply
3	Digital Out	Q4	Stepper Motor Phase D
4	Digital Out	Q2	Stepper Motor Phase C
6	Digital Out	Q1	Stepper Motor Phase A

J10

Pin #	Direction	Name	Description
1	Power Out	+5Vdc	Digital Power Supply (5V)
2	Digital In	Zpos3	Motor 3 Zero Position
3,4		dGnd	Digital Ground

J11

Pin #	Direction	Name	Description
1	Digital In	PH-A	Encoder Phase A
2,4		dGnd	Digital Ground
3	Digital In	PH-B	Encoder Phase B

J12

Pin #	Direction	Name	Description
1,2,4,6	Power In		External 5V power supply
3,5,13,14			External Ground
7,8,9,10		NC	Not Connected
11	Digital In	IIC-SCif	External IIC Serial Clock
12	Digital I/O	IIC-SDif	External IIC Serial Data

J13

Pin #	Direction	Name	Description
1,2,3	Power In		External Motor Power Supply
4,5,6			External Motor Ground

J14,15,16


Pin #	Direction	Name	Description
1,18,20			Digital Ground
2	Analog In	OSx	OS CCD signal
3	Analog In	DOSx	DOS CCD signal
4,12	Power Out	+5Vd	5V Digital Power Supply
5	Digital Out	FRMstx	Frame Start Signal
6	Out	LPx	Laser Pointer Switch
7	Digital Out	RSTx	Reset signal
8,10	Power Out	+3.3Vd	3.3V Digital power supply
9	Digital In	AUXoutx	Auxiliary Digital out
11	Digital In	CONVstx	Conversion start signal
13	Digital I/O	SDA	IIC serial data
14,16	Digital Out	E0/1	IIC EEPROM address configuration
15	Digital Out	SCL	IIC serial clock
17	Digital In	Zposx	Scanner home position signal
19	Digital Out	LASERx	Laser modulation signal

J10	J9	J8	J7	J6
Rear	Rear	Rear	Outside	Inside
Encoder	Scanner	Scanner	Scanner	Scanner
Zero	Motor	Motor	Motor	Motor
	Drive			

J13
Motor
Power

J12
PCB
Power

J11
Power
Clamp
Encoder



J16
Rear
CCD

J15
Outside
CCD

J14
Inside
CCD

ELECTRONIC BOX

The BFH/Optima is equipped with an electronic box somewhat like the Y2k balancers. Additional components have been added to the power supply pcb to operate the "Power Clamp" and the "Power Clamp switch". The box is backwards compatible but the older Ebox will not work in the BFH/Optima balancer.

SCANNER / LASER / CCD

The BFH/Optima is equipped with 3 Scanner assemblies. Each of these assemblies are installed and calibrated as complete assemblies. A role call is performed with each one on boot up. ***There are no serviceable components on these assemblies with the exception of the manufactures mechanical adjustments. DO NOT ATTEMPT TO MAKE ADJUSTMENTS OTHER THAN THE ZERO REFERENCE STATED LATER IN THIS MANUAL.*** Each scanner assembly has a zero stop that has minor adjustment. The rear scanner assembly and the outside scanner assembly are identical and can be swapped. However, the inside scanner assembly has a different mounting bracket and cannot be interchanged with the other two assemblies. For troubleshooting purposes the units can be swapped at board level. Should any of these assemblies require replacement the balancer will flag an E360 error code and force a scanner calibration.



POWER SUPPLY PCB

The Power Supply PCB receives 230VAC power from the Electronic box. This voltage can be measured using a Digital Volt Meter at J1 pins 1 and 2 on the Power Supply PCB. The AC power passes through on-board bridge rectifiers converting the power to 9VDC which is used to power all of the (4) Scanner Motors. This 9VDC can be measured at J2 pins 1,2 and 3. Pins 4,5 and 6 are ground connections. This voltage must be adjusted after the installation of the Power Supply PCB. Follow the procedure below to measure and adjust the output voltage to the scanner motors.

1. Remove the weight tray
2. Place the positive lead of the Digital Volt Meter on Pin 1 (Red wire) and the negative lead of the Digital Volt Meter on Pin 6 (Black wire).
3. Use a small pocket screwdriver and adjust the pot to obtain a voltage reading between 9 - 9.5 VDC.




POWER CLAMP ASSEMBLY

The BFH/Optima series balancer is equipped with a power clamp that eliminates the need for a standard or quick clamp nut. The Power Clamp is activated by lifting up on the foot pedal mounted on the balancer. The vibratory system has an optical sensor mounted on the shaft that senses variation on a visible encoder disk. The opti switch looks to see if the shaft is spinning before operating the power clamp. The power clamp will not open or close if the shaft is spinning. The large pulley drives the power clamping jaws while the magnetic brake is engaged and is holding the shaft. Should the clamping jaws be engaged during the event of a power failure there is a manual override to disengage the power clamp so the wheel/tire assembly can be removed.

Manual Override Wheel and Tire Removal Procedure

1. On the front of the balancer, remove the plug from the access holes.
2. Insert a large screwdriver into the access hole approximately 6 inches.
3. Slowly turn the Wheel and Tire assembly CW until the "Manual Stops" make contact with the screwdriver.
4. Continue to turn the Wheel and Tire assembly until the power clamp cup reaches the end of the shaft.
5. Once power is resumed simply lift up on the foot pedal to re-engage the power clamp mechanism.



SELF TEST DURING START UP

The BFH/Optima performs a start-up routine when power is applied. A series of self diagnostic tests is conducted after the machine has been turned on. If a test is not successful: a series of audible signals is given, or an error code is displayed. A three-tone signal is given once, the machine is operative. In case there is a functional error, it must be acknowledged by pressing the STOP or ESC key to proceed.

Listed below are the steps that the balancer performs along with possible "E Codes", "C Codes", or "H Codes" that could occur. This is for informational purposes.

1. Communication between microcontroller and embedded PC (Blue screen)

Service Codes: No service code available

Communication between micro-controller and embedded PC is not OK (check connecting cable). This can also indicate a bad connection to the keyboard. Check cabling between embedded PC and processor or cable to switches on the front panel.

2. Check availability of keyboard (E 300)

Service Codes : No service code available

The microcontroller was not able to detect a keyboard. Check cabling between microcontroller and keyboard.

3. Check content of permanent memories (E 145)

Service Codes: C85, C86 to copy content of permanent memory

Contents of both permanent memories are different, but both contain valid data. If the trouble signalled by the error code is not remedied (using service codes C85 or C86), the machine will remain in service code mode. It will be necessary to perform a manufactures calibration (C83, C84, C88)

4. Check model information (E 900)

Service Codes : C47 to set model

The stored machine model is not known. If the trouble signalled by the error code is not remedied (using service codes C47), the machine will remain in service code mode.

5. Check keyboard (E 89)

Service Codes : No service code available

One of the keys F1 to F6, HELP, ESC, START supplies a key code. The machine will proceed with the next step only if the trouble is remedied.

6. Check pedal switches (E 89)

Service Codes : C56 to check the pedal switches.

C75, AdC16 to check voltage to external switches. (See "C75")

One or, if available, both pedal switches are actuated. The user can now remedy the trouble. Press STOP or ESC key to check the pedal switch once again and to delete the error code reading. If the trouble cannot be remedied, the pedal is made inoperative.

7. Check BFH/Optima Calibration (E 360)

Service Codes : All codes available for this model

The BFH/Optima hardware requires wheel profiler position calibration.

When the camera controller board is replaced on the machine, the software detected that calibration data is missing.

Calibration procedure C122 is required to calibrate the actual position of the laser scanners with respect to the balancer reference plane.

8. Check BFH/Optima Hardware (E 361)

Service Codes: All codes available for this model

Wheel profiler is not present or responding during the self test. The balancer controller board was not able to communicate with the camera controller board during start-up test.

Possible causes:

- The camera controller board is missing or dead.
- The cable connecting the balancer controller board and the camera controller board is unplugged, damaged or missing.

9. Check BFH/Optima Hardware (E 362)

Service Codes : All codes available for this model

Main camera board self test failed.

Balancing is not possible since wheel data cannot be scanned.

Problem during power up. Switch power off and on again. Possible camera board failure.

10. Check BFH/Optima Inner Scanner (E 363)

Service Codes : All codes available for this model

Left side scanner self test failed or CCD not calibrated or zero mark not detected.

Balancing is not possible since wheel data cannot be scanned.

**11. Check BFH/Optima Outer Scanner (E 364)**

Service Codes : All codes available for this model

Right side scanner self test failed or CCD not calibrated or zero mark not detected.

Balancing is not possible since wheel data cannot be scanned.

**12. Check BFH/Optima Rear Scanner (E 365) (Excluding 800)**

Service Codes : All codes available for this model

Rear scanner self test failed or CCD not calibrated or zero mark not detected.

Wheel data can be scanned, balancing is possible. Runout measurement of the wheel is not possible.

**13. Hardware tests C1- - - -**

If an error occurs during the hardware test. The four hyphens replace the digits 0 to 9 and the letters A to F which all characterize an error/defect. **Refer to all Error Codes in Appendix A**

The following test are performed:

- A. Power supply voltage (235V)
- B. 5V line
- C. Incremental encoder (Current of optoelectronic LED)
- D. Transducer signal available
- E. Auto Stop System (Voltage for relay on Motor Control Board)

A. Hardware test - common errors

C10F02 - Test returned with an error. No valid test results available

C10F07- Test function reported an unknown error

C10F18- Test timed out. No valid test results available

B. Hardware test - Power supply voltage

C10800

C10801

C10804

Service Codes: C55 to check line voltage.

If the line voltage is below or above a limit the error code is displayed. (See "C55")

C. Hardware test - 5V line**C10810****C10811**

Service Codes: C110 to check 5V voltage.

If the 5V voltage is below or above a limit the error code is displayed.

D. Hardware test - Current of optoelectronic LED**C10705****C10706****C10707****C10708**

Service Codes: C75, AdC1 to check LED

If the current / voltage is below or above a limit the error code is displayed.

E. Hardware test - Transducer signals**C10410****C10420****C10430**

Service Codes: C103/C104 to check transimpedance and signal amplifiers and transducer values.

If no signals from the transducers are detected the error code is displayed.

F. Hardware test - Auto stop system**C10380****C10381****C10382****C10383**

Service Codes: C75, Adc21 to check voltage on capacitor of the auto stop system.

If the voltage is below or above a limit or the recharging time is above a limit the error code is displayed.

14. Hardware test disturbed H 82

Service Codes : All codes available for the model

A self test was disturbed (e.g. wheel was rotated during the transducer test)

The code is displayed for 3 seconds, then measurement is repeated (10 times maximum), or aborted using the STOP or ESC key.

15. Power clamp service interval expired E93

All codes available for this model.


After a successful boot up the following screen will appear on the display.



DISPLAY DESCRIPTION

The Display of the BFH/Optima Series balancer is divided into three parts. Each of these parts display different information throughout the use of the balancer.

- **Main Screen:** Main information screen for the user interface.
- **Function Key area:** Six function keys F1 to F6, the functionality of the keys can change in every screen. Represents the function of the keys on the keyboard.
- **Status Area:** Status information from top to bottom, balancer model and software revision, date and time, screen name, balancer status (i.e. adapter compensation active, loaded user), error messages.



BALANCER SETUP

On the initial installation the balancer should be setup for the customer preferences i.e. ounce/gram, day/month/year, time, etc. Press the "**Function**" key (F1)

Start = No Function

Stop = Stop the Main Shaft

Escape = No Function

Help = Go to Help Screen

F1 = Go to Function Screen / Enter Service Mode
User Calibration / Text Editor

F2 = Adapter compensation function or if adapter compensation is active; switch off. The unbalance of an adapter can be temporarily compensated with this function. If the adapter compensation is active it is indicated by the adapter compensation icon in the status area. (Operator Manual)

F3 = No Function

F4 = Go to Balancing Function (Operator Manual)

F5 = No Function

F6 = Optima menu (Operator Manual)



FUNCTION SCREEN

Start = No Function

Stop = Stop the Main Shaft

Escape = Back to Introduction Screen

Help = Go to Help Screen

F1 = User Calibration

F2 = Go to text editor

F3 = No Function

F4 = No Function

F5 = Used to toggle selected Function

F6 = Used to change selected Function

While pressing and holding in the <F6> key rotate the shaft. The green indicator arrows in the "Main Screen" area will either move up or down depending on the direction of the shaft rotation. Once the indicating arrow reaches the function to be changed release the "F6" key. Press and hold the <F5> key to toggle the function. The indicator arrow at the bottom of the "Main Screen" area indicates additional information. The two "--" marks at the top of the Main Screen area indicates that there is no information above the selected function.



FUNCTION DESCRIPTION

Balancer operating mode.

Saving the operating mode setting in the non volatile memory. The saved setting are now active after the next power on.

- 0: manual (The BFH/Optima must be set to the manual mode before running any C-Codes.)
- 1: profiling
- 2: optima

Setting factory default modes of operation.

- Set to 1 for changing all setting to factory defaults and settings.

Saving modes of operation in permanent memory.

Saving the user settings in the non volatile memory. The saved setting are now active after the next power on.

- 0: do not save
- 1: save settings

After successful write to the non volatile memory the display board speaker sounds the typical Snap-on "TüDüLü".

Language selection.

- The English Language is the first one on the list.

The volume of audible signals.

- 0 ... 100: selectable from 0 (off) to 100 (loud), 50 is default.

Resolution of unbalance amount readings.

The resolution of the unbalance display.

- Normal: rough, default 5 gram / .25 ounces
- Fine: fine 1 gram / .05 ounces

Suppression of minor unbalance readings.

The user threshold can be changed with C8. Below this threshold the unbalance value is set to zero.

- off
- on, default

Setting threshold value for unbalance suppression.

Threshold value for suppression of minor unbalance readings.

- 3.5 ... 20.0 grams, 3.5 grams is default
- 0.25 ... 2.00 ounces, 0.25 ounces is default

All unbalance values below the threshold are set to zero if suppression of minor unbalances is enabled. If the right, left and static unbalance values are set to zero the OK segment is on. If the ALU mode is not normal the unbalance values are transformed to the normal ALU mode to check the values.

Measurement units of the unbalance amount readings.

- grams, default
- ounces

Number of revolutions for a measurement run.

Note that a decrease of the number of revolutions for a measurement run can cause an in-accuracy of the measurement results.

- 5 ... 25: Number of revolutions for a measurement run, 10 is default.

Starting a measuring run by closing the wheel guard.

This feature does not work in the user codes, service codes, optimization and minimization.

- off, default
- on

Automatic braking when wheel guard is raised.

- off: no automatic braking, motor is switched off.
- on: braking to standstill, default.

Releasing of the power clamping device.

The power clamp system can be locked. This can be used if a special clamping device is in use.

- off: no lock, default
- on: locked

Actuation direction of pedal for clamping/releasing.

The functionality of the power clamp foot pedal can be changed.

- raise: raise pedal for clamping, default
- press: press pedal for clamping

Three lines for changing the date.

- Day: dd.—.—
- Month: —.mm.—
- Year: —.—.yy

Two lines for changing the time.

- Hour: hh:—
- Minute: —:mm

The balancer has counters to count the measured runs.

The counters are displayed in three lines:

- number of measurement runs / number of measurement runs with OK
- number of measurement runs since last calibration / number of clamping.
- number of optimization and minimization / number of measurement runs in service mode

Screensaver timeout (0=disable)

- Amount of time for screensaver to activate while unit is sitting idle (default 20)

CUSTOMER CALIBRATION

The BFH/Optima balancer features a simple user calibration program. Perform this procedure when the balancer has been moved, disturbed, or whenever accuracy is questioned. Occasional field calibration will ensure years of reliable service.

1. Press and release the **<Function>** key (F1) from the "Intro Screen".



2. Press and release the **<Calibration>** key (F1).

3. With nothing mounted on the shaft lower the



wheel guard and press the <**SPIN**> key. The balancer should spin and come to a complete stop.



4. After the balancer comes to a stop raise the wheel guard and screw the calibration slug into left side of the flange plate. Lower the wheel guard and press the <**SPIN**> key. The balancer should spin and come to a complete stop. Once the shaft stops the display should display "OK" and the speaker sounds the Snap-on "TüDüLü".

Calibration Complete



ENTERING SERVICE MODE

1. From the Introduction Screen press the <FUNCTION> key (F1) to enter in to the Function Menu.



2. By pressing the <F6> key 3 times successively the "SERVICE" key (F4) will become active.



NOTE: BEFORE PERFORMING ANY "C-CODES" ON THE BFH/OPTIMA BALANCER THE TECHNICIAN MUST FORCE THE BALANCER INTO THE MANUAL MODE. SEE "BALANCER OPERATING MODE" UNDER "FUNCTION DESCRIPTION EARLIER IN THIS CHAPTER.



3. By pressing the <F4> key the service program will become active.



C CODES

By pressing and holding the <**C-CODE**> key (F1) and rotating the main shaft the user can select the desired C-Code. Once the desired C-Code is displayed in the C-Code identifier window the technician needs to simply release the “**C-Code**” key (F1). After each C-Code change it is recommended that the technician save the change by use of the “**C90**” code. Many codes are written for engineering purposes and are not valid for field use.

C Description

- 28 Display and clear error codes
- 43 Reset counters
- 47 Select machine model
- 55 Indication of the line voltage
- 56 Indication of the circuit state of the wheel guard switch and both foot pedal switches
- 57 Indication of temperature
- 59 Indication of the residual unbalance compensated for using code C84
- 60 Motor: Indication of the RPM of main shaft
- 74 Indication of the position counter and basic incremental encoder test
- 75 Display values from AD converter
- 76 Indication of the voltages used by the 2 step motor control
- 80 Geodata arm adjustment and calibration (Hofmann Optima only)
- 81 Geodata arm calibration (Hofmann Optima only)
- 83 Calibration of the unbalance measurement with wheel/test rotor.
- 84 Compensation of unbalance of main shaft
- 85 Copy content of serial EEPROM (EEP) from micro-controller EEP to incremental encoder EEP.
- 86 Copy content of serial EEPROM (EEP) from incremental encoder EEP to micro-controller EEP.
- 88 Calibration of the 12 o'clock position for positioning the weights on the wheel.
- 90 **Saving the adjustments data**
- 98 Display angular position of power clamp pulley, incremental encoder test.
- 110 Indication of the operating voltages supplied by the power supply module.
- 120 Enable / Disable the laser pointer
- 122 Calibration of the Scanner / Laser / CCD assemblies (Inner, Outer and Rear).
- 123 Manufacturing diagnostic and mechanical adjustment test.



C28 DISPLAY AND CLEAR ERROR CODES

The last 10 different malfunction codes are written into the error memory so that they can be called up and reported by the operator of the wheel balancer e.g. for remote diagnosis of malfunctions. The most recent malfunction code is written into memory location 1 and the previous error codes are shifted to the higher memory locations. Displays the internal error code (6 digits).

NOTE: MAKE SPECIAL NOTE OF DIAGNOSTIC CODES THAT RELATE TO A SPECIFIC COMPONENT. REPEATED DIAGNOSTIC CODES POINT TO THE FAILED COMPONENT.

Use the “Enter” key (F4) to proceed to the next error message (reading Err1 -Err10). If no error occurred, “—” is displayed. Clearing the entire error memory (step 2): Press the Acknowledgment key to proceed to step 2. Use the option selection to choose “1” and acknowledge with the “Enter” key (F4).

C43 RESET COUNTERS

This C-Code is used to reset all balancer counters. The following counters are reset. This code will not clear any error codes that have been set into memory.

- Total number of measuring runs
- Number of measuring runs where balance quality was considered OK
- Number of optimizations and minimizations
- Number of measuring runs in service mode
- Number of measuring runs since the last calibration

0: No reset of counters

1: Reset of counters

C47 SELECT MACHINE MODEL

This balancer is sold world wide under different brands and model numbers. To validate any software upgrades. Enter C47, press the <F4> key followed by pressing the <F6> key, the balancer will reboot after a few seconds.

C55 INCOMING LINE VOLTAGE

Measured line voltage going into the electronic box. The correct voltage is 230VAC $\pm$ 10%.

C56 CIRCUIT STATE OF THE WHEEL GUARD

This test function can be used to determine the angle at which the wheel guard switch trips. With the wheel guard in the open (up) position the reading should be 000. Slowly lower the wheel guard to the closed (down) position, the reading will change once to 100 indicating the position of a closed wheel guard. By pressing down on the foot pedal the value should change to "010", by pulling up on the foot pedal the value should change to "001".

C57 VIBRATORY TEMPERATURE SENSOR

Measures the vibratory temperature, measurement displayed in Celcius.

C60 MOTOR RPM

Once this code is called up "---" is displayed in the right display. As soon as measured data is available, the current speed is displayed. The correct value is 190 $\pm$ 10 RPM.

C74 POSITION COUNTER AND BASIC INCREMENTAL SHAFT ENCODER TEST

Once this code is called up, the angular position and incremental encoder status register are display continuously. **For a short test turn the main shaft at least 2 turns in both directions, the status register then must show 23F.** For detailed status information see below.

Angular position:

As long as the incremental encoder has not yet synchronized with the zero reference, the angular location reading is "- - -". After synchronization the angular position is display as a value in a range between 0 and 511.

- 00 after switching power on (main shaft not moved at all), or after pressing the Special function key
- 07 after 2 turns backward → A- and B channel signals are OK, but there is no synchronisation in backward direction.
- 0b after 2 turns forward → A and B channel signals are OK, but there is no synchronisation in forward direction.
- 1b after 2 turns forward/ backward → A and B channel signals are OK, synchronisation in forward rotation is OK as well.
- 1F after 2 turns in each direction A and B channel signals are OK, but synchronisation was made in forward direction only
- 27 after 2 turns backward → A and B channel signals are OK, synchronisation in backward direction is OK as well

-2F after 2 turns in each direction → A and B channel signals are OK, but synchronisation was made in backward direction only.

23F Incremental encoder was rotated by more than 2 turns in each direction and performs properly.

>-40 Synchronisation error in forward direction

>-80 Synchronisation error in backward direction

Comments

If this test fails (**no 23F**) please check

- the cabling of the opto electronic – micro-controller
- the connectors of the cable
- clean the incremental encoder sleeve

C75 DISPLAY VALUES OF A/D CONVERTER

NOTE: SOME OF THESE CODES ARE NOT USED IN THE BFH/OPTIMA SOFTWARE.

AD input	Channel	Description	
AdC 0	0.0	REF-AD	Reference voltage of external AD converter
AdC 1	1.0	fLED-CW	LED current control
AdC 2	2.0	fSON-TMP	Temperature ultrasonic unit
AdC 3	3.0	fBAL-TMP	Temperature of transducer/vibratory system
AdC 4	4.0	fANA3	Motor current
AdC 5	5.0	fANA2	Power interface board multiplexer channel Y
AdC 6	6.0	fANA1	Power interface board multiplexer channel X
AdC 7	7.0	fPOT	free
AdC 8	8.0	fPOT-WHO	Width potentiometer (not used)
AdC 9	9.0	fPOT-OFS	Distance/extraction potentiometer (not used)
AdC 10	10.0	fPOT-DIA	Diameter/angle potentiometer (not used)
AdC 11	11.0	RF1V23	Internal reference voltage of analogue unit potentiometer
AdC 12	12.0	VCC-W	½ voltage of +5V supply
AdC 13	13.0	fLINE-V	Mains voltage control
AdC 14	14.0	AIR	Input of voltage amplifier in front unbalance channel
AdC 15	15.0	AIL	Input of voltage amplifier in rear unbalance channel
AdC 16	5.0	VCSSw*	0.793 * supply voltage to external switches
AdC 17	6.0		free
AdC 18	5.1	VBrCur*	Coil current of solenoid brake (not used)
AdC 19	6.1		free
AdC 20	5.2	VDisp*	Supply voltage of display board
AdC 21	6.2	VAssStat*	Voltage on capacitor of AutoStopSystem
AdC 22	5.3	VRimSens*	Identification of rim material (not used)
AdC23	6.3	VRelCur*	Coil current of relay
AdE 1	AE1		External AD converter (rear transducer)
AdE 2	AE2		External AD converter (front transducer)

* via multiplexer on the power interface

Page left blank intentionally

Page left blank intentionally


Page left blank intentionally

C83 CALIBRATION OF UNBALANCE MEASUREMENT



This test must be done using a Pruefrotor.

NOTE: THIS TEST REQUIRES THE USE OF A PRUEFROTOR. ALL TESTS MUST BE DONE WITH THE BALANCER IN THE MANUAL MODE. AFTER ALL TEST ARE DONE THE BALANCER MUST BE SWITCHED BACK INTO THE PREFERRED OPERATING MODE. ALSO CHECK THE VCC VOLTAGE "C110" AND ADJUST IF NECESSARY BEFORE ANY CALIBRATION IS DONE.


1. Mount the Pruefrotor on the balancer shaft and enter in the parameters of the Pruefrotor using the balance screen.
2. Enter the "**Service**" routine and select C83. Press the **<START>** button to begin the measuring run.




3. After the spin cycle completes, screw the 100 gram weight on the left side of the Pruefrotor and press the **<ENTER>** key (F6) to enter the value of the test weight and to advance to step 3. Press the **<START>** button to begin the measuring run.




4. Remove the 100 gram calibration weight and insert it into the right hand plane of the Pruefrotor. Press the **<START>** key to begin the measuring run.



5. Step Number 5 has not been programmed. Press the **<ENTER>** key (**F6**) to advance to the next step.




6. The ambient transducer temperature is displayed for 1 second.



7. Remove the Pruefroter. Install the small and medium cone on the shaft. Remove the pressure cup from clamping nut and clamp both cones on the shaft. Lower the hood and press the **<START>** button to begin a measuring run.

C83.

7.




START ?

8. Insert the calibration weight that is supplied with the balancer on the left side of the backing plate. Press the **<START>** button to begin a measuring run.
9. Store the new factors using C90.

C83.

8.



START ?


NOTE: MUST COMPLETE C84 AFTER THIS FUNCTION

CALIBRATION COMPLETE


C84 EMPTY SHAFT COMPENSATION

NOTE: THIS PROCEDURE REQUIRES THE USE OF A SPECIAL CALIBRATION RING (EAM0033D53A). DO NOT ATTEMPT THIS PROCEDURE WITHOUT IT. THE BALANCER MUST BE IN THE MANUAL MODE FOR THIS PROCEDURE.

1. Mount the Small Cone, Medium Cone and the clamping sleeve on the shaft.
2. Lower the hood and press the **<START>** button to begin the measuring run.


C84.**1****START ?**

3. After the spin cycle completes remove the clamping sleeve and install the 4mm calibration ring (EAM0033D53A) between the Medium Cone and the clamping sleeve. Press the **<Spin>** button for the balancer to complete a spin cycle. After the balancer comes to a stop the empty shaft calibration is complete.
4. Store the new factors using C90.


C84.**2****Calibration Spacer Ring****CALIBRATION COMPLETE**

C88 WHEEL WEIGHT POSITIONING

1. Mount the Pruefrotor on the balancer shaft and enter in the parameters of the Pruefrotor using the balance screen. Press the **<START>** button to begin the measurement run.




2. Attach the 100 gram weight to outside of the Pruefrotor and press the **<START>** button.



3. After the shaft comes to a complete stop rotate the shaft to locate the 100 gram weight at "**BOTTOM DEAD CENTER**" position. Press the **<ENTER>** key (F6) to save the data.
4. Store the new factors using C90.

CALIBRATION COMPLETE



C90 SAVING CALIBRATION DATA

All calibration data must be saved into memory before powering down the unit. Any data that is not saved will be lost if the power is recycled.

1. Press and hold the **<ENTER VALUES>** key (F4) and rotate the shaft to change the selection window from "0" to "1", release the key.



2. Press the **<ENTER KEY>** to save all previous calibration data to permanent memory.

CALIBRATION DATA SAVED

**C98 POWER CLAMP ENCODER**

Once the code is called up the reading should display "---". After the incremental encoder has identified zero reference, the angular location is displayed in a range between 0 and 63. Use of this C code and meaning are identical with C code 74.

If this test should fail (no 23F) check the following:

- Cables of the opto switch
- Connectors on cable
- Clean the incremental encoder tape.

C110 VCC VOLTAGE



The operating voltage of the processor is $+5.23 \text{ VDC} \pm .25 \text{ volts}$. If the voltage is out of range the balancer may experience a reset problem or it may display 81118b indicating that the voltage is too high or 81018b indicating that the voltage is below the acceptable range. A small adjustment on the balancer power supply can be made. Follow the procedure below to bring the voltage within the acceptable range. Before adjusting the output voltage of the power supply observe the voltage reading using C110 and record this reading. Place a DVM on the input power leads on the embedded PC, the acceptable voltage is $+5.10 \pm .05 \text{ A}$ difference of **.20** volts between the output (power supply pcb) and input (embedded PC) may indicate a problem with a connection or cable. Repairs must be made before attempting the voltage adjustment below.

1. Remove the weight tray.
2. Remove the cover from the power supply.
3. Power up the unit.
4. Enter the service menu and press <C110>.
5. Using a tweaker tool, adjust the voltage between $+5.20$ and $+5.26 \text{ VDC}$.



CAUTION!

HIGH VOLTAGE PRESENT



6. Verify the voltage reading at the embedded PC connection to ensure that it is acceptable.



C120 ENABLE / DISABLE LASER POINTER

0 = Disable laser pointer

1 = Enable laser pointer

This feature will turn the laser on/off during the ALU-S mode. It is recommended that the laser should be enabled.





C122 SCANNER / LASER / CCD CALIBRATION

Before the Scanner assemblies can accurately obtain the data needed to balance the wheel and tire assembly they must be calibrated. The calibration information is stored on the CCD / Scanner PCB. This information is stored automatically after completing the calibration. It is recommended that a check of scanner adjustments be made using the C123 procedure before calibrating the scanner assemblies.

NOTE: THE BALANCER MUST BE IN THE MANUAL MODE AND ALL PRUEFROTOR PARAMETERS ENTERED BEFORE CONTINUING THIS PROCEDURE. AT LEAST TWO REVOLUTIONS OF THE SHAFT SHOULD BE MADE SO THAT THE SHAFT ENCODER CAN LOCATE HOME REFERENCE. THIS CAN BE DONE BY QUICKLY ROTATING THE SHAFT UNTIL THE ENCODER READS.

1. Mount the Pruefroter as shown in the figure on the right, making sure the the orientation of the Pruefroter is turned correctly. Failure to do so will fail the calibration procedure.
2. Using a small magnetic torpedo level, turn the shaft until the Pruefroter is in the verticle position.
3. Press the **<Enter>** key (F6). After doing so the display will change and display a random number. This number is not important however make note of the number for the next step. For our example we have used 133.2.



4. Slowly rotate the shaft clockwise 20° (153.2). The display will quickly show "LOCK" and the magnetic brake of the balancer will engage. The inner scanner will scan the inside profile of the Pruefroter DO NOT MOVE THE SHAFT UNTIL INSTRUCTED. After the scanner completes the profile a beep will sound.



NOTE: LOWER THE HOOD FOR THE FOLLOWING STEPS.

5. Slowly rotate the shaft clockwise 70° (223.2). Once again the **"LOCK"** will display and the magnetic brake will engage.



The outside scanner will begin to take an outside profile of the Pruefrotor. The laser light will move from the balancer shaft out to the end of the Pruefrotor (See the red arrow to the right). After the profile has been taken a beep will sound.

At this point it is possible to proceed two different ways providing you have a "T" calibration tool, UI 2.9 (or higher) AWP 0.71 (or higher). If the balancer has the software and tool to accomodate the "T" fixture proceed to step 6b.

6. Slowly rotate the shaft clockwise 5° (228.2). Once the correct position is reached the **"LOCK"** will be displayed and the magnetic brake will engage and lock the shaft.



The rear scanner will begin to travel and make a complete cycle from the left to the right and back to the left. The scanner is determining the location of the face of the bell housing and the runout profile of the Pruefrotor.

7. The balancer will emit a tone after completing the calibration procedures and an **"END"** will be displayed for step 5. Perform a C90 to store the new calibration factors.

- 6b. Unclamp the Pruefrotor and clamp the "T" fixture on the shaft with the reference hole (yellow arrow) away from the balancer. Using a torpedo level, vertically level the "T" fixture. Press **<F6>** to confirm.

- 7b. Slowly rotate the "T" fixture -85 degrees (CCW) until **"LOCK"** appears and engages the magnetic brake. Hold that position until the brake locks and **"CAL"** appears on the screen. The rear scanner assembly will engage and travel across the back. When the scan is complete the brake WILL NOT release. Firmly grab the "T" fixture and press **<F6>**, the brake will release. Perform a C90 to store the new calibration factors.



NOTE: IF AN "ERROR" OCCURS DURING CALIBRATION REPEAT EACH STEP CAREFULLY. SHOULD AN ERROR OCCUR A SECOND TIME MAKE SURE EACH SCANNER IS ADJUSTED CORRECTLY USING C123.

CALIBRATION COMPLETE

C123 DIAGNOSTIC FUNCTIONS

When troubleshooting the BFH/Optima series balancer it is recommended that the technician use the diagnostic informa-

C122

STEP

3

DWP

223.2

LOCK



C122

STEP

4

DWP

228.2

LOCK



tion that is available on screen in both the C122 and C123 functions. Information from each scanner / laser assembly is reported on screen and is color coded for easy diagnostics. When the balancer is initially powered up the unit will run a self diagnostic test of all internal components. Each of these test are outlined in the service manual (TEEWB519A). After running the internal diagnostic test the software initiates a self test of all 3 scanner and laser assemblies along with the AWP board. If there are any failures to report the technician can determine the failed component using C123. Some failures reported are easily repaired with minor adjustments and calibration and other failures may require scanner replacement.

The information on C122 and C123 is broken into 3 categories:

1. Diagnostic bits - Self diagnostic test on CCD, EEP (memory), Cal (calibration) and ZMarks (home reference). If a Diagnostic bit is in red the unit will display an error code on boot up.
2. Status Flags - Status flags are used to indicate that a command has been issued to a device and the device has responded to the command. This does not mean that the component is functioning correctly.
3. Analog Inputs - There are eight A/D converter channels checked. Normal Analog errors reflect AWP failures.

When analyzing data from C122 / C123 diagnostic screen the scanner and laser assemblies are identified as:



Inside Camera

Car

CCD0 (camera)
EEP0 (memory)
Mot0 (motor)
Zmark0 (motor home)

Outside Camera

CCD1 (camera)
EEP1 (memory)
Mot1 (motor)
ZMark1 (motor home)

Rear Camera

CCD2 (camera)
EEP2 (memory)
Mot2 (motor)
ZMark2 (motor home)

Rear Slide

Mot3 (motor)
ZMark3 (motor home)

ACCESSING THE DIAGNOSTIC FEATURES

1. From the Introduction Screen press the <FUNCTION> key (F1) to enter in to the Function Menu.



2. By pressing the <F6> key 3 times successively the "SERVICE" key (F4) will become active.

NOTE: BEFORE PERFORMING ANY "C-CODES" ON THE BFH/OPTIMA BALANCER THE TECHNICIAN MUST FORCE THE BALANCER INTO THE MANUAL MODE.



3. By pressing the **<F4>** key the service program will become active.



4. Press and hold the **<C-CODE>** key (F1) and rotate the main shaft the to select C122 or C123. Release the **<F1>** key once the desired C-code is displayed.



BFH_1K 3.1.1
24.03.2006
14:07

SERVICE CODE



C123 .

Step		1				
DWP		127.3				
Diag						
MainPw	MainAdc	MainEEP	MainCal	Z0Fail	Z0Mark	Ch0: 5.21
CCD0	EEP0Ack	EEP0Chk	EEP0Cal	Z1Fail	Z1Mark	Ch1: -4.94
CCD1	EEP1Ack	EEP1Chk	EEP1Cal	Z2Fail	Z2Mark	Ch2: 3.31
CCD2	EEP2Ack	EEP2Chk	EEP2Cal	Z3Fail	Z3Mark	Ch3: 9.14
Las0Ena	Las0Pw	Las0Pwm	Mot0Pw	Mot0Chk	Mot0Ena	Ch4: 0.00
Las1Ena	Las1Pw	Las1Pwm	Mot1Pw	Mot1Chk	Mot1Ena	Ch5: 0.00
Las2Ena	Las2Pw	Las2Pwm	Mot2Pw	Mot2Chk	Mot2Ena	Ch6: 0.00
Busy	MsEnc	MotorPw	Mot3Pw	Mot3Chk	Mot3Ena	Ch7: 0.00

BEAN

F 1	F 2	F 3	F 4	F 5	F 6
C-CODE			ENTER VALUES		ENTER

MainPw(0) MainAdc(36) MainEEP(4) MainCal(8) Z0Fail(12) Z0Mark(28) Ch0:X.XX
 CCD00(1) EEP0Ack(33) EEP0Chk(5) EEP0Cal(9) Z1Fail(13) Z1Mark(29) Ch1:X.XX
 CCD1(2) EEP1Ack(34) EEP1Chk(6) EEP1Cal(10) Z2Fail(14) Z2Mark(30) Ch2:X.XX
 CCD2(3) EEP2Ack(35) EEP2Chk(7) EEP2Cal(11) Z3Fail(15) Z3Mark(31) Ch3:X.XX
 Las0Ena(45) Las0Pw(37) Las0Pwm(41) Mot0Pw(20) Mot0Chk(16) Mot0Ena(24) Ch4:X.XX
 Las1Ena(46) Las1Pw(38) Las1Pwm(42) Mot1Pw(21) Mot1Chk(17) Mot1Ena(25) Ch5:X.XX
 Las2Ena(47) Las2Pw(39) Las2Pwm(43) Mot2Pw(22) Mot2Chk(18) Mot2Ena(26) Ch6:X.XX
 Busy(44) MsEnc(40) MotorPw(32) Mot3Pw(23) Mot3Chk(19) MoteEna(27) Ch7:X.XX

DIAGNOSTIC BITS (SHOWN IN BLACK)

Diagnostic bits, 0 (failure) is displayed in **RED**, 1 (ok) is **GRAY**.

Note: Diagnostics bits will produce an error code.

Bit	Shown label	Meaning	Notes
0	MainPw	Analog/logic power supply	
1	CCD0	Inner CCD signals	
2	CCD1	Outer CCD signals	
3	CCD2	Rear CCD signals2	
4	MainEEP	Main board EEPROM memory valid	
5	EEP0Chk	Inner EEPROM memory valid	
6	EEP1Chk	Outer EEPROM memory valid	
7	EEP2Chk	Rear EEPROM memory valid	2
8	MainCal	Cameras calibration (E360,C122)	
9	EEP0Cal	Inner scanner factory calibration	
10	EEP1Cal	Outer scanner factory calibration	
11	EEP2Cal	Rear scanner factory calibration	2
12	Z0Fail	Inner motor home mark detection	
13	Z1Fail	Outer motor home mark detection	
14	Z2Fail	Rear motor home mark detection	2
15	Z3Fail	Rear shift motor home mark detection	2
16	Mot0Chk	Inner motor missing steps	
17	Mot1Chk	Outer motor missing steps	
18	Mot2Chk	Rear motor missing steps	2
19	Mot3Chk	Rear shift motor missing steps	2
20	Mot0Pw	Inner motor current sink / power check	1
21	Mot1Pw	Outer motor current sink / power check	1
22	Mot2Pw	Rear motor current sink / power check	1 - 2
23	Mot3Pw	Rear shift motor current sink / power check	1 - 2
32	MotorPw	External motor power supply	1
33	EEP0Ack	Inner EEPROM memory ACK	
34	EEP1Ack	Outer EEPROM memory ACK	
35	EEP2Ack	Rear EEPROM memory ACK	2
36	MainAdc	Camera board A/D converter check	
37	Las0Pw	Inner laser current sink / power check	1
38	Las1Pw	Outer laser current sink / power check	1
39	Las2Pw	Rear laser current sink / power check	1 - 2
40	MsEnc	Shaft encoder zero mark detection	3
41	Las0Pwm	Inner laser modulation	1
42	Las1Pwm	Outer laser modulation	1
43	Las2Pwm	Rear laser modulation	1 - 2

**Notes:**

1. Available only on new camera boards (EAP0204G50B), default to 1 on former boards.
2. Obviously fails on any BFH/Optima without the rear scanner. (this unit does not have a rear scanner and camera assembly)
3. Valid after runout measurement only.

STATUS FLAGS (SHOWN IN BLUE)

Status Bits, 0 (disable) is displayed in **GRAY**, 1 (enable) is **BLUE**.

Bit	Displayed	Meaning
24	Mot0Ena	Inner motor power enable
25	Mot1Ena	Outer motor power enable
26	Mot2Ena	Rear motor power enable
27	Mot3Ena	Rear shift motor power enable
28	Z0Mark	Inner motor home mark
29	Z1Mark	Outer motor home mark
30	Z2Mark	Rear motor home mark
31	Z3Mark	Rear shift motor home mark
44	Busy	Firmware ready/busy status
45	Las0Ena	Inner laser power enable
46	Las1Ena	Outer laser power enable
47	Las2Ena	Rear laser power enable

**ANALOG INPUTS: (SHOWN IN GREEN)**


For **Analog Values**, normal data is **GREEN**, out of range is **RED**.

Ch	Analog input	Valid range
0	5.00 V power supply	4.80 V ÷ 5.60 V
1	-5.00 V analog power supply	-5.60 V ÷ -4.80 V
2	3.30 V logic power supply	3.00 V ÷ 3.60 V
3	9.00 V external motor power supply	8.00 V ÷ 12.00 V
4	AUX 0 external input	0 V ÷ 4.096 V
5	AUX 1 external input	0 V ÷ 4.096 V
6	Laser current sink	0 V ÷ 4.096 V
7	Motor current sink	0 V ÷ 4.096 V

C123 MECHANICAL SCANNER / LASER / CCD ADJUSTMENT

If the BFH/Optima balancer fails any part of the C122 camera calibration it may be necessary to adjust one or more of the cameras. If any of the Scanner assemblies require replacement it will also be necessary to check the mechanical adjustment before calibration.

1. Access the service menu and program the balancer to run C123.
2. Step 1 accesses and activates the inside laser and "motor 0". Press the **<Enter>** key (F6) to start the inside scanner. Deactivate the scanner motor by pressing the **<Enter>** key (F6).




3. Looking down at the anchor tab just under the main shaft a laser light will be illuminated. The figure to the right shows the direction of travel. The scanner must stop somewhere between the two black illustrated lines. See **"Inside Scanner Adjustment"** for procedure.




4. Press the **<Enter Values>** key (F4) and turn the shaft to proceed to the outside scanner.
5. Step 2 accesses and runs the outside scanner test "motor 1". The Pruefroter must be mounted on the shaft to verify the accuracy of this test.


NOTE: THE HOOD OF THE BALANCER MUST CLOSE TO THE CORRECT HEIGHT BEFORE ANY ADJUSTMENTS ARE MADE. SEE "HOOD ADJUSTMENT" FOR THIS PROCEDURE.




7. Press the **<Enter>** key (F6) to start the outside scanner motor and laser. The laser must scan horizontally across the Pruefroter towards the back of the balancer. See *Outside Scanner Adjustment* for procedure. Press the **<Enter>** key to stop the scanner motor and to proceed to the next step.



8. Press the **<Enter Value>** key (F4) and turn the shaft to access the rear scanner "motor 2". Rotate the Pruefroter forward 5° from a level position.



9. Press the **<Enter>** key (F6). The rear scanner assembly will leave the home position and stop towards the middle. The scanner motor will begin to move between two fixed points. The laser line should fall somewhere within the cutout hole on the Pruefroter.



If the laser line does not scan the preferred area, adjust the hex screw on the back of the assembly to move the laser to the correct position.




Hex adjustment screw

10. Press the **<Enter>** key to stop the scanner motor and to proceed to step 4. Press and hold the **<Enter Value>** key (F4) and turn the shaft to access the rear scanner horizontal drive "motor 2".



11. Remove the Pruefroter from the shaft. Press the **<Enter>** key (F6). The rear scanner will begin to scan from left to right. From the rear of the unit see where the laser line is running along the shaft. The rear drive laser should run parallel with the shaft and in the center. If the laser does not run parallel with the shaft the rear scanner assembly may not be mounted parallel with the cabinet or the vibratory system may not be level with the cabinet. Press the **<Enter>** key (F6) to stop the motor drive. Press the **<Esc>** key on the keyboard to exit this test.




CCD / LASER / SCANNER INSTALLATION

Should any of the scanner assemblies require replacement it will be necessary to make some mechanical adjustment before calibrating the unit (C83, 84, 88 and 122) and returning it to service. These adjustments should run parallel with the C123. **The ribbon cable that feeds the CCD must have some slack at the scanner assembly.** This can be tested by manually pressing on the scanner assemblies. A small amount of play is necessary and they should return to the home position.


INNER SCANNER INSTALLATION



1. Power down the unit.
2. Remove the 4 phillip screws that secure the shield.




3. It may be necessary to manually swing the scanner assembly downward to access the bolts that secure the assembly to the vibratory.
4. Remove the two Socket Head Cap Screw that secure the assembly to the vibratory. DO NOT DROP THE SCANNER ASSEMBLY.
5. Disconnect all cables and reverse this procedures for installation.



OUTER SCANNER INSTALLATION

1. Power down the unit.
2. Remove the 4 phillip screws that secure the shield.
3. Firmly hold the scanner assembly and remove the 2 Socket Head Cap Screw (1 and 2) that secure the scanner assembly to the hood frame.
4. Disconnect all cable assemblies and reverse the procedure for installation.




NOTE: IF A CABLE IS REPLACED AND A ZIP TIE IS CUT OR SILICON ADHESIVE BOND IS BROKEN IT IS VERY IMPORTANT TO REINSTALL THESE SECURING FEATURES.

HOOD ADJUSTMET

Before making any adjustments to the outside scanner it is recommended that the hood be checked for the proper height in the closed position. Failure to do so could cause the outside scanner to fail during a C122 calibration.

5. Measure the distance from the ground to the center of the shaft and record this distance. Measure distance between the ground and the center of the adjustment screw labeled (3) in the figure above. If the measurements are different the hood must be adjusted to match the two measurements.
6. Loosen the Hex screw on the back side of the hood block. Loosen the jam nut (yellow). Using a wrench turn the adjustment screw (red) until while monitoring the height between the ground and the screw mentioned in step 5.






OUTER SCANNER INSTALLATION *CONTINUED*

The HOME reference and the orientation of the projected laser can only be adjusted using the mounting screws listed below. **NOTE: DO NOT TAMPER WITH THE SCANNER ASSEMBLY. THE SCANNER ASSEMBLY COMES CALIBRATED FROM THE FACTORY.**

7. Mount a Pruefroter on the balancer shaft and secure. Program the balancer for step 2 of C123. Verify that the laser light moves horizontally from left to right. The illustrations below show the direction that the laser line moves using the adjustments screws. Each direction of movement can and will effect the other adjustments. In most cases the number (1 & 2) adjustment screw is the only needed movement after replacement of a scanner. Secure all screws.
8. If the number 1 & 2 adjustment screw do not bring the laser within specification it may be necessary to adjust all adjustment screws. Before doing so it is recommended to level the scanner in two locations before any adjustments are made. Doing so will bring the scanner very close to specs and only a small amount of adjustment will be necessary. Level the scanner in the two locations indicated.






9. Using the adjustment points below will adjust the projected scanner light in the following orientation.



REAR SCANNER INSTALLATION

1. Remove the rear cover from the Slide Car.
2. Remove the philip screws from the scanner box.
3. Remove the front glass from the scanner box.
4. Remove the (1) Hex screw securing the scanner assembly and disconnect all wires.
5. Special attention must be spent when installing the rear scanner assembly. The scanner bracket and the mounting bracket must be aligned parallel with each other.
6. Install the protection glass onto the scanner box assembly.
7. Program step 4 of C123.
8. Look at the reflection of the laser back on the scanner. The reflection should come close to being on top of the original light source.



NOTE: AFTER ANY CHANGES AND OR ADJUSTMENTS TO EACH OF THE 3 SCANNERS THE BALANCER MUST BE CALIBRATED. FAILURE TO CALIBRATE THE BALANCER WILL YIELD ERRORS.



REAR SCANNER DRIVE BELT

The belt that drives the rear scanner inside the housing is a one piece cog belt. Over time the belt may be come hard and brittle and require replacement. The belt will come as a single belt that needs to simply be cut. The rear scanner assembly moves across the back of the balancer using a drive motor mentioned earlier. The drive motor has a cog gear mounted that drives the scanner assembly.


1. Loosen the two Phillips sheet metal screws and remove the broken or damaged drive belt.
2. Remove the rear cover of the rear drive assembly.
3. Using a pair of scissors cut the new drive belt and install the one end of the belt with the cog side facing down.
4. Feed the belt through the drive assembly. It may be necessary to loosen the motor to feed the belt through. Once the belt is installed lift up on the drive motor, this will tighten the belt and not allow it to slip off the gear drive.
5. Tighten each end that secures the belt. **DO NOT OVER TIGHTEN THE SCREWS SECURING THE BELT, THIS MAY CUT THROUGH THE BELT.**
6. Snip the remaining excess and retest the rear drive.



FIELD PROGRAMMING THE CAMERA PROCESSOR PCB

The BFH/Optima has two processors that can be programmed. The main processor which is inside of the Electronic box and the Camera Controller PCB. Each processor is programmed using the EEPROM socket on the Main Processor PCB. Programming the main Processor is mentioned earlier in this manual. The camera processor PCB is flashed in the same manner.


1. Turn off balancer.
2. Place EEPROM in micro-controller socket with flat end at bottom of socket close to large blue connector. The notched end is 3 spaces short of other end of socket.
3. Turn on balancer.
4. The following is a sequence of events that will take place; three light audible beeps accompanied by 3 green light flashes on the Camera PCB followed by 1 red flash followed by 3 more green flashes followed by a constant flicker of the red LED. (Location Circled Below).
5. A continuous sequence of tones will sound from the keyboard indicating that the program loading is complete and the red LED will stop flashing.
6. Turn off the balancer.
7. Remove EEPROM and turn on the balancer.
8. The normal startup procedure will be performed.



NOTE: IF A NEW COMPACT FLASH IS INSTALLED ON THE EMBEDDED PC IT WILL BE NECESSARY TO PERFORM A "C47" AFTER INSTALLTION. FAILURE TO DO SO WILL NOT DISPLAY ANY NEW GRAPHICS OR FEATURES THAT WERE INSTALLED.

9. Perform service codes in the following order;
 - **C123** - Verify all scanner are profiling correctly
 - **C122**- Calibration of all 3 scanner assemblies.

The machine is now ready for use.



REMOVING THE BELL HOUSING

It may be necessary to remove the bell housing from the vibratory member to either clean or replace it. Follow the process below.

1. Un-plug the balancer from the power source.
2. It may be necessary to remove the weight tray. Using a 13mm wrench slightly loosen the 2 bolts securing the bell housing to the main shaft.
3. Turn the main shaft and the bell housing opposite direction to line the Hex Head Cap Screw with the keyhole.
4. Using a rubber mallet tap the face of the bell housing to break taper of the shaft.
5. Pull the bell housing out away from the balancer.
6. Hold the main shaft and turn the bell housing clockwise, un-screwing and separating the two shafts.
7. When installing a new bell housing or re-installing the old bell housing make sure that both tapered portions are clean and free from any dirt particles. Failure to do so may cause damage to both pieces and separation may be impossible.
8. Always make sure that the bell housing is fully screwed onto the main shaft before aligning the key holes. This can be accomplished by pulling the bell housing away from the balancer and making sure that the bell housing is fully screwed onto the main shaft.



IMPORTANT BALANCER INFORMATION

Before calling technical support it will be necessary to know what revision of balancer is being serviced. Follow the steps below to enter the "Info" screen.



1. From the Introduction Screen press the "**FUNCTION**" key (F1) to enter in to the Function Menu.
2. By pressing the **F6** key 3 times successively the "**INFO**" key (F3) will show.



3. By pressing the **F3** key the "**INFO**" will become active.



4. Make note of the following line items:
User Interface - Revision Number and Date (Revision may not change however date may.
Balancer Kernel - Revision Number and Date
Display - Revision Number and Date
Optima - AWP, Version Number

QUALIFYING THE BALANCER

The BFH/Optima is a very precision piece of equipment. In order for each scanner to accurately measure tire and wheel profiles each scanner must be adjusted and calibrated within manufactures specification. Below is a step by step procedure that can easily be followed to qualify the BFH/Optima . Each of these procedures should be checked on every service call. These steps will validate each component, should a failure of a component occur the balancer will not pass one of these test and it will be necessary to complete a more in depth analysis.

1. Change the balancer to manual mode (Page 5-12)
2. Check C55 for the proper supply VAC in.
3. Check C110 for proper voltage +5.23 VDC $\pm$.05
4. Check that the proper voltage is being supplied to the embedded PC+5.00 VDC $\pm$.25 volts. (See adjustment)
5. 9 volt camera power supply - The output voltage of the camera power supply is 9.25 VDC $\pm$.25 (See adjustment)
6. C83 - Manufactures vibratory calibration. (Pruefroter required)
7. C84 - Empty shaft calibration. (4mm Calibration ring required)
8. C88 - Top Dead Center (TDC) wheel weight positioning. (Pruefroter required)
9. C123 - Mechanical adjustment of all three camera assemblies.
10. C122 - Calibration of all three camera assemblies. (Pruefroter required)
11. Change from Manual Mode back to customers preference.

NOTE: RUN A C90 PROCEDURE AFTER STEPS 4,5& 6.