

TRANSMISSION SECTION

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition.

When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

CONTROL SYSTEMS	CS
AUTOMATIC TRANSMISSION	4AT
AUTOMATIC TRANSMISSION (DIAGNOSTICS)	4AT(diag)
AUTOMATIC TRANSMISSION	5AT
AUTOMATIC TRANSMISSION (DIAGNOSTICS)	5AT(diag)
MANUAL TRANSMISSION AND DIFFERENTIAL	5MT
CLUTCH SYSTEM	CL

# AUTOMATIC TRANSMISSION

# 4AT

	Page
1. General Description .....	2
2. Automatic Transmission Fluid .....	31
3. Differential Gear Oil .....	33
4. Road Test .....	34
5. Stall Test .....	35
6. Time Lag Test .....	37
7. Line Pressure Test .....	38
8. Transfer Clutch Pressure Test .....	39
9. Automatic Transmission Assembly .....	40
10. Transmission Mounting System .....	48
11. Extension Case Oil Seal .....	50
12. Differential Side Retainer Oil Seal .....	51
13. Inhibitor Switch .....	52
14. Front Vehicle Speed Sensor .....	55
15. Rear Vehicle Speed Sensor .....	58
16. Torque Converter Turbine Speed Sensor .....	59
17. Control Valve Body .....	60
18. Air Bleeding of Control Valve .....	63
19. ATF Filter .....	64
20. Transmission Control Module (TCM) .....	65
21. Lateral G Sensor .....	66
22. ATF Cooler Pipe and Hose .....	67
23. ATF Cooler (with warmer function) .....	72
24. Warmer Cock .....	76
25. Air Breather Hose .....	78
26. Oil Charge Pipe .....	79
27. Torque Converter Clutch Assembly .....	80
28. Extension Case .....	82
29. Transfer Clutch .....	86
30. Multi-plate Clutch .....	92
31. Rear Drive Shaft .....	93
32. Reduction Driven Gear .....	94
33. Reduction Drive Gear .....	96
34. Center Differential Carrier .....	98
35. Parking Pawl .....	100
36. Converter Case .....	101
37. Oil Pump Housing .....	103
38. Drive Pinion Shaft Assembly .....	108
39. Front Differential Assembly .....	113
40. AT Main Case .....	119
41. Transmission Control Device .....	140

# General Description

## AUTOMATIC TRANSMISSION

### 1. General Description

#### A: SPECIFICATION

##### 1. TORQUE CONVERTER CLUTCH

Model	2.0 L	2.5 L
Type	Symmetric, 3 element, single stage, 2 phase torque converter	
Stall torque ratio	2.0 — 2.2	2.1 — 2.3
Nominal diameter mm (in)	236 (9.29)	249 (9.69)
Stall speed (at sea level)	2,300 — 2,700 rpm	2,500 — 2,900 rpm
One-way clutch	Sprague type one-way clutch	

##### 2. OIL PUMP

Type	Pracoid constant-displacement pump	
Driving method	Driven by engine	
Number of teeth	Inner rotor	9
	Outer rotor	10

##### 3. TRANSMISSION CONTROL ELEMENT

Type	4-forward, 1-reverse, double-row planetary gears
Multi-plate clutch	3 sets
Multi-plate brake	2 sets
One-way clutch (sprague type)	1 sets

##### 4. TRANSMISSION GEAR RATIO

1st	2.785
2nd	1.545
3rd	1.000
4th	0.694
Rev	2.272

##### 5. PLANETARY GEAR AND PLATE

Model	2.0 L	2.5 L
Front sun gear number of teeth	33	
Front pinion number of teeth	21	
Front internal gear number of teeth	75	
Rear sun gear number of teeth	42	
Rear pinion number of teeth	17	
Rear internal gear number of teeth	75	
Drive plate number of high clutch	4	
Drive plate number of low clutch	4	5
Drive plate number of reverse clutch	2	
Drive plate number of 2-4 brake	2	3
Drive plate number of low & reverse brake	4	5

##### 6. SELECTOR POSITION

P (Park)	Transmission in neutral, output member immovable, and engine start possible
R (Reverse)	Transmission in reverse for backing
N (Neutral)	Transmission in neutral and engine start possible
D (Drive)	4-forward automatic gear change 1st $\leftarrow$ 2nd $\leftarrow$ 3rd $\leftarrow$ 4th
SPORT mode	4-forward automatic gear change 1st $\leftarrow$ 2nd $\leftarrow$ 3rd $\leftarrow$ 4th
Manual mode (+)	4-forward manual gear change (shift up) 1st $\rightarrow$ 2nd $\rightarrow$ 3rd $\rightarrow$ 4th
Manual mode (-)	4-forward manual gear change (shift down) 1st $\leftarrow$ 2nd $\leftarrow$ 3rd $\leftarrow$ 4th
Control method	Wire cable

# General Description

AUTOMATIC TRANSMISSION

## 7. HYDRAULIC CONTROL AND LUBRICATION

Type	Electronic hydraulic control [Four forward speed changes by electrical signals of vehicle speed and accelerator (throttle) opening]
Fluid	SUBARU ATF or Idemitsu "Apolloil ATF HP", Castrol "Transmax J" NOTE: If the ATFs above are not available, use Dexron III.
Fluid capacity ℓ (US qt, Imp qt)	8.4 — 8.7 (8.9 — 9.2, 7.4 — 7.7)
Lubrication system	Forced feed lubrication with oil pump
Oil	Automatic transmission fluid (above mentioned)

## 8. COOLING AND HARNESS

Cooling System	Liquid-cooled cooler
Inhibitor switch	12 poles
Transmission harness	20 poles

## 9. TRANSFER

Model	2.0 L	2.5 L without vehicle dynamics control (VDC)	2.5 L with vehicle dynamics control (VDC)
Transfer type	Multi-plate transfer (MPT)		Variable torque distribution (VTD)
Drive & driven plate number of transfer clutch	4	5	3
Control method	Electronic hydraulic type		
Lubricant	The same Automatic transmission fluid used in automatic transmission		
Reduction gear ratio	1.000 (53/53)		

## 10.FINAL REDUCTION

Model	Except for OUTBACK	OUTBACK
Front final reduction gear ratio	4.111 (37/9)	4.444 (40/9)

## 11.RECOMMENDED GEAR OIL


Lubrication oil	<p>(1) Item</p> <p>(2) Front differential gear oil</p> <p>(3) API classification</p> <p>(4) SAE viscosity No. and applicable temperature</p>
Front differential oil capacity ℓ (US qt, Imp qt)	1.1 — 1.3 (1.2 — 1.4, 1.0 — 1.1)

# General Description

## AUTOMATIC TRANSMISSION

### B: COMPONENT

#### 1. TORQUE CONVERTER CLUTCH AND CASE



AT-02159

- |                                  |   |                            |
|----------------------------------|---|----------------------------|
| (1) Pitching stopper bracket     | (10) O-ring   | (18) Bracket (if equipped) |
| (2) O-ring                       | (11) Torque converter clutch ASSY                       | (19) Clip (if equipped)    |
| (3) Differential oil level gauge | (12) Drain plug   |                            |
| (4) Stay                         | (13) Gasket   |                            |
| (5) Seal pipe                    | (14) Oil seal   |                            |
| (6) Oil pump shaft               | (15) Converter case                                     |                            |
| (7) Clip                         | (16) Harness stay                                       |                            |
| (8) Oil drain pipe               | (17) ATF cooler ASSY with warmer function (if equipped) |                            |
| (9) Input shaft                  |   |                            |

#### **Tightening torque: N·m (kgf-m, ft-lb)**

**T1: 18 (1.8, 13.0)**


**T2: 23 (2.3, 16.7)**

**T3: 33 (3.4, 24.3)**

**T4: 41 (4.2, 30.4)**

**T5: 70 (7.1, 51.6)**

## 2. OIL PUMP



AT-00003

- (1) Oil pump rotor
- (2) Oil pump cover
- (3) Seal ring
- (4) Thrust needle bearing
- (5) Drive pinion shaft
- (6) Roller bearing
- (7) Shim
- (8) Oil pump housing
- (9) Nipple
- (10) Air breather hose

- (11) Gasket
- (12) O-ring
- (13) Test plug
- (14) Stud bolt
- (15) O-ring
- (16) O-ring
- (17) Oil seal retainer
- (18) Oil seal
- (19) O-ring
- (20) Drive pinion collar

- (21) Lock nut


### **Tightening torque: N·m (kgf-m, ft-lb)**

- T1: 7 (0.7, 5.1)**
- T2: 13 (1.3, 9.4)**
- T3: 18 (1.8, 13.0)**
- T4: 25 (2.5, 18.1)**
- T5: 40 (4.1, 30)**
- T6: 42 (4.3, 31)**
- T7: 116 (11.8, 85)**

# General Description

## AUTOMATIC TRANSMISSION

### 3. TRANSMISSION CASE AND CONTROL DEVICE



# General Description

## AUTOMATIC TRANSMISSION

(1) ATF level gauge	(19) Oil pan	(37) Transmission case
(2) Oil charge pipe	(20) Magnet	(38) Plate ASSY
(3) O-ring	(21) Stud bolt (Short)	(39) Washer
(4) Straight pin	(22) Stud bolt (Long)	(40) Inlet pipe (Model with ATF cooler with warmer function)
(5) Return spring	(23) Parking rod	(41) Outlet pipe (Model with ATF cooler with warmer function)
(6) Shaft	(24) Manual plate	
(7) Parking pawl	(25) Spring pin	
(8) Parking support	(26) Detention spring	
(9) Bushing	(27) Ball	
(10) Gasket	(28) Spring	
(11) Inlet pipe (Model without ATF cooler with warmer function)	(29) Gasket	
(12) Union screw	(30) Outlet pipe (Model without ATF cooler with warmer function)	
(13) O-ring	(31) Union screw	
(14) Test plug	(32) Oil seal	
(15) Oil filter	(33) Select lever	
(16) Oil filter stud bolt	(34) Inhibitor switch ASSY	
(17) Drain plug	(35) Nipple	
(18) Gasket	(36) Air breather hose	

### **Tightening torque: N·m (kgf-m, ft-lb)**

**T1: 3.4 (0.35, 2.5)**

**T2: 5 (0.5, 3.6)**

**T3: 6 (0.6, 4)**

**T4: 12 (1.2, 8.7)**

**T5: 13 (1.3, 10)**

**T6: 14 (1.4, 10)**

**T7: 18 (1.8, 13)**

**T8: 21 (2.1, 15.5)**

**T9: 25 (2.5, 18.1)**


**T10: 44 (4.5, 32.5)**



# General Description

## AUTOMATIC TRANSMISSION

### 4. CONTROL VALVE AND HARNESS ROUTING



AT-01322


- |   |                                |
|---|--------------------------------|
| (1) Stay                                  | (6) O-ring                     |
| (2) Transmission harness                  | (7) Front vehicle speed sensor |
| (3) O-ring                                | (8) O-ring                     |
| (4) O-ring                                | (9) Rear vehicle speed sensor  |
| (5) Torque converter turbine speed sensor | (10) Control valve body        |

**Tightening torque: N·m (kgf-m, ft-lb)**

**T1: 7 (0.7, 5.1)**

**T2: 8 (0.8, 5.8)**

## 5. HIGH CLUTCH AND REVERSE CLUTCH




AT-00006

- |                           |                                    |                                       |
|---------------------------|------------------------------------|---------------------------------------|
| (1) High clutch drum      | (8) Spring retainer                | (15) Dish plate                       |
| (2) Lip seal              | (9) Cover                          | (16) Driven plate (reverse clutch)    |
| (3) D-ring                | (10) Snap ring                     | (17) Drive plate (reverse clutch)     |
| (4) Reverse clutch piston | (11) Driven plate (high clutch)    | (18) Retaining plate (reverse clutch) |
| (5) D-ring                | (12) Drive plate (high clutch)     | (19) Snap ring                        |
| (6) D-ring                | (13) Retaining plate (high clutch) | (20) Thrust needle bearing            |
| (7) High clutch piston    | (14) Snap ring                     | (21) High clutch hub                  |

## General Description


### 6. PLANETARY GEAR AND 2-4 BRAKE



AT-00007

- |                             |                            |                                |
|-----------------------------|----------------------------|--------------------------------|
| (1) Thrust needle bearing   | (10) Washer                | (19) Snap ring                 |
| (2) Front sun gear          | (11) Thrust needle bearing | (20) Spring retainer           |
| (3) Thrust needle bearing   | (12) Rear internal gear    | (21) 2-4 brake piston          |
| (4) Snap ring               | (13) Washer                | (22) D-ring                    |
| (5) Front planetary carrier | (14) Snap ring             | (23) D-ring                    |
| (6) Thrust needle bearing   | (15) Retaining plate       | (24) 2-4 brake piston retainer |
| (7) Rear sun gear           | (16) Drive plate           | (25) 2-4 brake seal            |
| (8) Thrust needle bearing   | (17) Driven plate          | (26) Leaf spring               |
| (9) Rear planetary carrier  | (18) Pressure rear plate   |                                |

## 7. LOW CLUTCH AND LOW & REVERSE BRAKE




AT-01278

- |                        |                                |                                 |
|------------------------|--------------------------------|---------------------------------|
| (1) Snap ring          | (12) Low clutch drum           | (23) Return spring              |
| (2) Retaining plate    | (13) Needle bearing            | (24) Snap ring                  |
| (3) Drive plate        | (14) Snap ring                 | (25) Retaining plate            |
| (4) Driven plate       | (15) One-way clutch            | (26) Leaf spring                |
| (5) Dish plate         | (16) Snap ring                 | (27) Drive plate                |
| (6) Snap ring          | (17) Thrust needle bearing     | (28) Driven plate               |
| (7) Cover              | (18) Seal ring                 | (29) Dish plate                 |
| (8) Spring retainer    | (19) Needle bearing            | (30) Low & reverse brake piston |
| (9) D-ring             | (20) One-way clutch inner race |                                 |
| (10) Low clutch piston | (21) Socket bolt               |                                 |
| (11) D-ring            | (22) Spring retainer           |                                 |

**Tightening torque: N·m (kgf-m, ft-lb)**

**T: 25 (2.5, 18.1)**

## 8. REDUCTION GEAR




- (1) Seal ring
- (2) Ball bearing
- (3) Reduction drive gear
- (4) Reduction drive shaft
- (5) Drive pinion shaft

- (6) Snap ring
- (7) Ball bearing
- (8) Snap ring
- (9) Reduction driven gear
- (10) Washer

- (11) Lock nut

**Tightening torque: N·m (kgf·m, ft·lb)**  
**T: 100 (10.2, 73.8)**

## 9. REDUCTION GEAR WITH VTD




AT-02203

- |                            |                                   |                            |
|----------------------------|-----------------------------------|----------------------------|
| (1) Ball bearing           | (13) Rear drive shaft             | (25) Snap ring             |
| (2) Reduction drive gear   | (14) Ball bearing                 | (26) Ball bearing          |
| (3) Washer                 | (15) Multi-plate clutch (LSD) hub | (27) Snap ring             |
| (4) Needle bearing         | (16) Ball bearing                 | (28) Reduction driven gear |
| (5) Pinion gear            | (17) Revolution gear              | (29) Lock washer           |
| (6) Carrier                | (18) Driven plate (Thicker)       | (30) Lock nut              |
| (7) Planetary pinion shaft | (19) Drive plate                  | (31) Gasket                |
| (8) Snap ring              | (20) Driven plate (Thinner)       | (32) Extension case        |
| (9) Seal ring              | (21) Driven plate (Thicker)       |                            |
| (10) Thrust needle bearing | (22) Pressure plate               |                            |
| (11) Intermediate shaft    | (23) Rear drive shaft shim        |                            |
| (12) Thrust washer         | (24) Drive pinion shaft           |                            |

**Tightening torque: N·m (kgf-m, ft-lb)**

**T: 100 (10.2, 73.8)**

## 10.DIFFERENTIAL GEAR



AT-00011

- |                            |                                |
|----------------------------|--------------------------------|
| (1) Hypoid driven gear     | (7) Oil seal                   |
| (2) Pinion shaft           | (8) O-ring                     |
| (3) Differential case (RH) | (9) Differential side retainer |
| (4) Straight pin           | (10) Lock plate                |
| (5) Differential case (LH) | (11) Washer                    |
| (6) Taper roller bearing   | (12) Differential bevel pinion |


- (13) Differential bevel gear

**Tightening torque: N·m (kgf·m, ft·lb)**

**T1: 25 (2.5, 18.1)**

**T2: 62 (6.3, 45.6)**

## 11. TRANSFER AND EXTENSION CASE



AT-01784

- (1) Thrust needle bearing
- (2) Needle bearing
- (3) Snap ring
- (4) Pressure plate
- (5) Drive plate
- (6) Driven plate
- (7) Retaining plate
- (8) Snap ring
- (9) Transfer piston seal

- (10) Return spring
- (11) Transfer clutch piston
- (12) Rear drive shaft
- (13) Ball bearing
- (14) Seal ring
- (15) Gasket
- (16) Transfer clutch pipe
- (17) Extension case
- (18) Transmission hanger

- (19) Oil seal
- (20) Dust cover
- (21) Test plug
- (22) O-ring

**Tightening torque: N·m (kgf-m, ft-lb)**

**T1: 13 (1.3, 9.4)**


**T2: 25 (2.5, 18.1)**



# General Description

## AUTOMATIC TRANSMISSION

### 12.TRANSFER AND EXTENSION CASE WITH VTD



- (1) Driven plate (Thicker)
- (2) Drive plate
- (3) Driven plate (Thinner)
- (4) Driven plate (Thicker)
- (5) Adjusting plate
- (6) Snap ring
- (7) Spring retainer
- (8) Plate
- (9) O-ring

- (10) Multi-plate clutch (LSD) piston ASSY
- (11) D-ring
- (12) Gasket
- (13) Multi-plate clutch (LSD) pipe
- (14) Extension case
- (15) O-ring
- (16) Test plug
- (17) Oil seal

- (18) Dust cover
- (19) O-ring
- (20) Rear vehicle speed sensor


**Tightening torque: N·m (kgf-m, ft-lb)**

**T1: 7 (0.7, 5.1)**

**T2: 13 (1.3, 9.4)**

**T3: 25 (2.5, 18.1)**

## 13.ATF COOLER WITH ATF WARMER FUNCTION




- |                            |                                |
|----------------------------|--------------------------------|
| (1) ATF cooler outlet hose | (5) Engine coolant inlet pipe  |
| (2) ATF cooler inlet hose  | (6) Engine coolant outlet pipe |
| (3) Hose clamp             | (7) ATF cooler bracket         |
| (4) ATF cooler ASSY        | (8) Clip                       |

**Tightening torque: N·m (kgf-m, ft-lb)**  
**T: 23 (2.3, 16.6)**

# General Description

AUTOMATIC TRANSMISSION

## 14.TRANSMISSION MOUNTING



- |                         |                 |
|-------------------------|-----------------|
| (1) Pitching stopper    | (3) Crossmember |
| (2) Rear cushion rubber | (4) Stopper     |

**Tightening torque: N·m (kgf-m, ft-lb)**

**T1: 35 (3.6, 26)**

**T2: 40 (4.1, 30)**

**T3: 50 (5.1, 37)**

**T4: 58 (5.9, 43)**

**T5: 70 (7.1, 51)**

### **C: CAUTION**





- Wear work clothing, including a cap, protective goggles and protective shoes during operation.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust and dirt.
- Do not place the oil pan with its inner side facing upward until it is installed so as to prevent foreign matter intrusion into valve body.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly and replacement.
- When disassembling the case and other light alloy parts, use a plastic hammer to force it apart. Do not pry it apart with a screwdriver or other tool.
- Be careful not to burn yourself, because each part on the vehicle is hot after running.
- Use SUBARU genuine gear oil, grease etc. or the equivalent. Do not mix gear oil, grease etc. with that of another grade or from other manufacturers.
- Be sure to tighten bolts and nuts to the specified torque.
- Place shop jacks or rigid racks at the specified points.
- Apply gear oil or ATF onto sliding or revolution surfaces before installation in view of components usage.
- Replace deformed or otherwise damaged snap rings with new ones.
- Before installing O-rings or oil seals, apply sufficient amount of ATF to avoid damage and deformation.
- Be careful not to incorrectly install or fail to install O-rings, snap rings and other such parts.
- Before securing a part on a vice, place cushioning material such as wood blocks, aluminum plate or cloth between the part and the vice.
- Avoid damaging the mating surface of the case.
- Before applying liquid gasket, completely remove the old seal.

# General Description

AUTOMATIC TRANSMISSION





## D: PREPARATION TOOL

### 1. SPECIAL TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST-498575400</p>	498575400	OIL PRESSURE GAUGE ASSY	Used for measuring oil pressure.
 <p>ST-498897200</p>	498897200	ADAPTER	Used for oil pump housing when measuring reverse clutch pressure and line pressure.
 <p>ST-498897700</p>	498897700	ADAPTER SET	Used for measuring transfer clutch pressure.
 <p>ST-498545400</p>	498545400	FILTER WRENCH	Used for removing and installing ATF filter.





# General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST-498277200</p>	498277200	STOPPER SET	Used for removing and installing automatic transmission assembly to engine.
 <p>ST-398527700</p>	398527700	PULLER ASSY	<ul style="list-style-type: none"> <li>• Used for removing extension case roller bearing.</li> <li>• Used for removing extension oil seal.</li> <li>• Used for removing front differential side retainer bearing outer race.</li> <li>• Used for removing front differential side retainer oil seal.</li> </ul>
 <p>ST-498057300</p>	498057300	INSTALLER	Used for installing extension oil seal.
 <p>ST41099AC000</p>	41099AC000	ENGINE SUPPORT ASSY	Used for supporting engine. (1) ENGINE SUPPORT BRACKET (41099AC010) (2) ENGINE SUPPORT (41099AC020)





# General Description

## AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST-498077000</p>	498077000	REMOVER	Used for removing differential taper roller bearing.
 <p>ST-499247400</p>	499247400	INSTALLER	<ul style="list-style-type: none"> <li>Used for installing transfer outer snap ring.</li> <li>Used with GUIDE (499257300).</li> </ul>
 <p>ST-499257300</p>	499257300	SNAP RING OUTER GUIDE	<ul style="list-style-type: none"> <li>Used for installing transfer outer snap ring.</li> <li>Used with INSTALLER (499247400).</li> </ul>
 <p>ST-499787000</p>	499787000	WRENCH ASSY	Used for removing and installing differential side retainer.

# General Description





AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST-398437700</p>	398437700	DRIFT	Used for installing converter case oil seal.
 <p>ST-398487700</p>	398487700	INSTALLER	Used for installing front differential taper roller bearing.
 <p>ST-398673600</p>	398673600	COMPRESSOR	Used for removing and installing clutch spring.
 <p>ST-498255400</p>	498255400	PLATE	Used for measuring backlash of hypoid gear.







# General Description

## AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST-399893600</p>	399893600	PLIERS	Used for removing and installing clutch spring.
 <p>ST-498247001</p>	498247001	MAGNET BASE	<ul style="list-style-type: none"> <li>Used for measuring gear backlash.</li> <li>Used with DIAL GAUGE (498247100).</li> </ul>
 <p>ST-498247100</p>	498247100	DIAL GAUGE	<ul style="list-style-type: none"> <li>Used for measuring gear backlash.</li> <li>Used with MAGNET BASE (498247001).</li> </ul>
 <p>ST-498517000</p>	498517000	REPLACER	Used for removing front roller bearing.





# General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST-398623600</p>	398623600	SEAT	Used for removing spring of transfer clutch piston.
 <p>ST-499267300</p>	499267300	STOPPER PIN	Used for installing inhibitor switch.
 <p>ST-499787700</p>	499787700	WRENCH	Used for removing and installing drive pinion lock nut.
 <p>ST-499787500</p>	499787500	ADAPTER	Used for removing and installing drive pinion lock nut.





## General Description

### AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST-398643600</p>	398643600	GAUGE	Used for measuring total end play, extension end play and drive pinion height.
 <p>ST-498627100</p>	498627100	SEAT	Used for holding low clutch piston retainer spring when installing snap ring.
 <p>ST-499577000</p>	499577000	GAUGE	Used for measuring mating surface of transmission to end of reduction gear.
 <p>ST-499737000</p>	499737000	PULLER	Used for removing reduction driven gear assembly.





# General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST-499737100</p>	499737100	PULLER SET	Used for removing reduction drive gear assembly.
 <p>ST-498077600</p>	498077600	REMOVER	Used for removing ball bearing.
 <p>ST-498937110</p>	498937110	HOLDER	Used for removing and installing drive pinion lock nut.
 <p>ST-498677100</p>	498677100	COMPRESSOR	Used for installing 2-4 brake snap ring.





# General Description

## AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST-498437000</p>	498437000	HIGH CLUTCH PISTON GUIDE	Used for installing high clutch piston.
 <p>ST-498437100</p>	498437100	LOW CLUTCH PISTON GUIDE	Used for installing low clutch piston.
 <p>ST-899580100</p>	899580100	INSTALLER	Used for press-fitting of ball bearing for transfer clutch.
 <p>ST28399SA010</p>	28399SA010	OIL SEAL PROTECTOR	Used for installing axle shaft.


# General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST18675AA000</p>	18675AA000	DIFFERENTIAL OIL SEAL INSTALLER	Used for installing differential side retainer oil seal.
 <p>ST-398497701</p>	398497701	SEAT	Used for installing needle bearing.
 <p>ST-899524100</p>	899524100	PULLER SET	Used for bolt only. <ul style="list-style-type: none"> <li>• Used with PULLER SET (499737100).</li> <li>• Used with PULLER (499737000).</li> </ul> (1) Puller (2) Cap
 <p>ST24082AA230</p>	24082AA230	CARTRIDGE	Troubleshooting for electrical system.

## General Description

### AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST22771AA030</p>	22771AA030	SUBARU SELECT MONITOR KIT	Troubleshooting for electrical system. <ul style="list-style-type: none"> <li>English: 22771AA030 (Without printer)</li> <li>German: 22771AA070 (Without printer)</li> <li>French: 22771AA080 (Without printer)</li> <li>Spanish: 22771AA090 (Without printer)</li> </ul>

## 2. GENERAL TOOL

TOOL NAME	REMARKS
Depth gauge	Used for measuring transmission end play.
Thickness gauge	Used for measuring clearance of clutch, brake and oil pump.
Micro meter	Used for measuring thickness of drive pinion.
Spring balance	Used for measuring starting torque of drive pinion.
Circuit tester	Used for measuring resistance and voltage.
TORX® T70	Used for removing and installing differential gear oil drain plug.
Push/pull gauge	Used for measuring clutch piston stroke.


## 2. Automatic Transmission Fluid

### A: INSPECTION

#### NOTE:

The level of ATF varies with fluid temperature. Pay attention to the ATF temperature when checking ATF level.

- 1) Raise the ATF temperature by driving a distance of 5 to 10 km (3 to 6 miles). Otherwise, idle the engine to raise ATF temperature to 70 — 80°C (158 — 176°F) on Subaru Select Monitor. <Ref. to 4AT(diag)-17, READ CURRENT DATA, OPERATION, Subaru Select Monitor.>
- 2) Park the vehicle on a level surface.
- 3) After selecting all positions (P, R, N, D), set the select lever in "P" range. Measure the ATF level with engine idling for one or two minutes.



- (A) ATF level gauge
- (B) Upper level
- (C) Lower level

- 4) Make sure that ATF level is above the center of upper level and lower level at HOT side.
- 5) If the ATF level is below the center between upper level and lower level, replenish a recommended ATF until the fluid level exceeds the center between upper level and lower level.

#### CAUTION:

- Use care not to exceed the upper limit level.
- Be sure that the replenishment of ATF to the upper level with the transmission cold will cause overfilling of ATF and result in a transmission failure.

- 6) Raise the ATF temperature by driving a distance of 5 to 10 km (3 to 6 miles). Otherwise, idle the engine to raise ATF temperature to 70 — 80°C (158 — 176°F) on Subaru Select Monitor. <Ref. to 4AT(diag)-17, READ CURRENT DATA, OPERATION, Subaru Select Monitor.>

- 7) Check the ATF for leaks.

Make visual inspection for leaks from the inside of transmission. If there are leaks, repair or replace the gasket, oil seals, plugs or other parts.

### B: REPLACEMENT

- 1) Lift-up the vehicle.
- 2) Remove the ATF drain plug to drain ATF.

#### CAUTION:

**Directly after the engine has been running, the ATF is hot. Be careful not to burn yourself.**


- 3) Check the condition of ATF. <Ref. to 4AT-32, CONDITION CHECK, Automatic Transmission Fluid.>
- 4) Tighten the ATF drain plug.

#### NOTE:

Use a new gasket.

#### Tightening torque:

**25 N·m (2.5 kgf-m, 18.1 ft-lb)**



- (A) Oil pan
- (B) ATF drain plug

- 5) Lower the vehicle.
- 6) Pour ATF from the oil charge pipe.

#### Recommended fluid:

**SUBARU ATF (Part No. K0410Y0700) or Idemitsu "Apolloil ATF HP", Castrol "Transmax J".**

#### NOTE:

If the ATFs above are not available, use Dexron III.

#### Capacity:

**Fill the same amount of ATF drained.**

#### Capacity when transmission is overhauled:

**2.0 L model**

**8.4 — 8.7 ℓ (8.9 — 9.2 US qt, 7.4 — 7.7 Imp qt)**

**2.5 L model**

**9.3 — 9.6 ℓ (9.8 — 10.1 US qt, 8.2 — 8.4 Imp qt)**

- 7) Bleed the air of control valve.

<Ref. to 4AT-63, Air Bleeding of Control Valve.>

- 8) Check the level and leaks of ATF.

<Ref. to 4AT-31, INSPECTION, Automatic Transmission Fluid.>



## Automatic Transmission Fluid

### AUTOMATIC TRANSMISSION

---

#### **C: CONDITION CHECK**

**NOTE:**

When replacing ATF, check the inside condition of the transmission body by inspecting the drained ATF.

Fluid condition	Trouble and possible cause	Corrective action
Large amount of metallic pieces are found.	Excessive wear of the internal of the transmission body.	Replace ATF and check if AT operates correctly.
Thick and varnish-form fluid.	Burned clutch and etc.	Replace ATF and check AT itself and vehicle for faulty.
Clouded fluid or bubbles are found in fluid.	Water mixed in fluid.	Replace ATF and check the water entering point.


## 3. Differential Gear Oil

### A: INSPECTION

- 1) Park the vehicle on a level surface.
- 2) Remove the oil level gauge and wipe it clean.
- 3) Reinsert the level gauge all the way. Be sure that the level gauge is correctly inserted and in the proper orientation.
- 4) Remove the level gauge again and note the reading. If the differential gear oil level is below the "L" line, add oil to bring the level up to the "F" line.

#### NOTE:

To prevent overfilling the differential gear oil, do not add oil above the "F" line.



- (A) Oil level gauge
- (B) Upper level
- (C) Lower level

### B: REPLACEMENT

- 1) Lift-up the vehicle.
- 2) Remove the differential gear oil drain plug using TORX® BIT T70, and drain the differential gear oil completely.

#### CAUTION:

- Directly after the engine has been running, the differential gear oil is hot. Be careful not to burn yourself.
- Be careful not to spill the differential gear oil on exhaust pipe to prevent it from emitting smoke or fire. When the differential gear oil is spilled on exhaust pipe, wipe it away completely.


- 3) Tighten the differential gear oil drain plug using TORX® BIT T70.

#### NOTE:

Use a new gasket.

#### Tightening torque:

**70 N·m (7.1 kgf-m, 51.6 ft-lb)**



- (A) Oil pan
- (B) Differential gear oil drain plug

- 4) Lower the vehicle.
- 5) Pour gear oil into the gauge hole.

#### Recommended gear oil:

**<Ref. to 4AT-3, RECOMMENDED GEAR OIL, SPECIFICATION, General Description.>**

#### Differential gear oil capacity:

**1.1 — 1.3 ℓ (1.2 — 1.4 US qt, 1.0 — 1.1 Imp qt)**

- 6) Check the level of the differential gear oil.

**<Ref. to 4AT-33, INSPECTION, Differential Gear Oil.>**

## 4. Road Test

### A: INSPECTION

#### 1. GENERAL PRECAUTION

Road tests should be conducted to properly diagnose the condition of the automatic transmission.

**NOTE:**

When performing the test, do not exceed posted speed limit.

#### 2. D RANGE SHIFT FUNCTION

Check shifting between 1st ↔ 2nd ↔ 3rd ↔ 4th while driving on general city streets.

#### 3. D RANGE SHIFT SHOCK

Check the shock level when shifting up during normal driving.

#### 4. KICK-DOWN FUNCTION

Check kick-down for each gear. Also check the kick-down shock level.

#### 5. ENGINE BRAKE OPERATION

- Check the 3rd gear engine brake when shifting down from 4th to 3rd range while driving in 4th gear of manual mode [50 — 60 km/h (31 — 37 MPH)].
- Check the 2nd gear engine brake when shifting down from 3rd to 2nd range while driving in 3rd gear of manual mode [40 — 50 km/h (25 — 31 MPH)].
- Check the 1st gear engine brake when shifting down from 2nd to 1st range while driving in 2nd gear of manual mode [20 — 30 km/h (12 — 19 MPH)].

#### 6. LOCK-UP FUNCTION

- Check that rpm does not change sharply when the axle pedal is lightly depressed while driving on flat roads at normal speed in “D” range.
- Check slip lock-up with following procedure. Subaru Select Monitor is needed for checking. Before start checking, check that no DTC is displayed using Subaru Select Monitor. When DTC is displayed, perform the collective action with DTC and check that any more DTC is displayed, and then start the checking.

1) Perform the check on flat and straight road or free roller.

**NOTE:**

- Slip lock-up does not operate when the vehicle is lifted up, because of not occurring surface resistance.

- Also when checking on the free roller, check with depressing the foot brake lightly to make the checking easier, because the surface resistance will be deficient.

2) Connect the Subaru Select Monitor.

3) Check the ATF temperature using Subaru Select Monitor.

**NOTE:**

- ATF temperature is between 50 — 100°C (122 — 212°F).

- When the temperature is low, warm-up the ATF by running the vehicle or etc.

4) Start the engine, so that the lock-up duty can be read on data display of Subaru Select Monitor.

5) Drive the vehicle at a constant speed of 35 — 40 km/h (22 — 25 MPH).

6) Read the lock-up duty while vehicle is running.

**Standard value:**

**25 — 45%**

**NOTE:**

The value may be lower on the free roller.

- Slip lock-up control is not operating when the lock-up duty is less than 5%, or when the lock-up duty goes down immediately after starts rising. On these cases, improper ATF or deterioration of ATF may be the cause. Check the amount of ATF or replace them, and then recheck it.

#### 7. P RANGE OPERATION

Stop the vehicle on an uphill grade of 5% or more and shift to “P” range. Check that the vehicle does not move when the parking brake is released.

#### 8. NOISE AND VIBRATION

Check for noise and vibration while driving and during shifting.

#### 9. CLIMBING CONTROL FUNCTION

- Check that the gear remains in 3rd when going up a grade.
- Check that the gear remains in 3rd when applying the brakes while going down a grade.

#### 10. TRANSFER CLUTCH

Check tight corner braking when the vehicle started with steering fully turned.

#### 11. OIL LEAKS

After the driving test, inspect for oil leaks.

## 5. Stall Test


### A: INSPECTION

#### NOTE:


The stall test is of extreme importance in diagnosing the condition of the automatic transmission and the engine. It should be conducted to measure the engine stall speeds in "R" and 2nd of manual mode. Purposes of the stall test:

- To check the operation of the automatic transmission clutch.
- To check the operation of the torque converter clutch.
- To check engine performance.

- 1) Check that the throttle valve opens fully.
- 2) Check that the engine oil level is correct.
- 3) Check that the coolant level is correct.
- 4) Check that the ATF level is correct.
- 5) Check that the differential gear oil level is correct.
- 6) Increase ATF temperature to 70 — 80°C (158 — 176°F) by idling the engine for approximately 30 minutes (with select lever set to "N" or "P").
- 7) Place the wheel chocks at the front and rear of all wheels and engage the parking brake.
- 8) Move the manual linkage to ensure it operates properly, and then set to the 2nd on manual mode.



- 9) While forcibly depressing the foot brake pedal, gradually depress the accelerator pedal until the engine operates at full throttle.



- (A) Brake pedal  
(B) Accelerator pedal

- 10) When the engine speed is stabilized, record that speed quickly and release the accelerator pedal.

- 11) Shift the select lever to "N" range, and cool down the engine by idling it for more than one minute.

- 12) If the stall speed in the 2nd of manual mode is higher than specifications, low clutch slipping and 2-4 brake slipping may occur. To identify it, conduct the same test as above in "R" range.

- 13) Perform the stall tests with the select lever in "D" range.

#### NOTE:

- Do not continue the stall test for more than five seconds at a time (from closed throttle, fully open throttle to stall speed reading). Failure to follow this instruction causes the engine oil and ATF to deteriorate and the clutch and brake to be adversely affected.
- Be sure to cool down the engine for at least one minute after each stall test with the select lever set in "P" or "N" range and with the idle speed lower than 1,200 rpm.
- If the stall speed is higher than the specified range, attempt to finish the stall test in as short a time as possible, in order to prevent the automatic transmission from sustaining damage.

## Stall Test

### AUTOMATIC TRANSMISSION

---

**Stall speed (at sea level):****2.0 L model:****2,300 — 2,700 rpm****2.5 L model:****2,600 — 2,900 rpm**

Stall speed (at sea level)	Range	Cause
Less than standard	2nd on manual mode, R	<ul style="list-style-type: none"><li>• Throttle valve not fully open</li><li>• Erroneous engine operation</li><li>• Torque converter clutch's one-way clutch slipping</li></ul>
More than standard	D	<ul style="list-style-type: none"><li>• Line pressure is too low</li><li>• Low clutch slipping</li><li>• One-way clutch malfunctioning</li></ul>
	R	<ul style="list-style-type: none"><li>• Line pressure is too low</li><li>• Reverse clutch slipping</li><li>• Low &amp; reverse brake slipping</li></ul>
	2nd on manual mode	<ul style="list-style-type: none"><li>• Line pressure is too low</li><li>• Low clutch slipping</li><li>• 2-4 brake slipping</li></ul>

## 6. Time Lag Test

### A: INSPECTION

#### NOTE:

If the select lever is shifted while the engine is idling, there will be a certain time elapse or lag before the shock can be felt. This is used for checking the condition of the low clutch, reverse clutch, low & reverse brake and one-way clutch.

- Perform the test at normal operation fluid temperature 70 — 80°C (158 — 176°F).
- Be sure to allow a one minute interval between tests.
- Make three measurements and take the average value.

1) Fully apply the parking brake.

2) Start the engine.

Check the idling speed (A/C OFF).

3) Shift the select lever from “N” to “D” range.

Using a stop watch, measure the time it takes from shifting the lever until the shock is felt.

Time lag: Less than 1.2 seconds

If “N” → “D” time lag is longer than specified:

- Line pressure too low
- Low clutch worn
- One-way clutch not operating properly
- D-ring worn

4) In the same manner, measure the time lag for “N” → “R”.

Time lag: Less than 1.5 seconds

If “N” → “R” time lag is longer than specified:

- Line pressure too low
- Reverse clutch worn
- Low & reverse brake worn
- D-ring worn

### 7. Line Pressure Test

#### A: MEASUREMENT

##### NOTE:

If the clutch or the brake shows a sign of slippage or shifting sensation is not correct, the line pressure should be checked.

- Excessive shocks during upshifting or shifting takes place at a higher point than under normal circumstances, may be due to the line pressure being too high.
- Slippage or inability to operate the vehicle may, in most cases, be due to loss of oil pressure for the operation of the clutch, brake or control valve.

##### 1) Line pressure measurement (under no load):

- (1) Before measuring line pressure, jack-up all the wheels.
- (2) Maintain the temperature of ATF at approx. 70 — 80°C (158 — 176°F) during measurement. (ATF will reach the above-mentioned temperature after idling the engine for approx. 30 minutes with the select lever in “N” or “P”.)

##### 2) Line pressure measurement (under heavy load):

- (1) Before measuring line pressure, apply both the foot and parking brakes with all wheels chocked (Same as for “stall” test conditions).
- (2) Measure the line pressure when the select lever is in “R” or 2nd of manual mode with engine under stall conditions.
- (3) Measure the line pressure within 5 seconds after shifting the select lever to each position. (If the line pressure needs to be measured again, allow the engine to idle and cool it down more than 1 minute.)
- (4) Maintain the ATF temperature at approx. 70 — 80°C (158 — 176°F) during measurement. (ATF will reach the above-mentioned temperature after idling the engine for approx. 30 minutes with the select lever in “N” or “P”.)

##### 3) Remove the test plug and install the ST instead.

ST 498897200 OIL PRESSURE GAUGE  
ADAPTER


##### 4) Connect the ST1 with ST2.

ST1 498897200 OIL PRESSURE GAUGE  
ADAPTER

ST2 498575400 OIL PRESSURE GAUGE  
ASSY

##### 5) Check for duty ratio changes by adjusting the acceleration pedal position using Subaru Select Monitor.

Standard line pressure			
Range position	Line pressure duty ratio (%)	Throttle valve angle	Line pressure kPa (kg/cm <sup>2</sup> , psi)
Manual mode (2nd)	25 — 35	Full open	1,000 — 1,300 (10.2 — 13.3, 145 — 189)
R	15 — 25	Full open	1,500 — 1,850 (15.3 — 18.9, 217 — 268)
D	35 — 43	Full closed	500 — 800 (5.1 — 8.2, 73 — 116)



(A) Test plug

### 8. Transfer Clutch Pressure Test

#### A: INSPECTION


Check the transfer clutch pressure in accordance with the following chart in the same manner as with line pressure. <Ref. to 4AT-38, Line Pressure Test.>

ST 498897700 OIL PRESSURE ADAPTER SET  
ST 498575400 OIL PRESSURE GAUGE ASSY

#### NOTE:


- Before setting in FWD mode, install the spare fuse on FWD mode switch. (MPT model)
- MTP model

Range position	ON Duty ratio (%)	Acceleration pedal position (%)	Standard transfer clutch pressure kPa (kg/cm <sup>2</sup> , psi)	
			AWD mode	FWD mode
Manual mode (2nd)	95	Fully opened: 100	1,000 — 1,200 (10.2 — 12.2, 145 — 174)	—
	60	Adjust ON Duty ratio to 60%.	500 — 700 (5.1 — 7.1, 73 — 102)	—
	—	Fully closed: 0	—	0 (0, 0)
N or P	5	Fully closed: 0	0	—



(A) Test plug

- VTD model



(A) Test plug


- If no oil pressure is produced or if it does not change in AWD mode, the control valve body may be malfunctioning. If oil pressure is produced in FWD mode, the same problem as AWD mode occurs.




### 9. Automatic Transmission Assembly

#### A: REMOVAL


- 1) Set the vehicle on a lift.
- 2) Fully open the front hood and support with hood stay.
- 3) Disconnect the ground cable from battery.
- 4) Remove the air intake duct.  
<Ref. to IN(H4SO 2.0)-9, REMOVAL, Air Intake Duct.>
- 5) Remove the air intake chamber.  
<Ref. to IN(H4SO 2.0)-8, REMOVAL, Air Intake Chamber.>
- 6) Remove the air cleaner case stay.



- 7) Disconnect the following connectors.
  - (1) Transmission harness connectors



- (2) Transmission ground terminal
- 8) Remove the starter.  
<Ref. to SC(H4SO 2.0)-6, REMOVAL, Starter.>
- 9) Remove the pitching stopper.




- 10) Separate the torque converter clutch from drive plate.


- (1) Remove the V-belt covers.
- (2) Remove the service hole plug.
- (3) Remove the bolts which hold torque converter clutch to drive plate.
- (4) Insert the wrench to crank pulley bolt, and then remove all the bolts with slightly rotating crank pulley.

#### CAUTION:

Be careful not to drop bolts into torque converter clutch housing.




- 11) Install the ST to converter case.  
ST 498277200 STOPPER SET



- 12) Remove the ATF level gauge.

#### NOTE:

Plug the opening to prevent entry of foreign particles into transmission fluid.




- 13) Remove the throttle body. <Ref. to FU(H4SO 2.0)-10, REMOVAL, Throttle Body.>

# Automatic Transmission Assembly


## AUTOMATIC TRANSMISSION

14) Drain the engine coolant by approx. 2 ℓ (2.1 US qt, 1.8 Imp qt). (Model with ATF cooler with warmer function)


15) Disconnect the ATF cooler inlet and outlet hoses from ATF cooler pipes.




16) Disconnect each hose from warmer cock assembly.




17) Remove the ATF cooler with warmer function from transmission body, and then secure it to vehicle body by wire, etc.. Select the place not to prevent transmission from being replaced. (Model with ATF cooler with warmer function)



18) Remove the warmer cock assembly. (Model with ATF cooler with warmer function)




19) Remove the bracket for warmer cock assembly. (Model with ATF cooler with warmer function)




20) Remove the pitching stopper bracket.

21) Set the ST.

ST 41099AC000 ENGINE SUPPORT ASSEMBLY



22) Remove the bolts which hold upper side of transmission to engine.



23) Lift-up the vehicle.

24) Remove the under cover.


# Automatic Transmission Assembly

## AUTOMATIC TRANSMISSION


25) Remove the front, center and rear exhaust pipes and muffler.

<Ref. to EX(H4SO 2.0)-7, REMOVAL, Front Exhaust Pipe.> <Ref. to EX(H4SO 2.0)-11, REMOVAL, Rear Exhaust Pipe.> <Ref. to EX(H4SO 2.0)-13, REMOVAL, Muffler.>

26) Remove the heat shield cover.




27) Remove the ATF drain plug to drain ATF.



(A) Oil pan

(B) ATF drain plug

28) Disconnect the ATF cooler hoses from pipes of transmission side, and remove the oil charge pipe. (Model without ATF cooler with warmer function)



29) Remove the propeller shaft.


<Ref. to DS-10, REMOVAL, Propeller Shaft.>

30) Remove the shift select cable.

<Ref. to CS-12, REMOVAL, Select Cable.>

31) Remove the brackets (two) which hold front stabilizer.

32) Remove the bolt securing ball joint of front arm to housing.



33) Pull out the front drive shaft from transmission.

(1) Using a tire lever or a pinch bar, etc., pull out the front drive shaft until its joint facing to transmission can move smoothly.


### NOTE:

Place cloth between tire lever or pinch bar and transmission in order to avoid damaging the side retainer of transmission.

(2) Hold the transmission side joint portion of front drive shaft by hand and extract the housing from the transmission by pressing it outside so as not to stretch the boot.

34) Remove the bolts which hold the clutch housing cover.

35) Remove the bolts which hold lower side of transmission to engine.




36) Place the transmission jack under transmission.

### NOTE:

Make sure that the support plates of transmission jack don't touch the oil pan.

37) Remove the transmission rear crossmember from the vehicle.



38) Fully contract the engine support while lowering the transmission jack gradually, and tilt the engine backward.


**NOTE:**

Contract the support until the clearance between front crossmember and torque converter case becomes approx. 10 mm (0.39 in).

39) Remove the transmission.

**CAUTION:**

Remove the transmission and torque converter as a unit from engine.



40) Remove the rear cushion rubber from transmission assembly.

### B: INSTALLATION

1) Replace the differential side oil seal with a new one.

**NOTE:**

When a new oil seal has been installed, the replacement is not required.


2) Install the rear cushion rubber to transmission assembly.

**Tightening torque:**

**39 N·m (4.0 kgf-m, 29 ft-lb)**


3) Install the ST to converter case.

ST 498277200 STOPPER SET



4) Install the transmission onto engine.

(1) Lift up the transmission gradually using a transmission jack.



(2) Engage them at splines.


(3) Turn the screws of engine support while raising the transmission jack gradually, and tilt the engine forward.

5) Install the transmission rear crossmember.

**Tightening torque:**

**T1: 35 N·m (3.6 kgf-m, 26 ft-lb)**

**T2: 70 N·m (7.1 kgf-m, 51 ft-lb)**



6) Take off the transmission jack.


7) Tighten the bolts which hold the lower side of transmission to engine.

# Automatic Transmission Assembly

## AUTOMATIC TRANSMISSION

### Tightening torque:

**50 N·m (5.1 kgf-m, 36.9 ft-lb)**



- 8) Screw the bolts for the clutch housing cover.
- 9) Lower the lift.
- 10) Connect the engine and transmission.
  - (1) Remove the ST from converter case.

### NOTE:


When removing the ST, be careful not to drop it into converter case.

ST 498277200 STOPPER SET

- (2) Install the starter.  
<Ref. to SC(H4SO 2.0)-6, INSTALLATION, Starter.>
- (3) Tighten the bolts which hold the upper side of transmission to engine.

### Tightening torque:


**50 N·m (5.1 kgf-m, 36.9 ft-lb)**




- 11) Install the torque converter clutch to drive plate.
  - (1) Tighten the bolts which hold torque converter clutch to drive plate.
  - (2) Insert the wrench to crank pulley bolt, and then tighten all bolts while slightly rotating the crank pulley.

### Tightening torque:

**25 N·m (2.5 kgf-m, 18.1 ft-lb)**




- (3) Fit the plug to service hole.
- (4) Install the V-belt cover.
- 12) Remove the ST.



- 13) Install the warmer cock assembly bracket. (Model with ATF cooler with warmer function)

### Tightening torque:

**16 N·m (1.6 kgf-m, 11.6 ft-lb)**




- 14) Install the warmer cock assembly. (Model with ATF cooler with warmer function)




### Tightening torque:

**T1: 6.4 N·m (0.65 kgf-m, 4.7 ft-lb)**

**T2: 15 N·m (1.5 kgf-m, 10.8 ft-lb)**




15) Connect each hose to warmer cock assembly.  
(Model with ATF cooler with warmer function)



16) Install the pitching stopper bracket and bracket  
(Model with ATF cooler with warmer function).

### Tightening torque:

**41 N·m (4.2 kgf-m, 30.4 ft-lb)**





(A) Pitching stopper bracket

(B) Bracket (Model with ATF cooler with warmer function)


17) Install the ATF cooler with warmer function to transmission body. (Model with ATF cooler with warmer function)

### Tightening torque:

**23 N·m (2.3 kgf-m, 16.6 ft-lb)**



18) Connect the ATF cooler inlet and outlet hoses to ATF cooler pipes. (Model with ATF cooler with warmer function)




19) Install the throttle body. <Ref. to FU(H4SO 2.0)-10, INSTALLATION, Throttle Body.>  
20) Install the pitching stopper.

### Tightening torque:

**T1: 50 N·m (5.1 kgf-m, 37 ft-lb)**


**T2: 58 N·m (5.9 kgf-m, 43 ft-lb)**




# Automatic Transmission Assembly

## AUTOMATIC TRANSMISSION

- 21) Lift-up the vehicle.
  - 22) Replace the snap ring of front drive shaft with a new one.
  - 23) Apply grease to the oil seal lips.
  - 24) Install the ST to side retainer.
- ST 28399SA010 OIL SEAL PROTECTOR




- 25) Align the spline of front differential shaft to that of differential bevel gear for insertion, and remove them using ST.
- ST 28399SA010 OIL SEAL PROTECTOR
- 26) Insert the front drive shaft into transmission securely by pressing the front housing from outside.



- 27) Install the ball joint into housing.
- 28) Tighten the attachment bolts.

**Tightening torque:**  
**50 N·m (5.1 kgf-m, 36.9 ft-lb)**




- 29) Install the stabilizer to crossmember.

### NOTE:

- Install the bushing (on front crossmember side) while aligning it with the paint mark on stabilizer.

- Ensure the bushing and stabilizer have the same identification colors when installing.




- (1) Identification mark on stabilizer
- (2) Bushing identification color


- 30) Always tighten the rubber bushing location when wheels are in full contact with the ground and vehicle is curb weight.

**Tightening torque:**  
**25 N·m (2.5 kgf-m, 18.1 ft-lb)**

- 31) Install the shift select cable onto select lever.  
<Ref. to CS-13, INSTALLATION, Select Cable.>
- 32) Install the oil charge pipe, and connect the ATF cooler hoses to pipe. (Model without ATF cooler with warmer function)



- 33) Install the oil charge pipe. (Model with ATF cooler with warmer function)
- 34) Install the propeller shaft.  
<Ref. to DS-11, INSTALLATION, Propeller Shaft.>
- 35) Install the heat shield cover.



- 36) Install the rear exhaust pipe and muffler assembly.

<Ref. to EX(H4SO 2.0)-11, INSTALLATION, Rear Exhaust Pipe.> <Ref. to EX(H4SO 2.0)-13, INSTALLATION, Muffler.>


37) Install the front and center exhaust pipe.

<Ref. to EX(H4SO 2.0)-8, INSTALLATION, Front Exhaust Pipe.>

38) Install the under cover.

39) Lower the lift.

40) Install the ATF level gauge.



41) Connect the following connectors.

(1) Transmission harness connectors

(2) Transmission ground terminal

42) Install the air cleaner case stay.

### ***Tightening torque:***

**16 N·m (1.6 kgf-m, 11.6 ft-lb)**

43) Install the air intake chamber.

<Ref. to IN(H4SO 2.0)-8, INSTALLATION, Air Intake Chamber.>

44) Install the air intake duct.

<Ref. to IN(H4SO 2.0)-9, INSTALLATION, Air Intake Duct.>

45) Using a gauge hole, add the ATF until the fluid level is found at the center between upper and lower levels of level gauge "COLD" side. <Ref. to 4AT-31, Automatic Transmission Fluid.>

46) Take off the vehicle from a lift.

47) Check the level of differential gear oil. <Ref. to 4AT-33, Differential Gear Oil.>

48) Check the select lever operation.

<Ref. to 4AT-52, INSPECTION, Inhibitor Switch.>

49) Bleed the air of control valve. <Ref. to 4AT-63, Air Bleeding of Control Valve.>

50) Check the ATF level. <Ref. to 4AT-31, Automatic Transmission Fluid.>

51) Execute the learning control promotion. <Ref. to 4AT(diag)-19, FACILITATION OF LEARNING CONTROL, OPERATION, Subaru Select Monitor.>

52) Perform the road test.

<Ref. to 4AT-34, Road Test.>