View Safety Info

View Safety Info

SVM177-A


October, 2007

V160-5 & -T

For use with machines having Code Numbers: 10877, 10878 11031, 11032

Safety Depends on You

Lincoln arc welding and cutting equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation ... and thoughtful operation on your part. DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT. And, most importantly, think before you act and be careful.



SERVICE MANUAL



Copyright © Lincoln Global Inc.

· World's Leader in Welding and Cutting Products ·

• Sales and Service through Subsidiaries and Distributors Worldwide •

A WARNING



Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

The Above For Diesel Engines

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

The Above For Gasoline Engines

ARC WELDING CAN BE HAZARDOUS. PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.

SAFETY

Read and understand the following safety highlights. For additional safety information, it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2-1974. A Free copy of "Arc Welding Safety" booklet E205 is available from the Lincoln Electric Company, 22801 St. Clair Avenue, Cleveland, Ohio 44117-1199.

BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.



FOR ENGINE powered equipment.

 Turn the engine off before troubleshooting and maintenance work unless the maintenance work requires it to be running.



 b.Operate engines in open, well-ventilated areas or vent the engine exhaust fumes outdoors.



- 1.c. Do not add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.
- 1.d. Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.
- 1.e. In some cases it may be necessary to remove safety guards to perform required maintenance. Remove guards only when necessary and replace them when the maintenance requiring their removal is complete. Always use the greatest care when working near moving parts.



- 1.f. Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.
- 1.g. To prevent accidentally starting gasoline engines while turning the engine or welding generator during maintenance work, disconnect the spark plug wires, distributor cap or magneto wire as appropriate.



 To avoid scalding, do not remove the radiator pressure cap when the engine is hot



ELECTRIC AND MAGNETIC FIELDS may be dangerous

- 2.a. Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding current creates EMF fields around welding cables and welding machines
- EMF fields may interfere with some pacemakers, and welders having a pacemaker should consult their physician before welding.
- Exposure to EMF fields in welding may have other health effects which are now not known.
- 2.d. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:
 - 2.d.1. Route the electrode and work cables together Secure them with tape when possible.
 - 2.d.2. Never coil the electrode lead around your body.
 - 2.d.3. Do not place your body between the electrode and work cables. If the electrode cable is on your right side, the work cable should also be on your right side.
 - 2.d.4. Connect the work cable to the workpiece as close as possible to the area being welded.
 - 2.d.5. Do not work next to welding power source.



2

Return

" SAFETY "



ELECTRIC SHOCK can kill.

- 3.a. The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not touch these "hot" parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- 3.b. Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

In addition to the normal safety precautions, if welding must be performed under electrically hazardous conditions (in damp locations or while wearing wet clothing; on metal structures such as floors, gratings or scaffolds; when in cramped positions such as sitting, kneeling or lying, if there is a high risk of unavoidable or accidental contact with the workpiece or ground) use the following equipment:

- · Semiautomatic DC Constant Voltage (Wire) Welder.
- · DC Manual (Stick) Welder.
- · AC Welder with Reduced Voltage Control.
- 3.c. In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or semiautomatic welding gun are also electrically "hot".
- 3.d. Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
- 3.e. Ground the work or metal to be welded to a good electrical (earth) ground.
- Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
- 3.g. Never dip the electrode in water for cooling.
- 3.h. Never simultaneously touch electrically "hot" parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
- 3.i. When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.
- 3.j. Also see Items 6.c. and 8.



ARC RAYS can burn.

- 4.a. Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when welding or observing open arc welding. Headshield and filter lens should conform to ANSI Z87. I standards.
- 4.b. Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- 4.c. Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.



FUMES AND GASES can be dangerous.

5.a. Welding may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep

fumes and gases away from the breathing zone. When welding with electrodes which require special ventilation such as stainless or hard facing (see instructions on container or MSDS) or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and below Threshold Limit Values (TLV) using local exhaust or mechanical ventilation. In confined spaces or in some circumstances, outdoors, a respirator may be required. Additional precautions are also required when welding on galvanized steel.

- 5. b. The operation of welding fume control equipment is affected by various factors including proper use and positioning of the equipment, maintenance of the equipment and the specific welding procedure and application involved. Worker exposure level should be checked upon installation and periodically thereafter to be certain it is within applicable OSHA PEL and ACGIH TLV limits.
- 5.c. Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- 5.d. Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- 5.e. Read and understand the manufacturer's instructions for this equipment and the consumables to be used, including the material safety data sheet (MSDS) and follow your employer's safety practices. MSDS forms are available from your welding distributor or from the manufacturer.
- 5.f. Also see item 1.b.



" SAFETY "



WELDING SPARKS can cause fire or explosion.

6.a. Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot

materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.

- 6.b. Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.
- 6.c. When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- 6.d. Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned". For information, purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", AWS F4.1 from the American Welding Society (see address above).
- Vent hollow castings or containers before heating, cutting or welding. They may explode.
- 6.f. Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- 6.g. Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.
- 6.h. Also see item 1.c.



CYLINDER may explode if damaged.

- 7.a. Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.
- 7.b. Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- 7.c. Cylinders should be located:
 - Away from areas where they may be struck or subjected to physical damage.
 - •A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- 7.d. Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.
- Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.
- 7.f. Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.
- 7.g. Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-I, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association 1235 Jefferson Davis Highway, Arlington, VA 22202.



FOR ELECTRICALLY powered equipment.

- 8.a. Turn off input power using the disconnect switch at the fuse box before working on the equipment.
- 8.b. Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.
- Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.



iv

PRÉCAUTIONS DE SÛRETÉ

Pour votre propre protection lire et observer toutes les instructions et les précautions de sûreté specifiques qui parraissent dans ce manuel aussi bien que les précautions de sûreté générales suivantes:

Sûreté Pour Soudage A L'Arc

- 1. Protegez-vous contre la secousse électrique:
 - a. Les circuits à l'électrode et à la piéce sont sous tension quand la machine à souder est en marche. Eviter toujours tout contact entre les parties sous tension et la peau nue ou les vétements mouillés. Porter des gants secs et sans trous pour isoler les mains.
 - b. Faire trés attention de bien s'isoler de la masse quand on soude dans des endroits humides, ou sur un plancher metallique ou des grilles metalliques, principalement dans les positions assis ou couché pour lesquelles une grande partie du corps peut être en contact avec la masse.
 - c. Maintenir le porte-électrode, la pince de masse, le câble de soudage et la machine à souder en bon et sûr état defonctionnement.
 - d.Ne jamais plonger le porte-électrode dans l'eau pour le refroidir.
 - e. Ne jamais toucher simultanément les parties sous tension des porte-électrodes connectés à deux machines à souder parce que la tension entre les deux pinces peut être le total de la tension à vide des deux machines.
 - f. Si on utilise la machine à souder comme une source de courant pour soudage semi-automatique, ces precautions pour le porte-électrode s'applicuent aussi au pistolet de soudage.
- Dans le cas de travail au dessus du niveau du sol, se protéger contre les chutes dans le cas ou on recoit un choc. Ne jamais enrouler le câble-électrode autour de n'importe quelle partie du corps.
- 3. Un coup d'arc peut être plus sévère qu'un coup de soliel, donc:
 - a. Utiliser un bon masque avec un verre filtrant approprié ainsi qu'un verre blanc afin de se protéger les yeux du rayonnement de l'arc et des projections quand on soude ou quand on regarde l'arc.
 - b. Porter des vêtements convenables afin de protéger la peau de soudeur et des aides contre le rayonnement de l'arc.
 - c. Protéger l'autre personnel travaillant à proximité au soudage à l'aide d'écrans appropriés et non-inflammables.
- 4. Des gouttes de laitier en fusion sont émises de l'arc de soudage. Se protéger avec des vêtements de protection libres de l'huile, tels que les gants en cuir, chemise épaisse, pantalons sans revers, et chaussures montantes.
- Toujours porter des lunettes de sécurité dans la zone de soudage. Utiliser des lunettes avec écrans lateraux dans les zones où l'on pique le laitier.

 Eloigner les matériaux inflammables ou les recouvrir afin de prévenir tout risque d'incendie dû aux étincelles.

SAFETY

- Quand on ne soude pas, poser la pince à une endroit isolé de la masse. Un court-circuit accidental peut provoquer un échauffement et un risque d'incendie.
- 8. S'assurer que la masse est connectée le plus prés possible de la zone de travail qu'il est pratique de le faire. Si on place la masse sur la charpente de la construction ou d'autres endroits éloignés de la zone de travail, on augmente le risque de voir passer le courant de soudage par les chaines de levage, câbles de grue, ou autres circuits. Cela peut provoquer des risques d'incendie ou d'echauffement des chaines et des câbles jusqu'à ce qu'ils se rompent.
- Assurer une ventilation suffisante dans la zone de soudage.
 Ceci est particuliérement important pour le soudage de tôles galvanisées plombées, ou cadmiées ou tout autre métal qui produit des fumeés toxiques.
- 10. Ne pas souder en présence de vapeurs de chlore provenant d'opérations de dégraissage, nettoyage ou pistolage. La chaleur ou les rayons de l'arc peuvent réagir avec les vapeurs du solvant pour produire du phosgéne (gas fortement toxique) ou autres produits irritants.
- Pour obtenir de plus amples renseignements sur la sûreté, voir le code "Code for safety in welding and cutting" CSA Standard W 117.2-1974.

PRÉCAUTIONS DE SÛRETÉ POUR LES MACHINES À SOUDER À TRANSFORMATEUR ET À REDRESSEUR

- Relier à la terre le chassis du poste conformement au code de l'électricité et aux recommendations du fabricant. Le dispositif de montage ou la piece à souder doit être branché à une bonne mise à la terre.
- 2. Autant que possible, l'installation et l'entretien du poste seront effectués par un électricien qualifié.
- 3. Avant de faires des travaux à l'interieur de poste, la debrancher à l'interrupteur à la boite de fusibles.
- 4. Garder tous les couvercles et dispositifs de sûreté à leur place.



	Page
Safety	i-iv
Installation (V160-S)Sec	tion A
Installation (V160-T)	on AA
Operation (V160-S)	tion B
Operation (V160-T)	on BB
Accessories (V160-S)Sec	tion C
Accessories (V160-T)Section Section Sec	on CC
Maintenance (V160-S)Sec	tion D
Maintenance (V160-T)Secti	on DD
Theory of Operation (V160-S)Sec	tion E
Theory of Operation (V160-T)Secti	on EE
Troubleshooting and Repair (V160-S / T)	tion F
Electrical Diagrams (V160-S / T)Sec	tion G
Parts Manual (V160-S / T)	.P-403

Insta	Installation					
-	Technical Specifications					
(Safety Precautions					
9	Select Suitable Location					
(Stacking					
-	Filting					
I	nput Connections					
(Ground Connection					
(Output Connections					
(Output and Gas Connection for Tig Welding					
(Output Connection for Stick Welding					
	Quick Disconnect Plug					
	Output Connection for Tig Welding					
	Remote Control Connection					

Return to Master TOC

TECHNICAL SPECIFICATION V160-S

INPUT - SINGLE PHASE ONLY						
Input Voltage	ges / 50 /60 H	Z.	Max. Input Current at rated Output			
115 V (20 A branch) 115 V (30 A branch) 230 V			20 A 25 A 34 A			
		RATE	OUTPUT	Τ		
Duty Cycle	Output	Amps	Output Vol	Its	Input Circuit	
1000/	60 (St 90 (T	,			115V (20A Branch)	
100%	80 (St 110 (T		23.2 14.4		115V (30A Branch)	
35%	160 (S 160 (T		26.4 230V (230V (30A Branch)	
100%		(Stick) 25.2 0 (TIG) 15.2			230V (30A Branch)	
		O	JTPUT			
Output Current Range	Мах	Maximum Open Circuit Voltage		ge	Type of Output	
5-160 Amps		48 Volts Max.			DC	
RECOMMENDED	INPUT WIF	RE AND FUS	E SIZES F	OR MA	XIMUM RATED OUTPUT	
INPUT VOLTAGE FREQUENCY (HZ	′ ∥	TYPE S, SO ST, STO, OR EXTRA			AXIMUM TIME-DELAY CIRCUIT REAKER OR FUSE SIZE (AMPS	
230/50/60		#12			30	
	*	PHYSICAL	DIMENSIO)NS		
12.6 in. 7.	/idth .9 in. 00 mm	16.9 in. A		Appr	Weight Approx. 24.2lbs. 11 kgs.	
	TEMPERATURE RANGES					
OPERATING TEN -20°C	IPERATURE F to +40°C	RANGE	S.	_	TEMPERATURE RANGE -50°C to +85°C	

TOC

Return to Master

Read entire installation section before starting

SAFETY PRECAUTIONS

▲ WARNING



installation.

ELECTRIC SHOCK can kill.

- ·Only qualified personnel should perform this installation.
- Disconnect input power by removing plug from receptacle before working inside V160-S. Allow machine to sit for

5 minutes minimum to allow the power capacitors to discharge before working inside this equipment.

- · Insulate yourself from the work and ground.
- Always wear dry insulating gloves.
- · Always connect the V160-S to a power supply grounded according to the National Electrical Code and local codes.

SELECT SUITABLE LOCATION

This machine will operate in harsh environments. However, it is important that simple preventative measures are followed to assure long life and reliable operation.

- · Do not place or operate this machine on a surface with an incline greater than 15° from horizontal.
- This machine must be located where there is free circulation of clean air without restrictions for air movement to and from the air vents. Do not cover the machine with paper, cloth or rags when switched on.
- Dirt and dust that can be drawn into the machine should be kept to a minimum.
- · Keep the machine dry and do not place it on wet ground or in puddles.
- When operated in ambient temperatures greater than 40°C, the output duty cycle may be reduced.
- Do not mount over combustible surfaces.

STACKING

The Invertec V160-S cannot be stacked.

TILTING

INSTALLATION

Place the machine directly on a secure, level surface. The machine may topple over if this procedure is not followed.

INPUT CONNECTIONS

A WARNING



ELECTRIC SHOCK can kill.

- Have a qualified electrician install and service this equipment.
- · Disconnect input power by removing plug from receptacle before working inside V160-S. Allow machine to sit for

5 minutes minimum to allow the power capacitors to discharge before working inside this equipment. Do not touch electrically live parts.

GROUND CONNECTION



The frame of the welder must be grounded. A ground terminal marked with the symbol is located on the under panel for this purpose. See your local and national electrical codes for proper grounding methods.

A CAUTION

A grounding conductor is supplied in the input cord, it is important that the supply receptacle ground is connected.

WARNING

This installation should be performed by a qualified electrician to ensure correct connections of the leads to the plug spades.

- The electrical system must be made by skilled technicians with the specific professional and technical qualifications and in compliance with the regulations in force in the country where the equipment is installed.
- The welding power source supply cable is provided with a green or yellow/green wire that must ALWAYS be earthed. This green or yellow/green wire must NEVER be used with other voltage conductors.
- Install only plugs that confirm with safety regulations.

INSTALLATION A-4 A-4

Fuse the input circuit with time delay fuses marked "D" or delay type1 circuit breakers. Using fuses or circuit breakers smaller than recommended may result in "nuisance" shut-offs from welder inrush currents even if not welding at high currents.

¹Also called "inverse time" or "thermal/magnetic" circuit breakers. These circuit breakers have a delay in tripping action that decreases as the magnitude of the current increases.

The Invertec V160-S is recommended for use on an individual branch circuit.

115V INPUT

The rated output of the V160-S is available when connected to a 30A branch circuit. When connected to a branch circuit with lower ampacity, lower welding current and duty cycle must be used. An output guide is provided below. The values are approximate and must be adjusted downward if the fuse or circuit breaker trips off. Other loads on the circuit and fuse/circuit breaker characteristics will affect the available output. Do not exceed these welding conditions:

15A plug on a 15A branch

10% duty cycle Stick: 65A TIG: 95A

15A plug on a 20A branch

10% duty cycle Stick: 75A TIG: 105A

20A plug on a 20A branch

10% duty cycle Stick: 85A TIG: 120A

The Invertec V160-S is provided with a 115/230V cable, 6.6ft.(2m) in length, with a 15Amp 5-15P plug molded onto the cord.

The V160-S is supplied with an additional 20A plug that can replace the 15A plug to achieve higher output. To install the supplied 20A plug:

Connect the white (neutral) wire under terminal clamp with silver screw, and black (hot) wire under terminal clamp with brass screw. Connect green wire under terminal clamp with green screw.

ARFU (Auto-Restore Fuse)

The dual input voltage machine is provided with an ARFU device. It only operates when the input is connected to an 115V supply and protects from input over current conditions.

When the ARFU has been activated due to an input over current condition, the output will be turned off and the green Power LED will blink indicating an over-current condition. This condition usually occurs when the unit is operated beyond its rated duty cycle. The unit will self-restore after a short time and will be ready for normal operation once the green Power LED stops blinking and remains on.

NOTE: The ARFU replaces a fuse (F2) that was used in older V160's.

▲ WARNING

 Failure to wire as instructed may cause personal injury or damage to equipment. To be installed or checked by an electrician or qualified person only.

230V INPUT

To achieve the full output capacity of the V160-S, 230VAC inputs should be used. The change over is accomplished by replacing the 115VAC plug with a 30 Amp 230VAC plug (NEMA 6-30P).

ATTACHMENT PLUG

In all cases, the green or green/yellow grounding wire must be connected to the grounding pin of the plug, usually identified by a green screw.

All attachment plugs must comply with the Standard for Attachment Plugs and Receptacles, UL498.

The product is considered acceptable for use only when an attachment plug as specified is properly attached to the supply cord.

The Invertec V160-S will auto reconnect to either 115V or 230V supplies.

ENGINE DRIVEN GENERATOR

For use on engine drives, keep in mind the above input draw restrictions and the following precaution.

The Invertec V160-S can be operated on engine driven generators as long as the 230 volt auxiliary meets the following conditions:

- The AC waveform peak voltage is below 400 volts*.
- The AC waveform frequency is between 45 and
- The RMS voltage of the AC waveform is always greater than 208VAC *.
- * for 115 VAC input divide these values in half.

The following Lincoln engine drives meet these conditions when run in the high idle mode:

Return to Master TOC

• Ranger 250,305

Commander 300, 400, & 500

Many engine drives do not meet these conditions (eg Miller Bobcats, etc). Operation of the Invertec V160-S is not recommended on engine drives not conforming to these conditions. Such combinations may overvoltage the Invertec V160-S power source.

OUTPUT CONNECTIONS

A WARNING




ELECTRIC SHOCK can kill.

- Keep the electrode holder and cable insulation in good condition.
- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Turn the input line Switch on the Invertec V160-S "off" before connecting or disconnecting output cables or other equipment.


The Work Cable and Electrode Cable are supplied with the welder. To connect the cables, turnthe PowerSwitch "OFF".

OUTPUT AND GAS CONNECTION FOR TIG WELDING (FIGURE A.1)



This unit does not include a TIG torch, but one may be purchased separately. The Lincoln (K1781-7 PTA-9FV, K1782-11 PTA-17FV) and (K1782-6, K1782-8 PTA-17V) are recommended for use with this machine for this purpose; however, any similar TIG torch can be used. To attach the Twist-Mate Plug to a Lincoln Torch, slide the rubber boot onto the torch cable (enlarge the boot opening if necessary), screw the fitting on the torch cable into the brass connector snugly and slide the boot back over the brass connector.

OUTPUT CONNECTION FOR STICK WELDING (FIGURE A.2)



First determine the proper electrode polarity for the electrode to be used. Consult the electrode data for this information. Then connect the output cables to the output terminals corresponding to this polarity. For instance, for DC(+) welding, connect the electrode cable (which is connected to the electrode holder) to the "+" output terminal and the work cable (which is connected to the work clamp) to the "-" output terminal. Insert the connector with the key lining up with the key way, and rotate approximately 1/4 turn clockwise; until the connection is snug. Do not over tighten.


Return to Master TOC

Return to Master TOC


QUICK DISCONNECT PLUG (FOR STICK ELEC-TRODE CABLE)

A quick disconnect system is used for the welding cable connections. The stick electrode cable will need to have a plug attached.


- 1. Cut off welding cable lug, if present.
- 2. Remove .75 in. (19mm) of welding cable insulation.
- 3. Slide rubber boot onto cable end. The boot end may be trimmed to match the cable diameter. Use soap or other nonpetroleum-based lubricant to help slide the boot over the cable, if needed.



4. Cut 45-50% of the copper strands back 1/4" (6 mm).



5. Fold copper strands over cut strands and insert into ferrule.



- Slide the copper ferrule into the brass plug.
- Tighten set screw to collapse copper tube. Screw must apply pressure against welding cable. The top of the set screw will be well below the surface of the brass plug after tightening.

OUTPUT CONNECTION FOR TIG WELDING

A one piece Gas Valve Tig Torch is recommended for use with the V160-S. A K960-1 Tig Torch adapter is required. See Accessories Section.

REMOTE CONTROL CONNECTION

INSTALLATION

A remote control receptacle is provided on the lower center case front of the welder for connecting a remote control to the machine. The V160-S will automatically sense if a remote control connection is made. In Lift TIG mode (GTAW), WITHOUT a remote control device connected to the V160-S, the output will come on automatically. WITH a remote control device connected to the unit, the output will need to be triggered, i.e. a Foot Amptrol. Refer to the Optional Accessories section of this manual for available remote controls.

The following items can be connected to the 6 pin socket on the front panel:

- · Remote control potentiometer (K857) for Stick weld-
- · Remote Foot Amptrol (K870), Hand Amptrol (K963-3).

B-1

B-1

Operation	n
Safet	ry Precautions
Gene	eral Description
Weldi	ing Capability
Limita	ationsB-2
Rear	Control Panel
Contr	rols and SettingsB-3/B-4
DIP S	Switch Functions (Service Information)
D	DIP Switch 1: Machine TypeB-5
D	DIP Switch 6: European/USA Machine ConfigurationB-6

Return to Master TOC

Return to Master TOC

Return to Master TOC

Read and understand this entire section before operating your machine.

SAFETY INSTRUCTIONS

▲ WARNING



ELECTRIC SHOCK can kill.

- Do not touch electrically live parts such as output terminals or internal wiring.
- · Insulate yourself from the work and ground.
 - Always wear dry insulating gloves.



FUMES AND GASES can be dangerous.

- · Keep your head out of fumes.
- Use ventilation or exhaust to remove fumes from breathing zone.



WELDING, CUTTING and GOUGING SPARKS can cause fire or explosion

- · Keep flammable material away.
- Do not weld, cut or gouge on containers that have held combustibles.



ARC RAYS can burn.

Wear eye, ear and body protection.

Observe additional guidelines detailed in the beginning of this manual.

Only qualified personnel should operate this equipment. Observe all safety information throughout this manual.

GENERAL DESCRIPTION

OPERATION

The Invertec V160-S is an industrial 160 amp arc welding power source which utilizes single phase input power, to produce constant current output. The welding response of this Invertec has been optimized for stick (SMAW) and Touch Start TIG (GTAW). The unit is ideal for industrial applications where portability is important.

The Invertec V160-S is recommended for stick welding with such popular electrodes as Fleetweld 35, Fleetweld 37, Fleetweld 180 and LH 78. It features adjustable arc control to adjust the arc force and start.

The Invertec V160-S performs DC Touch Start Tig Starting with excellent results.

WELDING CAPABILITY

The Invertec V160-S is rated at 160 amps, 26.4 volts, at 35% duty cycle on a ten minute basis. It is capable of higher duty cycles at lower output currents. It is capable of 130 amps, 25.2 volts at at 100% duty cycle⁽¹⁾. If the duty cycle is exceeded, a thermal protector will shut off the output until the machine cools. See Technical Specifications in A-1 for other rated outputs.

The Invertec V160-S is recommended for stick welding with such popular electrodes as Fleetweld® 35, Fleetweld 37, Fleetweld 180 and Jet-LH 78 MR. It features adjustable arc control to adjust the arc force and start.

LIMITATIONS

The V160-S is not recommended for pipe thawing.

(1)When connected to 230VAC inputs.



Return to Master TOC

REAR CONTROL PANEL

B-3

- 1. Power Switch: Controls the input power to the machine. Make sure the machine is properly connected to the input supply before turning the machine on.(See Figure B.1)
- 2. Fan: The cooling fan will turn ON when the machine is turned ON and it will continue to run whenever the output of the machine is ON. If the output of the machine is OFF for more than five minutes, the fan will turn OFF. This reduces the amount of dirt that is deposited inside the machine and reduces power consumption.(See Figure B.1)

Refer to the Output LED section below for more information about conditions when the output of the machine is ON. (See Figure B.1)


CONTROLS AND SETTINGS (See Figure B.2)

3. Mode Switch: This switch changes the welding modes of the machine. The V160-S has two welding modes: Stick (SMAW) and Lift TIG (GTAW).

When the mode switch is in the Lift TIG position, the stick welding functions are disabled and the machine is ready for Lift TIG welding. Lift TIG is a method of starting a TIG weld by first pressing the TIG torch electrode on the work piece in order to create a low current short circuit. Then, the electrode is lifted from the work piece to start the TIG arc.

- 4. Arc Control: The Arc Control simultaneously adjust the level at Hot Start and Arc Force. Increasing the Arc Control setting increases both Hot Start and Arc Force.
- Hot Start: This is a temporary increase in the output current during the start of the stick welding process. This helps ignite the arc quickly and reliably.
- · Arc Force: This is a temporary increase in the output current during normal stick welding. This temporary increase in output current is used to clear intermittent shorts between the electrode and the weld puddle that occur during normal stick welding.
- 5. Power LED: This indicator will blink on and off when the machine is first turned on. After approximately 2 seconds it will stop blinking and remain on to signal that the machine is ready. The indicator will also blink during over current conditions when operating on 115V input.
- 6. Thermal LED: This indicator will turn on when the machine is overheated and the output has been disabled. This normally occurs when the duty cycle of the machine has been exceeded. Leave the machine on to allow the internal components to cool. When the indicator turns off, normal operation is again possible.





V160-S & -T

B-4

Return to Master TOC

Return to Master TOC

- 7. Remote LED: This indicator will turn on when a remote control is connected to the machine via the remote control connector. Using a remote control will change the function of the output current control, refer to the output current control section below.
- 8. Output LED: This indicator turns on when the output of the machine is on.
 - In stick welding mode, the output of the machine is automatically turned ON.
 - In Lift TIG welding mode without a remote control, the output of the machine is automatically turned ON. In this condition a triggering device is not needed.
 - In Lift TIG welding mode with a remote control, the output of the machine is turned ON and OFF by the remote device (i.e. hand or foot amptrol) connected to the remote connector on the front of the machine. Output must be triggered ON (output LED lit) to enable Lift TIG starting. After machine output is triggered ON, the arc must be started within 6.5 seconds or output will turn OFF and trigger sequence must be restarted. (Note: Any remote control device with trigger-only circuit, such as the K814 Arc Start Switch, will not be sensed by the V160-S remote control connection, and therefore will not allow control of the output).

Output Current Control: This controls the output or welding current of the machine.

The function of this control knob is changed if a remote control is connected. If the Remote LED is ON, this indicates that a remote control is connected and the function of the output current control will be:

- Stick Welding Mode: The remote control will adjust the output current of the machine from 5 to 160A.
 The output current control knob on the display panel is not used.
- TIG Welding Modes: The maximum output current of the machine is set by the output current control knob. The remote control then adjusts the output current from the minimum output (5A) to the value set by the output current control knob. For example, if the output current control knob on the machine is set to 100A then the remote control will adjust the output current from a minimum of 5A to a maximum of 100A.
- 10. "Twist-Mate" Connection (Negative):
- 11. Remote Control Connector:
- 12. "Twist-Mate" Connection (Positive):

FIGURE B.2



- 3. Mode Switch
- 4. Arc Control
- 5. Power LED
- 6. Thermal LED
- 7 Remote LED
- 0 Output LED
- 8. Output LED
- 9. Output Current Control
- 10. Electrode Connection (Negative)
- 11. Remote Control Connector
- 12. Electrode Connection (Positive)

Return to Master TOC

Return to Master TOC

DIP SWITCH FUNCTIONS

This section has 8 DIP switch functions of the V160-S. Read and understand the functions before making any changes because abnormal operation can occur with the wrong settings. The machine must be turned OFF when the DIP Switches are changed.

A WARNING



ELECTRIC SHOCK CAN KILL:

Be sure that all installation, operation, maintenance and repair procedures are performed only by qualified individuals. Lincoln Electric is not responsible for damages caused by

improper installation, improper care or abnormal operation.

Before opening the machine to make changes to the DIP Switches it must first be turned OFF and disconnected from the input source. Do not open the machine or change the DIP Switches with power applied to the machine. Only Lincoln trained service technicians are authorized to perform these modifications.

The DIP switches are numbered from 1 to 8 shown in Figure B.3. Switch 1 is on the bottom and switch 8 is on the top. When a switch is pushed to the right (or to the back of the machine) it is ON; when it is pushed to the left (or to the front of the machine) it is OFF.

The standard production settings for the V160-S are shown with in bold letters **ON** Table B.1. If a switch setting has bold letters **ON**, do not make any changes; abnormal operation could occur.

TABLE B.1


DIP	V160-S	V160-S
Switch	CE	USA
1	ON	ON
2	OFF	OFF
3	OFF	ON
4	ON	OFF
5	OFF	OFF
6	OFF	ON
7	OFF	OFF
8	OFF	OFF

DIP Switch 1: Machine Type

This controls the output of the V160-S and some welding waveform functions. It configures the V160-S to automatically turn ON depending on the position of the Welding Mode switch. Refer to DIP Switch 6 for more information.

DIP Switch 2 thru 5 non-functional for the V160-S.

FIGURE B.3



Return to Master TOC

Return to Master TOC

DIP Switch 6: European/USA Machine Configuration

This configures several functions of the V160-S as required by the European and USA markets. For the European market it is OFF and for the USA market it is ON.

Specifically, this configures the operation of the TIG slope timers, remote control, and trigger. However, this configuration also depends on the position of DIP Switch 1 which selects the machine type. This setting can be changed but only if the following functions are clearly understood.

(DIP Switch 1 = ON)

In TIG welding mode, the following conditions can exist.

- No TIG slopes are available. If slopes are needed a foot pedal remote control can be used.
- No remote control connected. With no remote control connected, the output is ON and a trigger is not needed. Simple Lift TIG welding is possible.
- Remote control connected. With a remote control connected, the output is OFF and a trigger is needed. Simple Lift-TIG welding is possible using a 2step trigger sequence.

DIP Switch 7 thru 8 non-functional for the V160-S.

START/CRATER CURRENT ADJUSTMENT

It is not possible to change the start/crater current of a "S" type machine. The values set from the factory are:

European Machines: 20% (160A welding current =

32A start/crater current)

USA Machines: 10% (160A welding current =

16A start/crater current)

Ac	cessories	.C-1
	Optional Accessories and Compatible Equipment	.C-2
	Factory, Field Installed	.C-2

C-1

Return to Master TOC

Return to Master TOC

OPTIONAL ACCESSORIES

AND COMPATIBLE EQUIPMENT

Factory Installed

Electrical Holder and Cable Assembly Work Cable and Clamp Strap Packet Instruction Manual

Field Installed

K870 - Foot Amptroltm for TIG welding. When the V160-S's Output Control is in the "REMOTE" position, the foot Amptrol energizes the output and controls the output remotely. The Foot Amptrol connects directly to the 6 pin Amphenol.

K963-3 - Hand Amptroltm for TIG welding. When the V160-S's Output Control is in the "Remote" position, the hand Amptrol energizes the output and controls the output remotely. The Hand Amptrol connects directly to the 6 pin Amphenol.

PTA-17V TIG Torch - 150 Amp air-cooled compact and durable Tig Torch with integral gas valve for gas control at the torch. The following 1-piece cable torches can be used with a K960-1 adapter:

- K1782-6 (12.50 Ft.) 1-Piece Cable
- K1782-8 (25.0 Ft.) 1-Piece Cable

PTA-9FV TIG Torch - Gas Valve flexible head torch:

• K1781-7 (25.0 Ft.) 1-Piece Cable

PTA-17FV TIG Torch - Gas Valve flexible head torch:

• K1782-11 (25.0 Ft.) 1-Piece Cable

K960-1-TIG Torch Adapter - for connection of PTA-17V torches (1-piece cable) to power sources without gas passing through the Twist Mate connection.

NOTE: Any remote control with trigger-only circuit, such as the K814 Arc Start Switch, will not be sensed by the V160-S remote control connection, and therefore will not allow control of the output.

CABLE PLUGS

K852-50 - Cable Plug Kit for #1-#2 cable. Attaches to welding cable to provide quick disconnect from machine.

TIG Torch Parts Kits - Parts kits are available for the PTA-17 TIG torch. This kit includes back cap, collets, collect bodies, nozzles and tungsten.

Order KP508 for PTA-17 torches See publication E12.150 for parts kits breakdown.

Cut Length Consumables - TIG welding filler metals are available for welding stainless steel, mild steel, aluminum and copper alloys. See publication C9.10.

Ma	aintenance	.D-1
	Safety Precautions	.D-2
	Input Filter Capacitor Discharge Procedure	.D-2
	Routine Maintenance	.D-2

D-1

Return to Master TOC

Return to Master TOC

SAFETY PRECAUTIONS





ELECTRIC SHOCK can kill.

- Have an electrician install and service this equipment.
- Turn the input power off at the fuse box, disconnect supply lines and allow machine to sit for five minutes minimum to allow the power capacitors to discharge before working inside this equipment.
- · Do not touch electrically hot parts.

A CAUTION

- Disconnect the power supply before every operation.
- Always use gloves in compliance with the safety standards.

INPUT FILTER CAPACITOR DISCHARGE PROCEDURE



WARNING

The machine has internal capacitors which are charged to a high voltage during power-on conditions. This voltage is dangerous and must be discharged before the machine can be serviced. Discharging is done automatically by the machine each time the power is switched off. However, you must allow the machine to sit for at least 5 minutes to allow time for the process to take place.

ROUTINE MAINTENANCE

Prevent metal powder from accumulating near the Heat Sink fins.



WARNING

Disconnect the power supply before every operation.


Carry out the following periodic controls on the power source:

- Clean the power source inside by means of lowpressure compressed air.
- Check the electric connections and all the connection cables.

E-1 TABLE OF CONTENTS-THEORY OF OPERATION SECTION E

Th	eory of Operation	E-1
	General Description	E-2
	Welding Capability	E-2
	Limitations	E-2
	Input Board	E-3
	Inverter Board	E-4
	Display Board	E-5
	Insulated Gate Bipolar Transistor (IGBT) Operation	E-6

FIGURE E.1 - V160-S BLOCK LOGIC DIAGRAM




T00C

Return to Master

T0C

Return to Master

FIGURE E.2 - GENERAL DESCRIPTION



GENERAL DESCRIPTION

The V160-S is an industrial 160 amp arc welding power source which utilizes single phase input power, to produce constant current output. The welding response of this Invertec has been optimized for stick (SMAW) and Touch Start TIG (GTAW). The unit is ideal for industrial applications were portability is important.

The Invertec V160-S is recommended for stick welding with such popular electrodes as Fleetweld 35, Fleetweld 37, Fleetweld 180 and LH 78. It features adjustable arc control to adjust the arc force and start.

The Invertec V160-S performs DC Touch Start Tig Starting with excellent results.

WELDING CAPABILITY

The Invertec V-160-S is rated at 160 amps, 26.4 volts, at 35% duty cycle on a ten minute basis. It is capable of higher duty cycles at lower output currents. It is capable of 130 amps, 25.2 volts at a 100% duty cycle. If the duty cycle is exceeded, a thermal protector will shut off the output until the machine cools. See *Technical Specifications* in A-2 for other related outputs.

LIMITATIONS

The V160-S is not recommended for pipe thawing.


NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion



TOC

Return to Master

FIGURE E.3 - INPUT BOARD



INPUT BOARD

The input board includes the following circuits:

INPUT LINE VOLTAGE, FAN CIR-CUIT, AUXILIARY VOLTAGE AND PRECHARGE

The Invertec V160-S can be connected to a 115V or 230V single phase input voltage.

This unit can also connect to engine driven generators but it must follow the below conditions:

- Vac peak voltage: below 250V (for 115Vac input) or 410V (for 230Vac input).
- Vac frequency: in the range of 50 and 60 Hertz.
- RMS voltage of the AC waveform:

V160-S: 115Vac or 230Vac +/- 10%

The initial power is applied to the Invertec V160-S directly on the input board. A line switch located on the back of the machine supplies the logic part that manages machine functions. The voltage is after

rectified by the input on the input rectifier on the input board and the resultant DC voltage is applied at inverter Pcb's.


During the precharge time the DC input voltage is applied to the filter capacitors (located on the inverter Pcb) through a precharge resistances (located on input board) that limit the charge current. During precharge time, an automatic system (manages by reconnect board mounted on the input board) sets the input board for 115V or 230V working mode (voltage duplicator when 115Vac is applied). After this time the start relays go closed and they by-pass the precharge resistances (there are two precharge relays, RL1B and RL4B). The input voltage is also applied to an auxiliary voltage circuit, that gives the necessary low voltages (+15V, -5V and +5V) for the control / display board and inverter board.

The fan is activated when the power is first supplied to the machine. It will stay on as long as output is present. The fan shuts down after 5 minutes when the output is shut off.

NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion



FIGURE E.4 - INVERTER BOARD



INVERTER BOARD

The inverter board includes the following circuits:


- Inverter circuit: Transforms the DC current at 80KHz and feeds the main transformer. The current is regulated via Pulse Width Modulation
- Main transformer: It has two functions:
 - 1) gives the correct output voltage for welding
 - 2) Insulates the operator side from the output line
- Output circuit: The output diodes rectify the output the current from the main transformer. The choke filters the output current. The shunt provides output feedback information to the control board.

NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion

Return to Master TOC

FIGURE E.5 - CONTROL/DISPLAY BOARD

THEORY OF OPERATION



DISPLAY BOARD

The display board receives status and analog signals from the inverter board and various sensors. It is composed of 2 parts:

- Weld controller: Interprets signals, makes decisions and changes the machine mode and output to satisfy the requirements dictated by the operator.
- Display board: Supports all the potentiometer, switches and LED

NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion

Return to Master TOC

Return to Master TOC


INSULATED GATE BIPOLAR TRAN-SISTOR (IGBT) OPERATION

An IGBT is a type of transistor. IGBT are semiconductors well suited for high frequency switching and high current applications.

Example A in figure E.6 shows an IGBT in passive mode. There is no gate signal, zero volts relative to the source, and therefore, no current flow. The drain terminal of the IGBT may be connected to a voltage supply; but since there is no conduction, the circuit will not supply current to the components connected to the source. The circuit is turned OFF like a light switch.

Example B shows the IGBT in an active mode. When the gate signal, a positive DC voltage relative to the source, is applied to the gate terminal of the IGBT, it is capable of conducting current. A voltage supply connected to the drain terminal will allow the IGBT to conduct and supply current to the circuit components coupled to the source. Current will flow through the conducting IGBT to downstream components as long as the positive gate signal is present. This is similar to turning ON a light switch.

FIGURE E.6 - IGBT



AA-1 TABLE OF CONTENTS - INSTALLATION SECTION V160-T AA-1

Inst	allation
	Technical Specifications
	Select Suitable Location
	Stacking
	Tilting
	Machine Grounding and High Frequency Interference Protection
	Input Connections
	Ground Connection
	Output Connections
	Output and Gas Connection for Tig Welding
	Work Cable Connection
	Output Connection for Stick Welding
	Quick Disconnect PlugAA-7
	Shielding Gas Connection
	Remote Control Connection

Return to Master TOC

Return to Master TOC

TECHNICAL SPECIFICATIONS - V160-T

INPUT - SINGLE PHASE ONLY						
Input Voltages / 50 /60 Hz.				Max. Input Current at rated Output		
115 V (20 115)	h)			20 A 25 A 34 A		
			D OUT			
Duty Cycle	Outp	out Amps	ut Amps Output Volts		Input Circuit	
1000/		(Stick)) (TIG)			115V (20A Plug and Branch)	
100%		(Stick) 0 (TIG)	23. 14.	_	115V (30A Branch)	
35%		160 (Stick) 26.4 160 (TIG) 16.4		230V (30A Branch)		
100%) (Stick) 0 (TIG)			230V (30A Branch)	
		0	UTPUT			
Output Current Range		Maximum Open Circuit Voltage		ltage	Type of Output	
5-160 Amps		48 Volts Max.		DC		
RECOMMENDE	D INPUT V	VIRE AND FUS	E SIZE	S FOR	MAXIMUM RATED OUTPUT	
INPUT VOLTAG FREQUENCY (I	I .			MAXIMUM TIME-DELAY CIRCUIT BREAKER OR FUSE SIZE (AMPS)		
230/50/60		#12			30	
PHYSICAL DIMENSIONS						
Height Width 12.6 in. 7.9 in. 320 mm 200 mm		16.9 in. A		1	Weight Approx. 24.2lbs. 11 kgs.	
	TEMPERATURE RANGES					
	OPERATING TEMPERATURE RANGE -20°C to +40°C				GE TEMPERATURE RANGE -50°C to +85°C	

Read entire installation section before starting installation.

SAFETY PRECAUTIONS

▲ WARNING



ELECTRIC SHOCK can kill.

- Only qualified personnel should perform this installation.
- Disconnect input power by removing plug from receptacle before working inside V160-T. Allow machine to sit for

5 minutes minimum to allow the power capacitors to discharge before working inside this equipment.

- Insulate yourself from the work and ground.
- Always wear dry insulating gloves.
- Always connect the V160-T to a power supply grounded according to the National Electrical Code and local codes.

SELECT SUITABLE LOCATION

This machine will operate in harsh environments. However, it is important that simple preventative measures are followed to assure long life and reliable operation.

- · Do not place or operate this machine on a surface with an incline greater than 15° from horizontal.
- This machine must be located where there is free circulation of clean air without restrictions for air movement to and from the air vents. Do not cover the machine with paper, cloth or rags when switched on.
- Dirt and dust that can be drawn into the machine should be kept to a minimum.
- · Keep the machine dry and do not place it on wet ground or in puddles.
- Locate the machine away from radio controlled machinery. Normal operation may adversely affect the operation of nearby radio controlled machinery, which may result in injury or equipment damage. Read the section on "Machine Grounding and High Frequency Interference Protection" in this manual.
- · When operated in ambient temperatures greater than 40°C, the output duty cycle may be reduced.

Do not mount over combustible surfaces.

STACKING

INSTALLATION

The Invertec V160-T cannot be stacked.

TILTING

Place the machine directly on a secure, level surface. The machine may topple over if this procedure is not followed.

MACHINE GROUNDING AND HIGH FRE-QUENCY INTERFERENCE PROTECTION

The Capacitor Discharge Circuit used in the high frequency generator can be blamed for many radio, TV and electronic equipment interference problems. These problems may be the result of radiated interference. Proper grounding methods can reduce or eliminate radiated interference.

The Invertec V160-T has been field tested under recommended installation conditions. It complies with FCC allowable limits for radiation.

Radiated interference can develop in the following four ways:

- 1. Direct interference radiated from the welder.
- 2. Direct interference radiated from the welding leads.
- 3. Direct interference radiated from feedback into the power lines.
- 4. Interference from re-radiation of "pickup" by ungrounded metallic objects.

Keeping these contributing factors in mind, installing equipment per the following instructions should minimize problems.

- Keep the welder power supply lines as short as possible and enclose as much of them as possible in rigid metallic conduit or equivalent shielding for a distance of 50ft. (15.2m). Both ends of the conduit should be connected to a driven ground and the entire length should be continuous.
- Keep the work and electrode leads as short as possible and as close together as possible. Lengths should not exceed 25ft. (7.6m). Tape the leads together when practical.
- 3. Be sure the torch and work cable rubber coverings are free of cuts and cracks that allow high frequency leakage. Cables with high natural rubber content, such as <u>Lincoln Stable-Arc</u>[®] better resist high frequency leakage than neoprene and other synthetic rubber insulated cables.
- 4. Keep the torch in good repair and all connections tight to reduce high frequency leakage.
- The work terminal must be connected to a ground within ten feet of the welder, using one of the following methods.
 - A metal underground water pipe in direct contact with the earth for ten feet or more.
 - b) A 3/4" (19mm) galvanized pipe or a 5/8" (16mm) solid galvanized iron, steel or copper rod driven at least eight feet into the ground.

The ground should be securely made and the grounding cable should be as short as possible using cable of the same size as the work cable, or larger. Grounding to the building frame electrical conduit or a long pipe system can result in re-radiation, effectively making these members radiating antennas.

- 6. Keep all panels securely in place.
- 7. All electrical conductors within 50 ft (15.2m) of the welder should be enclosed in grounded, rigid metallic conduit or equivalent shielding. Flexible metallic conduit is generally not suitable.
- 8. When the welder is enclosed in a metal building, several earth driven electrical grounds connected (as in 5 (b) above) around the periphery of the building are recommended.

Failure to observe these recommended installation procedures can cause radio or TV interference problems.

INPUT CONNECTIONS

WARNING

ELECTRIC SHOCK can kill.



- Have a qualified electrician install and service this equipment.
- Disconnect input power by removing plug from receptacle before working inside V160-T. Allow machine to sit for 5 minutes minimum to allow the power capacitors to discharge before working inside this equipment.
- Do not touch electrically hot parts.

GROUND CONNECTION



The frame of the welder must be grounded. A ground terminal marked with the symbol is located on the under panel for this purpose. See your local and national electrical codes for proper grounding methods.

A CAUTION

The grounding is supplied in the input cord, it is important that the Supply Receptacle Ground connection is connected.

A WARNING

This installation should be performed by a qualified electrician to ensure correct connections of the leads to the plug spades.

- The electrical system must be made by skilled technicians with the specific professional and technical qualifications and in compliance with the regulations in force in the country where the equipment is installed.
- The welding power source supply cable is provided with a green or yellow/green wire that must ALWAYS be earthed. This green or yellow/green wire must NEVER be used with other voltage conductors.
- Install only plugs that are corresponding to safety regulations.

Return to Master TOC

AA-5 INSTALLATION AA-5

Fuse the input circuit with time delay fuses marked "D" or delay type¹ circuit breakers. Using fuses or circuit breakers smaller than recommended may result in "nuisance" shut-offs from welder inrush currents even if not welding at high currents.

'Also called "inverse time" or "thermal/magnetic" circuit breakers. These circuit breakers have a delay in tripping action that decreases as the magnitude of the current increases.

The Invertec V160-T is recommended for use on an individual branch circuit.

115V INPUT

The rated output of the V160-T is available when connected to a 30A branch circuit. When connected to a branch circuit with lower ampacity, lower welding current and duty cycle must be used. An output guide is provided below. The values are approximate and must be adjusted downward if the fuse or circuit breaker trips off. Other loads on the circuit and fuse/circuit breaker characteristics will affect the available output. Do not exceed these welding conditions:

15A plug on a 15A branch

10% duty cycle Stick: 65A TIG: 95A

15A plug on a 20A branch

10% duty cycle Stick: 75A TIG: 105A

20A plug on a 20A branch

10% duty cycle Stick: 85A TIG: 120A

The Invertec V160-T is provided with a 115/230V cable, 6.6ft.(2m) in length, with a 15Amp 5-15P plug molded onto the cord.

The V160-T is supplied with an additional 20A plug that can replace the 15A plug to achieve higher output. To install the supplied 20A plug:

Connect the white (neutral) wire under terminal clamp with silver screw, and black (hot) wire under terminal clamp with brass screw. Connect green wire under terminal clamp with green screw.

ARFU (Auto-Restore Fuse)

The dual input voltage machine is provided with an ARFU device. It only operates when the input is connected to an 115V supply and protects from input over current conditions.

When the ARFU has been activated due to an input over current condition, the output will be turned off and the green Power LED will blink indicating an over-current condition. This condition usually occurs when the unit is operated beyond its rated duty cycle. The unit will self-restore after a short time and will be ready for normal operation once the green Power LED stops blinking and remains on.

NOTE: The ARFU replaces a fuse (F2) that was used in older V160's.

▲ WARNING

 Failure to wire as instructed may cause personal injury or damage to equipment. To be installed or checked by an electrician or qualified person only.

230V INPUT

To achieve the full output capacity of the V160-T, 230VAC inputs should be used. The change over is accomplished by replacing the 115VAC plug with a 30 Amp 230VAC plug (NEMA 6-30P).

ATTACHMENT PLUG

In all cases, the green or green/yellow grounding wire must be connected to the grounding pin of the plug, usually identified by a green screw.

All attachment plugs must comply with the Standard for Attachment Plugs and Receptacles, UL498.

The product is considered acceptable for use only when an attachment plug as specified is properly attached to the supply cord.

The Invertec V160-T will auto reconnect to either 115V or 230V supplies.

ENGINE DRIVEN GENERATOR

For use on engine drives, keep in mind the above input draw restrictions and the following precaution.

The Invertec V160-T can be operated on engine driven generators as long as the 230 volt auxiliary meets the following conditions:

- The AC waveform peak voltage is below 400 volts*.
- The AC waveform frequency is between 45 and 65Hz.
- The RMS voltage of the AC waveform is always greater than 208VAC *.
- * for 115 VAC input divide these values in half.

The following Lincoln engine drives meet these conditions when run in the high idle mode:

Return to Master TOC

Return to Master TOC

Return to Master TOC

- Ranger 250,305
- Commander 300, 400, & 500

Many engine drives do not meet these conditions (eg Miller Bobcats, etc). Operation of the Invertec V160-T is not recommended on engine drives not conforming to these conditions. Such combinations may overvoltage the Invertec V160-T power source.

OUTPUT CONNECTIONS


A WARNING




ELECTRIC SHOCK can kill.

Keep the electrode holder, TIG torch and cables insulation in good condition and in place.

OUTPUT AND GAS CONNECTION FOR TIG WELDING (FIGURE AA.1)



This unit does not include a TIG torch, but one may be purchased separately. The Lincoln PTA-9 (K1781-1 or K1781-3 only with no gas valve) or PTA-17 (K1782-1 or K1782-3) are recommended for use with this machine for this purpose; however, any similar TIG torch can be used. To attach the Twist-Mate Plug to a Lincoln Torch, slide the rubber boot onto the torch cable (enlarge the boot opening if necessary), screw the fitting on the torch cable into the brass connector snugly and slide the boot back over the brass connector.



The ground lead and TIG Torch Twist Mate® Connector are supplied with the welder. To connect the cables, turn the Power Switch "OFF". Connect the torch Twist Mate plug into the DC(-) Electrode/Gas Output Receptacle on the front of the welder and turn it clockwise until tight.


WORK CABLE CONNECTION

Next, connect the work cable to the "+" output terminal in the same way.

To minimize high frequency interference, refer to Machine Grounding and High Frequency Interference Protection section of this manual for the proper procedure on grounding the work clamp and work piece.

- Do not touch electrically live parts or electrode with skin or wet clothing.
- Insulate yourself from work and ground.
- Turn the input line Switch on the Invertec V160-T "off" before connecting or disconnecting output cables or other equipment.

OUTPUT CONNECTION FOR STICK WELDING (FIGURE AA.2)



First determine the proper electrode polarity for the electrode to be used. Consult the electrode data for this information. Then connect the output cables to the output terminals corresponding to this polarity. For instance, for DC(+) welding, connect the electrode cable (which is connected to the electrode holder) to the "+" output terminal and the work cable (which is connected to the work clamp) to the "-" output terminal. Insert the connector with the key lining up with the keyway, and rotate approximately 1/4 turn clockwise; until the connection is snug. Do not over tighten.

Return

T0C

Return to Master

Return to Master TOC


TOC

Return to Master


QUICK DISCONNECT PLUG (FOR STICK ELEC-TRODE CABLE)

A quick disconnect system is used for the welding cable connections. The stick electrode cable will need to have a plug attached.


- 1. Cut off welding cable lug, if present.
- 2. Remove .75 in. (19mm) of welding cable insulation.
- 3. Slide rubber boot onto cable end. The boot end may be trimmed to match the cable diameter. Use soap or other nonpetroleum-based lubricant to help slide the boot over the cable, if needed.




4. Cut 45-50% of the copper strands back 1/4" (6 mm).



5. Fold copper strands over cut strands and insert into ferrule.



- 6. Slide the copper ferrule into the brass plug.
- 7. Tighten set screw to collapse copper tube. Screw must apply pressure against welding cable. The top of the set screw will be well below the surface of the brass plug after tightening.



8. Slide rubber boot over brass plug. The rubber boot must be positioned to completely cover all electrical surfaces after the plug is locked into the receptacle.

SHIELDING GAS CONNECTION

Obtain the necessary inert shielding gas. Connect the cylinder of gas with a pressure regulator and flow gage. Install a gas hose between the regulator and gas inlet (located on the rear of the welder). The gas inlet has a 5/16-18 right hand female thread; CGA #032.

A WARNING



INSTALLATION

CYLINDER could explode if damaged.

- ·Keep cylinder upright and chained to a support.
- Keep cylinder away from areas where it could be damaged.
- •Never allow the torch to touch the cylinder.
- ·Keep cylinder away from live electrical circuits.

REMOTE CONTROL CONNECTION

A remote control receptacle is provided on the lower center case front of the welder for connecting a remote control to the machine. Refer to the Optional Accessories section of this manual for available remote controls.

The following items can be connected to the 6 pin socket on the front panel:

- Remote control potentiometer (K857) for Stick welding.
- Remote Foot Amptrol (K870), Hand Amptrol (K963-3).
- Arc Start Switch (K814).

Return to Section TOC Return to Master TOC

Return to Section TOC Return to Master TOC

Return to Section TOC Return to Master TOC

BB-1

BB-1

Operation	ion	BB-1
Safe	ety Precautions	BB-2
Gen	neral Description	BB-2
Wel	Iding Capability	BB-2
Limi	itations	BB-2
Rea	ar Control Panel	BB-3
Con	ntrols and Settings, 2 Step and 4 Step Tig Sequence	BB-3/BB-6
DIP	Switch Functions (Service Information)	BB-7
[DIP Switch 1: Machine Type	BB-7
[DIP Switch 2: Preflow Timer	BB-7
[DIP Switch 3: 2 Step Restart Enable	BB-8
[DIP Switch 4: 4 Step Restart Enable	BB-9/BB-10
[DIP Switch 5: Low OCV Enable	
[DIP Switch 6: European/USA Machine Configuration	
[DIP Switch 7 & 8: Upslope Timer	BB-12
5	Start/Crater Current Adjustment	BB-12

Return to Section TOC

Return to Master

Return to Master TOC

Return to Master TOC

Read and understand this entire section before operating your machine.

SAFETY INSTRUCTIONS

WARNING



ELECTRIC SHOCK can kill.

- Do not touch electrically live parts such as output terminals or internal wiring.
- Insulate yourself from the work and ground.
- · Always wear dry insulating gloves.



FUMES AND GASES can be dangerous.

- · Keep your head out of fumes.
- Use ventilation or exhaust to remove fumes from breathing zone.



WELDING, CUTTING and **GOUGING SPARKS** can cause fire or explosion

- Keep flammable material away.
- · Do not weld, cut or gouge on containers that have held combustibles.



ARC RAYS can burn.

 Wear eye, ear and body protection.

Only qualified personnel should operate this equipment. Observe all safety information throughout this manual.

GENERAL DESCRIPTION

OPERATION

The Invertec V160-T is an industrial 160 amp arc welding power source which utilizes single phase input power, to produce constant current output. The welding response of this Invertec has been optimized for stick (SMAW) and TIG (GTAW). The unit is ideal for industrial applications where portability is important.

The Invertec V160-T performs DC TIG with high frequency or Touch Start Tig Starting with excellent results.

WELDING CAPABILITY

The Invertec V160-T is rated at 160 amps, 26.4 volts, at 35% duty cycle on a ten minute basis. It is capable of higher duty cycles at lower output currents. It is capable of 130 amps, 25.2 volts at 100% duty cycle(1). If the duty cycle is exceeded, a thermal protector will shut off the output until the machine cools. See Technical Specifications in A-1 for other rated outputs.

The Invertec V160-T is recommended for stick welding with such popular electrodes as Fleetweld® 35, Fleetweld 37, Fleetweld 180 and Jet-LH 78 MR.

LIMITATIONS

The V160-T is not recommended for pipe thawing.

(1)When connected to 230VAC inputs.

Return to Master TOC

Return to Master TOC

REAR CONTROL PANEL

- Power Switch: Controls the input power to the machine. Make sure the machine is properly connected to the input supply before turning the machine on. (See Figure BB.1)
- 2. Fan: The cooling fan will turn ON when the machine is turned ON and it will continue to run whenever the output of the machine is ON. If the output of the machine is OFF for more than five minutes, the fan will turn OFF. This reduces the amount of dirt that is deposited inside the machine and reduces power consumption.(See Figure BB.1)

Refer to the Output LED section below for more information about conditions when the output of the machine is ON.

Gas Inlet: Connector for the TIG shielding gas. The gas source must have a pressure regulator and flow gage installed.(See Figure BB.1)

CONTROLS AND SETTINGS (See Figure BB.2)

 Mode Switch: This switch changes the welding modes of the machine. The V160-T has three welding modes: Stick (SMAW), Lift TIG (GTAW) and HF TIG (GTAW).

When the mode switch is in the Stick position, the following welding features are enabled:


- Hot Start: This is a temporary increase in the output current during the start of the stick welding process.
 This helps ignite the arc quickly and reliably.
- Arc Force: This is a temporary increase in the output current during normal stick welding. This temporary increase in output current is used to clear intermittent connections between the electrode and the weld puddle that occur during normal stick welding.
- Anti-Sticking: This is a function which decreases the output current of the machine to a low level when the operator makes an error and sticks the electrode to the work piece. This decrease in current allows the operator to remove the electrode from the electrode holder without creating large sparks which can damage the electrode holder.

1. Power Switch

Fan
 Gas Inlet



OPERATION



- V160-S & -T
 - INCOIN®


Return to Master TOC

BB-4 BB-4 OPERATION

When the mode switch is in the **Lift TIG** position, the stick welding functions are disabled and the machine is ready for Lift TIG welding. Lift TIG is a method of starting a TIG weld by first pressing the TIG torch electrode on the work piece in order to create a low current short circuit. Then, the electrode is lifted from the work piece to start the TIG arc. After machine output is triggered ON, the arc must be started within 6.5 seconds or output will turn OFF and trigger sequence must be restarted.

When the mode switch is in the **HF TIG** position, the stick welding functions are disabled and the machine is ready for HF TIG welding. During the HF TIG mode, the TIG arc is started by HF without pressing the electrode on the work piece. After triggering output ON, the HF (and output) used for starting the TIG arc will remain ON for 6.5 seconds. If the arc is not started in this time limit, the trigger sequence must be restarted.

- 5. Trigger Mode Switch: This switch changes between 2step and 4-step trigger sequences. For an explanation of these trigger sequences refer to the Trigger Mode Sequences following Controls and Settings.
- 6. Power LED: This indicator will blink on and off when the machine is first turned on. After approximately 2 seconds it will stop blinking and remain on to signal that the machine is ready. The indicator will also blink during over current conditions when operating on 115V input.
- 7. Thermal LED: This indicator will turn on when the machine is overheated and the output has been disabled. This normally occurs when the duty cycle of the machine has been exceeded. Leave the machine on to allow the internal components to cool. When the indicator turns off, normal operation is again possible.



- 8. Remote LED: This indicator will turn ON when a remote control is connected to the machine via the remote control connector. Using a remote control will change the function of the output current control., refer to the output current control section below. (Note: When K814 Arc Start Switch is connected to remote connector, remote LED will remain OFF).
- 9. Output LED: This indicator turns on when the output of the machine is on.
 - · In the stick welding mode, the output of the machine is automatically turned ON.
 - · For both of the TIG welding modes, the output of the machine is turned ON and OFF by an Arc Start Switch or Hand/Foot Amptrol attached to the Remote Control Connector, (See #4 - Mode Switch - above for details on output triggering for TIG arc starting).
- 10. Output Current Control: This controls the output or welding current of the machine.

The function of this control knob is changed if a remote control is connected. If the Remote LED is ON, this indicates that a remote control is connected and the function of the output current control will be:

- · Stick Welding Mode: The remote control will adjust the output current of the machine from 5 to 160A. The output current control knob on the display panel is not used.
- TIG Welding Modes: The maximum output current of the machine is set by the output current control knob. The remote control then adjusts the output current from the minimum output (5A) to the value set by the output current control knob. For example, if the output current control knob on the machine is set to 100A then the remote control will adjust the output current from a minimum of 5A to a maximum of 100A.
- 11. Downslope Control: In the TIG welding modes, this control knob will adjust the downslope time from 0.5 to 20 seconds. (The default upslope time is 0.5 seconds.) Refer to the trigger sequence section below to understand how downslope is activated. In Stick welding mode, this function is not used.
- 4. Mode Switch
- 5. Trigger Mode Switch
- 6. Power LED
- 7. Thermal LED
- 8. Remote LED
- 9. Output LED
- 10. Output Current Control
- 11. Downslope Control
- 12. Postflow Control
- 13. Digital Display

- 14. Pulse Mode Switch
- 15. Pulse LED
- 16. Pulse Frequence Control
- 17. Background Current Control
- 18. Electrode Connection (Negative)
- 19. Remote Control Connector
- 20. Electrode Connection (Positive)

- 12. Postflow Control: In the TIG welding modes, this control knob will adjust the shielding gas postflow time from 0.5 to 30 seconds. (The preflow time is always 0.5 seconds.) In Stick welding mode, this function is not used.
- 13. Digital Display: This meter displays the preset welding current before welding and the actual welding current during welding. Like the output current control, the function of the meter is changed if a remote control is connected.
- 14. Pulsing Mode Switch: In the TIG welding modes, this switch turns the pulsing function ON and controls the pulsing frequency range (20Hz or 300Hz). In Stick welding mode, this function is not used.
- 15. Pulsing LED: This indicator shows the pulsing frequency when pulsing is turned ON. With this indication, the operator can adjust the frequency to the desired value before welding. (Note: At higher frequencies the LED blinks very fast and seems to be continuously ON however it is pulsing.) If pulsing is turned OFF or if the machine is in Stick welding mode, the indicator will be OFF.
- 16. Pulsing Frequency Control: When the pulsing function is ON, this control knob will adjust the pulsing frequency. The pulsing frequency adjustment range is 0.2 20Hz or 3 300Hz depending on the Pulsing Mode Switch position.
- 17. Background Current Control: When the pulsing function is ON, this control knob will adjust the pulsing background current. This is the current during the low portion of the pulse waveform; it can be adjusted from 10% to 90% of the welding current.

TRIGGER MODE SEQUENCES

For the V160-T, TIG welding can be done in either the 2-step or 4-step mode which is selected with the Trigger Mode Switch. DIP Switch functions are set by the factory. For adjustments on DIP Switch settings and functions see DIP SWITCH FUNCTIONS in this Operations Section.

2-Step Sequence

Note: 2-Step works with either an Arc Start Switch (for output triggering only, current control is at machine) or with a Foot or Hand Amptrol™ (for both remote output triggering and current control). 2-Step used with Arc Start Switch is referenced in following sequence.

1. Press and hold the Arc Start Switch to start the sequence.

The machine will open the gas valve to start the flow of the shielding gas. After a 0.5 second preflow time to purge air from the torch hose, the output of the machine is turned ON. At this time the arc can be started. After the arc is started the output current will be increased to the welding current. The time for this increase or upslope is presettable. The default is 0.5 seconds.


2. Release the Arc Start Switch to stop welding.

OPERATION

The machine will now decrease the output current at a controlled rate or downslope time, until the Start/Crater current is reached and the output of the machine is turned OFF. The downslope time is adjusted by the Downslope Parameter.


After the arc is turned OFF, the gas valve will remain open to continue the flow of the shielding gas to the hot electrode and work piece. The duration of this postflow shielding gas is adjusted by the Postflow Parameter. This operation is shown in (2 step diagram 1).

2 Step Diagram 1



Possible variations of this standard sequence is shown below. It is possible to press and hold the TIG torch trigger a second time during downslope to restart. After the trigger is pressed the output current will increase to the welding current. This operation is shown in (2 step diagram 2).

2 Step Diagram 2



Return to Master TOC

Return to Master TOC

4-Step Sequence

Note: 4-Step works with Arc Start Switch only. Amptrol™ type devices will not work properly and should not be used. The Arc Start Switch's actuator is also referred to as the "Tig torch trigger" in the following sequence.

1. Press and hold the Arc Start Switch to start the sequence. The machine will open the gas valve to start the flow of the shielding gas. After 0.5 second preflow time to purge air from the torch hose, the output of the machine is turned ON. At this time the arc can be started. After the arc is started the output current will be at the Start/Finish current. This condition can be maintained as long or as short as necessary.

If the Start/Finish current is not necessary, do not hold the TIG torch trigger as described at the beginning of this step. Instead, quickly press and release the trigger. In this condition, the machine will automatically pass from Step 1 to Step 2 when the arc is started.

2. Release the TIG torch trigger to start the main part of the weld.

The output current will increase to the welding current. The time for this increase or upslope is presettable. The default is 0.5 seconds.


3. Press and hold the TIG torch trigger when the main part of the weld is complete.

The machine will now decrease the output current at a controlled rate or downslope time, until the Start/Finish current is reached. The downslope time is adjusted by the Downslope Parameter. This Start/Finish current can be maintained as long or as short as necessary.

4. Release the TIG torch trigger.


The output current of the machine will turn OFF and the gas valve will remain open to continue the flow of the shielding gas. The duration of this postflow time is adjusted by the Postflow control knob. This operation is shown in (4 step diagram 1).

4 Step Diagram 1



Possible variations of this standard sequence are shown below. It is possible to press and hold the TIG torch trigger another time to end the downslope time and maintain the output current at the Start/Finish current. When the TIG torch trigger is released the output will turn OFF and postflow will begin. This operation shown in (4 step diagram 2).

4 Step Diagram 2



Return to Master TOC

Return to Master TOC

DIP SWITCH FUNCTIONS

The following sections explain the 8 DIP switch functions of the V160. Read and understand the functions before making any changes because abnormal operation can occur with the wrong settings. The machine must be turned OFF when the DIP Switches are changed.

▲ WARNING



ELECTRIC SHOCK CAN KILL:

Be sure that all installation, operation, maintenance and repair procedures are performed only by qualified individuals. Lincoln Electric is not

responsible for damages caused by improper installation, improper care or abnormal operation.

Before opening the machine to make changes to the DIP Switches it must first be turned OFF and disconnected from the input source. Do not open the machine or change the DIP Switches with power applied to the machine. Only Lincoln trained service technicians are authorized to perform these modifications.

The DIP switches are numbered from 1 to 8 shown in Figure BB.3. Switch 1 is on the bottom and switch 8 is on the top. When a switch is pushed to the right (or to the back of the machine) it is ON; when it is pushed to the left (or to the front of the machine) it is OFF.

The standard production settings for the V160-T are shown with in bold letters **OFF** Table BB.1. If a switch setting has bold letters **OFF**, do not make any changes; abnormal operation could occur.

TABLE BB.1


DIP	V160-T	V160-T Pulse	V160-T
Switch	CE	CE	USA
1	OFF	OFF	OFF
2	OFF	OFF	OFF
3	OFF	OFF	ON
4	ON	ON	OFF
5	OFF	OFF	OFF
6	OFF	OFF	ON
7	OFF	OFF	OFF
8	OFF	OFF	OFF

DIP Switch 1: Machine Type

This controls the output of the V160-T and some welding waveform functions. It configures the V160-T to automatically turn OFF depending on the position of the Welding Mode switch. Refer to DIP Switch 6 for more information.

DIP Switch 2: Preflow Timer

This controls the preflow timer for TIG welding (used only on "T" type machines). When the DIP switch is OFF the preflow time is 0.5 seconds. When it is ON the preflow time is 0.1 seconds.



Return to Master TOC


Return to Master TOC

DIP Switch 3: 2 Step Restart Enable

This controls the 2 Step Restart function. When the switch is ON the 2 Step Restart function is enabled.


2-Step Restart Disabled (DIP Switch 3 = OFF)

- Press and hold the TIG torch trigger to start the sequence. The machine will open the gas valve to start the flow of the shielding gas. After the preflow time, the output of the machine is turned ON. At this time the arc is started according to the selected welding mode (Lift TIG or HF TIG). After the arc is started the output current will be increased (upslope) to the welding current.
- Release the TIG torch trigger to stop welding. The
 machine will now decrease the output current at a
 controlled rate (downslope), until the Start/Crater
 current is reached and the output of the machine is
 turned OFF. After the arc is turned OFF, the gas
 valve will remain open for the duration of the postflow time. FIGURE BB.4



As shown in figure BB.5, it is also possible to press and hold the TIG torch trigger a second time during downslope to end the downslope time and maintain the output current at the Start/Crater current. When the TIG torch trigger is released the output will turn OFF and the postflow time will start.

FIGURE BB.5




2-Step Restart Enabled (DIP Switch 3 = ON)

Same as step 1.

Same as step 2.

As shown in figure BB.6, it is possible to press and hold the TIG torch trigger a second time during downslope to restart. After the trigger is pressed the output current will increase to the welding current, like in step 1. When the main part of the weld is complete go to the beginning of step 2.




Return to Master TOC

DIP Switch 4: 4 Step Restart Enable

This controls the 4 Step Restart function. When the switch is ON the 4 Step Restart function is enabled. ("Foot pedal" remote controls should never be used with the 4 step sequences.)

- 4-Step Restart Disabled (DIP Switch 4 = OFF)
- 1. Press and hold the TIG torch trigger to start the sequence. The machine will open the gas valve to start the flow of the shielding gas. After the preflow time, the output of the machine is turned ON. At this time the arc is started according to the selected welding mode (Lift TIG or HF TIG). After the arc is started the output current will be at the Start/Crater current. This condition can be maintained as long or as short as necessary.





If the Start/Crater current is not necessary, do not hold the TIG torch trigger as described at the beginning of this step. Instead, quickly press and release it. In this condition, the machine will automatically pass from Step 1 to Step 2 when the arc is started.


- 2. Release the TIG torch trigger to start the main part of the weld. The output current will be increased (upslope) to the welding current.
- 3. Press and hold the TIG torch trigger when the main part of the weld is complete. The machine will now decrease the output current at a controlled rate (downslope), until the Start/Crater current is reached. This Start/Crater current can be maintained as long or as short as necessary.
- 3A. If it is not necessary to maintain the Start/Crater current, the TIG torch trigger can be pressed and released instead of holding it. In this case, step 4 will automatically follow.

Release the TIG torch trigger. The output current of the machine will turn OFF and the gas valve will remain open for the duration of the postflow time.


OPERATION

As shown in figure BB.8, after the TIG torch trigger is quickly pressed and released from step 3A, it is possible to press and hold the TIG torch trigger another time to end the downslope time and maintain the output current at the Start/Crater current. When the TIG torch trigger is released the output will turn OFF and postflow will begin.

FIGURE BB.8



As shown in figure BB.9, again after the TIG torch trigger is quickly pressed and released from step 3A, it is possible to quickly press and release the TIG torch trigger a second time to end the downslope time and stop welding.



Return to Master TOC

Return to Master TOC


4-Step Restart Enabled (DIP Switch 4 = ON)

Same as step 1.

Same as step 2.

3. Press and hold the TIG torch trigger when the main part of the weld is complete. The machine will now decrease the output current at a controlled rate (downslope), until the Start/Crater current is reached. This Start/Crater current can be maintained as long or as short as necessary.

FIGURE BB.10




This sequence has an automatic restart so welding will continue after this step. If the weld is completely finished, use the following sequence instead of step 3 described above.

- 3A. Quickly press and release the TIG torch trigger. The machine will now decrease the output current at a controlled rate (downslope), until the Start/Crater current is reached and the output of the machine is turned OFF. After the arc is turned OFF the postflow time will start.
- 4. Release the TIG torch trigger. The output current will again increase (upslope) to the welding current, like in step 2, to continue welding. When the main part of the weld is complete go to step 3.


As shown in figure BB.11, after the TIG torch trigger is quickly pressed and released from step 3A, it is possible to press and hold the TIG torch trigger another time to end the downslope time and maintain the output current at the Start/Crater current. When the TIG torch trigger is released the output will again increase (upslope) to the welding current, like in step 4, to continue welding. When the main part of the weld is complete go to step 3.

FIGURE BB.11

OPERATION



As shown in figure BB.12, again after the TIG torch trigger is quickly pressed and released from step 3A, it is possible to quickly press and release the TIG torch trigger a second time to end the downslope time and stop welding.



Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

BB-11 OPERATION

DIP Switch 5: Low OCV Enable

This controls the OCV of the machine. When the DIP switch is OFF the OCV is set to the normal level as stated in the manuals for the machines. When the DIP switch is ON the OCV is reduced to 20V. This low OCV mode was created for the Australian markets and should only be used as required by these Australian specifications. The low OCV will somewhat reduce the starting performance of the machine when dirt, rust, and/or slag is present on the work piece.

DIP Switch 6: **European/USA Machine** Configuration

This configures several functions of the V160 as required by the European and USA markets. For the European market it is OFF and for the USA market it is ON.

Specifically, this configures the operation of the TIG slope timers, remote control, and trigger. However, this configuration also depends on the position of DIP Switch 1 which selects the machine type. This setting can be changed but only if the following functions are clearly understood.

(DIP Switch 1 = OFF)

In TIG welding mode, the following conditions can exist.

 European Machine Configuration (DIP Switch 6 = OFF)

The TIG slope functions are always enabled. After the arc is started the output current will be increased (upslope) to the welding current. At the end of the weld the current will be decreased with the downslope function. Using a "foot pedal" remote control is not recommended with this setup.

A trigger is always needed to turn ON the output of the machine.

- USA Machine Configuration (DIP Switch 6 = ON) The TIG slope functions depends on the possible connection of a remote control.
- No remote control connected. The TIG slope functions are enabled. After the arc is started the output current will be increased (upslope) to the welding current. At the end of the weld the current will be decreased with the downslope function.

 Remote control connected. The TIG slope functions are disabled for the 2 step trigger mode. If slopes are needed a foot pedal remote control can be used. The TIG slope functions are enabled for the 4 step trigger mode.

A trigger is always needed to turn ON the output of the machine.

Return to Master TOC

Return to Master TOC

DIP Switch 7 & 8: Upslope Timer

These control the upslope timer for TIG welding (used only on "T" type machines). The following table shows the DIP Switch settings and selected upslope time.

DIP Switch 7	DIP Switch 8	Upslope Time
ON	ON	0.1 seconds
OFF	OFF	0.5 seconds
ON	OFF	1 second
OFF	ON	4 seconds

Start/Crater Current Adjustment

The start/crater current of a "T" type machine can be changed if necessary. The values are set from the factory.

European Machines:

20% (160A welding current = 32A start/crater current)

USA Machines:

10% (160A welding current = 16A start/crater current)

A WARNING

Be sure that all installation, operation, maintenance and repair procedures are performed only by qualified individuals. Lincoln Electric is not responsible for damages caused by improper installation, improper care or abnormal operation.

This adjustment procedure must be performed only by Lincoln trained service technicians. The machine will be operating with the cover removed where it is possible to come in contact with high Read all the following instructions voltages. before starting the procedure.



ELECTRIC SHOCK CAN KILL:

- · Welding equipment generates high voltages.
- Do not touch the live parts of the machine, the electrode, the work clamp, or connected work pieces when this equipment is on.
- · Insulate yourself from live electrical connections, the electrode, the work clamp, and the connected work pieces.

- 1. Remove the cover of the machine to access the control Printed Circuit Boards on the case front.
- To adjust the start/crater current, output current from the machine must flow through a load bank or a TIG arc. Connect the necessary equipment. In both cases, load bank or TIG arc, a trigger must be connected to the machine. If a load bank is used, it must be setup for 160A and approximately 25V.
- 3. Make sure all electrical connections are free from contact with other parts of the machine. Reconnect the case back if necessary. Turn ON the machine.
- 4. On the control panel of the machine, select the fol-
 - · Mode Switch: LIFT TIG (Do not use HF TIG or damage to measuring equipment will occur.)
 - Trigger Mode: 4 Step
 - Pulsing: OFF

OPERATION

- Output Current: Maximum (160A)
- 5. Activate the trigger of the machine to achieve the start or crater current portion of the welding sequence. Refer to the trigger sequences explained above if more information is needed.
- 6. In this condition, measure the output current of the machine and adjust the start/crater current as necessary. The calibration trimmer for the start/crater current is located on the left side of the machine (as viewed from the front) on the display board. The access hole for this trimmer is the higher one on the display board. (Do not adjust the lower trimmer on the display board; this is the output current calibration.)

The output current is set to 160A, therefore the start/crater current calibration will be a percentage of this 160A setting. Use the following equation for determining the desired start/crater current calibration:

Desired start/crater current percentage multiplied by 160 = calibration current.

For example, to calibrate the machine for 15% start/crater current, multiply this by 160 to get the calibration current ($0.15 \times 160 = 24$).

7. Release the trigger to turn off the output of the machine. Turn OFF the machine and disconnect it from the input source. Reassemble the machine making sure the ground wire to the cover is connected.

Accessories		CC-1
Optional Accessories and	Compatible Equipment	
Factory, Field Installed		

CC-1

Return to Master TOC

Return to Master TOC

OPTIONAL ACCESSORIES AND COMPATIBLE EQUIPMENT

Factory Installed

- 1-Twist-Mate Torch Connector (W/Gas Pass Through)
- 1- Ground Lead and Plug Assembly Strap Packet

Instruction Manual

Field Installed

K870 - Foot Amptroltm for TIG welding. When the V160-T's Output Control is in the "REMOTE" position, the foot Amptrol energizes the output and controls the output remotely. The Foot Amptrol connects directly to the 6 pin Amphenol.

K963-3 - Hand Amptroltm for TIG welding. When the V160-T's Output Control is in the "Remote" position, the hand Amptrol energizes the output and controls the output remotely. The Hand Amptrol connects directly to the 6 pin Amphenol.

K814 - Arc Start Switch - Energizes the output for TIG welding if remote output control of the amperage is not desired. It allows on/off TIG welding at the current set by the Current Control on the control panel. When using the Arc Start Switch set the Output Control to the "LOCAL" position.

Magnum® PTA-9 and PTA-17 TIG Torches - The following standard Magnum® TIG torches with one-piece cable may be used with the Invertec V160-T.

• K1781-1	PTA-9	12.5 ft	medium back cap
• K1781-3	PTA-9	25 ft	medium back cap
• K1782-1	PTA-17	12.5 ft	long back cap
• K1782-3	PTA-17	25 ft	long back cap

NOTE: Each torch requires a Twist-Mate adapter, (one is included with the machine). Collects, collect bodies, and nozzles are not included and must be ordered separately.

CABLE PLUGS

K852-50 - Cable Plug Kit for 1/0-2/0 cable. Attaches to welding cable to provide quick disconnect from machine.

Twist-Mate Torch Adapter K1622-1 - One is shipped with the welder to connect the Magnum PTA-9 torch. If you do not care to interchange this part between torches (one is required to connect Magnum PTA-9 or PTA-17 TIG torches with one-piece cable to the V160-T) you may order an additional adapters. The quick connect plug provides connection for both gas and welding current.

TIG Torch Parts Kits - Parts kits are available for the PTA-9 and PTA-17 TIG torches. These kits include back cap, collets, collect bodies, nozzles and tungsten.

Order KP507 for PTA-9 torches

Order KP508 for PTA-17 torches

See publication E12.150 for parts kits breakdown.

Cut Length Consumables - TIG welding filler metals are available for welding stainless steel, mild steel, aluminum and copper alloys. See publication C9.10.

Vla	nintenance	.DD-1
	Safety Precautions	.DD-2
	Input Filter Capacitor Discharge Procedure	.DD-2
	Routine Maintenance	.DD-2
	Major Component Location for V160S/T	.DD-3

DD-1

Return to Master TOC

Return to Master TOC

SAFETY PRECAUTIONS

M WARNING



ELECTRIC SHOCK can kill.

- Have an electrician install and service this equipment.
- Turn the input power off at the fuse box, disconnect supply lines and allow machine to sit for five minutes minimum to allow the power capacitors to discharge before working inside this equipment.
- · Do not touch electrically live parts.

A CAUTION

- Disconnect the power supply before every operation.
- Always use gloves in compliance with the safety standards.

INPUT FILTER CAPACITOR DISCHARGE PROCEDURE

Λ

WARNING

The machine has internal capacitors which are charged to a high voltage during power-on conditions. This voltage is dangerous and must be discharged before the machine can be serviced. Discharging is done automatically by the machine each time the power is switched off. However, you must allow the machine to sit for at least 5 minutes to allow time for the process to take place.

ROUTINE MAINTENANCE

Prevent metal powder from accumulating near the Heat Sink fins.

A

WARNING

Disconnect the power supply before every opera-


Carry out the following periodic controls on the power source:

- Clean the power source inside by means of lowpressure compressed air.
- Check the electric connections and all the connection cables.

Return to Master TOC

- Front Assembly
 Rear Assembly
- 3) Base/Main Assembly


Figure DD.1 - Major Component Locations



EE-1 TABLE OF CONTENTS-THEORY OF OPERATION SECTION EE-1

Theory of Operation		
	General Description	EE-2
	Welding Capability	EE-2
	Limitations	EE-2
	Input Board	EE-3
	Inverter Board	EE-4
	Display Board	EE-5
	Insulated Gate Bipolar Transistor (IGBT) Operation	EE-6

FIGURE E.1 - BLOCK LOGIC DIAGRAM.



T00

Return to Master


T0C

Return to Master

TOC

Return to Master

THEORY OF OPERATION FIGURE EE.2 - GENERAL DESCRIPTION, WELDING CAPABILITY & LIMITATIONS



GENERAL DESCRIPTION

The V160-T is an industrial 160 amp arc welding power source which utilizes single phase input power, to produce constant current output. The welding response of this Invertec has been optimized for stick (SMAW) and Touch Start TIG (GTAW). The unit is ideal for industrial applications were portability is important.

The Invertec V160-T performs DC TIG with high frequency or Touch Start Tig Starting with excellent results.

WELDING CAPABILITY

The Invertec V-160-T is rated at 160 amps, 26.4 volts, at 35% duty cycle on a ten minute basis. It is capable of higher duty cycles at lower output currents. It is capable of 130 amps, 25.2 volts at a 100% duty cycle. If the duty cycle is exceeded, a thermal protector will shut off the output until the machine cools. See *Technical Specifications* in AA-2 for other related outputs.

The Invertec V160-T is recommended for stick welding with such popular electrodes as Fleetweld 35, Fleetweld 37, Fleetweld 180 and Jet-LH 78 MR. It features adjustable arc control to adjust the arc force and start.

LIMITATIONS

The V160-S is not recommended for pipe thawing.

NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion



T00

Return to Master


T0C

Return to Master

TOC

Return to Master

THEORY OF OPERATION FIGURE EE.3 - INPUT BOARD



INPUT BOARD

The input board includes the following circuits:

High Frequency circuit: It generates the high voltage to start the welding arc

INPUT LINE VOLTAGE, FAN CIR-CUIT, AUXILIARY VOLTAGE AND **PRECHARGE**

The Invertec V160-T can be connected to a 115V or 230V single phase input voltage.

This unit can also connect to engine driven generators but it must follow the below conditions:

- Vac peak voltage: below 250V (for 115Vac input) or 410V (for 230Vac input).
- Vac frequency: in the range of 50 and 60 Hertz.
- RMS voltage of the AC waveform:

V160-T: 115Vac or 230Vac +/- 10%

The initial power is applied to the Invertec V160-T directly on the input board. A line switch located on the back of the machine supplies the logic part that manages machine functions. The voltage is after rectified by the input on the input rectifier on the input board and the resultant DC voltage is applied at inverter Pcb's.

During the precharge time the DC input voltage is applied to the filter capacitors (located on the inverter Pcb) through a precharge resistances (located on input board) that limit the charge current. During precharge time, an automatic system (manages by reconnect board mounted on the input board) sets the input board for 115V or 230V working mode (voltage duplicator when 115Vac is applied). After this time the start relays go closed and they by-pass the precharge resistances (there are two precharge relays, RL1B and RL4B). The input voltage is also applied to an auxiliary voltage circuit, that gives the necessary low voltages (+15V, -5V and +5V) for the control / display board and inverter board.

The fan is activated when the power is first supplied to the machine. It will stay on as long as output is present. The fan shuts down after 5 minutes when the output is shut off.


NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion



Return to Master TOC

Return to Master TOC

THEORY OF OPERATION FIGURE EE.4 - INVERTER BOARD



INVERTER BOARD

The inverter board includes the following circuits:

- Inverter circuit: Transforms the DC current at 80KHz and feeds the main transformer. The current is regulated via Pulse Width Modulation
- Main transformer: It has two functions:
 - 1) gives the correct output voltage for welding
 - 2) Insulates the operator side from the output line
- Output circuit: The output diodes rectify the output the current from the main transformer. The choke filters the output current. The shunt provides output feedback information to the control board.


NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion

T0C

Return to Master

FIGURE EE.5 - DISPLAY BOARD

THEORY OF OPERATION



DISPLAY BOARD

The display board receives status and analog signals from the inverter board and various sensors. It is composed of 2 parts:

- Weld controller: Interprets signals, makes decisions and changes the machine mode and output to satisfy the requirements as dictated by the operator.
- Display board: Supports all the potentiometer, switches and LED
- Meter board: Displays the pre-set and actual output current

NOTE: Unshaded areas of Block Logic Diagram are the subject of discussion

Return to Master TOC

Return to Master TOC

INSULATED GATE BIPOLAR TRAN-SISTOR (IGBT) OPERATION


An IGBT is a type of transistor. IGBT are semiconductors well suited for high frequency switching and high current applications.

Example A in figure EE.6 shows an IGBT in passive mode. There is no gate signal, zero volts relative to the source, and therefore, no current flow. The drain terminal of the IGBT may be connected to a voltage supply; but since there is no conduction, the circuit will not supply current to the components connected to the source. The circuit is turned OFF like a light switch.

Example B shows the IGBT in an active mode. When the gate signal, a positive DC voltage relative to the

source, is applied to the gate terminal of the IGBT, it is capable of conducting current. A voltage supply connected to the drain terminal will allow the IGBT to conduct and supply current to the circuit components coupled to the source. Current will flow through the conducting IGBT to downstream components as long as the positive gate signal is present. This is similar to turning ON a light switch.

FIGURE EE.6 - IGBT



F-1	TABLE OF CONTENTS - TROUBLESHOOTING & REPAIR	F-

leshooting and RepairF-1
ow to Use Troubleshooting GuideF-2
C Board Troubleshooting Procedures and ReplacementF-3
oubleshooting Guide
ase RemovalF-7
est Procedures
Input Board Capacitor Discharge Procedure
Input Board TestF-11
Main IGBT Inverter Board V160-T "Welding Logic and Inverter" Section TestF-19
eplacement Procedures
Input Board Removal and Replacement ProcedureF-27
Main IGBT Inverter Board Removal and Replacement Procedure
Display Board Removal and ReplacementF-35
Retest After Repair

Return to Master TOC

HOW TO USE TROUBLESHOOTING GUIDE

A WARNING

Service and Repair should only be performed by Lincoln Electric Factory Trained Personnel. Unauthorized repairs performed on this equipment may result in danger to the technician and machine operator and will invalidate your factory warranty. For your safety and to avoid Electrical Shock, please observe all safety notes and precautions detailed throughout this manual.

This Troubleshooting Guide is provided to help you locate and repair possible machine malfunctions. Simply follow the three-step procedure listed below.

Step 1. LOCATE PROBLEM (SYMPTOM). Look under the column labeled "PROBLEM

(SYMPTOMS)". This column describes possible symptoms that the machine may exhibit. Find the listing that best describes the symptom that the machine is exhibiting. Symptoms are grouped into the following categories: output problems, function problems, wire feeding problems, and welding problems.

Step 2. PERFORM EXTERNAL TESTS.

The second column labeled "POSSIBLE AREAS OF MISADJUSTMENT(S)" lists the obvious external possibilities that may contribute to the machine symptom. Perform these tests/checks in the order listed. In general, these tests can be conducted without removing the case wrap-around cover.

Step 3. RECOMMENDED COURSE OF ACTION

The last column labeled "Recommended Course of Action" lists the most likely components that may have failed in your machine. It also specifies the appropriate test procedure to verify that the subject component is either good or bad. If there are a number of possible components, check the components in the order listed to eliminate one possibility at a time until you locate the cause of your problem.

All of the referenced test procedures referred to in the Troubleshooting Guide are described in detail at the end of this chapter. Refer to the Troubleshooting and Repair Table of Contents to locate each specific Test Procedure. All of the specified test points, components, terminal strips, etc. can be found on the referenced electrical wiring diagrams and schematic. Refer to the Electrical Diagrams Section Table of Contents to locate the appropriate diagram.

A CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact the Lincoln Electric Service Department for technical troubleshooting assistance before you proceed. Call 1-888-935-3877.

Return to Master TOC

Return to Master TOC

TROUBLESHOOTING & REPAIR

PC BOARD TROUBLESHOOTING PROCEDURES

WARNING



ELECTRIC SHOCK can kill.

an electrician install and Have service this equipment. Turn the input power OFF at the fuse box before working on equipment. Do not touch electrically hot parts.

CAUTION

Sometimes machine failures appear to be due to PC board failures. These problems can sometimes be traced to poor electrical connections. To avoid problems when troubleshooting and replacing PC boards, please use the following procedure:

- 1. Determine to the best of your technical ability that the PC board is the most likely component causing the failure symptom.
- 2. Check for loose connections at the PC board to assure that the PC board is properly connected.
- 3. If the problem persists, replace the suspect PC board using standard practices to avoid static electrical damage and electrical shock. Read the warning inside the static resistant bag and perform the following procedures:

PC board can be damaged by static electricity.



ATTENTION Static-Sensitive **Devices** Handle only at Static-Safe Workstations

- Remove your body's static charge before opening the staticshielding bag. Wear an anti-static wrist strap. For safety, use a 1 Meg ohm resistive cord connected to a grounded part of the equipment frame.
- If you don't have a wrist strap, touch an un-painted, grounded, part of the equipment frame. Keep touching the frame to prevent static build-up. Be sure not to touch any electrically live parts at the same time.
- Tools which come in contact with the PC board must be either conductive, anti-static or static-dissipative.

- Remove the PC board from the static-shielding bag and place it directly into the equipment. Don't set the PC board on or near paper, plastic or cloth which could have a static charge. If the PC board can't be installed immediately, put it back in the static-shielding bag.
- If the PC board uses protective shorting jumpers, don't remove them until installation is complete.
- If you return a PC board to The Lincoln Electric Company for credit, it must be in the static-shielding bag. This will prevent further damage and allow proper failure analysis.
 - 4. Test the machine to determine if the failure symptom has been corrected by the replacement PC board.

NOTE: It is desirable to have a spare (known good) PC board available for PC board troubleshooting.

NOTE: Allow the machine to heat up so that all electrical components can reach their operating temperature.

- 5. Remove the replacement PC board and substitute it with the original PC board to recreate the original problem.
 - a. If the original problem does not reappear by substituting the original board, then the PC board was not the problem. Continue to look for bad connections in the control wiring harness, junction blocks, and terminal strips.
 - b. If the original problem is recreated by the substitution of the original board, then the PC board was the problem. Reinstall the replacement PC board and test the machine.
- 6. Always indicate that this procedure was followed when warranty reports are to be submitted.

NOTE: Following this procedure and writing on the warranty report, "INSTALLED AND SWITCHED PC BOARDS TO VERIFY PROBLEM," will help avoid denial of legitimate PC board warranty claims.

Return to Section TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Observe Safety Guidelines detailed in the beginning of this manual.

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENT(S)	RECOMMENDED COURSE OF ACTION
	GENERAL PROBLEMS	
The machine is dead No LED No Fan	 Make sure that the input voltage is present Check the input switch Check the fuse F1, F2, Auto (depending upon input board installed 	 Connect correct input voltage Replace if necessary Replace necessary fuse(s) if they fail again perform the <i>Input Board Test</i>
The machine has only the fan run- ning, no display	Check the auxiliary voltages on the JP1 to the input board	 Perform the <i>Input Board Test</i> Replace the display board, if the auxiliary voltages are present
The machine powers up correctly but there is no output	1. Check the output LED 2. Check the torch trigger 3. Check the welding cable	1. If the output LED is on perform the <i>IGBT Inverter Board Test</i> 2. The control board may be faulty

A CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact the Lincoln Electric Service Department for technical troubleshooting assistance before you proceed. Call 1-888-935-3877.

Return to Master TOC

Return to Master TOC

Observe Safety Guidelines detailed in the beginning of this manual.

PROBLEMS (SYMPTOMS)	POSSIBLE AREAS OF MISADJUSTMENT(S)	RECOMMENDED COURSE OF ACTION
	GENERAL PROBLEMS	
The machine powers up correctly but working only in stick mode (V160T pulse)	Make sure that the tig torch is good	1. The control board may be faulty
The machine has only touch start and no HF (V160T pulse only)	Check the HF transformer for loose or faulty connection in HF area	1. Perform the <i>Input Board Test</i>
The fan does not operate	1. Check if the machine is in	Replace the fan
	stand-by condition (after 5 min- utes of inactivity in tig mode the	2. Perform the <i>Input Board Test</i>
	fan stops)	3. The control board may be faulty
	Check the fan supply voltage, must be 12vdc	
The gas solenoid does not work	1. Check the gas solenoid supply	1. Perform the <i>Input Board Test</i>
(V160T only)	voltage, it must be 12vdc, when the trigger is pressed	2. The control board may be faulty
	Replace the gas solenoid	
The power LED on the front panel is "blinking"	Check the input voltage	 Connect the machine to the cor- rect voltage
Billikilig	Check for high input current due to exceeding duty cycle rating	Perform the <i>Input Board Test</i>
Bad welding in stick mode	Check the input voltage, must match the rating plate	Maybe the arc force does not work, Replace the weld con-
	2. Check the mode switch	troller board or the display board
The thermal light remains lit	Check the thermal protector on the output diodes heatsink	1. Perform the <i>Inverter Board Test</i>
The machine has output current but	1. Check the current potentiometer	Replace the control board
it is not adjustable		2. Perform the <i>Inverter Board Test</i>

A CAUTION

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact the Lincoln Electric Service Department for technical troubleshooting assistance before you proceed. Call 1-888-935-3877.

Return to Section TOC Return to Master TOC

Return to Section TOC Return to Master TOC

Return to Section TOC Return to Master TOC

Return to Master TOC

TROUBLESHOOTING & REPAIR CASE COVER REMOVAL AND REPLACEMENT PROCEDURE

WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

TEST DESCRIPTION

This procedure will aid the technician in the removal and replacement of the case cover.


MATERIALS NEEDED

Phillips Head Screwdriver

Return to Master TOC

CASE COVER REMOVAL AND REPLACEMENT PROCEDURE (CONTINUED)

FIGURE F.1 - CASE REAR SCREWS - REMOVAL



PROCEDURE

- 1. Remove input power to the V160S/T
- 2. Using a phillips head screwdriver, remove the four screws on the back. See Figure F.1
- 3. Pull out the rear panel, take off the handle, then remove the cover.
- Perform the Input Filter Capacitor
 Discharge Procedure detailed in this section.

Return to Master TOC

INPUT FILTER CAPACITOR DISCHARGE PROCEDURE

WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test / repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

DESCRIPTION

This procedure will drain off any charge stored in the capacitor that is part of the input board assembly. The procedure MUST be performed, as a safety precaution, before conducting any test or repair procedure that requires you to touch internal components of the machine.

MATERIALS NEEDED

Phillips Screwdriver

Insulated Pliers

Insulated Gloves

High Wattage Resistor (25-1000 ohms and 25 watts minimum)

Volt Meter

Return to Master TOC

INPUT CAPACITOR DISCHARGE PROCEDURE (continued)



ELECTRIC SHOCK can kill.


- Have an electrician install and service this equipment.
- Turn the input power off at the fuse box before working on equipment.
- Do not touch electrically hot parts.
- Prior to performing preventative maintenance, perform the following capacitor discharge procedure to avoid electric shock.

DISCHARGE PROCEDURE

- 1. Remove the input power to the machine.
- Using the phillips head screwdriver remove the screws securing the case wraparound cover.
- Be careful not to make contact with the capacitor solder pads located on the input board. See Figure F.2.

- Obtain a high resistance and high wattage resistor (25-1000 ohms and 25 watts minimum).
 This resistor is not with the machine. NEVER USE A SHORTING STRAP FOR THIS PROCEDURE.
- 5. Locate the eight capacitor solder pads shown in Figure F.2.
- Using electrically insulated gloves and pliers, hold the body of the resistor with the pliers and connect the resistor leads across the two capacitor solder pads. Hold the resistor in place for 15 seconds. DO NOT TOUCH CAPACITOR SOLDER PADS WITH YOUR BARE HANDS.
- Repeat the discharge procedure for the other capacitor.
- Check the voltage across the terminals of all capacitors with a DC voltmeter. Voltage should be zero.
 If any voltage remains, repeat the capacitor discharge procedure.

FIGURE F.2 - LOCATION OF INPUT FILTER CAPACITOR TERMINALS ON THE INPUT BOARD



V160-S & -T

Return to Master TOC

INPUT BOARD TEST V160-S/T

WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test / repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

TEST DESCRIPTION

This test will help determine if the Input Board is functioning properly.

Note: There have been some revisions to the input boards. The older boards are identified with line art drawings. The later boards are presented as digital photographs. Perform correct test procedures for suspect boards.


MATERIALS NEEDED

Analog Volt/Ohmmeter
Phillips Head Screwdriver
Wiring Diagram

Return to Master TOC

INPUT BOARD TEST V160-S/T (continued)

FIGURE F.3 - INPUT BOARD




TEST PROCEDURE

- 1. Remove input power to the V160S/T
- 2. Perform Case Removal Procedure.
- 3. Perform the *Input Filter Capacitor Discharge Procedure* detailed earlier in this section.
- 4. Locate the Input board. See Figure F.3.

Return to Master TOC

INPUT BOARD TEST V160-S/T (continued)

FIGURE F.4 - INPUT BOARD



- 1. Locate test points. See figure F.4.
- Check capacitors + input bridge for open or shorts.See input board schematic.
- 3. Check Fuse F1.
- 4. Check start resistor for 20 ohms.

INPUT BOARD TEST V160-S/T *(continued)*

TROUBLESHOOTING & REPAIR

FIGURE F.5 - INPUT BOARD


Voltage check on JP1 input board

Refer PIN 11 as ground

Pin 5 = -5Vdc

Pin 7 = +15Vdc

Pin 9 = +5 Vdc




- 1. Locate connector JP1. See figure F.5.
- 2. Check pin 5 to pin 11 for -5vdc.
- 3. Check pin 7 to pin 11 for +15vdc.
- 4. Check pin 9 to pin 11 for +5vdc.

Return to Master TOC

INPUT BOARD TEST V160-S/T (continued)

TROUBLESHOOTING & REPAIR

FIGURE F.6 - INPUT BOARD




- 1. Locate test points. See Figure F.6.
- 2. Check AC1 + AC2 for 115 VAC or 230 VAC depending on input voltage.
- 3. Check DC+ to DC- for 320Vdc.

Return to Master TOC

INPUT BOARD TEST V160-S/T (continued)

FIGURE F.6A - INPUT BOARD



INPUT PCB BACKSIDE

TEST PROCEDURE (NEW MODELS)


- 1. Locate connector JP1. See Figure F.6A. See Figure F.7. See Figure F.8.
- 2. Check pin 5 to pin 11 for -5vdc.
- 3. Check pin 7 to pin 11 for 15vdc.
- 4. Check pin 9 to pin 11 for +5vdc.

Return to Master TOC

INPUT BOARD TEST V160-S/T (continued)

FIGURE F.7 - INPUT BOARD


V160 INPUT PCB INSIDE



INPUT BOARD TEST V160-S/T (continued)

FIGURE F.8 - INPUT BOARD

V160 TOP VIEW



Return to Master TOC

Return to Master TOC

Return to Master TOC

MAIN IGBT INVERTER BOARD V160-S/T "WELDING LOGIC AND INVERTER" SECTION TEST

WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test / repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

TEST DESCRIPTION

This test will help determine if all of the Welding Logic Circuit and Inverter are functioning properly.

Note: There have been some revisions to the inverter boards. The older boards are identified with line art drawings. The later boards are presented as digital photographs. Perform correct test procedures for suspect boards.

MATERIALS NEEDED

Volt/Ohmmeter

Phillips Head Screwdriver

Wiring Diagram

Return to Master TOC

Return to Master TOC


Return to Master TOC

MAIN IGBT INVERTER BOARD V160-S/T "WELDING LOGIC AND INVERTER" SECTION TEST (continued)

TEST PROCEDURE

- Remove input power to the V160S/T machine.
- 2. Perform Case Cover Removal Procedure.
- 3. Perform the *Capacitor Discharge Procedure* detailed earlier in this section.
- Locate the inverter section of the Main inverter board.

FIGURE F.9 MAIN IGBT INVERTER BOARD LOCATION




Return to Master TOC

Return to Master TOC

MAIN IGBT INVERTER BOARD V160-S/T "WELDING LOGIC AND INVERTER" SECTION TEST (continued)

FIGURE F.10 MAIN IGBT INVERTER BOARD LOCATION



Return to Master TOC

Return to Section TOC Return to Master TOC

Return to Section TOC

Return to Master TOC


MAIN IGBT INVERTER BOARD V160-S/T "WELDING LOGIC AND INVERTER" SECTION TEST (continued)

FIGURE F.11 MAIN IGBT INVERTER BOARD LOCATION

WAVEFORM ON EACH GATE 5us/div 10V/div 0

Take note that you need an oscilloscope insulated from the supply line to do this measure

- 1. Locate 6 gate points indicated on Figure F.11.
- 2. Connect scope probe, set at 5us/div + 10V/div, and check waveform on each gate with ground probe to pin 2 in molex J1.



MAIN IGBT INVERTER BOARD V160-S/T "WELDING LOGIC AND INVERTER" SECTION TEST (continued)

TROUBLESHOOTING & REPAIR

FIGURE F.12 MAIN IGBT INVERTER BOARD LOCATION

CHECK THE IGBT S FOR SHORTS (AN OPEN STATUS NORMALLY IS EVIDENT) CHECK FOR THERMAL PROTECTION (~ 36 OHMS) CHECK THE OUTPUT **DIODES FOR SHORTS** CHECK FOR (~ 1K OHMS)

CHECK THE DIODES FOR SHORTS


- 1. Locate test points on inverter board. See Figure F.12.
- 2. Check IGBT and diodes for shorts.
- 3. Check thermal protector for ~ 36 ohms.
- 4. Check lower left section as marked for ~ 1K Ohms.



Return to Master TOC

MAIN IGBT INVERTER BOARD V160-S/T "WELDING LOGIC AND INVERTER" SECTION TEST (continued)

FIGURE F.13 MAIN IGBT INVERTER BOARD LOCATION




INVERTER PCB

Return to Master TOC

MAIN IGBT INVERTER BOARD V160-S/T "WELDING LOGIC AND INVERTER" SECTION TEST (continued)

FIGURE F.14 MAIN IGBT INVERTER BOARD LOCATION



INSIDE INVERTER PCB

Return to Section TOC Return to Master TOC

Return to Section TOC
Return to Master TOC

Return to Section TOC Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

INPUT BOARD REMOVAL AND REPLACEMENT PROCEDURE

WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the tests/repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

DESCRIPTION

This procedure will aid the technician in the removal and replacement of the Input Board.


MATERIALS NEEDED

Analog Volt/Ohmmeter Phillips Head Screwdriver 7mm Nutdriver Wiring Diagram

INPUT BOARD REMOVAL AND REPLACEMENT PROCEDURE

(continued)

FIGURE F.15 - INPUT BOARD



REMOVAL PROCEDURE

- 1. Remove input power to the V160-S/T.
- 2. Perform the **Case Cover Removal Procedure.**
- 3. Perform the *Capacitor Discharge Procedure.*
- 4. Locate the Input Board. See Figure F.15.
- 5. Label and remove plugs JP1, JP2, and JP3. **See Figure F.16.**

- 6. Label and remove leads DC-, DC+, AC1, AC2, and ground. *See Figure F.16.*
- 7. Using a 7mm nutdriver remove the four P.C. Board mounting screws. **See Figure F.16.**
- 8. The Board may now be tilted forward to gain access to leads HF1 and HF2. Label and disconnect these leads. **See** *Figure F.16.*
- 9. Disconnect ground lead. **See Figure** *F.16.*
- Carefully remove and replace Input Board.




Return to Master TOC

INPUT BOARD REMOVAL AND REPLACEMENT PROCEDURE

(continued)

FIGURE F.16 - INPUT BOARD



REPLACEMENT PROCEDURE

- 1. Connect leads HF1 and HF2 to the new P.C. Board.
- 2. Replace 7mm P.C. Board mounting screws.
- 3. Connect leads DC-. DC+, AC1, AC2, and ground to P.C. Board.
- 4. Connect plugs JP1, JP2, JP3 & Ground lead.
- 5. Install case cover.

Return to Section TOC Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

Return to Master TOC

TROUBLESHOOTING & REPAIR

MAIN IGBT INVERTER BOARD REMOVAL AND REPLACEMENT **PROCEDURE**

WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test / repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

DESCRIPTION

This procedure will aid the technician in the removal and replacement of the Main IGBT Inverter Board.

MATERIALS NEEDED

Volt/Ohmmeter

Phillips Head Screwdriver

7mm Nutdriver

10mm Nutdriver

Wiring Diagram

Oscilloscope

Return to Master TOC

Return to Master TOC


MAIN IGBT INVERTER BOARD REMOVAL AND REPLACEMENT PROCEDURE (continued)

REMOVAL PROCEDURE

- 1. Remove input power to the V160-S/T.
- Perform the Case Cover Removal Procedure.
- 3. Perform the *Capacitor Discharge Procedure.*
- 4. Locate the Inverter Board. See Figure F.17.
- 5. Using a 7mm nutdriver remove the four P.C. Board mounting screws. **See Figure F.19.**
- Label and disconnect leads DC-, DC+ and plug JP1 from the top of the Inverter Board. See Figure F.18.

- 7. Using a 10mm nutdriver remove the two bolts connecting the P.C. Board to heavy leads. **See** *Figure F.19*.
- 8. The Board may now be tilted forward to gain access to the ground lead.
- 9. Label ground lead position and disconnect.
- Remove and replace Main Input P.C. Board.

FIGURE F.17 MAIN IGBT INVERTER BOARD LOCATION



Return to Master TOC


Return to Master TOC

MAIN IGBT INVERTER BOARD REMOVAL AND REPLACEMENT PROCEDURE (continued)

REPLACEMENT PROCEDURE

- 1. Connect ground lead to new P.C. Board
- 2. Position new P.C. Board in its proper location.
- 3. Replace 2 10 mm bolts previously removed.
- 4. Connect leads DC-, DC+ and plugs to there proper position.
- 5. Replace the previously removed 7mm P.C. Board mounting screws.
- 6. Replace the case cover.

FIGURE F.18 MAIN IGBT INVERTER BOARD PLUG LOCATIONS






Return to Master TOC

MAIN IGBT INVERTER BOARD REMOVAL AND REPLACEMENT PROCEDURE (continued)

FIGURE F.19 MAIN IGBT INVERTER BOARD MOUNTING BOLTS



Return to Master TOC

Return to Master TOC

DISPLAY BOARD REMOVAL AND REPLACEMENT PROCEDURE

WARNING

Service and repair should be performed by only Lincoln Electric factory trained personnel. Unauthorized repairs performed on this equipment may result in danger to the technician or machine operator and will invalidate your factory warranty. For your safety and to avoid electrical shock, please observe all safety notes and precautions detailed throughout this manual.

If for any reason you do not understand the test procedures or are unable to perform the test / repairs safely, contact the Lincoln Electric Service Department for electrical troubleshooting assistance before you proceed. Call 1-888-935-3877.

DESCRIPTION

This procedure will aid the technician in the removal and replacement of the display board.

MATERIALS NEEDED

Analog Volt/Ohmmeter
Phillips Head Screwdriver
7mm Nutdriver
2.5mm Allen Wrench
Wiring Diagram

Return to Master TOC


Return to Master TOC

Return to Master TOC

DISPLAY BOARD REMOVAL AND REPLACEMENT PROCEDURE

(continued)

FIGURE F.20 - DISPLAY BOARD LOCATION



REMOVAL PROCEDURE

- 1. Remove input power to the V160-S/T.
- 2. Perform the **Case Cover Removal Procedure.**
- 3. Perform the *Capacitor Discharge Procedure.*
- Locate the Display Board. See Figure F.20.
- 5. Gently place machine on its side.
- 6. Using a 7mm nutdriver remove the three casefront mounting screws located on the bottom of the machine. **See Figure** *F.21.*
- Using a 7mm nutdriver remove the two casefront mounting screws (four total) on either side of the machine. See Figure F.20.
- The casefront may now be gently pulled forward to gain access to display board mounting bolts.

- Using a thin knife blade or small flathead screwdriver carefully remove the red caps on the 5 control knobs located on the front of the machine. See Figure F.20.
- Using a 6mm nutdriver remove the nut and associated washers located beneath the previously removed red caps on the control knobs. See Figure F.20.
- 11. Remove control knobs.
- Using a 2.5mm allen wrench remove the four display board mounting bolts located at corners of board. Note washer position for replacement. See Figure F.20.
- Disconnect plugs J1 and JP1 from the display board.
- 14. Remove and replace display board.




Return to Master TOC

DISPLAY BOARD REMOVAL AND REPLACEMENT PROCEDURE

(continued)

FIGURE F.21 - BOTTOM OF MACHINE

7 MM CASEFRONT MOUNTING SCREWS



REPLACEMENT PROCEDURE

- 1. Connect plugs J1 and JP1 to new display board.
- 2. Replace the four display board mounting bolts.
- 3. Replace control knobs.
- 4. Replace nuts and associated washers securing control knobs.
- 5. Replace previously removed red caps.

- 6. Replace the 4 mounting screws on either side of the machine.
- 7. Replace the three mounting screws on the bottom of the machine.
- 8. Replace the case cover.

Return to Master TOC

RETEST AFTER REPAIR

If a failed test indicates that any mechanical part that could affect the machine's electrical characteristics must be replaced or if any electrical components are repaired or replaced, the machine must be retested and meet the following standards.

INPUT - SINGLE PHASE ONLY			
Input Voltages / 50 /60 Hz.	Max. Input Current at rated Output		
115 V (20 A Plug and branch)	20 A		
115 V (30 A branch)	25 A		
230 V	34 A		

RATED OUTPUT						
Duty Cycle	Output Amps	Output Volts	Input Circuit			
100%	60 (Stick) 90 (TIG)	22.4 13.6	115V (20A Plug and Branch)			
	80 (Stick) 110 (TIG)	23.2 14.4	115V (30A Branch)			
35%	160 (Stick) 160 (TIG)	26.4 16.4	230V (30A Branch)			
100%	130 (Stick) 130 (TIG)	25.2 15.2	230V (30A Branch)			
,		OUTPUT				
Output Current Range	Maximum Op	en Circuit Voltage	Type of Output			
5-160 Amps	48 Vol	Its Max.	DC			

To test V160T on TIG mode set mode switch to LIFT TIG! "do not use HF TIG or damage to measuring equipment will occur!!


To test HF on V160T attach tig torch, remote amptrol, and argon shielding gas.

G-1

Ele	ectrical Diagrams	.G-1
	Wiring Diagram - V160-S (Code 10877)	.G-2
	Wiring Diagram - V160-S (Code 11031)	.G-3
	Wiring Diagram - V160-T (Code 10878)	.G-4
	Wiring Diagram - V160-T (Code 11032)	.G-5
	Schematic - V160-S / -T Page 1	.G-6
	Schematic - V160-S / -T Page 2	.G-7
	Schematic - V160-S / -T Input PC Board	.G-8
	Schematic - V160-S / -T Input PC Board Voltage Supplies	.G-9


* NOTE: Many PC Board Assemblies are now totally encapsulated, surface mounted and or multi-layered and are therefore considered to be unserviceable. Assembly drawings of these boards are no longer provided.

WIRING DIAGRAM - V160-S (CODE 10877)




NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The wiring diagram specific to your code is pasted inside one of the enclosure panels of your machine.








WIRING DIAGRAM - V160-T (CODE 10878)



NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The wiring diagram specific to your code is pasted inside one of the enclosure panels of your machine.




WIRING DIAGRAM - V160-T (CODE 11032)




NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The wiring diagram specific to your code is pasted inside one of the enclosure panels of your machine.





SCHEMATIC - V160-S & -T (PAGE 1)













G-8 **SCHEMATIC - INPUT PC BOARD** 400V D8 BW260 320VDC Input D5 1.5KE200V C14 100nF 630V U5 TOP223Y

R12 220R 220pF 630V D4 R13 220R W4028200 - C7 - 1000µF-+ 05 1000µF 25V 470nF 63V 97 4K99 -15Vdc 15VDC 2.5A C13 100pF 630V W59X0173 OND U4A CNY17-3 18V D3 1N4148 U1 L7805 +5VD0 con HS **PMW Controlled** + C9 220µF 25V HS4 W9108162 **100KZ to Maintain** HS5 W9108162 220nF 50V U4B CNY17-3 **Proper supply** H31 3H9 -5VD Grand REF LMC7660 ... VIN TL431 100nF + C4 100nF + 10µF 50V 63V D7 1N414B D25 BYV26E R15 L4 L3 W9108127 W58X0191 D19 BYV26E 100R W58X0200 1200Vdc 930K 330K 150nF **RL3B** D10 BYV26E D15 BYV26E 20mA D24 UF5404 R28 HS7 W9108162 100R R24 10K R25 1µF 63V TOP223Y C26 6n8F G25 33nF 100V

HIGH FREQ CIRCUIT ONLY ON TIG VERSION NOT ON STICK VERSION

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual.



SCHEMATIC - INPUT PC BOARD VOLTAGE SUPPLIES

