




Instruction Manual

FCX-A II SERIES TRANSMITTERS (FOUNDATION FIELDBUS Type)

TYPE: FDA FDW
FDB FDX
FDC FDY
FDD
FDE
FDG



INTRODUCTION

Thank you very much for your purchase of the Fuji FCX-AII Series Transmitters (FOUNDATION FIELDBUS Type).

- First read this instruction manual carefully until an adequate understanding is required, and then proceed to installation, operation and maintenance of the FCX-AII Series transmitter.
- The specifications of the transmitter will be changed without prior notice for further product improvement.
- Modification of the transmitter without permission is strictly prohibited. Fuji will not bear any responsibility for a trouble caused by such a modification.
- This instruction manual should be kept by a person who is actually using the transmitter.
- After reading this manual, keep it at a place easier to access.
- This manual should be delivered to the end user without fail.
- For detail specifications and outline diagrams, refer to the specifications furnished separately.

The product conforms to the requirements of “the Electromagnetic compatibility Directive 89/336/EEC” and “Equipment and protective systems intended for use in potentially explosive atmospheres Directive 94/9/EC” as detailed within the technical construction file number TN513035. The applicable standards used to demonstrate compliance are :

EN 61326: 1997 Class A

EN 61326: 1997 Annex A

Manufacturer:	Fuji Electric Instrumentation Co., Ltd.
Type:	Described in nameplate on main frame (see Page iv)
Date of manufacture:	Described in nameplate on main frame
Product nationality:	Japan

Request

- Transcription of a part or the whole of this manual without permission is prohibited.
- The contents of this manual are subject to change without prior notice.



© Fuji Electric Systems Co., Ltd. 2004


Issued in June, 2004

CAUTION ON SAFETY



First of all, read this “Caution on Safety” to ensure correct operation of the transmitter.

- The cautionary descriptions listed here contain important information about safety, so they should be observed without fail. Those safety precautions are classified into ranks "DANGER" and "CAUTION".

 DANGER	Wrong handling may cause a dangerous situation, in which there is a risk of death or heavy injury.
 CAUTION	Wrong handling may invite a dangerous situation, in which there is a possibility of medium-level trouble or slight injury or only physical damage is predictable.

On items listed under “ **CAUTION**”, they may also lead to serious accidents depending on circumstances, and must be fully observed.

- The signs of prohibition and indication are explained in the following.

 PROHIBITION	General items which pertain to prohibition (DO NOT)
 INDICATION	General items which pertain to user's action



Installation and Piping


DANGER


- Non-explosion-proof transmitter must not be used in a place with explosive gases to prevent serious accidents such as explosion, fire, etc.

CAUTION

- The transmitter is heavy. Be careful when handling it.
- The transmitter should be installed in a place that meets the operating conditions shown in DS sheet or this instruction manual.
- Install the transmitter according to the instruction manual. Improper installation may lead to the cause of fall, trouble or incorrect operation.
- When installing, make sure that the transmitter interior is free from cable chips and other foreign objects to prevent fire, trouble, or incorrect operation.
- When power is ON, do not change the position of the field indicator in an explosion-proof area.
- When power is ON, do not change the position of the amplifier unit in an explosion-proof area.
- When power is ON, do not change the angle of the indicator.
- Main valve used for piping should be selected with the maximum pressure of the process taken into account (piping parts such as main valve, etc. should be furnished by user). If the main valve and other parts do not meet the rating, it may result in leakage of gas or liquid which could lead to hazard.
- Pressure pipes to be used must meet the temperature/pressure rating.

Wiring
 DANGER
<ul style="list-style-type: none"> • On explosion-proof type transmitter, its wiring work must be performed according to the required laws and regulations. Incorrect wiring may cause explosion, fire or other serious accidents.
 CAUTION
<ul style="list-style-type: none"> • Before making wiring work, be sure to turn OFF the main power to prevent electric shocks. • Use wiring materials of correct rating to prevent fire accidents. • Connect a power source of correct rating to prevent fire accidents. • The transmitter should be grounded as specified to prevent electric shocks or incorrect operation. • After installing the transmitter, firmly close the covers of the amplifier unit and terminal box. If not, rain water enter the transmitter which may result in trouble or incorrect operation.

Adjustment
 DANGER
<ul style="list-style-type: none"> • When using a flame-proof transmitter, do not connect HHC to the transmitter terminals and junction terminals.

Replacement of Maintenance Parts
 DANGER
<ul style="list-style-type: none"> • When removing an explosion-proof transmitter, turn OFF the main power, then disconnect the piping and wiring. Do not remove it when the power is ON to prevent serious accident such as explosion, fire, etc.

CAUTIONS ON USE

Be sure to observe the following instructions

Storage for a long period

Store the transmitter in a dry room at normal temperature and humidity.
Keep protection caps in place at the conduit connection and process connection.

For installation, select an appropriate place

Site at location with minimal vibration, dust and corrosive gas

At a place allowing an adequate space for checkup

Site at location large enough to allow maintenance and checking.

Mounting angle

Mount to a pipe horizontally or vertically.

Attention to overload




Do not apply a pressure outside the specified range.

Other

Besides the above, be sure to observe the cautions given in this manual.

CONFIRMATION OF YOUR SPECIFICATION

The instrument nameplate as shown below is attached at the amplifier unit of this transmitter. Before use, make sure the contents of the nameplate agree exactly with your specifications.

FOX-AII		Tag No.	
_____ Transmitter			
Type	_____		
<input type="radio"/> Output scale	_____		
P.Supply	_____ Out. _____		
Range Limit	_____		
M.W.P.	_____		
Ser. No.	_____ Mfd.		
Fuji Electric Systems Co., Ltd.		Made in Japan	TK4H3107

CONTENTS

INTRODUCTION	i
CAUTION ON SAFETY	ii
CAUTIONS ON USE	iv
CONFIRMATION OF YOUR SPECIFICATION	iv
CONTENTS	v
1. OUTLINE	1
2. OPERATING PARTS AND THEIR FUNCTIONS	2
3. OPERATION AND SHUTDOWN	4
3.1 Preparation for operation	4
3.2 Operation	5
3.3 Shutdown	6
4. FIELDBUS	8
4.1 Outline	8
4.2 Logical structure of field device	8
4.2.1 VFD for system management	8
4.2.2 Function block VFD	8
4.3 Necessary equipment	10
4.4 Setting of host system	11
4.5 Setting of DD (Device Description)	12
4.6 Configuration	12
4.6.1 Network parameter setting	13
4.6.2 Function block schedule	13
4.6.3 Tag and address setting	14
4.6.4 Virtual Communication Relationship	14
4.6.5 Setting of Function Block VFD	16
4.6.6 Parameters of AI function block	21
4.6.7 Parameters of transducer block	22
4.6.8 Parameters of resource block	22
4.6.9 Alarms and events	23
5. ADJUSTMENT AND SETTING	25
5.1 Method of adjustment on host system	25
5.1.1 Zero adjustment on host system	25
5.1.2 Span adjustment on host system	25
5.2 Zero adjustment	26
5.3 How to set the output mode	27
5.4 Setting of low flow cut point	27
5.5 Damping adjustment	27
5.6 Setting of burnout direction	27
5.7 Locking of external adjustment function	28
5.8 Setting of display on digital indicator	28
5.8.1 Setting method	28
5.9 Setting of output scale	29
5.10 Simulation function	29

6. <i>MAINTENANCE</i>	30
6.1 Periodic inspection	30
6.2 Troubleshooting	31
6.3 Replacement of parts	32
7. <i>INSTALLATION AND PIPING</i>	39
7.1 Installation	39
7.2 Piping	42
7.2.1 Piping of differential pressure and flow transmitter (type: FDC.)	42
7.2.2 Piping of pressure and absolute pressure transmitter (types: FDG, FDA)	46
7.2.3 Piping of level transmitter (types: FDE, FDY)	48
7.2.4 Piping of remote seal type differential pressure transmitter (types: FDD, FDX)	51
7.2.5 Piping of remote seal type pressure transmitter (types: FDB, FDW)	54
8. <i>WIRING</i>	58
8.1 Wiring procedure	58
8.2 Configuration of fieldbus connection	60
8.3 Grounding	60
<i>Appendix 1 CALIBRATION</i>	61
<i>Appendix 2 PARAMETERS OF BLOCKS</i>	64
<i>Appendix 3 UNIT CODES</i>	66
<i>Appendix 4 HAZARDOUS LOCATION INSTALLATION INFORMATION</i>	67
<i>Appendix 5 DISPLAY UNIT CODES</i>	70
<i>Appendix 6 CABLES FOR H1 FIELDBUS</i>	71

1. OUTLINE


The FCX-AII series transmitter (FOUNDATION FIELDBUS type) detects the differential pressure or pressure of various fluids, converts it into a fieldbus signal and transmits it.

Specifications standardized by the FOUNDATION FIELDBUS are adopted for the FOUNDATION FIELDBUS type of FCX-AII series, whereby an interchangeability with products of our or other companies is ensured.

The AI function block is installed for carrying out differential pressure or pressure calculation.


Principle

The operating principle of the FCX-AII series transmitter is shown in the block diagram below. The input pressure is changed into an electrostatic capacitance in the detecting unit. The change proportional to the pressure undergoes amplification and calculation in the transmitting unit, and is then output to the fieldbus.



2. OPERATING PARTS AND THEIR FUNCTIONS

FCX-AII Series transmitter



Description of FCX-AII Series transmitter

Part name	Description
Detecting unit	Detects pressure, differential pressure or level of fluid.
Amplifier unit	Converts the detected signal into an output signal.
Vent/drain plug	Used for gas discharge or draining. (Attention should be paid under a high pressure.)
Process connection	Connects impulse pipes from the process.
Conduit connection	Connects the output cable.
External adjustment screw	Adjusts zero.
Terminal box	Used for connecting input/output cable and grounding cable.


Amplifier unit

Part name	Description
Field indicator connector	Used for connecting the field indicator.
Field indicator (option)	A digital field indicator can be mounted.
Simulation switch	Used when a simulation function (function block) is resorted to.

Terminals

Symbol	Description
+, -	Connects the cable to the fieldbus.
CK+, CK-	Not used for the FOUNDATION FIELDBUS type.
	Used for grounding within the terminals.

Mode and status indicating functions for field indicator



Mode and status indications

Mode	When indicated	When not indicated
%	% output (unused)	Actual scale
ZERO	External zero adjustment possible	External zero adjustment impossible
DISP √	Field indicator √ display	Field indicator LIN display
←	Transmitter operating (Flicker)	Transmitter not operating
abs	Absolute pressure	Gage pressure
–	Output value < Zero	Output value ≥ Zero
N	(Display at particular unit selection)	

3. OPERATION AND SHUTDOWN


3.1 Preparation for operation

Before operating the transmitter, be sure to perform the following checks and procedures. On zero point check or zero adjustment in hazardous area, do not open terminal cover.

Use the transmitter indicator and the external adjustment screw.

Preparation procedure

- (1) Check for liquid or gas leakage from the process connection, etc. by applying soapy water or the like.
- (2) Check the signal wiring according to the “Terminal block connection diagram” shown in 8.1.
- (3) Vent gas from the transmitter in the case of liquid measurement.



Important

When the plant requires chemical cleaning at the start of operation, be sure to close the valve of the transmitter to prevent entry of cleaning liquid into the pressure receiving unit.

- (4) Perform zero point adjustment.

Zero point adjustment

Turn on the fieldbus.

Watch the host system for checking the output signal of the transmitter.

After ten minutes or longer, adjust the transmitter output to zero in the following manner.


Zero adjustment

- (1) Adjustment by zero adjustment screw

Adjust zero point of the transmitter to a specified zero point output by turning the zero adjustment screw.

- (2) Adjustment by host instrument

Refer to “zero and span adjustment” on the host system in 5.1.



Fine adjustment : turning slowly
Rough adjustment : turning quickly




Important

1. After adjustment of the transmitter, it should be kept energized for about 10 seconds to write the adjustment results into memory.
2. Use a blade-edge screwdriver for adjusting the zero adjustment screw.

3.2 Operation


(1) Operation of pressure transmitter

Open the valve slowly to apply a pressure. When a pressure is applied, the transmitter is set in the operating status.




(2) Operation of differential pressure transmitter


Set the operating status by manipulating the manifold valve.




Make sure the equalizing valve is open.



Open the stop valve on the high pressure side slowly.



Close the equalizing valve.



Finally, open the stop valve on the low pressure side slowly.


Check of operating status

Use a field indicator, or host instrument to check the operating status.

3.3 Shutdown


(1) Shutdown of pressure transmitter

Close the valve slowly to stop applying a pressure. The transmitter is set in the measurement stop status.




(2) Shutdown of differential pressure transmitter


Set the shutdown status by manipulating the manifold valve.



Close the stop valve on the high pressure side (H side) slowly.



Open the equalizing valve.



Close the stop valve on the low pressure side (L side) slowly.



Important

Before a long shutdown, discharge the process fluid and drain completely from the transmitter.

This is to protect the transmitter from freezing, corrosion, etc.

4. FIELDBUS

4.1 Outline

The fieldbus type is a bidirectional digital communication method for field devices adopted instead of the conventional analog communication of 4 to 20 mA.

Specifications standardized by the FOUNDATION FIELDBUS are adopted for the FOUNDATION FIELDBUS type of FCX-AII series, whereby an interchangeability with fieldbus products of our or other companies is ensured.

One AI function block is installed for different pressure or pressure calculation.

4.2 Logical structure of field device

In the fieldbus version, two virtual field devices (VFD) exist, each having the functions given below.

4.2.1 VFD for system management

- Sets node address* and PD tag* (device tag name) necessary for communication.
- Controls the execution of the function block.
- Manages the parameters and communication resource (Virtual Communication Relationship: VCR) necessary for communication.

* Individual address and tag name are necessary for the field device in order that it can be connected to the fieldbus.

4.2.2 Function block VFD

- (1) Resource block
 - Manages the hardware statuses.
- (2) Transducer block
 - Converts the sensor output into a pressure signal, and transmits it to the AI function block.
- (3) AI function block

The function block of the Fieldbus Association version is a function model common to measurement and control.

There, functions used for field device and control system such as PID control, analog input and analog output are provided for common use.

The FCX-AII series is equipped with an analog input (AI) function block. This block receives data measured by the transducer block, and subjects the data to the following processing.

- Scaling
- Square root extraction
- Damping
- Alarm generation

Fig. 4-1 shows the internal configuration of the AI function block.




Fig. 4-1 AI function block.

Logical structure of field device




Fig. 4-2 Logical structure of field device

4.3 Necessary equipment

In order that a device of FOUNDATION FIELDBUS type can be used, the following equipment are required.

- Fieldbus power supply

Use a power supply dedicated to the fieldbus of a current capacity over the maximum current consumption of all connected devices. You cannot use the conventional DC power supply. (Recommended power supply: Relcom make FCS-BPC series fieldbus power conditioner.)

- Terminators

Two terminators dedicated to the fieldbus are required. On H1 fieldbus, a terminator with $100\ \Omega$ and $5\ \mu\text{F}$ connected in series is used on each of its ends. The host system side may incorporate one. Contact the supplier you purchased the host system from.

- Host system

Used for measurement and control of the fieldbus device. For details, refer to the instruction manual of the host system manufacturer.

- Cables

Used for connecting the devices. As an instrumentation cable, we recommend you to use type A cable of the FOUNDATION FIELDBUS. For the cable specifications, refer to Appendix 6 “CABLES FOR H1 FIELDBUS”.

For connection of the equipments, refer to Fig. 4-3.




Fig. 4-3 Connection of equipments



Important

For the FOUNDATION FIELDBUS type, the CHECK terminal cannot be used. The current check meter cannot be connected unlike the conventional analog output type.

4.4 Setting of host system


In order that the fieldbus can be used, the host system should be set as follows.



Do not turn off immediately after setting of the transmitter. It should be kept energized for about 10 seconds to store the data into the memory.
If power is turned off soon after setting change, the parameter settings may not be renewed but remain as last.

Table 4-1 Setting parameters

Parameter name	Description
Slot-Time(ST)	Select 5 or more.
Minimum-Inter-PDU-Delay(MID)	Select 10 or more.
Maximum-Response-Delay -Slot-Time(MRD)	Carry out setting so that $MRD \times ST$ will be equal to or greater than 20.
First-Unpolled-Node(FUN)	Limits the range of addresses the host system accesses. Set the FUN to the start address of the range that the host instrument need not access.
Number-of-consencutive -Unpolled-Node(NUN)	Sets the range of addresses the host system does not use. The host instrument does not access the range from the address to which FUN was set to the address to which NUN was set.



Notes

1. Link master device : Has a function of controlling the fieldbus (link master function).
2. Basic device : Does not have a function of controlling the fieldbus.

Fig. 4-4 Address range

Unless otherwise specified, settings prior to delivery are as follows.

- PD tag: EFB-001.
- Node address: 240 (0xF0).
- Device ID: 0003090032***** (0003090032 is followed by 7 numerics and/or alphabets)

Unless the FCX-AII (FOUNDATION FIELDBUS type) is detected on the fieldbus, check the address used by the host system against the specified range and power polarities.

Unless otherwise specified by you, default PD tag and node address are set prior to delivery. If 2 devices or more are simultaneously connected in default statuses, only one device is detected. In such a case, set the node address and PD tag every time each of devices is connected one by one.

4.5 Setting of DD (Device Description)

If the host system supports DD (Device Description), DD should be set for the FCX-AII on the host system. Check whether or not the directory for setting the DD of the host system is followed by the directory below.

000309¥0032 (000309 corresponds to Fuji's manufacturer number, and 0032 is device number for FCX-AII)

Unless this directory is present, create a directory.

To the above directory, copy the DD file (0101.ffo,0101.sym) supplied separately.

When DD has been set, all parameters of FCX-AII can be displayed.

It is also possible to carry out an off-line configuration using a capability file (CFF).

4.6 Configuration

On the fieldbus, several field devices are connected. Therefore, all of them should be covered by settings in the following procedure.

- (1) Network parameter setting
Set the tag, node address and communication parameters of the device to connect.
- (2) Function block linking
Set the link of function blocks.
- (3) Tag and address settings
Set the PD tag and node address for each of fieldbus devices.
- (4) Communication resource
Set the link between VCR (Virtual communication relationship) and function blocks.
- (5) Block setting
Set the link object, trend object and view object.

4.6.1 Network parameter setting

Before connecting fieldbus devices, set the network parameters. Assign node address and PD tag to all devices. The PD tag is the same as used for devices heretofore. The node address is used for communication, and its settable range is 16 to 247 (0x10 to 0xf7). Set the node address within the range shown in Fig. 4-3.

After determining the node address and PD tag for all devices, set the following network parameters for the link master device.

- First-Unpolled-Node (FUN)
- Number-of-consecutive-Unpolled-Node (NUN)
- Slot-Time (ST)
- Minimum-Inter-PDU-Delay (MID)
- Maximum-Response-Delay-Slot-Time (MRD)

Determine the FUN and NUN according to how many devices to connect.

Set the ST, MID and MRD to the most unfavorable values of devices to connect.

For the FCX-AII, carry out settings so that ST will be 5 or more, MID 10 or more, and MRD 20 or more.

4.6.2 Function block schedule

Connect the input/output of the function blocks. For the FCX-AII, connect the OUT parameter of AI function block.

The connected function block may be executed together with other blocks timed with the communication schedule. In such a case, set the schedule as given in Table 4-2.

Table 4-2 Execution schedule for function blocks

Parameter name	Setting contents (setting prior to delivery)
MACROCYCLE_DURATION	Control or measurement cycle (macrocycle) in increments of 1/32 msec (3200 = 1 sec).
FB_START_ENTRY.1	Startup time for AI function block in terms of lapse of time from macro cycle in increments of 1/32 msec (0 = 0 msec).
FB_START_ENTRY.2 to 10	Unused.

For execution of AI function block, it takes 100 msec maximum. Arrange the communication schedule so that the next function block will be connected only after lapse of this time.

4.6.3 Tag and address setting

Unless otherwise specified, the PD tag and node address are set prior to delivery in default at EFB-001 and 240 (0xF0 hex), respectively. For each of devices, determine and set the node address and PD tag.

4.6.4 Virtual Communication Relationship

For setting the communication function, you should change the data of VFD for system management. Set the VCR (Virtual Communication Relationship) for designating the communication destination and resource. The FCX-AII has 20 items of VCR. Except the first one used for system management, they can be changed. VCR of the FCX-AII includes 3 items below.

- Server (QUB) type VCR
For 1-to-1 communication answering the communication request from the host in an aperiodic manner. Used for access to tuning parameter, down-load/up-load of device data, etc.
- Source (QUU) type VCR
For 1-to-N communication among devices on the fieldbus in an aperiodic manner. If an event/trend notification has occurred on a device, data is sent to a device subjected to a configuration.
- Publisher (BNU) type VCR
Periodically sends the output of AI function block to another block.

Each connection information has parameters given in Table 4-3.

Do not change any single parameter but the parameters of the entire connection information in batch to avoid an inconsistent action.

Table 4-3 Virtual Communication Relationship (VCR_STATIC_ENTRY)

Sub-index	Parameter name	Description
1	FasArTypeAndRole	Kind of VCR to use. 0x32: Server type 0x44: Report distribution type 0x66: Publisher type
2	FasDIILocalAddr	Address for designating a VCR in FCX-AII .
3	FasDiiConfiguredRemote Addr	Node address of communication destination and address for designate its VCR.
4	FasDIISDAP	Communication quality. 0x2B: Server 0x01: Alert 0x03: Trend 0x91: Publisher/Subscriber
5	FasDIIMaxConfirmDelay OnConnect	Maximum time in msec to wait for an answer from the opposite party in order to establish a communication connection.
6	FasDIIMaxConfirmDelayOn Data	Maximum time in msec to wait for an answer from the opposite party to a request of data.
7	FasDIIMaxDisduSize	Maximum size of data part. Designate 256 for server or trend, and 64 for others.
8	FasDIIResidualActivity Supported	Whether to supervise the connection or not. Select 0xff for server type only.
9	FasDIITimelinessClass	Unused.
10	FasDIIPublisherTimeWindow Size	Unused.
11	FasDIIPublisherSynchronizaing Dlcep	Unused.
12	FasDIISubscriberTimeWindow Size	Unused.
13	FasDIISubscriberSynchronizaing Dlcep	Unused.
14	FmsVfdId	VFD of the FCX-AII to use. (0x012C: System management VFD, 0x0001: Function block VFD.)
15	FmsMaxOutstandingServer Calling	Select 0 for server. Not used for other purposes.
16	FmsMaxOutsatndingSever Called	Select 1 for server. Not used for other purposes.
17	FmsFeaturesSupported	Service type of application layer.

4.6.5 Block setting

Object of function block VFD.

(1) Link object

Connects the data sent spontaneously by a function block to the Virtual Communication Relationship (VCR). The FCX-AII has 15 link objects. Table 4-4 gives parameters of a link object. Do not change any single parameter but the parameters of the entire connection information in batch to avoid an inconsistent operation.

Table 4-4 Link object

Sub-index	Parameter name	Description
1	LocalIndex	Parameter index of function block to connect. Select 0 for trend or alarm.
2	VcrNumber	Index of VCR to connect.
3	RemoteIndex	Unused (0).
4	ServiceOperation	Select one of the following. 0: Undefined (unused) 2: Publisher 6: Trend 7: Alert
5	StaleCountLimit	Unused.

(2) Trend object

It is possible to automatically send the trend from a function block. The FCX-AII has one analog type trend object. The trend object has parameters given in Table 4-5. Out of them, the first 4 parameters should be set.

Table 4-5 Trend object

Sub-index	Parameter name	Description
1	Block Index	Function block index (508).
2	Parameter Relative Index	Index of parameter to take a trend from in a value relative to the top of function block. It falls into OUT parameter in case of the FCX-AII . OUT: 8
3	Sample Type	Select a method of taking a trend from the following. 1: Sample at an execution of function block 2: Sample an average
4	Sample Interval	Set the sample interval in increments of 1/32 msec and in integer multiple of execution cycle of function block.
5	Last Update	The last time of sample.
6 to 21	List of Status	Status part of sampled parameter.
21 to 37	List of Sample	Data part of sampled parameter.

(3) View object

Used for accessing data upon grouping the block parameters. 4 view objects each are supported by the FCX-AII for resource block, transducer block and function block as given in Tables 4-6 to 4-8. Values in the tables denote byte counts of each parameter.

Table 4-6 View object of resource block

Relative index	Parameter name	VIEW1	VIEW2	VIEW3	VIEW4
1	ST_REV	2	2	2	2
2	TAG_DESC				
3	STRATEGY				2
4	ALERT_KEY				1
5	MODE_BLK	4		4	
6	BLOCK_ERR	2		2	
7	RS_STATE	1		1	
8	TEST_RW				
9	DD_RESOURCE				
10	MANUFAC_ID				4
11	DEV_TYPE				2
12	DEV_REV				1
13	DD_REV				1
14	GRANT_DENY		2		
15	HARD_TYPES				2
16	RESTART				
17	FEATURES				2
18	FEATURE_SEL		2		
19	CYCLE_TYPE				2
20	CYCLE_SEL		2		
21	MIN_CYCLE_T				4
22	MEMORY_SIZE				2
23	NV_CYCLE_T		4		
24	FREE_SPACE		4		
25	FREE_TIME	4		4	
26	SHED_RCAS		4		
27	SHED_ROUT		4		
28	FAULT_STATE	1		1	
29	SET_FSTATE				
30	CLR_FSTATE				
31	MAX_NOTIFY				1
32	LIM_NOTIFY		1		
33	CONFIRM_TIME		4		
34	WRITE_LOCK		1		
35	UPDATE_EVT				

Relative index	Parameter name	VIEW1	VIEW2	VIEW3	VIEW4
36	BLOCK_ALM				
37	ALARM_SUM	8		8	
38	ACK_OPTION				2
39	WRITE_PRI				1
40	WRITE_ALM				
41	ITK_VER				2
42	ERROR_COUNT				
43	RESET_ERR_COUNT				
44	WD_COUNT				
45	DEV_ID				
46	W_PROTECT				
47	ALARM_SIMULATE				
48	VERSION				
49	DEVICE_SN				
50	DEVICE_PILC				
	Total No. of bytes	22	30	22	31

Table 4-7 View object of transducer block

Relative index	Parameter name	VIEW1	VIEW2	VIEW3	VIEW4
1	ST_REV	2	2	2	2
2	TAG_DESC				
3	STRATEGY				2
4	ALERT_KEY				1
5	MODE_BLK	4		4	
6	BLOCK_ERR	2		2	
7	UPDATE_EVT				
8	BLOCK_ALM				
9	TRANSDUCER_DIRECTORY				
10	TRANSDUCER_TYPE	2	2	2	2
11	XD_ERROR	1		1	
12	COLLECTION_DIRECTORY				
13	PRIMARY_VALUE_TYPE		2		
14	PRIMARY_VALUE	5		5	
15	PRIMARY_VALUE_RANGE				
16	CAL_POINT_HI		4		
17	CAL_POINT_LO		4		
18	CAL_MIN_SPAN				
19	CAL_UNIT				
20	SENSOR_TYPE				
21	SENSOR_RANGE				
22	SENSOR_SN				
23	SENSOR_CAL_METHOD				
24	SENSOR_CAL_LOC				
25	SENSOR_CAL_DATE				
26	SENSOR_CAL_WHO				
27	SENSOR_ISOLATOR_MTL				
28	SENSOR_FILL_FULID				
29	SECONDARY_VALUE	5		5	
30	SECONDARY_VALUE_UNIT		2		
31	BURNOUT_SET				
32	PV_SENSOR_INFO				
33	OUTPUT_INFO				
34	CAL_DATA				
35	CAL_UPPER				
36	CAL_LOWER				
37	DYNAMIC_INFO				
38	LOCAL_KEY				
39	CELL_BODY_NUMBER				
40	LCD_COMMAND				
41	LCD_DISP				
42	LCD_SEG_DATA				
43	MEM_COMMAND				
44	MEM_ACCESS				
	Total No. of bytes	21	16	21	7

Table 4-8 View object of AI function block

Relative index	Parameter name	VIEW1	VIEW2	VIEW3	VIEW4
1	ST_REV	2	2	2	2
2	TAG_DESC				
3	STRATEGY				2
4	ALERT_KEY				1
5	MODE_BLK	4		4	
6	BLOCK_ERR	2		2	
7	PV	5		5	
8	OUT	5		5	
9	SIMULATE				
10	XD_SCALE		11		
11	OUT_SCALE		11		
12	GRANT_DENY		2		
13	IO_OPTS				2
14	STATUS_OPTS				2
15	CHANNEL				2
16	L_TYPE				1
17	LOW_CUT				4
18	PV_FTIME				4
19	FIELD_VAL	5		5	
20	UPDATE_EVT				
21	BLCK_ALM				
22	ALARM_SUM	8		8	
23	ACK_OPTION				2
24	ALARM_HYS				4
25	HI_HI_PRI				1
26	HI_HI_LIM				4
27	HI_PRI				1
28	HI_LIM				4
29	LO_PRI				1
30	LO_LIM				4
31	LO_LO_PRI				1
32	LO_LO_LIM				4
33	HI_HI_ALM				
34	HI_ALM				
35	LO_LIM				
36	LO_LO_ALM				
	Total No. of bytes	31	26	31	46

4.6.6 Parameters of AI function block

Settings of parameters of the AI function block can be read, and they can be set on the host system. For main block parameters supported by the FCX-AII, refer to Appendix 2 “PARAMETERS OF BLOCKS”. Here, important parameters will be explained.

MODE_BLK

Determines the mode of the AI function block.

This parameter consists of 4 elements: Target, Actual, Permitted and Normal.

Target is an element by which the operator sets the operation mode of the AI function block. This element can be written.

Actual indicates the actual operation mode of the block, and is used for read only. If requirements were met, Actual works the same as Target. Actual may differ from Target for several reasons.

Permitted indicates which mode is allowed in this function block. Normal is an element by which the operator sets a mode where this function block operates normally. Permitted and Normal are elements where writing is available.

On the AI function block, Out of Service, Manual or Auto is selectable. In the Out of Service mode, the AI function block carries out no execution. In the Manual mode, the AI function block carries out an execution, but last value is not affected by its output and remains as it is. The output can be rewritten from the host instrument. In the Auto mode, the AI function block carries out an execution, and updates the output. This is a normal measurement mode.

XD_SCALE

Used for setting values corresponding to 0% and 100% of the input from the transducer block and industrial value unit. A calibrated range is set prior to delivery. The unit is fixed at kPa.

OUT_SCALE

Used for setting values corresponding to 0% and 100% of the output, and industrial value unit.

L_TYPE

Used for designating an operational method of the AI function block. If Direct was selected, the input from the transducer block directly affects the output. If Indirect was selected, scaling is made according to XD_SCALE and OUT_SCALE, and the output is affected. If Indirect Sq. Root was selected, scaling is made by XD_SCALE, then square root extraction is made, scaling is made by OUT_SCALE, and the output is affected.

PV_FTIME

Used for setting a damping time constant in seconds. Select a value 0 or more.

HI_HI_PRI,HI_PRI,LO_PRI,LO_LO_PRI

Used for setting the priority of process alarms. Selecting 3 or more delivers an alarm. Setting prior to delivery is 0.

HI_HI_LIM,HI_LIM,LO_LIM,LO_LO_LIM

Used for setting threshold values at which process alarms will occur. Settings prior to delivery are positive infinity and negative infinity so that no alarms will occur.

4.6.7 Parameters of transducer block

The transducer block has parameters peculiar to differential pressure and pressure measurements. For main block parameters available by the FCX-AII, refer to Appendix 2 “PARAMETERS OF BLOCKS”. Here, important parameters will be explained.

CAL_POINT_HI

The high limit (100%) of the calibrated point is set.

CAL_POINT_LO

The low limit (0%) of the calibrated point is set.

CAL_DATA

Used for a calibration. For a calibration with CAL_POINT_LO, select Calibration enable and Low Trim. Or, for a calibration with CAL_POINT_HI, select Calibration enable and Upper Trim. Or, for adjustment with industrial value of 0, select Calibration enable and Zero Calibration.

4.6.8 Parameters of resource block

The resource block has parameters related to the resources of the device. For main block parameters available by the FCX-AII, refer to Appendix 2 “PARAMETERS OF BLOCKS”. Here, important parameters will be explained.

ERROR_COUNT

Errors produced at device communications are counted.

RESET_ERR_COUNT

Used to clear ERROR_COUNT.

W_PROTECT

Controls rewriting parameters peculiar to the FCX-AII. Rewriting is unavailable if True is selected, or available if False is selected.

4.6.9 Alarms and events

The FCX-AII can report the following alarms and events.

Analog alarm: Produced when a process variable has exceeded a limit.


It occurs if the variable is beyond any of HI_HI_LIM, HI_LIM, LO_LIM, LO_LO_LIM of the AI function block.

Discrete alarm: Produced when any block has detected an anomaly.

Alerts produced in different blocks are as follows.

(1) Resource block

Block alarm	Produced when:
Out of Service	The Out of Service mode has been posted in the resource block.
Simulation Active	The simulation switch has been turned on.



(2) Transducer block

Block alarm	Produced when:
Out of Service	The Out of Service mode has been posted in the resource block.
Sensor error (XD_ERROR: I/O Failure)	The sensor has become abnormal (display output: FL-1).
Circuit error or memory error (XD_ERROR: Electronics Failure)	The internal circuit has troubled (display output: Circuit error FL-2, memory error FL-3).
Temperature error (XD_ERROR: General Err)	The temperature of the detecting unit has gone beyond the range of -45°C to $+90^{\circ}\text{C}$.

(3) AI function block

Block alarm	Produced when:
Out of Service	The Out of Service mode has been posted in the resource block.
Simulation Active	The simulation function is enabled.
Input Failure	The transducer input is abnormal.
Configuration error	The unit of XD_SCALE of the AI function block does not coincide with that of PRIMARY_VALUE_RANGE.

5. ADJUSTMENT AND SETTING

5.1 Method of adjustment on host system

The transmitter can be adjusted on the host system upon setting the block parameters.

5.1.1 Zero adjustment on host system

Zero adjustment is available while an input is being applied.

- (1) How to set a calibration point (adjustment input)
The adjustment input (calibration point) is set as follows. Set the TARGET of MODE_BLK of the transducer block to Out of Service (0x80). Set the CAL_POINT_LO to an adjustment input value in the unit displayed at CAL_UNIT.
After the end of setting, return the TARGET of MODE_BLK to Auto (0x08).
- (2) Set W_PROTECT of the resource block to False (0x00) to allow Fuji's original parameter to be written.
- (3) Set Command of CAL_DATA of the transducer block to Low_Trim and Calibration enabled (0x82), and write the parameter setting. Then, an adjustment will be executed at an adjustment input.
- (4) After the end of adjustment, set W_PROTECT of the resource block to True (0xff) to protect the original parameter setting from being changed.


5.1.2 Span adjustment on host system

Span adjustment is available while an input is being applied.

- (1) How to set a calibration point (adjustment input)
The adjustment input (calibration point) is set as follows. Set the TARGET of MODE_BLK of the transducer block to Out of Service (0x80). Set the CAL_POINT_HI to an adjustment input value in the unit displayed at CAL_UNIT.
After the end of setting, return the TARGET of MODE_BLK to Auto (0x08).
- (2) Set W_PROTECT of the resource block to False (0x00) to allow Fuji's original parameter to be written.
- (3) Set Command of CAL_DATA of the transducer block to Upper_Trim and Calibration enabled (0x84), and write the parameter setting. Then, an adjustment will be executed at an adjustment input.
- (4) After the end of adjustment, set W_PROTECT of the resource block to True (0xff) to protect the original parameter setting from being changed.

5.2 Zero adjustment

Zero adjustment is available by means of the screw (see the figure below) located on the transmitter.
(The span adjustment is carried out on the host system or HHC.)



Important

- After adjustment, the transmitter should be kept energized at about 10 seconds to write the adjustment result correctly.
- An external adjustment on the transmitter is unavailable if the adjustment function is locked (see Item 5.7).

5.3 How to set the output mode

On the differential pressure transmitter, the output signal is set to the proportional mode (proportional to input differential pressure) or square root mode (proportional to flow rate).

- (1) Set the TARGET of MODE_BLK of the AI function block to Out of Service (0x80) to change the mode.
- (2) Set the L_TYPE of the AI function block to:
Indirect (0x02) for proportional mode of output; or
Indirect Sq. Root (0x03) for square root mode of output.
- (3) Set the TARGET of MODE_BLK of the AI function block to Auto (0x08) to start a calculation in a selected output mode.

5.4 Setting of low flow cut point

If the square root extraction mode was selected for output, the flow rate below which the output is cut should be set in the unit of the output scale (OUT_SCALE) because it is based on the output scale. Set the LOW_CUT of the AI function block to a cut point. Then, set the bit10 (LOW_CUT off enable) of IO-OPTS of AI function block. A flow rate below the cut point will give 0% output.

5.5 Damping adjustment

If the process variable changes excessively, if the mounting place vibrates excessively, or if the measurement output of a very low differential pressure, for example, varies considerably, selecting an appropriate damping time constant is effective for suppressing the output variation. For this purpose, set the PV_FTIME of the AI function block to a desired time constant.

5.6 Setting of burnout direction

For how to treat the output in case of troubles, etc. of the detection unit, you can select the burnout direction.

- (1) Set the W_PROTECT of the resource block to False (0x00) to allow Fuji's original parameter to be written.
- (2) Set the BURNOUT_SET of the transducer block to a desired burnout direction as follows.
High (0x00) so that output will stick to high limit
Low (0x01) so that output will stick to low limit
Hold (0xef) so that last output will be held
- (3) Set the W_PROTECT of the resource block to True (0xff) to protect Fuji's original parameter setting from being changed.

5.7 Locking of external adjustment function

You can enable/disable the function of adjustment by the external adjustment screw.

- (1) Set the W_PROTECT of the resource block to False (0x00) to allow Fuji's original parameter to be written.
- (2) Set the LOCAL_KEY of the transducer block to:
Disable (0x01) to lock; or
Enable (0x00) to unlock.
- (3) Set the W_PROTECT of the resource block to True (0xff) to protect Fuji's original parameter setting from being changed.

5.8 Setting of display on digital indicator

You can change the indication scale and unit on the digital indicator, if provided, upon selecting the LCD_DISP of the transducer block.

The LCD_DISP has following parameters.

- (1) LCD_UPPER_DISPLAY_VALUE: Set to upper limit of display scale
- (2) LCD_LOWER_DISPLAY_VALUE: Set to lower limit of display scale
- (3) LCD_DIGIT: Set to number of digits below decimal point
- (4) LCD_UNIT: Set to unit code
- (5) LCD_OPTION: Unused

5.8.1 Setting method

- (1) Allowing Fuji's original parameter to be written
Set the W_PROTECT of the resource block to False (0x00) to allow Fuji's original parameter to be written.
- (2) Selecting LCD_DISP parameter
To set the LCD_UPPER_DISPLAY_VALUE, input the value of Upper_sensor_limit (PV_SENSOR_INFO) that was converted in terms of setting unit.
To set the LCD_LOWER_DISPLAY_VALUE, input the value of Lower_sensor_limit (PV_SENSOR_INFO) that was converted in terms of setting unit (input 0).
To set the LCD_DIGIT, input the number of digits displayed below decimal point.
To set the LCD_UNIT, input a unit code from the separate table.

[Example of setting]

For measurement at transmitter range of 32 kPa in setting unit of mmH₂O

LCD_UPPER_DISPLAY_VALUE = $32.381 \times 1.01972 \times 10^2 = 3200$ (mmH₂O)

LCD_LOWER_DISPLAY_VALUE = 0 (mmH₂O)

LCD_DIGIT = 0 (0 digit below point)

LCD_UNIT = 262145 (unit code for mmH₂O)

-
- (3) Writing LCD_DISP parameter
Write PARAM_WRITE in the LCD_COMMAND, and write data of LCD_DISP parameter.
 - (4) Protecting Fuji's original parameter setting from being changed
Set the W_PROTECT of the resource block to True (0xff) to protect Fuji's original parameter setting from being changed.

5.9 Setting of output scale

Setting the output scale determines the scale of the output (OUT) of the AI function block.

For changing the setting, rewrite the data of XD_SCALE and OUT_SCALE of the AI function block.

- (1) Set the TARGET of MODE_BLK of the AI function block to Out of Service (0x80) to change the mode.
- (2) Set the XD_SCALE of the AI function block to the output scale (based on transducer output unit).
 - EU at 100: Set the high limit of output based on the output unit of the transducer block.
 - EU at 0: Set the low limit of output based on the output unit of the transducer block.
- (3) Set the OUT_SCALE of the AI function block to the output scale.
 - EU at 100: Set to the value set at EU at 100 of XD_SCALE in terms of output unit.
 - EU at 0: Set to the value set at EU at 0 of XD_SCALE in terms of output unit.
 - UNIT: Set to the unit of the output scale.
- (4) Set the TARGET of MODE_BLK of the AI function block to Auto to resume the initial mode.
Upon the above setting, the arithmetic operation starts on the selected scale.

5.10 Simulation function

If the simulation switch on the transmitter has been set to Enable, the calculation of the function block can be executed with a simulation input.

Upon setting the SIMULATE parameters of the AI function block as follows, the arithmetic operation starts with a simulation input.

SIMULATE_VALUE: Set to a simulation input value based on the output unit of the transducer block.

SIMULATE_ENABLE/DISABLE: Set to ENABLE.

6. MAINTENANCE

6.1 Periodic inspection

In order to ensure the measurement accuracy and long life of the transmitter, it is essential to inspect the transmitter periodically according to the operating conditions.

Visual inspection

Visually inspect each part of the transmitter for damage, corrosion, etc.

If you detect any material which may cause corrosion, it should be cleaned off.


Check of cover and O-ring

The transmitter has a water and dust-proof construction.

Make sure the O-ring of the case cover is not damaged or deteriorated.


Carefully prevent foreign materials from sticking to threads.

Before remounting the transmitting cover and the terminal cover, apply grease.



Piping leakage check

Using soapy water or the like, check the all process connections for leakage of process fluid. If necessary, drain the moisture which has accumulated in the transmitter and process pipe.



6.2 Troubleshooting

If an abnormality occurred in the process or transmitter, action should be taken with reference to the table below.

Symptom	Cause	Remedy
Output overshoots scale.	(1) The manifold valve does not open/close normally. —→	Repair the valve so that it opens/closes normally.
	(2) Pressure leak is occurring. —→	Repair a leak.
	(3) Process piping is improper. —→	Make correct piping.
	(4) Process pipe is clogged. —→	Eliminate the cause of clogging.
	(5) Power supply voltage is improper. —→	Make arrangement to obtain proper values.
	(6) Voltage between the external connection terminals of amplifier unit is wrong. —→	Check for faulty cable, insulation, etc. and repair as needed. (Power supply voltage should be 9 to 32V DC.)
	(7) Electronics unit is faulty. —→	Replace the electronics unit according to Item 6.3.
No output	(1) Same as (1) to (4) above	
	(2) Power supply polarity is wrong. —→	Correct wiring according to Item 8.1.
	(3) Power supply voltage is improper. —→	Make arrangement to obtain proper value.
	(4) Voltage between the external connection terminals is wrong. —→	Check for faulty cable, insulation, etc. and repair as needed. (Power supply voltage should be 9 to 32V DC.)
	(5) Electronics unit is faulty. —→	Replace the electronics unit according to Item 6.3.
Output is large error	(1) Process piping is improper. —→	Correct the piping.
	(2) Gas or solution is mixed in. —→	Vent or drain the transmitter.
	(3) Liquid density changes. —→	Perform density compensation.
	(4) Ambient temperature changes widely. —→	Minimize the temperature change.
	(5) Electronics unit is faulty. —→	Replace the electronics unit according to Item 6.3.

If remedy is impossible, contact Fuji Electric's service department.

6.3 Replacement of parts

If malfunction occurs to the transmitter, remove the transmitter from the piping, and replace defective parts or the unit. It is desirable that the replacement work be done within an instrument adjustment room.



DANGER


When removing an explosion-proof transmitter, turn OFF the main power, then disconnect the piping and wiring. Do not remove it when the power is ON to prevent serious accident such as explosion, fire, etc.

To identify faulty part

Replace the amplifier unit with a spare one in order to determine whether it is the detecting unit or amplifier unit which is faulty.

When the faulty unit is identified, it should be replaced with a new one.

Replacement of electronics unit



Replacing procedure

- (1) Turn off the power supply.
- (2) Remove the indicator.
- (3) Remove the electronics unit.
- (4) Unplug each connector.
- (5) Replace the electronics unit with a new one and assemble it by reversing the above procedure from (4) to (1).



Important


The electronics unit should be removed carefully so as not to damage the internal wiring.

- (6) After completion of replacement, perform zero and span adjustments.




Important

When installing the electronics unit, make sure that the zero adjust screw and the volume control are positioned as shown the right.



Replacement of detecting unit



Replacing procedure

- (1) Remove the electronics unit according to “Replacement of electronics unit.”
- (2) Remove the hex. socket bolts from the electronic housing.
Pull the electronics housing straight forward and away from the detecting unit.
- (3) Replace the detecting unit with a new one of the same type.
- (4) Fit the amplifier unit to the detecting unit and tighten it.
- (5) Connect each connector of the electronics unit and attach it to the amplifier unit.
- (6) After reassembly, carry out zero and span adjustments.




Important

- Ensure that replacement detecting unit is the same specification as the original by comparing dataplates.
- When removing the transmitter case, pay attention not to damage the flatcable.

Replacement of the internal parts of detecting unit

In case of differential and flow transmitter (code symbol: FDC)




Replacing procedure

- (1) Remove four hexagon socket head bolts with a torque wrench, etc..
- (2) Disassembly gives access to the casing covers, O-rings (or gasket), hexagon socket head bolts and nuts.
- (3) After disassembly, replace the faulty part with a new one.
- (4) Before reassembly, clean the O-ring face of casing cover with the soft cloth immersed in water, alcohol, or similar detergent.
- (5) Reassemble the detecting unit by reversing the disassembling procedure. The casing covers should be assembled so as to be symmetrical with each other in the left-right direction and carefully so as not to damage the seal diaphragm. Tightening torque should follow the table below.

Bolt size	Bolt material	Tightening torque [N·m] (kgf·m) <ft-lb>	Maximum working pressure [MPa] {bar} <psi>	Application
M10	Cr-Mo steel	50 (5) <36>	42 {420} <6000>	Working pressure 42 MPa {420 bar} <6000 psi> or less
M10	SUS304 ASTMB7M ASTML7M	30 (3) <22>	10 {100} <1400>	Working pressure 10MPa {100 bar} <1400 psi> or less
M10	SUS630	50 (5) <36>	42 {420} <6000>	Working pressure 42 MPa {420 bar} <6000 psi> or less

- (6) After assembly, carry out a pressure test (leak test). Apply a pressure equal to 150% of the maximum working pressure to both high pressure (H) and low pressure (L) measurement chambers of the transmitter simultaneously for 15 minutes, and make sure there is no leakage.

In case of absolute pressure and pressure transmitter (code symbol: FDA and FDG)



- (1) Remove four bolts with a torque wrench, etc..
- (2) Disassembly gives access to casing covers, O-rings (or gasket), bolts and nuts.
- (3) After disassembly, replace the faulty part with a new one.
- (4) Before reassembly, clean the O-ring face of casing cover with the soft cloth immersed in water, alcohol, or similar detergent.
- (5) Reassemble the detecting unit by reversing the disassembling procedure. The casing covers should be assembled so as to be symmetrical with each other in the left-right direction and carefully so as not to damage the seal diaphragm. Tightening torque should follow the table below.

In case of absolute pressure transmitter (FDA)


Bolt size	Bolt material	Tightening torque [N·m] (kgf·m) <ft-lb>	Maximum working pressure [MPa abs] { bar abs } <psi abs>	Application
M10	Cr-Mo steel	50 (5) <36>	3 { 30 } <430>	Common over entire range
M10	SUS304 ASTMB7M ASTML7M	30 (3) <22>	3 { 30 } <430>	

In case of pressure transmitter (FDG)

Bolt size	Bolt material	Tightening torque [N·m] (kgf·m) <ft-lb>	Maximum working pressure [MPa] { bar } <psi>	Application
M10	Cr-Mo steel	50 (5) <36>	50 { 500 } <7100>	Common over entire range
M10	SUS304 ASTMB7M ASTML7M	30 (3) <22>	10 { 100 } <1400>	Range 10000 [kPa] <1400 psi> or less
M10	SUS630	50 (5) <36>	50 { 500 } <7100>	Exclusive for range 50000 [kPa]

- After assembly, carry out a pressure test (leak test).
Apply the allowable maximum pressure to the high pressure measurement chamber of the transmitter for 15 minutes, and make sure there is no leakage.

In case of level transmitter (code symbol: FDE, FDY)




- (1) Remove four hexagon socket head bolts with a torque wrench, etc..
- (2) Disassembly gives access to the casing cover, O-ring (or gasket) and hexagon socket head bolts.
- (3) After disassembly, replace the faulty part with a new one.
- (4) Before reassembly, clean the O-ring face of casing cover with the soft cloth immersed in water, alcohol, or similar.
- (5) Reassemble the detecting unit by reversing the disassembling procedure. The casing cover should be assembled carefully so as not to damage the seal diaphragm. Tightening torque should follow the table below.

Bolt size	Bolt material	Tightening torque [N·m] (kgf·m) <ft-lb>	Maximum working pressure
M10	Cr-Mo steel	50 (5) <36>	Up to rated flange pressure
M10	SUS304	30 (3) <22>	Up to rated flange pressure

- (6) After assembly, carry out a pressure test (leak test). Apply a pressure equal to 150% of the maximum working pressure to both flange side (high pressure side) and low pressure (L) measurement chamber of the transmitter simultaneously for 15 minutes, and make sure there is no leakage.

Removing and mounting the direct mount adaptor for small size flange type transmitter.
(code symbol: FDW, FDX, FDY)




- (1) The direct mount adaptor is fitted to the pressure bed with six M8 bolts. Loosen the bolts and remove the adaptor.
- (2) It is disassembled into direct mount adaptor, gasket, bolts and nuts.
- (3) After disassembling, replace damaged parts with new ones.
- (4) Before reassembling, clean the direct mount adaptor, the pressure bed and the gasket with a soft cloth moistened with water or alcohol.
- (5) Assemble all the parts in reverse order of disassembly.

When assembling, care should be taken not to damage the seal diaphragm at the pressure bed. Tighten the M8 bolts (SCM435) to 10N·m (1kgf·m) torque using a torque wrench.


- (6) After assembly, carry out a pressure test (leak test). Apply a pressure (150% of rated flange pressure) to the direct mount adaptor for 15 minutes and confirm that it is free from leakage.

Replacement of field indicator




Replacing procedure

- (1) Detach the transmitter cover.
- (2) Remove two fixing screws which fasten the field indicator and separate the indicator.
- (3) Disengage the connector pin that connects the field indicator to the electronics unit except when only the field indicator itself is to be replaced.
- (4) Connect the new field indicator and connector pin to the electronics unit.



- (5) Fasten the digital indicator to the electronics section by tightening two fixing screws.



- (6) Attach the transmitter cover.




7. INSTALLATION AND PIPING

7.1 Installation

After unpacking, check the delivered items.

This transmitter can be mounted on a pipe or on a wall.

(However, level transmitters (types: FDE, FDY) require flange mounting).


 CAUTION	<ul style="list-style-type: none">• The transmitter is heavy. Be careful when handling it.• The transmitter should be installed in a place that meets the operating conditions shown in DS sheet or instruction manual.• Install the transmitter according to the instruction manual. Improper installation may lead to the cause of fall, trouble or incorrect operation.• When installing, make sure that the transmitter interior is free from cable chips and other foreign objects to prevent fire, trouble or incorrect operation.
 DANGER	<ul style="list-style-type: none">• Non-explosion-proof transmitter must not be used in a place with explosive gas to prevent serious accidents such as explosion, fire, etc.
 Important	<p>If the transmitter is not used soon after delivery, then leave it packed and store it in a room at the normal temperature and humidity (25°C <77°F>, 60%RH).</p>

Bracket mounting


Mount the bracket to the transmitter.

The bracket should be mounted to the process cover as shown below.

Differential pressure/flow transmitters, pressure transmitters, and absolute pressure transmitters, types: FDC, FDG, FDA




Remote seal type transmitters, types: FDD, FDB, FDW, FDX



Mounting

Pipe mounting

- (1) Fasten the transmitter to a vertical or horizontal pipe using the supplied U-bolt (Tightening torque approximately 15 N·m (1.5 kgf·m)<11ft·lb>).
- (2) Use a pipe of outside diameter $\phi 60.5 < 2.38 > \text{mm}$.




Wall mounting

- (1) Fasten to wall face by M8 bolt utilizing the U-bolt holes.

Flange mounting

Bolt to tank flange.



Change of amplifier unit position




Avoid the following procedure in an explosionproof area.

Wiring is sometimes difficult depending on the installation location. In such a case, it is convenient to carry out the following.

Before turning the amplifier unit, remove the electronics unit.

The amplifier unit is secured by 2 hex socket bolts. Loosen the bolts, turn the amplifier unit at 90° or 180° in the clockwise or counterclockwise direction and fix it by the screws. Then, carry out wiring.



If the transmitting unit has been turned more than 360° without removing the amplifier unit, the flatcable which interconnects amplifier unit and detecting unit may twist. In such a case, remove the twisting before reassembly.


Change of vent/drain plug position

Grasp the hexagon part of vent/drain plug and rotate it to remove.

Bind vent/drain plug's thread with new seal tape and mount vent/drain plugs to new process connections.


Tightening torque : 25N·m (2.5kgf·m) <18ft·lb>

After remounting the vent/drain plug, check the airtightness upon applying a pressure.



Check space

Ensure a space of about 500mm against the cover in order to facilitate check, adjustment, etc.



7.2 Piping

It is generally recognized that there are appropriate positioning relationship between the transmitter and main process piping for accurate measurement to avoid harmful gas or liquid accumulation.

General recognizations are;

- (1) Mount transmitter below main process piping for liquid or steam measurement.
- (2) Mount transmitter above main process piping for gas measurement.

The above concept is important not to let the gas (or drain), which enters the piping from the process pipe, stay within the piping but let it return to the process pipe by itself.

The standard FCX-AII-series transmitters are provided with a pressure connection port and a vent/drain plug to allow the installation of piping by the method in (1) above. By reversing the vent/drain plug, the piping can also be installed by the method in (2).



Main valve used for piping should be selected with the maximum pressure of the process taken into account (piping parts such as main valve, etc. should be furnished by user). If the main valve and other parts do not meet the rating, it may result in leakage of gas or liquid which could lead to a hazard.

7.2.1 Piping of differential pressure and flow transmitter (type: FDC)

Check of high/low pressure sides of transmitter


The detecting unit of the differential pressure transmitter bears symbols H and L which represent high and low pressure sides, respectively.

Removal of protective cap

The process connection ports of the transmitter and manifold (equalizer) valve are fitted with protective caps. Before piping, be sure to remove the caps. When removing the caps, carefully protect the threaded portion and sealing face from damage.

Connection of transmitter and impulse pipes


- (1) When using the manifold valve, it should be fixed to the transmitter by tightening four oval flange setbolts (7/16-20UNF), and then the impulse pipe should be connected to the manifold valve. Tightening torque of 7/16-20UNF mounting bolt should be 30 to 40 N·m (3 to 4 kgf·m).
- (2) If a manifold valve is not used, the impulse pipes can directly be screwed into the transmitter. If thread size does not match between the transmitter and impulse pipes, an oval flange should be used. Tightening torque of 7/16-20UNF mounting bolt in an oval flange should be 30 to 40 N·m (3 to 4 kgf·m).



Position of process taps (Horizontal main process piping)

The position of the process tap is determined by the relationship between the condition, characteristics and measuring point of the process fluid.


Note the following figures when planning and installing the piping.



Typical examples of piping

1 Flow measurement (in case of gas)


Place the transmitter above the differential pressure source.



2 Flow measurement (in case of liquid)

Place the transmitter below the differential pressure source.


Make piping so that gas in the impulse pipe is not delivered to the transmitter, and incorporate gas reservoirs as required.



3 Flow measurement (in case of steam)


Set two condensers at the same height near the process tap. Fill the line between the condensers and transmitter with condensed water.

Install a drain port as required.



④ Pressure measurement (in case of liquid)

Zero point can be checked with a manifold valve installed.



Important


- (1) Protection is required to prevent dust from entering through the atmospheric air inlet after installation of the manifold valve.
- (2) If process pressure range is narrow (below 10kPa (1000mmH₂O)), the following should be considered.

- Pressure variation due to wind around atmospheric air inlet

To overcome this, provide atmospheric pressure-side pipe with a proper orifice and consider accommodating the transmitter and atmospheric air inlet in a box.

⑤ Pressure measurement (in case of gas)

Mount the transmitter above the process pipes to preventing moisture from entering the inside of transmitter.



⑥ Level measurement

- (1) In case of wet leg:

For measurement, connect the highest liquid level tapping of tank to the low pressure side of transmitter, and the lowest liquid level tapping of tank to the high pressure side of transmitter.

Level calculation formula

$$\text{LRV} : \rho H_2 - \rho_0 H_1$$

$$\text{URV} : \rho H_2 + \rho_1 h - \rho_0 H_1$$


$$\text{Span } (\Delta P) : \rho_1 h$$

LRV : Low limit of measurement
(0% point)

URV : High limit of measurement
(100% point)

ρ_0, ρ, ρ_1 : Density

H_1, H_2 : Liquid level, h : Liquid level change



(2) In case of dry leg:

For an open tank, leave the low pressure side of transmitter open to atmosphere.

Level calculation formula

$$\text{LRV: } \rho H_1$$

$$\text{URV: } \rho H_1 + \rho_1 h$$


$$\text{Span } (\Delta P): \rho_1 h$$

LRV: Low limit of measurement (0% point)

URV: High limit of measurement (100% point)

ρ, ρ_1 : Density

H_1 : Liquid level, h : Liquid level change




Cautions on piping

- For liquid, the impulse pipes should have an upward slope of 1/10 or more between the process connection and the transmitter to prevent accumulation of gas, etc. in the detecting unit.
- For gas, the impulse pipes should have a downward slope of 1/10 or more between the process connection and transmitter to prevent accumulation of moisture, etc. in the detecting unit.
- Avoid any sharp bends in impulse pipe which may cause gas or moisture to accumulate in the impulse pipe.
- Take care not to apply an excessive force to the transmitter during its connection.
- The impulse pipes used should be suitable for the working temperature, pressure, etc.
- When the measuring fluid is likely to freeze in the cover of the measurement chamber, the cover needs to be warmed up with steam or a heater.
- After piping, be sure to check the airtightness.

7.2.2 Piping of pressure and absolute pressure transmitter (types: FDG, FDA)

Removal of protective cap

The process connection port of the transmitter is fitted with a protective cap. Before piping, remove the cap carefully. When removing the cap, carefully protect the threaded portion and sealing face from damage.




Connection of transmitter and impulse pipe

- Impulse pipe should be connected with an oval flange. Also, the pipe can directly be screwed into the transmitter. Tightening torque of 7/16-20UNF mounting bolt in an oval flange should be 30 to 40 N·m (3 to 4 kgf·m).
- After connection, close the stop valve of transmitter in order to prevent foreign materials from entering the inside.

Position of process taps (Horizontal main process piping)


The position of the process tap is determined by the relationship between condition, characteristics and measurement point of process fluid. Note the following figures when planning and installing the piping.



Typical examples of piping

① Gas measurement


Place the transmitter above the pressure source.



② Liquid measurement


Place the transmitter below the pressure source.

Make piping so that gas in the process pipe is not delivered to the transmitter, and incorporate gas reservoirs as required.



③ Steam measurement

Place the transmitter below the pressure source.



Cautions on impulse piping

- For liquid, the impulse pipe should have an upward slope of 1/10 or more between the process connection and transmitter to prevent accumulation of gas, etc. in the detecting unit.
- For gas, the impulse pipe should have a downward slope of 1/10 or more between process connection and transmitter to prevent accumulation of moisture, etc. in the detecting unit.
- Avoid any sharp bends in impulse pipe which may cause gas or moisture to accumulate in the impulse pipe.
- Take care not to apply an excessive force to the transmitter during its connection.



CAUTION


The impulse pipe used should be suitable for the working temperature, pressure, etc.

- When the measuring fluid is likely to freeze in the cover of the measurement chamber, the cover needs to be warmed up with steam or a heater.
- After piping, be sure to check the airtightness.

7.2.3 Piping of level transmitter (types: FDE, FDY)


Check of high/low pressure sides of transmitter

The detecting unit of the level transmitter bears symbols H and L which represent high and low pressure sides, respectively.



Seal on mounting flange face


When mounting the flange on the high pressure side, a gasket should be inserted as follows.



On the flush flange type, be sure to use a gasket with an internal diameter larger than shown in the table below, to prevent the gasket from touching the seal diaphragm.
On the 80A (3B) type particularly, it should be noted that the 80A (3B) gasket available from the market is such that its inside diameter is smaller than the size shown below. If it is used, it touches the seal diaphragm and cause errors in measurements.

Minimum internal diameter of flush flange type gasket

Flange size	Minimum internal diameter of gasket
40A (1½B), 50A (2B)	49mm
80A (3B), 100A (4B)	100mm




It should be noted that leakage of fluid from the wetted parts would affect the performance due to the progress of corrosion.

Connecting method of the mounting flange

Tighten bolts of mounting flange and process flange in a diagonal order and about three cycles.

Removal of protective cap from process connection port

The process connection port on the low pressure side is fitted with a protective cap. Before piping, remove the cap carefully. When removing the cap, carefully protect the threaded portion and sealing face from damage.



Connection of transmitter and impulse pipe

- The pipe on the low pressure side can be connected with an oval flange. Also, the impulse pipe can directly be screwed into the transmitter. Tightening torque of 7/16-20UNF mounting bolt in an oval flange should be 30 to 40 N·m (3 to 4 kgf·m).
- After connection, close the stop valve of transmitter in order to prevent foreign materials from entering the inside.

Typical examples of piping

① Level measurement of open tank

Leave the low pressure side of transmitter open to atmosphere.

Level calculation formula

$$\text{LRV: } \rho H_1$$

$$\text{URV: } \rho (H_1 + h)$$

$$\text{Span } (\Delta P): \rho h$$


LRV: Low limit of measurement (0%)

URV: High limit of measurement (100%)

ρ : Measuring liquid density

H_1 : Liquid level (Refer to “Cautions on piping”)

h : Liquid level change



② Level measurement of enclosed tank

(1) In case of wet leg:

Connect the highest liquid level tapping of tank to the low pressure side of transmitter, and the lowest liquid level tapping of tank to the high pressure side (flange side) of transmitter.

Level calculation formula

$$\text{LRV: } \rho H_1 - \rho_0 H_2$$

$$\text{URV: } \rho (H_1 + h) - \rho_0 H_2$$

$$\text{Span } (\Delta P): \rho h$$

LRV: Low limit of measurement (0%)

URV: High limit of measurement (100%)


ρ : Measuring liquid density

ρ_0 : Seal liquid density

H_1 : Liquid level (Refer to “Cautions on piping”)

h : Liquid level change

H_2 : Seal liquid level



(2) In case of dry leg:

Connect the highest liquid level tapping of tank to the low pressure side of transmitter, and the lowest liquid level tapping of tank to the high pressure side (flange side) of transmitter.

Level calculation formula

LRV: ρH_1

URV: $\rho (H_1 + h)$

Span (ΔP): ρh


LRV: Low limit of measurement
(0%)

URV: High limit of measurement
(100%)

ρ : Measuring liquid density

H_1 : Liquid level (Refer to "Cautions on piping")

h : Liquid level change



Cautions on piping

- Restriction on H_1

Liquid level is not proportional to the transmitter output at some points inside the seal diaphragm.

Therefore, H_1 should be set higher than the value shown in the table below.

Minimum value of H_1


Flange size	Flush flange type	Extension flange type
40A (1½B)	30mm	—
50A (2B)	30mm	30mm
80A (3B)	55mm	40mm
100A (4B)	55mm	55mm

- Do not shock the seal diaphragm by hitting hard object against it, for example.
- Take care not to apply an excessive force to the flange during connection.
- When the measuring fluid is likely to freeze in the cover of the low pressure measurement chamber, the cover needs to be warmed up with steam or a heater.
- After piping, be sure to check the airtightness.

7.2.4 Piping of remote seal type differential pressure transmitter (types: FDD, FDX)


Check of high/low pressure sides of transmitter

The detecting unit of the remote seal type differential pressure transmitter bears symbols H and L which represent high and low pressure sides, respectively.



Seal on mounting flange face

When mounting the flange, a gasket should be inserted as follows.



Important

On the flush flange type, be sure to use a gasket with an internal diameter larger than shown in the table below, to prevent the gasket from touching the seal diaphragm.

On the 80A (3B) type particularly, it should be noted that the 80A (3B) gasket available from the market is such that its inside diameter is smaller than the size shown below. If it is used, it touches the seal diaphragm and cause errors in measurements.

Minimum internal diameter of flush flange type gasket

Flange size	Minimum internal diameter of gasket
40A (1½B), 50A (2B)	49mm
80A (3B), 100A (4B)	100mm




Important

When measuring a highly corrosive process fluid, care should be taken as corrosion may occur if the fluid leaks past wetted parts.


Connecting method of the mounting flange

Tighten the bolts of mounting flange and process flange in a diagonal order and about three cycles.



Mounting of flange and bed


The bed has two screw holes on the back face. It is therefore recommended to mount the bed to the flange in advance by tightening screws (M6). The flange should be supplied by the customer.



Piping for small flange transmitter with direct mount adaptor

When connecting the direct mount adaptor to the process piping, make sure that the 2 vent/drain plugs fitted to the adaptor are positioned up and down, respectively.

Gaskets, bolt and nuts used for connecting the process piping are not supplied from Fuji, and should be prepared by user.



Typical examples of piping

Level measurement

(1) Open tank

An open tank should be piped so that the flange on the low pressure side is open to atmosphere.

Level calculation formula

$$\text{LRV: } \rho H_1 - \rho' D$$

$$\text{URV: } \rho (H_1 + h) - \rho' D$$

$$\text{Span } (\Delta P): \rho h$$

LRV: Low limit of measurement (0%)


URV: High limit of measurement (100%)

ρ : Measuring liquid density

ρ' : Seal liquid density

H_1 : Liquid level (Refer to "Cautions on installation")

h : Liquid level change



(2) Enclosed tank

Connect the low pressure side flange to the highest liquid level tapping of tank, and the high pressure side flange to the lowest liquid level tapping of tank.

Level calculation formula

$$\text{LRV: } \rho H_1 - \rho' D$$

$$\text{URV: } \rho (H_1 + h) - \rho' D$$

$$\text{Span } (\Delta P): \rho h$$

LRV: Low limit of measurement (0%)


URV: High limit of measurement (100%)

ρ : Measuring liquid density

ρ' : Seal liquid density

H_1 : Liquid level (Refer to “Cautions on piping”)

h : Liquid level change



* The seal liquid density ρ' is a value at 25°C.

13th digit of type code	Density (g/cm ³)	Description
Y, G	0.96	For general measurement (silicone oil)
W, A, D	1.9	For oxygen and chlorine measurement (fluorine-group oil)
H, S, K	1.07	For high temperature, high temperature and vacuum, and high temperature and high vacuum (silicone oil)
J, T	1.09	



The transmitter body should be installed below any pressure receiving unit. This is mandatory where process pressure may become vacuum due to application.

Cautions on piping

- Restriction on H_1
Liquid level is not proportional to the transmitter output at some points inside the seal diaphragm. Therefore, H_1 should be set higher than the value shown in the table below.

Minimum value of H_1

Flange size	Flush flange type	Extension flange type
40A (1½B)	30mm	—
50A (2B)	30mm	30mm
80A (3B)	55mm	40mm
100A (4B)	55mm	55mm

- In order to prevent vibration of the transmitter body and capillary from interfering with output, the transmitter body should be installed at a vibration-free place and the capillary should be fixed to a stable support.
- For minimizing the influence by a difference in the ambient temperature, the capillaries on the high and low pressure sides should be laid together.
- Do not shock the seal diaphragm by hitting a hard object against it, for example.

- Water head pressure due to difference in the height of flange

When there is a difference (D) in flange mounting position between the high-pressure side and the low-pressure side, a water pressure head “ $-\rho'D$ ” is applied to the transmitter, so a zero point shift for the water head pressure ($-\rho'D$) due to difference in height of flange is required at range setting as shown in the example of typical piping.

On the FCX-AII series transmitter, the zero point shift can be made by the following methods.

1. Range change (LRV, URV) with the HHC
2. Change of LRV in rerange with the HHC


For details of the necessary procedure, refer to the relevant item.

- After piping, be sure to check the airtightness.

7.2.5 Piping of remote seal type pressure transmitter (types: FDB, FDW)

Seal on mounting flange face

When mounting the flange, a gasket should be inserted as follows.



Important

On the flush flange type, be sure to use a gasket with an internal diameter larger than shown in the table below, to prevent the gasket from touching the seal diaphragm.

On the 80A (3B) type particularly, it should be noted that the 80A (3B) gasket available from the market is such that its inside diameter is smaller than the size shown below. If it is used, it touches the seal diaphragm and cause errors in measurements.

Minimum internal diameter of flush flange type gasket

Flange size	Minimum internal diameter of gasket
40A (1½B), 50A (2B)	49mm
80A (3B), 100A (4B)	100mm



Important


When measuring a highly corrosive process fluid, care should be taken as corrosion may be aggravated if the fluid leaks out of wetted parts.

Connecting method of the mounting flange

Tighten the bolts of mounting flange and process pipe flange in a diagonal order and about three cycles.


Mounting of flange and bed

The bed has two screw holes on the back face. It is therefore recommended to mount the bed to the flange in advance by tightening screws (M6). The flange should be supplied by the customer.




Mounting method of screw-in type diaphragm section

- (1) The diaphragm section of this transmitter is of G1 screw-in type. Process tap should be made as shown below. Also, care should be taken so that the sealing face will be free from damages, contaminants, etc.




- (2) Install the furnished gasket.



- (3) After confirming that the aluminum gasket is inserted, screw in the bolt manually until the bolt no longer moves. Then tighten the bolt firmly with a wrench.


Spanner nominal size : 38
Tightening torque : 110N•m



Typical examples of piping


① Gas measurement

Locate the process tap above the pressure source.



② Liquid measurement

Locate the process tap below the pressure source.



③ Level measurement

Open tank

An open tank should be connected on the lowest liquid level tapping point.

Level calculation formula

$$\text{LRV: } \rho H_1 + \rho' D$$

$$\text{URV: } \rho (H_1 + h) + \rho' D$$

$$\text{Span } (\Delta P): \rho h$$

LRV: Low limit of measurement (0%)


URV: High limit of measurement (100%)

ρ : Measuring liquid density

ρ' : Seal liquid density

H_1 : Liquid level (Refer to "Cautions on piping")

h : Level change



Important

The transmitter body should be installed below any pressure receiving unit. This is mandatory where process pressure becomes vacuum due to application.

Cautions on piping

- Restriction on H_1

Liquid level is not proportional to the transmitter output at some points inside the seal diaphragm. Therefore, H_1 should be set higher than the value shown in the table below.

Minimum value of H_1

Flange size	Flush flange type	Extension flange type
40A (1½B)	30mm	—
50A (2B)	30mm	30mm
80A (3B)	55mm	40mm
100A (4B)	55mm	55mm

- In order to prevent vibration of the transmitter body and capillary from interfering with output, the transmitter body should be installed at a vibration-free place and the capillary should be fixed to a stable support.
- Do not shock the seal diaphragm by hitting hard object against it, for example.
- After piping, be sure to check the airtightness.

8. WIRING

Cautions on wiring

- (1) Application of a voltage exceeding 32 V DC between “+” and “-” terminals may result in damage to the transmitter.
- (2) Use type A cable of the Fieldbus Association where possible.
- (3) Avoid installation of signal cable and power cable in same conduit or cable tray in order to prevent increased noise. Also, do not bring the signal cable close to large electrical equipment.



In case of an explosionproof arrangement, wiring shall be made in accordance with the relevant regulations to ensure the explosionproofing.

Effect of cellular phone

The use of a cellular phone near the transmitter or the cables may adversely affect the output of the transmitter. Do not use a cellular phone within 20cm of the transmitter or the cables.


8.1 Wiring procedure



- Before making wiring work, be sure to turn OFF the main power to prevent electric shocks.
- Use wiring materials of correct rating to prevent fire accidents.
- After installing the transmitter, firmly close the covers of the amplifier unit and terminal box. If not, rain water enter the transmitter which may result in trouble or incorrect operation.

Sealing of conduit connection

To ensure airtightness of the conduit connection, use sealing tape for metal pipe screw coupling, and rubber gasket, fastening gland, etc. for JIS F8801 A15C for the ø11 cable.





Important

1. If the connection box is located above the transmitter when using a protective tube for the wiring, then moisture may enter the protective tube and have an adverse effect on the transmitter. So maintaining airtightness of the connection box is an important practice.
2. The thread of conduit tube should meet the selected size (parallel pipe thread G1/2).

Terminal block connection diagram

Tighten the terminal screws (M4 × 10) to a torque of approximately 1.5 N·m (15 kgf·cm) <11ft-lb> so that the wires will not loosen.

After connection, fasten the cover until it does not turn.





For terminal connection, do not mistake the “+” and “-” polarities of power source.

Things convenient to know beforehand

When using conduit connection at the top (In the case of 4th digit of type code “S, T, V, W, X”)

For wiring from the top conduit connection, use the following procedure.


- (1) Remove the screw plug of the top conduit connection.
- (2) Screw the removed screw plug into the bottom conduit connection.
- (3) Insert the cable from the top and connect it.



- The unused conduit connection is of great importance to flameproofing and moisture prevention. So be sure to tighten the flush screw and packing into the connection.

8.2 Configuration of fieldbus connection

In order that the fieldbus equipment can be used, the following configuration of connection is necessary.



Configuration of fieldbus connection


8.3 Grounding




The transmitter must be grounded as described below. Otherwise, it may cause electric shocks or incorrect operation.

Grounding terminals are provided at the inside of terminal box and on the side of conduit connection. By any of the methods given below, carry out grounding wiring of class D or better (grounding resistance 100 (or less). In case of intrinsically safe and flameproof installation, be sure to use the ground terminal for grounding.

Grounding of transmitter casing



Grounding from ground terminal



Appendix 1 CALIBRATION

Preparation for calibration

The transmitter should be calibrated in a calibration room. For calibration of each transmitter, the following devices are required.

- Pressure source and pressure measuring equipment (should have as high an accuracy as possible)
 - * Measurable ranges are listed in the table below.
- Link master (FOUNDATION FIELDBUS type)

Measurable range

Differential pressure range of differential pressure transmitter (FDC)

Differential pressure range [kPa] {mbar} <inH ₂ O>
0.1 to 1 {1 to 10} <0.4 to 4>
0.1 to 6 {1 to 60} <0.4 to 24>
0.32 to 32 {3.2 to 320} <1.25 to 12.5>
1.3 to 130 {13 to 1300} <5.2 to 520>
5 to 500 {50 to 5000} <0.7 to 70psi>
30 to 3000 {300 to 30000} <4.3 to 430psi>

Pressure range of pressure transmitter (FDG)

Pressure range [kPa] {bar} <psi>
1.3 to 130 {0.013 to 1.3} <0.2 to 20>
5 to 500 {0.05 to 5} <0.7 to 70>
30 to 3000 {0.3 to 30} <4.3 to 430>
100 to 10000 {1 to 100} <15 to 1500>
500 to 50000 {5 to 500} <70 to 7000>

Pressure range of absolute pressure transmitter (FDA)

Pressure range [kPa abs] {bar•abs} <inHg abs>
1.6 to 16 {0.016 to 0.16} <0.46 to 4.6>
1.6 to 130 {0.16 to 1.3} <0.46 to 38>
5 to 500 {0.05 to 5} <0.7 to 70psi abs>
30 to 3000 {0.3 to 30} <4.3 to 430psi abs>

Differential pressure range of remote seal type differential pressure transmitter (FDD)

Differential pressure range [kPa] {bar} <inH ₂ O>
0.32 to 32 {0.0032 to 0.32} <1.25 to 125>
1.3 to 130 {0.013 to 1.3} <5.2 to 520>
5 to 500 {0.05 to 5} <0.7 to 70psi>

Pressure range of remote seal type pressure transmitter (FDB)

Pressure range [kPa] {bar} <psi>
1.3 to 130 {0.013 to 1.3} <0.2 to 20>
5 to 500 {0.05 to 5} <0.7 to 70>
30 to 3000 {0.3 to 30} <4.3 to 430>
100 to 10000 {1 to 100} <15 to 1500>
500 to 50000 {5 to 500} <70 to 7000>

Differential pressure range of level transmitter (FDE)

Differential pressure range [kPa] {mbar} <inH ₂ O>
0.32 to 32 {3.2 to 320} <1.25 to 125>
1.3 to 130 {13 to 1300} <5.2 to 520>
5 to 500 {50 to 5000} <0.7 to 70psi>

Differential pressure range of remote seal type differential pressure transmitter (FDX)

Differential pressure range [kPa] {mbar} <inH ₂ O>
3 to 130 {30 to 1300} <12 to 520>
12.5 to 500 {125 to 5000} <50 to 2000>

Pressure range of remote seal type pressure transmitter (FDW)

Pressure range [kPa] {bar} <psi>
50 to 3000 {0.5 to 30} <7.2 to 430>
250 to 10000 {2.5 to 100} <37.5 to 1500>

Differential pressure range of level transmitter (FDY)

Differential pressure range [kPa] {mbar} <inH ₂ O>
3 to 130 {30 to 1300} <12 to 520>
12.5 to 500 {125 to 5000} <50 to 2000>

(1) Zero/span adjustment

Refer to “Zero/span adjustment” in Chapter 5.

(2) Accuracy test

Apply input pressures in the order of 0%, 25%, 50%, 75%, 100%, 75%, 50%, 25% and 0%, and read output at each input pressure.

Make sure the difference between each output value and input pressure (%) is within the accuracy rating listed in the table below.

Measurement category	Reference value	Accuracy (example)	
		Accuracy:0.1%	Accuracy:0.2%
Percent display (%)	0, 25, 50, 75, 100	±0.1	±0.20

Appendix 2 PARAMETERS OF BLOCKS

Main parameters are shown below.

Parameter		Setting prior to delivery	Description
Resource block			
MODE BLK (5)	TARGET PERMITTED NORMAL	0x08 (Auto) 0x88 (O/S, Auto) 0x08 (Auto)	Operation mode
FEATURE SEL (18)	———	0x000A	Select a function to support
CYCLE SEL (20)	———	0x0001	Select a scheduling type
DEVICE ID (48)		0003 09 0032 []	Device ID No.
Function block			
MODE BLK (5)	TARGET PERMITTED NORMAL	0x08 (Auto) 0x98 (O/S, Man, Auto) 0x08 (Auto)	Operation mode
XD SCALE (10)	EU100% EU0% UNITS INDEX DECIMAL	(Depends on device)	Set a range based on initial unit
OUT SCALE (11)	EU100% EU0% UNITS INDEX DECIMAL	(As specified)	Output scale
IO OPTS (13)	———	0x0000	0x0400: For setting a low flow cut point
CHANNEL (15)	———	1	Number of hard channel connected to I/O block
L TYPE (16)	———	(As specified)	2: Linear output, 3: Square root output
LOW CUT (17)	———	0	Low flow cut point
PV FTIME (18)	———	0	Damping time constant (sec)

Parameter		Setting prior to delivery	Description
Transducer block			
MODE BLK (5)	TARGET PERMITTED NORMAL	0x08 (Auto) 0x88 (O/S, Auto) 0x08 (Auto)	Operation mode
PRIMARY VALUE TYPE (13)	_____	(As specified)	107 : DP, 108 : GP, 109 : AP 110 : Level
CAL POINT HI (16)	_____	(Depends on device)	Calibration point high level (span adjustment point)
CAL POINT LO (17)	_____	(Depends on device)	Calibration point low level (zero adjustment point)
CAL UNIT (19)	_____		Calibration unit
BURNOUT_SET (31)	_____	(As specified)	0: Stick to high limit 1: Stick to low limit 239: Hold
CAL_DATA (34)	Command	0	129: Zero adjustment 130: Low-level adjustment 132: Span adjustment
LOCAL_KEY (38)	_____	0	0: Enable adjustment 1: Disable adjustment
LCD_COMMAND (40)		0	0: Unused 128: Write parameter 129: Write segment data
LCD_DISP (41)	LCD_UPPER_ DISPLAY_VALUE LCD_LOWER_ DISPLAY_VALUE LDC_DIGIT LCD_UNIT	(As specified)	Display value at URV input Display value at LRV input Number of digits displayed below point Display unit code (FCX-AII unit code)

Appendix 3 UNIT CODES

The following shows typical examples of unit codes determined by the FOUNDATION FIELDBUS. They are used for setting the unit of output scale.

Code	Unit	Code	Unit	Code	Unit
1130	Pa	1342	%	1518	kL/min
1132	MPa	1347	m ³ /S	1519	kL/h
1133	kPa	1348	m ³ /min	1541	Paa
1136	hPa	1349	m ³ /h	1545	MPaa
1137	bar	1351	L/S	1546	MPag
1138	mbar	1352	L/min	1547	kPaa
1139	torr	1353	L/h	1548	kPag
1140	atm	1356	CFS	1557	kg/cm ² a
1141	Psi	1357	CFM	1558	kg/cm ² g
1142	Psia	1358	CFH	1559	inH ₂ Oa
1143	Psig	1362	gaL/S	1560	inH ₂ Og
1145	kg/cm ²	1363	GPM	1565	mmH ₂ Oa
1146	inH ₂ O	1364	gaL/h	1566	mmH ₂ Og
1149	mmH ₂ O	1371	bb ℓ /S	1571	ftH ₂ Oa
1152	ftH ₂ O	1372	bb ℓ /min	1572	ftH ₂ Og
1155	inHg	1373	bb ℓ /h	1577	inHga
1157	mmHg	1450	kgaL/S	1578	inHgg
1322	kg/S	1451	MgaL/S	1581	mmHga
1323	kg/min	1454	kga ℓ /min	1582	mmHgg
1324	kg/h	1455	MgaL/min		
1326	t/S	1458	kga ℓ /h		
1327	t/min	1459	Mga ℓ /h		
1328	t/h	1485	kbb ℓ /min		
1330	ℓ b/S	1486	Mbb ℓ /min		
1331	ℓ b/min	1489	kbb ℓ /h		
1332	ℓ b/h	1490	Mbb ℓ /h		

Appendix 4 HAZARDOUS LOCATION INSTALLATION INFORMATION

This appendix contains documents that present installation instruction for the FCX-AII Series Transmitter in a hazardous location. Refer to the figures or the instruction manual when installing or servicing a transmitter mounted in a hazardous location.

When installed, the apparatus must be provided with a voltage limiting device which will prevent the rated voltage of 32V being exceeded.

INSTALLATION INSTRUCTIONS




Fig. 1 FCX-A II Series Transmitter, Typically FOUNDATION FIELDBUS
 Wiring Diagram for FISCO

EMC CONFORMITY OF FCX-AII

Emission lists:

EN 61326: 1997 Class A (Industrial location)

Frequency range	Limits	Reference standard
30 to 230 MHz	40 dB (μ V/m) quasi peak, measured at 10 m distance	CISPR 16-1 and CISPR 16-2
230 to 1000 MHz	47 dB (μ V/m) quasi peak, measured at 10 m distance	CISPR 16-1 and CISPR 16-2

Immunity requirements:

EN 61326: 1997 Annex A (Industrial location)

Phenomenon	Test value	Basic standard	Performance
Electrostatic discharge	4 kV (Contact) 8 kV (Air)	EN 61000-4-2	B
Electromagnetic field	80 to 1000 MHz 10V/m 80% AM (1kHz)	EN 61000-4-3	A
Rated power frequency magnetic field	30 A/m 50Hz	EN 61000-4-8	A
Burst	2kV 5kHz	EN 61000-4-4	B
Surge	1.2/50 μ s 1kV-line to line 2kV-line to ground	EN 61000-4-5	B
Conducted RF	0.15 to 80 MHz 3V 80% AM (1kHz)	EN 61000-4-6	A

Definition of performance criteria:

A: During testing, normal performance within the specification limits.

B: During testing, temporary degradation, or loss of function or performance which is self-recovering.

Appendix 5 DISPLAY UNIT CODES

Unit	Code
MPa	15532033
kPa	786433
hPa	15859713
Pa	720897
bar	458753
mbar	524289
kg/cm ²	655361
g/cm ²	589825
mmH ₂ O	262145
cmH ₂ O	15925249
mH ₂ O	15728641
inH ₂ O	65537
ftH ₂ O	196609
mmHg	327681
cmHg	16515330
mHg	15794177
inHg	131073
psi	393217
atm	57345
torr	851969
mm	3211265
cm	3145729
m	2949121
in	3080193
ft	2883585
Nm ³ /s	16520194
Nm ³ /min	16520450
Nm ³ /h	7929857
Nm ³ /d	16520706
m ³ /s	1835009
m ³ /min	8585217

Unit	Code
m ³ /h	1245185
m ³ /d	1900545
l/s	1572865
l/min	1114113
l/h	9043969
l/d	16521218
NI/s	16521474
NI/min	16521730
NI/h	7995393
NI/d	16521986
gal/s	1441793
gal/min	1048577
gal/h	15400961
gal/d	15400961
ft ³ /s	1703937
ft ³ /min	983041
ft ³ /h	8519681
ft ³ /d	1769473
bbl/s	8650753
bbl/min	8716289
bbl/h	8781825
bbl/d	8847361
kg/s	4784129
kg/min	4849665
kg/h	4915201
kg/d	4980737
t/s	16520962
t/min	5046273
t/h	5111809
t/d	5177345

Appendix 6 CABLES FOR H1 FIELDBUS

As cables for H1 fieldbus, 4 types given in the table below are defined.

Cable type		Wire diameter	Total extension length
Type A cable	Pair of twisted wires with individual shields	0.8mm ² #18AWG	1900m
Type B cable	Pair of twisted wires with batch shield	0.32mm ² #22AWG	1200m
Type C cable	Pair of twisted wires without shield	0.13mm ² #26AWG	400m
Type D cable	Untwisted wires	1.25mm ² #16AWG	200m

Fuji Electric Systems Co., Ltd.

Head Office

Gate City Ohsaki, East Tower, 11-2, Osaki 1-chome,
Shinagawa-ku, Tokyo 141-0032, Japan
<http://www.fesys.co.jp/eng>

Instrumentation Div.

International Sales Dept.

No.1, Fuji-machi, Hino-city, Tokyo 191-8502, Japan
Phone: 81-42-585-6201, 6202 Fax: 81-42-585-6187
<http://www.fic-net.jp/eng>
