


Assembly Instructions

Self-Piercing Rivet Tool

ERT/LS/LSC



Please read the assembly instructions before any operation!



© Emhart Technologies TUCKER GmbH

Max-Eyth-Straße 1

D-35394 Gießen

Tel.: +49 (0) 641 405 0

Fax.: +49 (0) 641 405-383

E-Mail: Info@tucker.de

Internet: www.tucker.de

Translation of the original assembly instructions MTA ERT LS LSC 01

Table of Contents:

1	General Information.....	5
1.1	Information Regarding the Assembly Instructions.....	5
1.2	Limitation of Liability.....	5
1.3	Symbol Legend	6
1.4	Copyright Protection.....	7
1.5	Replacement Parts.....	7
1.6	Guarantee Instructions.....	8
1.7	After Sales Service.....	8
1.8	Remark to the Declaration of Incorporation	8
2	Safety	9
2.1	Responsibility of the Operating Company	9
2.2	Personnel Requisition	10
2.2.1	Qualification	10
2.2.2	Trespassers	11
2.2.3	Instruction.....	11
2.3	Intended Use.....	12
2.3.1	Self-Piercing Rivet Tool ERT	12
2.3.2	Linear Slide LS.....	13
2.3.3	Linear Slide Control LSC.....	14
2.4	Personal Protective Equipment.....	15
2.5	Special Risks.....	16
2.6	Safety Installations	17
3	Technical Data	18
3.1	General Specifications Rivet Tool ERT 80.....	18
3.2	General Specifications Rivet Tool ERT 40.....	19
3.3	General Specifications Linear Slide	20
3.4	General Specifications Linear Slide Control.....	20
3.5	Equipment Fuses	21
3.6	Accessories.....	21
3.7	Tool List Self-Piercing Rivet Tool	22
3.8	Fastening Torques for Metric Screws	24
3.9	Table of Control Cables/Hoses	24
4	System Components	25
4.1	ERT 80 Tool with Linear Slide.....	25
4.2	ERT 40 Tool with Linear Slide.....	26
4.3	Linear Slide Control.....	28
4.4	Operation Sequence	29
4.4.1	Rivet Spindle Propulsion Concept.....	29

Table of Content

	4.4.2	Assembly Sequence	30
	4.4.3	Tool Changer	36
5		Connecting ERT Tool.....	37
	5.1	Connecting the ERT Tool to the ERC Control Unit.....	38
	5.2	Connecting Rivet Spindle to the Feeder	39
	5.2.1	Connecting Feed Tube to the Rivet Spindle	39
	5.2.2	Connecting Feed Tube to Feeder	40
	5.3	Connecting the Linear Slide Control to the Feeder.....	41
	5.4	Connecting the Linear Slide and the Linear Slide Control	42
	5.5	Compressed Air Supply for the Linear Slide Control	43
	5.6	Setting the Linear Slide Proximity Switch	44
	5.7	Setting Riveting Parameter.....	45
	5.8	Adjustment Travel.....	46
6		Transport, Packaging and Storing	47
	6.1	Security Advice for the Transport	47
	6.2	Transport Check	47
	6.3	Terms and Conditions for Overseas Transport.....	48
	6.4	Packaging	49
	6.5	Storing	49
7		Maintenance and Cleaning	50
	7.1	Safety.....	50
	7.2	Maintenance and Cleaning Schedule	50
	7.3	Emptying the Maintenance Unit.....	55
	7.4	Lubricating the ERT 80 Riveting Spindle	55
	7.5	Lubricating the ERT 40 Riveting Spindle	56
	7.5.1	Lubricating Sequence ERT	57
	7.6	Lubricating the Linear Slide	58
	7.7	Cleaning the Receiver and Upper Riveting Die	59
	7.8	Changing the Upper Riveting Die	59
8		Disposal	61

Appendix: Declaration of Incorporation

1 General Information

1.1 Information Regarding the Assembly Instructions

These assembly instructions contain important information regarding the handling of this device. The compliance with all security advisories and operation instructions is a precondition for a safe operation.

Furthermore the local accident prevention regulations and the general safety regulations effective for the application area of the device have to be observed.

Please read the assembly instructions carefully before any operation! It is a part of the product and has to be stored in an accessible location in the direct vicinity of the device for use by the appropriate personnel.

1.2 Limitation of Liability

All instructions and information in these assembly instructions have been compiled in consideration of the valid standards and regulations, the state of the art as well as our experience of many years.

The manufacturer assumes no liability for damages due to:

- Non-observance of the assembly instructions.
- Not intended use.
- Employment of unskilled personnel.
- Arbitrary rebuilding.
- Technical modifications.
- Use of non-licensed replacement parts.

On special design, on demands of additional order options or due to latest technical modifications the actual shipment may differ from the explanations and expositions described here.

Effective are the obligations agreed in the supply contract, the general terms and conditions as well as the delivery conditions of the supplier and the legal regulations valid to the time of conclusion of the contract.

Technical modifications within the improvement of the usage properties and the further development are reserved.

General Information**1.3 Symbol Legend****Warning notices**

The warning notices in this operation manual are indicated by symbols. The notes commence with a signal word which expresses the extent of the danger.

Observe the notes and act with caution to avoid accidents and damage to persons and property.

**DANGER!**

... points to a directly dangerous situation which can lead to death or severe injuries if it is not avoided.

**WARNING!**

... points to a possibly dangerous situation which can lead to death or severe injuries if it is not avoided.

**CAUTION!**

... points to a possibly dangerous situation which can lead to slight injuries if it is not avoided.

**CAUTION!**

... points to a possibly dangerous situation which can lead to damage of property if it is not avoided.

Tips and recommendations**NOTE!**

... highlights useful tips and recommendations as well as information for an efficient and failure-free operation.

Special security advisories

In order to draw attention to special dangers, the following symbols are used in connection with security advisories:



DANGER!

Danger to life by electric current!

... indicates perilous situations by electric current. Disregarding of the security advisories can lead to severe injuries or death.

The operations which need to be carried out may only be executed by electronic technicians.



WARNING! RISK OF HAND INJURY!

Keep hands away from areas marked with this warning sign. There is a risk that hands could be squeezed, pulled in or injured otherwise.

1.4 Copyright Protection

This instruction is protected by copyright and only intended for internal purposes.

The provision of the instruction to a third party, duplications in all kinds and forms - also in extracts - as well as the utilisation and/or communication of the content are, aside from internal purposes, not permitted without a written authorization of the manufacturer.

Non-compliances obligate to damages. Further claims remain reserved.

1.5 Replacement Parts



WARNING!

Safety risk due to false replacement parts!

False or defective replacement parts can affect the safety as well as lead to damages, malfunctions or total breakdown.

Therefore:

- Use original TUCKER replacement parts.

Purchase replacement parts via licensed dealer or directly at manufacturer. Address see page 2.

General Information**1.6 Guarantee Instructions**

For material and manufacturing faults, the guarantee period for this self-piercing riveting tool amounts to 1 year from delivery date on. Excluded from this is damage that is caused by accident or by incorrect handling.

The guarantee covers free-of-charge replacement of the faulty component. In this connection, liability for consequential damage is excluded.

Guarantee void in case of attempts to repair by personnel that has not been trained by the manufacturer and/or when using spare parts that TUCKER has not approved of. In the event of a defect the non-conforming appliance must be sent to the next TUCKER agent or directly to the manufacturer.

The guarantee claim lapses when attempts at repair are carried out by unauthorised or unqualified persons. In the event of a defect the non-conforming appliance must be sent to the next TUCKER agent or directly to the manufacturer. For further information concerning national representation, our customer service is at your disposal. The corresponding contact data can be found on page 2.

1.7 After Sales Service

Our service department is available for technical support.

Information about the responsible contact person is available via telephone, fax, E-Mail or anytime via the Internet, please see manufacturer address on page 2.

Furthermore, our employees are constantly interested in new information and experiences that result from the single applications and could be helpful for improving our products.

1.8 Remark to the Declaration of Incorporation**Note!**

A declaration of incorporation for the inc of an incomplete machine with the corresponding details according to the EC machinery directive 2006/42/EG, appendix II, paragraph B is attached to the documents.

2 Safety

This paragraph gives a review about all important safety aspects for an optimal protect of the personnel as well as for the safe and failure-free operation.

Disregard of the operating instructions and security advices mentioned in this manual could lead to serious dangers.

2.1 Responsibility of the Operating Company

The stud feeding unit is used industrially. Therefore the operating company of the unit is liable to the legal obligations of operational safety.

In addition to the operational safety advisories in these assembly instructions the safety-, accident prevention- and environmental regulations in force for the area of application need to be observed.

Please consider particularly the following:

- The operating company has to inform himself about the valid industrial safety regulations and determine additional dangers in an assessment of hazards which occur by the special working conditions on the site of the unit. He has to implement these for the operation of the unit in the form of operating instructions.
- The operating company has to verify that the operating instructions are state of the art during the complete operating time of the unit. If necessary, the operating company is to adjust the operating instructions to the valid rules and regulations.
- The operating company has to manage and determine the responsibilities for installation, operation, maintenance and cleaning in an explicit manner.
- The operating company has to ensure that all employees dealing with the unit have read and understood this manual. Moreover, the operating company has to train the operating personnel in regular intervals and has to provide information on possible dangers.
- The operating company has to provide the personnel with the required protective equipment.

2.2 Personnel Requisition

2.2.1 Qualification

**WARNING!****Risk of injury on insufficient qualification!**

Improper handling can lead to serious damage to persons and property.

Therefore:

- All activities are to be carried out by skilled personnel only!

The following qualifications for different areas of operations are named in the assembly instructions:

- **Instructed person**

Has been informed about the tasks assigned and possible dangers of improper execution of an instruction by the operating company.

- **Qualified personnel**

Qualified personnel are able to carry out the assigned tasks due to their qualified training, knowledge and job experience. In addition, the personnel are able to recognize and avoid possible dangers on their own.

- **Electrician**

The electrician is able to carry out activities on electric units due to his qualified training, knowledge and job experience. In addition, he is able to recognize and avoid possible dangers on his own.

The electrician has been trained for the special site he is working on and knows about the relevant rules and regulations.

Only persons who can be expected to carry out their work in a reliable manner can be accepted as personnel. Persons whose reactivity is influenced, e.g. by drugs, alcohol or medicaments, are not admitted.

- Please consider the regulations at site specific to age and profession when choosing personnel!

2.2.2 Trespassers



WARNING!

Danger for trespassers!

Trespassers who do not fulfil the requirements mentioned in this document do not know about the dangers of this working area.

Therefore:

- Keep trespassers away from the working area.
- When in doubt, approach persons and banish them from the working area.
- Interrupt your work as long as there are trespassers within the working area.

2.2.3 Instruction

The personnel have to be instructed regularly by the operating company. For a better traceability the implementation of the instruction should be recorded.

Date	Name	Kind of instruction	Instruction carried out by	Signature

2.3 Intended Use

2.3.1 Self-Piercing Rivet Tool ERT

The Self-Piercing Rivet Tool ERT was designed exclusively for the intended use mentioned in this manual.

The ERT Tool is intended to mount self-piercing rivets in industrial and commercial areas and only for application in premises. The ERT tool has been designed for automatic operation in robots, semiautomatic operation and manual operation.

Intended use also includes observing all the symbols and information in the assembly instructions.

Any excess of the intended use or different use of the device is considered as misuse and can lead to dangerous situations.



WARNING!

Risk by not intended use!

Every not intended use and/or different use can lead to dangerous situations.

Therefore:

- The ERT tool may only in conjunction with the system components specified in the assembly instructions.
- Do not operate the ERT tool in explosive areas.
- Do not operate the ERT tool in damp rooms.

Claims of any kind because of damages due to not intended use are excluded.

2.3.2 Linear Slide LS

The linear slide LS was designed exclusively for the intended use mentioned in this manual.

The linear slide is intended to mount self-piercing rivets in industrial and commercial areas and only for application in premises. The linear slide can only operate in conjunction with a linear slide control. The linear slide has been designed for automatic operation in robots, semiautomatic operation and manual operation.

Intended use also includes observing all the symbols and information in the assembly instructions.

Any excess of the intended use or different use of the device is considered as misuse and can lead to dangerous situations.



WARNING!

Risk by not intended use!

Every not intended use and/or different use can lead to dangerous situations.

Therefore:

- The linear slide may only in conjunction with the system components specified in the assembly instructions.
- Do not operate the linear slide in explosive areas.
- Do not operate the linear slide in damp rooms.

Claims of any kind because of damages due to not intended use are excluded.

2.3.3 Linear Slide Control LSC

The linear slide control LSC was designed exclusively for the intended use mentioned in this manual.

The linear slide control is intended to mount self-piercing rivets in industrial and commercial areas and only for application in premises. The linear slide control can only operate in conjunction with a linear slide. The linear slide control has been designed for automatic operation in robots, semiautomatic operation and manual operation.

Intended use also includes observing all the symbols and information in the assembly instructions.

Any excess of the intended use or different use of the device is considered as misuse and can lead to dangerous situations.

**WARNING!****Risk by not intended use!**

Every not intended use and/or different use can lead to dangerous situations.

Therefore:

- The linear slide control may only in conjunction with the system components specified in the assembly instructions.
- Do not operate the linear slide control in explosive areas.
- Do not operate the linear slide control in damp rooms.

Claims of any kind because of damages due to not intended use are excluded

2.4 Personal Protective Equipment

At work wearing personal protective equipment is essential to minimize the risks for the health.

- During working time always wear the required protective equipment for the respective work.
- Observe the signs regarding the personal protective equipment which exist in the working area.

Strictly to wear

Strictly to wear at working:



Protective glasses

For the protection of the eyes from foreign bodies.



Protective clothing

is close-fitting work wear with low tear strength, with tight-fitting sleeves and without flared parts. It is principally used to protect against capture by moving machinery parts. Do not wear rings, necklaces and other jewellery.



Safety boots

For the protection from heavy, falling parts and from slipping on slippery surfaces.

Wear on special work



Protective gloves

For the protection of the hands against friction, abrasives, stabbing or deeper injuries as well as for the protection against contact with hot surfaces.

2.5 Special Risks

The residual risks which arise from the hazard analysis are described in the following chapter.

Please consider the below mentioned security advices and warnings in the following chapters of this manual to reduce health hazards and to avoid dangerous situations.

Electric current



DANGER!

Danger of life by electric current!

Contact with components under current is perilous. Damage of the electrical isolation or of several components can be perilous.

Therefore:

- On damages of the electrical isolation cut-off immediately the power supply and induce repairing.
- Work on the electric installation may only be executed by qualified electricians/electronic technicians.
- Do not connect or disconnect the live plug connector.
- For maintenance work and repair operations disconnect the ERT tool from the power supply.
- Pay attention to the minimum bending radius of the electrical connecting cables.
- First, connect the ERT tool in an orderly fashion before you link the tool with the control unit and the other system components.
- Never reach into open, non-utilised sockets.

Moved components



WARNING!

Risk of injury by moved components!

Rotating and/or linearly moved components could cause severe injuries. Therefore:

- Do not grasp in or handle on moved components while operation.
- No not open the coverings while operation.
- Never invalidate the electrical, mechanical and pneumatic protective devices.
- Consider the follow-up time.

Before opening the covers ensure that parts do not move anymore.

Pneumatic



WARNING!

Risk of injury by pneumatic energy!

Pneumatic energies could cause severe injuries.

Pneumatically driven parts could move unexpectedly.

On damages of several components air can discharge under high pressure and damage e.g. the eyes.

Therefore:

- Wear protective glasses when working on the ERT tool.
- Use only clean and oil-free air.
- Pay attention to the minimum bending radius of the pneumatically connecting cables.
- When repairing at location of operation the ERT tool must be cut off from compressed-air supply.
- Check all pneumatic lines and the feeding tube for intactness before commissioning.
- In all cases any kind of maintenance and adjustments must be agreed on with the operating personnel.
- Do not reach into the danger zone of the ERT tool.

2.6 Safety Installations

The Self-Piercing Rivet Tool ERT is intended for the application within an installation. The self-piercing rivet tool is to be integrated into the safety concept of the self-piercing rivet installation.

Technical Data

3 Technical Data

3.1 General Specifications Rivet Tool ERT 80

	Specification	Value	Unit
	Weight	approx. 41	kg
	Length	approx. 377	mm
	Width	approx. 130	mm
	Height	approx. 823	mm
	max. riveting force	80	KN
	To define the riveting force for special applications, please contact Tucker GmbH.		
Max. opening stroke	Length nose piece 10 mm	198	mm
	Length nose piece 30 mm	178	mm
	Length nose piece 50 mm	158	mm
Maximum on-time at 40° ambient air temperature	Max. opening stroke	60	%
	Opening stroke 20 mm	40	%
C-Frame adaption	Diameter	70	mm
	Height	75	mm
	Width	308/358/408	mm
	System of protection: Protected against dust penetration	IP 54 according IEC529	Protected against drizzle
	Working position	Indefinite	
	Operating temperature	15 - 40	°C
	Stocking temperature	-10 - 55	°C
	Relative humidity of air, not condensing	5 - 95	%
Noise emission	Sound pressure level	< 75	dB (A)
Electromagnetic compatibility	The Self-Piercing Rivet Tool has been tested following the norms which are indicated under chapter 1.8.		

	Specification	
Electrical	Control voltage	Provided in ERC control unit

3.2 General Specifications Rivet Tool ERT 40

	Specification	Value	Unit
	Weight	approx. 25	kg
	Length	approx. 345	mm
	Width	approx. 120	mm
	Height	approx. 594	mm
	max. riveting force	40	KN
	To define the riveting force for special applications, please contact TUCKER GmbH		
Max. opening stroke	Length nose piece 10 mm	98	mm
	Length nose piece 30 mm	78	mm
	Length nose piece 50 mm	58	mm
Maximum on-time at 40° ambient air temperature	Max. opening stroke	60	%
	Opening stroke 20 mm	40	%
C-Frame adaption	Diameter	70	mm
	Height	75	mm
	Width	208/258/308	mm
	System of protection: Protected against dust penetration	IP 54 according IEC529	Protected against drizzle
	Working position	Indefinite	
	Operating temperature	15 - 40	°C
	Stocking temperature	-10 - 55	°C
	Relative humidity of air, not condensing	5 to 95	%
Noise emission	Sound pressure level	< 75	dB (A)
Electromagnetic compatibility	The Self-Piercing Rivet Tool has been tested following the norms which are indicated under chapter 1.8.		

	Specification	
Electrical	Control voltage	Provided in ERC control unit

Technical Data

3.3 General Specifications Linear Slide

	Specification	Value	Unit
LS 105	Weight	approx. 15	kg
LS 400	Weight	approx. 17	kg
LS 600	Weight	approx. 21	kg
	Opening stroke	18,5	mm
	max. opening stroke (optional)	48,5	mm
	System of protection: Protected against dust penetration	IP 54 according IEC529	Protected against drizzle
	Working position	Indefinite	
	Operating temperature	15 - 40	°C
	Stocking temperature	-25 - 55	°C
	Relative humidity of air, not condensing	5 - 95	%
Compressed-air supply			
from LSC	Operating pressure	4 to 10	Bar

3.4 General Specifications Linear Slide Control

	Specification	Value	Unit
	Weight	approx. 7,5	kg
	Length	approx. 373	mm
	Width	approx. 273	mm
	Height	approx. 200	mm
	System of protection: Protected against dust penetration	IP 54 according IEC529	Protected against drizzle
	Working position	Indefinite	
	Operating temperature	15 - 40	°C
	Stocking temperature	-25 - 55	°C
	Relative humidity of air, not condensing	5 - 95	%
Electrical	Control voltage	Provided in ERC control unit	
Compressed-air supply	Operating pressure	4 to 10	Bar
	Manually regulated by the maintenance unit		

3.5 Equipment Fuses




DANGER!

Opening the control cabinet as well as the replacement of the fuses inside the equipment is to be carried out by qualified personnel only!

Fuse elements in the linear slide control

Fuse	Protection by fuses	UNOM	INOM	Version
F 1	Linear slide	250V, 5x20mm	2,0A	semi time lag



NOTE!

Defective fuse elements are always to be replaced by the same design of fuses with identical nominal values!

3.6 Accessories

Rivet tool	Specification	Type	Order number
Grease	Lubricating grease 1 Kg	Klüberplex BEM 34-132	M081 506
Linear slide			
Grease	Lubricating grease 400 cm3	AFB	M081 504
	Greasing pump	500 cm3	M081 551

Technical Data

3.7 Tool List Self-Piercing Rivet Tool

Tool	Fastening torque	Application / Assembly	Order number	ERT
Torque wrench with sickle spanner D60-90	200 Nm*1 +7°	Self-piercing rivet tool in C-frame	M114 002	40/80
Sickle spanner with 4 grooves for head piece D90	200 Nm*1 +7°	Self-piercing rivet tool in C-frame	M214 368	40/80
Torque wrench with sickle spanner D40-42	50 Nm*1	Slotted round nut for clamping guide bushing	M114 003	40/80
Torque wrench with open-end wrench SW14	30 Nm*1	Swivel nut for riveting punch	M114 004	40/80
Torque wrench	70 Nm	Head piece in sleeve	M114 009	40/80
Grooved plate		Force measurement holding down force	M210 432	40/80
Reference sheet metal H=4 mm		Adjustment drive	M210 627	40/80
Key D=8 mm	30 Nm*1	Riveting punch	M210 467	40/80
Sickle spanner with clamping ring D40-42		Slotted round nut for clamping guide bushing	M110 105	40/80
Sickle spanner with front piece D60-90		Self-piercing rivet tool in C-frame	M110 109	40/80
Sickle spanner with dowel D34-36/4		Swivel nut-fastening rod	M110 114	40/80
Inner pliers for retaining rings J4		Retaining ring in PRG module	M110 851	80
Inner pliers for retaining rings J1		Retaining ring in PRG module	M110 852	40
Pliers for retaining rings A1		Retaining ring in PRG module	M110 853	40
Pin type face wrench D80-125/6		PRG front module	M110 113	80
Pin type face wrench D40-180/5		Locating ring housing PRG module		40

*1 Values are only effective on using the TUCKER special tools.

Tool list self-piercing rivet tool

Tool	Fastening torque	Application / Assembly	Order number	ERT
Drive-out ring		Deep groove ball bearing PRG module	M110 960	40
Mounting device PRG Module support		Fixing of the rivet tool on maintenance work	Z217 046	80
Mounting tool holding down spring		Pre-load the holding down spring fastening rod	Z217 047	40/80
Adapter L=80		Pre-load the holding down spring fastening rod	M214 429	40
Abrasive web		Remove the material deposits	M145 018	40/80
Grease press 500 cm ³		Grease PRG	M081 552	40
Support for hand file			M110 877	40/80
Hand file for ceramic fiber		Remove the material deposits	M110 876	40/80

3.8 Fastening Torques for Metric Screws

Values according VDI 2230 under utilization of the minimum yield stress of 75%

Metric screws	Fastening torques		
	Thread size	Property class 8.8	Property class 10.9
	M3	1,1 Nm	1,65 Nm
	M4	2,5 Nm	3,65 Nm
	M5	4,9 Nm	7,25 Nm
	M6	8,3 Nm	12,50 Nm
	M8	20,8 Nm	30,00 Nm
	M10	40,8 Nm	60,00 Nm

3.9 Table of Control Cables/Hoses


Components	Maximum length	Minimum bending radius	Diameter
Control cable ERC-rivet tool	approx. 20 m	160 mm	Ø 13+16 mm
Control cable ERF-linear slide control	approx. 15 m	150 mm	Ø 15 mm
Control cable ERC-ERF	approx. 15 m	150 mm	Ø 11 mm
Cable package LSC-LS	approx. 6 m	150 mm	Ø 20 mm
Feeding tube	approx. 15 m *	250 mm	Ø 27 mm


* Complete length of all feeding tubes between feeder and rivet spindle

4 System Components

In this chapter you will receive an overview concerning the system components “pressing (punching) and ERT tool with linear slides” and “linear slide control”. Here you will find information on the connections and the control elements. Familiarise yourself with the system components before installation.

4.1 ERT 80 Tool with Linear Slide




System Components**4.2 ERT 40 Tool with Linear Slide**

- 1 Die-plate:** The die assures that the rivet is properly stamped in the application.
- 2 Receiver:** The receiver constitutes the transition from feeder cable in the spindle. The rivet is held in the right position before assembly.

- 3 **Rivet spindle:** The rivets are pressed into the work piece by means of the rivet spindle.
- 4 **Connection ERC control unit:** The control unit are connected to the ERT tool by means with the motor cable and plug denoted "X1".
- 5 **Connection ERC control unit:** The control unit are connected to the ERT tool by means with the control cable and plug denoted "X3".
- 6 **Cable package:** The cable package serves for transmission of the control signal and the compressed air from the linear slide control to the linear slide.
- 7 **Robot adapter plate:** Connecting ERT tool on tool changer.
- 8 **Linear slide:** The linear slide moves the pressing (punching) and riveting tool with a defined force against the components, and compensates the tolerances in the appliances.
- 9 **Adapter plate:** Connecting C-Frame with the linear slide.
- 10 **C-Frame:** The C-frame absorbs the forces, which are created during riveting.

System Components

4.3 Linear Slide Control



- | | |
|---------------------------------------|---------------------------------------|
| 1. Input pressure manometer | 7. Compressed-air connection 6/10 bar |
| 2. Supply voltage LED | 8. Maintenance unit |
| 3. Type plate | 9. Connection X1 control unit |
| 4. Linear slide connection | 10. Connection pre-selection * |
| 5. Output pressure Manometer | 11. Fastening for pre-selection * |
| 6. LED Linear slide in basic position | |

* See assembly instructions feeding units.

4.4 Operation Sequence

4.4.1 Rivet Spindle Propulsion Concept

The propulsion of the rivet spindle is effected by means of a speed-controlled servomotor. The position of the motor is realised by means of a resolver flanged to the motor shaft.

The driven gear of the spur gear unit propels the planetary thread-rolling drive. In the planetary thread-rolling drive the rotation of the nut is converted into a linear movement of the spindle.

The sliding blocks run into two bearings in the housing and prevent the rotation of the spindle. The receiver rod and the riveting die mounted in the receiver rod are propelled by the spindle. The riveting die presses the rivet into the components.

The receiver is firmly connected to the sleeve which moves out of the housing. Before the assembly the rivet is kept in correct positional arrangement in the receiver. Before the rivet contacts the component the compact spring generates a holding down force which affects the components during the procedure of setting rivets via the nosepiece of the receiver.

The position of the sleeve is detected by a position measuring system which is mounted at the sleeve.

Motor rivet tool




WARNING!

Risk of injury due to heat!

In continuous operation the motor of the self-piercing rivet tool can reach a temperature of approx. 120° C.

Therefore:

- Do not touch the motor of the self-piercing rivet during operation.

System Components**4.4.2 Assembly Sequence**

From the programmable basic setting (home position), the rivet spindle moves forward in the direction of the die (1). The flanged riveting die (3) and the receiver (4) on the receiver rod (2) are traversed. The movement of the receiver (4) is measured via a path-Measuring system (6). This parallel motion is effected until the receiver (4) strikes the component (7) with the nose piece (5).

Receiver (4) on
component







Plate thickness
with F 4KN




As soon as the nose piece (5) strikes the component (8), the motion of the receiver (4) is stopped. Now only the receiver rod (2) is moved with the riveting die (3). The riveting die (3) pushes the rivet through the leg of the receiver (4) into the spring sleeves (9). The coil spring (10) beneath the compact spring (11) is compressed. No appreciable power increase in the system is able to be detected through the marginal spring rate of this spring. As soon as the sleeve bearing support (12) strikes the header (13), the initial tension of the compact spring (11) takes effect on the receiver (4) and the nose piece (5). The plate-thickness measurement of the component (7) is effected at this point. The actual meter reading of the path measuring system (6) is compared with the meter reading of the path measuring system (6) after the adjustment run. The differential evaluation yields the measured plate thickness. A defective plate thickness leads to an interruption of the riveting.


System ComponentsPlate thickness
with F 4KNMeasurement of
rivet length

The forward drive of the riveting die (3) in the direction of the die (1) causes an increase in the force of the compact spring (11), and thus a clamping force increase of the nose piece (5). The rivet length is measured when the rivet strikes the component (7) and the force in the rivet spindle increases to the rivet length measuring strength. It is evaluated with regard to how far the riveting die is located behind the nose piece (5). This value corresponds to the measured rivet length. A defective rivet length also leads to an interruption of the riveting.


Measurement of rivet length



Rivet pressed into component




As soon as the rivet length measurement has been executed, the rivet is pressed into the component (7). A distance-force curve is recorded during the impression. This curve is compared with the recorded rivet curve. If the rivet curve is within the defined tolerance range (sleeve curve), the riveting is in order. A deviation from the sleeve curve means that the riveting is not in order, and the system displays a disturbance after the riveting. In both cases, the rivet is completely impressed into the plate.


System Components

After the riveting the riveting die (3) recedes into the receiver (4). The clamping force of the receiver (4) is diminished until the sleeve bearing support (12) is no longer pressed against the header (13). The clamping force is reduced to the force of the coil spring (10). The riveting die (3) moves within the receiver (4) into the position in which the next rivet can be fed. The next feeding cycle begins at this point.


Riveting die
backward



Basic position/
Home position



If the riveting die (3) is located in the rear position within the receiver (4), the riveting die (3) and the receiver (4) recede together. The motion ends at the programmed basic setting (home position).

System Components**4.4.3 Tool Changer**

- Mount the ERT tool with the designated adapter plate (4) precise on the tool changer (1).
- Then retighten the screw (2).
- Secure the fixing screw (2) by tightening the counter nut (3).

**NOTE!**

The quick change system can be optionally replaced by customer-specific solutions.

Also pay attention to the information in the service manual!

5 Connecting ERT Tool

Do not start up the ERT tool until all system components are installed completely and orderly and linked with each other.



CAUTION!

Only connect the self-piercing rive tool with the ERC control unit switched off. Clearly label the control unit against unexpected restart.

In this chapter at hand it is described how you connect the ERT tool to the linear slide control. You will find the details regarding connection of individual system components among one another in the assembly instructions for each of the system components.

First, assemble all mechanical devices in accordance with the respective assembly instructions before connect the electrical and pneumatic supply lines.

Check whether all system components are in good condition, and then place the system components in such a manner that all connections are accessible without danger.

These possibilities are dealt with in the following chapter.



CAUTION!


Always consult Tucker when the ERT tool is to be installed in an already existing system as well as when connecting foreign appliances.

Connecting ERT Tool

5.1 Connecting the ERT Tool to the ERC Control Unit

The complete supply voltage and transmission of all measuring signals from the ERT tool to the ERC control unit are ensured by these two cables.

The connections for the electrical cables to the ERT tool are labelled with the designation X1 and X3. The connections for the electrical cables to the control unit are located inside the control cabinet and are labelled with the designation X6.1 and X7.1.



For connection observe the following sequence:

- The control unit must be switched off at the main switch.
- Connect one end of the electrical control cable to connection “X3” on the ERT tool. Connect the other end to the connection to plug “X7.1” on the ERC control unit.
- Connect one end of the motor cable to connection “X1” on the ERT tool. Connect the other end to the connection to plug “X6.1” on the ERC control unit




NOTE!

Details über Steuerleitungen und Schläuche siehe Kapitel Technische Daten

5.2 Connecting Rivet Spindle to the Feeder

A feed tube with quick-action lock connects the ERF feeder and the rivet spindle. The rivet spindle is supplied with rivets by means of the feed tube.

5.2.1 Connecting Feed Tube to the Rivet Spindle




For connection observe the following sequence:

- Press an Allen key (size 3 mm) into the connection of the receiver (1).
- Loosen the connection on the feeder by pressing and a half-turn to the left (2).
- The feed tube must be inserted safely and correctly in the connector of the receiver.
- Turn the Allen key a half-turn to the right to connect the feed tube to receiver.
- Now connect the connector of the feed tube sensor with the socket at the spindle.



NOTE!

Details about control cables and hoses see chapter Technical Data

Connecting ERT Tool**5.2.2 Connecting Feed Tube to Feeder**

For connection observe the following sequence:


- Press an Allen key (size 3 mm) into the connection of the coupling plate (1).
- Loosen the connection on the feeder by pressing and a half-turn to the left (2).
- The feed tube must be inserted safely and correctly in the connector of the coupling plate.
- Turn the Allen key a half-turn to the right to connect the feed tube to feeder.
- Now connect the connector of the feed tube sensor with the socket at the feeder.

**NOTE!**

Details about control cables and hoses see chapter Technical Data

5.3 Connecting the Linear Slide Control to the Feeder

The signal transmission to the linear slide control will be realised via the feeder in automatically functioning assembly operation. The plug "X5" Interface is to be found on the feeder back side.



For connecting observe the following sequence:

- The control unit must be switched off at the main switch.
- Connect one end of the electrical control cable to connection "X1" on the LSC linear slide control. Connect the other end to the connection to plug "X5" on the ERF feeder.



NOTE!

Details about control cables and hoses see chapter Technical Data

Connecting ERT Tool

5.4 Connecting the Linear Slide and the Linear Slide Control

The linear slide control (LSC) controls the movements of the linear slide (LS). Both are linked by means of a cable package.




WARNING! RISK OF HAND INJURIES!

Danger of crushing! The linear slide can move while being transported or connected.

Therefore: Do not reach into the danger zone!

The linear slide control must be mounted as close as possible to the linear slide so as to keep pneumatic transmission paths and the response times of the linear slide as short as possible.

The connection to the linear slide is made by means of a cable package at plug "X3" on the linear slide control. The tubes are marked with numbers so as to avoid any confusion.



For connecting observe the following sequence:

- The control unit must be switched off at the main switch.
- Connect one end of the cable package to connection "X3" on the linear slide control. Connect the other end to the linear slide.




NOTE!

Details about control cables and hoses see chapter Technical Data

5.5 Compressed Air Supply for the Linear Slide Control

The LSC linear slide control must be supplied with compressed air (6 bar). The LSC can also be operated with 10 bar of compressed air. Quicker reaction times are obtainable as a result.



The pneumatic connection between the maintenance unit (1) of the LCS and the compressed-air pipe system is a customer-specific design.

The connection of the compressed air pipe (at least Ø10mm) to the maintenance unit of the linear slide control LSC is effected by means of a 1/4"-threaded adapter.



NOTE!

In order to avoid having to switch off the entire compressed-air supply on the mains side when replacing the linear slide control, we recommend the use of a G 1/4" adapter with a self-sealing quick-fit connector system!

5.6 Setting the Linear Slide Proximity Switch

The linear slide proximity switch serves to detect the basic position of the linear slide. In the basic position the robot can travel to the next riveting point.

This setting has already been effected in the factory and should only be altered in consultation with the manufacturer. Adjustments at the location of operation are only to be performed by authorized personnel!

- Only set the linear slide proximity switch when the basic position of the linear slide has been reached, i.e. the LS linear slide has moved against the limit stop with its maximum pressure.




WARNING! RISK OF HAND INJURY!

Danger of crushing! The linear slide can move by connecting of the compressed air or other adjustable operations
Therefore: Do not reach into the danger zone!

Observe the following sequence, if the linear slide is not in basic position:

- Impinge the cylinder of the linear slide on the piston side with 6 bar at connection 1.1. The linear slide moves into the basic position.



- Loosen the clamping screws on the linear slide proximity switch.
- Move the linear slide proximity switch until it is touching the angle of the linear slide.
- Push the linear slide proximity switch until the LED on the linear slide proximity switch lights up.
- Tighten the clamping screws.

The basic position of the linear slide can now be detected.

5.7 Setting Riveting Parameter

See the programming manual “Operating terminal” for setting the riveting parameter.

Connecting ERT Tool

5.8 Adjustment Travel


You have to perform an adjustment travel after the following work:

- Mechanical works on the rivet tool, which influences the length of the receiver or of the upper die.
- After changing the rivet tool, the upper-die or the sensor cover
- After replacing the receivers or the die-plate.


Adjustment travel also has to be performed after the self-piercing riveting system has been put together.

Proceed as follows:

- Ensure that there is no rivet in the receiver.



close



open

- Remove the receiver from the rivet spindle by opening the quick-action lock by means of pressing and a half-turn to the left and then pull the receiver downwards off the tool. Press the rivet out of the receiver by hand, if necessary.
- Mount the receiver onto the tool and close the quick-action lock by pressing and a half-turn to the right.
- Actuate the soft key "Adjustment". A warning appears that as of now no rivet may be in the receptacle any longer, as otherwise faulty adjustment would take place.

(see operating manual "Control terminal" too)

- Place the reference plate supplied onto the die-plate.
- Press the soft key "Enter" to acknowledge the message.

Adjustment travel is performed. The control now calibrates its plate thickness measurement with the aid of the reference plate. The nose piece and the upper die are be adjusted in a position of equal height.

When switched on again you need not carry out any adjustment because the reference values gained are saved on a permanent basis.

6 Transport, Packaging and Storing



NOTE!

The installation and initial operation is effected exclusively by personnel or by authorized persons of the manufacturer. However, it may happen that in line with the installation and the further use operators or maintenance personnel of the operating company are consigned with the handling of packages. In this case regard the following notes.

6.1 Security Advice for the Transport

Improper transport



CAUTION!

Damages caused by improper transportation.

Improper transport could cause serious damage of property. Therefore.

- Transport and lifting operations are to be carried out exclusively using the crane eyes designed for this purpose.
- If no crane eyes are provided due to space considerations, transport the riveting tool with extreme care, without damaging the riveting tool.

6.2 Transport Check

Upon delivery, the equipment, including accessories, should be checked for completeness and damage.

On externally visible transport damage, proceed as follows:

- Do not accept the delivery or only accept with reservation.
- Note the extent of damage on the transport documents or on the delivery note of the deliverer.
- Induce complaint.



NOTE!

Complain each defect as soon as recognized. Claims for damages can only be asserted within the effective time for complaints.

6.3 Terms and Conditions for Overseas Transport


NOTE!

For onward transportation overseas use sea freight transport crate with the corresponding number of desiccant pouches for packing according to DIN 55473! The manufacturer bears no liability for damages caused by improper onward transportation.

The number of desiccant pouches depends on the size of the transport crate. Make sure that sufficient desiccant pouches are added to the transport crate.

Observe the humidity indicator of the desiccant pouch acc. to DIN 55473.


NOTE!

The desiccant pouch activity disintegration wrapping may only be removed directly before use. After removals from the packaging immediately seal tightly again.

- Pack the unit being shipped in a plastic shrink wrapping and weld.
- Place the device welded into the plastic into the transport crate and add sufficient desiccant pouches.
- Close transport crate.

Transport crate	Number of desiccant pouches
HZK 1, 2, 3, 4, 5, 6	6
HZK 7	4
HZK 8, 9, 10, 11	6
HZK 12, 13, 14	4

6.4 Packaging

The respective packaging pieces are packed according to the transport conditions to expect. Exclusively non-polluting materials were used for packaging. The packaging shall protect the respective components against transport damages, corrosion and other damages until assembly. Therefore do not destroy the packaging and remove just shortly before assembly.

Packaging materials handling Dispose packaging material according to the respectively valid legal regulations and local directives.



CAUTION!

Damage caused to the environment due to wrong disposal!

Packaging materials are valuable raw materials and can be further used in a lot of cases or can be prepared reasonably and recycled.

Therefore:

- Dispose packaging materials environmentally friendly.
- Regard the locally effective regulations for waste disposal. Charge a specialist with the disposal if applicable.

6.5 Storing

Storing of the packaging pieces

Store the packaging pieces under the following conditions:

- Do not store out of doors.
- Store dry and dust-free.
- Protect against insolation.
- Avoid mechanical vibrations.
- Stocking temperature: -25 to +55 °C.
- Relative humidity of air (not condensing): 5 to 95 %.
- On storage longer than 3 months the general condition of all parts and the packaging has to be checked regularly. Refresh or exchange the conservation if necessary.



NOTE!

Notes regarding storage which exceed the requirements mentioned here are possibly on the packaging pieces. These are to be observed respectively.

7 Maintenance and Cleaning

7.1 Safety

- | | |
|------------------|--|
| Personnel | <ul style="list-style-type: none">• The maintenance work described can be executed by the operator, unless it is marked differently.• Some maintenance work may only be executed by specially trained experts.• Maintenance work on the electric installation basically may only be executed by specialists for electronics. |
|------------------|--|

7.2 Maintenance and Cleaning Schedule

The maintenance work essential for an optimal and failure-free operation is described in the following chapters.

In case of detection of an increased abrasion during regular checks, shorten the required maintenance intervals accordingly to the actual signs of abrasion.

If you have questions concerning maintenance work and intervals contact the manufacturer, see service address on page 2.

Interval	Wearing work	To be carried out by
Daily	Check connection cables, pneumatic lines, plug connectors and feeding tubes for mechanical damage and loose contacts.	Operator
Weekly	Emptying maintenance unit	Qualified personnel
After 150000 cycles	Disassembly the riveting tool ERT80 (after completion of run-in period). Clean tool parts. Lubricate satellite roller screw, gearbox and bearings. Assemble and check the rivet tool.	Qualified personnel
After 250000 cycles	Lubricate riveting tool ERT40	Qualified personnel
Monthly or all 80000 cycles	<u>Control cables</u> Check for mechanical or electrical damage. Check the securely seated of strain relief. Check the min. bending radius of the cables.	Qualified personnel
Monthly or all 80000 cycles	<u>Die-plate and die-post</u> Check of mechanical or electrical damage. Remove any deposits or residues of adhesive. Check fixing screw of die-plate for firm fit, if necessary replace.	Qualified personnel
Monthly or all 80000 cycles	<u>Riveting die and guide bushing</u> CAUTION: Measure the correct receiver position before disassembly. Release receiver. Release slotted round nut and remove guide bushing. If the guide bushing cannot be pulled off the riveting die, the riveting die is compressed and has to be replaced. Test the riveting die for damages (broken-out edges, deformations) and deposits, if necessary replace. Tighten the die according to the defined torque. Clean riveting-die and guide bushing. Remove residues of adhesive. Insert the guide bushing and tighten swivel nut according to the defined torque. CAUTION: The angularity of the receiver has to be recalibrated.	Qualified personnel

Maintenance and Cleaning

Interval	Wearing work	To be carried out by
<p>Monthly or all 80000 cycles</p>	<p><u>Receiver (small cleaning)</u></p> <p>Unscrew the receiver and screw on afterwards. Pull apart the receiver circumspectly.</p> <p>CAUTION: Springs might fall out of the receiver.</p> <p>Check function of snap-in locking device. Push the unlocking pin, it has to move outwards self-acting.</p> <p>Verify smooth running of spring and snap-in locking device, if necessary replace.</p> <p>Check locating pin feed tube of mechanical damage and for firm fit, if necessary replace.</p> <p>Remove deposits with a cleaning fleece. Mount the upper part of the receiver to the rivet spindle. The snap-in locking device must not stick at the riveting die. Reassemble the receiver. Release the fixing screw for nose piece and take out the spring sleeve. Replace the O-Ring and mount nose piece. Tightening nose piece with threaded pin.</p>	<p>Qualified personnel</p>

Interval	Wearing work	To be carried out by
<p>Three months or all 250000 cycles</p>	<p><u>Receiver (large cleaning)</u> Unscrew the receiver and screw on afterwards. Pull apart the receiver circumspectly.</p> <p>CAUTION: Springs might fall out of the receiver. Finger: Remove deposits with a cleaning fleece. On heavy deposits dismount the finger and clean. Clean the air outlet hole. Check function of snap-in locking device.</p> <p>Push the unlocking pin, it has to move outwards self-acting. Verify smooth running of spring and snap-in locking device, if necessary replace. Check locating pin feed tube of mechanical damage and for firm fit, if necessary replace.</p> <p>Mount receiver upper part on the rivet spindle. The snap-in locking device must not stick at the riveting die. Assembly receiver.</p> <p>Release the fixing screw for nose piece and take out the spring sleeve. Clean spring sleeve and nose piece and test for grooves, if necessary replace.</p> <p>Replace the O-Ring and mount nose piece. Tightening nose piece with threaded pin.</p>	<p>Qualified personnel</p>
<p>Three months or all 250000 cycles</p>	<p><u>Linear slide</u> Check the connections, cables and hoses for mechanical and electrical faults.</p> <p>Clean the linear slide only with a dry cloth (Grease/dust).</p>	<p>Qualified personnel</p>

Maintenance and Cleaning

Interval	Wearing work	To be carried out by
Semi annually or all 500000 cycles	<p><u>Riveting die</u></p> <p>CAUTION: Measure the correct receiver position before disassembly.</p> <p>Release receiver. Release slotted round nut and remove guide bushing. Tighten the riveting die according to the defined torque.</p> <p>Clean guide bushing, remove residues of adhesive. Insert guide bushing and tighten the swivel nut according to the defined torque.</p> <p>CAUTION: The angularity of the receiver has to be recalibrated.</p>	Qualified personnel
Semi annually or all 500000 cycles	<p><u>Linear slide</u></p> <p>Check the connections, cables and hoses for mechanical and electrical faults.</p> <p>Clean the linear slide only with a dry cloth (Grease/dust). Lubricate the linear slide above the four lubricating nipples.</p>	Qualified personnel
Annually or all 1 Million cycles	<p><u>Riveting tool ERT40/80 (Preventive maintenance)</u></p> <p>Disassembly the riveting tool. Clean tool parts. Clean and lubricate satellite roller screw.</p> <p><u>Replace replacement parts:</u></p> <ul style="list-style-type: none"> - Guide rails. - Sliding blocks. - Guide bushings between housing and sleeve - Guide bushings between sleeve and sleeve bearing support. - Stripper. <p>Lubricate gearbox and bearings.</p> <p>Assemble and check the rivet tool.</p>	Qualified personnel
annually	Complete overhaul and check for wear	Manufacturer


7.3 Emptying the Maintenance Unit

- Execution by qualified personnel only



NOTE!

For emptying the condensate at the linear slide control it has to be aligned in correct positional arrangement.



Check condensate level

Check, if the level of the condensate in the collecting receiver (2) of the maintenance unit (1) has reached the marking (see arrow).

Remove condensate

Put a suitable collecting tray under the drain screw (3) and drain the condensate by turning the drain screw.

Tighten the drain screw (3) and remove collecting tray.

7.4 Lubricating the ERT 80 Riveting Spindle

The lubricating intervals depend on the work cycle of the riveting spindle and on the soiling of the lubricant when in use.

The ERT 80 spindle is lubricated on start-up and during the preventive maintenance. At each preventive maintenance the grease of the riveting spindle has to be exchanged completely.

Lubricating grease	Specification	Company	Type	Quantity
Riveting spindle ERT 80	Rolling bearing	Klüber	Klüberplex BEM 34-132	approx 10 cm ³
Riveting spindle ERT 80	Spur cut gear	Klüber	Klüberplex BEM 34-132	approx 10 cm ³
Riveting spindle ERT 80	Spindle satellite roller screw	Klüber	Klüberplex BEM 34-132	approx 5 cm ³
Riveting spindle ERT 80	Nut satellite roller screw	Klüber	Klüberplex BEM 34-132	approx 20 cm ³
Linear slide	Linear guide	THK	AFB 2KP2-K	approx 6 cm ³

Maintenance and Cleaning

Lubricate intervals ERT 80	Specification	Rivet cycle
	Riveting spindle	150 000, one-time after the run-in period
	Riveting spindle	1 Million
	Linear slide	500 000

7.5 Lubricating the ERT 40 Riveting Spindle

The lubricating intervals depend on the work cycle of the riveting spindle and on the soiling of the lubricant when in use.


The ERT 40 spindle is lubricated in regular intervals all 250.000 rivet cycles. At each preventive maintenance the grease of the riveting spindle has to be exchanged completely

Lubricating grease	Specification	Company	Type	Quantity
Riveting spindle ERT 40	Rolling bearing	Klüber	Klüberplex BEM 34-132	approx 10 cm ³
Riveting spindle ERT 40	Spur cut gear	Klüber	Klüberplex BEM 34-132	approx 10 cm ³
Riveting spindle ERT 40	Spindle lubricate	Klüber	Klüberplex BEM 34-132	approx 6 cm ³
Riveting spindle ERT 40	Refilling of spindle satellite roller screw	Klüber	Klüberplex BEM 34-132	approx 3,5 cm ³
Riveting spindle ERT 40	Refilling of nut satellite roller screw	Klüber	Klüberplex BEM 34-132	approx 5 cm ³
Linear slide	Linear guide	THK	AFB 2KP2-K	approx 6 cm ³

Lubricate intervals ERT 40	Specification	Rivet cycle
	Riveting spindle	250 000
	Riveting spindle preventive maintenance	1 Million
	Linear slide	500 000

Other lubricants are to be utilised only after effected consultation with and approval by Tucker.

7.5.1 Lubricating Sequence ERT



1. Drive the self-piercing rivet tool into basic position. Only in this position the re-greasing of the PRG is possible.
2. Release the threaded pins (2) approx. 4 turns.
3. Remove the cover (1).
4. Refill approx. 6 grams grease via the grease nipple (3).
5. Mount the cover and retighten the threaded pins.




NOTE!

List of special tools, including lubricating grease (⇒ chapter technical data.)

7.6 Lubricating the Linear Slide

For cleaning observe the following sequence:

- First, clean the linear guides only with a dry cloth.
- Check the linear guides for any damage.
- Lubricate the guide carriage above the four lubricating nipples.



NOTE!

List of special tools, including lubricating grease (⇒ chapter technical data.)

7.7 Cleaning the Receiver and Upper Riveting Die

Maintenance intervals:

Rivet cycle	Receiver	Upper riveting die
80 000	Check for damage Replace O-Ring in nose piece	Check for damage
250 000	Remove any deposits	Remove any deposits
	Clean receiver and upper riveting die with oil-free compressed air	

7.8 Changing the Upper Riveting Die


When the upper riveting die is worn, replace it with a new part.




NOTE!

Measuring the correct receiver position for disassembling.

- Put the rivet spindle in its basic position.



close




open

- Remove the receiver from the rivet spindle by opening the quick-action lock by means of pressing and a half-turn to the left and then pull the receiver downwards off the tool.
- Loosen the slotted round nut with a hook spanner and remove the guide bushing.

Maintenance and Cleaning

- Now place the upper die key, which is attached to the spindle, with the slot like working features in the direction of the spindle above the upper die.
- Slowly turn the upper die key so that the working feature can grip the upper die nut.



- Loosen the upper-die nut with an open-end wrench (wrench width 14).
- Completely unscrew the upper-die nut.
- Remove the upper-die nut together with the upper-die.
- Exchange the upper-die.
- Mount the aforesaid parts in the reverse order.
- To avoid a loosening of the upper-die during operation or to avoid damages of the die nut, tighten the die with the TUCKER mounting tool M114 004 (30Nm).



CAUTION!

After changing the upper riveting die, carry out adjustment travel!

8 Disposal

Unless no recovery- or disposal arrangement was made disassembled parts have to be recycled:

- Scrap metals.
- Recycle plastic elements.
- Dispose sorted all the rest of the components according material properties.



CAUTION!

Damage caused to the environment due to wrong disposal!

Electronic waste, electronic components, lubricants and other additives are subject to treatment of hazardous waste and may be disposed only by licensed certified specialists!

The local authority or special disposal specialists provide information regarding an environmentally friendly disposal.

Declaration of Incorporation acc. to the EC Machinery Directive 2006/42/EC,

Document number: EBE ERT 01

Manufacturer:

TUCKER GmbH
Max-Eyth-Straße 1
35387 Gießen
Deutschland

Authorized person to compile the relevant documentations:

Technische Dokumentation
TUCKER GmbH
Max-Eyth-Straße 1
35387 Gießen
Deutschland

Product name: ERT
Self-Piercing rivet tool for setting rivets

Serial number:

Year of manufacture:

The manufacturer declares that the above-mentioned product is a partly completed machinery according to the EC Machinery Directive 2006/42/EC. The product is to be solely used for installation in a machine or partly completed machine and therefore does not comply with all existing requirements of the EC Machinery Directive.

A list of the applied and complied with basic requirements of the EC Machinery Directive is attached to this declaration.

The special technical documents according to appendix VII, paragraph B have been generated. The above-mentioned authorized person commits to submit the specific product documents in response to a reasoned request by the national authorities. The submission is carried out by post in hardcopy form or via electronic data carriers. The putting into service of the product is prohibited till it has been made sure that the machine that is to be installed into the above-mentioned product complies with all basic requirements of the EC Machinery Directive.

The above product follows the provision of the following EC Directives:

Number: 2006/42/ EC Machinery Directive
2004/108/ EC "Electromagnetic Compatibility"

References of directives according to publication in Official Journal of the European Union

Issued by: Manfred Müller, General Manager

Location, date: Giessen,

Legally binding signature:



This declaration certifies compliance with the named Directives.

The appendix is an integral part of this declaration.

The safety instructions on the supplied product information sheet are to be followed.

1.1 Appendix to the Declaration of Incorporation

List of applied and adhered to basic safety and health requirements for construction and assembly of machines with respect to the product mentioned on page 1.

Number-Appendix	Description	Adhered to
1.	Essential health and safety requirements	
1.1.	General remarks	
1.1.3.	Materials and products	X
1.1.4.	Lightning	X
1.1.5.	Design of machinery to facilitate its handling	X
1.1.6.	Ergonomics	X
1.2.	Control system	
1.2.6.	Failure of power supply	X
1.3.	Protection against mechanical hazard	
1.3.3.	Risks due to falling ejected objects	X
1.3.4.	Risks due to surface, edges or angels	X
1.5.	Risks due other hazards	
1.5.1.	Electricity supply	X
1.5.2.	Static electricity	X
1.5.4.	Errors of fitting	X
1.5.5.	Extreme temperature	X
1.5.6.	Fire	X
1.5.8.	Noise	X
1.5.13.	Emissions of hazardous materials and substances	X
1.7.	Information	
1.7.1.	Information and warnings on the machinery	X
1.7.1.1.	Information and information devices	X
1.7.1.2.	Warning devices	X
1.7.2.	Warning of residual risks	X
1.7.3.	Marking of machinery	X