

Cybex[®] Plate Loaded Leg Press Owner's and Service Manual Strength Systems

Part Number 16110-999-4 A

www.cybexinternational.com



Cybex[®] Plate Loaded Leg Press Owner's and Service Manual

Strength Systems Part Number 16110-999-4 A

Cybex[®] and the Cybex logo are registered trademarks of Cybex International, Inc.

DISCLAIMER: Cybex International, Inc., makes no representations or warranties regarding the contents of this manual. We reserve the right to revise this document at any time or to make changes to the product described within it without notice or obligation to notify any person of such revisions or changes.

© Copyright 2010, Cybex International, Inc. All rights reserved.

Printed in the United States of America. 10 Trotter Drive Medway, MA 02053 • 508-533-4300 • FAX 508-533-5183 www.cybexinternational.com • techhelp@cybexintl.com • 16110-999-4 A • March 2010

Table of Contents

1 Safety Safety
2 Exercise Intended Use
3 Customer Service Contacting Service
4 Assembly Tools Required7
5 Maintenance Daily Procedures
6 Service Parts Lists

1 - Safety

Safety

Read the Owner's Manual carefully before assembling, servicing or using Cybex equipment.

WARNING: Serious injury could occur if these safety precautions are not observed:

User Safety Precautions

- Obtain a medical exam before beginning any exercise program.
- Stop exercising if feeling faint, dizzy or experiencing pain and consult your physician.
- Obtain instructions before using. Lisez les instructions avant l'untilisation.
- Read and understand the owner's manual and all warnings posted on the machine before using.
- Keep all children (12 and under) away. Teenagers (13 and over) and disabled must be supervised. Garder tous les enfants (de 12 ans et moins) éloignés. Les adolescents (de 13 ans et plus) et les handicapés doivent être surveillés.
- Use a spotter.
- Keep body and clothing free from and clear of all moving parts.
- Use the machine only for the intended use. **DO NOT** modify the machine.
- Inspect machine prior to use. **DO NOT** use if it appears damaged or inoperable.
- **DO NOT** attempt to fix a broken or jammed machine.
- Report any malfunctions, damage or repairs to the facility.
- Replace any warning labels if damaged, worn or illegible.

Facility Safety Precautions

- Read the Owner's Manual carefully before assembling, servicing or using this equipment.
- Securely anchor machine to the floor using the anchor holes provided in each machine.

NOTE: Cybex is not responsible for the actual anchoring of equipment. Consult with a professional contractor.

NOTE: Use fasteners having a minimum of 500 lbs. tensile capacity (3/8" grade 2 bolts or better).

NOTE: If legs/frame does not contact surface, DO NOT pull down with anchors. Shim any leg or frame not in contact with surface using flat washers.

- Make sure that each machine is set up and operated on a solid level surface. **Do not install** equipment on an uneven surface.
- Make sure that all users are properly trained on how to use this equipment.
- Make sure there is enough room for safe access and operation of this equipment.
- Perform regular maintenance checks on this equipment. Also pay close attention to all areas most susceptible to wear.

- Immediately replace worn or damaged components. If unable to immediately replace worn or damaged components then remove from service until the repair is made.
- **NOTE:** It is the sole responsibility of the user/owner or facility operator to ensure that regular maintenance is performed.

Safety Guidelines And Practices

Cybex recommends that all fitness equipment be used in a supervised area. It is recommended that the equipment be located in an access controlled area. Control is the responsibility of the owner. The extent of control is at the discretion of the owner.

It is the responsibility of the purchaser/user of Cybex products to read and understand the owner's manual, and warning labels; as well as instruct all individuals, whether end users or supervising personnel, on proper usage of the equipment.

PROPER USAGE:

Use machine only as described in the manual. Failing to follow proper instructions may result in injury.

Do Not Lean Against or Pull On the framework, weight stack, or any component, whether machine is at rest or in use. Inappropriate or improper use may result in injury to users or third parties (bystanders).

Do not use machine if it is not located on a solid level surface or is improperly installed.

Provide an adequate safety perimeter between the machine, walls and other equipment to ensure that the facility has the proper clearance for usage and training.

SECURING EQUIPMENT:

The machine has holes in the feet, which allow for ease in anchoring to the floor. Cybex strongly recommends that, to eliminate rocking, tipping or falling over due to incorrect usage and misuse, equipment be secured to a solid, level surface.

- **1.** The solid, level surface should not deviate more than 1/8" over a 10' distance or as defined and required by local building and architectural codes.
- 2. Anchoring of equipment must be completed by a qualified licensed contractor.
- **3.** Anchoring holes are provided on the feet of the frame. All anchoring locations must be used when anchoring the equipment to the floor.
- 4. Due to the wide variation of flooring on which machines may be anchored or installed, verify anchoring method and anchoring fasteners with a qualified and licensed contractor.
- 5. A minimum pull out force of 220 lbs/100 kgs is required for each anchor position..
- 6. Do not use machine until it is properly anchored.

MAINTENANCE:

Preventative maintenance allows proper equipment operation and reduces the risk of injury. Perform the maintenance requirements as specified in the manual.

STANDARD COMPLIANCE:

Cybex products meet or exceed applicable ASTM and EN Standards.




Warning/Caution Decals

Warning decals indicate a potentially hazardous situation, which, if not avoided, could result in death or serious injury.

Caution decals indicate a potentially hazardous situation, which, if not avoided, could result in minor or moderate injury.

The caution and warning decals are shown on this page.



Regular Maintenance Activities

Preventative maintenance activities must be performed to maintain normal operation of this equipment. Keeping a log sheet of all maintenance actions will assist you in staying current with all preventative maintenance activities.

WARNING: Equipment found to have worn or damaged components must be removed from service until repair(s) is made. Failure to do so could result in injury.

Daily

1. Clean upholstery.

Weekly

- 1. Inspect all nuts and bolts for looseness. Tighten as required.
- 2. Check for worn handles, and worn warning labeling. Replace all worn parts immediately.


2 - Exercise

Intended Use

The intended use of this equipment is to aid or improve general physical fitness and exercise. For Comercial use.

Instructions

Read and understand all instructions and warnings prior to using this machine. See Chapter 1, Safety in Owner's Manual or consult with floor staff.



NOTE: Refer to next page for set up and movement


Set Up

- 1. Load evenly with appropriate resistance..
- 2. Select desired back pad angle by pulling up on adjustment cable (located below seat pad) and tilt back pad to desired angle.
- 3. Position feet securely on foot pad
- 4. Push foot plate upward and rotate carriage stops to the UNLOCKED position. Grasp handles.

Movement

1. Push foot plate upward until legs are extended. Return to start with a smooth controlled movement while keeping pelvis against back pad.

NOTE: When performing calf exercise, ensure carriage stops are in the LOCKED position.



3 - Customer Service

Contacting Service

Hours of phone service are Monday through Friday from 8:30 to 6:00 p.m Eastern Standard Time.

For Cybex customers living in the USA, contact Cybex Customer Service at 888-462-9239.

For Cybex customers living outside the USA, contact Cybex Customer Service at 508-533-4300 or fax 508-533-5183.

Find information on the web at www.cybexintl.com or e-mail at techhelp@cybexintl.com.

Ordering Parts

Fax orders to **508-533-5183**. To speak with a customer service representative, call **888-462-9239** (for customers living within the USA) or **508-533-4300** (for customers outside the USA). You may also contact us through e-mail at techhelp@cybexintl.com

Having the following information ready when calling will assist our Cybex representatives in serving you.

- Unit Serial Number
- Product Name

The unit serial number and product name can be found on the serial number decal. See Chapter 6 for exact location of serial number decal.

- Part Description
- Part Number

Part descriptions and part numbers are located in Chapter 6 of this manual.

- Shipping Address
- Contact Name

In addition to your shipping address and contact name, your account number is helpful but not required.

Return Material Authorization (RMA)

The Return Material Authorization (RMA) system outlines the procedures to follow when returning material for placement, repair or credit. The system assures that returned materials are properly handled and analyzed. Follow the following procedures carefully.

Contact your authorized Cybex dealer on all warranty-related matters. Your local Cybex dealer will request a RMA from Cybex, if applicable. Under no circumstances will defective parts or equipment be accepted by Cybex without proper RMA and an Automated Return Service (ARS) label.

- 1. Call the Customer Service Hot Line listed above for the return of any item that is defective.
- **2.** Provide the technician with a detailed description of the problem you are having or the defect in the item you wish to return.
- 3. Provide the model and serial number of your Cybex equipment.
- 4. At Cybex's discretion, the technician may request that you return the problem part(s) to Cybex for evaluation and repair or replacement. The technician will assign you a RMA number and will send you an ARS label. The ARS label and the RMA numbers must be clearly displayed on the outside of the package that contains the item(s) to be returned. Include the description of the problem, the serial number of the equipment and the name and address of the owner in the package along with the part(s).
- 5. Forward the package through UPS to Cybex.
- Attn: Customer Service Department Cybex International, Inc. 1975 24th Ave SW Owatonna, MN 55060
- **NOTE:** Merchandise returned without an RMA number on the outside of the package or shipments sent COD will not be accepted by the Cybex receiving department.

Damaged Parts

Materials damaged in shipment should not be returned for credit. Shipping damages are the responsibility of the carrier (UPS, Federal Express, trucking companies, etc.)

Apparent Damage - Upon receipt of your shipment, check all items carefully. Any damage seen with a visual check must be noted on the freight bill and signed by the carrier's agent. Failure to do so will result in the carriers refusal to honor your damage claim. The carrier will provide you with the required forms for filing such claims.

Concealed Damage - Damage not seen with a visual check upon receipt of a shipment but notices later must be reported to the carrier as soon as possible. Upon discovery of the damage, a written or phone request to the carrier asking them to perform an inspection of the materials must be made within ten days of the delivery date. Keep all shipping containers and packing materials as they will be needed in the inspection process. The carrier will provide you with an inspection report and the necessary forms for filing a concealed damage claim. Concealed damage claim is the carrier's responsibility.

4 - Assembly

Tools Required


- 1/8" Allen wrench
- 5/16" Allen wrench
- 3/4" Wrench
- **NOTE:** It is the responsibility of the facility owner/owner of the equipment to ensure that there is appropriate clearance around each machine to allow for safe use and passage.
- NOTE: Refer to chapter 6 for reference diagrams.
- 1. Read and understand all instructions thoroughly before starting any of the procedures listed on this instruction sheet.
- 2. Verify you have received the appropriate configuration.
 - A. Verify that you received the correct color machine that you ordered.
 - B. Verify you received the appropriate owner's manual.
 - C. Verify you received the warranty sheet.

3. Move to desired location.

A. Note the diminsions of the machine: Machine Weight: 443 lbs. Size: 64 W" x 83" L x 54" H Machine Weight: 201 kg. Size: 163 cm W x 211 cm L x 137 cm H

NOTE: Keep all shipping packages near area of installation.

- B. Remove hardware pack and verify contents. See Figure 1.
- **C.** Carefully remove foam and shrink wrap securing weight bar and weight tubes.
- D. Carefully remove each (standard) cone-shaped shipping support using a 3/4" socket or wrench.
- E. Carefully place rubber feet (supplied with machine) on each foot of the frame.




- **A**. Locknut .500-13 (6), HN784000
- B. BHSCS .500-13 X 1.25 (6), JC780420
- C. Split, Lockwasher .375 (6), HS348300

Figure 1

4. Install weight bar.

- A. Position bar on Leg Press and insert all six Button Head Socket Cap Screws (BHSCS) (B from kit) through mounting plate. See Figure 2.
- **B.** Place washer (C) and locknut (A) on BHSCS from step 4A and finger tighten.
- **C.** Position carriage so that the bar is resting on lowest position. Raise and lower carriage. Verify stop plates on bar are hitting stop blocks at same time at both stop positions. See Figure 3.








Figure 3

D. Tighten all six BHSCS.

NOTE: If stop plates are not hitting stop plate at the same time then adjust arm before tightening BHSCS,

NOTE: If bar cannot be adjusted, loosen all bolts underneath carriage and align then tighten.

5. Install weight tubes.

- A. Remove one bearing sleeve.
- **B.** Insert weight tube through frame. See Figure 4.





Figure 4







- **D.** Using a 1/8" Allen wrench secure tube in place with set screws located on both sides of frame. See Figure 5.
- E. Repeat steps 5A- 5D for opposite weight tube.

6. Verify proper operation.

7. Anchor machine to floor.

- A. Securely anchor machine to the floor using the anchor holes provided in each machine.
- **NOTE:** Cybex is not responsible for the actual anchoring of equipment. Consult with a professional contractor.
- NOTE: Use fasteners having a minimum of 500 lbs. tensile capacity (3/8" grade 2 bolts or better).
- **NOTE:** If legs/frame does not contact surface, DO NOT pull down with anchors. Shim any leg or frame not in contact with surface using flat washers.

5 - Maintenance

All preventive maintenance activities must be performed on a regular basis. Performing routine preventive maintenance actions can aid in providing safe, trouble-free operation of all Cybex Strength Systems equipment.

NOTE: Cybex is not responsible for performing regular inspection and maintenance actions for your machines. Instruct all personnel in equipment inspection and maintenance actions and also in accident reporting/recording. Cybex phone representatives are available to answer any questions or concerns that you may have.

Daily Procedures

- 1. Upholstery Wipe down all upholstery.
- Frames Wipe down all frames using a mild solution of warm water and car wash soap. Be sure to dry thoroughly. AVOID acid or chlorine based cleaners and also cleaners containing abrasives as these could scratch or damage the equipment.
- **3. Chrome** Clean chrome tubes, first using chrome polish and then using a car wax seal. Neutral cleaners with a pH between 5.5 and 8.5 are recommended. Be sure to dry thoroughly. AVOID acid or chlorine based cleaners and also cleaners containing abrasives as these could scratch or damage the equipment.

Weekly Procedures

- 1. Inspect all nuts and bolts for looseness. Tighten as required
- 2. Inspect all labeling for readability. This includes instructional placards, warning and caution decals. Replace all worn labeling immediately.

6 - Service


Please refer to the next page for parts lists and exploded-view diagrams

Use only Cybex replacement parts when servicing. Failure to do so could result in personal injury. **NOTE:** All inspections and repairs must be performed by trained service personnel only.

Cybex will void warranty if non-Cybex replacement parts are used.

Plate Loaded Leg Press

PRODUCT NO. 16110



DESCRIPTION

PART NO.

DESCRIPTION

PART NO.

Α.	Warning Decal	5220-364-X
В.	Caution Decal	4000Y316-X
С.	Placard	16110-598-X
D.	Caution Decal	8500-025-X
Ε.	Warning Decal	5220-337-X
F.	Warning Decal	5220-346-X

G. Pad W/Wear cover......4800-184
H. Wear Cover.....4800-187
I. Seat Pad.....4800-188
J. Serial Number Decal
K. Non Slip.....12220-005
L. Grips.....4605-509

DESCRIPTION	ITEM	QTΥ	PART NO.	DESCRIPTION
END CAP	37	2	HN704901	LOCKNUT, .375-16 NYLON
RING, HANDLE GRIP	38	10	HN784000	HEX NUT .500-13
FOOT PAD	39	10	HS348300	LOCKWASHER, SPLIT .375
W MAIN FRAME	40	ø	HS387700	WASHER, SAE .500
W/HANDLE-LEFT	41	4	HY582910	SET SCREW
W/HANDLE-RIGHT	42	ø	HY622910	SET SC .250-20 X .375
W/STOP ROD	43	4	JC570412	BHSCS .190 10-32 X .375
W SEAT BACK	44	0	JC620422	BHSCS .250-20 × 1.50
W SLED	45	4	JC660412	BHSCS .312-18 X .50
PLATED WEIGHT BAR	46	7	JC700420	BHSCS .375-16 X 1.25
SHAFT MOUNT	47	-	JC700422	BHSCS .375-16 X 1.50
CAP	48	0	JC700424	BHSCS .375-16 X 1.75
LINK	49	8	JC780417	BHSCS .500-13 X 1.00
NON-SLIP	50	10	JC780420	BHSCS .500-13 X 1.25
CABLE	51	2	JC782815	SHCS .500-13 X .75
DECAL, CYBEX	52	4	JD343322	S BOLT .375 X 1.50 .312-18
BUMPER, HANDLE	53	0	JD403348	SHOULDER BOLT .750 X
GRAB GRIP 4.00				1.50.625-11
WARRANTY BOOK (NOT SHOWN)	54	0	JN814200	HEX NUT .625-11
SPACER, PLASTIC	55	4	JS347400	LOCKWASHER, INT TOOTH .375
C BEARING SLEEVE	56	10	JS388300	SPLIT LOCKWASHER .500
W SLIDE PLATE	57	2	PN660200	INSERT, PLASTIC 1.00 DIA-11 GA
SHAFT	58	2	PP080207	INSERT, PLASTIC .437 DIA 11 GA
P STOP ROD COLLET	59	8	PP130006	INSERT, PLASTIC END
PIN DETENT	60	2	PP470006	KNOB, OVAL
P/WEIGHT TUBE 5.00	61	4	PR060006	BUMPER, RECESS
PLATED WEIGHT TUBE (19.00)	62	-	4800-184	BACK PAD W/WEAR COVER
RETAINING RING	63	-	4800-187	WEAR COVER
COM SPRING .56 x .66 1.50 LG	64	7	4000Y316-X*	DECAL, CAUTION
BRG, LINEAR 1.50	65	-	5320-336-X*	DECAL
O-RING (.612 ID X .103 WIDE)	99	-	8500-025-X*	DECAL, CAUTION
SEAL, LINEAR BEARING	67	-	16110-598-X*	PLACARD
BEARING FLUSH OILITE	68	-	5220-364-X*	DECAL, WARNING
BHSCS .375-16 X 1.00	69	-	5320-346-X*	DECAL, WARNING
INSERT 3/4 X 1/4-20	20	2	5220-337-X*	DECAL, WARNING
NUT, HEX SELF-LOCKING .312-18	71	-	4800-188	SEAT PAD
ZINC	72	-	11040-790	DECAL, MADE IN USA

5320-205 5320-332

- 0 0 0 - 0 0 - 0 0 0 4 0

5220-367 5320-204 5321-302

16110-358 16110-388

 \sim

6110-357

6110-351

I6110-389

3900-434 4605-509

4540-321 51198

ý	1-German , 2-French, 3-Spanish, 4-Engli 6-Japanese, 7- Swedish, 8- Russian
Key	2-Fr - 7-
*Language Key	1-German , 6-Japanese,

ish,

BR030203

FS100006

4 4

5330P012

5320P040 5330P029 BS070201 FB110200 FS110200 HB-60008 HF449063

HN664900

HC700417

4 0 2 0 4

1090-376

6010-311

11090-374

2 2

~

PART NO.


QTY


ITEM


> 6110-210 6110-212 6110-213 6110-215 6110-216


6110-211

6110-200











10 Trotter Drive Medway, MA 02053 • 508-533-4300 • FAX 508-533-5183 www.cybexinternational.com • techhelp@cybexintl.com