



35C

DRAG-GUN™ PLUS

PLASMA CUTTING SYSTEM



Service Manual

Rev. AB
Operating Features:

Issue Date: October 18, 2007

Manual 0-4751



PLASMA

35
AMP



1
PHASE

230
V



WARNING

Read and understand this entire Manual and your employer's safety practices before installing, operating, or servicing the equipment.

While the information contained in this Manual represents the Manufacturer's best judgement, the Manufacturer assumes no liability for its use.

Plasma Cutting Power Supply
Drag-Gun Plus 35C
PCH 42 Torch
Service Manual Number 0-4751

Covered under U.S. Patents.

Published by:
Thermadyne Corporation
82 Benning Street
West Lebanon, New Hampshire, USA 03784
(603) 298-5711

www.thermal-dynamics.com

©Copyright 2006, 2007 by
Thermal Dynamics Corporation

All rights reserved.

Reproduction of this work, in whole or in part, without written permission of the publisher is prohibited.

The publisher does not assume and hereby disclaims any liability to any party for any loss or damage caused by any error or omission in this Manual, whether such error results from negligence, accident, or any other cause.

Printed in the United States of America

Publication Date: October 18, 2007

Record the following information for Warranty purposes:

Where Purchased: _____

Purchase Date: _____

Power Supply Serial #: _____

Torch Serial #: _____

TABLE OF CONTENTS

SECTION 1:	
GENERAL INFORMATION	1-1
1.01 Notes, Cautions and Warnings	1-1
1.02 Important Safety Precautions	1-1
1.03 Publications	1-2
1.04 Note, Attention et Avertissement	1-3
1.05 Precautions De Securite Importantes	1-3
1.06 Documents De Reference	1-4
1.06 Declaration Of Conformity	1-6
1.05 Statement of Warranty	1-7
SECTION 2:	
INTRODUCTION	2-1
2.01 INTRODUCTION	2-1
2.02 GENERAL SPECIFICATION	2-1
2.03 Features	2-1
2.04 Torch Specifications	2-2
2.05 System Contents	2-2
2.06 Transporting Methods	2-2
SECTION 3:	
INSTALLATION	3-1
3.01 Site Selection	3-1
3.02 Electrical Input Connections	3-1
3.03 Torch	3-1
SECTION 4:	
OPERATION	4-1
4.01 Front Control Panel	4-1
4.02 Preparations For Operating	4-2
SECTION 5: MAINTENANCE	5-1
5.01 General Maintenance	5-1
SECTION 6:	
TROUBLESHOOTING	6-1
6.01 Normal Setup and Operation	6-1
6.02 Basic Trouble Shooting Guide	6-2
6.03 Control PCB Indicators	6-3
6.04 Open Circuit Voltage Check	6-4
6.05 Detailed Fault Finding / Error Indicators	6-5
6.06 Torch Tests	6-9
SECTION 7:	
PARTS LIST	7-1
7.01 Parts List Power Supply	7-2
7.02 Replacement Hand Torch Parts With Ergonomic Handle	7-6

TABLE OF CONTENTS (Con't)

Appendix 1: Operating Sequence, Block Diagram	A-1
Appendix 2: Torch Connection	A-2
Appendix 3: Microchip Pin-Out	A-3
Appendix 4: System Schematic 230V CE	A-4
Appendix 5: System Schematic 230V	A-6
GLOBAL CUSTOMER SERVICE CONTACT INFORMATION	Inside Rear Cover

SECTION 1: GENERAL INFORMATION

1.01 Notes, Cautions and Warnings

Throughout this manual, notes, cautions, and warnings are used to highlight important information. These highlights are categorized as follows:

NOTE

An operation, procedure, or background information which requires additional emphasis or is helpful in efficient operation of the system.



CAUTION

A procedure which, if not properly followed, may cause damage to the equipment.



WARNING

A procedure which, if not properly followed, may cause injury to the operator or others in the operating area.

1.02 Important Safety Precautions



WARNING

OPERATION AND MAINTENANCE OF PLASMA ARC EQUIPMENT CAN BE DANGEROUS AND HAZARDOUS TO YOUR HEALTH.

Plasma arc cutting produces intense electric and magnetic emissions that may interfere with the proper function of cardiac pacemakers, hearing aids, or other electronic health equipment. Persons who work near plasma arc cutting applications should consult their medical health professional and the manufacturer of the health equipment to determine whether a hazard exists.

To prevent possible injury, read, understand and follow all warnings, safety precautions and instructions before using the equipment. Call 1-603-298-5711 or your local distributor if you have any questions.



GASES AND FUMES

Gases and fumes produced during the plasma cutting process can be dangerous and hazardous to your health.

- Keep all fumes and gases from the breathing area. Keep your head out of the welding fume plume.

- Use an air-supplied respirator if ventilation is not adequate to remove all fumes and gases.
- The kinds of fumes and gases from the plasma arc depend on the kind of metal being used, coatings on the metal, and the different processes. You must be very careful when cutting or welding any metals which may contain one or more of the following:

Antimony	Chromium	Mercury
Arsenic	Cobalt	Nickel
Barium	Copper	Selenium
Beryllium	Lead	Silver
Cadmium	Manganese	Vanadium

- Always read the Material Safety Data Sheets (MSDS) that should be supplied with the material you are using. These MSDSs will give you the information regarding the kind and amount of fumes and gases that may be dangerous to your health.
- For information on how to test for fumes and gases in your workplace, refer to item 1 in Subsection 1.03, Publications in this manual.
- Use special equipment, such as water or down draft cutting tables, to capture fumes and gases.
- Do not use the plasma torch in an area where combustible or explosive gases or materials are located.
- Phosgene, a toxic gas, is generated from the vapors of chlorinated solvents and cleansers. Remove all sources of these vapors.
- This product, when used for welding or cutting, produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code Sec. 25249.5 et seq.)



ELECTRIC SHOCK

Electric Shock can injure or kill. The plasma arc process uses and produces high voltage electrical energy. This electric energy can cause severe or fatal shock to the operator or others in the workplace.

- Never touch any parts that are electrically "live" or "hot."
- Wear dry gloves and clothing. Insulate yourself from the work piece or other parts of the welding circuit.
- Repair or replace all worn or damaged parts.
- Extra care must be taken when the workplace is moist or damp.
- Install and maintain equipment according to NEC code, refer to item 9 in Subsection 1.03, Publications.
- Disconnect power source before performing any service or repairs.
- Read and follow all the instructions in the Operating Manual.



FIRE AND EXPLOSION

Fire and explosion can be caused by hot slag, sparks, or the plasma arc.

- Be sure there is no combustible or flammable material in the workplace. Any material that cannot be removed must be protected.
- Ventilate all flammable or explosive vapors from the workplace.
- Do not cut or weld on containers that may have held combustibles.

DRAG-GUN PLUS 35C

- Provide a fire watch when working in an area where fire hazards may exist.
- Hydrogen gas may be formed and trapped under aluminum workpieces when they are cut underwater or while using a water table. **DO NOT** cut aluminum alloys underwater or on a water table unless the hydrogen gas can be eliminated or dissipated. Trapped hydrogen gas that is ignited will cause an explosion.



NOISE

Noise can cause permanent hearing loss. Plasma arc processes can cause noise levels to exceed safe limits. You must protect your ears from loud noise to prevent permanent loss of hearing.

- To protect your hearing from loud noise, wear protective ear plugs and/or ear muffs. Protect others in the workplace.
- Noise levels should be measured to be sure the decibels (sound) do not exceed safe levels.
- For information on how to test for noise, see item 1 in Subsection 1.03, Publications, in this manual.



PLASMA ARC RAYS

Plasma Arc Rays can injure your eyes and burn your skin. The plasma arc process produces very bright ultra violet and infra red light. These arc rays will damage your eyes and burn your skin if you are not properly protected.

- To protect your eyes, always wear a welding helmet or shield. Also always wear safety glasses with side shields, goggles or other protective eye wear.
- Wear welding gloves and suitable clothing to protect your skin from the arc rays and sparks.
- Keep helmet and safety glasses in good condition. Replace lenses when cracked, chipped or dirty.
- Protect others in the work area from the arc rays. Use protective booths, screens or shields.
- Use the shade of lens as suggested in the following per ANSI/ASC Z49.1:

Arc Current	Minimum Protective Shade No.	Suggested Shade No.
Less Than 300*	8	9
300 - 400*	9	12
400 - 800*	10	14

**These values apply where the actual arc is clearly seen. Experience has shown that lighter filters may be used when the arc is hidden by the workpiece.*

1.03 Publications

Refer to the following standards or their latest revisions for more information:

1. OSHA, SAFETY AND HEALTH STANDARDS, 29CFR 1910, obtainable from the Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402
2. ANSI Standard Z49.1, SAFETY IN WELDING AND CUTTING, obtainable from the American Welding Society, 550 N.W. LeJeune Rd, Miami, FL 33126
3. NIOSH, SAFETY AND HEALTH IN ARC WELDING AND GAS WELDING AND CUTTING, obtainable from the Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402
4. ANSI Standard Z87.1, SAFE PRACTICES FOR OCCUPATION AND EDUCATIONAL EYE AND FACE PROTECTION, obtainable from American National Standards Institute, 1430 Broadway, New York, NY 10018
5. ANSI Standard Z41.1, STANDARD FOR MEN'S SAFETY-TOE FOOTWEAR, obtainable from the American National Standards Institute, 1430 Broadway, New York, NY 10018
6. ANSI Standard Z49.2, FIRE PREVENTION IN THE USE OF CUTTING AND WELDING PROCESSES, obtainable from American National Standards Institute, 1430 Broadway, New York, NY 10018
7. AWS Standard A6.0, WELDING AND CUTTING CONTAINERS WHICH HAVE HELD COMBUSTIBLES, obtainable from American Welding Society, 550 N.W. LeJeune Rd, Miami, FL 33126
8. NFPA Standard 51, OXYGEN-FUEL GAS SYSTEMS FOR WELDING, CUTTING AND ALLIED PROCESSES, obtainable from the National Fire Protection Association, Batterymarch Park, Quincy, MA 02269
9. NFPA Standard 70, NATIONAL ELECTRICAL CODE, obtainable from the National Fire Protection Association, Batterymarch Park, Quincy, MA 02269
10. NFPA Standard 51B, CUTTING AND WELDING PROCESSES, obtainable from the National Fire Protection Association, Batterymarch Park, Quincy, MA 02269
11. CGA Pamphlet P-1, SAFE HANDLING OF COMPRESSED GASES IN CYLINDERS, obtainable from the Compressed Gas Association, 1235 Jefferson Davis Highway, Suite 501, Arlington, VA 22202
12. CSA Standard W117.2, CODE FOR SAFETY IN WELDING AND CUTTING, obtainable from the Canadian Standards Association, Standards Sales, 178 Rexdale Boulevard, Rexdale, Ontario, Canada M9W 1R3
13. NWSA booklet, WELDING SAFETY BIBLIOGRAPHY obtainable from the National Welding Supply Association, 1900 Arch Street, Philadelphia, PA 19103
14. American Welding Society Standard AWSF4.1, RECOMMENDED SAFE PRACTICES FOR THE PREPARATION FOR WELDING AND CUTTING OF CONTAINERS AND PIPING THAT HAVE HELD HAZARDOUS SUBSTANCES, obtainable from the American Welding Society, 550 N.W. LeJeune Rd, Miami, FL 33126
15. ANSI Standard Z88.2, PRACTICE FOR RESPIRATORY PROTECTION, obtainable from American National Standards Institute, 1430 Broadway, New York, NY 10018

1.04 Note, Attention et Avertissement

Dans ce manuel, les mots “note,” “attention,” et “avertissement” sont utilisés pour mettre en relief des informations à caractère important. Ces mises en relief sont classifiées comme suit :

NOTE

Toute opération, procédure ou renseignement général sur lequel il importe d'insister davantage ou qui contribue à l'efficacité de fonctionnement du système.



ATTENTION

Toute procédure pouvant résulter l'endommagement du matériel en cas de non-respect de la procédure en question.



AVERTISSEMENT

Toute procédure pouvant provoquer des blessures de l'opérateur ou des autres personnes se trouvant dans la zone de travail en cas de non-respect de la procédure en question.

1.05 Précautions De Sécurité Importantes



AVERTISSEMENTS

L'OPÉRATION ET LA MAINTENANCE DU MATÉRIEL DE SOUDAGE À L'ARC AU JET DE PLASMA PEUVENT PRÉSENTER DES RISQUES ET DES DANGERS DE SANTÉ.

Coupant à l'arc au jet de plasma produit de l'énergie électrique haute tension et des émissions magnétique qui peuvent interférer la fonction propre d'un "pacemaker" cardiaque, les appareils auditif, ou autre matériel de santé électronique. Ceux qui travail près d'une application à l'arc au jet de plasma devrait consulter leur membre professionnel de médication et le fabricant de matériel de santé pour déterminer s'il existe des risques de santé.

Il faut communiquer aux opérateurs et au personnel TOUS les dangers possibles. Afin d'éviter les blessures possibles, lisez, comprenez et suivez tous les avertissements, toutes les précautions de sécurité et toutes les consignes avant d'utiliser le matériel. Composez le + 603-298-5711 ou votre distributeur local si vous avez des questions.



FUMÉE et GAZ

La fumée et les gaz produits par le procédé de jet de plasma peuvent présenter des risques et des dangers de santé.

- Eloignez toute fumée et gaz de votre zone de respiration. Gardez votre tête hors de la plume de fumée provenant du chalumeau.
- Utilisez un appareil respiratoire à alimentation en air si l'aération fournie ne permet pas d'éliminer la fumée et les gaz.
- Les sortes de gaz et de fumée provenant de l'arc de plasma dépendent du genre de métal utilisé, des revêtements se trouvant sur le métal et des différents procédés. Vous devez prendre soin lorsque vous coupez ou soudez tout métal pouvant contenir un ou plusieurs des éléments suivants:

antimoine	cadmium	mercure
argent	chrome	nickel
arsenic	cobalt	plomb
baryum	cuivre	sélénium
béryllium	manganèse	vanadium

- Lisez toujours les fiches de données sur la sécurité des matières (sigle américain "MSDS"); celles-ci devraient être fournies avec le matériel que vous utilisez. Les MSDS contiennent des renseignements quant à la quantité et la nature de la fumée et des gaz pouvant poser des dangers de santé.
- Pour des informations sur la manière de tester la fumée et les gaz de votre lieu de travail, consultez l'article 1 et les documents cités à la page 5.
- Utilisez un équipement spécial tel que des tables de coupe à débit d'eau ou à courant descendant pour capter la fumée et les gaz.
- N'utilisez pas le chalumeau au jet de plasma dans une zone où se trouvent des matières ou des gaz combustibles ou explosifs.
- Le phosgène, un gaz toxique, est généré par la fumée provenant des solvants et des produits de nettoyage chlorés. Éliminez toute source de telle fumée.
- Ce produit, dans le procédé de soudage et de coupe, produit de la fumée ou des gaz pouvant contenir des éléments reconnu dans L'état de la Californie, qui peuvent causer des défauts de naissance et le cancer. (La sécurité de santé en Californie et la code sécurité Sec. 25249.5 et seq.)



CHOC ELECTRIQUE

Les chocs électriques peuvent blesser ou même tuer. Le procédé au jet de plasma requiert et produit de l'énergie électrique haute tension. Cette énergie électrique peut produire des chocs graves, voire mortels, pour l'opérateur et les autres personnes sur le lieu de travail.

- Ne touchez jamais une pièce "sous tension" ou "vive"; portez des gants et des vêtements secs. Isolez-vous de la pièce de travail ou des autres parties du circuit de soudage.
- Réparez ou remplacez toute pièce usée ou endommagée.
- Prenez des soins particuliers lorsque la zone de travail est humide ou moite.
- Montez et maintenez le matériel conformément au Code électrique national des Etats-Unis. (Voir la page 5, article 9.)
- Débranchez l'alimentation électrique avant tout travail d'entretien ou de réparation.
- Lisez et respectez toutes les consignes du Manuel de consignes.



INCENDIE ET EXPLOSION

Les incendies et les explosions peuvent résulter des scories chaudes, des étincelles ou de l'arc de plasma. Le procédé à l'arc de plasma produit du métal, des étincelles, des scories chaudes pouvant mettre le feu aux matières combustibles ou provoquer l'explosion de fumées inflammables.

- Soyez certain qu'aucune matière combustible ou inflammable ne se trouve sur le lieu de travail. Protégez toute telle matière qu'il est impossible de retirer de la zone de travail.
- Procurez une bonne aération de toutes les fumées inflammables ou explosives.
- Ne coupez pas et ne soudez pas les conteneurs ayant pu renfermer des matières combustibles.
- Prévoyez une veille d'incendie lors de tout travail dans une zone présentant des dangers d'incendie.
- Le gaz hydrogène peut se former ou s'accumuler sous les pièces de travail en aluminium lorsqu'elles sont coupées sous l'eau ou sur une table d'eau. NE PAS couper les alliages en aluminium sous l'eau ou sur une table d'eau à moins que le gaz hydrogène peut s'échapper ou se dissiper. Le gaz hydrogène accumulé explosera si enflammé.



RAYONS D'ARC DE PLASMA

Les rayons provenant de l'arc de plasma peuvent blesser vos yeux et brûler votre peau. Le procédé à l'arc de plasma produit une lumière infra-rouge et des rayons ultra-violet très forts. Ces rayons d'arc nuiront à vos yeux et brûleront votre peau si vous ne vous protégez pas correctement.

- Pour protéger vos yeux, portez toujours un casque ou un écran de soudeur. Portez toujours des lunettes de sécurité munies de parois latérales ou des lunettes de protection ou une autre sorte de protection oculaire.
- Portez des gants de soudeur et un vêtement protecteur approprié pour protéger votre peau contre les étincelles et les rayons de l'arc.
- Maintenez votre casque et vos lunettes de protection en bon état. Remplacez toute lentille sale ou comportant fissure ou rognure.
- Protégez les autres personnes se trouvant sur la zone de travail contre les rayons de l'arc en fournissant des cabines ou des écrans de protection.
- Utilisez la nuance de lentille qui est suggérée dans le recommandation qui suivent ANSI/ASC Z49.1:

Courant Arc	Nuance Minimum Protective Numéro	Nuance Suggérée Numéro
Moins de 300*	8	9
300 - 400*	9	12
400 - 800*	10	14

**Ces valeurs s'appliquent ou l'arc actuel est observé clairement. L'expérience a démontré que les filtres moins foncés peuvent être utilisés quand l'arc est caché par moicseau de travail.*



BRUIT

Le bruit peut provoquer une perte permanente de l'ouïe. Les procédés de soudage à l'arc de plasma peuvent provoquer des niveaux sonores supérieurs aux limites normalement acceptables. Vous devez vous protéger les oreilles contre les bruits forts afin d'éviter une perte permanente de l'ouïe.

- Pour protéger votre ouïe contre les bruits forts, portez des tampons protecteurs et/ou des protections auriculaires. Protégez également les autres personnes se trouvant sur le lieu de travail.
- Il faut mesurer les niveaux sonores afin d'assurer que les décibels (le bruit) ne dépassent pas les niveaux sûrs.
- Pour des renseignements sur la manière de tester le bruit, consultez l'article 1, page 5.

1.06 Documents De Référence

Consultez les normes suivantes ou les révisions les plus récentes ayant été faites à celles-ci pour de plus amples renseignements :

1. OSHA, NORMES DE SÉCURITÉ DU TRAVAIL ET DE PROTECTION DE LA SANTÉ, 29CFR 1910, disponible auprès du Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402
2. Norme ANSI Z49.1, LA SÉCURITÉ DES OPÉRATIONS DE COUPE ET DE SOUDAGE, disponible auprès de la Société Américaine de Soudage (American Welding Society), 550 N.W. LeJeune Rd., Miami, FL 33126
3. NIOSH, LA SÉCURITÉ ET LA SANTÉ LORS DES OPÉRATIONS DE COUPE ET DE SOUDAGE À L'ARC ET AU GAZ, disponible auprès du Superintendent of Documents, U.S. Government Printing Office, Washington, D.C. 20402
4. Norme ANSI Z87.1, PRATIQUES SURES POUR LA PROTECTION DES YEUX ET DU VISAGE AU TRAVAIL ET DANS LES ECOLES, disponible de l'Institut Américain des Normes Nationales (American National Standards Institute), 1430 Broadway, New York, NY 10018
5. Norme ANSI Z41.1, NORMES POUR LES CHAUSSURES PROTECTRICES, disponible auprès de l'American National Standards Institute, 1430 Broadway, New York, NY 10018
6. Norme ANSI Z49.2, PRÉVENTION DES INCENDIES LORS DE L'EMPLOI DE PROCÉDÉS DE COUPE ET DE SOUDAGE, disponible auprès de l'American National Standards Institute, 1430 Broadway, New York, NY 10018
7. Norme A6.0 de l'Association Américaine du Soudage (AWS), LE SOUDAGE ET LA COUPE DE CONTENEURS AYANT RENFERMÉ DES PRODUITS COMBUSTIBLES, disponible auprès de la American Welding Society, 550 N.W. LeJeune Rd., Miami, FL 33126
8. Norme 51 de l'Association Américaine pour la Protection contre les Incendies (NFPA), LES SYSTEMES À GAZ AVEC ALIMENTATION EN OXYGENE POUR LE SOUDAGE, LA COUPE ET LES PROCÉDÉS ASSOCIÉS, disponible auprès de la National Fire Protection Association, Batterymarch Park, Quincy, MA 02269
9. Norme 70 de la NFPA, CODE ELECTRIQUE NATIONAL, disponible auprès de la National Fire Protection Association, Batterymarch Park, Quincy, MA 02269

10. Norme 51B de la NFPA, LES PROCÉDÉS DE COUPE ET DE SOUDAGE, disponible auprès de la National Fire Protection Association, Batterymarch Park, Quincy, MA 02269
11. Brochure GCA P-1, LA MANIPULATION SANS RISQUE DES GAZ COMPRIMÉS EN CYLINDRES, disponible auprès de l'Association des Gaz Comprimés (Compressed Gas Association), 1235 Jefferson Davis Highway, Suite 501, Arlington, VA 22202
12. Norme CSA W117.2, CODE DE SÉCURITÉ POUR LE SOUDAGE ET LA COUPE, disponible auprès de l'Association des Normes Canadiennes, Standards Sales, 178 Rexdale Boulevard, Rexdale, Ontario, Canada, M9W 1R3
13. Livret NWSA, BIBLIOGRAPHIE SUR LA SÉCURITÉ DU SOUDAGE, disponible auprès de l'Association Nationale de Fournitures de Soudage (National Welding Supply Association), 1900 Arch Street, Philadelphia, PA 19103
14. Norme AWSF4.1 de l'Association Américaine de Soudage, RECOMMANDATIONS DE PRATIQUES SURES POUR LA PRÉPARATION À LA COUPE ET AU SOUDAGE DE CONTENEURS ET TUYAUX AYANT RENFERMÉ DES PRODUITS DANGEREUX , disponible auprès de la American Welding Society, 550 N.W. LeJeune Rd., Miami, FL 33126
15. Norme ANSI Z88.2, PRATIQUES DE PROTECTION RESPIRATOIRE, disponible auprès de l'American National Standards Institute, 1430 Broadway, New York, NY 10018



1.06 Declaration Of Conformity

Manufacturer: Thermadyne Corporation
Address: 82 Benning Street
West Lebanon, New Hampshire 03784
USA

The equipment described in this manual conforms to all applicable aspects and regulations of the 'Low Voltage Directive' (European Council Directive 73/23/EEC as amended by Council Directive 93/68/EEC) and to the National legislation for the enforcement of this Directive.

The equipment described in this manual conforms to all applicable aspects and regulations of the "EMC Directive" (European Council Directive 89/336/EEC) and to the National legislation for the enforcement of this Directive.

Serial numbers are unique with each individual piece of equipment and details description, parts used to manufacture a unit and date of manufacture.

National Standard and Technical Specifications

The product is designed and manufactured to a number of standards and technical requirements. Among them are:

- CSA (Canadian Standards Association) standard C22.2 No. 60 for Arc Welding Equipment.
- CENELEC EN50199 EMC Product Standard for Arc Welding Equipment.
- IEC/EN 60974-1 (EN50192) (EN50078) Arc Welding Equipment Part 1: Welding Power Supplies
- IEC/EN 60974-5 Arc Welding Equipment Part 5: Wire Feeders
- IEC/EN 60974-7 Arc Welding Equipment Part 7: Torches
- IEC/EN 60974-10 Arc Welding Equipment Part 10: Electromagnetic Compatibility (EMC) Requirements
- For environments with increased hazard of electrical shock, Power Supplies bearing the S mark conform to EN50192 when used in conjunction with hand torches with exposed cutting tips, if equipped with properly installed standoff guides.
- Extensive product design verification is conducted at the manufacturing facility as part of the routine design and manufacturing process. This is to ensure the product is safe, when used according to instructions in this manual and related industry standards, and performs as specified.

Thermadyne has been manufacturing products for more than 30 years, and will continue to achieve excellence in our area of manufacture.

Manufacturers responsible representative:

Steve Ward
Operations Director
Thermadyne Europe
Europa Building
Chorley N Industrial Park
Chorley, Lancashire,
England PR6 7BX

1.05 Statement of Warranty

LIMITED WARRANTY: Subject to the terms and conditions established below, Thermadyne® Corporation warrants to the original retail purchaser that new Thermadyne CutSkill Series plasma cutting systems sold after the effective date of this warranty are free of defects in material and workmanship. Should any failure to conform to this warranty appear within the applicable period stated below, Thermadyne Corporation shall, upon notification thereof and substantiation that the product has been stored operated and maintained in accordance with Thermadynes' specifications, instructions, recommendations and recognized industry practice, correct such defects by suitable repair or replacement.

This warranty is exclusive and in lieu of any warranty of merchantability or fitness for a particular purpose.

Thermadyne will repair or replace, at its discretion, any warranted parts or components that fail due to defects in material or workmanship within the time periods set out below. Thermadyne Corporation must be notified within 30 days of any failure, at which time Thermadyne Corporation will provide instructions on the warranty procedures to be implemented.

Thermadyne Corporation will honor warranty claims submitted within the warranty periods listed below. All warranty periods begin on the date of sale of the product to the original retail customer or 1 year after sale to an authorized Thermadyne Distributor.

LIMITED WARRANTY PERIOD

Product	Power Supply Components (Parts and Labor)	Torch and Leads (Parts and Labor)
Drag-Gun Plus	2 Year	1 Year

This warranty does not apply to:

1. Consumable Parts, such as tips, electrodes, shield cups, o - rings, starter cartridges, gas distributors, fuses, filters.
2. Equipment that has been modified by an unauthorized party, improperly installed, improperly operated or misused based upon industry standards.

In the event of a claim under this warranty, the remedies shall be, at the discretion of Thermadyne Corporation:

1. Repair of the defective product.
2. Replacement of the defective product.
3. Reimbursement of reasonable costs of repair when authorized in advance by Thermadyne.
4. Payment of credit up to the purchase price less reasonable depreciation based on actual use.

These remedies may be authorized by Thermadyne and are FOB West Lebanon, NH or an authorized Thermadyne service station. Product returned for service is at the owner's expense and no reimbursement of travel or transportation is authorized.

LIMITATION OF LIABILITY: Thermadyne Corporation shall not under any circumstances be liable for special or consequential damages such as, but not limited to, damage or loss of purchased or replacement goods or claims of customer or distributors (hereinafter "Purchaser") for service interruption. The remedies of the Purchaser set forth herein are exclusive and the liability of Thermadyne with respect to any contract, or anything done in connection therewith such as the performance or breach thereof, or from the manufacture, sale, delivery, resale, or use of the goods covered by or furnished by Thermadyne whether arising out of contract, negligence, strict tort, or under any warranty, or otherwise, shall not, except as expressly provided herein, exceed the price of the goods upon which liability is based.

This warranty becomes invalid if replacement parts or accessories are used which may impair the safety or performance of any Thermadyne product.

This warranty is invalid if the Thermadyne product is sold by non-authorized persons.

Effective August 28, 2005

This Page Left Blank

SECTION 2: INTRODUCTION

2.01 INTRODUCTION

Plasma is a gas which has been heated to an extremely high temperature and ionized so that it becomes electrically conductive. The plasma arc cutting process uses this plasma to transfer an electrical arc to the workpiece. The metal to be cut is melted by the heat of the arc and then blown away.

2.02 GENERAL SPECIFICATION

Model Description	Drag-Gun Plus
Maximum output	35 Amps
Input Voltage & Phase	230V, Single Phase
Frequency	50/60Hz
Input power	8.3 kVA
Current Input fuse	U.S. / Canada 40 Amps All others 20A Slow Blow Fuse
No Load Voltage	330V
Load Voltage	94V
Output Current	10 - 35 Amps
Post flow time	15 Seconds
Duty cycle @ 104°F / 40° C Ambient	35% @ 35A @ 94vdc
	60% @ 27A @ 91vdc
	100% @ 20A @ 88 vdc
Genuine Cutting Capacity	3/8" (9 mm)
Maximum Cutting Capacity	1/2" (12mm)
Dimension (W * D * H)	10.5"x15.5"x11" (267 mm x 394 mm x 279 mm)


NOTE:

Refer to Local and National Codes or local authority having jurisdiction for proper wiring requirements.

2.03 Features

- COMPACT and LIGHT - Designed for easy transportation.
- ENERGY EFFICIENCY - Advanced technology reduces power consumption.
- HIGH SPEED GENUINE CUTTING - The constricted plasma arc provides high speed cutting as well as a good quality genuine, narrow cut.
- LOW COST WITH COMPRESSED AIR - The Drag-Gun Plus operates on compressed air.
- ALL KINDS OF METALS - Useful for most metals such as stainless steel, aluminum, mild steel, copper and their alloys.
- PILOT ARC IGNITION FROM TORCH - The Pilot Arc ignites the cutting arc.
- POWERFUL CUTTING PERFORMANCE - Genuine cutting capacity is 3/8" (9 mm).
- ABLE TO CUT PAINTED MATERIALS - Pilot Arc ignition allows the Drag-Gun Plus to cut painted materials.
- EXTENDED PARTS LIFE - Consumable parts life is longer.

2.04 Torch Specifications



PCH-42 Torch Ratings	
Torch Configuration	Torch Head at 70° to Torch Handle
Torch Leads Length	20 feet / 6.1 m
Ambient Temperature	104° F 40° C
Duty Cycle	100% @ 40 Amps @ 200 scfh
Maximum Current	40 Amps, DC, Straight Polarity
Voltage (V _{peak})	500V
Arc Striking Voltage	12kV
Type of Cooling	Ambient air and gas stream through torch
Parts-in-Place:	Built-in Switch in Torch Head
Gas Requirement:	Single Gas, Compressed Air Only
Input Gas Pressure	65 psi (4.5 bar) (.45MPa)- 125 psi (8.6 bar) (.86MPa)
Minimum Gas Flow	200 SCFH (142 lpm)
Direct Contact Hazard	For operation with exposed tip the recommended standoff height is 1/8 - 3/8" (3-9 mm).
Plasma Power Supply Used With:	Drag-Gun Plus

2.05 System Contents

Description	ITEMS	Q'ty
Power source	Model Drag-Gun Plus	1
Torch Set	PCH-42, with 20' (6.1 m) leads	1
Accessories & Consumables	Work Cable	1
	Manual	1
	Torch Electrodes	2
	Torch Tips	3
Input Power Cable U.S. / CAN.	3 Meter NEMA 10 AWG / 4.8 mm ² with 6 - 50 P molded plug	1
Input Power Cable Outside of U.S. / CAN.	3 Meter 3x2.5 sq mm rubber wire	1

2.06 Transporting Methods

Lift unit with handle on top of case. Use handcart or similar device of adequate capacity for transporting.



WARNING

ELECTRIC SHOCK can kill. DO NOT TOUCH live electrical parts. Disconnect input power from supply before moving the power source.

FALLING EQUIPMENT can cause serious personal injury and equipment damage.

SECTION 3: INSTALLATION

3.01 Site Selection

- Place in a clean and dry area.
- Provide adequate ventilation and fresh air supply.
- Ideal ambient temperature should not exceed 40°C / 104°F. Temperatures exceeding that may diminish cutting capacity or quality.
- The cutting machine must be placed on an even, firm surface so that it stands firmly.



This equipment must be electrically connected by a qualified electrician.

3.02 Electrical Input Connections

- Input voltage is 230V ± 10%, 50/60 Hz single phase.



Check your power source for correct voltage before plugging in or connecting the unit. The primary power source, fuse, and any extension cords used must conform to local electrical code and the recommended circuit protection and wiring requirements as specified in Section 2.

3.03 Torch

- Make sure that the torch cable and torch switch terminals are connected to front panel.
- Make sure the Work Cable is connected properly to front panel.
- Before activating, turn torch away from yourself and others.



Do not cut in humid or wet surroundings.

- Before you maintain or replace torch parts, wait for the post flow air cycle (approximately 15 seconds), to stop, then turn the machine off.
- Always use original manufacturers parts. The use of aftermarket parts could result in lower parts life and in unsatisfactory cutting results. Any warranty claims would be waived.
- Recycle worn parts according to local requirements.


NOTE

Repairs must be done by skilled and qualified personnel only.

This Page Left Blank




SECTION 4: OPERATION

4.01 Front Control Panel




Roll bars not shown for clarity

A. INDICATOR LAMP


- Power Indicator  - Lights when primary power switch is turned on.
- TEMPERATURE Indicator  - Indicator is normally OFF. Indicator is ON when internal temperature exceeds normal limits. Shut unit OFF; let the unit cool before continuing operation.
- Air Error Indicator  - This indicator lights and is accompanied by an intermittent audible tone when there is not enough air pressure to operate the power supply.


NOTE

It is possible to have enough air pressure to operate the power supply but not enough air flow to operate the torch.

- Torch Switch Latch Indicator  - This indicator lights when the Torch Switch Latch Button has been pressed for continuous cutting.


B. BUTTONS

- Torch Switch Latch Button  - For continuous cutting performance. Depress this button (turn "On") while cutting with the torch. Release the torch trigger and the torch will continue to cut without depressing the torch trigger.

- Air Set Button  - To check for proper air setting and to cool down heated torch.

C. MAIN CURRENT CONTROL KNOB

To adjust cutting current. Turning clockwise increases the cutting current and counter clockwise decreases the cutting current.



Art # A-04387

D. PRIMARY POWER SWITCH, ON / OFF

The power switch is located on the front panel. Placing the primary power switch to the "ON" position energizes the power source.



WARNING

When the power source is overloaded, the switch turns to the OFF position automatically. DO NOT TURN ON BY FORCE.

4.02 Preparations For Operating

At the start of each operating session:




WARNING

Disconnect primary power at the source before assembling or disassembling power supply, torch parts, or torch and leads assemblies.

A. Torch Parts Selection


Check the torch for proper assembly and appropriate torch parts. The torch parts must correspond with the type of operation, and with the amperage output of this Power Supply (35 amps maximum). Use only genuine manufacturer's parts with this torch.



B. Torch Connection


Check that the torch is properly connected.

C. Connect Work Cable



D. Torch Operation

- Wear gloves and protective goggles.
 - Do not place bare hand on work piece.
1. For **drag cutting**, keep the torch in contact with the workpiece.
 2. For **standoff cutting**, hold the torch 1/8 - 3/8 in (3-9 mm) from the workpiece as shown below.



3. With the torch in starting position, press and hold the Torch Trigger. After an initial two second pre-flow, the pilot arc will come on and remain on until the cutting arc starts.
4. Once on, the cutting arc remains on as long as the Torch Trigger is held down, unless the torch is withdrawn from the work or torch motion is too slow.
5. To shut off the torch simply release the Torch Trigger. When the trigger is released a gas post-flow will occur. If the Torch Trigger is pushed during the post-flow, the cutting arc will restart immediately when the torch is brought within range of the workpiece.

E. Typical Cutting Speeds

Cutting speeds vary according to torch output, the type of material being cut, and operator skill. Speeds shown are typical for this cutting system using air plasma to cut mild steel, with output current at the highest setting and torch held at the indicated standoff height.

Unit	Standoff	Material Thickness	Maximum Travel Speed		Recommended Travel Speed	
			ipm	mm/m	ipm	mm/m
Drag-Gun Plus	Drag	(10 ga) 0.135" - (3mm)	95.0	2375	76.0	1900
Drag-Gun Plus	Drag	(7 ga) 0.179" - (4.5mm)	57.0	1425	46.0	1150
Drag-Gun Plus	1/8" - (3mm)	1/4" - (6mm)	36.0	900	29.0	725
Drag-Gun Plus	1/8" - (3mm)	3/8" - (9.5mm)	15.0	375	12.0	300
Drag-Gun Plus	1/8" - (3mm)	7/16" - (11mm)	10.0	250	8.0	200
Drag-Gun Plus	1/8" - (3mm)	1/2" - (12mm)	8	200	7	175

NOTE:

Drag or Drag mode refers to the torch tip being in contact with the work piece at all times.

This Page Left Blank

SECTION 5: MAINTENANCE

5.01 General Maintenance




Warning!
Disconnect input power before maintaining.

Maintain more often
if used under severe
conditions

Each Use

Visual check of
torch tip and electrode




Weekly

Visually inspect the torch body
tip, electrode and shield cup




Visually inspect the
cables and leads.
Replace as needed




3 Months

Replace all
broken parts




Clean
exterior
of power supply



6 Months


Visually check and
Carefully clean the
interior



This Page Left Blank

SECTION 6: TROUBLESHOOTING

6.01 Normal Setup and Operation

1. Connect the unit to power.
2. Connect the work lead clamp to cleaned area of work surface.
3. Turn the switch located on the front panel, to the "On" position. The  A/C indicator on the front panel lights and the cooling fan comes on.
4. Select the correct current setting for the material being cut.
5. Squeeze the torch trigger. The pilot arc and compressor start.
6. Transfer arc to work surface within 3-5 seconds before the pilot arc turns off. If arc was lost before transfer to work surface, release the torch trigger and squeeze the trigger again to establish the pilot arc.
7. When the torch trigger is released, the compressor will continue to run for post flow, approximately 15 seconds.



WARNING

There are extremely dangerous voltage and power levels present inside this unit. Do not attempt to diagnose or repair unless you have had training in power electronics measurement and troubleshooting techniques. Disconnect primary power at the source before disassembling the power supply, torch, or torch leads.

NOTE:

All procedures are done with the cover removed.

6.02 Basic Trouble Shooting Guide

Problem - Symptom	Possible Cause	Recommended Action
Power Switch is on but the A/C Indicator does not light	<ol style="list-style-type: none"> 1. Improper electrical connection. 2. System was overloaded. 3. Switch may be faulty 	<ol style="list-style-type: none"> 1. Check input power source and fuse. Check input cable and connections. 2. Turn Primary Power Switch Off and then On again. 3. Return to authorized service center for repair or replacement
Primary power switch is on, but the cooling fan does not work.	<ol style="list-style-type: none"> 1. No power or incorrect power to fan. 2. Faulty fan. 	<ol style="list-style-type: none"> 1. Check electrical connections to fan. 2. Return to authorized service center for repair or replacement
No air flow at torch when air check switch is turned on.	<ol style="list-style-type: none"> 1. Internal connection is loose or disconnected. 2. Internal air supply / compressor not working. 3. Control PCB faulty 	<ol style="list-style-type: none"> 1. Check all air line connections and fittings. 2. Return to an authorized service center for repair. 3. Return to an authorized service center for repair.
Torch will not pilot when torch switch is activated.	<ol style="list-style-type: none"> 1. Air pressure too high or too low. 2. Torch consumables missing. 3. Worn or faulty torch parts 4. Thermal Switch activated 	<ol style="list-style-type: none"> 1. There is no adjustment, return to an authorized service center for repair.. 2. Turn off power supply. Remove shield cup. Install missing parts. 3. Inspect torch consumable parts. Replace if necessary. 4. Allow the cooling fan to run for 2 minutes or longer until it will resume operation.
Pilot / transfer arc goes out and doesn't reactivate	<ol style="list-style-type: none"> 1. Torch removed from work piece or moved away from metal being cut 	<ol style="list-style-type: none"> 1. Release torch trigger and re-establish the pilot arc. See block diagram Appendix 1
Cut performance is diminished.	<ol style="list-style-type: none"> 1. Worn torch parts. 2. Poor Work Lead connection. 3. Current sensor or PWM PCB faulty. 	<ol style="list-style-type: none"> 1. Check current setting. Check the Electrode and Tip for excess wear. 2. Check the connection of the Work Lead to the work piece. 3. Return to an authorized service center for repair or replacement.
Air flows continuously and torch switch latch button doesn't work properly.	<ol style="list-style-type: none"> 1. Torch Switch Latch button on front panel faulty. 2. Control PCB faulty. 	<ol style="list-style-type: none"> 1. Return to an authorized service center for repair or replacement. 2. Return to an authorized service center for repair or replacement.


6.03 Control PCB Indicators



There are extremely dangerous voltage and power levels present inside this unit. Do not attempt to diagnose or repair unless you have had training in power electronics measurement and troubleshooting techniques.

NOTE:

All procedures are done with the cover removed.

1. Turn the switch located on the front panel, to the "On" position. The  A/C indicator on the front panel lights and the cooling fan comes on.
2. Locate the Control PCB behind the front panel. LD2 (EN) LED should be "ON".





Illustration 6-1, Control PCB


3. Press the Air Set Button . The the air compressor should come on causing air to flow through the torch and LD1 (SOL) LED should light. Press the Air Set Button again and the air compressor stops and the LED goes out.
4. Squeeze the torch trigger. The pilot arc and compressor start. LD2 (EN) should brighten and LD1 (SOL) LED and LD4 (H/V) should be on.
5. Transfer the arc to the work surface within 3-5 seconds. LD4 goes off and LD3 comes on so that three LEDs are on.

NOTE:

If no transfer of arc occurs, check the work lead connection.

6.04 Open Circuit Voltage Check

1. Unplug the CN1 connector on the H/V (spark gap) PCB.
2. Turn unit power on.
3. Measure terminal TB2, Pins 1 and 3. It should be 230VAC.
4. Measure output voltage on Input diode (+ and -). It should be 325VDC.
5. Depress and hold the torch trigger for each of the following checks /steps, numbers 6 - 9. Each check has to be done within the 3-5 second pilot arc time. If not, then the trigger will have to be released and then depressed again.
6. Check for illumination of the "SOL" LED and that the "EN" (Enable) LED brightens on the Logic PCB.




Art # A-06991

Illustration 6-2

7. Measure output to Main Transformer Input between points 5 and 6 in Illustration 6-2 above. It should be 220VAC.
8. Measure Main Transformer secondary voltage between points 3 and 4 in Illustration 6-2 above. It should be 190VAC.
9. Measure output OCV between points 1 and 2 in Illustration 6-2 above. It should be 325VDC.
10. Turn off the unit power and plug the connector back in to CN1, removed in step 1 above.

6.05 Detailed Fault Finding / Error Indicators

Problem	Check / Test	Recommended Action
 Air Indicator is on and or audible intermitant tone	1 - Check air and electrical connections to the internal air compressor 2 - Control PCB faulty 3 - Check the compressor relay	1 - If connections are good, return to an authorized service center for repair. 2 - Replace the Control PCB 3 - Replace the relay if bad.
Torch doesn't Pilot and the LD1 LED light on the Control PCB is on	1 - Check torch consumables. 2 - Check all air supply related issues before proceding. 3 - Check LD2 (EN) LED it should get brighter with the torch trigger depressed. 4 - Check OCV Voltage. If OCV Voltage is OK check C/T 1 connection	1 - Replace torch consumables as needed. 2 - Change air related items as needed. 3 - If OCV is not OK, follow OCV check procedures in section 6.04 4 - If CN9 connection is OK, replace the Control PCB
Torch doesn't Pilot and the LD1 LED on the Control PCB is not on	Check all air supply related issues before proceding.	If there are no air related issues, replace the Control PCB
"CO" LED on Control PCB comes on when not transferring.	Check Cable Connection on PCB (CN10) and Current Sensor.	If connection and Current Sensor are OK, replace the Control PCB

A. Diode Testing Basics




WARNING

There are extremely dangerous voltage and power levels present inside this unit. Do not attempt to diagnose or repair unless you have had training in power electronics measurement and troubleshooting techniques. Disconnect primary power at the source before disassembling the power supply, torch, or torch leads. Discharge power at the H/V spark gap using a metal tipped screw driver as shown:


Testing of diode modules requires a digital volt/ohmmeter that has a diode test scale. Remember that even if the diode module checks good, it may still be bad. If in doubt, replace the diode module.

1. Remove AC power. Refer to Appendix 3 Wiring diagram.
2. Locate the IGBT diode module to be tested.
3. Remove P5 from IGBT module.
4. Set digital volt/ohmmeter to diode test scale.
5. Connect the volt/ohmmeter positive lead to the anode (+) of the diode and the negative lead to the cathode (-) of the diode for forward bias testing (refer to following figure). A properly functioning diode will conduct in the forward bias direction and indicate between 0.3 to 0.9 volts.



Testing Diode Forward Bias

- Reverse the meter leads across the diode for reverse bias testing (refer to following figure). A properly functioning diode will block in the reverse bias direction and depending on the meter function will indicate an open or "OL".



- Using the Figures for each test, check each diode in the module. Each diode must be checked in forward bias (plus to negative) and reverse bias (negative to plus) direction.

B. Component Tests



Disconnect primary power at the source before taking any resistance checks.

1. Input Diode Module Board Circuit Test

- a. Check Input Diode for short per schematic located in Appendix 4.

2. IGBT Module Test

- a. With an ohmmeter set on the diode range remove P5 from the IGBT and make the following IGBT checks:

Gate PCB J5 IGBT Check		
+	-	
E1	White +	DD (1.020)
White +	E1	Open After Charging
E1	Black -	Open After Charging
Black -	E1	DD (1.270)
E1	G1	DD (.770)
G1	E1	DD (.770)
E2	G2	DD (.770)
G2	E2	DD (.770)
E3	White +	DD (1.270)
White +	E3	Open After Charging
E3	Black -	DD (.770)
Black -	E3	DD (.770)
G3	E3	DD (.770)
E3	G3	DD (.770)
G4	E4	DD (.770)
E4	G4	DD (.770)

Diode Test

P5 Gate Connector		Control Connector		
1	G1 Black	CN8	1	Black
2	E1 White		2	White
3	G2 Green		3	Green
4	E2 Red		4	Red
5	G3 Black	CN6	1	Black
6	E3 White		2	White
7	G4 Green		3	Green
8	E4 Red		4	Red

Pin-out diagram

- b. If reading is not as shown, replace both IGBT modules and Gate PCB.
- c. Reconnect P5 connector.


6.06 Torch Tests



Disconnect primary power at the source before disassembling the power supply, torch, or torch leads.

1. PIP and Torch Switch Adapter Check

- Disconnect input power from power supply.
- Confirm that the torch parts are in place and that they match the parts consumables label on the power supply cover.
- Refer to Appendix 2 for torch connection and access. With the power supply on it's side and the panel removed, disconnect the Power Supply Adapter from the power supply.
- While the torch trigger is depressed, complete an Ohm check on the two pins in the Power Supply Adapter. The reading should show a short (less than 1 Ohm). Refer to diagram.



2. Shorted Torch Check

- Disconnect input power from power supply.
- Disconnect the pilot lead (see previous diagram).
- Perform an Ohm check of the pilot lead to the negative lead. This should show "Open". If it does not show "Open", check that the correct consumables were installed per the consumables label on the unit cover.
- Replace Torch as needed.

NOTE

Every effort has been made to provide complete and accurate information in this manual. However, the publisher does not assume and hereby disclaims any liability to any party for any loss or damage caused by errors or omissions in this Manual, whether such errors result from negligence, accident, or any other cause.

This Page Left Blank

SECTION 7: PARTS LIST

General Information

This parts list covers the Drag-Gun Plus® Model 35C Plasma Cutting Power Supply with Internal Air Compressor. Do not use these instructions or parts on any other equipment.

Provide the power supply model number and serial number when ordering parts.

If a product must be returned for service, contact your distributor. Materials returned without proper authorization will not be accepted.

Contact Information

Thermal Dynamics Technical Service Dept.

Tel: 1-800-752-7622 (1-800-PLASMA2)


Fax: 1-800-221-4401

e-mail address: tdc-tech@thermadyne.com


Replacement parts are shown on the following pages. Catalog numbers are shown below each part.

7.01 Parts List Power Supply


Item Number	Quantity	Description	Catalog Number
1	1	Cable Ground PG29	9-0382
2	1	Case, Front	9-0309
3	1	Circuit Breaker	9-7143
4	1	PCB-Front	9-7117
5	1	Cover-Drag Gun Plus	9-7217
6	1	Cable Ground PG21	9-0296
7	1	Case, Back	9-0311
8	1	Cooling Fan	9-7163
9	1	Case, Roll Bar	9-7218
10	1	Case, Top	9-0312
11	1	PCB-Control	9-7181
12	1	H/V PCB	9-7147
13	1	Relay	9-0319
14	1	PCB-Input Filter (shown)	9-7128
14	1	PCB-Input Filter (CE)	9-7133
15	1	Resistor	9-0300
16	1	Control Transformer	9-7144
17	1	Bracket, Capacitor	9-0302
18	1	Electrolytic Capacitor Assembly	9-0303
19	1	Compressor Part	9-0320
20	1	Bracket, Upper	9-0313
21	1	Current Sensor	9-7153
22	1	Case, Torch Cover	9-0314
23	1	Pilot Relay Assembly	9-0304
24	1	Connector	9-0305
25	1	Heat Sink Assembly	9-0306
26	1	Compressor Assembly	9-0316
27	1	Rubber Bushing	9-0318
28	1	PCB-Torch Filter	9-7121
29	1	Case, Bottom-Drag Gun Plus	9-0322
30	1	Main Trans and Reactor Assy	9-0315



Art # A-07771




Art # A-07772



Art # A-07773


Qty	Description	Catalog #
1	Two Stage Air Line Filter Kit (Includes Hose & Mounting Screws)	9-0397
1	Bracket, Filter Mounting (Not shown)	9-0396
1	Dual Stage Air Filter Assembly	9-0395
1	Replacement First Stage Cartridge	9-1021
1	Replacement Second Stage Cartridge	9-1022
1	90 degree 1/4 NPT to 6mm fitting (Not shown, requires two)	9-0398



7.02 Replacement Hand Torch Parts With Ergonomic Handle

Item #	Qty	Description	Catalog #
1	1	Assembly, Basic Head 70° Head	9-8442
2	2	PIP (Parts - In - Place) Pins	9-5723
3	1	#6-32 x 3/16" Phillips Pan Head Screw	See Note
4	1	#6 Internal Star Washer	See Note
	1	Ergonomic Handle, Split, with Trigger (includes items #5 - 12)	9-8076
5	1	Trigger, Lexan, Orange	9-8059
6	1	Handle	9-8060
7	1	Spring, 0.390 O.D. x 0.750	9-8061
8	1	Torch Handle Socket Head Cap Screw Kit (5 pcs 6-32 x 1/2")	9-8062
9	1	Assembly, Torch Switch	9-8063
10	1	Negative / Plasma Lead Insulation Sleeving	9-8056
11	3	Pin Housing (Used with item #12)	9-8111
12	3	Pin	9-8101
13	3	Socket Housing (Used with item #14)	9-8112
14	3	Socket	9-8102
15	1	Lead Assembly, including items No. 6, 8, and 9 20 ft (7.6 m) Length	4-2989


NOTE: Item can be purchased locally.



Art # A-07061

This Page Left Blank




Appendix 1: Operating Sequence, Block Diagram



Art # A-04694

Appendix 2: Torch Connection


Art # A-04695




Appendix 3: Microchip Pin-Out


40 Pin Microchip													
CPU Socket on Control PCB	P2	1	2	3	4	5	6	7	8	9	10	11	12
	P1	24	22	20	18	16	14	12	10	8	6	4	2
		23	21	19	17	15	13	11	9	7	5	3	1
	P3	1	2	3	4	5	6	7	8	9	10	11	12

Appendix 4: System Schematic 230V CE






Appendix 5: System Schematic 230V



Art # A-07024



This Page Left Blank



GLOBAL CUSTOMER SERVICE CONTACT INFORMATION

Thermadyne USA

2800 Airport Road
Denton, Tx 76207 USA
Telephone: (940) 566-2000
800-426-1888
Fax: 800-535-0557

Thermadyne Canada

2070 Wyecroft Road
Oakville, Ontario
Canada, L6L5V6
Telephone: (905)-827-1111
Fax: 905-827-3648

Thermadyne Europe

Europe Building
Chorley North Industrial Park
Chorley, Lancashire
England, PR6 7Bx
Telephone: 44-1257-261755
Fax: 44-1257-224800

Thermadyne, China

RM 102A
685 Ding Xi Rd
Chang Ning District
Shanghai, PR, 200052
Telephone: 86-21-69171135
Fax: 86-21-69171139

Thermadyne Asia Sdn Bhd

Lot 151, Jalan Industri 3/5A
Rawang Integrated Industrial Park - Jln Batu Arang
48000 Rawang Selangor Darul Ehsan
West Malaysia
Telephone: 603+ 6092 2988
Fax : 603+ 6092 1085

Cigweld, Australia

71 Gower Street
Preston, Victoria
Australia, 3072
Telephone: 61-3-9474-7400
Fax: 61-3-9474-7510

Thermadyne Italy

OCIM, S.r.L.
Via Benaco, 3
20098 S. Giuliano
Milan, Italy
Tel: (39) 02-98 80320
Fax: (39) 02-98 281773

Thermadyne International

2070 Wyecroft Road
Oakville, Ontario
Canada, L6L5V6
Telephone: (905)-827-9777
Fax: 905-827-9797

Corporate Headquarters

16052 Swingley Ridge Road

Suite 300

St. Louis, MO 63017

Telephone: 636-728-3000

Email: TDCSales@Thermadyne.com

www.thermadyne.com

THERMAL DYNAMICS
By THERMADYNE® 