

ITW Dynatec  
An Illinois Tool Works Company  
31 Volunteer Drive  
Hendersonville, TN 37075 USA  
Telephone 615.824.3634  
FAX 615.264.5222

ITW Dynatec GmbH  
Industriestrasse 28  
D-40822 Mettmann, Germany  
Telephone 49.2104.915.0  
FAX 49.210.2104.915.111

*OPERATIONS & SERVICE MANUAL*  
*Manual # 50-09*  
*Revised 12/11/02*




ITW Dynatec K.K.  
Daiwashinagawa Bldg., 7-15 Konan, 3-Chome  
Minata-Ku, Tokyo 108 Japan  
Telephone 81.3.3450.5901  
FAX 81.3.3450.8405

Adhesive Application Solutions • ISO 9001 Certified

## DPC-4 Distanced-Based Pattern Controller OPERATIONS MANUAL

Software V. 2.70



### **IMPORTANT ! - READ ALL INSTRUCTIONS BEFORE OPERATING THIS EQUIPMENT**

It is the customer's responsibility to have all operators and service personnel read and understand this information. Contact your ITW Dynatec customer service representative for additional copies.

**NOTICE!** Please be sure to include the serial number of your application system each time you order replacement parts and/or supplies. This will enable us to send you the correct items that you need.

ITW Dynatec Service Parts Direct Dial: 1-800-538-9540  
ITW Dynatec Technical Service Direct Dial: 1-800-654-6711

ITW Dynatec  
An Illinois Tool Works Company



---

Adhesive Application Solutions

## TABLE OF CONTENTS

<i>Chapter 1 Safety Instructions</i>	<i>Chapter - Page #</i>
Concerning this Instruction Manual . . . . .	1 - 1
Purpose of System . . . . .	1 - 1
Manual Symbols . . . . .	1 - 1
Authorized Use of System . . . . .	1 - 1
Installation, Maintenance, Repair or Disposal of System . . . . .	1 - 1
Modifications to the System . . . . .	1 - 1
Working with the Cover Open . . . . .	1 - 2
 <i>Chapter 2 Product Description</i>	
Description . . . . .	2 - 1
Specifications . . . . .	2 - 2
Dimensions . . . . .	2 - 3
Controller Layout . . . . .	2 - 3
 <i>Chapter 3 System Setup</i>	
Opening of Case . . . . .	3 - 1
Location of the electrical components . . . . .	3 - 2
Four-Channel-Box . . . . .	3 - 3
Setting of Overexcitation . . . . .	3 - 4
Turning On Overexcitation . . . . .	3 - 4
Adjustment of unit addressing . . . . .	3 - 4
Display-CPU-Board . . . . .	3 - 5
Adjustment of encoder type and resolution . . . . .	3 - 5
 <i>Chapter 4 Start Up</i>	
Power Supply Selection . . . . .	4 - 1
Socket Assignments . . . . .	4 - 2
Connecting to the System. . . . .	4 - 3
 <i>Chapter 5 Programming</i>	
Display Panel . . . . .	5 - 1
Turning the Controller ON . . . . .	5 - 3
Software Version Display . . . . .	5 - 3
Service Settings . . . . .	5 - 4
Channel Selection . . . . .	5 - 5
Photo-eye Allocation (tr.1) . . . . .	5 - 5
Glue Start (LSu) . . . . .	5 - 6
Glue Stop (LSd) . . . . .	5 - 6
Maximum Speed Selection (SPE) . . . . .	5 - 6
Glue Pressure for Manual Gluing (Pr.C) . . . . .	5 - 6
Activation, Deactivation or Change of Access Code (Cod) . . . . .	5 - 7
Continuous Gluing Start (co.1) . . . . .	5 - 7
Photo eye (trigger) Setup (A.tr) . . . . .	5 - 8
Encoder Step Size (Enc.) . . . . .	5 - 8
Trigger Lock #1 (tL1) . . . . .	5 - 8
Trigger Lock #2 (tL2) . . . . .	5 - 9
Slave Address (Adr.) OPTION . . . . .	5 - 9

Exit Service Settings .....	5 - 9
Pressure Indication and Adjustment .....	5 - 10
Adjustment of Minimum & Maximum Pressure .....	5 - 10
Glue Pattern Programming .....	5 - 11
Program Selection .....	5 - 11
Channel selection .....	5 - 11
Head Position .....	5 - 11
Programming Glue Distance and Glue Length .....	5 - 12
Compensating the Switching Times of Solenoid Valves .....	5 - 14
Activation and Deactivation of Manual Gluing .....	5 - 15
Programming Lock .....	5 - 15
Shutter Opening (used in cold glue applications only) .....	5 - 16
Glue Stop .....	5 - 16
Manual Stop .....	5 - 16
Automatic Stop .....	5 - 16
By External Signal (at X17) .....	5 - 16
Stitching Setup .....	5 - 17

**Chapter 6 Troubleshooting**

Fault Messages .....	6 - 1
General Reset (re-boot) to Restore System Defaults .....	6 - 2

**Chapter 7 Parts and Accessories**

Fuses .....	7 - 1
Accessories .....	7 - 1

**Chapter 8 Engineering Drawings**

Tach Generator, Wheel Bracket Assembly .....	8 - 1
Dynacold Non-Contact Bracket Assembly .....	8 - 2
Transducer Assembly .....	8 - 3
Dynacold Non-Contact System Overview .....	8 - 4
Typical Hot Melt Gear Pump System .....	8 - 6
Controller Bracket Assembly .....	8 - 8

**Appendix**

Installation Instructions for Sensor Bracket Assembly .....	1
Pressure Transducer .....	3

## Chapter 1 SAFETY INSTRUCTIONS

### *Concerning this Instruction Manual*

Every person installing, starting-up, operating, maintaining, repairing or disposing of this system must first read and understand this manual and follow the instructions described herein.

### *Purpose of System*

The DPC-4 controller is designed for use as a triggering device for adhesive application heads. Consult ITW Dynatec before using the DPC-4 in any other manner.

### *Manual Symbols*



**CAUTION**

This symbol means that failure to observe the specific instructions could cause damage to the equipment.



**DANGER! HIGH VOLTAGE!**

This symbol refers to the danger of electrical shock to personnel.

*NOTE:* This symbol indicates a note for handling this unit.

### *Authorized Use of System*

Only authorized persons who have read and understood the instruction manual(s) or who have been trained by ITW Dynatec may operate this system.

### *Installation, Maintenance, Repair or Disposal of the System*

Only authorized, trained personnel or personnel under their supervision may install, work on or dispose of the system. Electro-technical regulations must be observed.

### *Modifications to the System*

No modifications can be made to the system without consulting ITW Dynatec. Use only factory-recommended parts and fittings. ITW Dynatec does not assume any responsibility for damage which occurs as a result of using parts that are not factory recommended.

### ***Working with the Cover Open***

Inside the controller are electric current-carrying components. To avoid personal injury, do not touch them while input power is ON. Disconnect and lockout main power before opening the cover. Then wait a few seconds until all electrical components have discharged.

## Chapter 2 PRODUCT DESCRIPTION

### *Description*

ITW Dynatec's DPC-4 Pattern Controller (DY2006/4) is a component of an adhesive application system consisting of an adhesive application unit (ASU), hoses and applicator heads.

It has four outputs (channels) capable of triggering the solenoid valves of application heads in such a way that various glue patterns can be produced. Up to six glue tracks and glue stops of different lengths (ie, a "pattern") can be adjusted per application head. These patterns are stored in up to 24 programs.

For fastest operation, the solenoid valves can be triggered with higher than nominal voltage for a short time. This is referred to as "overexcitation". The height of voltage is adjustable and can be switched on or off for individual channels.

Glue flow can be initiated by photo eye or initiator or by external signals. When using the photo eyes or initiators, glue flow is released by corresponding impulses. When using an external input, there is glue flow for the duration of the signal. This method is termed "continuous gluing".

The speed of the production machine is read by an encoder and shown on the controller's LED display. This speed is transmitted as 0-10v voltage to the motor control of a gear-pump-equipped ASU. When production speed varies, glue pressures change accordingly.

In cold glue applications, two IP pressure transducers are controlled separately via two pressure outputs adapting the glue pressures when production speed varies.

A machine contact is provided to release and lock the controller.

The DPC-4 is equipped with a shutter output to prevent the application head's nozzles from drying out during production stops.

Pattern programming can also be controlled through a remote computer with a corresponding program through an RS232 or RS485 interface.


Critical conditions can be displayed by means of audible or optical signals via an output.

### Specifications


Operating temperature	0°C to 50°C (32°F to 122°F)
Storage temperature	-10°C to 50°C (32°F to 122°F)
Power supply	1/N/PE 230 V/ 50-60 Hz (selectable 1/N/PE 115 V/ 50-60 Hz)
Power consumption	150 VA
Fuse	1 A T at 230 V, 2 A T at 115 V
Indication of speed of production machine	max. 900 m/min (2700 ft/min)
Glue pressure adjustment	min/max-value 0 to 100 % scaleable
Max. adjustable way	8000 mm in steps of 1 mm 80.00 inch in steps of 0.01 mm
Channels X1 to X4 for triggering the solenoid valves (short circuit proof):	
Quantity	4
Triggering of solenoid valves:	
Normally	24 V DC
Overexcitation	55 V, 170 V (factory set) (common value for all channels, can be switched off individually)
Time of overexcitation	1.5-2.25 ms, adjustable internally
Wattage capacity per channel	40 W maximum
Wattage capacity of all channels	120 W maximum
Compensation of switching times	0-200 mm (inch)
Control voltage X9	0 to 10 V DC, max. 10 mA, scaleable
Pressure control X10 and X11	2 x 4-20 mA, scaleable
Photo eye / sensor X13 and X14	15 V DC, 100 mA maximum, NPN, PNP (push-pull not admissible)
Input gluing signal X15	15 V DC, NPN
Encoder X16	15 V DC, max. 100 mA, NPN (scaleable from version 2.0)
Machine contact X17	NPN
Alarm output X18	24 V DC, 500 mA maximum
RS232, RS485 interface X19	future option
Shutter X20	24 V DC, max. 2 A



## Dimensions



## Controller Layout



ITW Dynatec  
An Illinois Tool Works Company



---

Adhesive Application Solutions

## Chapter 3 SYSTEM SETUP

### Opening of Case



**DANGER! HIGH VOLTAGE!**


Before opening the unit switch it OFF and disconnect the main plug.



**DANGER! HIGH VOLTAGE!**


After switching off the unit, wait a few seconds until all electrical components have discharged voltage.

1. Press the buttons (illustration ref. #1) at both locking bars and pull them apart.




2. Remove screws on the backside (2) if necessary.



3. Remove the cover from the case.



## Location of Electronic Components



### Four-Channel Box



### ***Setting of Overexcitation***

Overexcitation is factory-set to 170 V. If system solenoid valves are not suitable for this voltage, overexcitation must be adjusted, per the following steps:

1. Disconnect, lockout and tag external electrical power.



**DANGER! HIGH VOLTAGE!**

Before opening the unit switch it OFF and disconnect the main plug.



**DANGER! HIGH VOLTAGE!**

After switching off the unit, wait a few seconds until all electrical components have discharged voltage.

2. Turn the Overexcitation Selection Switch (*page 3-3*) to the desired position.

**NOTE:** *The brightness of the 170 V LED is governed by the chosen overexcitation.*

3. Close the case and turn ON the unit.


### ***Turning On Overexcitation***

Overexcitation can be turned ON or OFF for each channel.

### ***Adjustment of Unit Addressing***

ITW Dynatec factory-sets which channels shall be driven with the unit. If replacing the controller, check the adjustment and reset the addressing, if necessary.

## Display-CPU Board



### Adjustment of Encoder Type and Resolution

The controller can be set to meter- or inch-based encoder types via DIP switch 3. The resolution is described in Chapter 5.

1. Disconnect, lockout and tag external electrical power and open the case.



**DANGER! HIGH VOLTAGE!**

Before opening the unit switch it OFF and disconnect the main plug.



**DANGER! HIGH VOLTAGE!**

After switching off the unit, wait a few seconds until all electrical components have discharged voltage.

2. Place dip switch 3 in the desired position.
3. Close the case and turn ON the unit.
4. Adjust the resolution of the encoder.
5. Change the service settings, if necessary (see Chapter 5).

ITW Dynatec  
An Illinois Tool Works Company



---

Adhesive Application Solutions



## Chapter 4 START UP



### CAUTION

Only authorized and trained personnel may service the DPC-4 Timer. Observe the safety instructions in Chapter 1.



### CAUTION

Be sure that the unit is placed in a dry and dust-free area and not in way of other machinery. Safe accessibility for service personnel must be ensured.

### Power Supply Selection


**NOTE:** The power supply voltage is adjustable and is visible in a window above the main switch on the rear of the unit. It is factory-set to 230 V (to 115 V in the U.S.).




### CAUTION

Make sure that the power supply is adjusted to the correct value.

1. Insert a screw driver into the slot (illustration reference #1, at right) above the main switch.
2. Pull out the safety compartment (2).
3. Pull out the voltage selector (3) with pointed pliers.



4. Turn the voltage selector (3) until the desired value is visible.




### CAUTION

Factory-installed fuses correspond to factory-set voltage.

5. Push in the voltage selector (3).
6. Return the safety compartment (2) to its original position and press in until it snaps.  
You can now read your new value in the window.

### Socket Assignments



Socket	Function	Pin Assignment					
		1	2	3	4	5	6
X1, X2, X3, X4	Triggering of application heads 1 to 4	+		-	Screen		
X9	Voltage 0-10V for ASUs with gear pump	0 V		0 to + 10 V			
X10, X11	Output pressure control 1 and 2: 4-20 mA	-	+				
X13, X14	photo eye / sensor 1 and 2	0 V	+15 V	Signal NPN/PNP			
X15	Continuous gluing input	0 V	Input 1 NPN	+15 V	Input 2 NPN	0 V	
X18	Alarm outputs	Alarm 1	Alarm 1	Alarm 2	Alarm 2		
X16	Encoder	0 V	+15 V	Signal NPN			
X17	Machine contact	0 V	Signal NPN				
X19	RS 232 or RS485	T+	TXD T-	RXD R+	R-	GND GND	
X20	Shutter	+		-	Screen		

## Connecting to the System


**NOTE:** Triggering the application heads is caused by overexcitation of 170 V (factory-set). Verify that the application heads are suitable for this voltage. Adjust if necessary (see Chapter 3).



1. Place all necessary plugs into the corresponding sockets (for assignments see page 4-2).
2. Screw the safety screws (#1 in illustration) tight to the sockets.
3. Connect the main connection cable to the main connection socket at the unit.
4. Connect the unit to the main circuit.

**NOTE:** Before turning on the unit, check whether the voltage setting is correct.

**NOTE:** Perform the service settings (see Chapter 5).



ITW Dynatec  
An Illinois Tool Works Company




---

Adhesive Application Solutions

## Chapter 5 PROGRAMMING

### Display Panel



- 1 Pattern input keys:** Depending on demand, the glue pattern can be divided into six beads and six glue stops. The length of beads and glue stops are adjustable and programmable (see page 5-11).
- 2 Speed and distance Display:** Displays the current speed of the production machine, a distance or another parameter.
- 3 Unit indication:** The scale (mm/ inch or meter/feet) of the value on the speed and distance display. Also indicates percentage (%) or "error".
- 4 Channel selection:** To select a desired channel.
- 5 Channel Display:** The selected channel's number or a system setting parameter.
- 6 Stop:** Press this key once to stop glue flow. Press again and glue flow resumes. Glue flow can also be stopped by reaching the minimum machine speed or through an external signal (page 5-16).

- 7 **Head position:** In order to ensure that glue flow starts at the intended point, distance between the application head and the photo eye must be set. This value is programmable between 0 and 8000 mm (page 5-11).
- 8 **Stitch:** The glue bead can be interrupted In order to conserve adhesive.
- 9 **Glue pressure adjustment:** The current pressure is indicated as well as a minimum and maximum glue pressure. Therefore the glue quantity delivered through the application heads can be adjusted. As the speed of the production machine increases, the amount of adhesive automatically increases. The minimum pressure value is the pressure when the production machine stops. The maximum pressure value is the pressure allowed at full speed of the production machine. Both values are adjustable from 0 to 100 % (page 5-9).
- 10 **C:** To exit the current menu.
- 11 **Enter:** To confirm a selected value.
- 12 **Scroll Up:** To increase the value.
- 13 **Scroll Down:** To decrease the value.
- 14 **Lock:** The controller can be locked to protect the programmed values (page 5-15).
- 15 **P: Program selection:** Programmed glue patterns can be stored in up to 24 programs (page 5-11).
- 16 **Compensation of application head switching times:** There are delays between the times that application heads open and close. These delays can be balanced through the compensation of switching times. These values are adjustable between 0 and 200 mm (page 5-14).
- 17 **Manual gluing:** Glue flow can be started manually, independent of programmed values (page 5-15).
- 18 **Service:** Selects the service settings menu (page 5-4).


## Turning the Controller ON

The master switch is on the rear side of the unit.



### CAUTION

Make sure that the power supply is adjusted to the correct value.



## Software Version Display



Briefly press the LOCK key.



Press "C" and hold.

The software version is displayed on the speed and distance display (e.g. software version 2.00).



## *Service Settings*

Program the following parameters after installation or modifications to the system:

- **Photo-eye allocation (tr1):** For a selected channel, choose its corresponding photo eye (1 or 2) or turn its photo eye OFF (page 5-5).
- **Glue Starting point as production line accelerates (LSu):** The speed above which gluing begins (page 5-6).
- **Glue Stop point as production line decelerates (LSd):** The speed below which gluing stops (page 5-6).
- **Maximum speed (SPE):** This value determines the speed for the maximum pressure and the maximum compensation (page 5-6).
- **Glue pressure for manual gluing (Pr.C):** In manual gluing mode, this value is programmable between 0 and 100% (page 5-6).
- **Activation, deactivation or change of access code (COD)** (page 5-7).
- **Adjustment of continuous gluing (co.1):** Choose conditions for continuous gluing for each channel (page 5-7).
- **Combination of photo eyes (triggers) (A.tr):** Allows the photo eyes to work independently or in combination with each other (page 5-8).
- **Encoder step size (Enc.):** Programs the number of impulses per meter or inch (page 5-8).
- **Trigger Lock #1 (tL1):** Establishes the length of trigger lockout for Trigger Input #1 (X13 connection) (page 5-8).
- **Trigger Lock #2 (tL2):** Establishes the length of trigger lockout for Trigger Input #2 (X14 connection) (page 5-9).
- **Adjustment of slave address (Adr.):** Allows an external computer connection via interface (page 5-9).



### Channel Selection




Press the Channel Selection key until the desired channel number appears. The LED lights.



Program the following items, when applicable, for the selected channel:

#### Photo Eye Allocation (tr.1)


To choose if the selected channel responds to photo eye 1 or 2, or to turn it OFF.



Press STOP.



Press SERVICE twice.



Enter the access code via the Pattern Input keys. (The access code has been factory set to "1111").



Press ENTER.

**NOTE:**

*If the wrong access code has been entered, the letters "Cod" appear on the display. Press C and repeat the setting with the correct code.*




Scroll UP or DOWN.



- 0: Channel not used (OFF)
- 1: Channel responds to photo eye 1
- 2: Channel responds to photo eye 2



Press ENTER.



Only the selected channel is programmed.

### Glue Start (LSu)

Program the point at which glue flow will start, as the machine accelerates.



Press SERVICE.



Scroll UP or DOWN until the desired value appears.




### Glue Stop (LSd)

Program the point at which glue flow will stop, as the machine decelerates.



Press SERVICE.



Scroll UP or DOWN until the desired value appears.



### Maximum Speed Selection (SPE)

This value determines the speed for the maximum pressure and the maximum compensation.



Press SERVICE.



Scroll UP or DOWN until the desired value appears.




**NOTE:** *This value is adjustable in steps of 25 m/min. Select the exact value or a value a little higher than desired.*

### Glue Pressure for Manual Gluing (Pr.C)


Used in manual gluing mode, this value is programmable between 0 and 100%.



Press SERVICE.




Scroll UP or DOWN until the desired value appears.



### Activation, Deactivation or Change of Access Code (Cod)



Press SERVICE.





Enter the new access code (e.g. 3311) via the Glue Pattern keys. (The access code is factory set to "1111").



Press LOCK to deactivate the access code.

Press LOCK again to activate the access code.



### Continuous Gluing Start (co.1, co.2, co.3, co.4)

Program the conditions for continuous gluing. Adjust each channel individually.



Press SERVICE.



Scroll UP or DOWN until the desired starting condition appears.




0: Continuous gluing OFF (default)

1: Continuous gluing if input 1 from X15 is active

2: Continuous gluing if low speed is reached

3: Continuous gluing if low speed is reached and input 1 is active




### Photo Eye (Trigger) Setup (A.tr)

Select the photo eyes to work independently or in combination with each other.



Press SERVICE.



Scroll UP or DOWN until the desired value appears.

0: Each photo eye is independent of the other.

1: Photo eye 2 depends on photo eye 1, i.e. gluing starts when a signal is given by photo eye 1 accompanied by photo eye 2.



Press ENTER.

### Encoder Step Size (Enc.)

Adjust the number of impulses per meter or inch (depending on the encoder used).



Press SERVICE.



Scroll UP or DOWN until the desired value appears.

This value is programmable between 500 and 4000 impulses/m (5.00 and 99.99 impulses/inch).




### Trigger Lock #1 (t.L.1)

The Trigger Lock establishes the distance the machine must travel, after it receives a trigger input, before it will accept the next trigger input. This is used to avoid a false trigger on a window or other irregularity in the product. The Trigger Lock value is normally set to the actual length of the object being glued. The Control Unit default value is 5mm or 0.50 inches. Care must be taken to reduce this value for products shorter than this length, otherwise product may not be glued consistently.

Trigger Lock #1 allows programming for the trigger device connected to the X13 input on the back panel of the Control Unit.




Press SERVICE.



Scroll UP or DOWN until the desired value appears.

This value is programmable between 5 and 9999mm (0.05 and 99.99 inches).



Press ENTER.

### Trigger Lock #2 (t.L.2)

This parameter is the same as Trigger Lock #1, except that it allows programming for the trigger device connected to the X14 input on the back panel of the Control Unit.



Press SERVICE.



Scroll UP or DOWN until the desired value appears.

This value is programmable between 5 and 9999mm (0.05 and 99.99 inches).



Press ENTER.

### Slave Address (Adr.) OPTION

Slave address programming is necessary only if an external computer is interfaced.



Press SERVICE.



Enter the slave address via the Glue Pattern keys (1-42).




Press ENTER.

### Exit Service Settings




Press C to leave the Service Settings menu. The last selected channel number appears.



## Pressure Indication and Adjustment

### Pressure Indication (Pr.1, Pr.2 or Pr.3)



Press the Pressure Indication key.  
Pressure indication LED 1 is lit.



The actual pressure in system 1 is indicated (in %).



Press the key again and the actual pressure in system 2 (Pr.2) is indicated. Pressure indication LED 2 is lit.



Press the key a third time and the actual pressure in system 3 (Pr.3) is indicated. Pressure indication LEDs 1 and 2 are lit.

### Adjustment of Minimum and Maximum Pressure

Minimum pressure is the pressure at production stop (PL1, PL2, PL3). Maximum pressure is the pressure at maximum production speed (PH1, PH2, PH3).




Press LOCK.



Press Pressure Indication.



The programmed minimum pressure (PL1) in system 1 is shown.



Scroll UP or DOWN until the desired value appears.



By pressing Pressure Indication again, the maximum pressure in system 1 (PH1) can be viewed and changed.



**NOTE:**

*If the Pressure Indication key is pressed a third time the minimum pressure in system 2 is indicated. If this key is pressed a fourth time the maximum pressure in system 2 is indicated, etc.*

## Glue Pattern Programming

### Program Selection

After programming, the glue patterns are stored as “programs”. There are 24 programs available.



Press P.



Scroll UP or DOWN until the desired program number appears. The orange LEDs on the Pattern Input keys show the number of adjusted glue beads in the corresponding program.




Press ENTER to select the program.



Press C to exit the program.


The selected channel number is displayed again.




### Channel Selection



Press the Channel Selection key until the desired channel number appears (the standard version has 4 channels). The following adjustments are applicable for the selected channel.




### Head Position




Press the Head Position key.



Measure the distance between the application head and the photo eye (measured value e.g. 40 mm).




Enter the measured value in mm (inch) by scrolling UP or DOWN.




### Programming Glue Distance and Glue Length



Press key 1.  
The key's green LED is lit.




Set the desired distance from the start of the substrate to the start of the first glue bead (e.g. 40 mm) by scrolling UP or DOWN.



Press key 1 a second time. The key's orange LED is lit.




Enter the desired length of the glue bead (e.g. 40 mm) by scrolling UP or DOWN.



Press key 2.  
The key's green LED and all LEDs in the previous keys are lit.








Set the desired distance from the start of the substrate to the start of the 2nd glue bead (e.g. 100 mm) by scrolling UP or DOWN.





**NOTE:**

*If the entered value is less than the sum of the distances previously entered, the letters "ERROR" will briefly flash on the red LED.  
(This prevents an overlapping of glue beads.)*



Press key 2 a second time. The key's orange LED is lit.




Set the desired length of the second glue bead (e.g. 20 mm) by scrolling UP or DOWN.



**NOTE:**

*If the scroll keys (UP and DOWN) are pressed simultaneously, the distance or glue length are set to a minimum or are switched OFF.*



**NOTE:**

*For more glue pattern programs, select the next program number (ie, program #2) and program as described above.*




Press C to exit this menu.

Press C again to indicate the number of glue beads.

**NOTE:**

*If no key is pressed for 20 seconds, the menu automatically returns to speed indication.*



### Compensating the Switching Times of Solenoid Valves




valid for max. speed





Press LOCK.




Press Compensation.  
 The first orange LED is lit.




Measure the delay of glue bead (e.g. 2 mm) and enter this value by scrolling UP or DOWN.




Press Compensation again.  
 The second orange LED is lit.



Measure the distance from the point where the glue bead should stop to the point where the glue bead actually stops (e.g. 1 mm) and enter this value by scrolling UP or DOWN.




Press C to exit this menu.



Repeat this adjustment for each channel.


## Activation and Deactivation of Manual Gluing



Press Stop.



Press Channel Selection until the desired channel number appears. All the following settings are valid for the selected channel.



Press Manual Gluing.  
 The key's LED lights. Manual Gluing is activated.

**NOTE:**

*If the LED is flashing, another channel is already in manual operation.*

The other channels can be switched to manual operation in the same way.



Press Manual Gluing.  
 The key's LED goes out. Manual Gluing is deactivated.

If more than one channel is in manual operation, press Stop to deactivate manual gluing in all channels.

## Programming Lock

This function prevents unauthorized programming changes.



The unit can be locked only if the speed is displayed. If not, press C to return to the speed display.



Press LOCK and hold for a few seconds. The unit is now protected against programming changes.



The unit can be unlocked only if the speed is displayed. If not, press C to return to the speed display.





Press LOCK and hold for a few seconds.



The access code can be entered via the Pattern Input keys.



Press ENTER.




### Shutter Opening (used in cold glue applications only)

The shutter automatically closes to prevent the nozzles from drying out when not in use.



If the speed is displayed, the shutter can be opened. If not, press C to return to the speed display.



Press STOP.



Press Channel Selection key for 5 seconds.




Press Manual Gluing. The shutter is opened.



### Stop Gluing

Glue flow is stopped by one of the following three methods:


#### 1. Manual Stop



Press Glue Stop. Glue flow is interrupted. The key's red LED lights.



Press Glue Stop again. Glue flow resumes. The LED goes out.



#### 2. Automatic Stop

When the minimum speed (as programmed) is reached, gluing automatically stops. The speed display flashes.

#### 3. By External Signal (at X17)

The Glue Stop LED flashes.


## Stitching Setup

For economical glue application, each glue bead can be interrupted several times ("stitching"). Adjustment of stitch length and gap will effect all glue beads in the selected channel.

### Stitch Activation/ Deactivation




Press Channel Selection until the desired channel number appears.  
 The LED is lit.




Stitching can be activated only if speed is displayed. If not, press C to return to speed display.



Press Lock.



Press the Stitch key.  
 The LED is lit.  
 The orange LED's for glue beads 1 - 6 show the active glue beads.  
 Stitching is activated when the LEDs flash.



Press the appropriate glue bead's key to activate or deactivate stitching.

### Stitch Length


#### The Glue Length LED lights.



Scroll UP or DOWN to change the stitch length shown in left display.



This adjustment applies for all glue beads in the selected channel.




**NOTE:** *The smallest increment of stitch length and gap length is one encoder step.*

**Example:** Encoder = 1000 imp/m  
 stitch increment = 1 mm

Encoder = 20.00 imp/inch  
 stitch increment = 0.05 inch

### Stitch Gap



Press the Stitch key.  
The Stitch Gap LED in the Stitch key is lit.




Scroll UP or DOWN to change the stitch gap length shown in left display.  
This adjustment applies for all glue beads of this channel which have been activated for stitching.



Press Channel Selection to switch to other channels.  
Adjust as outlined above.



Press C to leave the menu.



ITW Dynatec  
An Illinois Tool Works Company







---

Adhesive Application Solutions

## Chapter 6 TROUBLESHOOTING


### Fault Messages

Fault message	Possible cause	Remedy
Code error 	A wrong access code has been entered.	Press "C" and Service key and enter correct access code.
		If the factory-set access code 1111 has been changed and the new code is unknown, change the access code to 1111 via General reset (re-boot) (page 6-2).
Short circuit error 	A short-circuit fuse has been triggered in channels 1-4.	Switch the unit OFF and ON.
	A short-circuit fuse has been triggered in channels 1-4. Cable of application head has been plugged in with the controller switched ON.	If this fault message occurs again after switching the unit OFF and ON again, check the application head and cable for a short circuit.  Switch OFF the unit and plug the cable in again. Switch the unit ON.
Data error 	Memory component (EPROM) has been replaced (e.g. software update).	Press "C". All values will be reset to the controller's defaults (General Reset, see (page 6-2). If this error continues to occur, check for another failure.
	Battery of the SRAM component is dead.	This failure can only be repaired by ITW Dynatec service personnel.
	Display CPU board has been damaged by electrostatic charge.	This failure can only be repaired by ITW Dynatec service personnel.
	Trouble in main power supply.	Check the system power supply and verify that controller setup corresponds (see Chapter 4).
Communication error 	Electronic failure. An internal communication error occurred.	This failure can only be repaired by ITW Dynatec service personnel.



### General Reset (Re-boot) to Restore System Defaults


**NOTE:** Access code must be activated (page 5-7).



If the STOP LED is not ON, press the STOP key.



Press SERVICE.



Enter code "6161" via the Pattern Input keys.



Press ENTER.



Press C.




The unit now has been reset to the following defaults:

Access code	1111
Photo eye allocation (tr.1)	all channels are allocated to photo eye 1
Lead time and gluing length	all gluing stops and tracks are 10 mm (0.2 inch)
Lead time of system	20 mm (0.4 inch) for all channels
Starting point at increased speed (LSu)	20 m/min (160 ft/min)
Stop point at reduced speed (LSd)	30 m/min (240 ft/min)
Minimum pressure at machine stop (PL1, PL2, PL3)	0 %
Maximum pressure at max. machine speed (PH1, PH2, PH3)	100 %
Pressure at manual gluing	70 %
Maximum speed (SPE)	300 m/min (2400 ft/min)
Compensation of solenoid valve switching times	0 mm (0 inch)
Encoder step size (Enc.)	1 mm (0.02 inch)

## Chapter 7 PARTS & ACCESSORIES

### Fuses

Item	Part No.	Part	Quantity
1	05.11020.004	Main fuses 250 V 2 A T (for 120 V)	2
	05.11010.004	250 V 1A T (for 230 V)	
	05.11063.004	Fuse 4 Channel Box 24 V 4 A T	1



### Accessories

Item	Part No.	Part Description	Qty.
1	-----	Main cable (included in scope of supply)	1
2	05.01013.600	Adapter cable for application heads M12-C16	
3	05.02104.616	Connecting cable for solenoid valves of DynaCold, Dyna BF (without plug for application head side), 5 m	
3	05.01004.610	Connecting cable for solenoid valves of DynaCold, Dyna BF (without plug for application head side), 10 m	
4	05.01013.610	Adapter cable ("Y" cable) for connection of 2 solenoid valves	
5	05.21004.501	Connecting cable for solenoid valves of Macon application heads, 5 m	
6	05.67000.705	Automatic pressure control unit 1 connection incl. accessories with one electro-pneumatic transducer 05.67000.102	
7	05.67000.706	Automatic pressure control unit 1 connection incl. accessories with two electro-pneumatic transducers 05.67000.102	
8	05.67000.102	Electro-pneumatic transducer EIT 201-002B incl. connecting cable	
9	05.67000.105	Electro-pneumatic transducer IT 601-000 incl. connecting cable	
10	05.02103.603	Connecting cable, 5 m	
11	05.65400.501	Photo eye, round version, 5 ms incl. connecting cable	
12	05.65300.105	Photo eye, flat version, 1 ms incl. connecting cable	
13	05.02105.603	Connecting cable, 5 m	
	05.02105.612	Connecting cable, 10 m	
	05.02105.604	Connecting cable, 25 m	
14	70.90000.702	Encoder 500/U incl. friction wheel, holding device and connecting cable	
15	05.02104.603	Connecting cable, 5 m	
	05.02104.612	Connecting cable, 10 m	
	05.02104.604	Connecting cable, 25 m	
16	05.03002.001	Plug for machine contact, 2 pin	
17	05.03003.003	Plug for control voltage for gear pump units, 3 pin	
18	05.03003.005	Plug for input continuous gluing, 5 pin	
19	05.03003.006	Plug for alarm output, 6 pin	
20		Connecting cable for shutter, 4 pin (see item 3)	



ITW Dynatec  
An Illinois Tool Works Company



---

Adhesive Application Solutions

## Chapter 8 ENGINEERING DRAWINGS



DMC. NO.	106233	SHT.	1	REV.	B
REL.	REV.	DESCRIPTION	DATE	BY	APPROVED
N99014	A	INITIAL RELEASE	01.26.99	DRR	
99137	B	ITEM 3 WAS 105116	3.29.99	BB	

- MANUFACTURING NOTES:**
- ASSEMBLE ALL ITEMS EXCEPT 12, 14 & 15.
  - PLACE ITEMS 12, 14 & 15 IN A SMALL BAG.
  - PACKAGE ALL ITEMS, ALONG WITH A "B" SIZED COPY OF THIS DRAWING INTO A BOX TO PROTECT THE EQUIPMENT FROM DAMAGE DURING SHIPMENT.

- INSTALLATION NOTES:**
- SET 2006 "Enc" MENU TO 57.9 PPI.
  - USE ONLY MODERATE SPRING PRESSURE ON THE TACH GENERATOR SHAFT TO AVOID PREMATURE BEARING WEAR.


ITEM	QTY.	U/M	DESCRIPTION
15	2	EA	SCREW, HHC, 1/4-20 x 0.75
14	2	EA	WASHER, SPRING LOCK
13	2	EA	NUT, HEX, M4
12	3	EA	WASHER, FLAT, 1/4
11	4	EA	SCREW, FL. HD, 4-40x3/8
10	4	EA	WASHER, SPRING LOCK
9	1	EA	O-RING-224, VITON, 70D
8	1	EA	WHEEL, ENCODER DRIVE
7	1	EA	SCR.SET, M3-0.5x5
6	1	EA	SCR. SHOULDER, 6x30, M5
5	1	EA	SPRING, TORSION, ENCODER PRELOAD
4	1	EA	TACH GEN ASY, 1.5"φ, 15V, 360PPR
3	1	EA	SCREW, BHS, M4-0.7 x 12
2	1	EA	BRACKET, ENCODER MOUNT
1	1	EA	BRACKET, ENCODER SWIVEL

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES DECIMALS ARE TO BE FRACTIONS UNLESS NOTED OTHERWISE		PARTS LIST FOR MACHINING STANDARDS AND SYMBOLS, SEE TM/DMATED SPEC. ADDRESS	
USED ON	APPROVALS	DATE	STATUS
XXXXXXX	DRR	01.26.99	A
XXXXXXX	XXX	XXXXXX	A
DO NOT SCALE DRAWING	COMPUTER RESOLUTION (Z CHARACTER)	SIZE	REV. GROUP
	TG/MH/BRKT ASY, 2006 MINI	C	0
		DATE	SHEET
		1:1:1	1 of 1

**TW Dynatec**  
 HENDERSONVILLE, TN  
 106233  
 TACH GENERATOR, WHEEL &  
 BRACKET ASY, 2006 MINI  
 106233  
 CAD DRAWING  
 REV. 00  
 1 of 1

TACH GENERATOR, WHEEL BRACKET ASSEMBLY PN 106233 REV B

THIS DRAWING IS THE PROPERTY OF TW/DYNATEC.  
 DO NOT REPRODUCE OR DISCLOSE TO  
 OTHERS WITHOUT EXPRESS WRITTEN  
 CONSENT OF TW/DYNATEC.



NOTES:

1. PACKAGE ALL PARTS FOR SHIPMENT
2. INCLUDE A COPY OF THIS DRAWING WITH THE PARTS TO ASSIST CUSTOMER ASSEMBLY

ITEM	PART NUMBER	QTY.	U/M	DESCRIPTION	U/M
5	106202	1	EA	EXT'N ROD, 3/8" DIA, 10" LONG	EA
4	106201	1	EA	EXT'N ROD, 3/8" DIA, 5" LONG	EA
3	106207	2	EA	CROSS COUPLE BRACKET ASY	EA
2	106205	1	EA	HEAD SUPPORT ROD ASY, 16"	EA
1	106210	1	EA	BAR RECEIVER BRACKET ASY	EA


UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES FRACTIONS DECIMALS ANGLES F.S.		FOR MACHINING STANDARDS AND SYMBOLS, SEE TW/DYNATEC SPEC. A05890		APPROVALS		DATE	SIZE	DWG. NO.	REV.	GROUP
±	.XXX:00	±	F.S	DRAWN	DHR					
USED ON	XXXXXXXXXX	CHECKED	XXXXXX	COMPUTER DESCRIPTION(25 CHARACTERS)	BPKT ASY, DYNACOLD, NC					
NEXT ASSTY	XXXXXXXXXX	DO NOT SCALE DRAWING								

DWG. NO.		SHT.		REV.		REVISIONS					
106214		1		B		REL.	REV.	DESCRIPTION	DATE	BY	APPROVED
						N98184	A	INITIAL RELEASE	01.21.99	DHR	
						99308	B	CHG DWG TO REFLECT MODS TO ITEM #2	06.24.99	DHR	

**TW Dynatec**  
 HENDERSONVILLE, TN

DYNACOLD NON-CONTACT  
 BRACKET ASSEMBLY

SCALE 1:1 CAD DRAWING SHEET 1 of 1



105754 1 A  
 N98111 A INITIAL RELEASE 05/21/98 DHR


TRANSDUCER ASSEMBLY PN 105754 REV. A

**NOTES TO FACTORY**

1. BAG ALL LOOSE PARTS FOR ASSEMBLY UPON INSTALLATION
2. INCLUDE A COPY OF THIS DRAWING WITH THE LOOSE PARTS

**NOTE TO CUSTOMER**  
 USE THREAD SEALANT WHEN ASSEMBLING ALL FITTINGS

**WIRING INFO**




6	N00752	4	EA	NUT, 1/4-20
5	078C011	4	EA	WASHER, LOCK, 1/4
4	078A161	4	EA	SCREW, 1/4-20 X 5/8, SHC
3	N02535	1	EA	MUFFLER, AIR EXHAUST, 1/4 NPT
2	N06412	2	EA	FTG, 1/4NPT X 1/4 TUBE, ELBOW
1	105753	1	EA	XDUCER, I/P, 4-20 mA

UNLESS OTHERWISE SPECIFIED  
 DIMENSIONS ARE IN INCHES  
 DECIMALS ARE TO BE  
 FRACTIONS  
 UNLESS NOTED

XXXXXXXXX DHR 05/21/98 TRANSDUCER ASSY P  
 XXXXXXXX DHR 06/08/98 I/P, 4 TO 20 MA O  
 XXXXXXXX  
 XDUCER ASSY, I/P, 4-20 MA 1:1 105754 A 00  
 1 of 1

Xref G:\LIBRARY\ACAD\TBLOCK\C.dwg



NOTES


1. BALL VALVE CLOSED (LEVER 90° TO VALVE BODY) DURING NORMAL OPS. THIS BYPASS IS USED TO PURGE AIR FROM PUMP WHEN GLUE BARREL IS CHANGED OR TO AGITATE GLUE TO MIX SOLIDS.

2. USE BRACKET, P/N 106214, FOR EACH APPLICATOR.

3. TWO APPLICATORS SHOWN FOR ILLUSTRATIVE PURPOSES.

24	106337	2	EA	FITTING, JIC-5(F) x 1/4NPT(M)
23	NO6651	2	EA	FITTING, ELBOW, 10-32 x 1/4" TUBE
22	70.04000.703	2	EA	NOZZLE SEALING DEVICE
21	70.04000.762	2	EA	HOLD DOWN DEVICE
20	950-020	4	EA	PLUG, 1/8 NPT BRASS
19	950-079	2	EA	MANIFOLD ASY
18	775-006	A/N	FT	TUBING, 3/8" COLORED
17	775-005	A/N	FT	TUBING, 1/4" COLORED
16	775-003	A/N	FT	TUBING, 3/8" CLEAR
15	552-042	1	EA	FLUID DELIVERY SYSTEM
14	91.000XX.102	2	EA	NOZZLE, NON-CONTACT, XXMM
13	05.02104.616	3	EA	DYNACOLD CABLE ASY, 5M
12	105621	2	EA	FTG, 90°, 1/4 PT x 1/4 TUBE
11	70.04304.755	2	EA	DYNACOLD W/ FILTER
10	105720	1	EA	SHUTTER CONTROL VALVE ASY
9	106233	1	EA	ENDODER W/ WHEEL & BRKT
8	775-010	A/N	FT	TUBE, 1/4" CLEAR
7	950-158	5	EA	CAP, PLASTIC, 3/8 TUBE
6	05.02105.603	1	EA	SENSOR CABLE ASY, 5M
5	105083	1	EA	OPTICAL SENSOR
4	551-138	1	EA	AIR TREE ASY, 3 REGULATORS
3	105688	1	EA	CBL ASY, PRESSURE XDUCER, 10'
2	105754	1	EA	PRESSURE XDUCER ASY
1	26.11101.701	1	EA	DPC-4 PATTERN CONTROL






———— AIR LINE  
 - - - - - ELECTRICAL LINE

TYPICAL HOT MELT GEAR PUMP SYSTEM

TYPICAL HOT MELT GEAR PUMP SYSTEM

ITEM	PART NUMBER	QTY.	U/M	DESCRIPTION
1	108730	1	EA	DPC-4 RANDOM LENGTH CONTROL
2	107956	1	EA	ENCODER/WHEEL/BRACKET ASY
3	05.02104.612	1	EA	ENCODER EXTENSION CABLE, 5M
	05.02104.601	1	EA	ENCODER EXTENSION CABLE, 10M
4	108961	2	EA	TRIGGER DEVICE
5	108897	2	EA	SENSOR ADAPTER CABLE, 5M
6	05.02105.603	2	EA	TRIGGER EXTENSION CABLE, 5M
	05.02105.612	2	EA	TRIGGER EXTENSION CABLE, 10M
7	05.02104.616	2	EA	DRIVE OUTPUT CABLE, 5M
	05.01004.610	2	EA	DRIVE OUTPUT CABLE, 10M
8	105082	1	EA	0-10VDC OUTPUT CABLE, 3M
9	XXXXXX	1	EA	HOT MELT ASU (AS REQ)
10	XXXXXX	2	EA	HOT MELT HOSE (AS REQ)
11	XXXXXX	2	EA	HOT MELT APPLICATOR HEAD (AS REQ)
12	XXXXXX	2	EA	SOLENOID KIT, 24VDC (AS REQ)
13	100055	1	EA	AIR FILTER/REGULATOR KIT

NOTE: PART NUMBERS SHOULD BE CONSIDERED AS REPRESENTATIVE ONLY. SPECIFIC PART NUMBERS MAY VARY




Item No.	Part Number	Description	Qty.
1	105934	Support Bracket	1
2	105935	Mounting Bracket	1
3	N00592	5/16 Lock Washer	4
4	N00739	5/16-24 x .25 HHC Screw	2
5	N07809	5/16-18 x 2.5 SHC Screw	2
6	078C008	5/16 Flat washer	2
7	078C027	Lock Washer, #10	4
8	N01408	10-32 x .375 SHC Screw	4
9	N00804	10-32 x .25 SHC Screw	8
10	105754	Transducer Assembly (purchased separately)	1
11	26.11101.701	DPC-4 Controller (purchased separately)	1

PN 105947 DPC-4 CONTROLLER BRACKET ASSEMBLY

## APPENDIX Installation Instructions for PN 105850 DYNACOLD SENSOR BRACKET ASSEMBLY

### Introduction

The DynaCold Sensor Bracket Assembly is designed for use with either the standard or "F" (internal filter) series DynaCold high-speed adhesive applicators. It is capable of mounting a variety of reflective optical sensors offered by ITW Dynatec. The bracket's modular construction allows a significant amount of flexibility to accommodate virtually any installation scenario. Below is provided a sampling of various mounting possibilities for both the standard and "F" series applicators. A two-foot (0.6M) length of 5/32" steel rod is provided with the kit to be cut as required.



**PN 105850 DynaCold Sensor Bracket Assembly**


Item No.	Part Number	Description	Qty.
1	105852	Sensor Bracket Clamp Asy.	3
2	101691	M4-0.7 x 40 SHC Screw	1
3	103121	M4-0.7 Nut	1
4	078C029	Washer Lock #8	1

*(cont. next page)*


PN 105850 DynaCold Sensor Bracket Assembly, cont.

Item No.	Part Number	Description	Qty.
5	105848	0.156 Dia. SS Rod, 24"	1
6	078A341	4-40 x 1.25" SHC Screw	2
7	N05342	Lockwasher, #4	2
8	N00941	Hex Nut, 4-40	2

PN 105083  
 Mounting Photo Eye Assembly  
 Visible Red



PN 105081  
 Mounting Fiber Optic Assembly



## APPENDIX

### *PN 105763 Pressure Transducer*

*PN 105763 Pressure Transducer, cont.*

*PN 105763 Pressure Transducer, cont.*



*PN 105763 Pressure Transducer, cont.*

*PN 105763 Pressure Transducer, cont.*

ITW Dynatec  
An Illinois Tool Works Company



---

Adhesive Application Solutions