


XS750 Power Flow Schematic







THE BASIC MECHANISM

1-1. An Introduction to the Mechanism

Power is transmitted from the crankshaft through the clutch and two transmission shafts to a third shaft, called the middle driven gear. A splined drive cam fits inside the middle driven gear and transmits power to the driven cam, which is located on the middle gear shaft. The drive and driven cams act as a shock damper in the drive line. These cams remain in the same position relative to each other; that is, they do not "ratchet" or slip over when under heavy load. The middle gear case contains two geared shafts; the drive pinion (shaft and gear) and the driven pinion (gear). A flange rides on the driven pinion spline and is bolted to the ball joint. The ball joint acts like the universal joints in an automobile drive shaft. The ball joint is permanently lubricated and rarely requires replacement. The swing arm (rear arm) serves as both a suspension component and a housing for the drive shaft. Power is transmitted through the ball joint to the drive shaft, and to the splined gear coupling in the final gear case. In the Final Gear Case, the power is transmitted to the Drive Pinion, through the Ring Gear, and finally to the rear wheel.

NOTE: _____

The following illustrations represent only selected components and not the actual complete assembly.




The main service concerns of the Middle Gear Case assembly are:

- (1) Gear Lash: The play between the gear teeth. This can be adjusted by shimming.
- (2) Tooth Patterns: The locations and terms of contact that are made on the gear teeth. This can be adjusted by shimming.
- (3) Bearing Clearance: The distance between a bearing and its bearing housing cap. This is an extremely small clearance that must be carefully adjusted by shimming.

(4) Bearing Preload: The set load forcing tapered roller bearings against their races.

In this case it is measured as the torsional resistance of the driven pinion bearings. It is usually adjusted by replacing the Expansion Spacer and very carefully adjusting the torque on the special nut.







1-2. Lubrication

The maintenance of proper lubrication is the most important consideration that can be given to the shaft drive system by the owner or service person. Almost any significant wear or failure can usually be traced to low lubricant level, contaminated lubricant, or the wrong choice of gear oil. See Chapter 3 for specific gear oil recommendations and checking procedures.

1-3. Identification

Some component assemblies, such as the Middle Gear Case assembly, may contain components of more than one type. These different types will be identified in the text as Type 1 or Type 2. Precise serial number identification of applicable machines is not available.


		Identifying Feature
Middle Gear Case	Type 1	 A circular housing cap with four mounting holes. A label 'Housing cap' points to the center.
	Type 2	 A circular housing cap with four mounting holes. A label 'Housing cap' points to the center.
Final Gear Case	Type 1	 A perspective view of a gear case assembly with a central gear and various mounting points.
	Type 2	 A perspective view of a gear case assembly, similar to Type 1 but with a different internal structure. A label 'Screw' points to a screw on the top.

The application of parts of the individual types will be discussed in the appropriate section of this manual.

NOTE: _____
Type 1 Final Gear See Type 1 preload specification (spacertype)
Type 2 Final Gear See Type 2 preload specification (expansion spacer type)

SPECIAL TOOLS


The following special tools are necessary for complete servicing of shaft drive components.



Gear lash measurement tool (final gear)
P.No. 90890 - 01231




Gear lash measurement tool (middle gear)
P.No. 90890 - 01230



Middle and final gear holding tool
P.No. 90890 - 01229



Ring gear holding tool
P.No. 90890 - 01254



Dial gauge stand
P.No. 90890 - 01232



Torque wrench 0 - 30 cm-kg)
P.No. 90890 - 05147

In addition to these tools and common hand tools, the following are required:

1-ton press

Universal bearing puller

Feeler gauges

Loctite or similar thread sealant

Contact pattern paint (See Section 6-2)

Bearing installation collars



Torque wrench 0 ~10 m-kg (0 ~70 ft-lbs)

Dial gauge


The following special tools are not available but can be constructed for shaft drive component disassembly and assembly:

Press Tool No. 1 For final gear guide
coller removal (see page126)

Press Tool No. 2 For final gear roller bearing and oil seal installation
(see page)



Final Gear Stand




ROUTINE MAINTENANCE AND INSPECTION

3-1. GEAR OIL TYPE AND QUANTITY

Middle Gear Oil Capacity: 375 cc
(13.0 U.S. fluid oz)
Final Gear Oil Capacity: 300 cc
(10.0 U.S. fluid oz)

Recommended oil:



NOTE:

"GL-4" is a gear oil quality and additive rating. "GL-5" or "GL-6" designated gear oils of the proper weight may also be used.


Lubrication Intervals

Initial Gear Oil Change:
400 km (250 mi)

Routine Gear Oil Change:
every 9,600 km (6,000 mi)

NOTE:

Middle gear and final gear oil can be checked with same level gauge, which is in the owners tool kit.



3-2. OIL LEVEL MEASUREMENT

A. Place the machine on a level surface and place it on the center stand. The engine should be cool (at atmospheric temperature). Allow 2 minutes for oil to drain to bottom of cases.

B. Remove the oil filler cap. Check the oil level with level gauge (from tool kit) as shown. The correct oil level is between the two marks on each end of the level gauge. Use end of gauge marked "REAR" for measuring the rear (final) gear case. Use the end marked "MIDDLE" for measuring the middle gear case.

CAUTION:


Take care not to allow foreign material to enter the middle and/or final gear case.

3-3. GEAR OIL REPLACEMENT

NOTE: _____

See Chapter 4 regarding the inspection of drained oil. page 110


- A. Place an oil pan under the transmission for the middle gear and under the final gear case.



- B. Remove the middle and/or final gear oil filler cap(s) and the drain plug(s), and drain the oil.

WARNING:

When draining or filling, take care not to allow foreign material to enter the middle and/or final gear case. Do not allow the gear oil to contact the tire and wheel.



- C. Reinstall the middle and/or final drain plug(s).

MIDDLE GEAR DRAIN BOLT TORQUE:

4.3 m-kp (31 ft-lb)

FINAL GEAR DRAIN BOLT TORQUE:

2.3 m-kp (17 ft-lb)

- D. Fill the gear case(s) up to specified level.

Oil Capacity:

Middle Gear Case: 375 cc
(13.0 U.S. fl. oz)

Final Gear Case: 300 cc
(10.0 U.S. fl.)

Recommended oil: (See page 9)

- E. Reinstall the filler cap(s) securely.

NOTE: _____

After initial 400 km (250 mi) oil change, it is normally not necessary to change middle and final gear oil more frequently than the indicated service interval of 9,600 km (6,000 mi).

TROUBLESHOOTING

4-1. TROUBLESHOOTING CONDITIONS

Basic conditions	Possible damaged areas
1. A pronounced hesitation or "jerky" movement during acceleration, deceleration, or sustained speed. (This must not be confused with engine surging or transmission characteries). 2. A "rolling rumble" noticeabte at low speed; a high-pitched whine; a "clunk" from a shaft drive component or area.	A. Damage to bearings. B. Improper gear lash; improper gear tooth contact. C. Gear tooth damage. D. Drive flange/ball joint bolts loose.
3. A locked-up condition of the shaft drive mechanism; no power transmitted from engine to rear wheel.	E. Broken drive shaft. F. Disconnected flange/ball joint connection. G. Driven cam seized to middle gear drive pinion shaft. H. Broken gear teeth. I. Seizure due to lack of lubrication. J. Small foreign object lodged between moving parts.

NOTE: Damage areas A, B and C above may be extremely difficult to diagnose. The symptoms are quite subtle and difficult to distinguish from normal machine operating noise. If there is reason to believe component (s) are damaged, remove component(s) for specific inspection.

B. Consider the following

Inspection Notes:

- (1) During coasting, accelerating or decelerating, the “rolling rumble” will increase with rear wheel speed, not engine or transmission gear speeds. However, such noise may also be due to wheel bearings.
- (2) Noise that varies with acceleration and deceleration: Following incorrect reassembly, a condition of too-little gear lash may produce a whine during deceleration.

CAUTION:

Too-little gear lash is extremely destructive to gear teeth. If a test ride following reassembly indicates this condition, stop riding immediately to minimize damage to gears.

- (3) A slight “thunk” must be distinguished from normal machine operation. It will be most noticeable at low speed and could indicate broken gear teeth.

WARNING:

If broken gear teeth are suspected, stop riding immediately. This condition could lead to locking-up of the shaft drive assembly and result in harm to a rider.


- (4) If the drive flange/ball joint bolts are slightly loose, a “clunk” may be felt when slowly taking off, or when changing from slow acceleration to slow deceleration. At high speed this will result in vibration.

WARNING:

Do not continue riding a machine suspected of having loose flange/ball joint bolts. The components may break, causing injury to a rider.

C. Troubleshooting Chart


Where Basic Conditions (1) and (2) above exist, consider the following Chart:



D. Oil Leak Inspection

If a shaft drive component is suspected of leaking oil, first thoroughly clean the entire machine. The apparent location of an oil leak on a dusty machine may be misleading. Dry the machine and apply a leak-localizing compound or a dry-powder spray deodorant that will limit the flow of any leaking oil. Operate the machine prepared in this way for the distance necessary to precisely locate the leak. There are the possibilities that a component housing may have been damaged by road debris or an accident, or a gasket or seal may be cracked or broken. However, on new or nearly new machines an apparent oil leak may be the result of a rust-preventive coating or excess assembly lubrication of seals. Always clean the machine and recheck the suspected location of any apparent leakage.

Oil Seals and Gaskets



E. Checking Drained Oil

Whenever a problem is suspected in either the middle or final gear assemblies, drain and inspect the oil. Metal particles on the drain plug or in the oil could indicate a bearing seizure or other problem in the component. However, a small amount of metal particles in the oil is normal.

REMOVAL OF COMPONENTS

5-1. Removal of Components

It is normally not necessary to remove the engine to remove the Middle Gear Case.

A. Drive Shaft Joint

- (1) Pull rubber boot from drive shaft coupling to expose four (4) bolts.
- (2) Remove 4 coupling bolts;


NOTE:

Use the rear brake to **lock** the drive shaft.



C. Middle Gear Removal

Remove seven (7) middle gear case securing bolts, Remove the middle gear case, drive cam and spring.



1. Drive cam

2. Spring

B. Final Gear Removal


- (1) Remove rear axle and left shock absorber. Remove rear wheel. See XS750D Service Manual for procedures.
- (2) Remove 4 nuts holding Final Drive unit to swing arm.

NOTE:

Keep the Final Drive pinion bearing housing attached to the Final Drive assembly. It may tend to separate from the Final Gear (for Type 1 Final Gear only).

D. Drive Shaft

Remove drive shaft as shown.




- (3) Remove the Final Drive Gear assembly.

5-2. Checking Gear Lash


A. Check final drive gear lash as follows

- (1) Remove final drive gear case.
- (2) Temporarily secure bearing housing as follows (Type 1 and Type 2):
Place a thickness of washer (about 1/4 inch thick) over 2 opposite bearing housing studs. Install 2 nuts on these studs and temporarily tighten the bearing housing to the final drive housing.




1. Washers

- (3) Place gear case in a vice or other support.
- (4) Remove one nut from a final drive case stud bolt. Place gear holder (Special Tool) over ring gear surface and stud bolt. Tighten holder to stud bolt with nut.




1. Ring gear holding tool

- (5) Install final gear lash measurement tool on gear coupling (input side).



1. Gear lash measurement tool

- (6) Mount a dial gauge against the lash measurement tool at the scribed mark (60 mm (2.36 in) from the center of the shaft).



- (7) Use special wrench to gently rotate gear coupling back and forth. Note the lash measurement on the dial gauge.


FINAL GEAR LASH

0.25 – 0.50 mm (0.010 – 0.020 in):

When using the measurement tool.

0.1 – 0.2 mm (0.004–0.008 in):

Actual gear lash on the final gear teeth.




1. Middle and final gear holding

- (8) Check this engagement at **4** positions.
Rotate the shaft 90° each time and repeat the gear lash check.


MIDDLE GEAR CASE LASH
0.1 – 0.2 (0.004 – 0.008 in):
Measured value and actual gear lash
are the same.

B. Check middle gear lash as follows

- (1) Support gear case in a vise by the output shaft flange. Install the lash measurement tool on the input shaft as shown.




1. Gear lash measurement tool



1. Middle and final gear holding tool

- (4) Check this engagement at **4** positions.
Rotate the driven pinion shaft 90° each time and repeat the gear lash check.

- (2) Mount a dial gauge against the lash measurement tool at the scribed mark (**34 mm (1.34 in)** from the center of the shaft).



Hold the gear case and rotate the input shaft back and forth using the special wrench. Read the gear lash on the dial gauge.