



Model XGS868

**Startup Guide
(One- and Two-Channel)**



Process Control Instrument Division

**Model XGS868 Steam
Ultrasonic Mass Flow Transmitter
(1- & 2-Channel)**

Startup Guide

910-196UA

Table of Contents

Chapter 1: Installation

| | |
|--|------|
| Introduction | 1-1 |
| Warranty | 1-2 |
| Return Policy | 1-2 |
| Unpacking | 1-2 |
| Site Considerations | 1-3 |
| Electronics Enclosure Location | 1-3 |
| Flowcell Location | 1-4 |
| Transducer Location | 1-4 |
| Cable Lengths | 1-4 |
| Temperature and Pressure Transmitters | 1-4 |
| Transducer Cables | 1-4 |
| Installing a Flowcell | 1-5 |
| Installing Temperature and Pressure Transmitters | 1-5 |
| Mounting the XGS868 Electronics Enclosure | 1-6 |
| Making the Electrical Connections | 1-7 |
| Wiring the Line Power | 1-8 |
| Wiring the Transducers | 1-10 |
| Wiring the Standard 0/4-20 mA Analog Outputs | 1-12 |
| Wiring the Serial Port | 1-13 |
| Wiring the Option Cards | 1-15 |
| What Next? | 1-20 |

Chapter 2: Initial Setup

| | |
|----------------------------------|------|
| Introduction | 2-1 |
| Site Parameters | 2-1 |
| Programming Methods | 2-1 |
| Using the RCCU | 2-2 |
| Communications Failure | 2-3 |
| Accessing the User Program | 2-4 |
| The PROG Menu | 2-6 |
| The GLOBL Menu | 2-7 |
| The GLOBL-SYSTM Submenu | 2-7 |
| The CHx Menu | 2-12 |
| The ACTIV Submenu | 2-12 |
| The CHx-SYSTM Submenu | 2-13 |
| The PIPE Submenu | 2-18 |
| Exiting the User Program | 2-24 |

Table of Contents (cont.)

Chapter 3: Operation

| | |
|--------------------------------|------|
| Introduction | 3-1 |
| Powering Up..... | 3-2 |
| The Optional LCD Display | 3-3 |
| The Optional RCCU Display..... | 3-4 |
| Taking Measurements | 3-5 |
| The LCD Display..... | 3-5 |
| The RCCU Display | 3-9 |
| What Next?..... | 3-12 |

Chapter 4: Specifications

| | |
|-------------------------------------|-----|
| General Specifications | 4-1 |
| Electrical Specifications..... | 4-2 |
| Flow Transducer Specifications..... | 4-4 |
| Flowcell Specifications | 4-4 |

Appendix A: CE Mark Compliance

| | |
|--------------------|-----|
| Introduction | A-1 |
| Wiring..... | A-1 |

Appendix B: Data Records

| | |
|------------------------------|-----|
| Available Option Cards | B-1 |
| Option Cards Installed | B-2 |
| Initial Setup Data | B-3 |

Appendix C: Measuring P and L Dimensions

| | |
|------------------------|-----|
| Introduction | C-1 |
| Measuring P and L..... | C-1 |

List of Figures

Chapter 1: Installation

| | |
|--|------|
| Figure 1-1: A Typical Model XGS868 System | 1-3 |
| Figure 1-2: Typical Temperature/Pressure Transmitter Mounting..... | 1-6 |
| Figure 1-3: Rear Cover with Connection Labels | 1-8 |
| Figure 1-4: Typical RS485 Connections | 1-14 |
| Figure 1-5: Conventional and Fail-Safe Operation | 1-16 |
| Figure 1-6: Analog Input Wiring Diagram..... | 1-17 |
| Figure 1-7: Totalizer/Frequency Outputs Wiring..... | 1-18 |
| Figure 1-8: Model XGS868 Outline Drawing #712-1002 | 1-21 |
| Figure 1-9: Model XGS868 Mounting Techniques | 1-22 |
| Figure 1-10: Model XGS868 Wiring Diagram..... | 1-23 |
| Figure 1-11: Option Card Connection Labels | 1-24 |
| Figure 1-12: Transducer Wiring for Remote Mounted XGS868 | 1-25 |

Chapter 2: Initial Setup

| | |
|--|------|
| Figure 2-1: The RCCU Keypad and Display | 2-2 |
| Figure 2-2: Model XGS868 Front Window | 2-4 |
| Figure 2-3: Model XGS868 Initial Setup Menu Map..... | 2-25 |

Chapter 3: Operation

| | |
|--|-----|
| Figure 3-1: A Typical LCD Flow Rate Display | 3-3 |
| Figure 3-2: A Typical RCCU Flow Rate Display | 3-4 |
| Figure 3-3: Data Display Menu Map | 3-6 |

Appendix C: Measuring P and L Dimensions

| | |
|--|-----|
| Figure C-1: Top View of Typical Transducer Installations | C-2 |
|--|-----|

List of Tables

Chapter 1: Installation

| | |
|--|------|
| Table 1-1: RS232 Connection to DCE or DTE Device | 1-13 |
| Table 1-2: Wiring a 703-1223-08 Option Card. | 1-19 |

Chapter 2: Initial Setup

| | |
|---|------|
| Table 2-1: Available Volumetric/Totalizer Units | 2-8 |
| Table 2-2: Available Mass Flow Units | 2-10 |
| Table 2-3: Available Volumetric/Totalizer Units | 2-14 |
| Table 2-4: Available Mass Flow Units | 2-16 |
| Table 2-5: Available Pipe OD Units | 2-20 |

Chapter 3: Operation

| | |
|--|------|
| Table 3-1: Channel Options | 3-7 |
| Table 3-2: Display Parameter Options | 3-8 |
| Table 3-3: Channel Display Options | 3-10 |
| Table 3-4: Display Parameter Options | 3-11 |

Appendix A: CE Mark Compliance

| | |
|---------------------------------------|-----|
| Table A-1: Wiring Modifications | A-1 |
|---------------------------------------|-----|

Appendix B: Data Records

| | |
|---|-----|
| Table B-1: Option Card Configurations | B-1 |
| Table B-2: Option Cards Installed | B-2 |
| Table B-3: Initial Setup Data | B-3 |

Chapter 1

Installation

| | |
|---|-------------|
| Introduction | 1-1 |
| Warranty | 1-2 |
| Return Policy | 1-2 |
| Unpacking | 1-2 |
| Site Considerations | 1-3 |
| Installing a Flowcell | 1-5 |
| Installing Temperature and Pressure Transmitters | 1-5 |
| Mounting the XGS868 Electronics Enclosure | 1-6 |
| Making the Electrical Connections | 1-7 |
| What Next? | 1-20 |

Introduction

To ensure safe and reliable operation of the Model XGS868 Steam Ultrasonic Mass Flow Transmitter, the system must be installed in accordance with the guidelines established by Panametrics' engineers. Those guidelines, which are explained in detail in this chapter, include the following specific topics:

- Unpacking the Model XGS868 system
- Selecting suitable sites for the electronics enclosure and the flowcell/transducers
- Installing the flowcell/transducers

Note: *See the enclosed Gas Transducer Installation Guide (916-049) for detailed instructions on transducer installation.*

- Installing optional temperature and pressure transmitters
- Installing the electronics enclosure
- Wiring the electronics enclosure

!WARNING!

The Model XGS868 flow transmitter can measure the flow rate of many gases, some of which are potentially hazardous. In such cases, the importance of proper safety practices cannot be overemphasized.

Be sure to follow all applicable local safety codes and regulations for installing electrical equipment and working with hazardous gases or flow conditions. Consult company safety personnel or local safety authorities to verify the safety of any procedure or practice.

!ATTENTION EUROPEAN CUSTOMERS!

To meet CE Mark requirements, all cables must be installed as described in Appendix A, *CE Mark Compliance*.

Warranty

Each Panametrics instrument is warranted to be free from defects in materials and workmanship. Liability under this warranty is limited to servicing an instrument returned to the factory for that purpose and/or replacing any defective parts. Fuses, batteries, and cables are specifically excluded from any liability. This warranty is effective for one year from the date of delivery to the original purchaser, provided the instrument has been installed and operated in the manner described in this User's Manual. Panametrics must determine that the instrument was defective for this warranty to be valid. If damage is determined to have been caused by misuse or abnormal conditions of operation, the owner will be notified and approved repairs will be billed at standard rates.

Return Policy

If any problem develops, the following steps should be taken:

1. Notify Panametrics, giving full details of the difficulty, and provide the model and serial numbers of the instrument. Upon notification, Panametrics will then supply a **RETURN AUTHORIZATION NUMBER** and/or shipping instructions, depending on the problem.
2. If Panametrics provides instructions for returning the instrument to the factory, it must be sent prepaid to the authorized repair station specified in the shipping instructions.
3. If the warranty has expired or the damage has been caused by misuse or abnormal operating conditions, an estimate will be provided before any repairs are begun.

A *Service Form* is included in back of this manual along with a list of Panametrics offices. Send the completed Service Form to the closest office for the fastest service. If you need additional forms, write to:

Panametrics Inc.
221 Crescent Street, Suite 1
Waltham, Massachusetts 02453-3497
Attn.: Technical Publications Department

Unpacking

Carefully remove the electronics enclosure, the transducers, and the cables from the shipping containers. Before discarding any of the packing materials, account for all components and documentation listed on the packing slip. The discarding of an important item along with the packing materials is all too common. If anything is missing or damaged, contact the factory immediately for assistance.

Site Considerations

Because the relative location of the flowcell and the electronics enclosure is important, use the guidelines in this section to plan the XGS868 installation. Figure 1-1 below shows a typical XGS868 enclosure and spoolpiece ready for insertion into a process line.




Figure 1-1: A Typical Model XGS868 System

Electronics Enclosure Location

The standard Model XGS868 electronics enclosure is a powder-coated, cast-aluminum, NEMA-7/4X explosion-proof enclosure; an optional stainless-steel enclosure is available. Typically, the enclosure is mounted as close as possible to the transducers. When choosing a site, make sure the location permits easy access to the electronics enclosure for programming, maintenance and service. If an RCCU will be used to communicate with the unit, the electronics enclosure window must have a clear line-of-sight from a distance of ≤ 8 ft (2.5 m) with an angle of incidence $\leq 15^\circ$.

Note: *For compliance with the European Union's Low Voltage Directive (73/23/EEC), this unit requires an external power disconnect device such as a switch or circuit breaker. The disconnect device must be marked as such, clearly visible, directly accessible, and located within 1.8 m (6 ft) of the Model XGS868.*

| | |
|---------------------------------------|---|
| Flowcell Location | The pipeline flowcell consists of the flow rate transducers and any pressure and/or temperature transducers employed as part of the flow measurement system. Ideally, choose a section of pipe with unlimited access to the flowcell; for example, a long stretch of pipe that is above ground. However, if the flowcell is to be mounted on an underground pipe, dig a pit around the pipe to facilitate installation of the transducers. |
| Transducer Location | <p>For a given fluid and pipe, the Model XGS868's accuracy depends primarily on the location and alignment of the transducers. In addition to accessibility, when planning for transducer location, adhere to the following guidelines:</p> <ol style="list-style-type: none">1. Locate the transducers so that there are at least 20 pipe diameters of straight, undisturbed flow upstream and 10 pipe diameters of straight, undisturbed flow downstream from the measurement point. To ensure undisturbed flow, avoid sources of turbulence in the fluid such as valves, flanges, expansions and elbows; swirl; and dips or low spots in which condensed liquid may collect.2. Because condensate or sediment at the bottom of the pipe may cause attenuation of the ultrasonic signal, locate the transducers on the side of a horizontal pipe, when possible. If limited pipe access necessitates top-mounted transducers and the sound beam path includes a reflection, shift the transducers to at least 10° off top dead center. This will minimize the influence of any sediment on the reflected ultrasonic signals. |
| Cable Lengths | Locate the electronics enclosure as close as possible to the flowcell/transducers, preferably directly on the flowcell. However, Panametrics can supply transducer cables up to 1,000 ft (300 m) in length for remote location of the electronics enclosure. If longer cables are required, consult the factory for assistance. |
| Temperature and Pressure Transmitters | When installing temperature and/or pressure transmitters in the flowcell, locate them downstream of the transducers. These transmitters should be positioned no closer to the Model XGS868 transducers than 2 pipe diameters and no further away from the transducers than 20 pipe diameters. |
| Transducer Cables | When installing the transducer cables, always observe established standard practices for the installation of electrical cables. Specifically, do not route transducer cables alongside high amperage AC power lines or any other cables that could cause electrical interference. Also, protect the transducer cables and connections from the weather and corrosive atmospheres. |

Transducer Cables (cont.)

Note: *When using non-Panametrics cables to connect the flow rate transducers to the Model XGS868 electronics enclosure, the cables must have electrical characteristics identical to the Panametrics cables. Type RG62 a/U coaxial cable should be used, and each cable must be the same length (within ± 4 in.).*

Installing a Flowcell

A flowcell is the section of pipe where the transducers are mounted. It can be created either by mounting the transducers on the existing pipeline or by mounting them on a spoolpiece. A spoolpiece is a separately manufactured pipe section, matched to the existing pipe, which contains ports for mounting the transducers. This approach allows the transducers to be aligned and calibrated before inserting the spoolpiece into the pipeline.

Figure 1-1 on page 1-3 shows a typical Model XGS868 spoolpiece, with a mounting bracket to hold the electronics enclosure. For detailed instructions on installing the transducers and/or spoolpiece, refer to the supplied drawings and the enclosed Panametrics *Gas Transducer Installation Guide (916-049)*.

Installing Temperature and Pressure Transmitters

Optional temperature and pressure transmitters may be installed near the ultrasonic transducer ports as part of the flowcell. Be sure to observe the siting requirements given earlier in this chapter. These transmitters should send a 0/4-20 mA signal to the Model XGS868. In turn, the Model XGS868 must be fitted with a suitable option card to process the signals and to provide the required 24 VDC power to the transmitters. Any desired transmitters or sensors may be used, but they must have an accuracy equal to 0.5% of the reading or better.

Note: *Resistive Thermal Devices (RTDs) are a good choice for measuring the temperature.*

Typically, a 1/2" NPT female threaded port is used to mount the transmitters on the flowcell. If the pipeline is insulated, the coupling may need to be extended to provide convenient access. Of course, other types of mounting ports, including flanged ports, may be used for the transmitters.

IMPORTANT: *Under changing temperature and pressure conditions, the Model XGS868 can calculate accurate steam density and mass flow only if live temperature and pressure transmitters have been installed in the system.*

Figure 1-2 on page 1-6 shows a typical mounting arrangement for the pressure and temperature transmitters. The temperature sensor should protrude 1/4 to 1/2 way into the pipe.




Figure 1-2: Typical Temperature/Pressure Transmitter Mounting

Mounting the XGS868 Electronics Enclosure

The standard Model XGS868 electronics package is housed in a NEMA-4X weather-resistant enclosure suitable for indoor or outdoor use. Refer to Figure 1-8 on page 1-21 for the mounting dimensions and the weight of this enclosure.

!WARNING!

If a unit equipped with an optional LCD display board is being installed in a hazardous area, be sure to adjust the backlight brightness and display contrast before mounting the electronics enclosure. See Chapter 2, *Displaying Data*, in the *Programming Manual* for details.

The Model XGS868 electronics enclosure is fitted with a mounting boss that has a single 3/4" NPTF threaded hole at its center and four 1/4-20 tapped holes at its corners. By using this mounting boss, the electronics enclosure may be mounted by any of the typical techniques shown in Figure 1-9 on page 1-22.

Making the Electrical Connections

This section contains instructions for making all the necessary electrical connections to the Model XGS868 flow transmitter. Refer to Figure 1-10 on page 1-23 for a complete wiring diagram.

Except for the power connector, all electrical connectors are stored on their terminal blocks during shipment and may be removed from the enclosure for more convenient wiring. Simply, feed the cables through the conduit holes on the side of the enclosure, attach the wires to the appropriate connectors and plug the connectors back onto their terminal blocks.

!ATTENTION EUROPEAN CUSTOMERS!
To meet CE Mark requirements, all cables must be installed as described in Appendix A, *CE Mark Compliance*.

Refer to Figure 1-3 on page 1-8 and prepare the Model XGS868 for wiring by completing the following steps:

!WARNING!
Always disconnect the line power from the Model XGS868 before removing either the front cover or the rear cover. This is especially important in a hazardous environment.

1. Disconnect any existing power line from its source.
2. Loosen the set screw on the rear cover.
3. Place a rod or long screwdriver across the cover in the slots provided, and rotate the cover counterclockwise until it comes free from the enclosure.
4. Install any required cable clamps in the appropriate conduit holes around the side of the enclosure.
5. Note the labels inside the rear cover to assist in wiring the power and option card connections. Also, Figure 1-11 on page 1-24 shows the rear cover option card labels for every available option card configuration.

Proceed to the appropriate section of this chapter to make the desired wiring connections.




Figure 1-3: Rear Cover with Connection Labels

Wiring the Line Power

The Model XGS868 may be ordered for operation with power inputs of 100-120 VAC, 220-240 VAC, or 12-28 VDC. The label on the side of the electronics enclosure lists the meter's required line voltage and power rating. The fuse size is listed in Chapter 4, *Specifications*. Be sure to connect the meter only to the specified line voltage.

Note: *For compliance with the European Union's Low Voltage Directive (73/23/EEC), this unit requires an external power disconnect device such as a switch or circuit breaker. The disconnect device must be marked as such, clearly visible, directly accessible, and located within 1.8 m (6 ft) of the Model XGS868.*

Refer to Figure 1-10 on page 1-23 to locate terminal block TB5 and connect the line power as follows:

!WARNING!

Improper connection of the line power leads or connecting the meter to the incorrect line voltage may damage the unit. It may also result in hazardous voltages at the flowcell and associated piping as well as within the electronics enclosure.

Wiring the Line Power (cont.)

1. Prepare the line power leads by trimming the line and neutral AC power leads (or the positive and negative DC power leads) to a length 0.5 in. (1 cm) shorter than the ground lead. This ensures that the ground lead is the last to detach if the power cable is forcibly disconnected from the meter.
2. Install a suitable cable clamp in the conduit hole indicated in Figure 1-10 on page 1-23. If possible, avoid using the other conduit holes for this purpose, to minimize any interference in the circuitry from the AC power line.

!ATTENTION EUROPEAN CUSTOMERS!
To meet CE Mark requirements, all cables must be installed as described in Appendix A, *CE Mark Compliance*.

3. Strip 1/4 in. of insulation from the end of each of the three power line leads.
4. Route the cable through the conduit hole and connect the line power leads to terminal block TB5, using the pin number assignments shown in Figure 1-10 on page 1-23.
5. Leaving a bit of slack, secure the power line with the cable clamp.

!WARNING!
Make sure both covers, with their o-ring seals, are installed and the set screws tightened before applying power in a hazardous environment.

Note: *If a unit with an optional LCD display board is being installed in a hazardous area, be sure to adjust the backlight brightness and display contrast before mounting the electronics enclosure. See Chapter 2, Displaying Data, in the Programming Manual for details.*

Caution!
The transducers must be properly wired before applying power to the meter.

Proceed to the next section to continue the initial wiring of the Model XGS868 flow transmitter.

Wiring the Transducers

Before wiring the XGS868 transducers, complete the following steps:

- disconnect the main power from the electronics enclosure
- remove the rear cover and install all required cable clamps

Based on the location of the electronics enclosure, proceed to the appropriate sub-section for detailed instructions.

Flowcell-Mounted Enclosure

For an electronics enclosure mounted directly on the flowcell, wire the transducers as follows:

!WARNING!

Before connecting the transducers, take them to a safe area and discharge any static buildup by shorting the center conductor of the transducer cables to the metal shield on the cable connector.

Note: *For transducer frequencies below 2 MHz, the cable lengths must be within 4 in. (10 cm) of each other. If the transducer frequency exceeds 2 MHz, the cable lengths must be within 0.5 in. (1.25 cm) of each other.*

1. Locate the CH1 transducer cables and connect them to the two CH1 transducers in the flowcell. Feed the free ends of the cables through the selected conduit hole in the electronics enclosure.
2. Refer to the wiring diagram in Figure 1-10 on page 1-23 and connect the transducer cables to terminal block J3. Then, secure the cable clamp.

Note: *The RED cable leads are the SIG(+) leads and the BLACK cable leads are the RTN(-) leads.*

!ATTENTION EUROPEAN CUSTOMERS!

To meet CE Mark requirements, all cables must be installed as described in Appendix A, CE Mark Compliance.

3. For a 2-Channel XGS868, repeat steps 1-2 to connect the CH2 transducers to terminal block J4. It is not required that both channels of a 2-Channel unit be connected.
4. If wiring of the unit has been completed, reinstall the rear cover on the enclosure and tighten the set screw.

Note: *A channel must be activated before it can begin taking measurements. See Chapter 2, Initial Setup, for instructions.*

Remote-Mounted Enclosure

For a remote mounted enclosure, refer to the wiring diagram in Figure 1-10 on page 1-23 and the remote transducer wiring in Figure 1-12 on page 1-25, and complete the following steps:

!WARNING!

Before connecting the transducers, take them to a safe area and discharge any static buildup by shorting the center conductor of the transducer cables to the metal shield on the cable connector.

1. Using the pair of coaxial cables with BNC to BNC connectors supplied by Panametrics (or equivalent cables), connect both CH1 transducers to the preamplifier.

Caution!

As part of maintaining the FM/CSA environmental rating (NEMA/TYP E 4) on the remote preamplifier, thread sealant is required on all conduit entries.

2. If an optional lightning protector is being installed, connect it to the preamplifier as shown.
3. Using the supplied coaxial cables with BNC to flying lead connectors (or equivalent cables), route the cables through one of the conduit holes in the electronics enclosure and connect the preamplifier to terminal block J3. Secure the cable clamp.

Note: *The RED cable leads are the SIG(+) leads and the BLACK cable leads are the RTN(-) leads.*

!ATTENTION EUROPEAN CUSTOMERS!

To meet CE Mark requirements, all cables must be installed as described in Appendix A, CE Mark Compliance.

4. For a 2-Channel XGS868, repeat steps 3-5 to connect the CH2 transducers to terminal block J4 in the electronics enclosure. It is not required that both channels of a 2-Channel unit be connected.
5. If wiring of the unit has been completed, reinstall the rear cover on the enclosure and tighten the set screw.

Note: *A channel must be activated before it can begin taking measurements. See Chapter 2, Initial Setup, for instructions.*

Proceed to the next section to continue the initial wiring of the unit.

Wiring the Standard 0/4-20 mA Analog Outputs

The standard configuration of the Model XGS868 flow transmitter includes two isolated 0/4-20 mA analog outputs (designated as outputs 1 and 2). Connections to these outputs may be made with standard twisted-pair wiring, but the current loop impedance for these circuits must not exceed 600 ohms.

To wire the analog outputs, complete the following steps:

1. Disconnect the main power and remove the rear cover.
2. Install the required cable clamp in the chosen conduit hole on the side of the electronics enclosure.
3. Refer to Figure 1-10 on page 1-23 for the location of terminal block J1 and wire the analog outputs as shown. Secure the cable clamp.

Note: *Analog outputs 1 and 2 in the wiring diagram correspond to analog outputs A and B in Slot 0 in the XGS868 software.*

!ATTENTION EUROPEAN CUSTOMERS!

To meet CE Mark requirements, all cables must be installed as described in Appendix A, CE Mark Compliance.

4. If wiring of the unit has been completed, reinstall the rear cover on the enclosure and tighten the set screw.

!WARNING!

Make sure both covers, with their o-ring seals, are installed and the set screws tightened before applying power in a hazardous environment.

Note: *Prior to use, the analog outputs must be set up and calibrated. See Chapter 1, Calibration, of the Service Manual for detailed instructions.*

Proceed to the next section to continue the initial wiring of the unit.

Wiring the Serial Port

The Model XGS868 flow transmitter is equipped with a built-in serial communications port. The standard port is an RS232 interface, but an optional RS485 interface is available upon request. For more information on serial communications refer to your *EIA-RS Serial Communications* manual (916-054). Proceed to the appropriate subsection for wiring instructions.

Wiring the RS232 Interface

Use the serial port to connect the Model XGS868 flow transmitter to a printer, an ANSI terminal or a personal computer. The RS232 interface is wired as Data Terminal Equipment (DTE), and the signals available at terminal block J1 are shown in Table 1-1 below. Refer to Figure 1-10 on page 1-23 to complete the following steps:

1. Disconnect the main power and remove the rear cover.
2. Install the required cable clamp in the chosen conduit hole on the side of the electronics enclosure.
3. Use the information in Table 1-1 below to construct a suitable cable for connecting the Model XGS868 to the external device. If desired, an appropriate cable may be purchased from Panametrics.

Table 1-1: RS232 Connection to DCE or DTE Device

| J1 Pin # | Signal Description | DCE DB25 Pin # | DCE DB9 Pin # | DTE DB25 Pin # | DTE DB9 Pin # |
|-------------|---------------------------|----------------------|---------------------|----------------------|---------------------|
| 5 | DTR (Data Terminal Ready) | 20 | 4 | 20 | 4 |
| 6 | CTS (Clear to Send) | 4 | 7 | 5 | 8 |
| 7 | COM (Ground) | 7 | 5 | 7 | 5 |
| 8 | RX (Receive) | 2 | 3 | 3 | 2 |
| 9 | TX (Transmit) | 3 | 2 | 2 | 3 |

4. Feed the cable's flying leads through the conduit hole and wire it to terminal block J1. Connect the other end of the cable to the external serial device, and secure the cable clamp.

!ATTENTION EUROPEAN CUSTOMERS!
To meet CE Mark requirements, all cables must be installed as described in Appendix A, CE Mark Compliance.

After the wiring has been completed, consult the *User's Manual* for the external device to configure it for use with the XGS868.

Wiring the RS485 Interface Use the optional RS485 serial port to network multiple XGS868 flow transmitters to a single control system. Upon request, the standard RS232 port on the XGS868 may be configured as a two-wire, half-duplex RS485 interface, through a device such as the INMAC Model 800052 RS232-RS422/RS485 converter.

IMPORTANT: *The Model XGS868 must be configured at the factory for RS485 operation.*

To wire the RS485 serial port, refer to Figure 1-10 on page 1-23 and complete the following steps:

1. Disconnect the main power and remove the rear cover.
2. Install the required cable clamp in the chosen conduit hole on the side of the electronics enclosure.
3. Feed one end of the cable through the conduit hole, wire it to terminal block J1 and secure the cable clamp. Connect the other end of the cable to the converter, as shown in Figure 1-4 below.




Figure 1-4: Typical RS485 Connections

!ATTENTION EUROPEAN CUSTOMERS!
To meet CE Mark requirements, all cables must be installed as described in Appendix A, *CE Mark Compliance*.

4. If wiring of the unit has been completed, reinstall the rear cover on the enclosure and tighten the set screw.

Proceed to the next section to continue the initial wiring of the unit.

Wiring the Option Cards

The Model XGS868 can accommodate one option card in Slot 1 and one option card in Slot 2. The following option card functions are available only in the combinations listed in Table B-1 on page B-1:

- Alarm Relays (Slot 1)
- Analog Inputs (Slot 1)
- Totalizer/Frequency Outputs (Slot 1)
- RTD Inputs (Slot 1)
- Analog Outputs (Slot 1)
- Datalogging (Slot 2) - *no wiring required*
- Modbus Communications (Slot 2) - *no wiring required*

Wiring any option card installed in Slot 1 requires completion of the following general steps:

1. Disconnect the main power and remove the rear cover.
2. Install a cable clamp in the chosen conduit hole on the side of the electronics enclosure and feed a standard twisted-pair cable through this conduit hole.
3. Locate the 12-pin terminal block (J2) in Figure 1-10 on page 1-23 and wire the option card as indicated on the label inside the rear cover (see Figure 1-3 on page 1-8 and Figure 1-11 on page 1-24). Secure the cable clamp.

IMPORTANT: *Because of the attached wiring label, all rear covers must remain with their original meters.*

!ATTENTION EUROPEAN CUSTOMERS!
**To meet CE Mark requirements, all cables must be
 installed as described in Appendix A, CE Mark
 Compliance.**

4. If wiring of the unit has been completed, reinstall the rear cover on the enclosure and tighten the set screw.

Note: *Prior to use, the option card must be set up and calibrated. See Chapter 1, Programming Site Data, in the Programming Manual and Chapter 1, Calibration, in the Service Manual for detailed instructions.*

For more specific instructions on particular option cards, proceed to the appropriate section(s) that follow.

Wiring an Alarms Option Card

Each alarms option card includes two or four *Form C* relays (designated as A, B, C and D), which are available in two types:

- general purpose
- hermetically sealed for Class I, Division 2 hazardous areas

The maximum electrical ratings for the relays are listed in Chapter 4, *Specifications*. Each of the alarm relays can be wired as either *Normally Open* (NO) or *Normally Closed* (NC).

In setting up an alarm relay, it may be wired for either *conventional* or *fail-safe* operation. In fail-safe mode, the alarm relay is constantly energized, except when it is triggered or a power failure or other interruption occurs. See Figure 1-5 below for the operation of a NO alarm relay in both conventional and fail-safe mode.

Connect each alarm relay in accordance with the wiring instructions shown on the label inside the rear cover (see Figure 1-3 on page 1-8 and Figure 1-11 on page 1-24).




Figure 1-5: Conventional and Fail-Safe Operation

Wiring a 0/4-20 mA Analog Inputs Option Card

To calculate the standard mass flow rates of the steam, the Model XGS868 requires accurate *temperature* and *pressure* data from the measurement site. Transmitters installed in the flowcell can provide this information via an optional 0/4-20 mA analog inputs option card. This option card includes two or four isolated 0/4-20 mA analog inputs (designated as A, B, C and D), each of which includes a 24 VDC power supply for loop-powered transmitters. Either input may be used to process the temperature signal, while the other input is used to process the pressure signal.

Note: *To properly enter programming data into the meter, it is necessary to know which input is assigned to which process parameter. This information should be entered in Appendix B, Data Records.*

The analog inputs, which have an impedance of 118 ohms, should be connected with standard twisted-pair wiring. Power to the transmitters may be supplied either by the integral 24 VDC power supply on the analog input option card or by an external power supply. Figure 1-6 below shows typical wiring diagrams, with and without an external power supply, for one of the analog inputs.




Figure 1-6: Analog Input Wiring Diagram

Wiring a 0/4-20 mA Analog Inputs Option Card (cont.)

Wire the analog inputs as shown on the label in the rear cover (see Figure 1-3 on page 1-8 and Figure 1-11 on page 1-24). The Model XGS868 is often equipped with an analog inputs option card, which is used to process the live pressure reading required for accurate mass flow calculations.

Note: *The analog inputs option card can be calibrated with the Model XGS868's built-in analog outputs. However, be certain that the analog outputs have been calibrated first. See Chapter 1, Calibration, in the Service Manual for the appropriate procedures.*

Wiring a Totalizer/Frequency Outputs Option Card

Each totalizer/frequency outputs option card provides two or four outputs (designated as A, B, C, and D) that can be used as either totalizer or frequency outputs.

Wire this option card in accordance with the connections shown on the label in the rear cover (see Figure 1-3 on page 1-8 and Figure 1-11 on page 1-24). Figure 1-7 below shows sample wiring diagrams of a totalizer output circuit and a frequency output circuit.




Figure 1-7: Totalizer/Frequency Outputs Wiring

Wiring an RTD Inputs Option Card

The Model XGS868 RTD (Resistance Temperature Device) inputs option card provides two or four direct RTD inputs (designated as A, B, C and D). Each RTD input requires three wires, and should be connected as shown on the label in the rear cover (see Figure 1-3 on page 1-8 and Figure 1-11 on page 1-24).

Note: *The Model XGS868 is often equipped with an RTD inputs option card, which is used to process the live temperature reading required for accurate mass flow calculations.*

Wiring a 0/4-20 mA Analog Outputs Option Card

The analog outputs option card includes two isolated 0/4-20 mA outputs (designated as A and B). Connections to these outputs may be made with standard twisted-pair wiring, but the total current loop impedance for these circuits must not exceed 1,000 ohms. Wire this option card with the connections shown on the label in the rear cover (see Figure 1-3 on page 1-8 and Figure 1-11 on page 1-24).

A Specific Example

To illustrate the procedures described in the previous sections for wiring the option cards, a specific example may prove helpful. Assume that an Model XGS868 is equipped with an option card numbered 703-1223-08. Table B-1 on page B-1 in Appendix B, *Data Records*, indicates that this option card includes two analog current inputs and two standard alarm relays.

By referring to Figure 1-11 on page 1-24, it is determined that the appropriate connection diagram for this option card is the first one from the left in the middle row. This label should also be found inside the rear cover of the Model XGS868. Based on this information, wiring of the Input/Output connections to terminal block J2 should be completed as shown in Table 1-2 below.

Table 1-2: Wiring a 703-1223-08 Option Card

| J2 Pin # | Description | Connection |
|----------|-------------|------------------|
| 1 | Alarm A | Normally Open |
| 2 | Alarm A | Common |
| 3 | Alarm A | Normally Closed |
| 4 | Alarm B | Normally Open |
| 5 | Alarm B | Common |
| 6 | Alarm B | Normally Closed |
| 7 | Out C | +24 V to Input C |
| 8 | Input C | Signal (+) |
| 9 | Input C | Return (-) |
| 10 | Out D | +24 V to Input D |
| 11 | Input D | Signal (+) |
| 12 | Input D | Return (-) |

Data Logging and Modbus Option Cards

The Model XGS868 can be fitted with either a data logging option card or a Modbus option card, which must be installed in Slot 2. The data logging option card increases the XGS868's memory by up to 2 MB, to enhance its logging capability, and includes an industry-standard PCMCIA card connector for additional expansion. The Modbus option card adds the Modbus communications protocols to meters equipped with the optional RS485 serial interface.

Note: *The Modbus option card provides its own RS485 connections. Thus, the meter can have its serial port configured for RS232 operation and still provide RS485 Modbus signals.*

IMPORTANT: *Because the Modbus option card uses pins 1 and 2 on terminal block J2, only those option cards that do not use these pins may be installed in Slot 1, while a Modbus card is installed in Slot 2. Specifically, only the option cards designated as "OI" and "OR" in Figure 1-11 on page 1-24 are compatible with the Modbus option card.*

What Next?

After the Model XGS868 has been completely installed and wired, proceed to Chapter 2, *Initial Setup*, to program the meter for taking flow rate measurements.

!WARNING!

Make sure both covers, with their o-ring seals, are installed and the set screws tightened before applying power in a hazardous environment.

IMPORTANT: *If a unit equipped with an optional LCD display board is to be installed in a hazardous area, be sure to adjust the backlight brightness and display contrast before mounting the electronics enclosure. See Chapter 2, Displaying Data, in the Programming Manual for details.*







Figure 1-8: Model XGS868 Outline Drawing #712-1002




TYPICAL BRACKET MOUNTING
(Horizontal Pipe)





TYPICAL BRACKET MOUNTING
(Vertical Pipe)




TYPICAL MOUNTING POST



TYPICAL PIPE MOUNTING
(Horizontal Pipe)




BRACKET MOUNTING - SIDE VIEW



ANGLE MOUNTING BRACKET

Figure 1-9: Model XGS868 Mounting Techniques







Figure 1-11: Option Card Connection Labels



CAUTION!
As part of maintaining the FM/CSA environmental rating (NEMA/TYPE 4) on the remote preamplifier, thread sealant is required on all conduit entries.




Figure 1-12: Transducer Wiring for Remote Mounted XGS868

Chapter 2

Initial Setup

| | |
|---|-------------|
| Introduction | 2-1 |
| Site Parameters | 2-1 |
| Programming Methods | 2-1 |
| Using the RCCU | 2-2 |
| Accessing the User Program | 2-4 |
| The PROG Menu..... | 2-6 |
| Exiting the User Program | 2-24 |

Introduction

This chapter provides instructions for programming the minimum amount of data required to place the Model XGS868 flowmeter into operation. Before the Model XGS868 can begin taking measurements and displaying valid data, the current system and pipe parameters must be entered. In addition, a 2-Channel meter requires that each channel be activated prior to use. Additional programming options provide access to the more advanced features of the Model XGS868, but this information is not required to begin taking measurements.

Note: *See the Programming Manual for information on those User Program features not covered in this chapter.*

Site Parameters

In order to begin using the Model XGS868, the following submenus within the *User Program* will be accessed:

- CHx-ACTIV - activate one or both channels and select the desired measurement method
- CHx-SYSTM - enter the individual channel parameters
- GLOBL-SYSTM - enter the global system parameters
- CHx-PIPE - enter the pipe parameters

As a guide in following the programming instructions in this chapter, the relevant portions of the Model XGS868 menu map have been reproduced in Figure 2-3 on page 2-25.

Programming Methods

There are two methods for programming the Model XGS868:

- **Remote Control Communications Unit (RCCU)** - a hand-held device that communicates with the Model XGS868 via wireless, infrared transmissions.
- **Instrument Data Manager (IDM)** - a PC-based, non-resident software program that communicates with the Model XGS868 via its RS232 serial port.

Note: *The Model XGS868 cannot be programmed at the electronics enclosure. One of the above methods must be used.*

Although the screen displays and the methods of navigating through the menu system differ, the programming sequences and all of the available menu options are identical for the RCCU and IDM methods. This chapter provides specific instructions for the RCCU method, and your *IDM User's Manual* (910-185) provides similar instructions for IDM. Regardless of the programming method chosen, refer to the menu prompts and menu options presented in this chapter.

Using the RCCU

To energize the RCCU, press the [ON] key on its keypad. The LCD display, which consists of 4 lines x 20 characters, is activated. See Figure 2-1 below for the layout of the RCCU keypad and display.

Note: For detailed instructions on using and maintaining the RCCU, refer to the Service Manual and/or the Programming Manual.

For reliable RCCU operation, the XGS868's infrared receiver should:

- have a clear line of sight to the RCCU
- be located within 8 ft (2.5 m) of the RCCU
- have an angle of incidence of no more than 15°




Figure 2-1: The RCCU Keypad and Display

Using the RCCU (cont.)

Immediately upon power up, the RCCU performs its normal startup routine. This results in a display of the Panametrics logo, followed by these informational displays:

| | | |
|---------------------|--|--|
| PANAMETRICS Inc. | | |
| --RCCU-- | | |
| Remote Control | | |
| Communications Unit | | |

| | | |
|-------------------|--|--|
| Software Revision | | |
| RCCU R1B | | |

F1 F2 F3

| | | |
|-------------|--------|---|
| IDM MENU | START | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> |
| IDM MENU | | |
| RCCU System | | |
| SYSTEM | ONLINE | OFFLINE |

F1 F2 F3

When the startup routine has been completed, this IDM Menu Start display appears.

Note: See page 2-1 for a description of the IDM software.

Communications Failure

If a working communications link with the Model XGS868 cannot be established, an error message such as the following appears:

| | | |
|----------------------|-------|-----|
| 8C or Communicating | | |
| NO Packet Rcvd | | ce2 |
| Retry/Abort Commlink | | |
| RETRY | ABORT | |

F1 F2 F3

At this display, press [F1] to try again or press [F2] to quit.

In the event of such an error message, try the following remedies:

- make sure that the RCCU battery is not weak
- clean the windows on both the RCCU and the XGS868
- make sure the transmission distance does not exceed 8 ft (2.5 m)
- make sure the angle of incidence does not exceed 15°
- make sure there is an unobstructed line of sight

Then, carefully aim the RCCU and try again. If this fails to resolve the problem, contact Panametrics for assistance.

Accessing the User Program

To access the XGS868's *User Program*, the RCCU must be pointed directly at the receiver in the window on the electronics enclosure whenever data is being sent or received (see Figure 2-2 below).

Note: For the corresponding IDM procedures, see your IDM User's Manual (910-185).





Figure 2-2: Model XGS868 Front Window

The green light in the window glows continuously to indicate that the XGS868 is receiving power, while the red light should glow for more than two seconds whenever a signal is sent from the RCCU. If the red light blinks repeatedly, the XGS868 is not receiving the RCCU signal correctly. The Send/Receive lights on the RCCU blink once to indicate the sending/receiving of a signal.

Note: If the red (Fault) light blinks once or flickers briefly, a flow fault is indicated. This is unrelated to the RCCU, and the problem must be resolved by referring to Chapters 2 and 3, Error Codes and Diagnostics, in the Service Manual.



At this display, press [F2] to select ONLINE

IMPORTANT: Always keep the RCCU pointed directly at the XGS868 while communicating with the meter.

Accessing the User Program (cont.)

| | | |
|--|--------|----|
| Uploading Basic Target System Info. Press RCV Key... | | |
| RCV | CANCEL | |
| F1 | F2 | F3 |

Press the [F1] key to select RCV and begin communications, or press [F2] to select CANCEL and abort the operation.

If the operation was aborted, the RCCU resets to the main menu. Otherwise, proceed to the next display.

| | | |
|---|----|----|
| Communicating... PRESS EXIT to ESCAPE 50 Percent Complete <div style="background-color: black; width: 50%; height: 10px;"></div> | | |
| F1 | F2 | F3 |

This display shows the status of the communication attempt.

| | | |
|-----------------------------------|----|----|
| TARGET METER ID THIS IS AN XGS | | |
| F1 | F2 | F3 |

When the connection is established, this message appears briefly and is then replaced by the following display.

| | | |
|--|-----|------|
| ONLINE PROGRAM □□□▶ | | |
| On Line Operations | | |
| Edit Site | | |
| PROG | LOG | DATA |
| F1 | F2 | F3 |

| | | |
|--|-------|------|
| ONLINE PROGRAM □□□▶ | | |
| On Line Operations | | |
| Edit Site | | |
| SITE | CLEAR | TEST |
| F1 | F2 | F3 |

The XGS868 is now ready to be programmed. To begin programming, press [F1] to select PROG.

(These additional options are accessed by pressing the [◀] and/or [▶] keys.)


Note: The right arrow in the upper right corner of the display indicates that additional options are available. These are accessed by pressing the [◀] or [▶] key.

Refer to the *Menu Map* in Figure 2-3 on page 2-25, and proceed to the next section to begin setting up your meter.

The PROG Menu


This *Startup Guide* provides instructions only for entering the setup data required for basic operation. Refer to the *Programming Manual* for information on programming all other features. Be sure to record all programming data in Appendix B, *Data Records*.

After pressing [ENT] or one of the [Fx] keys on the RCCU, the following screen appears:



This display shows the status of the communication attempt.

IMPORTANT: *Wait for the RCCU and the XGS868 to communicate and for the next prompt to appear before pressing any other keys. Although the above display always appears, it will not be specifically shown in this manual after every selection entry.*



Press [F1] to enter the PROG menu, and proceed to the next section.

(These additional options, which only appear if a data logging option card is installed in Slot 2, are accessed by pressing the [◀] or [▶] key.)

Note: *In this manual, only the programming of Channel 1 will be described. To program Channel 2 of a 2-Channel meter, simply repeat the procedures used for Channel 1.*

For either the RCCU or the IDM programming method, after reaching the *Main Menu*, follow the programming steps shown in the remainder of this chapter and in Figure 2-3 on page 2-25.

The GLOBL Menu

The first step in programming the XGS868 is to select the desired system units in the GLOBL menu. To do this, proceed as follows:

| | | | |
|-----------|-----|-------|------|
| PROGRAM | | | □□□□ |
| Channel 1 | | | |
| CH1 | CH2 | GLOBL | |
| F1 | F2 | F3 | |

Press the [Fx] key under GLOBL to select it. (For a 1-Channel meter, the CH2 option does not appear.)

| | | | |
|---------------------------------|-----|------|------|
| Global PROGRAM | | | □□□□ |
| previous selection appears here | | | |
| SYSTM | I/O | COMM | |
| F1 | F2 | F3 | |

Press [F1] to select SYSTM.

The GLOBL-SYSTM Submenu

This submenu is used to specify the desired system units. In addition, for a 2-Channel meter, the choices made in this submenu are used to calculate the SUM, DIF, and AVE values. Any conflicting data entered in the CHx-SYSTM submenu is ignored.

| | | | |
|--------------------------------|-------|----|------|
| SYSTEM UNITS | | | □□□□ |
| current selection appears here | | | |
| ENG | METRC | | |
| F1 | F2 | F3 | |

Press [F1] to select English units, or press [F2] to select metric units. Then, proceed to either the 1-Channel meter or 2-Channel meter section.

A: 1-Channel Meter

For a 1-Channel XGS868, the meter exits the GLOBL-SYSTM submenu upon responding to the previous prompt. (For a 2-Channel meter, skip this section and proceed directly to the next page.)

| | | | |
|----------------|-----|------|------|
| Global PROGRAM | | | □□□□ |
| system | | | |
| SYSTM | I/O | COMM | |
| F1 | F2 | F3 | |

Press [EXIT] to leave the Global PROGRAM submenu.

Skip the 2-Channel meter instructions that follow and proceed directly to the CHx menu on page 2-12.

The GLOBL-SYSTM Submenu (cont.)

B: 2-Channel Meter

For a 2-Channel meter, continue the programming as follows:

| | | | |
|--|------|-------|------|
| VOLUMETRIC UNITS current selection appears here | | | □□□▶ |
| ACF | KACF | MMACF | |

Press [F1]-[F3] to select the desired volumetric units for the flow rate display.

| | | | |
|--|------|-------|------|
| VOLUMETRIC UNITS current setting appears here | | | □□□▶ |
| SCF | KSCF | MMSCF | |
| F1 | F2 | F3 | |

Use the [◀] and [▶] keys to access the additional choices shown.

Note: *The above prompt shows English units, as an example. If metric units were selected as the SYSTEM UNITS, the appropriate choices would appear instead.*

All the available volumetric and totalizer units are listed in Table 2-1 below. The choices shown at the above prompt are determined by the selection made at the SYSTEM UNITS prompt.

Table 2-1: Available Volumetric/Totalizer Units

| English | Metric |
|---------------------------|-----------------------------|
| Actual Units | |
| ACF = Actual Cubic Feet | ACM = Actual Cubic Meters |
| KACF = Thousands of ACF | KACM = Thousands of ACM |
| MMACF = Millions of ACF | MMACM = Millions of ACM |
| Standard Units | |
| SCF = Standard Cubic Feet | SCM = Standard Cubic Meters |
| KSCF = Thousands of SCF | KSCM = Thousands of SCM |
| MMSCF = Millions of SCF | MMSCM = Millions of SCM |

| | | | |
|---|------|-----|------|
| VOLUMETRIC TIME current setting appears here | | | □□□▶ |
| /SEC | /MIN | /HR | |

Press [F1]-[F3] to select the desired time units for the volumetric flow rate display.

| | | | |
|---|----|----|------|
| VOLUMETRIC TIME current setting appears here | | | □□□▶ |
| /DAY | | | |
| F1 | F2 | F3 | |

Use the [◀] and [▶] keys to access the additional choice shown.

The GLOBL-SYSTM Submenu (cont.)

| | | | |
|------------------------------|---|---|------|
| VOL DECIMAL DIGITS | | | □□□▶ |
| current setting appears here | | | |
| 0 | 1 | 2 | |

Press [F1]-[F3] to select the desired number of digits to the right of the decimal point in the volumetric flow rate display.

| | | | |
|------------------------------|----|----|------|
| VOL DECIMAL DIGITS | | | □□□▶ |
| current setting appears here | | | |
| 3 | | | |
| F1 | F2 | F3 | |

Use the [◀] and [▶] keys to access the additional choice shown.

| | | | |
|------------------------------|------|-------|------|
| TOTALIZER UNITS | | | □□□▶ |
| current setting appears here | | | |
| ACF | KACF | MMACF | |

Press [F1]-[F3] to select the desired units for the totalized flow rate display.

| | | | |
|------------------------------|------|-------|------|
| TOTALIZER UNITS | | | □□□▶ |
| current setting appears here | | | |
| SCF | KSCF | MMSCF | |
| F1 | F2 | F3 | |

Use the [◀] and [▶] keys to access the additional choices shown.

Note: The above prompt shows English units, as an example. If metric units were selected as the SYSTEM UNITS, the appropriate choices would appear instead.

All the available volumetric and totalizer units are shown in Table 2-1 on page 2-8. The choices shown at the above prompt are determined by the selection made at the SYSTEM UNITS prompt.

| | | | |
|------------------------------|---|---|------|
| TOTAL DECIMAL DIGITS | | | □□□▶ |
| current setting appears here | | | |
| 0 | 1 | 2 | |

Press [F1]-[F3] to select the desired number of digits to the right of the decimal point in the totalized flow rate display.

| | | | |
|------------------------------|----|----|------|
| TOTAL DECIMAL DIGITS | | | □□□▶ |
| current setting appears here | | | |
| 3 | | | |
| F1 | F2 | F3 | |

Use the [◀] and [▶] keys to access the additional choice shown.

The GLOBL-SYSTM Submenu (cont.)

□□□▶

MASS FLOW

current setting appears here

| | | |
|----|-----|------|
| LB | KLB | MMLB |
|----|-----|------|

Press [F1]-[F3] to select the desired mass flow units for the flow rate display.

□□□▶

MASS FLOW

current setting appears here

| | | |
|------|--|--|
| TONS | | |
|------|--|--|

Use the [◀] and [▶] keys to access the additional choice shown.

F1 F2 F3

The available mass flow units are shown in Table 2-2 below.

Table 2-2: Available Mass Flow Units

| English | Metric |
|-----------------------|-------------------------------|
| LB = Pounds | KG = Kilograms |
| KLB = Thousands of LB | TONNE = Metric Tons (1000 KG) |
| MMLB = Millions of LB | |
| TONS = Tons (2000 LB) | |

□□□▶

MASS FLOW TIME

current setting appears here

| | | |
|------|------|-----|
| /SEC | /MIN | /HR |
|------|------|-----|

Press [F1]-[F3] to select the desired time units for the mass flow rate display.

□□□▶

MASS FLOW TIME

current setting appears here

| | | |
|------|--|--|
| /DAY | | |
|------|--|--|

Use the [◀] and [▶] keys to access the additional choice shown.

F1 F2 F3

□□□▶

MDOT DECIMAL DIGITS

current setting appears here

| | | |
|---|---|---|
| 0 | 1 | 2 |
|---|---|---|

Press [F1]-[F3] to select the desired number of digits to the right of the decimal point in the mass flow rate display.

□□□▶

MDOT DECIMAL DIGITS

current setting appears here

| | | |
|---|--|--|
| 3 | | |
|---|--|--|

Use the [◀] and [▶] keys to access the additional choice shown.

F1 F2 F3

The GLOBL-SYSTM Submenu (cont.)

| | | |
|---|-----|------|
| <div style="text-align: right;">□□□▶</div> MASS (TOTALIZER) current setting appears here | | |
| LB | KLB | MMLB |

Press [F1]-[F3] to select the desired units for the totaled mass flow rate display.

| | | |
|---|----|----|
| <div style="text-align: right;">□□□▶</div> MASS (TOTALIZER) current setting appears here | | |
| TONS | | |
| F1 | F2 | F3 |

Use the [◀] and [▶] keys to access the additional choice shown.

The available mass flow units are shown in Table 2-2 on page 2-10.

| | | |
|--|---|---|
| <div style="text-align: right;">□□□▶</div> MASS DECIMAL DIGITS current setting appears here | | |
| 0 | 1 | 2 |

Press [F1]-[F3] to select the desired number of digits to the right of the decimal point in the totaled mass flow display.

| | | |
|--|----|----|
| <div style="text-align: right;">□□□▶</div> MASS DECIMAL DIGITS current setting appears here | | |
| 3 | | |
| F1 | F2 | F3 |

(Use the [◀] and [▶] keys to access the additional choice shown.)

| | | |
|---|-----|------|
| <div style="text-align: right;">□□□□</div> Global PROGRAM system | | |
| SYSTM | I/O | COMM |
| F1 | F2 | F3 |

Press [EXIT] to leave the Global PROGRAM submenu.

Proceed to the next section to continue programming your meter.

The CHx Menu

This menu is used to enter data that is specific to each channel. Refer to the *Menu Map* in Figure 2-3 on page 2-25 and remember to record all programming data in Appendix B, *Data Records*.

| | | | |
|-----------|-----|-------|------|
| PROGRAM | | | □□□□ |
| Channel 1 | | | |
| CH1 | CH2 | GLOBL | |
| F1 | F2 | F3 | |

Press the [F1] key under CH1 to select it. (For a 1-Channel meter, the CH2 option does not appear.)

Note: *In this manual, only the programming of Channel 1 is described. To program Channel 2 of a 2-Channel meter, select CH2 above and follow the same general procedures.*

The ACTIV Submenu

The ACTIV submenu permits selection of the desired measurement method. In addition, it is used to activate/deactivate one or both of the channels in a 2-Channel Model XGS868.

| | | | |
|-----------------|-------|------|------|
| Channel PROGRAM | | | □□□▶ |
| status | | | |
| ACTIV | SYSTM | PIPE | |

| | | | |
|-----------------|-------|----|------|
| Channel PROGRAM | | | □□□▶ |
| status | | | |
| I/O | SETUP | | |
| F1 | F2 | F3 | |

Press [F1] to enter the ACTIV submenu.

| | | | |
|---------------------------------|-------|----|------|
| Channel status | | | □□□□ |
| previous selection appears here | | | |
| OFF | BURST | | |
| F1 | F2 | F3 | |

Press the [Fx] key under BURST to activate Channel 1. (For a 1-Channel meter, this prompt is called Site status and the OFF option does not appear.)

| | | | |
|---------------------------------|-----|----|------|
| Skan/Measure Mode | | | □□□□ |
| previous selection appears here | | | |
| SKAN | S/M | | |
| F1 | F2 | F3 | |

Press [F1] to select Skan mode or [F2] to select Skan/Measure mode. The meter returns to the Channel PROGRAM prompt.

The CHx-SYSTEM Submenu

After completing the final entry in the ACTIV submenu, the meter returns to the Channel PROGRAM prompt:

Channel PROGRAM
status
ACTIV | SYSTM | PIPE

Press the [F2] key to enter the SYSTM submenu.

Channel PROGRAM
status
I/O | SETUP |

F1 F2 F3

CHANNEL LABEL
current label appears here

F1 F2 F3

Key in the desired CHANNEL LABEL (up to 9 characters) and press [ENT].

CHANNEL MESSAGE
current message appears here

F1 F2 F3

Key in the desired CHANNEL MESSAGE (up to 21 characters) and press [ENT]. (For a 1-Channel meter, this prompt is called SITE MESSAGE.)

PRESSURE UNITS
current setting appears here
bar | kPa |

F1 F2 F3

Press [F1] or [F2] to select the desired PRESSURE UNITS. (This prompt only appears if METRC was selected for the SYSTEM UNITS.)

EQUATION
current setting appears here
STAND | ACTUL |

F1 F2 F3

Press [F1] to display data in *standard* volumetric units or press [F2] to display data in *actual* volumetric units.

The XGS868 uses the gas equation specified above to calculate the flow rate corresponding to the measured signal transit times.

The CHx-SYSTM Submenu (cont.)

□□□▶

VOLUMETRIC UNITS
current selection appears here

| | | |
|-----|------|-------|
| ACF | KACF | MMACF |
|-----|------|-------|

□□□▶

VOLUMETRIC UNITS
current setting appears here

| | | |
|-----|------|-------|
| SCF | KSCF | MMSCF |
|-----|------|-------|

F1
F2
F3

Press [F1]-[F3] to select the desired volumetric units for the flow rate display.

Use the [◀] and [▶] keys to access these additional choices, which are only available if STAND was selected at the EQUATION prompt.

Note: *The above prompt shows English units, as an example. If metric units were selected as the SYSTEM UNITS, the appropriate choices would appear instead.*

The abbreviations and definitions of all the available volumetric and totalizer units are shown in Table 2-3 below. The choices shown at the above prompt are determined by the selections made at the EQUATION and SYSTEM UNITS prompts.

Table 2-3: Available Volumetric/Totalizer Units

| English | Metric |
|---------------------------|-----------------------------|
| Actual Units | |
| ACF = Actual Cubic Feet | ACM = Actual Cubic Meters |
| KACF = Thousands of ACF | KACM = Thousands of ACM |
| MMACF = Millions of ACF | MMACM = Millions of ACM |
| Standard Units | |
| SCF = Standard Cubic Feet | SCM = Standard Cubic Meters |
| KSCF = Thousands of SCF | KSCM = Thousands of SCM |
| MMSCF = Millions of SCF | MMSCM = Millions of SCM |

□□□▶

VOLUMETRIC TIME
current setting appears here

| | | |
|------|------|-----|
| /SEC | /MIN | /HR |
|------|------|-----|

□□□▶

VOLUMETRIC TIME
current setting appears here

| | | |
|------|--|--|
| /DAY | | |
|------|--|--|

F1
F2
F3

Press [F1]-[F3] to select the desired time units for the volumetric flow rate display.

Use the [◀] and [▶] keys to access the additional choice shown.

The CHx-SYSTM Submenu (cont.)

| | | | |
|------------------------------|---|---|------|
| VOL DECIMAL DIGITS | | | □□□▶ |
| current setting appears here | | | |
| 0 | 1 | 2 | |

Press [F1]-[F3] to select the desired number of digits to the right of the decimal point in the volumetric flow rate display.

| | | | |
|------------------------------|----|----|------|
| VOL DECIMAL DIGITS | | | □□□▶ |
| current setting appears here | | | |
| 3 | | | |
| F1 | F2 | F3 | |

Use the [◀] and [▶] keys to access the additional choice shown.

| | | | |
|------------------------------|------|-------|------|
| TOTALIZER UNITS | | | □□□▶ |
| current setting appears here | | | |
| ACF | KACF | MMACF | |

Press [F1]-[F3] to select the desired units for the totalized flow rate display.

| | | | |
|------------------------------|------|-------|------|
| TOTALIZER UNITS | | | □□□▶ |
| current setting appears here | | | |
| SCF | KSCF | MMSCF | |
| F1 | F2 | F3 | |

Use the [◀] and [▶] keys to access the additional choices, which are only available if STAND was selected at the EQUATION prompt.

Note: The above prompt shows English units, as an example. If metric units were selected as the SYSTEM UNITS, the appropriate choices would appear instead.

The abbreviations and definitions of all the available volumetric and totalizer units are shown in Table 2-3 on page 2-14. The choices shown at the above prompt are determined by the selections made at the EQUATION and SYSTEM UNITS prompts.

| | | | |
|------------------------------|---|---|------|
| TOTAL DECIMAL DIGITS | | | □□□▶ |
| current setting appears here | | | |
| 0 | 1 | 2 | |

Press [F1]-[F3] to select the desired number of digits to the right of the decimal point in the totalized flow rate display.

| | | | |
|------------------------------|----|----|------|
| TOTAL DECIMAL DIGITS | | | □□□▶ |
| current setting appears here | | | |
| 3 | | | |
| F1 | F2 | F3 | |

Use the [◀] and [▶] keys to access the additional choice shown.

The CHx-SYSTM Submenu (cont.)

□□□▶

MASS FLOW

current setting appears here

| | | |
|----|-----|------|
| LB | KLB | MMLB |
|----|-----|------|

Press [F1]-[F3] to select the desired mass flow units for the flow rate display.

□□□▶

MASS FLOW

current setting appears here

| | | |
|------|--|--|
| TONS | | |
|------|--|--|

Use the [◀] and [▶] keys to access the additional choice shown.

F1 F2 F3

Note: *The prompt above shows English units, as an example. If metric units were specified, these appear instead.*

The abbreviations and definitions of the available mass flow units are shown in Table 2-4 below. The choices shown at the above prompt are determined by the selection made at the SYSTEM UNITS prompt.

Table 2-4: Available Mass Flow Units

| English | Metric |
|-----------------------|-------------------------------|
| LB = Pounds | KG = Kilograms |
| KLB = Thousands of LB | TONNE = Metric Tons (1000 KG) |
| MMLB = Millions of LB | |
| TONS = Tons (2000 LB) | |

□□□▶

MASS FLOW TIME

current setting appears here

| | | |
|------|------|-----|
| /SEC | /MIN | /HR |
|------|------|-----|

Press [F1]-[F3] to select the desired time units for the mass flow rate display.

□□□▶

MASS FLOW TIME

current setting appears here

| | | |
|------|--|--|
| /DAY | | |
|------|--|--|

Use the [◀] and [▶] keys to access the additional choice shown.

F1 F2 F3

The CHx-SYSTM Submenu (cont.)

| | | |
|---|--|--|
| <div style="text-align: right;">□□□▶</div> MDOT DECIMAL DIGITS current setting appears here <div style="display: flex; justify-content: space-around;"> 0 1 2 </div> | | |
|---|--|--|

Press [F1]-[F3] to select the desired number of digits to the right of the decimal point in the mass flow rate display.

| | | |
|---|----|----|
| <div style="text-align: right;">□□□▶</div> MDOT DECIMAL DIGITS current setting appears here <div style="display: flex; justify-content: space-around;"> 3 </div> | | |
| F1 | F2 | F3 |

Use the [◀] and [▶] keys to access the additional choice shown.

| | | |
|--|--|--|
| <div style="text-align: right;">□□□▶</div> MASS (TOTALIZER) current setting appears here <div style="display: flex; justify-content: space-around;"> LB KLB MMLB </div> | | |
|--|--|--|

Press [F1]-[F3] to select the desired units for the totaled mass flow rate display.

| | | |
|---|----|----|
| <div style="text-align: right;">□□□▶</div> MASS (TOTALIZER) current setting appears here <div style="display: flex; justify-content: space-around;"> TONS </div> | | |
| F1 | F2 | F3 |

Use the [◀] and [▶] keys to access the additional choice shown.

Note: The prompt above shows English units, as an example. If metric units were specified, these appear instead.

The available mass flow units are shown in Table 2-4 on page 2-16. The choices shown at the above prompt are determined by the selection made at the SYSTEM UNITS prompt.

| | | |
|---|--|--|
| <div style="text-align: right;">□□□▶</div> MASS DECIMAL DIGITS current setting appears here <div style="display: flex; justify-content: space-around;"> 0 1 2 </div> | | |
|---|--|--|

Press [F1]-[F3] to select the desired number of digits to the right of the decimal point in the totaled mass flow display.

| | | |
|---|----|----|
| <div style="text-align: right;">□□□▶</div> MASS DECIMAL DIGITS current setting appears here <div style="display: flex; justify-content: space-around;"> 3 </div> | | |
| F1 | F2 | F3 |

(Use the [◀] and [▶] keys to access the additional choice shown.)

Proceed directly to the next section to program the PIPE submenu.

The PIPE Submenu

After completing the final entry in the CHx-SYSTM submenu, continue programming the meter as follows:

| | | | |
|---------|-------|------|------|
| PROGRAM | | | □□□▶ |
| status | | | |
| ACTIV | SYSTM | PIPE | |

| | | | |
|---------|-------|----|------|
| PROGRAM | | | □□□▶ |
| status | | | |
| I/O | SETUP | | |
| F1 | F2 | F3 | |

Press the [F3] key to enter the PIPE sub-menu.

| | | | |
|---------------------|------|----|------|
| TRANSDUCER NUMBER | | | □□□□ |
| number appears here | | | |
| STD | SPEC | | |
| F1 | F2 | F3 | |

For a standard transducer, press [F1], enter the number engraved on the transducer head, and press [ENT]. If there is no number engraved on the transducer head, press [F2] and then press [ENT].

IMPORTANT: *Special transducers, which have no engraved number on the head, are rarely used. Examine the transducer head carefully for a number.*

Based on your response to the above prompt, proceed as follows:

- To program the Model XGS868 for use with a special transducer, proceed to the instructions on page 2-19.
- To program the Model XGS868 for use with a standard transducer, proceed to the instructions on page 2-20.

Special Transducers

The next three prompts apply only to special transducers. If a standard transducer is being used, skip ahead to the PIPE OD prompt on page 2-20.

| | | |
|--|----|----|
| <div style="text-align: right;">□□□□</div> SPECIAL TRANSDUCER number appears here | | |
| F1 | F2 | F3 |

Assign a number between 91 and 99 to the special transducer and press [ENT].

| | | |
|---|----|----|
| <div style="text-align: right;">□□□▶</div> FREQUENCY current setting appears here <div style="display: flex; justify-content: space-around;"> 50k 100k 200k </div> | | |
| F1 | F2 | F3 |

Press [F1]-[F3] to select the frequency of the special transducer.

| | | |
|--|----|----|
| <div style="text-align: right;">□□□▶</div> FREQUENCY current setting appears here <div style="display: flex; justify-content: space-around;"> 500k 25k 33k </div> | | |
| F1 | F2 | F3 |

Use the [◀] and [▶] keys to access the additional choices shown.

IMPORTANT: *The frequency is required to transmit an excitation voltage at the transducer's natural frequency.*

| | | |
|--|----|----|
| <div style="text-align: right;">□□□□</div> Tw xx.xxx usec (current value) | | |
| F1 | F2 | F3 |

Enter the special transducer time delay value (in μsec) supplied by Panametrics and press [ENT].

Note: *Tw is the time required for the transducer signal to travel through the transducer and its cable. This time delay must be subtracted from the transit times of the upstream and downstream transducers to ensure an accurate flow rate calculation.*

The PIPE Submenu (cont.)

After the standard or special transducer data has been entered, the programming sequence should be rejoined at this point.

□□□▶

PIPE OD

current value appears here

inch
feet
in/PI

□□□▶

PIPE OD

current value appears here

ft/PI

F1
F2
F3

Press [F1]-[F3] to select the appropriate units and enter the known PIPE OD or circumference. Press [ENT] when done.

Use the [◀] and [▶] keys to access the additional choice shown.

Note: *The prompt above shows English units, as an example. If metric units were specified, these appear instead.*

Obtain the required information by measuring either the pipe outside diameter (OD) or circumference at the transducer installation site. The data may also be obtained from the *Sound Speeds and Pipe Size Data* manual (914-004). The available English and metric units and their definitions are listed in Table 2-5 below.

Table 2-5: Available Pipe OD Units

| English | Metric |
|--------------------------------------|---|
| inch = pipe OD in inches | mm = pipe OD in millimeters |
| feet = pipe OD in feet | m = pipe OD in meters |
| in/PI = pipe circumference in inches | mm/PI = pipe circumference in millimeters |
| ft/PI = pipe circumference in feet | m/PI = pipe circumference in meters |

□□□□

PIPE WALL

current value appears here

F1
F2
F3

Enter the known thickness of the PIPE WALL, in the same units used for the PIPE OD, and press [ENT].

IMPORTANT: *The PIPE WALL thickness must be entered in the same units used for the PIPE OD.*

If the pipe wall thickness cannot be measured, look it up in the *Sound Speeds and Pipe Size Data* manual (914-004).

The PIPE Submenu (cont.)

| | | | |
|----------------------------|------|----|------|
| PATH LENGTH P | | | □□□□ |
| current value appears here | | | |
| inch | feet | | |
| F1 | F2 | F3 | |

Press [F1] or [F2] to select the desired units. Then, enter the PATH LENGTH of the ultrasonic signal and press [ENT].

Note: *If a spoolpiece was ordered with the meter, both the transducer signal path length (P) and the transducer signal axial length (L) are engraved on the flowcell and/or are included in the documentation supplied with the meter. For on-site transducer installations, refer to Appendix C, Measuring P and L Dimensions, for instructions.*

| | | | |
|----------------------------|------|----|------|
| AXIAL LENGTH L | | | □□□□ |
| current value appears here | | | |
| inch | feet | | |
| F1 | F2 | F3 | |

Press [F1] or [F2] to select the desired units. Then, enter the AXIAL LENGTH of the ultrasonic signal and press [ENT].

| | | | |
|--------------------------------|-------|----|------|
| FLUID TYPE | | | □□□□ |
| current selection appears here | | | |
| STEAM | OTHER | | |
| F1 | F2 | F3 | |

Press [F1] to select STEAM as the gas type or press [F2] to configure the meter for a different gas.

If [F2] = OTHER was selected as the FLUID TYPE, the following prompt appears. If [F1] = STEAM was chosen, skip the following prompt and proceed directly to the Mass Flow (static)? prompt on page 2-22.

| | | | |
|----------------------------|----|----|------|
| FLUID SOUNDSPEED | | | □□□□ |
| current value appears here | | | |
| F1 | F2 | F3 | |

Enter the speed of sound (in feet per second) in the gas to be measured, and press [ENT].

Note: *If the speed of sound in your fluid is not known, look it up in the Sound Speeds and Pipe Size Data manual (914-004).*

The PIPE Submenu (cont.)

The Model XGS868 calculates the actual steam density from the live or fixed temperature and pressure inputs, as programmed in the I/O menu. However, setting the Mass Flow (static)? prompt to YES overrides this value and uses the density entered at the FLUID DENSITY prompt below to calculate mass flow.

| | | | |
|------------------------------|-----|----|------|
| | | | □□□□ |
| Mass Flow (static)? | | | |
| current setting appears here | | | |
| NO | YES | | |
| F1 | F2 | F3 | |

Press [F1] to select NO or press [F2] to select YES.

If [F2] = YES was selected above, the following prompt appears. If [F1] = NO was chosen, skip the following prompt.

| | | | |
|----------------------------|----|----|------|
| | | | □□□□ |
| FLUID DENSITY | | | |
| current value appears here | | | |
| | | | |
| F1 | F2 | F3 | |

Enter the density of the gas to be measured and press the [ENT] key. (This prompt appears only if Mass Flow (static) ? is set to YES.)

| | | | |
|-----------------------------|----|----|------|
| | | | □□□□ |
| Multi K-factors | | | |
| current status appears here | | | |
| OFF | ON | | |
| F1 | F2 | F3 | |

Press [F1] to disable this function, or press [F2] to enable multiple K-factors.

Based on your response to the above prompt, proceed as follows:

- If Multi K-factors are turned OFF, proceed to the CALIBRATION FACTOR prompt on page 2-23.
- If Multi K-factors are turned ON, continue with the next prompt.

| | | | |
|--------------------------------|-----|----|------|
| | | | □□□□ |
| Edit table? | | | |
| current selection appears here | | | |
| NO | YES | | |
| F1 | F2 | F3 | |

Press [F1] to retain the current K-factor table and proceed directly to the CALIBRATION FACTOR prompt, or press [F2] to edit the K-factor table.

Note: *If velocity vs. K-factor data was not provided with the Model XGS868's documentation, the K-factor table cannot be edited.*

The PIPE Submenu (cont.)

| | | |
|--|----|----|
| <div style="text-align: right;">□□□□</div> Enter # of K factors current number appears here | | |
| F1 | F2 | F3 |

Enter the number of K-factors to be entered into the table and press [ENT]. This number must be between 2 and 20.

IMPORTANT: When editing the K-factor table, the velocities must be entered in increasing order.

| | | |
|---|----|----|
| <div style="text-align: right;">□□□□</div> Velocity # x current value appears here | | |
| F1 | F2 | F3 |

Enter the velocity value for K-factor number “x” and press [ENT].

| | | |
|---|----|----|
| <div style="text-align: right;">□□□□</div> K Factor # x current value appears here | | |
| F1 | F2 | F3 |

Enter the K-factor corresponding to velocity number “x” and press [ENT]. (The Velocity # x and K Factor # x prompts repeat until all of the data points have been entered.)

Regardless of the choices made at the various Multi K-factors prompts, the programming sequences converge here.

| | | |
|---|----|----|
| <div style="text-align: right;">□□□□</div> CALIBRATION FACTOR current value appears here | | |
| F1 | F2 | F3 |

Enter a value for the flow calibration factor and press [ENT]. The default value is 1.00, but values between 0.90 and 1.10 may be entered.

After the CALIBRATION FACTOR entry, the meter leaves the PIPE submenu. At that point, press the [EXIT] key on the RCCU keypad to leave the Channel PROGRAM submenu, and proceed to the next section.

Exiting the User Program

After leaving the Channel PROGRAM submenu, the meter returns to the following prompt:

| | | | |
|---------|-----|-------|------|
| PROGRAM | | | □□□□ |
| CH1 | | | |
| CH1 | CH2 | GLOBL | |
| F1 | F2 | F3 | |

Press the [EXIT] key to leave the *User Program*. (For a 1-Channel meter, the CH2 option does not appear.)

Note: See your IDM User's Manual (910-185) for instructions on terminating IDM communications.

| | | |
|--------------------|----|----|
| Link Edit complete | | |
| Aborting comm link | | |
| F1 | F2 | F3 |


This display appears briefly.

| | | |
|----------|--------|---------|
| IDM MENU | START | □□□□ |
| IDM MENU | | |
| On Line | | |
| SYSTEM | ONLINE | OFFLINE |
| F1 | F2 | F3 |

The initial RCCU startup display then reappears.

Note: The site data programmed in this chapter is automatically stored in the meter's non-volatile RAM (NVR). If the power to the meter is disconnected, the same site data will be reapplied when the unit is next powered on.

Proceed to Chapter 3, *Operation*, for instructions on taking measurements or refer to the *Programming Manual* for instructions on programming the Model XGS868's advanced features.



Chapter 3

Operation

| | |
|---------------------------------|------|
| Introduction | 3-1 |
| Powering Up | 3-2 |
| The Optional LCD Display | 3-3 |
| The Optional RCCU Display | 3-4 |
| Taking Measurements | 3-5 |
| What Next? | 3-12 |

Introduction

See Chapter 1, *Installation*, and Chapter 2, *Initial Setup*, to prepare the Model XGS868 system for operation. When the meter is ready to take measurements, proceed with this chapter. The following specific topics are discussed:

- Powering Up
- Using the Displays
- Taking Measurements

Note: *All inputs and outputs of the Model XGS868 are calibrated at the factory, prior to shipment. If it becomes necessary to recalibrate any of the inputs and/or outputs, see Chapter 1, Calibration, of the Service Manual for instructions.*

!WARNING!

To ensure the safe operation of the Model XGS868, it must be installed and operated as described in this manual. In addition, be sure to follow all applicable local safety codes and regulations for the installation of electrical equipment.

Powering Up

Because the Model XGS868 does not have an ON/OFF switch, it powers up as soon as the connected power source is energized.

Note: *For compliance with the European Union's Low Voltage Directive (73/23/EEC), this unit requires an external power disconnect device such as a switch or circuit breaker. The disconnect device must be marked as such, clearly visible, directly accessible, and located within 1.8 m (6 ft) of the Model XGS868.*

There are four methods for obtaining readings from the XGS868:

- Built-In LCD Display - see page 3-3
- Remote Control Communications Unit (RCCU) - see page 3-4
- Instrument Data Manager (IDM) - see *Programming Manual*
- The Model XGS868's analog output - see *Programming Manual*

At least one of the above options must be installed and configured in order to obtain flow rate readings from the meter. For instructions on using the IDM or analog output options, refer to the *Programming Manual* and/or the *IDM User's Manual* (914-185).

Immediately upon power up the green PWR light begins to glow, and about 15 seconds later the software version display appears. Then, the meter performs a series of internal checks, which takes about 45 seconds, prior to outputting the flow rate data.

Note: *If the Model XGS868 fails any of the internal checks (see Chapter 2, Error Codes, in the Service Manual), try disconnecting the power and then re-powering the unit. If the meter continues to fail any of the internal checks, contact the factory for assistance.*

After successfully performing the internal checks, the Model XGS868 begins taking measurements and the software version display is replaced by a measurement mode display (assuming that a display has been enabled). Proceed to the appropriate section for instructions on using the LCD display and the RCCU display options.

Note: *As a minimum, the system and pipe parameters (for each installed channel of a 2-channel meter) must be entered before the Model XGS868 can display valid data. Refer to Chapter 2, Initial Setup, for specific instructions.*

The Optional LCD Display

The components of the optional LCD display are shown in Figure 3-1 below, along with a typical mass flow rate readout.




Figure 3-1: A Typical LCD Flow Rate Display

As shown in Figure 3-1 above, the display screen includes the following information:

- Channel Number
- Flow Parameter
- Units of Measure
- Flow Rate Value

!WARNING!

If a unit equipped with an optional LCD display board is being installed in a hazardous area, be sure to adjust the backlight brightness and display contrast before mounting the electronics enclosure. See Chapter 2, *Displaying Data*, in the *Programming Manual* for details.

The example in Figure 3-1 above uses the default display settings. However, the first three items in the list above may be reprogrammed to display those parameters that are most frequently used. See the *Programming Manual* for instructions on changing these parameters.

Note: *Error code messages may appear in the upper right corner of the LCD display. For information about these error codes and how to respond to them, refer to Chapter 2, Error Codes, in the Service Manual.*

Proceed to the *Taking Measurements* section to use the XGS868.

The Optional RCCU Display

The components of the optional RCCU display are shown in Figure 3-2 below, along with a typical mass flow rate readout.




Figure 3-2: A Typical RCCU Flow Rate Display

As shown in Figure 3-2 above, the display screen includes the following information:

- Channel Number
- Flow Parameter
- Units of Measure
- Parameter Option Choices
- Flow Rate Value

The example in Figure 3-2 above is typical, but the first three items in the list above may be reprogrammed to display those parameters that are most frequently used. See the *Programming Manual* for detailed instructions on changing these parameters.

Note: Error code messages may appear in the upper right corner of the LCD display. For information about these error codes and how to respond to them, refer to Chapter 2, Error Codes, in the Service Manual.

Proceed to the *Taking Measurements* section on the next page.

Taking Measurements

The Model XGS868 is capable of displaying several different variables in a variety of formats. However, this manual only discusses the basic measurement displays using the LCD and the RCCU. Refer to Chapter 2, *Displaying Data*, in the *Programming Manual* for instructions on setting up alternate choices. Also, refer to the *Programming Manual* and/or the *IDM User's Manual* (910-185) to use IDM or the analog outputs to obtain flow rate data.

The LCD Display

To use the optional LCD display for obtaining live data, simply power on the XGS868 as described earlier in this chapter. Then, read the flow rate directly from the display (see Figure 3-1 on page 3-3).

If the LCD shows only the XGS868 identification screen upon power up, the data display must be initialized. Use the Remote Control Communications Unit (RCCU) to establish communications with the XGS868 and enter the GLOBL menu, as described in Chapter 2. Then, refer to Figure 3-3 on page 3-6 and complete the following steps:

Note: To perform this task with the optional IDM software, refer to the *Instrument Data Manager User's Manual* (910-185).

| | | | |
|---------------------------------|-----|------|------|
| | | | □□□□ |
| Global PROGRAM | | | |
| previous selection appears here | | | |
| SYSTM | I/O | COMM | |
| F1 | F2 | F3 | |

Press [F2] to select I/O.

| | | | |
|---------------------------------|------|-----|------|
| | | | □□□□ |
| Global I/O | | | |
| previous selection appears here | | | |
| ERROR | OPTN | LCD | |
| F1 | F2 | F3 | |

Press [F3] to select LCD.

| | | | |
|---------------------------------|----|----|------|
| | | | □□□▶ |
| # OF LCD PARAMS | | | |
| previous selection appears here | | | |
| OFF | 1 | 2 | |
| | | | |
| | | | □□□▶ |
| # OF LCD PARAMS | | | |
| previous selection appears here | | | |
| 3 | 4 | | |
| F1 | F2 | F3 | |

Press the [Fx] key under the desired number of parameters to be sequentially displayed.

(These additional options are accessed by pressing the [◀] and/or [▶] keys.)




Figure 3-3: Data Display Menu Map

The LCD Display (cont.)

Note: *The XGS868 refers to the parameters specified for display as 1st channel, 2nd channel, 3rd channel and 4th channel. If OFF is selected, the meter returns to the Global I/O prompt.*

For a 1-Channel XGS868, the following prompt does not appear; proceed directly to the next page. However, for a 2-Channel meter, the channel option to be used for the display of each parameter must be specified as follows:

| | | |
|---------------------------------|-----|-----|
| □□□▶ | | |
| Channel 1 | | |
| previous selection appears here | | |
| CH1 | CH2 | SUM |

| | | |
|---------------------------------|-----|----|
| □□□▶ | | |
| Channel 1 | | |
| previous selection appears here | | |
| DIF | AVE | |
| F1 | F2 | F3 |

Press the [Fx] key under the desired channel option to select it.

(These additional options are accessed by pressing the [◀] and/or [▶] keys.)

IMPORTANT: *Both channels must be activated (see Chapter 2, Initial Setup) to make all of the above channel options available. If one of the channels is disabled, only the individual active channel appears.*

See Table 3-1 below for descriptions of the available channel options.

Table 3-1: Channel Options

| Option | Description |
|--------|-------------|
| CH1 | Channel 1 |
| CH2 | Channel 2 |
| SUM | CH1+CH2 |
| DIF | CH1-CH2 |
| AVE | (CH1+CH2)/2 |

Proceed to the next page to continue setting up the LCD.

The LCD Display (cont.) The flow parameter to be displayed may now be selected as follows:

| | | |
|---------------------------------|-------|-------|
| □□□▶ | | |
| Measurement Name 1 | | |
| previous selection appears here | | |
| VEL | VOLUM | +TOTL |

| | | |
|---------------------------------|------|------|
| □□□▶ | | |
| Measurement Name 1 | | |
| previous selection appears here | | |
| -TOTL | TIME | MDOT |

| | | |
|---------------------------------|-------|-------|
| □□□▶ | | |
| Measurement Name 1 | | |
| previous selection appears here | | |
| +MASS | -MASS | DIAG* |

F1
F2
F3

Use the [◀] and [▶] keys to find the desired flow parameter, and press the [Fx] key under it to select it.

(These additional options are accessed by pressing the [◀] and/or [▶] keys.)

(These additional options are accessed by pressing the [◀] and/or [▶] keys.)

Table 3-2 below describes the display parameters that are available at the previous prompt

Table 3-2: Display Parameter Options

| Available Choice | Description |
|--|-------------------------------|
| [F1] = VEL | Flow Velocity |
| [F2] = VOLUM | Volumetric Flow |
| [F3] = +TOTL | Forward Totalized Volume Flow |
| [▶] + [F1] = -TOTL | Reverse Totalized Volume Flow |
| [▶] + [F2] = TIME | Total Flow Measurement Time |
| [▶][→] + [F3] = MDOT | Mass Flow |
| [▶] + [▶] + [F1] = +MASS | Forward Totalized Mass Flow |
| [▶] + [▶] + [F2] = -MASS | Reverse Totalized Mass Flow |
| [▶] + [▶] + [F3] = DIAG* | Diagnostic Parameters* |
| The DIAG* option represents all of the individual diagnostic parameters. See Chapter 3, <i>Diagnostics</i> , of the <i>Service Manual</i> for a complete description of these options. | |

The two previous prompts repeat until all of the specified # OF LCD PARAMS are set up. Then, the meter returns to the Global I/O prompt. To leave the *User Program*, press the [EXIT] key three times. After the XGS868 resets, all of the specified parameters are displayed on the LCD in sequence, with a pause of several seconds between the display of each parameter.

The RCCU Display

Flow rate data and diagnostic parameters may be displayed on the optional Remote Control Communications Unit (RCCU) screen. To access and program this display, establish a link between the Remote Control Communications Unit (RCCU) and the XGS868, and enter the ONLINE program (see Chapter 2, *Initial Setup*). Then, refer to Figure 3-3 on page 3-6 and complete the following instructions to display the desired data:

Note: See Chapter 2, *Initial Setup*, in this manual and/or Chapter 1, *Programming Site Data*, in the Programming Manual for complete instructions on using the RCCU.

| | | |
|---|-----|------|
| ONLINE PROGRAM <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | | |
| On Line Operations | | |
| previous selection appears here | | |
| PROG | LOG | DATA |

Press the [F3] key to select DATA.

| | | |
|---|-------|------|
| ONLINE PROGRAM <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | | |
| On Line Operations | | |
| previous selection appears here | | |
| SITE | CLEAR | TEST |

(These additional options are accessed by pressing the [◀] and/or [▶] keys.)

F1 F2 F3

Upon entering the ONLINE-DATA submenu, the following display appears:

| | | |
|---|-------|-------|
| ONLINE PROGRAM <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | | |
| Live Data Update | | |
| current setting appears here | | |
| 5sec | 10sec | 30sec |

Use the [◀] and [▶] keys to find the desired time between data updates, and press the [Fx] key under it to select that interval.

| | | |
|---|------|------|
| ONLINE PROGRAM <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | | |
| Live Data Update | | |
| current setting appears here | | |
| 1min | 3min | 6min |

(These additional options are accessed by pressing the [◀] and/or [▶] keys.)

| | | |
|---|--|--|
| ONLINE PROGRAM <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | | |
| Live Data Update | | |
| current setting appears here | | |
| 12min | | |

(These additional options are accessed by pressing the [◀] and/or [▶] keys.)

F1 F2 F3

The RCCU Display (cont.)

Note: For a 1-Channel XGS868, only the CH1 option in the [F1] position appears at the next prompt.

| | | |
|--|-----|-----|
| <div style="text-align: right;">□□□▶</div> | | |
| CHAN NAMES | | |
| current selection appears here | | |
| CH1 | CH2 | SUM |

Use the [◀] and [▶] keys to find the desired channel option, and press the [Fx] key under it to select it.

| | | |
|--|-----|--|
| <div style="text-align: right;">□□□▶</div> | | |
| CHAN NAMES | | |
| current selection appears here | | |
| DIF | AVE | |

(These additional options are accessed by pressing the [◀] and/or [▶] keys.)

F1 F2 F3

IMPORTANT: Both channels must be activated (see Chapter 2, Initial Setup) to make all of the above channel options available. If one of the channels is disabled, only the individual active channel appears.

See Table 3-3 below for a complete description of the channel display options available at the above prompt.

Table 3-3: Channel Display Options

| Display Type | Description |
|------------------|-------------------------------|
| [F1] = CH1 | Channel 1 |
| [F2] = CH2 | Channel 2 |
| [F3] = SUM | (Channel 1) + (Channel 2) |
| [▶] + [F1] = DIF | (Channel 1) - (Channel 2) |
| [▶] + [F2] = AVE | [(Channel 1) + (Channel 2)]/2 |

| | | |
|----------------------|--------|--|
| Uploading Chan Names | | |
| To Start Upload | | |
| Press RCV Key... | | |
| RCV | CANCEL | |

Press the [F1] key to select RCV and begin uploading live data, or press [F2] to select CANCEL and abort the operation.

F1 F2 F3

| | | |
|--|--|--|
| Communicating... | | |
| PRESS EXIT to ESCAPE | | |
| 50 Percent Complete | | |
| <div style="background-color: black; width: 50%; height: 10px;"></div> | | |

This display shows the status of the communication attempt.

F1 F2 F3

The RCCU Display (cont.)

After the previous response has been communicated to the XGS868, the RCCU is connected to the meter by a *Live Flow Link* and displays the current flow rate value for the channel option specified. At this time, the flow parameter to be displayed may be changed as follows:

| | | | |
|----------------|-------|-------|------|
| LIVE FLOW Link | | | □□□▶ |
| CH1 Mass flow | | | |
| 4500 LB/HR | | | |
| VEL | VOLUM | +TOTL | |

| | | | |
|----------------|-------|------|------|
| LIVE FLOW Link | | | □□□▶ |
| CH1 Mass flow | | | |
| 4500 LB/HR | | | |
| -TOTL | TIMER | MDOT | |

| | | | |
|----------------|-------|-------|------|
| LIVE FLOW Link | | | □□□▶ |
| CH1 Mass flow | | | |
| 4500 LB/HR | | | |
| +MASS | -MASS | DIAG* | |

F1 F2 F3

Use the [◀] and [▶] keys to find the desired flow parameter, and press the [Fx] key to select it.

(These additional options are accessed by pressing the [◀] and/or [▶] keys.)

(These additional options are accessed by pressing the [◀] and/or [▶] keys.)

Table 3-4 below describes the measurement parameters that are available at the above prompt.

Table 3-4: Display Parameter Options

| Available Choice | Description |
|--|-------------------------------|
| [F1] = VEL | Flow Velocity |
| [F2] = VOLUM | Volumetric Flow |
| [F3] = +TOTL | Forward Totalized Volume Flow |
| [▶] + [F1] = -TOTL | Reverse Totalized Volume Flow |
| [▶] + [F2] = TIME | Total Flow Measurement Time |
| [▶][→] + [F3] = MDOT | Mass Flow |
| [▶] + [▶] + [F1] = +MASS | Forward Totalized Mass Flow |
| [▶] + [▶] + [F2] = -MASS | Reverse Totalized Mass Flow |
| [▶] + [▶] + [F3] = DIAG* | Diagnostic Parameters* |
| The DIAG* option represents all of the individual diagnostic parameters. See Chapter 3, <i>Diagnostics</i> , of the <i>Service Manual</i> for a complete description of these options. | |

Note: To terminate the live data connection between the XGS868 and the RCCU, simply press the [EXIT] key on the RCCU keypad, between actual data transmissions.

What Next?

This *Startup Guide* is intended to provide only those instructions necessary to get the XGS868 installed and operating. By following the instructions in this chapter, the Model XGS868 can be set up to display the desired channel option and the desired measurement parameter, using either the LCD display or the RCCU.

To utilize the more advanced capabilities of the Model XGS868, refer to the *Programming Manual* and/or the *Service Manual* for the instrument. Also, refer to the *IDM User's Manual* (910-185) for instructions on using the IDM software with the XGS868.

Chapter 4

Specifications

| | |
|---|------------|
| General Specifications | 4-1 |
| Electrical Specifications | 4-2 |
| Flow Transducer Specifications | 4-4 |
| Flowcell Specifications | 4-4 |

| | |
|-------------------------------|--|
| General Specifications | The general specifications for the Model XGS868 flow transmitter are as follows: |
| Hardware Configuration | <p>Package Options:</p> <p><i>Epoxy-coated aluminum (standard):</i> NEMA 7/4X Explosion-Proof Class 1, Div. 1, Groups C, D Flameproof EExd IIC T6</p> <p><i>Stainless steel (optional):</i> same ratings as above</p> <p>Physical:</p> <p>Size: 8.2 in. long x 6.6 in. diameter (208 x 168 mm) Weight: Al = 10 lb (4.5 kg), SS = 30 lb (13.6 kg)</p> |
| Environmental | <p>Operating Temperature:</p> <p>-40° to 140°F (-40° to 60°C)</p> <p>Storage Temperature:</p> <p>-67° to 167°F (-55° to 75°C)</p> |
| Velocity Accuracy | <p>% of Reading:</p> <p>±1% of reading at ± 3 to ± 150 ft/s (± 0.9 to ± 46 m/s)</p> <p>Note: Accuracy depends on pipe size and other factors, such as 1-path or 2-path measurement.</p> |
| Velocity Range | <p>Bidirectional:</p> <p>-150 to -0.1 ft/s (-46 to -0.03 m/s) 0.1 to 150 ft/s (0.03 to 46 m/s)</p> |
| Rangeability | 1500:1 |
| Repeatability | <p>±0.2 to ±0.5% at 1 to 150 ft/s (0.3 to 46 m/s)</p> <p>Note: Specifications assume a fully developed flow profile, with a straight run of pipe 20 diameters upstream and 10 diameters downstream.</p> |

Electrical Specifications

The electrical specifications for the Model XGS868 flow transmitter are as follows:

Power Supply**Input Options:**

110 to 130 VAC $\pm 10\%$, 50/60 Hz with 0.25 A Slo-Blo Fuse

200 to 240 VAC $\pm 10\%$, 50/60 Hz with 0.25 A Slo-Blo Fuse

12 to 28 VDC $\pm 5\%$, with 2.0 A Slo-Blo Fuse

Power Consumption

20 W maximum

Operating Mode

Correlation Transit-Time™ flow measurement

European Compliance

This unit complies with EMC Directive 89/336/EEC and 73/23/EEC Low Voltage Directive (Installation Category II, Pollution Degree II).

Input/Output Specifications**Digital Display:**

Optional 2-line x 16-character, software-configurable, LCD display with LED backlight

Digital Communications:

Standard: RS232 serial port for PC, Terminal or Printer

Optional: RS485 serial port for multi-user network

Analog Outputs (built-in):

Two isolated 0/4–20 mA analog outputs, 600 Ω maximum load

Option Cards:

Optional Inputs/Outputs of the following types may be added:

1. *Analog Inputs:* two or four isolated 0/4–20 mA inputs, 24-V loop power.
2. *RTD Inputs:* two or four isolated 3-wire RTD inputs; Span -148° to 662°F (-100° to 350°C)

Inputs of the following types may be used:

Input A: Temp from -40° to 500°F (-40° to 260°C)

Input B: Pressure from 0–3,000 psig

Input C: Steam quality from 0.0 to 1.0

Input/Output Specifications (cont.)

Option Cards (cont.):

3. *Analog Outputs:* two isolated 0/4–20 mA analog outputs, 1000 Ω maximum load
4. *Data Logging:* 512 kB (expandable to 2 MB) of memory, includes industry-standard PCMCIA card connector
5. *Totalizer/Frequency Outputs:* two or four optically isolated pulse or frequency outputs, 100 VDC/3 A/1 W/10 kHz max.

Totalizer Mode: one pulse per defined unit of parameter (e.g., 1 pulse/gal).

Frequency Mode: pulse frequency proportional to magnitude of parameter (e.g., 10 Hz = 1 gal/min).

6. *Alarm Relays:* two or four Form-C relays

General Purpose: 120 VAC, 28 VDC max., 5 A max., DC = 30 W max., AC = 60 VA max.

Hermetically Sealed: 120 VAC, 28 VDC max., 2 A max., DC = 56 W max., AC = 60 VA max.

Note: *The above optional inputs/outputs are available only in specific combinations. Consult Panametrics or see Table B-1 on page B-1 for details.*

Infrared Communications Link:

Hand-held, battery powered (9 V) remote control communications unit (RCCU)

Preamplifier

Inline preamplifier for long cable lengths or attenuating installations, operating temperature -40° to 140°F (-40° to 60°C)

Flow Transducer Specifications

The ultrasonic flow transducer specifications for the Model XGS868 flow transmitter are as follows:

| | |
|-------------------|--|
| Type | Standard: T9 Optional: BWT™ System |
| Temperature Range | Standard: -40° to 400°F (-40° to 205°C) Optional: -310° to 932°F (-190° to 500°C) |
| Pressure Range | Standard: 0-250 psig (0.1013-1.824 MPa), 750 psig (5.272 MPa) test Optional: 3,480 psig (240 barg) |
| Materials | Standard: all metal, titanium Optional: Monel, Hastalloy, and 316 stainless steel |
| Physical | Cable Type and Length: <i>Standard:</i> RG62 a/U coaxial, up to 3 ft (1 m) <i>Optional:</i> RG62 a/U coaxial, up to 1,000 ft (300 m) Housing Options: Explosion-proof (Class 1, Div. 1, Groups C & D) Flameproof (INIEX/ISSeP certified for EEx d II C T4 & T6) Weatherproof (NEMA 4X, IP65) |

Flowcell Specifications

The flowcell specifications for the Model XGS868 flow transmitter are as follows:

| | |
|-----------------------|--|
| Process Connections | Spoolpiece: Flanged (typical), threaded (optional) Transducer Insertion Method: Cold Tap Transducer Connection: 1 in. NPTM |
| Pipe Size & Materials | Outside Diameter (OD): 2 to 48 in. NB ANSI (50 to 1,200 mm NB) |

Appendix A

CE Mark Compliance

Introduction A-1

Wiring A-1

Introduction

For CE Mark compliance, the Model XGS868 flow transmitter must be wired in accordance with the instructions in this appendix.

IMPORTANT: *CE Mark compliance is required only for units intended for use in EEC countries.*

Wiring

The Model XGS868 must be wired with the recommended cable, and all connections must be properly shielded and grounded. Refer to Table A-1 below for the specific requirements.

Table A-1: Wiring Modifications

| Connection | Cable Type | Termination Modification |
|--------------|--|--|
| Transducer | RG62 a/U | Add metallic cable clamp from braid to chassis ground. |
| | Armored RG62 a/U or conduit | None - grounded via cable gland. |
| Input/Output | 22 AWG shielded (e.g. Baystate #78-1197) | Terminate shield to chassis ground. |
| | Armored conduit | None - grounded via cable gland. |
| Power | 14 AWG, 3 conductor, shielded (e.g. Belden #19364) | None required |
| | Armored Conduit | None - grounded via cable gland. |

Note: *If the Model XGS868 is wired as described in this appendix, the unit will comply with the EMC Directive 89/336/EEC.*

Appendix B

Data Records

| | |
|-------------------------------------|------------|
| Available Option Cards | B-1 |
| Option Cards Installed..... | B-2 |
| Initial Setup Data | B-3 |

Available Option Cards The Model XGS868 can hold one option card in Slot 1 and one in Slot 2. The available configurations are listed in Table B-1 below.

Table B-1: Option Card Configurations

| Card # | Slot # | Configuration |
|---------|--------|---|
| 1215-02 | 1 | FF - 4 Frequency Outputs |
| 1215-03 | | TT - 4 Totalizer Outputs |
| 1215-04 | | FT - 2 Frequency Outputs/2 Totalizer Outputs |
| 1215-05 | | FO - 2 Frequency Outputs |
| 1215-06 | | TO - 2 Totalizer Outputs |
| 1215-07 | | AA - 4 Standard Alarms |
| 1215-08 | | HH - 4 Hermetic Alarms |
| 1215-09 | | FA - 2 Frequency Outputs/2 Standard Alarms |
| 1215-10 | | FH - 2 Frequency Outputs/2 Hermetic Alarms |
| 1215-11 | | TA - 2 Totalizer Outputs/2 Standard Alarms |
| 1215-12 | | TH - 2 Totalizer Outputs/2 Hermetic Alarms |
| 1223-02 | | OI - 2 Current Inputs |
| 1223-03 | | OR - 2 RTD Inputs |
| 1223-04 | | TI - 2 Current Inputs/2 Totalizer Outputs |
| 1223-05 | | TR - 2 RTD Inputs/2 Totalizer Outputs |
| 1223-06 | | FI - 2 Current Inputs/2 Frequency Outputs |
| 1223-07 | | FR - 2 RTD Inputs/2 Frequency Outputs |
| 1223-08 | | AI - 2 Current Inputs/2 Standard Alarms |
| 1223-09 | | HI - 2 Current Inputs/2 Hermetic Alarms |
| 1223-10 | | AR - 2 RTD Inputs/2 Standard Alarms |
| 1223-11 | | HR - 2 RTD Inputs/2 Hermetic Alarms |
| 1225-13 | | CO - 2 Current Outputs |
| 1225-14 | | CF - 2 Current Outputs/2 Frequency Outputs |
| 1225-15 | | CT - 2 Current Outputs/2 Totalizer Outputs |
| 1225-16 | | CA - 2 Current Outputs/2 Standard Alarms |
| 1225-17 | | CH - 2 Current Outputs/2 Hermetic Alarms |
| 1233-02 | | RR - 4 RTD Inputs |
| 1233-03 | | IR - 2 RTD Inputs/2 Current Inputs |
| 1233-04 | | II - 4 Current Inputs |
| 1272-02 | | CI - 2 Current Outputs/2 Current Inputs |
| 1272-03 | | CR - 2 Current Outputs/2 RTD Inputs |
| 1272-04 | | CIR - 2 Current Outputs/1 Current Input/1 RTD Input |
| 1146-02 | 2 | 512 KB Memory + PCMCIA Card Connector |
| 1146-03 | | 2 MB Memory + PCMCIA Card Connector |
| 1310 | | Modbus Communications Protocols |

Option Cards Installed

Whenever an option card is installed or changed in the Model XGS868 flow transmitter, record the type of card and any additional setup information in the appropriate row of Table B-2 below.

Table B-2: Option Cards Installed

| Slot # | Type of Option Card | Additional Setup Information |
|--------|-----------------------|------------------------------|
| 0 | Analog Outputs (A, B) | |
| 1 | | |
| 2 | | |

Initial Setup Data

After the Model XGS868 flow transmitter has been installed, some initial setup data must be entered via the *User Program* prior to operation. Record that information in Table B-3 below.

Table B-3: Initial Setup Data

| General Information | | | | | |
|---|----------|--------|--|---------------------------|-----------------|
| Model # | | | | Serial # | |
| Software Vers. | | | | Setup Date | |
| Global System Parameters - <i>GLOBL/SYSTM (1-Channel Meter)</i> | | | | | |
| System Units | English | Metric | | | |
| Global System Parameters - <i>GLOBL/SYSTM (2-Channel Meter)</i> | | | | | |
| System Units | English | Metric | | Mass Flow | |
| Vol. Units | | | | Mass Flow Time | |
| Vol. Time Units | | | | MDOT Dec. Dig. | |
| Vol. Dec. Digits | | | | Mass Totalizer | |
| Totalizer Units | | | | Mass Dec. Dig. | |
| Tot. Dec. Digits | | | | | |
| Measurement Method - <i>ACTIV (1-Channel meter)</i> | | | | | |
| Site Status | Burst | | | Measure Mode | Skan S/M |
| Measurement Method - <i>ACTIV (2-Channel meter)</i> | | | | | |
| Channel 1 | | | | Channel 2 | |
| Channel Status | Off | Burst | | Channel Status | Off Burst |
| Measure Mode | Skan | S/M | | Measure Mode | Skan S/M |
| Channel System Parameters - <i>CHx/SYSTM</i> | | | | | |
| Channel 1 | | | | Channel 2 (if applicable) | |
| Channel Label | | | | Channel Label | |
| Site/Channel Msg. | | | | Channel Message | |
| Metrc Press. Units | bar | kPa | | Metrc Press. Units | bar kPa |
| Gas Equation | Standard | Actual | | Gas Equation | Standard Actual |
| Vol. Units | | | | Vol. Units | |
| Vol. Time Units | | | | Vol. Time Units | |
| Vol. Dec. Digits | | | | Vol. Dec. Digits | |
| Totalizer Units | | | | Totalizer Units | |
| Tot. Dec. Digits | | | | Tot. Dec. Digits | |
| Mass Flow | | | | Mass Flow | |
| Mass Flow Time | | | | Mass Flow Time | |
| MDOT Dec. Dig. | | | | MDOT Dec. Dig. | |
| Mass Totalizer | | | | Mass Totalizer | |
| Mass Dec. Dig. | | | | Mass Dec. Dig. | |

Table B-3: Initial Setup Data (cont.)**Pipe/Transducer Parameters - PIPE**

| Channel 1 | | | Channel 2 (if applicable) | | |
|-----------------------|----------|----------|---------------------------|----------|----------|
| Trans. Type | STD | SPEC | Trans. Type | STD | SPEC |
| Transducer # | | | Transducer # | | |
| Spec. Trans. Hz | | | Spec. Trans. Hz | | |
| Spec. Trans. Tw | | | Spec. Trans. Tw | | |
| Pipe O.D. | | | Pipe O.D. | | |
| Pipe Wall | | | Pipe Wall | | |
| Path Length (P) | | | Path Length (P) | | |
| Axial Length (L) | | | Axial Length (L) | | |
| Fluid Type | Steam | Other | Fluid Type | Steam | Other |
| Other/Sndspd | | | Other/Sndspd | | |
| Mass Flow | No | Yes | Mass Flow | No | Yes |
| Fluid Density | | | Fluid Density | | |
| Multi K-factors | Off | On | Multi K-factors | Off | On |
| Edit Table | No | Yes | Edit Table | No | Yes |
| K-factor Table | | | K-factor Table | | |
| K-Factor # | Velocity | K-Factor | K Factor # | Velocity | K-Factor |
| 1 | | | 1 | | |
| 2 | | | 2 | | |
| 3 | | | 3 | | |
| 4 | | | 4 | | |
| 5 | | | 5 | | |
| 6 | | | 6 | | |
| 7 | | | 7 | | |
| 8 | | | 8 | | |
| 9 | | | 9 | | |
| 10 | | | 10 | | |
| 11 | | | 11 | | |
| 12 | | | 12 | | |
| 13 | | | 13 | | |
| 14 | | | 14 | | |
| 15 | | | 15 | | |
| 16 | | | 16 | | |
| 17 | | | 17 | | |
| 18 | | | 18 | | |
| 19 | | | 19 | | |
| 20 | | | 20 | | |
| Cal. Factor | | | Cal. Factor | | |

Appendix C

Measuring P and L Dimensions

| | |
|-------------------------|-----|
| Introduction | C-1 |
| Measuring P and L | C-1 |

Introduction

When programming the PIPE menu in the Model XGS868's *User Program*, the *path length* (P) and the *axial dimension* (L) must be entered. These parameters are determined by measurements on the actual transducer installation, with P equal to the face-to-face distance between the transducers and L equal to the axial distance between the centers of the transducer faces.

The accuracy of the programmed P and L values is critical to precise flow rate measurements. If Panametrics supplies the flowcell for the system, the correct values will be included in the documentation supplied with the system. For transducers installed on an existing pipe (see Figure C-1 on page C-2), P and L must be measured at the site. This appendix provides instructions for properly determining these dimensions.

Measuring P and L

Whenever possible, physically measure the face-to-face distance (P) and the axial distance (L) between the centers of the flat faces of the transducers. Refer to Figure C-1 on page C-2 for an illustration of the proper distances to measure, in a typical installation.

In some situations only one of the required distances can be directly measured. When this happens, a knowledge of the installation angle (θ) of the transducers, permits the second distance to be calculated from Equation C-1 below:

$$\cos \theta = \frac{L}{P} \quad (C-1)$$

As an example, assume that the transducer installation angle is known to be 45° and the L distance is measured to be 10.00 inches. Then, the P distance is calculated to be $P = 10.00/0.707 = 14.14$ inches.

With a Bias 90° transducer installation, it sometimes happens that the only known parameters are the transducer angle (θ) and the centerline distance between the transducer bodies (CL). In these cases, it is still possible to calculate P and L by combining Equation C-1 above with the additional Equation C-2 below (see Figure C-1 on page C-2):

$$P = CL - 1.2 \quad (C-2)$$

Standard Panametrics 90° transducers have the face offset from the centerline of the body by 0.6 inches. Thus, a pair of transducers has a total offset of 1.2 inches, as indicated in Equation C-2 above. For example, suppose that the transducer installation angle is 30° and CL is measured to be 12.00 inches. Then, $P = 12.00 - 1.2 = 11.80$ inches and $L = 11.80 \times 0.866 = 10.93$ inches.




Figure C-1: Top View of Typical Transducer Installations

Index

A

Abbreviations, Volumetric Units 2-8, 2-14
 ACTIV Submenu 2-12
 Address. 1-2
 Alarms Option Card
 Connecting 1-15
 Fail-Safe Operation 1-16
 Pin Assignments. 1-22
 Analog Inputs Option Card
 Connecting 1-17
 Pin Assignments. 1-17
 Rating 1-17
 Analog Outputs (Slot 0)
 Connecting 1-12
 Pin Assignments. 1-22
 Analog Outputs Option Card
 Connecting 1-19, 1-20
 Pin Assignments. 1-22
 Axial Dimension
 Measuring. C-1
 Programming 2-21

C

Cable
 Serial Port. 1-13
 Transducers 1-4, 1-11
 Calibration Factor, Programming. 2-23
 CE Mark Compliance. A-1
 Connectors, Electrical 1-7

D

Diagnostic Parameters 3-8, 3-11
 Display
 Channel Mode Options 3-10
 Data 3-2
 Measurement Mode 3-2
 Parameter Options 3-8, 3-11

E

Electrical Connectors. 1-7
 Electronics Console
 Description. 1-3
 Mounting 1-6, 1-21

F

Flowcell
 Description 1-4
 Installing 1-5
 Fluid Type, Selecting 2-21
 Fuse Ratings 4-2

I

Initial Setup
 Data Table. B-3
 Minimum Required. 2-1
 Input Voltage. 1-8
 Internal Tests. 3-2

K

K-Factors, Programming. 2-22

L

Lightning Protector, Connecting. 1-11
 LVD Statement 1-3

M

Measurements
 Displaying. 3-2, 3-5
 Parameter Options. 3-8, 3-11
 Taking 3-2, 3-5

O

Option Card
 Alarms. 1-15
 Analog Inputs 1-17
 Analog Outputs. 1-19, 1-20
 RTD Inputs 1-19
 Setup Information Table B-2
 Totalizer/Frequency Outputs. 1-18

P

Parameter Options. 3-8, 3-11
 Path Length
 Measuring C-1
 Programming. 2-21
 Pipe OD, Programming. 2-20
 PIPE Submenu 2-18
 Pipe Wall, Programming. 2-20

Index (cont.)

P (cont.)

| | |
|--------------------------|-----------|
| Power | |
| Connecting | 1-8 |
| Terminal Block | 1-8, 1-22 |
| Powering Up | |
| Display | 3-2 |
| Internal Checks | 3-2 |
| Preamplifier, Connecting | 1-11 |
| Pressure Transmitter | |
| Installing | 1-5 |
| Location | 1-4 |

R

| | |
|-----------------------------|------|
| Return Policy | 1-2 |
| RS232 Port | |
| <i>See Serial Port</i> | |
| RTD Inputs Option Card | |
| Connecting | 1-19 |
| Pin Assignments | 1-22 |
| RTD Temperature Transmitter | 1-5 |

S

| | |
|------------------------------------|------------------|
| Serial Port | |
| Cable | 1-13 |
| Connecting | 1-13, 1-14 |
| Pin Assignments | 1-13, 1-14, 1-22 |
| Service Form | 1-2 |
| Slot 0 | |
| <i>See Analog Outputs (Slot 0)</i> | |
| Special Transducers | 2-19 |
| Specifications | |
| Electrical | 4-2 |
| Flowcell | 4-4 |
| General | 4-1 |
| Transducer | 4-4 |
| SYSTEM Submenu | 2-13 |

T

| | |
|-------------------------|-----|
| Temperature Transmitter | |
| Installing | 1-5 |
| Location | 1-4 |
| RTD | 1-5 |

T (cont.)

| | |
|--|------------------|
| Terminal Block | |
| Analog Outputs - I/O | 1-12, 1-22 |
| Power - TB1 | 1-8, 1-22 |
| Serial Port - RS232 | 1-13, 1-14, 1-22 |
| Transducers - CH1/CH2 | 1-11, 1-22 |
| Totalizer/Frequency Option Card | |
| Connecting | 1-18 |
| Pin Assignments | 1-22 |
| Transducers | |
| 180° Installation | C-1 |
| Axial Dimension | C-1 |
| Bias 90° Installation | C-1 |
| Cables | 1-4, 1-11 |
| Connecting | 1-11 |
| Installation Angle | C-1 |
| Location | 1-4 |
| Path Length | C-1 |
| Pin Assignments | 1-22 |
| Special | 2-19 |
| Transmitter | |
| <i>See Temperature or Pressure Transmitter</i> | |

U


| | |
|----------------|------|
| Unpacking | 1-2 |
| User Program | |
| ACTIV Submenu | 2-12 |
| Entering | 2-2 |
| PIPE Submenu | 2-18 |
| SYSTEM Submenu | 2-13 |

V

| | |
|------------------|-----------|
| Voltage, Input | 1-8 |
| Volumetric Units | |
| Abbreviations | 2-8, 2-14 |
| Selecting | 2-8, 2-14 |
| Table of Options | 2-8, 2-14 |

W

| | |
|--------------------|-----------------------|
| Warranty | 1-2 |
| Wiring | |
| CE Mark Compliance | A-1 |
| Option Card | <i>See Card Name</i> |
| Terminal Block | <i>See Block Name</i> |



DECLARATION OF CONFORMITY

We Panametrics Limited

(supplier's name)

Shannon Industrial Estate, Shannon, Co. Clare, Ireland

(supplier's address)

declare under our sole responsibility that the product

Model XGS868 Steam Ultrasonic Flow Transmitter

(name, type or model)

to which this declaration relates is in conformity with the following standards:

- EN 61326: 1998
- EN 61010-1: 1995

following the provisions of 89/336/EEC EMC Directive and 73/23/EEC Low Voltage Directive


Shannon: November 2, 2000

(place and date of issue)

(name and signature or equivalent
marking of authorized person)

Mr. James Gibson
GENERAL MANAGER





DECLARATION DE CONFORMITE

Nous Panametrics Limited

(Nom du Fournisseur)

Shannon Industrial Estate, Shannon, Co. Clare, Ireland

(Adresse)

déclarons, sous notre propre responsabilité, que le produit

Model XGS868 Steam Ultrasonic Flow Transmitter

(Nom, type et modèle)

relatif à cette déclaration est en conformité avec les documents suivants:

- EN 61326: 1998
- EN 61010-1: 1995

suivant, en celà, les règles de la Directive CEM 89/336/EEC et de la Directive Basse Tension DBT 73/23/EEC.


Shannon: November 2, 2000

(lieu et date)

(Nom et signature ou cachet
de la personne autorisée)

Mr. James Gibson
GENERAL MANAGER





KONFORMITÄTSERKLÄRUNG

Wir, Panametrics Limited

(Name des Lieferanten)

Shannon Industrial Estate, Shannon, Co. Clare, Ireland

(Anschrift)

erklären in alleiniger Verantwortung, daß das Produkt

Model XGS868 Steam Ultrasonic Flow Transmitter

(Name, Typ oder Modell)

folgende Normen erfüllt:

- EN 61326: 1998
- EN 61010-1: 1995

gemäß den Europäischen Richtlinien, Niederspannungsrichtlinie Nr.: 73/23/EWG und
EMV-Richtlinie Nr.: 89/336/EWG.

Shannon: November 2, 2000

(Ort und Datum der Ausstellung)

(Name und Unterschrift bzw. gleichwertige
Zeichnung des Bevollmächtigten)

Mr. James Gibson
GENERAL MANAGER





PANAMETRICS WORLDWIDE OFFICES

PCI Division, 221 Crescent Street, Suite 1, Waltham, MA 02453-3497 USA
Telephone (781) 899-2746 • Toll-Free (800) 833-9438 • Fax (781) 894-8582
E-Mail pci@panametrics.com • Web Site <http://www.panametrics.com>

ISO 9001
CERTIFIED

MAIN OFFICES:

USA

Panametrics, Inc.
221 Crescent St., Suite 1
Waltham, MA 02453-3497
USA
Telephone 781-899-2719
Toll-Free 800-833-9438
Fax 781-894-8582
E-Mail pci@panametrics.com
Web Site www.panametrics.com
ISO 9001 Certified

Ireland

Panametrics Limited
Bay 148, Shannon Airport
Shannon, Co. Clare
Ireland
Telephone 353-61-471377
Fax 353-61-471359
E-Mail info@panametrics.ie
ISO 9002 Certified

INTERNATIONAL OFFICES:

Australia

Panametrics Pty. Ltd.
P.O. Box 234
Gymea N.S.W. 2227
Australia
Telephone 61 (02) 9525 4055
Fax 61 (02) 9526 2776
E-Mail panaptyaus@bigpond.com

Austria

Panametrics Messtechnik GmbH
Waldgasse 39
A-1100 Wien
Austria
Telephone +43-1-602 25 34
Fax +43-1-602 25 34 11
E-Mail panametrics@netway.at

Benelux

Panametrics B.V.
Postbus 111
3870 CC Hoevelaken
The Netherlands
Telephone +31 (0) 33 253 64 44
Fax +31 (0) 33 253 72 69
E-Mail panabv@worldonline.nl

France

Panametrics S.A.
BP 106
11 Rue du Renard
92253 La Garenne Colombes Cedex
France
Telephone 33 (0) 1 47-82-42-81
Fax 33 (0) 1 47-86-74-90
E-Mail panametrics@panametrics.fr

Germany

Panametrics GmbH
Mess-und Pruftechnik
Robert-Bosch-Strasse 20a
65719 Hofheim
Germany
Telephone +49-6122-8090
Fax +49-6122-8147
E-Mail panametrics@t-online.de

Italy

Panametrics S.r.l.
Via Feltre, 19/A
20132 Milano
Italy
Telephone 02-2642131
Fax 02-26414454
E-Mail pana.it@iol.it

Japan

Panametrics Japan Co., Ltd.
5F, Sumitomo Bldg.
5-41-10, Koishikawa, Bunkyo-Ku
Tokyo 112-0002
Japan
Telephone 81 (03) 5802-8701
Fax 81 (03) 5802-8706
E-Mail pci@panametrics.co.jp

Korea

Panametrics Korea Ltd.
Kangnam P.O. Box 1902
Seoul
Korea
Telephone 82-2-555-4611
Fax 82-2-556-4351
E-Mail panakor@soback.kornet.nm.kr

Spain

Panametrics Instrumentacion S.L.
Santa Hortensia 15
28002 Madrid
Spain
Telephone 34 (91) 515.59.60
Fax 34 (91) 515.59.63
E-Mail info@panametrics.infonegocio.com

Sweden

Panametrics AB
Box 160
S147 23 Tumba
Sweden
Telephone +46-(0)8-530 685 00
Fax +46-(0)8-530 357 57
E-Mail pana@panametrics.se

Taiwan

Panametrics Exim Ltd.
8F, No. 251, Min Hwa Road
Ku Shan District
Kaohsiung
Taiwan
Telephone 886-7-552-5498
Fax 886-7-552-3596
E-Mail panaexim@ms11.hinet.net

United Kingdom

Panametrics UK Limited
Unit 2, Villiers Court
40 Upper Mulgrave Road
Cheam
Surrey SM2 7AJ
England
Telephone 020-8643-5150
Fax 020-8643-4225
E-Mail uksales@panametrics.ie