

TRANSMISSION SECTION

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

CONTROL SYSTEMS**CS****AUTOMATIC TRANSMISSION****4AT****AUTOMATIC TRANSMISSION
(DIAGNOSTICS)****4AT(diag)****MANUAL TRANSMISSION AND
DIFFERENTIAL****5MT****MANUAL TRANSMISSION AND
DIFFERENTIAL****6MT****MANUAL TRANSMISSION AND
DIFFERENTIAL (DIAGNOSTICS)****6MT(diag)****CLUTCH SYSTEM****CL**

MANUAL TRANSMISSION AND DIFFERENTIAL

5MT

	Page
1. General Description	2
2. Transmission Gear Oil	37
3. Manual Transmission Assembly	38
4. Transmission Mounting System	45
5. Oil Seal.....	47
6. Switches and Harness	48
7. Vehicle Speed Sensor.....	51
8. Preparation for Overhaul.....	52
9. Transfer Case and Extension Case Assembly.....	53
10. Rear Case	57
11. Transfer Drive Gear	58
12. Transfer Driven Gear	60
13. Center Differential	62
14. Reverse Check Sleeve.....	63
15. Transmission Case	66
16. Main Shaft Assembly for Single-Range	72
17. Main Shaft Assembly for Dual-Range	82
18. Input Shaft Assembly	87
19. Drive Pinion Shaft Assembly.....	91
20. Front Differential Assembly	102
21. Speedometer Gear.....	109
22. Reverse Idler Gear.....	110
23. Shifter Fork and Rod.....	112
24. Counter Gear	115
25. General Diagnostic.....	117

Transmission Mounting System


MANUAL TRANSMISSION AND DIFFERENTIAL

4. Transmission Mounting System

A: REMOVAL

1. PITCHING STOPPER

- 1) Disconnect the ground cable from battery.
- 2) Remove the air intake duct (Non-turbo model). <Ref. to IN(H4SO)-6, REMOVAL, Air Intake Duct.>
- 3) Remove the air cleaner case (Non-turbo model). <Ref. to IN(H4SO)-5, REMOVAL, Air Cleaner Case.>
- 4) Remove the intercooler (Turbo model). <Ref. to IN(H4DOTC)-10, REMOVAL, Intercooler.>
- 5) Remove the pitching stopper.




2. CROSSMEMBER AND CUSHION RUBBER

- 1) Disconnect the ground cable from battery.
- 2) Jack-up the vehicle and support it with sturdy racks.
- 3) Remove the front and center exhaust pipes. (Non-turbo model)
Without OBD
<Ref. to EX(H4SOw/oOBD)-6, REMOVAL, Front Exhaust Pipe.>
With OBD
<Ref. to EX(H4SO)-6, REMOVAL, Front Exhaust Pipe.>
- 4) Remove the center exhaust pipe. (Turbo model)
<Ref. to EX(H4DOTC)-9, REMOVAL, Center Exhaust Pipe.>
- 5) Remove the rear exhaust pipe and muffler.
- 6) Remove the heat shield cover. (If equipped)
- 7) Set the transmission jack under the transmission body.

CAUTION:

Always support the transmission case with a transmission jack.

- 8) Remove the rear crossmember.



- 9) Remove the rear cushion rubber.

B: INSTALLATION

1. PITCHING STOPPER

- 1) Install the pitching stopper.

Tightening torque:

T1: 50 N·m (5.1 kgf-m, 37 ft-lb)

T2: 58 N·m (5.9 kgf-m, 43 ft-lb)

- 2) Install the air intake duct and cleaner case. (Non-turbo model)
<Ref. to IN(H4SO)-5, INSTALLATION, Air Cleaner Case.> and <Ref. to IN(H4SO)-6, INSTALLATION, Air Intake Duct.>
- 3) Install the intercooler. (Turbo model)
<Ref. to IN(H4DOTC)-10, INSTALLATION, Intercooler.>
- 4) Connect the battery ground cable to battery.

2. CROSSMEMBER AND CUSHION RUBBER

- 1) Install the rear cushion rubber.

Tightening torque:


35 N·m (3.6 kgf-m, 26 ft-lb)

- 2) Install the rear crossmember.

Tightening torque:

T1: 70 N·m (7.1 kgf-m, 51 ft-lb)

T2: 140 N·m (14.3 kgf-m, 103 ft-lb)



- 3) Remove the transmission jack.
- 4) Install the heat shield cover. (If equipped)

Transmission Mounting System

MANUAL TRANSMISSION AND DIFFERENTIAL

5) Install the front and center exhaust pipes. (Non-turbo model)

Without OBD

<Ref. to EX(H4SOw/oOBD)-7, INSTALLATION, Front Exhaust Pipe.>

With OBD

<Ref. to EX(H4SO)-7, INSTALLATION, Front Exhaust Pipe.>

6) Install the center exhaust pipe. (Turbo model)
<Ref. to EX(H4DOTC)-10, INSTALLATION, Center Exhaust Pipe.>

7) Install the rear exhaust pipe and muffler.

C: INSPECTION

Repair or replace parts if the results of the inspection below are not satisfactory.

1. PITCHING STOPPER

Make sure the pitching stopper is not bent or damaged. Make sure the rubber is not stiff, cracked, or otherwise damaged.

2. CROSSMEMBER AND CUSHION RUBBER

Make sure the crossmember is not bent or damaged. Make sure the cushion rubber is not stiff, cracked, or otherwise damaged.

5. Oil Seal

ST 498057300 INSTALLER

A: INSPECTION

Check the oil seal portion for leakage. If leakage is found, replace the oil seal with a new one.

B: REPLACEMENT


- 1) Clean the transmission exterior.
- 2) Drain the gear oil completely.

NOTE:


Tighten the drain plug after draining gear oil.

Tightening torque:

69 N·m (7.0 kgf·m, 50.6 ft-lb)




- 3) Remove the rear exhaust pipe and muffler.
 - 4) Remove the heat shield cover. (If equipped)
 - 5) Remove the propeller shaft. <Ref. to DS-16, REMOVAL, Propeller Shaft.>
 - 6) Using the ST, remove the oil seal.
- ST 398527700 PULLER ASSY



(A) Oil seal

- 7) Using the ST, install the oil seal.



- 8) Install the propeller shaft. <Ref. to DS-17, INSTALLATION, Propeller Shaft.>
- 9) Install the heat shield cover.
- 10) Install the rear exhaust pipe and muffler.
- 11) Pour gear oil and check the oil level. <Ref. to 5MT-37, REPLACEMENT, Transmission Gear Oil.>

Switches and Harness

MANUAL TRANSMISSION AND DIFFERENTIAL


6. Switches and Harness

A: REMOVAL

1. BACK-UP LIGHT AND NEUTRAL POSITION SWITCH


- 1) Disconnect the ground cable from battery.
- 2) Remove the air intake duct and cleaner case. (Non-turbo model) <Ref. to IN(H4SO)-5, REMOVAL, Air Cleaner Case.> and <Ref. to IN(H4SO)-6, REMOVAL, Air Intake Duct.>
- 3) Remove the intercooler (Turbo model). <Ref. to IN(H4DOTC)-10, REMOVAL, Intercooler.>
- 4) Disconnect the connector of back-up light switch and neutral position switch.

- Non-turbo MODEL




- (A) Neutral switch (Brown)
- (B) Back-up light switch (Gray)

- Turbo MODEL



- 5) Lift-up the vehicle.


- 6) Remove the back-up light switch and neutral position switch with harness.



- (A) Neutral switch (Brown)
- (B) Back-up light switch (Gray)


2. HIGH-LOW SWITCH

- 1) Disconnect the ground cable from battery.
- 2) Remove the air intake duct and cleaner case. (Non-turbo model) <Ref. to IN(H4SO)-5, REMOVAL, Air Cleaner Case.> and <Ref. to IN(H4SO)-6, REMOVAL, Air Intake Duct.>
- 3) Disconnect the connector of high-low switch.



- (A) Neutral switch (Brown)
- (B) Back-up light switch (Gray)
- (C) High-low switch (Black)

- 4) Remove the high-low switch cable from clamp.
- 5) Remove the high-low switch.



- (A) Clamp
- (B) High-low switch


B: INSTALLATION

1. BACK-UP LIGHT SWITCH AND NEUTRAL POSITION SWITCH

1) Install the back-up light switch and neutral position switch with harness.

Tightening torque:

24.5 N·m (2.5 kgf·m, 18.1 ft·lb)



- (A) Neutral switch
- (B) Back-up light switch

2) Connect the connector of back-up light switch and neutral position switch.
 3) Install the air intake duct and cleaner case. (Non-turbo model) <Ref. to IN(H4SO)-5, INSTALLATION, Air Cleaner Case.> and <Ref. to IN(H4SO)-6, INSTALLATION, Air Intake Duct.>
 4) Install the intercooler. (Turbo model) <Ref. to IN(H4DOTC)-10, INSTALLATION, Intercooler.>
 5) Connect the battery ground cable to battery.

2. HIGH-LOW SWITCH

1) Install the high-low switch.

Tightening torque:

24.5 N·m (2.5 kgf·m, 18.1 ft·lb)

2) Install the high-low switch cable to clamp.
 3) Connect the connector of high-low switch.
 4) Install the air intake duct and cleaner case. <Ref. to IN(H4SO)-5, INSTALLATION, Air Cleaner Case.> and <Ref. to IN(H4SO)-6, INSTALLATION, Air Intake Duct.>
 5) Connect the battery ground cable to battery.

C: INSPECTION

1. BACK-UP LIGHT SWITCH

Inspect the back-up light switch. <Ref. to LI-7, INSPECTION, Back-up Light System.>

2. NEUTRAL POSITION SWITCH

1) Turn the ignition switch to OFF.
 2) Disconnect the connector of neutral position switch.
 3) Measure the resistance between neutral position switch terminals.


Non-turbo model:

Gear shift position	Terminal No.	Specified resistance
Neutral position	1 and 2	Less than 1 Ω
Other positions		More than 1 MΩ


Turbo model:

Gear shift position	Terminal No.	Specified resistance
Neutral position	1 and 3	Less than 1 Ω
Other positions		More than 1 MΩ

• NON-TURBO MODEL



• TURBO MODEL



4) Replace defective parts.


3. HIGH-LOW SWITCH

1) Turn ignition switch to OFF.
 2) Disconnect connector high-low switch.
 3) Measure the resistance between high-low switch terminals.

Switches and Harness

MANUAL TRANSMISSION AND DIFFERENTIAL

Gear shift position	Terminal No.	Specified resistance
LO position	1 and 2	Less than 1 Ω
HIGH position		More than 1 M Ω




4) Replace defective parts.

7. Vehicle Speed Sensor

A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Lift-up the vehicle.
- 3) Remove the front, center rear exhaust pipes and muffler.
- 4) Disconnect the connector from vehicle speed sensor.
- 5) Turn and remove the vehicle speed sensor.



B: INSTALLATION

NOTE:

- Discard the vehicle speed sensor and after removal, replace with a new one.
- Ensure the sensor mounting hole is clean and free of foreign matter.
- Align the tip end of key with key groove on end of speedometer shaft during installation.

- 1) Hand tighten the vehicle speed sensor.
- 2) Tighten the vehicle speed sensor using suitable tool.

Tightening torque:

5.9 N·m (0.6 kgf-m, 4.3 ft-lb)

- 3) Connect the connector to vehicle speed sensor.
- 4) Install the front, center exhaust pipes and muffler.
- 5) Lower the vehicle.
- 6) Connect the battery ground cable to battery.

C: INSPECTION

Inspect the vehicle speed sensor.

Without OBD

<Ref. to EN(H4SOw/oOBD)(diag)-80, DTC 33 VEHICLE SPEED SIGNAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

With OBD Non-turbo model

<Ref. to EN(H4SO)(diag)-185, DTC P0502 VEHICLE SPEED SENSOR CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> <Ref. to EN(H4SO)(diag)-186, DTC P0503 VEHICLE SPEED SENSOR INTERMITTENT/ERRATIC/HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

Turbo model

<Ref. to EN(H4DOTC)(diag)-200, DTC P0502 VEHICLE SPEED SENSOR CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> <Ref. to EN(H4DOTC)(diag)-202, DTC P0503 VEHICLE SPEED SENSOR INTERMITTENT/ERRATIC/HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

Preparation for Overhaul

MANUAL TRANSMISSION AND DIFFERENTIAL

8. Preparation for Overhaul

A: PROCEDURE


- 1) Clean oil, grease, dirt and dust from transmission.
- 2) Remove the drain plug to drain oil. After draining, retighten it as before.

NOTE:


Replace the gasket with a new one.

Tightening torque:

69 N-m (7.0 kgf-m, 50.6 ft-lb)



- 3) Attach the transmission to ST.
ST 499937100 TRANSMISSION STAND



- 4) Rotating parts should be coated with oil prior to assembly.
- 5) All disassembled parts, if to be reused, should be reinstalled in the original positions and directions.
- 6) Gaskets, lock washers and lock nut must be replaced with new ones.
- 7) Liquid gasket should be used where specified to prevent leakage.


Transfer Case and Extension Case Assembly

MANUAL TRANSMISSION AND DIFFERENTIAL


9. Transfer Case and Extension Case Assembly

A: REMOVAL

- 1) Remove the manual transmission assembly from vehicle. <Ref. to 5MT-38, REMOVAL, Manual Transmission Assembly.>
- 2) Remove the back-up light switch and neutral position switch. <Ref. to 5MT-48, REMOVAL, Switches and Harness.>
- 3) Remove the transfer case with extension case assembly.




- 4) Remove the shifter arm.
- 5) Remove the extension case assembly.




B: INSTALLATION

- 1) Install the center differential and transfer driven gear into transfer case.




- 2) Remove the bearing outer race from extension case.



- (A) Bearing outer race
(B) Extension case


- 3) While pressing the bearing outer race horizontally, turn the driven shaft ten rotations.
- 4) Measure the height "W" between transfer case and taper roller bearing on the transfer driven gear.



- 5) Measure the depth "X".

NOTE:

Measure with bearing cone and thrust washer removed.



- 6) Calculate the washer thickness "t" using the following equation:

$$t = X - W + 0.2 \text{ to } 0.3 \text{ mm (0.008 to 0.012 in)}$$

- 7) Select the nearest washer in the following table:

Preload between thrust washer and taper roller bearing:

$$0.2 - 0.3 \text{ mm } T (0.008 - 0.012 \text{ in } T)$$

Transfer Case and Extension Case Assembly

MANUAL TRANSMISSION AND DIFFERENTIAL


NOTE:

Be sure to observe preload.

Thrust washer (50 × 61 × t)	
Part No.	Thickness mm (in)
803050060	0.50 (0.0197)
803050061	0.55 (0.0217)
803050062	0.60 (0.0236)
803050063	0.65 (0.0256)
803050064	0.70 (0.0276)
803050065	0.75 (0.0295)
803050066	0.80 (0.0315)
803050067	0.85 (0.0335)
803050068	0.90 (0.0354)
803050069	0.95 (0.0374)
803050070	1.00 (0.0394)
803050071	1.05 (0.0413)
803050072	1.10 (0.0433)
803050073	1.15 (0.0453)
803050074	1.20 (0.0472)
803050075	1.25 (0.0492)
803050076	1.30 (0.0512)
803050077	1.35 (0.0531)
803050078	1.40 (0.0551)
803050079	1.45 (0.0571)


- 8) Fit the thrust washers on transfer drive shaft.
- 9) Install the bearing cone into extension case.
- 10) Measure the depth “S” between transfer case and center differential.

ST 398643600 GAUGE



- 11) Measure the depth “T” between extension case and transfer drive gear.

ST 398643600 GAUGE



- 12) Calculate the space “U” using the following equation:

$$U = \{15 \text{ mm (0.59 in)} - T\} - \{S - 15 \text{ mm (0.59 in)}\} - 0.15 - 0.35 \text{ mm (0.0059 - 0.0138 in)}$$

- 13) Select the suitable washer in the following table:

Standard clearance:


0.15 — 0.35 mm (0.0059 — 0.0138 in)

Thrust washer	
Part No.	Thickness mm (in)
803036050	0.9 (0.035)
803036054	1.0 (0.039)
803036051	1.1 (0.043)
803036055	1.2 (0.047)
803036052	1.3 (0.051)
803036056	1.4 (0.055)
803036053	1.5 (0.059)
803036057	1.6 (0.063)
803036058	1.7 (0.067)

- 14) Fit the thrust washer on center differential.
- 15) Apply proper amount of liquid gasket to the transfer case mating surface.

Liquid gasket:

THREE BOND 1215




Transfer Case and Extension Case Assembly

MANUAL TRANSMISSION AND DIFFERENTIAL

16) Install the extension assembly into transfer case.


Tightening torque:

40 N·m (4.1 kgf·m, 29.7 ft·lb)




Tightening torque:


25 N·m (2.5 kgf·m, 18.1 ft·lb)



17) Install the shifter arm to transfer case.



18) Hang the shifter arm on 3rd-4th fork rod.



(A) Shifter arm


(B) 3rd-4th fork rod

19) Install the transfer case with extension case assembly to transmission case.

C: DISASSEMBLY


1. TRANSFER CASE

- 1) Remove the reverse check assembly. <Ref. to 5MT-63, REMOVAL, Reverse Check Sleeve.>
- 2) Remove the oil guide.



2. EXTENSION CASE

- 1) Remove the transfer drive gear assembly. <Ref. to 5MT-58, REMOVAL, Transfer Drive Gear.>
- 2) Remove the shift bracket.



- 3) Remove the oil seal from extension case. <Ref. to 5MT-47, Oil Seal.>

Transfer Case and Extension Case Assembly

MANUAL TRANSMISSION AND DIFFERENTIAL

D: ASSEMBLY

1. EXTENSION CASE

1) Using the ST, install the oil seal to extension case. <Ref. to 5MT-47, Oil Seal.>


NOTE:

Use a new oil seal.

2) Install the shift bracket to extension case.

Tightening torque:

25 N·m (2.5 kgf·m, 18.1 ft·lb)




3) Install the transfer drive gear to extension case. <Ref. to 5MT-58, INSTALLATION, Transfer Drive Gear.>

2. TRANSFER CASE

1) Install the oil guide to transfer case.

Tightening torque:

6.4 N·m (0.65 kgf·m, 4.7 ft·lb)



2) Install the reverse check sleeve assembly to transfer case. <Ref. to 5MT-63, INSTALLATION, Reverse Check Sleeve.>

10.Rear Case

A: REMOVAL

- 1) Remove the manual transmission assembly from vehicle. <Ref. to 5MT-38, REMOVAL, Manual Transmission Assembly.>
- 2) Remove back-up light switch and neutral position switch. <Ref. to 5MT-48, REMOVAL, Switches and Harness.>
- 3) Remove rear case.

B: INSTALLATION

- 1) Install rear case.

Tightening torque:

24.5 N·m (2.5 kgf·m, 18.1 ft·lb)

- 2) Install back-up light switch and neutral position switch. <Ref. to 5MT-49, INSTALLATION, Switches and Harness.>
- 3) Install the manual transmission assembly to vehicle. <Ref. to 5MT-41, INSTALLATION, Manual Transmission Assembly.>

C: DISASSEMBLY

- 1) Remove the reverse check assembly. <Ref. to 5MT-63, REMOVAL, Reverse Check Sleeve.>
- 2) Remove oil guide.


D: ASSEMBLY

- 1) Install oil seal.
- 2) Install oil guide.


Tightening torque:

6.4 N·m (0.65 kgf·m, 4.7 ft·lb)

- 3) Install the reverse check assembly. <Ref. to 5MT-63, INSTALLATION, Reverse Check Sleeve.>



- 3) Remove oil seal.




Transfer Drive Gear

MANUAL TRANSMISSION AND DIFFERENTIAL

11. Transfer Drive Gear

A: REMOVAL

- 1) Remove the manual transmission assembly from vehicle. <Ref. to 5MT-38, REMOVAL, Manual Transmission Assembly.>
- 2) Remove the back-up light switch and neutral position switch. <Ref. to 5MT-48, REMOVAL, Switches and Harness.>
- 3) Remove the transfer case with extension case assembly. <Ref. to 5MT-53, REMOVAL, Transfer Case and Extension Case Assembly.>
- 4) Remove the extension case assembly.
- 5) Remove the transfer driven gear.
- 6) Remove the transfer drive gear.




B: INSTALLATION

- 1) Install the transfer drive gear.

Tightening torque:


26 N·m (2.7 kgf·m, 20 ft·lb)




- 2) Install the transfer driven gear.
- 3) Install the extension case assembly.
- 4) Install the transfer case and extension case assembly. <Ref. to 5MT-53, INSTALLATION, Transfer Case and Extension Case Assembly.>
- 5) Install the back-up light switch and neutral position switch. <Ref. to 5MT-49, INSTALLATION, Switches and Harness.>
- 6) Install the manual transmission assembly from vehicle. <Ref. to 5MT-41, INSTALLATION, Manual Transmission Assembly.>

C: DISASSEMBLY

- 1) Remove the snap ring.



- 2) Remove the ball bearing.




D: ASSEMBLY

- 1) Set the ST applying to inner race of bearing and install to drive shaft.

ST 398177700 INSTALLER

NOTE:

Do not apply pressure in excess of 10 kN (1 ton, 1.1 US ton, 1.0 Imp ton).



- 2) Install the snap ring on transfer drive shaft.
- 3) Check the clearance between snap ring and ball bearing. <Ref. to 5MT-59, INSPECTION, Transfer Drive Gear.>

E: INSPECTION

1) Bearings

Replace the bearings in the following cases:

- Broken or rusty bearings
- Worn or damaged
- Bearings that fail to turn smoothly or make abnormal noise when turned after gear oil lubrication.

2) Drive gear


Replace the drive gear in the following cases:

- If their tooth surfaces and shaft are excessively broken or damaged.

3) Measure the clearance between snap ring and inner race of ball bearing with a thickness gauge.

Clearance:

0.01 — 0.15 mm (0.0004 — 0.0059 in)



If the measurement is not within specification, select a suitable snap ring.

Snap ring (Outer-30)	
Part No.	Thickness mm (in)
805030041	1.53 (0.0602)
805030042	1.65 (0.0650)
805030043	1.77 (0.0697)


Transfer Driven Gear

MANUAL TRANSMISSION AND DIFFERENTIAL


12. Transfer Driven Gear

A: REMOVAL

- 1) Remove the manual transmission assembly from vehicle. <Ref. to 5MT-38, REMOVAL, Manual Transmission Assembly.>
- 2) Remove the back-up light switch and neutral position switch. <Ref. to 5MT-48, REMOVAL, Switches and Harness.>
- 3) Remove the transfer case with extension case assembly. <Ref. to 5MT-53, REMOVAL, Transfer Case and Extension Case Assembly.>
- 4) Remove the extension case assembly.
- 5) Remove the transfer driven gear.




- 6) Remove the bearing outer race from extension case and transfer case.



- (A) Bearing outer race (transfer case)
- (B) Bearing outer race (extension case)


B: INSTALLATION

- 1) Install the bearing outer race to extension case and transfer case.



- (A) Bearing outer race
- (B) Bearing outer race
- (C) Transfer case
- (D) Extension case

- 2) Install the transfer driven gear.



- 3) Install the transfer case and extension case assembly. <Ref. to 5MT-53, INSTALLATION, Transfer Case and Extension Case Assembly.>
- 4) Install the back-up light switch and neutral position switch. <Ref. to 5MT-49, INSTALLATION, Switches and Harness.>
- 5) Install the manual transmission assembly to vehicle. <Ref. to 5MT-41, INSTALLATION, Manual Transmission Assembly.>


Transfer Driven Gear

MANUAL TRANSMISSION AND DIFFERENTIAL

C: DISASSEMBLY

1) Using the ST, remove the roller bearing (extension case side).

ST 498077000 REMOVER




(A) Roller bearing

2) Using the ST1 and ST2, remove the roller bearing (transfer case side).

ST1 498077000 REMOVER

ST2 899864100 REMOVER



(A) Roller bearing

D: ASSEMBLY


1) Using the ST, install the roller bearing (extension case side).

ST1 398177700 INSTALLER

ST2 899864100 REMOVER

NOTE:

Do not apply pressure in excess of 10 kN (1 ton, 1.1 US ton, 1.0 Imp ton).




(A) Roller bearing

2) Using the ST, install the roller bearing (transfer case side).

ST 499757002 INSTALLER

NOTE:

Do not apply pressure in excess of 10 kN (1 ton, 1.1 US ton, 1.0 Imp ton).



(A) Roller bearing

E: INSPECTION

1) Bearings

Replace the bearings in the following cases:

- Broken or rusty bearings
- Worn or damaged
- Bearings that fail to turn smoothly or make abnormal noise when turned after gear oil lubrication.

2) Driven gear

Replace the drive gear in the following cases:

- If their tooth surfaces and shaft are excessively broken or damaged.

Center Differential

MANUAL TRANSMISSION AND DIFFERENTIAL

13.Center Differential

A: REMOVAL

- 1) Remove the manual transmission assembly from vehicle. <Ref. to 5MT-38, REMOVAL, Manual Transmission Assembly.>
- 2) Remove the transfer case with extension case assembly. <Ref. to 5MT-53, REMOVAL, Transfer Case and Extension Case Assembly.>
- 3) Remove the extension case assembly. <Ref. to 5MT-53, REMOVAL, Transfer Case and Extension Case Assembly.>
- 4) Remove the transfer driven gear. <Ref. to 5MT-60, REMOVAL, Transfer Driven Gear.>
- 5) Remove the center differential.

B: INSTALLATION

- 1) Install the center differential into transfer case.
- 2) Install the transfer driven gear. <Ref. to 5MT-60, INSTALLATION, Transfer Driven Gear.>
- 3) Install the extension case assembly. <Ref. to 5MT-53, INSTALLATION, Transfer Case and Extension Case Assembly.>
- 4) Install the transfer case with extension case assembly. <Ref. to 5MT-53, REMOVAL, Transfer Case and Extension Case Assembly.>
- 5) Install the back-up light switch and neutral position switch. <Ref. to 5MT-48, REMOVAL, Switches and Harness.>
- 6) Install the manual transmission assembly to vehicle. <Ref. to 5MT-41, INSTALLATION, Manual Transmission Assembly.>

C: DISASSEMBLY

NOTE:


Do not disassemble the center differential because it is a non-disassemble part.

Remove the ball bearing using ST.

NOTE:

Do not reuse the ball bearing.

ST 498077300 CENTER DIFFERENTIAL BEARING REMOVER




D: ASSEMBLY

Install the ball bearing to center differential assembly.

NOTE:

Do not apply pressure in excess of 10 kN (1 ton, 1.1 US ton, 1.0 Imp ton).



(A) Ball bearing

E: INSPECTION

1) Bearings

Replace the bearings in the following cases:

- Broken or rusty bearings
- Worn or damaged
- Bearings that fail to turn smoothly or make abnormal noise when turned after gear oil lubrication.
- Bearings having other defects

2) Center differential

Replace the center differential assembly in the following case:

- Worn or damaged


Reverse Check Sleeve

MANUAL TRANSMISSION AND DIFFERENTIAL


14. Reverse Check Sleeve

A: REMOVAL

- 1) Remove the manual transmission assembly from vehicle. <Ref. to 5MT-38, REMOVAL, Manual Transmission Assembly.>
- 2) Remove the transfer case with extension case assembly. <Ref. to 5MT-53, REMOVAL, Transfer Case and Extension Case Assembly.>
- 3) Remove the shifter arm.
- 4) Remove the plug, spring, washer and reverse check ball.



- 5) Remove the reverse check sleeve.




B: INSTALLATION

- 1) Install the reverse check sleeve.

Tightening torque:


6.4 N-m (0.65 kgf-m, 4.7 ft-lb)



- 2) Install the ball, spring, washer and plug to transfer case.

Tightening torque:

10 N-m (1.0 kgf-m, 7.2 ft-lb)




- 3) Install the shifter arm to transfer case assembly.
- 4) Install the transfer case with extension case assembly. <Ref. to 5MT-53, INSTALLATION, Transfer Case and Extension Case Assembly.>
- 5) Install the manual transmission assembly to vehicle. <Ref. to 5MT-41, INSTALLATION, Manual Transmission Assembly.>

C: DISASSEMBLY

- 1) Cover the reverse check sleeve with a rag, and remove the snap ring using a screwdriver.

NOTE:

Replace the snap ring with a new one if deformed or weakened.




(A) Snap ring

Reverse Check Sleeve

MANUAL TRANSMISSION AND DIFFERENTIAL

2) Remove the reverse check plate, reverse check spring, reverse check cam, return spring (5th-Rev), reverse accent shaft, return spring cap and return spring (1st-2nd).



- (A) Reverse check plate
- (B) Reverse check spring
- (C) Return spring (5th-Rev)
- (D) Reverse check cam
- (E) Reverse accent shaft
- (F) Return spring cap
- (G) Return spring (1st-2nd)

3) Remove the O-ring.

NOTE:


- Reverse check sleeve assembly uses an O-ring which should not be scratched.
- Be careful not to break the adjustment shim placed between reverse check sleeve assembly and case.

D: ASSEMBLY

1) Install the return spring (1st-2nd), return spring cap, reverse accent shaft, check cam, return spring and check spring onto reverse check sleeve.

NOTE:

Be sure the bent section of reverse check spring is positioned in the groove in check cam.



- (A) Reverse check plate
- (B) Reverse check spring
- (C) Return spring (5th-Rev)
- (D) Reverse check cam
- (E) Reverse accent shaft
- (F) Return spring cap
- (G) Return spring (1st-2nd)

2) Hook the bent section of reverse check spring over reverse check plate.

3) Rotate the cam so that the protrusion of reverse check cam is at the opening in plate.

4) With the cam held in that position, install the plate onto reverse check sleeve and hold with snap ring.

5) Position the O-ring in groove in sleeve.


Reverse Check Sleeve

MANUAL TRANSMISSION AND DIFFERENTIAL

E: INSPECTION

- Make sure the cutout section of reverse accent shaft is aligned with the opening in reverse check sleeve.
- Spin the cam by hand for smooth rotation.
- Move the cam and shaft all the way toward plate and release.

If the cam does not return properly, replace the reverse check spring; if shaft does not, check for scratches on the inner surface of sleeve. If sleeve is in good order, replace the spring.



- (A) Snap ring
- (B) Reverse check plate
- (C) Check spring
- (D) Check cam

- Select a suitable reverse accent shaft and reverse check plate. <Ref. to 5MT-65, ADJUSTMENT, Reverse Check Sleeve.>

F: ADJUSTMENT

1. NEUTRAL POSITION ADJUSTMENT

- 1) Shift the gear into 3rd gear position.
- 2) Shifter arm turns lightly toward the 1st/2nd gear side but heavily toward the reverse gear side because of the function of return spring, until arm contacts the stopper.
- 3) Make adjustment so that the heavy stroke (reverse side) is a little more than the light stroke (1st/2nd side).
- 4) To adjust, remove the bolts holding reverse check sleeve assembly to the case, move the sleeve assembly outward, and place adjustment shim (0 to 1 ea.) between sleeve assembly and case to adjust the clearance.

CAUTION:

Be careful not to break the O-ring when placing shim(s).

NOTE:

- When the shim is removed, the neutral position will move closer to reverse; when shim is added, the neutral position will move closer to 1st gear.

- If the shims alone cannot adjust clearance, replace the reverse accent shaft and re-adjust.


Adjustment shim	
Part No.	Thickness mm (in)
32190AA000	0.15 (0.0059)
32190AA010	0.30 (0.0118)

Reverse accent shaft		
Part No.	Mark	Remarks
32188AA130	S	Neutral position is closer to 1st gear.
32188AA140	T	Standard
32188AA150	V	Neutral position is closer to reverse gear.

2. REVERSE CHECK PLATE ADJUSTMENT

- 1) Shift the shifter arm to "5th" and then to reverse to see if reverse check mechanism operates properly.
- 2) Also check to see if the arm returns to neutral when released from reverse position. If the arm does not return properly, replace the reverse check plate.

Reverse check plate			
Part No.	(A): No.	Angle θ	Remarks
32189AA000	0	28°	Arm stops closer to 5th gear.
32189AA010	1	31°	Arm stops closer to 5th gear.
32189AA020	2	34°	Arm stops in the center.
32189AA030	3	37°	Arm stops closer to reverse gear.
32189AA040	4	40°	Arm stops closer to reverse gear.



Transmission Case


MANUAL TRANSMISSION AND DIFFERENTIAL

15. Transmission Case


A: REMOVAL

1. SINGLE-RANGE

- 1) Remove the manual transmission assembly from vehicle. <Ref. to 5MT-38, REMOVAL, Manual Transmission Assembly.>
- 2) Remove the clutch release lever. <Ref. to CL-26, REMOVAL, Release Bearing and Lever.>
- 3) Remove the transfer case with extension case assembly. <Ref. to 5MT-53, REMOVAL, Transfer Case and Extension Case Assembly.>
- 4) Remove the bearing mounting bolts.




- 5) Remove the main shaft rear plate.



(A) Main shaft rear plate


- 6) Separate the transmission case into right and left cases by loosening the coupling bolts and nuts.



- 7) Remove the drive pinion shaft assembly from left side transmission case.

NOTE:

Use a hammer handle, etc. to remove if too tight.




(A) Main shaft assembly
(B) Drive pinion shaft assembly

- 8) Remove the main shaft assembly.
- 9) Remove the differential assembly.

NOTE:

- Be careful not to confuse the right and left roller bearing outer races.
- Be careful not to damage the retainer oil seal.




2. DUAL-RANGE

- 1) Remove the manual transmission assembly from vehicle. <Ref. to 5MT-38, REMOVAL, Manual Transmission Assembly.>
- 2) Remove the clutch release lever. <Ref. to CL-26, REMOVAL, Release Bearing and Lever.>
- 3) Remove the transfer case with extension case assembly. <Ref. to 5MT-53, REMOVAL, Transfer Case and Extension Case Assembly.>

Transmission Case

MANUAL TRANSMISSION AND DIFFERENTIAL

4) Remove the input shaft holder.



- (A) Input shaft holder
- (B) Input shaft


5) Remove the high-low switch. <Ref. to 5MT-48, REMOVAL, Switches and Harness.>

6) Using the ST, drive out the straight pin, and remove high-low shifter lever.

ST 398791700 STRAIGHT PIN REMOVER 2


NOTE:

When driving out the straight pin, remove it in the direction that it does not butt against transmission case.




- (A) Straight pin
- (B) High-low shifter lever

7) Remove the main shaft rear plate.



- (A) Main shaft rear plate


8) Separate the transmission case into right and left cases by loosening the seventeen coupling bolts and nuts.



9) Remove the drive pinion shaft assembly from left side transmission case.

NOTE:

Use a hammer handle, etc. to remove if too tight.




- (A) Main shaft assembly
- (B) Drive pinion shaft assembly

10) Removing high-low shifter fork:

Raise the main shaft assembly slightly, and remove the high-low shifter fork together with high-low shifter shaft and washer.

NOTE:

Be careful not to drop the two high-low shifter pieces.



- (A) High-low shifter fork
- (B) Input shaft ASSY


Transmission Case

MANUAL TRANSMISSION AND DIFFERENTIAL

11) Remove the main shaft assembly and input shaft assembly.

NOTE:

Be careful not to drop the input shaft and main shaft as they are separable.




(A) Main shaft ASSY
(B) Input shaft ASSY

12) Remove the differential assembly.

NOTE:

- Be careful not to confuse the right and left roller bearing outer races.
- Be careful not to damage the retainer oil seal.



B: INSTALLATION

1. SINGLE-RANGE

- 1) Wipe off grease, oil and dust on the mating surfaces of transmission cases with white gasoline.
- 2) Install the front differential assembly.
- 3) Install the main shaft assembly.
Install the transmission case knock pin into needle bearing knock pin hole.
- 4) Install the drive pinion shaft assembly.
Install the transmission case knock pin into roller bearing knock pin hole.
- 5) Apply liquid gasket, and then put the case right side and left side together.

Liquid gasket:

THREE BOND 1215 or equivalent

- 6) Tighten the seventeen bolts with bracket, clip, etc. as shown in the figure.

NOTE:

- Insert the bolts from bottom and tighten the nuts at top.
- Put the cases together so that drive pinion shim and input shaft holder shim are not caught up in between.
- Confirm that the speedometer gear is meshed.


Tightening torque:

8 mm bolt

25 N·m (2.5 kgf·m, 18.1 ft·lb)

★ 10 mm bolt


39 N·m (4.0 kgf·m, 28.9 ft·lb)



7) Tighten the ball bearing attachment bolts.

Tightening torque:

29 N·m (3.0 kgf·m, 21.7 ft·lb)




8) Backlash adjustment of hypoid gear and preload adjustment of roller bearing:

NOTE:

Support the drive pinion assembly with ST.

ST 498427100 STOPPER




Transmission Case

MANUAL TRANSMISSION AND DIFFERENTIAL

9) Place the transmission with case left side facing downward and put ST1 on bearing cup.

10) Screw the retainer assembly into left case from the bottom using ST2. Fit the ST3 on transmission main shaft. Shift the gear into 4th or 5th and turn the shaft several times. Screw in the retainer while turning ST3 until a slight resistance is felt on ST2. This is the contact point of hypoid gear and drive pinion shaft. Repeat the above sequence several times to ensure the contact point.

ST1 399780104 WEIGHT
ST2 499787000 WRENCH ASSY
ST3 499927100 HANDLE




11) Remove the weight and screw in the retainer without O-ring on upper side and stop at the point where slight resistance is felt.

NOTE:

At this point, the backlash between hypoid gear and drive pinion shaft is zero.

ST 499787000 WRENCH ASSY



12) Fit the lock plate. Loosen the retainer on the lower side by 1-1/2 notches of lock plate and turn in the retainer on upper side by the same amount in order to obtain the backlash.

NOTE:

The notch on the lock plate moves by 1/2 notch if the plate is turned upside down.

13) Turn in the retainer on the upper side additionally by 1 notch in order to apply preload on taper roller bearing.

14) Tighten temporarily both the upper and lower lock plates and mark both holder and lock plate for later readjustment.

15) Turn the transmission main shaft several times while tapping around the retainer lightly with plastic hammer.

16) Inspect and adjust the backlash and tooth contact of hypoid gear. <Ref. to 5MT-105, INSPECTION, Front Differential Assembly.>


17) After checking the tooth contact of hypoid gears, remove the lock plate. Then loosen the retainer until the O-ring groove appears. Fit the O-ring into groove and tighten the retainer into the position where retainer has been tightened in. Tighten the lock plate.

NOTE:

Carry out this job on both upper and lower retainers.

Tightening torque:

T: 25 N·m (2.5 kgf-m, 18.1 ft-lb)



18) Selecting of main shaft rear plate. <Ref. to 5MT-80, ADJUSTMENT, Main Shaft Assembly for Single-Range.>

19) Install the clutch release lever and bearing. <Ref. to CL-26, INSTALLATION, Release Bearing and Lever.>

20) Install the transfer case with extension case assembly. <Ref. to 5MT-53, INSTALLATION, Transfer Case and Extension Case Assembly.>

21) Install the manual transmission assembly into the vehicle. <Ref. to 5MT-41, INSTALLATION, Manual Transmission Assembly.>

2. DUAL-RANGE

1) Wipe off grease, oil and dust on the mating surfaces of transmission cases with white gasoline.

2) Install the front differential assembly.

3) Install the main shaft assembly and input shaft assembly.

Connect the main shaft assembly and input the shaft assembly, and install needle bearing knock pin hole into transmission case knock pin.

4) Install the drive pinion shaft assembly.

Install the roller bearing knock pin hole into transmission case knock pin.

Transmission Case

MANUAL TRANSMISSION AND DIFFERENTIAL

5) Apply liquid gasket, and then put the case right side and left side together.

Liquid gasket:

THREE BOND 1215 or equivalent

6) Tighten the seventeen bolts with bracket, clip, etc. as shown in the figure.

NOTE:

- Insert the bolts from bottom and tighten the nuts at top.
- Put the cases together so that the drive pinion shim and input shaft holder shim are not caught up in between.
- Confirm that the speedometer gear is meshed.


Tightening torque:

8 mm bolt

25 N·m (2.5 kgf·m, 18.1 ft·lb)

★ 10 mm bolt


39 N·m (4.0 kgf·m, 28.9 ft·lb)



7) Tighten the ball bearing attachment bolts.

Tightening torque:


29 N·m (3.0 kgf·m, 21.7 ft·lb)



8) Tighten the input shaft holder attaching bolts.

Tightening torque:

20 N·m (2.0 kgf·m, 14.5 ft·lb)



(A) Input shaft holder


(B) Input shaft

9) Backlash adjustment of hypoid gear and preload adjustment of roller bearing

NOTE:

Support the drive pinion assembly with ST.

ST 498427100 STOPPER




10) Place the transmission with case left side facing downward and put ST1 on bearing cup.

11) Screw the retainer assembly into left case from the bottom using ST2. Fit the ST3 on transmission main shaft. Shift the gear into 4th or 5th and turn the shaft several times. Screw in the retainer while turning ST3 until a slight resistance is felt on ST2. This is the contact point of hypoid gear and drive pinion shaft. Repeat the above sequence several times to ensure the contact point.

Transmission Case

MANUAL TRANSMISSION AND DIFFERENTIAL

ST1	399780104	WEIGHT
ST2	499787000	WRENCH ASSY
ST3	499927100	HANDLE




12) Remove the weight and screw in the retainer without O-ring on upper side and stop at the point where slight resistance is felt.

NOTE:

At this point, the backlash between hypoid gear and drive pinion shaft is zero.

ST	499787000	WRENCH ASSY
----	-----------	-------------



13) Fit the lock plate. Loosen the retainer on the lower side by 1-1/2 notches of lock plate and turn in the retainer on upper side by the same amount in order to obtain the backlash.

NOTE:

The notch on the lock plate moves by 1/2 notch if the plate is turned upside down.

14) Turn in the retainer on the upper side additionally by 1 notch in order to apply preload on taper roller bearing.

15) Tighten temporarily both the upper and lower lock plates and mark both holder and lock plate for later readjustment.

16) Turn the transmission main shaft several times while tapping around the retainer lightly with plastic hammer.

17) Inspect and adjust the backlash and tooth contact of hypoid gear. <Ref. to 5MT-105, INSPECTION, Front Differential Assembly.>


18) After checking the tooth contact of hypoid gears, remove the lock plate. Then loosen the retainer until the O-ring groove appears. Fit the O-ring into groove and tighten the retainer into the position where retainer has been tightened in. Tighten the lock plate.

NOTE:

Carry out this job on both upper and lower retainers.

Tightening torque:

T: 25 N·m (2.5 kgf·m, 18.1 ft·lb)



19) Selection of main shaft rear plate <Ref. to 5MT-80, ADJUSTMENT, Main Shaft Assembly for Single-Range.>

20) Install the transfer case with extension case assembly. <Ref. to 5MT-53, INSTALLATION, Transfer Case and Extension Case Assembly.>

21) Install the clutch release lever and bearing. <Ref. to CL-26, INSTALLATION, Release Bearing and Lever.>

22) Install the manual transmission assembly into the vehicle. <Ref. to 5MT-41, INSTALLATION, Manual Transmission Assembly.>

C: INSPECTION

Check the transmission case for cracks, damage, and oil leaks.