


JVC

SERVICE MANUAL

POWER AMPLIFIER

KS-AX4500



Area Suffix	
E ---	Continental Europe
J -----	Northern America

Caution

If electricity is connected during disassembly, it must be a no load current. If it is load current, be sure to attach a heat sink to the power-amp IC. This will be damaged if the above precautions are not followed, as it does not have a sub heat sink attached to it.




Contents



Safety precaution	1-2
Location of main parts	1-3
Removal of main parts	1-5
Test method	1-7
Description of major ICs	1-8



CAUTION Burrs formed during molding may be left over on some parts of the chassis. Therefore, pay attention to such burrs in the case of performing repair of this system.

Location of main parts





Removal of main parts

CAUTION: If electricity is connected during disassembly, it must be a no load current. If it is load current, be sure to attach a heat sink to the power-amp IC. This will be damaged if the above precautions are not followed, as it does not have a sub heat sink attached to it.

■ Removing the bottom cover (see Fig. 1)

1. From the bottom side of the main unit, remove the 4 screws A retaining the bottom cover.
2. Then remove the 6 screws B retaining the bottom cover.
3. Remove the bottom cover.




Fig. 1

■ Removing the MAIN PCB (see Fig. 2 to 8)

1. Remove the bottom cover from the main unit.
2. Loosen and remove the 2 screws C retaining the top plate on the main unit. (Stoppers are attached to the backs of the C screws so that they cannot be removed easily.)




Fig. 2

3. Remove the 4 volume knobs on top of the control panel. If it cannot be pulled out easily, insert a rope or wire between the base of the volume knob and the control panel so that the volume knob is raised a little above the surface and then remove it.

(Be careful when inserting a lever etc. not to scratch the surface of the control panel).

4. Remove the 4 screws D retaining the control panel. Then detach the control panel and the switch knobs.




Fig. 3




Fig. 4

5. Remove the 13 screws E retaining the panels on both sides of the main unit.




Fig. 5




Fig. 6

6. Remove the 14 screws F attaching the MAIN PCB to the bottom of the main unit.





Fig. 7

7. Remove the MAIN PCB by lift up the arrow mark.




(Side view)

Fig. 8

Test method

1. Check the voltage and frequency of the secondary toroidal coil.

FREQUENCY: 22.87kHz ± 50Hz
 VOLTAGE VALUE: 60Vp-p ± 2.5V



2. Measure the secondary toroidal coil, if the standard frequency value of 22.87 kHz ± 50 Hz is not attained, measure the R60 terminal, then adjust the SV01 so that the R60 terminal becomes 22.87 kHz ± 50Hz.


Note: When measuring, adjust and apply power with no signal or load on each board.

DC/DC CONVERTER SECOND GENERATOR SWITCHING


TEST ITEM	SPECIFICATION	CONDITION	
VOLTAGE TEST	60Vp-p±2.5V	OSCILLOSCOPE VOLT/DIV: 10 TIME/DIV: 10msec	
FREQUENCY CHECK	22.87KHz±50Hz		

Description of major ICs

PIN CONNECTIONS



TL494



JVC

VICTOR COMPANY OF JAPAN, LIMITED

MOBILE ELECTRONICS DIVISION

PERSONAL & MOBILE NETWORK B.U. 10-1,1Chome,Ohwatari-machi,Maebashi-city,Japan