



FB3000 Series Instrument With Intalogix™ Technology

FB3000 Kernel Program





Amendment Record

FB3000 Series Instrument With Intalogix™ Technology

FB3000 KERNEL PROGRAM OPERATORS MANUAL

DOCUMENT 51147

Manufactured by Fairbanks Scales Inc.
821 Locust Street
Kansas City, Missouri 64106

Created	08/2007	
Revision 1	09/2007	Documentation Release
Revision 2	03/2009	Updates to software
Revision 3	04/2012	Corrected current specification

© Copyright 2007-2012

This document contains proprietary information protected by copyright. All rights are reserved; no part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without prior written permission of the manufacturer.

Trademarks

IBM, EGA, VGA, XT/AT, OS/2 and PS/2 are registered trademarks of International Business Machine Corporation.

Award is a trademark of Award Software International, Inc. RTL is a trademark of Realtek Semiconductor Co., Ltd.

VIA is a trademark of VIA Technologies, Inc.

Winbond is a trademark of Winbond Technology, Inc.

CF and CompactFlash are trademarks of ScanDisk Corporation.

Microsoft, Windows, Windows NT, Windows XP, and MS-DOS are either trademarks or registered trademarks of Microsoft Corporation.

All other product names mentioned herein are used for identification purpose only and may be trademarks and/or registered trademarks of their respective companies.

Disclaimer

Every effort has been made to provide complete and accurate information in this manual. However, although this manual may include a specifically identified warranty notice for the product, Fairbanks Scales makes no representations or warranties with respect to the contents of this manual, and reserves the right to make changes to this manual without notice when and as improvements are made.

It is the responsibility of the requesting party to develop, maintain, install, and connect networking devices and general network connectivity as it applies to the originating party's network. No warranty or guarantee, expressed or implied, concerning the network, its design, its installation, or operational characteristics has been offered by Fairbanks Scales. Fairbanks Scales shall not be liable for any loss, damage, cost of repairs, incidental or consequential damages of any kind, whether or not based on express or implied warranty, contract, negligence, or strict liability arising in connection with the design, development, installation, or use of an intended network.

Table of Contents

SECTION 1: GENERAL INFORMATION	6
1.1. Introduction.....	6
1.1.1. <i>The FB 3000</i>	6
1.1.2. <i>Kernel Description</i>	6
1.2. Technical Specifications.....	7
1.3. Features.....	9
SECTION 2: CUSTOMER RESPONSIBILITY.....	11
2.1. Users' Responsibilities	11
2.2. Equipment/ Component Care.....	12
SECTION 3: KEY FUNCTIONS AND MENUS	13
3.1. Key Functions.....	13
3.2. Backing Up Changes	16
3.3. Saving Changes to a Folder	16
SECTION 4: INPUT/ OUTPUT (I/O)	17
4.1. Introduction	17
4.2. Configure Output.....	17
4.2.1. <i>Introduction</i>	17
4.2.2. <i>Configuring an Output Data String</i>	17
4.2.3. <i>Two Methods of Formatting</i>	17
4.2.4. <i>Load Default Data Protocols</i>	18
4.2.5. <i>Load the Default COM Settings</i>	18
4.2.6. <i>Customizing the Output Data Strings</i>	20
4.2.7. <i>Steps in Customizing</i>	20
4.2.8. <i>ASCII and Text Data Character Types</i>	23
4.2.9. <i>Other Data String Customization</i>	24
4.3. 20 mA Serial Current Loop Programming.....	30
4.4. IP Network Output.....	32
4.4.1. <i>IP Setup Menu Overview</i>	32
4.4.2. <i>IP Network Output Setup Instructions</i>	34
4.4.3. <i>Testing the IP Network Output</i>	37
SECTION 5: OPERATION.....	38
5.1. System Boot-up Procedure	38
5.2. Viewing Options	39
5.3. Gross Weighing	39
5.3.1. <i>Using the Display Screen Function Buttons</i>	40
5.4. Application Shut-Down Procedure	41
5.5. System Shutdown Procedure	42



SECTION 6: SERVICE & MAINTENANCE 43

- 6.1. Troubleshooting 43
- 6.2. Remote Service and Diagnostics 44
 - 6.2.1. *Opening the VNC Connection* 44

APPENDIX I: GPIO PORT 45

- Programming the GPIO Port* 45
- Reading the GPIO Data* 45
- Writing the GPIO Data* 45

APPENDIX II: I/O ADDRESSES & CONTROL 46

- Interrupt Controller 46
- DMA Channel Assignment 46
- Memory Map 47
- Shared Memory (Kernel Mapped Output) 48
- I/O Map 51

APPENDIX III: DATA OUTPUT 52

- Remote Display Output 52
- Configure Output 52
 - Fairbanks Data Format* 52
 - Toledo Data Format* 54
 - Cardinal 738 Continuous Scoreboard Data Format* 56
 - Weightronix Data Format* 56
 - Condec Continuous Data Format* 57
 - COM Port Connections* 57

APPENDIX IV: IP COMMAND FUNCTIONS 58

APPENDIX V: PROGRAMMING THE WATCHDOG TIMER 59

APPENDIX VI: KERNEL 20MA CODES 60

APPENDIX VII: SOCKS INFORMATION 61

APPENDIX VIII: REMOTE FUNCTIONS 65

APPENDIX IX: ASCII CODES 66

Section 1: General Information

1.1. INTRODUCTION

The Fairbanks FB3000 Solutions Series instrument is a powerful, versatile, indicator which has flexibility, open architecture, and integrated capabilities of many computer functions. With these abilities, the FB3000 collects, processes, and transmits data through RS232, RS485, RS422 serial ports, USB, parallel port, and PCI 10/100 Mbs Ethernet interfaces.

1.1.1. The FB 3000

Current FB3000 Units include the following applications:

- **NewScale Program**
- **Kernel Weight Server Program**
- **In/Out Application**
- **LabelBank Application**
- **Highway System Application**
- **SoftBatch Application**
- **Interact Inside Program**

1.1.2. Kernel Description

The FB3000 Kernel is weight serving program for all FB3000 applications. It provides the core metrological functions for all the applications. It includes the following additional features:

- Multicasting capability to monitor and operate multiple scales across a network.
- Backup and Restore feature.
- Programmable Serial Communication Outputs



The FB3000 KERNEL is a Fairbanks-developed Weight Server Program



1.2. TECHNICAL SPECIFICATIONS

ENCLOSURE	<ul style="list-style-type: none">• Painted Steel (NEMA 12)<ul style="list-style-type: none">— Product 24737; 26154• Stainless Steel (NEMA 12)<ul style="list-style-type: none">— Product 24900; 26138; 26155• Stainless Steel and Aluminum (NEMA 12)<ul style="list-style-type: none">— Product 26867; 26868• Stainless Steel (NEMA 4X)<ul style="list-style-type: none">— Product 28000
PROCESSOR	400 MHz or 1 GHz processor
BIOS	256 KB Flash
RAM	144-pin SDIMM socket, 256 MB or 512 MB SDRAM
STORAGE	40 GB Hard Drive standard
OPERATING SYSTEM	Microsoft XP Pro™ Embedded with Service Pack 2
OUTPUTS	<p>Parallel Port - One (1) bi-directional parallel port with SPP/ECP/EPP support.</p> <p>Serial Ports - One (1) internal RS-232 interface, COM 1; One (1) RS-232/422/485 (scale interface), COM 2; Two (2) external RS232 ports, COM 3 and COM 4.</p> <p>USB Ports - Two (2) internal ports and Two (2) external ports.</p> <p>SVGA Port - One (1) SVGA display output.</p>
KEYBOARD AND MOUSE INTERFACE	Supports PS2 or USB keyboards Supports PS2 or USB mice
PC/104 CONNECTOR	One (1) internal PC/104 connector
DIGITAL I/O	Eight (8) internal digital inputs and outputs
ETHERNET INTERFACE	PCI 100/10 Mbps Ethernet interface with a female RJ45 connector. Complies with IEEE 802.3x Standards
DISPLAY	<ul style="list-style-type: none">• 10.4" Color SVGA Color LCD-TFT; Full graphic support; 600 x 800 resolution• 10.4" Color SVGA Color DVI; 600 x 800 resolution (FB3000T models)
BATTERY	Lithium, data retention up to 10 years



1.2. TECHNICAL SPECIFICATIONS, CONTINUED

SCALE INTERFACE OPTIONS	<ul style="list-style-type: none">• Intalogix Technology<ul style="list-style-type: none">— QMB Interface (26148)<ul style="list-style-type: none">▪ <i>Maximum of two (2) QMB Interfaces per instrument</i>— External Intalogix Communication Board (28330)<ul style="list-style-type: none">▪ <i>Maximum of twenty (20) 1000 Ω or twelve (12) 350 Ω cells</i>— Dual External Intalogix Communication Board (28333)<ul style="list-style-type: none">▪ <i>Up to forty (40) 1000 Ω or twenty-four (24) 350 Ω cells</i>• Analog Technology<ul style="list-style-type: none">— Analog Load Cell Interface (25543)<ul style="list-style-type: none">▪ <i>Up to sixteen (16) 1000 Ω or ten (10) 350 Ω cells</i>▪ <i>Maximum of two (2) per FB3000.</i>— PC104 Weight Controller (27104)<ul style="list-style-type: none">▪ <i>High Speed A/D</i>▪ <i>Maximum of ten (10) 1000 ohm load cells per scale input</i>▪ <i>Controls up to two (2) scales</i>▪ <i>Provides passive 20mA serial output</i>▪ <i>Provides passive 4-20mA analog output</i>▪ <i>Maximum of two (2) per FB3000.</i>
ACCESSORIES	<ul style="list-style-type: none">• Mini keyboard (25498)<ul style="list-style-type: none">— 87 key— PS2• NEMA 4 Rubberized keyboard (27077)<ul style="list-style-type: none">— USB• Mouse (26387)<ul style="list-style-type: none">— Two (2) button with scroll wheel— USB• Wall Bracket – Painted Steel (26223)• Wall Bracket – Stainless Steel (26224)• Compact Flash Card 32MB (25853)• SVP/ Uninterruptible Power Supply (UPS) (15892)<ul style="list-style-type: none">— 500 VA Rating



1.2. TECHNICAL SPECIFICATIONS, CONTINUED

ACCESSORIES CONTINUED	<ul style="list-style-type: none"> • External Serial Port Relay Kit (26727) <ul style="list-style-type: none"> — Basic traffic light control (Interact) • 4-20mA analog and 20mA serial output (25284) <ul style="list-style-type: none"> — PC140 Weight Controller
POWER REQUIREMENTS	100 - 130 VAC @ 1A @ 60 Hz +/- 2 Hz <ul style="list-style-type: none"> — Separate and dedicated circuit. — Neutral to Ground voltage should be ≤ 0.2 vAC
ETL LISTED	<ul style="list-style-type: none"> • Conforms to UL STD 60950-1. • CAN/CSA C 22.2 NO.60950-1-03.
APPROVALS	<ul style="list-style-type: none"> • CC# 04-013; FB 3000T = CC#04-013A5; NEMA 4 = CC#04-013A6 • MC# AM-5552C

1.3. FEATURES

DIAGNOSTICS	Built-in self diagnostics reports on: <ul style="list-style-type: none"> • Calibration change • Time and date change • Remote access enabled • Routine maintenance required' • Flash memory error • Load cell ghosted • Load cell failure
LOAD CELL FLAG	Visual "flags" identify problem load cell(s) on diagnostic screen until flag is manually cleared to identify intermittent problems
LOAD CELL GHOSTING	Ability to electronically "mimic" or duplicate a failed load cell if equipped with Intalogix™ Interface for load cell communications (preventing system failure and/or shutdown)
REMOTE DIAGNOSTICS	Programmable Remote Diagnostic Utility provides remote diagnostics and configuration from any PC with proper authorization and access



1.3. FEATURES, CONTINUED

EMAIL ERROR REPORTING	Built-in email client for reporting error conditions such as the following: <ul style="list-style-type: none">• Calibration change• Time and date change• Flash memory error• Remote access enabled• Routine maintenance required• Load cell ghosted• Load cell failure
ERROR DISPLAYING	Programming-selected display of error messages
BACKUP	Features the ability to backup information to optional Flash Memory card, network or USB pen drive
WEB BROWSER	Built-in browser allowing web access for software updates and web site viewing if desired

Section 2: Customer Responsibility

2.1. USERS' RESPONSIBILITIES

It is **the customer/operator's responsibility** to ensure the equipment provided by Fairbanks is operated within the parameters of the equipment's specifications and protected from accidental or malicious damage.



WARNING!

Absolutely no physical, electrical or program modifications other than selection of standard options and accessories can be made by customers to this equipment

Repairs are performed by Fairbanks Scales Service Technicians and Authorized Distributor Personnel ONLY!

Failure to comply with this policy voids all implied and/or written warranties

2.2. EQUIPMENT/ COMPONENT CARE

- ✓ **Do not remove power** from this unit unless it is performed by the proper shut down method. Failure to comply with the proper shut down procedures can result in damage to the hard disk drive or data.
- ✓ The AC receptacle/outlet shall be located near the instrument and easily accessible.
- ✓ Electrical connections other than those specified may not be performed.
- ✓ Absolutely **no physical, electrical or program modifications** other than selection of standard options and accessories are to be made to this equipment.
 - Electrical connections other than those specified may not be performed, and physical alterations (holes, etc.) are not allowed.
- ✓ The equipment consists of printed circuit assemblies which must be handled using proper ESD handling procedures.
 - Replacement of individual components is not allowed.
 - Any assemblies which are replaced must be properly packaged in ESD protective material if they are returned for replacement credit under a warranty condition.



Section 3: Key Functions and Menus

3.1. KEY FUNCTIONS



On-Screen Keyboard	External Keyboard	Description
Arrows	Arrows	<ul style="list-style-type: none"> • Navigates through the display. • Used also for scrolling.
Menu Button	Esc	<ul style="list-style-type: none"> • Changes the display to the Operation Menu. • Returns user to the previous menu.
Zero	Pause Break	Key(s) will Zero the Scale .
Print	Prt Sc	Prints a ticket. <ul style="list-style-type: none"> • In the In/Out Device, an Inbound or Outbound Gross ticket. • A Gross, Tare, Net ticket may also be printed. • In the Weigh Only mode, a Gross Weight ticket may be printed with a manually entered Tare and the Net will be calculated.



3.1. KEY FUNCTIONS, CONTINUED

On-Screen Keyboard	External Keyboard	Description
Units	Scroll Lock	Changes the units of weight displayed, depending on the selection made in the Calibration Menu .
0 to 9	0 to 9	Used to enter numeric data, such as tares and IDs.
Enter	Enter	Stores selections into memory during data entry or programming.
F1	F1	Toggles between the scales that are viewed and operated.
F2	F2	Unassigned
F3	F3	Unassigned
F4	F4	Unassigned
F5	F5	Toggles between the scale groups when more than four (4) scales are used.
F6	F6	Toggles between the Operational Screen and the Multi-Scale Screen , if more than one scale is being controlled.
	F7	Unassigned
	F8	Unassigned
	F9	Unassigned
	F10	<ul style="list-style-type: none">• Service Usage only. !!Warning!! changing this items in this area can effect the proper operation of the scale.
	F11	Unassigned
	F12	Unassigned

The Kernel can be set up to operate in one of two **Modes of Operation**, depending upon the service programming:

- **Gross Weighing**
- **GTN (Gross / Tare / Net)**

Additional Windows Tips

- **ALT + F4 key** Shuts down the active program *immediately*
- **Windows Key + D** Moves to the **Desktop**
- **Windows Key + E** Opens **MS Windows Explorer™**




3.2. GENERAL PROGRAMMING MENUS

The programming menus which contain all of the parameters for the system are listed below.

Options Menu

This is the main menu, used to **gain access to other system menus for configuration and calibration.**


- It is accessible without a password by pressing the **MENU** key.
- Access provided for **Weights and Measures Official** to view the **Audit Trail** for calibration and configuration changes.
- Quick access to electronic **Operators' Manual**.



Configuration Menu

This menu is used to access **diagnostics utilities** and **communications programming.**

- *Optional programmable* password protection.




Service Menu

This menu is used to program the **metrological parameters of the system**, such as **scale capacity, calibration**, and **graduation size.**


- **Must be** password protected for all **Legal For Trade** applications.

The Service Menu functions are used by Fairbanks Authorized Service Personnel ONLY.



3.2. BACKING UP CHANGES

Each time a programming change is made to the Kernel Program, a **Backup Changes** popup window appears.




- The normal answer is **NO**.

- Either double-click the  or click the .

NOTE: Save changes **ONLY WHEN** the programming change(s) are correct, and the system is proven to operate properly for all conditions.


3.3. SAVING CHANGES TO A FOLDER

- For backing up the changes to a folder, click either the 

- or on the **Weight Screen's keypad**, click the .

- Each file is saved by the date.
- (**yyyymmdd.BAK**).

IMPORTANT NOTE: Backup **EVERY** Configuration change... **EVERY TIME!**



Section 4: Input/ Output (I/O)

4.1. INTRODUCTION

Connectivity is one of the primary features of the FB3000 and Kernel Weight Server program. The FB3000 has multiple RS232 ports, USB ports, Ethernet port, and a Parallel port to name a few. This section will provide steps in order to connect the FB 3000 in a variety of manners to a variety of devices.

4.2. CONFIGURE OUTPUT

4.2.1. Introduction

This menu selection provides a means to configure data strings protocols, configuration parameters, and output modes such as Continuous, Demand, Auto, To File, and Network.

4.2.2. Configuring an Output Data String

In order to interface an FB3000 Instrument to software or a pre-existing peripheral device, such as a remote display, knowing their specific Output Data String is **mandatory**.

- This allows the software or peripheral device to communicate with the FB3000.
- When adding to other manufacturer's devices, refer to their Service Manuals for Output Data String information.
- Interfacing with other manufacturer's software, refer to either a web site, Service Manual, or contact the manufacturer directly for the Output Data String information.

Fairbanks' current programming for setting up an **Output Data String** provides quick and easy flexibility for customizing the FB3000 Serial Outputs.

4.2.3. Two Methods of Formatting

There are two methods to format an **Output Data String**.

1. Use one of the five (5) preconfigured **Load Defaults** under the **Load tab**.
2. Use the most similar **Load Default** as a basis for customizing an **Output Data String** which matches the manufacturer's company-specific configuration. This method is done in the **Build tab**.

4.2.4. Load Default Data Protocols

When programming a **Output Data String**, the Fairbanks' FB3000 has five of the most commonly used pre-configurations, known as **Load Defaults**. These data strings are listed below:

Fairbanks	<STX><A><C><GGGGGG><TTTTTT><CR>
Toledo	<STX><A><C><GGGGGG><TTTTTT><CR>
Cardinal	<CR><P><WWWWW><m><SP><U><SP><g><SP><SP><ETX>
Weightronix	< ><M><WWWWW>< ><U><CR><LF>
Condec	<STX><P><WWWWW><U><G><M><CR>


4.2.5. Load the Default COM Settings

Follow these steps to configure the **Load Default** into the **Output Data String**.


1. From the **Weighing Application Window**, press the **MENU** button, from the Kernel Options Menu, select **Configuration Menu**.




2. Select **Configure Output..**




4.2.5. Load the Default COM Settings

3. Open the **Load** tab.
4. Select the **COM Port** to be configured.
5. Select the appropriate **Load Default**.
6. Press the  button.



7. Open the **Port Settings** tab.
8. Program the **Baud Rate**, **Stop Bits**, and the **Parity** to the appropriate settings.





4.2.6. Customizing the Output Data Strings

The FB3000 Kernel Weight Server program can also be customized to support numerous manufacturers software interfaces and peripheral devices. When programming a Data String Protocol not formatted as one of the **Load Defaults**, the Output Data String must be **programmed manually** using the **Build, Tokens, and Weights Tabs**.

4.2.7. Steps in Customizing


Follow these steps to customize the **Output Data String**.

1. Locate the required **Output Data String** by viewing history from previous work completed with the customer, or by emailing and/or calling the company directly and asking their **IT Department** for this information.
2. Compare the required **Output Data String** with the five **Load Default** configurations.
3. Open the **Load** tab.
4. Select the **COM Port** to be configured.
5. Select the **Load Default** that most resembles the required Output Data String format.
6. Press the  button.




4.2.7. Steps in Customizing, Continued

7. Open the **Build** tab.



8. **Left-click** on the appropriate field to be generated within the specific data string, then select **Text**.

- This adds a new **Text** box to the **Output Data String**.




9. Program a command within the **Data String**, either enter an **ASCII Character**, or **input text**.

- When inputting ASCII Characters, **always** precede the message with **"0x..."** and the equivalent ASCII code up to 3 digits (*i.e.* **0x099**).

10. Open the **Port Settings** tab.

11. Program the **Baud Rate**, **Stop Bits**, and the **Parity** to the appropriate settings.



4.2.7. Steps in Customizing, Continued

The screenshot shows the 'KERNEL CONFIGURE... OUTPUTS' window. At the top, there are dropdowns for 'COM1' and 'OFF'. Below are tabs for 'Settings', 'Load', 'Build', 'Tokens', 'StatusCodes', 'Weights', and 'IP Setup'. A table lists items with columns for 'Item', 'Data Type', and 'Value'. Item 2 is 'Scale4 Gross Weight' with value '<4G>'. Item 6 is 'Scale1 Gross Weight' with value '<1G>'. A dropdown menu is open for item 6, showing a list of options including 'Scale2 Load Cell Status'. A callout box points to the 'Data Type' column with the text: 'A drop-down Menu Window opens when any Data Type choice is selected by left-clicking in the field'.

Item	Data Type	Value
1	Text	[40]
2	Scale4 Gross Weight	<4G>
3	Text	[0x03]
4	Text	[0x02]
5	Text	[41]
6	Scale1 Gross Weight	<1G>
7	Text	[0x03]
8	Text	[0x02]

[40], <4G>, [0x03], [0x02], [41], <1G>, [0x03], [0x02], [43], <3G>

Drop-down menu options:

- Text
- Units Token
- Mode Token (G,T,N)
- Scale Status
- Load Cell Status
- Status Byte A
- Status Byte B
- Status Byte C
- Gross Weight
- Tare Weight
- Net Weight
- Displayed Weight
- Scale1
- Scale2**
 - Scale2 Gross Weight
 - Scale2 Scale Status
 - Scale2 Load Cell Status**
 - Scale2 Status Byte A
 - Scale2 Status Byte B
 - Scale2 Status Byte C
 - Scale2 Units
- Scale3
- Scale4
- Scale5
- Scale6
- Scale7
- Scale8
- << Remove >>

Window Name	Description
CONFIGURE OUTPUT, — Build Tab	Configures the data string protocol order , written in ASCII text . By left-clicking in any item, a drop-down menu offers different parameters, or removes them. Text may be added to the data string by clicking in the Value field, then entering it. — Also by clicking into the Data Type box and choosing text from the drop down box.

4.2.8. *ASCII and Text Data Character Types*

There are two types of data configuration characters. Both have an important and have a specific function; both are used within the same data string. Both types are defined below.


ASCII (American Standard Code for Internet Interchange) **Characters**

- **Text Formatted Characters** are always written with a “**0x_ _ _**” prefix, which tells the **Kernel Program Read-me Trigger** to post it as text character (*i.e.* **0x120**).
- A code for information exchange between computers using a string of seven (7) binary digits represents each character.
- Each character identifies either a alphanumeric symbol (*i.e.* **065 = A**, **066 = B**, *etc.*) or invokes an on-screen action (*i.e.* **013 = CR = Carriage Return**).
- One **Text Block** must be added to the Data String for each character before formatting it.
- The data entries use *decimal-based ASCII character codes*.
- Complete ASCII Chart found in **Appendix IV**.

Text Formatted Characters


- A **Text** block must be added to the **Data String** before formatting the next character.
- These **Text Formatted Characters** are used to add a specific message to the Service Technician, and it is done in combination with the text and with other ASCII Text Characters.

4.2.9. Other Data String Customization





Window Name	Description
CONFIGURE OUTPUT — Settings Tab	<p>RS232 COM Port Drop-down – Selects COM Port with its settings.</p> <p>Data Transmission Options*</p> <ul style="list-style-type: none"> – Continuous [transmission] – Demand – Upon demand as a poll character is received – Auto – A transmission is sent when requested or when the transaction is completed. – To File – The message is not transmitted, but written to a file instead. – Network – Transmission via IP over a network. <p>Port Settings*</p> <ul style="list-style-type: none"> – Baud Rate, Parity, Data Bits and Stop Bits. – Checksum – Returns a confirmation of transmission message between computers. – Delimited – Transmits data in Comma Delimited Format. – Multicast – Method of networking scale weight information to other FB3000 instruments across a Network. – Map View – Displays data in a memory mapped location. <ul style="list-style-type: none"> ▪ <i>The Testapp.exe, located in the Kernel folder, is used to verify memory mapped data,</i> – Output to PC104 – Sends data to optional PC 104 Weight Controller Card using the 20mA or 4-20mA outputs. <p>Software Hand Shaking – A means to control data flow using software functions for communication between two or more devices.</p> <ul style="list-style-type: none"> – None – Bits are sent to source computer constantly without waiting for available receiving modem. – Both, Receive or Transmit – Determines which computer(s) wait to accept the message packets.

4.2.9. Other Data String Customization, Continued




Window Name	Description
CONFIGURE OUTPUT, CONTINUED — Settings Tab, Continued	<p>Hardware Hand Shake – A means to control data flow using hardware functions for communication between two or more devices.</p> <p>Network Controls</p> <ul style="list-style-type: none"> – DTR (Data Terminal Ready) – A control signal that indicates that the Data Terminal Equipment (DTE) is ready for data transmission. – RTS (Request To Send) – A control line which receives a verification signal from the CTS Control Line when it is ready to send data.

4.2.9. Other Data String Customization, Continued




Window Name	Description
CONFIGURE OUTPUT, CONTINUED — [Port] Settings Tab 1	Control Signals — DSR (Data Set Ready) – A control signal that indicates the device is ready to transmit data. — CTS (Clear To Send) – A control signal used to notify the device that it has line control.
— Load Tab 2	Selects a preconfigured data protocol based on the scale manufacturer selected. — Select this item first when configuring an output. — Press the OK button to load the data protocol selected.
DEFAULT DATA PROTOCOLS Fairbanks <STX><A><C><GGGGGG><TTTTTT><CR> Toledo <STX><A><C><GGGGGG><TTTTTT><CR> Cardinal <CR><P><WWWWWW><m><SP><U><SP><g><SP><SP><ETX> Weightronix < ><M><WWWWWW>< ><U><CR><LF> Condec <STX><P><WWWWWWW><U><G><M><CR>	
** See Appendix III for more formatting information.	

4.2.9. Other Data String Customization, Continued





Window Name	Description
CONFIGURE OUTPUT, CONTINUED — Tokens Tab	<p>Programs the various data string tokens, such as the Motion flag. Tokens are setup for the data protocol requirements.</p> <p>Wrappers</p> <ul style="list-style-type: none"> — Poll – Polling character for a demand output. <ul style="list-style-type: none"> ▪ <i>Applicable only to the Demand Mode.</i> — Start – The first character of a data string. — Stop – The last character of a data string. — Block – The character that separates the data fields.
	<p>Units – The character(s) used to define the unit of measure in the data string</p> <ul style="list-style-type: none"> — Primary – The main indicator unit of measure. — Secondary – The alternate indicator unit of measure.
	<p>Mode – The character(s) used to define the Weighing Mode in the data string.</p> <ul style="list-style-type: none"> — Gross – Character(s) used to designate the gross weight. — Tare – Character(s) used to designate the tare weight. — Net – Character(s) used to designate the net weight.

4.2.9. Other Data String Customization, Continued



Window Name	Description
CONFIGURE OUTPUT, CONTINUED – Tokens Tab	Status – Identifies invalid weight conditions. <ul style="list-style-type: none"> – Motion – Character(s) used to identify the scale weight is in motion. – Capacity – Character(s) used to identify the scale weight is over capacity – OK – Character(s) used to identify the scale weight is valid. – Invalid – Character(s) used to identify the scale weight is invalid.

4.2.9. Other Data String Customization, Continued



Window Name	Description
CONFIGURE OUTPUT, CONTINUED — Status Codes Tab ①	Programs data bits for Status Words A, B and C within the Fairbanks and Toledo data streams. — Status Word is eight (8) bits long. 12. Put the Status Words in the blank Data Entry Position . 13. Press the Loaded it button.
— Weights Tab ②	Programs specific values for the Weight Tokens. — Weighing Digits – Programs the length of the weight data. ▪ Typically six or seven digits in length. — Leading Zeros – When checked, adds leading zeros to the weight data. — Justification – Right or left. — Decimal Point – None, Floating, Fixed, Trailing. — Fixed Decimal Places – Sets number of decimal places in weight data string. — Test Weight – A manual weight entry to test data output. Polarity – When checked, it places a polarity token in front of the weight data item. — Positive Token – (+), None or Space — Negative Token – (–), None or Space


4.3. 20 MA SERIAL CURRENT LOOP PROGRAMMING

Procedure steps skipped or omitted during this process may cause certain features to not operate or function as expected. The 20 mA output is passive.


Note: The PC104 Weight Controller Kit (27104) must be installed for this output to be available.

Procedure:

1. In the **Kernel Weighing Program**, click the **MENU** button to open the Configuration Menu.





2. Open the **Remote Display**.




4.3. 20mA Serial Current Loop Programming, Continued


3. Set the **Remote Display** to **COM 1**.
4. Configure the **Baud, Parity, Data Bits**, and **Stop Bits** required.
5. Reset the **Remote Display** back to **OFF**.
6. Select the **Enable 20ma Output** check option.
7. Select **ACTIVE** in the **Scale** dropdown window.
8. Select **Continuous** in the correct drop-down window.



4.4. IP NETWORK OUTPUT


4.4.1. IP Setup Menu Overview.



Window Name	Description
CONFIGURE OUTPUT — IP Setup Tab	IP Port Settings <ul style="list-style-type: none"> • Local Port – The socket number on the local FB3000 used to transmit and receive data. • Remote Port – Set to the same socket number as the Local Port in which the remote transmits and receives data. • Remote Host – The IP Address of the Remote Host • TimeOut – The amount of time lapses before it is disconnected. • Keep Alive – Keeps the connection active. ✓ Default Setting = False. • Linger – When set to True, connections are terminated gracefully. ✓ Default Setting = False. <p>Verifies connectivity or connection.</p> 

NOTE: See Appendix IV for complete information regarding **SOCKS Protocol**.

4.4.1. IP Setup Menu Overview, Continued



Window Name	Description
CONFIGURE OUTPUT, CONTINUED — IP Setup Tab	Firewall Settings <ul style="list-style-type: none"> • Host – The Host IP Address. • Port – The Port Socket number used. • Type <ul style="list-style-type: none"> ✓ Default = No Firewall. – Tunnel – Set to 80. – SOCKS4* – Set to 1080. – SOCKS5* – Set to 1080. • User – User Login name • Password – User Password to login to the Host. • Connect – Establishes a connection. <p> Terminates all active connections.</p> <p> Show a log of all IP events.</p> <p> Stop Listening Stops the monitoring signal with the scale.</p>

* See **Appendix IV** for complete information regarding **SOCKS Protocol**.

4.4.2. IP Network Output Setup Instructions


The following procedure outlines the setup instructions required to activate the **IP NETWORK** output function. Procedure steps skipped or omitted during this process may cause certain features to not operate or function as expected.

Follow these steps to configure the **IP Network Output**.


9. From the **Weighing Application Window**, press the **MENU** button, from the Kernel Options Menu, select **Configuration Menu**.




10. Select **Configure Output**.




4.4.2. IP Network Output Setup Instructions, Continued

11. Select an unused **COM Port** to be configured. Example: COM 5.
12. Access the **Load** tab and select a default format similar to what is required.
13. Press the  button.



14. Select the **Build** tab and configure the data output format as desired.



4.4.2. IP Network Output Setup Instructions, Continued

15. Use the **Mode** drop down list to select the **Network** mode.
16. Select the **IP Setup** tab to configure the network parameters. Pointing to each edit box will display a brief help message, to assist in the setup
17. Program the **IP Port Settings**, by setting the **Local Port** and the **Remote Port** to the same number as appropriate for the users network.

Example: port = 2000.



- Set the **Remote Host** to one of the following
 - The IP address of the remote computer which will receive the weight data,
 - The network computer name of the remote computer which will receive the weight data as in the example shown above.

18. **Firewall Settings** – Leave the defaults as shown

19. The customer will need to provide a receiving application on a network computer which will open a connection through a TCP/IP socket with

- The IP address must be set to the address of the FB3000 and the Port set to the FB3000 **Local Port** setting. Example: 2000.
- When the IP is configured correctly, it will display **Listening**.

20. The data stream will be a continuous stream in the format set in step 6 above.





4.4.3. Testing the IP Network Output

Test Instructions to activate the **IP Network Output** function from the FB3000 Kernel Weight Server program.

1. Setup the **IP Network Output** as described in Section 7.6.2. of this manual.
2. Return the Kernel back to the **Weight Processing Screen**.
3. At a different computer on the same network, use Hyper-Terminal to receive the data.
4. Start Hyper-Terminal, enter a **New Connection** name. Example: Test. Click OK.
5. Set the **Connect Using** drop down box to **TCP/IP (Winsock)**.
7. Set the **Host Address** to the **IP address** of the computer or FB3000 that the Kernel.exe is running on.
7. Set the **Port Number** to the same value as the **Local port** is set.
8. Click OK. If a connect attempt is made, it will fail at this point, ignore and clear the error message.
9. Select the **Call** menu item and select **Wait for Call** from the drop down menu.
10. If all is working, the instrument should make connection and weight data should be displayed in the Hyper-Terminal window in the format set previously in the setup instructions

Section 5: Operation

5.1. SYSTEM BOOT-UP PROCEDURE

Initiate the power up sequence using the power **ON/OFF** rocker switch located on the **bottom-left side** of the instrument.


Normal indications include the following:

- Lights on the keyboard should blink.
- After approximately **one minute**, the **Fairbanks Logo** appears along with a mouse pointer, located approximately in the center of the screen.




- The **Fairbanks Logo** disappears.
- A Windows welcome screen appears.
- Lastly, a weighing application window appears.

5.2. VIEWING OPTIONS



The **GTN Screen** application



The **Multi-Scale Screen** application

When using the **Kernel Program**, there are **two viewing options** for weighing.

The **GTN Screen**

The **GTN Screen** displays the weighments for only .one scale at a time.

Multi-scale Screen

The **Multi-scale Screen** displays all configured scales on the screen at one time.


- The Golden Diamond show which weighment is being used
- The scale being used is identified in the lower-left corner of the screen.

5.3. GROSS WEIGHING

21. Press the **ZERO** key to zero the scale.
22. Place the object to be weighed on the platform.
23. View the weight from the screen.

NOTE: The Operating Mode is **Service-Programmable only**.

5.3.1. Using the Display Screen Function Buttons




- When in the **Multi-scale Screen**, press the **F1 button** to toggle thru the available scales.
- Press the *display screen's* **F6 button** to toggle back-and-forth from the GTN Screen to the Multi-scale Screen.

5.4. APPLICATION SHUT-DOWN PROCEDURE

1. To close the **Kernel Program**, press the **Exit** button on the open weighing application screen.



2. Double-click on the **Exit Application** button.




5.5. SYSTEM SHUTDOWN PROCEDURE



1. Using the external keyboard, press and hold the **ALT + F4** keys simultaneously to exit the program.

The FB3000 will close down properly.

2. Click the **Turn Off** button.
 - The instrument turns off.
 - Upon shut down, the display turns dark.
3. Turn off the power using the **ON/OFF** rocker switch.



Section 6: Service & Maintenance

IMPORTANT PRECAUTIONS

Electrostatic Discharge (ESD) can easily damage the FB3000 board assemblies.

6.1. TROUBLESHOOTING

Error Condition(s)	Solution(s)
<ul style="list-style-type: none"> • Check that scale is empty. • If Scale is empty, Call for Service. • Load Cell(s) bad. 	<ul style="list-style-type: none"> • A large amount of weight is zeroed. • This is normal. • Press OK and continue weighing. • Possible load cell damage. • Call for Service.
<ul style="list-style-type: none"> • Load Cell Failure(s) • Flashing and displays “- - - -” 	<ul style="list-style-type: none"> • Possible load cell damage. • Call for Service. • Access the Load Cell Diagnostics Menu to verify the load cell status. • Count stability or change of counts. • Contact the local service for further trouble-shooting.
<p>SC Cells Found None</p>	<ul style="list-style-type: none"> • Possible damaged load cell cable. • Load cell shortened. • Defective Pit Power Supply. • Defective Smart Sectional Controller(s). • Defective Analog Assembly. • Call for Service.
<p>Displays “ - - - - ” ~ lb GROSS</p>	<ul style="list-style-type: none"> • Communication error to load Cells. • Call for Service.

6.2. REMOTE SERVICE AND DIAGNOSTICS


The FB3000 can be serviced and have diagnostics performed from a remote location, such as the nearest **authorized Fairbanks Service Center**.

- The instrument must be connected to a network with internet access.
- The **Remote VNC Connection** can be programmed to display in the **Weight Window** or in the **minimized tray**.

6.2.1. Opening the VNC Connection

1. To open the remote connection, left-click on the **Fairbanks Globe**.
2. Click the **Menu** key.
3. Give the Remote Fairbanks Technician the **IP address** listed within the **Remote Diagnostic Mode Window**.
4. Upon completion of diagnostics, the Remote Fairbanks Technician will disconnect at his or her end.



5. Disconnect the **Remote VNC Connection** by clicking the  box.
 - This returns the Kernel Program back to normal operations.

Appendix I: GPIO Port

Programming the GPIO Port

The FB3000 embedded PCB provides an 8-bit GPI port and an 8-bit GPO port through which to read and write data. The GPIO port base address is 440 (hex).

Reading the GPIO Data

MOV DX, 440: **GPIO Address**

IN AL, DX: **Read the data into AL register**

Writing the GPIO Data

MOV DX, 440: **GPIO Address**

MOV AL, XXH: **Output data value "XX" OUT DX, AL**

bit0 = **GPI(O)0**

bit1 = **GPI(O)1**

bit2 = **GPI(O)2**

bit3 = **GPI(O)3**

bit4 = **GPI(O)4**

bit5 = **GPI(O)5**

bit6 = **GPI(O)6**

bit7 = **GPI(O)7**

Appendix II: I/O Addresses & Control

INTERRUPT CONTROLLER

The FB3000 embedded PCB is a fully PC compatible control board. It consists of 16 ISA interrupt request lines. Most of them are already in use by other parts of the board. Both ISA and PCI expansion cards may need to use IRQs, so make sure the IRQs do not conflict when using add-on cards.

System IRQs are available to cards installed in the ISA expansion bus first. Any remaining IRQs then may be assigned to the PCI bus. **Check out an AMI diagnostic utility to see the map.**

IRQ	Assignment
IRQ0	System Timer Output
IRQ1	Keyboard
IRQ2	Interrupt rerouting from IRQ8 through IRQ15
IRQ3	Serial Port 2
IRQ4	Serial Port 1
IRQ5	Reserved
IRQ6	Floppy Disk Controller
IRQ7	Parallel Port
IRQ8	Real Time Clock
IRQ9	Reserved
IRQ10	Reserved
IRQ11	Reserved
IRQ12	PS/2 Mouse
IRQ13	Math Coprocessor
IRQ14	Primary IDE Controller
IRQ15	Secondary IDE Controller

DMA CHANNEL ASSIGNMENT

By default, **Channel four (4)** is used to **cascade the two controllers.**

Channel	Assignment
DMA0	Available for PCI and ISA Slot
DMA1	Sound Card
DMA2	Floppy Disk Controller
DMA3	ECP Printer Port
DMA4	Cascade
DMA5	Sound Card
DMA6	Available for PCI and ISA Slot
DMA7	Available for PCI and ISA Slot



MEMORY MAP

The following tables indicate memory of the FB3000. The address ranges specify the runtime code length.

Memory *below* 1MB (1MB ~ 640KB)

Address Range	Type	Owner
A0000~AFFFF	ISA	VGA Adapter
B0000~BFFFF	ISA	VGA Adapter
C0000~C7FFF	ISA	Adapter ROM
C8000~CBFFF	ISA	Adapter ROM
F0000~FFFFF	ISA	System BIOS

Memory *above* 1MB (1MB ~ 142336KB)

Address Range	Type	Owner
40011000~40011D7F	PCI	Multimedia Audio
40012000~400120FF	PCI	Bridge Device
40800000~40FFFFFFF	PCI	VGA Adapter
D0000000~D00000FF	PCI	Ethernet Controller
D0004000~D0004FFF	PCI	USB Controller

System Memory Map

Start High	Start Low	Size High	Size Low	Type
00000000	00000000	00000000	0009FC00	Available
00000000	0009FC00	00000000	00000400	Available
00000000	000F0000	00000000	00010000	Reserved
00000000	FFFF0000	00000000	00010000	Reserved
00000000	00100000	00000000	08B00000	Available



SHARED MEMORY (KERNEL MAPPED OUTPUT)

```
//*****  
// Sample code to read Kernel Mapped Output (Shared Memory)  
//*****  
// FileMap Memory Structure  
struct FileMapStruct  
{  
    unsigned char    data[256];    // configured output string from kernel  
    unsigned char    command[2];  // command to return to kernel i.e. "z" = zero all scales, "Z1" =  
    zero scale 1  
    int    length;                // length of string in data  
    int    counter;              // sequential number  
    char    status[128];         // kernel status  
};  
  
bool TScaleForm::ReadMappedOutput(char *input)  
{  
    bool    result = false;  
    bool    CommandSent = false;  
  
    if( MappedOutputHandle == NULL )  
    {  
        wSemaphore = CreateSemaphore(NULL, 1, 1, "Output1 Write");  
        if( wSemaphore == NULL )  
            return 0;  
        rSemaphore = CreateSemaphore(NULL, 0, 1, "Output1 Read");  
        if( rSemaphore == NULL ) {  
            CloseHandle(wSemaphore);  
            wSemaphore = NULL;  
            return 0;  
        }  
    }  
}
```




SHARED MEMORY (KERNEL MAPPED OUTPUT), CONTINUED

```
MappedOutputHandle = CreateFileMapping((HANDLE)0xFFFFFFFF, NULL,
    PAGE_READWRITE,
    0,
    sizeof(struct FileMapStruct),
    "Output1");

    if( MappedOutputHandle == NULL )
    {
        CloseHandle(rSemaphore);
        rSemaphore = NULL;
        CloseHandle(wSemaphore);
        wSemaphore = NULL;
        return 0;
    }
}

if( MapOutputData == NULL ) {
    MapOutputData = (struct FileMapStruct*)MapViewOfFile(MappedOutputHandle,
    FILE_MAP_WRITE,
    0, 0,
    sizeof(struct FileMapStruct));
}

if( MapOutputData != NULL )
{
    // wait for kernel to release
    if( WaitForSingleObject(rSemaphore, 5) == WAIT_FAILED )
        return false;

    // Check Counter to see if Kernel has sent a new string
    if( MapOutputData->counter != LastCounter )
```



SHARED MEMORY (KERNEL MAPPED OUTPUT), CONTINUED

```
{  
    LastCounter = MapOutputData->counter;  
    int len = MapOutputData->length;  
    if( len > sizeof(MapOutputData->data)-1 )  
        len = sizeof(MapOutputData->data)-1;  
  
    ScaleStatus_Text->Caption = (String)MapOutputData->status;  
    input[0] = NULL;  
    for ( int mf = 0; mf < len; mf++ ) {  
        input[mf] = MapOutputData->data[mf];  
    }  
    input[len] = NULL;  
    // return command i.e. 'z' to zero scales, 'u' to change units etc... (2 char buffer... 'Z1' to zero  
    // scale 1)  
    if( KernelCommand[0] != NULL )  
    {  
        MapOutputData->command[0] = KernelCommand[0];  
        MapOutputData->command[1] = KernelCommand[1];  
        KernelCommand[0] = NULL;  
        CommandSent = true;  
    }  
    result = true;  
}  
// release semaphore for kernel  
ReleaseSemaphore(wSemaphore, 1, NULL);  
}  
return result;  
}  
//-----
```



I/O MAP

The Addresses shown in the table are typical locations.

I/O Port	Assignment
0 ~ F	AT DMA Controller
20 ~ 21	AT Interrupt Controller
40 ~ 43	82C54 Compatible Programmable Timer
60	8042 Compatible keyboard Controller
61	AT Style Speaker
64	8042 Compatible keyboard Controller
70 ~ 71	Real Time Clock
81 ~ 83	AT DMA Controller
87	AT DMA Controller
89 ~ 8B	AT DMA Controller
8F ~ 91	AT DMA Controller
A0 ~ A1	AT Interrupt Controller
C0 ~ DF	AT DMA Controller
F0 ~ FF	Math Coprocessor
170 ~ 177	IDE Controller
1F0 ~ 1F7	IDE Controller
220 ~ 22E	Sound Card
2F8 ~ 2FF	Communication Port (COM2)
330	Midi
376	IDE Controller
378 ~ 37A	LPT1
3B0 ~ 3BB	VGA Adapter
3C0 ~ 3DF	VGA Adapter
3F0 ~ 3F5	FDD Controller
3F6	IDE Controller

Appendix III: Data Output

REMOTE DISPLAY OUTPUT

Remote Display Data Format

<STX><4><0><SP/-><XXXXXX><ETX>

Note(s):

1. Characters denoted by **X** are characters 0-9.
 2. Leading zeroes are suppressed.
 3. Polarity indication for a positive value is a space (**SP**).
– Negative values are not transmitted.
 4. Identifier code <4><0> = **Gross weight**.
– Transmission is **Gross Only**.
 5. Transmission for the **DEMAND Mode** occurs when a carriage return (**CR**) Hex **0D** is received.
-

CONFIGURE OUTPUT

Fairbanks Data Format

<STX><A><C><GGGGGG><TTTTTT><CR>

Note(s):

1. Characters denoted by **G** and **T** are characters 0-9.
 2. Leading zeroes are suppressed.
 3. **Gross Weight Data = G**
Tare Weight Data = T
-

Status Code (Word) A

Bit #	X00	X0	X	X.X	X.XX	X.XXX	X.XXXX	X.XXXXX
0	0	1	0	1	0	1	0	1
1	0	0	1	1	0	0	1	1
2	0	0	0	0	1	1	1	1

CONFIGURE OUTPUT, CONTINUED

Increment Size

Bit #	Count By 1	Count by 2	Count by 5
3	1	0	1
4	0	1	1
5		Always Logic 1	
6		Always Logic 0	
7		Parity Bit	

Status Code (Word) B

Bit #	Description
0	Gross = 0 Net = 1
1	Positive = 0 Negative = 1
2	In Range = 0 Overcapacity = 1
3	No Motion = 0 Motion = 1
4	Lb = 0 Kg = 1
5	Always Logic 1
6	Normal = 0 Power Up = 1
7	Parity Bit

Status Code (Word) C

Bit #	Description
0	Always Logic = 0
1	Always Logic = 0
2	Always Logic = 0
3	Normal = 0 Print Switch Pushed = 1
4	Always Logic = 0
5	Always Logic = 0
6	Normal = 0 Keyboard Tare = 1
7	Parity Bit



Toledo Data Format

<STX><A><C><GGGGGG><TTTTTT><CR>

Note(s):

1. Characters denoted by **G** and **T** are **Characters 0-9**.
2. Leading zeroes are **not suppressed**.
3. **Gross Weight data = G**
Tare Weight data = T

Status Code (Word) A

Bit #	X00	X0	X	X.X	X.XX	X.XXX	X.XXXX	X.XXXXX
0	0	1	0	1	0	1	0	1
1	0	0	1	1	0	0	1	1
2	0	0	0	0	1	1	1	1

Increment Size

Bit #	Count By 1	Count by 2	Count by 5
3	1	0	1
4	0	1	1
5		Always Logic 1	
6		Always Logic 0	
7		Parity Bit	

Toledo Data Format, Continued

Status Code (Word) B

Bit #	Description		
0	Gross = 0		Net = 1
1	Positive = 0		Negative = 1
2	In Range = 0		Overcapacity = 1
3	No Motion = 0		Motion = 1
4	Lb = 0		Kg = 1
5	Always Logic = 0		
6	Normal = 0		Power Up = 1
7	Parity Bit		

Status Code (Word) C

Bit #	Description		
0	Always Logic = 0		
1	Always Logic = 0		
2	Always Logic = 0		
3	Normal = 0		Print Switched Pushed = 1
4	Always Logic = 0		
5	Always Logic = 1		
6	Normal = 0		Keyboard Tare = 1
7	Parity Bit		



Cardinal 738 Continuous Scoreboard Data Format

<CR><P><WWWWWW><m><SP><U><SP><g><SP><SP><ETX>

Note(s):

1. *W = Displayed weight*
P = Polarity
+ = Positive weight
- = Negative weight
U = Units
lb = pounds
kg = kilograms
m = Motion or o = Overload
g = Gross; n = Net
SP = Space
 2. *Leading zeros are not suppressed.*
-

Weightronix Data Format

< ><M><WWWWWW>< ><U><CR><LF>

Note(s):

1. *< > = Space*
M = Mode
G =Gross
T=Tare
N=Net
W = Displayed weight
U = Units
m = Motion
o = Overload
 2. *Leading zeros are suppressed.*
-

Condec Continuous Data Format

<STX><P><WWWWWW><U><G><M><CR>


Note(s):

1. *P = Polarity*
space = positive weight
- = negative weight
W = Displayed weight
U = Units
L = pounds
K = kilograms
G = Gross; N = Net
M = Motion
2. *Leading zeros are suppressed.*

Build Tab Definitions

Load Cell Status <L> This item, if included in the data output string, indicates if a load cell(s) are indicating an error. If no error is present, a zero (0) will be present or the character equivalent of the decimal number of load cell with an error will be indicated. i.e. 1 = <SOH>, 28 = <FS>

COM Port Connections



CN 2: COM1
 External COM3 and COM4

Appendix IV: IP Command Functions

Command Structure:

[Sender],[COMMAND],Command,[End][LF]

Where **Sender** is:

The Computer Name of the PC which is sending the command.

Where Command is:

Lowercase z = Zeroes all scales.

Uppercase Z1, Z2, etc = Zero a specific scale.

Uppercase ZA or ZB = Zero ScaleA (1 to 4) or ScaleB (5 to 8)

Lowercase u = Change units on all scales.

Uppercase U1, U2, etc. = Change units on a specific scale.

Uppercase UA or UB = Change units on ScaleA (1 to 4) or
ScaleB (5 to 8)

Poll Character (see Configured Output) sends configured output.

Where LF is: Line Feed

Example:

[Fred's PC],[COMMAND],Z1,[End][LF]

i.e. – Fred's PC is requesting Scale 1 to Zero.

Appendix V: Programming the Watchdog Timer

The **FB3000 Embedded PCB** provides a Watchdog Timer that resets the CPU or generates an interrupt if processing comes to a stop.

- This function ensures greater system reliability in industrial standalone and unmanned environments.
- **To enable the Watchdog Timer**, output the value of the Watchdog Timer Interval to the Controller.
- The value range is from **01H to FFH**, and the related time Watchdog Timer interval is **one (1) second to 255 seconds**.

DATA	TIMER INTERVAL
00	Disabled
01	One (1) second
02	Two (2) seconds
*	*
*	*
FF	255 seconds

NOTE: To program the Watchdog Timer, write the timer value to the **I/O Port 444 (hex)**.

Example: **Assembly Language**

Start Watchdog Timer	DOS Debug
MOV DX, 444H	OUT 444, XX
MOV AL, XXH	
OUT DX, AL	

Start Watchdog Timer	DOS Debug
MOV DX, 444H	IN 441
IN AL, DX	

Appendix VI: Kernel 20mA Codes

Code	Units	Data Displayed	Scale #
00		Display all data.	
40	lbs	Gross	1
41	lbs	Net	1
42	lbs	Tare	1
43	kg	Gross	1
44	kg	Net	1
45	kg	Tare	1
46	lbs	Gross	2
47	lbs	Net	2
48	lbs	Tare	2
49	kg	Gross	2
50	kg	Net	2
51	kg	Tare	2
52	lbs	Gross	3
53	lbs	Net	3
54	lbs	Tare	3
55	kg	Gross	3
56	kg	Net	3
57	kg	Tare	3
58	lbs	Gross	4
59	lbs	Net	4
60	lbs	Tare	4
61	kg	Gross	4
62	kg	Net	4
63	kg	Tare	4
64	lbs	Gross	5
65	lbs	Net	5
66	lbs	Tare	5
67	kg	Gross	5
68	kg	Net	5
69	kg	Tare	5
70	lbs	Gross	6
71	lbs	Net	6
72	lbs	Tare	6
73	kg	Gross	6
74	kg	Net	6
75	kg	Tare	6
76	lbs	Gross	7
77	lbs	Net	7
78	lbs	Tare	7
79	kg	Gross	7
80	kg	Net	7
81	kg	Tare	7
82	lbs	Gross	8
83	lbs	Net	8
84	lbs	Tare	8
85	kg	Gross	8
86	kg	Net	8
87	kg	Tare	8
99	lbs	TOTAL	For FB3000 HWY SYS

* Existing 2500 output (excluding HWY SYS application)

Appendix VII: SOCKS Information

SOCKS is an Internet Protocol that allows client-server applications to transparently use the services of a network firewall.

- **SOCKS** is an abbreviation for "sockets".
- Clients behind a firewall, needing to access exterior servers, may connect to a SOCKS proxy server instead. Such a proxy server controls the eligibility of the client to access the external server and passes the request on to the server.
- **SOCKS** can also be used in the opposite way, allowing the clients outside the firewall (exterior clients) to connect to servers inside the firewall (internal servers).

A typical **SOCKS 4** connection request looks like the following (each number is one byte).

Client to SOCKS Server:

Field 1: SOCKS version number, 1 byte, must be 0x04 for this version

Field 2: Command code, 1 byte:

- **0x01** = Establish a TCP/IP stream connection.
- **0x02** = Establish a TCP/IP port binding.

Field 3: Network byte order port number, 2 bytes.

Field 4: Network byte order IP address, 4 bytes.

Field 5: The user ID string, variable length, terminated with a null (0x00).

Server to SOCKS client:

Field 1: Null byte.

Field 2: Status, 1 byte:

- **0x5a** = Request granted.
- **0x5b** = Request rejected or failed.
- **0x5c** = Request failed because client is not running identd (or not reachable from the server).
- **0x5d** = Request failed because client's identd could not confirm the user ID string in the request.

Field 3: 2 arbitrary bytes, that should be ignored.

Field 4: 4 arbitrary bytes, that should be ignored.



APPENDIX VII: SOCKS INFORMATION, CONTINUED

The **SOCKS 5 Protocol**, an extension of the **SOCKS 4 Protocol** that offers more choices of authentication, is defined in **RFC 1928**.

The initial handshake now consists of the following:

Client connects and sends a greeting which includes a list of authentication methods supported.

Server chooses one (or sends a failure response if none of the offered methods are acceptable).

Several messages may now pass between the client and the server depending on the authentication method chosen.

Client sends a connection request similar to SOCKS 4.

Server responds similar to SOCKS 4.

The authentication methods supported are numbered as follows:

0x00 - No authentication.

0x01 – GSSAPI.

0x02 - Username/Password.

0x03-0x7F - Methods assigned by IANA.

0x80-0xFE - Methods reserved for private use.

The initial greeting from the client is:

Field 1: SOCKS version number (must be 0x05 for this version).

Field 2: Number of authentication methods supported, 1 byte.

Field 3: Authentication methods, variable length, 1 byte per method supported.

The server's choice is communicated:

Field 1: SOCKS version, 1 byte (0x05 for this version).

Field 2: Chosen authentication method, 1 byte, or 0xFF if no acceptable methods were offered.

APPENDIX VII: SOCKS INFORMATION, CONTINUED

The subsequent authentication is method-dependent and described in **RFC 1929**.

The client's authentication request is:

Field 1: Version number, 1 byte (must be 0x01).

Field 2: Username length, 1 byte.

Field 3: Username.

Field 4: Password length, 1 byte.

Field 5: Password.

Server response for authentication:

Field 1: Version, 1 byte.

Field 2: Status code, 1 byte.

- **0x00** = success.
- **Any other value** = failure, connection must be closed.

The client's connection request is:

Field 1: SOCKS version number, 1 byte (must be 0x05 for this version).

Field 2: Command code, 1 byte:

- **0x01** = establish a TCP/IP stream connection.
- **0x02** = establish a TCP/IP port binding.
- **0x03** = associate a UDP port.

Field 3: Reserved, must be 0x00.

Field 4: Address type, 1 byte:

- **0x01** = IPv4 address.
- **0x03** = Domain name.
- **0x04** = IPv6 address.

Field 5: Destination address of:

- 4 bytes for IPv4 address.
- 1 byte of name length followed by the name for Domain name.
- 16 bytes for IPv6 address.

Field 6: Port number in a network byte order, 2 bytes.



APPENDIX VII: SOCKS INFORMATION, CONTINUED

Server response:

Field 1: SOCKS protocol version, 1 byte (0x05 for this version).

Field 2: Status, 1 byte:

- **0x00** = Request granted.
- **0x01** = General failure.
- **0x02** = Connection not allowed by *ruleset*.
- **0x03** = Network unreachable.
- **0x04** = Host unreachable.
- **0x05** = Connection refused by destination host.
- **0x06** = TTL expired.
- **0x07** = Command not supported / protocol error.
- **0x08** = Address type not supported.

Field 3: Reserved, must be 0x00.

Field 4: Address type, 1 byte:

- **0x01** = IPv4 address.
- **0x03** = Domain name.
- **0x04** = IPv6 address.

Field 5: Destination address of :

- 4 bytes for IPv4 address.
- 1 byte of name length followed by the name for Domain name.
- 16 bytes for IPv6 address.

Field 6: Network byte order port number, 2 bytes.

Appendix VIII: Remote Functions

REMOTE FUNCTIONS	CN14	
Remote Zero Switch	3	11 or 12
Remote Print	9	11 or 12

**Dry contacts only.*

APPENDIX IX: ASCII CODES

HEX	DEC	CHAR
00	000	NUL
01	001	SOH
02	002	STX
03	003	ETX
04	004	EOT
05	005	ENQ
06	006	ACK
07	007	BEL
08	008	BS
09	009	HT
0A	010	LF
0B	011	VT
0C	012	FF
0D	013	CR
0E	014	SO
0F	015	SI
10	016	DLE
11	017	DC1
12	018	DC2
13	019	DC3
14	020	DC4
15	021	NAK
16	022	SYN
17	023	ETB
18	024	CAN
19	025	EM
1A	026	SUB
1B	027	ESC
1C	028	FS
1D	029	GS
1E	030	RS
1F	031	US
20	032	SPACE
21	033	!
22	034	"
23	035	#
24	036	\$
25	037	%
26	038	&
27	039	5
28	040	(
29	041)
2A	042	*

HEX	DEC	CHAR
2B	043	+
2C	044	,
2D	045	-
2E	046	.
2F	047	/
30	048	0
31	049	1
32	050	2
33	051	3
34	052	4
35	053	5
36	054	6
37	055	7
38	056	8
39	057	9
3A	058	:
3B	059	;
3C	060	<
3D	061	=
3E	062	>
3F	063	?
40	064	@
41	065	A
42	066	B
43	067	C
44	068	D
45	069	E
46	070	F
47	071	G
48	072	H
49	073	I
4A	074	J
4B	075	K
4C	076	L
4D	077	M
4E	078	N
4F	079	O
50	080	P
51	081	Q
52	082	R
53	083	S
54	084	T
55	085	U

HEX	DEC	CHAR
56	086	V
57	087	W
58	088	X
59	089	Y
5A	090	Z
5B	091]
5C	092	\
5D	093	[
5E	094	^
5F	095	--
60	096	'
61	097	a
62	098	b
63	099	c
64	100	d
65	101	e
66	102	f
67	103	g
68	104	h
69	105	i
6A	106	j
6B	107	k
6C	108	l
6D	109	m
6E	110	n
6F	111	o
70	112	p
71	113	q
72	114	r
73	115	s
74	116	t
75	117	u
76	118	v
77	119	w
78	120	x
79	121	y
7A	122	z
7B	123	{
7C	124	
7D	125	}
7E	126	~
7F	127	DEL



Manufactured by Fairbanks Scales, Inc.
821 Locust
Kansas City, Missouri 64106
www.fairbanks.com

FB3000 KERNEL
OPERATOR MANUAL
DOCUMENT 51147