



# HAWKJAW

# OPERATION, MAINTENANCE

AND SERVICE MANUAL

# MODEL 100K-2GSR

Serial # 128-130

### HAWK INDUSTRIES, INC.

1245 East 23rd Street Long Beach, CA 9080 **Phone: 562-424-0709** Fax: 562-490-9959 www.hawkindustries.com

### Introduction

Hawk's design philosophy is simple: Design with the end user in mind. Make it tough, dependable and easy to maintain.

Hawk has designed the HawkJaw with this same simple formula.

#### **FEATURES**

The HawkJaw 100K-2GSR is a hanging unit that will spin, make up and break out drill pipe. It is revolutionary because the tool spins and makes up drill pipe or breaks out and spins drill pipe in 12 seconds or less. A patented self-energized grip system provides consistent torque values to the drill string. Consistent torque ensures that wash outs and "post tightening" down hole do not occur under normal conditions.

A patented adjustable wrench system eliminates the need for separate jaws, spinning wrench rollers or gripping dies. The HawkJaw's modular design enables the unit to be maintained on the rig floor.

#### SAFETY

The HawkJaw 100K-2GSR provides a fast, safe and efficient method of spinning and make up or break out and spinning. It eliminates costly and dangerous spinning chain and rig tong accidents.

#### TIME AND LABOR SAVINGS

The HawkJaw improves trip time over any comparable torquing and spinning device in the industry. The unit easily adapts to any land or offshore rig because it hangs in the derrick. Handles mounted near the control buttons enable one rig hand to move the hanging unit on and off the pipe.

Control buttons are used to grip, torque and spin drill pipe. Drillers and operators of the HawkJaw 100K-2GSR work more efficiently and suffer less fatigue on long round trips. The unit saves trip time because the HawkJaw breaks out and spins in 12 seconds or less, and makes up and spins in 10 seconds or less. Crew fatigue is reduced, pipe is properly torqued and the work is efficient.

# Table of Contents

Introduction	2
Table of Contents	3
Warranty	6
Specification Sheet	7
Ordering Instructions	8
Installation	9
Hanging Cable Location	9
HawkJaw Location	9
Hanging Cable Requirements	10
Hydraulic Requirements	11
Air Requirements	12
Raise/Lower Cylinder Hook - Up	13
Winch Hook - Up	14
Operation	17
Start-up Procedure	17
Adjust for Make Up	18
Adjusting the Wrenches	18
Adjusting the Spinner	19
Position for Make Up	20
Setting Make Up Torque	22
MakeUp	23
Low Torque Warning Test	24
Adjust for Break Out	25
Adjusting the Spinner	26
Position for Break Out	27
Break Out	29
Maintenance & Repair	30
Wrench Maintenance	30
Die Pivot Blocks	30
Wrench Hook	31
Wrench Nut	31
Hook Pivot Bearing Cap	31
Wrench Maintenance	31
Grip Cylinder Pivot Points	32
Torque Cylinder Pivot Points	32
Tilt Cyl inder Pivot Points	32
Mounting Arm Pivot Points	33
Filter Maintenance	34
Hydraulic Filter	34
Air Filters	35

Table of Contents

# Table of Contents

Changing the Hook Dies	36
Hook Dies	36
Changing the Heel Dies	37
Top Wrench Heel Die	37
Middle Wrench Heel Die	39
Bottom Wrench Heel Die	41
Spinner Maintenance	43
Chain Lubrication	43
Drive Roller Sprocket Bearings	44
Chain Drive Shaft Bearing	45
Spinner Grip Cylinders	45
Spinner Mount Sliding Block	46
Spinner Mount Sliding Tube	46
Reducer Gear Box	47
Winch Gear Box	47
Changing the Spinner Chain	48
Chain	48
Changing the Drive Rollers	50
Drive Rollers	50
Changing the Drive Roller Sprocket Bearings	52
Drive Roller Sprocket Bearings	52
Changing the Torque Cylinder	54
Torque Cylinder	54
Changing the Grip Cylinders	58
Top Grip Cylinder	58
Middle Grip Cylinder	60
Bottom Grip Cylinder	62
Main Hydraulic Block Fitting and Hose Access	64
Main Block Fittings and Hoses	64
Air Logic System and Main Block	65
Spinner Motor Sequence Valve Access	66
Spinner Motor Sequence Valve	66
Trouble Shooting	67
Drawings	78
100K-2GJR Full Hawkjaw Assembly	78
100K-2GJR Top-Bottom Wrench Assembly	80
100K-2GJR Midde Wrench Assembly	82
100K-2GJR Hydro-Pneumatic Assembly	84
100K-2GJR HangerAssembly	86

# Table of Contents

100K-2GJR Left Control Handle Assembly	88
100K-2GJR Right Control Handle Assembly	90
100K-2GJR Winch MountAssembly	92
100K-2GJR Spinner MountAssembly	94
100K-2GJR Stand Assembly	96
100K-2GJR Hawkjaw Spinner Assembly	98
100K-2GJR Pipe Stop Assembly	100
100K-2GJR Hydraulic Connections	102
100K-2GJR Spin Manifold Assembly	104
100K-2GJR Raise/Lower Cylinder Assembly	106
100K-2GJR Main Manifold Assembly	108
100K-2GJR Main Manifold Air Connections	110
100K-2GJR Left Control Handle Air Connections	112
100K-2GJR Right Control Handle Air Connections	114
100K-2GJR Torque Cylinder Assembly	116
100K-2GJR Left Control Tube Assy Air Conn	118
100K-2GJR Right Control Tube Assy Air Conn	120
25726 Chain Oiler Assembly	122
20209-BOT Heel Die Holder Assembly, Bottom	124
20209-MID Heel Die Holder Assembly, Middle	126
20209-TOP Heel Die Holder Assembly, Top	128
20211-MID Hook Die Holder Assembly, Middle	130
20211-TB Hook Die Holder Assembly, Middle	132
CYL25-AS Top, -BS Bottom Spinner Grip Cyl	134
59R Roller Assembly, Winch	136
A11-1LCH Multiplex Connector Assembly	138
A11-2RCH Multiplex Connector Assembly	140
A11-LCH Multiplex Connector	142
A11-RCH Multiplex Connector	144
A22 On Board Air Filter Assembly	146
H18S Grip Tilt Cylinder Assembly	148
H25 Hydraulic Filter Assembly	150
H37S-2 Push Cylinder Assembly	152
100K-2GSR Hydraulic Pipe Clamp	154
100K-2GSR H18 Top Grip Cylinder	156
100K-2GSR Torque Manifold	158
100K-2GSR Gage Manifold	160
100K-2GSR Winch Assembly	162
Maintenance Schedule	165

Table of Contents

### Warranty

### HAWKJAW 100K-2GSR STANDARD WARRANTY AND FIELD SERVICE

Your Hawkjaw must be free of material and workmanship defects for a period of six months from the date of delivery. If any items fail because of a manufacturing defect within that period of time, that item will be replaced by Hawk Industries. Hawk Industries at its discretion may extend this war-ranty period.

Replacement of parts will be accomplished either at the factory or at a designated service point. This guarantee does not include the replacement of parts where failure occurred due to normal wear and tear or misuse of the tool. Defective parts must be inspected by Hawk Industries, at its Long Beach plant, before warranty can be honored. Customer must obtain an RGA# (Return of Goods Authorization) from the California, USA factory.

Hawk Industries' liability is limited to replacement of defective parts only and does not include the cost of labor, communications, transportation or handling connected with the replacement of such parts.

Hawk Industries will in no event be liable for consequential damages or contingent liabilities arising out of the failure of any parts to operate properly.

No expressed, implied or statutory guarantee other than herein set forth is made or authorized to be made by Hawk Industries.

### CAUTION

Factory specifications for hydraulics, pneumatics, lubricants, adjustments and safety precautions as set forth in the operation and maintenance manual are for the mutual protection of the owner of the HawkJaw 100K-2GSR and the company. Failure to adhere to these specifications can reduce the efficiency or life of the equipment and/or cause bodily injury.

### <u>Warning</u>

The Hawkjaw includes specially modified valves, fasteners and other components for extreme environments and service. Any attempt to substitute standard components could reduce reliability and performance, void the warranty and/or cause bodily injury. Any modification made by any third party without express written consent of Hawk Industries Inc. shall nullify the existing standing warranty.

# Specification Sheet



DIMENSIONS

DEPTH: 58 in. WIDTH: 50 in. HEIGHT: 100 in.

> pecification Sheet

#### PERFORMANCE AND POWER REQUIREMENTS

TORQUE: MAXIMUM PIPE ROTATION: WRENCH SIZE RANGE: SPINNER SIZE RANGE:

AIR POWER SOURCE: HYDRAULIC POWER SOURCE: HYDRAULIC POWER SOURCE TYPE:

#### WEIGHT:

GRIP, SPIN, MAKE UP & RESET CYCLE TIME: GRIP, BREAK OUT, SPIN & RESET CYCLE TIME: 100,000 ft. lbs. 50 degrees 4" – 9 1/2" OD tool joints 3" – 9 1/2" OD tube

100 psi @ 2-10 cfm 2,600 psi @ 20-35 gpm Closed Center System (Optional Open/Closed Center)

3,700 lbs.

10 sec. or less 12 sec. or less

# Ordering Instructions

All parts must be ordered by giving the quantity needed, the full part number as listed in this manual under Part #, the unit serial number, the model number and part name.

		Example		
Quantity	Part #	Serial #	Model #	Part Name
2	061-20194	01	100K-2GSR	Die
3	061-H18	01	100K-2GSR	Grip Cylinder
1	031-25CHAIN	01	100K-2GSR	Chain

# Hanging Cable Location

- Anchor the hanging cable to a point as close to the derrick crown as possible. The longer the hanging cable, the easier the HawkJaw is to move on and off the drill pipe.
- 2. Locate the cable hang point as high above the center of the rotary table as possible. The cable must hang within

2'-3' ft. of the rotary table center.

### <u>NOTE</u>

The hanging cable must permit the HawkJaw to move from the drill pipe connection to the mouse hole connection to the HawkJaw rest position (3'- 5' ft. away from the rotary table).

# HawkJaw Location

- Place the HawkJaw on the side of the rotary table away from the setback zone. This allows the drill pipe stands to swing straight from pick-up to stabbing.
- If possible, place the HawkJaw on the opposite side of the setback zone. If the rig has dual setback zones, Step 1 applies.
- The HawkJaw may rest on the rig floor
   3' -5' ft. away from the rotary table.

# Hanging Cable Requirements

- 1. 5/8" diameter steel cable.
- Appropriate hanging cable hardware for 5/8" diameter steel cable.
- 3. Enough cable length to suspend the Hanger Eye (HE) 20' ft. above the rig floor.
- 4. Enough cable length to allow the HawkJaw to rest on the rig floor 3'- 5' ft. away from the rotary table with the lift cylinder completely stroked out. The lift cylinder is 13' ft. long when completely stroked out.



- 1. **Pressure compensated pump** set to pressure compensate at **2500 psi**.
- 2. Minimum volume of **20 gpm**. **35 gpm** for **top performance**.
- 1" minimum Pressure line. 1 1/4" Pressure line if the power unit is located more than 100' apart from the HawkJaw. The hose working pressure must be 3000 psi or greater.
- 4. 1 1/4" minimum Tank line. 500 psi minimum hose working pressure.
- Hawk approved quick disconnects [Male: Part # 061-H52 (MQD). Female: Part # 061-H53 (FQD)]. Initial quick disconnects supplied with the HawkJaw.
- Hydraulic power unit located in a clean, dry, ventilated area.
- Enough slack in the lines for the HawkJaw to move from its rest position to the drill pipe connection to the mousehole connection.

#### WARNING

The HawkJaw is a **closed center system** which **must have** a **pressure compensated volume controlled** power unit. If the only available hydraulic power unit is **constant volume**, then the **optional hydraulic converter kit** (Part # 061-J80) is required. Running the HawkJaw with a **constant volume** hydraulic power unit may result in **bodily injury** and will cause **damage** to the **HawkJaw** and to the **hydraulic power unit**.

#### **WARNING**

The HawkJaw must receive **clean hydraulic fluid**. Running the HawkJaw without a Hawk approved filter (Part # 061-H25) and installed filter element (Part # 061-H25A) voids the warranty and severely shortens component life.



FQD Tank

MQD Pressure

# Air Requirements

- 1. Clean, dry air at 100 psi @ a negligible volume.
- On-board auto-dump air filter (Part # 061-A22). Initial on-board filter (OF) supplied with the HawkJaw.
- Auto-dump air filter (Part # 061-J29) located between the air source and the HawkJaw air supply line (A). Initial inline filter supplied with the HawkJaw.
- Enough slack in the line for the HawkJaw to move from its rest position to the drill pipe connection to the mouse hole connection.

#### **WARNING**

The HawkJaw must receive **clean**, **dry air**. Running the HawkJaw without a Hawk approved air filter (Part # 061-J29) voids the warranty and shortens component life.





Make sure the larger air filter (Part # 061-J29) is mounted vertically with the red and black arrows on the cannisters pointing up.

#### <u>NOTE</u>

The smaller air filter (OF) is located on board the HawkJaw. (Part # 061-A22)



OF -

## Raise/Lower Cylinder Hook - Up

- Use the Raise/Lower cylinder Cap side Bolt (B) to connect the HawkJaw Suspension Ring (SR) to the Raise/ Lower cylinder (C).
- Use the Raise/Lower cylinder Cap side Lock Nut (N) to secure the Raise/Lower cylinder Cap side Bolt (B).
- 3. Connect the Hanger Swivel (HS) to the hanging cable.
- 4. Connect the HawkJaw Rod side (HR) and Cap side (HC) hydraulic Leader hoses to the Raise/Lower cylinder Rod side (RR) and Cap side (RC) hoses. The HawkJaw Rod side (HR) Leader hose Quick Disconnect is male.

#### <u>NOTE</u>

Make sure the **rod side** of the Raise/Lower cylinder (R) **connects** to the **hanging cable**.

#### <u>NOTE</u>

**Tightly connect** the **quick disconnects**. A loose connection causes a pressure drop in the hydraulic fluid which heats up the fluid and reduces component life. A loose quick disconnect may also stop cylinder movement.

### <u>NOTE</u>

Use only Hawk approved quick disconnects.



Male Quick Disconnect (HC, RR)061-H26MFemale Quick Disconnect (RC, HR)061-H26F





## Winch Hook - Up

- 1. **Connect** the air power source with the **Air** (A) line.
- 2. Make sure the hydraulic **reservoir** is **full**.
- Connect the hydraulic Pressure

   (P) and Tank (T) lines. The
   Pressure line (P) Quick
   Disconnect is male.
- 4. Make sure the "E" stop (E) is pulled out.
- Check for hydraulic leaks. If leaks occur, see Trouble Shooting.
- 6. With the exception of the hooks retracting, **no motion** should occur. If any other parts on the HawkJaw move, see Trouble Shooting.

Continued on next page.

#### <u>NOTE</u>

#### Tightly connect the quick disconnects.

A loose connection causes a pressure drop in the hydraulic fluid which heats up the fluid and reduces component life.

#### <u>NOTE</u> Use only Hawk approved quick disconnects.

Part Numbe	Part Numbers	
Part Name	Part #	
Male Quick Disconnect (P)	061-H52	
Female Quick Disconnect (T)	061-H53	
Male Air Quick Disc. (A)	061-A12M	
Female Air Quick Disc.	061-A12F	





# Winch Hook - Up

- 7. Center the Suspension Ring (SR) on the Lateral tilt screw (LTS).
- 8. Use Raise (R) to raise the HawkJaw 1'- 2' ft. off the rig floor.
- 9. Use the Control Handles (CH) on both Control Panels and Raise (R) and Lower (L) to position the HawkJaw middle wrench (MW) near the drill pipe shoulder (S) location.

Continued on next page.





MW



## Winch Hook - Up

- 10. Disengage the Winch Clutch (C).
  Spool out enough line to anchor the Winch Cable Spring Shackle (S) to a structural point on the derrick.
- 11. Anchor the Winch Cable Spring
  Shackle (S) to a structural point on the derrick. Make sure there is enough slack in the line to enable the HawkJaw to move onto the drill pipe connection.
- 12. Engage the Winch Clutch (C).
- 13. Use Winch Off (WOff) to pull the HawkJaw 3' to 5' ft. away from the wellbore. This allows the drill pipe stands to swing straight from pick-up to stabbing.





WOff

С



### <u>IMPROVED</u>

Winch Cable Spring improves overall winch performance and eliminates excess tension while making up drill pipe.

S

# Start-up Procedure

- 1. **Connect** the air power source with the **Air** (A) line.
- 2. Make sure the hydraulic reservoir is full.
- 3. Make sure the hydraulic
   Pressure (P) and Tank (T) lines are connected. The Pressure line
   (P) Quick Disconnect is male.
- 4. Make sure the "E" stop (E) is pulled out.
- Check for hydraulic leaks. If leaks occur, see Trouble Shooting.
- 6. With the exception of the hooks retracting, **no motion** should occur. If any other parts on the HawkJaw move, see Trouble Shooting.





**Tightly connect** the **quick disconnects**. A loose connection causes a pressure drop in the hydraulic fluid which heats up the fluid and reduces component life.

#### <u>NOTE</u> Use only Hawk approved quick disconnects.

Part Numbers	
Part Name	Part #
Male Quick Disconnect (P)	061-H52
Male Air Quick Disconnect (1)	061-H53 061-A12M
Female Air Quick Disc.	061-A12F



## Adjust for Make Up

### Adjusting the Wrenches

- 1. **Measure** the **tool joint** with OD calipers.
- 2. Use the 1 1/4" wrench to adjust the Pointer (P) on the Pipe stop index (PI) to the OD tool joint size. Its always better to adjust the pointer 1/4" larger than the measured diameter of the tool joint.
- For safety, adjust the Bottom wrench nut (BN) 1" larger than the Top wrench nut (TN) and Middle wrench nut (MN).
- 4. Rotate the Top wrench nut (TN) and the Middle wrench nut (MN) to the OD tool joint size. Visually align the end face (F) of the wrench nut with the scale (S) on the wrench.



BN <sup>′</sup>





Shown set for 6 " OD tool joint

Shown set for 6" OD tool joint

## Adjust for Make Up

I

QR

### Adjusting the Spinner

- 1. **Measure** the drill pipe **tube** with OD calipers.
- 2. **Remove** the **quick release** pins (QR).
- 3. Slide the whole Drive unit (D) forward or backward to the appropriate holes. Use the pipe size index (I) to adjust the drive unit to the correct setting.
- 4. **Replace** the **quick release** pins (QR).



D



#### NOTE

Spinner performance could be reduced if the spinner push cylinder stroke is insufficient to allign the spinner correctly with the drill pipe, especially on sizes above 5 1/2" tube. To correct this problem:

- 1. Loosen the four spinner slide assembly bolts (SAB).
- 2. Re-adjust the spinner slide assembly (SSA) forward so that the push cylinder strokes out far enough to reach the connection.
- 3. Tighten the spinner slide assembly bolts (SAB).

SAB SSA



### Position for Make Up

- 1. Stab the drill stand.
- 2. Center the Suspension Ring (SR) on the Lateral tilt screw (LTS).
- 3. Push and hold down Winch On (WOn) to move the HawkJaw onto the drill pipe connection.
- 4. Use Raise (R) and Lower (L) to center the Top wrench dies (TD) and the Middle wrench dies (MD) between the shoulder (S).
- Keep the Middle wrench dies (MD) away from the Hard banding (HB).
- 6. Keep the Top wrench dies (TD) and Middle wrench dies (MD) away from the shoulder (S).

Continued on next page.

WOn









MD HB

# Position for Make Up (cont.)

- 7. Check that the HawkJaw **Top** wrench (TW), Middle wrench (MW) and Bottom wrench (BW) hang straight and level when the drill pipe is against the pipe stop.
- 8. If the HawkJaw wrenches (TW, MW, BW) hang tilted forward or backward, use the Top Tilt (TT) button or the Bottom Tilt (BT) button to level the wrenches. Center the level bubble (LB).
- 9. If the HawkJaw wrenches (TW, MW, BW) hang sloped to the **right** or to the **left**, push and hold down Winch Off (WOff) to back the HawkJaw off the pipe. Use Lower (L) to lower the HawkJaw to the rig floor.

#### Repeat Step 2.

10. Make sure the **Pipe stop** (PS) is against the drill pipe connection.

NOTE The HawkJaw performs best when it hangs aligned with pipe.

LB





TW

MW

TΤ

BT







Operation

## Setting Make Up Torque

- 1. Follow the steps on pages 17-21.
- 2. Turn the Selector Switch (SS) to Make.
- Use the Red needle adjust (RNA) to rotate the Torque gauge red needle (RN) to the desired torque.
- 4. Rotate the Torque Set knob (K)
   counter- clockwise as far as the Torque Set knob (K) will turn.
- 5. Press in the **Grip Hold** (GH) button.
- 6. Press and hold **Spin** (S) until the stand rotates down to the shoulder.
- 7. Release Spin (S). Immediately press and hold **Grip** (G).
- 8. While holding down Grip (G), press and hold Torque (T).
  While holding down both Grip (G) and Torque (T), rotate the Torque Set knob (K) clockwise.
- 9. When the Torque gauge needle (TN) reaches the desired torque, stop rotating the Torque Set knob (K).
- 10. Release both Torque (T) and Grip (G) at the same time.
- 11. Pull out the **Grip Hold** (GH) button.







Shown set for 35,000 ft. lbs.

### Make Up

- 1. Press in the **Grip Hold** (GH) button.
- 2. Press and hold **Spin** (S) until the stand rotates down to the shoulder.
- 3. Release Spin (S).
- 4. **Push in** and **hold** the wrench **Grip** (G).
- 5. **Push** and **hold** down **Torque** (T).
- 6. Watch the Torque gauge needle (TN).
- 7. When the Torque gauge needle rises above and settles at the desired torque (this rising above is a normal hydraulic adjustment), release Torque (T). Immediately release Torque (T) button and the wrench Grip (G) button.
- 7a. Note: If the desired torque is not achieved, repeat steps 4-7.
- 8. Pull out the **Grip Hold** (GH) button.
- 9. The Hawkjaw can now be removed from the pipe.

#### SEE LOW TORQUE WARNING SYSTEM CHECK PG. 24





### Low Torque Warning Test

### **CHECK**

If the Torque cylinder strokes out before the **desired torque** is reached, the Torque gauge needle (TN) will fall off to approximately a 8000 Ft.-Lb. reading. If this happens, release **Torque** (T). Immediately **release** Grip (G). Wait for the Torque cylinder to reset.

#### LOW TORQUE WARNING SYS-**TEM CHECK**

Test#1: Hawk strongly recommends testing the Low Torque Warning System on every trip. If this test procedure is not performed, the drill string could be over torqued. Disconnect the Low torque warning test connector (LTC) located on the main hanger. Torque the first **connection**. Note the torque gage **needle position**; keep the Hawkjaw positioned on the same connection. Now re-connect the Low Torque Warning Connector. Re-torque the connection. The torque gage should indicate the same reading. If it does not, see Trouble Shooting.

Test#2: Hawk strongly recommends testing the Low Torque Warning System on every trip. If this test procedure is not performed, the drill string could be under torqued. When breaking the first connection, push in the Grip Hold (GH) button, hold down both **Torque** (T) and **Grip** (G) until the Torque Cylinder fully strokes out. When the Torque Cylinder fully strokes out, the Torque Gauge Needle will fall off to approximately an 8000 Ft.- Lb reading. If this does not occur.





GH



LTC



NOTE For safety, push in the "E" stop when the HawkJaw is at rest.

WARNING Do not make up pipe with the low torque warning test connector dis-connected. This may result in under torqued pipe in the hole.

## Adjust for Break Out

### **Adjusting the Wrenches**

- 1. **Measure** the **tool joint** with OD calipers.
- Use the 1 1/4" wrench to adjust the Pointer (P) on the Pipe stop index (PI) to the OD tool joint size. Its always better to adjust the pointer 1/4" larger than the measured diameter of the tool joint.
- 3. For safety, **adjust** the **Top wrench nut** (TN) **1" larger** than the Middle wrench nut (MN) and the Bottom wrench nut (BN).
- 4. Rotate the Middle wrench nut (MN) and the Bottom wrench nut (BN) to the OD tool joint size. Visually align the end face (F) of the wrench nut with the scale (S) on the wrench.





PI PI P

Shown set for 6 " OD tool joint

# Adjust for Break Out

#### Adjusting the Spinner

- 1. **Measure** the drill pipe **tube** with OD calipers.
- 2. **Remove** the **quick release** pins (QR).
- 3. Slide the whole Drive unit (D) forward or backward to the appropriate holes. Use the pipe size index (I) to adjust the drive unit to the correct setting.
- 4. **Replace** the **quick release** pins (QR).



D

QR



SAB SSA

#### NOTE

Spinner performance could be reduced if the spinner push cylinder stroke is insufficient to allign the spinner correctly with the drill pipe, especially on sizes above 5 1/2" tube. To correct this problem:

- 1. Loosen the four spinner slide assembly bolts (SAB).
- 2. Re-adjust the spinner slide assembly (SSA) forward so that the push cylinder strokes out far enough to reach the connection.
- 3. Tighten the spinner slide assembly bolts (SAB).



## Position for Break Out

- 1. Center the Suspension Ring (SR) on the Lateral tilt screw (LTS).
- Push and hold down Winch On (WOn) to move the HawkJaw onto the drill pipe connection.
- 3. Use Raise (R) and Lower (L) to center the Middle wrench dies (MD) and the Bottom wrench dies (BD) between the shoulder (S).
- 4. Keep the Bottom wrench dies(BD) away from the Hard banding (HB).
- 5. Keep the Middle wrench dies
  (MD) and Bottom wrench dies
  (BD) away from the shoulder

(S).

Continued on next page.







WOn



### Position for Break Out

- 6. Check that the HawkJaw Top wrench (TW), Middle wrench (MW) and Bottom wrench (BW) hang straight and level when the drill pipe is against the pipe stop.
- 7. If the HawkJaw wrenches (TW, MW, BW) hang tilted forward or backward, use the Top Tilt (TT) button or the Bottom Tilt (BT) button to level the wrenches. Center the level bubble (LB).
- 8. If the HawkJaw wrenches (TW, MW, BW) hang sloped to the right or to the left, push and hold down Winch Off (WOff) to back the HawkJaw off the pipe. Use Lower (L) to lower the HawkJaw to the rig floor. Repeat Step 2.
- 9. Make sure the **Pipe stop** (PS) is against the drill pipe connection.

### <u>NOTE</u>

The HawkJaw performs best when it hangs aligned with pipe.







LB



## Break Out

- 1. Rotate the Selector Switch (SS) clockwise to the break position.
- 2. Push in the **Grip Hold** (GH) button.
- 3. **Push** and **hold** in the wrench **Grip** (G).
- 4. Push and hold down **Torque** (T).
- When break out occurs, release Torque (T). Immediately release the wrench Grip (G). See note below.
- 6. Press and hold down Spin (S) until the stand pops out of the connection. Release Spin (S). If the stand will not spin, release Spin (S). Repeat Steps 4-6.
- 7. Pull out the **Grip Hold** (GH) button.
- 8. You are now able to **remove** the **Hawkjaw** from the pipe.





TN



Shown set for 35,000 ft. lbs.

Grease Once per Trip

Tools Required

Grease gun

### **Initial Steps**

- 1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.
- 2. Shut down the Hydraulic power unit.
- 3. **Press** the **Grip button repeatedly** to bleed hydraulic pressure.
- 4. **Disconnect** the **Air** power supply.
- 5. Push in the "E" stop.
- 6. **Assume** that there is still a **load** on every actuator. Proceed with caution.

### **Die Pivot Blocks**

 Pump grease fittings D1-D2 on the Top wrench (TW), Middle Wrench (MW), and Bottom Wrench (BW).

### <u>NOTE</u>

Consistent lubrication of the wrenches increases performance and component life.



### Grease Once per Week, Minimum

### Wrench Hook

- 1. Surface grease the hook thread (T) on the top wrench, middle wrench, and bottom wrench.
- 2. Rotate the wrench nut (N) on the top wrench, middle wrench, and bottom wrench to spread grease on the full thread area.

### Wrench Nut

1. Surface grease the wrench nut surface (NS) on the top wrench, middle wrench, and bottom wrench.

#### **Hook Pivot Bearing Cap**

1. **Pump** the Hook pivot bearing cap grease fittings (H1-H2) on the top and bottom of each wrench.

Г

	Part Nur	nbers	
Part	Name	Part #	
Stra	ight Grease Fitting	061-11031	K1
45° (	Grease Fitting	061-11031	K2
90°	Grease Fitting	061-11031	<u>×</u> 3

### NOTE

Consistent lubrication of the wrenches increases performance and component life.





H2

Maintenance & Repair

### Grease Once per Week, Minimum

Tools Required



G2

G1



Grease gun

### Initial Steps

- 1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.
- 2. Shut down the Hydraulic power unit.
- 3. **Press** the **Grip button repeatedly** to bleed hydraulic pressure.
- 4. **Disconnect** the **Air** power supply.
- 5. Push in the "E" stop.
- 6. **Assume** that there is still a **load** on every actuator. Proceed with caution.

### Grip Cylinder Pivot Points

1. **Pump grease fittings** G1-G2 on each Grip Cylinder.

### **Torque Cylinder Pivot Points**

1. **Pump grease fittings** T1-T3.

### Tilt Cyl inder Pivot Points

1. Pump grease fittings TC1-TC2.

<u>NOTE</u>

Consistent lubrication of the cylinder pivot points increases performance and component life.

32 Maintenance & Repair

### Grease Once per Week, Minimum

Tools Required

Grease gun

### **Initial Steps**

- 1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.
- 2. Shut down the Hydraulic power unit.
- 3. **Press** the **Grip button repeatedly** to bleed hydraulic pressure.
- 4. **Disconnect** the **Air power** supply.
- 5. Push in the "E" stop.
- 6. **Assume** that there is still a **load** on every actuator. Proceed with caution.

### **Mounting Arm Pivot Points**

 Pump grease fittings MP1-MP3 on each Mounting Arm (M1, M2).

Part NumbersPart NamePart #Straight Grease Fitting061-1103K145° Grease Fitting061-1103K290° Grease Fitting061-1103K3



M2



### <u>NOTE</u>

Consistent lubrication of the mounting arm pivot points increases performance and component life.

# Filter Maintenance

#### **Change Every 2 Months** RB **Initial Steps** SC 1. Depress the Red button (RB) WARNING located under the See-through S Running the HawkJaw rubber weather cap (SC). without a Hawk approved 2. Operate the HawkJaw. pressure-side filter element 3. If the Red button pops up, (Part #061-H25A) voids proceed with Step 4. the warranty and severely E shortens component life. 4. Make sure the HawkJaw is off the drill pipe connection and in С the **rest position** on the derrick. NOTE 5. Shut down the Hydraulic If the Cannister power unit. (C) leaks, change 6. Press the Grip button the "O" ring and repeatedly to bleed hydraulic back-up (S). Part Numbers pressure. 7. Disconnect the Air power Part Name Part # supply. Filter 061-H25 8. Push in the "E" stop. Filter Element (E) 061-H25A 9. **Assume** that there is still Filter Cannister/Body (C) 061-H25B pressure in the Pressure Line. 061-H25RC Weather Cap (RB) Proceed with caution. Hydraulic Filter Filter Seal Kit (S) 061-H25SK **Hydraulic Filter** 1. **Remove** the Filter **Cannister** (C). 2. **Remove** the Filter **Element** (E). 3. **Insert** the new Filter **Element**. 4. **Replace** the Filter **Cannister** (C).

# Filter Maintenance

### **Change Every 2 Months**

Initial Steps

- 1. **Disconnect** the **Air power** supply.
- 2. Bleed Air Pressure.

### **Air Filters**

- 1. **Remove** the two right **Corner bolts** (CB).
- 2. Slide out the Second stage filter cartridge (SC) and Star spacers (S).
- 3. Slide out the First stage filter cartridge (FC) and Star spacers (S).
- 4. Slide in the new First stage filter cartridge and Star spacers (S).
- 5. Slide in the new Second stage filter cartridge and Star spacers (S).
- 6. **Replace** the two right **Corner Bolts** (CB).

Part Numbers		
Part N	Jame	Part #
In-lin	e Air Filter (not shown)	061-J29
Float	Drain (D)	061-J29A
Filter Cartridge Kit (FC&SC) 061-J29B/C		
Gaske	et (G)	061-J29D
Base	Core (C)	061-J29E
Corne	er Bolt Kit (CB)	061-J29F



### <u>WARNING</u>

Running the HawkJaw without Hawk approved air filters (Part # 061-J29, 061-A22) voids the warranty and shortens component life.

## Changing the Hook Dies

### Tools Required

В

3/4" wrench, See Drawings.

#### **Initial Steps**

- 1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.
- 2. Shut down the Hydraulic power unit.
- 3. **Press** the **Grip button repeatedly** to bleed hydraulic pressure.
- 4. **Disconnect** the **Air** power supply.
- 5. Push in the "E" stop.
- 6. **Assume** that there is still a **load** on every actuator. Proceed with caution.

#### Hook Dies

- Use the 3/4" wrench to remove the Die Holder Bolts (B).
   Remove the Die Retainer (DR).
- 2. Slide out the worn Die (D).
- 3. Make sure the **back** and **sides** of the **new Die** are **clean**.
- 4. Grease the back of the new Die.
- 5. **Insert** the **new Die** into the Die Holder (DH) with the **teeth** of the Die **facing out**.
- 6. Replace the Die Retainer (DR). Use the 3/4" wrench to replace the Die Holder Bolts (B) and Lock Washers.



DR DH \

D



### Part Numbers

Part Name	Part #
Die (D)	061-20194
Die Holder Bolt (B)	999-806245
Spirol Lock Washer	999-810703
Die Holder (DH)	061-20192B
### Tools Required

3/4" wrench, See Drawings.

## Initial Steps

- 1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.
- 2. Shut down the Hydraulic power unit.
- 3. **Press** the **Grip button repeatedly** to bleed hydraulic pressure.
- 4. **Disconnect** the **Air** power supply.
- 5. Push in the "E" stop.
- 6. **Assume** that there is still a **load** on every actuator. Proceed with caution.

### **Top Wrench Heel Die**

- Use the 3/4" wrench to remove the Heel Die Roller Bolts (B) on the top of the Die Rollers (R).
- 2. **Remove** the **Roller Bushings** (RB).
- 3. **Remove** the **Heel Die Rollers** (R).
- 4. **Pull** out the **Heel Die Pin** (P).
- 5. **Remove** the Top **Die Retainer** (DR).
- 6. Slide out the worn Die (D).

Continued on next page.







DH

& Repair

- 7. Make sure the back and sides of the new Die are clean.
- 8. Grease the back of the new Die.
- 9. **Insert** the **new Die** into the Die Holder (DH) with the **teeth** of the Die **facing out**.
- 10. **Replace** the Top **Die Retainer** (DR).
- 11. Insert the Heel Die Pin (P).
- 12. **Replace** the **Heel Die Rollers** (R).
- 13. **Replace** the **Roller Bushings** (RB).
- 14. Use the 3/4" wrench to **replace** the **Heel Die Roller Bolts** (B) and Lock Washers.

RB	В	Р	
	R	5	A
			TA
R	ĎН	]	DR

Part Numbers		bers
Part	Name	Part #
Spire	ol Lock Washer	999-810703
Die I	Roller Bolt (B)	999-806307
Die	Roller (R)	061-20210
Die I	Roller Bushing (RB)	061-20208A
Die	(D)	061-20194
Die I	Holder (DH)	061-20192-1A
Heel	Die Pin (P)	061-92384A092

### **Initial Steps**

- 1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.
- 2. Shut down the Hydraulic power unit.
- 3. **Press** the **Grip button repeatedly** to bleed hydraulic pressure.
- 4. **Disconnect** the **Air** power supply.
- 5. Push in the "E" stop.
- 6. **Assume** that there is still a **load** on every actuator. Proceed with caution.



- 1. Use the 3/4" wrench to **remove** the **Heel Die Roller Bolts** (B).
- 2. **Pull** out the **Heel Die Pin** (P).
- 3. **Remove** the Top **Die Retainer** (DR).
- 4. Slide out the worn Die (D).
- 5. Make sure the **back** and **sides** of the **new Die** are **clean**.
- 6. Grease the back of the new Die.
- Insert the new Die into the Die Holder (DH) with the teeth of the Die facing out.

Continued on next page.



DR

DH

D



faintenance & Repair

- 8. **Replace** the Top **Die Retainer** (DR).
- 9. Insert the Heel Die Pin (P).
- 10. Use the 3/4" wrench to **replace** the **Heel Die Roller Bolt** (B) and Lock Washers.



DR

Part Numbers	
Part Name	<u>Part #</u>
Spirol Lock Washer	999-810703
Die Roller Bolt (B)	999-806307
Die Roller (R)	061-20210
Die Roller Bushing (RB)	061-20208A
Die (D)	061-20194
Die Holder (DH)	061-20192-1A
Heel Die Pin (P)	061-92384A092

### Tools Required

3/4" wrench, See Drawings.

### Initial Steps

- 1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.
- 2. Shut down the Hydraulic power unit.
- 3. **Press** the **Grip button repeatedly** to bleed hydraulic pressure.
- 4. **Disconnect** the **Air** power supply.
- 5. Push in the "E" stop.
- 6. **Assume** that there is still a **load** on every actuator. Proceed with caution.

#### **Bottom Wrench Heel Die**

- 1. Use the 3/4" wrench to **remove** the **Heel Die Bolts** (B).
- 2. **Pull** out the **Heel Die Pin** (P).
- 3. **Remove** the Top **Die Retainer** (DR).
- 4. Slide out the worn Die (D).
- 5. Make sure the **back** and **sides** of the **new Die** are **clean**.

Continued on next page.



D

B

- 6. Grease the back of the new Die.
- 7. **Insert** the **new Die** into the Die Holder (DH) with the **teeth** of the Die facing out.
- 8. Replace the Top Die Retainer (DR).
- 9. Insert the Heel Die Pin (P).
- 10. Use the 3/4" wrench to **replace** the Heel Die Bolts (B) and Lock Washers.

Part Numbers



DR

Р

D

<u>Part Name</u>	<u>Part #</u>
Lock Washers	999-810703
Die Roller Bolt (B)	999-806245
Die Roller (R)	061-20210
Die (D)	061-20194
Die Holder (DH)	061-20192-1A
Heel Die Pin (P)	061-92384A092

#### Notice

Spinner chain lubrication must be done during normal operation of the Hawkjaw. Do not run the spinner when the Hawkjaw is not on the pipe.

### **Initial Steps**

1. Position the **Hawkjaw** for breakout.

### **Chain Lubrication**

- Pull the Hawkjaw onto the pipe. 1.
- 2. Press in the Grip Hold (GH) button.
- **3.** Press and hold the Spin (S) button. While holding down the Spin (S) button, press and hold the Chain Oiler (CO) button for 3 seconds.
- 4. Release the Spin (S) button.
- 5. Pull out the Grip Hold (GH) button.

**CAUTION:** This chain oiling system uses minimal amount of hydraulic oil from power unit - we suggest you monitor hydraulic oil level accordingly.





GH





Chain oiler nozzle NOTE: Clean nozzle screen as required

**Grease Once per Month** 

Tools Required

Grease gun, 7/16" wrench

### **Initial Steps**

- 1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.
- 2. Shut down the Hydraulic power unit.
- 3. **Press** the **Grip button** repeatedly.
- 4. **Disconnect** the **Air power** supply.
- 5. Push in the "E" stop.
- 6. **Assume** that there is still a **load** on every actuator. Proceed with caution.

### Drive Roller Sprocket Bear-

- Use the 7/16" wrench to remove one of the four small screws (S) from the top of each bearing cap (BC).
- 2. **Pump** the **grease fittings** G1-G4 until grease comes out of the small screw hole.
- 3. Use the 7/16" wrench to **replace** the **small screw** (S).







Part Numbers	
Part Name	Part #
Bearing Cap Screw (S)	999-805834
Straight Grease Fitting	061-1103K1

Grease Once per Month

Tools Required

Grease gun

## Spinner Grip Cylinders

1. Pump grease fittings SC1-SC4.

Chain Drive Shaft Bearing

1. Pump grease fitting CB1.



SC3

SC4



CB1

**Grease Once per Month** 

Tools Required

Grease gun

**Spinner Mount Sliding Tube** 

1. Pump grease fittings ST1-ST4.

Spinner Mount Sliding Block

1. Pump grease fittings SB1.

### <u>NOTE</u>

Consistent lubrication of the Spinner sliding tube and block increases performance and component life.



ST3

ST4



SB1

## **Check Oil Level Once per Month**

Lubricant Required

85-90 weight gear oil SAE #AGMA5

## **Reducer Gear Box**

1. Make sure the gear box **oil level** reaches the **top pipe plug** (RP).

## Winch Gear Box

1. Make sure the gear box **oil level** reaches the **top pipe plug** (WP).

#### <u>NOTE</u>

Consistent lubrication of the Spinner and Winch increases performance and component life.







# Changing the Spinner Chain

### Tools Required

7/8" wrench, 7/16" wrench, Hammer, Needle-Nose Pliers

### **Initial Steps**

- Make sure the HawkJaw is off the drill pipe connection and in the rest position on the derrick.
- 2. Shut down the Hydraulic power unit.
- 3. **Press** the **Grip button repeatedly** to bleed hydraulic pressure.
- 4. **Disconnect** the **Air** power supply.
- 5. Push in the **"E" stop** (E).
- 6. **Assume** that there is still a **load** on every actuator. Proceed with caution.

#### Chain

- 1. Make sure the **Spinner doors** (SD) are **open**.
- 2. Use the 7/8" wrench to **loosen** the **Spacer Bolts** (B).
- Use the 7/16" wrench to remove the four rubber Safety shield bolts (SB).
- 4. **Remove** the rubber Safety **shield** (SS).
- 5. Remove the Spacer Bolts (B) and Spacers (S).

Continued on next page.





SB

SS

48 Maintenance & Repair

SD

# Changing the Spinner Chain

- From the front of the unit, use the Needle-nose pliers to remove the Cotter pins (CP) in one of the Chain links.
- 7. Use the hammer to **remove** the **Chain link pin** (CLP).
- 8. **Pull out** the **old chain**. Make sure the chain does not catch on the Drive Sprocket (DS).
- 9. Feed the chain into the spinner behind the Drive Sprocket (DS) until both ends of the new chain meet at the Drive roller sprockets (DRS).
- 10. Feed the ends of the chain around the outside of the Drive roller sprockets (DRS).
- 11. Place the ends of the new chain together.
- 12. Insert the Master Link.
- 13. Place the End Cap on the Master Link.
- Use the Needle-nose pliers to insert the Master Link Cotter Pins.

#### Part Numbers

Part Name

<u>Part #</u>

Chain031-25CHAINChain Repair Kit031-24CHAIN-RK









<u>WARNING</u>

Running a new chain with worn Drive Rollers severely shortens chain life. If the Drive Roller Groove is no longer visible, replace the Drive Roller. Maintenance & Repair

# Changing the Drive Rollers

### Tools Required

3/4" wrench

### Initial Steps

- 1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.
- 2. Shut down the Hydraulic power unit.
- 3. **Press** the **Grip button repeatedly** to bleed hydraulic pressure.
- 4. **Disconnect** the **Air** power supply.
- Press the Grip button repeatedly to bleed hydraulic pressure.
- 6. Push in the **"E" stop** (E).
- 7. **Assume** that there is still a **load** on every actuator. Proceed with caution.

## **Drive Rollers**

 Make sure the Drive Roller Groove is no longer visible on the Drive Rollers (DR).

Continued on next page.





## Changing the Drive Rollers

- Use the 3/4" wrench to remove all Bearing Cap Bolts (9).
- 3. Remove the Bearing Caps (2) and Bearing Seals (3).
- 4. Slide out the Drive Roller Sprockets (4).
- 5. **Remove** the Drive Roller **Snap Rings** (7).
- 6. Remove the Drive Rollers (5) and Keys (6).
- 7. Slide on the new Drive Rollers and replace the Keys (6).
- 8. **Replace** the Drive Roller **Snap Rings** (7).
- 9. Slide in the Drive Roller Sprockets (4). Make sure the "T" on each Drive Roller Sprocket faces up.
- 10. **Replace** the Bearing **Caps** (2) and Bearing Seals (3).
- 11. Use the 3/4" wrench to replace all Bearing Cap Bolts (9). Use new Lock Washers (12) and red loctite when replacing the Bearing Cap Bolts (9).
  Assemble the Lock Washers (12) as shown. Torque Bearing Cap Bolts (9) to 75 lb. ft.





#### **WARNING**

Replace all four Drive Rollers. Running the Spinner with worn Drive Rollers will damage the chain and hinder Spinner performance.

# Changing the Drive Roller Sprocket Bearings

### Tools Required

Four 1/4"-20 x 1 1/2" Hex Tap SS (Part # 999-805867), 7/16" wrench, 3/4" wrench

#### Initial Steps

- 1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.
- 2. Shut down the Hydraulic power unit.
- 3. **Press** the **Grip button repeatedly** to bleed hydraulic pressure.
- 4. **Disconnect** the **Air** power supply.
- 5. Push in the "E" stop (E).
- 6. **Assume** that there is still a **load** on every actuator. Proceed with caution.

#### **Drive Roller Sprocket Bear-**

- Use the 3/4" wrench to remove all Bearing Cap Bolts (9).
- 2. **Remove** the Bearing **Caps** (2) and Bearing Seals (3).
- 3. Use the 7/16" wrench to remove the four small screws in the top of the Bearing Caps (2).

Continued on next page.



# Changing the Drive Roller Sprocket Bearings

- 4. Use the 7/16" wrench to screw in the Hex Tap screws into the four small threaded holes in the top of the Bearing Caps (2). As the screws tighten, the bearing (8) is pushed out. Tighten the Hex Tap screws evenly, or the bearing (8) will tilt and lodge in the bearing cap (2).
- 5. **Insert** the **new bearings** into the Bearing Caps (2).
- 6. **Replace** the Bearing **Caps** (2) and Bearing Seals (3).
- 7. Use the 3/4" wrench to replace all Bearing Cap Bolts (9). Use new Lock Washers (12) and Red Loctite when replacing the Bearing Cap Bolts (9). Assemble the Lock Washers (12) as shown. Torque Bearing Cap Bolts (9) to 75 lb. ft.

#### <u>NOTE</u>

Hawk recommends that all four bearings (8) be replaced each time a bearing (8) is changed. Always use new lock washers (12) when replacing bearing cap bolts (9).

#### <u>NOTE</u>

Hawk recommends that all four bearing seals (3) be replaced each time a bearing (8) is changed.



#### **Initial Steps**

1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.

## **Torque Cylinder**

- 1. Press Grip Hold (GH).
- 2. Press and hold **Grip** (G)
- While holding down Grip (G), press and hold down Torque (T) until the Torque Cylinder Rod Pin (P) extends out from underneath the Reset Cam (RC).
- Release both Torque (T) and Grip (G), and immediately push in the "E" stop (E). The Torque Cylinder (C) will freeze and remain partially extended.
- Shut down the Hydraulic power unit. Press the Grip button repeatedly to bleed hydraulic pressure. Proceed with caution. Make sure no bodily parts are in the extension path of the cylinder bore.

Continued on next page.







С

- 6. Use the 1 1/8" wrench to **slowly** loosen the Cap side Hoses (CH1), (CH2). Check for fluid flow. Bleed any pressure. **Disconnect** the Cap side Hoses (CH1), (CH2).
- 7. Use the 1" wrench to **slowly** loosen the Rod side Hose (RH). Check for fluid flow. Bleed any pressure. Disconnect the Rod side Hose (RH).
- 8. **Pull** out the Torque Cylinder Safety Clip (SC).
- 9. Use the Torque Cylinder Safety Clip (SC) to pull out the Torque Cylinder Rod Pin (P).
- 10. Disconnect the Low Torque Warning System Hydraulic Hoses (HH & HH1).
- 11. Use the 1 1/8" wrench and 5/8" Allen wrench to **remove** the **Top Torque Cylinder Mount Bolts** (TBH), (TBA).
- 12. Use the 1 1/8" wrench to **remove** all Four **Bottom Torque** Cylinder Mount Bolts (BB).
- 13. Slide out the Torque Cylinder (C).
- 14. **Remove** the **Bottom** Trunion Mount **Plate** (BMP) and the **Top** Trunion Mount Plate (TMP).

Continued on next page.





HH1



- 15. Use air pressure or manual force to extend the new Torque Cylinder Rod to the length of the old Torque Cylinder Rod.
- 16. Place the Bottom Trunion MountPlate (BMP) and Top TrunionMount Plate (TMP) on the newTorque Cylinder.
- 17. Slide in the new Torque Cylinder.
- 18. Use the 1 1/8" wrench to replace the Bottom Torque Cylinder Mount Bolts (BB). Use new Lock Washers and red loctite when replacing the Bottom Torque Cylinder Mount Bolts (BB). Assemble the Lock Washers as shown.
- 19. Use the 1 1/8" wrench and 5/8" Allen wrench to replace the Top Torque Cylinder Mount Bolts (TBH), (TBA). Use new Lock Washers and red loctite when replacing the Top Torque Cylinder Mount Bolts (TBH), (TBA). Assemble the Lock Washers as shown.
- 20. Connect the **Low** Torque Warning System **Hydraulic Hoses** (HH &HH1).



HH1







- 21. Use the 1" and 1 1/8" wrench to connect the Rod side Hose (RH) and the Cap side Hoses (CH1), (CH2).
- 22. Insert the Torque Cylinder Rod Pin (P).
- 23. Insert the Torque Cylinder Safety Clip (SC).
- 24. Make sure no bodily parts are in the retract path of the Torque Cylinder. Turn on the hydraulic power unit. Pull out the "E" stop. The Middle wrench will retract.



Part Numbers		ers
Part	Name	Part #
Mou	nt Bolt (TBH)	999-806542-1
Mou	nt Bolt (TBA)	999-806542
Mou	nt Bolt (BB)	999-806529
Lock	Washers	061- 91074A036
Safet	ty Clip (SC)	061- 98335A114
Torq	ue Cylinder Rod Pin (P)	061-20204
Torq	ue Cylinder (C)	061-H17
Torq Torq	ue Cylinder Rod Pin (P) ue Cylinder (C)	061-20204 061-H17

#### <u>WARNING</u>

Make sure the Torque Cylinder Rod and Cap side Hoses are properly connected.

#### **WARNING**

Make sure the Low Torque Warning System Hydraulic Hoses are securely connected.



Maintenance & Repair

### Tools Required

Two 11/16" wrenches, Two 1 1/2" wrenches

#### **Initial Steps**

- 1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.
- 2. Shut down the Hydraulic power unit.
- 3. **Press** the **Grip button repeatedly** to bleed hydraulic pressure.
- 4. **Disconnect** the **Air** power supply.
- 5. Push in the "E" stop (E).
- 6. **Assume** that there is still a **load** on every actuator. Proceed with caution.

## **Top Grip Cylinder**

- Use the Two 11/16" wrenches to slowly loosen the Rod side Hose (RH). Check for fluid flow.
   Bleed any pressure. Disconnect the Rod side Hose (RH).
- 2. Use the Two 11/16" wrenches to slowly loosen the Cap side Hose (CH). Check for fluid flow.
  Bleed any pressure. Disconnect the Cap side Hose (CH).

Continued on next page.



СН

RH



- Use the Two 1 1/2" wrenches to remove the Grip Cylinder Cap side Bolt (CB) and Flex Lock Nut.
- 4. Use the 1 1/2" wrench to remove the Grip Cylinder Rod side Pin (RP).
- 5. Slide out the Grip Cylinder (C).
- 6. Place the new Grip Cylinder into the Cap side Eye (CE) and Rod side Eye (RE).
- Use the Two 1 1/2" wrenches to replace the Grip Cylinder Cap side Bolt (CB) and Flex Lock Nut.
- 8. **Replace** the Grip Cylinder **Rod** side **Bolt** (RB). Assemble with cotter pin.
- 9. Use the Two 11/16" wrenches to **connect** the **Cap** side **Hose** (CH).
- 10. Use the Two 11/16" wrenches to **connect** the **Rod** side **Hose** (RH).

Part Numbers		bers	
Part 1	Name	Part #	
Grip	Cylinder Cap Bolt (CB)	999-806628	
Flex	Lock Nut	999-806594-500	
Grip	Cylinder Rod Bolt (RB)	061-20270	
Cotte	er Pin	061-98401A446	
Lock	Washers	061-91074A038	
Grip	Cylinder (C)	061-H18	



#### **WARNING**

Make sure the Grip Cylinder Rod and Cap side Hoses are properly connected. See Drawings.

### Tools Required

Two 11/16" wrenches, Two 1 1/2" wrenches

### **Initial Steps**

- 1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.
- 2. Follow Steps 1-4 on p. 52.

## Middle Grip Cylinder

- Use the Two 11/16" wrenches to slowly loosen the Rod side Hose (RH). Check for fluid flow.
   Bleed any pressure. Disconnect the Rod side Hose (RH).
- Use the Two 11/16" wrenches to slowly loosen the Cap side Hose (CH). Check for fluid flow.
   Bleed any pressure. Disconnect the Cap side Hose (CH).
- Use the Two 1 1/2" wrenches to remove the Grip Cylinder Cap side Bolt (CB) and Lock Washers.
- 4. Use the 1 1/2" wrench to remove the Grip Cylinder Rod side Bolt (RB) and Lock Washers.
- 5. Slide out the Grip Cylinder (C).





CH RH

- Place the new Grip Cylinder into the Cap side Eye (CE) and Rod side Eye (RE).
- Use the Two 1 1/2" wrenches to replace the Grip Cylinder Cap side Bolt (CB).
- 8. **Replace** the Grip Cylinder **Rod** side **Bolt** (RB). Assemble with cotter pin.
- Use the Two 11/16" wrenches to connect the Cap side Hose (CH).
- 10. Use the Two 11/16" wrenches to connect the Rod side Hose (RH).
- 11. Make sure no bodily parts are
  in the retract path of the Torque
  Cylinder. Turn on the
  hydraulic power unit. Pull out
  the "E" stop. The Middle
  wrench will retract.





Part Numbers

Part Name

<u>Part #</u>

Grip Cylinder Cap Bolt (CB) Lock Washers Grip Cylinder Rod Bolt (RB) Cotter Pin Grip Cylinder (C) 999-806627 061-91074A038 061-20270 061-98401A446 061-H18S

**Grip Cylinder Seals** 

#### **WARNING**

Make sure the Grip Cylinder Rod and Cap side Hoses are properly connected. See Drawings.

#### **Initial Steps**

- 1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.
- 2. Shut down the Hydraulic power unit.
- 3. **Press** the **Grip button repeatedly** to bleed hydraulic pressure.
- 4. **Disconnect** the **Air** power supply.
- 5. Push in the "E" stop (E).
- 6. **Assume** that there is still a **load** on every actuator. Proceed with caution.



### Bottom Grip Cylinder

- Use the Two 11/16" wrenches to slowly loosen the Rod side Hose (RH). Check for fluid flow.
   Bleed any pressure. Disconnect the Rod side Hose (RH).
- 2. Use the Two 11/16" wrenches to slowly loosen the Cap side Hose (CH). Check for fluid flow.
  Bleed any pressure. Disconnect the Cap side Hose (CH).



СН

ŔН

- Use the Two 1 1/2" wrenches to remove the Grip Cylinder Cap side Bolt (CB) and Flex Lock Nut.
- 4. Use the 1 1/2" wrench to remove the Grip Cylinder Rod side Bolt (RB).
- 5. Slide out the Grip Cylinder (C).
- 6. Place the new Grip Cylinder into the Cap side Eye (CE) and Rod side Eye (RE).
- Use the Two 1 1/2" wrenches to replace the Grip Cylinder Cap side Bolt (CB) and Flex Lock Nut.
- 8. **Replace** the Grip Cylinder **Rod** side **Bolt** (RB).
- Use the Two 11/16" wrenches to connect the Cap side Hose (CH).
- 10. Use the Two 11/16" wrenches to **connect** the **Rod** side **Hose**

(RH).

Part Numbers		
Part Name	Part #	
Grip Cylinder Cap Bolt (CB)	999-806628	
Flex Lock Nut	999-806594-500	
Grip Cylinder Rod Bolt (RB)	061-20270	
Lock Washers	061-91074A038	
Grip Cylinder (C)	061-H18S	

### **Grip Cylinder Seals**



#### **WARNING**

Make sure the Grip Cylinder Rod and Cap side Hoses are properly connected. See Drawings.

# Main Hydraulic Block Fitting and Hose Access

### **Initial Steps**

- Make sure the HawkJaw is off the drill pipe connection and in the rest position on the derrick.
- Use Raise (R) to raise the HawkJaw 6"-12" inches off the derrick floor.
- 3. Shut down the Hydraulic power unit.
- 4. **Press** the **Grip button repeatedly** to bleed hydraulic pressure.
- 5. **Disconnect** the **Air** power supply.
- 6. Push in the "E" stop (E).
- 7. **Assume** that there is still a **load** on every actuator. Proceed with caution.

### Main Block Fittings and Hoses

- Use the 7/8" wrench to remove the Main Block Housing Retainer Bolt (B) and Lock Washers on each side of the Main Block Housing (H).
- Tilt the Main Block Housing (H) back to expose the main block fittings and hoses.











# Main Hydraulic Block Fitting and Hose Access

### **Initial Steps**

- Make sure the HawkJaw is off the drill pipe connection and in the rest position on the derrick.
- Use Raise (R) to raise the HawkJaw 3"-5" inches off the derrick floor.
- 3. Shut down the Hydraulic power unit.
- 4. **Press** the **Grip button repeatedly** to bleed hydraulic pressure.
- 5. **Disconnect** the **Air** power supply.
- 6. Push in the "E" stop (E).
- 7. **Assume** that there is still a **load** on every actuator. Proceed with caution.

### Air Logic System and Main Block

- Use the 7/8" wrench to remove the Main Block Housing Cover Plate Bolts (B) on each side.
- 2. **Remove** the Main Block Housing **Cover Plate** (CP) to expose the **Main Manifold** (M).







/aintenance & Repair

# Spinner Motor Sequence Valve Access

### **Tools Required**

3/4" wrench, 3/16" Allen wrench

### **Initial Steps**

- 1. Make sure the HawkJaw is off the drill pipe connection and in the **rest position** on the derrick.
- 2. Shut down the Hydraulic power unit.
- 3. Press the Grip button **repeatedly** to bleed hydraulic pressure.
- 4. **Disconnect** the **Air** power supply.
- 5. Push in the "E" stop (E).
- 6. Assume that there is still a load on every actuator. Proceed with caution.

### **Spinner Motor Sequence** Valve

- 1. Use the 3/4" wrench to **remove** the Sequence Valve Cover Bolts (B) and Cover (C).
- 2. The Sequence Valve is located within the Sequence Valve Rubber Sleeve (S).

## Changing All Other HawkJaw Parts





В



Problem	Remedy
Hose leaks.	• <b>Replace</b> the <b>hose</b> . See Drawings.
All Grip cylinders extend, and the Torque cylinder extends.	• The <b>Pressure</b> and <b>Tank</b> lines are <b>switched</b> . Properly <b>connect</b> the Pressure and Tank <b>lines</b> . See Operation.
One or more Grip cylinders extend.	• Make sure the hydraulic power unit is shut down. Press the Grip button repeatedly to bleed hydraulic pressure. Properly connect the Rod side and Cap side hoses to the Grip cylinder. See Maintenance & Repair & Drawings.
Dies do not grip pipe across from each other.	• Adjust the wrenches and the pipe stop index to the <b>OD</b> tool joint size. See Operation.
Dies slide on the drill pipe during make up or break out.	<ul> <li>Adjust the pipe stop index and the wrenches to the OD tool joint size. See Operation.</li> <li>If the dies still slip on the pipe while torquing, the throat of the hook could be contacting the body of the pipe (this can occur especially running tool joints larger than 7"). This problem can be solved by gripping the Hawkjaw on the pipe and looking to see if the throat of the hook is contacting the pipe body. If the hook is contacting the pipe body while gripping (not torquing), then the wrench adjust nut needs to be adjusted slightly smaller to get hook throat stand-off.</li> <li>The dies are worn out. Replace the dies. See Maintenance &amp; Repair.</li> <li>There is a Grip cylinder piston leak. See Trouble Shooting.</li> </ul>
While performing up to par, the Spinner clamps on the drill pipe tube, but the drill pipe does not spin.	<ul> <li>For break out, if the drill pipe connection is not broken, the spinner is unable to spin the drill pipe.</li> <li>Break out the connection, and spin again. See</li> </ul>

Operation.

Problem	Remedy
Spinner pops off the drill pipe tube when the	• The spinner is adjusted too small for the drill pipe
spinner rotates the pipe.	tube. Adjust the spinner to the correct pipe size. See Operation.
Spinner Drive Rollers touch when the spinner	• Adjust the spinner to the next smaller pipe size.
clamps onto the drill pipe tube.	See Operation. If the Drive Rollers still touch, the
	chain is severely stretched. Replace the chain. See
	Maintenance & Repair.
Spinner does not slide forward on the spin	• Grease the spinner mount sliding block first and check
mount block or does slide forward and closes	if symtom continues. See Maintenance & Repair, p.
prematurely and bangs on pipe body while	47. If symtom continues, Adjust the Spinner push
closing.	cylinder valve (Spin Block port V1) slightly clock-
	wise .
Spinner chain hinders the correct alignment of	• The spinner is adjusted too small for the drill pipe.
the HawkJaw on the pipe.	Adjust the spinner to the correct pipe size. See
	Operation.
Spinner clamps on the pipe and forces the	• Use an allen wrench to <b>tighten</b> the <b>Spinner Push</b>
HawkJaw back away from the pipe.	cylinder pressure reducing valve adjustment
	counter-clockwise until the spinner does not force the
	HawkJaw away from the pipe. While holding the
	pressure reducing valve adjustment steady with an
	allen wrench, lock in the adjustment by
	tightening the valve lock nut. The pressure
	reducing valve is located at Port V1 on the Spinner
	hydraulic <b>block</b> . See Drawings.
The spinner doors do not begin to close as the	• Use an allen wrench to <b>rotate</b> the <b>Spinner Door</b>
spinner moves onto the pipe.	sequence valve adjustment counter-clockwise until
	the spinner doors begin to close as the HawkJaw
	moves onto the pipe. While holding the sequence
	valve <b>adjustment steady</b> with an allen wrench, <b>lock</b>
	in the adjustment by tightening the differential valve
	lock nut. The Spinner door sequence valve is located
	at <b>Port V2</b> on the <b>Spinner</b> hydraulic <b>block</b> . See
	Drawings.
Spinner begins to spin before the spinner doors	• Use an allen wrench to <b>rotate</b> the <b>Spinner motor</b>
close on the drill pipe tube.	sequence valve adjustment clockwise until the doors
	close before the spinner begins to spin. While hold-
	ing the sequence valve adjustment steady with an
	allen wrench, lock in the adjustment by

tightening the differential valve lock nut. The

Problem	Remedy
Spinner begins to spin before the spinner doors close on the drill pipe tube. (Cont.)	<ul> <li>Spinner motor sequence valve is located at Port MSEQ on the main hydraulic block. See Mainte- nance &amp; Repair, Drawings.</li> </ul>
Spinner moves forward and the doors close on the pipe, but the spinner does not spin.	• Use an allen wrench to rotate the Spinner motor sequence valve adjustment counter-clockwise until the doors close and the spinner begins to spin. While holding the sequence valve adjustment steady with an allen wrench, lock in the adjustment by tightening the differential valve lock nut. The Spinner motor sequence valve is located at Port MSEQ on the main hydraulic block. See Maintenance & Repair, Drawings.
Spinner retracts from the pipe and forces the HawkJaw back away from the pipe.	<ul> <li>Use an allen wrench to rotate the Spinner retract needle valve adjustment counter-clockwise until the spinner gradually opens as the spinner backs off the pipe. While holding the needle valve adjustment steady with an allen wrench, lock in the adjustment by tightening the valve lock nut. The Spinner retract needle valve is located at Port V9 on the Spinner hydraulic block. See Drawings.</li> </ul>
Spinner chain slips on the drill pipe tube.	<ul> <li>The spinner is adjusted too large for the drill pipe tube. Adjust the spinner to the correct pipe size. See Operation.</li> <li>The spinner chain is worn out. Replace the spinner chain. See Maintenance &amp; Repair.</li> </ul>
Spinner chain wears out prematurely.	<ul> <li>Lubricate the spinner chain. See Maintenance &amp; Repair.</li> <li>Running the spinner with worn Drive rollers severely shortens chain life. If the Drive Roller Groove is no longer visible, replace the Drive rollers. See Maintenance &amp; Repair. Inspect the chain. Replace the chain if the links are worn flat. See Maintenance &amp; Repair.</li> </ul>
Drill pipe does not rotate down to the shoulder, or Spinner performance and speed not up to par.	• The spinner push cylinder is not stroke out far enough to contact drill pipe with correct allignment. See Adjusting Spinner.

Problem		Remedy	
ProblemSpinnerDrill pipe does not rotate downPerformanceto the shoulder, or Spinner performance and speed not up to par. (cont.)•The filter element is clogged. Replace the filter element. See Maintenance & Repair.•The air pressure is low. Increase the air pressure to the HawkJaw. See Installation.•Check to make sure the hydraulic power unit is producing 2500 psi at 20-35 gpm.•Check to make sure the hydraulic power unitunitpressure compensator setting is at 2500 psi.•Check that the drill pipe connections are within API tolerance.•The Drive Roller Sprocket Bearings are worn out. Replace the Drive Roller Sprocket Bearings. See Maintenance & Repair.HawkJawHawkJaw performance and Performance	<ul> <li>On long drill pipe tool joints of 10" or more it may be neccessary to remove the top wrench heel die when breaking out drill pipe or the bottom wrench heel die holder win making up drill pipe. To do this first remove the quick release pin and slide out die. Make sure to grease the die holder when replacing.</li> <li>The Drive Rollers are worn out. If the Drive Roller Groove is no longer visible, replace the Drive Rollers. See Maintenance &amp; Repair.</li> <li>The Bottom Drive Shaft Flange Bearing is worn out. Replace the Flange Bearing. See Drawings.</li> <li>The Reducer is worn out. If properly lubricated, the reducer is a long term wear item. If all other rotating members on the spinner work, inspect the gears and bearings in the reducer for wear. Replace where necessary. See Drawings.</li> <li>The Drive motor is a long term wear item. If all other rotating members on the spinner work, inspect the rotating group, bearings and seals for wear. Replace where necessary. See Drawings.</li> </ul>		
HawkJaw Performance	HawkJaw performance and speed not up to par.	• Check that the hydraulic filter element is not completely full of contaminants. If the red indicator button on the hydraulic filter body pops up, change the filter element. See Filter Maintenance.	
		• Check the lead-in pressure and tank lines for any obstructions. Also check the quick disconnects	

Problem	Remedy
HawkJaw performance and speed not	• to see that they are <b>securely tightened</b> . A bad quick
up to par.	disconnect can cause the Hawkjaw to mal-function.
	Replace the faulty connector.
	• The air pressure is low. Increase the air pressure to
	the HawkJaw. See Installation.
	• Check to make sure the hydraulic power unit is
	producing 2500 psi at 20-35 gpm.
	• Check to <b>make sure</b> the hydraulic power unit
	pressure compensator setting is at 2500 psi.
	• There is a leak in the hydraulic system. Check for
	any visual leaks in the hoses, fittings, manifolds,
	cylinder rod heads, or cylinder rod wiper seals. Re-
	place necessary components. See Drawings.
	• There is a leak in the hydraulic system. Operate the
	HawkJaw. Feel the outside of all actuators. If a
	portion of the cylinder surface is too hot to leave
	your hand on the cylinder, the leak is inside the
	cylinder. Replace the cylinder seals. If necessary,
	replace the cylinder. For a Grip cylinder, see
	Maintenance & Repair. For a Spinner grip cylinder,
	see Drawings. For the Torque cylinder, see Mainte-
	nance & Repair. For the Raise/Lower Cylinder, see
	Drawings.
	• There is a leak in the hydraulic system. Disconnect
	the air supply hose to the HawkJaw. Make sure the
	hydraulic power unit is on. Check for Grip cylinder
	piston seal integrity. Make sure no bodily parts are
	in the extension path of the cylinder rod. Begin
	with the Top Grip cylinder. Slowly loosen the Cap
	side hose. Check for fluid flow. If there is a piston
	seal leak, fluid will flow with volume out of the Cap
	side fitting. <b>Replace</b> the seals. See Drawings. Re-
	place the cylinder if necessary. See Maintenance &
	Repair. Repeat for the Middle Grip cylinder. See
	Drawings. Replace the cylinder if necessary. See
	Maintenance & Repair. Repeat for the <b>Bottom Grip</b>
	cylinder. See Drawings. Replace the cylinder if
	necessary. See Maintenance & Repair.

Problem	Remedy
HawkJaw performance and speed not up to	• There is a <b>leak</b> in the <b>hydraulic system</b> . Make sure
par.	the air supply hose to the HawkJaw is discon-
	nected. Make sure the hydraulic power unit is on.
	Check for Torque cylinder piston seal integrity.
	Make sure no bodily parts are in the extension
	path of the cylinder rod. Slowly loosen the Cap
	side hose. Check for fluid flow. If there is a piston
	seal leak, fluid will flow with volume out of the Cap
	side hydraulic fitting. Replace the seals. See Draw-
	ings. Replace the cylinder if necessary. See Mainte-
	nance & Repair.
	• There is a <b>leak</b> in the <b>hydraulic system</b> . Make sure
	the air supply hose to the HawkJaw is
	disconnected. Make sure the hydraulic power unit is
	on. Make sure no bodily parts are in the exten-
	sion path of the cylinder rod. Check for Spinner
	grip cylinder cap side seal integrity. Slowly loosen
	the Spin Block Port SR fitting . Check for fluid flow.
	If there is a piston seal leak, fluid will flow with
	volume out of the fitting. Replace the seals if neces-
	sary. See Drawings. Replace the cylinder if neces-
	sary. See Drawings.
While in make-up mode, a desired torque	• The Hawkjaw may have an obstructed tank lead-in
setting cannot be achieved or the torque	hose or quick disconnect. Check the pressure at the
control valve will not effect the torque output	tank out-put port on the Hawkjaw main hydraulic
of the Hawkjaw.	manifold. Pressure readings should not exceed 200
	<b>psi</b> . If the pressure reading is above 200 psi, <b>clear</b> the
	obstruction in the hose or replace the quick-
	aissconnect. Also cneck believille springs #061-
	0228 for correct placement or breakage. See Draw-
	ings.
Problem	Remedy
---	---
Hydraulic fluid heats up.	• There is a leak in the hydraulic system. See Trouble
	Shooting.
The Raise/Lower Cylinder moves slower than	• Check to make sure the hydraulic power unit is
usual, or the HawkJaw sinks while it hangs.	producing 2500 psi at 20-35 gpm.
	• Check that the HawkJaw is getting at least 100 psi air.
	• Check that the <b>pump pressure compensator setting</b>
	is at <b>2500 psi</b> .
	• Check that the hydraulic filter element is not com-
	pletely full of contaminants. If the red indicator
	button on the hydraulic filter body pops up, change
	the filter element. See Filter Maintenance.
	• There is an <b>inner seal leak</b> in the cylinder. Make sure
	the HawkJaw rests on the rig floor. Shut down the
	hydraulic power unit. Push the Grip button
	repeatedly to bleed all hydraulic pressure. Push in
	the "E" stop button. Disconnect the Raise/Lower
	cylinder Hanger Eye from the hanging cable. See
	Installation & Drawings. Place the Raise/Lower
	cylinder Rod side end on the rig floor. Pull out the
	"E" stop button. Turn on the hydraulic power unit.
	Push in the Lower button, and hold down the Lower
	<b>button</b> . While holding down the Lower button, <b>check</b>
	for Raise/Lower cylinder piston seal integrity. Make
	sure no bodily parts are in the extension path of
	the cylinder rod. Slowly loosen the HawkJaw Rod
	side Leader hose. Check for fluid flow. If there is a
	piston seal leak, fluid will flow with volume out of the
	Rod side leader hose. Replace the seals. See Draw-
	ings. Replace the cylinder if necessary. See Drawings.
	Push and hold the Raise button. After the Raise/
	Lower cylinder has fully retracted, check for Raise/
	Lower cylinder piston seal integrity. Make sure no
	bodily parts are in the extension path of the
	cylinder rod. Slowly loosen the HawkJaw Cap side
	Leader hose. Check for fluid flow. If there is a
	piston seal leak, fluid will flow with volume out of the

Cap side leader hose. **Replace** the **seals**. See Drawings. Replace the cylinder if necessary. See Drawings.

Problem	Remedy
The Raise/Lower Cylinder moves at an	• Push in the "E" stop button. Access the main
undesired speed	hydraulic block. See Maintenance & Repair &
	Drawings. Use a 7/32" allen wrench to <b>adjust</b> the VR/
	L sandwich valve H6 flow settings at each end.
	Rotate clockwise to reduce speed and counter-
	clockwise to increase speed of the Raise/Lower
	cylinder. Pull out the "E" stop button to test
	settings. Repeat process if necessary.
The Tilt Cylinder moves at an undesired	• Push in the "E" stop button. Access the main
speed.	hydraulic block. See Maintenance & Repair &
	Drawings. Use a 7/32" allen wrench to adjust the VF/
	B sandwich valve H6 flow settings at each end.
	Rotate clockwise to reduce speed and counter-
	clockwise to increase speed of the Tilt cylinder. Pull
	out the "E" stop button to test settings. Repeat
	process if necessary.
The mount arms do not pivot freely.	• The mount arm thrust bearing plates are reversed.
	Properly <b>connect</b> the mount arm <b>thrust bearing</b>
	plates. See Drawings.
	• The mount arm <b>thrust bearings</b> are <b>worn out</b> .
	<b>Replace</b> the mount arm <b>thrust bearings</b> . See Draw-
	ings.
Push in the Winch On or Winch Off button,	• Properly <b>connect</b> the <b>Winch</b> hoses to the Winch
and the HawkJaw moves opposite the	Motor. See Drawings.
desired direction.	• Check that the Winch On and Winch Off air hoses are
	properly <b>connected</b> to the Winch <b>Valve</b> . See Draw-
	ings.
	• Check that the Winch On and Winch Off <b>air hoses</b> are
	properly <b>connected</b> in the Right control handle. See
	Drawings.
Winch does not operate.	• Check that the <b>Winch</b> is <b>engaged</b> . See Installation.
· · · · · · · · · · · · · · · · · · ·	• Make sure the "E" stop is pulled out.
	• Check to <b>make sure</b> the <b>hvdraulic power unit</b> is
	producing 2500 psi at 20-35 gpm.
	• Check that the HawkJaw is getting at least 100 psi air
	• Check that the <b>pump pressure compensator</b> setting
	is at 2500 psi.
	• Check that the hydraulic filter element is not com-

Problem	Remedy
	pletely full of contaminants. If the red indicator
	button on the hydraulic filter body pops up, change
	the filter element. See Filter Maintenance.
	• Check that no hissing sound comes from the Winch
	On or Winch Off button. An air hose is broken,
	switched or disconnected if there is a hissing sound.
	Locate the leak, and replace the hose or connect the
	hose properly. See Drawings.
	• Check that the Winch On and Winch Off button air
	valves work. Disengage the winch. See Installation.
	Push in the button. Air should sound like it is being
	sharply inhaled. Release the button. Air should
	sound like it is being sharply exhaled. If these
	sounds do not occur, <b>replace</b> the Winch On and/or
	Winch Off button air valve. See Drawings.
	• Check the Winch sandwich valve H6 flow setting.
	No fluid will flow to the Winch if the flow setting is
	rotated clockwise to refusal. See Trouble Shooting,
	"Winch moves at an undesired speed".
The Tilt Cylinder moves at an undesired	• Use a 7/32" allen wrench to <b>adjust</b> the Winch sand-
speed.	wich valve H6 flow settings at each end. See
	Drawings. Rotate clockwise to reduce speed and
	counter-clockwise to increase speed of the winch on
	and off the pipe. Use Winch On and Winch Off to
	test. Repeat process if necessary.
The Low torque warning system Test #1	• The low torque warning poppet pin #061-30064 and
has failed.	#061-20238 poppet seat may have seal damage or the
	bellville springs #061-022S need replacement or
	correct placement. See Drawings. To check poppet
	seal damage, refer to page 24 for LOW TORQUE
	WARNING TEST #1 PROCEDURES.
The Low torque warning system Test #2	• The low torque warning small "U" cup seal is
has failed.	leaking. Replace the seal. Make sure the seal is
	installed with the top of the "U" facing in. Order
	Hawk # 061-LTW-RK. See Drawings. Refer to
	LOW TORQUE WARNING TEST #2 PROCE-
	DURES.

e low torque warning poppet pin #061-30064 and
51-20238 poppet seat may have seal damage or the
lville springs #061-022S need replacement or
rect placement. See Drawings. To check poppet
l damage, refer to page 23 for LOW TORQUE
ARNING TEST #1 PROCEDURES.
e low torque warning small "U" cup seal is
king. Replace the seal. Make sure the seal is
talled with the top of the "U" facing in. Order
wk # 061-LTW-RK. See Drawings. Refer to
W TORQUE WARNING TEST #2 PROCE-
JRES.

#### Notes

#### 100K-2GSR Full Hawkjaw Assembly



## 100K-2GSR Full Hawkjaw Assembly

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	100K-2GSR-12 Top-Bottom Wrench Assembly	See Explosion
2	1	100K-2GSR-9 Middle W rench Assembly	See Explosion
3	1	100K-2GSR-5 Hydro-Pheumatic Assembly	See Explosion
4	1	100K-2GSR-4 Hanger Assembly	See Explosion
5	1	100K-2GSR-6 Left Control Handle Assembly	See Explosion
6	1	100K-2GSR-7 Right Control Handle Assembly	See Explosion
7	1	100K-2GSR-13 Winch Mount Assembly	See Explosion
8	1	100K-2GSR-2 Spinner Mount Assembly	See Explosion
9	1	100K-2GSR-11 Stand Assembly	See Explosion
10	1	100K-2GSR-15 Hawkjaw Spinner Assembly	See Explosion
11	1	100K-2GSR-10 Pipe Stop assembly	See Explosion
12	1	100K-2GSR Hydraulic Pipe Clamp Sys Assy	See Explosion

#### 100K-2GSR Top-Bottom Wrench Assembly



#### 100K-2GSR Top-Bottom Wrench Assembly

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	20145 Base Plate Assembly	
2	1	20084 Torque Cylinder Bracket, Upper Assembly	
3	1	20088 Torque Cylinder Bracket, Lower	
4	1	20080-2 Torque Cylinder Mount, Lower Assembly	
5	1	20004-3A Jaw Plate Assembly, Welded	
6	1	20004-1B Jaw Plate Assembly, Welded	
7	10	12042 Shim	
8	2	20002A Hook Assembly	
9	2	20188 Adjust Nut Assembly	
10	2	20072 Nut Bearing Plate	
11	1	20209-TOP Heel Die Holder Assembly, Top	See Explosion
12	2	20078 Stationary Jaw Cradle Assembly	Occ. Evelopier
13	2	20211-1B Hook Die Holder Assembly, Middle	See Explosion
14	2	20209 LOCK Fible	
10	4	20217 Shoulder Bolt	
10	8	806594-500 1-14 Lock Nut	
18	2	20289-1A Lock Plate Wrench Bolt	
19	2	20289-2A Lock Plate, Wrench Bolt	
20	4	20218 Bolt, Wrench	
21	4	807493-250 Cotter Pin	
22	1	20049A Stud. Pipe Stop Retrofit	
23	4	20234 Pivot Sleeve	
24	4	20198 Pivot Pin	
25	7	1103K1 Grease Fitting, Straight	
26	2	20202 Nut Stop Retainer	
27	2	20200 Nut Stop	
28	8	806004_3.8-16 x .75 Lg. Hex Bolt	
29	10	810645_3.8 Lock Washer	
30	8	1103K3 Grease Fitting, 90 Degree	
31	2	808413_1.2-13 x .75 lg. Soc. Hd. Cap Screw	
32	4	810703_1.2 Lock Washer	
33	2	92384A092 Push Button Pin	
34	1	20209-BOT Heel Die Holder Assembly, Bottom	See Explosion
35	4	20270 Hook Bin	
37	2	20270 FIOR FIII	
38	1	20173A Filter Bracket Assembly	
39	1	H25 Hydraulic Filter Assembly	See Explosion
40	1	A22 On Board Air Filter Assembly	See Explosion
41	2	806011 3.8-16 x 1.0 Hex Bolt	
42	4	805847 1.4-20 x 1.00 la. Hex Bolt	
43	4	810587 1.4 Lock Washer	
44	2	806246_1.2-13 x 1.00 Hex Bolt Grd. 9	
45	2	30117 Angle Braket Bolt, Small	
46	4	30118 Angle Bracket Bolt, Large	
47	4	91074A038 Lock Washer Assembly, 1.0	
48	22	91074A036 Lock Washer Assembly, 3.4	
49	4	806529_3.4-16 x 1.75 lg. Hex Bolt Grd. 9	
50	1	20258 Bumper, Torque Cylinder	
51	2	91259A118_5.8 x .50 lg. Shoulder Bolt	
52	1	20268 Level	
53	2	809476 10 Look Weater List Caller	
54	2	009470_10 LOCK WASNEF, HIGN COllar	
50	<u> </u>	806627 1-14 x 5 00 la Hex Bolt Grd 0	
57	1	200044-38 Jaw Plate Assembly Welded	
58	1	20004A-1A Jaw Plate Assembly, Welded	
59	1	620 Cent 1.75x14.0 x .207 Extention Spring	
60	1	807520 3.16 x 1.50lg. SS Roll Pin	
61	1	20121 Torque Cylinder Mount. Upper Assembly	
62	1	H18S Grip Tilt Cylinder Assembly	See Explosion
63	1	H17 Torque Cylinder Assembly	See Explosion
64	4	2062-6-6S_6MORB x 6MJIC Fitting 90	
65	2	806628-H Bolt, Grip Cylinder Middle Wrench	
66	2	SL5 Danger Label	
67	8	807801_ Pop Rivet	
68	4	20234-1 Pivot Sleeve Keeper	
69	16	806539_3.4-16 x 3.00 lg.Hex Bolt Grd. 9	
70	1	H18 Grip Tilt Cylinder Assembly	See Explosion

#### 100K-2GSR Midde Wrench Assembly



#### 100K-2GSR Middle Wrench Assembly

ITEM	ΟΤΥ		COMMENTS
1	<b>u</b> (1).	20008 Base Plate Moving Assembly, Welded	COMMENTS
2	2	20016A Linkage Split Assembly	
3	1	20028-245 Pin. Linkage Mount Assembly	
4	2	20028-245B Pin, Linkage Mount Assembly	
5	12	146 Thrust Bearing Assembly	
6	1	20024 Linkage Assembly	
7	4	20029-138AM Washer Assembly	
8	1	20024-1 Stepped Linkage Arm Assembly	
9	1	20002A Hook Assembly	
10	1	20072 Nut Bearing Plate	
11	1	20188 Adjust Nut Assembly	
12	1	20274 Grease Bolt, Linkage Pin	
13	19	806369 1.2-20 x 1.00 lg. Hex Bolt Grd. 9	
14	21	810703_1.2 Lock Washer	
15	16	PRP568-229 O Ring	
10	4	20020 1 Washer	
17	4	20029-1 Washel	
10	7	807493-250 Cotter Pin	
20	8	1103K1 Grease Fitting Straight	
21	4	PRP568-122 O Ring	
22	2	1103K3 Grease Fitting, 90 Degree	
23	2	1103K2 Grease Fitting, 45 Degree	
24	1	20048A Stud, Cam Retro-fit	
25	1	20047A Stop Cam Roller	
26	2	20038 Pivot Bushing	
27	2	20214-2A Bolt, Modified	
28	6	806523_3.4-16 Flex Nut (31FK1216)	
29	1	20028-362 Pin, Linkage Mount Assembly	
30	2	20218 Bolt, Wrench	
31	1	20289-1A Lock Plate, Wrench Bolt	
32	1	20289-2A Lock Plate, Wrench Bolt	
33	3	806627_1-14 x 5.00 lg. Hex Bolt Grd. 9	
34	1	20270 Heek Bin	
36	1	20270 Flook Fill 984014446 3 32 x 1 50 lg Cotter Pin	
37	1	20204A Torque Cylinder Pin	
38	1	98335A114 Hair Pin Retainer	
39	1	20078 Stationary Jaw Cradle Assembly	
40	1	20209-MID Heel Die Holder Assembly, Middle	See Explosion
41	1	92384A092 Push Button Pin	· · · ·
42	2	806644_1 1.4-7 x 4.00 lg. Hex Bolt Grd. 9	
43	1	20217 Shoulder Bolt	
44	1	20269 Lock Plate	
45	1	806594-500_1-14 Lock Nut	
46	1	20211-MID_Hook Die Holder Assembly, Middle	See Explosion
47	1	808413_1.2-13 x .75 lg. Soc. Hd. Cap Screw	
48	2	20198 PIVOL PIN 20224 Rivet Sloove	
49 50	1	20204 FIVOL Steeve	
51	1	20202 Nut Stop Retainer	1
52	4	806004 3.8-16 x .75 La. Hex Bolt	<u> </u>
53	4	810645_3.8 Lock Washer	
54	1	20004A-2A Jaw Plate Assembly, Welded	
55	1	20004A-2B Jaw Plate Assembly, Welded	
56	1	807520_3.16 x 1.50lg. SS Roll Pin	
57	1	H18S Grip Tilt Cylinder Assembly	See Explosion
58	1	20010-5 Reset Bumper Welded Assy	
59	1	20010-4 Bumper	
60	2	810/05_1.2 Flat Washer	
61	2	000221_1.2-13 FIEX NUT (21FKF813)	
63	4	200474-3.4-10 x 5.50 lg. nex buil Gid. 9	
64	1	20023A Spring Mount Plate	
65	2	806590 1-14 Nylock Nut	1
66	2	91074A038 Washer 1.0	
67	1	SL5 Danger Label	
68	4	807801_ Pop Rivet	
69	2	20234-1 Pivot Sleeve Keeper	
70	8	91074A036 Lock Washer Assembly, 3.4	
71	8	806539_3.4-16 x 3.00 lg.Hex Bolt Grd. 9	
72	1	806628-H Bolt, Grip Cylinder Middle Wrench	

#### 100K-2GSR Hydro-Pneumatic Assembly



## 100K-2GSR Hydro-Pneumatic Assembly

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	100K-2GSR Hydraulic Connections (J1A-A)	See Explosion
2	1	20169 Control Housing Assembly	
3	1	20176A Block Plate Assembly	
4	1	20167-2 Inspection Cover	
5	1	20167-3A Inspection Cover	
6	1	20162A Control Housing Assembly	
7	8	806244_1.2-13 x 1.0 Hex Bolt	
8	14	810703_1.2 Lock Washer	
9	8	810705_1.2 Flat W asher	
10	6	806239_1.2-13 x .75lg. Hex Bolt	
11	4	806003_3.8-16 x .75 lg. Hex Bolt	
12	8	810645_3.8 Lock Washer	
13	4	806004-1_3.8-16 x .75 Lg. Hex Bolt Drilled	
14	1	A11-1LCH Multiplex Connector Assembly	See Explosion
15	1	A11-2RCH Multiplex Connector Assembly	See Explosion
16	1	A11-RT_Right Control Tube Assembly	See Explosion
17	1	A11LFT Left Control Tube Assembly	See Explosion
18	2	20400 Grommet	
19	1	9307K62 Grommet	

## 100K-2GSR HangerAssembly



# 100K-2GSR HangerAssembly

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	20147 Hanger Assembly	
2	1	20151 Spindle Block	
3	1	20267 Hose Mount, 2GSR Assembly	
4	1	20059 U Bolt for 2GSR	
5	1	H18S Grip Tilt Cylinder Assembly	See Explosion
6	2	SH30540PP 1.4 Hose Clamp (pipe)	
7	2	SH5150PP 1_1.2 Hoseclamp (tube)	
8	2	SH61900PP	
9	1	H30540-1 Bracket, Hose Clamp	
10	1	H5150-1 Bracket, Hose Clamp	
11	1	H61900-1	
12	1	PRP568-226 O Ring	
13	1	PRP-568-329 O-Ring	
14	6	806446_5.8-11 x 5.50lg. Hex Bolt	
15	6	810732_5.8 Lock Washer	
16	1	20029-2 Washer, Spindle Block	
17	1	806581-1 Castle Nut	
18	1	806510_3.4-10 x 9.50 Hex Bolt	
19	3	806503_3.4-10 Flex Nut (31FAF1210)	
20	1	13143 Suspension Ring	
21	1	20180 Gage Housing Assembly	
22	2	806504_3.4-10x6.00lg Hex Bolt, Grd 9	
23	1	H178 Torque Gauge	
24	1	806624_1-14 x 4.50 lg. Hex Bolt Grd. 9	
25	1	806594-500_1-14 Lock Nut	
26	2	805987-750 3.8-16 Flex Nut (21FKF616)	
27	2	810703_1.2 Lock Washer	
28	2	806310_1.2-13 x 4.00 Hex Bolt	
29	4	810645_3.8 Lock Washer	
30	2	806042_3.8-16 x 2.00lg. Hex Bolt	
31	2	806049 3.8-16 x 3.25lg. Hex Bolt	
32	1	807493-250 Cotter Pin	
33	3	805842 1.4-20 x .75 lg. Hex Bolt	
34	3	810587 1.4 Lock Washer	
35	1	100K-2GSR Gage Manifold Assembly	See Explosion
36	2	805922 5.16-18 x 2.0 Hex Bolt	
37	2	810616 5.16 Lock Washer	
38	2	2062-6-4S 6MORB x 4MJIC Fitting 90	
39	1	2047-2-2S 2MNPTX2FNPT Fitting 90 Drg Swivel	
40	2	1103K2 Grease Fitting, 45 Degree	
41	1	13179-2 Adjust Screw	
42	1	G2130-5.8 Shackle	
43	1	SC74 Safety Cable	
44	1	G215-1 1.8 Shackle	
45	1	93750A715 Push-Button Pin w Cable	
46	1	807800_ Pop Rivet	

#### 100K-2GSR Left Control Handle Assembly



#### 100K-2GSR Left Control Handle Assembly

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	70100 Left Control Handle Assembly	
2	1	70103 Left Control Panel Assembly	
3	1	A15 Air Manifold	
4	2	20104-1 Control Handle, Top & Bottom Cover	
5	4	805916_5.16-18 x .50 LG. HEX BOLT	
6	4	810616_5.16 Lock W asher	
7	12	806004_3.8-16 x .75 Lg. Hex Bolt	
8	12	810645_3.8 Lock Washer	
9	4	806041_3.8-16 x 2.00 lg. Hex Bolt Grd. 5	
10	4	805987-750 3.8-16 Flex Nut (21FKF616)	
11	2	20247 Guard, Air Connector	
12	1	20117A Rubber Shock Mount	
13	1	A11-LCH Multiplex Connector Assembly	See Explosion
14	1	A1 Selector Switch Assembly	
15	1	A8GH Grip Hold Button Assy	
16	5	A3 Button Air Valve Assembly	
17	1	A4G Grip Valve Assembly	
18	1	2081-4-2S 1.4 x 1.8 H.P. Hex Bushing	

100K-2GSR Right Control Handle Assembly



#### 100K-2GSR Right Control Handle Assembly

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	70101 Right Control Handle Assembly	
2	1	70105 Right Control Panel Assembly	
3	4	805916_5.16-18 x .50 LG. HEX BOLT	
4	4	810616_5.16 Lock Washer	
5	12	806004_3.8-16 x .75 Lg. Hex Bolt	
6	12	810645_3.8 Lock Washer	
7	4	806041_3.8-16 x 2.00 lg. Hex Bolt Grd. 5	
8	6	805987-750 3.8-16 Flex Nut (21FKF616)	
9	1	20104-1 Control Handle, Top & Bottom Cover	
10	2	20247 Guard, Air Connector	
11	1	20222 Torque Control Block, Modification	
12	1	J55A Torque Control Valve Assembly	
13	1	CXGD-XBN Check Valve	
14	1	20104-2 Control Handle, Right Bott. Assembly	
15	2	806051_3.8-16 x 3.50lg. Hex Bolt	
16	1	A15 Air Manifold	
17	1	30113 Orifice Fitting	
18	1	2087-019 Orifice Plug	
19	2	2081-4-2S 1.4 x 1.8 H.P. Hex Bushing	
20	1	900598-6S_MORB Plug	
21	1	2047-2-2S 2MNPTX2FNPT Fitting 90 Drg Swivel	
22	1	20117A Rubber Shock Mount	
23	2	A20 Button Air Valve Assembly	
24	2	A3 Button Air Valve Assembly	
25	1	A80 'E' Stop Button Assy	
26	1	A11-RCH Multiplex Connector Assembly	See Explosion
27	1	HOS-18_1.8MNPTx1.8MNPTx54lg_1.8 Hose	
28	1	HOS-18A_1.8MNPTx1.8MNPTx50lg_1.8 Hose	
29	1	HOS-6B10FJICx-10FJICx92.00lg. Hose	
30	2	2062-12-10S_12MORB x 10MJIC Fitting 90	

#### 100K-2GSR Winch MountAssembly



#### 100K-2GSR Winch MountAssembly

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	20223 Winch Mount Assembly	
2	1	H59 Winch Assembly, Manual	
3	1	59R Roller Assembly, Winch	
4	1	20286 Winch Cover	
5	4	20203 Spacer, Winch	
6	2	806542-1_3.4-16 x 4.50 Hex Bolt	
7	4	91074A036 Lock Washer Assembly, 3.4	
8	2	806542_3.4-16 X 4.50lg. Soc. Hd. Cap Screw	
9	6	806284_1.2-13 x 2.00lg. Hex Bolt	
10	8	810703_1.2 Lock Washer	
11	2	806244_1.2-13 x 1.0 Hex Bolt	
12	2	2061-10-8S_10MORB x 8MJIC Fitting 45	
13	1	2081-4-2S 1.4 x 1.8 H.P. Hex Bushing	
14	1	2047-2-2S 2MNPTX2FNPT Fitting 90 Drg Swivel	
15	1	C028 Winch Cable Spring	
16	2	G2130-5.8 Shackle	

## 100K-2GSR Spinner MountAssembly



## 100K-2GSR Spinner MountAssembly

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	20094A Spinner Mount Assembly	
2	1	HA-032596A Spring	
3	1	20118 Slide Tube Assembly	
4	1	20126 Slide Base	
5	2	20127 Side Slide	
6	2	20131 Slide Cap	
7	1	20129 Slide Block	
8	1	20134 Pivot Pin	
9	1	20125 Return Bumper	
10	4	20133 Cylinder Bolt	
11	4	20135 Cylinder Mount, Rubber	
12	2	4 Thrust Bearing Assembly	
13	2	PRP568-231 O Ring	
14	1	9108A041 Washer	
15	1	806594-500_1-14 Lock Nut	
16	1	806642_1.25-12 Castle Nut	
17	1	807493-250 Cotter Pin	
18	7	1103K1 Grease Fitting, Straight	
19	1	M030 Alignment Coupler	
20	1	806539_3.4-16 x 3.00 lg.Hex Bolt Grd. 9	
21	4	806358-300_1.2-20 Flex Nut (21FK820)	
22	6	806543_3.4-16 x 5.00lg. Hex Bolt Grd.9	
23	6	91074A036 Lock Washer Assembly, 3.4	
24	2	806445_5.8-11 x 5.00lg. Hex Bolt Grd. 9	
25	6	810732_5.8 Lock Washer	
26	1	806088_3.8-24 x .375lg. Set Screw, Cup Point	
27	1	100K-2GSR-1 Spin Manifold Assembly	See Explosion
28	2	20012 Boss, Mount	
29	2	806042_3.8-16 x 2.00lg. Hex Bolt	
30	2	810645_3.8 Lock Washer	
31	1	807511_3.8 Dia. x 2.50lg. HCS Spirol Pin	
32	1	806585_1-8 x 5.00lg. Hex Bolt Grd.9	
33	1	806580_1.0-8 Lock Nut	
34	1	810821_1.00 Flat Washer	
35	1	20138C Pivot Mount	
36	1	H37S-2 Push Cylinder AsseMbly	See Explosion
37	2	2062-8-8S_8MORB x 8MJIC Fitting 90	
38	1	PRP568-217 O Ring	
39	1	808372_3.8-16 x .375 Lg. Soc. Hd. Set Screw, Cup Point	
40	4	806414-500_5.8-11 Flex Nut (31FA1011)	
41	4	806353_1.2-20 Hex Jam nut	

#### 100K-2GSR Stand Assembly



#### 100K-2GSR Stand Assembly

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	20075A Stand Assembly	
2	1	806542-1_3.4-16 x 4.50 Hex Bolt	
3	2	91074A036 Lock Washer Assembly, 3.4	
4	6	806436_5.8-11 x 1.50 lg. Hex Bolt Grd. 9	
5	7	810732_5.8 Lock W asher	
6	1	806439_5.8-11 x 2.50 lg Hex Bolt Grd. 9	
7	1	806538_3.4-16 x 2.00 lg. Hex Bolt Grd. 9	
8	1	806594-500_1-14 Lock Nut	
9	2	806414-500_5.8-11 Flex Nut (31FA1011)	
10	2	806438_5.8-11 x 2.00 lg Hex Bolt Grd. 9	

#### 100K-2GSR Hawkjaw Spinner Assembly



## 100K-2GSR Hawkjaw Spinner Assembly

ITEM	ΟΤΥ	PART NO /DESCRIPTION	COMMENTS
1	1	25710-SR Case Assembly, Stationary	
2	4	956014435 Fiber Washer	
3	1	25703-SR Case Assembly Moving Arm	
4	1	24625 Reducer Assembly	See Explosion
5	1	24701 Mounting Plate Gear Box	
6	4	24646 Wear Block	
7	1	24642 Key Drive Sprocket	
8	1	24641 Drive Sprocket	
9	1	24635 Spacer Drive Sprocket	
10	1	24656 Drive Shaft Bearing Modified	
11	1	24702 Mounting Plate, Rearing	
12	1	24658 Chain Guard	
12	3	24000 Chain Guard	
14	2	08404A878 Quick Boloaso Bin Assembly	
14	<u> </u>	M22 Motor Mount Caskot	
10	1	ME22 Motor Mount Gasket	
17	1		
17	4	24654 Bearing Soal Assombly	
10	- +	24623 Pollor Sprockot	
19	2	24623 Roller Splocket	
20	4	24649 Roller	
21	4	24043 Key, Rollel	
22	4	RST-275-5 Retainer Ring	
23	4	24731 Sphere-Roi Bearing	
24	2	25725 Idler Bushing	
25	<u>∠</u>	25721 IUIEI KUIIEI	
20	4		
21	<u>∠</u>		
28	4	25721-B Bearing Assembly, Idler Roller	
29	4	25/21-RR Retainer Ring, Idler Roller	
30	4	25/21-S Seal, Idler Roller	
31	1	R25 Sun Gear Kit	
32	1	M21 Key	
33	1	25CYL25-BS Grip Cylinder, Bottom	See Explosion
34	1	25CYL25-AS Grip Cylinder, Top	See Explosion
35	4	806267_1.2-13 x 1.50lg. Hex Bolt	
36	8	810703_1.2 Lock Washer	
37	2	806435_5.8-11 x 1.50 lg. Hex Bolt	
38	5	810732_5.8 Lock Washer	
39	2	806452_5.8-11 x 9.00 lg. Hex Bolt	
40	2	806416_5.8-11 Hex Nut	
41	2	24729 Flanged Bearing	
42	2	24637 Bushing	
43	20	806373_1.2-20 x 2.00 lg.Hex Bolt Grd. 9	
44	5	1103K1 Grease Fitting, Straight	
45	8	805834_1.4-20 x .50 lg. Hex Bolt	
46	8	811150_#14 Brass Washer	
47	2	13002 Warning Tag	
48	8	807800_ Pop Rivet	
49	1	91257A983_1.0-8 x 9.50 lg. Hex Bolt	
50	1	806580_1.0-8 Lock Nut	
51	2	91074A038 Lock Washer Assembly, 1.0	
52	8	806003_3.8-16 x .75 lg. Hex Bolt	
53	8	810648_3.8 Flat Washer	
54	1	806450-1_5.8-11 x 7.00 lg. Hex Bolt Grd. 9	
55	20	91074A033 Lock Washer Assembly, 1.2	
56	2	25725 Pin	
57	4	806594-500_1-14 Lock Nut	
58	2	806586_1.0-14 Hex Jam Nut	
59	4	806276_1.2-13 x 1.75 Hex Bolt	
60	1	25CHAIN SpinMaster Chain Assembly	
61	4	806016_3.8-16 x 1.25 lg Hex Bolt	
62	4	810645_3.8 Lock Washer	
63	2	25720 Safety Cover	
64	1	25726 Chain Oiler Assy	See Explosion
65	3	2089-8-8S_8MNPT x 8FNPT Fitting 90 Elbow	· · · · · · · · · · · · · · · · · · ·
66	1	2084-8S-3 lg. Nipple, Hydraulic Plated	
67	2	2090-8-8S_1.2 FNPT Elbow, Hyraulic	
68	2	2021-8-8S_8MNPT x 8FJIC Hydraulic Adaptor	
69	1	2083-8S-8Sx1.89 lg. Hex Nipple, Hydraulic	
70	2	2047-8-8S 1.2 MNPT x 1.2 FNPT Fitting 90 Swivel	
71	1	24738-8 1.2 MNPT x 1.2 MNPTx 31.0la8Hvd. Hose	
72	1	24738-13 1.2 MNPT x 1.2 MNPTx 26.0lg8Hvd. Hose	
73	2	2061-10-8S 10MORB x 8MJIC Fittina 45	
74	1	24723 Rubber Cover	
75	4	805842 1.4-20 x .75 la. Hex Bolt	
76	4	810589 1.4 Flat Washer	
	· ·		1

## 100K-2GSR Pipe Stop Assembly



#### 100K-2GSR Pipe Stop Assembly

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	20066 Pointer	
2	1	20060 Adjust Clevis	
3	1	20050 Linkage, Stop Assembly	
4	4	809403_10-32x.375 Screw SS	
5	1	20041A Pipe Stop Rubber	
6	1	20029-250 Washer, Pipe Stop	
7	1	20214-3 Hex Bolt	
8	1	806414-500_5.8-11 Flex Nut (31FA1011)	
9	4	809476_10 Lock Washer, High Collar	
10	1	20229 Linkage Nut, Modified	
12	1	20061A Shock Sleeve	
13	1	20069 Index, Pipe Stop	
14	2	106 Ball Thrust Bearing Aseembly	
15	1	20062A Adjust Screw	
16	1	20070 Adjust Nut	
18	1	20068 Adjust Base	
19	1	RR-150-S Retainer Ring	
20	1	20067 Bearing	
21	4	806311_1.2-13 x 4.5 Hex Bolt	
22	4	810703_1.2 Lock Washer	
23	1	807493-250 Cotter Pin	
24	1	1103K1 Grease Fitting, Straight	
25	1	20044A Pipe Stop Assembly	
26	1	20045-1 Crank, Pipe Stop	
27	1	98380A591 5.16 X 2.50 LGg Dowel Pin	

#### 100K-2GSR Hydraulic Connections



## 100K-2GSR Hydraulic Connections

ITEM	QTY.	PART NO./DESC	PORT/DESC.	HOSE DESTINATION
1	1	100K-2GSR Main Manifold Assembly (J1A-A)		
2	1	HOS-1210FJICx-10FJICx35.00lg. Hose	TCR	Torque Cyl. Rod
3	1	HOS-132G10FJICx-10FJICx 110.0lg-10. Hose	TCP	PR2-Torque Cntrl. Manifold
4	2	HOS-82G8FJICx-8FJICx100.00lg. Hose	WIN, WOUT	Winch Motor
5	2	HOS-42G_1.4MNPTx-4FJICx117.00lg. Hose	R, L	Raise/Lower Cyl. Rod, Pist.
6	2	HOS-102G10FJICx-10FJICx115.00lg. Hose	SM1, SM2	Spinner Motor
7	1	HOS-72G8FJICx-8FJICx92.00lg-8. Hose	T4	PR3-Spin Manifold
8	2	HOS-52G4FJICx-4FJICx86.00lg-4. Hose	TB, TF	Tilt Cyl. Piston, Rod
9	2	HOS-142G6FJICx-6FJICx95.00lg-6. Hose	G3R, G3P	Top Grip Rod, Piston
10	6	HOS-62G6FJICx-6FJICx36.00lg. Hose	G1R, G1P, G2R, G2P,	Bott. Grip Rod, Pist.; Midd. Grip Rod, Pist.;
			JHR, JHP	Jaw Holder Rod, Pist.
11	1	HOS-122G_3.4MNPTx-1 MNPTx30.00lg12 Hose	TANK	Tank Line (HOS-24)
12	1	HOS-24_1 MNPTx1 MNPTx180.00lg20 Hose	HOS-122G	Tank Line, Power Unit
13	2	HOS-92G8FJICx-10FJICx92.00lg. Hose	SCR, SCP	Spinner Manifold SCR, SCP
14	1	HOS-OIL_1.8MNPTx1.8MNPTx130 lg_1.8 Hose	Oiler Needle Valve	Spray Nozzle, Spinner
15	1	H26F_Female Quick Disconnect		
16	1	H26M_Male Quick Disconnect		
17	1	H53 Female Quick Disconnect		
18	1	2096-16_1.0 Pipe Coupling, HP		

# 100K-2GSR Spin Manifold Assembly



#### 100K-2GSR Spin Manifold Assembly

ITEM	QTY.	PART NO./DESC	PORT/DESC.	HOSE DESTINATION
1	1	H38 Spin Manifold		
2	1	H35 Sequence Valve	V2	
3	1	H34 Check Valve	V4	
4	1	H31 Flow Control Valve	V7	
5	2	H33 Check Valve	V3,V8	
6	1	H36 Pressure Reducing Valve	V1	
7	1	H45 Needle Check Valve	V9	
8	2	2062-8-8S_8MORB x 8MJIC Fitting 90		
9	1	206209-6-6S_8MORB x 8MJIC Fitting 90 Ext.		
10	1	2216-4-6S6MORB x-4FNPT Str. Adaptor		
11	1	2081-4-2S 1.4 x 1.8 H.P. Hex Bushing		
12	1	2254-2-2S_2MNPT x 2FNPT_T Fitting Swivel		
13	1	2216-2-4S4MORB x-4FNPT Str. Adaptor		
14	1	2047-2-2S 2MNPTX2FNPT Fitting 90 Drg Swivel		
15	4	202702-8-8S8MORB x -8MJIC Str. Adaptor		
16	1	HOS-108FJICx-8FJICx33.00lg. Hose	PCR-Spin Manifold	Rod-Push Cyl.
17	1	HOS-88FJICx-8FJICx49.00lg. Hose	SR-Spin Manifold	Rod-Spinmaster
18	1	HOS-78FJICx-8FJICx49.00lg. Hose	SP-Spin Manifold	Piston-Spinmaster
19	1	HOS-98FJICx-8FJICx24.00lg. Hose	PCP-Spin Manifold	Piston-Push Cyl.
20	1	HOS-32_1.8MNPTx1.8MNPTx17lg_1.8 Hose	RT-Spin Manifold	Winch Motor Drain
21	1	JHOS-OIL 1.8MNPTx1.8MNPTx83lg_1.8 Hose	RT1	Torque Cylinder
22	1	HOS-18_1.8MNPTx1.8MNPTx54lg_1.8 Hose	RT1	Torque Cntrl. Blk, RT

#### **NOTE**

To adjust the Spinner move forward, close and open sequence:

- 1. Use a 5/32" allen wrench to rotate the Push cylinder pressure reducing valve at Port V1 counterclockwise until refusal.
- 2. Use a 5/32" allen wrench to rotate the Spinner Door sequence valve at Port V2 clockwise until refusal.
- 3. Starting with the **needle valve** at **Port V9** full open (turned counterclockwise until refusal), use a 1/4" allen wrench to **rotate** the **Spinner retract needle valve** at **Port V9 clockwise** until the spinner doors **open fully**. Then rotate the valve in the same direction another 1/2 turn, then lock the valve.
- 4. Use a 5/32" allen wrench to rotate the Spinner motor sequence valve at Port MSEQ on the main hydraulic block clockwise until refusal.
- 5. Set the **Selector switch** to **Break**. Adjust the spinner to the drill pipe tube OD. Place the HawkJaw on the drill pipe connection.
- 6. Press the Grip Hold button. Press the Spin button. Rotate the Push cylinder pressure reducing valve at Port V1 clockwise until the spinner moves forward and the chain touches the pipe. If the chain forces the HawkJaw away from the pipe, back off on the adjustment until the spinner chain touches the pipe without forcing the Hawkjaw back. The spinner will close if you hold the spin button too long.
- 7. Rotate the Spinner Door sequence valve at Port V2 counterclockwise until the spinner doors begin to close as the spinner chain touches the pipe. For each adjustment, press and hold the Spin button to test the adjustment. Continue to rotate the adjustment counterclockwise until the spinner begins to close before the chain touches the pipe. Rotate the adjustment clockwise until the spinner begins to close as the spinner chain touches the pipe. Lock in the adjustment.
- 8. For each adjustment, press and hold the Spin button until the spinner doors close. Release the Spin button to test the adjustment. If the rollers grab the pipe while retracting, adjust the needle valve clockwise. If the chain forces the HawkJaw backwards while retracting, adjust the needle valve counterclockwise.
- 9. Adjust the spinner motor sequence valve at Port MSEQ. Use a 3/16" allen wrench to rotate the sequence valve counterclockwise until the chain moves before the doors close. Next, rotate the adjustment clockwise until the spinner doors close before the chain moves. Rotate one half-turn clockwise. Lock in the adjustment.

#### 100K-2GSR Raise/Lower Cylinder Assembly



#### 100K-2GSR Raise/Lower Cylinder Assembly

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	2572-9 Barrel, Raise Lower Cylinder	
2	1	2572-6 Rod, Raise Lower Cylinder	
3	1	2572-8 Rod Clevis, Raise Lower Cylinder	
4	1	2572-7 Seal Retainer, Raise Lower Cyl.	
5	1	TPO-28 Piston Seal	*
6	2	TPO-28 Backup, Piston Seal	*
7	1	940-15 Rod Wiper, Raise Lower Cyl.	*
8	1	MCD-2500-1000 Wear Ring, Raise lower Cyl.	*
9	1	2-228-90 O Ring	*
10	1	2572-5 Cotter Pin 3.16 dia. x 3.5 lg, Raise Lower Cyl.	
11	1	1870-1375-312B Rod Seal, Raise Lower Cyl.	*
12	2	2089-8-8S_8MNPT x 8FNPT Fitting 90 Elbow	
13	1	HOS-23_1.2 MNPT x 1.2 MNPTx 8.50lg8Hyd. Hose	
14	1	HOS-22_1.2 MNPT x 1.2 MNPTx 84.0lg8Hyd. Hose	
15	1	H26F_Female Quick Disconnect	
16	1	H26M_Male Quick Disconnect	
17	2	FS59004 Swivel Joint	
18	1	20230 Swivel Assembly	
19	1	806594-500_1-14 Lock Nut	
20	1	806622_1.00-14 x 4.00lg. Hex Bolt	

#### \*NOTE: THESE PARTS AVAILABLE ONLY IN KIT #H20S-RK

#### 100K-2GSR Main Manifold Assembly


#### 100K-2GSR Main Manifold Assembly

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	J1A-A Main Manifold	
2	1	V6APBCP_DO5_Assembly	
3	1	V6ABT_D05_Assembly	
4	2	H7 Pilot Check Sandwich Assembly	
5	5	H6 Flow Control Sandwich Assembly	
6	2	H53S Directional Valve Assembly	
7	2	H93S Directional Valve Assembly	
8	3	H6P Pressure Control Sandwich	
9	1	H4B Air Piloted 2-Way Valve	
10	1	V6SR_DO5_Assembly	
11	1	H9JR 3Grip Valve	
12	1	H5 Directional Valve Assembly	
13	16	A46 5.32 x 1.8 PTC Elbow	
14	1	2082-4S_1.4 Pipe Plug	
15	2	9005912-12S_MORB Plug	
16	1	H35 Sequence Valve	
17	1	H72 Sequence Valve	
18	1	2216-2-4S4MORB x-4FNPT Str. Adaptor	
19	1	2047-2-2S 2MNPTX2FNPT Fitting 90 Drg Swivel	
20	1	HOS-OIL_1.8MNPTx1.8MNPTx130 lg_1.8 Hose	
21	4	202702-6-4S6MORB x -4MJIC Str. Adaptor	
22	2	202702-6-8S6MORB x -8MJIC Str. Adaptor	
23	3	202702-8-8S8MORB x -8MJIC Str. Adaptor	
24	1	2062-6-6S_6MORB x 6MJIC Fitting 90	
25	1	206209-6-6S_6MORB x 6MJIC Fitting 90 Ext.	
26	2	206209-10-10S_10MORB x 10MJIC Fitting 90 Ext.	
27	2	2062-10-10S_10MORB x 10MJIC Fitting 90	
28	1	900598-8S_MORB Plug	
29	6	202702-6-6S6MORB x -6MJIC Str. Adaptor	
30	4	900598-6S_MORB Plug	
31	1	H94S Directional Valve	
32	2	2216-1212S Adaptor, Hydraulic	
33	1	2081-4-2S 1.4 x 1.8 H.P. Hex Bushing	
34	1	A47 3.16 x 1.8 PTC Elbow	
35	1	A48 1.4 x 1.4 PTC Elbow	
36	4	DO5 O Ring, Viton	
37	4	D03 O Ring, Viton	

#### VALVE ADJUSTMENT

FUNCTION	PORT	PRESSURE/ADJUSTMENT
RAISE/LOWER CYL	R/L	Flow Cntrl. Valve (H6); Screw in for FASTER mvmnt., out for SLOWER
		mvmnt. (top screw LOWER adj., bottom UPPER adj.)
<b>BOTTOM WRENCH</b>	GRIP1	<b>Pressure (H6P)</b> Preset to 1000psi; Screw in for higher pressure, out for lower
		pressure; Flow Cntrl. Valve (H6); Screw out for more flow, in for less flow
MIDDLE WRENCH	GRIP2	Pressure (H6P) Preset to 1000psi; Screw in for higher pressure, out for lower
		pressure; Flow Cntrl. Valve (H6); Screw out for more flow, in for less flow
UNIT TILT	TILT	Flow Cntrl. Valve (H6); Screw in for faster mvmnt., out for slower mvmnt.
		(top screw FORWARD tilt, bottom for BACKWARD tilt)
WINCH	WINCH	Flow Cntrl. Valve (H6); Screw in for faster mvmnt., screw out for slower
		mvmnt.
MOTOR SEQUENCE	MSEQ	Sequences the spinner motor to begin turning at the correct time; 3/16" socket
		wrench turn in to delay motor start, turn out to advance motor start

#### 100K-2GSR Main Manifold Air Connections









#### 100K-2GSR Main Manifold Air Connections

#### LEFT CONNECTOR DUPLICATE PORT DESCRIPTION COLOR SIZE AIR SUPPLY BLACK Α 3/16 В AIR SUPPLY TORQUE YELLOW 5/32 С AIR SUPPLY SPIN CLEAR 5/32 AIR SUPPLY WINCH 1 RED 5/32 YELLOW Х 2 GRIP #1 5/32 **GRIP #2** 3 ORANGE 5/32 BLUE GRIP #3 4 5/32 RAISE VALVE SIDE "b" 5 GREEN 5/32 Х LOWER VALVE SIDE "a" 6 BLACK 5/32 Х 7 TILT VALVE SIDE "b" CLEAR 5/32 8 TILT VALVE SIDE "a" GREY 5/32 BLACK 9 OILER 5/32

#### **RIGHT CONNECTOR**

DUPLICATE	PORT	DESCRIPTION	COLOR	SIZE
	Α	SUPPLY FRONT FILTER AIR 1	CLEAR	3/16
	В	SUPPLY RETURN	BLACK	3/16
	С	SUPPLY TORQUE	YELLOW	5/32
	1	SUPPLY WINCH	RED	5/32
	2	SUPPLY SPIN	CLEAR	5/32
	3	TORQUE VALVE SIDE "a"	GREY	5/32
	4	TORQUE VALVE SIDE "b"	BLUE	5/32
	5	SPIN VALVE SIDE "b"	GREEN	5/32
	6	SPIN VaLVE SIDE "a"	ORANGE	5/32
	7	WINCH VALVE SIDE "b"	BLACK	5/32
X	8	WINCH VALVE SIDE "a"	GREY	5/32
Х	9	SPARE	GREEN	5/32

#### 100K-2GSR Left Control Handle Air Connections



○ CIRCLE DENOTES "ITEM NUMBER"
□ BOXES DENOTES "HOSE DESTINATION"

# 100K-2GSR Left Control Handle Air Connections

ITEM NO.	QTY.THIS ASSY.	PART NO./ DESCRIPTION	COMMENTS
1	1	A15 Air Manifold	
2	16	A40-5 Red Air Hose	
3	5	A36 Port Plug	
4	1	A1 Selector Switch Assembly	
5	1	A8GH Grip Hold Button Assy	
6	5	A3 Button Air Valve Assembly	
7	1	A4G Grip Valve Assembly	
8	1	2081-4-2S 1.4 x 1.8 H.P. Hex Bushing	
9	1	A47 3.16 x 1.8 PTC Elbow	
10	1	A40L-4_3.16 Black Air Hose	
11	4	A40-4 Clear Air Hose	
12	2	A40-6 Black Air Hose	
13	1	A40-8 Gray Air Hose	
14	5	A40-1 Yellow Air Hose	
15	8	A40-2 Orange Air Hose	
16	3	A40-3 Blue Air Hose	
17	1	A40-7 Green Air Hose	
19	1	A11-LCH Multiplex Connector Assembly	See Explosion
20	1	J37 'Or' Element Connector	
21	10	A52 Y PTC Fitting	
22	1	A53 PTC Coupler Fitting	
23	1	59063-2GSR_Logic Manifold Assembly	

#### 100K-2GSR Right Control Handle Air Connections



## 100K-2GSR Right Control Handle Air Connections

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	A15 Air Manifold	
2	1	A40-1 Yellow Air Hose	
3	1	A40-2 Orange Air Hose	
4	2	A40-8 Gray Air Hose	
5	2	A40-4 Clear Air Hose	
6	5	A36 Port Plug	
7	1	2081-4-2S 1.4 x 1.8 H.P. Hex Bushing	
8	1	A47 3.16 x 1.8 PTC Elbow	
9	1	A40L-4_3.16 Black Air Hose	
10	5	A40-5 Red Air Hose	
11	2	A20 Button Air Valve Assembly	
12	2	A3 Button Air Valve Assembly	
13	1	A80 'E' Stop Button Assy	
14	1	A11-RCH Multiplex Connector Assembly	
15	1	A40-6 Black Air Hose	
16	1	A40-3 Blue Air Hose	
17	1	A40-7 Green Air Hose	

#### 100K-2GSR Torque Cylinder Assembly



# 100K-2GSR Torque Cylinder Assembly

ITEM NO.	QTY.	PART NO./ DESCRIPTION	COMMENTS
1	1	4H080 Tube Assembly	
4	1	20259 Torque Cylinder Guard	
5	1	20238 Poppet Seat	***
6	1	30064 Poppet Pin	***
7	1	30065 Body, Poppet Valve	
10	1	LTW-RK U Cup, Poppet Pin	**
11	1	PRP568-016 O Ring, Poppet Seat	**
12	1	PRP568-018 O Ring, Body	**
15	1	20011_1 1.4 Flex Nut, H17 Torque Cylinder	
16	1	11963 Seal Retainer, H17 Torque Cylinder	
19	1	11963 Spring, Seal	
23	14	022S Bellville Spring	
24	2	805959_5.16-24 x .75 Socket Head Cap Screw	
25	1	809396-1_10-32 x .25 Socket Head Set Screw	
26	1	10904 O Ring, H17 Torque Cylinder	
27	2	91074A030 Lock Washer Assembly, 5.16	
28	1	1103K1 Grease Fitting, Straight	
30	1	202702-12-10S12MORB x -10MJIC Str. Adaptor	
31	1	900598-12S_MORB Plug	
32	1	2062-12-10S_12MORB x 10MJIC Fitting 90	
33	1	5C475 Rod, H17 Torque Cylinder	
34	1	74483 Head, Torque Cylinder	
35	1	10007 Rod Wiper, Torque Cylinder	*
36	1	10017 Rod Seal, Torque Cylinder	*
37	1	73225 Piston, Torque Cylinder	
38	1	10418 O Ring, Torque Cylinder Rod	*
39	1	11963 Seal	*
40	1	30218 Bearing, Piston H17 Torque Cylinder	*
41	1	10236 O Ring, H17 Torque Cylinder	*
42	1	10237 O Ring Backup, Torque Cylinder	*
43	1	20087 Retainer Ring, H17 Torque Cylinder	
44	2	2047-2-2S 2MNPTX2FNPT Fitting 90 Drg Swivel	
		* These parts are kitted Hawk P/N J20-RK	
		** These parts are kitted Hawk P/N/ LTW-RK	
		*** These parts are available in set only as P/N LTW-P/S	

#### 100K-2GSR Left Control Tube Assy Air Conn



## 100K-2GSR Left Control Tube Assy Air Conn

ITEM NO.	QTY.THIS ASSY	PART NO./DESCRIPTION	COMMENTS
1	1	A11-1LCH Multiplex Connector Assembly	See Explos. Drw.
2	1	A11-LCH Multiplex Connector Assembly	See Explos. Drw.
3	1	A11LFT Left Control Tube Assembly	

#### 100K-2GSR Right Control Tube Assy Air Conn

Port#-Typ. Both Ends	-	2	с	4	5	9	2	8	6	A	В	ပ
Tube Marker #	None	None	-	None	None	None	None	2	None	None	None	None
Hose Color	Red	Clear	Gray	Blue	Green	Orange	Black	Gray	Plugged	Black 3/16"	Clear 3/16"	Yellow

(m)\_\_\_\_

#### 100K-2GSR Right Control Tube Assy Air Conn

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	A11-RT_Right Control Tube Assembly	See Explosion
2	1	A11-RCH Multiplex Connector Assembly	See Explosion
3	1	A11-2RCH Multiplex Connector Assembly	

## 25726 Chain Oiler Assembly



#### 25726 Chain Oiler Assembly

ITEM NO.	QTY.THIS ASSY	PART NO./ DESCRIPTION	COMMENTS
3	1	2083-4-45 1-4 NPT ADAPTER	
4	1	11432-SSP Body, SST, Polished	
5	1	8536-200 STRAINER, SST	
6	1	7894-NY TIP GASKET, NYLON	
7	1	7894-NY TIP GASKET, NYLON	
8	1	TP400025-TC .013 Nozzle	
9	1	7890-SSP CAP,SST, POLISHED	
10	2	805916_5.16-18 x .50 LG. HEX BOLT	
11	1	2049-2-2 1-8,45 Drg Adapter	
12	2	810616_5.16 Lock Washer	
13	1	25726 Chain Oiler Weldment	

#### 20209-BOT Heel Die Holder Assembly, Bottom



#### 20209-BOT Heel Die Holder Assembly, Bottom

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	20192-1B Die Holder, Heel Side	
2	2	810703_1.2 Lock Washer	
3	1	20194 Die	
4	2	20212-1A Retainer, Heel Die	
5	2	20208-870 Spacer, Die Holder	
6	2	98381A622_3.8 Dia. x .75 lg. SS Dowel Pin	
7	2	20210 Roller Assembly	
8	2	806307_1.2-13 x 3.25 lg. Hex Bolt	
9	2	20208A Spacer Bushing, Roller	

#### 20209-MID Heel Die Holder Assembly, Middle



#### 20209-MID Heel Die Holder Assembly, Middle

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	20192-1B Die Holder, Heel Side	
2	1	20210 Roller Assembly	
3	1	20208A Spacer Bushing, Roller	
4	1	806276_1.2-13 x 1.75 Hex Bolt	
5	2	810703_1.2 Lock Washer	
6	1	810705_1.2 Flat W asher	
7	1	806307_1.2-13 x 3.25 lg. Hex Bolt	
8	2	98381A622_3.8 Dia. x .75 lg. SS Dowel Pin	
9	1	20194 Die	
10	2	20212-1A Retainer, Heel Die	
11	1	20208-870 Spacer, Die Holder	

#### 20209-TOP Heel Die Holder Assembly, Top



# 20209-TOP Heel Die Holder Assembly, Top

ITEM NO.	QTY.THIS ASSY	PART NO./ DESCRIPTION	COMMENTS
1	1	20192-1B Die Holder, Heel Side	
2	2	20210 Roller Assembly	
3	2	20208A Spacer Bushing, Roller	
4	2	806307_1.2-13 x 3.25 lg. Hex Bolt	
5	2	810703_1.2 Lock W asher	
6	1	20194 Die	
7	2	20212-1A Retainer, Heel Die	
8	2	98381A622_3.8 Dia. x .75 lg. SS Dowel Pin	

#### 20211-MID Hook Die Holder Assembly, Middle



# 20211-MID Hook Die Holder Assembly, Middle

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	20192B Die Holder, Hook Side	
2	1	20194 Die	
3	4	806246_1.2-13 x 1.00 Hex Bolt Grd. 9	
4	1	1103K2 Grease Fitting, 45 Degree	
5	4	810703_1.2 Lock Washer	
6	1	20212A Die Retainer, Upper Hook	
7	1	20213 Die Retainer, Bottom	

#### 20211-TB Hook Die Holder Assembly, Middle



## 20211-TB Hook Die Holder Assembly, Middle

ITEM NO.	QTY./THIS ASSY	PART NO./ DESCRIPTION	COMMENTS
1	1	20192B Die Holder, Hook Side	
2	1	1103K2 Grease Fitting, 45 Degree	
3	1	20212A Die Retainer, Upper Hook	
4	1	20213 Die Retainer, Bottom	
5	4	806246_1.2-13 x 1.00 Hex Bolt Grd. 9	
6	4	810703_1.2 Lock Washer	
7	1	20194 Die	

#### CYL25-AS Top, -BS Bottom Spinner Grip Cyl



## CYL25-AS Top, -BS Bottom Spinner Grip Cyl

ITEM NO.	QTY.THIS ASSY	PART NO./DESCRIPTION	COMMENTS
1	1	2560-AS.BS Barrel, Spinner Grip	AS-Top/BS-Bott.
2	1	5A049A Rod, Spinner Grip	
3	1	70017 Piston, Spinner Grip	
4	1	25000 Seal Retainer, Spinner Grip	
5	1	SL Stover Nut 3.4-16, Spinner Grip Cyl.	
6	2	002-138 Piston Seal, Spinner Grip Cyl.	*
7	1	1870-1250-312B Rod Seal	*
8	1	SHD-1250 Rod Wiper, Spinner Grip Cyl.	*
9	1	2-228-90 O Ring	*
10	1	8-228 Back Up, Spinner Grip Cyl.	*
11	1	2-016-90 O Ring, Spinner Grip Cyl.	*
12	2	1103K1 Grease Fitting, Straight	

#### 59R Roller Assembly, Winch



## 59R Roller Assembly, Winch

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	H59R-1 Roller Body	
2	2	H59R-2B Roller, Long w Bushing	
3	2	H59R-2A Roller, Short w Bushing	
4	2	H59R-1BZ Axle Shaft, Long	
5	4	H59R-1AZ Axle Shaft, Short	
6	6	1103K1 Grease Fitting, Straight	

## A11-1LCH Multiplex Connector Assembly



## A11-1LCH Multiplex Connector Assembly

ITEM NO.	QTY./THIS ASSY	PART NO./ DESCRIPTION	COMMENTS
1	1	70033 Male Coupler	
2	1	807512_3.16 x .50lg. Roll Pin	
3	12	90130A029 Rubber Washer Seal	
4	1	70031 Panel Nut	
5	1	70051 Female Coupler	
6	1	70044 Swivel Nut	
7	1	US-206-S Retainer Ring	
8	21	A27 5.32 x 1.8 PTC Str. Fitting	

## A11-2RCH Multiplex Connector Assembly



## A11-2RCH Multiplex Connector Assembly

ITEM NO.	QTY.THIS ASSY	PART NO./ DESCRIPTION	COMMENTS
1	1	70033 Male Coupler	
2	1	807512_3.16 x .50lg. Roll Pin	
3	12	90130A029 Rubber Washer Seal	
4	1	70031 Panel Nut	
5	1	70051 Female Coupler	
6	1	70044 Swivel Nut	
7	1	US-206-S Retainer Ring	
8	20	A27 5.32 x 1.8 PTC Str. Fitting	
9	4	A49 3.16 x 1.8 PTC Str. Fitting	
10	2	A36 Port Plug	

## A11-LCH Multiplex Connector



## A11-LCH Multiplex Connector

ITEM NO.	QTY./THIS ASSY.	PART NO./ DESCRIPTION	COMMENTS
1	1	70033 Male Coupler	
2	1	807512_3.16 x .50lg. Roll Pin	
3	12	90130A029 Rubber Washer Seal	
4	1	70031 Panel Nut	
5	1	70051 Female Coupler	
6	1	70044 Swivel Nut	
7	1	US-206-S Retainer Ring	
8	20	A27 5.32 x 1.8 PTC Str. Fitting	
9	2	A28 5.32 x 1.8 PTC Male Run T	
10	2	A49 3.16 x 1.8 PTC Str. Fitting	

## A11-RCH Multiplex Connector


#### A11-RCH Multiplex Connector

ITEM NO.	QTY.THIS ASSY.	PART NO./ DESCRIPTION	COMMENTS
1	1	70033 Male Coupler	
2	1	807512_3.16 x .50lg. Roll Pin	
3	12	90130A029 Rubber Washer Seal	
4	1	70031 Panel Nut	
5	1	70051 Female Coupler	
6	1	70044 Swivel Nut	
7	1	US-206-S Retainer Ring	
8	20	A27 5.32 x 1.8 PTC Str. Fitting	
9	3	A49 3.16 x 1.8 PTC Str. Fitting	
10	1	A28 5.32 x 1.8 PTC Male Run T	
11	2	A36 Port Plug	

#### A22 On Board Air Filter Assembly



#### A22 On Board Air Filter Assembly

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	A22 Top Cover, Air Filter	Not Spare part
2	1	A22 Base Top, Air Filter	Not Spare part
3	1	A22H Base Core, Air Filter	
4	1	A22E Base, Air Filter	
5	1	A22D Gasket, Air Filter	
6	4	A22 Star Spacer, Air Filter	Not Spare part
7	2	A22B_C Filter Cartrige, Air Filter	
8	4	A22F Corner Bolt, Air Filter	
9	4	810557_3.16 Flat Washer	Not Spare part
10	1	A22A Float Drain, Air Filter	
11	2	2089-4-4S4MNPT x-4FNPT Fitting 90 Elbow	
12	1	2045-4-4S4MNPT x -4FNPT Fitting Str. Swivel	
13	1	HOS-29_1.4MNPTx1.4MNPTx204lg_1.4 Hose	
14	1	CP-20-B Male Quick Disconnect	
15	1	C-20-B Female Quick Disconnect	
16	1	A22I Indicator, Air Filter	

#### H18S Grip Tilt Cylinder Assembly



#### H18S Grip Tilt Cylinder Assembly

ITEM NO.	QTY./THIS ASSY	PART NO./ DESCRIPTION	COMMENTS
1	1	H18S-3 Barrel Assembly	
2	1	H18S-5 Seal Retainer	
3	1	H18S-6 Rod	
4	1	H18S-4 Piston	
5	1	H18S-RK-1 Wear Ring	*
6	1	H18S-RK-3 Static Seal	*
7	3	1103K1 Grease Fitting, Straight	
8	1	H18S-RK-4 Seal Backup	*
9	1	H18S-RK-5 Rod Seal	*
10	1	H18S-RK-6 Rod Wiper	*
11	1	H18S-RK-2 Piston Seal	*
12	2	H18S-RK-2A Backup, Piston Seal	*

#### H25 Hydraulic Filter Assembly



# H25 Hydraulic Filter Assembly

ITEM	QTY.	PART NO./DESC	PORT/DESC.	HOSE DESTINATION
1	1	Hydraulic Filter Body		
2	1	H25RC Indicator Fitting		
3	1	H25A Filter Element		
4	1	H25B Filter Canister		
5	2	2062-16-12S_16MORB x 12MJIC Fitting 90		
6	1	H52 Male Quick Disconnect		
7	1	HOS-1_1 MNPTx-12FJICx180.00lg16 Hose	Pressure Line, Power Unit	Right Port, Filter
8	1	HOS-112G_3.4MNPTx-12FJICx41.00lg12 Hose	Left Port, Filter	Main Press. Port, Man.

### H37S-2 Push Cylinder Assembly



### H37S-2 Push Cylinder Assembly

ITEM	QTY.	PART NO./ DESCRIPTION	COMMENTS
1	1	2006-10 Barrel	
2	1	2006-12 Seal Retainer	
3	1	2006-11 Rod	
4	1	2006-13 Piston	
5	1	1870-1250-312B Rod Seal	Repair Kit 061-H37S-2-RK
6	1	D-1250 Rod Wiper	Repair Kit 061-H37S-2-RK
7	1	TPO-24 Piston Seal	Repair Kit 061-H37S-2-RK
8	2	TPO-24 Backup, Piston Seal	Repair Kit 061-H37S-2-RK
9	1	MCD-2000-0500 W ear Ring	
10	1	2006-14 Piston Set Screw_1.4 x .25lg.	
11	1	2-326-90 O Ring	Repair Kit 061-H37S-2-RK
12	2	2062-8-8S_8MORB x 8MJIC Fitting 90	

## 100K-2GSR Hydraulic Pipe Clamp



## 100K-2GSR Hydraulic Pipe Clamp

ITEM	QTY.	PART NO./DESCRIPTION	DESTINATION	COMMENTS
1	1	20045A-10 Mount Plate Wldmnt		
2	1	20045A-15 Stepped Hook Wldmnt		
3	2	146 Thrust Bearing Assembly		
4	2	20208 Spacer Bushing, Roller		
5	2	20210 Roller Assembly		
6	2	20045A-6 Bolt, Roller Assy 1.5-13 x 2.75		
7	1	20045A-2 Bushing		
8	1	62205K29 Clevis,Rod		
9	1	806542-1_3.4-16 x 4.50 Hex Bolt		
10	1	1103K1 Grease Fitting, Straight		
11	2	PRP568-229 O Ring		
12	1	20029-1 Washer		
13	4	807493-125 Cotter Pin SST		
14	1	807493-250 Cotter Pin		
15	1	20229A Linkage Nut, Modified		
16	2	810703_1.2 Lock Washer		
17	3	20045A-24 Stud		
18	1	HOS-12G6FJICx-6FJICx85.00lg. Hose	Mid. Grip Cyl. Rod Side	
19	1	HOS-152G6FJICx-6FJICx75.00lg. Hose	Mid. Grip Cyl. Cap Side	
20	1	HV50R2NA Cylinder, SR		
21	1	62205K22 Pin		
22	1	806523_3.4-16 Flex Nut (31FK1216)		
23	2	203102-6-6S T Fitting		
24	2	2062-8-6S_6MORB x 4MJIC Fitting 90		

# 100K-2GSR H18 Top Grip Cylinder



### 100K-2GSR H18 Top Grip Cylinder

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
1	1	4E550A Grip Cylinder Tube	
2	1	5A223A Rod	
3	1	74005 Rod Head	
4	1	73384 Piston	
5	1	32172 Wear Ring	*
6	1	10323 U Cup Seal	*
7	1	14251 Cap Seal	*
8	1	14252 O Ring	
9	1	10005 Rod Wiper	*
10	1	10042 O Ring	*
11	1	20010 Lock Nut	
12	1	10032 O Ring	*
13	1	20027 Retainer Ring, Grip Tilt Cyl.	
14	1	10072 Back Up	*
15	1	14752 O Ring	*

#### 100K-2GSR Torque Manifold



# 100K-2GSR Torque Manifold

ITEM	QTY.	PART NO./DESC	PORT/DESC.	HOSE DESTINATION
1	1	20222 Torque Control Block, Modification		
2	1	J55A Torque Control Valve Assembly		
3	1	CXGD-XBN Check Valve		
4	1	900598-6S_MORB Plug		
5	2	2062-12-10S_12MORB x 10MJIC Fitting 90		
6	1	HOS-6A10FJICx-10FJICx87.00lg. Hose	PR1	Piston-Torque Cyl.
7	1	2047-2-2S 2MNPTX2FNPT Fitting 90 Drg Swivel		
8	1	30113 Orifice Fitting		
9	1	2081-4-2S 1.4 x 1.8 H.P. Hex Bushing		
10	1	2045-2-2S_2MNPT x 2FNPT Fitting Str. Swivel		
11	1	HOS-18A_1.8MNPTx1.8MNPTx50lg_1.8 Hose	GAGE-Torque Man	Gage Man. (See Explosion)

## 100K-2GSR Gage Manifold



## 100K-2GSR Gage Manifold

ITEM	QTY.	PART NO./DESC.	HOSE DESTINATION	COMMENTS
1	1	20275 Gage Manifold		
2	3	2047-2-2S 2MNPTX2FNPT Fitting 90 Drg Swivel		
3	1	2084-2S-3.4 Nipple, Hydraulic Plated		
4	1	H40F Hydraulic Q.D. Socket		
5	1	HOS-32_1.8MNPTx1.8MNPTx17.00lg_1.8 Hose	Gage	
6	1	H40M Hydraulic Q.D. Plug		
7	1	JHOS-OIL 1.8MNPTx1.8MNPTx83lg_1.8 Hose	Top Port, Torque Cyl. Block	
8	1	2082-2S_1.8 Pipe Plug		
9	1	HOS-18A_1.8MNPTx1.8MNPTx50lg_1.8 Hose	GAGE Port, Torque Cntr. Block	

# 100K-2GSR Winch Assembly



#### 100K-2GSR Winch Assembly

ITEM	QTY.	PART NO./DESCRIPTION	COMMENTS
2	1	061-W202-2-25 Worm Shaft	
3	1	061-W203-2-25 Bronze Gear	
4	1	061-W204 Drum	
6	1	061-W206 Gear Case Cover	
7	1	061-W207-K Yoke Kit	
8	1	061-W208 End Bearing	
10	1	061-W210-K Gear Case Cover Gasket Kit	
13	1	061-W213 Spring	
14	1	061-W214 Friction Block	
16	1	061-W216 Oil Seal	
17	2	061-W217 Key	
18	1	061-W218 Drum Shaft	
20	1	061-W220 Retaining Ring	
23	1	061-W223 Clutch Dog	
24	2	061-W224 Bearing Cap	
25	2	061-W225 Bearing Cone	
26	3	061-W226 Pipe Plug	
27	6	061-W227 Ht Cap Screw	
28	2	061-W228 Socket Set Screw	
29	1	061-W229 Socket Set Screw	
32	1	061-W232 Bearing Cap	
33	1	061-W233 Bearing Cone	
34	1	061-W234 Bearing Cap	
35	1	061-W235 Bearing Cone	
36	1	061-W255 Wide Spacer	
37	1	061-W237-K Motor Gasket Kit	
49	2	061-W249 Hex Head Screw	
50	1	061-4369 Key	
52	1	061-3847 Motor	
65	1	061-W265 Gear Case	
66	1	061-W266 Clutch Housing	
67	1	061-W267 Clutch Lever	
79	1	061-W279 Spring	
80	1	061-W280 Washer	

#### <u>NOTE</u>

When ordering winch parts, specify Serial No. and Model stamped on winch cover.

#### Notes

#### Maintenance Schedule

#### HAWK INDUSTRIES, INC.

#### HAWKJAW® RECOMMENDED MAINTENANCE CHECKLIST

Hawkjaw S/N: Rig Name: Maintenance Check Date:

Pipe Size: A TICK SHOWN IN THE CLEAR CELLS, WILL INDICATE THE ITEM WAS FOUND TO BE ACCEPTABLE Daily Wily 1 Mo

#### PLACE A TICK IN THE APPROPRIATE BOX ON THE RIGHT

Overall Visual Inspection					
CHECK THAT EMERGENCY STOP BUTTONS ARE OPERATIONAL					
Check all cables for broken strands					
Check pipe stop assy & indicator screws					
Check that die holders are greased and swiveling					
Check level of Middle Wrench for bearing wear					
Check for wear and grease dies					
Check for Hydraulic plumbing leaks					
Check spinner chain and grease (spray)					
Check Low Torque warning system					
Check Torque readings					
Activate & grease all wrench adjustment nuts					
Check & grease pivot pins behind adjustment nuts					
Check adjustment of spinner push cvl. & tightness of mounting bolts					
Check Hydraulic filter (Red button IN)					
Remove & check all pivot pins, sleeves & sleeve keepers					
Check angle brackets					
Check all Grip CvI mount bolts					
Check all linkage mount pins					
Check bolts on Stand Assy					
Check hoses on spinner assy					
Check die rollers & holders for position +hardware					
Check & grease spinner slide block					
Apply grease to all grease fittings & check if in place					
Check quick release pins on die holders					
Check wear grooves on spinner rollers					
PERFORM FUNCTION TEST					
Check ball thrust bearings					
Check spinner reducer bearing					
Check spinner push rod coupler					
Check level of spinner					
Check cylinder bumper					
Check winch oil level					
Check spinner gearbox oil level					
Check spinner mount thrust bearings					
Drain water seperator in air system					
Check tightness of all bolts & castle nuts					
Check all castle nuts for cotter pins					
Clean air filter dryers					
Check grip pressure (1000psi)					
Rotate Hooks					
Check welds on all Jaw Plates					
Change Spinner Reducer Oil (10W)					
Change Winch Gear Case Oil (90W)					
MPI, All Hook Threads (retest 12 mos) EXP DATE:					
MPI, Angle Brackets (retest 12 mos) EXP DATE:					
MPI, Hanger Assy (retest 12 mos) EXP DATE:					
Replace Bolt (p/n806510)& Nut (p/n806503) on Hanger Assy					
Remove & clean all end caps on BOSCH valves					
Torque Gauge Calibration:Next Calib. Date:S/N:					
Maintenance Inspection by:Workshop Supe	ervisor's	approva	l:	 	

2 Yrs

6 Mo

1 2.

Shop