
ACCUPRINT

AP42CL 8000 Closed Loop High Resolution Printer Service Manual



*This manual is designed for technical personnel
and should only be used by authorized Dealer
service personnel.*

*This manual is written to provide an
understanding of the equipment, as
well as a plan for troubleshooting.*

0. Contents

1. Specifications

Crated Dimensions	1-1
Shipping Weight	1-1
Actual Dimensions	1-1
Effective Exposure Frame Area	1-2
Intensity	1-2
Typical Room Requirements	1-2
Electrical specifications and connections	1-2
Connecting power to printer	1-4
Cooling Requirements	1-5

2. Cooling System

Connecting the Evaporator	2-1
Connecting the chiller	2-2
Filling the Closed Loop System	2-4
Checking the chiller	2-4
Closed Loop Cooling Assembly	2-6

3. Integrator Functions and Features

Integrator	3-1
Feature Quick Reference	3-3
Operator Control Panel	3-4
Table Showing the 12 Calibration Positions	3-4
Calibration Procedures	3-5
Changing the Calibration Number	3-6
Matching Exposure Surfaces	3-7
Splitting Steps	3-8
Matching with a meter	3-8

4. Integrator Program Set Up


To Enter the Select Mode	4-1
Lock Level Feature	4-1
Lock Level Description and Operation	4-2
Setting or Changing your Lock Code feature	4-3
To Clear Lamp Statistics	4-3
To Clear Memory and Exposure Statistics	4-3
Two Value Exposure Mode	4-4
Split Exposure Mode	4-4
Single Surface Mode	4-5
Board Count Display Mode	4-5
Frame Control Interface Mode	4-6
Automatic Vacuum Mode	4-6
Auto Step Mode	4-7
Set Default Vacuum Delay	4-7
Tray Mode	4-8

Type Mode	4-8
Exposure Statistics (Elapsed Hours)	4-9
Exposure Statistics (Total Exposures)	4-9
Selecting a Memory Location	4-10
Quick Keypad	4-10
Entering an Exposure Time	4-10
Setting the Light Intensity	4-11
Making an exposure	4-11
Blank frame cycle	4-11
Error Handling System	4-12
5. Diagnostics	
Output Diagnostics	5-1
Output Functions Check	5-1
Functions Table	5-2
Input Diagnostics	5-3
Typical values that you will see when all switches are good.	5-3
Typical values that you will see when a fault occurs.	5-4
6. Lamp Changing Instructions	
Lamp Changing Instructions	6-1
7. Preventive Maintenance	
Preventive Maintenance Daily	7-1
Preventive Maintenance Monthly	7-1
Preventive Maintenance Semi-Annually	7-1
8. Vacuum System	
Vacuum Pumps	8-1
Flushing the Pump	8-1
Pump Disassembly	8-2
Pump Check	8-2
Pump Replacement	8-3
Tubing/Fitting Replacement	8-4
Vacuum Gauge Replacement	8-4
Vacuum Seal Replacement	8-5
Phototool Wiring Diagram (optional)	8-7
9. Nose Assembly	
Removing the Left and Right Rail Covers	9-1
Replacing the Display and Keypad PC Board	9-1
Replacing the  Emergency Stop Button	9-1
Replacing the  and  Buttons	9-1
Replacing the Glass Tool Vacuum Buttons	9-2
Replacing the Vacuum Gauges	9-2
Nose Section Autoformer	9-2
Work Lights	9-3
Nose Fans	9-3
Cleaning or Replacing Nose Filters	9-3

Nose Assembly Drawings	9-4
Nose Assembly Left and Right Covers	9-6
10. Exposure Trays	
Mylar® Replacement	10-1
If Mylar® Pulls Out of the Frame.	10-1
Outer Frame Replacement	10-1
Tray Assembly Drawing	10-3
Outer Frame Assembly	10-5
Inner Frame Assembly	10-6
Gas Spring Removal and Replacement	10-7
Replacing the Linear Bearings	10-7
Frame Glass Replacement	10-8
11. Center/Drive Assembly	
Center/Drive Assembly Diagram	11-1
Tray Transport System	11-3
Tray Drive Motor Replacement	11-3
Tray Drive Clutch Adjustment	11-3
Tray Speed Adjustment	11-4
Light Block Assembly	11-6
Lower Light Block (insert section) Assembly Drawing	11-7
Replacing Light Block Springs	11-8
12. Diagrams	
Control Box Front View Typical	12-1
Control Box Wiring Diagram	12-2
Base Assembly Diagram	12-4
Unit Cabling Diagram (new style)	12-7
Unit Cabling Diagram (old style)	12-8
13. Light Source	
Component Layout	13-1
Ballast/Tap Switch Wiring	13-3
Path of Power to the PC Board	13-4
Interlock System	13-4
Lamp Voltage	13-5
Lamp Power Path	13-5
Trigger Board	13-6
Capacitors and Level Switching	13-6
Opening the Lamp Head	13-9
Shutter	13-9
Shutter Switch	13-10
Shutter Brake	13-10
Shutter Motor	13-10
Installing the Motor	13-11
Shutter Removal	13-12
LT8 Shutter Assembly Drawing	13-13

Idle Setting.....	13-14
Lamp Head Blowers	13-15
Blown Fuse on PC Board	13-15
Lamp Head Signals.....	13-16
Light Function States.....	13-18
Printed Circuit Board Layout	13-19
Signal Description	13-20
Circuit Diagram (64MV407 60Hz)	13-22
Lamphead for all Lights	13-23
AL 84 Power Supply 60Hz.....	13-24
AL 84-480 Power Supply 60Hz	13-25
AL 94 Power Supply 50Hz.....	13-26
Interconnect Cable	13-27
14. Printing Light Check List	
Check List for Printing Light Troubleshooting and Service	14-1
15. Fault Trees	
No Strike Fault Tree	15-1
Shutter Rotation Fault Tree	15-2
Drive Motor Fault Tree.....	15-3
16. Parts List	
Parts List	16-1
17. Warranty	
Limited Warranty	17-1
Lamp Warranty	17-1

1. Specifications



Crated Dimensions

Length	Width	Height
130"	78"	85"
330cm	198cm	216cm

Shipping Weight

Crated	2,400 lbs.	1089kg
Uncrated	2,000 lbs.	907kg

Actual Dimensions

Cabinet, welded heavy gauge steel construction, with access doors on both sides.

Length	Width	Height
110"	61"	99"
279cm	155cm	251cm

Note: The AP42CL can be disassembled (see Base Assembly Diagram) into 4 pieces if required to pass through most doorways or hallways. Please make sure there is adequate room for its passage.


Effective Exposure Frame Area

Width	42"	107cm
Depth	34"	86cm

Intensity





AP42CL-8000 Lamps can be operated at 8 kW, 5 kW, and 2 kW.

Typical Room Requirements



Electrical specifications and connections


3 phase (Wye)	See Figure A	3 wires + neutral + ground	380/415V~ 50 Hz, 24 amp.
3 phase (Delta)	See Figure B	3 wires + ground	208/240V~ 60 Hz, 44 amp.
3 phase (Delta)	See Figure C	3 wires + ground	480V~ 60 Hz, 18 amp.
Single phase	See Figure D	2 wires + ground	480V~ 60Hz, 35 amp.



Connecting power to printer

We recommend installing a circuit breaker box within easy reach of the operator.

- Install and run the main power cord through a strain relief then into the channel on the lower right rear of the printer and up to the power control box on the left side (see diagram below).
- Connect the main leads to the 4 position or 6 position terminal block and connect the ground lead to the single ground terminal (see Figures A,B,C,D).
- Reinstall the lower side door.



- Energize the main power circuit. You should hear the lamp head and power supply cooling fans go into a cool-down cycle. Ensure that the voltage select switch on the hinged control panel is switched to the lit LED.
- Install the lower front and rear black trim pieces over the forklift channels, using a $\frac{5}{32}$ " Allen wrench.

Cooling Requirements

Minimum pressure and flow rate of the chilled water depends on input temperature.



CAUTION  If water temperature and water flow do not meet the following specifications the unit will overheat, one or both light sources will shut themselves off randomly under heavy usage and damage to the unit could be the result.

- AP42CL-8000

Cooling Requirements	24,000 BTU / hr at idle	65,000 BTU / hr at full load
Water Pressure	26 PSI (20 GPM) minimum at 50°F (10°C)	10 PSI (10 GPM) minimum at 45°F (7°C)


2. Cooling System

Connecting the Evaporator

- Place the evaporator flat on the floor.
- Connect the hose from the evaporator to the bottom of the rear panel drain.



CAUTION  Make sure the hose end on the evaporator is lower than the bottom of the rear panel drain or moisture will collect in the bottom of the Closed Loop System.



- Attach the plate to rear of cabinet. Connect it to the 3 pin connector P63 marked "Evaporator" provided inside the unit.

Note: The evaporator is ON when the machine is ON.

- If the fan in the evaporator does not come ON when the machine is turned ON, unplug the electrical connector P8 on the evaporator and check with a voltage meter the P8 connector between pins 1 & 2 for 240V~.

If voltage is present and the blower is not running replace the blower.

If voltage is not present, go to the control box and unplug the J12 connector and measure for 240V~ between pins 3 & 4 on the board. If voltage is present, there is a break in the cable from the board to the evaporator and it needs to be replaced. If there is no voltage, replace the 64CT464 PCB in the Control Box.


Connecting the chiller



- Mount the Flow Meter and Temperature Gauge assembly on a wall in a horizontal position.

CAUTION  The Flow Meter and Temperature Gauge assembly must be mounted horizontal or the Flow Meter will not function properly.


- Connect the hose from the "Water in from Chiller" to the flow meter.




- Connect another hose from the temperature gauge to the "Closed Loop In".
- Connect the hose from the "Closed Loop Out" to the "Water out to Chiller".

Continued on next page

Connecting the chiller (cont.)



ITEM	QTY	DESCRIPTION :	OLEC PART #	NOTE
1	3	SOLENOID VALVE, TWO WAY	31S0V09	[5]
2	3	SOLENOID COIL	31S0V09-C240	
3	1	1/2" NPT BALL VALVE, (BLEED VALVE)	43FTT41	
4	5	1"HOSE ID.BARB-1"NPT MALE PIPE	43FTT42	
5	5	1"HOSE ID.BARB-3/4"NPT MALE PIPE	43FTT43	
6	1	1" NPT HEX NIPPLE - MALE	43FTT44	
7	8	1/2" NPT HEX NIPPLE - MALE	43FTT57	
8	3	REDUCER NIPPLE - MALE 3/4"-1/2"	43FTT46	
9	2	BUSHING - FEMALE TO MALE 1"-1/2"	43FTT58	
10	1	NIPPLE, FLOW METER (1"NPT)	12D3466A07	[1]
11	2	1" NPT FEMALE COUPLING	43FTT49	
12	1	NIPPLE, LONG 1/2"NPTx6"LONG	43FTT66	
13	2	MALE-FEMALE ELBOW 1"NPT	43FTT51	
14	3	FEMALE TEE 1"NPT	43FTT52	
15	3	1/2" NPT MALE BRANCH TEE	43FTT65	
16	1	FEMALE CROSS 3/4"NPT	43FTT54	
17	3	1/2" NPT BRAIDED HOSE, 20' lg.	49DCT38	
18	2	1/2" NPT FEMALE-FEMALE ELBOW	43FTT60	
19	10FT	BRAIDED CLEAR PVC TUBING	49DCT34	[2]
20	6	HOSE CLAMP FOR 1" HOSE	43CLM10	
21	3	1/2" NPT BRAIDED HOSE, 12" lg.	49DCT39	
22	2	MOUNTING PLATE	11D3382A62	
23	4	HOSE CLAMP, ø 1.5"-2"	43CLM13	
24	1	FLOW METER	49FLOW01	
25	1	TEMPERATURE GAGE	49THERM01	
26		TAPE, TEFLON 1/2" WIDTH	81TAP12	[3]
27	1	LABEL, FLOW DIRECTION (COLD)	15D3567A00	
28	1	LABEL, FLOW DIRECTION (HOT)	15D3567B00	
29	10FT	HOSE INSULATION 1.0"x 3/8" WALL	49DCT41	[8]





Filling the Closed Loop System

CAUTION  If the Closed Loop System is not filled properly the unit will overheat, one or both light sources will shut themselves off randomly under heavy usage and damage to the unit will be the result.

- Hook a hose to the bleed valve and put the hose end into a bucket.
- Turn the power on, and set the temperature level in the integrator program to 55°F to open the solenoid valves.
- Open the "outlet" valve and then the "inlet" valve of the chiller to allow the water into the heat exchangers.
- Slowly open the bleed valve to let the air out of the cooling system.
- Close the bleed valve when there are no more air bubbles in the system.
- Set the temperature in the program to appropriate level depending on application (approx. 70°F).

Note: This setting can be changed in the future for different applications.

- Once the system has been bled make sure the bleed valve is closed and remove the bleed valve handle.

Checking the chiller if the Closed Loop System is getting to hot or shutting itself down

- Make sure temperature and pressure in the system meets those in section Cooling Requirements.
- Make sure the air in the system is properly bled as described in Filling the Closed Loop System.
- Make sure the four blowers in the back of the unit are all spinning.

Turn the unit off and wait for the cool down cycle to finish.

Remove the upper and lower rear panels see DETAILS A and K in section Electrical Connections.

Remove the rear plate item 4 in section Closed Loop Cooling Assembly drawing and turn the unit on to inspect the blowers.

- Check the 3 flow solenoids feeding the heat exchangers to make sure they are operating.

Turn the unit off and wait for the cool down cycle to finish.

Open each side door and unplug the 5 pin din socket in the front of each light source power supply then close both doors.

Remove the bottom rear panel in the back of the unit.

When looking at the back of the unit locate the 3 flow solenoids on the left side just at the bottom of the top rear panel (see Closed Loop Cooling Assembly Item 5).



Pull the solenoid coils off the solenoid valve base, the coils are retained by a spring clip and should pull off easily, do not remove the spring clip from coils.

Set the thermostat on the inside of the unit to 100°F (20°C) and turn the unit on. The flow meter should read no flow.

Turn the unit off and reconnect one of the coils and turn the unit back on the flow meter should show water flowing through the unit. Turn the unit off and disconnect the coil. Repeat for each of the other two coils.

If water does not flow with any of the coils connected and you have the new style go to the J1 connector on the 64AX501V01 PCB and measure for 240V~ from pin 6 (white) to pin 3 (black) for valve #1, pin 6 (white) to pin 2 (green) for valve #2, and pin 6 (white) to pin 1 (red) for valve #3. If you have the old style go to the J2 connector on the 64CL489 PCB on top of the control box and measure for 240V~ from pin 2 (white) to pin 3 (black) for valve #1, pin 2 (white) to pin 6 (green) for valve #2, and pin 2 (white) to pin 5 (red) for valve #3.

Closed Loop Cooling Assembly



Continued on next page


Closed Loop Cooling Assembly (cont.)

DETAIL A 8 PLACES	DETAIL G 16 PLACES	DETAIL N 2 PLACES																																																												
DETAIL B 8 PLACES	DETAIL H 2 PL	<table><tr><td>44</td><td>12</td><td>1/4-20 X .75 HEX HD BOLT</td><td>41-F0BHX.75</td></tr><tr><td>43</td><td>1</td><td>BRACKET, ELECTR.</td><td>11D3857A17</td></tr><tr><td>42</td><td>1</td><td>BOX, ELECTR. COOLING MOD.</td><td>11D3984A17</td></tr><tr><td>41</td><td>4</td><td>FOAM, CLOSED CELL</td><td>72FOM43</td></tr><tr><td>40</td><td>8</td><td>5/16 SPLIT LOCK WASHER</td><td>41-F2WLS</td></tr><tr><td>39</td><td>8</td><td>5/16 FLAT WASHER</td><td>41-F10WFR</td></tr><tr><td>38</td><td>8</td><td>5/16-18 HEX NUT</td><td>41BF2NHX</td></tr><tr><td>37</td><td>8</td><td>5/16-18 X .75 HEX BOLT</td><td>41BF2BHX.75</td></tr><tr><td>36</td><td>1</td><td>BRACKET, UPPER</td><td>11D3920A17</td></tr><tr><td>35</td><td>1</td><td>STAND, PAN (WELDMENT)</td><td>11D3983A17</td></tr><tr><td>34</td><td>-</td><td>ADHESIVE, SPRAY</td><td>82ADH15</td></tr><tr><td>33</td><td>4</td><td>FOAM SHEET 1.0 X 24 X 60.0</td><td>72FOM42</td></tr><tr><td>32</td><td>4</td><td>6-32 WASHER, SPLIT LOCK</td><td>41 60WLS</td></tr><tr><td>31</td><td>4</td><td>#6-32 WASHER, FLAT</td><td>41 06WFR</td></tr></table>	44	12	1/4-20 X .75 HEX HD BOLT	41-F0BHX.75	43	1	BRACKET, ELECTR.	11D3857A17	42	1	BOX, ELECTR. COOLING MOD.	11D3984A17	41	4	FOAM, CLOSED CELL	72FOM43	40	8	5/16 SPLIT LOCK WASHER	41-F2WLS	39	8	5/16 FLAT WASHER	41-F10WFR	38	8	5/16-18 HEX NUT	41BF2NHX	37	8	5/16-18 X .75 HEX BOLT	41BF2BHX.75	36	1	BRACKET, UPPER	11D3920A17	35	1	STAND, PAN (WELDMENT)	11D3983A17	34	-	ADHESIVE, SPRAY	82ADH15	33	4	FOAM SHEET 1.0 X 24 X 60.0	72FOM42	32	4	6-32 WASHER, SPLIT LOCK	41 60WLS	31	4	#6-32 WASHER, FLAT	41 06WFR				
44	12		1/4-20 X .75 HEX HD BOLT	41-F0BHX.75																																																										
43	1		BRACKET, ELECTR.	11D3857A17																																																										
42	1		BOX, ELECTR. COOLING MOD.	11D3984A17																																																										
41	4		FOAM, CLOSED CELL	72FOM43																																																										
40	8		5/16 SPLIT LOCK WASHER	41-F2WLS																																																										
39	8		5/16 FLAT WASHER	41-F10WFR																																																										
38	8		5/16-18 HEX NUT	41BF2NHX																																																										
37	8		5/16-18 X .75 HEX BOLT	41BF2BHX.75																																																										
36	1		BRACKET, UPPER	11D3920A17																																																										
35	1		STAND, PAN (WELDMENT)	11D3983A17																																																										
34	-		ADHESIVE, SPRAY	82ADH15																																																										
33	4		FOAM SHEET 1.0 X 24 X 60.0	72FOM42																																																										
32	4		6-32 WASHER, SPLIT LOCK	41 60WLS																																																										
31	4	#6-32 WASHER, FLAT	41 06WFR																																																											
DETAIL C 4 PLACES	DETAIL J 10 PLACES	<table><tr><td>30</td><td>1</td><td>ASSY., UPPER COLLECTOR</td><td>11D4079A17</td></tr><tr><td>29</td><td>1</td><td>DUCT,INTAKE (UPPR.)</td><td>11D3685B17</td></tr><tr><td>28</td><td>1</td><td>LABEL, BLACK</td><td>15D509</td></tr><tr><td>27</td><td>6 ft.</td><td>FOAM TAPE, .5 x .12 THK.</td><td>81TAP18</td></tr><tr><td>26</td><td>1</td><td>CLAMP CABLE 1/2"</td><td>43CLM01</td></tr><tr><td>25</td><td>8 ft.</td><td>GASKET 1/16 THK.</td><td>44GKT01</td></tr><tr><td>24</td><td>1</td><td>BOX, ELECT. HANDY</td><td>43HBX02</td></tr><tr><td>23</td><td>1</td><td>COVER, ELECT. HANDY BOX</td><td>43BXC01</td></tr><tr><td>22</td><td>6</td><td>#8-32 HEX KEP NUT</td><td>41 08NKP</td></tr><tr><td>21</td><td>6</td><td>#8-32x.38 PHIL. PAN HD.</td><td>41 08PPS.37</td></tr><tr><td>20</td><td>46</td><td>#10 WASHER, FLAT</td><td>41 10WFR</td></tr><tr><td>19</td><td>12</td><td>#10 WASHER, SPLIT LOCK</td><td>41 10WLS</td></tr><tr><td>18</td><td>34</td><td>#10-32 HEX KEP NUT</td><td>41 12NKP</td></tr><tr><td>17</td><td>26</td><td>#10-32x.38 PHIL.PAN HD.</td><td>41 12PPS.37</td></tr><tr><td>16</td><td>4</td><td>1/4 WASHER, SPLIT LOCK</td><td>41 F0WLS</td></tr></table>	30	1	ASSY., UPPER COLLECTOR	11D4079A17	29	1	DUCT,INTAKE (UPPR.)	11D3685B17	28	1	LABEL, BLACK	15D509	27	6 ft.	FOAM TAPE, .5 x .12 THK.	81TAP18	26	1	CLAMP CABLE 1/2"	43CLM01	25	8 ft.	GASKET 1/16 THK.	44GKT01	24	1	BOX, ELECT. HANDY	43HBX02	23	1	COVER, ELECT. HANDY BOX	43BXC01	22	6	#8-32 HEX KEP NUT	41 08NKP	21	6	#8-32x.38 PHIL. PAN HD.	41 08PPS.37	20	46	#10 WASHER, FLAT	41 10WFR	19	12	#10 WASHER, SPLIT LOCK	41 10WLS	18	34	#10-32 HEX KEP NUT	41 12NKP	17	26	#10-32x.38 PHIL.PAN HD.	41 12PPS.37	16	4	1/4 WASHER, SPLIT LOCK	41 F0WLS
30	1	ASSY., UPPER COLLECTOR	11D4079A17																																																											
29	1	DUCT,INTAKE (UPPR.)	11D3685B17																																																											
28	1	LABEL, BLACK	15D509																																																											
27	6 ft.	FOAM TAPE, .5 x .12 THK.	81TAP18																																																											
26	1	CLAMP CABLE 1/2"	43CLM01																																																											
25	8 ft.	GASKET 1/16 THK.	44GKT01																																																											
24	1	BOX, ELECT. HANDY	43HBX02																																																											
23	1	COVER, ELECT. HANDY BOX	43BXC01																																																											
22	6	#8-32 HEX KEP NUT	41 08NKP																																																											
21	6	#8-32x.38 PHIL. PAN HD.	41 08PPS.37																																																											
20	46	#10 WASHER, FLAT	41 10WFR																																																											
19	12	#10 WASHER, SPLIT LOCK	41 10WLS																																																											
18	34	#10-32 HEX KEP NUT	41 12NKP																																																											
17	26	#10-32x.38 PHIL.PAN HD.	41 12PPS.37																																																											
16	4	1/4 WASHER, SPLIT LOCK	41 F0WLS																																																											
DETAIL D 12 PLACES	DETAIL K 6 PLACES	<table><tr><td>15</td><td>4</td><td>1/4-20x.62 BUTN. HD.SCREW</td><td>41BF0SHC.62</td></tr><tr><td>14</td><td>12</td><td>1/4 WASHER, FLAT</td><td>41 40WFR</td></tr><tr><td>13</td><td>8</td><td>1/4-20 NUT, HEX NYLON LOCK</td><td>41B40NLN</td></tr><tr><td>12</td><td>6</td><td>#6-32x.38 PHIL.PAN. HD.</td><td>41 06PPS.38</td></tr><tr><td>11</td><td>2</td><td>HEAT EXCHANGER 34"</td><td>39HTX01</td></tr><tr><td>10</td><td>4</td><td>BLOWER, 495 CFM</td><td>39BLO17</td></tr><tr><td>9</td><td>2</td><td>COVER, REAR (LOWER)</td><td>11D3687A08</td></tr><tr><td>8</td><td>1</td><td>COVER, REAR (UPPER)</td><td>11D3980A08</td></tr><tr><td>7</td><td>1</td><td>MIDWALL, COOLING MOD.</td><td>11D3982A17</td></tr><tr><td>6</td><td>4</td><td>BRACKET, MOUNT</td><td>11D3371A62</td></tr><tr><td>5</td><td>1</td><td>MOUNTING PLATE, VALVES</td><td>11D3382A62</td></tr><tr><td>4</td><td>1</td><td>PLATE, REAR (BLOWERS)</td><td>11D3381A17</td></tr><tr><td>3</td><td>2</td><td>PANEL, SIDE (HEAT EXCH.)</td><td>11D3374A17</td></tr><tr><td>2</td><td>1</td><td>DUCT,INTAKE (LOW.HEAT EXCH.)</td><td>11D3685A17</td></tr><tr><td>1</td><td>1</td><td>FRAME, WELDMENT</td><td>11D3981A08</td></tr></table>	15	4	1/4-20x.62 BUTN. HD.SCREW	41BF0SHC.62	14	12	1/4 WASHER, FLAT	41 40WFR	13	8	1/4-20 NUT, HEX NYLON LOCK	41B40NLN	12	6	#6-32x.38 PHIL.PAN. HD.	41 06PPS.38	11	2	HEAT EXCHANGER 34"	39HTX01	10	4	BLOWER, 495 CFM	39BLO17	9	2	COVER, REAR (LOWER)	11D3687A08	8	1	COVER, REAR (UPPER)	11D3980A08	7	1	MIDWALL, COOLING MOD.	11D3982A17	6	4	BRACKET, MOUNT	11D3371A62	5	1	MOUNTING PLATE, VALVES	11D3382A62	4	1	PLATE, REAR (BLOWERS)	11D3381A17	3	2	PANEL, SIDE (HEAT EXCH.)	11D3374A17	2	1	DUCT,INTAKE (LOW.HEAT EXCH.)	11D3685A17	1	1	FRAME, WELDMENT	11D3981A08
15	4	1/4-20x.62 BUTN. HD.SCREW	41BF0SHC.62																																																											
14	12	1/4 WASHER, FLAT	41 40WFR																																																											
13	8	1/4-20 NUT, HEX NYLON LOCK	41B40NLN																																																											
12	6	#6-32x.38 PHIL.PAN. HD.	41 06PPS.38																																																											
11	2	HEAT EXCHANGER 34"	39HTX01																																																											
10	4	BLOWER, 495 CFM	39BLO17																																																											
9	2	COVER, REAR (LOWER)	11D3687A08																																																											
8	1	COVER, REAR (UPPER)	11D3980A08																																																											
7	1	MIDWALL, COOLING MOD.	11D3982A17																																																											
6	4	BRACKET, MOUNT	11D3371A62																																																											
5	1	MOUNTING PLATE, VALVES	11D3382A62																																																											
4	1	PLATE, REAR (BLOWERS)	11D3381A17																																																											
3	2	PANEL, SIDE (HEAT EXCH.)	11D3374A17																																																											
2	1	DUCT,INTAKE (LOW.HEAT EXCH.)	11D3685A17																																																											
1	1	FRAME, WELDMENT	11D3981A08																																																											
DETAIL E 4 PLACES	DETAIL L 4 PLACES	<table><tr><td>ITEM</td><td>QTY</td><td>DESCRIPTION</td><td>PART NO.</td></tr></table>	ITEM	QTY	DESCRIPTION	PART NO.																																																								
ITEM	QTY	DESCRIPTION	PART NO.																																																											
DETAIL F 14 PLACES	DETAIL M 6 PLACES																																																													

3. Integrator Functions and Features

Microprocessor-controlled light integrator with LED display, 40 memories, battery backup, single button control, lamp statistics and self-diagnostics. The operator control panel is composed of two sections, the display board and the memory board.

Note: The number of digits in each window.




Memory Window

Vacuum Window

Exposure Window

Integrator



POWER

Press the power button on the integrator to turn the AP 42CL on or off. When the unit is off, the light system blowers will run for about two minutes to cool the lamp.

MEMORY

Pressing the memory key will advance the memory location. The display will show which memory is selected.

VACUUM

Press the vacuum key and use the numerical keypad to enter a vacuum delay time. The window shows the delay in seconds.

EXPOSURE

Press the exposure key and use the numerical keypad to enter an exposure. The window shows the exposure units selected. This key can also be used to move forward through the selectable features in the setup mode.

INTENSITY

Press this key to select Low, Medium or High power. LEDs lit will indicate the level selected.

DIFFUSER

Press this key to select the motorized diffuser option.

FILTER

Press this key to select the motorized filter option.

SECONDS

Press this key to expose by time, not integrated light units. This key also can be used to move backward through selectable features in the setup mode.



MENU

This key is used as the autostep indicator and for the continuous vacuum feature.


Note: **MENU Special Function**

The  key has the optional function to be used to set auto-step and continuous vacuum per memory in normal operating mode. The frame control switch feature must be turned ON and the automatic vacuum feature must be turned OFF. Press the  key the memory window will read  and the exposure window will read . Press the  key to turn auto-step function ON or OFF. Press the  key the memory window will read  and the exposure window will read . Press the  key to turn continuous vacuum function ON or OFF.



MEASURE

This key is used to check the lamp intensity.



NUMERICAL KEYPAD

These keys are used to enter the vacuum time, exposure units, and to access a particular memory location.



INSTANT MEMORY KEYPAD

The OV 45/33HD has 40 independent memory locations, the first ten of which are on the lower section of the integrator for instant access. There is a space provided to write down the application of these memories. Simply press the lower  through  key that corresponds to the most commonly used applications.

Feature Quick Reference

The following feature descriptions appear in the exposure window while setting each feature. In order to select or setup the following features you must first be in the setup mode.

The text 'Lock' is displayed in a stylized, segmented font within a rectangular frame.

Lock Level Feature

The text 'code' is displayed in a stylized, segmented font within a rectangular frame.

Lock Code Feature

The text '2VAL' is displayed in a stylized, segmented font within a rectangular frame.

2 (two) Value Exposure Feature

The text 'SPILT' is displayed in a stylized, segmented font within a rectangular frame.

Motorized Filter Feature

The text 'SSUR' is displayed in a stylized, segmented font within a rectangular frame.

Single Surface Exposure Feature

The text 'bcnt' is displayed in a stylized, segmented font within a rectangular frame.

Exposure Count Feature

The text 'FCL' is displayed in a stylized, segmented font within a rectangular frame.

Frame Control Switch Feature

The text 'AVAC' is displayed in a stylized, segmented font within a rectangular frame.

Automatic Vacuum Feature

The text 'ASTP' is displayed in a stylized, segmented font within a rectangular frame.

Auto Step Feature

The text 'dual' is displayed in a stylized, segmented font within a rectangular frame.

Vacuum Delay Feature


The text 'LrAY' is displayed in a stylized, segmented font within a rectangular frame.

Frame Speed Feature

The text 'LYPE' is displayed in a stylized, segmented font within a rectangular frame.

System Type Setting Feature

Operator Control Panel



The AP 30 heavy duty exposure system has a power key on the integrator.

- Press the  key to turn on the unit.
- Press the  key again after use, and the system will run through a 2 minute cool down cycle and then turn off all blowers.

STOP Button


- Press the  button once. Frame movement will stop.
- Press the  button once more, the frame will return, at slow speed, to the original position and vacuum will turn off.
- Press the  button twice to cancel an exposure.
- Holding the  button down then pressing the  button starts a blank cycle - no vacuum or exposure.

GO Button

- Press the  button once to initiate vacuum drawdown on the exposure frame.
- Press the  button a second time to move the frame into the unit and start an exposure.
- If frame switch  and auto vacuum  are turned on, press the  button once to move the frame into the unit and start an exposure.
- If frame switch  and auto vac  are turned on, press the  button once without opening the upper or lower frame will start a blank frame cycle - no vacuum or exposure.

Note: If a vacuum delay  is used, the exposure will not begin until the vacuum delay time has counted down.

Table Showing the 12 Calibration Positions



Upper Frame, Top Surface
Upper Frame, Bottom Surface
Lower Frame, Top Surface
Lower Frame, Bottom Surface

1st	5th	9th
2nd	6th	10th
3rd	7th	11th
4th	8th	12th

Calibration Procedures

Note: The AP42 high resolution printer has been calibrated at the factory.

Note: The following calibration procedures can be applied to all three light intensities, if starting calibration from scratch. To adjust existing calibration set the integrator to 500 mj and make the exposure. Increase or decrease the calibration number the same percentage the 500 mj is off.

- Press the  key on the integrator to power up the lights, the front switches, and the printer's computer system.

Note: Allow the printer a 5 minute warm-up period before any calibration procedures. This will allow for complete and accurate light level stabilization.

- Press the integrator  key to select the desired light level to be calibrated, always start at Low Intensity.

For 8kW	Low 2000 W	Medium 5000 W	High 8000 W
---------	------------	---------------	-------------

- In order to prevent possible damage to the high resolution printers Mylar® while calibrating we recommend you set the no vacuum feature.
- Press the  key on the keypad, the Memory and Exposure windows will dim.
- Press the  key three times.
- Press the  key once. This will prevent vacuum while calibrating. The Vacuum window will read .
- The high resolution printer's calibration has been set at the factory.

Upper frame top surface



Upper frame bottom surface



Lower frame top surface



Lower frame bottom surface



Note: Preset all 12 calibration factor numbers to 500 units. Place a slim UV meter facing up on the center of the top frame, below the Mylar®.

- Enter a 500 unit exposure into the integrator. Be sure the seconds mode is off.

- Press the  button twice. This will send the frame into the unit and start the exposure.
- After the exposure, retrieve your frame by holding down the  button and press  button. When the frames start to move, release both buttons.
- Record the resulting mj reading from the meter.

Example: Let's say our 500 unit exposure gave us 600 mj. That means we got 1.2 mj per unit or a 1.2:1 ratio. The objective is to get a 1:1 ratio. To get that we would multiply our current calibration number of 500 by 1.2, $500 \times 1.2 = 600$.

- Since we are working with the Upper Tray Top Surface or , we have to change the preset 500 to 600.
- Change to 600 as described earlier in Calibration Procedures Section.

Remember: The lower the CAL number, the longer the exposure and the higher the mj reading.

- Now make a 500.0 unit exposure with the UV meter and record the resulting mj reading. It should be $500 \pm 3\%$. Perform this procedure on the remaining three surfaces.



Press , ,  then  on the numerical keypad. The Vacuum window will read . This places you in select mode.

- Press the  key once and press the  key to clear, then  key, then the  key to activate the vacuum after being turned off earlier in this procedure.

Changing the Calibration Number

- Press the  key on the integrator. The Memory window will read , the Exposure window will show the existing calibration number for the top surface of the upper frame at the selected intensity.
- Press the  key to select frame surface (, , , ).

Remember: For top frame calibration use  and  and for bottom frame calibration use  and . Also, the larger the calibration number the faster that surface will count and the less accumulated energy will result on the frame.

- Enter the new calibration number on the desired surface by pressing  key to open the program, then use numerical keypad.

Example: To change  from 500 to 650 simply press , , , .

- Press the  key to close the program.
- Press the  key twice to return to the operating mode.

Matching Exposure Surfaces

- Do a test exposure in the frame being calibrated to the reference frame.
- Determine the correction necessary to make each surface the same at the reference surface. If this is done with a step scale the correction is as follows.

.15 Density Scale	
Step	Correction
-2.00	0.50
-1.75	0.55
-1.50	0.60
-1.25	0.65
-1.00	0.71
-0.75	0.77
-0.50	0.84
-0.25	0.92
0.00	1.00
0.25	1.09
0.50	1.19
0.75	1.30
1.00	1.41
1.25	1.54
1.50	1.68
1.75	1.83
2.00	2.00

.05 Density Scale	
Step	Correction
-2.00	0.79
-1.75	0.82
-1.50	0.84
-1.25	0.87
-1.00	0.89
-0.75	0.92
-0.50	0.94
-0.25	0.97
0.00	1.00
0.25	1.03
0.50	1.06
0.75	1.09
1.00	1.12
1.25	1.15
1.50	1.19
1.75	1.22
2.00	1.26



Press 1, 2, 3 then 4 on the numerical keypad. The Vacuum window will read SEL. This places you in select mode.

- Then press the ⏏ key and the exposure window will show previous calibration number. There is a separate number for each intensity. Select the intensity to be adjusted with the ⏏ key.
- Read the current calibration number and multiply it times the correction. For example if you double the calibration number, the integrator will count twice as fast consequently the exposure energy will be cut in half.



Press 1, 2, 3 then 4 on the numerical keypad. The Vacuum window will read SEL. This places you in select mode.


Then press the ⏏ key and the exposure window will show previous calibration number. (for example 1063).

- Press the ⏏ key, the memory window will dim and you will be able to enter the new calibration number by pressing the new number into the key pad.

Splitting Steps

A densitometer can be used to assist in determining a fractional difference in step scales. When measuring density, make several measurements to avoid being influenced by pinholes.

Example



- Pick a step from the reference with a density greater than .15 and less than 2.0.
- Find the steps on the second scale that straddle the first. In the example the reference is .30, step "A" is .24 and step "B" is .40. $(\text{Ref.} - A) / (B - A) = .06 / .16 = .375$. The example step is .375 steps under the reference.

Matching with a meter

If an integrating meter is available that has a photocell that matches the film, it can be used to match the surfaces. We recommend that the results be verified on film.

- Make a reading on the reference surface and then the surface to be adjusted.
- Divide the reading on the surface to be adjusted by the reading from the reference surface.
- Multiply the current calibration number by the result above.

4. Integrator Program Set Up

To Enter the Select Mode

Note: This step must be followed in several of the program set ups.

- Press the  key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.



Press , ,  then  in sequence. The Vacuum window will read . This places you in the select mode.

Lock Level Feature

The lock levels are provided to keep operators from accessing any features and functions that should be left alone. There are five different lock levels available. Lock levels 1 - 3 allow the locking of individual memory locations, while lock levels 0 and 4 apply to all of the memory locations.

- Level 0 - No locks. Most of the features and functions can be accessed by any operator.
- Level 1 - Locks functions per memory (seconds, exposure, vacuum, intensity, filter, diffuser) to prevent accidental changes to these settings. Locks on individual memories may be turned ON and OFF without the need to enter a code.
- Level 2 & 3 - Locks functions per memory similar to lock level 1, except once lock is turned ON for a particular memory, it may not be turned OFF again without entering the lock code. Also locks the parameters on the set up menu so they cannot be changed without entering the lock code.
- Level 4 - Locks all functions. A code is required to change any operating parameters.

Note: You *must* ensure the lock level is set to 0 before continuing with the Integrator Program Set Up Features and the exposure memory options detailed below in Lock Level Description and Operation. When programming is completed return to Lock Level Feature and set the desired lock level.

- Press the  key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.



Press , ,  then  in sequence. The Vacuum window will read . This places you in the select mode.

Press the  key once, the Exposure window will read .


- Press the  key once.
- If the Lock Level is set at 0 or 1 the Memory and Exposure windows will

dim. Enter the lock level desired.

- Press the  key to set entry.
- If the Lock Level is set for 2, 3 or 4, the Exposure window will read . Enter your 3 digit code.
- Press the  key.
- Press the  key.
- Press the  key.

Note: If you want a higher Lock Level after you have completed the Integrator Program Set Up and/or made any changes return to Lock Level Feature and set the lock level described in Lock Level Description and Operation.

Lock Level Description and Operation



Lock Level 0

The Vacuum window will read .

Lock Level 1

The Vacuum window will read . Locks functions for seconds, enter, vacuum and intensity per memory. Once this mode is turned ON and the set up programing has been completed, enter all needed information into a memory location. Then press the  key, the Memory window will read  and the Exposure window will read . Press the  key to turn the lock for this memory ON or OFF, then press the  key. When the lock is turned ON, a decimal point will be displayed after each digit in the Memory window.



Lock Level 2, 3

The Vacuum window will read  or . Locks functions for seconds, enter, vacuum and intensity per memory and Integrator Program Set Up Features. Before this mode is turned ON, enter all needed information into a memory location. Then press the  key, the Memory window will read , the Vacuum window will read  and the Exposure window will read . Press the  key to turn the lock ON or OFF for this memory. When the lock is turned ON a decimal point will be displayed after each digit in the Memory window. Once this level is turned ON you will not be able to unlock the features described above without the Lock Code. See Setting or Changing your Lock Code Feature.



Lock Level 4

The Vacuum window will read . This locks all functions. When the lock is turned ON, a decimal point will be displayed after each digit in the Memory window. Once this level is turned ON and the set up programing has been completed, before you can change any programmed features or the exposure statistics you must use the Lock Code to set the Lock Level back to 0, see Setting or Changing your Lock Code Feature.

Setting or Changing your Lock Code feature

Note: If you are setting the code you must know the existing code.

Note: Lock Level *must* be set to 0 to program this step and reset when finished see Lock Level feature.

A digital display showing the characters 'SEL' in a stylized, segmented font.A digital display showing the characters 'code' in a stylized, segmented font.

- Press the  key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.
Press , ,  then  in sequence. The Vacuum window will read . This places you in the select mode.
- Press the  key once. The Memory window will read .
Press and release the  key until the Exposure window reads .
- Press the  key the Memory and Exposure windows will dim. Enter your new 3 digit code
- Press the  key to set entry.
- Press the  key twice to exit this mode.

To Clear Lamp Statistics



CAUTION

This step clears all lamp statistics explained in sections Lamp Statistics.

Note: You can abort clearing the lamp statistics by pressing the  key before the display counts down to  and you will not change any memory and exposure statistics.

Note: Lock Level *must* be set to 0 to program this step and reset when finished, see Lock Level feature.

A digital display showing the characters 'SEL' in a stylized, segmented font.

- Press the  key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.
Press , ,  then  in sequence. The Vacuum window will read . This places you in the select mode.
- Press the  key five (5) times.
- Press the  key once to exit this mode.

To Clear Memory and Exposure Statistics



CAUTION

This step clears all information stored in the memory.

Note: You can abort clearing the memory by pressing the  key before the display counts down to  and you will not change any memory and exposure statistics.



- Press the key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.
Press , , then in sequence. The Vacuum window will read . This places you in the select mode.
- Press the key five (5) times.
- Press the key once to exit this mode.

Two Value Exposure Mode

Note: The two value mode enables the operator to run a different job or resist on each frame. With this feature turned ON, a value entered in the Vacuum window becomes an exposure value. For instance, if you enter 800 in the Vacuum window and 450 in the Exposure window, during an exposure both surfaces on the upper frame will receive 800 mj while both surfaces on the lower frame will receive 450 mj. To activate this option:



- Press the key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.
Press , , then in sequence. The Vacuum window will read . This places you in the select mode.
- Press the key once. The Memory window will read .
Press and release the key until is displayed in the Exposure window.
- Press the key to cycle mode ON or OFF.
- Press the key twice to exit this mode.

Split Exposure Mode

The split exposure mode works in conjunction with the previously mentioned two value mode. It enables the user to select separate exposure values for the upper and lower surfaces of each frame, in case different exposures are required for each surface of the panel. An exposure can be entered in the center display which will be used on the top surface of each frame and a separate exposure value can be entered in the lower display which will be used on the bottom surface of each frame.

Note: The two value mode MUST be selected ON for the split exposure mode to function.



- Press the key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.
Press , , then in sequence. The Vacuum window will read . This places you in the select mode.
- Press the key once. The Memory window will read .

Press and release the e key until SPILT appears in the Exposure window. This places you in the split exposure option.

- Press the key to cycle the split exposure mode ON or OFF.
- Press the key twice to exit this mode.

Single Surface Mode

The printer may be programmed to use the top light only, the bottom light only, or both lights. For exposing phototools or single sided exposures, you may want to use only one light. Each of the 40 memories is independent, to allow for any combination you wish on a particular memory. While programming:

- Press the key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.

Press , , then in sequence. The Vacuum window will read SEL. This places you in the select mode.

- Press the key once. The Memory window will read SU.

Press and release the e key until SSUR appears in the Exposure window. This places you in the single surface mode.

- Press the key to turn the single surface option ON or OFF.
- Press the key twice to exit this mode.

Note: Press the key to activate feature in operating mode so that the Memory display reads RC and the Exposure display reads [SURF]. Press the key to select bottom bot, top top or both both. Now press the key. If you have selected both lamps, the left memory digit is complete and means upper and lower lamps are selected. If you have top lamp only, the left memory digit displays upper segment only and means only the upper lamp is selected. If the left memory digit displays lower segment only it means only the lower lamp is selected.

Board Count Display Mode


The printer will constantly display all the exposure information. With the board count display option turned ON, the Vacuum window will show a running total of the number of exposures that have taken place. This can be very useful in verifying that all exposures were made for a particular job.

Note: It is recommended to leave this feature OFF when the two value or split features are activated. To activate the board count display option:

- Press the key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.

A digital display showing the text "SEL" in a stylized, segmented font.A digital display showing the text "bent" in a stylized, segmented font.


Press , ,  then  in sequence. The Vacuum window will read . This places you in the select mode.

- Press the  key once. The Memory window will read .
Press and release the e key until  appears in the Exposure window. This places you in the board count option.
- Press the  key to cycle the board count ON or OFF.
- Press the  key twice to exit this mode.

Frame Control Interface Mode

The frame control interface works in conjunction with each frame's magnetic switch. If either frame is open, motorized transport will not function. This prevents inadvertent frame movement with the outer frame open. It is recommended that this safety feature be turned ON at all times. In the event of a switch failure or a unit without switches, it can be bypassed.

Note: This safety feature will always be ON unless you turn it OFF. To deactivate the frame control interface mode:

- Press the  key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.
Press , ,  then  in sequence. The Vacuum window will read . This places you in the select mode.
- Press the  key once. The Memory window will read .
Press and release the e key until  appears in the Exposure window. This places you in the frame control interface mode.
- Press the  key to cycle the frame control interface mode ON or OFF.
- Press the  key twice to exit this mode.

Automatic Vacuum Mode

The automatic vacuum mode allows the printer to start vacuum automatically by closing the frame. If a preset vacuum delay is used, such as default vacuum delay, the center display will show the vacuum countdown. The  button then only needs to be pressed once to start frame movement. With this feature turned ON, a blank frame cycle will be initiated simply by pressing the  button once when the frame has not been opened. To activate this option:

- Press the  key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.
Press , ,  then  in sequence. The Vacuum window will read . This places you in the select mode.
- Press the  key once. The Memory window will read .

A digital display showing the text "SEL" in a stylized, segmented font.



Press and release the e key until **AVAL** appears in the Exposure window. This places you in the automatic vacuum option.

- Press the key to cycle the automatic vacuum mode ON or OFF.
- Press the key twice to exit this mode.

Auto Step Mode

Note: This feature allows you to run a series of exposures in sequence.

Note: If Auto Step is selected, the LED over the key will indicate if the feature is ON or OFF. If ON, press the key to turn it OFF.

- Press the key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.



Press , , then in sequence. The Vacuum window will read **SEL**. This places you in the select mode.

- Press the key once. The Memory window will read **SW**.



Press and release the key until **ASTP** appears in the Exposure window. This places you in the autostep option.

- Press the key to cycle the Auto-Step mode ON or OFF.
- Press the key twice to exit this mode.

Set Default Vacuum Delay

Note: This feature is used to provide sufficient vacuum drawdown time before exposure. The time begins when the frame lid is closed with the **AVAL** turned ON, or when you press the button for the first time. If you press the button again before the vacuum delay counts down, the frame will move into the cabinet, but the exposure will not start until the time is completed.

Note: This default delay time will be ignored if a delay time other than 0 has been programmed into the memory location being displayed.

- Press the key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.



Press , , then in sequence. The Vacuum window will read **SEL**. This places you in the select mode.

- Press the key once. The Memory window will read **SW**.



Press and release the key until the Exposure window reads **dVAL**.

- Press the key and enter the time you wish the vacuum turned ON before the exposure begins. The time you selected has now been programmed for all memories.
- Press the key twice to exit this mode.

Tray Mode



CAUTION

The default tray speed is set at the factory to 5 seconds. OLEC does not recommend changing this setting without consulting the OLEC factory. Damage to the transport can occur.

SEL

TRAY

- Press the key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.
Press , , then in sequence. The Vacuum window will read . This places you in the select mode.
- Press the key once. The Memory window will read .
Press the key until appears in the Exposure window.
- Press the key once. The Vacuum window will read and the Exposure window will read . If lock mode was turned ON, enter your code now, then press the key, (If the lock code has never been changed *section 4.3*, the default code is 000).
- Enter the time you wish to have the tray speed set for. For example, for a 5.0 second travel time, press , and then press the key again the Memory window and Exposure window will return to normal brightness.
- Press the key twice to exit this mode.

Type Mode



CAUTION

The type has been set at the factory and should not be changed. Proper operation of the unit will be affected if changed.

SEL

TYPE

AP30

- Press the key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.
Press , , then in sequence. The Vacuum window will read . This places you in the select mode.
- Press the key once. The Memory window will read .
Press the key until appears in the exposure window. This places you in the System Type option.
- Press the key once. The Vacuum window will read and the Exposure window will read . If lock mode was turned ON, enter your code now, then press the key, (If the lock code has never been changed, the default code is 000).
Press the V key to cycle the Vacuum window to read [AP30]. This setting applies to both the AP30 5kW and AP30 8kW, air conditioned and closed loop models.
- Press the key twice to exit this mode.

Exposure Statistics (Elapsed Hours)


Note: The exposure statistics should be reset to zero when the lamps are changed.

Note: This provides the operating hours on the lamps in total and at each intensity since the last reset. This function should be used whenever the exposure lamps are replaced.

- Press the  key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.



Press , ,  then  in sequence. The Vacuum window will read . This places you in the select mode.



Press the  key. The letters  will appear in the Vacuum window. The Exposure window will display the exposure time, in seconds, of the last exposure, regardless of its memory position or intensity.



Press the  key a second time, the letters  will appear in the Vacuum window. The total elapsed time, in hours, that the unit has been ON will be displayed in the Exposure window.



Press the  key a third time. The letters  will appear in the Vacuum window. The elapsed time, in hours, that the lamp has been used at medium power will show in the Exposure window.



Press the  key a fourth time. The letters  will appear in at the Vacuum window. The elapsed time, in hours, that the lamp has been used at low power will show in the Exposure window.



Press the  key a fifth time. The letters  will appear in the Vacuum window. The elapsed time, in hours, that the lamp has been used at high power will show in the Exposure window.

- Press the  key twice to exit this mode.

Exposure Statistics (Total Exposures)

Note: To find out how many exposures your system has made since the last reset.

Note: The exposure statistics should be reset when the lamps are changed.

- Press the  key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.



Press , ,  then  in sequence. The Vacuum window will read . This places you in the select mode.



Press the key. The letters will appear in the Vacuum window. The Exposure window will display the number of exposures made at high power.

Press the key a second time. The letters will appear in the Vacuum window. The Exposure window will display the number of exposures at low power.

Press the key a third time. The letters will appear in the Vacuum window. The number of exposures at medium power will be displayed in the Exposure window.


- Press the key twice to exit this mode.

Selecting a Memory Location

- Press and release the key on the operator control panel to cycle through the 40 memory locations (0-39).
- You may go to a particular memory by entering the desired memory number on the numerical keypad on the integrator.

EXAMPLE: Enter a desired memory number, e.g. 12. Press the corresponding keys, 1 then 2 on the numerical keypad, then press the Y key.

Quick Keypad



Instant access by pressing any of the memory locations from 0 to 9.

Entering an Exposure Time

Press the key on the integrator.


Note: The Memory and Vacuum windows will dim.



Enter desired exposure time by depressing corresponding number on keypad. For example , , ,

- Press the key to confirm the entry.

Setting the Light Intensity



- Press the key to set intensity. Press for the first time. The first LED on the left indicates the intensity is set to low 2kW.
- Press: for the second time. The first two LEDs light to indicate the intensity is set to medium 4kW.
- Press: key for the third time. All three LEDs light to indicate the intensity is set to high 8kW.

Optional: Press the key to set for time or integrate mode. The LED ON indicates a timed exposure and OFF an integrated exposure.

Note: During operation, ensure that the mode is OFF.

Making an exposure

Place material in the exposure frame and close the frame.

- If and options are turned ON, vacuum will start automatically when the frame is closed. If and are OFF, press the button to start vacuum. The upper or lower vacuum gauge will indicate the vacuum level for the appropriate frame.
- Examine both sides of the frame to check the vacuum drawdown visually.
- When good vacuum contact is assured, press the button to move the frame into the cabinet and start exposure. If second frame has been examined press the button and the frame will go into the cabinet (The frames will not move if the previous exposure is still in progress.)
- Remove the material from the frame that was previously exposed and repeat for the next exposure.
- To stop the frame after it has started moving, press the button once. To retrieve it, press again, or to continue with the exposure, press the button. The frame will move in at a slower speed.

Blank frame cycle

To change frame position with no vacuum or exposure:

Note: If is turned ON and you do not open the frame, press the button and the frame will move in without vacuum or exposure.



Front right arm of
operator control panel

- Press and hold the button.
- Press the button.
- Release both buttons when the frames start moving

Error Handling System

If an error occurs, the machine displays an error code to aid in troubleshooting. The error codes defined are:



The message  will appear in the Vacuum window, and a number in the Exposure window. Look up the number below for a description of the condition.

Description



Frames did not reach intended position after the maximum amount of time.

Solution: Determine why. Were the frames moving at all? Did they get close? Is something obstructing their movement?

See I/O test mode for instructions on how to test motors and switches.

Not used.



Internal error. Please call your service rep.

Solution: Cycle the power switch.

Please note the circumstances under which this error occurred; was the machine exposing? Calibrating? Idle? Were new exposure values being entered? What was the last button pressed? How long ago?



Frames not in position at start of exposure.

Solution: Put the frames in position by cycling the power switch. If the frames don't move, check the wiring to the frame motor and the frame position sensing switches. If everything is OK, and this error still occurs, call your service representative. See also the I/O test mode description.



Switch error. The machine thinks both frames are at the exposure position.

Possible causes are: Bad cable between master board and memory board, switches have failed, bad or no connection to switches.



Communication error. Remote board is not communicating with the master board.

Possible causes are: no power to remote board, bad or disconnected communication cable.



Remote board has reset or temporarily lost power. After clearing the error, normal function should continue.



At least one lamp intensity/frame/surface has not been calibrated.

Solution: Ensure the unit has been completely calibrated.

5. Diagnostics

Output Diagnostics

One of the many advancements OLEC has introduced to the field is the ability of its equipment to run a self-diagnostic check. All computer-activated functions and all internal and external switches can be checked out on the integrator display by using the numerical keypad.

Output Functions Check



- Press the  key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.

Press , , , then  in sequence. The Vacuum window will read . This places you in select mode.




- Press the  key to enter the Diagnostics mode. The number in the Vacuum window will be the sum of all values for peripherals that are turned On.

Press the  key to reset the Diagnostics mode. This turns Off all peripherals. Therefore the Vacuum window will indicate .

- Refer to the Functions Table.
- Press the number key to actuate the desired function. The numerical value shown in the table should appear in the Vacuum window.
- Press the function key number again to turn off the function. Press the  key to turn off all functions.
- Press the  key twice to return to normal operation.

Functions Table

	Function	Value
	Heat Exchanger Solenoids	
	Blower On/Off	
	Upper Vacuum Pump On/Off	
	Lower Vacuum Pump On/Off	
	Work Light and Nose Section Fans On/Off	
	Motor Direction Control	
	Frame Motor On/Off	
	Motor Fast/ Slow	
	All controls off	
	Return to Select mode	



Input Diagnostics



- Switch Check
The switch check can be done while in the Select mode.
- Press the key on the integrator to power up the light, the front remote switches, and the exposure unit's computer system.
Press , , , then in sequence. The Vacuum window will read . This places you in select mode.
- Press the key. The Exposure window on the integrator will show various numbers as the switches or keys are closed.


Examples: With the upper frame moved in, the side access door switches closed, and the key pressed on the nose section, the lower integrator display should read . With the lower frame in, the display should read .

	DOOR	FRAME SWITCH	FRAME	NUMBER DISPLAYED
128	+32	+4	+1	= (Upper Frame In)
128	+32	+4	+8	= (Lower Frame In)

- Switch Table

Switch Value	Function
1	Upper frame in (labeled "frame")
4	Frame switch
8	Lower frame in (labeled "frame")
16	key, nose section
32	Door/emergency switch
128	key, nose section

Typical values that you will see when all switches are good.



- Upper tray in, Frame switch closed, Door and Emergency switches closed.
The bottom display should read .

When the button is pushed the value should change to .

When the button is pushed the value should change to .

0044

0172

0060

- Lower tray in, Frame switch closed, Door and Emergency switches closed.
The Exposure window should read 0044.

When the  button is pushed the value should change to 0172.

When the  button is pushed the value should change to 0060.

Typical values that you will see when a fault occurs.

0004

Indicates neither frame in position, magnetic frame switches closed, and does not have the correct reading from either the door switches or emergency  button.

0005

Indicates upper frame in position, magnetic frame switches closed, and does not have the correct reading from either the door switches or emergency  button.

0012

Indicates lower frame in position, magnetic frame switches closed, and does not have the correct reading from either the door switches or emergency  button.

- Whatever the switch value display reads when the  button is pressed and the value does not increase by a value of 128 the  switch is bad.
- Whatever the switch value display reads when the  switch is pressed and the value does not increase by a value of 16 the  switch is bad.


6. Lamp Changing Instructions



WARNING The lamps and safety glass may be very hot and cause burns. Prior to changing the lamp, ensure the lamp head is turned off and allowed to complete its cooldown cycle.

OLEC recommends that every year you unplug your light, remove the safety glass, and clean the glass and reflector with denatured alcohol and a soft cloth. Lamps should be checked for excessive exposure times and should be replaced if exposure time has become too long.

- Support the safety glass on the lamp head and loosen the two thumbscrews to release the glass. Carefully slide the holding brackets up or down. The safety glass will slide from either side of the lamp head.
- Loosen the thumbscrews for both lamp wire spade lugs.
- Disconnect and remove the lamp by removing the spade lugs and wires from under the thumbscrews.
- Carefully lift each end of the lamp (one end at a time) out of the holders and remove the lamp from the lamp head.



- Clean the reflector with a mild solvent, such as denatured alcohol, and a clean soft cloth. Use glass cleaner to clean the safety glass. Dirty

reflectors and glass can substantially reduce light output.

- Wear the white lightweight fabric gloves that are provided and unpack the new lamp. Clean the lamp with the alcohol wipe included.
- Place each end of the new OLITE lamp (one end at a time) on the holders. DO NOT touch the lamp with your hands. Contamination of the quartz tube of the lamp with skin oils will shorten the life considerably and may lead to failure.
- Reconnect the lamp by fully inserting the spade lugs on the connecting wires under BOTH thumbscrews and tighten. Ensure the wires are positioned so they do not touch the lamp body or the reflector and cooling tube.
- Insert the safety glass into the holders and push against the housing. Ensure the safety interlock lever is positioned firmly underneath the glass towards the lamp and not squeezed to the side. Also, ensure the safety glass is loose enough to allow for heat expansion during an exposure. The light will not operate unless the safety glass is installed properly. When the safety glass is properly installed, it will be able to move slightly. If the safety glass is installed too tight, it may be damaged during use.

Note: OLITE Lamps are specifically designed for OLEC and undergo careful testing and preparation before shipment. They carry the OLEC Warranty of Satisfaction. Substitutes and copies of lamps are not approved by OLEC, nor do they carry our Warranty. Use approved OLEC replacement parts ONLY!

7. Preventive Maintenance

Preventive Maintenance Daily (Approximately 15 minutes required)

- Clean exposure frame glass and Mylar. The exposure frame glass and Mylar should be kept meticulously clean. Dirt and resist flakes on these surfaces will cause exposure defects.
- Inspect Mylar for cuts and tears. Check the condition of the Mylar on both exposure frames. The film should be clear and free of holes, creases, and scratches. Replace the Mylar whenever necessary. Replacement procedures are in the Service section of this manual.
- Inspect exposure frame vacuum seals for cracks. Check the condition of the inner and outer rubber seals on the frame glass. Cuts or nicks in the seals could cause vacuum leaks and slow frame evacuation. Replace the seals as necessary. Replacement procedures are in the Service section of this manual.

Preventive Maintenance Monthly (Approximately 1 hour required)

Perform daily maintenance steps plus the following:



CAUTION

Do not use silicone spray lubricants in the printer.

- Lightly oil frame tracks. Lightly oil the upper and the lower exposure frame tracks every month. Wet a small piece of cloth or paper towel with a lightweight machine oil and rub it on the linear bearing surface. Keeping the linear bearings oiled will ensure smooth and quiet operation.



CAUTION

Do not use silicone spray lubricants in the printer.

- Lubricate gas strut mounts. Apply a light coat of oil on the retaining ball mountings for the gas struts that support the upper half of each exposure frame.

Preventive Maintenance Semi-Annually (Approximately 2 hours required)

Perform daily and monthly maintenance steps plus the following:

- Clean unit and power supplies. The inner cabinet and power supply areas should be cleaned to prevent dust buildup.
- Turn the printer off and allow the internal blowers to run through their cool-down cycle. Disconnect the power and lock it out.
- Open both side cabinet doors. Remove both power supply covers by removing the two top forward screws and lift the covers up and forward. Using a vacuum or compressed air, remove all accumulated dust and debris from the cabinet and the power supplies.
- Clean reflectors and lamp head safety glass. Clean the lamp reflectors and the safety glass on the upper and lower lamp heads. Refer to the lamp replacement procedures in the Service section of this manual for disassembly information.



CAUTION Do not use silicone spray lubricants in the printer.

- Lubricate frame drive chain and check tension.
- Apply a light coat of machine oil to the exposure frame drive chain by rubbing an oil wetted rag along the chain. Do not wet the chain enough to cause the oil to run or drip.
- The chain tension adjustment is along the inner left hand side of the nose section. Turning the adjuster nut clockwise tightens the chain; counterclockwise loosens it. Adjust the chain to allow no more than a 1 inch (25 mm) flex between the drive motor and the adjuster wheel.



CAUTION Do not use silicone spray lubricants in the printer.

- Lubricate upper and lower light block mechanisms. Apply a light coat of machine oil to the piano-style hinges on the upper and lower light blocks. Apply a light coat only otherwise excess oil will drip on the exposure frames during operation.
- Clean vacuum pump filters. Remove and clean the filters in each vacuum pump. Replace the filter if plugged with debris. Refer to “Vacuum System” in the Service section of this manual for more detailed information.



CAUTION Do not use silicone spray lubricants in the printer.

- Lubricate frame latches. Apply a small drop of light machine oil to each of the four frame latches.

8. Vacuum System

Vacuum Pumps

Description:

The printer uses two $\frac{1}{4}$ -hp oilless rotary vane vacuum pumps, one for each exposure frame. Pressing the  button on the front nose assembly activates the pump for frame that is out of the cabinet. The vacuum gauge on the front panel indicates which pump is activated.


Pump Construction:



CAUTION

This is an oilless vacuum pump; it should never be lubricated. The pump end plate, body, rotor, and mounting bracket are cast iron. Consequently, any moisture that accumulates in the pump will corrode the interior, especially if it stands idle. The muffler box on the front of the unit is made of aluminum.

- The vanes are hard carbon and are precision ground. They should last many thousands of hours, depending upon the degree of vacuum or pressure at which the pump is run. The carbon vanes and grease-packed motor bearings require no oil.



- Filtration: Be certain that dirt, chips, and other foreign material, often found in new plumbing, is not allowed to enter the pump. Liquid, moisture vapor, or oil-based contaminants will affect pump performance and must be prevented from entering the pump. Dirty filters restrict air flow and, if not corrected, could lead to motor overload, poor performance, and early pump failure. Check the filters semi annually or when necessary. The filters can be dried with compressed air. Filters should be cleaned or replaced every 1500 to 3000 hours, depending on the application.

Flushing the Pump



WARNING

Wear eye protection and flush the pump in a well-ventilated area. Do not use kerosene or other combustible solvents to flush the pump. Use Gast AH 255 flushing solvent or its equivalent. If excessive dirt, foreign particles, moisture, or oil enter the pump, the vanes will act sluggish or may even break. Flushing the pump should remove these materials. There are two options for flushing the pump.

Flushing Option #1

This option requires two pipe nipples at least 4" (102 mm) long with $\frac{3}{8}$ " NPT threads on one end.

- Remove the filter elements from the front of the muffler box and screw the nipples into the same holes.
- With the pump running, allow about 2 tbsp. of flushing solvent to be ingested into the vacuum side of the unit.
- Repeat the flushing procedure. If it does not correct and clear the pump, remove the end plate for further examination.

Flushing Option #2

- Remove the filter elements from the front of the muffler box.
- Carefully remove the five bolts that hold the muffler box in place (be careful not to damage the gaskets). Tap the box with a small hammer to break it loose.



CAUTION  **Prying with a screwdriver will damage the gasket.** This will allow access to the intake and exhaust ports.

- Remove the filter elements from the front of the muffler box and screw the nipples into the same holes.
- With the pump running, allow about 2 tbsp. of flushing solvent to be ingested into the vacuum side of the unit.

Pump Disassembly

Pump disassembly is required if flushing does not remove the foreign materials.

- Disconnect the power to the pump motor.
- Remove the six bolts holding the end plate to the body.
- Remove the end plate and the four vanes (do not remove the rotor or loosen any electric motor through-bolts).
- The vanes could be worn or only require further cleaning. The top clearance (between rotor and body) may be adjusted by:
- Loosening the body bolts.
- Lightly tapping on the pump body and turning the rotor, while setting this clearance, to assure that all points on the rotor clear the body.

Pump Check

If the pump does not activate when the  button is pressed, see the Diagnostics section, then:


- Ensure that the exposure frame is in its full outward position.
- Check for  switch continuity at the switch connector. The switch harness connector is under the nose assembly, where it meets the front bulkhead.
- Check if the vacuum pump LED is lit at the control box. If so, check for

voltage at the pump. If voltage is present at the pump connector, but the pump fails to operate, replace the pump. If the control box LED is not on, check the wiring and connections from the switch to the control box.

Pump Replacement

Vacuum pump replacement is straightforward. The front pump controls the upper frame; the rear pump controls the lower frame. (Front and rear as viewed by the operator.)

- Remove the right side lower cabinet panel.
- Disconnect the vacuum tubing from the pump. Push the outer ring on the connector and pull the vacuum tubing out.



- Disconnect the in-line electrical pump connection located approx. 6" from the motor end of the pump.
- Remove the four $\#1/4$ - 20 nuts that secure the pump mounting plate to the isolation mounts. Then lift the pump out of the unit.
- Remove the mounting plate from the defective pump. Install it to the new pump.
- Note the wire positions and remove the electrical harness from the defective pump. Install it on the new pump.
- Install the new pump in reverse order of removal and verify the correct operation and rotation.

Tubing/Fitting Replacement

If a vacuum line or connection is cracked, loose, leaking or broken, replace it as soon as possible. A faulty vacuum line or connection will greatly increase the vacuum drawdown time required, if not eliminate full vacuum altogether. All vacuum lines are separated from the connectors by pressing down and holding the connection outer ring while pulling the vacuum line out. To replace the vacuum line into the connections, simply push the line all the way into the connection.

Vacuum Gauge Replacement


See section Nose Assembly.

Vacuum Seal Replacement

A cut, torn or otherwise damaged vacuum frame seal will greatly inhibit, if not prevent, full vacuum. A bad seal can be lifted and peeled off the frame glass. If necessary, use a razor blade or other suitable item to remove any leftover seal adhesive. Install the new seal as shown below.



CAUTION ⚠ If using a razor blade or any other sharp object, be careful not to damage or scratch the glass. It is VERY IMPORTANT not to stretch the seal as it is being placed onto the frame glass.



REF. TEXTURE NEARSIDE
(TYP.)

8	1	TAPE, TEFLON SEALANT	81TAP12
7	2.5ft	TUBING, CLEAR VINYL	49DCT24
6	2	HOSE ADAPTER	44ADT03
5	14ft	SEAL, "WAVE" SHAPE	44GKT13
4	4	O-RING 6.562 I.D.	44ORNG02
3	2	INTAKE PORT	12D1728A62
2	2	VACUUM BLOCK	12D1738A71
1	1	GLASS, AP30D	18D3728A00
ITEM QTY		DESCRIPTION	PART NO.
-A00			

Continued on next page

Vacuum Seal Replacement (cont.)

- Unless otherwise specified

Dimensions are in inches.

Dwg. per ANSI Y14.5

Tolerances are: Angles ± 5 deg. $.X \pm 1$ $.XX \pm .03$ $.XXX \pm .010$ $.XXXX \pm .0030$.

- Clean glass perimeter. Press transfer tape onto glass. (as shown) Trim tape along edge of glass. Peel off paper.
- Peel off paper from seal, press seal onto transfer tape. Align seal with outside edge of glass.




CAUTION Do not stretch seal. Cut 90° notch, see Detail B. Use a seal miter cutting tool.



- Continue peeling off paper from seal, bend 90° and press seal onto transfer tape while aligning seal with outside edge of the glass.

CAUTION Do not stretch seal.

- Press ABS strip, items 9&10, onto transfer tape, align with seal. Clean any excess transfer tape along inside edge. Press transfer tape onto back of short ABS strip. (Item 13) Peel paper off tape and align as shown.



Phototool Wiring Diagram (optional)


If the unit is equipped with the Glass Photo Tool Option you will have a third vacuum pump installed in the bottom of the unit.

See Vacuum Pumps and Tubing/Fitting Replacement for vacuum problems.

Several different glass tools are available according to customer needs so each tool itself is going to be different, however the electrical wiring and operation is the same.

The glass tool vacuum pump is independent of the integrator and is used to hold the art work to the glass tool. The operation of the pump and buttons are on the left front rail cover of the unit.

- The vacuum button must be pressed to turn ON the vacuum pump.
- Once the pump has been turned ON, the button for the upper tool or lower tool can be pressed to activate the respective solenoid in order to hold the art work to the glass tool.



ITEM	DESCRIPTION	OLEC PART NO.	QTY
1	RELAY, 12VDC, CHASSIS MOUNT	33RLY20	1
2	HARNESS, CNTRL BOX - GTOOL	16D3208A00	1

9. Nose Assembly

Removing the Left and Right Rail Covers

- Turn unit OFF, allow the unit to complete its cool down cycle and disconnect power.
- To remove rail covers:
- To remove the right rail cover: While standing in front of the unit locate and disconnect all multi-pin connectors and vacuum lines below the rail cover on the right side.
- To remove the left cover: While standing in front of the unit locate and disconnect all multi-pin connectors and vacuum lines below the rail cover on the left side.
- Remove the two $\frac{1}{4}$ -20 hex bolts holding the cover to the main cabinet using a $\frac{7}{16}$ " wrench. (see Nose Assembly Left and Right Covers)
- Remove the two $\frac{1}{4}$ -20 hex bolts holding the cover to the drawer rails using a $\frac{7}{16}$ " wrench. (see Nose Assembly Left and Right Covers)
- Carefully slide the cover off of the structure.
- Reassemble in reverse order.

Replacing the Display and Keypad PC Board

- Remove the right rail cover and place it on carpet or any surface that will not damage the keypad overlay or the paint. (see Nose Assembly Left and Right Covers)
- Remove the 6 nuts holding the Display Keypad and the 4 nuts from the Quick Memory Keypad along with all the plug in connectors. Cut any tie straps holding wiring harnesses soldered to the boards in order to remove them.
- Install the new pc boards in reverse order and reassemble the nose.

Replacing the Emergency Stop Button

- Remove the left rail cover and place it on carpet or any surface that will not damage the paint. (see Nose Assembly Left and Right Covers)
- Disconnect the plug on the back of the switch base.
- Remove the two screws from the bottom of the switch base.
- While holding the top of the button twist the switch base to separate the switch in two pieces and remove it from the rail cover.
- Install the new switch in reverse order.

Replacing the and Buttons

- Remove the right rail cover and place it on carpet or any surface that will not damage the keypad overlay or the paint. (see Nose Assembly Left and Right Covers)

- Use a small screw driver inserted between the switch and the sheet metal to break the glue holding the two black retainer clips on each side of the switch from the rail cover.
- Press together the switch retainer clips on the base of the switch and push the switch out through the top. Replace wire for wire onto the new switch.
- Install in reverse order. Put a drop of super glue on each retainer clip to hold it to the rail cover.

Replacing the Glass Tool Vacuum Buttons

- Remove the left rail cover and place it on carpet or any surface that will not damage the paint. (see Nose Assembly Left and Right Covers)
- Disconnect and mark the wires on the back of the switch base.
- Remove the two screws from the bottom of the switch base.
- While holding the top of the button unscrew the switch base to separate the switch in two pieces and remove it from the rail cover.
- Install the new switch in reverse order.

Replacing the Vacuum Gauges

- Remove the right rail cover and place it on carpet or any surface that will not damage the keypad overlay or the paint. (see Nose Assembly Drawings)
- Remove the vacuum tubing from the gauge.
- Remove the gauge retaining bracket and the faulty vacuum gauge.
- Install in reverse order.

Nose Section Autoformer

Note: The work lights and nose fans receive their power from this autoformer, if both the fans and the work lights are not working check this autoformer first.

- Remove the right and left rail covers and place them on carpet or any surface that will not damage the keypad or the paint. (see Nose Assembly Left and Right Covers)
- Remove the twelve #10 - 32 x 1/2 Soc. button head screws (see Base Assembly Diagram DETAIL H).
- Slide cooling compartment out to get access to the autoformer
- Meter input and output of the autoformer from 0 to 240V, 0 to 208V and 0 to 120V. If defective replace.

Work Lights

Note: The work lights are controlled by a rocker switch on the underside of the right front corner of the nose cover.

Note: If the work lights are not turning ON, check the rocker switch and power to the switch.

Note: The work lights receive their power from the autoformer in the nose section

- To change the lamps the trays must first be moved to the center position. This is done by:
- Press and hold the  button.
- Press the  button.
- Release both buttons when trays start moving.
- Just before the trays reach the center turn the power OFF.
- Lift the diffusion cover off of the light assembly.
- Twist the lamp to disengage it from the socket and remove it.
- Install in reverse order.

Nose Fans

Note: The nose fans are controlled by a rocker switch on the underside of the right front corner of the rail cover.


Note: If the nose fans are not turning ON, check the rocker switch and power to the switch.

- Remove the nose.
- Disconnect the power leads to the blower(s).
- Remove the blower(s).
- Install in reverse order.

Cleaning or Replacing Nose Filters

- Slide the filters toward the front of the unit and out of the brackets.
- Clean metal filters with water or environmentally safe solvent.

Nose Assembly Drawings




BOTTOM VIEW

58	--	-----	-----	29	1	HARNES, SW, OPERATOR OV45	16D2196A00
57	--	-----	-----	28	-	-----	-----
56	2	SWITCH, CW	55SW01	27	--	-----	-----
55	--	-----	-----	26	--	-----	-----
54	4	NSI 8-32 X 3/8 PPMS ZINC	41-08PPS.37	25	--	-----	-----
53	--	-----	-----	24	--	-----	-----
52	--	-----	-----	23	--	-----	-----
51	4	NSI #10 FLAT WASHER SAE	41-10WFR	22	--	-----	-----
50	8	NSI 6-32 X 3/8 PHIL PAN MS BLK	41B06PPS.37	21	--	-----	-----
49	3	NSI CABLE TIE 4" #18 MAX	44TIE02	20	--	-----	-----
48	3	TIE WRAP ADHESIVE MOUNT BASE	44PAD03	19	--	-----	49DCT27
47	2	1/4-20 LOCKNUT NYLON	41B40NLN	18	1	5 POSITION TERMINAL STRIP OV24	52TS05
46	16	NSI #6 FLAT WASHER SAE	41-06WFR	17	2	LIGHT FIXTURE UNDERCABINET 24"	39CLF02
45	6	NSI #8 FLAT WASHER, SAE	41-08WFR	16	2	BLOWER	39BLO11
44	8	NSI 1/4 SAE FLAT WASHER	41-40WFR	15	2	LAMP, YELLOW VIEWING 20 WATT	35LMF06
43	16	NSI #6 SPLIT LOCK WASHER	41-06WLS	14	1	AUTOFORMER,120/208/240V50/60Hz	32TRC08
42	6	NSI #8 SPLIT LOCK WASHER	41-08WLS	13	--	-----	-----
41	8	NSI WASHER, SPLIT LOCK 1/4	41-F0WLS	12	--	-----	-----
40	2	NSI 8-32 KEP NUT ZINC	41-08NKP	11	2	FILTER, TOP AP30	19D1942A99
39	4	NSI 10-32 KEP NUT ZINC	41-12NKP	10	2	BRACKET, FILTER HOLDER (RHT)	11D1939B62
38	2	NSI 8-32 X 3/4 PPMS ZINC	41-08PPS.75	9	2	BRACKET, FILTER HOLDER (LFT)	11D1939A62
37	4	NSI 10-32 X 1/2 PPMS ZINC	41-12PPS.50	8	1	BEZEL, WORKLIGHT	18D3776A00
36	8	NSI 6-32 X 1/2 BLK SELF TAP	41B06PST.50	7	1	DIVIDER NOSE	11D3746B17
35	16	NSI 8-32 X3/8 PFMS 100-ZINC	41-08PFO.37	6	1	DIVIDER NOSE	11D3746A17
34	14	NSI 6-32 X 3/8 PHIL PAN MS BLK	41-06PFO.37	5	1	AIR DIRECTOR NO. 3	11D3736A08
33	6	1/4-20 X 5/8 SOCKET BTN HD BLK	41BF0SHC.62	4	1	AIR DIRECTOR NO. 2	11D3735A08
32	--	-----	-----	3	1	AIR DIRECTOR NO. 1	11D3734A08
31	--	-----	-----	2	1	REFLECTOR, WORK LIGHT	11D3733A07
30	--	-----	-----	1	1	WELDMENT, COOLING	11D3751A00
ITEM	QTY	DESCRIPTION	PART NO.	ITEM	QTY	DESCRIPTION	PART NO.



Continued on next page

Nose Assembly Drawings (cont.)



Continued on next page

Nose Assembly Left and Right Covers




22	4	BARRIER	55SW45-5
21	1	SUPPORT, RAIL COVER-OV45	11D2535A08
20	8	ADHESIVE, SQUARE 4026	44PAD02
19	10	NSI 6-32 KEP NUT ZINC	41 06NKP
18	20	NSI #6 INTERLOCK LOCK WASHER	41 06WLI
17	10	6-32X .312 HEX THD. SPACER	44HHS9292
16	44"	TUBING, NYLON 1/4" OD 0.126	49DCT27
15	8"	TAPE, TEFLON SAE LANT 1/2"	81TAP12
14	2	CONNECTOR, TUBE 3/8 TO 1/4 OD.	43FIT14
13	2	VACUUM GAUGE, 0-30" HG. 1-1/2	49VAG02
12	1	OVERLAY, CONTROL PANEL	15D2270A00
11	1	HARNESS, MERGENCY SWITCH	16D2412A00
10	1	HARNESS, SW, OPERATOR OV45	16D2196A00
9	1	CONTACT BLOCK	55SW48-1
8	1	EMERGENCY PUSHBOTTON	55SW53
7	1	BUTTON, YELLOW "STOP"	55SW45-2
6	1	BUTTON, GREEN, "GO"	55SW45-1
5	2	SWITCH, NOSE AP30/33	55SW45
4	1	ASSEMBLED SUPPLEMENTAL KEYBOARD	64MI477
3	1	KEYBOARD FOR OV45	64MI478
2	1	COVER, RAIL, LEFT - 45	11D2163A08
1	1	COVER, RAIL, RIGHT - OV45	11D2163B08
ITEM	QTY	DESCRIPTION	PART NO.

10. Exposure Trays

Mylar® Replacement

- Close the Mylar® frame and open the twelve cam latches.
- Remove the inner Mylar® frame and position a pre-cut Mylar® sheet into the frame. Make sure that the Mylar® is overlapping on all sides.



- Reinstall the inner Mylar® frame and ensure all cam latches are closed.
- Trim the excess Mylar® from between the inner and outer frames.

If Mylar® Pulls Out of the Frame.


- Make sure the Mylar® is not cut too small. The Mylar® must overlap on all sides so that it comes up between the inner and outer frames. Mark on the Mylar® where the cam latches are and cut a small slit in the mylar to allow the cam latches to lock down. Then trimmed off once the inner frame has all the cam latches in the closed position.
- Make sure the inner and outer frames are not bent or damaged, if so, replace them.

Outer Frame Replacement


- Remove the inner frame.
- Open the frame then remove the safety clips from the gas shocks.
- While holding the frame up pull the gas shocks off of the mounting ball joints then lower the frame.
- Remove the 2 Allen screws from each of the four hinges in the back of the frame and lift the frame off.

Note: The frame MUST be squared when it is reinstalled.

- Place the new frame flat on the tray. Line up and insert the Allen head screws through the hinge into the frame. Make sure the frame is $\frac{1}{32}$ " to $\frac{1}{16}$ " above the top of the hinge to avoid the possibility of damaging the glass, then tighten them down.
- Reinstall the inner frame (without the Mylar®) and close all cams.



- Loosen all the Allen head screws in the corners of the inner and outer frames shown in the diagram.
- Tighten the outer frame Allen head screws in the order shown in the diagram, 2 per corner.
- Tighten the inner frame Allen head screws in the order shown in the diagram, 2 per corner.







- Lift the frame and push the gas shocks back onto the ball joints.
- Reinstall the safety clips into the ends of the gas shocks.

Tray Assembly Drawing



Continued on next page

Tray Assembly Drawing (cont.)



50	2	GAS SPRING (80 LBS)	43SPR24
49	161"	ADHESIVE RUBBER GASKET	SEE BOM
48	2	HINGE BLOCK CLAMP	19D3815A02
47	5	NSI CABLE TIE, UV, 4"	44TIE08
46	1	CABLE, MAGNETIC TRAY SWITCH	16D2970A99
45	12	NSI 6-32 X 1/2 PHIL PAN BLK	41B06PPS.50
44	10	NSI #6 KEP NUT ZINC	41-06NKP
43	1	RAMP SWITCHES, AP30/OV33	11D2112A62
42	1	1/4-20 X 3/8 BOTTON HEAD	41-F0SHB.37
41	6	NSI 10-32 X 3/8 PPMS BLK	41B12PPS.37
40	2	NSI LOCKWASHER SPLIT 1/4"	41-F0WLS
39	8	10-32 X 3/4 SHCS	41B12SHC.75
38	18	NSI #10 FLAT WASHER BLACK	41B10WFR
37	18	NSI #10 LOCKWASHER SPLIT	41 10WLS
36	2	5/16-18 HEX NUTS BLK ZINC	41BF2NHX
35	2	NSI 1/4 - 20 X 1 SKT HD CAP	41B0SHC1.0
34	9	1/4-20 X 5/8 SKT BTN HD SCREW	41BF0SHC.62
33	8	NSI #6 SPLIT LOCK WASHER	41-06WLS
32	28	NSI #6 FLAT WASHER, BLACK ZINC	41B06WFR
31	6	NSI 6-32 X 3/8 PHIL PAN MS BLK	41B06PPS.37
30	13	NSI 10-32 X5/8 SOC HD CAP BLK	41B12SHC.62
29	2	NSI 6-32 X 1/4 PHIL PAN MS BLK	41B06PPS.25
28	1	NSI 8-32 X 3/16 PPMS BLK ZINC	41B08PPS.18
27	1	WASHER, .380 ID .625	41WFR03
26	2	NSI SOCKET SHOULDER BOLT-	41BF2BHX.75
25	2	WASHER, NYLON, 3/8 X3/4 X1/16	41HHS2679
24	1	PIVOT BAR, OV45	12D1727B99
23	1	BRACKET, VACUUM HOSE OV45	11D1696A02
22	1	GUIDE, LT. BLOCK (65SEAL)R.	11D2709B62
21	1	GUIDE, LT. BLOCK (65SEAL)L.	11D2709A62
20	2	WHEEL	43BLB17
19	2	LINEAR BEARING 1/2" DIA.	43BLB12
18	1	MOUNT, LIGHT BLOCK GIUDE	12D1737A62
17	1	SWITCH, MAGNETIC INTE.	55SW50-B
16	6	BALL STUD, MODIFIED	43SDB03
15	2	GAS SPRING 60 LBS.	43SPR25
14	2	BALL STUD MOUNT PLATE	43SDB03
13	4	HINGE, BLOCK	19D3825A76
12	3	END PIVOT BLOCK	12D1895A99
11	1	FRONT WHEEL BLOCK	12D1731A71
10	1	REAR WHEEL BLOCK	12D1733A00
9	1	FRONT BEARING BLOCK	12D1730A71
8	1	REAR BEARING BLOCK	12D1732A71
7	1	TIE WRAP ADHESIVE MOUNT BASE	44PAD03
6	2	HANDLE, 6", ALUM. BLACK	44HDL05
5	2	GIUDE, LIGHT BLOCK, LOWER	11D2145A62
4	4	SOCKET HEAD, CAP SCREW	SEE BOM
3	1	MYLAR FRAME ASSEMBLY	91MYLFRM-AP42
2	1	GLASS FRAME ASSEMBLY	91GLFRM-42
1	1	WELDMENT, TRAY, OV42	19D3826A02
	QTY	DESCRIPTION	PART NO.

4 TO ASSEMBLE LOWER TRAY, USE 2 LOWER LIGHT BLOCK GUIDES (ITEM NO. 5) IN PLACE OF ITEMS NO. 21 & 22. SEE DRAWING.


3 APPLY LOCTITE (82ADH04) TO THREADS WHERE INDICATED.

2. PLACE MYLAR FRAME ASSEMBLY (ITEM 3) ATOP GLASS FRAME ASSEMBLY (ITEM 2) AND TRAY WELDMENT (ITEM 1). ASSEMBLE AS SHOWN.

6 CUT TWO PIECES OF GASKET (ITEM 49) AT 37" LONG, AND TWO PIECES AT 43.25". ASSEMBLE AS SHOWN.


5 CONNECT MAG. SWITCH CABLE (ITEM 46) TO SWITCH ON WELDMENT (ITEM 1); ROUTE TOWARD REAR. SECURE WITH FIVE CABLE TIES (ITEM 47), AND ONE TIE WRAP (ITEM 7). BE SURE HARNESS DOES NOT COME IN CONTACT WITH ANY SHARP EDGES ON WELDMENT.

Outer Frame Assembly



Continued on next page

Inner Frame Assembly



17	SCREW, SHLDR ø.187 X 1.25	41-08SBL1.25	2	34	NSI #6 FLAT WASHER, BLK	41B06WFR	2
16	NSI #8 X .5 SLOTTED, BNDG	SEE B.O.M.	12	33	NSI #8 FLAT WASHER	41-08WFR	12
15	GASKET, 1/16 W X 1/2	81TAP21	-	32	NSI 6-32 X .25 PPMS BLK	41B06PPS.25	38
14	SPRING, 7/16 X 9/16 COMP.	43SPR12	2	31	LOWER LEDGE (SIDES)	19D3822A76	2
13	SWITCH, MAGNETIC INTE.	55SW50-B	1	30	LOWER LEDGE (FRT & RR)	19D3821A76	2
12	HANDLE, 6 INCH	44HDL05	1	29	MYLAR SHEEET	13D3901A00	1
11	MOUNT, MAGNETIC SWITCH	11D2971A71	1	28	NSI 6-32 FLEXLOCK NUT	41-06NLM	2
10	CAM LATCH	12D2379A76	12	27	NSI #6 SPLIT LOCK WASHER	41-06WLS	2
9	CATCH	11D2392A62	1	26	NSI 6-32 X 3/8 PHIL BLK	41-06PPS.37	2
8	LATCH	12D2391A76	2	25	WAVE WASHER #10	41-12WSW	12
7	MOUNT, HANDLE	12D2390A76	2	24	NSI 10-32 X .50 PHIL PAN	41B12PPS.50	2
6	BASE, HANDLE/LATCH	12D2389A76	2	23	NSI, #10 FLAT WASHER BLK	41B10WFR	2
5	FRAME, MYLAR, INNER-F/R	19D3823A76	2	22	NSI 6-32 X 3/8 FLT BLK	41B06PFO.37	2
4	FRAME, MYLAR, INNER-SIDES	19D3824A76	2	21	SHCS, 10-32 X 3/4	41B12SHC.75	6
3A	FRAME, MYL, OUTER-RH SIDE	19D3819A76	1	20	SHCS, 8-32 X 3/8	41B08SHC.37	16
3	FRAME, MYL. OUTER-LH SIDE	19D3819B76	1	19	BALL STUD, SHRT.	43SDB02	2
2	FRAME, MYLAR, OUTER-FRONT	19D3817B17	1	18	NSI #8 X .250 SPACER	42HHS8521	12
1	FRAME, MYLAR, OUTER-REAR	19D3817B76	1				
ITEM NO.	DESCRIPTION	OLEC P/N	QTY.				
PARTS LIST							

Gas Spring Removal and Replacement



Each frame assembly has two gas springs to support the top cover sheet frame when it is opened.

- Open the frame with the spring to be replaced.

CAUTION  The glass frame assembly is heavy, make sure you support it well before removing the gas spring.

- Remove the retainer from both ends of the spring.
- Pull the spring from the retaining ball mounts.
- Install the new spring in the reverse order.

Replacing the Linear Bearings

There are two linear bearings on the left-hand side of each exposure frame, one in the front and one in the rear. They move along the shaft when the frames move in and out of the AP 42CL 8000. Check the linear bearings if frame transport becomes noisy.

To replace the lower frame front bearing see Tray Assembly Drawing

- Remove all the mounting bolts from the left rail cover and slide it forward about 3" to 4" (76mm to 102mm).
- Remove both linear bearing retainer block screws, using a $\frac{5}{32}$ " Allen wrench.
- Lift up the frame assembly about 2" (51 mm) and slide the bearing block assembly forward off the shaft, support the frame to prevent contact with the shaft.
- Remove the bearing from the retainer block (see Tray Assembly Drawing Detail B)
- Install in reverse order.
- To replace the upper front bearing: (see Tray Assembly Drawing)
- Open the upper frame.
- Remove the left light-block rail and then close the upper frame
- Unplug the drive motor electrical connector from the control box and slide the top frame back about 10" (254 mm).
- Remove both of the linear bearing retainer block screws, using a $\frac{5}{32}$ " Allen wrench.
- Lift up the frame assembly about 2" (51 mm) and slide the bearing block assembly forward off the shaft, support the frame to prevent contact with the shaft.
- Remove the bearing from the retainer block.
- Install in reverse order.

To replace either of the rear bearings:

- Remove the left gas spring mount from the Mylar® frame.
- Remove the left side panel.

- Unplug the drive motor electrical connector from the control box and position both frames near the mid-travel position.
- Remove three linear bearing retainer block screws using a $\frac{5}{32}$ " Allen wrench.
- Lift up the frame assembly about 2" (51 mm) and slide the bearing block assembly backward off the shaft, support the frame to prevent contact with the shaft.
- Remove the bearing from the retainer block.
- Install in reverse order.

Frame Glass Replacement

Note: Wear leather gloves and safety glasses when performing this procedure.





- Open the frame to be changed.

CAUTION

 The glass frame could suddenly move up as soon as the glass (weight) is removed. Secure the glass frame to the tray cable ties or heavy duty tape.
- Remove the black silicone fillers in each corner on the front edge of the glass frame.
- Push up on the glass from under the frame. Hold it up about 12" (305 mm) off of the frame.
- Disconnect both vacuum hoses and lift out the glass.
- Install new glass in the reverse order.

11. Center/Drive Assembly

Center/Drive Assembly Diagram



Continued on next page

Center/Drive Assembly Diagram (cont.)

74	1	NSI #8 FLAT WASHER	41BO8WFR
73	1	5/16 SPLIT LOCK WASHER	41F2WLS
72	1	SOCKET HEAD FLAT #5/16-18 X .62	41BF2SHF.62
71	1	INSULATION PAD AL13/14	15D725
70	1	COVER, DRIVE CHAIN-LOWERLD.	11D2799B08
69	1	COVER, DRIVE CHAIN-UPPER	11D2799A08
68	4	NSI 6-32 X 3/8 PHIL FLAT	41 06PFO.37
67	1	NSI 3/8 X A3/4 SOC. SHLD.	41BF3SHC1.7
44	1	3/8-16 NYLON LOCK NUT, OV45	41 F3NLN
43	1	THREADED ROD	12D1751A00
42	2	5/16 - 18 X 3/4 HEX BOLT BLK.	41BF2BHX.75
41	1	TENSIONER BUSHING	12D1755A00
40	1	NSI 1/4-20 X 1 3/4 HEX BOLT BLK.	41B40BHX1.75
39	6	NSI 8-32 5/8 FLAT HEAD 82	41B08PF2.62
38	19	NSI #10 FLAT WASHER BLACK	41B10WFR
37	24	NSI #8 LOCK WASHER SPLIT	41 08WLS
36	24	NSI 8-32 X 1/2 SOC. HD CAP SCR	41B08SHC.50
35	4	NSI 1/4-20 LOCKNUT NYLON INS.	41B40NLN
34	8	NSI 1/4 SAE FLAT WASHER	41 FOWLS
33	3	WASHER, SPLIT LOC 1/4"	41 40WFR
32	4	1/4-20 X 3/4 HEX HEAD BOLT	41 FOBHX.75
31	4	NSI 6-32 X 3/4 PPMS ZINC	41 06PPS.75
30	4	4/40 X 5/8 PHIL FLAT MS	41 04PFO.62
29	2	NSI 6-32 X 5/8 PPMS ZINC	41 06PPS.62
28	2	NSI 4-40 KEP NUT	41 04NKP
27	6	NSI 4-40 FLEXLOCK METAL	41 04NLM
21	1	OVERTORQUE SAFETY DEVICE	43OSD01
18	5	NSI #10-31HEX KEP NUT	52RCP28
17	1	DEFLECTOR, AIR	11D3395A17
16	1	CHAIN, #35 RLR- 10 FT	43CHA05
15	10	BLOCK, MOUNT AC-TRACK	12D1635A62
14	1	HARNESS, MOTOR- POS SWT	16D2319A00
13	4	SWITCH, TIMING-ROLLER	55SW02
12	2	CHAIN YOKE	12D1757A62
11	1	TENSIONER SPROCKET	12D1996A00
10	1	SPRING, CHAIN TENSIONER	43SPR14
9	1	IDLER BUSHING	12D1754A00
8	1	IDLER SPROCKET	12D1753A00
7	1	SLIDER	12D1752A62
6	1	SLIDE	12D1750A62
5	2	SWITCH MOUNT, OV45	11D2111B62
4	1	MOTOR, DRIVE ASS'Y	62D3798A00
3	191"	TAPE GLIDE (BLACK UHMW)	81TAP17
2	2	SHAFT, ACCUTRACK	12D2150A99
1	1	WELDMENT OV45 TOP,RAIL & LOW	11D3750A00
ITEM	QTY	DESCRIPTION	PART NO.

Tray Transport System

The printer has two aluminum exposure tray assemblies. Vacuum for frame evacuation is drawn through two ports in the glass, one at each of the rear corners. The top Mylar® frame is hinged in the back, with a gas strut on each side that holds the Mylar® frame open.

The exposure frame transport system is powered by a $\frac{1}{8}$ -hp PMDC (Permanent Magnet Direct Current) gear motor. It is controlled and operated by the control panel, through the rail cover  and  switches.

Pressing the  switch once will start a vacuum cycle. The second time  is pressed, the frames will move into position and an exposure will start. The frames can be operated through a blank frame cycle by holding down the  switch before pressing the  switch and then releasing both.

The frames move at two speeds; a fast speed initially, then a slow speed near the end of their travel. This prevents a noisy, hard-stop condition and possible machine damage. For added safety, the drive motor has a slip clutch to prevent machine damage. A system switch inside the cabinet stops frame movement when it is actuated by the frame moving into the exposure position. If the system switch fails, the frame contacts a second switch that turns off power to the frame drive motor.

Tray Drive Motor Replacement

The drive motor is in the left rear corner of the cabinet. It is a $\frac{1}{8}$ -hp PMDC design, with a slip clutch on the output shaft. The clutch is intended to prevent frame damage in the event of a jam or if an object blocks frame movement. See Frame Drive Clutch Adjustment for procedures.

Note: Remove your watch when working on the drive motor. The drive motor magnet could damage watches or similar devices.

- Remove the left side cabinet panels.
- Disconnect the motor connector from the control box.
- Position both frames to approximately a midpoint state.
- Disconnect the two wire connectors at the motor end of the drive motor.
- Remove the four $\frac{1}{4}$ -20 x $\frac{1}{2}$ " counter sunk screws that attach the motor to the rear brace of the center section. Use a $\frac{7}{16}$ " open end wrench and lift out the motor.
- Install the new motor in the reverse order.

Tray Drive Clutch Adjustment



WARNING ⚠

A personnel safety hazard may exist, or machine damage may occur if the slip clutch on the exposure frame drive motor is set too tight. If the clutch is set too loose, the frame drive

will be too slow and a transport error may occur. Use the following procedure to set the clutch at the minimum setting for operation.


- Remove the left side center panel on the printer and locate the clutch at the left rear corner.
- Loosen the two set screws which lock the hex nut to the motor shaft.
- Adjust the hex nut until the minimum setting is found that provides frame movement with no slippage.
- Retighten the set screws in the hex nut.
- Replace the left side panels removed above.

Tray Speed Adjustment

Note: Frame speed is set at the factory and normally does not require adjustment.


Note: An adjustment of the frame speed must be preformed whenever the Control Box PCB, part #64CT464, or the Motor Speed Control Board, part #31MSC02 is replaced. This adjustment is critical, failure to do so can damage the board and/or hardware.

- Locate the 'FAST' and 'SLOW' potentiometers in the upper left hand corner of the Control Box. The frame speed adjustments will be made from these pots.




- Activate the Diagnostics Mode through the keypad;
- Press the [1], [2], [3] then [4] keys, the center display will read SEL.
- Press the [6] key: this will activate the diagnostic mode.
- Press the [9] key: this will reset the vacuum window to 0000.
- Press the [7] key to set motor drive: the vacuum window should read 0064.
- Press the [6] key: upper tray should move in, the vacuum window should read 0096.
- Press the [6] key: lower tray should move in, the vacuum window should read 0064.

- Press the 6 key again: upper tray should move in, the vacuum window should read 0096.
- Set Volt meter for VDC and measure across pins 5 & 6 on motor speed connector. Adjust the 'SLOW' pot on the control box to read 25 to 32 VDC. Notice that the frame moves slower than normal. The total travel time of the frame should be 12 seconds.



- Exit the diagnostic mode by pressing the 9 key then the 0 key.
- Adjust the 'FAST' pot on the control box.
- Press and hold the 'STOP' key then press the 'GO' key and then release both keys to start a blank frame cycle, no vacuum or exposure.
- Measure across pins 5 & 6 on motor speed connector. Adjust the 'FAST' pot on the control box to read between 70 and 84 VDC. The frame should travel at high speed for about 4.5 seconds, then shift to a slower speed and stop about 0.750" (19mm) to 1" (25mm) from the end of the tray rod.





CAUTION

Verify the adjustment by noting the position of the frame when it is inside the Unit. Check the frame position switches for each frame. When adjusted properly, the frame will come to a stop depressing the first switch, but not the second. If the second switch is depressed, check slow speed adjustment.

Light Block Assembly


Upper Light Block (center section) Assembly Drawing



67	1	NSI 3/8 X A3/4 SOC. SHLD.	41BF3SHC1.7
66	2	1/4 ID NYLON WASHER	44WFN02
65	16	NSI #10 LOCK WASHER SPLIT	41 10WLS
63	22	NSI #6 KEP NUT ZINC	41 06NKP
62	4	NSI 6-32 X 5/16 PHIL FLAT 100	41B06PFO.31
61	4	NSI #6 LOCKWASHER SPLIT	41 06WLS
60	16	NSI #6 FLAT WASHER, BLACK ZINC	41B06WFR
59	4	NSI 6-32 X 3/8 PHIL PAN MS ZINC	41B06PPS.37
58	2	NSI 10 X 24 HEX NUT ZINC	41 14NHX
57	1	Bezel AP 42	65D3774A00
56	2	NSI SHOULDER SCREW	41BF3SHC.37
55	2	#6 BRASS 6-32 RND. THD. SPACER	42HHS8779
54	1	SPRING, TORS. RH.	43SPR18
53	1	SPRING, TORS. LH.	43SPR17
52	2	MOUNT DOOR SWITCH-OV45	11D2240A62
51	2	SWITCH, INTERLOCK	55SW46
50	2	MOUNT SPRING LT. BLK. AP30	11D1660A99
49	2	NYLON IDLER PULLEY	49PUL01
48	2	BRACKET, WHEEL MOUNT OV45	11D1659A99
47	1	LIGHT BLOCK, UPPER, OV45	11D2148A17
46	1	HINGE, LIGHT BLOCK OV45	12D1653B62
45	1	SPACER, HINGE OV45	11D2202B02
38	19	NSI #10 FLAT WASHER BLACK	41B10WFR
3	4"	TAPE GLIDE (BLACK UHMW)	81TAP16
ITEM	QTY	DESCRIPTION	PART NO.

Continued on next page

Lower Light Block (insert section) Assembly Drawing




67	2	1/4 ID NYLON WASHER	44WFN02
65	2	NSI #10 LOCKWASHER SPLIT	41-10WLS
59	2	BRACKET WHEEL MOUNT OV45	11D1659A99
58	2	1/2" THIN FLAT WASHER	41-F5WFT
57	2	ASS'Y. CONTROL DELAY BOX	62D2719A00
53	1	SPACER, HINGE OV45	11D2202B02
52	2	NSI 6-32 X1/4 PPMS ZINC	41-06PPS.50
51	5	NSI #6 SPLIT WASHER	41-06WLS
50	13	NSI #6 FLAT WASHER BLACK ZINC	41B06WFR
49	8	NSI 10-32 KEP NUT ZINC	41-12NKP
48	1	HINGE, LIGHTBLOCK OV45	12D1653B62
47	7"	TAPE GLIDE (BLACK UHMW)	81TAP16
46	1	LIGHTBLOCK, LOWER OV45	11D2147A17
45	29	NSI 6-32 KEP NUT ZINC	41-06NKP
44	2	NSI 6-32 X 3/4 PPMS ZINC	41-06PPS.75
43	2	#1/2 -13 HEX NUT	41-F5NHX
42	1	SPRING, TORS, LH	43SPR22
41	1	SPRING, TORS, RH (LOW)	43SPR21
40	2	MANDREL, SPRING, LOW LT.BLK.	12D1653B62
39	1	MOUNT, SPRING, LOW LT.BLK LFT	11D2051B62
38	1	MOUNT, SPRING, LOW LT.BLK-RT	11D2051A62
37	2	#1/2 FLAT WASHER	41-F5WFR
36	2	NSI 1/2-13 X 2.0SHCS-BLK	41BF5SHC2.0
35	16	NSI 6-32 X .312 HEX THD SPACER	42HHS9292
34	1	ACCUPRINT PCB, MASTER	64MI441E-APM
33	1	ACCUPRINT PCB, REMOTE	64MI441E-APR
32	32	NSI 36 INTERNAL LOCK WASHER	41-06WLI
31	16	NSI 6-32 X 3/16 PPMS ZINC	41 06PPS.18
30	2	NSI 10 X 24 HEX NUT ZINC	41-14NHX
29	2	NYLON IDLER PULLY	49PUL01
28	2	NSI SHOULDER SCREW	41BF5HC.37
ITEM	QTY	DESCRIPTION	PART NO.

Replacing Light Block Springs

- For the lower light block, move upper exposure frame into the cabinet. For the upper light block, move lower exposure frame into the cabinet.
- Disconnect main power.
- Remove the left and right side panels.
- Remove the left mounting bracket first.
- Use the new mounting bracket.
- Insert two #8-32 x 0.62" screws and secure to mounting bracket with two 8-32 kep nuts.
- Use the $\frac{1}{2}$ -13 x 2.0" shoulder screw and large $\frac{1}{2}$ " washer and insert through the hole in the mounting bracket. Place the mandrel over the shoulder screw.
- Place left spring over mandrel.
- Secure washer and nut over shoulder screw.
- Reinstall left and right side panels and reconnect power.


12. Diagrams

Control Box Front View Typical




* - On 480VAC printers only


208VAC 60Hz/380VAC 50Hz



480VAC 60Hz




Base Assembly Diagram




Continued on next page


Base Assembly Diagram (cont.)



Unit Cabling Diagram (new style)




Unit Cabling Diagram (old style)




13. Light Source

Component Layout


Lamphead for AL 84 and AL 94 50/60Hz




Power Supply for AL 84 60Hz



Power Supply for AL 84-480 60Hz




Power Supply for AL 94 50Hz




Ballast/Tap Switch Wiring


AL 94 Ballast Wiring



AL 84 Ballast / Tap Switch Wiring



AL 84-480 Ballast Wiring



Path of Power to the PC Board

- This section is useful when there is no power reaching the PC board (no LEDs lighted). Before tracing the power, check the fuse on the PC board and the incoming power.
- On 240V equipment, the power cord enters the rear of the unit. The two hot conductors are connected by wire nuts to wires that are in turn connected to the front of a terminal strip. One of these two wires passes through a fuse and on 60 Hz units is then connected to a voltage selector switch, then is connected to taps on a step-down autotransformer. This transformer is located under the terminal strip on the component bracket near the dividing wall. The transformer tap marked 120V becomes the unit common and returns to the terminal strip. The other line wire is connected to the transformer common and becomes the hot 120V lead to the PC Board and also returns to the terminal strip. The power is distributed from the strip and a pair of wires goes to the PC board.

Interlock System

- The internal interlock system serves two purposes. The first is for operator safety by insuring the safety glass is in place before operation. This glass filters short UV radiation and covers the high voltage lamp terminals. This interlock also protects from overheating by traveling through two thermostats in the lamp head. There is also an outlet on some equipment marked “interlock” and is not used in this equipment.

- The internal interlock is a loop that travels through the light head, passing through the glass switch and two thermostats. This interlock is in series with the control circuit of the large relays in the power supply. When the interlock is opened, the relays will open and cut the power to the lamp terminals. The PC board senses the drop in voltage and closes the shutter.
- The first place to check is the glass switch. The switch lever is located near the edge of the glass on the end of the lamp where the cable enters. By releasing the glass, the lever can be seen. If the lever can slip past the glass, it should be bent slightly toward the reflector. If the switch is closed, the loop can be traced. First measure the voltage between lamp wires (#4 AC Common) and wire (#10 Interlock). The presence of voltage between these terminals indicates an open loop. This loop travels to the lamp head on wire (#10), then to the glass switch, the far end thermostat, the near end thermostat and terminates on wire (#4). The thermostats are mounted in the air tubes leading to the lamp. There are no splices in the air tubes.

Lamp Voltage

The lamp voltage measurement can provide useful information for lamp striking, lamp output, and level switching information. The meter used to measure can cause different results. We use traditional needle movement meters in our factory, due to the trigger pulses on the lamp before striking. The waveforms are not sinusoidal, so different meters may produce different results. Here is a chart with typical measurements:

Lamp Voltage (Terminals 2 & 3)						Lamp Fan Voltage (Terminals 4 & 5)			
Model	Idle	Low	Med.	High	Trig.	Idle/Low	Med.	High	Trig.
AL84 w/L1280	360-380	360-380	380-410	415-445	500+	75-95	90-120	115-125	115-125
AL84 w/L1281	400-430	400-430	425-500	460-530	500+	75-95	90-120	115-125	115-125
AL84 w/L1282	400-430	400-430	425-500	460-530	500+	75-95	90-120	115-125	115-125
AL94 w/L1280	360-380	360-380	380-410	415-445	500+	70-90	90-120	115-125	115-125
AL94 w/L1281	400-430	400-430	425-500	460-530	500+	65-90	90-120	115-125	115-125
AL94 w/L1282	400-430	400-430	425-500	460-530	500+	65-90	90-120	115-125	115-125


Lamp Power Path

The basic path that the power to the lamp takes is almost identical for all units. The basic path is incoming line, main power relay, ballasts, capacitors, trigger board, and then the lamp. See the point to point wiring diagrams for each light source in Section 16.

Trigger Board

A trigger board is provided in the light head to start the lamp. This board operates on demand by sensing the lamp voltage. This board can be heard when it is functioning, although the sound is faint. By turning the unit on and off, the sound can be compared during trigger and cool-down. In both situations, the fans are running full speed. The fans may be disabled by pulling the blue wire from terminal #5 to aid in determining if the trigger board is functioning. Use caution that the lamp doesn't run without cooling.

The trigger board is located in the lamp head, in the end where the cable enters. It is located in the cool air path inside the air plenum. One lamp lead is in series with the trigger transformer [(1) input (3) output], the other lamp lead (2) is used to sense the lamp voltage. Outside the unit, the board can be tested by putting 350-750VAC between terminals [(1) and (3)], and causing an arc from terminal (3) to terminal (1). This arc should be .015 or greater.




Capacitors and Level Switching

The capacitors pass all the current that flows through the lamp. They are also used to switch power levels.


- The capacitors for the AL 84, AL 84-480, AL 94, are divided into three sections. All units have one or two idle capacitors, they are connected with a yellow wire. High power capacitors are switched in during warm-up and high power exposures. There are two high power capacitors connected with a blue wire. All capacitors have an orange wire which acts as a common.
- The capacitors for high and medium levels are pulled in with relays during warm-up and exposures. The medium relay will pull in to select medium power. In this case the medium relay will also always pull in for high power exposures.
- The capacitors set the operating current of the lamp. If the lamp output has changed rapidly, inspect the capacitors for swelling. The design of

capacitor we use will burn open if it begins to short. A swollen capacitor should be replaced, and the unit should be tested to see that the capacitor did not damage the high or medium relay. To test the unit's ability to switch power levels, make a manual exposure, then switch between the power levels, noting the change in intensity. When switching down in power, allow the unit three seconds to respond.


AL 84 Capacitor Assembly



AL 84-480 Capacitor Assembly



AL 94 Capacitor Assembly




Opening the Lamp Head


- Unplug the unit.
- Remove the glass and the four screws attaching the large outer reflector section.




CAUTION DO NOT TOUCH THE REFLECTOR SURFACE WITH YOUR HANDS.



Remove the 2 center screws from the bottom side and the 2 screws from the top side of the lighthouse.



Remove the 6 screws from each side of the lamphead and remove the two endcaps. On 8kW lampheads you can now access the trigger board and shutter position switch that are located at the opposite end from the shutter motor under the air plenum plate.



Shutter

The shutter is controlled by the PC board, with information from a switch in the lamp head to provide position information. During cool-down and exposure, the shutter is open and during warm-up and idle, the shutter is closed.

The PC board compares the shutter position with the requested position. The shutter motor will run until the switch position matches. The shutter motor has a brake that is magnetically operated. Whenever the power is released from the motor, the brake falls into a slot. There is an LED on the PC board that lights whenever the shutter is being energized. (Look in the PC board pin section for a diagram of the LEDs).

Shutter Switch

The switch provides shutter position information to the PC board. This switch is in the lamp end where the cable enters, inside the manifold cover. The cam is in the chamber with the shutter. A failure of the switch can cause the shutter to rotate continuously or erratically. Similar problems may be due to the shutter motor brake, the idle setting, or the PC board.

The switch contacts close when the shutter is fully open and remain closed until the shutter closes. This level can be measured on the terminal strip from terminal 9 (+) to terminal 7 (-). The level is 12 VDC when the shutter is closed, and 0 V when the shutter opens. The switch is in the lamp head on the end where the cable enters inside the air manifold on older units. On newer units we use the normally open contacts, COM contact and the center contact. We use the normally closed contacts, the two outside leads, not the center contact. This switch is adjustable on older units. We recommend scribing a line around the switch and the bracket, if replacement is necessary, to return to the same position. The switch roller should be centered on the cam and closed when the cam pushes the wheel on the switch halfway.

Shutter Brake

The motor that drives the shutter has a brake that is magnetically operated. When the motor core magnetizes, it pulls a lever to release the brake. If the shutter coasts or rotates continuously, look at the shutter LED on the PC board. On early boards, where there are three LEDs in a row near the front of the power supply, it is the third from the front of the power supply. On the newer models, there are five in a row; it is the fourth from the front of the power supply. When this light goes out, the shutter brake should engage. If the shutter coasts, the brake may have failed. The shutter may coast to the point where the switch will switch again to cause the motor to energize. The LED on the board will flash if this occurs.

Shutter Motor

The shutter motor is located in the lamp head on the side with the shutter drive chain. We recommend checking the power and signals from the switch and to the motor coil, before entering the lamp head. These items are covered in the preceding sections. Changing the shutter motor requires a Phillips screw driver and a $\frac{3}{32}$ " Allen wrench.

- Remove the glass and outer reflector from the light head.
- Open the end of the light head, where the drive chain and the sprocket are located.
- There are four screws that hold the motor; two of them require access through holes in the sprocket. The shutter can be turned counterclockwise to access these screws, by pushing the brake on the motor.



CAUTION Turn the shutter only counterclockwise (looking from the motor end) or you may damage the shutter switch on the other end of the light.

- Remove the chain from the sprocket with care to keep tension. The chain has shortened links and will separate if slackened. If the chain opens, attach an end to the sprocket with tape or wire and revolve the shutter.
- Remove the motor sprocket by loosening the set screw.
- Remove the two wire nuts from the motor coil wires.
- Remove the four motor screws.

Installing the Motor

- Mount the motor with four screws.
- Install the sprocket in line with the shutter sprocket and tighten.
- Install the chain on the sprockets.
- Set the chain to where it has $\frac{3}{8}$ " side travel and tighten the two accessible motor screws lightly.



CAUTION Turn the shutter only counterclockwise (looking from the motor end) or you may damage the shutter switch on the other end of the light.

- Rotate the sprocket to tighten the other two screws and attach the wires.
- The shutter can be tested with the unit open by disconnecting one of the lamp leads and holding the interlock switch.




CAUTION **DO NOT light the lamp without the safety glass or when you are close to the bulb.**

Shutter Removal


LT8 lampheads

- Remove the four hex nuts mounting the blowers, disconnect the blower and thermostat wires.




- Remove the four screws holding the rear reflector to the cooling tubes and remove the reflector and lamp from the lamp head.

CAUTION DO NOT TOUCH THE REFLECTOR SURFACE WITH YOUR HANDS.



- Remove the three screws from the blower mounting plate to the cooling tubes on both sides. Compress the cooling tubes into the shutter assembly, remove the chain from the motor sprocket, then remove the shutter assembly.







- Reassemble in reverse order.





CAUTION DO NOT TOUCH THE REFLECTOR SURFACE WITH YOUR HANDS.



LT8 Shutter Assembly Drawing



29	2	THERMOSTAT	56THM01
28	2	BUSHING, IDLER ARM	12D3550A62
27	4	#8 WASHER, SPLIT LOCK	41 08WLS
26	4	#8-32X.25 SCREW, PHIL.PN.HD.	41 08PPS.25
25	21	#6 WASHER, SPLIT LOCK	41 06WLS
24	4	#6-32 NUT, FLEX LOCK	41 06NLM
23	4	#6 FLAT WASHER	41 06WFR
22	2	6-32 X 7/16 SOC FLAT	41B065HF.43
21	2	IDLER ARM, SHUTTER	63D3530A62
20	4	#6-32X.62 SCREW, 100° FLAT HD.	41B065HF.62
19	3	#6-32X.37 SCREW, 100° FLAT HD.	41 06PF0.37
18	13	#6-32X.37 SCREW, PHIL.PN.HD.	41B06PPS.37
17	8	#6-32X.25 SCREW, PHIL.PN.HD.	41B06PPS.25
16	2	#4-40 NUT HEX	41 04NHX
15	2	#4-40X.25 SCREW, 100° FLAT HD.	41B04PF025
14	6	#6-32X.687 RD. SPACER	42HHS8779
13	2	FUSE CLIP	43CLP02
12	3	#6 WASHER, LOCK INTERNAL	41 06WLI
11	2	LAMP SUPPORT ASSEMBLY	63D0142B03
10	6	BEARING, BALL	SEE BOM
9	1	SPROCKET, DRIVE (MACHINED)	12D1998A99
8	1	AIR TUBE, FRONT	12D1874A62
7	2	SPRING, SHUTTER ALB3	12D2060A07
6	1	AIR TUBE, DRIVE	12D1873A62
5	4	#6 X .187 ROUND SPACER	42HHS8500
4	1	REFLECTOR, INNER, RF83-SW-G	11D1876B99
3	1	LT8 SHUTTER-REFLECTOR ASS'Y	11D2216
2	1	TIMING DISC, LT-1	11D0210A62
1	2	SHUTTER END, PHOTOCCELL, SLOT	11D3974A71
ITEM	QTY	DESCRIPTION	D4358A
		PART NO.	



Idle Setting

- The idle level occurs between exposures and low power exposures. The idle setting determines the power and temperature of the lamp, while at idle. It also allows for much lower idle power than was ever attainable before.
- This lower power level provides a wider light output range, low power consumption, lower heat generation, and increased lamp life. At low power levels, the lamps normally become unstable. If over cooled, they begin to dissipate less energy, which causes them to cool more. This can continue until they extinguish. When lamps become hotter at idle, they become more efficient and dissipate more energy, making them hotter still. This becomes stable, and is commonly done in conventional light sources, but will shorten the life of the lamp and wastes energy. We have chosen to servo the cooling, by sensing the lamp condition and adjusting the cooling to regulate the idle temperature.
- The idle setting is done at the factory and is rarely necessary in the field. Always check all other causes of problems before changing the setting.
- If the lamp becomes too cool during operation, the board will sense this level and initiate a warm-up cycle. During warm-up, the shutter will close and will not open until the unit is sufficiently warm. A symptom of this is: after an exposure is started, the shutter will open, then close again for several seconds, before finishing the exposure. This should only happen if the unit is left for a period of time. Successive rapid exposures would not fail, since it takes many minutes for the unit to over cool. This over cooling situation could also be due to a bad idle capacitor, which would not allow sufficient energy to the lamp to keep it warm.
- After checking the capacitors, mark the factory setting of the trimpot that is located on the back side of the PC board. The trimpot sets the power level that the lamp idles at. Turning the trimpot counterclockwise will first slow the lamp blowers. As the lamp reaches the new idle setting, the blowers will speed up to hold the new level. Setting with a meter is done by measuring the lamp voltage on terminals 2 and 3. See section on Lamp Voltage for proper idle voltage setting. The voltage will increase with a counterclockwise and decrease with a clockwise direction. This voltage change is a secondary effect after the lamp has responded to the change in cooling. The changes should be done in small increments, waiting between adjustment for the voltage to stabilize.
- The idle setting affects the power that the lamp attains on warm-up cycle, before switching to idle and the idle temperature of the lamp. If the setting is too high (too far counterclockwise), the unit will run at high power, with no cooling until the thermostats switch the unit off. The idle temperature of the lamp affects its life and reliability. If the idle setting is too low (too far clockwise), the lamp will be slow to come to power for exposures, and the unit may close the shutter, after the unit has begun to expose to warm back to power. For these reasons, please take care when making this adjustment and check other problems first.

Lamp Head Blowers

- The lamp head blowers are controlled by the printed circuit board to provide the correct cooling to the lamp. During warm-up, the blowers are off or run very slowly. At idle and during low exposure, the blowers vary in speed. Both at high exposure and cool-down the blowers run at full speed.
- A symptom of a defective blower would be: during high power exposure, after approximately 10 seconds, the lamp extinguishes and requires 2 to 4 minutes to restart. One blower will speed up to compensate for the defective unit or low power. When the unit switches to high power, the additional heat causes one of the lamp thermostats to open. (See also Interlock System for information on the thermostats.)
- To test the blowers, turn the power supply main switch on then off. During the cool-down cycle, place a piece of paper over each intake vent located on the lamp end. The paper should be drawn to the lamp end. If one lamp end does not draw, that blower is suspect.
- To replace the blower in the lamp head, see section Opening Lamp Head.

Blown Fuse on PC Board

- If the fuse blows on the printed circuit board, check if the fuse is a 5 amp fuse.
- The printed circuit board drives five or six circuits: the lamp head blowers, shutter motor, power supply blower, and the relays. To find the cause, unplug the unit and replace the fuse; then disconnect the wires to the lamp head on terminals 5 and 6, and disconnect one of the wire nuts connecting the blower in the power supply. The relay coils rarely cause any problem.
- Plug in the unit and turn on the power switch for 10 seconds. If the fuse blows, the problem is either: the power supply blower, the p.c.board or in one of the relay coils. Unplug the unit and reconnect the red wire to the terminal strip. Plug in the unit and turn on, then off. The shutter should now turn. If the fuse blows, the problem is in the shutter motor or wiring to the motor. Unplug the unit and connect the blue wire to the terminal strip. Turn on the unit, then off for the cool-down cycle to test the lamphead blowers. If the fuse blows during this test, the problem could be with either of the two blowers in the lamp head. Normally, when the coil on a blower fails, the coil will become discolored. See section Opening Lamp Head. If the fuse has not blown throughout the test, the power supply blower is suspect.

Lamp Head Signals

Signals at the Terminal Strip (Cable to the Lamp Head)

A great deal of information about the operation of the lamp may be found at the terminal strip, in the power supply that connects to the lamp head. The terminals are counted number 1 at the end where the cable begins, and wire number 18 is the last wire. Terminal number 1 is closest to the dividing wall in the power supply.

Terminal#	Description
#1	Ground to lamp head
#2	Lamp
#3	Lamp
#4	V~ common
#5	Lamp fans
#6	Shutter motor
#7	Shutter position switch
#8	Not currently used
#9	Shutter position switch
#10	Interlock and thermostat switching
#11	Not currently used
#12	Incoming voltage
#13	Autoformer
#14	Incoming voltage

- #1 The ground terminal is for safety purposes and carries no current.
- #2#3 Lamp terminals 2 and 3 carry the power to the lamp. If the lamp is hot or fails to start, the voltage should be 600 to 950V~. During this time, there are voltage pulses that may damage a sensitive voltmeter. Immediately after the lamp strikes, the voltage will drop as low as 20V~, then rise as the lamp warms to the operating voltage, between 180 and 240V~.
- #4 V~ common terminal is the V~ return for the lamp fans, the shutter motor, and the interlock switch. On 120V~ equipment, this is the V~ common from the power line. This potential is generated on 208/240V~ equipment and may be 60V~ from the line common.
- #5 The voltage applied to the lamp fan varies as cooling is required. The voltage is measured referenced to terminal 4 and terminal 5. This voltage starts at 0V~ during unit warm-up and when the lamp temperature

rises it increases. As the lamp reaches temperature, the fans speed increases to regulate the lamp. At idle, this voltage is typically 45 - 90V~ and depends on the lamp age and ambient temperature. When an exposure at high power is initiated, the lamp voltage rises to the maximum. The voltage remains there after the lamp returns to low power, until the lamp temperature again stabilizes.

- #6 The shutter voltage is present during the rotation of the shutter. The shutter motor runs on 120V~ measured to terminal 4.
- #7 Shutter position DC common (see terminal 9)
- #8 Not presently used
- #9 The shutter position switch reports the position of the shutter to the printed circuit board. This switch is open when the shutter is closed, and closes when the shutter opens. This signal is low voltage DC and can be measured (+) on terminal 9, (-) on terminal 7. The meter will read +12 VDC when the shutter is closed, and 0 VDC when the shutter is opened.
- #10 Interlock and thermostat switching. During normal operation, terminal 10 is shorted to terminal 4 (V~ common). An V~ voltage present would indicate the glass switch or one of the two thermostat switches open.
- #11 Not presently used.
- #12#14 Incoming voltage. To get load voltage, meter between terminals 12 & 14 while power is on. On 208/240V~ equipment set voltage selection switch accordingly, (low=219V~ or below, high=220V~ or above).
- #13 a. Autoformer

Light Function States

Model	Warm-Up	Idle	Low Exp.	Med Exp.	High Exp.	Cool Down	Trigger
Unit Fans	On / On	On / On	On / On	On / On	On / On	On / On	On / On
Power Relay	On / On	On / On	On / On	On / On	On / On	Off / Off	Off / Off
Shutter	Closed / Off	Closed / Off	Open / Off	Open / Off	Open / Off	Open / Off	* / Off
	Lamp Fans	Off / Off	Var.Slow / On	Slow/Med. / On	Med./Fast / On	Fast / On	Fast / On
Off / Off	High Relay	On / On	Off / Off	Off / Off	Off / Off	On / On	* / *
* / *	Medium Relay	On / On	Off / Off	Off / Off	On / On	On / On	* / *

Warm-Up - Occurs after the lamp ignites and ends when the lamp has warmed to operating temperatures. The lamp fans are held off and the unit goes to high power. Due to the technology of the power supply, the units do not draw large amounts of current during warm-up. Due to the restrictive cooling, the lamps warm up rapidly, without surge current. The shutter will not open until the unit reaches temperature.

Idle - Between exposures, the lamp is held in idle. During this period, the lamp fans vary in speed to maintain the proper lamp temperature. This allows the unit to consume less power on idle, and provides a wider range of exposure capabilities, since this same low power level is available for exposures. The lower idle saves power, generates less heat, and extends the lamp life.

Expose - The units allow exposures at three levels. At high power, the high and medium relays are activated. At medium power, the medium relay is activated.

Cool-Down - When the unit is switched off, all fans are turned on to cool the equipment. After the cooling period, the unit disables all of its functions until it is started again.


Trigger - If the lamp is turned on before the unit has fully cooled, the fans will run at full power and a trigger pulse is created. This mode will release itself when the lamp strikes. The unit is responding to conditions to provide these functions. It is therefore not possible to confuse the unit. If there is a momentary loss of power, the unit will cool the lamp until it strikes. It is recommended that the unit be shut off and allowed to cool, rather than turning off the power supplied to the unit.

Printed Circuit Board Layout

This is a description of the signals and voltages present on the pins of the printed circuit board.

64MV407V24 Control Board layout.

Note: Graphic of the new style p.c.board is shown. Relay style p.c.board has the same connector hookups and pin outs, however the LEDs are on the component side of the p.c.board not on the solder side as on the new style. The old style board is replaced by the new style and is interchangeable.



Front View of Control Board


Triacs & Relay	
K1	Unit Power
TR101	Shutter Motor
TR102	High Relay
TR103	Medium Relay
TR104	Main Contactor
TR105	Lamp head fans

P1 Power Connector			
1	AC Hot	7	Unit Fan
2	AC Common	8	Power Relay
3	Lamp Fans	9	Not Connected
4	Shutter Motor	10	Aux Terminal
5	High Relay	11	DC Common
6	Medium Relay	12	Position

P2 Switch Connector			
1	AC Hot	7	High Switch
2	AC Common	8	Low/Med Switch
3	Not Connected	9	Manual Expose
4	Aux Terminal	10	Interlock
5	DC Com/Ground	11	Not Connected
6	Power Switch	12	+12 VDC

LED's	
D18	Lamp head fans
D13	Power Supply Fan
D17	Shutter Motor
D15	High Relay
D16	Medium Relay
D14	Power Relay

Check Idle Voltage on Board or on Terminal Strip Lugs #2 and #3



Idle Voltage Adjustment

Back View of Control Board

Signal Description

Power Connector

P1)	V~ Hot: Supply to board approximately 125V~.
P2)	V~ Common: Common to board is the common also for relays, shutter fans, and the internal lamp head interlock. (This may not be at ground potential and should be measured with caution).
P3)	Lamp Fans: V~ proportional drive output for the blowers in the lamp head.
P4)	Shutter: V~ output to drive the shutter motor.
P5)	High: V~ Output to drive the high relay, which engages the high power capacitor bank during warm-up and high power exposures.
P6)	Medium: V~ Output to drive the medium relay which engages the medium capacitor bank during warm-up and both high and medium level exposures.
P7)	Unit Fan: V~ Output to drive the power supply blower or fans.
P8)	Power Relay: V~ Output to drive the main relay. This provides power to the lamp circuit.
P9)	Not currently used.
P10)	Aux: Terminal connects to the signal connector for accessories (Not used in most equipment).
P11)	DC Common: Circuit common for low voltage signals from the lamp (this may not be the same potential as V~ Common connection and should never be interchanged).
P12)	Position: Shutter switch active signal from the lamp head - Low voltage when the shutter is open and 12VDC when closed.

Switch Connection

S1)	V~ Hot: Output, V~ supply for internal accessories.
S2)	V~ Common: Output, V~ common for internal Accessories.
S3)	Not currently used.
S4)	Aux: Terminal connects to the power connector for accessories (Not used in most equipment).
S5)	DC common: DC circuit common for switches (Not the same as V~ Common).
S6)	Power Switch: Switch to turn on power. Low (0V) for power on. The power can also be turned on by the integrator through the outlet. (Only a signal ! Power is always present on the PC Board).

Continued on next page

Switch Connection (cont.)

S7)	High Switch: Switch to select high power level. Low (0V) for high.
S8)	Low/Med Switch: Switch to select power level when high switch is off. Low (0V) for medium power, High (12VDC) for low power.
S9)	Manual Switch: Manual expose switch. Low (0V) to cause exposure.
S10)	Interlock: External interlock outlet. Line must be connected to DC common to allow an exposure. (Outlet is normally shorted when plug in not inserted).
S11)	Not currently used.
S12)	+12V: Output for internal accessories (Not used in most equipment).


DIN Connection

D1)	Expose: High expose when connected to a compatible integrator. High / Medium / Low expose depending on the unit switches when connected to an older style integrator or other manufacturer's equipment.
D2)	DC Common: Common for all signals.
D3)	Low Exp: Low expose input.
D4)	Power: Signal from integrator to turn on the power.
D5)	Medium Exp: Medium expose input.


LEDs

The LEDs are an indicator of an acting command that you are asking the control board to do. For a list of which commands activate which LEDs, look at the chart above, labeled LED indicators. The LEDs light when they detect a ground or negative going pulse.


Circuit Diagram (64MV407 60Hz)




Lamphead for all Lights




AL 84 Power Supply 60Hz




AL 84-480 Power Supply 60Hz



AL 94 Power Supply 50Hz



Interconnect Cable



14. Printing Light Check List

Check List for Printing Light Troubleshooting and Service



CAUTION In order for this check list to be effective it must be followed step by step.

- 1) Disconnect the integrator/timer from the power supply.
This will make sure that a faulty integrator or cable is not responsible for the malfunction and also eliminate a bad DIN socket on the p.c.board.
- 2) Check the tap switch (208/240V~ power supplies only. If the top LED is lit, make sure the switch is in the UP position, and if the bottom LED is lit, make sure the switch is in the DOWN position (see Printing Light Installation Manual). Improper setting will most likely cause blower, capacitor, and/or PC board failure and will prematurely age the lamp.
The LEDs next to the switch are not controlled by the switch, the LEDs tell you where to put the switch.



CAUTION You **MUST NOT** flip this switch with the power supply turned on! You will arc the contacts inside and this will damage the switch.

- If the tap switch is set for 240V~ and you have 208V~ coming in, the light source is going to draw excess amperage (as voltage goes down amperage draw has to go up). If when you open the power supply you notice right off burnt wires or connectors, one of the most likely causes is the tap switch in the wrong position. This condition usually take months and sometimes years (depending upon the degree of voltage discrepancy) to show up. When the burnt wire is on the tap switch itself or on the bottom side of the power relay it is very difficult to see the burnt wires without some disassembly of the power supply.
- If the tap switch is set for 208V~ and you have 240V~ coming in, the p.c.board and the blowers are usually the two items to get damaged. Over voltage to the blowers will burn them out and are usually the first to component damaged, the p.c.board will also be damaged under extended usage in an over voltage condition.
- If the voltage fluctuates there is a line that you can not cross 219V~ 220V~ the voltage must always stay 220V~ or above or always stay 219V~ or below.

If the switch itself is bad with no external signs of burning make sure that the user is not flipping the switch with the power supply on. Flipping the switch with the light source turned on will cause damage to the switch that may take time to show up.

- 3) Check the safety glass for proper installation. The long dimension of the glass goes parallel with the long dimension of the lamphead. Improper installation can cause the glass to shatter and/or an 'open' in the safety interlock circuit.



- You must be able to reach up, place your fingers against the safety glass and there must be play front to back and side to side. Otherwise the glass does not have room for expansion and will more than likely shatter under use.

CAUTION **NEVER** operate the light source without the safety glass in place.

- 4) Check the beau plug at the lamphead. Make sure it is pushed in all the way. The most likely problem caused by a loose beau plug is an erratic shutter operation or an open safety interlock circuit.

Just push in on the beau plug while rocking it up and down to make sure it is in all the way.

- 5) Check the lamphead interlock circuit. Remove or lower the safety glass. Turn the power supply on. Check for 120V~ from terminal 4 to terminal 10; when the glass is reinstalled, the voltage should go low. (See Interlock System for operation.)

With the interlock open what should happen is the shutter should close and the power supply blower should come on, that's all. After you remove the glass and you turn on the power supply, if the light source comes on turn power off immediately and determine what is shorting out and bypassing the safety interlock circuit. If this does happen it is possible that the safety interlock circuit is shorting to ground. On older light sources this condition would burn up the autoformer. On newer light sources this condition will blow the 3A slow blow fuse on the dividing wall below the wiring harness.

- 6) Check input voltage with the power off at terminals 12 & 14. Then with power on, intensity level on high, and manual expose set on, check the voltage again. If the voltage drops more than 6 V~, the incoming power is most likely a problem.

You can do checks 6 and 7 at the same time. Write down the voltage that you get before turning power on and after turning power on but before the light source completes the warm up cycle. This is maximum amperage draw so the voltage will show maximum drop.

If the voltage in check 6 drops more than 6V~ the incoming power is a problem and it can not be corrected in the power supply (there is nothing you can do in the power supply to correct bad voltage from the wall).

- 7) Check input voltage to the PC board with the power off at pins 1 & 2 (see p.c.board layout for pin location). Then with power on, intensity level on high, and manual expose set on, check the voltage again. If the voltage drops more than 6 V~, the autoformer is most likely a problem.
- If and only if the voltage on 12 and 14 in step 6 is good can you say that the autoformer is definitely bad, if the voltage on 12 and 14 in step 6 is bad you can not get a correct reading for step 7.

8) Check capacitors and relay circuit by:

The capacitors and relays are checked by watching the voltage changes that take place at the different intensity levels. If a capacitor is not in the circuit the voltage readings on input and output will be the same. If the capacitor is pulled into the circuit the input and output voltages will be hundreds of volts apart. Now the tricky part, if a capacitor is pulled into the circuit the way it is supposed to be then we need to look at the voltage itself to see if we see an increase in the overall voltage to make sure that the capacitor is adding voltage to the circuit. If the capacitor is pulled into the circuit when it is supposed to be but the overall voltage does not increase then the capacitor is defective.

9) Check voltage from terminal 3 to the capacitor input (orange wire on top of the capacitors). The voltage should be 700+ V~. If voltage is lower, check the power path to the tap switch and ballasts. 700+ V~ for the 8kW light sources. If the voltage on a 208/240V~ is low, then not all the ballasts are being powered properly. This is usually caused by a bad tap switch or a burnt connector at the tap switch, however any of the wiring between ballast and tap switch is suspect. If the voltage is zero then a burnt wire at the power relay or a bad power relay is most likely the problem. There is a possibility that if there is zero V~ that you might have a grounded safety interlock circuit.

- At idle, check voltage from terminal 3 to the capacitor outputs (yellow, brown, and blue wires on top of the capacitors).

On the following charts find the Wattage of the unit you are working on and then for the lamp installed into the unit, these are the general voltages you should read. These voltages are a ball park figure depending upon several factors and the actual voltage is not as important as to whether or not the voltages change on the capacitors according to intensity level. For instance on a 8kW light with an L1280 lamp at low intensity two capacitors will be about 370V~ and three capacitors will be over 700V~. Now when you go to medium intensity you should see three capacitors at about 395V~ and two capacitors at over 700V~. **NOTE** the number of capacitors at the lower voltage (i.e. in the circuit) and the voltage increase from the previous intensity 370V~ at low and 395V~ at medium.

- At low power, manual expose on, check voltage from terminal 3 to the capacitor outputs (yellow, brown, and blue wires on top of the capacitors).
- At medium power, manual expose on, check voltage from terminal 3 to the capacitor outputs (yellow, brown, and blue wires on top of the capacitors).
- At high power, manual expose on, check voltage from terminal 3 to the capacitor outputs (yellow, brown, and blue wires on top of the capacitors).
- SEE CHART FOR PROPER VOLTAGE READINGS (ALL VOLTAGES ARE READ TO TERMINAL 3).

8kW with L1280 LAMP						
		ORANGE	YELLOW	BROWN	BLUE #1	BLUE #2
a.	IDLE	700+	360	700+	700+	700+
b.	LOW	700+	360	700+	700+	700+
c.	MEDIUM	700+	390	390	700+	700+
d.	HIGH	700+	425	425	425	425

8kW with L1281 LAMP						
		ORANGE	YELLOW	BROWN	BLUE #1	BLUE #2
a.	IDLE	700+	395	700+	700+	700+
b.	LOW	700+	395	700+	700+	700+
c.	MEDIUM	700+	425	425	700+	700+
d.	HIGH	700+	485	485	485	485

8kW with L 1282 LAMP						
		ORANGE	YELLOW	BROWN	BLUE #1	BLUE #2
a.	IDLE	700+	395	700+	700+	700+
b.	LOW	700+	395	700+	700+	700+
c.	MEDIUM	700+	430	430	700+	700+
d.	HIGH	700+	510	510	510	510

‡ The voltage readings described in the following are typical of 5kW light sources see voltage chart to find high and low values for others.

10) If a reading remains high (700V~ or more see note ‡) and it should be low (less than 600V~ see note ‡), the capacitor is not being pulled into the circuit. Check the respective relay, resistor, and wiring for an open.

11) If a reading remains low (less than 600V~ see note ‡) and it should be high (700V~ or more see note ‡), the capacitor is locked into the circuit. Check the respective relay, wiring, and PC board for a short.

12) If the readings show voltage changes from high to low and from low to high, but the overall low reading does not increase from the previous power level, then the capacitor being pulled into the circuit has failed.

13) Check the blowers using a piece of paper held up to the intakes at each of the lamphead during a cool-down cycle. The paper should get held up to each intake, if it doesn't, the blower is bad.

Blowers speed can not be checked until this point because all previous

checks affect the operation and can make them appear to be operating incorrectly. Also check blower voltage at terminals 4 & 5 for most lights this voltage should be a MINIMUM of 65V~ to 75V~ some lights this voltage will be higher depending on lamp used and lamp condition.

- 14) Check for cooling obstructions on intakes and exhausts. If any are found, remove them.
- 15) Check lamp idle voltage at terminals 2 & 3. This voltage should match the voltage chart above, if not, YOU MUST install a new lamp and recheck (see Idle Setting if adjustment is necessary).



CAUTION DO NOT ADJUST idle voltage with a used lamp.

Lamp voltage can be effected by all the checks in the check list to this point. So if this check list is used properly (followed step by step) if at this point the lamp voltage is out of specification it can now be adjusted if the lamp is less than two weeks old **AND "not or"** has no sign of deformation otherwise a new lamp must be installed before adjusting. Adjusting lamp idle voltage without first checking other causes of the lamp voltage deviation can damage the equipment.

- 16) If used, check the power supply safety interlock jack next to the power supply power on/off switch. A failure in this circuit will not allow the unit to do an exposure, the only time the shutter will rotate if this circuit is open, is when the power is turned on or off.


If you suspect this circuit is faulty, turn the manual expose switch on, then short the blue and white wires on the jack together with a screwdriver (make sure you do not short to ground) and see if the shutter opens, if it opens the circuit is at fault.

- 17) Check for smooth shutter rotation. If the shutter rotates smoothly, skip to step 20, otherwise continue.
- 18) If the shutter does not rotate smoothly, it may not stop in the correct position and the bearings must be greased.
- 19) If the shutter fails to rotate at any time, then check the following:
- 20) When the shutter is supposed to be moving. Check for 120V~ between terminals 4 & 6. If there is voltage, go to the lamphead and check for voltage at the shutter motor then skip to step 22.
- 21) If there is no voltage between terminals 4 & 6, check the PC board output for voltage at pins 2 & 4 (see PC Board Layout for pin location).
- 22) Check to make sure the shutter stops immediately in the correct position.
- 23) If the shutter stops immediately, but in the wrong position, check the shutter position switch.
- 24) If the shutter coasts to a stop in the wrong position, check the shutter brake.
- 25) If you run into a situation where you are not getting voltage at the terminal strip, relay, blower, etc. make sure you go to the PC board itself and Double check the PC board outputs before replacing it.


- 26) Before you reassemble everything it is a real good idea to: Check the manual operations of the light source. Just to make sure everything is back together.
- 27) Reconnect all wires to the integrator and then: Check the remote operations of the light source from the integrator.

15. Fault Trees


No Strike Fault Tree



Shutter Rotation Fault Tree




Front View of Control Board



Front View of Control Board

Triacs & Relay	
K1	Unit Power
TR101	Shutter Motor
TR102	High Relay
TR103	Medium Relay
TR104	Main Contactor
TR105	Lamp head fans

Drive Motor Fault Tree



16. Parts List

Part Number	Description	Qty. per unit
62AP42CL	Base Kit AccuPrint Closed Loop	1
39VAP05	Vacuum Pump 230 V 60 HZ	2
55SW45-6	Button, white 'GO'	1
55SW45-7	Button, white 'STOP'	1
62D3542A00	Assembly Rail Cover, OV45	1
62D3705A00	Base Assembly AP 42CL	1
68D3827A00	Assy, mylar frame	2
90KITCHN-CVR	Kit, Drive Chain Cover	1
32TRC05	(480V units only) Transf. 5KVA, 480/240	1
16D3503A00	(480V units only) harness, XMR	1
62AP42CL-CENTER	Assy AP42 Center Section	1
11D1660A99	Mount Spring Lt. Blk	2
11D2111B62	Switch Mount	2
11D2148A17	Light Block, Upper	1
11D2202B02	Spacer, hinge	1
11D2240A62	Mount, Door Switch	2
11D3395A17	Deflector, Air	1
11D4326A07	Strip right rail	2
12D1635A00	Block, Mount Accu-Trac	10
12D1653B62	Hinge, Light Block	1
12D1750A62	Slide	1
12D1751A00	Threaded Rod	1
12D1752A62	Slider	1
12D1753A00	Idler Sprocket	1
12D1754A00	Idler Bushing	1
12D1755A00	Tensioner Bushing	1
12D1757A62	Chain Yoke	2
12D1996A00	Tensioner Sprocket	1
12D2150A99	Shaft, AccuTrack, OV	2
15D725	Insulation Pad AL 13	1
16D2319A00	Harness, Motor - POS	1
43CHA05	Chain, #35 RLR - 10	10
43OSD01	Overtorque Safety De	1
43SPK07	Sprocket, 35A22, for	1
43SPR14	Spring, Chain Tension	1

Part Number	Description	Qty. per unit
43SPR17	Spring, Tors. LH	1
43SPR18	Spring, Tors, RH	1
44GKT01	Gasket, 1/16 Thick	0
44TIE08	NSI Cable Tie, UV	5
55SW02	Switch, Timing	4
55SW55	Pushbutton switch	2
62D2321A00	Assembly, Wheel, Lig	2
62D3706A00	Exposure tray(Lower)	1
62D3706B00	Exposure tray(Upper)	1
62D3707A00	Seal, Glass AP42CL	2
62D3798A00	Ass'y drive mtr w/co	1
65D3774A00	Silkscreen, bezel AP	1
81TAP16	Tape Glide (Black UH	0.1
81TAP17	Transfer Tape,3/4	1
62AP42CL-COOL	Assy Cooling Module AP42	1
11D3371A62	Bracket, Mount (Heat Exchanger)	4
11D3374A17	Panel, side (Clsd. Loop)	2
11D3381A17	Plate, Rear Blower(Clsd. Loop)	1
11D3382A62	Mounting plate, Plumbing	2
11D3685A17	Duct, Intake	1
11D3685B17	Duct, Intake	1
11D3687A08	Cover, Rear(Lower)	1
11D3857A17	Bracket, molex connector	1
11D4079A17	Ass'y upper collector	1
12D3466A07	Nipple, flow meter	1
16D3808A00	Harness, valves	1
16D3810A00	Harness, blowers	1
31SOV09	Two way solenoid valve	3
31SOV09-C240	Solenoid coil -208/240V	3
39BLO17	Blower, 495 cfm	4
39HTX01	Heat exchanger (34" wide)	2
43BXC01	Cover, Handy Box	1
43CLM10	Hose clamp 1" ID	6
43CLM13	Hose clamp 1 $\frac{1}{2}$ "-2 $\frac{1}{2}$ "	4
43FIT41	Manual ball valve	1
43FIT42	Barb-male straight connec	5
43FIT43	Barb-male straight connec	5
43FIT44	Hex nipple-male Brass	1

Part Number	Description	Qty. per unit
43FIT46	Reducer nipple-male	3
43FIT49	Female Conn. 1"NPT Brass	2
43FIT51	Male-female elbow	2
43FIT52	Female tee, Brass, 1"NPT	3
43FIT54	Cross-female, $\frac{3}{4}$ "NPT	1
43FIT57	Hex nipple-male	8
43FIT58	Bushing,femal-male 1" x $\frac{1}{2}$ "	2
43FIT60	Female elbow, $\frac{1}{2}$ "NPT	2
43FIT65	$\frac{1}{2}$ "NPT male branch 'T'	3
43FIT66	Nipple, 6" lg $\frac{1}{2}$ " NPT, BRASS	1
43FLOW01	Flow meter	1
43HBX02	Handy Box	1
44GKT01	Gasket, $\frac{1}{16}$ " Thick $\frac{1}{2}$ "	0
49DCT24	Tubing, $\frac{5}{16}$ " I.D. x $\frac{1}{2}$ " O.D	4
49DCT34	Braid clear tubing, PVC	30
49DCT38	Hose,braided $\frac{1}{2}$ "NPT x 20"L	3
49DCT39	Hose,braided $\frac{1}{2}$ "NPT x 12"L	3
49DCT41	Hose insulation	30
49THERM01	Thermometer	1
68D3765A00	Assy inst.,plumb,cool mdl	0
72FOM42	Foam, close loop 1" thk	4
72FOM43	Foam, closed cell polyethe	4
11D4326A07	Strip, right rail	2
81TAP17	Transfer tape 3/4	18'
90KITSTRIP-OV45	Retrofit kit for drawer rail tape	1
62AP42CL-INSERT	Ass'y insert sectiion	1
11D2051A62	Mount, Spring, Low Lt. Blk-R	1
11D2051B62	Mount, Spring, Low Lt. Blk L	1
11D2147A17	Lightblock, Lower	1
11D2273A17	Cover, Power Terminal	1
11D3395A17	Deflector, Air (Clds. Loop)	1
11D3869A08	Cover, plate switch	1
12D1653B62	Hinge, Light Block	1
12D2053A62	Mandrel, Spring, Low.Lt.B	2
15D1852	Label Connectors, Ctl Box	1
43SPR21	Spring,tors LH	1
43SPR22	Spring,tors RH	1
44GKT01	Gasket, $\frac{1}{16}$ " Thick $\frac{1}{2}$ "W	0

Part Number	Description	Qty. per unit
49VAV01	Valve, Vacuum Relief	2
62D2321A00	Assembly, Wheel, Light Bl	2
62AP42CL-NSA	Assy Nose Fan/Work Light	1
11D1939A62	Bracket, Filter Holder	2
11D1939B62	Bracket, Filter Holder	2
11D3733A07	Reflector, Worklight	1
11D3734A08	Air Director No 1	1
11D3735A08	Air Director No.2	1
11D3736A08	Air Director No.3	1
11D3746A17	Divider Nose (Left)	1
11D3746B17	Divider Nose (Right)	1
16D3804A00	Harness, light/blower	1
18D3776A00	Bezel, Worklight	1
19D1942A99	Filter, Top	2
26CF4-15-4	Resistor,15Kohm,2W,5%	1
32TRC08	Autoformer 208/225/240 V	1
35LMF06	Lamp, Yellow Viewing 20 w	4
39BLO11	Blower	2
39CLF02	Light Fixture Undercabine	4
43FIT13	Reducer, Tube $\frac{3}{8}$ " to $\frac{1}{4}$ "	2
43FIT14	Connector, $\frac{1}{4}$ " Tube to 1"	2
49DCT27	Tubing, Nylon $\frac{1}{4}$ " OD	0
51SI18E	Spade, Ins. 22-18Ga #8	4
52SKL13	Lampholder, Bi-Pin	0
52TS05	5 Position Terminal Strip	1
55SW01	Switch, CW	2
62AP42CL-TOP	Assy, Top Section AP42	1
11D2222A17	Side Mount	1
11D2222B17	Side-Mount	1
11D2223A17	Bracket, Rolling Filter	1
11D2223B17	Bracket, Rolling Filter Mo	1
11D2224A17	Bracket, Lamp Head Mount	1
11D2224B17	Bracket, Lamp Head Mount	1
11D2260A17	Bracket, Lamp Support	1
11D2266A17	Bracket, Support, Sml	1
11D2368A62	Bracket, shipping	2
11D249	H D1 Lamp Head Heat Defl	2
45KOB06	Knob, Lite Std	4

Part Number	Description	Qty. per unit
62D3476A00	Assy, condensate evap-CLS	1
39EVP01	Condensate Evaporator, 23	1
42HHS2175	Grommet,rubber $\frac{3}{4}$ "	1
51TML03	Terminal male 14-20 AWG	3
52RCP08	Receptacle, 3 Pin	1
68D3477A00	Instr. Assy,cond evap-CLS	1
62D3555A00	Assy,Ctrl Bx-8K CLS,GT, 208/240 60hZ	1
16D3208A00	Harness, Cntrl Bx -GTools	1
16D3448A00	Harness, 8k CT Closed Loo	1
16D3878A00	Harness, cntrl bx suppl	1
31MSC02	Motor, speed control-KB	1
32PSF01	Power Supply, Open Frame	1
32TRC01	Autoformer 208-240 Volt	1
33RLY20	Relay, 12VDC, Chassis Mou	1
44CPG08	Plug,plastic,black $1\frac{1}{2}$ " DIA	3
44RUB03	Grommet,Continuous .06	0
44TIE03	NSI Cable Tie $7\frac{1}{2}$ "#50 Max	10
52FUH04	Fuse Holder, 3AG/3AB	4
52FUH08	Fuseholder, 3AG, .25 Tab	2
52LUG01	Lug Connector, #2-#8 Wire	1
52RCP21	Receptacle, 250V/15A (6-1	2
52RCP24	Receptacle, 250V/50A (6-5	2
52TS20	Pwr. Dist. Block, 2 pole	2
56FUS15	Fuse, 3A 250V 3AG Slow Bl	1
56FUS16	Fuse, 1/2A 250V 3AG Slow	1
56FUS28	Fuse, 10A 250V, Slow Blow	4
62D2483A00	Blower, 220V	1
62D331A	Voltage Selector Assembly	1
64CT464	PCB Assembly. AccuPrint	1
62D3558A	Assy,Ctrl Bx-8K CLS,GT, 480 60hZ	1
15D3586A00	Label, Wiring Conn 480V	1
16D3074A00	Harness, Control Box Supl	1
16D3208A00	Harness, Cntrl Bx -GTools	1
16D3455A00	Harness , CT Box - Closed	1
16D3878A00	Harness, cntrl bx suppl	1
31MSC02	Motor, speed control-KB	1
32PSF01	Power Supply, Open Frame	1
32TRC01	Autoformer 208-240 Volt	1

Part Number	Description	Qty. per unit
33RLY20	Relay, 12VDC, Chassis Mount	1
44RUB03	Grommet,Continuous .06	0
44TIE03	NSI Cable Tie 7 $\frac{1}{2}$ "#50 Max	10
51SI18	NSI Spade, Ins 22-18 # 8	2
52FUH04	Fuse Holder, 3AG/3AB	6
52FUH07	Fuse Block- $\frac{13}{32}$ " x 1 $\frac{1}{2}$ "	1
52FUH08	Fuseholder, 3AG, .25 Tab	2
52LUG01	Lug Connector, #2-#8 Wire	1
52RCP20	Receptacle, 125V/20A	2
52RCP21	Receptacle, 250V/15A	2
52RCP24	Receptacle, 250V/50A	2
52TS19	Power Dist.Block 3 pole 4	2
56FUS04	Fuse, 5A/250V Slow Bl 3AG	2
56FUS13	Fuse, 30 A 250 V Slow-Blow	4
56FUS15	Fuse, 3A 250V 3AG Slow Blow	1
56FUS16	Fuse, 1/2A 250V 3AG Slow	1
56FUS28	Fuse, 10A 250V, Slow Blow	4
62D2483A00	Blower, 220V	1
62D331A	Voltage Selector Assembly	1
64CT464	PCB Assembly. AccuPrint	1
62AL85-L2	Printing Light with L 1282 208/240 60Hz	2
62CL85-8K	CL85 Power Supply 208/240 60Hz	1
16D1045A00	Harness, Beau Plug OEM	1
16D1585	Interlock Harness	1
16D2617B00	Power Cable, AL85-AP42 PS	1
16D2629A00	Harness, 8K-B P/S - Main	1
32BAL01	Ballast	4
32TRC08	Autoformer 208/225/240 V	1
33RLY04	Relay, Sealed	2
33RLY18	Contactors Relay 50 Amp	1
39BLO03	Blower,Model Ball Bearing	1
52FUH04	Fuse Holder, 3AG/3AB	1
56FUS15	Fuse, 3A 250V 3AG Slow Blow	1
62D1046-85	Capacitor Assembly	1
62D1047	Voltage Selector 60 Hz AL	1
64MV407V04	Assy UV Lt Ctrl 8K 60Hz	1
62LH83SE-SW	Lamp Head 8K Stdrd Rev SE	1

Part Number	Description	Qty. per unit
62CL84-480-L2	Power Supply 480V 60Hz,8K	
16D2617B00	Power Cable, AL85-AP42 PS	
16D1045A00	Harness, Beau Plug	1
16D1585	Interlock Harness	1
16D2617A00	Power cable	1
16D2629A00	Harness, 8K-B P/S - main	1
32BAL01	Ballast, AL 83	4
33RLY02	Contactor, 2 pole,NO,30Amp	1
33RLY04	Relay, Sealed	2
39BLO03	Blower,Model Ball Bearing	1
43CLM02	Cable Clamp, Regal $\frac{3}{4}$ "	1
43SPR08	Compression Spring $\frac{7}{16}$ "	2
44LEG03	Leveling Glide, Non-Skid	4
44RUB02	Grommet,Continuous	1.25
51WRN07	NSI Wire crimp nut	6
52FUH04	Fuse Holder, 3AG/3AB	1
54PWR05	Pwr Crd 18/3 SJT 12" 5-15	1
56FUS15	Fuse, 3A 250V 3AG Slow Blow	1
62D3533A00	Assy, Capacitor 60H,480V	1
64MV407V04	Assy UV Lt Ctrl 8K 60Hz	1
62LH83SE-SW	Lamp Head 8K Stdrd Rev SE	1
62LH83SE-SW	Lamp Head 8K Stdrd Rev SE	1
62LHK02-83	Roller Assembly AL 83	1
62SA83SE-BASE	AL 83 Shutter	1
63D0142B03	8K Lamp Support Bracket	2
L1282	Lamp	1
PA91	photocell assembly	1
11D0863A71	Glass Clamp	2
12D1361	Ladder Chain, # 18-49	1
12D1577	Spring, Idler-5K Shutter	1
12D1997A99	Sprocket, Hub Machined	1
16D0180A00	Harness, Lamp Head 5 K	1
HG 1	Safety Glass	1
18D319	Glass, 5K Frosted Diffuser	1
31MOT06	Shutter Motor	1
39BLO14	Blower, 50/60 Hz (8K)	2
44WFN02	1/4 ID Nylon Washer	1
45KOB05	Knob, Glass. Carriage	2

Part Number	Description	Qty. per unit
55SW03	Switch, Glass, 2 Pos Blk	1
56THM01	Thermostat, model K	2
62LHK01	Switch Assembly	1
63D3669A00	Idler, Arms Assy LT8	1
64MV414-T	Trigger Board Tested 8K	1

17. Warranty

OLEC

Limited Warranty

OLEC equipment is warranted against defects in material for ONE (1) Year from date of purchase. Faulty parts will be repaired, replaced, or purchase price refunded at OLEC's option, for the original Buyer, provided the parts have been replaced by authorized personnel and are returned prepaid to the OLEC factory in Irvine, CA. Shipment must be accompanied by proof of purchase and the Dealer/Distributor name.

This Warranty applies only to equipment which was installed and used according to instructions and in the way it was intended to be used by the manufacturer. Unauthorized repairs, use of non-OLEC parts and lamps, modification, or Serial Numbers that have been removed or defaced, void this Warranty. Glass parts are not included in this Warranty. Lamps are covered according to the Warranty below.

The OLEC Corporation and/or the Seller shall not be liable for any loss, damage or injury arising out of the improper use of, the failure of, or the inability to use the equipment. It is the Buyer's responsibility to ascertain the suitability of the equipment for the application. The Buyer assumes all risk and responsibility for the proper installation, for reading the Instruction Manual and retaining it with the equipment for the safe use of the OLEC product. All operators must be made familiar with the proper use and safe operation upon installation and periodically thereafter.

No one is authorized to assume any obligation, either on behalf of the OLEC Corporation or the Seller, which is not in accordance with the above.

Lamp Warranty

Should any original OLITE Lamp fail prematurely when used in OLEC lights, it should be returned promptly to OLEC, prepaid. It should be accompanied by proof of purchase, explanation of the type of failure incurred, and the approximate useful life of the lamp prior to failure. If it is determined by OLEC that the failure or shortened life has been caused by faulty material or workmanship, full or partial replacement will be extended to the Buyer.

IMPORTANT: The use of any lamp, other than those purchased or approved by OLEC will void this Warranty.

*All Warranty Service should be handled through the Distributor
through whom the equipment was purchased.*



Corporation

17112 Armstrong Avenue, Irvine Ca U.S.A. 92614
U.S.A. (949) 399-6500 Fax (949) 399-6501