


# MCS 12000 ND (Compact)

Date 07/2010  
Manual date: 09.07.2010



## Operating Instruction and Documentation

Serial number:.....

Retailer address / phone

Made in Germany



# Nussbaum

Otto Nußbaum GmbH & Co.KG//Korker Straße 24//D-77694 Kehl-Bodersweier  
Tel: +49(0)7853/8990 Fax: +49(0)7853/8787  
E-mail: [info@nussbaum-lifts.de](mailto:info@nussbaum-lifts.de)//<http://www.nussbaum-lifts.de>

## Contents

Foreword .....	3
Record of handing over .....	5
<b>1.Introduction.....</b>	<b>6</b>
1.1 Installation and check of the automotive lift .....	6
1.2 Information of Warning .....	6
<b>2.Master document of the MCS 12000 .....</b>	<b>7</b>
2.1 Lift–manufacturer.....	7
2.2 Application .....	7
2.3 Changes at the construction .....	7
2.4 Page for notice .....	8
<b>3.Technical Information .....</b>	<b>9</b>
3.1 Technical ratings.....	9
3.2 Safety device .....	9
3.3 Data sheet .....	11
<b>4.Safety regulations .....</b>	<b>12</b>
<b>5.Operating instructions .....</b>	<b>14</b>
5.1 Positioning the Mobile column lift .....	14
5.2 Lifting the vehicle .....	15
5.3 Lowering the vehicle .....	16
5.4 Single-Mode „Lifting“ .....	17
5.5 Single-Mode „Lowering“ .....	17
5.6 Function Microprocessor / Display-advertisement .....	18
5.7 Equalisation of the Mobile column lift.....	18
<b>6.Troubleshooting .....</b>	<b>19</b>
6.1 Lowering on a obstacle .....	20
6.1.1 Remove the obstacle .....	20
6.2 Emergency lowering .....	20
6.2.1 Procedure of the emergency lowering .....	20
6.3 Reset the Mobile column lift after an emergency lowering.....	21
<b>7. Inspection and Maintenance.....</b>	<b>22</b>
7.1 Maintenance plan of the Mobile column lift.....	23
7.2 Cleaning of the Mobile column lift.....	24
<b>8.Security check .....</b>	<b>25</b>
<b>9.Handing over and Initiation .....</b>	<b>26</b>
9.1 Regulations.....	26
9.2 Initiation .....	26
9.3 Cable connection of the Mobile column lift .....	27
First security check before installation .....	28
Regular security check and Maintenance .....	29
Extraordinary security check.....	37
Hydraulic diagram.....	38
Electric diagram .....	<b>Fehler! Textmarke nicht definiert.</b>

## Foreword

Nußbaum lifting systems are the result of a long time experience in the automotive lifting industry. The high quality and the superior concept ensure reliability, a long lift lifetime and above all and economic business solution.

To avoid unnecessary damage, injury or even death, read the operating instructions with care and observe the contents.

Nußbaum lifts is not responsible for incidents involving the use of Nußbaum lifting systems for applications other than those for which they were designed.

***The Otto Nußbaum GmbH & Co. KG is not liable for any resulting damages. The user carries the risk alone.***

## Obligations of the user:

- To observe and adhere to the operating instructions.
- To follow the recommended inspection and maintenance procedures and carry out the prescribed tests.
- The operating instructions must be observed by all persons working with or around the lift.
- Above all chapter 4 "Safety Regulations" is very important and must be closely adhered to.
- In addition to the safety regulations stated in the operating instructions manual, the appropriate safety regulations and the operating procedures of the place of operation must also be considered.

## Obligations of the operator:

The operator is obliged to allow only those persons complying to the following requirements to work with or around the unit.

- Persons being familiar with the basic regulations concerning labour safety and accident prevention and being trained to operate the particular unit.
- Persons having read and understood the chapter concerning safety and warning symbols.
- Persons using the lift are required to confirm that they have read and understood the chapter on safety and warning symbols by signing the appropriate form.

## Dangers when operating the lift:

Nußbaum-Lifts are designed and built according to technical standards and the approved regulations for technical safety. The use of Nußbaum lifts for purposes other than those for which they were designed, may result in injury or even death.

## **The lift must only be operated :**

- For its appropriate use
- In faultless condition concerning technical security.

## **Organisational Requirements**

- The instructions for use are to be kept at the place of operation being easily accessible at any time.
- In addition to the instructions for use, rules pertaining to other regulations i.e. accident prevention and environmental rules are to be observed and adhered to.
- The owner of the Nußbaum lifting system must ensure that operators and persons working with or around the lift occasionally conduct “refresher” courses to ensure that the appropriate operating procedures and safety precautions are known.
- Personal Protective Equipment (PPE) must be used according to the appropriate regulations.
- All safety- and danger signs on and around the lift are to be observed and followed!
- Spare parts must comply with the technical requirements specified by the manufacturer. This is only warranted with original parts.
- Observe and adhere to the specified time intervals between tests and inspections.

## **Maintenance works, repairing faults**

- Adjustments, maintenance, and inspections, are to be followed according to the time intervals specified. Details regarding the exchange of parts and components as mentioned in the operating instructions are to be adhered to.  
These works must only be carried out by expert personal.
- After maintenance- and repair works loose screws, nuts and bolts must always be firmly tightened!

## **Guarantee and liability**

- Our “General conditions of selling and delivering” are in force.  
There will be no guarantee or liability for incidents involving injuries or death or damage to equipment if these incidents are the result of one or more of the following reasons.
- Inappropriate use of the lift
- Inappropriate installation, initiation, operation and maintenance of the lift.
- Use of the lift while one or several security devices do not work, do not work correctly or are not installed correctly.
- Failure to follow the regulations of the operating instructions regarding transport, storage, installation, initiation, operation and maintenance of the lift.
- Unauthorized changes to the structure of the lift without first asking the producer.
- Unauthorized changes of adjustments of important components of the lift (e.g. driving elements, power rating, motor speed, etc)
- Wrong or incorrect maintenance practice.
- Catastrophes, acts of God or external reasons.

## Record of handing over

The Mobile column lift with the

serial number:..... was installed on:.....

at the firm:..... at:.....

the safety was checked and the lift was started.

The persons below were introduced after the installation of the automotive lift. The introduction was carried out from an erector of the lift-manufacturer or from a franchised dealer (competent person).

.....  
date name signature

.....  
date name signature

.....  
date name signature

.....  
date name signature

.....  
date name signature

.....  
date name signature

.....  
date name of competent signature of the competent

Your customer service:.....

## 1. Introduction

The document "**Operating Instructions and Documentation**" contains important information about installation, operation and maintenance of the lift.

To furnish proof of **installation of the automotive lift** the form "Record of Installation" must be signed and returned to the manufacturer.

To furnish proof of the singular, felt this documentation contains forms. The forms should be used to document the checks. They should not be removed from this documentation.

Every **Changes to the construction** and **displacement** of the automotive lift must be registered in the "**Master document**" of the lift.

### 1.1 Installation and check of the automotive lift

Only specialist staff is allowed to do work concerning safety and to do the safety checks of the lift. They are called experts and competent person in this document.

**Experts** are persons (for example self-employed engineers, experts) which have received instruction and have experience to check and to test automotive lifts. They know the relevant labour and accidents prevention regulations.

**Competent person** are persons who have acquired adequate knowledge and experience with automotive lifts. They took part in training from the lift-manufacturer (servicing technicians of the manufacturer or dealer, are competent)

### 1.2 Information of Warning

To show danger and to show important information the three symbols below are used. Pay attention to those passages, which are marked with these symbols.



***Danger! This sign indicates danger to life. Inexpert handling of the described operation may be dangerous to life.***



***Caution! This sign cautions against possible damage to the automotive lift or other material defects in case of inexpert handling .***



***Attention! This sign indicates for an important function or other important notes.***

## 2. Master document of the MCS 12000

### 2.1 Lift-manufacturer

Otto Nußbaum GmbH & Co. KG  
Korker Straße 24  
D-77694 Kehl-Bodersweier

### 2.2 Application

The mobile column lift is a lifting device for raising heavy vehicles (Truck, Bus...)  
The maximum capacity of one mobile column lift is 12000 lbs (5500 kg).  
It's not allowed to install the standard-automotive lift in a hazardous location or washing bays.

### 2.3 Changes at the construction

**Changes at the construction, expert checking, resumption of work**  
(date, kind of change, signature of the expert)

.....  
.....  
.....

name, address of the expert

.....  
place, date

.....  
signature of the expert

## 2.4 Page for notice



## 3. Technical Information

### 3.1 Technical ratings

Capacity of one mobile column lift	12000 lbs (5500 kg)
Lifting time	approx. 70 sec. with load
Lowering time	approx. 55 sec. with load
Lifting height	66.14" (1680 mm)
Line voltage	208 – 240 volt, 60 Hz, single phase
Control rating	24 V
Power rating	2.01 HP (1,5 kW)
Motor speed	1490 rpm
Pump capacity	2,1 cm <sup>3</sup> /rotation (1BK7S3,3)
Hydraulic pressure	approx. 3144 PSI (220 bar) with load
Pressure relief valve	approx. 3573 PSI (250 bar) with load
Pressure relief valve (safety device)	approx. max. 35 bar
Oil tank	approx. 17 Liter/tank
Sound level L <sub>pA</sub> :	≤ 70 dB
Connection by customer	1~/N+PE, 230V, 60 Hz (standard version) With fuse 22,5 Ampere (time lag) for 4 mobile columns (Pay attention to the voltage of your country)

### 3.2 Safety device

1. Pressure relief valve  
Overprint-safety of the hydraulic system
2. Holding valve  
safety device against unintentional lowering
3. Lockable main switch  
safety device against unauthorised operation
4. CE-STOP  
Safety device against squeeze
5. Hydraulically unlocking safety-system at the cylinder  
Safety device against unintentional lowering
6. Safety Star System (SST)
  - The SST observed the complete Process of the Lift during „Lifting“ and „Lowering“.
  - The lift will be lowering during the normal work with 0,05 Meter per sec.  
If the lift descends noticeable faster there may be a problem with the hydraulic system. The computer-control-system recognizes the problem and switch off the hydraulic supply for the cylinder.  
The Safety-star system locks and the lift stopped.
  - Switch off the main switch.
  - Check the complete hydraulic system. If the system is defective, call the service of your retailer.
  - The lift can be repaired by an expert, the satisfactory knowledge and experiences with hydraulic lifts has.

## **CE-STOP**

- The automotive lift stops automatically approx. minimum 120 mm before the lowest position.
- Check the dangerous places of the lift and be sure that there are no objects or people in the immediate area of the lift or on the lift.
- An acoustic signal is heard until the lift is in the lowest position

## **Top-Limit**

- The Computer-control-system recognizes the top-height position of the lift and switch off.

## 3.3 Data sheet

Hydraulikaggregat  
hydraulic unit

Bedienelement  
operating unit

Deichsel  
shaft

1226

73

1090

906

1335

377

Tragfähigkeit: 12000 lbs (5500kg)  
capacitity

Einstellbereich der Gabel:  
van 12" bis 22" Eigendurchmesser  
von 450mm bis 1250 Reifendurchmesser  
Hubhöhe 1600mm

Adjustment of the fork:  
from 12" until 22" Rim diameter  
from 450mm until 1250mm wheel diameter  
lifting height 1600mm

155RGK05001

Maschinennummer / Serial number		Bezeichnung / Name	
155RGK05001		MCS 12000 ND C	
Hersteller / Manufacturer		Antriebsart / Drive type	
Nussbaum		7012-EINBAU	
Produktionsjahr / Year of production		Lagerort / Storage location	
Gewicht / Weight		Höhe / Height	

## 4. Safety regulations

- Read all instructions.
- The total weight of the lifted vehicle must not exceed the maximum capacity of the lift.
- Lower the lift completely before driving the vehicle into the lifting position.
- Use the lift only as described by the instructions in this manual.
- Before lifting low clearance, sport vehicles, vehicles with ground effects or running boards, check carefully that no damage will occur before lifting.
- Only trained personnel 18 or older are allowed to operate the lift.
- The lift operator must observe the entire lifting and lowering process.
- Only the operator may remain under the lift while in use.
- Do not lift persons on the lift or in a vehicle on the lift.
- Do not climb onto the lift when raised.
- Keep hair, loose clothing, fingers, and all body parts away from the moving parts.
- Any changes or modifications to the lift must be checked by an expert (qualified service person).
- To reduce the risk of shock the standard lift may not be installed in a hazardous (wet) location.
- Power supply must be disconnected (main switch, plug, breaker) before any maintenance is performed on the lift.
- Care must be taken as burns can occur from touching hot parts.
- Do not operate equipment with a damaged cord or if the equipment has been dropped or damaged until it has been examined by a qualified service person (expert).
- To reduce the risk of fire, do not operate equipment in the vicinity of open containers of flammable liquids (gasoline).
- ALWAYS WEAR SAFETY GLASSES. Everyday eyeglasses only have impact lenses, they are not safety glasses.
- Adequate ventilation should be provided when working on operating internal combustion engines.
- Do not let a cord hang over the edge of the table, bench, or counter or come in contact with hot manifolds or moving fan blades.
- If an extension cord is necessary, a cord with a current rating equal to or more than that of the equipment should be used. Cords rated for less current than the equipment may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
- Always unplug equipment from electrical outlet when not in use. Never use the cord to pull the plug from the outlet. Grasp plug and pull to disconnect. Let equipment cool completely before putting away. Loop cord loosely around equipment when storing.
- Vehicles with low clearance or vehicles that are specially equipped should be pre tested to ensure that they clear the lift ramp to avoid damage.
- The mobile column lift must be checked from an expert after changes in construction.
- It's not allowed to start with operations at the lift before the main switch is switched off.
- During lifting or lowering the operator must observe the vehicle to ensure that the vehicle and the lift are functioning correctly.
- The main switch must be switched off and locked before work on the vehicle can commence. This is a safety precaution to ensure that the lift does not move during work.

- Installation of the standard-mobile column lift in hazardous or dangerous locations such as washing bays is dangerous and is not allowed.
- Check the center of gravity of the vehicle if heavy parts are removed. Secure the load with suitable tools.
- Check the lift again, if the vehicle was raised 200 millimeter.


## 5. Operating instructions




**The Safety Regulations must be observed during working with the automotive lift. Read the safety regulations in chapter 4 carefully before working with the lift!**

### 5.1 Positioning the Mobile column lift

- Every solid surface (concrete quality min C20/25) is suitable as installation-place.
- Position the shaft in arrow direction (1) under the support and lock it with the foot (c). position the lever up before lift the mobile column lift. Pull the lever (A) and unlock the safety device (B). Then position the lever up and let go of the lever again. The safety device (B) must lock again.
- The column is raising by pressing in the direction of the arrow (2) . Then the column can moved.



pic. A



pic. B

pic. C



*Position the shaft,  
Position the lever up and  
press it back*



*Lock the shaft*



*Unlock after the movement  
and remove the shaft.*

## 5.2 Lifting the vehicle




pic 3: operating unit

- A - mobile column lift 1
- B - mobile column lift 2
- C - mobile column lift 3
- D - mobile column lift 4
- E - Display
- F - main switch
- G- Button "lifting"
- H- Button "lowering"
- I- connection for remote control wire
- J- key switch operation at the control box or remote control wire


- 2 plug => column 2
- 3 plug => column 3
- 4 plug => column 4

Switch on every individual columns (A,B,C,D). It is possible to move each column individually, two columns opposite or two columns diagonal or all columns together.

- Block the vehicle against rolling, put into gear.
- Position the Mobile column lift to the wheels and let it down with the hand lever. If necessary use the additional supports.




pic 4:  
Rim diameter 12" –20"  
Wheel diameter 450mm – 1125mm




pic 5:  
secure the adjustable lifting arms with bolt and clamp before working with the MCS

- Observe the position of the wheels in the mobile column lift (see pic. 6 and 7).



*wrong*



*Correct*



**Before lifting the load, lower the mobile-column-lift in the lowest position (remove the shaft), otherwise a malfunction can lead it to damages.**

- Connect or disconnect the columns (observe the sketch) only if the main switch is switched off. Otherwise a malfunction can occur.
- Check the dangerous places of the lift and be sure that there are no objects or people in the immediate area of the lift or on the lift.
- Switch on the control system; Switch-on the main switch on position "1" .
- Raise the vehicle. Use all columns. Press the buttons „1-4“, at the operating unit. If the column is active, the switches of the chosen columns, are lighted.
- Lift the vehicle on the working height. Press the button „lifting“ .
- In the display of the operating unit you can read the momentary height of the supports.
- Observe the complete process.



**It is only allowed to lift or to lower the column lift with load. Otherwise a column lift without load can cause an unequal. After it, this column lift switch-off the complete system.**

**Accordingly, the number of the lifting wheels must agree with the number of the column lift. Please, switch off the column, which do you not need.**

## 5.3 Lowering the vehicle

- Check the dangerous places of the lift and be sure that there are no objects or people in the immediate area of the lift or on the lift.
- Lower the lift at the height for working or in the lowest position. Use all columns. Press the buttons „1-4“, at the operating unit. If the column is active, the switches of the chosen columns, are shining. Press the button „lowering“ at the operating unit. The MCS 12000 raises a little bit (unlocking the safety device), before the lowering starts.
- The mobile lift stops minimum 120 mm over the floor. Control the dangerous places of the mobile lift and be sure that there are no objects or people in the immediate area of the lift or on the lift. Press the button “ lowering” again. You hear an acoustic signal until the lift reaches the lowest position.
- Observe the complete process.
- If the lifts are in the lowest position the mobile lifts can be removed. Raise the column lift with the hand lever (read chapter 5.1).





**The motor is switched on approximately 6 times during the lowering, to hold the pressure of the unlocking system.**


## 5.4 Single-Mode „Lifting“



**Before dismounting heavy parts (motor, axle, set of gears) check the center of gravity. Otherwise a malfunction can lead it to damages or lead to danger for body and lives.**

It is possible to move each the column lift individually. This is necessary to reach the different levels of the pick-up points.

pic 8:



Omnibu3.jpg

Through this measure, it is possible to raise the vehicle horizontally.

- Block the vehicle against rolling, put into gear.
- Position the column lift. Whenn necessary use the additional supports.
- Lower the column lift in the lowest position (with the handlever).
- Check the dangerous places of the lift and be sure that there are no objects or people in the immediate area of the lift or on the lift.
- Switch on the control system; Switch on the main switch on position "1" .
- Choose the column. Press the button 1-4 at the operating unit.  
If the column is active, the switches of the chosen columns, are shining.
- Press the button "lifting" until each lift is reaching individualy the pick-up-points of the vehicle.
- If all the points are reached, switch on all columns.
- Now, all mobile lift are ready for the synchronous working.
- Press the button „lifting“ at one operating unit.
- Lift the vehicle on the working height
- Observe the complete process.
- Switch off the main switch if you don´t use the Mobile column lifts.

## 5.5 Single-Mode „Lowering“

- Check the dangerous places of the lift and be sure that there are no objects or people in the immediate area of the lift or on the lift.
- Switch on all columns.

Lower the vehicle on the working height or the lowest position.

Press the button „lowering“ at the operating unit. The mobile lift raises a little bit (unlocking the safety device), before the lowering starts.

- (CE-Stop) The mobile lift stops a few millimeter (min. 120mm) before reaching the lowest position. Control the dangerous places of the mobile lift and be sure that there are no objects or people in the immediate area of the lift or on the lift. Press the button "lowering" again. You hear an acoustic signal until the lift reaches the lowest position.
- Observe the complete process.
- The mobile lift which are standing on a higher level, lower with the "single-mode". Press only the switch of the column which do you need.
- If the lifts are in the lowest position the mobile columns can be removed. Raise the Mobile column lift with the hand lever (read chapter 5.1).



***The motor switches on approx. six times during the lowering procedure, to hold the pressure of the unlocking system.***

## 5.6 Function Microprocessor / Display-advertisement

- The automotive lift is equipped with a microprocessor. This system recognizes an unequal of the lift and regulate the hydraulic valves until the lift has the same height.
- The processor recognizes the present position of the cylinder. The lift switched off if the automotive lift reaches the top end position or the bottom end position or the position of the CE-Stop.
- The display shows the present position of the cylinder.
- this display is required also for the service-business, over a foil-keyboard.

## 5.7 Equalisation of the Mobile column lift

- The mobile column lift are adjusting automatically during lifting and lowering procedure. First, lower the mobile column lift always into the lowest position, this is the prerequisite for a trouble-free work. The complete system will be reset in this position.

## 6. Troubleshooting

If the lift does not work properly, the reason for this might be quite simple. Please check the lift for the potential reasons mentioned on the following pages. If the cause of trouble cannot be found, please call the technical service.

<b>Problem: The Motors does not start!</b>	
<b>Potential causes:</b>	<b>Solution:</b>
- All columns are not working	check the plug (see the arrow)
- no power supply	check the main fuse
- the main switch is not switched on.	check the position of the main switch
- the fuse is defective	check the fuse /exchange it
- the feed line is cut	check the feed line
- the thermo-fuse is active	let it cool down approx. 10 min.
- no column was selected	check the press buttons
- the lift is out of the rule-window of $\pm 50$ mm	read chapter 6.1

<b>Problem: The motor starts, the lift does not lifting!</b>	
<b>Potential causes:</b>	<b>Solution:</b>
- the vehicle is too heavy	unload the vehicle
- the level of the oil is too low	refill oil
- the hydraulic valve is defective	call your service partner

<b>Problem: The Mobile lift does not lowered!</b>	
<b>Potential causes:</b>	<b>Solution:</b>
- the mobile lift is standing on a obstacle	single-mode operate
- the hydraulic valve is defective	call your service partner
- the fuse is defective	exchange the fuse
- the button „lowering“ is not pressed or defective	call your service partner
- the holding valve is defective	call your service partner
- the safety star system is always locked	call your service partner

## 6.1 Lowering on a obstacle

The lift switched off if the lift is running onto an obstacle and out of the rule-window  $\pm 50$  mm.

### 6.1.1 Remove the obstacle

- Press the button "lifting" in the single-mode. (see the chapter 5.4/5.5)



**Keep an eye on it, at the singles-mode, that one Mobile column lift is lifted never too high, otherwise the crash of the vehicle can occur.**

## 6.2 Emergency lowering



**A emergency lowering is an intervention into the control of the lift and can be done only by experienced expert. The emergency lowering must be carried in this order. Otherwise a malfunction can lead it to damages or lead to danger for body and lives.**



**Every kind of external leakage has to be removed. This is necessary in particular before an emergency lowering. The emergency lowering may only be done by persons which are trained in using the lift.**

Reasons, that can make an emergency lowering necessary, are a defect of the electric system or disturbances of the valves, etc.

In case of power-failure or defective Valves there is the possibility through suitable tools to lower the lift in the lowest position, so that the vehicle can be driven off.

### 6.2.1 Procedure of the emergency lowering

- Switch off the main switch and safe it. (lock it)
- Remove the covers of hydraulic unit.
- Secure the dangerous place around the lift.




Pic 11

Loosen and remove the 2 lock nuts with a suitable tool in arrow direction. Carry out this process at both columns. (Key 41)



Pic 12:

The piston rod can be stuck through the dirty deposit at the top of the hole. Use the solvent and lubricating stuff (for an example WD40) to loosen the connection. The WD40 is sprayed generously between the screw thread and the bore hole (see arrow). The time of the effect follows the contamination-degree.



Pic 13:

Loosen the cap of the Minimes connection (Me3) and the cap of the tank. Fasten the Minimes hydraulic tube at the screw fitting and put the other end into the tank.



Pic 14:

Use the long screw thread-bushing and turns with a suitable tool (key-widened 24, available with your dealer,), clockwise. Lower the lifting carriage only approx. 5cm – 10 cm. Repeat the process at the next column. Lower always 5 cm-10 cm until all lifts are in the lowest position. Repair the defective lift. Call your service partner. After it create a Reset which is described in the operating instruction.



**Attention!! Lower the automotive-lift only approx. 5cm – 10 cm.**



**Observe the complete emergency lowering procedure.**



**Do not work with the lift until the defective parts are changed.**



**You can only work again with the automotive-lift, if it is in a safety-related perfect condition.**

- After it, carry out an reset as described in the operating instruction.

### 6.3 Reset the Mobile column lift after an emergency lowering




**A reset of the system can be enforced, if the Mobile column lifts are in the lowest position.**



**An access on the DIP-Switch can take place only with a switched off main switch and only through instructed, authorized technical personnel.**

- There must not be a vehicle on the lift.
- Remove the cover of the operating unit.
- Open the cover of the electrical box.
- Press the button 1 (see pic. 11) and hold it.
- Switch-off the main switch and wait 5 sec. Hold the reset button.

- f) Switch-on the main switch and wait 5 sec. Hold the reset button.
- g) Let go off the reset button.
- h) Press the button „lowering“ until all lifts are in the lowest position.
- i) If necessary repeat several times the steps d) until h) so that the lift is surely in the lowest position.
- j) After that move the Dip-switch 7 on position „on“.
- k) Dip-switch 5 stays on position „on“.
- l) Repeat the steps d) until h)
- m) After that, move the Dip-switch 7 on position „off“. Dip-switch 5 stays on position „on“.
- n) On the computer-board must now three diodes lighten permanently. One additional diode must be blinking in the frequency of approx. 1 sec.
- o) Raise and lower the automotive lift a few times without load. Observe the process.
- p) Mount the covers.



pic 15: controller

## 7. Inspection and Maintenance



**Before conducting maintenance work, preparations must be made to ensure that during maintenance and repair work there is no risk to the safety of people working on or around the lift and also that there is no risk of damage to equipment being used on or around the lift.**

To guarantee the utmost availability and to ensure that the lift remains functional, maintenance work contracts are organised between our clients and their local retailers. A service must be performed at regular intervals of 3 months through the operator in accordance with following service manual. If the lift is in continuous operation or in a dirty environment, the maintenance rate must be increased.



During daily operation the lift must be closely observed to ensure that it is functioning correctly. In the case of malfunction or leakage the technical service must be informed.



**German legal guidelines : BSV (Prescription of working tools) + BGR500 (Work with working tools)**

## 7.1 Maintenance plan of the Mobile column lift



**Before beginning any maintenance work isolate the power supply. Secure the main switch (lock it). Secure the danger area around the automotive lift and secure the lift against unintentional lowering**

Maintenance plan	Period of time
Check the condition of the type plate, sticker, short operating instruction. Clean it and if necessary replace it.	at least once a year
In case of heavy dirt deposit clean the piston rods of the hydraulic cylinders from deposit. Remove the cover of the Mobile column lift. If necessary raise the Mobile column lift with the single-mode in the highest position. Grease the piston rods with a high capacity lipid (approx. 5 g of S2 DIN51503 KE2G of the Renolit Company).	at least once a year
Clean and check the moving parts. Lubricate the moving parts of the lift (hinge bolts, rolls, sliding surfaces) with a multipurpose lipid (example: Auto Top 2000 LTD. Agip).	at least once a year
Check the colour if necessary make a repair.  Damages through outer effects are immediately to be treated after recognising. In case of not-treatment of the positions, the powder-coating can be durably damaged through infiltration of deposits of all type Grind these position (120 ryes) and after it degrease it. After it use a suitable lacquer (Observe the RAL Number).  Check the zinc surface if necessary make a repair. White rust becomes through lasting moisture, bad ventilation favours. Rust is evoked by mechanical damages, wear, aggressive infiltration (salt, water ; also in connection with other environmental influences) and bad or not implemented cleaning. Grind these position (A280 ryes) and after it degrease it. After it use a suitable lacquer (Observe the RAL Number).	at least once a year
Check the hydraulic tubes for leakage.	at least once a year
Check the oil level. Fill in a clean, high quality oil (32 cst)in the tank.	at least once a year
The hydraulic oil has to be changed at least once a year. To change the oil, lower the lift into the lowest position. Empty the tank and replaced	at least once a year

<p>clean oil, approx. 17 litres are needed. A high quality hydraulic oil is recommended, its should be 32 cst. (e.g.g. HLP 32 LTD. OEST Company)</p> <p>Use a ATF-Suffix hydraulic-oil (OEST Company ) if the ambient temperature is under 5 degree centigrade. After the fill up, the hydraulic oil must be between the upper and low marking of the oil level gauge.</p>																																																									
<p>Check all welded joints for cracks on the automotive-lift. If any cracks are found on the lift cease use immediately. Switch-off and secure the main switch (lock) and call the service partner.</p>	at least once a year																																																								
<p>Check the condition and the function of the moving device.(pressure spring, bolts, roller</p>	at least once a year																																																								
<p>Check the safety device of the lift. (CE-STOP)</p>	at least once a year																																																								
<p>Check the Battery of the controller (ASC). The Battery has a working life at normal business between 4 ½ - 5 Years (manufacturers statement). To avoid a permanent data-loss through an empty battery, you must examine the battery of the controller during the regularly maintenance. The measuring can only take place at the controller which was switched-off. The measuring is possible with a commercial tensiometer. standard voltage approx. 3.2 V (no exchange necessary), but a value under 2.9 V, the controller must be exchanged. Send the controller to the Nußbaum Headquarter. Before, contact your service partner.</p>	at least once a year																																																								
<p>Check the function of the handlever.</p>	at least once a year																																																								
<p>Check condition and function of the moving device.</p>	at least once a year																																																								
<p>Check the condition and function of the electrical buttons, main switch, cables, plugs, CE-Stop.</p>	at least once a year																																																								
<p>Check the turning moment of the screws (see the list pic. 16)</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Turning moment for screws property class 8.8</p> <table border="1"> <thead> <tr> <th></th> <th>0,10*</th> <th>0,15**</th> <th>0,20***</th> </tr> </thead> <tbody> <tr><td>M8</td><td>20</td><td>25</td><td>30</td></tr> <tr><td>M10</td><td>40</td><td>50</td><td>60</td></tr> <tr><td>M12</td><td>69</td><td>87</td><td>105</td></tr> <tr><td>M16</td><td>170</td><td>220</td><td>260</td></tr> <tr><td>M20</td><td>340</td><td>430</td><td>520</td></tr> <tr><td>M24</td><td>590</td><td>740</td><td>890</td></tr> </tbody> </table> </div> <div style="text-align: center;"> <p>property class 10.9</p> <table border="1"> <thead> <tr> <th></th> <th>0,10*</th> <th>0,15**</th> <th>0,20***</th> </tr> </thead> <tbody> <tr><td>M8</td><td>30</td><td>37</td><td>44</td></tr> <tr><td>M10</td><td>59</td><td>73</td><td>87</td></tr> <tr><td>M12</td><td>100</td><td>125</td><td>151</td></tr> <tr><td>M16</td><td>250</td><td>315</td><td>380</td></tr> <tr><td>M20</td><td>490</td><td>615</td><td>740</td></tr> <tr><td>M24</td><td>840</td><td>1050</td><td>1250</td></tr> </tbody> </table> </div> </div> <p style="font-size: small; margin-top: 10px;">             * sliding friction 0,10 for very good surfaces, lubricated              ** sliding friction 0,15 for good surfaces, lubricated oder dry              *** sliding friction 0,20 surface black or phosphatized, dry         </p>		0,10*	0,15**	0,20***	M8	20	25	30	M10	40	50	60	M12	69	87	105	M16	170	220	260	M20	340	430	520	M24	590	740	890		0,10*	0,15**	0,20***	M8	30	37	44	M10	59	73	87	M12	100	125	151	M16	250	315	380	M20	490	615	740	M24	840	1050	1250	at least once a year
	0,10*	0,15**	0,20***																																																						
M8	20	25	30																																																						
M10	40	50	60																																																						
M12	69	87	105																																																						
M16	170	220	260																																																						
M20	340	430	520																																																						
M24	590	740	890																																																						
	0,10*	0,15**	0,20***																																																						
M8	30	37	44																																																						
M10	59	73	87																																																						
M12	100	125	151																																																						
M16	250	315	380																																																						
M20	490	615	740																																																						
M24	840	1050	1250																																																						

## 7.2 Cleaning of the Mobile column lift

A regular and appropriate maintenance served the preservation of the lift. It can be a prerequisite for claims at possible corrosion. The best protection for the lift is the regular cleaning of dirt of all manner.

- Including this:
  - de-icing salt



- sand, pebble stone, natural soil
- industrial dust of all manner
- water ; also in connection with other environmental influences
- aggressive deposit of all manner
- constant humidity by insufficient ventilation

### How often must the lift be cleaned ?

This is dependent on the use, of the working with the lift, of the cleanness of the workshop and location of the lift. The degree of the dirt is dependent on the season, of the weather conditions and the ventilation of the workshop.

Under bad circumstances it is necessary to clean the lift every week, but a cleaning every month can suffice.

Clean the lift and the floor with a non-aggressive and non-abrasive detergent. Use gentle detergent to clean the parts. Use an standard washing-up liquid and lukewarm water.

- Do not use for cleaning a steam jet cleaning
- Remove all dirt careful with a sponge if necessary with a brush.
- Pay attention that are no remains of the washing-up liquids on the lift after cleaning.
- Do not use aggressive means for cleaning the workshop floor and the automotive lift.
- A permanent contact with every kind of liquid is forbidden. Do not use any high pressure device for cleaning the lift.

## 8.Security check

The security check is necessary to guarantee the safety of the lifting during use. It has to be performed in the following cases:

1. Before the initial operation, after the first installation  
**Use the form “First security check before initiation”**
2. In regular intervals after the initial operation, at least annually.  
**Use the form “Regular security check at least annually”**
3. Every time the construction of that particular lift has been changed.  
**Use the form “Extraordinary security check”**




***The first and the regular security check must be performed by a competent person. It is recommended to service the lift at this occasion.***



***After the construction of the lift has been changed (changing the lifting height or capacity for example) and after serious maintenance works (welding on carrying parts) an extraordinary security check must be performed by an expert.***

This manual contains form with a schedule for the security checks. Please use the adequate form for the security checks. The form should remain in this manual after they have been filled out. In the following there is a short description about special safety devices.

## 9. Handing over and Initiation



### 9.1 Regulations

- It's not allowed to install the standard-automotive lift in a hazardous location or washing bays.
- Every solid surface (concrete quality min C20/25) is suitable as installation-place. We point out the minimum requirement of the foundation in our plans. The condition of the local realities (for example: ground under the foundation) does not lie our responsibility. If necessary an architect must be consulted.
- Standard Version: an electrical supply 1x220V 50/60 Hz has to be provided. In the case of supply into other countries the lifting platform is accordingly electrically prepared.

### 9.2 Initiation



**Before the initiation a security check must be performed. Therefore use form: First security check.**


If the lift is installed by a competent person, he will perform this security check. If the operator installs the lift by himself, he has to instruct a competent person to perform the security check.

The competent confirms the faultless function of the lift in the installation record and form for the security check and allows the lift to be used.



**Please send the filled installation record to the manufacturer after installation.**


## 9.3 Cable connection of the Mobile column lift



Säulen Anordnung.jpg

**Standard Version**

## First security check before installation

 Filling out and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	verification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity" at every column.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function „Single-mode“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „lifting,lowering“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „1,2,3,4“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function shaft and hand lever.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety star system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition color.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition pulleys.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition bearings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition weldings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation,cracking).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition cable + protecting tube + plug .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition of the cover .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Tightness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic tubes .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Test Mobile column lift with a vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Mobility of the Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function remote control wire.(optional)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator


If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Regular security check and Maintenance

 Filling out and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	verification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity" at every column.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function „Single-mode“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „lifting,lowering“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „1,2,3,4“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function shaft and hand lever.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety star system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition color.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition pulleys.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition bearings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition weldings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation,cracking).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition cable + protecting tube + plug .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition of the cover .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Tightness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic tubes .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Test Mobile column lift with a vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Mobility of the Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function remote control wire.(optional)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator


If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Regular security check and Maintenance

 Filling out and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	verification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity" at every column.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function „Single-mode“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „lifting,lowering“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „1,2,3,4“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function shaft and hand lever.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety star system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition color.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition pulleys.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition bearings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition weldings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation,cracking).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition cable + protecting tube + plug .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition of the cover .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Tightness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic tubes .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Test Mobile column lift with a vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Mobility of the Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function remote control wire.(optional)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator


If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Regular security check and Maintenance

 Filling out and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	verification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity" at every column.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function „Single-mode“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „lifting,lowering“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „1,2,3,4“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function shaft and hand lever.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety star system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition color.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition pulleys.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition bearings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition weldings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation,cracking).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition cable + protecting tube + plug .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition of the cover .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Tightness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic tubes .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Test Mobile column lift with a vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Mobility of the Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function remote control wire.(optional)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator


If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Regular security check and Maintenance

 Filling out and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	verification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity" at every column.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function „Single-mode“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „lifting,lowering“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „1,2,3,4“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function shaft and hand lever.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety star system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition color.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition pulleys.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition bearings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition weldings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation,cracking).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition cable + protecting tube + plug .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition of the cover .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Tightness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic tubes .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Test Mobile column lift with a vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Mobility of the Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function remote control wire.(optional)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:


Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)



## Regular security check and Maintenance

 Filling out and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	verification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity" at every column.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function „Single-mode“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „lifting,lowering“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „1,2,3,4“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function shaft and hand lever.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety star system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition color.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition pulleys.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition bearings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition weldings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation,cracking).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition cable + protecting tube + plug .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition of the cover .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Tightness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic tubes .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Test Mobile column lift with a vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Mobility of the Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function remote control wire.(optional)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Regular security check and Maintenance



Filling out and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	verification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity" at every column.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function „Single-mode“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „lifting,lowering“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „1,2,3,4“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function shaft and hand lever.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety star system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition color.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition pulleys.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition bearings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition weldings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation,cracking).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition cable + protecting tube + plug .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition of the cover .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Tightness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic tubes .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Test Mobile column lift with a vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Mobility of the Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function remote control wire.(optional)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator


If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Regular security check and Maintenance

 Filling out and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	verification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity" at every column.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function „Single-mode“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „lifting,lowering“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „1,2,3,4“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function shaft and hand lever.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety star system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition color.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition pulleys.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition bearings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition weldings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation,cracking).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition cable + protecting tube + plug .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition of the cover .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Tightness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic tubes .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Test Mobile column lift with a vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Mobility of the Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function remote control wire.(optional)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Regular security check and Maintenance



Filling out and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	verification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity" at every column.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function „Single-mode“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „lifting,lowering“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „1,2,3,4“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function shaft and hand lever.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety star system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition color.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition pulleys.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition bearings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition weldings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation,cracking).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition cable + protecting tube + plug .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition of the cover .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Tightness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic tubes .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Test Mobile column lift with a vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Mobility of the Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function remote control wire.(optional)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Extraordinary security check



Filling out and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	verification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity" at every column.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function „Single-mode“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „lifting,lowering“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function button „1,2,3,4“.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function shaft and hand lever.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety star system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition color.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition pulleys.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition bearings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition weldings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation,cracking).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition cable + protecting tube + plug .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition of the cover .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Tightness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic tubes .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Test Mobile column lift with a vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Mobility of the Mobile column lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition, Function remote control wire.(optional)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator


If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator



(Use another form for verification!)

## Hydraulic diagram



## Hydraulic parts list

Pos.	Description	order number
0.1	oil tank	
0.2	filter	980012
0.3	gear pump	980486
0.4	sub oil motor	991055
0.5	oil level gauge	980098
0.7	hydraulic block complete	99 540 06 005
DB1	pressure relief valve	155211
DMV	pressure relief valve DR08-01-C-V-120V	161350
M1-M3	measure connection	118495
VW1	proportional valve WEP06DA013B0240D	161060
V1	2/2 way valve	158502
V2	2/2 way valve	158503
VR1	holding valve	130053
VR2	holding valve	130053
1.0	cylinder	155RGK...
2.0	unlocking cylinder	

0	1	2	3	4	5	6	7	8	9												
																					
<p style="text-align: center;"> <b>Nussbaum Hebeteknik</b>                  GmbH &amp; Co. KG                  Korcker Straße 24                  D-77694 Kehl Bodersweier                  Tel.: +49(0)7853/899-0             </p>																					
<h2 style="text-decoration: underline; text-decoration-color: red;">SCHALTPLAN</h2>																					
<p><b>OBJEKT</b> : MCS5000 C USA 1x220V  <b>ANLAGE</b> : 1 x 220V  <b>KUNDE</b> : 50/60 Hz  <b>SCHALTPLANNR:</b> MCS5000 C USA 07/10/002</p>																					
<p><b>1.) Schaltpläne und Schaltunterlagen</b>                  Die Schaltpläne werden von uns nach besten Gewissen angefertigt. Für bestellte Schaltpläne und Schaltunterlagen werden wir keine Haftung übernehmen. Die Schaltpläne werden von uns nach dem vom Auftragsgeber überlassenen Unterlagen des Herstellers angefertigt. Diese werden von uns nur nach den vom Auftragsgeber überlassenen Unterlagen des Herstellers angefertigt.</p>																					
<p><b>2.) Funktionsprüfung der Schaltanlagen</b>                  Schaltpläne sind keine Serienzeugnisse. Bei der Prüfung des Schaltstranges am Werk können Fehler wie Fühler, Herangehensweise und Motoren nicht entzogen werden. Auch bei sorgfältiger Prüfung durch uns kann es zu Fehlern kommen. Sie ist grundsätzlich Bestandteil unseres Auftrages. Mängel werden im Rahmen unserer Gewährleistung bei der Inbetriebnahme beseitigt. Keine Haftung für Schäden, die aus den Nachbesserungen, einschließlich der Berechtigung von Schaltplänen bei nicht von uns in Betrieb genommenen Schaltanlagen, resultieren. Nachbesserungen werden deshalb nur gegen Berechnung gemäß unseren Service-Bedingungen ausgeführt. Kosten für Nachbesserungen durch Dritte können wir nicht anerkennen.</p>																					
<p>Diese Pläne sind auf einem CAD-System erstellt worden. Um die Pläne immer auf dem aktuellen Stand zu halten, bitten wir Änderungen nur durch uns vornehmen zu lassen.</p>																					
<p><b>3.) Sicherheitsprüfung und Schutzmaßnahmen</b>                  Die Schaltpläne sind unter Beachtung der anerkannten Regeln der Technik nach dem Stand der Technik angefertigt. Die Schaltpläne sind durch uns geprüft und geprüft. Folgende Prüfungen wurden durchgeführt:                  1. Prüfung der Verdrahtung der Schaltpläne.                  2. Prüfung der Verdrahtung der Schaltpläne.                  3. Prüfung der Verdrahtung der Schaltpläne.                  4. Prüfung der Verdrahtung der Schaltpläne.                  5. Prüfung der Verdrahtung der Schaltpläne.                  6. Prüfung der Verdrahtung der Schaltpläne.                  7. Prüfung der Verdrahtung der Schaltpläne.                  8. Prüfung der Verdrahtung der Schaltpläne.                  9. Prüfung der Verdrahtung der Schaltpläne.                  10. Prüfung der Verdrahtung der Schaltpläne.</p>																					
<p>Diese Schaltpläne sind unser geistiges Eigentum. Sie dürfen ohne unsere Genehmigung weder vervielfältigt noch Dritten weitergegeben werden!</p>																					
<table border="1" style="width: 100%;"> <tr> <td colspan="3" style="text-align: center;">MCS5000 C USA 1x220V</td> </tr> <tr> <td style="width: 33%;"></td> <td style="width: 33%;"></td> <td style="width: 33%;"></td> </tr> <tr> <td style="text-align: center;">1 x 220V</td> <td style="text-align: center;">50/60 Hz</td> <td style="text-align: center;">Deckblatt</td> </tr> <tr> <td style="text-align: center;">81</td> <td style="text-align: center;">1</td> <td style="text-align: center;">19 81</td> </tr> </table>										MCS5000 C USA 1x220V						1 x 220V	50/60 Hz	Deckblatt	81	1	19 81
MCS5000 C USA 1x220V																					
1 x 220V	50/60 Hz	Deckblatt																			
81	1	19 81																			
																					
Nussbaum Hebeteknik GmbH & Co. KG			Korcker Straße 24			D-77694 Kehl - Bodersweier			Tel.: +49(0)7853/899-0												
Urspr.			Ers. F.			Ers. d.			Ers. e.												




0		1		2		3		4		5		6		7		8		9	
<b>Inhaltsverzeichnis</b>																			
Seite X: eine automatisch erzeugte Seite wurde manuell nachbearbeitet																			
MUPJ00050 24.02.1994																			
Seite	Seitenbenennung	Seitenzusatzfeld													Datum	Bearbeiter	X		
1	Deckblatt														09.07.2010	BOE			
2	Inhaltsverzeichnis														09.07.2010	BOE			
3	Änderung														09.07.2010	BOE			
4	Hauptstrom														09.07.2010	BOE			
5	Hauptstrom														09.07.2010	BOE			
6	Steuerspannung														09.07.2010	BOE			
7	Bedientasten														09.07.2010	BOE			
8	Vorwahl														09.07.2010	BOE			
9	Achscontroller														09.07.2010	BOE			
10	Proportionalven.														09.07.2010	BOE			
11	Ventile														09.07.2010	BOE			
12	Ventile														09.07.2010	BOE			
13	frei														09.07.2010	BOE			
14	X1														09.07.2010	BOE			
15	XS2														09.07.2010	BOE	X		
16	XS3														09.07.2010	BOE	X		
17	XS4														09.07.2010	BOE	X		
18	Stückliste														09.07.2010	BOE			
19	Stückliste														09.07.2010	BOE	X		
																			3


  

 Nussbaum Hebeteknik GmbH & Co. KG D-70614 Heilbronn - Bismarckstr. 24 Tel.: +49 (0) 71 45 92 82 50 Fax: +49 (0) 71 45 92 87 07		Ers. F.    Ers. d. MFC5000 C USA 1x220V		J. x 220V 50/60 Hz		Inhaltsverzeichnis Bl. 19 Bl. 2	
Änderung	Datum	Name	Norm	Datum	Bearb.	Datum	Bearb.
					BOE		
					09.07.2010		





MCS5000 C USA 1x220V		Primary current	
Nussbaum Hebe-technik GmbH & Co. KG Luiser-Str. 24 D-70549 Heilbronn Tel.: +49(0)7141 22992220 Fax: +49(0)7145 9787		1 x 220V 50/60 Hz	
Erspr.		Ers d	
Ers f		Ers b	
Name		Hauptstrom	
Datum		81	
Bearb. 80E		19 81	
Bepr. 02.07.2010			




Nussbaum Rebertechnik GmbH & Co. KG  
 80704 Inzell - Bayern  
 Tel. +49(0)7202/8220 Fax. +49(0)7202/8270

MCS5000 C USA 1x220V  
 Primary current  
 1 x 220V  
 50/60 Hz


Hauptstrom  
 81 19 81


Änderung	Datum	Name	Norm	Urspr.	Ers. F.	Ers. d.

Datum	Bearb.
	BOE
Bearb.	Datum
02.07.2010	




<b>Technical Specifications</b> MCS5000 C USA 1x220V 1 ~ 220V 50/60 Hz			Control voltage			-	
			Erster Spr. Urspr.			Erster d. Ers. f.	
			Muesbaum Hebeteknik GmbH & Co. KG 0 - 76949 Heilbrunn - Heilbrunnstr. 24 Tel.: +49 (0) 71 42 93 62 54 Fax: +49 (0) 71 42 93 6 76 7			Freigebe / Enabling	
Datum	Bearb.	Bepr.	Steuerspannung			81	
Änderung	Datum	Name				19 Bl.	






7	9	8	7	6	5	4	3	2	1	0
<p>Taster vorwahl säule 1 ein Switch column 1 on/off</p> <p>Taster vorwahl säule 2 ein Switch column 2 on/off</p> <p>Taster vorwahl säule 3 ein Switch column 3 on/off</p> <p>Taster vorwahl säule 4 ein Switch column 4 on/off</p>										
<p>7.9/L+ →</p> <p>→ L-/9.0</p>										
<p>Erkennung für RSC Achse angeschlossen</p>										
<p>4-Säule /12.5 3-Säule /12.0 2-Säule /11.5 1-Säule /11.0</p> <p>Achse 4 ein /9.1 Achse 3 ein /9.1 Achse 2 ein /9.1 Achse 1 ein /9.1</p>										
<p>PIC_Nullen /9.1</p>										
<p>81 8</p> <p>1 x 220V 50/60 Hz</p> <p>Vorwahl</p>										
<p>MCS5000 C USA 1x220V</p> <p>Nussbaum Hebe-technik GmbH &amp; Co. KG Luiser-Str. 24 D-70548 Bad. - Barmershausen Tel. +49(0)7142929250 Fax. +49(0)7145518707</p>										
<p>Urspr. Erspr. Ers d.</p>										
<p>Datum Bearb. BOE Bepr. 02.07.2010</p>										
<p>Name Norm</p>										








11


MCS5000 C USA 1x220V		Nussbaum Heberteknik GmbH & Co. KG D-70544 Bad-Neuenahr Tel. +49(0)725292250 Fax. +49(0)7252 9270	
1 x 220V 50/60 Hz		Proportionalvent.	
81		19 81	
Datum	Bearb	Datum	Bearb
	BOE		02.07.2010
Urspr.	Ers F	Ers d	




10

Änderung	Datum	Name	Norm	Urspr.	Ers. F.	Ers. d.	MCS5000 C USA 1x220V	1 x 220V 50/60 Hz	Ventile	81	11	19 B1

Nussbaum Hebe- und Transporttechnik GmbH & Co. KG  
 80769 Maimarkt, StraÙe 24  
 Tel.: +49 (0) 72 92 92 52 52 Fax: +49 (0) 72 92 92 52



11	Datum			13	14	15	16	17	18	19	20
	Bearb.	BOE									
	Befr.	09.07.2010									
11	Urspr.	Ers. F		Ers. d		Ers. e		Ers. f		Ers. g	
	Name	MCS5000 C USA 1x220V		MCS5000 C USA 1x220V		MCS5000 C USA 1x220V		MCS5000 C USA 1x220V		MCS5000 C USA 1x220V	
	Datum										
	Name	Ventile		Ventile		Ventile		Ventile		Ventile	
	Urspr.	Ers. F		Ers. d		Ers. e		Ers. f		Ers. g	
	Urspr.	Ers. F		Ers. d		Ers. e		Ers. f		Ers. g	

0	1	2	3	4	5	6	7	8	9
									
12									14
	Datum					MCS5000 C USA 1x220V		-	
	Bearb.	BOE						+	
	Bepr.	02.07.2010							
Änderung	Datum	Name	Norm	Urspr.	Ers. f.	Ers. d.			
							1 x 220V 50/60 Hz		81
							frei		13
									19 81











### Stückliste

WUP00030 24.02.1994

0	1	2	3	4	5	6	7	8	9
Bauteilbenennung	Menge	Bezeichnung	Typen Nummer	Lieferant	Artikelnummer				
-401	1	Hauptsch. Mot.-Rus 3p 30R/UL	01-30-ET 3	ABB	0130ET 3				
-401	1	Griff für Hauptsch. 0132ET3	GRIFFF 0132ET3	ABB	GRIFFF 0132ET3				
-481	1	Motorbreitabdeckung	991312	Nussbaum	991312				
-481	1	Klemmbrettstützung	991313	Nussbaum	991313				
-481	1	Klemmbrett	991314	Nussbaum	991314				
-401	1	Unteromotor 1,5kV/ 11,5A 60Hz	007H4-312	Hanning GmbH	991055				
-482	1	Motorbreitabdeckung	991312	Nussbaum	991312				
-482	1	Klemmbrettstützung	991313	Nussbaum	991313				
-482	1	Klemmbrett	991314	Nussbaum	991314				
-402	1	Unteromotor 1,5kV/ 11,5A 60Hz	007H4-312	Hanning GmbH	991055				
-581	1	Motorbreitabdeckung	991312	Nussbaum	991312				
-581	1	Klemmbrettstützung	991313	Nussbaum	991313				
-581	1	Klemmbrett	991314	Nussbaum	991314				
-581	1	Unteromotor 1,5kV/ 11,5A 60Hz	007H4-312	Hanning GmbH	991055				
-582	1	Motorbreitabdeckung	991312	Nussbaum	991312				
-582	1	Klemmbrettstützung	991313	Nussbaum	991313				
-582	1	Klemmbrett	991314	Nussbaum	991314				
-582	1	Unteromotor 1,5kV/ 11,5A 60Hz	007H4-312	Hanning GmbH	991055				
-582	4	Schutzleiterklemme	W 2 575 PI	Entretec	ENT 10518822				
X1	4	Blanko Schild	RC310 5x10	Entretec	ENT 23100007				
-661	1	Trafo + Gleichrichter + Kondensator	TRAF0 1-PH	5Schmelzer	990835				
-662	1	Trafo + Gleichrichter + Kondensator	TRAF0 1-PH	5Schmelzer	990835				
X11	1	Rundstecker Einbau Buchse 3pol me	RUNDSTECKER BUCHSE	Contact GmbH	990371				
X11	1	Rundstecker 3pol me	RUNDSTECKER STECKER	Contact GmbH	991130				
-654	1	Kontaktblock 1S (N22)	N22-RK10	Hoeller	990142				
-654	1	Schlüsselschleife 25c. abzug in 0 u 1 rast. (N22)	N22-0-X	Hoeller	990220				
-681	1	Industrierelaissockel für 4 Wechsler	110178	BTR	990361				
-681	1	INDUSTRIERELAIS 24V 4 Wechsler	2741	BTR	990267				
-685	1	Drucklaste Flach o. Tast. Platte (N22)	N22-0-X	Hoeller	990130				
-655	1	Tastentafel Pfeil (N22)	N22-X0-S-X7	Hoeller	990131				
-655	1	Kontaktblock 1S 10 (N22)	N22-RK11	Hoeller	990132				
-655	1	Kontaktblock 1S 10 (N22)	N22-RK10	Hoeller	990133				
-656	1	Drucklaste Flach o. Tast. Platte (N22)	N22-0-X	Hoeller	990130				
-656	1	Tastentafel Pfeil (N22)	N22-X0-S-X7	Hoeller	990131				
-656	1	Kontaktblock 1S 10 (N22)	N22-RK11	Hoeller	990132				
-656	1	Kontaktblock 1S 10 (N22)	N22-RK10	Hoeller	990133				
-761	1	Schalt-Netzgerät. Rechtscontroller DC 24 V / 4,5000-A24	N22-0-F24	Lust GmbH	940268				
-7F1	1	SICHERUNGSHALTER kp 1 mit KARPE Sockel/Kopf FPG1 -3101.0110 -	FEIN SICHERUNG	5Schurter GmbH	995059				
-7F1	1	Feinsicherung	FEIN SICHERUNG	GIF	990307				
-851	1	Kontaktblock 1S 10 (N22)	N22-RK11	Hoeller	990132				
-851	1	Leuchtdrucklaste rast. - weid (N22)	N22-0RL-W	Hoeller	990837				
-8H1	1	Lampenfassung LED weid (N22)	N22-LED-W	Hoeller	991193				
-852	1	Leuchtdrucklaste rast. - weid (N22)	N22-0RL-W	Hoeller	990837				
-852	1	Leuchtdrucklaste rast. - weid (N22)	N22-0RL-W	Hoeller	990837				
-8H2	1	Lampenfassung LED weid (N22)	N22-LED-W	Hoeller	991193				
-853	1	Kontaktblock 1S 10 (N22)	N22-RK11	Hoeller	990132				
-8H3	1	Leuchtdrucklaste rast. - weid (N22)	N22-0RL-W	Hoeller	990837				
-8H3	1	Lampenfassung LED weid (N22)	N22-LED-W	Hoeller	991193				
-854	1	Leuchtdrucklaste rast. - weid (N22)	N22-0RL-W	Hoeller	990837				
-854	1	Kontaktblock 1S 10 (N22)	N22-RK11	Hoeller	990132				

17

19

Datum	09.07.2010								
Bearb	806								
Bearf.	09.07.2010								
Urspr.		Ers. F		Ers. d					
Nussbaum Rebertechnik GmbH & Co. KG D-70614 Heilbronn - Rebertechnik Tel. +49(0)7141 9291910 Fax. +49(0)7141 9291911					MCS5000 C USA 1x220V				
Nussbaum					Stückliste				
					1 x 220V				
					50/60 Hz				
					81				
					19 Bl.				

