


**STANLEY**<sup>®</sup>

# Service Manual

# DLO7 Hydraulic Drill



Copyright©2002TheStanleyWorks  
USA&CEVersion  
607897/2003 Ver. 1



**DANGER**

**SERIOUS INJURY OR DEATH COULD RESULT FROM THE IMPROPER REPAIR OR SERVICE OF THIS TOOL.**

**REPAIRS AND/OR SERVICE TO THIS TOOL MUST ONLY BE DONE BY AN AUTHORIZED AND CERTIFIED DEALER.**



---

# Table of Contents

---

# DLO7

## Hydraulic Drill

### SERVICING THE DL07HYDRAULIC DRILL:

This manual contains Safety, Operation, and Troubleshooting information. Stanley Hydraulic Tools recommends that servicing of hydraulic tools, other than routine maintenance, must be performed by an authorized and certified dealer. Please read the DANGER warning on the cover and the SAFETY warning below.

Certificate of Conformity	3
Specifications	4
Torque and Drill Speeds	4
General Safety Instructions	5
Tool Decals and Tags	6
Hydraulic Hose Requirements	7
HTMA Requirements	8
Operating Instructions	9
Service Instructions	12
Troubleshooting	15
Parts Illustration	17
Parts List	18
Accessories	20
Warranty	21

Copyright © 2003 The Stanley Works  
All rights reserved.

Under copyright law, this document may not be copied in whole or in part without the prior written consent of The Stanley Works. This exception does not permit copies to be made for others, whether or not sold. Under the law, copying includes translating into another language, format or medium. This copyright notice must appear on any permitted copies.

## SAFETY FIRST

*It is the responsibility of the operator and service technician to read rules and instructions for safe and proper operation and maintenance.*

*A cautious worker using common sense is the greatest safety device.*

# Certificate of Conformity

**CERTIFICATE OF CONFORMITY**  
**ÜBEREINSTIMMUNGS-ZERTIFIKAT**  
**CERTIFICAT DE CONFORMITE CEE**  
**D'UN MARTEAU-PIQUEUR D'UN BRISE-BETON EXAMINE**  
**CERTIFICADO DE CONFORMIDAD**  
**CERTIFICATO DI CONFORMITÀ**



I, the undersigned:  
Ich, der Unterzeichnende:  
Jesoussigné:  
Elabajaofirmante:  
Io sottoscritto:

**Burrows, James**

Surname and First names / Familienname und Vornamen / Nom et prénom / Nombrey apellido / Cognome e nome

**hereby certify that the construction plant or equipments specified hereunder:**  
**bestätigt hiermit, daß die Konstruktion und Ausrüstung wie folgt spezifiziert ist:**  
**atteste que le brise-béton:**  
**porel present certificado que la fabrica o equipo especificado a continuación:**  
**certifico che l'impianto o l'attrezzatura sottospesificata:**

1. Category: Drill  
Kategorie:  
Catégorie:  
Categoria:  
Categoria:

2. Make/Ausführung/ Marque/Marca/Fabbricazione: **Stanley**

3. Type/Typ/Type/Tipo/Tipo: DL0755001

4. Type serial number of equipment:  
Typ und Serien-Nr. der Ausrüstung:  
Numéro dans la série du type de matériel:  
Número de serie tipo de equipo:  
Matricola dell'attrezzatura:

**ALL**

5. Year of manufacture/Baujahr/année de fabrication/Año de fabricación/Annodifabbricazione: 2003

**has been manufactured in conformity with-EEC type examination as shown.**  
**wurde hergestellt in Übereinstimmung mit-EEC Typ-Prüfung nach.**  
**est fabriqué conformément -au(x) type(s) examiné(s) comme indiqué dans le tableau ci-après.**  
**ha sido fabricado de acuerdo con tipo examen EEC como dice.**  
**è stato costruito in conformità con la norme CEE come illustrato.**

Directive Richtlinie Directives particulières Directriz Direttiva	No. Nr Numéro No n.	Date Datum Date Fecha Data	Approved body Prüfung durch Organisme agréé Aprobado Collaudato	Date of expiry Ablaufdatum Dated'expiration Fecha de caducidad Data di scadenza
EN	792-3	1994	Self	NA
EN ISO	3744	1995	Self	NA
EN	28662-1	1988	Self	NA

6. Special Provisions: **None**  
Spezielle Bestimmungen:  
Dispositions particulières:  
Provisiones especiales:  
Misure special:

Sound Level: <80 dBA

Vibration Level: 1.2 m/s<sup>2</sup>

Done at/Ort/Faità/Dadoen/Fatto a **Stanley Hydraulic Tools, Milwaukie, Oregon USA** Date/Datum/le/Fecha/Data 7/23/03

Signature/Unterschrift/Signature/Firma/Firma

Position/Position/Fonction/Puesto/Posizione **Engineering Manager**




---

# General Safety Instructions

---

Always observe safety symbols. They are included for your safety and the protection of the tool.




This tool will provide safe and dependable service if operated in accordance with the instructions given in this manual. Read and understand this manual and any stickers and tags attached to the tool and hoses before operation. Failure to do so could result in personal injury or equipment damage.

- Operator must start in a work area without bystanders. The operator must be familiar with all prohibited work areas such as excessive slopes and dangerous terrain conditions.
- Establish a training program for all operators to ensure safe operations.
- Do not operate the tool unless thoroughly trained or under the supervision of an instructor.
- Always wear safety equipment such as goggles, head protection, and safety shoes at all times when operating the tool.
- Do not inspect or clean the tool while the hydraulic power source is connected. Accidental engagement of the tool can cause serious injury.
- Do not operate this tool without first reading the Operating Instructions.
- Do not install or remove this tool while the hydraulic power source is connected. Accidental engagement of the tool can cause serious injury.
- Never operate the tool if you cannot be sure that underground utilities are not present. Underground electrical utilities present an electrocution hazard. Underground gas utilities present an explosion hazard. Other underground utilities may present other hazards.
- Do not operate in a potentially explosive atmosphere.
- Do not wear loose fitting clothing when operating the tool. Loose fitting clothing can get entangled with the tool and cause serious injury.
- Supply hoses must have a minimum working pressure rating of 2500 psi/175 bar.
- Be sure all hose connections are tight.
- The hydraulic circuit control valve must be in the "OFF" position when coupling or uncoupling the tool. Wipe all couplers clean before connecting. Failure to do so may result in damage to the quick couplers and cause overheating. Use only lint-free cloths.
- Do not operate the tool at oil temperatures above 140° F/60° C. Operation at higher oil temperatures can cause operator discomfort and may cause damage to the tool.
- Do not operate a damaged, improperly adjusted, or incompletely assembled tool.
- To avoid personal injury or equipment damage, all tool repair, maintenance and service must only be performed by authorized and properly trained personnel.
- Do not exceed the rated limits of the tool or use the tool for applications beyond its design capacity.
- Always keep critical tool markings, such as labels and warning stickers legible.

# Tool Decals & Tags

A Name Tag Sticker is attached to the tool. Never exceed the flow and pressure levels specified on this sticker. The information listed on the name tag sticker must be legible at all times. Replace this sticker if it becomes worn or damaged. A replacement is available from your local Stanley distributor.



\* Not all stickers are furnished on all tool models. Consult parts list and model number for details.

The SAFETY TAG, P/N 15875, shown at right, smaller than actual size, is attached to the tool when shipped from the factory. Read and understand the safety instructions listed on this tag before removal. We suggest you retain this tag and attach it to the tool when not in use.

**DANGER**

1. FAILURE TO USE HYDRAULIC HOSE LABELED AND CERTIFIED AS NON-CONDUCTIVE WHILE USING HYDRAULIC TOOLS OR NEAR ELECTRICAL LINES MAY RESULT IN A HOSE OR PERSONAL INJURY. BEFORE USING HOSE, LABELLED AND CERTIFIED AS NON-CONDUCTIVE OR NEAR ELECTRICAL LINES, BE SURE THE HOSES MAINTAINED AS NON-CONDUCTIVE. THE HOSES SHOULD BE REGULARLY TESTED FOR ELECTRICAL CURRENT LEAKAGE IN ACCORDANCE WITH YOUR SAFETY DEPARTMENT INSTRUCTIONS.

2. A HYDRAULIC LEAK OR BURST MAY CAUSE OIL INJECTION INTO THE BODY OR CAUSE OTHER SEVERE PERSONAL INJURY.

A. DO NOT EXCEED SPECIFIED FLOW AND PRESSURE FOR THIS TOOL. EXCESS FLOW OR PRESSURE MAY CAUSE A LEAK OR BURST.

B. DO NOT EXCEED RATED WORKING PRESSURE OF HYDRAULIC HOSES USED WITH THIS TOOL. EXCESS PRESSURE MAY CAUSE A LEAK OR BURST.

C. CHECK TOOL, HOSE, COUPLERS & CONNECTORS DAILY FOR LEAKS. DO NOT FEEL FOR LEAKS WITH YOUR HANDS. CONTACT WITH A LEAK MAY RESULT IN SEVERE PERSONAL INJURY.

**IMPORTANT**

READ OPERATION MANUAL AND SAFETY INSTRUCTIONS FOR THIS TOOL BEFORE USING IT.

USE ONLY PARTS AND REPAIR PROCEDURES APPROVED BY STANLEY AND DESCRIBED IN THE OPERATION MANUAL.

TAG TO BE REMOVED ONLY BY TOOL OPERATOR.

(517) SEE OTHER SIDE 15875

**DANGER**

D. DO NOT LIFT OR CARRY TOOL BY THE HOSES. DO NOT ABUSE HOSE. DO NOT USE KNEED, TORQUE OR MANGLED HOSES.

3. MAKE SURE HYDRAULIC HOSES ARE PROPERLY CONNECTED TO THE TOOL BEFORE PRESSURIZING SYSTEM. SYSTEM PRESSURE HOSE MUST ALWAYS BE CONNECTED TO TOOL "IN" PORT. SYSTEM RETURN HOSE MUST ALWAYS BE CONNECTED AT TOOL "OUT" PORT. REVERSING CONNECTIONS MAY CAUSE REVERSE TOOL OPERATION WHICH CAN CAUSE SEVERE PERSONAL INJURY.

4. DO NOT CONNECT CLOSED-CENTER TOOL TO OPEN-CENTER HYDRAULIC SYSTEMS. THIS MAY CAUSE EXTREME SYSTEM HEAT AND/OR SEVERE PERSONAL INJURY.

DO NOT CONNECT OPEN-CENTER TOOL TO CLOSED-CENTER HYDRAULIC SYSTEMS. THIS MAY RESULT IN LOSS OF OTHER HYDRAULIC FUNCTIONS POWERED BY THE SAME SYSTEM AND/OR SEVERE PERSONAL INJURY.

5. BYSTANDERS MAY BE INJURED IN YOUR WORK AREA. KEEP BYSTANDERS CLEAR OF YOUR WORK AREA.

6. WEAR HEARING, EYE, FOOT, HAND AND HEAD PROTECTION.

7. TO AVOID PERSONAL INJURY OR EQUIPMENT DAMAGE, ALL TOOL REPAIR, MAINTENANCE AND SERVICE MUST BE PERFORMED BY AUTHORIZED AND PROPERLY TRAINED PERSONNEL.

**IMPORTANT**

READ OPERATION MANUAL AND SAFETY INSTRUCTIONS FOR THIS TOOL BEFORE USING IT.

USE ONLY PARTS AND REPAIR PROCEDURES APPROVED BY STANLEY AND DESCRIBED IN THE OPERATION MANUAL.

TAG TO BE REMOVED ONLY BY TOOL OPERATOR.

(517) SEE OTHER SIDE 15875

# Hydraulic Hose Requirements

## HOSE TYPES

Hydraulic hose types authorized for use with Stanley Hydraulic Tools are as follows:

- 1 Certified non-conductive
- 2 Wire-braided (conductive)
- 3 Fabric-braided (not certified or labeled non-conductive)

Hose 1 listed above is the only hose authorized for use near electrical conductors.


Hoses 2 and 3 listed above are **conductive** and **must never** be near electrical conductors.

## HOSE SAFETY TAGS

To help ensure your safety, the following DANGER tags are attached to all hoses purchased from Stanley Hydraulic Tools. **DONOT REMOVE THESE TAGS.**

If the information in a tag is illegible because of wear or damage, replace the tag immediately. A new tag may be obtained at no charge from your Stanley Distributor.


This Tag attached to "Certified Non-Conductive" hose.  
(shown smaller than actual size) p/n27987



Side 1

Side 2

This Tag attached to "Conductive" hose.  
(shown smaller than actual size) p/n29144



Side 1




Side 2

## HOSE PRESSURE RATING

The rated working pressure of the hydraulic hose must be equal to or higher than the relief valve setting on the hydraulic system.



# HTMA Requirements

Hydraulic System Requirements	Tool Category			
	 Type I	 Type II	 Type III	
Flowrate	4-6 gpm (15-23lpm)	7-9gpm (26-34lpm)	10.5-11.6gpm (36-44lpm)	11-13 gpm (42-49lpm)
Tool Operating Pressure (at the power supply outlet)	2000psi (138bar)	2000psi (138bar)	2000psi (138bar)	2000psi (138bar)
System relief valve setting (at the power supply outlet)	2100-2250psi (145-155bar)	2100-2250psi (145-155bar)	2100-2250psi (145-155bar)	2100-2250psi (145-155bar)
Maximum backpressure (at tool end of the return hose)	200psi (14bar)	200psi (14bar)	200psi (14bar)	200 psi (14bar)
Measured data max. fluid viscosity of: (at min. operating temperature)	400ssu* (82centistokes)	400ssu* (82centistokes)	400ssu* (82centistokes)	400 ssu* (82centistokes)
Temperature				
Sufficient heat rejection capacity to limit max. fluid temperature to: (at max. expected ambient temperature)	140° F (60°C)	140° F (60°C)	140° F (60°C)	140° F (60°C)
Min. cooling capacity at a temperature difference of between ambient and fluid temps	3 hp (2.24kW) 40° F (22°C)	5 hp (3.73kW) 40° F (22°C)	6 hp (4.47kW) 40° F (22°C)	7 hp (5.22kW) 40° F (22°C)
NOTE: Do not operate the tool at oil temperatures above 140°F (60°C). Operation at high temperatures can cause operator discomfort at the tool.				
Filter				
Min. full-flow filtration Sized for flow of at least: (For cold temp. startup and max. dirt-holding capacity)	25 microns 18 gpm (68lpm)	25microns 30gpm (114lpm)	25microns 35gpm (132lpm)	25microns 40gpm (151lpm)
Hydraulic fluid				
Petroleum based (premium grade, anti-wear, non-conductive)				
Viscosity (at min. and max. operating temps)	100-400 ssu* (20-82centistokes)	100-400 ssu* (20-82centistokes)	100-400 ssu* (20-82centistokes)	100-400 ssu* (20-82centistokes)
NOTE: When choosing hydraulic fluid, the expected oil temperature extremes that will be experienced in service determine the most suitable temperature viscosity characteristics. Hydraulic fluids with a viscosity index over 140 will meet the requirements over a wider range of operating temperatures.				
*SSU=Saybolt Seconds Universal				

NOTE: These are general hydraulic system requirements. See tool Specification page for tool specific requirements.

---

# Operating Instructions

---

## Pre-Operation Procedures

### Install Chuck

Screw the chuck onto the output shaft. Tighten to 50 ft/lbs/68 Nm torque, lubricated.

### CAUTION

*Use the flats on the shaft to hold the shaft during tightening or loosening of the chuck.*

### Check Power Source

1. Using a calibrated flow meter and pressure gauge, check that the hydraulic power source develops a flow of 4-12 gpm/15-45 lpm at 1000-2000 psi/70-140 bar.
2. Make certain that the hydraulic power source is equipped with a relief valve set to open at 2100 psi/145 bar maximum.

### Connect Hoses

1. Wipe all hose couplers with a clean lint-free cloth before making connections.
2. Connect hoses from the hydraulic power supply to the tool quick disconnects. It is a good practice to connect the return hose first and disconnect it last to minimize or avoid trapped pressure within the drill.
3. Observe the arrow on hose couplers to ensure that the flow is in the proper direction. The male coupler on the circuit hose end is the supply (pressure) coupler.
4. Make sure the circuit PRESSURE hose (with male quick disconnect) is connected to the port at the back of the drill handle. The circuit RETURN hose (with female quick disconnect) is connected to the port closest to the trigger.
5. Move the hydraulic circuit control valve to the **ON** position to direct hydraulic flow to the drill.

**NOTE:** If uncoupled hoses are left in the sun, pressure increase inside the hose may result in making them difficult to connect. Whenever possible, connect the free ends of the hoses together.

## Drill Operation

1. Observe all safety precautions.
2. Place the selected drill bit fully into the chuck. Center the bit and tighten the chuck using the key provided. Remove the key and store away from the drill.
3. Momentarily press the trigger to ensure that the drill bit rotates clockwise and runs true.

### CAUTION

*Make certain that the chuck has been securely mounted.*

4. Select a work position that gives secure footing and balance while operating the drill.
5. Press the drill against the work and squeeze the trigger.

The drilling method used is determined by the material being drilled and the size and depth requirements of the hole.

Brittle materials such as rock, brick or concrete can be drilled efficiently when the bit is caused to strike (hammer) the hole bottom to break up the material. Without hammering, the rotating bit will only grind down and become dull. The Stanley HD08 should be used for this application.

Ductile material such as metal or wood is drilled efficiently when a steady down force is applied to the drill center to cause the bit to slice chips of material from the hole bottom. When drilling in metal, use a cutting lubricant to prolong bit life and reduce the amount of force required to drill effectively.

Large drill holes are more productively created from small drill holes. Drill bits are incrementally selected to enlarge the hole until the desired hole size is obtained. Each bit selected must always be tooled to thread and jam into an existing hole;

---

# Operating Instructions

---

otherwise the bit may break and endanger the operator.

## Cold Weather Operation

If the tool is to be used during cold weather, preheat the hydraulic fluid at low engine speed. When using the normally recommended fluids, fluid temperature should be at or above 50°F/10°C (400 ssu/82 centistokes) before use.

Damage to the hydraulic system or tool can result from use with fluid that is too viscous or thick.

## Open Center/ Closed Center Setup (OC/CC)

This tool can be configured to run on both open center and closed center systems. Set for proper system before use.

1. Determine system type.
2. Remove hex plug (81) from spring cap using a 3/16 in. Hex.

**Closed Center**      Using a 3/16 in. Hex, reach through the hole in the spring cap and turn the selector screw fully clockwise. When the selector screw bottoms, closed center operation is selected.

**Open Center**      Using a 3/16 in. Hex, reach through the hole in the spring cap and turn the selector screw counter-clockwise until meeting resistance (from the retaining ring). Turn the selector clockwise and then counter-clockwise to be sure the selector is being stopped by the retaining ring. Do not force the selector screw. Open center operation is now selected.



3. Reinstall hex plug. Failure to install plug may introduce contaminants to the spool bore resulting in replacement of the valve spool and main Housing.

---

# Service Instructions

---

**Note:** For orientation of parts in the following procedures, refer to the parts drawing later in this manual.

## Prior to Disassembly

1. Clean the exterior of the tool and place on a clean work surface.
2. Obtain the seal kit listed on the PARTSLIST so all seal exposed during disassembly can be replaced.

## Prior to Reassembly

1. Clean all parts with a degreasing solution.
2. Blow dry all parts or use lint-free cloths.
3. Ensure that all seal exposed during disassembly are replaced with new parts.
4. Apply clean grease or o-ring lubricant to all parts during assembly.

## Tool Disassembly

### Gear Housing

1. Remove the chuck (33) from the output shaft (36) by holding the seal nut (35) with an open end wrench and turning the chuck counter-clockwise.
2. Remove the capscrews (31) and lock washers (32) securing the gear housing (69) to the main housing assembly (76). If the tool has a trigger guard (80), remove capscrew (34), nut (20) and trigger guard before removing the gear housing.
3. Remove the ring gear (27), roll pin (5) and gasket (71).
4. Remove the retaining ring (29) near the planet shafts (23) before removing the planet shafts. Remove the seal nut (35) by using the planet shaft hole to keep the output shaft from turning. Pull the output shaft with attached parts from the gear housing.

5. Remove the planet gears (26) from the output shaft. Inspect shafts, gears and gear bore bushings (see CLEANING AND INSPECTION procedure).

6. Spin the ball bearing (28) on the output shaft. The bearing should turn smoothly. To replace the bearing, support the outer race and press down on the output shaft from the chuck end. Do not reuse the ball bearing once it has been removed from the output shaft.

7. Remove the output shaft seal (30) by pressing it from the gear housing bore.

8. Check the end faces of the seal nut and output shaft for nicks and wear (see CLEANING AND INSPECTION procedure).

### Motor Cap

9. Remove the six capscrews (41) and lock washers (3) securing the motor cap assembly (46) to the main housing assembly and lift off the motor cap assembly. Do not in any way excessively force the motor cap off the main housing assembly.

10. Remove the o-ring (9) from the motor cap.

### Main Shaft and Idler Shaft

11. Tap on the small gear end of the main shaft (5) and push the shaft from the main body.

12. Remove the idler gear (45) and idler shaft (47).

13. Remove the retaining ring (16) and then pick out the seal washer (44), back-up ring (39) and o-ring (4) from the main housing.

### Valve Spool

14. Unscrew the spring cap (66), pick out the spring (79) and push the valve spool (59) out of the spring cap end of the main housing.

### Trigger

15. Remove the trigger by first removing the capscrews (8) and lock washers (32) and removing the trigger and trigger mount (78) as an assembly. Drive out the roll pin (21).

---

# Service Instructions

---

## Reversing Spool

16. Remove the retaining rings (67) and end caps (65).

17. Unscrew the seal caps (64) and slide the reversing spool (68) out of the main housing. Make sure the idler shaft has been removed prior to completing this step.

## Cleaning and Inspection

### Cleaning

Clean all parts with a de-greasing solution. Blow dry with compressed air or use lint-free cloths.

### Gear Chamber (Motor Cap)

The chamber bores and bottoms around the shaft bushings should be polished and not rough or grooved. If the bushing bores are yellow-bronze, replace them and investigate the cause of wear.

The flat surfaces around the chamber and bolt holes should be flat and free of nicks or burrs that could cause misalignment or leaks.

### Bushings

The inside of the bushings should be gray with some bronze showing through. If significant yellow-bronze shows, replace the bushings. Inspect the motor shaft and idler shaft for corresponding wear and replace as required.

### Gears

The drive and idler gears should have straight tips without nicks, square tooth ends and have smooth even polish on the teeth and end faces. Replace the gear if cracks are present.

### Main Housing Assembly

The surface near the gears should show two interconnecting polished circles without a step.

### Shafts

The shaft diameter at the bearing and seal locations must be smooth. Grooves, roughness or a reduced diameter indicate fluid contamination or damaged bushings. Grit particles may have been imbedded in the bushings, grinding into the hardened shaft. If abnormal shaft wear as noted above occurs (more than normal polishing), replace both the shaft and associated bushings.

Also check the hydraulics system for excess contamination in the fluid and for filter condition. Operating conditions may require changing from a 25-

micron filter to an oversized 10-micron filter.

## Tool Reassembly

1. Lubricate and install a new o-ring (4) and back-up ring (39) into the main housing. Install the seal back-up washer (44) and retaining ring (16).

2. Slide the reversing spool (68) into the main housing assembly. Insert the spool with the slot toward the idler shaft hole and then the narrow side of the depression in the spool facing up toward the top of the main housing.

3. Insert the idler shaft (47) to prevent the reversing spool from turning.

4. Lubricate and install a new wiper seal (63), o-ring (10), back-up ring (17) and o-ring (2) into each seal cap (64). Install each seal cap onto the main housing assembly.

5. Install each end cap (65) and secure with a snap ring (67).

6. Lubricate seal area of main shaft (50) and install it into the main housing. Install the idler gear (45) onto the idler shaft.

7. Lubricate and install a new o-ring (9) onto the motor cap (46). Lubricate cap screw threads (41) with an anti-seize compound and install the motor cap with the cap screws and lock washers (3). Tighten bolts to 15-17 ft lbs / 20-23 Nm in a cross pattern.



8. Lubricate and install a new o-ring (19) in the main housing and a new seal wiper (61) in the trigger mount (78). Secure the trigger (77) to trigger mount with roll pin (21). Install trigger assembly to main housing with cap screws (8) and lock washers (32).

9. Lubricate and install a new o-ring (18) on the valve spool (59) before installing valve spool into the main housing from the spring cap end. Do not install the valve spool from the trigger side of the main housing as this will result in spool seal damage. Ensure that the tab on the valve spool nose is aligned with the slot in the trigger. Install spring (79) behind valve spool. Using Loctite™ 242, install the spring cap (66) to the main housing.

10. Lubricate and install the shaft seal (30) into the gear

---

# Service Instructions

---

housing. Install shaft keeper(24) and bearing keeper(25) before installing bearing(28) on output shaft(36). Install planet gears(26) into output shaft and install the output shaft with attached parts into the gear housing(69). Install the ring gear(27) into the gear housing and secure with the roll pin(5). Install the seal gasket(71) around the ring gear.

11. Lubricate and install the o-ring(4) on the output shaft. Install the seal nut(35), using the planet shaft bore stop to prevent the output shaft from turning. Install the planet shafts(23) and secure them with retaining ring(29). Install the gear chamber and attached parts to the main housing using capscrews(31) and lock washers(32). If the tool has a trigger guard(80), install guard with capscrew(34) and nut(20) at this time.

12. Lubricate the output shaft threads and install the chuck(33). While holding the seal nut secure with an open end wrench, torque the chuck to 50 ftlbs / 69Nm.

# Troubleshooting

This section describes how to find and resolve problems users may experience. If a situation occurs that is not covered, call your Stanley Customer Service representative for assistance.

## WARNING

*Inspecting the tool or installing parts with the hydraulic hoses connected can result in severe personal injury or equipment damage.  
To prevent accidental startup, disconnect the hydraulic power before beginning any inspection or installation task.*

If symptoms of poor performance develop, the following chart can be used as a guide to correct the problem.

When diagnosing faults in operation of the tool, always check that the hydraulic power source is supplying the correct hydraulic flow and pressure to the tool as listed in the table. Use a flow meter known to be accurate. Check the flow with the hydraulic coil temperature at least 80°F/27°C.

Symptom	Possible Cause	Solution
Tool will not start.	Power not being supplied.	Check to make certain that both hoses are connected.
		Turn hydraulic circuit control valve ON.
Low drilling torque.	Defective quick disconnects.	Check each quick disconnect separately. Replace as necessary.
	Relief valve setting too low. Fluid restriction in hose or valve. Excess flow and pressure loss.	Set relief valve at 2100 psi/145 bar.
		Locate and remove restriction.
		Use correct fluid.
		Fluid not warmed-up. Preheat system.
		Hoses too long for hose I.D. Use shorter hose.
Hoses I.D. too small for hose length. Use larger I.D. hose.		
Low tool speed.	Fluid flow rate is too low.	Check circuit flow rate.
Tool speed too high.	Fluid flow rate is excessive.	Check circuit flow rate; add a proper flow control valve or reduce the pump RPM.
Oil leaks around gear housing.	Hydraulic pressure and return hoses reversed.	Correct hose connections. Pressure should be to the handle port away from the trigger, return is near the trigger; then replace the main shaft oil seal.
	Main shaft seal o-ring leaking.	Replace seal; check seal contact surfaces.


*continued*

# Troubleshooting

Symptom	Possible Cause	Solution
Oil gets hot, power unit working hard.	Open center tool on a closed center circuit and vice versa.	Use tool to match circuit.
	Circuit relief set too low.	Adjust relief valve to 2100 psi/ 145 bar.
	Too much oil going through tool.	Adjust flow for 12 gpm/45 lpm maximum, or less.
Oil leaks at reversing spool.	Damaged o-rings.	Replace as required.
	Wrong hydraulic fluid. Circuit too hot.	See OPERATING INSTRUCTIONS for correct fluid/ circuit specifications.
Oil leak at motor cap face.	Fasteners loose.	Refer to SERVICE MANUAL
	Face o-ring worn or missing.	Replace as required.
	Motor cap/ main housing damaged.	Replace as required.



# DL07 Parts Illustration



# DL07 Parts List

Item	Part	Qty.	Description	Notes
1	00026	2	O-ring3/16x5/16x1/16-008	
2	00175	2	O-ring1/2x5/8x1/16-014	
3	00231	6	Lockwasher5/16".I.D	
4	00354	2	O-ring1/2x11/16x3/32-112	
5	00563	1	RollPin3/16O.D.x.375LG.	
6	00713	2	DowelPin1/4x1	
7	00717	1	O-ring1/4x3/8x1/16-010	
8	00803	2	HSHCS10-24x5/8	
9	01262	1	O-ring1-3/4x1-7/8x1/16-031	
10	01604	1	O-ring.755x.949x.097-910	
11	02324	1	Cap&Plug1/2in.	ModelDL07552SUPOnly
12	03288	1	Cap&Plug3/8in.	ModelDL07552SUPOnly
13	03364	1	O-ring.441x.558x.072-905	
14	05206	2	Bushing	
15	05207	2	Bushing	
16	06635	1	RetainingRing	
17	07224	2	BackupRing-014	
18	07626	1	O-ring1/2x5/8x1/16-014	
19	07627	1	O-ring5/8x3/4x1/16-016	
20	07724	1	NylockNut10-24unc	
21	07970	1	RollPin3/16O.d.x1.375LG.	
22	08130	1	Handle	ModelsDL07652,552S,552SUP,572SOnly
23	08161	2	PlanetShaft	
24	08162	1	ShaftKeeper	
25	08163	1	BearingKeeper	
26	08165	2	PlanetGearAssembly	IncludesItem#14
27	08166	1	RingGear	
28	08175	1	BallBearing	
29	08440	1	RetainingRing	
30	09621	1	ShaftSeal	
31	09622	3	HSHCS10-24x1-1/4	
32	09623	5	Lockwasher#10	
33	09624	1	1/2in.DrillChuck	ModelsDL07550,5001,652,552S,552SUPOnly
	27628	1	5/8in.DrillChuck	ModelDL07572SOnly
34	09687	1	HSHCS10-24x2.000	
35	09778	1	SealNut	
36	09779	1	OutputShaft	
37	11207	1	Circuittype"D"Sticker	ModelDL0755001Only
38	11354	1	OC/CCSticker	
39	13995	1	Back-upRing-112	
40	16070	1	RetainingRing	
41	18206	6	HSHCS5/16-18x1-3/4	
42	20758	1	Bushing	
43	20760	1	Bushing	
44	27067	1	SealBack-upWasher	
45	20769	1	IdlerGearAssembly	IncludesItem#43
46	20770	1	MotorCapAssembly	IncludesItem#6and15
47	20782	1	IdlerShaft	
48	24058	1	3/8in.Flush-faceCouplerBody3/8npt	PartofSet24069-ModelsDL07552S,552SUP,572S Only
49	24059	1	3/8in.Flush-faceCouplerNose3/8npt	PartofSet54069-ModelsDL07552S,552SUP,572SOnly
50	24271	1	MainShaft	
51	25610	1	RailroadHelpDeskSticker	ModelsDL07552S,552SUP,572SOnly
52	28323	2	Sticker"CE"12mm	ModelDL0755001Only
53	60807	1	DL07ModelNo.Sticker	
54	28788	2	Sticker-Manual	
55	29148	1	RPMSticker	ModelDL0755001Only
56	29149	1	RotationDirectionSticker	ModelDL0755001Only
57	38676	1	DepthGageRod	ModelsDL07552S,572SOnly
58	38685	1	ThumbScrew10-32UNFx.375	ModelsDL07552S,572SOnly
59	48987	1	ValveSpool	
60	48989	1	SelectorScrew	
61	49139	1	SealWiper	
62	56725	2	HoseAssy471ST-05-01-08-06-08-18	ModelsDL07552S,552SUP,572SOnly
63	56747	2	SealWiper	
64	56749	2	SealCap	

# DL07 Parts List

Item	Part	Qty.	Description	Notes
65	56757	2	EndCap	
66	56758	1	SpringCap	
67	56764	2	RetainingRing	
68	56765	1	ReversingSpool	
69	58403	1	GearHousingMachining	
70	58462	1	ReliefCartridgePlugAssembly	IncludesItems#7and13
71	58635	1	SealGasket	
72	58856	1	3/8in.Flush-faceCouplerBody-8(1/2)MaleSAE	PartofSet58718-ModelsDL07550,55001,652Only
73	58857	1	3/8in.Flush-faceCouplerNose-8(1/2)MaleSAE	PartofSet58718-ModelsDL07550,55001,652Only
74	58862	1	WarningSticker - Pressure	ModelsDL07550,652,552S,552SUP,572SOnly
75	58864	1	WarningSticker - Electrical	ModelsDI07550,652,552S,552SUP,572SOnly
76	59049	1	MainHousingAssembly	IncludesItems#15and42
77	60677	1	TriggerCasting	
78	60678	1	TriggerMountCasting	
79	60679	1	Spring	
80	60710	1	TriggerGuard	
81	350041	1	HollowHexPlug-4SAE	

**NOTE:**  
Use Part Number and  
Description when ordering.

SealKitP/N60792			
1	00026	O-ring,3/16x5/16x1/16-008	2
2	00175	O-ring,1/2x5/8x1/16-014	2
4	00354	O-ring,1/2x11/16x3/32-112	2
7	00717	O-ring,1/4x3/8x1/16-010	1
9	01262	O-ring,1-3/4x1-7/8x1/16-031	1
10	01604	O-ring,.755x.949x.097-910	2
13	03364	O-ring,.441x.558x.072-905	1
17	07224	Backupring,-014	2
18	07626	O-ring,1/2x5/8x1/16-014	1
19	07627	O-ring,5/8x3/4x1/16-016	1
30	09621	ShaftSeal	1
39	13995	Backupring-112	1
63	49139	SealWiper	1
65	56747	SealWiper	2
73	58635	SealGasket	1

# Accessories

NOTE:  
Use Part Number  
and Description when  
ordering.

Part	Description
	WoodAugerBits,5/8 in.Hex
27845 27847	9/16in.diax18in.CarbideTippedAugerBit(22in.oal) 13/16in.diax18in.CarbideTippedAugerBit(22in.oal)
	WoodAugerBits,7/16in.Hex
27850 27851 27852 27853 27854 27855 27856 27857 27858 27859 27860 27861 27862 27863 27864 27869 32399 32400	9/16in.dia.x8in.CarbideTippedAugerBit(12in.oal) 11/16in.dia.x8in.CarbideTippedAugerBit(12in.oal) 13/16in.dia.x8in.CarbideTippedAugerBit(12in.oal) 15/16in.dia.x8in.CarbideTippedAugerBit(12in.oal) 1-1/16 in.dia.x8in.CarbideTippedAugerBit(12in.oal) 9/16in.dia.x12in.CarbideTippedAugerBit(16in.oal) 11/16in.dia.x12in. CarbideTippedAugerBit(16in.oal) 13/16in.dia.x12in.CarbideTippedAugerBit(16in.oal) 15/16in.dia.x12in.CarbideTippedAugerBit(16in.oal) 1-1/16 in.dia.x12in.CarbideTippedAugerBit(16in.oal) 9/16in.dia.x18in.CarbideTippedAugerBit(22in.oal) 11/16in.dia.x18in.CarbideTippedAugerBit(22in.oal) 13/16in.dia.x18in.CarbideTippedAugerBit(22in.oal) 15/16in.dia.x18in.CarbideTippedAugerBit(22in.oal) 1-1/16 in.dia.x18in.CarbideTippedAugerBit(22in.oal) 13/16in.diax36in.CarbideTippedAugerBit(48in.oal) 11/16in.diax15in.CarbideTippedAugerBit(18in.oal) 13/16in.diax15in.CarbideTippedAugerBit(18in.oal)

---

# Warranty

---

Stanley Hydraulic Tools (hereinafter called "Stanley"), subject to the exceptions contained below, warrants new hydraulic tools for a period of one year from the date of sale to the first retail purchaser, or for a period of 2 years from the shipping date from Stanley, whichever period expires first, to be free of defects in material and/or workmanship at the time of delivery, and will, at its option, repair or replace any tool or part of a tool, or new part, which is found upon examination by a Stanley authorized service outlet or by Stanley's factory in Milwaukie, Oregon to be DEFECTIVE IN MATERIAL AND/OR WORKMANSHIP.

## EXCEPTIONS FROM WARRANTY

**NEW PARTS:** New parts which are obtained individually are warranted, subject to the exceptions herein, to be free of defects in material and/or workmanship at the time of delivery and for a period of 6 months after the date of first usage. Seals and diaphragms are warranted to be free of defects in material and/or workmanship at the time of delivery and for a period of 6 months after the date of first usage or 2 years after the date of delivery, whichever period expires first. Warranty for new parts is limited to replacement of defective part only. Labor is not covered.

**FREIGHT COSTS:** Freight costs to return parts to Stanley, if requested by Stanley for the purpose of evaluating a warranty claim for warranty credit, are covered under this policy if the claimed part or parts are approved for warranty credit. Freight costs for any part or parts which are not approved for warranty credit will be the responsibility of the individual.

**SEALS & DIAPHRAGMS:** Seals and diaphragms installed in new tools are warranted to be free of defects in material and/or workmanship for a period of 6 months after the date of first usage, or for a period of 2 years from the shipping date from Stanley, whichever period expires first.

**CUTTING ACCESSORIES:** Cutting accessories such as breaker tool bits are warranted to be free of defects in material and/or workmanship at the time of delivery only.

**ITEMS PRODUCED BY OTHER MANUFACTURERS:** Components which are not manufactured by Stanley and are warranted by their respective manufacturers.

- a. Costs incurred to remove a Stanley manufactured component in order to service an item manufactured by other manufacturers.

**ALTERATIONS & MODIFICATIONS:** Alterations or modifications to any tool or part. All obligations under this warranty shall be terminated if the new tool or part is altered or modified in any way.

**NORMAL WEAR:** Any failure or performance deficiency attributable to normal wear and tears such as tool bushings, retaining pins, wear plates, bumpers, retaining rings and plugs, rubber bushings, recoil springs, etc.

**INCIDENTAL/CONSEQUENTIAL DAMAGES:** To the fullest extent permitted by applicable law, in no event will STANLEY be liable for any incidental, consequential or special damages and/or expenses.

**FREIGHT DAMAGE:** Damage caused by improper storage or freight handling.

**LOSSTIME:** Loss of operating time to the user while the tool(s) is out of service.

**IMPROPER OPERATION:** Any failure or performance deficiency attributable to a failure to follow the guidelines and/or procedures as outlined in the tool's operation and maintenance manual.

**MAINTENANCE:** Any failure or performance deficiency attributable to not maintaining the tool(s) in good operating condition as outlined in the Operation and Maintenance Manual.

**HYDRAULIC PRESSURE & FLOW, HEAT, TYPE OF FLUID:** Any failure or performance deficiency attributable to excess hydraulic pressure, excess hydraulic back-pressure, excess hydraulic flow, excessive heat, or incorrect hydraulic fluid.

**REPAIRS OR ALTERATIONS:** Any failure or performance deficiency attributable to repairs by anyone which in Stanley's sole judgment caused or contributed to the failure or deficiency.

**MIS-APPLICATION:** Any failure or performance deficiency attributable to mis-application. "Mis-application" is defined as usage of products for which they were not originally intended or usage of products in such a manner which exposes them to abuse or accident, without first obtaining the written consent of Stanley. PERMISSION TO APPLY ANY PRODUCT FOR WHICH IT WAS NOT ORIGINALLY INTENDED CAN ONLY BE OBTAINED FROM STANLEY ENGINEERING.

**WARRANTY REGISTRATION: STANLEY ASSUMES NO LIABILITY FOR WARRANTY CLAIMS SUBMITTED FOR WHICH NO TOOL REGISTRATION IS ON RECORD.** In the event a warranty claim is submitted and no tool registration is on record, no warranty credit will be issued without first receiving documentation which proves the sale of the tool or the tools' first date of usage. The term "DOCUMENTATION" as used in this paragraph is defined as a bill of sale, or letter of intent from the first retail customer. A WARRANTY REGISTRATION FORM THAT IS NOT ALSO ON RECORD WITH STANLEY WILL NOT BE ACCEPTED AS "DOCUMENTATION".

## NO ADDITIONAL WARRANTIES OR REPRESENTATIONS

This limited warranty and the obligation of Stanley thereunder is in lieu of all other warranties, expressed or implied including merchantability or fitness for a particular purpose except for that provided herein. There is no other warranty. This warranty gives the purchaser specific legal rights and other rights may be available which might vary depending upon applicable law.

For additional Sales & Service information, contact:



StanleyHydraulicTools  
Division of the Stanley Works  
3810SENaefRoad  
Milwaukie, OR 97267 USA

Tel: (503)659-5660  
Fax: (503) 652-1780  
[www.stanley-hydraulic-tools.com](http://www.stanley-hydraulic-tools.com)