

CHAPTER 3

ENGINE

Torque Specifications - 2 Stroke	3.1
Torque Specifications - 4 Stroke	3.2
Torque Patterns	3.3
Piston Identification	3.4
Piston Clearance Specifications - 2 Stroke	3.4
ES33PF / EH50PL Service Data	3.5-3.8
Cooling System Pressure Test	3.9
Cooling System Specifications	3.10
Engine Removal	3.11-3.12
Engine Installation Notes	3.13
EC25PF / EC28PF Engine Disassembly	3.14-3.15
EC25PF / EC28PF Engine Assembly	3.16-3.20
EC25PF / EC28PF Oil Pump End Play Adjustment ..	3.21
EC25PF / EC28PF Oil Check Valve Testing	3.22
EC25PF Recoil Disassembly	3.23
EC25PF Recoil Assembly	3.24-3.25
EC38PL Engine Disassembly	3.26-3.32
EC38PL Engine Inspection	3.32-3.35
Cylinder/Piston Inspection - 2 Stroke	3.36-3.37
Cylinder Honing	3.38
Connecting Rod Inspection - 2 Stroke	3.39
Crankshaft Runout Inspection - 2 Stroke	3.40
ES33PF / EH50PL Engine Lubrication	3.43
ES33PF Lubrication/Oil Flow	3.44-3.45
ES50PL Lubrication/Oil Flow	3.46-3.47
ES33PF Engine Exploded View	3.48
EH50PL Engine Exploded View	3.49
ES33PF / EH50PL Engine Removal	3.50
ES33PF / EH50PL Engine Top End Disassembly	3.50-3.65
ES33PF / EH50PL Valve Seat Service	3.66-3.71
ES33PF / EH50PL Engine Bottom End Disassembly .	3.72-3.89
ES33PF / EH50PL Crankcase & Bearing Assembly ..	3.90
ES33PF / EH50PL Crankshaft End Play Inspection ..	3.91-3.92
ES33PF / EH50PL Counter Balancer End Play Insp. .	3.93-3.94
ES33PF / EH50PL Engine Assembly/Inspection	3.95-3.109
Sealed Recoil Disassembly/Inspection	3.110-3.111
Sealed Recoil Assembly	3.112
Spark Plug Fouling Checklist	3.113
2 Stroke Troubleshooting	3.114-3.115
4 Stroke Troubleshooting	3.116-3.118

ENGINE
Torque Specifications - 2 Cycle

TORQUE SPECIFICATIONS				
2 CYCLE ENGINES				
Fastener	Size	<u>250</u> EC25PFE Ft. Lbs. (Nm)	<u>300</u> EC28PFE Ft. Lbs. (Nm)	<u>400</u> EC38PLE Ft. Lbs. (Nm)
Cylinder Head Bolts	8mm	18-20 (24-27)	18-20 (24-27)	18-20 (24-27)
Cylinder Base Bolts	10mm	25-29 (34-40)	25-29 (34-40)	25-29 (34-40)
Crankcase	8mm	17-18 (23-24)	17-18 (23-24)	17-18 (23-24)
Crankcase	6mm	6-8 (8-11)	6-8 (8-11)	6-8 (8-11)
Crankshaft Slotted Nut	16mm	-	-	29-44 (40-60)
Water Pump Impeller Nut	6mm	-	-	5-6.5 (7-9)
Stator Plate	6mm	5-6.5 (7-9)	5-6.5 (7-9)	5-6.5 (7-9)
Flywheel	16mm	44-62 (60-85)	44-62 (60-85)	29-44 (40-60)
Starter Motor	6mm	5-6.5 (7-9)	5-6.5 (7-9)	5-6.5 (7-9)
Recoil Housing	6mm	5-6.5 (7-9)	5-6.5 (7-9)	5-6.5 (7-9)
Spark Plug (New)	14mm	9-11 (12-15)	9-11 (12-15)	9-11 (12-15)
Spark Plug (Used)	14mm	17-20 (23-27)	17-20 (23-27)	17-20 (23-27)
Drive Clutch Bolt	7/16 - 20	40 (55)	40 (55)	40 (55)


ENGINE
Torque Specifications - 4 Cycle

TORQUE SPECIFICATIONS				
4 CYCLE ENGINES				
Fastener	Size	335 ES33PFE Ft. Lbs. (Nm)	425 EH42PLE Ft. Lbs. (Nm)	500 EH50PLE Ft. Lbs. (Nm)
Blind Plug (Oil Pressure)	1/8 Pipe Thread	6.5-11 (9-15 Nm)	6.5-11 (9-15 Nm)	6.5-11 (9-15 Nm)
Camshaft Sprocket	6mm	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)
Camshaft Chain Tensioner Lever	6mm	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)
Camshaft Chain Tensioner	6mm	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)
Camshaft Chain Tensioner Cap	11mm	14-19 (20-25 Nm)	14-19 (20-25 Nm)	14-19 (20-25 Nm)
Carburetor Adaptor	8mm	12-14 (16-20 Nm)	12-14 (16-20 Nm)	12-14 (16-20 Nm)
Crankcase	8mm	14-15 (19-21 Nm)	14-15 (19-21 Nm)	14-15 (19-21 Nm)
Crankshaft Slotted Nut (Cam Chain Drive Sprocket)	28mm	35-51 (47-69 Nm)	35-51 (47-69 Nm)	35-51 (47-69 Nm)
Cylinder Base Bolts	10mm 6mm	45-49 (61-67 Nm) 6-8 (9-11 Nm)	45-49 (61-67 Nm) 6-8 (9-11 Nm)	45-49 (61-67 Nm) 6-8 (9-11 Nm)
Cylinder Head Bolts	11mm 6mm	47-53 (64-72 Nm) 5-7 (7-9 Nm)	Refer to Engine Assembly for torque procedure	
Drive Clutch Bolt	7/16 - 20	40 (55 Nm)	40 (55 Nm)	40 (55 Nm)
Flywheel	16mm	58-72 (78-98 Nm)	58-72 (78-98 Nm)	58-72 (78-98 Nm)
Oil Delivery Pipe	12mm	11-15 (15-21 Nm)	11-15 (15-21 Nm)	11-15 (15-21 Nm)
Oil Drain Bolt (Crankcase)	14mm	14-17 (19-23 Nm)	14-17 (19-23 Nm)	14-17 (19-23 Nm)
Oil Filter Pipe Fitting	20mm	36-43 (49-59 Nm)	36-43 (49-59 Nm)	36-43 (49-59 Nm)
Oil Hose Fitting	1/8 Pipe Thread	6.5-11 (9-15 Nm)	6.5-11 (9-15 Nm)	6.5-11 (9-15 Nm)
Oil Pump	6mm	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)
Oil Pump Case Screw	5mm	1.5-2 (2-3 Nm)	1.5-2 (2-3 Nm)	1.5-2 (2-3 Nm)
One Way Valve	11mm	14-19 (20-25 Nm)	14-19 (20-25 Nm)	14-19 (20-25 Nm)
Recoil Housing	6mm	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)
Rocker Cover	6mm	7-8 (9-11 Nm)	7-8 (9-11 Nm)	7-8 (9-11 Nm)
Rocker Support	8mm	-	8-10 (11-13 Nm)	8-10 (11-13 Nm)
Rocker Adjuster Screw	6mm	6-7 (8-10 Nm)	6-7 (8-10 Nm)	6-7 (8-10 Nm)
Water Pump Impeller Nut	6mm	-	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)
Water Pump Housing Cover	6mm	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)
Stator Plate	6mm	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)
Starter Motor	6mm	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)	5-6.5 (7-9 Nm)
Spark Plug	14mm	9-11 (12-15 Nm)	9-11 (12-15 Nm)	9-11 (12-15 Nm)


ENGINE

Engine Fastener Torque Patterns


Tighten cylinder head, cylinder base, and crankcase fasteners in 3 steps following the sequence outlined below.




**Cylinder Head
250 / 300**



**Cylinder Head
400**




**Cylinder Base
250 / 300 / 400**




**Cylinder Head
Cylinder Base
335 / 425 / 500**

**Crankcase
400L**



**Crankcase
250/300**



**Crankcase
335 / 425 / 500**

ENGINE

Piston Identification

Piston Identification

Note the directional and identification marks when viewing the pistons from the top. The letter “F”, “!”, “ ” or : must always be toward the flywheel side of the engine. The other numbers are used for identification as to diameter, length and design. Two stroke rings are keystone design. Four stroke engine rings are rectangular profile. The numbers or letters on all rings (except 4-stroke oil control rings) must be positioned upward. See text for 4 stroke oil control ring upper rail installation. Use the information below to identify pistons and rings.

Engine Model No.	Oversize Available* (mm)	Piston Length	Standard Piston Identification
EC25PFE-08, 09, 10, 11, 13	.25 .50 1.00	68 mm	3W, 4W
EC28PFE-01, 02	.25 .50	70 mm	28
ES33PFE01/02	.25 .50	52.5 mm	None
EC38PLE-04, 05	.25 .50	78mm	38A
EC38PLE-06, 07, 08, 09	.25 .50	78mm	38B
EH42PL-02	.25 .50	66mm	B
EH50PLE04, 06, 08, 09	.25 .50	72mm	C

*

Pistons and rings marked 25 equal .25mm (.0101) oversized
Pistons and rings marked 50 equal .50mm (.0201) oversized
Pistons and rings marked 10 equal 1.0mm (.0401) oversized (250 engines only)

Piston Clearance Specifications (2 Stroke Engines)

NOTE: See page 3.5 - 3.8 for 4 Stroke engine service data.

Machine Model	Engine Model	Cyl. Disp. (CCs)	Bore (in./mm)	Stroke (in./mm)	Piston Ring End Gap (Installed) in. (mm)	Piston Clearance in. (mm)	Clearance Svc. Limit (in. / mm)
Trail Blazer Trail Boss	EC25PF	244	2.8346 / 72	2.362 / 60	.009-.018 (.23-.46)	.0011-.0021 (.03-.05)	.006 / .15
Xpress 300 Xplorer 300	EC28PF	283	2.935 / 74.5	2.561 / 65	.012-.022 (.31-.56)	.0012-.0026 (.03-.07)	.006 / .15
Xplorer 400 Sport Scrambler 400	EC38PLE-08, 09	379	3.270 / 83	2.758 / 70	.007-.015 (.18-.38)	.0023-.0037 (.06-.09)	.006 / .15

ES33PFE01 / 02 Engine Service Data

Cylinder Head / Valve				ES33PFE01 / 02
Rocker Arm	Rocker arm ID			.8669-.8678" (22.020-22.041 mm)1.
	Rocker shaft OD			.8656-.8661" (21.987-22.0 mm)
	Rocker shaft Oil Clearance		Std	.0008-.0021" (.020-.054 mm)
			Limit	.0039" (.10 mm)
Camshaft	Cam lobe height	In	Std	1.2884-1.2924" (32.726-32.826 mm)
			Limit	1.2766" (32.426 mm)
		Ex	Std	1.2884-1.2924" (32.726-32.826 mm)
			Limit	1.2766" (32.426 mm)
	Camshaft journal OD		Mag	1.4935-1.4941" (37.935-37.950 mm)
			PTO	1.4935-1.4941" (37.935-37.950 mm)
	Camshaft journal bore ID		Mag	1.4963-1.4970" (38.005-38.025 mm)
			PTO	1.4963-1.4970" (38.005-38.025 mm)
	Camshaft Oil clearance		Std	.0022-.0035" (.055-.090 mm)
			Limit	.0039" (.10 mm)
Cylinder Head	Surface warpage limit			.0020" (.05 mm)
	Standard height			3.870" (98.3 mm)
Valve Seat	Contacting width	In	Std	.028" (.7 mm)
			Limit	.055" (1.4 mm)
		Ex	Std	.039" (1.0 mm)
			Limit	.071" (1.8 mm)
Valve Guide	Inner diameter			.2362-.2367" (6.0-6.012 mm)
	Protrusion above head			.689-.709" (17.5-18.0 mm)
Valve	Margin thickness	In	Std	.039" (1.0 mm)
			Limit	.031" (.8 mm)
		Ex	Std	.047" (1.2 mm)
			Limit	.031" (.8 mm)
Valve	Stem diameter		In	.2343-.2348" (5.950-5.965 mm)
			Ex	.2341-.2346" (5.945-5.960 mm)
	Stem oil clearance	Std	In	.0014-.0024" (.035-.062 mm)
			Ex	.0016-.0026" (.040-.067 mm)
		Limit	.0059" (.15 mm)	
	Overall length		In	3.976" (101.0 mm)
Ex			3.984" (101.2 mm)	
Valve Spring	Free length		Std	1.654" (42.0 mm)
			Limit	1.575" (40.0 mm)
	Squareness			.075" (1.9 mm) 2.5°

ENGINE

Service Data

ES33PFE01 / 02 Engine Service Data

Cylinder / Piston / Connecting Rod				ES33PFE01	
Cylinder	Surface warpage limit (mating with cylinder head)			.0020" (.05 mm)	
	Cylinder bore		Std	3.0732-3.0740" (78.000-78.020 mm)	
	Taper limit			.002" (.05 mm)	
	Out of round limit			.002" (.05 mm)	
	Piston clearance		Std	.0012-.0035" (.030-.090 mm)	
			Limit	.0043" (.11 mm)	
Boring limit			.020" (.5 mm)		
Piston	Outer diameter		Std	3.0704-3.0720" (77.93-77.97 mm)	
			.0098" (.25 mm) OS	3.0803-3.0819" (78.18-78.22 mm)	
			.0197" (.50 mm) OS	3.0901-3.0917" (78.43-78.47 mm)	
	Standard inner diameter of piston pin bore			.9055-.9057" (23.0-23.006 mm)	
Piston Pin	Outer diameter			.9053-.9055" (22.994-23.0 mm)	
	Standard clearance-piston pin to pin bore			.0002-.0003" (.004-.008 mm)	
	Degree of fit			Piston pin must be fitted into position with thumb at 68° F (20° C)	
Piston Ring	Piston ring installed gap	Top ring	Std	.0079-.0138" (.20-.36 mm)	
			Limit	.039" (1.0 mm)	
		Second ring	Std	.0138-.0197" (.35-.50 mm)	
			Limit	.039" (1.0 mm)	
		Oil ring	Std	.0079-.0276" (.20-.70 mm)	
			Limit	.059" (1.5 mm)	
Piston Ring	Standard clearance - piston ring to ring groove	Top ring	Std	.0014-.0030" (.035-.075 mm)	
			Limit	.0059" (.15 mm)	
		Second ring	Std	.0010-.0026" (.025-.065 mm)	
			Limit	.0059" (.15 mm)	
Connecting Rod	Connecting rod small end ID			.9058-.9063" (23.007-23.020 mm)	
	Connecting rod small end radial clearance		Std	.0003-.0010" (.007-.026 mm)	
			Limit	.0020" (.05 mm)	
	Connecting rod big end side clearance		Std	.0039-.0256" (.1-.65 mm)	
			Limit	.0315" (.80 mm)	
	Connecting rod big end radial clearance		Std	.0004-.0015" (.011-.038 mm)	
		Limit	.0020" (.05 mm)		
Crankshaft	Crankshaft runout limit			.0024" (.06 mm)	

KEY - Std: Standard; OS: Oversize; ID: Inner Diameter; OD: Outer Diameter; Mag: Magneto Side; PTO: Power Take Off Side

EH42PLE02 / EH50PLE04, 06, 08, 09 Engine Service Data

Cylinder Head / Valve				EH42PLE-01	EH50PLE-01	
Rocker Arm	Rocker arm ID			.8669-.8678" (22.020-22.041 mm)1.	.8669-.8678" (22.020-22.041 mm)	
	Rocker shaft OD			.8656-.8661" (21.987-22.0 mm)	.8656-.8661" (21.987-22.0 mm)	
	Rocker shaft Oil Clearance		Std	.0008-.0021" (.020-.054 mm)	.0008-.0021" (.020-.054 mm)	
			Limit	.0039" (.10 mm)	.0039" (.10 mm)	
Camshaft	Cam lobe height	In	Std	1.2884-1.2924" (32.726-32.826 mm)	1.2884-1.2924" (32.726-32.826 mm)	
			Limit	1.2766" (32.426 mm)	1.2766" (32.426 mm)	
		Ex	Std	1.2884-1.2924" (32.726-32.826 mm)	1.2884-1.2924" (32.726-32.826 mm)	
			Limit	1.2766" (32.426 mm)	1.2766" (32.426 mm)	
	Camshaft journal OD		Mag	1.4935-1.4941" (37.935-37.950 mm)	1.4935-1.4941" (37.935-37.950 mm)	
			PTO	1.4935-1.4941" (37.935-37.950 mm)	1.4935-1.4941" (37.935-37.950 mm)	
	Camshaft journal bore ID		Mag	1.4963-1.4970" (38.005-38.025 mm)	1.4963-1.4970" (38.005-38.025 mm)	
			PTO	1.4963-1.4970" (38.005-38.025 mm)	1.4963-1.4970" (38.005-38.025 mm)	
	Camshaft Oil clearance		Std	.0022-.0035" (.055-.090 mm)	.0022-.0035" (.055-.090 mm)	
			Limit	.0039" (.10 mm)	.0039" (.10 mm)	
Cylinder Head	Surface warpage limit			.0020" (.05 mm)	.0020" (.05 mm)	
	Standard height			3.870" (98.3 mm)	3.870" (98.3 mm)	
Valve Seat	Contacting width	In	Std	.028" (.7 mm)	.028" (.7 mm)	
			Limit	.055" (1.4 mm)	.055" (1.4 mm)	
		Ex	Std	.039" (1.0 mm)	.039" (1.0 mm)	
			Limit	.071" (1.8 mm)	.071" (1.8 mm)	
Valve Guide	Inner diameter			.2362-.2367" (6.0-6.012 mm)	.2362-.2367" (6.0-6.012 mm)	
	Protrusion above head			.689-.709" (17.5-18.0 mm)	.689-.709" (17.5-18.0 mm)	
Valve	Margin thickness	In	Std	.039" (1.0 mm)	.039" (1.0 mm)	
			Limit	.031" (.8 mm)	.031" (.8 mm)	
		Ex	Std	.047" (1.2 mm)	.047" (1.2 mm)	
			Limit	.031" (.8 mm)	.031" (.8 mm)	
Valve	Stem diameter		In	.2343-.2348" (5.950-5.965 mm)	.2343-.2348" (5.950-5.965 mm)	
			Ex	.2341-.2346" (5.945-5.960 mm)	.2341-.2346" (5.945-5.960 mm)	
	Stem oil clearance		Std	In	.0014-.0024" (.035-.062 mm)	.0014-.0024" (.035-.062 mm)
				Ex	.0016-.0026" (.040-.067 mm)	.0016-.0026" (.040-.067 mm)
			Limit	.0059" (.15 mm)	.0059" (.15 mm)	
	Overall length		In	3.976" (101.0 mm)	3.976" (101.0 mm)	
Ex			3.984" (101.2 mm)	3.984" (101.2 mm)		
Valve Spring	Overall length		Std	1.654" (42.0 mm)	1.654" (42.0 mm)	
			Limit	1.575" (40.0 mm)	1.575" (40.0 mm)	
	Squareness			.075" (1.9 mm)	.075" (1.9 mm)	

ENGINE

Service Data


EH42PLE02 / EH50PLE04, 06, 08, 09 Engine Service Data

Cylinder / Piston / Connecting Rod				EH42PL	EH50PL	
Cylinder	Surface warpage limit (mating with cylinder head)			.0020" (.05 mm)		
	Cylinder bore		Std	3.4606-3.4614" (87.900-87.920 mm)		
	Taper limit			.0020" (.050 mm)		
	Out of round limit			.0020" (.050 mm)		
	Piston clearance		Std	.0006-.0018" (.015-.045 mm)		
			Limit	.0024" (.060 mm)		
Boring limit			.020" (.5 mm)			
Piston	Outer diameter		Std	3.4596-3.4600" (87.875-87.885 mm)		
			.0098" (.25 mm) OS	3.4695-3.4699" (88.125-88.135 mm)		
			.0197" (.50 mm) OS	3.4793-3.4797" (88.375-88.385 mm)		
	Standard inner diameter of piston pin bore			.9055-.9057" (23.0-23.006 mm)		
Piston Pin	Outer diameter			.9053-.9055" (22.994-23.0 mm)		
	Standard clearance-piston pin to pin bore			.0002-.0003" (.004-.008 mm)		
	Degree of fit			Piston pin must be a push (by hand) fit at 68° F (20° C)		
Piston Ring	Piston ring installed gap		Top ring	Std	.0079-.0138" (.20-.36 mm)	
				Limit	.039" (1.0 mm)	
			Second ring	Std	.0079-.0138" (.20-.36 mm)	
				Limit	.039" (1.0 mm)	
			Oil ring	Std	.0079-.0276" (.20-.70 mm)	
				Limit	.059" (1.5 mm)	
Piston Ring	Standard clearance - piston ring to ring groove		Top ring	Std	.0016-.0031" (.040-.080 mm)	
				Limit	.0059" (.15 mm)	
			Second ring	Std	.0012-.0028" (.030-.070 mm)	
				Limit	.0059" (.15 mm)	
Connecting Rod	Connecting rod small end ID			.9058-.9063" (23.007-23.020 mm)		
	Connecting rod small end radial clearance		Std	.0003-.0010" (.007-.026 mm)		
			Limit	.0020" (.05 mm)		
	Connecting rod big end side clearance		Std	.0039-.0256" (.1-.65 mm)		
			Limit	.0315" (.80 mm)		
	Connecting rod big end radial clearance		Std	.0004-.0015" (.011-.038 mm)		
Limit			.0020" (.05 mm)			
Crankshaft	Crankshaft runout limit			.0024" (.06 mm)		

KEY - Std: Standard; OS: Oversize; ID: Inner Diameter; OD: Outer Diameter; Mag: Magneto Side; PTO: Power Take Off Side


ENGINE Cooling System

WARNING: Never remove radiator cap when engine is warm or hot. The cooling system is under pressure and serious burns may result. Allow the engine and cooling system to cool before servicing.



Bleed Hole Inspection

When coolant is added, air is purged through a bleed hole at the top between the two halves (see illustration above). If there is difficulty bleeding the cooling system or if overheating problems are encountered, remove the radiator cap and inspect to see if the bleed hole is clear.



System Pressure Test


1. Remove radiator cap access panel from front of headlamp housing.
2. Remove recovery bottle hose from radiator.
3. Connect a Mity Vac™ (PN 2870975) to radiator and pressurize system to 10 PSI. The system must retain 10 lbs of pressure for five minutes or longer. If pressure loss is evident within five minutes, check radiator, all cooling system hoses and clamps, or water pump seal.

Radiator Cap Pressure Test

1. Remove radiator cap and test using a cap tester (commercially available).
2. The radiator cap relief pressure is 13 lbs. for all models.


ENGINE

Cooling System



Recommended Coolant

Use only high quality antifreeze/coolant mixed with *distilled* water in a 50/50 or 60/40 ratio, depending on freeze protection required in your area. **CAUTION:** Using tap water in the cooling system will lead to a buildup of deposits which may restrict coolant flow and reduce heat dissipation, resulting in possible engine damage. Polaris Premium 60/40 Antifreeze/Coolant is recommended for use in all cooling systems, and comes pre-mixed and ready to use.



Cooling System Specifications

	250/300	Scrambler and Sport	Liquid Cooled Except Scrambler and Sport
Fan Switch (Off)	210° F (99° C) ± 10°	154° F (68° C) ± 5°	175° F (79° C) ± 5°
Fan Switch (On)	235° F (113° C)	174° F (79° C)	190° F (88° C)
Hot Light On - 4 Strokes	-	-	221° F (105° C)
Hot Light On - 2 Strokes	-	205° F (96° C)	205° F (96° C)
System Capacity	-	2.25 Quarts	2.25 Quarts
Radiator Cap Relief Pressure	-	13 PSI	13 PSI

Accessible Components - All Models

The following components can be serviced or removed with the engine installed in the frame:

- S Flywheel
- S Alternator/Stator
- S Starter Motor/Starter Drive
- S Cylinder Head
- S Cylinder
- S Piston/Rings
- S Oil pump (250 / 400)
- S Counterbalance Shaft or Bearing(s) (400 engines)
- S Camshaft (4 Strokes)
- S Rocker Arms
- S Cam Chain and Sprockets (4 Strokes)
- S Water Pump / Water Pump Mechanical Seal*

The following components require engine removal for service:

- S Oil pump / Oil Pump Drive Gear (300, 335, 425, 500)
- S Counterbalance Shaft or Bearing(s) (4 Cycle engines)
- S Connecting Rod
- S Crankshaft
- S Crankshaft Main Bearings
- S Crankcase

*It may be necessary to loosen engine mounts and move engine slightly to access water pump on some 4 stroke models. Special tool PN 2872105 is required to replace mechanical seal with engine in frame.

ENGINE

Engine Removal

Engine Removal (Typical)

1. Clean work area.
2. Thoroughly clean the ATV engine and chassis.
3. Disconnect battery negative (-) cable.
4. Remove the following parts as required, depending on model.
 - § Seat
 - § Left and Right Side Covers (Gen II and Gen IV)
(Refer to Chapter 5)
 - § Fuel Tank Cover / Front Cab (Refer to Chapter 5)
 - § Fuel Tank (Refer to Chapter 4)
5. Disconnect oil pump cable.
6. Disconnect spark plug high tension lead.
7. Remove springs from exhaust pipe and remove pipe.
8. Drain coolant and engine oil (where applicable).
9. Remove air pre-cleaner and duct.
10. Remove airbox.
11. Remove carburetor. Insert a shop towel into the carburetor flange to prevent dirt from entering the intake port.
12. Loosen auxiliary brake master cylinder mount, if necessary for clearance.
13. Remove center chain guard on chain drive AWD models.
14. Remove center drive and driven sprocket bolts and remove chain and sprockets as an assembly.
15. Refer to PVT System to remove outer clutch cover, drive belt, drive clutch, driven clutch, and inner cover.
16. Starter motor. Note ground cable location. Mark positive (+) cable mounting angle and remove cable.
17. Remove transmission linkage rod(s) from gear selector and secure out of the way.
18. Disconnect coolant temperature sensor wire (where applicable).
19. Remove engine to chassis ground cable (where applicable).
20. Remove all engine mount nuts and / or engine mount plates.
21. Remove engine through right side of frame.

Engine Installation Notes

After the engine is installed in the frame, review this checklist and perform all steps that apply.

General Items

1. Install previously removed components using new gaskets, seals, and fasteners where applicable.
2. Perform regular checks on fluid levels, controls, and all important areas on the vehicle as outlined in the daily pre-ride inspection checklist (refer to Chapter 2 or the Owner's Safety and Maintenance Manual).

PVT System

1. Adjust center distance of drive and driven clutch. (Chapter 6)
2. Adjust clutch offset, alignment, and belt deflection. (Chapter 6)
3. Clean clutch sheaves thoroughly and inspect inlet and outlet ducts for proper routing and sealing. (Chapter 6)

Transmission

1. Inspect transmission operation and adjust linkage if necessary. Refer to Chapter 2 and Chapter 8.

Exhaust

1. Replace exhaust gaskets. Seal connections with high temp silicone sealant.
2. Check to be sure all springs are in good condition.

Bleed Cooling System

1. Remove radiator cap and slowly add coolant to top of filler neck.
2. Fill coolant reservoir tank to full mark.
3. Loosen bleed screw at top of cylinder head (400) until all air is purged from engine. Tighten bleed screw.
4. Install radiator cap and squeeze coolant lines to force air out of system.
5. Again remove radiator cap and slowly add coolant to top of fill neck.
6. Start engine and observe coolant level in the radiator. Allow air to purge and top off as necessary. Reinstall radiator cap and bring engine to operating temp. Check level in reservoir tank after engine is cool and add coolant if necessary.

Engine Break In Period - 2 Cycle

2 Cycle Engine Break-In Period is defined as the first 3 hours of engine operation, or one full tank of fuel.

1. (2 - Cycle) Pre-mix the first FULL tank of fuel at a 40:1 ratio with Polaris Premium 2 Cycle Lubricant.
2. Fill the oil tank with Polaris injection oil. Never substitute or mix oil brands. Serious engine damage can result.
3. Bleed oil pump thoroughly. Refer to Chapter 2.
4. Verify proper oil usage from oil tank during the first tank of fuel. Instruct operator to observe oil level in tank during the first tank of fuel. If the level has not dropped, repeat the oil pump bleeding procedure, fill the tank with pre-mix, and investigate problem (oil tank vent or supply line restriction, pump problem, etc.).
5. Avoid prolonged idle, heavy loads, or periods of sustained full throttle. Use low gear if available. Vary throttle settings during the break in period.

Engine Break In Period - 4 Cycle

4 Cycle Engine Break-In Period is defined as the first 10 hours of engine operation, or 2 full tanks of fuel.

1. Use only Polaris Premium 4 All Season synthetic oil, or API certified "SH" oil. Never substitute or mix oil brands. Serious engine damage can result.
2. Use fuel with a minimum octane of 87 (R+M)/2 method.
3. Change break-in oil and filter at 20 hours or 500 miles, whichever comes first.

ENGINE

EC25PF/EC28PF Engine

Disassembly

NOTE: Inspect all parts during disassembly as outlined on page 3.35-3.40.

1. Remove the flywheel nut and flywheel with puller (PN 2871043). Mark position of stator plate on crankcase, remove stator plate screws and stator assembly.


Flywheel Puller
PN 2871043

Flywheel Holder
PN 8700229



2. Remove cylinder head and cylinder. Remove piston pin clips. Use Piston Pin Puller to remove piston pin from piston.
3. Refer to Top End Component Parts Inspection on page 3.36-3.39 to inspect cylinder, piston, rings and connecting rod small end bearing.

Piston Pin Puller
PN 2870386



4. Remove the crankcase half attaching bolts. Heat crankcase in the bearing support areas. After applying heat, tap on PTO end and magneto end to separate case half from crankshaft.
5. After removing the crankshaft, thoroughly clean the bearings and lubricate. Check the crankshaft runout as outlined in Crankshaft Inspection procedure on page 3.40.



Disassembly, cont.

Connecting Rod Side Clearance

1. Measure clearance between lower rod and counterweight with a feeler gauge (connecting rod big end side clearance). New measurement should be between .016"-.020" (.4-.5 mm). Clearance should not exceed .036" (.9mm).



Crankshaft Main Bearing Inspection

1. Clean crankshaft thoroughly and oil main and connecting rod bearings with Polaris Premium 2 engine oil. Carefully check each main bearing on the shaft.

NOTE:Due to extremely close tolerances, the bearings must be inspected visually, and by feel. Look for signs of discoloration, scoring or galling. Turn the outer race of each bearing. The bearings should turn smoothly and quietly. The inner race of each bearing should fit tightly on the crankshaft. The outer race should be firm with minimal side to side movement and no detectable up and down movement. Replace any loose or rough bearings.

Refer to crankshaft inspection on page 3.40.

ENGINE

EC25PF/EC28PF Engines

Engine Assembly


Before reassembling the crankcase, the following steps should be performed to determine the amount of crankshaft end play. Excessive end play will cause the engine to be noisy at idle and slow speeds. Too little end play will side load the main bearings, which may cause premature bearing failure.

Measure Crankshaft Width - Bearings Installed


1. Measure distance from outer edge of PTO end bearing race to outer edge of mag side bearing race. Record measurement.

If bearings and spacers are already installed, measure distance as shown in photo at right, then proceed to Step 5.

or...



If PTO end bearings have not yet been installed, measure distance as shown in photo at right, then proceed to Step 2.




2. Measure distance from crank wheel to bearing seating surface (A). Record measurement.





Assembly, Cont.

3. Measure total width of main bearings with bearings. Add the thickness of the spacer between the bearings on EC28 engines. Record total measurement.
4. Add all recorded measurements from Steps 1, 2, and 3 and record the total on line A below. If PTO bearings were assembled on crankshaft, record the measurement from Step 1.



5. Measure PTO crankcase half as shown to determine depth of case. Place a piece of flat stock on the case mating surface and measure from this surface to the bearing seating surface. Subtract thickness of flat stock and record the measurement on line B below.
6. Measure magneto side case half using the same procedure. Record measurement on line C below. (Remember to subtract thickness of flat stock.)
7. Add the readings from steps 5 and 6 and record on line D. Subtract line A from line D. The result is the amount of crankshaft end play.
8. If adjustment is required, determine the amount of spacers needed to achieve proper end play. Install spacers on crankshaft followed by PTO bearings.



Total from Step 1, 2, and 3. (or from Step 1 only if PTO bearings were installed). (A) _____
Step 5 Result (B) _____
Step 6 Result (C) _____
Line B + Line C = (D) _____
Line D - Line A = End Play _____
Subtract Target End Play - .012" (.3mm) _____
Shim Thickness Required = _____

Correct crankshaft end play is .008" - .016" (.2 - .4 mm). End play is adjusted by adding or subtracting spacer washers from between the inner PTO end bearing and the crank wheel. Two different thickness spacers are available for EC 25 and EC28 engines:

For EC25PF - PN 3083629 - .008" (.2 mm); and PN 3083630 - .004" (.1 mm).


For EC28PF and EC38PL - PN 3084778 - .008" (.2 mm); and PN 3084779 - .012" (.3 mm).

ENGINE


EC25PF/EC28PF Engines

Assembly, Cont.

9. Remove crankcase end seals and thoroughly clean the case half mating surfaces.
10. Heat PTO side case half until it is hot to the touch.
11. Reinstall crankshaft into heated case. Allow case to cool to room temperature before proceeding.




12. Heat mag side case half until it is hot to the touch.
13. Place Loctite 518 gasket eliminator on one of the case halves.
14. Reinstall the mag side half.
15. Torque case half attaching bolts in three steps to torque specified on page 3.1. Follow the torque pattern shown on page 3.3.




NOTE: Before proceeding, check piston to cylinder clearance, ring end gap and cylinder honing procedures on page 3.36 - 3.38.

16. Install piston rings, beveled side up, onto piston. Keystone rings are beveled to the inside. This bevel must be toward the top of the piston (letter and/or number marks near end gap of ring face upward).



Assembly, Cont.

17. Position C clip onto driver of C-clip installation tool (PN 2870773) with open end down. Slide portion of tool barrel over driver.
 18. Install guide pin at the driver into the piston pin and position the barrel up against the piston. While holding the barrel against the piston, push the driver in until you hear the clip engage into the piston groove.
 19. Rotate driver to complete engagement of clip.
 20. Visually inspect the C-clip to be sure it is fully seated in the groove.
 21. Reinstall piston onto rod with "F" mark or → toward the magneto side of the engine. Support with support block.
 22. Lubricate piston pin and pin bearing with 2 Stroke oil.
 23. Reinstall piston pin. Warm piston crown lightly with heat gun to ease pin installation.
- CAUTION:** Do not overheat piston. Do not apply heat to piston rings or loss of temper may result.
24. Repeat Step 17 through 20 for other C-clip.




ENGINE

EC25PF/EC28PF Engines

Assembly, Cont.


25. Apply Loctite No. 518 Gasket Eliminator to both sides of the cylinder base gasket. Install the base gasket and cylinder. Torque the cylinder base nuts in 3 steps to 28 ft. lbs. (3.9 kg-m). Install the head gasket and head. Torque nuts to 20 ft. lbs. (2.8 kg-m) following pattern on page 3.2.




When installing base gasket use gasket eliminator no. 518 on both sides of the base gasket.

Oil check valve should release as specified below.

1. Reinstall stator plate and align timing marks. Refer to Electrical Chapter 10 for dynamic ignition timing.
2. Reinstall flywheel.
3. Reinstall magneto housing.
4. Torque flywheel bolt to specification found on page 3.1.
5. Reinstall recoil starter assembly.



6. Seal wire harness grommet to crankcase using RTV silicone sealant.
7. Refer to electrical section of this manual for starter motor inspection. Reinstall starter motor.



Assembly

Oil Pump End Play Adjustment


The oil pump is a positive displacement type pump. Whenever the oil pump, oil pump bushing, or crankcase are replaced, the end play clearance must be checked. Target clearance is .008-.024" (.2-.6mm) between the oil pump boss and the bushing in the crankcase. Symptoms of excessive gear end play include: noticeable engine noise at idle; pump lever arm binds in the 1/2 open position (will release when engine is rotated).

NOTE:Some 250/300 cc ATV engine oil pumps were produced with a plastic oil pump drive gear (PN 3084825). The plastic drive gear is no longer available and subs to a metal drive gear (PN 3083429). If you are replacing a plastic drive gear with a metal one, you must also order and install thrust washer (PN 3083428). If you install the metal drive gear without the thrust washer you will not be able to achieve the proper drive gear end play as outlined below. Refer to the Illustration on page 3.22

250/300 Models

Refer to Illustration on following page.

1. Lubricate and install pump drive gear thrust washer, pump drive gear, and bushing into crankcase. Make sure parts are completely seated.
2. Measure the distance from the pump bushing to the crankcase pump mounting surface. Record this as measurement A. Example: 4.8mm (Refer to example below)
3. Measure distance from pump shoulder to pump mounting flange. Record this as measurement B. (Example: 3.9mm Refer to example below)
4. Subtract measurement B (Step 3) from measurement A (Step 2). See example below. The difference between these two measurements is the end play the pump bushings will have without shims. Subtract the target clearance from measured and add shims equal to that amount.



EXAMPLE:	A (Step 2)	4.8	
	B (Step 3)	- 3.9	
		=	.9
	Target clearance	- (.2-.6 mm)	
	Total thickness of shims required	=	.3-.7mm

Spacer shim part numbers:


- PN 3083671 .15 mm/.006"
- PN 3083672 .3 mm/.012"
- PN 3083673 .6 mm/.024"

ENGINE
EC25PF/EC28PF Engine

Assembly



Oil Check Valve Testing (EC25PF)

The oil pump check valve on the EC25PF engine must be tested by applying 2-7 PSI of pressure to the line spigot of the check valve. Use a Mity Vac (PN2870975) or similar tester. The valve should release between 2 and 7 PSI. The check valve is located on the cylinder.




Oil Check Valve Testing (EC28PF)

The oil pump check valve on the EC28PF engine must be tested by applying 3-7 inches of mercury VACUUM to the line spigot of the check valve. The valve should release between 3 and 7 inches of mercury. Use a Mity Vac (PN2870975) or similar vacuum tester. The check valve is located on the oil pump.




Recoil Disassembly

1. Remove four 6mm bolts securing reel housing to flywheel housing. **NOTE:** When the last bolt is removed, the reel housing will rotate, unwinding the recoil spring.
2. Remove reel housing. **NOTE:** If rope replacement is the only service necessary, it may be replaced without any further disassembly.
3. Remove pawl return spring.
4. Clamp sides of ratchet pawl bracket in the corner of the jaws of a vise.
5. Using a cloth belt type strap wrench wrapped around the outside edge of the reel, unscrew the reel counterclockwise to remove it from the ratchet pawl bracket shaft.
6. Remove the ratchet pawl bracket, spring hook, ratchet friction ring and friction spring. **NOTE:** It is not necessary to remove the spring retainer plate and spring unless it is damaged.
7. Clean and inspect all parts. Repair or replace as required.



1. Flywheel Housing
2. Reel
3. Recoil Spring
4. Spring Retaining Plate
5. Seal
6. Spring Hook
7. Ratchet Pawl
8. Pawl Pin
9. Ratchet Friction Ring and Pawl Guide
10. Friction Spring
11. Ratchet Pawl Bracket
12. Reel Housing
13. Pawl Return Spring
14. Recoil Rope
15. Rope Handle
16. Recoil Cup
17. Timing Plug
18. Bushing



ENGINE


EC25PF Engine

Recoil Assembly

1. If the recoil spring was removed, reinstall it in its recess in the flywheel housing. The spring should spiral counterclockwise toward the center.
2. Grease spring with Polaris low temperature grease.
3. Install recoil spring retaining plate.
4. Grease and install spring hook, making sure it properly engages the spring end.
5. Install ratchet friction ring and friction spring assembly. The friction spring should engage the bent tab on the recoil spring retaining plate. The "L" on the friction ring should be positioned as shown in the photo at right.
6. Grease the center hole and seal in the flywheel housing.
7. Install ratchet pawl bracket. The alignment pin and the square drive on the bracket shaft should properly align in the spring hook.
8. While holding the bracket tight against the spring hook, flip the flywheel housing over and thread the reel onto the pawl bracket shaft.
9. Clamp the ratchet pawl bracket in the corner of the jaws of a vise. Firmly hand tighten the reel.
10. If the rope was removed, or if a new rope is being installed, attach one end of the rope to the reel, pass the other end of the rope through the guide in the reel housing and attach it to the rope handle.
11. Install the rope housing over the reel.
12. Holding the flywheel housing with one hand, rotate the rope housing clockwise until the rope is completely re-wound.
13. Rotate the housing three more turns and reinstall bolts.
14. Reinstall pawl return spring.
15. Check recoil and ratchet operation.
16. When reinstalling assembly onto engine, use Loctite 518 Gasket Eliminator between the flywheel housing and crankcase.

Recoil Assembly

1. Pass the free end of recoil rope through the reel housing.
2. Holding the flywheel housing with one hand, rotate the reel clockwise until the rope is completely re-wound.
3. Rotate the housing three more turns and install the pawl return spring with the large end of the spring going into rope housing; reinstall retainer plate, lock washer and bolt.
4. Check recoil and ratchet operation.
5. When reinstalling assembly onto engine, use Loctite 518 Gasket Eliminator between the flywheel housing and crankcase.




ENGINE

EC38PL Engine


Disassembly

1. Remove the six bolts retaining the starter assembly and flywheel cover.
2. Remove starter pulley and flywheel nut.
3. Hold flywheel with holder tool and remove flywheel nut.

Flywheel Holder PN 8700229



4. For starter removal, remove bolts retaining starter bracket on PTO side, and two bolts (A) on mag side.



5. Remove flywheel using puller.

Flywheel Puller PN 2871043



Disassembly, Cont.

6. Remove stator assembly.

Reassembly Note: During reassembly be sure to seal rubber grommet (A) completely with silicone sealer to avoid water or dirt ingestion into stator assembly.


150 Watt alternator shown at right.



200 Watt alternator shown at right.



7. Remove six cylinder head bolts using a 12 mm socket. Note the position of the bleeder plug for the coolant system.



ENGINE


EC38PL Engine

Disassembly, Cont.

Reassembly Note: The head gasket should have the word *UP* (B) toward the cylinder head and the tab (C) toward the exhaust, matching the tab area on the cylinder.


400L Head Gasket pictured at right.

NOTE: Small hole in cylinder above exhaust port is a decompression aid for starting.




8. Remove oil line from intake boot.
9. Loosen clamps retaining coolant transfer hose and remove the four cylinder nuts. **NOTE:** Use a 14 mm socket on the exhaust side. A 14 mm wrench will be necessary on the intake side.
10. Remove cylinder.
11. Refer to page 3.35-3.40 to inspect parts.

Reassembly Note: Due to limited clearance, a torque adaptor must be used to apply specified torque to base nuts upon reassembly.




12. Install piston support block and remove C clips.
Reassembly Note: When reinstalling C clips, make sure that the open end of the retainer clip points either up or down, not to the side.
13. Remove piston pin using Polaris piston pin puller (PN 2870386).
14. Refer to page 3.35-3.40 to inspect parts.



Disassembly, Cont.

15. Remove slotted *left hand thread* crankshaft nut using Polaris tool (PN 2870967).


Reassembly Note: Refer to page 3.1 for torque specification upon reassembly.



16. Remove five crankcase bolts (A) indicated in the photo at right with a 12 mm socket.

17. Remove four nuts and two bolts (B) indicated in the photo at right with a 10 mm socket.


18. Remove cover, tapping lightly with a soft face hammer if necessary.



19. Using a 10 mm socket, remove the impeller nut (C).

20. Slide water pump assembly from counterbalance assembly.

Reassembly Note: Watch for adjuster shims which may be between the impeller and pump housing. Make sure to reinstall any shims removed. Apply Loctite 242™ to impeller nut.



ENGINE

EC38PL Engine

Disassembly, Cont.

21. Remove collar, O-ring, guide washer and crankshaft gear.

22. Remove oil pump assembly (D).

23. Remove two bolts securing the counter balance retaining bracket (A) using a 10 mm socket.
CAUTION: Complete Step 20 and 21 before removing the counterbalance assembly, or damage may result.

24. Attach counterbalance puller (B) onto counter balance shaft and position as shown in the photo at right.

Reassembly Note: The retainer bracket must be in position on the counterbalance assembly before the assembly is installed in the crankcase. Punch marks (C) on both gears must be across from each other during reassembly. See photo three at right.

Counter Balance Puller





PN 2870968

25. Heat counter balance bearing areas (D) and (E) on the crankcase with a heat gun for approximately one to two minutes.

WARNING: Oil and gasoline are highly flammable and explosive under certain conditions. Use extreme caution when using a heat gun or propane torch in this environment.

26. Once these areas are thoroughly heated, add tension to the puller by turning the large nut. Continue tensioning the puller until the counterbalance assembly is completely removed.


Reassembly Note - Counter Balance Shaft: For reassembly of counterbalancer shaft after crankcase assembly, heat areas (D) and (E) and press the balancer and bracket back into place.



Disassembly, Cont.

27. Remove crankcase bolts.

28. Tap cases apart with a soft faced hammer.



ENGINE

EC38PL Engine

Connecting Rod Side Clearance

29. Remove crankshaft. Inspect connecting rod side clearance.
30. Measure clearance between lower rod and counterweight with a feeler gauge (connecting rod big end side clearance). New measurement should be between .016"-.020" (.4-.5 mm). Clearance should not exceed .036" (.9mm).

Connecting Rod Side Clearance:	
Standard	.016"-.020" (.4-.5mm)
Service Limit	.036" (.9mm)




Connecting Radial Clearance

31. Measure the total movement of the connecting rod big end bearing. Movement should not exceed .0013" (.033mm).
32. Remove seals from crankcase.
33. Clean crankcase thoroughly and install new seals until flush with edge of seal bore.

Reassembly Notes:


1. Before assembling the crankcase, calculate crankshaft end play and place shims between as required. Follow procedure on page 3.16 - 3.17.




Refer to page 3.40 for crankshaft inspection.

Reed Valve Inspection

1. Measure reed stop height (A). Recommended stop height is .350" (9 mm).




2. Measure the air gap of each reed valve petal with a feeler gauge (B) as shown in the photo at right. The air gap should not exceed .015" (.4 mm).
NOTE: An early sign of reed valve failure may be hard starting, and poor low-end performance.
3. Check each reed valve petal for white stress marks or missing material. Replace if necessary.



Water Pump Impeller Clearance

Whenever the counterbalance assembly is removed it will be necessary to verify impeller clearance. Following is a recommended procedure for measuring water pump impeller clearance.

1. Apply a small amount of putty or clay to the top of one impeller blade (A).
2. Assemble impeller and bearing/seal housing on balancer shaft.





ENGINE

EC38PL Engine

Water Pump Impeller Clearance, cont.

- Reinstall case gasket and bolt case together in areas (B) and (C) as indicated on the photo at right.
- Carefully remove case cover.
- Remove water pump impeller and check clearance measurement. Acceptable clearance measured with a dial caliper is between .020" - .040" (.05 - .1 cm). **CAUTION:** If the clearance is less than .020" (.05 cm) the impeller may grind against the case. If the clearance is more than .040" (.1 cm) the water pump may cavitate and cause overheating.
- The photo at right illustrates checking clearance measurement with a dial caliper. A feeler gauge can also be used to check thickness by removing half of the putty or clay from the impeller blade.




Impeller Spacer shim part numbers:

- PN 3084188 0.1 mm/.004"
- PN 3084189 0.2 mm/.008"

The illustration depicts correct positioning of the seals. The water seal is identified by counting the number of sealing "lips". It is a triple lip seal and has a protruding edge that faces away from the spring.

The oil seal is a double lip variety. The lip (on the spring end) angles back toward the spring. The spring end of the seals (open side) must face the oil or coolant as shown in the illustration.


To assemble the pump casing, press the bearing into the casing until *flush* with the casting. Note: *Do not* press the bearing in until it seats against the shoulder, or the oil hole will be covered by the bearing outer race. Next, press the oil seal into the seal bore until the weep hole is visible. Now press the water seal in until flush with the outer edge of the seal bore.



Top End Component Parts Inspection (2 Stroke Engines)**Assembly****Oil Check Valve Testing (EC38PL)**

The oil pump check valve on the EC38PL engine must be tested by applying 2-7 PSI of pressure to the line spigot of the check valve. Use a Mity Vac (PN2870975) or similar tester. The valve should release between 2 and 7 PSI. The check valve is located on the cylinder.

NOTE: Refer to page 3.22 for check valve testing on 250 and 300cc engines.



ENGINE


Piston/Cylinder Clearance (2 Strokes)

Cylinder Inspection/M Measurement

CAUTION

Careless handling of the cylinder, pistons or rings may cause irreparable damage. Handle these parts with care. Do not damage the gasket surfaces during the cleaning operation.

Inspect cylinder for wear, scratches, or damage. If no damage is evident, measure cylinder for taper and out of round with a telescoping gauge and micrometer or a dial bore gauge. Measure bore $1/2''$ down from top of cylinder in two directions - in line with piston pin and 90° to the pin to determine if bore is out-of-round. Repeat measurements at bottom of cylinder to determine taper or out of round. Record all measurements.




Piston Inspection/M Measurement (2 Stroke)

1. Check piston for scoring or cracks in piston crown or pin area. Excessive carbon buildup below the ring lands is an indication of piston, ring or cylinder wear.
2. Measure piston outside diameter at a point 10 mm ($3/8''$) up from bottom of skirt at a 90° angle to the direction of the piston pin. Record the measurement.

NOTE: The piston must be measured at this point to provide accurate piston-to-cylinder clearance measurement.

3. Subtract this measurement from the maximum cylinder measurement recorded previously. If clearance exceeds the service limit, determine if piston or cylinder is worn (calculate clearance with a new piston) and recondition the cylinder or replace piston as necessary. Refer to page 3.4 for piston to cylinder clearance specifications.





Piston Ring Installed Gap

1. Position each piston ring 1/2I (1.3 cm) from the top of the cylinder using the piston to push it squarely into place. Measure installed gap with a feeler gauge at both the top and bottom of the cylinder.

NOTE: A difference in end gap between the bottom and top of the cylinder indicates cylinder taper. The cylinder should be measured for excessive taper and out of round. Replace rings if the installed end gap exceeds the service limit. Refer to page 3.4 for specifications.

NOTE: Always check piston ring installed gap after re-boring a cylinder or when installing new rings.

NOTE: Install rings with mark facing UP.



ENGINE

Cylinder Hone Selection/Honing Procedure

Selecting a hone which will straighten as well as remove material from the cylinder is very important. Using a common spring loaded finger type glaze breaker for honing is never advised. Polaris recommends using a rigid hone or arbor honing machine which also has the capability of oversizing.


Cylinders may be wet or dry honed depending upon the hone manufacturer's recommendations. Wet honing removes more material faster and leaves a more distinct pattern in the bore.

CAUTION:

Honing To Oversize

If cylinder wear or damage is excessive, it will be necessary to oversize the cylinder using a new oversize piston and rings. This may be accomplished by either boring the cylinder and then finish honing to the final bore size, or by rough honing followed by finish honing.

For oversize honing always wet hone using honing oil and a coarse roughing stone. Measure the piston (see piston measurement) and rough hone to the size of the piston. Always leave .002 - .003" (.05 - .07 mm) for finish honing. Refer to piston-to-cylinder clearance specifications on page 3.4 before honing. Complete the sizing with fine grit stones to provide the proper cross-hatch finish and required piston clearance.



EXAMPLE OF CROSS HATCH PATTERN

A finished cylinder should have a cross-hatch pattern to ensure piston ring seating and to aid in the retention of the fuel/oil mixture during initial break in. Hone cylinder according to hone manufacturer's instructions, or these guidelines:

- S Use a motor speed of approximately 300-500 RPM, run the hone in and out of the cylinder rapidly until cutting tension decreases. Remember to keep the hone drive shaft centered (or cylinder centered on arbor) and to bring the stone approximately 1/2" (1.3 cm) beyond the bore at the end of each stroke.
- S Release the hone at regular intervals and inspect the bore to determine if it has been cleared, and to check piston fit. **NOTE:** Do not allow cylinder to heat up during honing. The thinner areas of the liner around the ports will expand causing uneven bore.
- S After honing has been completed inspect all port opening areas for rough or sharp edges. Apply a slight chamfer to all ports to remove sharp edges or burrs, paying particular attention to the corners of the intake and exhaust ports.

IMPORTANT:




Cleaning the Cylinder After Honing

It is very important that the cylinder be thoroughly cleaned after honing to remove all grit material. Wash the cylinder in a solvent, then in hot, soapy water. Pay close attention to areas where the cylinder sleeve meets the aluminum casting (transfer port area). Use electrical contact cleaner if necessary to clean these areas. Rinse thoroughly, dry with compressed air, and oil the bore immediately with Polaris 2 Cycle Lubricant.

Connecting Rod Small End Inspection (2 Stroke Engines)

Connecting Rod Small End Bearing Inspection

1. Clean small end of connecting rod and inspect inner bore with a magnifying glass. Look for any surface irregularities including pitting, wear, or dents.
2. Feel the bearing surface inside the rod and check for rough spots, galling, or wear.
3. Clean needle bearing in solvent and dry with compressed air.
4. Inspect needle cage carefully for cracks or shiny spots which indicate wear. Replace needle bearing if worn or cracked, and always replace if piston damage has occurred.
5. Visually inspect piston pin for damage, discoloration, or wear. Feel along the length of the pin and replace it if any rough spots, galling or wear is detected.
6. Oil and install needle bearing and pin in connecting rod. Rotate pin slowly and check for rough spots or any resistance to movement. Slide pin back and forth through bearing while rotating and check for rough spots.
7. With pin and bearing centered in rod, twist ends back and forth in all directions to check for excessive axial play. Pull up and down evenly on both ends of pin to check for radial play. Replace pin *and* bearing if there is any resistance to rotation or excessive axial or radial movement. If play or roughness is evident with a new pin and bearing, replace the connecting rod.



ENGINE

Crankshaft Runout Inspection


Crankshaft Straightening

Lubricate the bearings and clamp the crankshaft securely in the holding fixture. Refer to the illustrations below.


**Crankshaft Alignment Fixture
PN 2870569**

NOTE:The rod pin position in relation to the dial indicator position tells you what action is required to straighten the shaft.

8. To correct a situation like the one shown in the illustration at right, strike the shaft at point A with a brass hammer.




9. To correct a situation like the one shown in the illustration at right, squeeze the crankshaft at point A. (Use tool from alignment kit).



10. If the crank rod pin location is 180° from the dial indicator (opposite that shown above), it will be necessary to spread the crankshaft at position A as shown in the illustration at right. When rebuilding and straightening a crankshaft, runout must be as close to zero as possible.

NOTE:Maximum allowable runout is .0041 (.1 mm) for 2 stroke engines and .0024 for 4 stroke engines.



4 Stroke Engine Service

ENGINE
Notes

Engine Lubrication - ES33PF / EH50PL

Oil Type Polaris Premium 4 Synthetic (PN 2871281); or API certified "SH" 5W30 oil
Capacity Approximately 2 U.S. Quarts (1.9 l)
Filter PN 3084963
Filter Wrench Snap On PN YA997 or equivalent
Drain Plug / Screen Fitting ... 14 ft. lbs. (19 Nm)
Oil Pressure Specification 20 PSI @ 5500 RPM, Polaris 0W/40 Synthetic (Engine Hot)

Oil Pressure Test - ES33PF / EH50PL

1. Remove blind plug on front left cylinder head.
2. Insert a 1/8 NPT oil pressure gauge adaptor into the cylinder head and attach the gauge.
3. Start engine and allow it to reach operating temperature, monitoring gauge indicator.

NOTE: Use Polaris Premium 4 Synthetic Engine Lubricant

**Oil Pressure at 5500 RPM (Engine Hot):
Standard: 20 PSI
Minimum: 12 PSI**

ENGINE

Lubrication/Oil Flow - ES33PF

Oil Flow - ES33PF


The ES33PF engine is equipped with a thermostatically controlled valve that directs oil returning to the tank through a cooler when the oil is hot. Valve operation is described below. The chart on page 3.44 describes the flow of oil through the ES33PF engine and oil cooler. Beginning at the oil tank, the oil flows through a screen fitting in the bottom of the tank and into the oil supply hose. The feed side of the oil pump draws oil through the hose and into the crankcase inlet oil passage, and then pumps the oil through another passage to the one way valve. (Note: The one way valve closes under light spring pressure when the engine is off to prevent oil in the tank from draining into the crankcase. The valve requires very little maintenance). After passing through the one-way valve, oil is pumped through a delivery pipe to the oil filter. If the oil filter is obstructed, a bypass valve contained in the filter allows oil to bypass the filter element.

At this point, the oil is diverted in two directions. Oil is supplied to the camshaft through the left front cylinder stud, and an oil passage in the head. Oil enters the camshaft through the PTO (L) journal. The camshaft journals, cam lobes, and rocker arms are lubricated through holes in the camshaft. The oil lubricates the cam chain and sprocket and drains to the sump.


The other oil path from the filter leads through a delivery pipe to the crankcase main oil gallery, which leads to the stator plate oil passage. Here it passes through the slotted friction bearing (located in the stator plate) into the crankshaft. An oil seal on the stator plate prevents oil from entering the stator/flywheel area. Oil travels through the crankshaft to the crank pin, lubricating the connecting rod large end bearing directly. Oil also passes through an oil jet (drilled orifice) in the end of the crank pin to the PTO end main bearings and counterbalancer gears.

Residual oil from the lubrication of the crankshaft and connecting rod indirectly lubricates the cylinder wall, piston, rings, connecting rod small end bearing, piston pin, oil/water pump drive gears, cam chain and drive sprocket, and Magneto end crankshaft main bearing.


After returning to the engine sump, oil is drawn by the scavenge pump out of the sump and through a screen. Scavenged oil is directed through another crankcase oil passage through the outlet hose to the thermo-valve, and directly back to the oil tank. When the oil reaches a pre-determined temperature, the thermo-valve opens to direct oil through the cooler, and then back to the tank



ENGINE Oil Flow Diagram - ES33PF



335 (ES33PFE) Oil Flow Chart



ENGINE

EH50PL Lubrication/Oil Flow

Oil Flow - EH50PL

The chart on page 3.47 describes the flow of oil through the EH50PL engine. Beginning at the oil tank, the oil flows through a screen fitting in the bottom of the tank and into the oil supply hose. The feed side of the oil pump draws oil through the hose and into the crankcase oil gallery, and then pumps the oil through another passage to the one way valve. (When the engine is off, the one way valve closes to prevent oil in the tank from draining into the crankcase.) The oil is pumped through a delivery pipe to the oil filter. If the oil filter is obstructed, a bypass valve contained in the filter allows oil to bypass the filter element.


At this point, the oil is diverted in two directions. Oil is supplied to the camshaft through the left front cylinder stud, and an oil passage in the head. Oil enters the camshaft through the PTO (L) journal. The camshaft journals, cam lobes, and rocker arms are lubricated through holes in the camshaft. The oil lubricates the cam chain and sprocket and drains to the sump.

The other oil path from the filter leads through a delivery pipe to the crankcase main oil gallery, which leads to the stator plate oil passage. Here it passes through the slotted friction bearing (located in the stator plate) into the crankshaft. An oil seal on the stator plate prevents oil from entering the stator/flywheel area. Oil travels through the crankshaft to the crank pin, lubricating the connecting rod large end bearing directly. Oil also passes through an oil jet (drilled orifice) in the end of the crank pin to the PTO end main bearings and counterbalancer gears.


Residual oil from the lubrication of the crankshaft and connecting rod indirectly lubricates the cylinder wall, piston, rings, connecting rod small end bearing, piston pin, oil/water pump drive gears, cam chain and drive sprocket, and Magneto end crankshaft main bearing.

The one-way valve is located on the front left (PTO) side of the crankcase. The valve prevents oil in the tank from draining into the engine sump when the engine is off. The valve mechanism consists of a plunger, return spring, guide plug, and sealing washer. When the engine is running, oil pressure lifts the plunger off the seat, allowing oil flow. When the engine is off, spring pressure forces the plunger against the oil passage seat, preventing oil flow from the tank to the sump. The one-way valve requires very little maintenance. If engine oil drains into the sump when the engine is off, inspect the valve sealing surface for debris or damage. Inspect the return spring for distortion or damage.

ENGINE EH50PL Oil Flow Diagram




EH50PL Oil Flow Chart




ENGINE

ES33PF Engine Exploded View


Crankcase




Cylinder/ Cylinder Head



Crankshaft and Piston







Valve Train



ENGINE

EH50PL Engine Exploded View



ENGINE

Engine Service - ES33PF / EH50PL

Engine Removal

Refer to page 3.11 - 3.13 for engine removal / installation notes.

The following service procedures are for the ES33PF and EH50PL engines. Differences are noted where necessary.


Engine Disassembly / Inspection

Cam Chain Tensioner/Rocker Arm/Camshaft Removal


1. Remove ignition timing inspection plug from recoil housing.

To position crankshaft at Top Dead Center (TDC) on compression stroke:

2. Rotate engine slowly in the direction of rotation watching intake valves open and start to close.
3. Continue to rotate engine slowly, watching camshaft sprocket marks and the mark in the timing inspection hole.



4. Align single (TDC) mark on flywheel with projection in inspection hole, and the cam sprocket pin (facing upward) aligned with the camshaft to crankshaft center line. **NOTE:** The cam lobe should be pointing down and valves should have clearance at this point.




5. Remove cam chain tensioner plug, sealing washer, and spring. **CAUTION:** The plug is under spring tension. Maintain inward pressure while removing.
6. Remove the two 6x25 mm cam chain tensioner flange bolts.
7. Tap lightly on tensioner body with a soft face hammer and remove tensioner.




Engine Disassembly, Cont.

Cam Chain Tensioner Inspection

1. Pull cam chain tensioner plunger outward to the end of its travel. Inspect teeth on ratchet pawl (A) and plunger teeth (B) for wear or damage.
2. Push ratchet pawl and hold it. The plunger should move smoothly in and out of the tensioner body.
3. Release ratchet pawl and push inward on plunger. It should remain locked in position and not move inward.



4. Measure free length of tensioner spring. Replace spring if excessively worn. Compare to specifications on page 3.5 - 3.8.



5. Replace entire tensioner assembly if any part is worn or damaged.


ENGINE

ES33PF, EH50PL Engine


Rocker Arm/Shaft Removal

ES33PF

1. Slide shaft out of support boss, keeping rocker arms in order. Note position of spring washer on rocker shaft. Flats face out, toward the shaft support.





1. Loosen rocker shaft retaining bolt (A) to remove shaft.
2. Remove the four bolts securing rocker shaft supports, and remove the supports, rocker shaft and rocker arms as an assembly, being careful not to drop the dowel pins into the engine.



Rocker Arm/Shaft Inspection

1. Mark or tag rocker arms to keep them in order for assembly.
2. Inspect each rocker arm cam follower surface. If there is any damage or uneven wear, replace the rocker arm. **NOTE:** Always inspect camshaft lobe if rocker arms are worn or damaged.



3. Measure O.D. of rocker shaft. Inspect it for wear or damage. Compare to specifications on page 3.5 - 3.8.



ENGINE


ES33PF, EH50PL Engine

Rocker Arm/Shaft Inspection, cont.

4. Measure I.D. of each rocker arm and compare to specifications on page 3.5 - 3.8.



5. Measure I.D. of both rocker arm shaft supports and visually inspect surface. Compare to specifications on page 3.5 - 3.8.



6. Inspect rocker adjuster screws for wear, pitting, or damage to threads of the adjuster or locknut. Replace all worn or damaged parts. **NOTE:** The end of the adjuster screw is hardened and cannot be ground or re-faced.



Camshaft Removal

1. Remove camshaft sprocket inspection cover.
2. Loosen three camshaft sprocket bolts.



3. Remove camshaft end cap and O-Ring.



4. Inspect camshaft end cap (thrust face) for wear. Replace if worn or damaged.




ENGINE




ES33PF, EH50PL Engine

Engine Disassembly, Cont.

5. Place a clean shop towel in the area below cam chain sprocket and remove sprocket retaining bolts.
6. Slide camshaft inward to allow removal of cam sprocket and remove sprocket from camshaft and chain.



7. Secure cam chain with a wire to prevent it from falling into the crankcase.
8. Inspect cam sprocket teeth for wear or damage. Replace if necessary.
9. Slide camshaft out the PTO side of the cylinder head.



Engine Disassembly, Cont.

Automatic Compression Release Removal/Inspection

NOTE: The automatic compression release mechanism can be inspected and serviced without removing the camshaft from the cylinder head. The actuator ball in the camshaft is not replaceable. Replace the camshaft as an assembly if the actuator ball is worn or damaged.

1. Check release lever shaft for smooth operation throughout the entire range of rotation. The spring should hold the shaft weight against the stop pin. In this position, the actuator ball will be held outward in the compression release mode.
2. Remove release lever shaft and return spring.
3. Inspect shaft for wear or galling.
4. Inspect lobe on end of release lever shaft and actuator ball for wear and replace if necessary.



Automatic Compression Release Installation

1. Slide spring onto shaft.
2. Apply engine oil to release lever shaft.

The actuator ball must be held outward to allow installation of the release lever shaft.


If Camshaft Is Removed From Engine:

3. Turn the camshaft until the actuator ball is in the lowest position and install the release lever shaft, pre-winding the spring approximately 1/4" (6.5mm).

If Camshaft Is Installed In The Engine:

4. Use a small magnet to draw the actuator ball outward, or rotate the engine until the cam lobes face upward and install release lever shaft.
5. Position camshaft as shown at bottom of illustration at right.
6. Place arm of spring under stop pin as shown and push release lever inward until fully seated. *Do not* pre-wind the spring one full turn or the compression release will not disengage when the engine starts. Check operation of mechanism as outlined in step 1 of Removal (above).

NOTE: When shaft is properly installed, actuator ball will be held in the "out" position. It is important to note that spring pressure is very light.




ENGINE

ES33PF, EH50PL Engine


Engine Disassembly, Cont.

Camshaft Inspection

1. Visually inspect each cam lobe for wear, chafing or damage.
2. Thoroughly clean the cam shaft, making sure the oil feed holes are not obstructed.
3. Measure height of each cam lobe using a micrometer. Compare to specifications on page 3.5 - 3.8.



4. Measure camshaft journal outside diameter (O.D.)
5. Measure ID of camshaft journal bore.
6. Calculate oil clearance by subtracting journal OD from journal bore ID. Compare to specifications on page 3.5 - 3.8.




Replace camshaft if damaged or if any part is worn past the service limit.

Replace cylinder head if camshaft journal bore is damaged or worn excessively.

Engine Disassembly, Cont.

Cylinder Head Exploded View, ES33PF



ES33PF


1. Remove the two 6mm flange bolts from cylinder head.



ENGINE
ES33PF, EH50PL Engine


Cylinder Head Exploded View, EH50PL

1. Remove the two 6mm flange bolts (A) from cylinder head.



Engine Disassembly, Cont.


2. Loosen each of the four cylinder head bolts evenly 1/8 turn each time in a criss-cross pattern until loose.
3. Remove bolts (A) and tap cylinder head lightly with a plastic hammer until loose. **CAUTION:** Tap only in reinforced areas or on thick parts of cylinder head casting to avoid damaging casting.



4. Remove cylinder head and head gasket.

ES33PF

New head gasket must be installed with sealant facing upward.



Cylinder Head Inspection

1. Thoroughly clean cylinder head surface to remove all traces of gasket material and carbon. **CAUTION:** Use care not to damage sealing surface.



ENGINE

ES33PF, EH50PL Engine


Engine Disassembly, Cont.

Cylinder Head Warpage

1. Lay a straight edge across the surface of the cylinder head at several different points and measure warpage by inserting a feeler gauge between the straight edge and the cylinder head surface. If warpage exceeds the service limit, replace the cylinder head.

Cylinder Head Warpage Limit:

.002" (.05 mm)




Cylinder Head Disassembly

WARNING: Wear eye protection or a face shield during cylinder head disassembly and reassembly.

NOTE: Keep all parts in order with respect to their location in the cylinder head. The EH50 cylinder head is shown in examples throughout cylinder head service section. The ES33 cylinder head is similar to EH50.


1. Using a valve spring compressor, compress the valve spring and remove the split keeper. **NOTE:** To prevent loss of tension, do not compress the valve spring more than necessary.



2. Remove spring retainer and spring.



NOTE: The valve springs should be positioned with the tightly wound coils against the cylinder head on progressively wound springs (A).

3. Push valve out, keeping it in order for reassembly in the same guide.



Engine Disassembly, Cont.

4. Measure free length of spring with a Vernier caliper. Check spring for squareness. Compare to specifications on page 3.5 - 3.8. Replace spring if either measurement is out of specification.



5. Remove valve seals. **CAUTION:** Replace seals whenever the cylinder head is disassembled. Hardened, cracked or worn valve seals will cause excessive oil consumption and carbon buildup.




ENGINE

ES33PF, EH50PL Engine


Engine Disassembly, Cont.

Valve Inspection


1. Remove all carbon from valve with a soft wire wheel.
2. Check valve face for runout, pitting, and burnt spots. To check for bent valve stems, mount valve in a drill or use "V" blocks and a dial indicator.



3. Check end of valve stem for flaring, pitting, wear or damage (A).
4. Inspect split keeper groove for wear or flaring of the keeper seat area (B). **NOTE:** The valves cannot be re-faced or end ground. They must be replaced if worn, bent, or damaged.




5. Measure diameter of valve stem with a micrometer in three places and in two different directions (six measurements total). Compare to specifications on page 3.5 - 3.8.



Engine Disassembly, Cont.

6. Measure valve guide inside diameter at the top middle and end of the guide using a small hole gauge and a micrometer. Measure in two directions, front to back and side to side.
7. Subtract valve stem measurement to obtain stem to guide clearance. **NOTE:** Be sure to measure each guide and valve combination individually.
8. Replace valve and/or guide if clearance is excessive. Compare to specifications on page 3.5 - 3.8.

NOTE: If valve guides are replaced, valve seats must be reconditioned. Refer to Valve Seat Reconditioning for procedure.



Combustion Chamber

Clean all accumulated carbon deposits from combustion chamber and valve seat area with a soft wire brush.



ENGINE

Valve Seat Reconditioning

Valve Seat Inspection

Inspect valve seat in cylinder head for pitting, burnt spots, roughness, and uneven surface. If any of the above conditions exist, the valve seat must be reconditioned. See Valve Seat Reconditioning, page 3.67. *If the valve seat is cracked the cylinder head must be replaced.*

Cylinder Head Reconditioning

NOTE: Servicing the valve guides and valve seats requires special tools and a thorough knowledge of reconditioning techniques. Follow the instructions provided in the cylinder head service tool kit.

CAUTION: Wear eye protection when performing cylinder head service. Valve guide replacement will require heating of the cylinder head. Wear gloves to prevent burns.

Valve Guide Removal/Installation



1. Remove all carbon deposits from the combustion chamber, valve seat and valve guide area before attempting to remove valve guides. **CAUTION:** Carbon deposits are extremely abrasive and may damage the valve guide bore when guides are removed.
2. Place new valve guides in a freezer for at least 15 minutes while heating cylinder head.
3. Heat cylinder head in an oven or use a hot plate to bring cylinder head temperature to 212° F (100° C). **CAUTION:** Do not use a torch to heat cylinder head or warpage may result from uneven heating. Head temperature can be checked with a pyrometer or a welding temperature stick.

Valve Seat Reconditioning

Follow the manufacturers instructions provided with the valve seat cutters in the Cylinder Head Reconditioning Kit (PN 2200634). Abrasive stone seat reconditioning equipment can also be used. Keep all valves in order with their respective seat.


NOTE: Valve seat width and point of contact on the valve face is very important for proper sealing. The valve must contact the valve seat over the entire circumference of the seat, and the seat must be the proper width all the way around. If the seat is uneven, compression leakage will result. If the seat is too wide, seat pressure is reduced, causing carbon accumulation and possible compression loss. If the seat is too narrow, heat transfer from valve to seat is reduced and the valve may overheat and warp, resulting in burnt valves.

1. When thoroughly heated, place cylinder head on blocks of wood which will allow the old guides to be removed.
2. Using valve guide driver, drive guides out of the cylinder head from the combustion chamber side. Be careful not to damage guide bore or valve seat when removing guides.
3. Place cylinder head on cylinder head table.
NOTE: Be sure cylinder head is still at 212° F (100° C) before installing new guides.
4. Place a new guide in the valve guide installation tool and press guide in to proper depth. Check height of each guide above the cylinder head (A). Refer to specifications on page 3.5 - 3.8.
NOTE: The guide can also be driven in to the proper depth. Inspect the guide closely for cracks or damage if a driver is used.



Reaming The Valve Guide

5. Allow cylinder head to cool to room temperature. Apply cutting oil to the reamer. Guides should be reamed from the valve spring side of the cylinder head. Ream each guide to size by turning the reamer clockwise continually. Continue to rotate reamer clockwise during removal of the tool.
6. Clean guides thoroughly with hot soapy water and a nylon brush. Rinse and dry with compressed air. Apply clean engine oil to guides.




ENGINE


Valve Seat Reconditioning

Valve Seat Reconditioning, cont.

1. Install pilot into valve guide.
2. Apply cutting oil to valve seat and cutter.




3. Place 46° cutter on the pilot and make a light cut.
4. Inspect the cut area of the seat.
 - S If the contact area is less than 75% of the circumference of the seat, rotate the pilot 180° and make another light cut.
 - S If the cutter now contacts the uncut portion of the seat, check the pilot. Look for burrs, nicks, or runout. If the pilot is bent it must be replaced.
 - S If the contact area of the cutter is in the same place, the valve guide is distorted from improper installation and must be replaced. Be sure the cylinder head is at the proper temperature and replace the guide.
 - S If the contact area of the initial cut is greater than 75%, continue to cut the seat until all pits are removed and a new seat surface is evident. **NOTE:** Remove only the amount of material necessary to repair the seat surface.
5. To check the contact area of the seat on the valve face, apply a thin coating of Prussian Blue™ paste to the valve seat. If using an interference angle (46°) apply black permanent marker to the entire valve face (A).
6. Insert valve into guide and tap valve lightly into place a few times.




Valve Seat Reconditioning, cont.

7. Remove valve and check where the Prussian Blue™ indicates seat contact on the valve face. The valve seat should contact the middle of the valve face or slightly above, and must be the proper width.
 - S If the indicated seat contact is at the top edge of the valve face and contacts the margin area(B) it is too high on the valve face. Use the 30° cutter to lower the valve seat.
 - S If too low use the 60° or 75° cutter to raise the seat. When contact area is centered on the valve face, measure seat width.
 - S If the seat is too wide or uneven, use both top and bottom cutters to narrow the seat.
 - S If the seat is too narrow, widen using the 45° cutter and re-check contact point on the valve face and seat width after each cut.




NOTE:When using an interference angle, the seat contact point on the valve will be very narrow, and is a normal condition. Look for an even and continuous contact point on the black marker, all the way around the valve face.

ES33PF / EH50PL Valve Seat Width:
Refer to Engine Service Specifications on Page 3.5 - 3.8.



8. Clean all filings from the area with hot soapy water, rinse, and dry with compressed air.
9. Lubricate the valve guides with clean engine oil, and apply oil or water based lapping compound to the face of the valve. Lapping is not required with an interference angle.



ENGINE


Valve Seat Reconditioning

Valve Seat Reconditioning, cont.

10. Insert the valve into its respective guide and lap using a lapping tool or a section of fuel line connected to the valve stem.
11. Rotate the valve rapidly back and forth until the cut sounds smooth. Lift the valve slightly off of the seat, rotate 1/4 turn, and repeat the lapping process. Do this four to five times until the valve is fully seated, and repeat process for the other valve(s).



12. Clean cylinder head, valves, and camshaft oil supply passage (A) thoroughly.
13. If oil passage blind plug was removed, apply 3 Bond 1215 or equivalent sealer to the threads and install, torquing to 8 ft. lbs. (1.1 kg-m). **CAUTION:** Do not allow sealant to enter oil passage.
14. Spray electrical contact cleaner into oil passage and dry using compressed air.



Cylinder Head Assembly

CAUTION: Wear eye protection during assembly.


NOTE: Assemble the valves one at a time to maintain proper order.

1. Install new valve seals on valve guides.
2. Apply engine oil to valve guides and seats.
3. Coat valve stem with molybdenum disulfide grease.
4. Install valve carefully with a rotating motion to avoid damaging valve seal.



Cylinder Head Assembly, Cont.

5. Dip valve spring and retainer in clean engine oil and install spring with closely spaced coils toward the cylinder head.



6. Place retainer on spring and install valve spring compressor. Compress spring only enough to allow split keeper installation to prevent loss of spring tension. Install split keepers with the gap even on both sides.
7. Repeat procedure for remaining valve.
8. When all valves are installed, tap lightly with soft faced hammer on the end of the valves to seat the split keepers.



Valve Sealing Test

1. Clean and dry the combustion chamber area.
2. Pour a small amount of clean, high flash point solvent into the intake port and check for leakage around each intake valve. The valve seats should hold fluid with no seepage.
3. Repeat for exhaust valves by pouring fluid into exhaust port.


ENGINE ES33PF, EH50PL Engine

Engine Bottom End Disassembly


Cylinder/Piston Removal and Inspection

Follow engine disassembly procedures to remove valve cover, camshaft and rocker arms, and cylinder head.

1. Remove cam chain guide at front of cylinder.




2. Loosen all four oil pipe banjo bolts and then remove the bolts and eight sealing washers. Remove the pipes.





EH50PL

3. Loosen hose clamps and remove coolant inlet hose.



Engine Disassembly, Cont.

4. Remove the two 6 mm cylinder base bolts.



5. Loosen each of the four large cylinder base bolts 1/4 turn at a time in a criss-cross pattern until loose and remove bolts.

EH50PL

The bolts are inside the water jacket.



6. Tap cylinder lightly with a plastic hammer in the reinforced areas only until loose.
7. Rock cylinder forward and backward and lift it from the crankcase, supporting piston and connecting rod. Support piston with piston support block PN 2870390.
8. Remove dowel pins from crankcase.



ENGINE

ES33PF, EH50PL Engine

Engine Disassembly, Cont.

Piston Removal

ES33PF

1. Remove circlip. Note piston orientation with circlip removal notch facing the front or rear. The ES33 piston is non-directional. A new piston can be installed with the circlip notch facing either way. However, if a used piston is re-installed, install in the same direction as removed.

EH50PL

1. Remove circlip. Note piston directional arrow pointing toward the right (Mag) side of engine.
2. Remove piston circlip and push piston pin out of piston. If necessary, heat the crown of the piston *slightly* with a propane torch. **CAUTION:** Do not apply heat to the piston rings. The ring may lose radial tension.



3. Remove top compression ring.

***Using a piston ring pliers:** Carefully expand ring and lift it off the piston. **CAUTION:** Do not expand the ring more than the amount necessary to remove it from the piston, or the ring may break.

***By hand:** Placing both thumbs as shown, spread the ring open and push up on the opposite side. Do not scratch the ring lands.


4. Repeat procedure for second ring.



EH50PL

The oil control ring is a three piece design consisting of a top and bottom steel rail and a center expander section. The top rail has a locating tab on the end which fits into a notch (A) in the upper oil ring land of the piston.

5. Remove the top rail first followed by the bottom rail.
6. Remove the expander.



Cylinder Inspection


1. Remove all gasket material from the cylinder sealing surfaces.
2. Inspect the top of the cylinder for warpage using a straight edge and feeler gauge.

Cylinder Warpage:
.002" (.05 mm)



3. Inspect cylinder for wear, scratches, or damage.

4. Inspect cylinder for taper and out of round with a telescoping gauge or a dial bore gauge. Measure in two different directions, front to back and side to side, on three different levels (1/2" down from top, in the middle, and 1/2" up from bottom).



ENGINE ES33PF, EH50PL Engine

Engine Disassembly, Cont.

- Record measurements. If cylinder is tapered or out of round beyond .002, the cylinder must be re-bored oversize, or replaced.


Cylinder Taper
Limit: .002 Max.
Cylinder Out of Round
Limit: .002 Max.

Standard Bore Size:
Refer to Page 3.5 - 3.8

Piston-to-Cylinder Clearance

- Measure piston outside diameter at a point 5 mm up from the bottom of the piston at a right angle to the direction of the piston pin.
- Subtract this measurement from the maximum cylinder measurement obtained in step 5 above.

Piston to Cylinder Clearance
Refer to Page 3.5 - 3.8
Piston O.D.:
Refer to Page 3.5 - 3.8




Engine Disassembly, Cont.

3. Measure piston pin bore.

Piston Pin Bore:


Refer to Specifications on Page 3.5 - 3.8



4. Measure piston pin O.D. Replace piston and/or piston pin if out of tolerance.

Piston Pin O.D.

Refer to Specifications on Page 3.5 - 3.8




Piston Pin Measurement Locations

5. Measure connecting rod small end ID.

Connecting Rod Small End I.D.

Refer to Specifications on Page 3.5 - 3.8



6. Measure piston ring to groove clearance by placing the ring in the ring land and measuring with a thickness gauge. Replace piston and rings if ring-to-groove clearance exceeds service limits.


Piston Ring-to-Groove Clearance

Refer to Specifications on Page 3.5 - 3.8

ENGINE
ES33PF, EH50PL Engine
Engine Disassembly, Cont.


Piston Ring Installed Gap

1. Place each piston ring inside cylinder using piston to push ring squarely into place as shown at right.



2. Measure installed gap with a feeler gauge at both the top and bottom of the cylinder. **NOTE:** A difference in end gap indicates cylinder taper. The cylinder should be measured for excessive taper and out of round.
3. If the *bottom* installed gap measurement exceeds the service limit, replace the rings.

NOTE: Always check piston ring installed gap after re-boring a cylinder or when installing new rings. A re-bored cylinder should always be scrubbed thoroughly with hot soapy water, rinsed, and dried completely. Wipe cylinder bore with an oil rag immediately to remove residue and prevent rust.



<p>Piston Ring Installed Gap</p> <p>Top Ring</p> <p>Second Ring</p> <p>Oil Ring</p> <p>Refer to Specifications on Page 3.5 - 3.8</p>

Engine Disassembly, Cont.

Crankcase Disassembly


NOTE: The recoil starter, starter motor, starter drive, flywheel, stator, cam chain and sprockets can be serviced with the engine in the frame.

Starter Drive Removal/Inspection

1. Remove recoil housing bolts and remove housing.
2. Remove starter drive assembly. Note the thrust washer located at the rear of the drive mechanism.
3. Inspect the thrust washer for wear or damage and replace if necessary.



4. Measure the OD of the starter drive shaft on both ends and record.
5. Measure the ID of the bushing in the recoil housing (A) and in the crankcase and record. Measure in two directions 90° apart to determine if bushing is out of round. Calculate bushing clearance. Replace bushing if clearance exceeds the service limit.



Std. Bushing ID:
.4735"-.4740" (11.11-12.04 mm)

Std. Shaft OD:
.470"-.472" (11.93-11.99 mm)

Starter Drive Bushing Clearance:
Std: .0015"-.004" (.038-.102 mm)

Service Limit:
.008" (.203 mm)

ENGINE


ES33PF, EH50PL Engine

Engine Disassembly, Cont.

6. Inspect gear teeth on starter drive. Replace starter drive if gear teeth are cracked, worn, or broken.

Flywheel/Stator Removal/Inspection

1. Remove flywheel nut and washer.
2. Install flywheel puller (PN 2870159) and remove flywheel. **CAUTION:** Do not thread the puller bolts into the flywheel more than 1/4" or stator coils may be damaged.
3. Mark or note position of stator plate on crankcase.
4. Remove bolts and carefully remove stator assembly, being careful not to damage crankshaft bushing on stator plate.
5. Replace crankshaft seal.



6. Remove oil passage O-Ring.




7. Remove large sealing O-Ring from outer edge of stator plate.



Cam Chain/Tensioner Blade

1. Remove bolt securing tensioner blade to crankcase (A).
2. Remove blade and inspect for cracks, wear, or damage.



3. Remove cam chain. Inspect chain for worn or missing rollers or damage. Stretch chain tight on a flat surface and apply a 10 lb. (4.53 kg) load. Measure length of a 20 pitch section of chain. Replace if worn past service limit.



Chain Service Limit:
5.407" (13.7 cm)



ENGINE ES33PF, EH50PL Engine

Engine Disassembly, Cont.

4. Using the special socket, remove the crankshaft slotted nut (A). **NOTE:** The slotted nut is a left hand thread.
5. Remove cam chain drive sprocket (B) and Woodruff key from crankshaft.
6. Inspect sprocket teeth for wear or damage.
7. Inspect Woodruff key for wear.
8. Replace any worn or damaged parts.



One Way Valve

The one way valve prevents oil from draining out of the oil tank and into the crankcase when the engine is off. It must be clean and have adequate spring pressure in order to seal properly.

1. Remove cap bolt, sealing washer, spring, and one way valve from PTO side crankcase.
2. Inspect free length of spring and check coils for distortion.

One Way Valve Spring Free Length:

Std: 1.450" (3.68 cm)

3. Inspect valve for wear.
4. Check seat area for nicks or foreign material that may prevent proper sealing of valve.




Crankcase Separation

1. Remove flange bolts (10) from magneto side crankcase evenly in a criss-cross pattern.
2. Separate crankcase by tapping with a soft faced hammer in reinforced areas.
3. Tap lightly on balancer gear with a brass drift through the hole in the crankcase if necessary, to ensure the balancer shaft stays in the PTO side crankcase. Watch the gap along the crankcase mating surface and separate the crankcase evenly. It may also be necessary to tap the oil pump shaft lightly to separate the crankcase.

CAUTION: Do not strike the oil pump shaft at an angle or the shaft may bend, causing irreparable damage. Tap only *lightly* on the pump shaft if necessary.

4. Remove the Mag (RH) crankcase from the PTO case.




ENGINE

ES33PF, EH50PL Engine


Engine Disassembly, Cont.

Oil Pump Removal/Inspection


1. Remove pump shaft bearing (A) and thrust washer (B) from pump shaft.
2. Remove pump drive gear (C).
3. Inspect drive gear teeth for cracks, damage or excessive wear.



4. Remove three oil pump retaining bolts and pump.




5. Inspect mating surface of crankcase and oil pump. Check for nicks, burrs, or surface irregularities.



Engine Disassembly, Cont.

6. Remove the three screws and strainer screen from pump.
7. Clean screen thoroughly.




8. Remove pump body screw and feed chamber cover.



9. Measure pump end clearance using a feeler gauge and straight edge.

Pump End Clearance:
Std: .001-.003 (.0254-.0762 mm)
Wear Limit: .004 (.1016 mm)



ENGINE

ES33PF, EH50PL Engine

Engine Disassembly, Cont.

10. Measure clearance between outer feed rotor and pump body with a feeler gauge.

**Outer Feed Rotor to Pump
Body Clearance:**

Std: .001-.003 (.0254-.0762 mm)

Wear Limit: .004 (.1016 mm)



11. Measure rotor tip clearance with a feeler gauge.

Rotor Tip Clearance:

Std: .005 (.127 mm)

Wear Limit: .008 (.2032 mm)



12. Remove inner and outer feed rotor and pump chamber body.
13. Repeat measurements for scavenge rotor.
14. Remove inner and outer scavenge rotor and inspect pump shaft for wear.

Oil Pump Assembly

1. Clean and dry all parts thoroughly. Apply clean engine oil to all parts. *Do not* use gasket sealer on the pump body mating surfaces or oil passages will become plugged.
2. Install pump shaft and scavenge rotor drive pin.
3. Install outer scavenge rotor, inner scavenge rotor, and scavenge casing.
4. Install outer feed rotor and inner feed rotor drive pin.
5. Install inner feed rotor and feed chamber cover with screw.
6. Tighten screw securely.
7. Install screen on pump body.
8. Install oil pump on crankcase and torque bolts to 6 ft. lbs. (.828 kg-m).

**Oil Pump Attaching Bolt Torque:
6 ft. lbs. (.828 kg-m)**

Engine Disassembly, Cont.

Counter Balancer Shaft Removal/Inspection

1. Remove the shim washer from the counter balancer shaft.



2. Note the alignment dots on the balancer and crankshaft gears, the marks must be aligned during reassembly.



3. Turn the shaft until balancer counter weights clear the crankshaft and remove the balancer shaft from the crankcase.
4. Inspect the balancer drive gear and pump shaft drive gear.
5. Replace the shaft if gear teeth are abnormally worn or damaged.
6. Inspect the balancer shaft bearings.

NOTE: Due to extremely close tolerances and minimal wear, the balancer shaft ball bearings must be inspected visually and by feel. Look for signs of discoloration, scoring or galling. Turn the inner race of each bearing. The bearings should turn smoothly and quietly. The outer race of each bearing should fit tightly in the crankcase. The inner race should be firm with minimal side to side movement and no detectable up and down movement.




ENGINE ES33PF, EH50PL Engine

Engine Disassembly, Cont.

Crankshaft Removal/Inspection

1. Remove the shim washer from the crankshaft.
2. Support the PTO side crankcase and crankshaft; press the crankshaft out. Be careful not to damage the crankcase mating surface or connecting rod.



3. Use a feeler gauge to measure the connecting rod big end side clearance.

Connecting Rod Big End Side Clearance:

Refer to page 3.5-3.8.

4. Place the crankshaft in a truing stand or V-blocks and measure the runout on both ends with a dial indicator. Refer to page 3.40.

Max Runout: .0024" (.06 mm)



5. Measure the connecting rod big end radial clearance.

Big End Radial Clearance:

Refer to page 3.5-3.8.

6. Inspect the crankshaft main bearing journals for scoring and abnormal wear.

Engine Disassembly, Cont.

Crankcase Bearing Inspection

1. Remove the seal from the PTO side crankcase.
2. Inspect the crankshaft main bearings, balancer shaft bearings, and pump shaft bearing.

NOTE: Due to extremely close tolerances and minimal wear, the bearings must be inspected visually, and by feel. Look for signs of discoloration, scoring or galling. Turn the inner race of each bearing. The bearings should turn smoothly and quietly. The outer race of each bearing should fit tightly in the crankcase. The inner race should be firm with minimal side to side movement and no detectable up and down movement.

3. Support the crankcase and drive or press the main bearings out of each crankcase.
4. To remove balancer shaft bearings and pump shaft bearing use a blind hole bearing puller.

NOTE: Bearings are stressed during the removal process and *should not* be re-used!

Pump Shaft Oil Seal/ Water Pump Mechanical Seal Removal (Engine Disassembled)

NOTE:The water pump mechanical seal can be removed without removing the engine. Refer to Water Pump Mechanical Seal Installation.

Replace the pump shaft seal and water pump mechanical seal whenever the crankcase is disassembled.

1. Remove the pump shaft bearing from the Magneto (right hand) side crankcase.
2. Pry out the oil seal, noting the direction of installation with the spring side facing IN (toward inside of case).
3. Drive the water pump mechanical seal out of the crankcase from inside to outside. Note: The new mechanical seal must be installed after the crankcases are assembled, using a special tool. See Mechanical Seal Installation.



ENGINE

ES33PF, EH50PL Engine

Assembly

Crankcase Assembly

1. Remove all traces of gasket sealer from the crankcase mating surfaces. Inspect the surfaces closely for nicks, burrs or damage.
2. Check the oil pump and oil passage mating surfaces to be sure they are clean and not damaged.

Bearing Installation

NOTE: To ease bearing installation, warm the crankcase until hot to the touch. Place the bearings in a freezer.

1. Install the bearings so the numbers are visible.
2. Drive or press new bearings into the crankcases, using the proper driver. **CAUTION:** Press only on outer race of bearing to prevent bearing damage.
 - S 70mm (2.755") driver- For crankshaft main bearings.
 - S 46mm (1.810") For counter balancer bearings.
 - S 28mm (1.100") For pump shaft bearing.

Assembly, Cont.

End Play Inspection/Adjustment


Before reassembling the crankcase, the following steps should be performed to determine the amount of crankshaft, counter balancer shaft, and pump shaft end play. Excessive end play may cause engine noise at idle and slow speeds. Too little play will side load the bearings which may lead to premature bearing failure.

Crankshaft End Play Adjustment

1. Make sure all bearings are firmly seated in the both Mag and PTO crankcase.



2. Measure the distance from the PTO crankcase mating surface to the main bearing using a dial caliper and a straight edge.



3. Subtract the thickness of the straightedge from the measurement obtained in Step 2 and record.

PTO Case Depth _____



ENGINE

ES33PF, EH50PL Engine

Crankshaft End Play Adjustment, cont.

4. Measure the distance from the Magneto crankcase mating surface to the main bearing using the same method and record.



5. Subtract the thickness of the straightedge from the measurement obtained in Step 4 and record.

Mag Case Depth _____

6. Add the readings recorded in Step 3 and Step 5 and record below.

Total Case Width _____


7. Measure the width of the crankshaft at the bearing seats with a micrometer or dial caliper and record.

Crankshaft Width _____

8. Subtract the Crankshaft Width measured in Step 7 from the Total Case Width recorded in Step 6, and record below.

Total End Play _____

9. Subtract the thickness of the existing shim from the result of step 8 to determine if a different shim is required. The result must be within the specified range listed below.




Crankshaft End Play:

.008"-.016" (.02-.04 cm)


Assembly, Cont.

Counter Balancer Shaft End Play Adjustment

1. Make sure all bearings are firmly seated in the crankcase.
2. Measure the width of the counter balancer shaft at the bearing seats with a dial caliper or micrometer, and record reading.



3. Measure the distance from the Mag crankcase mating surface to the balance shaft bearing using a dial caliper and a straight edge. Subtract the thickness of the straightedge and record.
4. Measure the distance from the PTO crankcase mating surface to the bearing using the same method outlined in Step 1, 2, and-3.



5. Add the readings obtained in Step 3 and Step 4.
6. Subtract the counter balancer shaft width measured in step 2 from the figure obtained in step 5.
7. Subtract the thickness of the existing shim from the result of step 6 to determine if a different shim is needed. The result must be within the specified range listed below.

Counter Balancer Shaft End Play:

.008"-.016" (.02-.04 cm)

ENGINE

ES33PF, EH50PL Engine


Assembly, Cont.

Pump Shaft

1. Make sure the pump shaft bearing is firmly seated in the Magneto side crankcase.
2. Measure the distance from the magneto crankcase mating surface to the bearing using a dial caliper and a straight edge. Subtract the thickness of the straightedge and record.



3. Install the gear on the oil pump and measure the width of the pump and gear. Subtract this measurement from the measurement recorded in Step 2.
4. Subtract the thickness of the existing shim from the result of Step 3 to determine if a different shim is needed.



Pump Shaft End Play:

.008"-.016" (.02-.04 cm)

Pump Shaft Oil Seal Installation

1. Install the seal from the outside of the crankcase (water pump side) with the spring facing inward, toward the pump shaft bearing.
2. Drive or press the seal into place using a 25mm (.985") seal driver, until flush with the bottom of the mechanical seal bore.
3. Lubricate the seal lip with grease.



Assembly, Cont.

Crankshaft, Counter Balancer, and Oil Pump Installation

Lubricate all bearings with clean engine oil before assembly. See engine disassembly photos page 3.50-3.89 for reference.

Use the crankshaft installation tool kit PN 2871283 to prevent damage to the crankshaft and main bearings during installation.

1. Install the crankshaft into the PTO side crankcase. Screw the threaded rod into the crankshaft until the threads are engaged a minimum of one inch (25.4mm).
2. Install the collar, washer, and nut onto the threaded rod. Hold the crankshaft and tighten the nut to draw the crankshaft into the main bearings until fully seated. Loosen the nut and remove the threaded rod from the crankshaft. If removal is difficult, install two nuts on the end of the threaded rod and tighten against each other.
3. Install the proper shim on the magneto end of the crankshaft.
4. Place the balancer shaft in the PTO crankcase aligning the timing marks on the crankshaft and balancer gears. Install the proper shim washer on the shaft.
5. Inspect the oil pump sealing surface on the crankcase. Apply a light film of engine oil to the surface and install the oil pump.

NOTE: Do not use gasket sealer on the pump mating surfaces.

Oil Pump Bolt Torque:

6. ft. lbs. (.828 kg-m)

6. Align the drive gear with the drive pin on the pump shaft and install the gear. Be sure the gear is fully seated and properly engaged.
7. Install the proper shim washer on the pump shaft.

Crankcase Assembly

1. Apply 3 Bond 1215 (P/N 2871557) to the crankcase mating surfaces. Be sure the alignment pins are in place.
2. Set the crankcase in position carefully to avoid damaging the pump shaft seal, and install the magneto end crankshaft installation tool (follow instructions provided with tool kit PN 2871283). Draw the crankcase halves together by tightening the nut on the tool and tapping lightly in the pump shaft area with a soft faced hammer to maintain alignment. Continually check alignment of the cases during installation, closing the gap equally until the surfaces are tightly seated.
3. Remove the tool.
4. Install the crankcase flange bolts and tighten in 3 steps in a criss-cross pattern to specified torque.

Crankcase Bolt Torque:

14 ft. lbs. (19-20 Nm)

Crankcase Sealant:

PN 2871557

ENGINE

EH50PL Engine

Water Pump Mechanical Seal Installation (EH50PL)

1. Clean the seal cavity to remove all traces of old sealer.
2. Place a new mechanical seal in the seal drive collar, and install on the pump shaft.
3. Screw the guide onto the end of the pump shaft.
4. Install the washer and nut and tighten to draw seal into place until fully seated.
5. Remove the guide adaptor using the additional nut as a jam nut if necessary.

Water Pump Mechanical Seal Removal - Engine Installed (EH50PL)

Water pump mechanical seal removal tool: 2872105


Replacement T-handle for 2872105: 2872106

This tool allows a technician to replace the mechanical water pump seal on EH42PL & EH50PL engines without removing the engine and splitting the cases.


CAUTION:

Improper or careless use of this tool or procedure can result in a bent water pump shaft. Pump shaft replacement requires engine removal and crankcase separation. Use caution while performing this procedure. Make sure that the puller is parallel to the shaft at all times. Do not place side loads on the water pump shaft or strike the puller or shaft in any way.

1. After the coolant has been drained, remove the water pump cover, impeller and the sealing washer. (III. 1)




2. Slide the main puller body over the outer portion of the mechanical seal as shown in III. 2 and turn T-Handle clockwise until it contacts water pump shaft. Continue rotating until outer portion of mechanical seal is separated from the metal seal body.




Water Pump Mechanical Seal Removal - Engine Installed, Cont.


3. Insert the puller legs between the water pump drive shaft and the remaining portion of the mechanical seal. Attach the puller legs to the main puller body. III. 3




4. Ensure that the split between the puller legs is fully supported by the main body of the tool (III 4).



5. Tighten the hex socket screws on the puller legs sufficiently so the lip of the puller legs will grasp the mechanical seal. III. 5



6. Turn the puller T-Handle clockwise until it contacts the water pump shaft. Continue rotating until the remaining portion of mechanical seal has been removed from the cases. III. 6 Pump shaft oil seal can also be replaced at this time if necessary.



7. Special tool (PN 5131135) is required to install the new mechanical seal. This tool is available separately and it is also included in the Crankshaft/Water Pump Seal Installation Kit (PN 2871283).

ENGINE

ES33PF, EH50PL Engine

Assembly, Cont.

One Way Valve Installation

Install the one way valve plunger, spring, and plug using a new sealing washer.

One Way Valve Plug Torque:

16 ft. lbs. (2.2 kg-m)

Cam Chain Drive Sprocket Installation

1. Install the Woodruff key, drive sprocket, and slotted nut. Tighten the nut to the specified torque.

Slotted Nut Torque:


35-51 ft. lbs. (4.71-6.86 kg-m)

Tensioner Blade Installation

1. Install the tensioner blade and tighten the mounting bolt to specified torque.

Tensioner Blade Mounting Bolt Torque:

6 ft. lbs. (.828 kg-m)




Piston Ring Installation

NOTE: Apply clean engine oil to all ring surfaces and ring lands. Always check piston ring installed gap before rings are installed on piston. See page 3.74. If the piston has been in service clean any accumulated carbon from the ring grooves and oil control ring holes.

1. Place the oil control ring expander in oil ring groove with the end gap facing forward. The expander has no up or down marking and can be installed either way. The ends should butt squarely together and must not overlap.
2. Install the oil ring top rail.

NOTE: The top rail has a locating tab to prevent rotation. The tab must be positioned in the notch on the side of the piston as shown (A).



ENGINE


ES33PF, EH50PL Engine

Assembly, Cont.

3. Install the bottom rail with the gap at least 30° from the end of the expander on the side opposite the top rail gap. (See III.)
4. Install the second ring with the "R" mark facing up. Position the end gap toward the rear (intake) side of the piston.
5. Install the top ring (chrome faced) with the "R" mark facing up and the end gap facing forward (toward the exhaust). (See III.)
6. Check to make sure the rings rotate freely in the groove when compressed.

Piston Installation


1. Clean the gasket surfaces on the cylinder and crankcase. Remove all traces of old gasket material.
2. Make sure the cylinder mounting bolt holes are clean and free of debris.




3. Install a new circlip on one side of the piston with the end gap facing *up* or *down*, and tang outward.

CAUTION: Circlips become deformed during the removal process. Do not re-use old circlips. Do not compress the new clip more than necessary upon installation to prevent loss of radial tension. Severe engine damage may result if circlips are re-used or deformed during installation.

4. Apply clean engine oil to the piston rings, ring lands, piston pin bore, piston pin, and piston skirt. Lubricate the connecting rod (both ends), balancer drive gear, and crankshaft main bearing area.



5. Install the piston on the connecting rod with the arrow facing the magneto (RH) end of the crankshaft. The piston pin should be a push fit in the piston.
6. Install the other circlip with the gap facing up or down and tang outward. (See Caution with step 3 above). Push the piston pin in both directions to make sure the clips are properly seated in the groove.




Assembly, Cont.

7. Place the dowel pins in the crankcase and install a new cylinder base gasket.

Cylinder Installation


1. Position the piston support block PN 2870390 (A) beneath the piston skirt to support the piston during cylinder installation.
2. Apply clean engine oil to the ring compressor (Snap On™ PN RCL30) and install the compressor following manufacturers instructions. **CAUTION:** Make sure the oil control ring upper rail tab is positioned properly in the notch of the piston. Verify all ring end gaps are correctly located.



3. Apply clean engine oil liberally to the cylinder bore and tapered area of the sleeve. Install the cylinder with a slight rocking motion until the rings are captive in the sleeve.



4. Remove the ring compressor.



5. Push the cylinder downward until fully seated on the base gasket.

ENGINE

ES33PF, EH50PL Engine

Assembly, Cont.

6. Apply a light film of oil to the threads and flange surface of the cylinder mounting bolts.
7. Install all four bolts finger tight. Rotate the engine and position the piston at BDC.

NOTE: If cam chain is installed, hold it up while rotating the engine to avoid damage to the chain, drive sprocket teeth, or tensioner blade.

8. Tighten the cylinder bolts in three steps in a criss cross pattern and torque to specifications.
9. Install the two 6mm bolts.

Cylinder Bolt Torque:

10mm - 46 ft. lbs. (6.348 kg-m)

6mm - 6 ft. lbs. (.828 kg-m)

Assembly, Cont.

Cylinder Head Installation

Clean the gasket surfaces on the cylinder head and cylinder. Remove all traces of old gasket material. Refer to disassembly photos.

1. Install the cam chain tensioner guide. Be sure bottom end of guide is located properly in crankcase.
2. Install the two dowel pins and a new cylinder head gasket.
3. Place the cylinder head on the cylinder. Apply a film of engine oil to the cylinder head bolt threads and washers, and hand tighten the bolts.

The following procedure must be used to torque the cylinder head properly:

Torque all bolts evenly in a criss cross pattern

***Torque bolts to 22 ft. lbs. (3.04 kg-m)**

***Torque bolts to 51 ft. lbs. (7.04 kg-m)**

***Loosen bolts evenly 180° (1/2 turn)**


***Loosen bolts again another 180° (1/2 turn)**

***Torque bolts to 11 ft. lbs. (1.52 kg-m)**

***From this point, tighten bolts evenly 90° (1/4 turn)**

***Finally, tighten another 90° (1/4 turn)**

***Install two 6mm bolts and torque to 6 ft. lbs. (.828 kg-m)**



ENGINE

ES33PF, EH50PL Engine

Cam Chain/Camshaft Installation



Install the cam chain over the crankshaft.

CAUTION: Serious engine damage may result if the camshaft is not properly timed to the crankshaft.


IMPORTANT CAMSHAFT TIMING NOTE: In order to time the camshaft to the crankshaft, the piston must be precisely located at Top Dead Center (TDC).

Camshaft Timing


1. Apply Polaris Premium Starter Drive grease to the camshaft main journals and cam lobes. Lubricate automatic compression release mechanism with clean engine oil. (To install the compression release mechanism, refer to page 3.57).
2. Install the camshaft with the lobes facing downward and the sprocket alignment pin facing upward.
3. Disconnect the wire from the cam chain and rotate the engine to align the single (TDC) timing mark (Top Dead Center) on the flywheel with the notch in the timing inspection window. Be sure to use the *single* TDC mark when installing the cam. Do not use the advance marks. See Ill. on next page.



4. Loop the cam chain on the cam sprocket with the dots on the sprocket facing outward and the alignment pin notch facing directly upward.




5. Before positioning the sprocket on the camshaft, check the position of the cam sprocket alignment pin. When the cam is positioned properly, the cam sprocket alignment pin (A) is directly in line with the crankshaft/camshaft centerline (B).
6. Install the sprocket on the camshaft. Apply Loctite 242 to the cam sprocket bolts and torque to specifications.



Cam Sprocket Bolt Torque:
6 ft. lbs. (.828 kg-m)



7. Verify TDC mark in timing inspection hole and alignment pin is directly in line with crankshaft to camshaft centerline. Refer to Ill. on following page.



8. Apply Loctite 515 or 518 Gasket Eliminator, or 3 Bond 1215 to the camshaft end cap and install using a new O-Ring.
9. Check all cam timing marks to verify proper cam timing, and install the cam chain tensioner body with a new gasket.
10. After tensioner installation, rotate engine at least two revolutions and re-check marks/timing.

ENGINE
ES33PF, EH50PL Engine Assembly

Camshaft Timing




Assembly, Cont.

Cam Chain Tensioner Installation

1. Release the ratchet pawl (A) and push the tensioner plunger (B) all the way into the tensioner body.
2. Install the tensioner body with a new gasket and tighten the bolts.

Tensioner Bolt Torque:

6 ft. lbs. (.828 kg-m)



3. Install the spring, new sealing washer, and tensioner plug.

Tensioner Plug Torque:

17 ft. lbs. (2.346 kg-m)


4. Slowly rotate engine two to three revolutions and re-check cam timing.

Stator, Flywheel and Starter Drive Installation

NOTE: The stator, flywheel, starter drive, and recoil can be assembled with the engine in the frame.

Stator

1. Apply a light film of grease to the crankshaft seal. Apply molybdenum disulfide grease or assembly lubricant to the crankshaft bushing.
2. Install a new O-Ring in the oil passage recess in the crankcase.
3. Apply 3 Bond 1215, Loctite 515 or 518, or an equivalent sealer to the stator plate outer surface and install a new O-Ring.
4. Install the stator plate being careful not to damage the seal. Align timing reference marks on the plate and crankcase. Be sure the plate is fully seated. **NOTE:** This is a static timing mark. Strobe timing should be performed after start up.



ENGINE

ES33PF, EH50PL Engine

Assembly, Cont.

5. Torque bolts evenly to specification.

Stator Plate Bolt Torque:

5.1-6.5 ft. lbs. (.68-.88 kg-m)

6. Seal stator wire grommet with 3 Bond 1215 or equivalent sealer.

Flywheel

1. Install flywheel, washer, and nut. Torque flywheel to specification.

Flywheel Nut Torque:



58-72 ft. lbs. (7.85-9.81 kg-m)

Starter Drive

1. Be sure the washer is positioned on the back of the drive gear.
2. Apply grease to the drive bushing in the crankcase and all moving surfaces of the starter drive mechanism. Install the starter drive.
3. Install recoil housing gasket and recoil housing.

Starter Drive Grease:

PN 2871460



Assembly, Cont.

Rocker Shaft/Rocker Arm Assembly Installation

1. Assemble rocker arms, rocker shaft, and shaft supports.
2. Install and tighten rocker arm shaft locating bolt.
3. Apply molybdenum disulfide grease to the cam lobes and cam follower surfaces.
4. Rotate the engine until the cam lobes are pointing downward.
5. Be sure the dowel pins are in place and install the rocker shaft assembly.
6. Apply a light film of engine oil to the threads of the bolts and tighten evenly.

Rocker Shaft Support Tower Bolt Torque:

9 ft. lbs. (1.242 kg-m)

Rocker Shaft Locating Bolt Torque:

6 ft. lbs. (.828 kg-m)

7. Adjust valves according to the valve adjustment procedure found in Chapter 2, Maintenance.
8. Apply clean engine oil liberally to the valve springs, cam chain, rocker arms, and camshaft.
9. Place a new rocker cover gasket on the cylinder head and install the cover and bolts.

Rocker Cover Bolt Torque:

6 ft. lbs. (.828 kg-m)

Thermostat Installation

Install the thermostat with one of the air bleed holes positioned next to the upper thermostat cover bolt hole as shown.

Oil Pipes

Install the oil pipes with new sealing washers. Tighten all bolts evenly to specified torque.

Oil Pipe Bolt Torque:

20 ft. lbs. (2.76 kg-m)



ENGINE


ES33PF, EH50PL Engine - Recoil Starter,

Recoil Disassembly/Inspection

CAUTION: The recoil is under spring tension. A face shield and eye protection is required during this procedure.

Replace any parts found to be worn or damaged.

1. Remove bolts and recoil housing.
2. Pull recoil rope so it is extended approximately 12-18". Check handle c-ring for proper tension, and the handle for cracks or damage which may allow water or dirt to enter the recoil housing through the rope. **NOTE:** The handle must seal tightly on the recoil housing to prevent water from entering.
3. Remove center bolt from recoil friction plate (A).



4. Inspect plate for wear or damage. Inspect plate friction spring for wear, damage, and proper tension. The spring should fit tightly on friction plate.



5. Remove ratchet pawl with spring and inspect. Replace spring or ratchet pawl if worn, broken, or damaged.

NOTE: Long arm of spring engages reel. Short end against pawl.




Recoil Disassembly/Inspection, Cont.

6. Hold reel firmly in housing. Pull rope handle until 12-18" of rope is exposed, and hold reel in place.
7. Place rope in notch on outer edge of reel. Release tension on hub and allow reel to unwind approximately 6-7 turns until spring tension is released.



8. Slowly and carefully remove reel from recoil housing making sure the spring remains in the housing. Inspect the reel hub and bushing (A) for wear.
9. Unwind rope and inspect for cuts or abrasions.
10. Inspect drive tab on hub return spring for damage. To remove hub return spring, hold outer coils in place with one hand and slowly remove spring one coil at a time from the inside out.
11. Pull knot out of of recoil reel. Untie knot. Remove rope from reel.



ENGINE

ES33PF, EH50PL Engine - Recoil Starter

Recoil Assembly

CAUTION: Be sure to wear a face shield and eye protection when performing this procedure.

To install a new spring:



1. Place spring in housing with the end positioned so the spring spirals inward in a counterclockwise direction. See photo at right.
2. Hold spring in place and cut retaining wire.

To reinstall an old spring:

1. Hook outer tab in place in recoil housing and wind spring in a counterclockwise direction one coil at a time while holding the installed coils in place.
2. Lubricate the spring with light lubricant such as Premium All Season Grease.

To complete recoil assembly:

1. Route rope through guide bushing in recoil housing and into reel. Tie a secure knot in end of the rope.
2. Wind rope counterclockwise onto the reel, as viewed from ratchet side of reel.
3. Lock rope into notch on outer edge of reel.
4. Apply a small amount of grease or equivalent to the center post of the housing and the bushing.
5. Install reel into housing making sure the spring drive tab on the reel engages the spring and the reel is fully seated in the housing.
6. Apply downward pressure on the reel and rotate counterclockwise approximately 6-7 turns to pre-wind the spring. Continue rotating counterclockwise until rope on outer edge aligns with rope guide bushing.
7. Release rope from notch and allow reel to rewind completely. If more pre-wind is required, place rope in notch and add additional turns of pre-wind.
8. Install ratchet pawl and return spring, with long leg of spring engaged in reel.
9. Reinstall friction plate. **NOTE:** The friction plate must be positioned with both end tabs of the friction spring opposite the ratchet pawl.
10. Torque friction plate retaining bolt to 5-6 ft. lbs. (7-9 Nm).
11. Reinstall recoil housing using a new gasket. Seal stator wire harness grommet with RTV silicone.



Spark Plug Fouling - 2 Stroke Engines

- S Oil pump adjusted incorrectly
- S Adjustment (pilot screw)
- S Restricted air filter (main or pre-cleaner)
- S Improperly assembled air intake system
- S Oil pump shaft seal leaking (fills crankcase)
- S Oil pump arm or reel not returning properly (cable, arm or reel sticking)
- S Spark plug cap loose or faulty
- S Choke cable adjustment or plunger/cable sticking
- S Foreign material on choke plunger seat or plunger
- S Incorrect spark plug heat range or gap
- S Carburetor inlet needle and seat worn
- S Jet needle and/or needle jet worn or improperly adjusted
- S Excessive carburetor vibration (loose or missing needle jet locating pins)
- S Loose jets in carburetor or calibration incorrect for altitude/temperature
- S Incorrect float level setting
- S PVT system calibrated incorrectly or components worn or mis-adjusted
- S Fuel quality poor (old) or octane too high
- S Low compression
- S Restricted exhaust
- S Weak ignition (loose coil ground, faulty coil, stator, or ETC switch)
- S ETC switch mis-adjusted
- S Oil line check valve leaking

Spark Plug Fouling - 4 Stroke Engines

- S Spark plug cap loose or faulty
- S Choke cable adjustment or plunger/cable sticking
- S Foreign material on choke plunger seat or plunger
- S Incorrect spark plug heat range or gap
- S Carburetor inlet needle and seat worn
- S Jet needle and/or needle jet worn or improperly adjusted
- S Excessive carburetor vibration (loose or missing needle jet locating pins)
- S Loose jets in carburetor or calibration incorrect for altitude/temperature
- S Incorrect float level setting
- S PVT system calibrated incorrectly or components worn or mis-adjusted
- S Fuel quality poor (old) or octane too high
- S Low compression
- S Restricted exhaust
- S Weak ignition (loose coil ground, faulty coil, stator, or ETC switch)
- S ETC switch mis-adjusted
- S Restricted air filter (main or pre-cleaner)
- S Improperly assembled air intake system
- S Restricted engine breather system
- S Oil contaminated with fuel
- S Restricted oil tank vent

ENGINE

2 Stroke Engine Troubleshooting

Condition	Possible Cause	Action/Possible Cause
Engine turns over but does not start	<ul style="list-style-type: none"> -No fuel -Dirt in fuel line or filter -Fuel will not pass through on-off valve (petcock) -Tank vent plugged -Carb starter circuit -Engine flooded -Low compression (below 100 PSI at sea level) -No spark 	<ul style="list-style-type: none"> -Add fuel as required -Clean line, replace filter -Clean or replace valve as necessary -Repair vent system -Clean or replace as needed -Turn off fuel and drain crankcase <ul style="list-style-type: none"> a. Inspect carb venting system for obstructions b. Inspect carb needle and seat a. Inspect head gasket b. Inspect piston and cylinder (repair as required) -Repair ignition system (refer to ignition troubleshooting)
Engine does not turn over	<ul style="list-style-type: none"> -Dead battery -Starter motor does not turn -Engine stuck 	<ul style="list-style-type: none"> -Charge or replace battery (refer to battery testing) -Repair starter (refer to starter testing) -Repair engine as required
Engine runs but will not idle	<ul style="list-style-type: none"> -Plugged carb pilot system -Carb misadjusted -Choke not adjusted properly -Low compression -Crankcase leak 	<ul style="list-style-type: none"> -Clean or replace pilot jet -Adjust as per specification -Adjust choke as per specification -Repair engine as required -Repair crankcase as required
Engine idles but will not rev up	<ul style="list-style-type: none"> -Broken throttle cable -Obstruction in air intake -Incorrect carb jetting -ETC limiting speed (1989 and newer) -Reverse speed limiter limiting speed -Incorrect ignition timing -Restricted exhaust system 	<ul style="list-style-type: none"> -Replace cable -Clean or repair air intake -Jet as per jetting chart -Repair ETC (refer to ETC troubleshooting) -Repair reverse speed limiter (refer to reverse speed limiter troubleshooting chart) -Check and adjust ignition timing -Repair or replace exhaust system
Engine has low power	<ul style="list-style-type: none"> -Cylinder, piston and ring wear or damage (check compression) -PVT not operating properly -Plugged exhaust 	<ul style="list-style-type: none"> -Repair cylinder and piston as needed -Clean, repair or replace as required -Repair or replace exhaust system
Piston failure Scoring Melted piston top Skirt breakage Excessive smoke and carbon buildup	<ul style="list-style-type: none"> -Lack of lubrication -Engine overheating -Lean air fuel ratio -Air leak in crankcase -Low octane fuel -Incorrect ignition timing -Incorrect spark plug -Piston fatigue from scoring -Excessive piston-to-cylinder clearance -Oil pump misadjusted -Oil pump cable not allowing pump to return to idle position 	<ul style="list-style-type: none"> -Fill oil tank and bleed pump -Check pump for proper operation, pinched vent line -Restricted oil delivery (lines, filter, check valve) -Oil pump drive gear failure -Install fan or check fan operation, test cooling system, loose or broken impeller -Clean carb and jet as per chart -Repair as needed -Use 87 octane minimum -Adjust timing as per specifications -Install recommended spark plug -Repair cylinder (Check air filter and air box) -Synchronize pump to carb (refer to oil pump bleeding and adjustment) -Lubricate or replace cable
Engine coolant found in counter balance assembly (Liquid cooled models)	<ul style="list-style-type: none"> -Water pump gasket -Water pump seal 	<ul style="list-style-type: none"> -Inspect/replace gasket -Replace

ENGINE

Piston Damage Troubleshooting, 2-Stroke Engines

(Some items may not apply to all engines)

- S Oil tank empty; oil wrong type or contaminated
- S Oil filter restricted
- S Oil pump inoperative (drive gear, cable, pump); oil check valve restricted or faulty
- S Lean carburetion or oil delivery due to: Vent lines pinched, kinked, or restricted (carburetor, oil tank, fuel tank etc.); Restricted oil or fuel passages, incorrect jetting for altitude/temperature
- S Inoperative fan or low fan RPM (check fan motor amp draw-should be less than 6.5 amps; low battery, fan switch or connections, wiring)
- S Cooling system, cooling fins, radiator fins restricted, air flow obstructed
- S Incorrect piston to cylinder clearance
- S Air leaks in intake tract / air intake ducts / mounting flange (damaged or loose)
- S Foreign material ingestion
- S Air in oil pump / lines
- S Air in cooling system / low coolant level
- S Poor fuel quality
- S Restricted exhaust
- S Incorrect ignition timing
- S Spark plug heat range incorrect
- S Fan blade incorrectly installed or damaged
- S Air box, carburetor, or exhaust modified

ENGINE

4 Stroke Troubleshooting

Engine Turns Over But Fails to Start

- S No fuel
- S Dirt in fuel line or filter
- S Fuel will not pass through fuel valve
- S Fuel pump inoperative/restricted
- S Tank vent plugged
- S Carb starter circuit
- S Engine flooded
- S Low compression (high cylinder leakage)
- S No spark (Spark plug fouled)

Engine Does Not Turn Over

- S Dead battery
- S Starter motor does not turn
- S Engine seized, rusted, or mechanical failure

Engine Runs But Will Not Idle

- S Restricted carburetor pilot system
- S Carburetor misadjusted
- S Choke not adjusted properly
- S Low compression
- S Crankcase breather restricted

Engine Idles But Will Not Rev Up

- S Spark plug fouled/weak spark
- S Broken throttle cable
- S Obstruction in air intake
- S Air box removed (reinstall all intake components)
- S Incorrect or restricted carburetor jetting
- S ETC switch limiting speed
- S Reverse speed limiter limiting speed
- S Carburetor vacuum slide sticking/diaphragm damaged
- S Incorrect ignition timing
- S Restricted exhaust system

Engine Has Low Power

- S Spark plug fouled
- S Cylinder, piston, ring, or valve wear or damage (check compression)
- S PVT not operating properly
- S Restricted exhaust muffler
- S Carburetor vacuum slide sticking/diaphragm damaged
- S Dirty carburetor

Piston Failure - Scoring

- S Lack of lubrication
- S Dirt entering engine through cracks in air filter or ducts
- S Engine oil dirty or contaminated

Excessive Smoke and Carbon Buildup

- S Excessive piston-to-cylinder clearance
- S Wet sumping
- S Worn rings, piston, or cylinder
- S Worn valve guides or seals
- S Restricted breather
- S Air filter dirty or contaminated

Low Compression

- S Decompressor stuck
- S Cylinder head gasket leak
- S No valve clearance or incorrectly adjusted
- S Cylinder or piston worn
- S Piston rings worn, leaking, broken, or sticking
- S Bent valve or stuck valve
- S Valve spring broken or weak
- S Valve not seating properly (bent or carbon accumulated on sealing surface)
- S Rocker arm sticking

Backfiring

- S ETC or speed limiter system malfunction
- S Fouled spark plug or incorrect plug or plug gap
- S Carburetion faulty - lean condition
- S Exhaust system air leaks
- S Ignition system faulty:
 - Spark plug cap cracked/broken
 - Ignition coil faulty
 - Ignition or kill switch circuit faulty
 - Ignition timing incorrect
 - Sheared flywheel key
- S Poor connections in ignition system
- S System wiring wet
- S Valve sticking
- S Air leaks in intake
- S Lean condition

ENGINE

4 Stroke Troubleshooting

EH42PL/EH50PL Cooling System Troubleshooting

Overheating

- S Low coolant level
- S Air in cooling system
- S Wrong type of coolant
- S Faulty pressure cap or system leaks
- S Restricted system (mud or debris in radiator fins or restriction to air flow, passages blocked in radiator, lines, pump, or water jacket)
- S Lean mixture (restricted jets, vents, fuel pump or fuel valve)
- S Fuel pump output weak
- S Restricted radiator (internally or cooling fins)
- S Water pump failure
- S Cooling system restriction
- S Cooling fan inoperative or turning too slowly (perform current draw test)
- S Ignition timing misadjusted
- S Low oil level
- S Spark plug incorrect heat range
- S Faulty hot light circuit
- S Thermostat stuck closed or not opening completely

Temperature Too Low

- S Thermostat stuck open

Leak at Water Pump Weep Hole

- S Faulty water pump mechanical seal (coolant leak)
- S Faulty pump shaft oil seal (oil leak)