

SAFETY.CAT.COM

3512C and 3516C MARINE AUXILIARY ENGINES

Maintenance Intervals

Excerpted from Operation & Maintenance Manual (SEBU8224-00-01)

i02616670

Maintenance Interval Schedule

SMCS Code: 1000; 4450; 7500

Factors that affect the oil change interval include the following factors: operating conditions, fuel type, oil type, and size of the oil sump . Scheduled oil sampling analyzes used oil in order to determine if the oil change interval is suitable for your specific engine.

In the absence of scheduled oil sampling, change the engine oil and filters according to the following intervals.

Engines with Shallow Oil Sumps - Every 250 Service Hours

Engines with a Standard Oil Sump - Every 500 Service Hours

Engines with a Deep Oil Sump - Every 1000 Service Hours

Refer to this Operation and Maintenance Manual, “Engine Oil and Filter - Change” in order to determine the oil change interval that is suitable for your specific engine.

Note: To determine the maintenance intervals for the overhauls, refer to this Operation and Maintenance Manual, “Maintenance Recommendations” .

Note: Ensure that the safety information, warnings, and instructions are read and understood before operation or maintenance procedures are performed.

Use the interval that occurs first in order to determine the maintenance interval from fuel consumption, service hours, or calendar time. Engines that operate in severe operating conditions may require more frequent maintenance.

Before each consecutive interval is performed, all of the maintenance requirements from the previous interval must also be performed.

When Required

Batteries - Replace	61
Battery or Battery Cable - Disconnect	62
Closed Crankcase Ventilation (CCV) Fumes Disposal Filter - Replace	63
Engine Air Cleaner Element (Dual Element) - Clean/Replace	74
Engine Air Cleaner Element (Single Element) - Clean/Replace	76
Fuel System - Prime	88

Daily

Air Starting Motor Lubricator Oil Level - Check	58
Air Tank Moisture and Sediment - Drain	59
Cooling System Coolant Level - Check	68
Driven Equipment - Inspect/Replace/Lubricate ...	73
Engine Air Cleaner Service Indicator - Inspect	79
Engine Oil Filter Differential Pressure - Check	81
Engine Oil Level - Check	81
Fuel Tank Water and Sediment - Drain	92
Instrument Panel - Inspect	93
Walk-Around Inspection	104

Initial 250 Service Hours

Engine Valve Lash - Inspect/Adjust	88
Fuel Injector - Inspect/Adjust	88
Speed Sensor - Clean/Inspect	101

Every 250 Service Hours

Battery Electrolyte Level - Check	61
Belts - Inspect/Adjust/Replace	62
Cooling System Coolant Sample (Level 1) - Obtain	69
Cooling System Supplemental Coolant Additive (SCA) - Test/Add	70
Engine Oil Sample - Obtain	82
Fuel Injector - Inspect/Adjust	88
Hoses and Clamps - Inspect/Replace	92

Initial 500 Hours (for New Systems, Refilled Systems, and Converted Systems)

Cooling System Coolant Sample (Level 2) - Obtain	70
--	----

Every 500 Service Hours

Air Shutoff - Test	56
Engine Oil and Filter - Change	83

Every 1000 Service Hours

Engine - Clean	73
Engine Crankcase Breather - Clean	80
Engine Oil and Filter - Change	83
Engine Protective Devices - Check	87
Fuel System Primary Filter - Clean/Inspect/Replace	89
Fuel System Secondary Filter - Replace	89

Every 2000 Service Hours

Air Starting Motor Lubricator Bowl - Clean	57
Crankshaft Vibration Damper - Inspect	72
Engine Mounts - Check	81

Every Year

Cooling System Coolant Sample (Level 2) - Obtain	70
--	----

Every 3000 Service Hours or 3 Years

Cooling System Coolant (DEAC) - Change	64
Cooling System Coolant Extender (ELC) - Add	67

Every 4000 Service Hours

Auxiliary Water Pump - Inspect	59
Engine Valve Lash - Inspect/Adjust	88
Fuel Injector - Inspect/Adjust	88

Every 6000 Service Hours or 6 Years

Air Shutoff Damper - Remove/Check	55
Alternator - Inspect	59
Cooling System Water Temperature Regulator - Replace	71
Prelube Pump - Inspect	101
Speed Sensor - Clean/Inspect	101
Starting Motor - Inspect	102
Turbocharger - Inspect	103
Water Pump - Inspect	105

Every 12 000 Service Hours or 6 Years

Cooling System Coolant (ELC) - Change	66
---	----

Overhaul

Aftercooler Core - Inspect/Clean	54
Maintenance Recommendations	94
Overhaul (Major)	95
Overhaul (Top End)	97
Overhaul Considerations	99

i02623956

Aftercooler Core - Inspect/Clean

SMCS Code: 1063-040; 1064-571

1. Remove the core. Refer to the Disassembly and Assembly Manual, "Aftercooler - Remove and Install" for the procedure.
2. Turn the aftercooler core on one side in order to remove debris. Remove the debris that is accessible.

NOTICE

Do not use a high concentration of caustic cleaner to clean the core. A high concentration of caustic cleaner can attack the internal metals of the core and cause leakage. Only use the recommended concentration of cleaner.

3. Back flush the core with cleaner.

Caterpillar recommends the use of Hydrosolv liquid cleaner. Table 15 lists Hydrosolv liquid cleaners that are available from your Caterpillar dealer.

Table 15

Hydrosolv Liquid Cleaners ⁽¹⁾		
Part Number	Description	Size
1U-5490	Hydrosolv 4165	19 L (5 US gallon)
174-6854	Hydrosolv 100	19 L (5 US gallon)

⁽¹⁾ Use a two to five percent concentration of the cleaner at temperatures up to 93°C (200°F). Refer to Application Guide, NEHS0526 or consult your Caterpillar dealer for more information.

4. Remove the drain plug.
5. Steam clean the core in order to remove any residue. Flush the fins of the aftercooler core. Remove any other trapped debris from the inside and from the outside of the core.

Note: Do not use high pressure when the fins are cleaned. High pressure can damage the fins.

6. Wash the core with hot, soapy water.
7. Flush the core thoroughly in order to remove residue and remaining debris. Flush the core with clean, fresh water until the water that is exiting the core is clear and free of debris.

WARNING

Personal injury can result from air pressure.

Personal injury can result without following proper procedure. When using pressure air, wear a protective face shield and protective clothing.

Maximum air pressure at the nozzle must be less than 205 kPa (30 psi) for cleaning purposes.

8. Dry the core with compressed air. Direct the air in the reverse direction of the normal flow.
9. Prior to installation, inspect any O-rings or seals for damage. If necessary, replace the O-rings or seals.
10. Inspect the core for trapped debris and cleanliness. If it is necessary, remove the debris and repeat the cleaning procedure.
11. Inspect the core for damage and perform a pressure test in order to detect leaks. Many shops that service radiators are equipped to perform pressure tests.
12. Install the core. Refer to Disassembly and Assembly Manual, "Aftercooler - Remove and Install" for the procedure.

For more information on cleaning the core, consult your Caterpillar dealer.

i02622938

Air Shutoff Damper - Remove/Check (if equipped)

SMCS Code: 1078-011; 1078-535




Illustration 33

g01286554

Typical air shutoff (back view)

- (1) Air shutoff gate
- (2) Damper assembly

The vibration damper on the air shutoff minimizes the vibration of the air shutoff gate when the engine is operating and the air shutoff gate is in the latched position. The components of the damper assembly must be removed in order to ensure correct performance of the damper.




Illustration 34

g01286567

Damper assembly

- (3) Plug
- (4) Seal ring
- (5) Housing
- (6) Spring
- (7) Plunger

1. The body of the damper should not be loosened or removed from the air shutoff when the plunger is removed. In order to remove the plunger without loosening or removing the damper, unscrew the plug with the following tools: a 6.35 mm (0.25 inch) Allen wrench and an open end wrench .
2. Check the seal ring for damage or wear. If necessary, replace the seal ring.
3. Inspect the internal parts of the vibration damper for wear or damage. Clean the components with 138-8440 component cleaner.




Illustration 35

g01286606

Damper plunger

4. Remove the plunger from the spring. Visually inspect the exposed end of the plunger for dirt, fouling, damage, and wear. If distance "A" is less than 18.3 mm (0.72 inch) or if a visual inspection reveals dirt, fouling, damage, or wear on the active end of the plunger, replace the plunger. Insert the tapered end of a clean, undamaged plunger into the spring. Install the open end of the spring into the plug. Apply 9S-3263 thread lock or apply 9S-4030 thread lock onto the threads of the plug. Screw the assembly into the damper body. The thread lock should cure for a minimum of 1 hour before the air shutoff is used.

i02624677

Air Shutoff - Test (Engines That Are Equipped with ADEM II or ADEM III Engine Control Modules (If equipped))

SMCS Code: 1078-081




Illustration 36 g01285348
Typical air shutoffs on a 3500B engine
(1) Air shutoffs




Illustration 37 g01285609
Left hand side air shutoff in the OPEN position




Illustration 38 g01285610
Right hand side air shutoff in the OPEN position

Refer to the Troubleshooting Guide, "Air Shutoff System" information in your Service Manual for further information about the electrical system for the air shutoff system.

Engines That Are Equipped with ADEM II Engine Control Modules

Note: Do not start the engine. Ensure that the engine control is in the "OFF" position.

1. Ensure that both air shutoff gates are latched in the OPEN position and ensure that both air shutoff switches are connected. Turn on the power to the engine control panel. Both air shutoff gates should remain open. If both air shutoff gates do not remain open, check the wiring for the air shutoff switches.
2. With the power for the engine control panel in the ON position, activate the "EMERGENCY STOP" switch. Both of the air shutoff gates should close. If both air shutoff gates close, proceed to step 3. If both air shutoff gates do not close, check the wiring for the air shutoff switches and check the wiring for the solenoids. Activate the "EMERGENCY STOP" switch again. When both air shutoff gates close, proceed to step 3.
3. Turn the power to the engine control panel to the OFF position. Ensure that the "EMERGENCY STOP" switch is in the RUN position. Latch only the right side air shutoff gate to the OPEN position. Turn the power for the engine control panel to the ON position. The right side air shutoff gate should close. If the right side air shutoff closes, proceed to step 4. If the right side air shutoff gate does not close, check the air shutoff switch for the right side air shutoff and check the wiring for the right side air shutoff. When the right side air shutoff closes, proceed to step 4.

4. Turn the power for the engine control panel to the OFF position. Latch only the left side air shutoff gate to the OPEN position. Turn the power for the engine control panel to the ON position. The left side air shutoff gate should close. If the left side air shutoff gate does not close, check the switch and the wiring for the left side air shutoff .

Note: Testing is only complete when the engine successfully passes step 1 through step 4.

5. Operate the engine normally. Ensure that the air shutoff gates continue to be latched.

Engines That Are Equipped with ADEM III Engine Control Modules

Note: Do not start the engine. Ensure that the engine control is in the "OFF" position.

1. Ensure that both air shutoff gates are latched in the OPEN position. Ensure that both air shutoff switches are connected. Turn the power for the engine control panel to the ON position. The air shutoff gates should remain in the OPEN positions. If the air shutoff gates do not remain in the OPEN positions, check the wiring for the air shutoffs. When step 1 has been successfully completed, proceed to step 2.
2. While the power for the engine control panel is in the ON position, activate the "EMERGENCY STOP" switch . Both air shutoff gates should close. If the air shutoff gates do not close, check the wiring for the air shutoffs and the wiring for the solenoids. Both air shutoff gates must close before proceeding to step 3.
3. Turn the power for the engine control panel to the OFF position. Reset the "EMERGENCY STOP" switch to the RUN position. Reset the right side air shutoff to the OPEN position. Turn the power for the engine control panel to the ON position. Select "Run/Start" on the engine control panel. **The engine should fail to start.** If the engine does not start, proceed to 4. If the engine starts, turn off the engine. Check the right side air shutoff. Check the wiring for the right side air shutoff. Retest the air shutoff. When the procedure in 3 is followed and the engine fails to start, proceed to 4.
4. Reset the "EMERGENCY STOP" switch to the RUN position. Set the power for the engine control panel to the ON position. Activate the "EMERGENCY STOP" switch . Both air shutoff gates should close. Set power for the engine control panel to the OFF position. Reset the "EMERGENCY STOP" switch to the RUN position. Reset the left side air shutoff to the OPEN position. Turn the power for the engine control panel to the ON position. Select "START/RUN" on the engine control panel. **The engine should fail to start.** If the engine does not start, proceed to 5. If the engine starts, turn off the engine. Check the left side air shutoff. Check the wiring for the left side air shutoff. Retest the left side air shutoff. When the procedure in step 4 is followed and the engine fails to start, proceed to 5.
5. Turn the power for the engine control panel to the ON position. Reset both air shutoffs. Start the engine. Disconnect only the right side air shutoff. Both air shutoff gates should close. The engine should shut down. If the engine does not shut down, use the "EMERGENCY STOP" switch to stop the engine. Check the wiring for both air shutoffs. Use the above procedure in order to retest the right side air shutoff. When the procedure in step 5 is followed and results of the test are successful, reconnect the right side air shutoff. Reset both air shutoffs.
6. Turn the power for the engine control panel to the ON position. Reset both air shutoffs. Start the engine. Disconnect only the left side air shutoff. Both air shutoff gates should close. The engine should shut down. If the engine does not shut down, use the "EMERGENCY STOP" switch to stop the engine. Check the wiring for both air shutoffs. Use the above procedure in order to retest the left side air shutoff. When the procedure in 6 is followed and the results of the test are successful, reconnect the right side air shutoff. Reset both air shutoffs.
7. Testing is complete only when the engine successfully passes steps 1 through 6.
8. Reset both air shutoffs. Ensure that the "EMERGENCY STOP" switch has been reset. Operate the engine normally.

i02654935

Air Starting Motor Lubricator Bowl - Clean

SMCS Code: 1451-070

If the engine is equipped with an air starting motor, use the following procedure:

⚠ WARNING

Personal injury can result from removing hoses or fittings in a pressure system.

Failure to relieve pressure can cause personal injury.

Do not disconnect or remove hoses or fittings until all pressure in the system has been relieved.

1. Ensure that the air supply to the lubricator is OFF.




Illustration 39 g01333332
(1) Filler plug
(2) Bowl
(3) Drain valve

2. Slowly loosen filler plug (1) in order to release the pressure from the lubricator.

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.

3. Place a suitable container under bowl (2) and open drain valve (3) in order to drain the oil from the bowl.
4. Remove bowl (2). Clean the bowl with warm water.

5. Dry the bowl. Inspect the bowl for cracks. If the bowl is cracked, replace the damaged bowl with a new bowl. Inspect the gasket. If the gasket is damaged, replace the gasket.
6. Install the bowl.
7. Make sure that drain valve (3) is closed.
8. For instructions on filling the lubricator, see this Operation and Maintenance Manual, "Air Starting Motor Lubricator Oil Level - Check" topic.

i02654969

Air Starting Motor Lubricator Oil Level - Check

SMCS Code: 1451-535

NOTICE

Never allow the lubricator bowl to become empty. The air starting motor will be damaged by a lack of lubrication. Ensure that sufficient oil is in the lubricator bowl.




Illustration 40 g01333366

1. Observe the oil level in sight gauge (3). If the oil level is less than 1/2, add oil to the lubricator bowl.

⚠ WARNING

Personal injury can result from removing hoses or fittings in a pressure system.

Failure to relieve pressure can cause personal injury.

Do not disconnect or remove hoses or fittings until all pressure in the system has been relieved.

2. Ensure that the air supply to the lubricator is OFF. Slowly loosen filler plug (4) in order to release pressure from the lubricator bowl.

3. Remove filler plug (4). Pour oil into the lubricator bowl. Use nondetergent SAE 10W oil for temperatures that are greater than 0 °C (32 °F). Use air tool oil for temperatures that are below 0 °C (32 °F).

4. Install filler plug (4).

Adjust the Lubricator

Note: Adjust the lubricator with a constant rate of air flow. After the adjustment, the lubricator will release oil in proportion to variations of the air flow.

1. Ensure that the fuel supply to the engine is OFF.

NOTICE

Do not crank the engine continuously for more than 30 seconds. Allow the starting motor to cool for two minutes before cranking the engine again.

2. Operate the air starting motor. Observe the drops of oil that are released in dome (1).

Note: Some lubricators have an adjustment screw rather than a knob.

3. If necessary, adjust the lubricator in order to release from one to three drops of oil per second. To increase the rate, turn knob (2) counterclockwise. To decrease the rate, turn the knob clockwise.

i00351324

Air Tank Moisture and Sediment - Drain

SMCS Code: 1466-543-M&S

Moisture and sediment in the air starting system can cause the following conditions:

- Freezing
- Corrosion of internal parts
- Malfunction of the air starting system

WARNING

When opening the drain valve, wear protective gloves, a protective face shield, protective clothing, and protective shoes. Pressurized air could cause debris to be blown and result in personal injury.

1. Open the drain valve that is on the bottom of the air tank. Allow the moisture and sediment to drain.
2. Close the drain valve.

i02084374

Alternator - Inspect

SMCS Code: 1405-040

Inspect the alternator for the following conditions:

- Proper connections
- Clean ports for cooling airflow
- Proper charging of the battery

Observe the ammeter during engine operation in order to ensure proper battery performance and/or proper performance of the electrical system.

Make repairs, if necessary. See the Service Manual for service procedures. Consult your Caterpillar dealer for assistance.

i02619426

Auxiliary Water Pump - Inspect (if equipped)

SMCS Code: 1371-040; 1371

Remove the auxiliary water pump from the engine. Refer to the Disassembly and Assembly Manual, "Auxiliary Water Pump - Remove" in order to remove the auxiliary water pump.

Refer to the Disassembly and Assembly Manual, "Auxiliary Water Pump - Disassemble" in order to disassemble the auxiliary water pump.

Impellers and seals require periodic inspection. Impellers have a service life that is limited. The service life depends on the engine operating conditions.

Inspect the components more frequently when the pump is exposed to debris, sand, or other abrasive materials. Inspect the components if the pump is operating at a differential pressure of more than 103 kPa (15 psi).

There are different types of pumps. Some pumps will have a cover that is bolted to the main pump body. Some pumps will have a clamp that holds the front part of the pump body to the main part of the pump body. The cover or the front part of the pump body must be removed in order to inspect the pump.

Pumps with a Cover




Illustration 41

g01136356

- (1) Plug
- (2) Bolt
- (3) Cover

1. Remove plug (1) and drain the water out of the pump.
2. Remove bolts (2) and cover (3).
3. Inspect the priming impeller, the wear plates for the priming impeller and the impeller for wear or damage. Inspect the pump housing for wear, damage or buildup.
4. Inspect the pump shaft and the impeller for excessive axial movement.
5. If wear or damage is found, replace the components which are worn or damaged. Use the proper repair kit for the pump.

Pumps with a Clamp




Illustration 42

g01136382

- (1) Plug
- (2) Clamp
- (3) Clamp
- (4) Front part of the pump body

1. Remove plug (1) and drain the water out of the pump.
2. Remove the water line and clamp (2), if necessary.
3. Loosen clamp (3) and remove the front part of the pump body (4).
4. Inspect the impeller, the wear plates and the wear ring for wear or damage. Inspect the pump housing for wear, damage or buildup.
5. Inspect the pump shaft and the impeller for excessive axial movement.
6. If wear or damage is found, replace the components which are worn or damaged. Use the proper repair kit for the pump.

Assembly and Installation of the Auxiliary Water Pump

Refer to the Disassembly and Assembly Manual, "Auxiliary Water Pump - Assemble" in order to assemble the auxiliary water pump.

Refer to the Disassembly and Assembly Manual, "Auxiliary Water Pump - Install" in order to install the auxiliary water pump onto the engine.

i02601752

Batteries - Replace

i01041029

SMCS Code: 1401-510

WARNING

Batteries give off combustible gases which can explode. A spark can cause the combustible gases to ignite. This can result in severe personal injury or death.

Ensure proper ventilation for batteries that are in an enclosure. Follow the proper procedures in order to help prevent electrical arcs and/or sparks near batteries. Do not smoke when batteries are serviced.

1. Turn the key start switch to the OFF position. Remove the key and all electrical loads.
2. Turn OFF the battery charger. Disconnect the charger.
3. The NEGATIVE "-" cable connects the NEGATIVE "-" battery terminal to the ground plane. Disconnect the cable from the NEGATIVE "-" battery terminal.
4. The POSITIVE "+" cable connects the POSITIVE "+" battery terminal to the starting motor. Disconnect the cable from the POSITIVE "+" battery terminal.

Note: Always recycle a battery. Never discard a battery. Return used batteries to an appropriate recycling facility.

5. Remove the used battery.
6. Install the new battery.

Note: Before connecting the cables, ensure that the key start switch is OFF.

7. Connect the cable from the starting motor to the POSITIVE "+" battery terminal.
8. Connect the cable from the ground plane to the NEGATIVE "-" battery terminal.

Battery Electrolyte Level - Check

SMCS Code: 1401-535-FLV

When the engine is not run for long periods of time or when the engine is run for short periods, the batteries may not fully recharge. Ensure a full charge in order to help prevent the battery from freezing.

WARNING

All lead-acid batteries contain sulfuric acid which can burn the skin and clothing. Always wear a face shield and protective clothing when working on or near batteries.

1. Remove the filler caps. Maintain the electrolyte level to the "FULL" mark on the battery.

If the addition of water is necessary, use distilled water. If distilled water is not available use clean water that is low in minerals. Do not use artificially softened water.
2. Check the condition of the electrolyte with the 245-5829 Coolant Battery Tester Refractometer.
3. Keep the batteries clean.

Clean the battery case with one of the following cleaning solutions:

- A mixture of 0.1 kg (0.2 lb) of baking soda and 1 L (1 qt) of clean water
- A mixture of 0.1 L (0.11 qt) of ammonia and 1 L (1 qt) of clean water

Thoroughly rinse the battery case with clean water.

Use a fine grade of sandpaper to clean the terminals and the cable clamps. Clean the items until the surfaces are bright or shiny. DO NOT remove material excessively. Excessive removal of material can cause the clamps to not fit properly. Coat the clamps and the terminals with 5N-5561 Silicone Lubricant, petroleum jelly or MPGM.

i01492654

Battery or Battery Cable - Disconnect

SMCS Code: 1401; 1402-029

WARNING

The battery cables or the batteries should not be removed with the battery cover in place. The battery cover should be removed before any servicing is attempted.

Removing the battery cables or the batteries with the cover in place may cause a battery explosion resulting in personal injury.

1. Turn the start switch to the OFF position. Turn the ignition switch (if equipped) to the OFF position and remove the key and all electrical loads.
2. Disconnect the negative battery terminal at the battery that goes to the start switch. Ensure that the cable cannot contact the terminal. When four 12 volt batteries are involved, the negative side of two batteries must be disconnected.
3. Tape the leads in order to help prevent accidental starting.
4. Proceed with necessary system repairs. Reverse the steps in order to reconnect all of the cables.

i02229322

Belts - Inspect/Adjust/Replace

SMCS Code: 1357-025; 1357-040; 1357-510

Inspection

Inspect the alternator belt and any accessory belts for wear and for cracking. Replace the belts if the belts are not in good condition.

Check the belt tension according to the information in the Service Manual, "Specifications".

Slippage of loose belts can reduce the efficiency of the driven components. Vibration of loose belts can cause unnecessary wear on the following components:

- Belts
- Pulleys
- Bearings

If the belts are too tight, unnecessary stress is placed on the components. This reduces the service life of the components.

Replacement

For applications that require multiple drive belts, replace the drive belts in matched sets. Replacing one drive belt of a matched set will cause the new drive belt to carry more load because the older drive belts are stretched. The additional load on the new drive belt could cause the new drive belt to fail.

Alternator Belt Adjustment




Illustration 43

g00960176

- (1) Adjusting nuts
- (2) Mounting bolt
- (3) Mounting bolt
- (4) Mounting bolt

1. Remove the drive belt guard.
2. Loosen mounting bolts (2), (3), and (4). Loosen adjusting nuts (1).
3. Turn adjusting nuts (1) in order to increase or decrease the drive belt tension.
4. Tighten adjusting nuts (1). Tighten mounting bolts (2), (3), and (4).
5. Reinstall the drive belt guard.

If new drive belts are installed, check the drive belt tension again after 30 minutes of engine operation at the rated rpm.

i02657797

Closed Crankcase Ventilation (CCV) Fumes Disposal Filter - Replace (If Equipped)

SMCS Code: 1317-510-FI




Illustration 44

g01294089

Typical example of the Closed Crankcase Ventilation (CCV) system

- (1) Return to the air inlet system
- (2) Fumes from crankcase breather
- (3) Oil drain to crankcase

The Closed Crankcase Ventilation (CCV) system requires the replacement of the fumes disposal filter. The service interval of the CCV will be affected by the following items:

- Engine load
- Concentration of soot
- Condition of the engine

The CCV is equipped with a service indicator. If the fumes disposal filter becomes plugged prior to the normal service interval, increased restriction of the filter will cause the vacuum to become positive. When the pressure continues to rise, the service indicator will show through the cap. The service indicator indicates the need for the fumes disposal filter to be changed. Reset the service indicator by using the following procedure:

Resetting the Service Indicator




Illustration 45

g01292899

1. Remove plastic cover (4).
2. Push down on service indicator (5).
3. Replace cover (4).
4. Replace the fumes disposal filter by using the following procedure:

Replacing the Fumes Disposal Filter

WARNING

Hot oil and hot components can cause personal injury. Do not allow hot oil or hot components to contact the skin.

Note: When possible, perform the maintenance while the engine is off.




Illustration 46

g01292905

1. Release latches (7) that hold the canister to filter base assembly (6).

Note: Removing canister (8) may be difficult while the engine is operating. The canister has negative air pressure while the engine is operating. This creates a vacuum.

2. Lower the canister in order to expose the element. There may be oil in the bottom of the canister. Avoid spilling the oil.
3. Remove the filter element by pulling down. Dispose of the used element properly.
4. Remove the O-ring assembly on the top end cap of the used element.
5. Replace the O-ring seal on the bottom of the filter base assembly.
6. Install the new O-ring on the top end cap of the element. Install the element into the correct place.
7. Replace the canister and align the canister with the boss on the filter base assembly.
8. Clamp the latches in the closed position.

i02417350

Cooling System Coolant (DEAC) - Change

SMCS Code: 1350-044

Clean the cooling system before the recommended maintenance interval if the following conditions exist:

- The engine overheats frequently.
- The coolant is foaming.
- Oil or fuel has entered the cooling system and the coolant is contaminated.

Drain the Cooling System

1. Stop the engine and allow the engine to cool. Close the water inlet for the separate circuit aftercooler (if equipped). Ensure that the engine will not start when the cooling system is drained.
2. Loosen the radiator filler cap slowly in order to relieve any pressure. Remove the radiator filler cap.




Illustration 47
(1) Coolant drain

g00750410




Illustration 48
Locations of the cooling system drain plugs

g00750410

- (1) Oil cooler
- (2) Jacket water pump
- (3) Engine block

Note: If the engine has a jacket water heater, drain the coolant from the heater.

3. Open the coolant drain. Remove the cooling system drain plugs. Allow the coolant to drain.

NOTICE

Dispose of used engine coolant properly or recycle. Various methods have been proposed to reclaim used coolant for reuse in engine cooling systems. The full distillation procedure is the only method acceptable by Caterpillar to reclaim the used coolant.

For information regarding the disposal and the recycling of used coolant, consult your Caterpillar dealer or consult Caterpillar Dealer Service Tools Group:

Outside U.S.A.: (309) 675-6277
 Inside U.S.A.: 1-800-542-TOOL
 Inside Illinois: 1-800-541-TOOL
 Canada: 1-800-523-TOOL
 CSTG COSA Geneva, Switzerland:
 41-22-849 40 56

Clean the Cooling System

NOTICE

Use of commercially available cooling system cleaners may cause damage to cooling system components. Use only cooling system cleaners that are approved for Caterpillar engines.

1. After the cooling system has been drained, flush the cooling system with clean water in order to remove any debris.
2. Close the cooling system drain. Clean the cooling system drain plugs and install the cooling system drain plugs.

NOTICE

Fill the cooling system no faster than 19 L (5 US gal) per minute to avoid air locks.

3. Fill the cooling system with a mixture of clean water and Caterpillar Fast Acting Cooling System Cleaner. Add .5 L (1 pint) of cleaner per 15 L (4 US gal) of the cooling system capacity. Install the radiator filler cap.
4. Open the water inlet for the separate circuit aftercooler (if equipped). Start the engine. Operate the engine for a minimum of 30 minutes with a coolant temperature of at least 82 °C (180 °F).
5. Stop the engine and allow the engine to cool. Close the water inlet for the separate circuit aftercooler (if equipped). Loosen the radiator filler cap slowly in order to relieve any pressure. Remove the radiator filler cap. Open the coolant drain. Remove the cooling system drain plugs. Allow the water to drain.

NOTICE

Improper or incomplete rinsing of the cooling system can result in damage to copper and other metal components.

To avoid damage to the cooling system, make sure to completely flush the cooling system with clear water. Continue to flush the system until all signs of the cleaning agent are gone.

6. Flush the cooling system with clean water until the water that drains is clean. Close the coolant drain. Clean the cooling system drain plugs and install the cooling system drain plugs. Open the water inlet for the separate circuit aftercooler (if equipped).

Cleaning a Cooling System that has Heavy Deposits or Plugging

Note: For the following procedure to be effective, there must be an active flow through the cooling system components.

1. After the cooling system has been drained, flush the cooling system with clean water in order to remove any debris.
2. Close the coolant drain. Clean the cooling system drain plugs and install the cooling system drain plugs.
3. Fill the cooling system with a mixture of clean water and Caterpillar Fast Acting Cooling System Cleaner. Add .5 L (1 pint) of cleaner per 3.8 to 7.6 L (1 to 2 US gal) of the cooling system capacity. Install the radiator filler cap.
4. Open the water inlet for the separate circuit aftercooler (if equipped). Start the engine. Operate the engine for a minimum of 90 minutes with a coolant temperature of at least 82 °C (180 °F).
5. Stop the engine and allow the engine to cool. Close the water inlet for the separate circuit aftercooler (if equipped). Loosen the radiator filler cap slowly in order to relieve any pressure. Remove the radiator filler cap. Open the coolant drain. Remove the cooling system drain plugs. Allow the water to drain.

NOTICE

Improper or incomplete rinsing of the cooling system can result in damage to copper and other metal components.

To avoid damage to the cooling system, make sure to completely flush the cooling system with clear water. Continue to flush the system until all signs of the cleaning agent are gone.

6. Flush the cooling system with clean water until the water that drains is clean. Close the cooling system drain. Clean the cooling system drain plugs and install the cooling system drain plugs.

Fill the Cooling System

Note: For information about the proper coolant to use, see this Operation and Maintenance Manual, "Refill Capacities and Recommendations" (Maintenance Section). For the capacity of the cooling system, see this Operation and Maintenance Manual, "Refill Capacities and Recommendations" (Maintenance Section).

NOTICE

Fill the cooling system no faster than 19 L (5 US gal) per minute to avoid air locks.

1. Fill the cooling system with coolant/antifreeze. After filling the cooling system, do not install the radiator filler cap.
2. Open the water inlet for the separate circuit aftercooler (if equipped). Start the engine. Operate the engine in order to purge the air from the cavities of the engine block. Allow the coolant to warm and allow the coolant level to stabilize. Stop the engine.
3. Check the coolant level. Maintain the coolant to the proper level on the sight gauge (if equipped). If a sight gauge is not equipped, maintain the coolant within 13 mm (.5 inch) below the bottom of the filler pipe.
4. Clean the radiator filler cap. Inspect the gaskets of the radiator filler cap. If the gaskets of the radiator filler cap are damaged, discard the old radiator filler cap and install a new radiator filler cap. If the gaskets of the radiator filler cap are not damaged, use a 9S-8140 Pressurizing Pump in order to pressure test the radiator filler cap. The correct pressure is stamped on the face of the radiator filler cap. If the radiator filler cap does not maintain the correct pressure, install a new radiator filler cap.
5. Start the engine. Inspect the cooling system for leaks and for proper operating temperature.

i02417402

Cooling System Coolant (ELC) - Change

SMCS Code: 1350-044-NL

Use only clean water to flush the cooling system when ELC (Extended Life Coolant) is drained and replaced.

Drain the Cooling System

1. Stop the engine and allow the engine to cool. Close the water inlet for the separate circuit aftercooler (if equipped). Ensure that the engine will not start when the cooling system is drained.
2. Loosen the radiator filler cap slowly in order to relieve any pressure. Remove the radiator filler cap.




Illustration 49

g00750410

(1) Coolant drain




Illustration 50

g00750411

Locations of the cooling system drain plugs

- (1) Oil cooler
- (2) Jacket water pump
- (3) Engine block

Note: If the engine has a jacket water heater, drain the coolant from the heater.

3. Open the coolant drain. Remove the cooling system drain plugs. Allow the coolant to drain.

NOTICE

Dispose of used engine coolant properly or recycle. Various methods have been proposed to reclaim used coolant for reuse in engine cooling systems. The full distillation procedure is the only method acceptable by Caterpillar to reclaim the used coolant.

For information regarding the disposal and the recycling of used coolant, consult your Caterpillar dealer or consult Caterpillar Dealer Service Tools Group:

Outside U.S.A.: (309) 675-6277
 Inside U.S.A.: 1-800-542-TOOL
 Inside Illinois: 1-800-541-TOOL
 Canada: 1-800-523-TOOL
 CSTG COSA Geneva, Switzerland:
 41-22-849 40 56

Clean the Cooling System

1. After the cooling system has been drained, flush the cooling system with clean water in order to remove any debris.
2. Close the coolant drain. Clean the drain plugs and install the drain plugs.

NOTICE

Fill the cooling system no faster than 19 L (5 US gal) per minute to avoid air locks.

3. Open the water inlet for the separate circuit aftercooler (if equipped). Fill the cooling system with clean water. Install the radiator filler cap. Operate the engine until the temperature reaches 49 °C (120 °F) to 66 °C (150 °F).
4. Stop the engine and allow the engine to cool. Close the water inlet for the separate circuit aftercooler (if equipped). Ensure that the engine will not start when the cooling system is drained. Loosen the radiator filler cap slowly in order to relieve any pressure. Remove the radiator filler cap.
5. Open the coolant drain. Remove the drain plugs. Allow the coolant to drain. Flush the cooling system with clean water. Close the coolant drain. Install the drain plugs.
6. Repeat Steps 3, 4, and 5.

Fill the Cooling System

NOTICE

Fill the cooling system no faster than 19 L (5 US gal) per minute to avoid air locks.

1. Fill the cooling system with ELC (Extended Life Coolant). After filling the cooling system, do not install the radiator filler cap.

2. Open the water inlet for the separate circuit aftercooler (if equipped). Start the engine. Operate the engine in order to purge the air from the cavities of the engine block. Allow the ELC to warm and allow the coolant level to stabilize. Stop the engine.
3. Check the coolant level. Maintain the coolant to the proper level on the sight gauge (if equipped). If a sight gauge is not equipped, maintain the coolant within 13 mm (.5 inch) below the bottom of the filler pipe.
4. Clean the radiator filler cap. Inspect the gaskets of the radiator cap. If the gaskets of the radiator filler cap are damaged, discard the old radiator filler cap and install a new radiator filler cap. If the gaskets of the radiator filler cap are not damaged, use a 9S-8140 Pressurizing Pump in order to pressure test the radiator filler cap. The correct pressure is stamped on the face of the radiator filler cap. If the radiator filler cap does not maintain the correct pressure, install a new radiator filler cap.
5. Start the engine. Inspect the cooling system for leaks and for proper operating temperature.

i02482066

Cooling System Coolant Extender (ELC) - Add

SMCS Code: 1352-544-NL

Cat ELC (Extended Life Coolant) does not require the frequent additions of any supplemental cooling additives which are associated with the present conventional coolants. The Cat ELC Extender only needs to be added once.

NOTICE

Use only Cat Extended Life Coolant (ELC) Extender with Cat ELC.

Do NOT use conventional supplemental coolant additive (SCA) with Cat ELC. Mixing Cat ELC with conventional coolants and/or conventional SCA reduces the Cat ELC service life.

Check the cooling system only when the engine is stopped and cool.

⚠ WARNING

Personal injury can result from hot coolant, steam and alkali.

At operating temperature, engine coolant is hot and under pressure. The radiator and all lines to heaters or the engine contain hot coolant or steam. Any contact can cause severe burns.

Remove cooling system pressure cap slowly to relieve pressure only when engine is stopped and cooling system pressure cap is cool enough to touch with your bare hand.

Do not attempt to tighten hose connections when the coolant is hot, the hose can come off causing burns.

Cooling System Coolant Additive contains alkali. Avoid contact with skin and eyes.

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.

1. Loosen the cooling system filler cap slowly in order to relieve pressure. Remove the cooling system filler cap.
2. It may be necessary to drain enough coolant from the cooling system in order to add the Cat ELC Extender.
3. Add Cat ELC Extender according to the requirements for your engine's cooling system capacity. Refer to the Operation and Maintenance Manual, "Refill Capacities and Recommendations" article for more information.
4. Clean the cooling system filler cap. Inspect the gaskets on the cooling system filler cap. Replace the cooling system filler cap if the gaskets are damaged. Install the cooling system filler cap.

i02158408

Cooling System Coolant Level - Check

SMCS Code: 1350-535-FLV

⚠ WARNING

Climbing equipment may be required to access this service point. Refer to the Operation and Maintenance Manual, "Mounting and Dismounting" topic for safety information.

Engines That Are Equipped With a Sight Gauge




Illustration 51

g00750429

- (1) Filler cap
- (2) Sight gauge

If the engine is equipped with a sight gauge, observe the position of the coolant in the sight gauge. At normal operating temperature, the proper coolant level is in the upper half of the sight gauge. If the coolant level is low, add the proper coolant mixture.

Engines That Are Not Equipped With a Sight Gauge

⚠ WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

Check the coolant level when the engine is stopped and cool. Check the coolant level only after the engine has been stopped and the cooling system filler cap is cool enough to touch with your bare hand.

Remove the cooling system filler cap slowly in order to relieve any pressure. Maintain the coolant within 13 mm (0.5 inch) below the bottom of the filler pipe.

Add Coolant

Note: For the proper coolant mixture to use, see this Operation and Maintenance Manual, "Refill Capacities and Recommendations" (Maintenance Section).

1. Stop the engine. Allow the engine to cool.
2. Remove the cooling system filler cap slowly in order to relieve any pressure. Pour the proper coolant mixture into the filler pipe.




Illustration 52
Gaskets

g00103639

3. Clean the cooling system filler cap. Inspect the gaskets of the cooling system filler cap. If the gaskets are damaged, replace the old cooling system filler cap with a new cooling system filler cap. Install the cooling system filler cap.
4. Start the engine. Inspect the cooling system for leaks.

i02603581

Cooling System Coolant Sample (Level 1) - Obtain

SMCS Code: 1350-008; 1395-008; 1395-554; 7542

Note: Obtaining a Coolant Sample (Level 1) is optional if the cooling system is filled with Cat ELC (Extended Life Coolant). Cooling systems that are filled with Cat ELC should have a Coolant Sample (Level 2) that is obtained at the recommended interval that is stated in the Maintenance Interval Schedule.

Note: Obtain a Coolant Sample (Level 1) if the cooling system is filled with any other coolant instead of Cat ELC. This includes the following types of coolants:

- Commercial long life coolants that meet the Caterpillar Engine Coolant Specification -1 (Caterpillar EC-1)
- Cat DEAC (Diesel Engine Antifreeze/Coolant)
- Commercial heavy-duty coolant/antifreeze

Table 16

Recommended Interval		
Type of Coolant	Level 1	Level 2
Cat DEAC	Every 250 Hours ⁽¹⁾	Yearly ⁽¹⁾⁽²⁾
Cat ELC	Optional ⁽²⁾	Yearly ⁽²⁾

⁽¹⁾ This is the recommended interval for coolant samples for all conventional heavy-duty coolant/antifreeze. This is also the recommended interval for coolant samples of commercial coolants that meet the Cat EC-1 specification for engine coolant.

⁽²⁾ The Level 2 Coolant Analysis should be performed sooner if a problem is suspected or identified.

NOTICE

Always use a designated pump for oil sampling, and use a separate designated pump for coolant sampling. Using the same pump for both types of samples may contaminate the samples that are being drawn. This contaminate may cause a false analysis and an incorrect interpretation that could lead to concerns by both dealers and customers.

Note: Level 1 results may indicate a need for Level 2 Analysis.

Obtain the sample of the coolant as close as possible to the recommended sampling interval. In order to receive the full effect of S·O·S analysis, you must establish a consistent trend of data. In order to establish a pertinent history of data, perform consistent samplings that are evenly spaced. Supplies for collecting samples can be obtained from your Caterpillar dealer.

Use the following guidelines for proper sampling of the coolant:

- Complete the information on the label for the sampling bottle before you begin to take the samples.
- Keep the unused sampling bottles stored in plastic bags.

i02417522

- Obtain coolant samples directly from the coolant sample port. You should not obtain the samples from any other location.
- Keep the lids on empty sampling bottles until you are ready to collect the sample.
- Place the sample in the mailing tube immediately after obtaining the sample in order to avoid contamination.
- Never collect samples from expansion bottles.
- Never collect samples from the drain for a system.

Submit the sample for Level 1 analysis.

For additional information about coolant analysis, see Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engine Fluids Recommendations" or consult your Caterpillar dealer.

i01987714

Cooling System Coolant Sample (Level 2) - Obtain

SMCS Code: 1350-008; 1395-008; 1395-554; 7542

NOTICE

Always use a designated pump for oil sampling, and use a separate designated pump for coolant sampling. Using the same pump for both types of samples may contaminate the samples that are being drawn. This contaminate may cause a false analysis and an incorrect interpretation that could lead to concerns by both dealers and customers.

Refer to Operation and Maintenance Manual, "Cooling System Coolant Sample (Level 1) - Obtain" for the guidelines for proper sampling of the coolant.

Submit the sample for Level 2 analysis.

For additional information about coolant analysis, see Special Publication, SEBU6251, "Caterpillar Commercial Diesel Engines Fluids Recommendations" or consult your Caterpillar dealer.

Cooling System Supplemental Coolant Additive (SCA) - Test/Add

SMCS Code: 1352-045; 1395-081

This maintenance procedure is required for conventional coolants such as DEAC and for mixtures of water and SCA. **This maintenance is NOT required for cooling systems that are filled with Extended Life Coolant.**

WARNING

Cooling system coolant additive contains alkali. To help prevent personal injury, avoid contact with the skin and eyes. Do not drink cooling system coolant additive.

Note: Caterpillar recommends an S-O-S coolant analysis (Level 1).

Test the Concentration of the SCA

Coolant/Antifreeze and SCA

NOTICE

Do not exceed the recommended six percent supplemental coolant additive concentration.

Test the concentration of the SCA with the 8T-5296 Coolant Conditioner Test Kit.

Water and SCA

NOTICE

Do not exceed the recommended eight percent supplemental coolant additive concentration.

Test the concentration of the SCA with the 8T-5296 Coolant Conditioner Test Kit. Use the instructions that follow:

1. Fill the syringe to the "1.0 ml" mark with the coolant.
2. Dispense the 1.0 mL coolant sample from the syringe into the empty mixing bottle.
3. Add tap water to the mixing bottle in order to bring the level up to the "10 ml" mark. Place the cap on the bottle and shake the bottle.

4. Add 2 to 3 drops of the “NITRITE INDICATOR SOLUTION B” to the mixing bottle. Move the bottle in a circular motion in order to mix the solution.
5. Add 1 drop of “NITRITE TEST SOLUTION A” to the mixing bottle. Move the bottle in a circular motion in order to mix the solution.
6. Repeat 5 until the solution changes color from red to light gray, green, or blue. Record the number of drops of “NITRITE TEST SOLUTION A” that were required to cause the color change.
7. Use Table 17 to interpret the results.

Table 17

Number of Drops	Concentration of SCA	Maintenance Required
Less than 25	Less than the recommended concentration of SCA	Add SCA. Retest the coolant.
25 to 30	The recommended concentration of SCA	None
More than 30	More than the recommended concentration of SCA	Remove the coolant. Replace with water only. Retest the coolant.

Add the SCA, If Necessary

WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

1. Remove the cooling system filler cap slowly.
- Note:** Always dispose of fluids according to local regulations.
2. If necessary, drain some coolant in order to allow space for the addition of the SCA.

NOTICE

Excessive supplemental coolant additive concentration can form deposits on the higher temperature surfaces of the cooling system, reducing the engine's heat transfer characteristics. Reduced heat transfer could cause cracking of the cylinder head and other high temperature components.

Excessive supplemental coolant additive concentration could also result in blockage of the heat exchanger, overheating, and/or accelerated wear of the water pump seal.

Do not exceed the recommended amount of supplemental coolant additive concentration.

3. Add the proper amount of SCA. For the proper amount of SCA, refer to this Operation and Maintenance Manual, “Refill Capacities and Recommendations” topic. The proper concentration of SCA depends on the type of coolant that is used. For the proper concentration of SCA, refer to Special Publication, SEBU6251, “Caterpillar Commercial Diesel Engine Fluids Recommendations”.
4. Clean the cooling system filler cap. Install the cooling system filler cap.

i02623972

Cooling System Water Temperature Regulator - Replace

SMCS Code: 1355-510

Replace the water temperature regulator before the water temperature regulator fails. This is a recommended preventive maintenance practice. Replacing the water temperature regulator reduces the chances for unscheduled downtime.

A water temperature regulator that fails in a partially opened position can cause overheating or overcooling of the engine.

A water temperature regulator that fails in the closed position can cause excessive overheating. Excessive overheating could result in cracking of the cylinder head or piston seizure problems.

A water temperature regulator that fails in the open position will cause the engine operating temperature to be too low during partial load operation. Low engine operating temperatures during partial loads could cause an excessive carbon buildup inside the cylinders. This excessive carbon buildup could result in an accelerated wear of the piston rings and wear of the cylinder liner.

NOTICE

Failure to replace your water temperature regulator on a regularly scheduled basis could cause severe engine damage.

Caterpillar engines incorporate a shunt design cooling system and require operating the engine with a water temperature regulator installed.

If the water temperature regulator is installed incorrectly, the engine may overheat, causing cylinder head damage. Ensure that the new water temperature regulator is installed in the original position. Ensure that the water temperature regulator vent hole is open.

Do not use liquid gasket material on the gasket or cylinder head surface.

Refer to two articles in the Disassembly and Assembly Manual, "Water Temperature Regulators - Remove and Water Temperature Regulators - Install" for the replacement procedure of the water temperature regulator, or consult your Caterpillar dealer.

Note: If only the water temperature regulators are replaced, drain the coolant from the cooling system to a level that is below the water temperature regulator housing.

i02623987

Crankshaft Vibration Damper - Inspect

SMCS Code: 1205-040

The crankshaft vibration damper limits the torsional vibration of the crankshaft. The visconic damper has a weight that is located inside a fluid filled case.

Damage to the crankshaft vibration damper or failure of the damper can increase torsional vibrations. This can result in damage to the crankshaft and to other engine components. A deteriorating damper can cause excessive gear train noise at variable points in the speed range.

A damper that is hot may be the result of excessive friction. This could be due to misalignment. Use an infrared thermometer to monitor the temperature of the damper during operation. If the temperature reaches 93 °C (200 °F), consult your Caterpillar dealer.

Inspect the damper for evidence of dents, cracks, and leaks of the fluid.

If a fluid leak is found, determine the type of fluid. The fluid in the damper is silicone. Silicone has the following characteristics: transparent, viscous, and smooth.

If the fluid leak is oil, inspect the crankshaft seals for leaks. If a leak is observed, replace all of the seals.

Inspect the damper and repair or replace the damper for any of the following reasons.

- The damper is dented, cracked, or leaking.
- The paint on the damper is discolored from heat.
- The engine has had a failure because of a broken crankshaft.
- The crankshaft bearings are showing excessive wear.
- There is a large amount of gear train wear that is not caused by a lack of oil.

Dampers With Sampling Ports




Illustration 53

g00819045

Some dampers have ports for fluid samples. If the damper has no external damage, collect a 2 to 5 mL sample of the damper fluid. The fluid should be analyzed in order to check for a loss of viscosity. Use the results of the analysis to determine if the damper should be rebuilt or replaced. Kits for fluid samples are available from the address that follows. Return the kits to the same address for analysis.

Hasse & Wrede GmbH
Mohriner Allee 30-42
D-12347 Berlin
Germany
Phone: 49 30 / 70 181 195
Fax: 49 30 / 70 09 08-11

Dampers Without Sampling Ports

Some dampers do not have a port for a fluid sample. These dampers must be rebuilt or the dampers must be replaced when one of the following criteria has been met:

- the damper has reached 20,000 hours of operation.
- the engine is undergoing a major overhaul.

Removal and Installation

Refer to the Disassembly and Assembly Manual, "Vibration Damper - Remove and Install" article or consult your Caterpillar dealer for information about damper replacement.

i00935098

Driven Equipment - Inspect/Replace/Lubricate

SMCS Code: 3279-040

Observe the driven equipment during operation. Look for the following items:

- Unusual noise and vibration
- Loose connections
- Damaged parts

Perform any maintenance that is recommended by the OEM of the driven equipment. Refer to the literature of the OEM of the driven equipment for the following service instructions.

- Inspection
- Lubricating grease and lubricating oil requirements
- Specifications for adjustment

- Replacement of components
- Requirements for ventilation

i01646701

Engine - Clean

SMCS Code: 1000-070

WARNING

Personal injury or death can result from high voltage.

Moisture can create paths of electrical conductivity.

Make sure that the electrical system is OFF. Lock out the starting controls and tag the controls "DO NOT OPERATE".

NOTICE

Accumulated grease and oil on an engine is a fire hazard. Keep the engine clean. Remove debris and fluid spills whenever a significant quantity accumulates on the engine.

Periodic cleaning of the engine is recommended. Steam cleaning the engine will remove accumulated oil and grease. A clean engine provides the following benefits:

- Easy detection of fluid leaks
- Maximum heat transfer characteristics
- Ease of maintenance

Note: Caution must be used in order to prevent electrical components from being damaged by excessive water when you clean the engine. Avoid electrical components such as the alternator, the starter, and the ECM.

i01553486

Engine Air Cleaner Element (Dual Element) - Clean/Replace

SMCS Code: 1051; 1054-037

NOTICE

Never run the engine without an air cleaner element installed. Never run the engine with a damaged air cleaner element. Do not use air cleaner elements with damaged pleats, gaskets or seals. Dirt entering the engine causes premature wear and damage to engine components. Air cleaner elements help to prevent air-borne debris from entering the air inlet.

NOTICE

Never service the air cleaner element with the engine running since this will allow dirt to enter the engine.

Servicing the Air Cleaner Elements

If the air cleaner element becomes plugged, the air can split the material of the air cleaner element. Unfiltered air will drastically accelerate internal engine wear. Your Caterpillar dealer has the proper air cleaner elements for your application. Consult your Caterpillar dealer for the correct air cleaner element.

- Check the precleaner (if equipped) daily for accumulation of dirt and debris. Remove any dirt and debris, as needed.
- Operating conditions (dust, dirt and debris) may require more frequent service of the air cleaner element.
- The air cleaner element may be cleaned up to six times if the element is properly cleaned and inspected.
- The air cleaner element should be replaced at least one time per year. This replacement should be performed regardless of the number of cleanings.

Replace the dirty paper air cleaner elements with clean air cleaner elements. Before installation, the air cleaner elements should be thoroughly checked for tears and/or holes in the filter material. Inspect the gasket or the seal of the air cleaner element for damage. Maintain a supply of suitable air cleaner elements for replacement purposes.

Dual Element Air Cleaners

The dual element air cleaner contains a primary air cleaner element and a secondary air cleaner element. The primary air cleaner element can be used up to six times if the element is properly cleaned and inspected. The primary air cleaner element should be replaced at least one time per year. This replacement should be performed regardless of the number of cleanings.

The secondary air cleaner element is not serviceable or washable. The secondary air cleaner element should be removed and discarded for every three cleanings of the primary air cleaner element. When the engine is operating in environments that are dusty or dirty, air cleaner elements may require more frequent replacement.




Illustration 54

g00736431

- (1) Cover
- (2) Primary air cleaner element
- (3) Secondary air cleaner element
- (4) Turbocharger air inlet

1. Remove the cover. Remove the primary air cleaner element.
2. The secondary air cleaner element should be removed and discarded for every three cleanings of the primary air cleaner element.

Note: Refer to "Cleaning the Primary Air Cleaner Elements".

3. Cover the turbocharger air inlet with tape in order to keep dirt out.
4. Clean the inside of the air cleaner cover and body with a clean, dry cloth.
5. Remove the tape for the turbocharger air inlet. Install the secondary air cleaner element. Install a primary air cleaner element that is new or cleaned.
6. Install the air cleaner cover.
7. Reset the air cleaner service indicator.

Cleaning the Primary Air Cleaner Elements

NOTICE

Caterpillar recommends certified air filter cleaning services that are available at Caterpillar dealers. The Caterpillar cleaning process uses proven procedures to assure consistent quality and sufficient filter life.

Observe the following guidelines if you attempt to clean the filter element:

Do not tap or strike the filter element in order to remove dust.

Do not wash the filter element.

Use low pressure compressed air in order to remove the dust from the filter element. Air pressure must not exceed 207 kPa (30 psi). Direct the air flow up the pleats and down the pleats from the inside of the filter element. Take extreme care in order to avoid damage to the pleats.

Do not use air filters with damaged pleats, gaskets, or seals. Dirt entering the engine will cause damage to engine components.

The primary air cleaner element can be used up to six times if the element is properly cleaned and inspected. When the primary air cleaner element is cleaned, check for rips or tears in the filter material. The primary air cleaner element should be replaced at least one time per year. This replacement should be performed regardless of the number of cleanings.

Use clean primary air cleaner elements while dirty elements are being cleaned.

NOTICE

Do not clean the air cleaner elements by bumping or tapping. This could damage the seals. Do not use elements with damaged pleats, gaskets or seals. Damaged elements will allow dirt to pass through. Engine damage could result.

Visually inspect the primary air cleaner elements before cleaning. Inspect the air cleaner elements for damage to the seal, the gaskets, and the outer cover. Discard any damaged air cleaner elements.

There are two common methods that are used to clean primary air cleaner elements:

- Pressurized air
- Vacuum cleaning

Pressurized Air

Pressurized air can be used to clean primary air cleaner elements that have not been cleaned more than two times. Pressurized air will not remove deposits of carbon and oil. Use filtered, dry air with a maximum pressure of 207 kPa (30 psi).




Illustration 55

g00281692

Note: When the primary air cleaner elements are cleaned, always begin with the clean side (inside) in order to force dirt particles toward the dirty side (outside).

Aim the hose so that the air flows inside the element along the length of the filter in order to help prevent damage to the paper pleats. Do not aim the stream of air directly at the primary air cleaner element. Dirt could be forced further into the pleats.

Note: Refer to “Inspecting the Primary Air Cleaner Elements”.

Vacuum Cleaning

Vacuum cleaning is a good method for cleaning primary air cleaner elements which require daily cleaning because of a dry, dusty environment. Cleaning with pressurized air is recommended prior to vacuum cleaning. Vacuum cleaning will not remove deposits of carbon and oil.

Note: Refer to “Inspecting the Primary Air Cleaner Elements”.

Inspecting the Primary Air Cleaner Elements




Illustration 56

g00281693

Inspect the clean, dry primary air cleaner element. Use a 60 watt blue light in a dark room or in a similar facility. Place the blue light in the primary air cleaner element. Rotate the primary air cleaner element. Inspect the primary air cleaner element for tears and/or holes. Inspect the primary air cleaner element for light that may show through the filter material. If it is necessary in order to confirm the result, compare the primary air cleaner element to a new primary air cleaner element that has the same part number.

Do not use a primary air cleaner element that has any tears and/or holes in the filter material. Do not use a primary air cleaner element with damaged pleats, gaskets or seals. Discard damaged primary air cleaner elements.

Storing Primary Air Cleaner Elements

If a primary air cleaner element that passes inspection will not be used, the primary air cleaner element can be stored for future use.




Illustration 57

g00281694

Do not use paint, a waterproof cover, or plastic as a protective covering for storage. An airflow restriction may result. To protect against dirt and damage, wrap the primary air cleaner elements in Volatile Corrosion Inhibited (VCI) paper.

Place the primary air cleaner element into a box for storage. For identification, mark the outside of the box and mark the primary air cleaner element. Include the following information:

- Date of cleaning
- Number of cleanings

Store the box in a dry location.

i01553508

Engine Air Cleaner Element (Single Element) - Clean/Replace

SMCS Code: 1051; 1054-037

NOTICE

Never run the engine without an air cleaner element installed. Never run the engine with a damaged air cleaner element. Do not use air cleaner elements with damaged pleats, gaskets or seals. Dirt entering the engine causes premature wear and damage to engine components. Air cleaner elements help to prevent airborne debris from entering the air inlet.

NOTICE

Never service the air cleaner element with the engine running since this will allow dirt to enter the engine.

Servicing the Air Cleaner Elements

If the air cleaner element becomes plugged, the air can split the material of the air cleaner element. Unfiltered air will drastically accelerate internal engine wear. Your Caterpillar dealer has the proper air cleaner elements for your application. Consult your Caterpillar dealer for the correct air cleaner element.

- Check the precleaner (if equipped) daily for accumulation of dirt and debris. Remove any dirt and debris, as needed.
- Operating conditions (dust, dirt and debris) may require more frequent service of the air cleaner element.
- The air cleaner element may be cleaned up to six times if the element is properly cleaned and inspected.

- The air cleaner element should be replaced at least one time per year. This replacement should be performed regardless of the number of cleanings.

Replace the dirty paper air cleaner elements with clean air cleaner elements. Before installation, the air cleaner elements should be thoroughly checked for tears and/or holes in the filter material. Inspect the gasket or the seal of the air cleaner element for damage. Maintain a supply of suitable air cleaner elements for replacement purposes.




Illustration 58

g00735127

- (1) Cover
(2) Air cleaner element
(3) Turbocharger air inlet

1. Remove the air cleaner cover. Remove the air cleaner element.

Note: Refer to “Cleaning the Air Cleaner Elements”.

2. Cover the air inlet with tape in order to keep dirt out.
3. Clean the inside of the air cleaner cover and body with a clean, dry cloth.
4. Remove the tape for the air inlet. Install an air cleaner element that is new or cleaned.
5. Install the air cleaner cover.
6. Reset the air cleaner service indicator.

Cleaning the Air Cleaner Elements

NOTICE

Caterpillar recommends certified air filter cleaning services that are available at Caterpillar dealers. The Caterpillar cleaning process uses proven procedures to assure consistent quality and sufficient filter life.

Observe the following guidelines if you attempt to clean the filter element:

Do not tap or strike the filter element in order to remove dust.

Do not wash the filter element.

Use low pressure compressed air in order to remove the dust from the filter element. Air pressure must not exceed 207 kPa (30 psi). Direct the air flow up the pleats and down the pleats from the inside of the filter element. Take extreme care in order to avoid damage to the pleats.

Do not use air filters with damaged pleats, gaskets, or seals. Dirt entering the engine will cause damage to engine components.

The air cleaner element can be used up to six times if the element is properly cleaned and inspected. When the air cleaner element is cleaned, check for rips or tears in the filter material. The air cleaner element should be replaced at least one time per year. This replacement should be performed regardless of the number of cleanings.

Use clean air cleaner elements while dirty elements are being cleaned.

NOTICE

Do not clean the air cleaner elements by bumping or tapping. This could damage the seals. Do not use elements with damaged pleats, gaskets or seals. Damaged elements will allow dirt to pass through. Engine damage could result.

Visually inspect the air cleaner elements before cleaning. Inspect the air cleaner elements for damage to the seal, the gaskets, and the outer cover. Discard any damaged air cleaner elements.

There are two common methods that are used to clean air cleaner elements:

- Pressurized air
- Vacuum cleaning

Pressurized Air

Pressurized air can be used to clean air cleaner elements that have not been cleaned more than two times. Pressurized air will not remove deposits of carbon and oil. Use filtered, dry air with a maximum pressure of 207 kPa (30 psi).




Illustration 59

g00281692

Note: When the air cleaner elements are cleaned, always begin with the clean side (inside) in order to force dirt particles toward the dirty side (outside).

Aim the hose so that the air flows inside the element along the length of the filter in order to help prevent damage to the paper pleats. Do not aim the stream of air directly at the air cleaner element. Dirt could be forced further into the pleats.

Note: Refer to “Inspecting the Air Cleaner Elements”.

Vacuum Cleaning

Vacuum cleaning is a good method for cleaning air cleaner elements which require daily cleaning because of a dry, dusty environment. Cleaning with pressurized air is recommended prior to vacuum cleaning. Vacuum cleaning will not remove deposits of carbon and oil.

Note: Refer to “Inspecting the Air Cleaner Elements”.

Inspecting the Air Cleaner Elements




Illustration 60

g00281693

Inspect the clean, dry air cleaner element. Use a 60 watt blue light in a dark room or in a similar facility. Place the blue light in the air cleaner element. Rotate the air cleaner element. Inspect the air cleaner element for tears and/or holes. Inspect the air cleaner element for light that may show through the filter material. If it is necessary in order to confirm the result, compare the air cleaner element to a new air cleaner element that has the same part number.

Do not use an air cleaner element that has any tears and/or holes in the filter material. Do not use an air cleaner element with damaged pleats, gaskets or seals. Discard damaged air cleaner elements.

Storing Air Cleaner Elements

If an air cleaner element that passes inspection will not be used, the air cleaner element can be stored for future use.




Illustration 61

g00281694

Do not use paint, a waterproof cover, or plastic as a protective covering for storage. An airflow restriction may result. To protect against dirt and damage, wrap the air cleaner elements in Volatile Corrosion Inhibited (VCI) paper.

Place the air cleaner element into a box for storage. For identification, mark the outside of the box and mark the air cleaner element. Include the following information:

- Date of cleaning
- Number of cleanings

Store the box in a dry location.

i00641711

Engine Air Cleaner Service Indicator - Inspect

SMCS Code: 7452-040




Illustration 62

g00291942

Typical air cleaner service indicator that is mounted on the air cleaner housing

An air cleaner service indicator may be mounted on the air cleaner element or in a remote location.

Some vessels are equipped with a low air pressure indicator that monitors the inlet air pressure. This indicator measures air pressure before the air is drawn through the air cleaner element. Then, the indicator monitors the pressure level after the air has passed through the air cleaner element. As the air cleaner element becomes dirty, this air cleaner pressure differential rises.

Some vessels may be equipped with a different air cleaner indicator.

If your vessel is equipped with a different type of air cleaner indicator, follow the recommendations for the vessel. You can also follow the recommendations in the air cleaner OEM in order to service the air cleaner element.




Illustration 63

g00103777

Typical Air Cleaner Service Indicator

Observe the air cleaner service indicator. You should clean the air cleaner element, or you should replace the air cleaner element under two conditions:

- The yellow diaphragm enters the red zone.
- The service indicator displays the red color at any time.
- The red piston locks in the visible position.

Test the Air Cleaner Service Indicator

Air cleaner service indicators are important, inexpensive instruments. Two methods can be used to test the service indicator.

- Check for ease of resetting. The service indicator should reset in less than three pushes.
- Check the movement of the yellow core when the engine is accelerated to the engine rated rpm. The yellow core should latch at the approximate greatest vacuum that is attained.

The air cleaner service indicator should be replaced under certain conditions and at certain times:

- The service indicator does not reset easily.
- The yellow core does not latch at the greatest vacuum.
- The engine is used for a year.
- The engine is overhauled.
- Major engine components are replaced.

Note: Replace the air cleaner service indicator often whenever you operate in a severely dusty environment.

If the new service indicator will not reset, the hole for the service indicator may be plugged.

Note: When a new service indicator is installed, excessive force may crack the top of the service indicator. Tighten the service indicator to a torque of 2 N·m (18 lb in).

Service the Air Cleaner Service Indicator

NOTICE

Never run the engine without an air cleaner element installed. Never run the engine with a damaged air cleaner element. Do not use air cleaner elements with damaged pleats, gaskets or seals. Dirt entering the engine causes premature wear and damage to engine components. Air cleaner elements help to prevent air-borne debris from entering the air inlet.

NOTICE

Never service the air cleaner element with the engine running since this will allow dirt to enter the engine.

If the air cleaner element becomes plugged, the air can split the filter material. Unfiltered air will drastically accelerate internal engine wear. Your Caterpillar dealer has air filter elements for this unit. Consult your Caterpillar dealer for the correct air cleaner element.

If the air cleaner service indicator appears red at any time, clean the air cleaner element or install a new air cleaner element. At 250 hour intervals, clean the air cleaner element or replace the air cleaner element .

Refer to the Operation and Maintenance Manual (Maintenance Section) for more information on servicing the air cleaner element.

i01225429

Engine Crankcase Breather - Clean

SMCS Code: 1317-070

If the crankcase breather is not maintained on a regular basis, the crankcase breather will become plugged. A plugged crankcase breather will cause excessive crankcase pressure that may cause crankshaft seal leakage.




Illustration 64

g00597463

1. Loosen clamp (1). Slide the clamp down on tube (2).
2. Loosen clamps (3). Remove both breathers as a unit.




Illustration 65

g00597465

3. Remove O-ring seals (4) from the valve covers. Inspect the O-ring seals for good condition. Obtain new O-ring seals, if necessary.




Illustration 66

g00597466

4. Remove two clamps (6). Remove both breathers (5) from hose tee (7).

Inspect the hose tee for cracks. If the tee is cracked, discard the old tee and obtain a new tee for installation.

- Turn the breathers upside-down in order to inspect the condition of the breather elements.

Clean the breather elements with clean, nonflammable solvent. If the breather elements remain contaminated after the cleaning, discard the breathers and obtain new breathers. Do not attempt to disassemble the breathers.

Allow the breather elements to dry before installation.

Note: Coat the rubber parts with clean engine oil or petroleum jelly in order to make installation easier.

- Place clamps (6) over the parts of hose tee (7) that will receive breathers (5). Install the breathers into the tee. Tighten the clamps to the torque that is listed in the Service Manual, "Specifications".
- Coat O-ring seals (4) with clean engine oil. Place the O-ring seals on the valve covers.
- Place clamps (3) around the parts of the breathers that will be attached to the valve covers. Install both breathers as a unit. Tighten the clamps.
- Place clamp (1) on the part of the hose tee that will receive tube (2). Install the tube into the hose tee. Tighten the clamp to the torque that is listed in the Service Manual, "Specifications".

i01786814

Engine Mounts - Check

SMCS Code: 1152-535

Misalignment of the engine and the driven equipment will cause extensive damage. Excessive vibration can lead to misalignment. Excessive vibration of the engine and the driven equipment can be caused by the following conditions:

- Improper mounting
- Loose bolts
- Deterioration of the isolators

Ensure that the mounting bolts are tightened to the proper torque. For standard torques, see Specifications, SENR3130, "Torque Specifications".

Ensure that the isolators are free of oil and contamination. Inspect the isolators for deterioration. Ensure that the bolts for the isolators are tightened to the proper torque.

Replace any isolator that shows deterioration. For more information, see the literature that is provided by the OEM of the isolators. Also see the Application and Installation Guide for the engine. Consult your Caterpillar dealer for assistance.

i02110431

Engine Oil Filter Differential Pressure - Check

SMCS Code: 1308-535

Observe the oil filter differential pressure frequently during engine operation.



Oil Filter Differential Pressure (Restriction)

– This gauge indicates the difference in pressure between the inlet side and the outlet side of the engine oil filters. As the oil filter elements become plugged, oil filter differential pressure will increase.

The nominal oil filter differential pressure during normal engine operation is approximately 60 kPa (9 psi).

Replace the oil filter elements when the oil filter differential pressure reaches 103 kPa (15 psi).

For instructions on replacement of the oil filter elements, see this Operation and Maintenance Manual, "Engine Oil and Filter - Change" topic.

i02418058

Engine Oil Level - Check

SMCS Code: 1348-535-FLV

The most accurate check of the engine oil level is obtained when the engine is stopped.




Illustration 67

g01208341

- (1) Filler cap
- (2) Engine oil level gauge (dipstick)

1. Remove filler cap (1) in order to ensure that the crankcase pressure is equal to the atmospheric pressure.

Excess pressure or a slight vacuum will affect engine oil level that is measured.

2. Ensure that engine oil level gauge (2) is seated.




Illustration 68

g00735162

- (3) "ENGINE STOPPED WITH OIL COLD" side
- (4) "ENGINE AT LOW IDLE WITH WARM OIL" side
- (5) "ADD" mark
- (6) "FULL" mark

- a. If the engine is stopped, remove the engine oil level gauge. Observe the engine oil level on "ENGINE STOPPED WITH OIL COLD" side (3).
- b. If the engine is operating, reduce the engine speed to low idle. Remove the engine oil level gauge and observe the engine oil level on "ENGINE AT LOW IDLE WITH WARM OIL" side (4).

The engine oil level should be between "ADD" mark (5) and "FULL" mark (6).

NOTICE

Engine damage can occur if the crankcase is filled above the "FULL" mark on the oil level gauge (dipstick).

An overfull crankcase can cause the crankshaft to dip into the oil. This will reduce the power that is developed and also force air bubbles into the oil. These bubbles (foam) can cause the following problems: reduction of the oil's ability to lubricate, reduction of oil pressure, inadequate cooling, oil blowing out of the crankcase breathers, and excessive oil consumption.

Excessive oil consumption will cause deposits to form on the pistons and in the combustion chamber. Deposits in the combustion chamber lead to the following problems: guttering of the valves, packing of carbon under the piston rings, and wear of the cylinder liner.

If the oil level is above the "FULL" mark on the oil level gauge, drain some of the oil immediately.

3. If necessary, add engine oil. For the correct engine oil to use, refer to this Operation and Maintenance Manual, "Refill Capacities and Recommendations" topic (Maintenance Section). Do not fill the crankcase above the "FULL" mark on the engine oil level gauge. Clean the filler cap (1). Install the filler cap.

4. Record the amount of engine oil that is added. For the next engine oil sample and analysis, include the total amount of engine oil that has been added since the previous oil change. This will help to provide the most accurate analysis.

i01928733

Engine Oil Sample - Obtain

SMCS Code: 1348-554-SM

In addition to a good preventive maintenance program, Caterpillar recommends using S-O-S oil analysis at regularly scheduled intervals in order to monitor the condition of the engine and the maintenance requirements of the engine.

Obtain the Sample and the Analysis



Hot oil and hot components can cause personal injury. Do not allow hot oil or hot components to contact the skin.

Before you take the oil sample, complete the Label, PEEP5031 for identification of the sample. In order to help obtain the most accurate analysis, provide the following information:

- Engine model
- Service hours on the engine
- The number of hours that have accumulated since the last oil change
- The amount of oil that has been added since the last oil change

To ensure that the sample is representative of the oil in the crankcase, obtain a warm, well mixed oil sample.

To avoid contamination of the oil samples, the tools and the supplies that are used for obtaining oil samples must be clean.




Illustration 69

g01003274

The engine oil sampling valve (if equipped) is located on the engine oil cooler.

Caterpillar recommends using the sampling valve in order to obtain oil samples. The quality and the consistency of the samples are better when the sampling valve is used. The location of the sampling valve allows oil that is flowing under pressure to be obtained during normal engine operation.

The 169-8373 Fluid Sampling Bottle is recommended for use with the sampling valve. The fluid sampling bottle includes the parts that are needed for obtaining oil samples. Instructions are also provided.

NOTICE

Do not use the same vacuum sampling pump for extracting oil samples that is used for extracting coolant samples.

A small residue of either type sample may remain in the pump and may cause a false positive analysis for the sample being taken.

Always use a designated pump for oil sampling and a designated pump for coolant sampling.

Failure to do so may cause a false analysis which could lead to customer and dealer concerns.

If the engine is not equipped with a sampling valve, use the 1U-5718 Vacuum Pump. The pump is designed to accept sampling bottles. Disposable tubing must be attached to the pump for insertion into the sump.

For instructions, see Special Publication, PEHP6001, "How To Take A Good Oil Sample". Consult your Caterpillar dealer for complete information and assistance in establishing an S-O-S program for your engine.

i02622330

Engine Oil and Filter - Change

SMCS Code: 1318-510

If the engine is equipped with duplex oil filters, the engine oil filter elements can be changed while the engine is in operation. This is useful if the oil filter elements require more frequent replacement than the engine oil. Refer to "Replacing the Engine Oil Filters During Engine Operation".

The oil change interval can be affected by several factors:

- Air/fuel ratio
- Ambient air conditions
- Engine application
- Fuel type
- Oil type
- Size of the oil sump

The S-O-S oil analysis program analyzes used oil in order to determine if the oil change interval is suitable for your specific engine. In the absence of S-O-S oil analysis, change the engine oil and filters according to the interval that is listed in Table 18.

Table 18

Engine Oil Change Intervals		
Engine	Sump Capacity	Oil Change Interval
Engines With a Shallow Sump		
3508C	104 L (27 US gal)	Every 250 Service Hours
3512C	152 L (40 US gal)	
3516C	204 L (53 US gal)	
Engines With a Standard Sump		
3508C	227 L (60 US gal)	Every 500 Service Hours
3512C	318 L (84 US gal)	
3516C	405 L (107 US gal)	
Engines With a Deep Sump		
3508C	443 L (117 US gal)	Every 1000 Service Hours
3512C	625 L (165 US gal)	
3516C	807 L (213 US gal)	

Drain the Oil

WARNING

Hot oil and components can cause personal injury.

Do not allow hot oil or components to contact skin.

Do not drain the oil when the engine is cold. As the oil cools, waste particles settle on the bottom of the oil pan. The waste particles are not removed when the cold oil is drained. Drain the crankcase when the oil is warm. This method allows proper draining of the waste particles that are suspended in the oil.

Failure to follow this recommended procedure will allow the waste particles to be recirculated through the engine lubrication system with the new oil.

1. After the engine has been operated at normal operating temperature, STOP the engine.
2. Drain the oil according to the equipment on the engine.

Note: Drain the oil into a suitable container. DO NOT drain the oil into the bilge sump. Dispose of the oil according to local regulations.




Illustration 70

g00574534

Oil drain plug

Note: If a suction device is used in order to remove the oil from the oil pan, ensure that the suction device is clean. This will prevent dirt from entering into the oil pan. Be careful not to strike the engine oil suction tubes or the piston cooling jets.

- a. If the engine does not have a drain valve or a pump, remove an oil drain plug. Allow the oil to drain. After the oil has drained, clean the drain plug and clean the fitting for the drain plug. Install the drain plug. Tighten the drain plug to $145 \pm 15 \text{ N}\cdot\text{m}$ ($105 \pm 10 \text{ lb ft}$).
 - b. If the engine has an oil drain valve, open the valve. After the oil has drained, close the valve.
 - c. If the engine has a pump for removing dirty oil, connect a hose to the outlet of the pump. Place the hose in a suitable container. Open the valve for the drain line. The two marks on the valve must be turned so that one mark points to the pump and the second mark points to the drain line. Operate the pump until the crankcase is empty. Close the valve to the drain line. Disconnect the hose.
 - d. If the oil drain valve has a “quick connect” coupling, attach the coupling. Open the drain valve in order to drain the crankcase. After the oil has drained, close the drain valve. Disconnect the coupling.
3. Replace the engine oil filter elements before filling the crankcase with new oil.

Replace the Oil Filter Elements

Replace the engine oil filters when any of the following conditions occur:

- Every oil change

- The engine oil filter differential pressure reaches 103 kPa (15 psi).
- The oil filter elements have been used for 1000 service hours.

Note: Do not attempt to clean the used oil filters. Used oil filters will retain waste particles. The used oil filters would not filter the oil properly.

Service tools are available to aid in the service of oil filters. Consult your Caterpillar dealer for the part names and the part numbers. Follow the instructions that are supplied with the service tools. If the service tools are not used, perform the following appropriate procedure.

Replacing the Engine Oil Filters With the Engine Stopped

! WARNING

Hot oil and components can cause personal injury.

Do not allow hot oil or components to contact skin.

Perform the following procedure after the oil has been drained.

Note: Use this procedure if the engine oil filters do not have a control valve.




Illustration 71

g00799719

- (1) Bolts
- (2) Cover
- (3) Plug
- (4) Drain valve
- (5) Drain

Note: Drain the oil into a suitable container. Dispose of the oil according to local regulations.

1. Connect a hose to drain (5). Place the other end of the hose into a suitable container in order to collect the oil.

2. Open drain valve (4). Remove plug (3). Allow the oil to drain. Clean the plug and install the plug. Close the drain valve. Remove the hose from the drain.

Note: Some oil will remain in the housing after the oil has been drained. This oil will pour out of the housing when cover (2) is removed. Prepare to catch the oil in a suitable container. Clean up any spilled oil with absorbent pillows or towels. DO NOT use absorbent particles to clean up the oil.

! WARNING

Personal injury can result from parts and/or covers under spring pressure.

Spring force will be released when covers are removed.

Be prepared to hold spring loaded covers as the bolts are loosened.

3. Be alert to the spring force. Gradually loosen but do not remove bolts (1). Before removing the bolts, pry cover (2) loose or tap the cover with a rubber mallet in order to relieve any spring pressure.

Section view of the engine oil filter




Illustration 72

g00799721

- (2) Cover
- (6) O-ring seal
- (7) Spring
- (8) Retainer
- (9) Oil filter element

4. Remove cover (2) and spring (7). Remove O-ring seal (6), retainer (8), and oil filter elements (9).

5. Clean cover (2), spring (7), O-ring seal (6), and retainer (8). Clean the inside of the oil filter housing.

NOTICE

Caterpillar oil filters are built to Caterpillar specifications. Use of an oil filter not recommended by Caterpillar could result in severe engine damage to the engine bearings, crankshaft, etc., as a result of the larger waste particles from unfiltered oil entering the engine lubricating system. Only use oil filters recommended by Caterpillar.

6. Ensure that the new oil filter elements are in good condition. Install the new oil filter elements.
7. Inspect the O-ring seal. Ensure that the surfaces for the O-ring seal are clean. Install a new O-ring seal if the old O-ring seal is damaged or deteriorated.
8. Install retainer (8), spring (7) and cover (2). Ensure that the retainer and the spring are properly seated between the oil filter elements and the cover.
9. Start the engine according to this Operation and Maintenance Manual, "Starting The Engine" procedure (Operation Section). Check for oil leaks.

Replacing the Engine Oil Filters During Engine Operation

If the engine is equipped with duplex oil filters, the engine oil filter elements can be changed while the engine is in operation. This is useful if the oil filter elements require more frequent replacement than the engine oil.

 **WARNING**

This filter contains hot, pressurized oil that can cause burns and fire hazards, which may result in bodily injury or death. Follow the instructions given in this Operation and Maintenance Manual and stop the engine if rapid air movement exists to blow the oil.

1. Open the "FILL" valve for a minimum of five minutes in order to fill the oil filter elements that will not be serviced. The oil filters that will not be serviced must be full of engine oil. Close the FILL valve.
2. Move the control valve to the "AUX RUN" position in order to change the main oil filter elements. Move the selector valve to the "MAIN RUN" position in order to change the auxiliary oil filter elements.
3. Allow the oil pressure gauge for the oil filter that is being changed to reach a "ZERO" pressure reading.

4. Perform Step 1 through Step 8 of "Replacing the Engine Oil Filters With the Engine Stopped".
5. Open the "FILL" valve for a minimum of five minutes in order to fill the new oil filter elements.
6. Close the "FILL" valve. Rotate the control valve to the "RUN" position for the oil filter that was serviced.

Fill the Crankcase

NOTICE

Only use oils that are recommended by Caterpillar. For the proper oil to use, refer to this Operation and Maintenance Manual, "Refill Capacities and Recommendations" topic (Maintenance Section).

NOTICE

If the engine is equipped with an auxiliary oil filter system, extra oil must be added when filling the crankcase. If equipped with an auxiliary oil filter system that is not supplied by Caterpillar, follow the recommendations of the OEM.

NOTICE

Engine damage can occur if the crankcase is filled above the "FULL" mark on the oil level gauge (dipstick).

An overfull crankcase can cause the crankshaft to dip into the oil. This will reduce the power that is developed and also force air bubbles into the oil. These bubbles (foam) can cause the following problems: reduction of the oil's ability to lubricate, reduction of oil pressure, inadequate cooling, oil blowing out of the crankcase breathers, and excessive oil consumption.

Excessive oil consumption will cause deposits to form on the pistons and in the combustion chamber. Deposits in the combustion chamber lead to the following problems: guttering of the valves, packing of carbon under the piston rings, and wear of the cylinder liner.

If the oil level is above the "FULL" mark on the oil level gauge, drain some of the oil immediately.

Use the following procedure in order to fill the crankcase if the engine oil filters were replaced during engine operation.

1. If the engine oil filters were replaced during engine operation operate the engine at low idle. Ensure that the oil level is at the "FULL" mark on the "LOW IDLE" side of the oil level gauge.
2. Add oil, if necessary. Remove the oil filler cap. Fill the crankcase through the oil filler tube only.

Use the following procedure in order to fill the crankcase if the engine oil filters were replaced with the engine stopped.

1. Remove the oil filler cap. Fill the crankcase through the oil filler tube only. For the amount of oil to use, see this Operation and Maintenance Manual, "Refill Capacities and Recommendations" topic (Maintenance Section). Clean the oil filler cap. Install the oil filler cap.

NOTICE

To prevent crankshaft or bearing damage, crank engine with fuel off to fill all filters before starting.

Do Not crank engine for more than 30 seconds.

2. Close the fuel supply line and crank the engine until the oil pressure gauge indicates 70 kPa (10 psi). Open the fuel supply line. Allow the starting motor to cool for two minutes before cranking again.
3. Start the engine according to this Operation and Maintenance Manual, "Starting The Engine" procedure (Operation Section). Operate the engine at low idle for two minutes. This will ensure that the lubrication system has oil and that the oil filters are filled with oil. Inspect the engine for oil leaks. Ensure that the oil level is at the "FULL" mark on the "LOW IDLE" side of the oil level gauge.
4. Stop the engine and allow the oil to drain back into the sump for a minimum of ten minutes.
5. Remove the oil level gauge and check the oil level. Maintain the oil level to the "FULL" mark on the "ENGINE STOPPED" side of the oil level gauge.

Inspect the Used Oil Filter Elements

Cut the used oil filter element open with a utility knife. Remove the metal wrap. Cut the filter element free from the end caps. Spread apart the pleats and inspect the element for metal debris. An excessive amount of debris in the element may indicate early wear or a pending failure.

Use a magnet to differentiate between the ferrous metals and the nonferrous metals that are found in the element. Ferrous metals may indicate wear on the steel and the cast iron parts of the engine. Nonferrous metals may indicate wear on the aluminum parts, the brass parts, or the bronze parts of the engine. Parts that may be affected include the following components: main bearings, rod bearings, turbocharger bearings, and cylinder heads.

Aluminum debris may indicate problems with the bearings of the front gears. If you find aluminum debris, inspect the crankshaft vibration damper and the idler gear bearings.

Due to normal wear and friction, it is not uncommon to find small amounts of debris in the oil filter element. If an excessive amount of debris is found in the oil filter element, consult your Caterpillar dealer in order to arrange for further oil analysis.

i00626013

Engine Protective Devices - Check

SMCS Code: 7400-535

Alarms and shutoffs must function properly. Alarms provide timely warning to the operator. Shutoffs help to prevent damage to the engine. It is impossible to determine if the engine protective devices are in good working order during normal operation. Malfunctions must be simulated in order to test the engine protective devices.

A calibration check of the engine protective devices will ensure that the alarms and shutoffs activate at the setpoints. Ensure that the engine protective devices are functioning properly.

NOTICE

During testing, abnormal operating conditions must be simulated.

The tests must be performed correctly in order to prevent possible damage to the engine.

To prevent damage to the engine, only authorized service personnel or your Caterpillar dealer should perform the tests.

Visual Inspection

Visually check the condition of all gauges, sensors and wiring. Look for wiring and components that are loose, broken, or damaged. Damaged wiring or components should be repaired or replaced immediately.

i02623997

Engine Valve Lash - Inspect/Adjust

SMCS Code: 1102-025

Note: For procedures on adjusting the valve lash and for the correct valve lash settings, see the Systems Operation/Testing and Adjusting Manual, "Valve Lash and Valve Bridge Adjustment". You may also consult your Caterpillar dealer for assistance.

NOTICE

Only qualified service personnel should perform this maintenance. Refer to the Systems Operation/Testing and Adjusting Manual, "Valve Lash and Valve Bridge Adjustment" article or consult your Caterpillar dealer for the complete valve lash adjustment procedure.

Operation of Caterpillar engines with improper valve adjustments can reduce engine efficiency. This reduced efficiency could result in excessive fuel usage and/or shortened engine component life.

Perform the valve lash setting when the engine is cold. After the engine has been shut down and the valve covers are removed, the engine is considered cold. Before performing maintenance, prevent the entry of foreign matter into the top of the cylinder head and the valve mechanism. Thoroughly clean the area around the valve mechanism covers.

i01225237

Fuel Injector - Inspect/Adjust

SMCS Code: 1290-025

Note: Perform this procedure when the engine valve lash is inspected.

WARNING

The Electronic Control module produces high voltage. To prevent personal injury make sure the Electronic Control Module is not powered and the unit injector solenoids are disconnected.

NOTICE

The camshafts must be correctly timed with the crankshaft before an adjustment of the lash for the fuel injector is made. The timing pins must be removed from the camshafts before the crankshaft is turned or damage to the cylinder block will be the result.

Inspect the adjustment of the lash for the fuel injector according to the Systems Operation/Testing And Adjusting, "Fuel System" topic. Adjust the lash for the fuel injector, if necessary.

i01398238

Fuel System - Prime

SMCS Code: 1250-548; 1258-548

1. Open the fuel supply valve. Ensure that the engine will not start during the priming procedure. Turn the start switch to the OFF position.




Illustration 73

g00736817

(1) Fuel priming pump plunger

2. Turn the fuel priming pump plunger counterclockwise in order to release the lock plate from the retainer.
3. Operate the fuel priming pump until the air in the fuel system has been pumped through the fuel return line back to the fuel tank.
4. Press the fuel priming pump plunger to the locking position. Turn the fuel priming pump plunger clockwise in order to engage the lock plate in the retainer.

Note: Enable the starting system only after all maintenance has been completed.

Priming Procedure for Dry Starting

If the air cannot be completely purged from the fuel system and the engine will not start, see Special Instruction, SEHS9586, "3500 EUI Fuel Priming Procedure".

i01398258

Fuel System Primary Filter - Clean/Inspect/Replace

SMCS Code: 1260-510; 1260-571

WARNING

Fuel leaked or spilled onto hot surfaces or electrical components can cause a fire. To help prevent possible injury, turn the start switch off when changing fuel filters or water separator elements. Clean up fuel spills immediately.

1. Stop the engine. Ensure that the engine will not start during this procedure.
2. Shut off the fuel supply valve to the engine.

NOTICE

Do not allow dirt to enter the fuel system. Thoroughly clean the area around a fuel system component that will be disconnected. Fit a suitable cover over disconnected fuel system component.

NOTICE

Use a suitable container to catch any fuel that might spill. Clean up any spilled fuel immediately.




Illustration 74

g00736845

- (1) Filter case
(2) Nut

3. Loosen nut (2). Hold filter case (1) and remove nut (2). Prepare to catch the fuel that is inside of the filter case with a suitable container. Remove the filter case from the mounting bolt.
4. Remove the element and wash the element in clean, nonflammable solvent. Allow the element to dry. Inspect the element. Install a new element if the old element is damaged or deteriorated.

5. Clean the inside of the filter case. Allow the filter case to dry.
6. Inspect the O-ring seals. Obtain new seal rings if the old seal rings are damaged or deteriorated. Ensure that the sealing surfaces for the seals are clean. Install the seals.

NOTICE

Do not fill the fuel filters with fuel before installing them. The fuel would not be filtered and could be contaminated. Contaminated fuel will cause accelerated wear to fuel system parts.

7. Place the element in the filter case. Slide the filter case over the mounting bolt.
8. Install the nut.
9. Open the fuel supply valve.
10. Prime the fuel system. See this Operation and Maintenance Manual, "Fuel System - Prime" topic.

i01970987

Fuel System Secondary Filter - Replace

SMCS Code: 1261-510-SE

Note: If the engine is equipped with duplex fuel filters, the fuel filter elements can be changed while the engine is in operation. Refer to "Replacing the Fuel Filter Elements During Engine Operation".

WARNING

Fuel leaked or spilled onto hot surfaces or electrical components can cause a fire. To help prevent possible injury, turn the start switch off when changing fuel filters or water separator elements. Clean up fuel spills immediately.

Replace the secondary fuel filter elements whenever the following conditions occur:

- The fuel filter differential pressure gauge registers 103 kPa (15 psi).
- The fuel filters have been used for 1000 service hours.

Replacing the Fuel Filter Elements with the Engine Stopped

Canister

1. Stop the engine. Ensure that the engine will not start during this procedure.
2. Shut off the fuel supply valve to the engine.

NOTICE

Do not allow dirt to enter the fuel system. Thoroughly clean the area around a fuel system component that will be disconnected. Fit a suitable cover over disconnected fuel system component.

NOTICE

Use a suitable container to catch any fuel that might spill. Clean up any spilled fuel immediately.




Illustration 75

g00329184

- (1) Drain
- (2) Drain valve
- (3) Plug
- (4) Bolts
- (5) Cover

3. Connect a hose to drain (1). Place the other end of the hose into a suitable container in order to collect the fuel.
4. Open drain valve (2). Remove plug (3). Allow the fuel to drain. Clean the plug and install the plug. Close the drain valve. Remove the hose from the drain.

Note: Some fuel will remain in the housing after the fuel has been drained. This fuel will pour out of the housing when cover (5) is removed. Prepare to catch the fuel in a suitable container. Clean up any spilled fuel with absorbent towels or pillows. DO NOT use absorbent particles to clean up the fuel.

WARNING

Personal injury can result from parts and/or covers under spring pressure.

Spring force will be released when covers are removed.

Be prepared to hold spring loaded covers as the bolts are loosened.

5. Be alert to the spring force. Gradually loosen but do not remove bolts (4). Before removing bolts (4), pry cover (5) loose in order to relieve any spring pressure. Remove cover (5). Remove the O-ring seal on the inside of the cover. Remove the fuel filter elements.
6. Clean cover (5) and clean the O-ring seal. Clean the inside of the fuel filter housing.
7. Install new fuel filter elements.
8. Inspect the O-ring seal. Ensure that the surfaces for the O-ring seal are clean. Install a new O-ring seal if the old O-ring seal is damaged or deteriorated.
9. Install cover (5). Ensure that the springs are seated properly between the cover and the fuel filter elements.
10. Open the fuel supply valve. Reconnect the battery.
11. Prime the fuel system. Refer to this Operation and Maintenance Manual, "Fuel System - Prime" topic (Maintenance Section).

Spin-On Filter

NOTICE

Do not allow dirt to enter the fuel system. Thoroughly clean the area around a fuel system component that will be disconnected. Fit a suitable cover over disconnected fuel system component.




Illustration 76
Secondary fuel filters
g00425598

1. Remove the used fuel filter with a 1U-8760 Chain Wrench. Discard the used fuel filter.
2. Clean the gasket sealing surface of the fuel filter base.

Ensure that all of the old gasket is removed.
3. Apply clean diesel fuel to the new fuel filter gasket.

NOTICE

Do not fill the fuel filters with fuel before installing the fuel filters. The fuel will not be filtered and could be contaminated. Contaminated fuel will cause accelerated wear to fuel system parts.

4. Install the new fuel filter.

Spin the new fuel filter onto the fuel filter base until the gasket contacts the base. Tighten the fuel filter by hand by one full turn. Do not overtighten the fuel filter. Use the rotation index marks that are on the fuel filter as a guide for proper tightening.

5. Prime the fuel system.

See this Operation and Maintenance Manual, "Fuel System - Prime" topic (Maintenance Section).

Replacing the Fuel Filter Elements During Engine Operation

If the engine is equipped with duplex fuel filters, the fuel filters can be changed while the engine is in operation.

WARNING

This filter contains pressurized fuel that can cause a fire hazard, which may result in bodily injury or death. Follow the instructions given in this Operation and Maintenance Manual and stop the engine if rapid air movement exists to blow the fuel.

Duplex Fuel Filters




Illustration 77
g00657535
(1) Fill valve
(2) Control valve

1. Open FILL valve (1) for a minimum of five minutes in order to fill the fuel filters that will not be serviced. The fuel filters that will not be serviced must be full of fuel. Close the FILL valve.
2. If the main filter will be serviced, rotate control valve (2) to the "AUX RUN" position.

If the auxiliary filters will be serviced, rotate control valve (2) to the "MAIN RUN" position.

NOTICE

Do not allow dirt to enter the fuel system. Thoroughly clean the area around a fuel system component that will be disconnected. Fit a suitable cover over disconnected fuel system component.

NOTICE

Use a suitable container to catch any fuel that might spill. Clean up any spilled fuel immediately.

3. See "Replacing the Fuel Filter Elements with the Engine Stopped". Perform Step 3 through Step 9 from the "Canister" instructions.
4. Open fill valve (1) for a minimum of five minutes in order to fill the new elements. Close the fill valve.

After the new filter elements are full of fuel, either the main filter or the auxiliary filter may be used.

i02571779

Fuel Tank Water and Sediment - Drain

SMCS Code: 1273-543-M&S

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.

Fuel Tank

Fuel quality is critical to the performance and to the service life of the engine. Water in the fuel can cause excessive wear to the fuel system. Condensation occurs during the heating and cooling of fuel. The condensation occurs as the fuel passes through the fuel system and the fuel returns to the fuel tank. This causes water to accumulate in fuel tanks. Draining the fuel tank regularly and obtaining fuel from reliable sources can help to eliminate water in the fuel.

Drain the Water and the Sediment

Fuel tanks should contain some provision for draining water and draining sediment from the bottom of the fuel tanks.

Open the drain valve on the bottom of the fuel tank in order to drain the water and the sediment. Close the drain valve.

Check the fuel daily. Drain the water and sediment from the fuel tank after operating the engine or drain the water and sediment from the fuel tank after the fuel tank has been filled. Allow five to ten minutes before performing this procedure.

Fill the fuel tank after operating the engine in order to drive out moist air. This will help prevent condensation. Do not fill the tank to the top. The fuel expands as the fuel gets warm. The tank may overflow.

Some fuel tanks use supply pipes that allow water and sediment to settle below the end of the fuel supply pipe. Some fuel tanks use supply lines that take fuel directly from the bottom of the tank. If the engine is equipped with this system, regular maintenance of the fuel system filter is important.

Fuel Storage Tanks

Drain the water and the sediment from the fuel storage tank during the following conditions:

- Weekly
- Oil change
- Refill of the tank

This will help prevent water or sediment from being pumped from the storage tank into the engine fuel tank. A 4 micron [c] filter for the breather vent on the fuel tank is also recommended. Refer to Special Publication, SENR9620, "Improving Fuel System Durability".

If a bulk storage tank has been refilled or moved recently, allow adequate time for the sediment to settle before filling the engine fuel tank. Internal baffles in the bulk storage tank will also help trap sediment. Filtering fuel that is pumped from the storage tank helps to ensure the quality of the fuel. When possible, water separators should be used.

i02121526

Hoses and Clamps - Inspect/Replace

SMCS Code: 7554-040; 7554-510

Inspect all hoses for leaks that are caused by the following conditions:

- Cracking
- Softness
- Loose clamps

Replace hoses that are cracked or soft. Tighten any loose clamps.

NOTICE

Do not bend or strike high pressure lines. Do not install bent or damaged lines, tubes or hoses. Repair any loose or damaged fuel and oil lines, tubes and hoses. Leaks can cause fires. Inspect all lines, tubes and hoses carefully. Tighten all connections to the recommended torque.

Check for the following conditions:

- End fittings that are damaged or leaking
- Outer covering that is chafed or cut
- Exposed wire that is used for reinforcement
- Outer covering that is ballooning locally
- Flexible part of the hose that is kinked or crushed
- Armoring that is embedded in the outer covering

A constant torque hose clamp can be used in place of any standard hose clamp. Ensure that the constant torque hose clamp is the same size as the standard clamp.

Due to extreme temperature changes, the hose will heat set. Heat setting causes hose clamps to loosen. This can result in leaks. A constant torque hose clamp will help to prevent loose hose clamps.

Each installation application can be different. The differences depend on the following factors:

- Type of hose
- Type of fitting material
- Anticipated expansion and contraction of the hose
- Anticipated expansion and contraction of the fittings

Replace the Hoses and the Clamps

WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

1. Stop the engine. Allow the engine to cool.
2. Loosen the cooling system filler cap slowly in order to relieve any pressure. Remove the cooling system filler cap.

Note: Drain the coolant into a suitable, clean container. The coolant can be reused.

3. Drain the coolant from the cooling system to a level that is below the hose that is being replaced.
4. Remove the hose clamps.

5. Disconnect the old hose.
6. Replace the old hose with a new hose.
7. Install the hose clamps with a torque wrench.

Note: Refer to the Specifications, SENR3130, "Torque Specifications" in order to locate the proper torques.

8. Refill the cooling system.
9. Clean the cooling system filler cap. Inspect the cooling system filler cap's gaskets. Replace the cooling system filler cap if the gaskets are damaged. Install the cooling system filler cap.
10. Start the engine. Inspect the cooling system for leaks.

i01048507

Instrument Panel - Inspect

SMCS Code: 7451-040

Inspect the instrument panel for good condition. Perform the self-test. All of the warning lamps should illuminate. If a warning lamp does not illuminate, replace the bulb immediately. If the alarm does not sound, investigate the problem and correct the problem.

Check the condition of all of the gauges. If a gauge is broken, repair the gauge or replace the gauge immediately.

Frequently monitor the gauges during normal operation.

Record the data in a log. Compare the new data to the data that was previously recorded. Comparing the new data to the recorded data will help to establish the trends of engine performance. A gauge reading that is abnormal may indicate a problem with operation or a problem with the gauge.

i02624673

Maintenance Recommendations

SMCS Code: 1000

Experience has shown that maintenance intervals are most accurately based on fuel consumption. Fuel consumption corresponds more accurately to the engine load. Table 19 lists average ranges of fuel consumption and service hours for a load factor of approximately 60 percent. Use the range of fuel consumption only as a guideline.

Table 19

Maintenance Interval Schedule Service Hours and Fuel Consumption for 3512C and 3516C Engines ⁽¹⁾		
Overhaul Type	3512CEngines	3516CEngines
Top End Overhaul	7500 Service Hours	
	976,000 L (257,830 US gal)	1,298,000 L (342,893 US gal)
Major Overhaul	22,500 Service Hours	
	2,928,000 L (773,490 US gal)	3,894,240 L (1,028,741 US gal)

⁽¹⁾ Fuel consumption is based on a load factor of approximately 60 percent.

Severe Operation

Severe operation is the use of an engine that exceeds current published standards for that engine. Caterpillar maintains standards for the following engine parameters:

- Horsepower
- Range of rpm
- Fuel consumption
- Fuel quality
- Altitude
- Maintenance intervals
- Selection of oil
- Selection of coolant
- Environmental qualities
- Installation

Refer to the standards for your engine or consult your Caterpillar dealer in order to determine if your engine is operating within the defined parameters.

Severe operation can accelerate component wear. Engines that are operating under severe conditions may need more frequent maintenance intervals for the following reasons:

- Maximum reliability
- Retention of full service life

Because of individual applications, it is not possible to identify all of the factors which can contribute to severe operation. Consult your Caterpillar dealer about the maintenance that is needed for your specific engine.

The following factors can contribute to severe operation: environment, improper operating procedures, and improper maintenance practices.

Environmental Factors

Extreme Ambient Temperatures

Extended operation in environments that are extremely cold or hot can damage components. Valve components can be damaged by carbon buildup if the engine is frequently started and stopped in very cold temperatures. Extremely hot inlet air reduces the performance capabilities of the engine.

Note: See this Operation and Maintenance Manual, “Cold Weather Operation” topic (Operation Section), or see Supplement, SEBU5898, “Cold Weather Recommendations”.

Cleanliness

Unless the equipment is cleaned regularly, extended operation in a dirty environment and in a dusty environment can damage components. Built up mud, dirt, and dust can encase components. This can make maintenance difficult. The buildup can contain corrosive chemicals. Corrosive chemicals and salt can damage some components.

Improper Operating Procedures

- Extended operation at low idle
- Minimum cool down periods after high load factor operation
- Operating the engine beyond the guidelines for the engine rating
- Operating the engine at loads that are greater than the rated load

- Operating the engine at speeds that are greater than the rated speed
- Use of the engine for an application that is not approved

Improper Maintenance Practices

- Extension of maintenance intervals
- Not using recommended fuel, lubricants, and coolant/antifreeze

i02624456

Overhaul (Major)

SMCS Code: 7595-020-MJ

Refer to this Operation and Maintenance Manual, "Maintenance Recommendations" in order to determine the maintenance interval for a major overhaul.

The need for a major overhaul is determined by several factors.

- An increase of oil consumption
- An increase of crankcase blowby
- The total amount of fuel consumption
- The service hours of the engine
- The wear metal analysis of the lube oil
- An increase in the levels of noise and vibration

An increase of wear metals in the lube oil indicates that the bearings and the surfaces that wear may need to be serviced. An increase in the levels of noise and vibration indicates that rotating parts require service.

Note: It is possible for oil analysis to indicate a decrease of wear metals in the lube oil. The cylinder liners may be worn so that polishing of the bore occurs. Also, the increased use of lube oil will dilute the wear metals.

Monitor the engine as the engine accumulates service hours. Consult your Caterpillar dealer about scheduling a major overhaul.

Note: The driven equipment may also require service when the engine is overhauled. Refer to the literature that is provided by the OEM of the driven equipment.

A major overhaul includes all of the work that is done for the top end overhaul. A major overhaul includes additional parts and labor. Additional parts and labor are required in order to completely rebuild the engine.

For the major overhaul, all of the bearings, seals, gaskets, and components that wear are disassembled. The parts are cleaned and inspected. If necessary, the parts are replaced. The crankshaft is measured for wear. The crankshaft may require regrinding. Alternatively, the crankshaft may be replaced with a Caterpillar replacement part.

Your Caterpillar dealer can provide these services and components. Your Caterpillar dealer can ensure that the components are operating within the appropriate specifications.

Replacement of Components

Replace the following components during the major overhaul:

- Camshaft bearings
- Connecting rod bearings
- Crankshaft seals
- Crankshaft thrust washers
- Electronic unit injectors
- Gear train bushings
- Gear train bearings
- Main bearings
- Piston rings

Inspection, Reconditioning or Exchanging of Components

Inspect the following components according to the instructions that are in Caterpillar reusability publications. Refer to Guidelines for Reusable Parts and Salvage Operations, SEBF8029, "Index of Publications on Reusability or Salvage of Used Parts".

Recondition the worn components or exchange the components, if necessary. Your Caterpillar dealer can provide these services and components.

- Camshaft followers
- Camshaft thrust washers
- Connecting rods

- Crankshaft vibration damper
- Cylinder head assembly
- Cylinder liners
- Engine mounts
- Scavenge oil pump
- Engine wiring harness
- Exhaust manifold seals
- Exhaust manifold bellows
- Fuel pressure regulating valve
- Fuel priming pump
- Fuel transfer pump
- Inlet manifold gaskets
- Inlet manifold seals
- Oil cooler core
- Oil pump
- Pistons
- Piston pins
- Prelube pump
- Pushrods
- Rocker arms
- Spacer plate
- Software update
- Turbocharger

Inspection of Components

Inspect the following components according to the instructions that are in Caterpillar reusability publications. Refer to Guidelines for Reusable Parts and Salvage Operations, SEBF8029, "Index of Publications on Reusability or Salvage of Used Parts".

- Aftercooler core
- Camshaft
- Crankshaft

- Driven equipment (alignment)
- Engine cylinder block
- Engine control module
- Exhaust bellow shields
- Flywheel
- Front gear train (gears)
- Oil suction screen
- Rear gear train

Inspect the camshaft for damage to the journals and the lobes.

Inspect the crankshaft for any of the following conditions:

- Deflection
- Damage to the journals
- Bearing material that has seized to the journals

Check the journal taper and the profile of the crankshaft journals. Check these components by interpreting the wear patterns on the following components:

- Rod bearing
- Main bearings

Note: If the crankshaft or the camshaft are removed for any reason, use the magnetic particle inspection process to check for cracks.

Replace the crankshaft vibration damper if any of the following conditions occur:

- Engine failure due to a broken crankshaft
- Excessive wear of the front bearing for the crankshaft
- Excessive wear of the gear train that is not caused by a lack of lubrication

Inspect the gears of the gear train and inspect the gear train bushings for the following conditions:

- Worn gear teeth
- Unusual fit
- Unusual wear

In addition to the inspection of components, inspect the alignment of the driven equipment. See the Application and Installation Guide for the engine or see the literature that is provided by the OEM of the driven equipment.

Cleaning of Components

Clean the oil cooler core and the aftercooler core. Then, pressure test both of these cores. For instructions on cleaning the cores, see this Operation and Maintenance Manual, "Aftercooler Core - Inspect/Clean" topic.

Clean the oil suction screen. Also, remove side covers in order to clean the oil sump. For instructions on removal and installation of components, see the Service Manual, "Disassembly and Assembly" module.

Obtain a Coolant Analysis

For conventional heavy-duty coolant/antifreeze, check the concentration of supplemental coolant additive (SCA) regularly. The concentration of SCA can be checked with an S-O-S coolant analysis (Level I). A more detailed coolant analysis is recommended periodically.

For example, considerable deposits are found in the water jacket areas on the external cooling system, but the concentrations of coolant additives were carefully maintained. The coolant water probably contained minerals which were deposited on the engine over time.

A coolant analysis can be conducted in order to verify the condition of the water that is being used in the cooling system. A full water analysis may be obtained from the following sources:

- Caterpillar dealer
- Local water utility company
- Agricultural agent
- Independent laboratory

Caterpillar recommends an S-O-S coolant analysis (Level II). This is a comprehensive chemical evaluation of the coolant. This analysis is also a check of the overall condition of the inside of the cooling system. The following services are provided:

- Full Level I analysis
- Identification of the source of metal corrosion and of contaminants

- Identification of buildup of the impurities that cause corrosion
- Identification of buildup of the impurities that cause scaling
- Determination of possible electrolysis within the engines' cooling system

A report of the results of the analysis is provided. Maintenance recommendations are based on the results.

For more information about S-O-S coolant analysis, consult your Caterpillar dealer.

i02668438

Overhaul (Top End)

SMCS Code: 7595-020-TE

Refer to this Operation and Maintenance Manual, "Maintenance Recommendations" in order to determine the maintenance interval for a top end overhaul.

A top end overhaul involves the removal, the inspection, and the rework of the cylinder head components. Some additional components are replaced and serviced.

Your Caterpillar dealer can provide these services and components. Your Caterpillar dealer can ensure that the components are operating within the appropriate specifications.

Note: The driven equipment may also require service when the engine is overhauled. Refer to the literature that is provided by the OEM of the driven equipment.

If you elect to perform an overhaul without the services of a Caterpillar dealer, be aware of the following recommendations.

Cylinder Head Assembly

Inspect the cylinder head assembly according to the instructions that are in Caterpillar reusability publications. Refer to Guidelines for Reusable Parts and Salvage Operations, SEBF8029, "Index of Publications on Reusability or Salvage of Used Parts".

Your Caterpillar dealer can provide these services and components. Your Caterpillar dealer can ensure that the components are operating within the appropriate specifications.

The use of out-of-spec parts will cause unscheduled downtime and/or costly repairs.

Unit Injectors

Replace the unit injectors. Consult your Caterpillar dealer about exchanging the unit injectors. Your Caterpillar dealer can provide these services and components.

The wear of unit injectors is affected by the following considerations:

- Quality of the fuel
- Quality of the filtration of the fuel

The wear of the unit injectors can result in elevated levels of exhaust emissions and/or poor engine performance. The misfire of a single cylinder is not typically attributed to normal wear. This condition can be repaired by replacing the faulty unit injector.

The following list of circumstances indicate that the unit injectors should be inspected more frequently:

- Use of fuels that are not recommended in this Operation and Maintenance Manual, "Refill Capacities and Recommendations"
- Extreme ambient temperatures that reduce the ability of the fuel to provide lubrication
- Frequent plugging of the fuel filters
- Insufficient maintenance of the fuel tank or the fuel storage tank that can allow excessive water, sediment, etc.
- Insufficient maintenance of the fuel filters

Oil Suction Screen

Clean the oil suction screen after the oil has been drained.

Note: Approximately 1 L (1 qt) of oil will remain in the housing after the sump has been completely drained. This oil will pour out of the housing when cover (1) is removed. Prepare to catch the oil in a pan. Clean up any spilled oil with absorbent towels or pillows. DO NOT use absorbent particles to clean up the oil.

1. Remove the screen assembly according to the instructions in the Service Manual, "Disassembly and Assembly" module. Discard the used O-ring seals.
2. Wash the screen assembly in clean nonflammable solvent. Allow the screen assembly to dry before installation.

3. Remove side covers in order to gain access to the sump. Clean the bottom of the sump with absorbent towels or pillows. When the bottom of the sump is clean, install the side covers.
4. Inspect the screen assembly for good condition. Obtain a new screen assembly, if necessary. Install the screen assembly. Install new O-ring seals.

Replacement of Components

Replace the following components during the top end overhaul:

- Electronic unit injectors

Inspection, Reconditioning or Exchanging of Components

Inspect the following components according to the instructions that are in Caterpillar reusability publications. Refer to Guidelines for Reusable Parts and Salvage Operations, SEBF8029, "Index of Publications on Reusability or Salvage of Used Parts".

Recondition the worn components or exchange the components, if necessary. Your Caterpillar dealer can provide these services and components.

- Camshaft followers
- Cylinder head assembly
- Scavenge oil pump
- Engine wiring harness
- Exhaust manifold seals
- Exhaust manifold bellows
- Fuel pressure regulating valve
- Fuel priming pump
- Fuel transfer pump
- Inlet manifold gaskets
- Inlet manifold seals
- Oil pump
- Prelube pump
- Pushrods
- Rocker arms

- Spacer plate
- Software update
- Turbocharger

Inspection of Components

Inspect the following components according to the instructions that are in Caterpillar reusability publications. Refer to Guidelines for Reusable Parts and Salvage Operations, SEBF8029, "Index of Publications on Reusability or Salvage of Used Parts".

- Aftercooler core
- Camshaft
- Driven equipment (alignment)
- Engine control module
- Exhaust bellow shields
- Oil suction screen

i02565333

Overhaul Considerations

SMCS Code: 7595-043

Severe Operation

Severe operation is the use of an engine that exceeds current published standards for that engine. Caterpillar maintains standards for the following engine parameters:

- Horsepower
- Range of rpm
- Fuel consumption
- Fuel quality
- Altitude
- Maintenance intervals
- Selection of oil
- Selection of coolant
- Environmental qualities
- Installation

Refer to the standards for your engine or consult your Caterpillar dealer in order to determine if your engine is operating within the defined parameters.

Severe operation can accelerate component wear. Engines that are operating under severe conditions may need more frequent maintenance intervals for the following reasons:

- Maximum reliability
- Retention of full service life

Because of individual applications, it is not possible to identify all of the factors which can contribute to severe operation. Consult your Caterpillar dealer about the maintenance that is needed for your specific engine.

The following factors can contribute to severe operation: environment, improper operating procedures, and improper maintenance practices.

Environmental Factors

Extreme Ambient Temperatures

Extended operation in environments that are extremely cold or hot can damage components. Valve components can be damaged by carbon buildup if the engine is frequently started and stopped in very cold temperatures. Extremely hot inlet air reduces the performance capabilities of the engine.

Note: See this Operation and Maintenance Manual, "Cold Weather Operation" topic (Operation Section), or see Supplement, SEBU5898, "Cold Weather Recommendations".

Cleanliness

Unless the equipment is cleaned regularly, extended operation in a dirty environment and in a dusty environment can damage components. Built up mud, dirt, and dust can encase components. This can make maintenance difficult. The buildup can contain corrosive chemicals. Corrosive chemicals and salt can damage some components.

Improper Operating Procedures

- Extended operation at low idle
- Minimum cool down periods after high load factor operation
- Operating the engine beyond the guidelines for the engine rating
- Operating the engine at loads that are greater than the rated load

- Operating the engine at speeds that are greater than the rated speed
- Use of the engine for an application that is not approved

Improper Maintenance Practices

- Extension of maintenance intervals
- Not using recommended fuel, lubricants, and coolant/antifreeze

Overhaul Information

An overhaul is replacing the major worn components of the engine. An overhaul interval is a maintenance interval that is planned. The engine is rebuilt with certain rebuilt parts or new parts that replace the worn parts.

An overhaul also includes the following maintenance:

- Inspection of all the parts that are visible during the disassembly
- Replacement of the seals and gaskets that are removed
- Cleaning of the internal passages of the engine and the engine block

Most owners will save money by overhauling the engine at the intervals that are recommended in this Operation and Maintenance Manual. Consider the graph in Illustration 78.




Illustration 78

g00745964

- (Y) Cost
- (X) Time
- (1) Cost of maintenance and repair that is planned
- (2) Cost of maintenance and repair that is not planned

In Illustration 78, line (1) represents the maintenance and repair costs for an owner that followed the recommendations for inspection, maintenance, and repair. The peaks represent overhauls.

Line (2) represents the maintenance and repair costs for an owner that chose to operate beyond the recommended intervals. The initial cost of the “repair-after-failure” philosophy is lower. Also, the first overhaul was delayed. However, the peaks are significantly higher than the peaks for the customer that used the “repair-before-failure” philosophy.

The higher peaks result from two key factors:

- Delaying an overhaul until a breakdown increases the chance of a catastrophic failure. This type of failure requires more parts, labor, and cleanup.
- Excessive wear means that fewer components will be reusable. More labor may be required for salvage or repair of the components.

When all of the costs are considered, “repair-before-failure” is the least expensive alternative for most components and engines.

It is not practical to wait until the engine exhibits symptoms of excessive wear or failure. It is not less costly to wait. A planned overhaul before failure may be the best value for the following reasons:

- Costly unplanned downtime can be avoided.
- Many original parts can be reused according to the guidelines for reusable parts.
- The service life of the engine can be extended without the risk of a major catastrophe due to engine failure.
- Achieve the best cost/value relationship per hour of extended service life.

Overhaul Inspection

Refer to the Service Manual for the disassembly and assembly procedures that are necessary in order to perform the required maintenance on the items that are listed. Consult your Caterpillar dealer for assistance.

To determine the reusability publications that are needed to inspect the engine, refer to Guidelines for Reusable Parts and Salvage Operations, SEBF8029, “Index of Publications on Reusability or Salvage of Used Parts”.

The Guidelines For Reusable Parts and Salvage Operations is part of an established Caterpillar parts reusability program. These guidelines were developed in order to assist Caterpillar dealers and customers reduce costs by avoiding unnecessary expenditures for new parts. If the engine parts comply with the established inspection specifications, the parts can be reused.

i01879911

The use of out-of-spec parts could result in unscheduled downtime and/or costly repairs. The use of out-of-spec parts can also contribute to increased fuel consumption and reduction of engine efficiency. New parts are not necessary if the old parts can be reused, repaired, or salvaged. Otherwise, the old parts can be replaced or exchanged.

Your Caterpillar dealer can provide the parts that are needed to rebuild the engine at the least possible cost.

Overhaul Programs

An economical way to obtain most of the parts that are needed for overhauls is to use Caterpillar remanufactured parts. Caterpillar remanufactured parts are available at a fraction of the cost of new parts. These parts have been rebuilt by Caterpillar and certified for use. The following components are examples of the remanufactured parts:

- Cylinder heads
- Oil Pumps
- Turbochargers
- Water pumps

Consult your Caterpillar dealer for details and for a list of the remanufactured parts that are available.

Your Caterpillar dealer may be offering a variety of overhaul options.

A Flat Rate Overhaul guarantees the maximum price that you will pay for an overhaul. Flat rate prices on preventive maintenance programs or major repair options are available from many servicing dealers for all Caterpillar engines. Consult your Caterpillar dealer in order to schedule a before failure overhaul.

Overhaul Recommendation

Caterpillar recommends a scheduled overhaul in order to minimize downtime. A scheduled overhaul will provide the lowest cost and the greatest value. Schedule an overhaul with your Caterpillar dealer.

Overhaul programs vary between dealers. To obtain specific information about the types of overhaul programs and services, consult your Caterpillar dealer.

Pre-lube Pump - Inspect

SMCS Code: 1319-040

Inspect the pre-lube pump for the following conditions:

- Cracks
- Pin holes
- Proper operation
- Wear

Perform a pressure check on the pre-lube pump.

Inspect the hoses and the fittings for leaks.

Inspect the pre-lube pump for leaks. Replace all of the seals if a leak is observed.

Inspect the wiring for the following conditions:

- Damage
- Fraying

Ensure that the wiring is in good condition.

Inspect the electrical connections. Ensure that the electrical connections are secure.

Inspect the brushes. Replace the brushes, if necessary.

If repair or replacement is necessary, see the Service Manual or see literature that is provided by the OEM of the pump. Consult your Caterpillar dealer for assistance.

i02623059

Speed Sensor - Clean/Inspect

SMCS Code: 1907-040; 1907-070

An engine speed/timing sensor is mounted in the flywheel housing. The speed/timing sensor provides information about engine speed and the position of the crankshaft to the engine control module (ECM).




Illustration 79

g00760464

1. Remove engine speed/timing sensor (1). Inspect the condition of the end of the magnet. Look for signs of wear and contaminants.
2. Clean any debris from the face of the magnet.




Illustration 80

g01115363

3. Check the tension of the sliphead. Gently extend sliphead (2) for a minimum of 4 mm (0.16 inch). Then push back the sliphead.

When the sliphead has the correct tension, at least 22 N (5 lb) of force is required to push in the sliphead from the extended position.

NOTICE

The sliphead must be fully extended when the speed/timing sensor is installed so that the sensor maintains the correct clearance with the speed-timing wheel. If the correct clearance is not maintained, the signal from the sensor will not be generated.

Do not install the sensor between the teeth of the speed-timing wheel. Damage to the sensor would result. Before installing the sensor, ensure that a tooth of the wheel is visible in the mounting hole for the sensor.

4. Install the engine speed/timing sensor.
 - a. Ensure that a tooth on the speed-timing wheel is visible in the mounting hole for the sensor.
 - b. Extend sliphead (2) by a minimum of 4 mm (0.16 inch).

- c. Coat the threads of the sensor with 4C-5597 Anti-Seize Compound.

Note: The sliphead is designed to contact a tooth during the first revolution of the speed-timing wheel. For the maximum allowable clearance between the sliphead and the tooth, refer to the Specifications Manual.

- d. Install the sensor. Tighten the locknut to $40 \pm 5 \text{ N}\cdot\text{m}$ ($30 \pm 4 \text{ lb ft}$).

i02618737

Starting Motor - Inspect (If equipped)

SMCS Code: 1451-040; 1453-040

Air Starting Motor

If the starting motor fails, the engine may not start in an emergency situation. A scheduled inspection of the starting motor is recommended.

The starting motor pinion and the flywheel ring gear must be in good condition in order for the engine to start properly. The engine will not start if the starting motor pinion does not engage the flywheel ring gear. The teeth of the starting motor pinion and the flywheel ring gear can be damaged because of irregular engagement.

Inspect the starting motor for proper operation. Listen for grinding when the engine is started. Inspect the teeth of the starting motor pinion and the flywheel ring gear. Look for patterns of wear on the teeth. Look for teeth that are broken or chipped. If damaged teeth are found, the starting motor pinion and the flywheel ring gear must be replaced.

WARNING

Personal injury or death can result from improperly checking for a leak.

Always use a board or cardboard when checking for a leak. Escaping air or fluid under pressure, even a pin-hole size leak, can penetrate body tissue causing serious injury, and possible death.

If fluid is injected into your skin, it must be treated immediately by a doctor familiar with this type of injury.

Inspect all of the components in the air circuit for the starting motor. Inspect all of the air lines and connections for leaks.

If damaged teeth are found, the air circuit for the starting motor must be examined in order to determine the cause of the problem.

Electric Starting Motor

If the starting motor fails, the engine may not start in an emergency situation. A scheduled inspection of the starting motor is recommended.

The starting motor pinion and the flywheel ring gear must be in good condition in order for the engine to start properly. The engine will not start if the starting motor pinion does not engage the flywheel ring gear. The teeth of the starting motor pinion and the flywheel ring gear can be damaged because of irregular engagement.

Inspect the starting motor for proper operation. Listen for grinding when the engine is started. Inspect the teeth of the starting motor pinion and the flywheel ring gear. Look for patterns of wear on the teeth. Look for teeth that are broken or chipped. If damaged teeth are found, the starting motor pinion and the flywheel ring gear must be replaced.

Problems with the electric starting motor can be caused by the following conditions: malfunction of the solenoid and malfunction of the electric starting system.

Inspect the electrical system for the following conditions:

- Loose connections
- Corrosion
- Wires that are worn or frayed
- Cleanliness

Removal and Installation of the Starting Motor

Refer to the Service Manual, "Disassembly and Assembly" module for information on removing the starting motor and installing the starting motor.

Consult your Caterpillar dealer for assistance and/or for options on replacement of the starting motor.

i01261768

Turbocharger - Inspect

SMCS Code: 1052-040

Periodic inspection and cleaning is recommended for the turbocharger compressor housing (inlet side).

Fouling of the compressor can contribute to loss of engine power, increased black smoke and overall loss of engine efficiency.

If the turbocharger fails during engine operation, damage to the turbocharger compressor wheel and/or to the engine may occur. Damage to the turbocharger compressor wheel could allow parts from the compressor wheel to enter an engine cylinder. This can cause additional damage to the pistons, the valves, and the cylinder head.

NOTICE

Turbocharger bearing failures can cause large quantities of oil to enter the air inlet and exhaust systems. Loss of engine lubricant can result in serious engine damage.

Minor leakage of a turbocharger housing under extended low idle operation should not cause problems as long as a turbocharger bearing failure has not occurred.

When a turbocharger bearing failure is accompanied by a significant engine performance loss (exhaust smoke or engine rpm up at no load), do not continue engine operation until the turbocharger is repaired or replaced.

An inspection of the turbocharger can minimize unscheduled downtime. An inspection of the turbocharger can also reduce the chance for potential damage to other engine parts.

Note: Turbocharger components require clearances that are precise. The turbocharger cartridge must be balanced due to high rpm. Severe service applications can accelerate the wear of the components. Severe service applications may require more frequent inspections of the turbocharger.

Removal and Installation

For options regarding the removal, installation, repair and replacement, consult your Caterpillar dealer. Refer to the Service Manual for this engine or consult your Caterpillar dealer for the procedure and specifications.

Cleaning and Inspecting

1. Remove the exhaust outlet piping and remove the air inlet piping from the turbocharger. Visually inspect the piping for the presence of oil.

2. Turn the compressor wheel and the turbine wheel by hand. The assembly should turn freely. Inspect the compressor wheel and the turbine wheel for contact with the turbocharger housing. There should not be any visible signs of contact between the turbine wheel or compressor wheel and the turbocharger housing. If there is any indication of contact between the rotating turbine wheel or the turbocharger wheel and the turbocharger housing, the turbocharger should be reconditioned or replaced.

3. Check the compressor wheel for cleanliness. If only the blade side of the wheel is dirty, dirt and/or moisture is passing through the air filtering system. If oil is found only on the back side of the wheel, there is a possibility of a failed turbocharger oil seal.

The presence of oil may be the result of extended engine operation at low idle. The presence of oil may also be the result of a restriction of the line for the inlet air (plugged air filters), which causes the turbocharger to slobber.

4. Inspect the bore of the turbine housing for corrosion.
5. Clean the turbocharger housing with standard shop solvents and a soft bristle brush.
6. Fasten the air inlet piping and the exhaust outlet piping to the turbocharger housing.

i02622549

Walk-Around Inspection

SMCS Code: 1000-040

Inspect the Engine for Leaks and for Loose Connections

A walk-around inspection should only take a few minutes. When the time is taken to perform these checks, costly repairs and accidents can be avoided.

For maximum engine service life, thoroughly inspect the engine compartment before starting the engine. Look for items such as leaks, loose bolts, loose connections and trash buildup. Make repairs, as needed.

- The guards must be in the proper place. Repair damaged guards or replace missing guards.
- Wipe all caps and plugs before the engine is serviced in order to reduce the chance of system contamination.

NOTICE

For any type of leak (coolant, lube, or fuel) clean up the fluid. If leaking is observed, find the source and correct the leak. If leaking is suspected, check the fluid levels more often than recommended until the leak is found or fixed, or until the suspicion of a leak is proved to be unwarranted.

NOTICE

Accumulated grease and/or oil on an engine or deck is a fire hazard. Remove this debris with steam cleaning or high pressure water.

Note: Use care when you use steam cleaning. Use care when you use high pressure water. Direct spray to rotating electrics or electronic components can cause nonfixable damage.

NOTICE

Water and/or condensation can cause damage to electrical components. Protect all electrical components from exposure to water.

- Ensure that the cooling lines are clamped properly and ensure that the cooling lines are tight. Check for leaks. Check the condition of all pipes.
- Inspect the water pumps for coolant leaks.

Note: The water pump seal is lubricated by coolant in the cooling system. It is normal for a small amount of leakage to occur when the engine cools and the parts contract.

Excessive coolant leakage may indicate the need to replace the water pump seal. For the removal of water pumps and the installation of water pumps and/or seals, refer to two articles in the Disassembly and Assembly Manual, "Water Pump - Remove and Water Pump - Install" or consult your Caterpillar dealer.

- Inspect the lubrication system for leaks at the following locations: front crankshaft seal, rear crankshaft seal, oil pan, oil filters, valve cover, turbocharger, external oil lines, and connections.
- Inspect the fuel system for leaks. Look for loose fuel line clamps or connections.
- Inspect the piping for the air inlet system and the elbows for cracks and for loose clamps.
- Drain the water and the sediment from fuel tanks on a daily basis in order to ensure that only clean fuel enters the fuel system.

-
- Inspect the wiring and the wiring harnesses for loose connections and for worn wires or frayed wires.
 - Inspect the ground strap for a good connection and for good condition.
 - Inspect the closed crankcase ventilation (CCV) filter, if equipped. If the restriction indicator is visible, service the CCV.
 - Check the condition of the gauges. Replace any gauge that is damaged. Replace any gauge that can not be calibrated.
 - Inspect the exhaust system for leaks. Inspect the gaskets and the exhaust bellows joint. If a leak is found, make repairs.

i02624237

Water Pump - Inspect

SMCS Code: 1361-040

A failed water pump might cause severe engine overheating problems that could result in cracks in the cylinder head, a piston seizure or other potential damage to the engine.

Visually inspect the water pump for leaks. If leaking of the water pump seals is observed, replace all of the water pump seals. Refer to two articles in the Disassembly and Assembly Manual, "Water Pump - Disassemble and Water Pump - Assemble" for the disassembly and assembly procedure. If it is necessary to remove the water pump, refer to two articles in the Disassembly and Assembly Manual, "Water Pump - Remove and Water Pump - Install".

Inspect the water pump for wear, cracks, pin holes and proper operation. Refer to the Parts Manual for the correct part numbers for your engine or consult your Caterpillar dealer if repair is needed or replacement is needed.