



12.1 PROGRAMMING SECTION

All programming of the V21 is done in the service mode as indicated in the following steps below. The main service modes are indicated in white text and the sub-modes are indicated in black text.

Example:

time Time/Date Setting Mode

year Year Setting

nth Month Setting

DATE Date Setting

Hour Hour Setting

DSt Daylight Saving Time

THREE-BUTTON PROGRAMMING

All programming of the V21 control board is done in the service mode. To enter the service mode open the vendor door, find the service mode button located on the control board, then press and release the service mode button. To scroll through all the service modes, use selection button one.

The first three selection buttons are used to navigate through the programming as follows:

Button	Description	Usage
Selection Button 1	Up/Down	Increase/Decrease, Next/Previous
Selection Button 2	Enter	Go to sub-level, activate function
Selection Button 3	Exit	Return to previous level, exit, save

FIGURE 1

The controller will automatically return to the Open-Door Sales Mode if:

1. No information from the selection switches is received within approximately 30 seconds.
2. The service mode button is pressed a second time.
3. The (Exit) button is pressed.

When the programming is entered, any established credit is returned. When and if the door is closed, the controller will exit the service mode and return to the sales mode.

MIS Data

As soon as the outer door is opened, the non-resettable MIS data will be displayed if no errors exist. "CAns XXX" will flash for approximately 30 seconds, indicating the total number of units the machine has sold. After 30 seconds, "CASH XX.XX" will begin to scroll, indicating the total dollar amount the machine has accumulated. **NOTE:** Pressing selection button one will eliminate the 30-second wait time and advance you immediately to the "CASH XX.XX" scroll.

To access MIS data by individual selection, press selection button two during the "CAnS XXXX" or "CASH XX.XX" scroll. Use selection button one to advance forward or backward through the selections. Please see page PG-7 to choose between count by selection or count by price.

NOTE: The MIS data that is displayed when the outer door is opened ("CAnS XXXX" and CASH XX.XX") is non-resettable. This data is accumulated over the life of the control board and can only be changed by replacing the control board.

SET-UP AND CODE DESCRIPTION

Error Error Display Mode

If selection button two is pressed at the “**Error**” prompt, the controller will enter the Error Display Mode. If no errors have occurred, the display will show “**none**”. If an error has been detected since the last error reset, the display will show the first error summary code that has occurred. If selection button three is pressed while displaying any summary code, the controller will return to the “**Error**” prompt.

Note: See the Trouble Shooting section for errors and how to clear them.

EXAMPLE: “**CJ01**” would indicate a column jam error in column 1.

COIn Coin Pay Out/Tube Fill Mode

If selection button two is pressed at the “**COIn**” prompt, the controller will enter the Coin Pay Out Mode. Pressing selection one will scroll through the denominations and pressing selection button two will start the denomination flashing. The display will indicate the denomination along with the number of that coin stored in the coin mechanism. If selection button two is pressed, a pay out of the displayed value will be made. Coins will continue to pay out as long as that selection button is held down.

EXAMPLE: If selection button two is pressed while 5 cents is displayed it will pay out a nickel.

When the controller enters the “**COIn**” mode, the operator is allowed to deposit any coin into the coin changer’s acceptor when that coin’s tube is not full. The tube inventory level will be displayed after each coin is accepted.

tEst Test Mode

If selection button two is pressed at the “**tEst**” prompt, the controller will enter the Test Mode where you are able to test the motors, the display, the compressor, the lights, the evaporator fans and the heater.

UEnd Vend Testing

Pressing selection button two at the test mode will enter the controller into the vend test mode. Upon entry into the vend test mode the display will show the first summary test, “**COL1**” (column 1). Pressing selection button one will scroll through the column selections. Pressing selection button two will test vend the displayed column. In order to exit the setting, press selection button three.

SET-UP AND CODE DESCRIPTION (CONTINUED)

JoG Jogging the Column

Pressing selection button two at the "JoG" mode, will enter into the Jog test mode. Upon entry into the Jog test mode the display will show the first summary test, "COL1" (column 1). Pressing selection button one will scroll through the column selections. Pressing selection button two will access **for** (forward) or **rEU** (reverse). Pressing selection button two again will move the motor in the desired direction. To exit the setting, press selection button three.

diSP Display Testing

Pressing selection button one at the Jog test mode will advance the controller to the Display test mode. Upon entry into the Display test mode the display will flash a series of lines and dashes if all characters in the display are operational. To exit the setting, press selection button three.

rELY Relay Testing

Pressing selection button one at the display test mode will advance the controller into the Relay test mode which allows the user to test the lights, compressor, evaporator fans or the heater. Upon entry into the relay test mode the display will read "cnPO" for the compressor test. To scroll through the components for testing, press selection button one. To activate the component, press selection button two and the "0" will begin to flash. Use selection button one to toggle between "0" (deactivate) and "1" (activate). Pressing selection button two will activate the component if the display reads "XXX1". To exit the setting, press selection button three.

CnPO/1 – Compressor test

Lit0/1 – Light test

FAn0/1 – Evaporator fan test

Htr0/1 – Heater testing

cASh MIS Data – Cash Mode

If selection button two is pressed at the "cASh" prompt, the display will show the non-resettable historical amount of money accepted by the machine. If selection button one is pressed, the display will show "SL 1"(selection one) and the amount received for selection button one. Continue pressing selection button one to scroll through all of the selections. To exit the setting, press selection button three.

SET-UP AND CODE DESCRIPTION (CONTINUED)

SALE MIS Data – Sales Mode

If selection button two is pressed at the “**SALE**” prompt, the display will show the non-resettable historical amount of units sold by the machine. If selection button one is pressed, the display will show “**SL 1**” (selection one) and the units sold for selection button one. Continue pressing selection button one to scroll through all of the selections. To exit the setting, press selection button three.

COSt Cost Setting Mode

The purpose of this mode is to enable the controller to set the vend price for each of the selections. If selection button two is pressed at the “**COSt**” prompt, the display will indicate “**SL 1**”. Pressing selection button one will scroll through all of the selections or “**ALL**” to have all the vend prices set at the same price. Pressing selection button two will enter into the displayed selection button. Pressing selection button one will change the displayed vend price. Pressing selection button two again will save the price and selection button three will exit the mode.

dCtr Discount Counter (Only shows when discounts are used)

The discount counter allows you to access the sales and cash data for vends that have been discounted. Press selection button #2 when the display reads **dCtr**. The display will change to read **CASh**. Press selection button #2 when the display reads **CASh**. The display will change to read **CASh** and XXXX.XX, where XXXX.XX is the value of all discounts towards paid sales. This total is non-resettable and begins when the discount feature is enabled. Pressing selection button #1 will scroll through all of the selection buttons and display the value of the discounts toward product sales. The amounts for the individual selections can be reset using the rules in the **oPts** mode. To exit this mode, press selection button #3. The display will return to **CASh**. To advance to the sales information, press selection button #1. The display **CASh** will change to **SALE**. Press selection button #2 to access this information. The total number of discounted sales will be displayed. This total is non-resettable and begins when the discount feature is enabled. Pressing selection button #1 will scroll through all of the selection buttons and display each selection’s number of discounted sales. The amounts for the individual selections can be reset using the rules in the **oPts** mode.

Fctr Free Counter (Only show if free vends during closed-door sales mode have been made)

The free counter allows you to access the sales and cash data (loss) for vends that have been free. Press selection button #2 when the display reads **Fctr**. The display will change to read XXXX.XX, where XXXX.XX is the value of all lost money based on the price value setting. This total is non-resettable and begins when the free vend override feature is enabled. Pressing selection button #1 will change to the second screen. The display will change to read **SALE** XXX.XX. It will display the total number of free vends that have occurred. This total is non-resettable and begins when the free vend override feature is enabled. Press selection button #3 to exit the mode.

SET-UP AND CODE DESCRIPTION (CONTINUED)

dSet Depth Setting Mode

The purpose of this mode is to enable the controller to set the vending depth for each column. If selection button two is pressed at the “dSet” prompt, the display will indicate “OX”. Pressing selection button one will scroll through all of the columns. Pressing selection button two will enter into the displayed column. Pressing selection button one again will change the displayed depth settings from 1-4. Pressing selection button two will save the depth setting and selection button three will exit the mode.

OPtS Option Mode

If selection button two is pressed at the “OPtS” prompt, the controller will enter the Option mode. The purpose of this mode is to allow the controller to select the configuration options desired.

Display	Description	Meaning
FS	Force Select	Force select enabled (y) or disabled (n)
bE	Bill Escrow	Bill Escrow enabled (y) or disabled (n)
SE	Error/Sold Out Indicator	Error/Sold Out indicator “o” enabled (y) or disabled (n)
SP	Single Price	Single Price enabled (y)/Multi-Price enabled (n)
ct	Count by Price/Count by Selection	y = count by price n = count by selection
CC	Correct Change Light	Correct Change Light enabled (y)/Correct Change Light disabled (n)
OP	Allow Overpay	Allow overpay enabled (y)/Allow overpay disabled (n)
SC	Save Credit	Credit will remain for 5 minutes (y)/Credit will remain indefinitely (n)
NU	Multi Vend	Multi vend enabled, single vend disabled (y)/ Single vend enabled, multi vend disabled (n)
dL	Learning Mode*	Learning mode enabled (y)/Learning mode disabled (n)*
AR	Auto MIS reset	MIS data will reset with DEX read (y)/MIS data will not reset with DEX read (n)

FIGURE 2

* The learning mode uses self adaptive logic to “learn” what the depth setting of the column is, in the event that the control board depth setting isn’t programmed properly.

SET-UP AND CODE DESCRIPTION (CONTINUED)

StS Space-to-Sales Setting Mode

If selection button two is pressed at the “StS” prompt, the controller will enter the Space-to-Sales option. Upon entry into this setting the display will show the current option setting. Pressing selection button one will scroll through the various space to sales options as listed below. Pressing selection button two will change the current option and selection button three will save the desired option. **For proper configuration settings refer to the label located on the inner door shear panel (See figure 3.)**

SPACE-TO-SALES CONFIGURATIONS

SEL#	STS10	STS9	STS8	STS7	STS6	STS5	STS4	STS3	STS2	STS1
	COL	COL	COL	COL	COL	COL	COL	COL	COL	COL
1	1	1,2	1	1	1,2,3	1,2	1	1,2	ALL	NONE
2	2	1,2	2	2	1,2,3	1,2	1	1,2	ALL	NONE
3	3	3	3	3	1,2,3	3	2	3	ALL	NONE
4	4	4	4	4	4	4	2	4	ALL	NONE
5	5	5	5	5	5	5	3	5	ALL	NONE
6	6	6	6	6	6	6	4	6	ALL	NONE
7	7	7	7	7	7	7	5	7	ALL	NONE
8	8	8	8	~	8	8	6	8	ALL	NONE
9	9	9	~	~	9	~	7	9	ALL	NONE
10	10	10	~	~	10	~	8	9	ALL	NONE
11*	~	~	~	~	~	~	9	10	ALL	NONE
12*	~	~	~	~	~	~	10	10	ALL	NONE

FIGURE 3

*Where available

Note: If none of the space-to-sales configurations are suitable, the operator can use the Custom Space-to-Sales Setting Mode.

CStS Custom Space-to-Sales Setting Mode

If selection button two is pressed at the “CStS” prompt, the controller will enter the Custom Space-to-Sales option. Upon entry into this setting the display will show the current selection setting followed by the columns connected to that selection button.

Programming Connection Option

If selection button two is pressed while “SL X” is displayed, the display will change to “CO 1”. Pressing selection button one will increase or decrease the column number displayed. Pressing selection button two will actuate the changed connection status of the column number displayed. If the column number is flashing it is assigned to the selection that was entered. If the column number is steady, it is not assigned to the selection button. To exit this mode, press selection button three to display “SAVE”, then press selection 2 to confirm save.

SET-UP AND CODE DESCRIPTION (CONTINUED)

Cddr Closed Door Data Retrieval Mode

If selection button two is pressed at the “Cddr” prompt, the controller will enter the Closed Door Data Retrieval Mode by displaying “XXXX” where “XXXX” is the password. Pressing selection button number one while the digits are flashing will change the current password. The available digits are 0-6. (See note below.) Pressing selection button two will save the change and advance to the next digit. In order to save the password and exit the mode, press selection button two while the last/fourth digit is flashing.

Note: If one of the digits in the password is “0” this feature will be disabled since selection button “0” does not exist.

Note: This feature is not available when the vend price is set to “0.00”.

LANg Language Mode

If selection button two is pressed at the “LANg” prompt, the controller will enter the Language Mode by displaying the currently assigned language. The available languages are **EnG** – English, **Frn** – French, **GEr** – German, **ItA** – Italian, **Port** – Portuguese, and **ESP** – Spanish. Pressing selection button one will toggle through the language options. If selection button two is pressed, the display will save the language change and return the display to **LANg**.

CLOC Clock Setting Mode

If selection button two is pressed at the “CLOC” prompt, the controller will enter the Clock Mode which allows you to set the clock on the control board. This field must be set in order to operate any modes associated with the time. Pressing selection button two while any of the options are displayed will enter you in to the clock setting options. Pressing selection button one will toggle you through the options. Pressing selection button three will exit this mode.

CLOCK SETTING OPTIONS	
YEAr	Current Year (Example: 2002)
dAtE	Current Date (month, day)
Hour	Current Time (hours, minutes)
dSt	Daylight Savings Time
CtLC	Clock Control

SET-UP AND CODE DESCRIPTION (CONTINUED)

Lite Lighting Control Mode

If selection button two is pressed at the “Lite” prompt, the controller will enter the Lighting Control Mode which allows you to have the lights turned off and on during specific time periods to conserve energy. Pressing selection button two while any of the settings are displayed will enter you in to the light control settings. Pressing selection button one will toggle you through the options. Pressing selection button three will exit this mode.

LIGHTING CONTROL SETTINGS	
Enb	Lighting control enabled (1)/disabled (0)
Str1	Start Time – Time lights shut off
dAY	Days associated with start time
Hour	Hour associated with start time
End1	End Time – Time lights turn back on
dAY	Days associated with end time
Hour	Hour associated with end time
Str2	2nd Start time – time lights shut off
dAY	Days associated with 2nd start time
Hour	Hour associated with 2nd start time
End2	2nd End Time – Time lights turn back on
dAY	Days associated with 2nd end time
Hour	Hour associated with 2nd end time

rFrG Refrigeration Mode

If selection button two is pressed at the “rFrG” prompt, the controller will enter the Refrigeration Control Mode by displaying “SEtP” for set point temperature. Pressing selection button two again enters the temperature settings from “hhh”(warmest) to “ccc”(coldest). Pressing selection button one will toggle through the settings. If selection button two is pressed, the display will return to “SEtP”. Pressing selection button one will change the display to “tNP” for temperature. To view the temperature, press selection button two. To change the degree scale, press selection button two when the display reads “ForC” for Fahrenheit or Celsius. To change the current degree scale, press selection button one to scroll between F and C. Pressing selection button two will return the display to “ForC”.

Note: The displayed thermostat setting and the actual temperature sensor reading for refrigeration control are listed below in Figure 4:

SET-UP AND CODE DESCRIPTION (CONTINUED)

Thermostat Setting Displayed	cccc	ccc	cc	c	norn	h	hh	hhh	hhhh
Cut-in Temperature (F)	34°	35°	36°	37°	38°	39°	40°	41°	42°
Cut-out Temperature (F)	30°	31°	32°	33°	34°	35°	36°	37°	38°
Nominal Temperature (F)	32°	33°	34°	35°	36°	37°	38°	39°	40°
Nominal Temperature (C)	0	0.6	1.1	1.7	2.2	2.8	3.3	3.9	4.4

FIGURE 4

There are two sub-modes within the refrigeration mode that can be activated to achieve energy conservation

The first sub-mode, **FAnX**, refers to an optional evaporator fan relay. When X =

- 0 - the fan mode is disabled and the evaporator will turn on/off with the activation of the compressor
- 1 - (Fan Mode 1) the evaporator fan will turn off 5 minutes after the compressor fan is turned off

The second sub-mode, **dEFX**, refers to the Periodic Defrost mode. If X =

- 0 - the periodic defrost mode is disabled
- 1 - the machine will defrost every 6 hours for 30 minutes - used in high humidity environments .

Within the refrigeration mode, there is also a refrigeration conservation mode which raises the cabinet temperature 18° F or 10° C during specified periods of time. Pressing selection button two while any of the settings are displayed will enter you in to the refrigeration control settings. Pressing selection button one will toggle you through the options. Pressing selection button three will exit this mode.

SET-UP AND CODE DESCRIPTION (CONTINUED)

REFRIGERATION CONTROL SETTINGS	
Enb	Refrigeration control enabled (1)/disabled (0)
Str1	Start Time – Time temperature rises 18°F/10°C
dAY	Days associated with start time
Hour	Hour associated with start time
End1	End Time – Time temperature returns
dAY	Days associated with end time
Hour	Hour associated with end time
Str2	2 nd Start time – Time temperature rises 18°F/10°C
dAY	Days associated with 2 nd start time
Hour	Hour associated with 2 nd start time
End2	2 nd End Time – Time temperature returns
dAY	Days associated with 2 nd end time
Hour	Hour associated with 2 nd end time

- "nno" – Monday
- "tUE" – Tuesday
- "UUE" – Wednesday
- "Thu" – Thursday
- "Fri" – Friday
- "SAt" – Saturday
- "Sun" – Sunday
- "ALL" – All Days

bLC1 Block Selection Setting

This feature is used to choose a group of selections and the time when those selections will be blocked from vending product. If selection button two is pressed at the "bLC1" or "bLC2" prompt, the controller will enter the Selection Blocking Control Mode. Upon entry into this program, the display will show the first sub-mode "Ctl1" or "Ctl2" depending on which blocking mode you are using. Using selection button one will let the operator toggle between the following modes:

SET-UP AND CODE DESCRIPTION (CONTINUED)

BLOCK SELECTION OPTIONS	
CtL1	Controls blocking option
SbL1	Set selection buttons – (y) assigned/(n) not assigned
Str1	Set time for machine to turn off
dAY	Set days for blocking to start
hour	Set hours for blocking to start
StP1	Set time for machine to turn back on
dAY	Set days for blocking to stop
hour	Set hours for blocking to stop

diSC Discount Setting Mode

This feature is used to choose a group of selections that will be discounted, the amount of discount, and the time when the discount will occur. If selection button two is pressed at the “diSC” prompt, the controller will enter the Discount Setting Mode. Upon entry into this program the display will show “CtL1”. If selection button one is pressed it will toggle through the discount setting mode as listed below. Pressing selection button three will save the settings and return to the “diSC” mode.

DISCOUNT SETTING OPTIONS	
CtL1	Turns the discount setting On/Off
SdSC	Set selection buttons – (y) assigned/(n) not assigned
Strt	Set time for discounting to begin
dAY	Set days to discount
Hour	Set time for discounting to begin
StoP	Set time for discounting to stop
dAY	Set days for discounting to stop
Hour	Set time to start (24 hours)
LESS	Set discount amount

SET-UP AND CODE DESCRIPTION (CONTINUED)

OUEr Over-Ride Mode (Units equipped with optional key switch)

This feature is used to allow you to manually over-ride (via a key switch) pricing, blocking, low energy operation and discounting. If selection button two is pressed at the "OUEr" prompt, the controller will enter the Over-Ride Mode. Upon entry into this program the display will show "FrEn". If selection button one is pressed it will cycle through the override setting options as listed below. Pressing selection button three will save the currently displayed setting and return the operator to the "OUEr" prompt.

OVER-RIDE SETTING OPTIONS	
FrEn	Enable/Disable free vend (Edit mode Y/N)
bLCn	Selection blocking over-ride
Litn	Lighting over-ride
rFGn	Refrigeration over-ride
dScn	Discounting over-ride

FrEn Over-Ride Free Vend

If selection button two is pressed at the "FrEn" prompt, the controller will enter the Free Vend Enable Option. Upon entry into this program the display will show the current setting "FrEn". Press selection button two. Pressing selection button one will toggle between "y" for enabled and "n" for disable. Pressing selection button two will save the currently displayed setting. Pressing selection button three will return the operator to the "FrEn" prompt.

"Y" = Enable free vend.

"N" = Disable free vend.

bLCn Over-Ride Selection Blocking

If selection button two is pressed at the "bLCn" prompt, the controller will enter the Selection Blocking Over-Ride Enable Option. Upon entry into this program the display will show the current setting "bLCn". Press selection button two. Pressing selection button one will toggle between "Y" for enable and "N" for disable. Pressing selection button two will save the currently displayed setting. Pressing selection button three will return the operator to the "bLCn" prompt.

"Y" = Enable selection blocking.

"N" = Disable selection blocking

SET-UP AND CODE DESCRIPTION (CONTINUED)

Litn Over-Ride Lighting

If selection button two is pressed at the “Litn” prompt, the controller will enter the Lighting Over-Ride Option. Upon entry into this program the display will show the current setting “Lit4” for enable and “Litn” for disable. Pressing selection button one will toggle between “y” for enabled and “n” for disable. Pressing selection button two will save the currently displayed setting. Pressing selection button three will return the operator to the “Litn” prompt.

“Y” = Enable Over-Ride Lighting blocking.

“N” = Disable Over-Ride Lighting blocking

rFGn Over-Ride Refrigeration

If selection button two is pressed at the “rFGn” prompt, the controller will enter the Refrigeration Over-Ride Option. Upon entry into this program the display will show the current setting “rFG4” for enable and “rFGn” for disable. Pressing selection button one will toggle between “y” for enabled and “n” for disable. Pressing selection button two will save the currently displayed setting. Pressing selection button three will return the operator to the “rFGn” prompt.

“Y” = Enable refrigeration over-ride.

“N” = Disable refrigeration over-ride.


dScn Over-Ride Discount

If selection button two is pressed at the “dScn” prompt, the controller will enter the Discounting Over-Ride Enable Option. Upon entry into this program the display will show the current setting “dSc4” for enable and “dScn” for disable. Pressing selection button one will toggle between “y” for enabled and “n” for disable. Pressing selection button three will save the currently displayed setting and return the operator to the “dScn” prompt.


“Y” = Enable discount over-ride.

“N” = Disable discount over-ride.

12.1 WIRING DIAGRAM



12.1 WIRING DIAGRAM (CONTINUED)



NOTE: If the outer door is left open for over an hour, the lights, and compressor will become active. In order to over-ride this option, press the door switch one time.