

# Operation

## Marine Generator Sets



Models:

**9-32EOZD**  
**7-28EFOZD**

**KOHLER**<sup>®</sup>  
POWER SYSTEMS

**9001**  
**KOHLER**  
POWER SYSTEMS  
NATIONALLY REGISTERED

TP-6710 5/11a



# Table of Contents

<b>Product Identification Information</b> .....	<b>2</b>
<b>Safety Precautions and Instructions</b> .....	<b>5</b>
<b>Introduction</b> .....	<b>9</b>
<b>Service Assistance</b> .....	<b>10</b>
<b>Maintenance and Service Parts/Related Literature</b> .....	<b>11</b>
<b>Section 1 Service Views</b> .....	<b>13</b>
<b>Section 2 Operation</b> .....	<b>15</b>
2.1 Prestart Checklist .....	15
2.2 Marine Inspection .....	16
2.3 Angular Operation .....	16
2.4 Operation in European Union Member Countries .....	16
2.5 Load Profile .....	16
2.6 Advanced Digital Control Operation .....	17
2.6.1 Controls and Indicators .....	17
2.6.2 Starting the Generator Set .....	18
2.6.3 Stopping the Generator Set .....	19
2.6.4 Power Mode Options .....	19
2.6.5 Fault Shutdowns .....	19
2.6.6 Resetting the Controller after a Fault Shutdown .....	21
2.7 Circuit Protection .....	22
2.7.1 Line Circuit Breaker .....	22
2.7.2 Fuses .....	22
<b>Section 3 Scheduled Maintenance</b> .....	<b>23</b>
3.1 General Maintenance .....	23
3.2 Service Schedule—9-32EOZD and 7-28EFOZD Models .....	24
3.3 Lubrication System .....	26
3.3.1 Oil Specifications .....	26
3.3.2 Oil Check .....	26
3.3.3 Oil Change .....	27
3.4 Fuel System .....	28
3.4.1 Fuel Specifications .....	28
3.4.2 Fuel Filter .....	28
3.4.3 Priming the Fuel System .....	29
3.5 Air Intake Silencer/Cleaner .....	30
3.6 Exhaust System .....	31
3.7 Cooling System .....	32
3.7.1 Closed Heat Exchanger .....	32
3.7.2 Checking and Filling Coolant .....	32
3.7.3 Flushing and Cleaning .....	32
3.7.4 Pressure Cap .....	33
3.7.5 Seawater Pump .....	33
3.7.6 Siphon Break .....	34
3.7.7 Anticorrosion Zinc Anode .....	36
3.8 Belt Tension .....	37
3.8.1 Seawater Pump Belt Tensioning Procedure, If Equipped .....	37
3.8.2 Battery Charging Alternator Belt Tensioning Procedure .....	37
3.9 Battery .....	38
3.10 Generator Storage Procedure .....	38

<b>Section 4 Troubleshooting</b> .....	<b>39</b>
4.1 Fault Codes .....	39
4.2 Controller Troubleshooting .....	39
<b>Section 5 Wiring Diagrams</b> .....	<b>43</b>
5.1 Wiring Diagram Reference .....	43
<b>Appendix A Abbreviations</b> .....	<b>49</b>
<b>Appendix B Operating Hour Service Log</b> .....	<b>51</b>

# Safety Precautions and Instructions

IMPORTANT SAFETY INSTRUCTIONS. Electromechanical equipment, including generator sets, transfer switches, switchgear, and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. **SAVE THESE INSTRUCTIONS.**

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.

## DANGER

Danger indicates the presence of a hazard that **will cause severe personal injury, death, or substantial property damage.**

## WARNING

Warning indicates the presence of a hazard that **can cause severe personal injury, death, or substantial property damage.**

## CAUTION

Caution indicates the presence of a hazard that **will or can cause minor personal injury or property damage.**

## NOTICE

Notice communicates installation, operation, or maintenance information that is safety related but not hazard related.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

## Accidental Starting

### WARNING



**Accidental starting. Can cause severe injury or death.**

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

**Disabling the generator set. Accidental starting can cause severe injury or death.** Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

## Engine Backfire/Flash Fire

### WARNING



**Fire. Can cause severe injury or death.**

Do not smoke or permit flames or sparks near fuels or the fuel system.



**Servicing the fuel system. A flash fire can cause severe injury or death.** Do not smoke or permit flames or sparks near the fuel injection system, fuel line, fuel filter, fuel pump, or other potential sources of spilled fuels or fuel vapors. Catch fuels in an approved container when removing the fuel line or fuel system.

**Servicing the air cleaner. A sudden backfire can cause severe injury or death.** Do not operate the generator set with the air cleaner/silencer removed.

**Combustible materials. A sudden flash fire can cause severe injury or death.** Do not smoke or permit flames or sparks near the generator set. Keep the compartment and the generator set clean and free of debris to minimize the risk of fire. Catch fuels in an approved container. Wipe up spilled fuels and engine oil.

**Combustible materials. A fire can cause severe injury or death.** Generator set engine fuels and fuel vapors are flammable and explosive. Handle these materials carefully to minimize the risk of fire or explosion. Equip the compartment or nearby area with a fully charged fire extinguisher. Select a fire extinguisher rated ABC or BC for electrical fires or as recommended by the local fire code or an authorized agency. Train all personnel on fire extinguisher operation and fire prevention procedures.

## Exhaust System

 <b>WARNING</b>

<p><b>Carbon monoxide.</b> <b>Can cause severe nausea, fainting, or death.</b></p> <p>The exhaust system must be leakproof and routinely inspected.</p>

**Carbon monoxide symptoms.** **Carbon monoxide can cause severe nausea, fainting, or death.** Carbon monoxide is a poisonous gas present in exhaust gases. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Carbon monoxide poisoning symptoms include but are not limited to the following:



- Light-headedness, dizziness
- Physical fatigue, weakness in joints and muscles
- Sleepiness, mental fatigue, inability to concentrate or speak clearly, blurred vision
- Stomachache, vomiting, nausea

If experiencing any of these symptoms and carbon monoxide poisoning is possible, seek fresh air immediately and remain active. Do not sit, lie down, or fall asleep. Alert others to the possibility of carbon monoxide poisoning. Seek medical attention if the condition of affected persons does not improve within minutes of breathing fresh air.

**Inspecting the exhaust system.** **Carbon monoxide can cause severe nausea, fainting, or death.** For the safety of the craft's occupants, install a carbon monoxide detector. Never operate the generator set without a functioning carbon monoxide detector. Inspect the detector before each generator set use.

**Operating the generator set.** **Carbon monoxide can cause severe nausea, fainting, or death.** Be especially careful if operating the generator set when moored or anchored under calm conditions because gases may accumulate. If operating the generator set dockside, moor the craft so that the exhaust discharges on the lee side (the side sheltered from the wind). Always be aware of others, making sure your exhaust is directed away from other boats and buildings.



## Fuel System

 <b>WARNING</b>

<p><b>Explosive fuel vapors.</b> <b>Can cause severe injury or death.</b></p> <p>Use extreme care when handling, storing, and using fuels.</p>



**The fuel system.** **Explosive fuel vapors can cause severe injury or death.** Vaporized fuels are highly explosive. Use extreme care when handling and storing fuels. Store fuels in a well-ventilated area away from spark-producing equipment and out of the reach of children. Never add fuel to the tank while the engine is running because spilled fuel may ignite on contact with hot parts or from sparks. Do not smoke or permit flames or sparks to occur near sources of spilled fuel or fuel vapors. Keep the fuel lines and connections tight and in good condition. Do not replace flexible fuel lines with rigid lines. Use flexible sections to avoid fuel line breakage caused by vibration. Do not operate the generator set in the presence of fuel leaks, fuel accumulation, or sparks. Repair fuel systems before resuming generator set operation.

**Draining the fuel system.** **Explosive fuel vapors can cause severe injury or death.** Spilled fuel can cause an explosion. Use a container to catch fuel when draining the fuel system. Wipe up spilled fuel after draining the system.

## Hazardous Noise

 <b>CAUTION</b>

<p><b>Hazardous noise.</b> <b>Can cause hearing loss.</b></p> <p>Never operate the generator set without a muffler or with a faulty exhaust system.</p>

## Hazardous Voltage/ Moving Parts

 <b>WARNING</b>

<p><b>Hazardous voltage. Moving parts.</b> <b>Can cause severe injury or death.</b></p> <p>Operate the generator set only when all guards and electrical enclosures are in place.</p>

**Servicing the generator set when it is operating.** **Exposed moving parts can cause severe injury or death.** Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator set.

**Grounding electrical equipment.** **Hazardous voltage can cause severe injury or death.** Electrocutation is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.


**Disconnecting the electrical load. Hazardous voltage can cause severe injury or death.** Disconnect the generator set from the load by turning off the line circuit breaker or by disconnecting the generator set output leads from the transfer switch and heavily taping the ends of the leads. High voltage transferred to the load during testing may cause personal injury and equipment damage. Do not use the safeguard circuit breaker in place of the line circuit breaker. The safeguard circuit breaker does not disconnect the generator set from the load.

**Short circuits. Hazardous voltage/current can cause severe injury or death.** Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

**Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death.** Connect the generator set to the building/marina electrical system only through an approved device and after the building/marina main switch is turned off. Backfeed connections can cause severe injury or death to utility personnel working on power lines and/or personnel near the work area. Some states and localities prohibit unauthorized connection to the utility electrical system. Install a ship-to-shore transfer switch to prevent interconnection of the generator set power and shore power.

**Testing live electrical circuits. Hazardous voltage or current can cause severe injury or death.** Have trained and qualified personnel take diagnostic measurements of live circuits. Use adequately rated test equipment with electrically insulated probes and follow the instructions of the test equipment manufacturer when performing voltage tests. Observe the following precautions when performing voltage tests: (1) Remove all jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Do not touch the enclosure or components inside the enclosure. (4) Be prepared for the system to operate automatically.  
*(600 volts and under)*

## Hot Parts



## Notice

### NOTICE

**Fuse replacement.** Replace fuses with fuses of the same ampere rating and type (for example: 3AB or 314, ceramic). Do not substitute clear glass-type fuses for ceramic fuses. Refer to the wiring diagram when the ampere rating is unknown or questionable.

### NOTICE

**Saltwater damage.** Saltwater quickly deteriorates metals. Wipe up saltwater on and around the generator set and remove salt deposits from metal surfaces.

# Notes



This manual provides operation instructions for 9-32EOZD and 7-28EFOZD model generator sets.

Refer to the engine operation manual for generator set engine scheduled maintenance information.

Information in this publication represents data available at the time of print. Kohler Co. reserves the right to change this publication and the products represented without notice and without any obligation or liability whatsoever.

Read this manual and carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety Precautions and Instructions section at the beginning of this manual. Keep this manual with the equipment for future reference.

The generator set specification sheets provide specific generator and engine information. Refer to the spec sheet for data not supplied in this manual. Consult the generator set service manual, engine operation manual, and engine service manual for additional specifications. Obtain copies of the latest spec sheets, manuals, diagrams, and drawings from your local distributor/dealer.

The equipment service requirements are very important to safe and efficient operation. Inspect the parts often and perform required service at the prescribed intervals. Obtain service from an authorized service distributor/dealer to keep equipment in top condition.

---

**Before installing a marine generator set, obtain the most current installation manual from your local distributor/dealer. Only qualified persons should install the generator set.**

---

# Service Assistance

---

For professional advice on generator set power requirements and conscientious service, please contact your nearest Kohler distributor or dealer.

- Consult the Yellow Pages under the heading Generators—Electric.
- Visit the Kohler Power Systems website at KohlerPower.com.
- Look at the labels and stickers on your Kohler product or review the appropriate literature or documents included with the product.
- Call toll free in the US and Canada 1-800-544-2444.
- Outside the US and Canada, call the nearest regional office.

## **Headquarters Europe, Middle East, Africa (EMEA)**

Kohler Power Systems  
3 rue de Brennus  
93200 Saint Denis  
France  
Phone: (33) 1 49 178300  
Fax: (33) 1 49 178301

## **Asia Pacific**

Power Systems Asia Pacific Regional Office  
Singapore, Republic of Singapore  
Phone: (65) 6264-6422  
Fax: (65) 6264-6455

## **China**

North China Regional Office, Beijing  
Phone: (86) 10 6518 7950  
(86) 10 6518 7951  
(86) 10 6518 7952  
Fax: (86) 10 6518 7955

East China Regional Office, Shanghai  
Phone: (86) 21 6288 0500  
Fax: (86) 21 6288 0550

## **India, Bangladesh, Sri Lanka**

India Regional Office  
Bangalore, India  
Phone: (91) 80 3366208  
(91) 80 3366231  
Fax: (91) 80 3315972

## **Japan, Korea**

North Asia Regional Office  
Tokyo, Japan  
Phone: (813) 3440-4515  
Fax: (813) 3440-2727

## **Latin America**

Latin America Regional Office  
Lakeland, Florida, USA  
Phone: (863) 619-7568  
Fax: (863) 701-7131

# Maintenance and Service Parts/Related Literature

## Maintenance and Service Parts

Figure 1 identifies maintenance and service parts for your generator set. Obtain a complete list of maintenance and service parts from your authorized generator distributor/dealer.

Part Description	Models						
	9EOZD and 7EFOZD	10EOZD and 8.5EFOZD/ 9EFOZD	13EOZD and 11EFOZD	14EOZD/ 15EOZD and 11.5EFOZD/ 13EFOZD	20EOZD and 17EFOZD/ 17.5EFOZD	23EOZD/ 24EOZD and 20EFOZD	28EOZD/ 32EOZD and 25EFOZD/ 27EFOZD
Air Filter Element	278858	278858	GM24456	229442	GM24456	250902	GM16944
Fuse, Auxiliary Winding (F1) 10 amp	358337	358337	358337	358337	358337	358337	358337
Fuse, Relay Interface Board (F2) 10 amp	223316	223316	223316	223316	223316	223316	223316
Fuse, Controller (F3) 10 amp	223316	223316	223316	223316	223316	223316	223316
Fuel Filter Element	229715	GM32359	GM32359	GM32359	GM32359	GM32359	GM32359
Oil Filter	229678	GM47465	GM47465	GM47465	GM47465	GM47465	252834
Seawater Pump Impeller Kit	229826	229826	229826	229826	229826	229826	229826
V-Belt (Alternator)	GM47044	225428 (12 volt) 226929 (24 volt)	GM11551 (12 volt) 344829 (24 volt)	GM11551 (12 volt) 344829 (24 volt)	GM11551 (12 volt) 344829 (24 volt)	GM11551 (12 volt) 344829 (24 volt)	GM66406 (12 volt) 258955 (24 volt)
V-Belt (Seawater Pump)	GM13660	229125	256503	256503	256503	256503	249989
Zinc Anode	267928	267928	N/A	N/A	N/A	N/A	GM79414

**Figure 1** Maintenance and Service Parts

x:in:001:004

## List of Related Literature

Figure 2 identifies related literature available for the generator sets covered in this manual. Only trained and qualified personnel should install or service the generator set.


Literature Type	Models				
	9EOZD and 7EFOZD	10EOZD and 8.5/9EFOZD	13-15EOZD and 11-13EFOZD	20-24EOZD and 17-20EFOZD	28/32EOZD and 25/28EFOZD
Installation Manual	TP-6711				
Operation Manual	TP-6710				
Parts Catalog*	TP-6270	TP-6270	TP-6271	TP-6272	TP-6273
Service Manual (Engine)	TP-6709	TP-6703	TP-6703	TP-6703	TP-6703
Service Manual (Generator)	TP-6255				

\* Includes generator and engine information.

**Figure 2** Generator Set Literature

xin:001:005


# Section 1 Service Views



**Figure 1-1** Service Views—Typical (9EOZD/7EFOZD Model Shown Unless Noted)

**Note:** Consult installation drawings in the spec sheet or installation manual for fuel and battery connection points. Consult an authorized distributor/dealer or the service manual for items not shown.

**⚠ WARNING**




**Accidental starting.  
Can cause severe injury or death.**

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

**Sound Shield Equipped Models:** For access to the generator set to perform regular maintenance, remove the sound shield doors and roof.


**Sound Shield Roof and Door Removal**

1. Open the service-side door.
2. Release the two quarter-turn fasteners located underneath the roof. See Figure 1-2.
3. Lift up the roof.
4. Slide the roof towards the service side of the unit for removal.
5. Open the front, rear, and non-service side doors as needed.



**Figure 1-2** Sound Shield Roof Removal

### 2.1 Prestart Checklist



**Operating the generator set. Carbon monoxide can cause severe nausea, fainting, or death.** Be especially careful if operating the generator set when moored or anchored under calm conditions because gases may accumulate. If operating the generator set dockside, moor the craft so that the exhaust discharges on the lee side (the side sheltered from the wind). Always be aware of others, making sure your exhaust is directed away from other boats and buildings.

To ensure continued satisfactory operation perform the following checks or inspections before or at each startup, as designated, and at the intervals specified in the service schedule. In addition, some checks require verification after the unit starts.

**Air Cleaner.** Check for a clean and installed air cleaner element to prevent unfiltered air from entering the engine.

**Air Inlets.** Check for clean and unobstructed air inlets.

**Battery.** Check for tight battery connections. Consult the battery manufacturer's instructions regarding battery care and maintenance.

**Coolant Level.** Check the coolant level according to the cooling system maintenance information.

**Drive Belts.** Check the belt condition and tension of the water pump and battery charging alternator belt(s).

**Exhaust System.** Check for exhaust leaks and blockages. Check the silencer and piping condition and check for tight exhaust system connections.

Inspect the the exhaust system components (exhaust manifold, mixing elbow, exhaust line, hose clamps, silencer, and outlet flapper) for cracks, leaks, and corrosion.

- Check the hoses for softness, cracks, leaks, or dents. Replace the hoses as needed.
- Check for corroded or broken metal parts and replace them as needed.
- Check for loose, corroded, or missing clamps. Tighten or replace the hose clamps and/or hangers as needed.
- Check that the exhaust outlet is unobstructed.
- Visually inspect for exhaust leaks (*blowby*). Check for carbon or soot residue on exhaust components. Carbon and soot residue indicates an exhaust leak. Seal leaks as needed.
- Ensure that the carbon monoxide detector(s) is (1) in the craft, (2) functional, and (3) energized whenever the generator set operates.

**For your safety: Never operate the generator set without a functioning carbon monoxide detector(s) for your safety and the safety of others on your vessel.**

**Fuel Level.** Check the fuel level and keep the tank(s) full to ensure adequate fuel supply.

**Oil Level.** Maintain the oil level at or near, not over, the full mark on the dipstick.


**Operating Area.** Check for obstructions that could block the flow of cooling air. Keep the air intake area clean. Do not leave rags, tools, or debris on or near the generator set.

**Seawater Pump Priming.** Prime the seawater pump before initial startup. To prime the pump: (1) close the seacock, (2) remove the hose from the seawater-filter outlet, (3) fill the hose and seawater pump with clean water, (4) reconnect the hose to the water filter outlet, and (5) open the seacock. Confirm seawater pump operation on startup as indicated by water discharge from the exhaust outlet.

## 2.2 Marine Inspection

Kohler Co. recommends that all boat owners have their vessels inspected at the start of each boating season by the US Coast Guard, the local Coast Guard Auxiliary, or local state agency.

Kohler Co. also recommends having the generator's exhaust system inspected at the start of each boating season by an authorized Kohler® distributor/dealer. Repair any problems identified before operating the generator set.



## 2.3 Angular Operation

See Figure 2-1 for angular operation limits.

Continuous	Intermittent— 3 minutes or less
25°	30°
Maximum value for all directions	

Figure 2-1 Angular Operation

## 2.4 Operation in European Union Member Countries

This generator set is specifically intended and approved for operation below the deck in the engine compartment. Operation above the deck and/or outdoors would constitute a violation of European Union Directive 2000/14/EC noise emission standard.

## 2.5 Load Profile

Whenever operating the generator set, Kohler Co. recommends maintaining the minimum load profile indicated in Figure 2-1. Maintaining the load profile prevents corrosion formation on internal engine components when they're exposed to the breakdown of exhaust gases. Extended light loading may result in engine "wet stacking".

Minimum Load Requirement	Ideal Load Requirement
30% load	70% load or more

Figure 2-2 Load Profile

**Wet Stacking** occurs when water vapor condenses in the exhaust system. At normal combustion temperatures, water stays vaporized but at low combustion temperatures, it condenses back to a liquid. When running the generator set under normal loads (30% load or more), diesel exhaust stays hot enough to prevent water vapor from condensing. At low load situations, wet stacking can occur.


The operator should perform all of the prestart checks. Start the generator set according to the starting procedure in the controller section of this manual. While the generator set is operating, listen for a smooth-running engine and visually inspect the generator set for fluid or exhaust leaks.



## 2.6 Advanced Digital Control Operation

Figure 2-3 illustrates the user interface on the Advanced Digital Control (ADC 2100).

**Note:** Have setup and adjustments of the ADC 2100 performed only by an authorized Kohler distributor/dealer. The setup and adjustments are password protected.



**Figure 2-3** ADC 2100 Control

Control or Indicator	Item	Description
LED display	Runtime hours	Displays total generator set runtime hours.
	Crank indication	Displays CC_1, CC_2, or CC_3 to indicate the first, second or third attempt to start the engine. The last digit flashes during the crank cycle rest periods.
	Fault codes	Flashes a 2- or 3-letter fault code to indicate various fault conditions. See Section 2.6.5.
	Software version	See the Generator Set Installation Manual.
Keypad	Select and arrow buttons	The keypad is used for controller setup and adjustment only. Have setup and adjustments performed only by an authorized distributor/dealer. The setup and adjustment functions are password-protected.
Generator set master switch	Three-position switch	Switch functions as the generator set operation and controller reset switch.


**Figure 2-4** ADC 2100 Controls and Indicators

### 2.6.1 Controls and Indicators

Figure 2-4 describes the controls and indicators located on the controller. The LED display indicates generator set status as shown in Figure 2-4. The display is active when the master switch is in the RUN or AUTO position and remains active until the generator set master switch is moved to the OFF/RESET position or the power to the controller is removed.

The buttons on the controller keypad are used only for system configuration and adjustment. The controller is factory-set and should not require configuration or adjustment under normal operating conditions. If the generator set is reconnected to a different voltage and/or frequency, refer to an authorized Kohler distributor/dealer for system configuration and adjustment instructions.

## 2.6.2 Starting the Generator Set



**Operating the generator set. Carbon monoxide can cause severe nausea, fainting, or death.** Be especially careful if operating the generator set when moored or anchored under calm conditions because gases may accumulate. If operating the generator set dockside, moor the craft so that the exhaust discharges on the lee side (the side sheltered from the wind). Always be aware of others, making sure your exhaust is directed away from other boats and buildings.

**Note: Opening the seacock.** Before starting the generator set, open the seacock to allow cooling water passage. Failure to do so could damage the seawater pump impeller and cause serious engine overheating damage.

**Note: Transfer switch.** Check that the marine ship-to-shore transfer switch, if equipped, is in the ship position.

**Note: If the generator set does not start after 3 crank attempts (an overcrank fault occurs):**

- 1) Close the seacock.
  - 2) Completely drain the water from the exhaust system at the silencer's drain plug.
  - 3) Do not attempt generator set restart.
  - 4) Contact an authorized Kohler® distributor/dealer.
- A water-filled exhaust piping and silencer may further hinder generator starting and cause seawater entry into the engine cylinders through the exhaust valves. Water ingested into the engine may cause major engine damage that the Kohler Co. warranty does not cover.

The following procedures describe the actions required to start the generator set.

The controller attempts to start the generator set three times. If the generator set does not start in three attempts, the system shuts down on an overcrank fault.

### Local Starting.

Move the generator set master switch to the RUN position. The ADC 2100 attempts to start the generator set in three crank cycles (crank cycle time is pre-programmed).

### Auto (Automatic) Starting.

Move the generator set master switch to the AUTO position to allow startup by the remote start/stop switch or remote digital gauge. A remote start/stop switch (connected to P21 connector leads 3 and 4) or a remote digital gauge (connected to P21, pins 1, 2, and 5 via CAN) can be connected to the customer interface connection. See the wiring diagrams in Section 5.

**Note:** The ADC 2100 allows three crank cycle attempts before the overcrank shutdown occurs.

### 2.6.3 Stopping the Generator Set

The following procedures describe the actions required to stop the generator set.

#### Local Stopping.

1. Run the generator set at no load for at least 2 minutes to ensure adequate engine cooldown.
2. Move the generator set master switch to the OFF/RESET position. The engine stops.

#### Auto (Automatic) Stopping.

1. Run the generator set at no load for at least 2 minutes to ensure adequate engine cooldown.
2. With the generator set master switch in the AUTO position, the generator set stops when the remote start/stop switch contacts close momentarily.

**Note:** If the ADC 2100 is configured for a CAN gauge, see Section 2.6.4 for possible power mode options.

**Note:** If the ADC 2100 is not configured for a CAN gauge, the controller will power down after 48 hours (if the master switch is in the AUTO position). If the generator has been started, the controller will power down 48 hours after the generator stops. See Section 2.6.4.

### 2.6.4 Power Mode Options

The controller is powered by the generator set engine starting battery.

**Note:** Remote communications require an active (powered-up) controller. Be advised that the ADC consumes 250 mA when the master switch is in the AUTO position. If you do not plan to use your generator set for a long period of time, Kohler recommends moving the master switch to the OFF/RESET position (complete power down, 0 mA draw).

With the generator set master switch in the AUTO position, there are three possible controller power mode options.

**Note:** Have setup and adjustments of the ADC 2100 performed only by an authorized Kohler distributor/dealer. The setup and adjustments are password protected.

- **48-hour power down.** If the ADC 2100 communication parameter setting has a 48-hour power down, the controller will power down after 48 hours of inactivity. If the generator set has been started, the controller will power down 48 hours after the generator set stops.

- **Continuous power mode.** If the ADC 2100 communication parameter setting has a continuous power mode, the controller will not power down. The controller remains powered at all times to maintain CAN communications and allow remote start commands from the CAN gauge.

- **1-hour power down.** If the ADC 2100 communication parameter setting has a 1-hour power down, the controller will power down after 1 hour of inactivity. In this mode, a remote start/stop switch or the generator set master switch must be used to activate the controller after it has powered down. ADC 2100 application code version 1.21 or higher is required for the 1-hour power down option.

**Note:** After controller power down, a remote digital gauge will not have power and therefore will not be able to send a start signal to activate the controller.

**Note:** Kohler's 2-inch digital gauge allows "wake-up" of the controller remotely.

### 2.6.5 Fault Shutdowns

The generator set shuts down automatically under the fault conditions listed in Figure 2-5 and the controller displays a fault code. The generator set cannot be restarted until the fault condition is corrected and the controller is reset. See Section 2.6.6 to reset the controller after a fault shutdown. The controller resets automatically after a battery voltage fault condition is corrected.

Shutdown switches on the generator set automatically reset when the problem is corrected. The high engine temperature switch automatically resets when the generator set cools. However, the fault does not clear until the controller is reset.

The controller displays a fault code but the generator set does not shut down under the conditions shown in Figure 2-6.

Code	Fault	Description	Check
AF	Auxiliary fault input shutdown	Input from a customer-supplied switch that closes when the fault is active. Shutdown occurs 0.3 seconds after the fault is detected and will not start when the fault is active (input is grounded). This protection becomes active 3 seconds after crank disconnect.	Check the cause of the auxiliary fault.
HE	High engine temperature shutdown	Shutdown occurs if the engine coolant temperature exceeds the maximum temperature for more than 5 seconds. This protection becomes active after the engine reaches the crank disconnect speed. <b>Note:</b> The high engine temperature shutdown functions only when the coolant level is in the operating range.	Check for a low engine coolant level.
LOC	Loss of seawater pressure and flow shutdown	Shutdown occurs 5 seconds after a loss of seawater pressure and flow condition is detected. This protection becomes active 10 seconds after the engine has reached its stated crank disconnect speed and remains active as long as the generator run command is active.	Check for a clogged seawater intake or sea strainer. Check for a damaged seawater pump impeller. Check the exhaust temperature switch and loss of coolant switch wiring for grounded connections.
LOP	Low oil pressure shutdown	Shutdown occurs if a low oil pressure condition exists for more than 5 seconds. This protection becomes active 30 seconds after the engine has reached crank disconnect speed (30 second inhibit). <b>Note:</b> The low oil pressure shutdown does not protect against low oil level. Check the oil level at the engine.	Check for leaks in the lubrication system. Check the oil level and add oil if the level is low.
OC	Overcrank shutdown	Shutdown occurs after 3 unsuccessful starting attempts. The crank cycle is set for three starting attempts.	Check the fuel supply and battery. If there is no output voltage, check the line circuit breaker. Also check for loose connections. Contact an authorized distributor/dealer for service.
OF	Overfrequency shutdown	Shutdown occurs when the governed frequency exceeds 110% of the system's frequency setpoint for more than 5 seconds. This protection becomes active 10 seconds after engine start (10 second inhibit).	Contact an authorized distributor/dealer for service if problem continues.
OS	Overspeed shutdown	Shutdown occurs if the engine speed exceeds 115% of the normal running speed for more than 0.3 seconds.	Contact an authorized distributor/dealer for service if problem continues.
OU	Overvoltage shutdown	Shutdown occurs if the voltage exceeds 120% of the voltage regulator setpoint for more than 2 seconds.	Contact an authorized distributor/dealer for service if problem continues.
UF	Underfrequency shutdown	Shutdown occurs when the governed frequency falls below 90% of the system's frequency setpoint for more than 5 seconds. This protection becomes active 10 seconds after engine start (10 second inhibit).	Reduce the load and restart the generator set. Contact an authorized distributor/dealer for service if problem continues.
UU	Undervoltage shutdown	Shutdown occurs if the voltage falls below 80% of the voltage regulator setpoint for more than 10 seconds.	Reduce the load and restart the generator set. Contact an authorized distributor/dealer for service if problem continues.
SCF0	Controller error	Indicates a software or communication problem within the ADC 2100.	Contact an authorized distributor/dealer for service if problem continues.

**Figure 2-5** ADC 2100 Fault Shutdown Codes

Code	Fault	Description	Check
HB	High battery voltage warning	Fault code is displayed if the engine starting battery voltage rises above 16 VDC for a 12 VDC system or above 30 VDC for a 24 VDC system for more than 2 seconds when the engine is not running. This fault condition does not inhibit engine starting.  The fault condition clears when the battery voltage returns to a voltage within the limits for more than 2 seconds.	Check the battery rating and condition.
LB	Low battery voltage warning	Fault code is displayed if the engine starting battery voltage falls below 9.5 VDC for a 12 VDC system or below 16 VDC for a 24 VDC system for more than 2 seconds when the engine is not running. This fault condition does not inhibit engine starting.  The fault condition clears when the battery voltage returns to a voltage within the limits for more than 2 seconds.	Check the battery rating and condition.  Charge or replace the battery.

**Figure 2-6** ADC 2100 Fault Warning Codes

## 2.6.6 Resetting the Controller after a Fault Shutdown

Always identify and correct the cause of a fault shutdown before resetting the controller. Use the following procedure to reset the generator set controller after a fault shutdown.

1. Move the generator set master switch to the OFF/RESET position.
2. Disconnect the generator set from the load using the line circuit breaker or ATS. See the safety precautions at the beginning of this manual before proceeding.
3. Identify and correct the cause of the fault shutdown. See the safety precautions at the beginning of this manual before proceeding. Refer to Section 4, Troubleshooting.

4. Start the generator set by moving the generator set master switch to RUN. Test operate the generator set to verify that the cause of the shutdown has been corrected.
5. Shut the generator off by moving the generator set master switch to the OFF/RESET position.
6. Reconnect the generator set to the load using the line circuit breaker or ATS.
7. Move the generator set master switch to the AUTO position for startup by remote transfer switch, remote start/stop switch, or remote digital gauge.

**Note:** The controller's LED display remains off until an engine start command is received.

**Opening and closing the remote start/stop contact also resets the controller.**

## 2.7 Circuit Protection

If the generator set circuit breaker trips or the fuses blow repeatedly, see Section 4, Troubleshooting, for possible causes.

### 2.7.1 Line Circuit Breaker

A line circuit breaker interrupts the generator output in the event of a fault in the wiring between the generator and the load. The line circuit breaker location is shown in Figure 1-1. If the circuit breaker trips, reduce the load and switch the breaker back to the ON position.

### 2.7.2 Fuses

The engine harness (or junction box for the 9EOZD/7EFOZD model) contains three 10-amp inline fuses. Always identify and correct the cause of a blown fuse before restarting the generator set. Refer to section 4, Troubleshooting, for conditions that may indicate a blown fuse. Obtain service from an authorized distributor/dealer.

**Controller Fuse.** A replaceable 10-amp fuse protects the controller circuitry. If the controller display is dark, check the battery and battery connections and then check the controller fuse. Replace the fuse if it is blown.


**Relay Fuse.** A replaceable 10-amp fuse protects the engine relays. If the generator set does not crank, check the battery and battery connections and then check the relay fuse. Replace the fuse if it is blown.

**Auxiliary Winding Fuse.** A replaceable 10-amp fuse protects the alternator.

Fuse	Label	Location (*)
Auxiliary Winding	F1	Lead 55
Relay Interface Board	F2	Lead PF2
Controller	F3	Lead PF1

\* See Figure 2-8 for the fuse location on 9EOZD/7EFOZD models.

**Figure 2-7** Fuses




**Figure 2-8** Fuse Location on 9EOZD/7EFOZD Model

## Section 3 Scheduled Maintenance

### 3.1 General Maintenance



#### WARNING



#### **Accidental starting. Can cause severe injury or death.**

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

**Disabling the generator set. Accidental starting can cause severe injury or death.** Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.



#### **Hazardous voltage. Moving parts. Can cause severe injury or death.**

Operate the generator set only when all guards and electrical enclosures are in place.

**Servicing the generator set when it is operating. Exposed moving parts can cause severe injury or death.** Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator set.

#### NOTICE

**Saltwater damage.** Saltwater quickly deteriorates metals. Wipe up saltwater on and around the generator set and remove salt deposits from metal surfaces.

#### NOTICE

The engine and generator set may use both American Standard and metric hardware. Use the correct size tools to prevent rounding of the bolt heads and nuts.

See the Safety Precautions and Instructions at the beginning of this manual before attempting to service, repair, or operate the generator set. Have an authorized distributor/dealer perform generator set service.

**Engine Service.** Perform generator set engine service at the intervals specified by the engine operation manual.

**Generator Set Service.** Perform generator set service at the intervals specified by the generator set operation manual.

If the generator set operates under dusty or dirty conditions, use *dry* compressed air to blow dust out of the alternator. With the generator set running, direct the stream of air in through the cooling slots at the alternator end.

**Routine Maintenance.** Refer to the following generator set service schedule, the engine service schedule, and the runtime hours shown on the ADC 2100 to determine when to schedule routine maintenance. Service more frequently generator sets that are subject to extreme weather or dusty or dirty conditions.

**Service Log.** Use the Operating Hour Service Log located in the back of this manual to document performed services.

**Service Schedule.** Perform maintenance on each item in the service schedule at the designated intervals for the life of the generator set. For example, an item requiring service every 100 hours or 3 months also requires service after 200 hours or 6 months, 300 hours or 9 months, and so on.

### 3.2 Service Schedule—9-32EOZD and 7-28EFOZD Models

Perform Service at Intervals Indicated (X)	Reference Section	Daily	Every 50 Hrs. or 1 Month	Every 250 Hrs. or 3 Months	Every 500 Hrs. or 6 Months	Every 1000 Hrs. or Yearly
<b>FUEL SYSTEM</b>						
Check the fuel level and fill as necessary	3.4	X (Before operation)				
Check for any unusual noise †		X (During operation)				
Remove the sediment from the fuel tank and drain the fuel tank †§				X		
Bleed the fuel system (if encountering hard starting)	3.4.3		X			
Replace the fuel filter element *	3.4.2				X	
Fuel/water separator draining *†			X			
Fuel/water separator cleaning *†					X	
Inspect, clean, and test the fuel injectors *†‡	Eng. S/M					X (1500 hrs.)
Inspect the fuel injection nozzle pressure *†‡	Eng. S/M					X
Adjust the fuel injection timing *†‡	Eng. S/M					X (2000 hrs. or 2 yrs.)
Inspect and adjust the fuel injection pump *†‡	Eng. S/M					X (2000 hrs. or 2 yrs.)
<b>LUBRICATION SYSTEM</b>						
Check the crankcase oil level and add oil as necessary	3.3.2	X (Before operation)				
Replace the oil in the crankcase *	3.3.3		X (Break-in period)	X		
Replace the lube oil filter element *	3.3.3		X (Break-in period)	X		
<b>COOLING SYSTEM</b>						
Check the coolant level and fill as necessary *	3.7.2	X (Before operation)				
Check the seawater outlet and clean as necessary	3.6	X				
Check/adjust the seawater pump belt tension *	3.8.1		X (Break-in period)	X		
Check the function of the siphon break, if equipped	3.7.6			X		
Check/replace the seawater pump impeller *†	3.7.5				X (Check)	X (Replace)
Replace the coolant *†	3.7.3					X
Check/replace the heat exchanger anticorrosion zinc anode, if equipped *†	3.7.7			X (Check 100 hrs.)		X (Replace)

\* Requires removal of the sound shield door, if installed

† Consult your local distributor/dealer for service

‡ Read the WARNING found at the beginning of the manual regarding moving parts

§ Consult the operating instructions supplied with the craft



## Service Schedule—9-32EOZD and 7-28EFOZD Models, continued

Perform Service at Intervals Indicated (X)	Reference Section	Daily	Every 50 Hrs. or 1 Month	Every 250 Hrs. or 3 Months	Every 500 Hrs. or 6 Months	Every 1000 Hrs. or Yearly
<b>INTAKE/EXHAUST SYSTEM</b>						
Inspect the exhaust system components *†	3.6	X (Before operation)				
Check the exhaust gas condition. If the exhaust is blue or black, contact your local distributor/dealer	3.6	X (During operation)				
Clean the air cleaner element *	3.5			X		
Replace the air cleaner element *	3.5				X	
Clean the exhaust/water mixing elbow *†	3.6				X	
Inspect the crankcase breather system *†	Eng. S/M					X (1500 hrs.)
Check the breather pipe for obstructions *†					X	
Clean the turbocharger blower, if equipped *†						X (1500 hrs.)
Inspect the complete exhaust system †	2.2					X
<b>ELECTRICAL SYSTEM</b>						
Keep the battery charged and in good condition §	3.9	X (Before operation)				
Check/adjust the alternator driving belt tension *	3.8.2		X (Break-in period)	X		
Check and tighten the electrical connections *			X			
Clean the battery cables †						X
<b>ENGINE AND MOUNTING</b>						
Check for water, fuel, coolant, and oil leakage *†‡		X (After operation)				
Retighten any loose nuts and bolts *		X (Before operation)				
Check the mounting bolts/vibromounts and tighten if necessary *					X	
Adjust the intake/exhaust valve clearance *†	Eng. S/M					X
Lap the intake/exhaust valve seats *†	Eng. S/M					X (2000 hrs. or 2 yrs.)
Check the compartment condition (fuel, oil, or water leaks)		X (Before operation)				
<b>REMOTE START PANEL</b>						
Check the remote start panel operation, if equipped			X (Break-in period)			X
<b>GENERATOR</b>						
Test run the generator set			X (Weekly)			
Blow dust out of the generator *†	3.1					X

\* Requires removal of the sound shield door, if installed

† Consult your local distributor/dealer for service

‡ Read the WARNING found at the beginning of the manual regarding moving parts

§ Consult the battery manufacturer's instructions

### 3.3 Lubrication System


See the Scheduled Maintenance section for oil change and oil filter replacement intervals. See Section 1 for the oil drain, oil check, oil fill, and oil filter locations.

x:sm:001:002:

#### 3.3.1 Oil Specifications

Use oil that meets the American Petroleum Institute (API) classification of CD or CF. Using an unsuitable oil or neglecting an oil change may result in damage and a shorter engine life. Figure 3-1 shows the recommended Society of Automotive Engineers (SAE) viscosity designation for given operating temperature ranges.


**Note:** Failure to observe the oil specifications may cause inadequate lubrication/oil pressure and cold-starting difficulties.



**Figure 3-1** Engine Oil Selection for Models 9-32EOZD and 6.5-28EFOZD

#### 3.3.2 Oil Check

Check the oil level in the crankcase daily or before each startup to ensure that the level is in the safe range. To check the oil level, remove the dipstick and wipe the end clean, reinsert as far as possible, and remove. Maintain the oil level between the Min and Max marks on the dipstick, as shown in Figure 3-2. See Section 1 for dipstick location.



**Figure 3-2** Oil Level Check Marks

**Note:** Do not operate the set if the oil level is below the Min mark or above the Max mark.

### 3.3.3 Oil Change

Change the oil more frequently if the generator operates under dirty, dusty conditions. See Figure 3-3 for oil capacities.

Model	L (Qts.)
9EOZD and 7EFOZD	3.6 (3.8)
10EOZD and 8.5/9EFOZD	3.6 (3.8)
13/14/15EOZD and 11/11.5/13EFOZD	4.7 (5.0)
20/23/24EOZD and 17/17.5/20EFOZD	5.8 (6.1)
28/32EOZD and 25/28EFOZD	10.2 (10.8)

**Figure 3-3** Oil Capacities

#### Oil Change Procedure

Whenever possible, drain the oil while it is still warm.

##### 1. Drain the oil.

- Place the generator set master switch in the OFF position.
- Disconnect the power to the battery charger, if equipped.
- Disconnect the generator set engine starting battery, negative (-) lead first.
- Remove the oil drain hose from its retaining clip. Remove the cap from the oil drain hose and lower the hose into an oil collection container.

**Electric Oil Drain/Oil Fill Pump Procedure:** Connect the pump to the end of the oil drain hose. Place the outlet of the pump into an oil collection container. Remove the oil fill cap(s).

- Open the oil drain valve on the engine.
- Allow time for the engine oil to drain completely.

**Electric Oil Drain/Oil Fill Pump Procedure:** Activate the pump until all of the oil is removed. Go to step 2.

- Close the oil drain valve.
- Replace the cap on the oil drain hose. Replace the oil drain hose in its retaining clip.

##### 2. Replace the oil filter.

- Remove the oil filter by rotating it counterclockwise with an oil filter wrench.
- Apply a light coat of clean oil to the rubber seal of the new oil filter.
- Install the new oil filter following the instructions provided with the filter.

**Note:** Dispose of all waste materials (engine oil, fuel, filter, etc.) in an environmentally safe manner.

##### 3. Fill with oil.

Add new oil of the weight, grade, and quantity specified in Section 3.3.

**Electric Oil Drain/Oil Fill Pump Procedure:** Disconnect the pump. Close the oil drain valve. Replace the cap on the oil drain hose.

##### 4. Check for leaks.

- Check that the generator set master switch is in the OFF position.
- Reconnect the generator set engine starting battery, negative (-) lead last.
- Reconnect the power to the battery charger, if equipped.
- Start the generator set and check for leaks around the oil filter.
- Stop the generator set and tighten the oil filter to stop any leaks.

x:sm:001:003:

## 3.4 Fuel System

### 3.4.1 Fuel Specifications

Use a clean, good quality diesel fuel oil with a cetane number of 45 or greater. Clean fuel prevents the diesel fuel injectors and pumps from clogging.

Diesel Fuel Recommendations	
United States	No. 2-D, No. 1-D, ASTM D975-94
United Kingdom	BS 2869-A1 or A2
European Union	EN590:96
Japan	JIS K2204 Grade No. 2
Korea	KSM-2610
China	GB252

**Note:** Never store diesel fuel in galvanized containers; diesel fuel and the galvanized coating react chemically to produce flaking that quickly clogs filters or causes fuel pump or injector failure.

**Note:** Avoid storing fuel for more than one month. Take special precautions to keep all dirt, water, and other contaminants out of fuel to prevent the growth of microbes. Microbes form slime that clogs the fuel filter and lines.

**Note:** Do not run the generator set out of fuel because the fuel lines will draw in air and necessitate bleeding the fuel system before restarting the unit.

### 3.4.2 Fuel Filter

The quality and condition of the fuel largely determine the filter's useful life. Replace the fuel filter element as listed in the service schedule. Section 1 shows the typical location of a fuel filter. Use the applicable procedure below to replace the fuel filter.

#### Fuel Filter Cleaning/Replacement Procedure

##### 9EOZD and 7EFOZD Models:

1. Close the fuel supply valve.
2. Remove the collar from the fuel filter adapter while holding the filter bowl in place.

3. Remove the filter bowl and fuel filter. Clean the fuel filter with fresh diesel fuel and blow compressed air from the inside outward. Replace a damaged fuel filter. Dispose of the fuel filter in an approved manner.
4. Wipe off all parts with a clean rag. Inspect all mating surfaces and threads for damage; replace as necessary.
5. Place the fuel filter into the filter bowl and lubricate the rubber seal with fresh diesel fuel.
6. With the collar against the filter bowl flange, position the fuel filter against the adapter and hand-tighten the collar.
7. Wash hands after any contact with fuel oil.
8. Open the fuel supply valve.
9. Prime the system. See Section 3.4.3, Priming the Fuel System.

##### 10-32EOZD and 9-28EFOZD Models:

1. Close the fuel supply valve.
2. Loosen the fuel filter by turning it counterclockwise. Remove the fuel filter and use rags to clean up spilled fuel oil. Dispose of the fuel filter in an approved manner.
3. Clean the contact surface of the fuel oil filter adapter.
4. Lightly lubricate the gasket surface of the new fuel filter with fresh fuel oil. Thread the filter on the adapter until the gasket makes contact; hand-tighten the filter an additional one-half turn. Wash hands after any contact with fuel oil.
5. Open the fuel supply valve.
6. Bleed the system. See Section 3.4.3, Priming the Fuel System.

### 3.4.3 Priming the Fuel System

Prime the fuel system to bleed the air from the system. Trapped air in the fuel system can cause difficult starting and erratic engine operation.


Prime the fuel system under the following conditions:

- Before starting the engine for the first time.
- After running out of fuel and adding fuel to the tank.
- After fuel system maintenance such as changing the fuel filter, draining the fuel/water separator, or replacing a fuel system component.

#### Fuel System Priming Procedure (Preferred)

**Note:** To prevent damage to the starter motor, do not crank the engine to prime the fuel system. Use the following procedure.

1. Press and hold the Select button located on the ADC. See Figure 3-4.
2. Move the generator set master switch to the RUN position to enter the programming mode.
3. Continue to hold the Select button for 10 seconds. The ADC will display "Fuel" and the fuel priming pump will start.
4. Continue to hold the Select button for as long as you want the fuel priming pump to function (typically 10 seconds).
5. Release the Select button and move the Master switch to the OFF position.
6. Place the Master switch to the RUN position to start the unit.



**Figure 3-4** ADC Control

#### Fuel System Priming Procedure

If the above priming procedure does not accomplish adequate fuel system priming, use the following procedure.

**Note:** Connect the battery during the priming procedure to allow engine cranking.

**Note:** If the ADC 2100 indicates an overcrank fault during this procedure, disconnect the negative wire from the fuel solenoid (allowing the fuel injection pump to fill with fuel) and repeat this procedure after allowing the starter motor to cool down.


**Note:** Have a rag handy during the bleeding procedure. Wipe up all spilled diesel fuel after bleeding the system. Wash hands after any contact with fuel oil.

#### 9EOZD and 7EFOZD Models:

1. Loosen the fuel filter screw at position 1. See Figure 3-5.
2. Initiate the auto/start sequence until fuel, free of air bubbles, flows from the vent screw at position 1. Tighten the screw.
3. Loosen the fuel filter screw at position 2.
4. Initiate the auto/start sequence until fuel, free of air bubbles, flows from the vent screw at position 2. Tighten the screw.
5. Loosen the fuel injection pump screw at position 5.
6. Initiate the auto/start sequence until fuel, free of air bubbles, flows from the vent screw at position 5. Tighten the screw.

#### 10-32EOZD and 9-28EFOZD Models:

1. Loosen the fuel injection pump screw. See Figure 3-5.
2. Initiate the auto/start sequence until fuel, free of air bubbles, flows from the injection pump screw.
3. Tighten the fuel injection pump screw.



**Figure 3-5** Fuel System (Typical)

### 3.5 Air Intake Silencer/Cleaner

At the interval specified in the service schedule, clean or *replace* the air intake filter. Clean the filter more frequently if the generator set operates in dirty, dusty conditions. Follow one of the procedures described below.


#### Air Cleaner Service/Replacement

##### 9/10EOZD and 7/9EFOZD Models:

A dry-type air cleaner silences and filters the intake air. The air intake silencer assembly connects to the intake manifold via a flexible hose.

1. Release the spring clips to open the housing and remove the air filter element. See Figure 3-6.


2. Tap the element lightly against a flat surface to dislodge loose surface dirt. Do not clean in any liquid or use compressed air as these will damage the filter element.
3. Examine the element and housing for damage and wear. Replace the element or housing if necessary.
4. Wipe the cover and base with a clean rag to remove any dirt. Make sure that the sealing surfaces fit correctly, and reattach the spring clips.



**Figure 3-6** Air Cleaner Element Element

##### 13/20/28/32EOZD and 11/17/17.5/25/28EFOZD Models:

A dry-type air cleaner silences and filters the intake air. The air intake silencer assembly connects to the intake manifold via a flexible hose. Refer to Figure 3-7 during this procedure.



**Figure 3-7** Air Cleaner


1. Release the spring clips to open the housing and remove the air silencer element.

2. Tap the element lightly against a flat surface to dislodge loose surface dirt. Do not clean the element in any liquid or use compressed air as these will damage the filter element.
3. Examine the element and housing for damage. Replace the element or housing if necessary.
4. Wipe the cover and housing with a clean rag to remove dirt. Make sure the sealing surfaces fit correctly and reattach the spring clips.

#### 14/15/23/24EOZD and 11.5/13/20EFOZD Models:

A round air cleaner silences and filters the intake air. Replace a damaged or dirt-contaminated air silencer. See Section 1 and refer to the following procedure:


1. Release the two spring clips and remove the intake silencer cover.
2. Remove the filter element and inspect. If the element is not damaged, continue with step 3. If the element is damaged, replace it, skip step 3, and go to step 4.
3. Wash the element in mild detergent and water solution. Rinse and air dry the element. See Figure 3-8.



**Figure 3-8** Element Washing

4. Wipe the intake silencer cover and base with a clean rag to remove any dirt. Check the base for damage; replace as necessary.
5. Reassemble the element and cover assembly to the intake silencer base. Make sure that the sealing surfaces fit and reattach the spring clips. The air intake silencer duct should be at the 5 o'clock position as viewed from the generator end.

## 3.6 Exhaust System



**Inspecting the exhaust system. Carbon monoxide can cause severe nausea, fainting, or death.** For the safety of the craft's occupants, install a carbon monoxide detector. Never operate the generator set without a functioning carbon monoxide detector. Inspect the detector before each generator set use.

At the interval specified in the service schedule, inspect the exhaust system components (exhaust manifold, mixing elbow, exhaust hose, hose clamps, silencer, and outlet flapper) for cracks, leaks, and corrosion. See Section 1 for the exhaust outlet location.

Ensure that the carbon monoxide detector(s) is (1) in the craft, (2) functional, and (3) energized whenever the generator set operates.

**For your safety: Never operate the generator set without a functioning carbon monoxide detector(s) for your safety and the safety of others on your vessel.**

#### Exhaust System Inspection Points

Check for exhaust leaks and blockages. Check the silencer and piping condition and check for tight exhaust system connections.

- Check the hoses for softness, cracks, leaks, or dents. Replace the hoses as needed.
- Check for corroded or broken metal parts and replace them as needed.
- Check for loose, corroded, or missing clamps. Tighten or replace the hose clamps and/or hangers as needed.
- Check that the exhaust outlet is unobstructed.
- Visually inspect the exhaust system for exhaust leaks (*blowby*). Check for carbon or soot residue on exhaust components. Carbon and soot residue indicates an exhaust leak. Seal leaks as needed.

## 3.7 Cooling System


### 3.7.1 Closed Heat Exchanger

In a closed cooling system, the seawater circulates through separate chambers within the heat exchanger or manifold to cool the engine coolant. The seawater then mixes with the engine exhaust and ejects out of the exhaust outlet. See Figure 3-9 for coolant capacities (include coolant recovery tank capacity of 0.24 L (8 oz.).

Model	L (Qts.)
9EOZD and 7EFOZD	2.5 (2.6)
10EOZD and 8.5/9EFOZD	2.5 (2.6)
13/14/15EOZD and 11/11.5/13EFOZD	4.4 (4.6)
20/23/24EOZD and 17/17.5/20EFOZD	6.0 (6.3)
28/32EOZD and 25/28EFOZD	7.6 (8.0)

Figure 3-9 Engine Coolant Capacities

### 3.7.2 Checking and Filling Coolant



Allow the engine to cool. Release pressure from the cooling system before removing the pressure cap. To release pressure, cover the pressure cap with a thick cloth and then slowly turn the cap counterclockwise to the first stop. Remove the cap after pressure has been completely released and the engine has cooled. Check the coolant level at the tank if the generator set has a coolant recovery tank.

#### NOTICE

**Saltwater damage.** Saltwater quickly deteriorates metals. Wipe up saltwater on and around the generator set and remove salt deposits from metal surfaces.

Maintain the coolant level in the coolant recovery tank at approximately 1/4 full. Before filling the cooling system, close all petcocks and tighten all hose clamps. Use a solution of 50% ethylene glycol and 50% clean, softened water to inhibit rust/corrosion and prevent freezing. Add additional coolant solution, as necessary, to the coolant recovery tank. Periodically check the coolant level on closed systems by removing the pressure cap. Do not rely solely on the level in the coolant recovery tank. Add fresh coolant until the level is just below the overflow tube opening.

**Note:** A coolant solution of 50% ethylene glycol is required. This mix provides freezing protection to  $-37^{\circ}\text{C}$  ( $-34^{\circ}\text{F}$ ) and overheating protection to  $129^{\circ}\text{C}$  ( $265^{\circ}\text{F}$ ). A coolant solution with less than 50% ethylene glycol may not provide adequate freezing and overheating protection. A coolant solution with more than 50% ethylene glycol can cause engine or component damage. Do not use alcohol or methanol antifreeze or mix them with the specified coolant. Consult the engine manufacturer's operation manual for engine coolant specifications.

**Note:** Do not add coolant to an overheated engine. Adding coolant to a hot engine can cause the cylinder block or cylinder head to crack. Wait until the engine has cooled.

**Note:** Pay special attention to the coolant level. After the coolant drains, allow time when refilling the coolant for a complete refill of the engine water jacket. Check the coolant level as prescribed in the Prestart Checklist.

### 3.7.3 Flushing and Cleaning

For optimum protection, drain, flush, and refill the cooling system at the interval listed in the service schedule.

#### Flushing and Cleaning Procedure

1. Open the pressure cap and open petcocks located at the heat exchanger, engine block, and cooling system, and let the system drain completely. Some models may have petcocks located behind the belt guard. Remove the pressure cap to simplify draining.
2. Drain, clean, and flush the coolant recovery tank.
3. Flush the system with clean water.
4. Fill the system with recommended coolant.



### 3.7.4 Pressure Cap

Closed heat exchanger systems utilize a pressure cap to raise the boiling point of the engine coolant, enabling proper operating temperatures. If the cap leaks, replace it with a cap of the same rating. The pressure cap typically has the pressure rating stamped on the cap body.

### 3.7.5 Seawater Pump

The belt-driven seawater pump is located on the service side of the generator set. Check and change the seawater pump impeller at the interval specified in the service schedule. Follow the instructions included with the impeller kit. If the instructions are not included with the kit, use the following procedure:

#### Impeller Inspection and Replacement Procedure:

1. Close the seacock.
2. Remove the seawater pump coverplate. See Figure 3-10.
3. Remove the impeller.
4. Inspect the impeller for damaged, cracked, broken, missing or flattened vanes. The impeller vanes should be straight and flexible. See Figure 3-11. Replace the impeller if it is damaged.




Figure 3-10 Seawater Pump, Typical




Figure 3-11 Worn Impeller

5. Lubricate the impeller with soapy water before installation.
6. Install the impeller.

**Note:** During installation push and rotate the impeller in the same direction as the engine rotation until it is thoroughly seated in the impeller housing.

7. Inspect the coverplate and gasket for corrosion and/or damage. Replace components as necessary.
8. Lubricate the gasket with silicon grease and attach the gasket and coverplate to the seawater pump housing.
9. Open the seacock.
10. Start the generator set and check for leaks.
11. Stop the generator set and repair leaks or replace damaged or worn components.

m:sm:003:008

### 3.7.6 Siphon Break


A siphon break prevents seawater entry into the generator set's engine when the engine exhaust manifold outlet is less than 230 mm (9 in.) above the waterline of a fully loaded, docked or stationary craft. See Figure 3-13. The siphon break may malfunction when the generator set operates while the craft is in contaminated waters or saltwater. Use the following procedure to inspect the siphon break at the intervals listed in the service schedule.

#### Siphon Break Inspection

1. Stop the generator set.
2. Remove the retaining cap and remove the reed valve for inspection. See Figure 3-12.
3. Use a mild detergent to remove residue and oxidation from the reed valve.
4. Clear blockage from the reed valve opening.
5. Replace the siphon break if the reed valve is cracked or if the reed valve material has hardened or deteriorated.


6. Install the reed valve into the mounting base with the valve downward. See Figure 3-12, item 2.
7. Install and only finger tighten the retaining cap. Do not overtighten it.

**Note:** Ensure that the siphon break's cap is tight before operating the generator set.



**Figure 3-12** Siphon Break

m:sm:003:007



**Figure 3-13** Siphon Break (Plastic “U” Type) Installation

**Note:** Consult the installation manual for complete explanation of dimensions and other installation considerations.

### 3.7.7 Anticorrosion Zinc Anode

The heat exchanger on models 9/10EOZD, 7/9EFOZD, 28/32EOZD, and 25/28EFOZD contains an anticorrosion zinc anode (plug) to prevent electrolytic corrosion by seawater.


Check and replace the anticorrosion zinc anode at intervals recommended in the service schedule. Depending upon operating conditions and seawater properties, the anticorrosion zinc anode may require more frequent replacement. See Section 1 for the location and use the following procedure.

#### Anticorrosion Zinc Anode Replacement

1. With the generator set cooled, close the seacock, open the petcock on the engine, and drain the coolant into a suitable container.
2. Remove the anticorrosion zinc anode (plug) from the heat exchanger.
3. Use a wire brush to remove the loose corrosion on the anticorrosion zinc anode. Replace the anode according to Figure 3-14 and Figure 3-15.

Anticorrosion Zinc Anode Replacement		
Models	New Anode Dimensions mm (in.)	Replace When Percent of Zinc Remaining Is:
9/10EOZD 7/9EFOZD	9 (0.34) x 43 (1.7)	<50% of length/diameter
28/32EOZD 25/28EFOZD	9 (0.34) x 76.2 (3.0)	<50% of length/diameter


**Figure 3-14** Anticorrosion Zinc Anode (Plug) Measurements



**Figure 3-15** Anticorrosion Zinc Anode (Plug)


4. Clean the threaded hole of the heat exchanger and coat the threads of the anticorrosion zinc anode (plug) with pipe sealant suitable for marine applications. Cut the anticorrosion zinc to the correct length. Install the anticorrosion zinc anode into the heat exchanger.
5. Close the petcock on the engine and open the seacock. Refill the cooling system.
6. Start the generator set and check for leaks at the anticorrosion zinc anode location. The pump is operating if the cooling water flows from the exhaust outlet. If water is not discharging at the exhaust outlet, see Section 2.1, Prestart Checklist—Seawater Pump Priming.

### 3.8 Belt Tension



**Servicing the generator set when it is operating. Exposed moving parts can cause severe injury or death.** Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator set.

Check the belt tensions at the interval specified in the service schedule. If tensions are not within the specifications, adjust as necessary using the following procedures.



**Figure 3-16** Belt Tension (Typical)

#### 3.8.1 Seawater Pump Belt Tensioning Procedure, If Equipped

1. Remove the belt guard.
2. Check the belt tension at the midpoint of the longest span of the belt using a belt-tensioning tool set to 55 ft. lbs. See Figure 3-16. Recheck a new belt tension after 10 minutes of operation.

**Note:** If the belt tension is not within specifications, go to step 3. If the belt tension is within specifications, go to step 7.

3. Loosen the pivot and adjusting screws.
4. While prying the seawater pump outward, tighten the adjusting screw.
5. Tighten the pivot screw.
6. Recheck and adjust as necessary.
7. Replace the belt guard.

#### 3.8.2 Battery Charging Alternator Belt Tensioning Procedure

1. Remove the belt guard.
2. Check the belt tension at the midpoint of the longest span of the belt by pressing with your finger. See Figure 3-16 and Figure 3-17. If the belt is not within the specifications, go to step 3. If the belt is within the specifications, go to step 7.

Belt Type	Deflection mm (in.)
New	8-12 (0.3-0.5)
Used	10-14 (0.4-0.6)

**Figure 3-17** Belt Specifications

3. Loosen the adjusting arm pivot screw, alternator pivot screw, and alternator adjusting screw.
4. While prying the alternator outward, tighten the alternator adjusting screw.
5. Tighten the adjusting arm pivot screw and alternator pivot screw.
6. Recheck and adjust as necessary.
7. Replace the belt guard.

## 3.9 Battery

Consult the battery manufacturer's instructions regarding battery care and maintenance.

## 3.10 Generator Storage Procedure

Keep the craft afloat for generator operation during the storage procedure. Follow the procedure below when storing your generator set for 3 months or more.

### Generator Set Storage Procedure

1. Start and run the generator set until it reaches operating temperature or about 15 minutes.
2. Stop the generator set.
3. Change the oil and oil filter. See Section 3.3.3.
4. Close the seacock and remove the hose at the seacock. Place the hose in a container having approximately 3.7-7.5 L (1-2 U.S. gallons) of coolant/antifreeze. Kohler Co. recommends using an environmentally friendly potable antifreeze such as Peak® RV/marine propylene glycol/water mix or equivalent.
5. Disconnect the lead (#87) to the low seawater pressure (LWP) switch.
6. With a suitable container at the exhaust outlet, run the generator set until coolant discharges at the exhaust outlet or until the coolant mixture is depleted. Do not allow coolant mixture to flow into waterways.

7. Reconnect the lead (#87) to the low seawater pressure (LWP) switch.
8. Stop the generator set.
9. Connect a hose to the seacock. Leave the seacock closed.
10. Check the coolant level of the heat exchanger and add coolant if necessary.

**Note:** Use antifreeze capable of withstanding the lowest possible temperatures.

11. Clean the exterior of the generator set and spread a light film of oil or silicon spray over any exposed surfaces that may be subject to rust or corrosion.
12. Disconnect and remove the battery. Place the battery in a warm, dry location for the storage period. Recharge the battery once a month to maintain a full charge.
13. Select a well-ventilated (not humid or dusty) location to store the generator.
14. Cover the entire unit with a dust cover.

**Note:** Run the generator set once a month whenever possible.

# Section 4 Troubleshooting

This section contains generator set troubleshooting, diagnostic, and repair information.

Use the following charts as a quick troubleshooting reference. The table groups generator set faults and suggests likely causes and remedies. The table also refers you to more detailed information including sections of this manual, the generator set service manual (S/M), the generator set installation manual (I/M), and the engine service manual (Engine S/M) to correct the indicated problem.

Corrective action and testing often require knowledge of electrical and electronic circuits. To avoid additional problems caused by incorrect repairs, have an authorized service distributor/dealer perform service.

### NOTICE

**Fuse replacement.** Replace fuses with fuses of the same ampere rating and type (for example: 3AB or 314, ceramic). Do not substitute clear glass-type fuses for ceramic fuses. Refer to the wiring diagram when the ampere rating is unknown or questionable.

Maintain a record of repairs and adjustments performed on the equipment. If the procedures in this manual do not explain how to correct the problem, contact an authorized distributor/dealer. Use the record to help describe the problem and repairs or adjustments made to the equipment.

x:gt:001:002a:

## 4.1 Fault Codes

The Advanced Digital Control displays fault codes to aid in troubleshooting. Fault codes, descriptions, and recommended actions are listed in Figure 2-5.

Identify and correct the cause of the fault condition. Then reset the controller after a fault shutdown. See Section 2.6.6.

## 4.2 Controller Troubleshooting

Figure 4-1 contains troubleshooting, diagnostic, and repair information for the Advanced Digital Control.

Problem	Possible Cause	Corrective Action
Controller LED display is off	No power to the controller:  Continuous power mode jumper is disconnected and the generator set has not run for 48 hours or longer.	Controller display will automatically activate when a remote start command is received or the generator set master switch is moved to the RUN position. Connect the jumper to maintain continuous power to the controller, if desired.
	Controller fuse (F3) is blown.	Replace the fuse. If the fuse blows again, contact the distributor/dealer.
	Low or no battery voltage.	Check connections. Check generator set battery.
	Generator set master switch is in the OFF/RESET position.	Move generator set master switch to the AUTO or RUN position.
	Generator set master switch in AUTO but no start command has been received since last controller reset.	No action required. Controller display will activate when a remote start command is received or the generator set master switch is moved to the RUN position. Use the remote switch to start generator set and activate the controller display, if desired.

**Figure 4-1** Controller Troubleshooting Chart

Trouble Symptoms										Probable Causes	Recommended Actions	Section or Publication Reference*
Does not crank	Cranks but does not start	Starts hard	No or low output voltage	Stops suddenly	Lacks power	Overheats	Low oil pressure	High fuel consumption	Excessive or abnormal noise			
<b>Controller</b>												
X				X						Generator, set master switch in the OFF position	Move the generator set master switch to the correct position (RUN or AUTO).	Section 2
X				X						Controller fuse (F3) blown	Replace the blown controller fuse. If the fuse blows again, troubleshoot the controller.†	Section 2, W/D
X				X						The relay interface board fuse (F2) blown	Replace the blown relay interface board fuse. If the fuse blows again, troubleshoot the controller.†	Section 2, W/D
				X						The auxiliary winding fuse (F1) blown	Replace the blown auxiliary winding fuse. If the fuse blows again, troubleshoot the controller.†	Section 2, W/D
X										Controller master or start/stop switch inoperative	Replace the controller master switch/check switch wiring.	—
				X						Controller fault	Troubleshoot the controller.†	Gen. S/M
				X						Remote stop command received from a remote switch or ATS	Check the remote switch position.	
<b>Cooling System</b>												
						X		X		Air openings clogged	Clean the air openings.	—
						X				Impeller inoperative	Replace the impeller	Section 3
						X		X		Seawater strainer clogged or restricted	Clean the strainer, check the seawater pump impeller for damage.	Section 3
				X						High temperature shutdown	Allow the engine to cool down. Then troubleshoot the cooling system.	Sec. 3, Eng. O/M
						X				Coolant level low	Restore the coolant to normal operating level.	Section 3
						X				Thermostat inoperative	Replace the thermostat.	Eng. S/M
						X				Cooling water pump inoperative	Tighten or replace the belt. Replace the water pump.	Eng. O/M or S/M

\* Sec./Section—numbered section of this manual; ATS—Automatic Transfer Switch; Eng.—Engine; Gen.—Generator Set; I/M—Installation Manual; O/M—Operation Manual; S/M—Service Manual; S/S—Spec Sheet; W/D—Wiring Diagram

† Have an authorized service distributor/dealer perform this service.



Trouble Symptoms										Probable Causes	Recommended Actions	Section or Publication Reference*
Does not crank	Cranks but does not start	Starts hard	No or low output voltage	Stops suddenly	Lacks power	Overheats	Low oil pressure	High fuel consumption	Excessive or abnormal noise			
<b>Electrical System (DC circuits)</b>												
x	x									Battery connections loose, corroded, or incorrect	Verify that the battery connections are correct, clean, and tight.	Section 3
x	x									Battery weak or dead	Recharge or replace the battery. The spec sheet provides recommended battery CCA rating.	Section 3, S/S
x			x							Engine harness connector(s) not locked tight	Disconnect the engine harness connector(s) then reconnect it to the controller.	W/D
			x							Fault shutdown	Reset the controller.	Section 2
x	x									Starter/starter solenoid inoperative	Replace the starter or starter solenoid, check F2 fuse.	Eng. S/M
<b>Engine</b>												
	x	x			x			x		Air cleaner/backfire flame arrester clogged	Clean or replace the filter element.	Section 2
	x	x				x		x		Compression weak	Check the compression. †	Eng. S/M
			x		x			x		Engine overload	Reduce the electrical load. See the generator set installation manual for wattage specifications.	I/M
									x	Exhaust system leak	Inspect the exhaust system. Replace the inoperative exhaust system components. †	Section 3, I/M
									x	Exhaust system not securely installed	Inspect the exhaust system. Tighten the loose exhaust system components. †	Section 3, I/M
				x						Overspeed shutdown	Reset the controller. If the overspeed fault occurs again, contact the distributor/dealer.	
		x			x					Governor inoperative	Adjust the governor. †	Gen. S/M
			x						x	Valve clearance incorrect	Adjust the valves. †	Eng. S/M
									x	Vibration excessive	Tighten all loose hardware.	—

\* Sec./Section—numbered section of this manual; ATS—Automatic Transfer Switch; Eng.—Engine; Gen.—Generator Set; I/M—Installation Manual; O/M—Operation Manual; S/M—Service Manual; S/S—Spec Sheet; W/D—Wiring Diagram


† Have an authorized service distributor/dealer perform this service.

Trouble Symptoms									Probable Causes	Recommended Actions	Section or Publication Reference*
Does not crank	Cranks but does not start	Starts hard	No or low output voltage	Stops suddenly	Lacks power	Overheats	Low oil pressure	High fuel consumption			
<b>Fuel System</b>											
	X			X					Fuel tank empty or fuel valve shut off	Add fuel and move the fuel valve to the ON position.	—
	X	X		X	X				Fuel filter restriction	Clean or replace the fuel filter.	Eng. O/M
	X								Fuel solenoid inoperative	Troubleshoot the fuel solenoid. †	Eng. S/M
	X	X			X				Air in fuel system (diesel only)	Bleed the diesel fuel system.	Eng. O/M
	X	X			X				Fuel or fuel injectors dirty or faulty (diesel only)	Clean, test, and/or replace the inoperative fuel injector. †	Eng. S/M
	X	X			X			X	Fuel injection timing out of adjustment (diesel only)	Adjust the fuel injection timing. †	Eng. S/M
	X				X			X	Fuel feed or injection pump inoperative (diesel only)	Rebuild or replace the injection pump. †	Eng. S/M
<b>Generator</b>											
			X						AC output circuit breaker open	Reset the breaker and check for AC voltage at the generator side of the circuit breaker.	—
X									Transfer switch test switch in the OFF position	Move the transfer switch test switch to the AUTO position.	ATS O/M
			X						Wiring, terminals, or pin in the exciter field open	Check for continuity.	Gen. S/M, W/D
			X						Main field (rotor) inoperative (open or grounded)	Test and/or replace the rotor. †	Gen. S/M
			X						Stator inoperative (open or grounded)	Test and/or replace the stator. †	Gen. S/M
								X	Vibration excessive	Tighten loose components. †	—
<b>Lube System</b>											
						X	X		Oil level low	Restore the oil level. Inspect the generator set for oil leaks.	Eng. O/M
				X					Low oil pressure shutdown	Check the oil level.	Eng. O/M
	X	X					X		Crankcase oil type incorrect for ambient temperature	Change the oil. Use oil with a viscosity suitable for the operating climate.	Eng. O/M

\* Sec./Section—numbered section of this manual; ATS—Automatic Transfer Switch; Eng.—Engine; Gen.—Generator Set; I/M—Installation Manual; O/M—Operation Manual; S/M—Service Manual; S/S—Spec Sheet; W/D—Wiring Diagram

† Have an authorized service distributor/dealer perform this service.


**⚠ WARNING**



**Accidental starting.  
Can cause severe injury or death.**

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

**⚠ WARNING**



**Hazardous voltage. Moving parts.  
Can cause severe injury or death.**

Operate the generator set only when all guards and electrical enclosures are in place.

**Disabling the generator set. Accidental starting can cause severe injury or death.** Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

**Grounding electrical equipment. Hazardous voltage can cause severe injury or death.** Electrocutation is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

## 5.1 Wiring Diagram Reference

Figure 5-1 lists the wiring diagram numbers and locations.

Model	Wiring Diagram	Figure	Schematic	Figure	Accessory	Figure
9EOZD 7EFOZD	GM50490-C	Figure 5-2	ADV-7283A-C ADV-7283B-C	Figure 5-4 Figure 5-5	GM33846-D	Figure 5-6
10-32EOZD, 8.5-28EFOZD	GM50488-C	Figure 5-3				

**Figure 5-1** Wiring Diagrams




Figure 5-2 Wiring Diagram for Model 9EOZD/7EFOZD




Figure 5-3 Wiring Diagram for Models 10-32EOZD/8.5-28EFOZD




Figure 5-4 Schematic for Models 9-32EOZD/7-28EFOZD (Sheet 1 of 2)




Figure 5-5 Schematic for Models 9-32EOZD/7-28EFOZD (Sheet 2 of 2)




Figure 5-6 Accessory Diagram for Models 9-32EOZD/7-28EFOZD



# Appendix A Abbreviations

The following list contains abbreviations that may appear in this publication.

A, amp	ampere	CG	center of gravity	fglass.	fiberglass
ABDC	after bottom dead center	CID	cubic inch displacement	FHM	flat head machine (screw)
AC	alternating current	CL	centerline	fl. oz.	fluid ounce
A/D	analog to digital	cm	centimeter	flex.	flexible
ADC	analog to digital converter	CMOS	complementary metal oxide substrate (semiconductor)	freq.	frequency
adj.	adjust, adjustment			FS	full scale
ADV	advertising dimensional drawing	cogen.	cogeneration	ft.	foot, feet
AHWT	anticipatory high water temperature	Com	communications (port)	ft. lbs.	foot pounds (torque)
AISI	American Iron and Steel Institute	conn.	connection	ft./min.	feet per minute
ALOP	anticipatory low oil pressure	cont.	continued	g	gram
alt.	alternator	CPVC	chlorinated polyvinyl chloride	ga.	gauge (meters, wire size)
Al	aluminum	crit.	critical	gal.	gallon
ANSI	American National Standards Institute (formerly American Standards Association, ASA)	CRT	cathode ray tube	gen.	generator
		CSA	Canadian Standards Association	genset	generator set
AO	anticipatory only	CT	current transformer	GFI	ground fault interrupter
API	American Petroleum Institute	Cu	copper	GND, ⊕	ground
approx.	approximate, approximately	cu. in.	cubic inch	gov.	governor
AR	as required, as requested	cw.	clockwise	gph	gallons per hour
AS	as supplied, as stated, as suggested	CWC	city water-cooled	gpm	gallons per minute
ASE	American Society of Engineers	cyl.	cylinder	gr.	grade, gross
ASME	American Society of Mechanical Engineers	D/A	digital to analog	GRD	equipment ground
assy.	assembly	DAC	digital to analog converter	gr. wt.	gross weight
ASTM	American Society for Testing Materials	dB	decibel	H x W x D	height by width by depth
ATDC	after top dead center	dBA	decibel (A weighted)	HC	hex cap
ATS	automatic transfer switch	DC	direct current	HCHT	high cylinder head temperature
auto.	automatic	DCR	direct current resistance	HD	heavy duty
aux.	auxiliary	deg., °	degree	HET	high exhaust temperature
A/V	audiovisual	dept.	department	hex	hexagon
avg.	average	dia.	diameter	Hg	mercury (element)
AVR	automatic voltage regulator	DI/EO	dual inlet/end outlet	HH	hex head
AWG	American Wire Gauge	DIN	Deutsches Institut für Normung e. V. (also Deutsche Industrie Normenausschuss)	HHC	hex head cap
AWM	appliance wiring material	DIP	dual inline package	HP	horsepower
bat.	battery	DPDT	double-pole, double-throw	hr.	hour
BBDC	before bottom dead center	DPST	double-pole, single-throw	HS	heat shrink
BC	battery charger, battery charging	DS	disconnect switch	hsg.	housing
BCA	battery charging alternator	DVR	digital voltage regulator	HVAC	heating, ventilation, and air conditioning
BCI	Battery Council International	E, emer.	emergency (power source)	HWT	high water temperature
BDC	before dead center	EDI	electronic data interchange	Hz	hertz (cycles per second)
BHP	brake horsepower	EFR	emergency frequency relay	IC	integrated circuit
blk.	black (paint color), block (engine)	e.g.	for example ( <i>exempli gratia</i> )	ID	inside diameter, identification
blk. htr.	block heater	EG	electronic governor	IEC	International Electrotechnical Commission
BMEP	brake mean effective pressure	EGSA	Electrical Generating Systems Association	IEEE	Institute of Electrical and Electronics Engineers
bps	bits per second	EIA	Electronic Industries Association	IMS	improved motor starting
br.	brass	EI/EO	end inlet/end outlet	in.	inch
BTDC	before top dead center	EMI	electromagnetic interference	in. H <sub>2</sub> O	inches of water
Btu	British thermal unit	emiss.	emission	in. Hg	inches of mercury
Btu/min.	British thermal units per minute	eng.	engine	in. lbs.	inch pounds
C	Celsius, centigrade	EPA	Environmental Protection Agency	Inc.	incorporated
cal.	calorie	EPS	emergency power system	ind.	industrial
CARB	California Air Resources Board	ER	emergency relay	int.	internal
CB	circuit breaker	ES	engineering special, engineered special	int./ext.	internal/external
cc	cubic centimeter	ESD	electrostatic discharge	I/O	input/output
CCA	cold cranking amps	est.	estimated	IP	iron pipe
ccw.	counterclockwise	E-Stop	emergency stop	ISO	International Organization for Standardization
CEC	Canadian Electrical Code	etc.	et cetera (and so forth)	J	joule
cfh	cubic feet per hour	exh.	exhaust	JIS	Japanese Industry Standard
cfm	cubic feet per minute	ext.	external	k	kilo (1000)
		F	Fahrenheit, female	K	kelvin
				KA	kiloampere
				KB	kilobyte (2 <sup>10</sup> bytes)

kg	kilogram	MW	megawatt	rms	root mean square
kg/cm <sup>2</sup>	kilograms per square centimeter	mW	milliwatt	rnd.	round
kgm	kilogram-meter	μF	microfarad	ROM	read only memory
kg/m <sup>3</sup>	kilograms per cubic meter	N, norm.	normal (power source)	rot.	rotate, rotating
kHz	kilohertz	NA	not available, not applicable	rpm	revolutions per minute
kJ	kilojoule	nat. gas	natural gas	RS	right side
km	kilometer	NBS	National Bureau of Standards	RTV	room temperature vulcanization
kOhm, kΩ	kilo-ohm	NC	normally closed	SAE	Society of Automotive Engineers
kPa	kilopascal	NEC	National Electrical Code	scfm	standard cubic feet per minute
kph	kilometers per hour	NEMA	National Electrical Manufacturers Association	SCR	silicon controlled rectifier
kV	kilovolt	NFPA	National Fire Protection Association	s, sec.	second
kVA	kilovolt ampere	Nm	newton meter	SI	<i>Système international d'unites</i> , International System of Units
kVAR	kilovolt ampere reactive	NO	normally open	SI/EO	side in/end out
kW	kilowatt	no., nos.	number, numbers	sil.	silencer
kWh	kilowatt-hour	NPS	National Pipe, Straight	SN	serial number
kWm	kilowatt mechanical	NPSC	National Pipe, Straight-coupling	SPDT	single-pole, double-throw
L	liter	NPT	National Standard taper pipe thread per general use	SPST	single-pole, single-throw
LAN	local area network	NPTF	National Pipe, Taper-Fine	spec, specs	specification(s)
L x W x H	length by width by height	NR	not required, normal relay	sq.	square
lb.	pound, pounds	ns	nanosecond	sq. cm	square centimeter
lbm/ft <sup>3</sup>	pounds mass per cubic feet	OC	overcrank	sq. in.	square inch
LCB	line circuit breaker	OD	outside diameter	SS	stainless steel
LCD	liquid crystal display	OEM	original equipment manufacturer	std.	standard
ld. shd.	load shed	OF	overfrequency	stl.	steel
LED	light emitting diode	opt.	option, optional	tach.	tachometer
Lph	liters per hour	OS	oversize, overspeed	TD	time delay
Lpm	liters per minute	OSHA	Occupational Safety and Health Administration	TDC	top dead center
LOP	low oil pressure	OV	overvoltage	TDEC	time delay engine cooldown
LP	liquefied petroleum	oz.	ounce	TDEN	time delay emergency to normal
LPG	liquefied petroleum gas	p., pp.	page, pages	TDES	time delay engine start
LS	left side	PC	personal computer	TDNE	time delay normal to emergency
L <sub>wa</sub>	sound power level, A weighted	PCB	printed circuit board	TDOE	time delay off to emergency
LWL	low water level	pF	picofarad	TDON	time delay off to normal
LWT	low water temperature	PF	power factor	temp.	temperature
m	meter, milli (1/1000)	ph., ∅	phase	term.	terminal
M	mega (10 <sup>6</sup> when used with SI units), male	PHC	Phillips head crimplite (screw)	TIF	telephone influence factor
m <sup>3</sup>	cubic meter	PHH	Phillips hex head (screw)	TIR	total indicator reading
m <sup>3</sup> /min.	cubic meters per minute	PHM	pan head machine (screw)	tol.	tolerance
mA	milliampere	PLC	programmable logic control	turbo.	turbocharger
man.	manual	PMG	permanent-magnet generator	typ.	typical (same in multiple locations)
max.	maximum	pot	potentiometer, potential	UF	underfrequency
MB	megabyte (2 <sup>20</sup> bytes)	ppm	parts per million	UHF	ultrahigh frequency
MCM	one thousand circular mils	PROM	programmable read-only memory	UL	Underwriter's Laboratories, Inc.
MCCB	molded-case circuit breaker	psi	pounds per square inch	UNC	unified coarse thread (was NC)
meggar	megohmmeter	pt.	pint	UNF	unified fine thread (was NF)
MHz	megahertz	PTC	positive temperature coefficient	univ.	universal
mi.	mile	PTO	power takeoff	US	undersize, underspeed
mil	one one-thousandth of an inch	PVC	polyvinyl chloride	UV	ultraviolet, undervoltage
min.	minimum, minute	qt.	quart	V	volt
misc.	miscellaneous	qty.	quantity	VAC	volts alternating current
MJ	megajoule	R	replacement (emergency) power source	VAR	voltampere reactive
mJ	millijoule	rad.	radiator, radius	VDC	volts direct current
mm	millimeter	RAM	random access memory	VFD	vacuum fluorescent display
mOhm, mΩ	milliohm	RDO	relay driver output	VGA	video graphics adapter
MOhm, MΩ	megohm	ref.	reference	VHF	very high frequency
MOV	metal oxide varistor	rem.	remote	W	watt
MPa	megapascal	RFI	radio frequency interference	WCR	withstand and closing rating
mpg	miles per gallon	RH	round head	w/	with
mph	miles per hour	RHM	round head machine (screw)	w/o	without
MS	military standard	rly.	relay	wt.	weight
m/sec.	meters per second			xfrm	transformer
MTBF	mean time between failure				
MTBO	mean time between overhauls				
mtg.	mounting				



**TP-6710 5/11a**

© 2009 and 2011 by Kohler Co. All rights reserved.

# **KOHLER**<sup>®</sup> POWER SYSTEMS

KOHLER CO. Kohler, Wisconsin 53044  
Phone 920-457-4441, Fax 920-459-1646  
For the nearest sales/service outlet in the  
US and Canada, phone 1-800-544-2444  
KohlerPower.com

Kohler Power Systems  
Asia Pacific Headquarters  
7 Jurong Pier Road  
Singapore 619159  
Phone (65)6264-6422, Fax (65)6264-6455