



52765 Bridger Court  
Elkhart, IN 46514  
USA

www.actia.com

## Instrument Cluster Service Guide



### NOTICE OF PROPRIETARY INFORMATION

This document and its contents are proprietary to Actia Automotive.

This publication and its contents may not be shared with anyone outside of WCC or its authorized service network without the written permission of Actia.

	WCC Ref.	Revision
<p><b>MY08 WCC Gas Cluster</b></p> <p><b>Instrument Cluster Service Guide</b></p>	W0010338, W0010339, W0010929 W0011282, W0011283	<b>A</b>
	Page 1	Format US Letter
<small>© 2008 Any reproduction of this document whether total or partial without the written consent of ACTIA is forbidden.</small>		

0	S Myers	11.13.06	Original Draft-based on MY07 Whirlaway function (107456) and WCC spec rev d0072.
1	S Myers	11.20.06	Changed source address for ABS system to 0B hex per customer table
			Added clarification to Check ABS message in PIM table.
			Changed cruise control lamp SPN from 595 to 596 per customer table.
			Added running light command info to 1939 message table
			Change left and right turn signal indicator data source to binary per customer spec.
			Added total vehicle distance message info to 1939 table per customer table.
			Changed all SA 11 to SA 33 or 0B depending on whether it came from the BCM or ABS system.
2	S Myers	11.22.06	Corrected Pinout in back to reflect PIN 20 designation for Right turn input
			Corrected cruise message name in 1939 table for clarification
			Added "click" to turn signals in indicator table.
3	S Myers	11.24.06	Corrected Oil Pressure message definition in 1939 table.
4	S Myers	11.29.06	Corrected CM1 message hexadecimal definition in 1939 table to match Whirlaway due to DA problem.
			Corrected all references of BCM addressing to reflect hexadecimal value of 21.
			Removed configuration byte definition table as the gas cluster is no longer configured for anything accept metric or English which is handled with a command, not cofig bit setting. (need to take this up with manf.)
			Removed fuel tank configuration reference because the cluster does not need to be configured for different fuel tanks as it simply receives level as a function of the databus.
			Modified Startup mode section to match previous WCC functionality as well as the customer spec.
			Modified Comm Detection section to remove gauge wag detail to match previous WCC functionality as well as the customer spec.
			Added 7/8 tick value to Engine Coolant Gauge per customer spec.
			Added PIN 9 as trigger for Battery Charge indicator
5	S Myers	11.30.06	Removed Alarm only messages and integrated them into the PIM section per customer retest to have all alarms associated with a lamp, display message or gauge reading.
			Removed data bus trigger for HIGH IDEL per customer request.
			Changed Low Coolant Level DM1 trigger to FMI 17
			Changed Shift inhibit SPN from 1851 to 2900
6	S Myers	12.7.06	Updated Section 3 to state that the cluster is configurable for tank size due to the need for some logic calculations that depend on fuel tank capacity (i.e. fuel range)
7	S Myers	12.7.06	Changed trigger for Check Transmission Temp PIM in section 11.4. Per customer request.
			Changed trigger for Turn Signal Reminder in section 11.4. Per customer request.
			Changed Data source for Seatbelt lamp in section 6.1 and updated 6.2.6 accordingly. Per customer request
			Added Stop Engine lamp function in section 6.1 and updated 6.2.7 accordingly. Also added supporting message to 1939 table. Per customer request.
			Changed Data source for Park brake lamp in section 6.1 by removing data

			message. Per customer request.
			Change data source for Daytime running light lamp in section 6.1 and updated section 6.2.20 and pinout accordingly. Per customer request.
8	S Myers	12.11.06	Added Auto Park reset menu option to Diagnostic Menu in section 12.
9	S Myers	12.11.06	Modified seatbelt logic verbage in section 6.2.6
10	S Myers	12.13.06	Modified section 11.2.3 to add 4, 5 & 6 <sup>th</sup> gears to the Data range as we have always supported this but accidentally removed.
			Removed Volt Meter reading from upper right corner of the last display example in section 11.2.8 because we no longer support this (Ron S.)
			Referenced CCM vs BCM for proprietary Megatech messages in section 11.4 per customer request. (BCM spec. not available)
			Corrected Battery Charge indicator binary input detail in warning lamp table and in section 6.2.3
11	S Myers	12.14.06	Corrected speedo scale from 300 degrees to 200.
12	S Myers	12.18.06	Corrected conflicting input info for auto park in section 11.4 to say AH instead of AL.
13	S Myers	12.20.06	Modified section 11.2.3 to give better description concerning what gear info is displayed. The table was also updated to clarify Max gear limit.
			Added differentiation between instantaneous fuel units displayed when moving and when sitting still. This was in section 11.2
14	S Myers	1.2.07	Removed Stop Engine warning lamp support as it is not sued on the Gas product...only Diesel.
15	S Myers	1.23.07	Adding REDUCED ENGINE POWER message for PIM. Updated 1939 table and PIM table accordingly.
16	S Myers	1.30.07	Added CHANGE ENGINE OIL NOW/SOON to PIM and same DM1 to 1939 table.
			Modified HIGH COOLANT TEMP data source for PIM and added same DM1 to 1939 table.
			Corrected Check Trans Temp lamp and PIM data source. This is reflected in lamp table, section 6.2.14 and 1939 table.
			Corrected SPN for ABS lamp data source. Updated this in lamp table as well as 1939 message table. This will effect Check ABS PIM as well.
			Added DM1 for ABS lamp and PIM trigger. Updated in lamp table, PIM table and 1939 message table.
			Clarified Service Engine Soon Data sources in lamp table, section 6.2.9 and 1939 table.
			Replaced binary input for HIGH IDLE with DM1 message. This is reflected in lamp table, section 6.2.10, and added in 1939 table as well as the pinout table.
			Corrected check tire lamp data source. This is reflected in lamp table and section 6.2.23.
			Replaced BCM COM FAIL message in PIM table with SPEED SIG FAIL per customer request.
			Removed all Door Ajar references as this is not supported in this product. This is reflected in Key in ignition features and pintout
			Removed all reference to AUTO PARK APPLY feature. This is reflected in lamp table, section 6, PIM table, pinout table and also the diagnostic menu.
17	S Myers	1.31.07	Added section 4.5.2 to add a function that keeps the cluster awake if hazard light are on. This Is not a wakup but keeps it from going to sleep. Must NOT work only on right or left but both turn signals (hazards).
18	S Myers	2.5.07	Added Check Tire DM1 message info to 1939 table.
			Changed sleep delay in section 4.5 from 3 sec. to 120 sec. per customer request.

			Modified sections 4.5.1 and 4.5.1 to change the way the cluster handles the Hazard feature.
19	S. Myers	2.6.07	Changed SA for Tire Pressure from 21 hex to 33 hex per customer request.
20	S. Myers	2.11.07	Added D408 LED designation for check tire in lamp table
21	S Myers	4.17.07	Removed Vehicle Settings option from Diag menu in section 12 per customer request.
22	S Myers	4.19.07	Added to section 11.2.1 outside temp data range and stated to remove if outside that range
23	S Myers	5.3.07	Updated Check Trans Temp PIM with correct DM1 info. To match 1939 table.
24	S Myers	5.8.07	Added ODO display to Hazard feature in section 4.5.2
			Added Engine Oil Life 1939 message info in section 12.8 and 1939 table.
25	S Myers	5.17.07	Added Fuel Rate message to section 11.2.1 so that Instantaneous fuel can be supported if vehicle is not moving.
26	S Myers	5.24.07	Corrected message values for Hydraulic Fluid Pressure Message in section 6.2.12
27	S Myers	6.5.07	Section 11.2.1.1—Corrected temp value in resistance table to 0C equal to 32F instead of -32F
28	S Myers	7.13.07	Added alarm to lamp table for Battery Charge Lamp.
			Removed seat belt alarm
29	S Myers	7.16.07	Modified park brake/HPB/ABS lamp activity table in section 6.2.12 per Louis Smith to add discrete wire for Low Brake Fluid.
			Removed Grade Brake per Louis Smith.
30	S Myers	7.19.07	Added PIN 23 as BIN AL input for ABS lamp which effected lamp table, section 6.2.16 and the Check ABS PIM per Louis Smith
			Removed Low Brake Fluid feature for PIN 23 from section 6.2.12 as it is used for ABS per Louis Smith
			Referenced Park Brake PIM to section 6.2.12 instead of lamp for better detail.
			Added ABS lamp to turn on for Hydraulic brake fluid warning PIN 25 in section 6.2.12 per Louis Smith
			Changed Hydraulic Brake fluid warning PIM to LOW BRAKE FLUID in section 6.2.12 per Louis Smith.
31	S Myers	7.24.07	Corrected High Beam from AL to AH in lamp table.
			Corrected Park Brake behavior scenario in section 6.2.12 for Park Brake Applied while not in Park Gear to show less than 3mph instead of greater than 3mph.
			Modified Park Brake behavior scenario in section 6.2.12 for HBS hydraulic Brake Failure Warning Circuit 1 Binary to differentiate it as Low Fluid Level.
			Corrected Change engine Oil Soon descrip in PIM table to make it different from Change Oil Now.
			Section 4.5.2—removed active ODO display from hazard function.
32	S Myers	7.27.07	Removed Fuel Range from CTC Per Louis Smith
			Added missing brake message 61441 to ABS lamp as trigger Per Louis Smith
33	S Myers	8.1.05	Added PIN 25 trigger to ABS lamp table for clarification. This was already listed in the HBS table in section 6.2.12
			Added reference to Battery Charge Fail PIM in PIM table.
34	S Myers	8.7.07	Corrected High Idle trigger from DM1 to CCVS per customer
A	S Myers	8.7.07	Released to production with software 1.9548v02_00.

## Table of Content

<b>1. PURPOSE .....</b>	<b>8</b>
<b>2. SCOPE .....</b>	<b>8</b>
<b>3. CONFIGURATION .....</b>	<b>8</b>
<b>4. MODES OF OPERATION .....</b>	<b>9</b>
4.1. SLEEP MODE .....	9
4.2. ODOMETER MODE.....	9
4.3. KEY-IN-IGNITION MODE.....	10
4.4. START-UP MODE .....	10
4.4.1. <i>Start-up Functional diagnostic</i> .....	11
4.4.2. <i>System Initialization</i> .....	11
4.4.3. <i>System Configuration</i> .....	11
4.4.4. <i>Comm Detection</i> .....	11
4.5. IGNITION MODE.....	11
4.5.1. <i>Normal Shutdown</i> .....	11
4.5.2. <i>Hazard function</i> .....	12
4.6. DIAGNOSTIC MODE .....	12
<b>5. STANDARD GAUGES .....</b>	<b>13</b>
5.1. ENGINE COOLANT TEMPERATURE.....	13
5.2. FUEL LEVEL .....	13
5.3. SPEEDOMETER .....	14
5.4. TACHOMETER .....	14
<b>6. WARNING INDICATORS .....</b>	<b>14</b>
6.1. LAMP GENERAL DETAIL.....	14
6.2. LAMP FUNCTION .....	17
6.2.1. <i>Left Turn</i> .....	17
6.2.2. <i>Right Turn</i> .....	17
6.2.3. <i>Battery Charge</i> .....	17
6.2.4. <i>Low Oil Pressure</i> .....	17
6.2.5. <i>High Beam</i> .....	17
6.2.6. <i>Seat Belt</i> .....	17
6.2.7. <i>Stop Engine</i> .....	17
6.2.8. <i>Cruise</i> .....	17
6.2.9. <i>Service Engine</i> .....	17
6.2.10. <i>High Idle</i> .....	18
6.2.11. <i>Range Inhibit</i> .....	18
6.2.12. <i>Park Brake Indicator/HPB Behavior</i> .....	19
6.2.13. <i>Check Trans</i> .....	19
6.2.14. <i>Wait to Start</i> .....	20
6.2.15. <i>Water in Fuel</i> .....	20
6.2.16. <i>ABS</i> .....	20
6.2.17. <i>DPF-Diesel Particulate Filter Fault</i> .....	20
6.2.18. <i>HEST-High Exhaust System Temp</i> .....	20

6.2.19. Daytime Running lights.....	20
6.2.20. Overdrive Off.....	20
6.2.21. Grade Brake.....	20
6.2.22. Check Tire.....	20
<b>7. TRIP AND MODE BUTTONS .....</b>	<b>20</b>
7.1. TRIP SWITCH.....	20
7.2. MODE SWITCH.....	21
<b>8. UNITS SELECTION .....</b>	<b>21</b>
<b>9. DIMMING .....</b>	<b>22</b>
<b>10. AUDIBLE ALARM.....</b>	<b>23</b>
10.1. ALARM MESSAGES.....	24
<b>11. MESSAGE DISPLAY CENTER .....</b>	<b>24</b>
11.1. MENU NAVIGATION OVERVIEW .....	24
11.2. SCREEN CONFIG OVERVIEW .....	24
11.2.1. Trip Computer Features.....	25
11.2.2. Power Train Features .....	26
11.2.3. PRND123 Features .....	26
11.2.4. Oil Pressure Features .....	26
11.2.5. Large Font Features.....	27
11.2.6. Trip Computer Config Menu.....	29
11.2.7. Power Train Computer Config Menu.....	30
11.2.8. PRND321 Config Menu .....	31
11.2.9. Oil Pressure Config Menu.....	32
11.2.10. Large Font Config Menu.....	33
11.3. STANDARD DISPLAY MESSAGES.....	35
11.3.1. Odometer accumulated .....	35
11.3.2. Trip odometer 1 and Trip odometer 2 .....	35
11.3.3. Gear Selection.....	35
11.4. PRIORITY INTERRUPT MESSAGES (PIM).....	35
<b>12. ON BOARD DIAGNOSTIC.....</b>	<b>37</b>
12.1. CONTRAST ADJUSTMENT .....	37
12.2. RESTORE DEFAULT .....	37
12.3. GAUGE BACKLIGHT.....	38
12.4. SOFTWARE VERSION .....	38
12.5. PART NUMBER .....	38
12.6. MAX ENGINE RPM.....	38
12.7. MAX VEHICLE SPEED.....	38
12.8. ENGINE OIL LIFE REMAINING .....	38
12.9. CLUSTER DIAGNOSTICS.....	39
12.9.1. Gauge Test .....	39
12.9.2. Warning Lamp Test .....	39
12.9.3. LCD Test .....	39
12.9.4. Backlight Test.....	39
12.9.5. Speaker Test .....	39
12.9.6. Switch Inputs.....	39
12.9.7. Analog Inputs .....	39

12.9.8. Vehicle Settings .....	40
12.10. EXIT .....	40
<b>13. DATA LINK DIAGNOSTICS.....</b>	<b>40</b>
13.1. DIAGNOSTIC SESSION .....	40
13.2. REPROGRAM MICROPROCESSOR .....	40
13.3. CURRENT VALUE MONITOR .....	40
13.4. SET PARAMETERS .....	40
<b>14. J1939 TABLE OF MESSAGES .....</b>	<b>41</b>
<b>15. RELATED DOCUMENTS.....</b>	<b>42</b>
<b>16. GLOSSARY/ABBREVIATIONS.....</b>	<b>42</b>
<b>17. APPENDIX A .....</b>	<b>45</b>
17.1. CLUSTER PINOUT .....	45
17.2. MATING CONNECTORS .....	46
17.2.1. CONNECTOR 1 .....	46
17.2.2. CONNECTOR 2 .....	46
17.3. PWA CONFIGURATION .....	47

## 1. PURPOSE

This document is the functional design specifications for the model year 2008 instrument Cluster for Workhorse. This specification will be used to communicate the application software functional requirements for the GAS cluster. In this Specification all numeric values are considered to be a decimal number value unless specified. (Subscript <sub>h</sub> indicates a Hexadecimal value)

## 2. SCOPE

This document will only describe software/hardware functionality of the instrument system assuming it is installed in a model year 2008 GAS chassis variations of the WCC chassis line with an interface that supplies the proper inputs and communications for the operations detailed (assumed chassis modules interfacing to this system listed below). All other details for this IP can be found in the documents referenced by this specification.

<u>Engines</u>	<u>Transmissions</u>	<u>ABS Systems</u>	<u>Traction Control System</u>	<u>Multiplex System</u>
ECM (SA=00 <sub>h</sub> )	Allison EVS 2500, EVS 3000, EVS 4000 (SA=03 <sub>h</sub> )	WABCO Hydraulic and Air Systems (SA= 0B <sub>h</sub> )	ATC (SA=11 <sub>h</sub> )	Megatech BCM (SA=21 <sub>h</sub> )

## 3. CONFIGURATION

This product will be available in several programmable configurations all of which are listed below. Feature availability and some logic will be dependant on configuration of the cluster. All features will be detailed in this document but not all will be available in each configuration. Configuration is set by the manf. and stored in the EEPROM.

### PRND123

This configuration selection will place a PRND123 gear selection on the display.

### CTC

This selection is Trip Computer setting.

### CTP

This selection is Power Train setting.

### METRIC


The metric configuration will change standard English values to metric ones. (i.e. MPH to KMH)

### Fuel Tank Capacity

The cluster uses the fuel tank capacity to calculate certain display values and needs to be configured for the tank size that will be used with it.



## 4. MODES OF OPERATION



### 4.1. Sleep Mode

If battery power is applied to the system with no other activity, it will be in sleep mode. When the system is in Sleep Mode the microprocessor is stopped.

The system exits Sleep Mode when one of the wake-up inputs becomes active. When the micro wakes up, it first begins to control the power supply by activating the power supply maintain output. It then decides, depending on which wake up input is active, what mode must be entered.

When the system goes back to sleep after the deactivation of the wakeup input, it simply deactivates the power supply maintain output.

### 4.2. Odometer Mode

The system can enter odometer mode when battery power is available, the ignition input is not active. When in odometer mode the system will backlight the display and show the last saved distance.

The inputs that can cause the system to enter this mode are pushing either the mode or trip button or by activating the headlight input with the conditions above.

The system exits this mode immediately when the ignition becomes active or after the headlight input signal is deactivated. If trip or mode was used to enter this mode the system will remain in this mode for 15 sec. The system goes back to sleep mode upon exiting this mode.


### 4.3. Key-in-Ignition Mode

If a key in ignition input is active at any point during a 60 sec. period starting at ignition off the system will sound alarm 1 (see audible alarm section). The chime will continue to sound until key is removed from the ignition and input is deactivated or the 60-second period has elapsed.

The odometer is visible in this mode also until either the key is removed from the ignition or the 60-second period has elapsed.

The system goes back to sleep mode upon exiting this mode.

### 4.4. Start-up Mode



The ignition binary input is used to sense if the key switch is on or off. The system enters start-up mode when the ignition input is active. The system will then go through the functional diagnostic tests described below.

#### 4.4.1. START-UP FUNCTIONAL DIAGNOSTIC

The start up functional diagnostic activity described in this section will have a duration no longer than 3 sec.

##### 4.4.1.1. Gauges

Gauge pointers will drive to zero position and then to the commanded position.

##### 4.4.1.2. LCD

LCD will turn all its segments on for one second, off for one second and then display any default information or active messages.

##### 4.4.1.3. Warning Lights

All warning lights will turn on for 2 seconds and then go out. Active warning lights will turn on when the gauges go to their commanded position.

#### 4.4.2. SYSTEM INITIALIZATION

If the self-test option is disabled the system will initialize in which case the gauges should index themselves and then default to actual values received by data buss messages/senders at startup. All warning lights will perform a lamp check by turning on and then go out. After lamp check, active warning lights will turn back on. Initialization duration no more than 3 sec.

#### 4.4.3. SYSTEM CONFIGURATION

Once self test/initialization is complete the cluster will retrieve the configuration information. If the cluster detects that the mode or trip button is pressed during this time the display will show the software version and part number of the system for 2 sec.

#### 4.4.4. COMM DETECTION

Next the system will determine which devices are present. Error messages will display if a device that should be present is missing. If the data bus should fail, a communications error should be displayed on the LCD.

### 4.5. Ignition Mode

The ignition mode is active as long as the ignition input is active. Ignition mode is the normal operational mode of the system and will be the mode referred to throughout this document unless otherwise stated.

#### 4.5.1. NORMAL SHUTDOWN

If the ignition line goes below 9VDC, or when the ignition switch is turned off, the following current settings of the cluster must be stored in non-volatile memory:

- Last odometer value transmitted by the CCM.
- Last Trip 1 and Trip 2 Values calculated in Cluster
- The user selection of US, or Metric units on the message display.
- The last message selection being displayed on the second line of the message display.
- The LCD contrast setting.

After storing these settings, the cluster goes to sleep mode after a delay of 120 seconds. During this delay all active warnings and backlight will be off.

#### 4.5.2. HAZARD FUNCTION

If the hazard lights (right and left turn inputs) are active during the 120 sec. sleep delay the cluster will allow these lamps to be active and the cluster will continue to delay sleep mode until the loss of these active inputs for more than 3 sec

Hazard function will NOT act as a wakeup so once cluster is in sleep mode it will require a normal wakeup input before hazards can be turned on.

#### **4.6. Diagnostic Mode**

The self-diagnostic mode is entered when a start diagnostic mode command is made. The start diagnostic request is sent either by a diagnostic tool through CAN or through a menu selection using the LCD to navigate. Diagnostics is only available when the Park Brake is set, and accessed by pressing and holding the MODE button for 5 seconds.

Detail specifications are found in the Diagnostic section of this document.


## 5. STANDARD GAUGES

These gauges will always be present in the system.

### 5.1. Engine Coolant Temperature

Engine coolant temperature is read from the BCM. Pointer remains in last active position w/ignition off, or when communication is lost.

Data Source	Range	Movement	Scale
PGN65262_SPN110	140°	CW	Piecewise Linear 0° = 40°C (C) 70° = 88 to 107°C (center tick) 122.5° = 127 °C (7/8 tick) 140° = 150°C (H)



### 5.2. Fuel Level

Fuel level is read from BCM. Depending on how the system is configured the scale will have different values (see Fuel tank capacity configuration above). Pointer remains in last active position w/ignition off or when communication is lost

Data Source	Range	Movement	100, 75 and 60gal Scale	40gal Scale	30gal Scale
PGN65276_SPN96	140°	CW	Piecewise Linear 3° below E= 0% tank (no tick) 0° = 10% (E) 35° = 25% (1/4) 70° = 46% (1/2) 105° = 69% (3/4) 140° = 93% (F) 5° above F = 100% (no tick)	Piecewise Linear 3° below E= 0% tank (no tick) 0° = 11% (E) 35° = 25% (1/4) 70° = 46% (1/2) 105° = 69% (3/4) 140° = 93% (F) 5° above F = 100% (no tick)	Piecewise Linear 3° below E= 0% tank (no tick) 0° = 12% (E) 35° = 25% (1/4) 70° = 46% (1/2) 105° = 69% (3/4) 140° = 93% (F) 5° above F = 100% (no tick)

### 5.3. Speedometer

The Speedometer will display the vehicle speed and is read from the BCM. Pointer returns to zero w/ignition off, or when communication is lost.

Data Source	Range	Movement	Scale
PGN65265_SPN84	200°	CW	Linear 0° = 0 MPH /0 KMH 200° = 100 MPH /160 KMH

### 5.4. Tachometer

The Tachometer will display the engine speed and is read from the BCM. Pointer returns to zero w/ignition off, or when communication is lost.

Data Source	Range	Movement	Scale
PGN61444_SPN190	166°	CW	Linear 0° = 0 RPM 166° = 6000 RPM

## 6. WARNING INDICATORS

### 6.1. Lamp General Detail

The lamps detailed below are either indicator lights activated to show the engagement of some chassis function or warning lights to show a fault in some chassis functions.

Some warning lights have an alarm associated with them. This alarm will be one of several preset speaker profiles. See alarm section for profile details.

Some warnings have an associated LCD Warning message that will be displayed along with the warning light. See the message display section for specifics on those messages.

All warnings with associated alarms/display messages can be “acknowledged”. If the user acknowledges the warning by pressing the *Trip button*, the display will go back to the previous screen and the alarm will stop, but the indicator lamp will remain active. The alarm/display message will be displayed again after “Recurrence” time if the condition is still present (the user can acknowledge it again). If no reoccurrence time is listed, the warning will not reoccur until then next ignition cycle.

Pos	Function	Color	Graphic	Data Source	Trigger Logic	Alarm/Duration
D405	Left Turn	GREEN	J1362 #0084	PIN 19, BIN AH		3/ once for every cycle of input
D406	Right Turn	GREEN	J1362 #0084	PIN 20, BIN AH		3/ once for every cycle of input
D401	Battery Charge	RED	SYMBOL	PIN 9, AL BIN	Active input	1/3sec
				DM1_SPN167	FMI = 1	
				DM1_SPN521116	FMI= ANY	
D402	Low Oil Pressure	RED	SYMBOL	DM1_SPN100	FMI = 0	1/until acknowledged
D407	High Beam	BLUE	J1362 #0082	PIN 21, AH BIN		NONE
D416	Seat Belt	RED	J2402 #6..18	PIN 26, AL BIN	See Lamp function	None
D412	Stop Engine	RED	SYMBOL	NOT USED		
D404	Cruise	GREEN	SYMBOL	PGN65265_SPN595		NONE
D417	Service Engine	YELLOW	SYMBOL	PIN 27, AL BIN DM1_SPN520992 DM1_SPN521144 DM1_SPN521232 DM1_SPN521134 DM1_SPN521277	FMI_ANY	NONE
D419	High Idle	YELLOW	TEXT	PGN65265_SPN976	value=1-17	NONE
D420	Range Inhibit	RED	SYMBOL	PGN65098_SPN2900		NONE
D410	Auto Park	RED	TEXT	NOT USED		NONE
D415	Park Brake	RED	J2402 #6.32	See Lamp Function	See Lamp Function	See Lamp Function
D403	Check Trans	YELLOW	SYMBOL	DM1_SPN2003	FMI_31	1/3sec
	WAIT TO START	YELLOW	TEXT	NOT USED		
	WATER IN FUEL	YELLOW	TEXT	NOT USED		
D414	ABS	YELLOW	J2402 #6.47	PIN 23 BIN AL	Active Binary	1/3sec
				PIN 25 BIN AL		
				PGN61441_SPN563	ON=01	
				DM1_SPN563 PGN61441_SA 0B	FMI_ANY Missing messages from PGN61441_SA 0B >1s	
	DPF	YELLOW	SYMBOL	NOT USED		
	HEST	YELLOW	SYMBOL	NOT USED		
D418	Daytime Running	GREEN	SYMBOL	PIN 33, AL BIN		NONE

	Lights					
D413	Overdrive Off	YELLOW	TEXT	PIN 16, AL BIN	4 <sup>th</sup> Gear selected w/AL BIN	NONE
D411	Grade Brake	GREEN	SYMBOL	Not used	Not used	Not used
D408	Check Tire	YELLOW	SYMBOL	DM1_SPN929 DM1_SPN241	FMI_12,31 FMI_1, 16, 18	NONE



## 6.2. Lamp Function

### 6.2.1. LEFT TURN

Lamp flashes in sequence with the binary input supplied by the chassis.

### 6.2.2. RIGHT TURN

Lamp flashes in sequence with the binary input supplied by the chassis.

### 6.2.3. BATTERY CHARGE

Lamp turns on steady with presence correct SPN and FMI combination in the DM1 message, or with binary input active. Turns off immediately when not present or deactivated input.

### 6.2.4. LOW OIL PRESSURE

Lamp turns on steady with presence correct SPN and FMI combination in the DM1 message. Lamp will flash if no information is receive in PGN65263. Turns off immediately when not present.

### 6.2.5. HIGH BEAM

Lamp turns on steady with binary input active. Turns off immediately when input is deactivated.

### 6.2.6. SEAT BELT

This light shows that the seat belt is unbuckled and is considered unbuckled when this binary is Low. When the seatbelt is buckled the circuit is broken and the input is left open allowing the gauge to pull it high.

During 60 second period after startup completion, the lamp turns on steady with binary input active for the first 20 sec. and flashes for remaining 40 seconds of the 60 second period after startup completion if the binary input is still active. Turns off immediately when input is not active.

### 6.2.7. STOP ENGINE

Not available on this product.

### 6.2.8. CRUISE

Lamp turns on steady when data bus message value on. Turns off immediately when message value is off.

### 6.2.9. SERVICE ENGINE

Lamp turns on steady with binary input active or correct DM1 message is present with any FMI. Turns off immediately when input is deactivated or DM1 messages are missing.

#### 6.2.10. HIGH IDLE

Lamp turns on steady with a message value of 1-17. Turns off immediately when value is 0.

#### 6.2.11. RANGE INHIBIT

Lamp turns on steady when data bus message value on. Turns off immediately when message value is off.

### 6.2.12. PARK BRAKE INDICATOR/HPB BEHAVIOR

The park brake lamp will light up, flash and be accompanied by PIM's or alarms depending on inputs or messages from the chassis and brake system. Brake system warnings take precedence over applied park brake indications or warnings.

Function	Data Source	Trigger	Cluster Behavior
Park Brake Applied	PIN 24 , AL BIN	Active Input Vehicle speed < 3mph Park Gear requested	-Park Brake Indicator Lamp on Steady
Park Brake Applied while moving	PIN 24 , AL BIN	Active Input Vehicle speed ≥ 3mph Any gear but Park	-Park Brake Indicator Lamp flashing -3 sec Alarm 2 (not acknowledgeable) -LCD PIM: PARK BRAKE ON
Park Brake Applied out of Park Gear	PIN 24 , AL BIN	Active Input Vehicle speed < 3mph Any gear but Park	-Park Brake Indicator Lamp Steady -3 sec Alarm 2 (not acknowledgeable) -LCD PIM: PARK BRAKE ON
HBS hydraulic Brake Low Brake Fluid	PIN 25, AL BIN	IGN for >10sec Active Input AND RPM > 500	-Park Brake Indicator Lamp on Steady -ABS Lamp on Steady -Alarm1 until acknowledged -LCD PIM: LOW BRAKE FLUID
HBS hydraulic Brake Failure Circuit 1	PGN64998_SPN2582	Value = 00	-Park Brake Indicator Lamp on Steady -ABS Lamp on Steady -Alarm1 until acknowledged -LCD PIM: HYD BRAKE PRESS WARN
HBS hydraulic Brake Failure Circuit 2	PGN64998_SPN2583	Value = 00	-Park Brake Indicator Lamp on Steady -ABS Lamp on Steady -Alarm1 until acknowledged -LCD PIM: HYD BRAKE PRESS WARN
HBS hydraulic Brake Failure Warning Circuit 1	PGN64998_SPN2584	Value = 01	-Park Brake Indicator Lamp on Steady -ABS Lamp on Steady -Alarm1 until acknowledged -LCD PIM: HYD BRAKE PRESS WARN
HBS hydraulic Brake Failure Warning Circuit 2	PGN64998_SPN2585	Value = 01	-Park Brake Indicator Lamp on Steady -ABS Lamp on Steady -Alarm1 until acknowledged -LCD PIM: HYD BRAKE PRESS WARN

\*Active Low binary considered active if <2v and not active if > 4v

\*\* The HBS hydraulic brake system failure warning takes precedence over other park brake warnings and indications.

### 6.2.13. CHECK TRANS

Lamp turns on steady with correct DM1 message present with correct FMI. Turns off immediately when DM1 message is missing or FMI is not correct.

#### 6.2.14. WAIT TO START

Not available on this product.

#### 6.2.15. WATER IN FUEL

Not available on this product.

#### 6.2.16. ABS

Lamp turns on steady when data bus message value is 01 or input is active. Turns off immediately when message value is not equal to 01 or input is not active.

#### 6.2.17. DPF-DIESEL PARTICULATE FILTER FAULT

Not used on this product.

#### 6.2.18. HEST-HIGH EXHAUST SYSTEM TEMP

Not used on this product.

#### 6.2.19. DAYTIME RUNNING LIGHTS

Lamp turns on steady with binary input active. Turns off immediately when input is deactivated.

#### 6.2.20. OVERDRIVE OFF

Lamp turns on steady with binary input active and 4<sup>th</sup> gear is selected. Turns off immediately when input is deactivated.

#### 6.2.21. GRADE BRAKE

NOT USED

#### 6.2.22. CHECK TIRE

Lamp turns on steady with correct DM1 message present with correct FMI. Turns off immediately when DM1 message is missing or FMI is not correct.

## 7. TRIP AND MODE BUTTONS

The Trip Reset and Mode switch contacts are used to navigate menus, operate features of the message display and acknowledge warnings.

Both switches are also available on the cluster connector for remote operation.

### 7.1. Trip switch

- Selects and resets trip odometers

- Scrolls menu up
- Used along with “Mode switch” to select menu line and to toggle units (US/metric).
- Wake up cluster, while the ignition is off, to display the odometer.
- Available remotely through AL BIN on PIN 17

## **7.2. Mode switch**

- Enters inquiry mode
- Scrolls menu down
- Used along with “Trip switch” to select menu line and to toggle units (US/metric).
- Wake up cluster, while the ignition is off, to display the odometer.
- Available remotely through AL BIN on PIN 18

## **8. UNITS SELECTION**


Select either US or Metric units by pressing and releasing the trip and mode switches simultaneously.

## 9. DIMMING

Gauge, pointer and display backlight intensity are controlled by a 5000 +/-5  $\Omega$  potentiometer.

When the headlights are on, all of these features dim together in accordance with the dimmer position. A selection in the diagnostic menu on the message display will allow resetting to the original factory value (this value is calculated with no load connected in parallel with the back-lighting input).

If the headlights are off, the LCD backlighting will be on full bright.




## 10. AUDIBLE ALARM

The following table lists the available alarms. These will be referred to by number throughout this document to define audible alarms for specific functions.

<b>Audible Alarm</b>	<b>Freq.</b>	<b>T1</b>	<b>Period</b>
1 (Buzzer)	2.8KHz	120msec	Continuous
2 (Chime)	2.8KHz	120msec	320msec
3 (Click)	See below	See below	See Below

<b>Turn signal Click</b>				
<b>T1</b>	<b>On Click (Hz)</b>	<b>Duration (ms)</b>	<b>Off Click (Hz)</b>	<b>Duration (ms)</b>
t1	10,000	160	10,000	160
t2	6,200	80	2,800	80
t3	2,400	10	2,400	10
t4	10,000	160	10,000	160
t5	6,200	150	6,200	80
t6	3,600	80	2,800	40
t7	920	40	10,000	160
t8	6,200	150	6,200	80



### **10.1. Alarm Messages**

All alarms are associated with a light, display message or gauge reading and will be detailed in the section it is associated with. See those sections for alarm details.

## **11. MESSAGE DISPLAY CENTER**

The message center is a graphical, backlit, LCD that displays information to the vehicle operator. In addition to basic odometer & gear display functions, a variety of customer-defined options will be displayed. The message center can be used to navigate through menus to configure and diagnose problems. Priority messages and warning can also be displayed as they are received.

\*\*All screen shots shown in this section are for basic graphic positioning only. Font size and style as well as symbols may differ from these references.

### **11.1. Menu Navigation Overview**

- Menus have 4 lines.
- The highlighted line is shown in reverse video.
- To highlight a line, the trip switch is used to scroll up and the mode switch is used to scroll down.
- Once high-lighted, a menu item can be selected in either of two ways:
  - Depressing and then releasing the trip and the mode switches at the same time chooses the item. Or after 3 seconds of inactivity, the line shown in reverse video is automatically chosen.
  - Then, the display exits from the menu to the previous display.

### **11.2. Screen Config Overview**

The default drive screen can be configured in several ways. This configuration is accessed by pushing the mode button while in the default screen. This brings up a menu of options as shown in the sections below. When selected it configures the default screen with different options.

ODO, Trip 1 or Trip 2 will always be displayed in the upper left corner of the screen.



### 11.2.1. TRIP COMPUTER FEATURES

These features are available in the display if the cluster is configured with Trip computer. When selected they will appear in the bottom center of the display as shown in the sections below. PRNDL123 will be displayed in the upper right corner.

Feature	Data Source	Data Range	Units
Instantaneous Fuel	PGN65266_SPN184 (moving)	0-125.5	L/100 km (mpg) if vehicle speed is > 0
	PGN65266_SPN183 (not moving) *if supported*		L/hrs (g/hr) if vehicle speed is = 0
Average Fuel Economy	PGN65266_SPN185	0-125.5	L/100km (mpg)
Average Vehicle Speed	Logic based on time and distance traveled	since last trip reset	km/hr (mph)
Outside Temperature	PIN 3_ANALOG	*-30 to 70	°C (°F)

\*Outside temp input data outside of range shown will be considered disconnected and will not show up in the menu.

#### 11.2.1.1. Outside Temp Details

If Outside temp range falls outside valid range it will be considered disconnected and not available in the menu.

Outside Temperature	Temperature Sender Resistance
-30°C (-22°F)	52595 Ω
-20°C (-4°F)	28580 Ω
-10°C (14°F)	16120 Ω
0°C (32°F)	9400 Ω
10°C (50°F)	5660 Ω
20°C (68°F)	3500 Ω
30°C (86°F)	2300 Ω
40°C (104°F)	1500 Ω
50°C (122°F)	1000 Ω
60°C (140°F)	670 Ω
70°C (158°F)	470 Ω

### 11.2.2. POWER TRAIN FEATURES

These features are available in the display if the cluster is configured with Power Train computer. When selected they will appear in the bottom center of the display as shown in the sections below. PRNDL123 will be displayed in the upper right corner.

Feature	Data Source	Data Range	Units
Battery Voltage	PIN 36_ANALOG	+VDC	Volts
Coolant Temp	Same as gauge	-40 to 210	°C
Engine Speed	Same as gauge	0 to 6000	RPM
Vehicle Speed	Same as gauge	0-100 or 0-160	mph or kmh
Boost Pressure	PGN65270_SPN102	0-500	Kpa
Intake Air Temp	PGN65270_SPN105	-40 to 210	°C

### 11.2.3. PRND123 FEATURES

The main feature available for display if the cluster is configured with PRND123 option is the Requested Range showing the operator selected gear in the bottom center as PRND123 with the requested gear highlighted in reverse video. For values of P, R, N, 1, 2 & 3 this area will highlight that value. For any gear requested over 3 (4, 5 & 6) it will simply highlight the D.

This configuration will also display the Current Range in the upper right corner which is the currently engaged gear. This is simply displayed as the character for the gear.

In the bottom right corner it will show the Maximum Gear Limit which is the highest gear the automatic transmission will engage. This is read from the same message as Requested range. This is simply displayed as the character for the gear in reverse video.

Feature	Data Source	Data Range	Units
Transmission Requested Range	PGN61445_SPN162	P,R,N,D,1,2,3	ASC11 32
Transmission Current Range	PGN61445_SPN163	P,R,N,1-6	ASC11 32
Maximum Gear Limit	PGN61445_SPN162	P,R,N,1-6	ASC11 32

### 11.2.4. OIL PRESSURE FEATURES

When this display option is selected the following will appear in the bottom center of the display as shown in the sections below. PRNDL123 will be displayed in the upper right corner.


Feature	Data Source	Data Range	Units
Oil Pressure	PGN65263_SPN100	0-125	kpa

#### 11.2.5. LARGE FONT FEATURES


When this display option is selected a large font PRNDL will appear in the bottom center of the display as shown in the sections below. A large font ODO can be toggled to replace this area of the display by pressing the Trip button. A large font Trip 1 and Trip 2 can also be toggled to replace this spot on the display.





11.2.6. TRIP COMPUTER CONFIG MENU




11.2.7. POWER TRAIN COMPUTER CONFIG MENU



11.2.8. PRND321 CONFIG MENU

11.2.9. OIL PRESSURE CONFIG MENU



11.2.10. LARGE FONT CONFIG MENU



### **11.3. Standard Display Messages**

These messages will be shown in the areas of the display shown in the sections above depending on the default screen configuration.

#### **11.3.1. ODOMETER ACCUMULATED**

Maximum display is 999,999.9 miles. Odometer will not roll over. Odometer mileage is incremented by reading the BCM (SA=21h) J1939 PGN 65248. During normal operation the odometer value is stored in the BCM. Last received mileage is stored in the cluster at Ignition off for viewing with wakeup inputs. This value will be overwritten when first Odometer message is received on next startup.

#### **11.3.2. TRIP ODOMETER 1 AND TRIP ODOMETER 2**

Two independently operating trip odometers are available. Maximum display is 9,999.9 miles. Trip odometer will then roll over. The individual trip counters are independently reset by depressing and holding "Trip" switch.

#### **11.3.3. GEAR SELECTION**

##### **11.3.3.1. Transmission Gear Selected**

The transmission range selected is displayed on PRND321. Transmission Requested Range is defined as the gear commanded by the driver with the gear selector.

The gear selected is read from PGN 61445 (SA=03) Byte 5, Display transmission gears as "P", "R", "N", "D", "3", "2" or "1". The D will be shown as a "D" with an "O" around it. See (Appendix M: Selected Gear/Engaged Selection) for selection.

##### **11.3.3.2. Transmission Gear Engaged**

Transmission Current Range is read from PGN 61445 (SA=03) Byte 7 and is displayed in the upper right corner when in PRND321 option. Gear Engaged will be displayed as: "gear 1" or, "2", "3", "4", "5", "6", "N", "R", "P".

##### **11.3.3.3. Maximum Attainable Gear**

Maximum attainable gear is displayed in the lower right corner of the LCD when in PRND321 option. It will display a driver selected highest attainable gear number in reverse video. Automatic shifting can go no higher than this displayed gear.

### **11.4. Priority Interrupt Messages (PIM)**

These messages will be shown in the bottom center of the display due to various inputs or data messages. If a PRNDL is present in this areas it will move to the upper right corner of the display. Multiple messages will be displayed by continually cycling active messages every 3 seconds. A maximum of 10 messages can be displayed.

All messages can be acknowledged, by pressing the Trip button while being displayed, at which time the message will leave the display and the associated alarm will silence. The alarm/message will reoccur if / when the message trigger stops and reoccurs or the next key-on cycle if the trigger never stops.

**For all proprietary messages from CCM Source Address 21<sub>h</sub>, refer to Megatech Documentation .**

Function	Data Source	Trigger	Exact Text	Alarm/Duration
Trans Comm Failure	PGN61445_SA 03	Missing messages from PGN61445_SA 03>240ms	TRANS COMM FAIL	NONE
Check Transmission Temp	DM1_SPN177	FMI 15	CHECK TRANS TEMP	1/3sec
ABS Comm Failure	PGN61441_SA 0B	Missing messages from PGN61441_SA 0B >1s	ABS COMM FAIL	1/3sec
Check ABS	Same as ABS indicator	Same as ABS indicator	CHECK ABS	NONE
*Speed Signal Fail	PGN61444_SPN190	Missing messages from PGN61444_SPN190>1s	SPEED SIG FAIL	1/until acknowledged
Park Brake	See Section 6.2.12	See Section 6.2.12	PARK BRAKE ON	See Section 6.2.12
Range Inhibit	Same as indicator	Same as indicator	TRANS SHIFT INHIBIT	Same as Indicator
Door Ajar	PIN 15, AL BIN	Active Binary	DOOR AJAR	2/3sec
Low Oil Pressure	Same as indicator	Same as indicator	LOW OIL PRESS	Same as indicator
Check Eng Oil Level	DM1_SPN98	FMI 1	CHECK OIL LVL	2/3sec
High Coolant Temp	PGN65262_SPN110 DM1_SPN110	On if >125C; Off if<121C or FMI 0 or 15	HIGH COOLNT TEMP	1/3sec
**Low Coolant Level	DM1_SPN111	FMI 17	LOW COOLANT LVL	1/until acknowledged
***Brake Fail/Hydraulic Fluid Pressure	See Section 6.2.12	See Section 6.2.12	HYD BRAKE PRESS WARN	See Section 6.2.12
No 1939 Activity	CAN BUS	Missing 1939 messages for >2.5s	NO 1939 ACTIVITY	1/until acknowledged
Auto park Fail	PIN 34, AH BIN	REMOVED; NOT SUPPORTED	AUTO PARK FAIL	1/until acknowledged
Low Fuel Level	DMI_SPN96	FMI 17	LOW FUEL LEVEL	1/3sec
Low Voltage	PIN 36 ANALOG VAR VOLTAGE	On if <11V for more than 30s	LOW VOLTAGE	1/until acknowledged
High Voltage	PIN 36 ANALOG VAR VOLTAGE	On if>16V for more than 5s	HIGH VOLTAGE	1/until acknowledged
Headlight Reminder	PIN 22, AL BIN	IGN off w/input active	HEADLIGHTS ON	2/until acknowledged
Turn Signal Reminder	PIN 19 PIN 20	One of the two is active for >.75mi	TURN SIGNAL ON	2/3sec
Key-in Ignition	PIN 28, AL BIN	Active input within 60sec of IGN off	KEY IN IGNITION	2/Reference key-in-ignition mode section
BATTERY CHARGE FAIL	Same as Lamp	Same as Lamp	ALT FIELD FAIL	1/3sec. or T button
Reduced Engine Power	DM1_SPN 521241	FMI_11	REDUCED ENG PWR	2/3sec
Change Oil Now	DM1_SPN 521242	FMI_16	CHANGE ENG OIL NOW	2/3sec
Change Oil Soon	DM1_SPN 521243	FMI_15	CHANGE ENG OIL SOON	2/3sec

\*Reoccurrence every 10 min


\*\*Self-canceling after 5s of no message.

\*\*\*10 sec delay after ignition is required to avoid false failures.

## **12. ON BOARD DIAGNOSTIC**

On-board diagnostic functions can be initiated and executed with transmission in park, the park brake is set and the Mode switch is depressed for longer than 5 seconds.

Refer to Menu Navigation section for information on how to select menu options.



### **12.1. Contrast Adjustment**

This feature will allow the user to increase or decrease the contrast of the display by pressing Trip to increase or Mode to decrease. The contrast is limited to a specific visible range to prevent the user from rendering the display unusable.

### **12.2. Restore Default**

The user can restore all factory defaults for any setting that can be modified by the end user (i.e. Contrast, Backlight Color, etc)

### **12.3. Gauge Backlight**

Opens a menu for user selectable backlight colors. Pointers will remain Amber, and LCD backlight remains white. The color options can be scrolled through using the “trip” button. Pressing the “Mode” button exits the selection menu and automatically sets the Gauge Backlight color to the last highlighted selection. Available colors are as follows:

Blue Backlight  
Yellow Backlight  
Lt. Blue Backlight  
White Backlight  
Red Backlight  
Green Backlight

### **12.4. Software Version**

Display the software part number and version programmed into the micro controller.  
Pressing the mode switch exits to the diagnostic menu. (The message "m to exit" appears on the screen).

### **12.5. Part Number**

Display the part number programmed into the micro controller.  
Pressing the mode switch exits the diagnostic menu. (The message "m to exit" appears on the screen).

### **12.6. Max Engine RPM**

Displays the maximum engine RPM that was sustained for > 3 seconds. Pressing the mode switch exits the diagnostic menu. (The message “m to exit” appears on the screen).

### **12.7. Max Vehicle Speed**

Display the maximum vehicle speed that was sustained for > 5 seconds. Pressing the mode switch exits the diagnostic menu. (The message “m to exit” appears on the screen).

### **12.8. Engine Oil Life Remaining**

Gas Engine will display this value in % from 0 to 100% read from J1936 (PGN 61184\_SPN521246)  
Pressing the mode switch exits the diagnostic menu. (The message “m to exit” appears on the screen).

## **12.9. Cluster Diagnostics**

Features in this menu will allow the end user or service to trouble shoot the cluster components and wiring and also set some configurations.

### **12.9.1. GAUGE TEST**

One at a time, each gauge pointer will be driven through three positions, pausing at each position for ½ second. The LCD shows the position of the pointer as a percentage of full scale. At the end of the test, the gauges revert back to their original pointer position and the program returns to the Cluster Diagnostics Menu. The test can be exited at any time by pressing the Mode button.

### **12.9.2. WARNING LAMP TEST**

At the start of the test, all lights are turned off. Each light is then toggled to the “on” state, and then “off”. The LCD displays the name of the light being tested and its status. At the end of the test, the lights revert back to their commanded state (on or off) and the display returns to the Cluster Diagnostics Menu. The test can be exited at any time by pressing the Mode button.

### **12.9.3. LCD TEST**

Uses a test pattern to make sure all pixels in the display are working properly. The pattern is a Workhorse patten that will change positive to negative 3 times and then exit to the Cluster Diagnostics menu. The test can be exited at any time by pressing the Mode button.

### **12.9.4. BACKLIGHT TEST**

The backlight for the gauges, pointers and display is cycled through 0%, 50% and 100% intensity while displaying this percentage on the LCD. When finished the display returns to the Cluster Diagnostics Menu. The test can be exited at any time by pressing the Mode button.

### **12.9.5. SPEAKER TEST**

This test will cycle 3 times by sounding 2 different tones each cycle. When finished the display will exit to the Cluster Diagnostics Menu. The test can be exited at any time by pressing the Mode button.

### **12.9.6. SWITCH INPUTS**

This routine tells the operator the status of each Binary input. The display indicates the switch input by descriptive name and the status level (ON/OFF) at the pin. Four inputs are shown per screen page. The level status reflects the active state of the input. For example, if an input is active to ground, and the input level is 0 volts, then the status will be ON. Press Mode to exit to the Cluster Diagnostics Menu.

### **12.9.7. ANALOG INPUTS**

This routine tells the operator the status of each Analog input. The display indicates status of the input by descriptive name and the status to the right. Four inputs are shown per screen page. Press Mode to exit to the Cluster Diagnostics Menu.

### 12.9.8. VEHICLE SETTINGS

NOT USED ON THIS PRODUCT

### 12.10. **Exit**

Selecting Exit will return the display to the default drive screen.

## 13. **DATA LINK DIAGNOSTICS**

Data link diagnostics is done through the cluster CAN channel.  
It requires a PC and RS232-to-CAN interface hardware.  
The capabilities are the following.

### 13.1. **Diagnostic Session**

Start diagnostic session  
End diagnostic session

### 13.2. **Reprogram Microprocessor**

Flashing shall not change odometer value.

### 13.3. **Current Value Monitor**

Show in real time the state of the cluster inputs.

- A/D Inputs
- Logic Inputs
- Frequency Inputs

### 13.4. **Set Parameters**

Using proprietary software written by ACTIA, the cluster will allow the following through the data link.

Clear “maximum RPM” and “maximum vehicle speed”

Set odometer (eliminates odometer statements). This software will write any value into the odometer. A secure method will be used to set the odometer.

Calibrate gauges.

Cluster configuration.

Control the outputs of the cluster.

- LCD pixels
- Individual warning lights
- Gauge back lighting
- Individual gauges
- Speaker



**14. J1939 TABLE OF MESSAGES**

Frame	PGN / SPN	Name	Byte	TX/ RX	English/ Metric Units	Source Address (all in hex)
CCVS	65,265 (00FEF1) / 595	Cruise Control Active	4B 2&1	RX	N/A	21
CCVS	65,265 (00FEF1) / 84	Wheel-Based Vehicle Speed	3-2	RX	Mph/kmh	21
CCVS	65,265 (00FEF1) / 597	Brake Switch	4b 6&5	RX	N/A	21
CCVS	65,265 (00FEF1) / 976	PTO State	7b 5-1	RX	N/A	21
EEC1	61,444 (00F004) / 190	Engine speed	4,5	RX	RPM	21
ETC2	61,445 (00F005) / 523	Transmission Current Gear	4	RX	PRND123	03
ETC2	61,445 (00F005) / 162	Transmission Request Range	6-5	RX	PRND123	03
ETC2	61,445 (00F005) / 163	Transmission Current Range	8-7	RX	PRND123	03
ETC2	65,195 (00FEAB) / 1115	Highest Possible Gear	2	RX	PRND123	03
ETC7	65,098 (00FE4A) / 2900	Transmission Shift Inhibit Indicator	2b 8&7	RX	N/A	03
DD	65276 (00FEFC) / 96	Fuel Level	2	RX	%	21
LC	65089 (00FE41) / 2367	Left Turn Signal Light Command	2 b 8&7	RX	N/A	21
LC	65089 (00FE41) / 2369	Right Turn Signal Light Command	2 b 6&5	RX	N/A	21
LC	65,089 (00FE41) / 2369	Running Light Command	1b 2&1	RX		21
ET1	65,262 (00FEEE) / 110	Engine coolant temp.	1	RX	°F / °C	21
EFL/PI	65,263 (00FEFF) / 100	Engine oil pressure	4	RX	PSI / KPa	21
VEP1	65,271 (00FEF7) / 167	Charging system potential (volts)	4-3	RX	V	21
CM1	57,344 (00E0FF) / 1865	Seat Belt Switch	4b 8&7	RX	N/A	21
TRF1	65,272 (00FEF8) / 177	Transmission oil temp.	6-5	RX	°F / °C	03
HBS	64,998 (00FDE6) / 2584	Hydraulic Brake Pressure Warning State Circuit 1	3 b 2&1	RX		0B
HBS	64,998 (00FDE6) / 2583	Hydraulic Brake Pressure Supply State Circuit 2	3 b 8&7	RX		0B
HBS	64,998 (00FDE6) / 2582	Hydraulic Brake Pressure Supply State Circuit 1	3 b 6&5	RX		0B
HBS	64,998 (00FDE6) / 2585	Hydraulic Brake Pressure Warning State Circuit 2	3 b 4&3	RX		0B
HBS	64,998 (00FDE6) / 2931	Hydraulic Brake Fluid Level	4 b 4&3	RX		0B
HBS	64,998 (00FDE6) / 2930	Hydraulic Brake System Audible Warning Command	4 b 2&1	RX		0B
B	65,274 (FEFA) / 619	Parking brake actuator	4b 2&1	RX		0B
EBC1	61,441 (00F001) / 563	ABS Warning Lamp	6b 6&5	RX		0B
LFE	65,266 (00FEF2) / 184	Instantaneous fuel econ	4-3	RX	MPG / Km/L	21
LFE	65,266 (00FEF2) / 185	Average fuel economy	6-5	RX	MPG / Km/L	21
HOURS	65,253 (00FEE5) / 247	Total engine hours	1-4	RX	H	21
IC1	65,270 (00FEF6) / 102	Eng Turbocharger Boost pressure	2	RX	PSI / kPa	21
IC1	65,270 (00FEF6) / 105	Eng Intake Manifold 1 Temp	3	RX	°F / °C	21
VD	65,248 (00FEE0) / 245	Total Vehicle Distance	8-5	RX		21
PropA	61184 (00EF00) / 521246	Engine Oil Life	8b 7-1	RX	%	21
<b>Defined Faults</b>	<b>PGN</b>	<b>Name</b>	<b>Byte</b>	<b>SPN</b>	<b>FMI</b>	<b>SA</b>
DM1	65,226 (00FECA)	Low Oil Pressure		100	0	21
DM1	65,226 (00FECA)	High Transmission Temp		177	15	03
DM1	65,226 (00FECA)	Low Coolant Level		111	1	21
DM1	65,226 (00FECA)	Check Trans		2003	31	03
DM1	65,226 (00FECA)	Alternator DTC		167	1	21
DM1	65,226 (00FECA)	Alternator Fail DTC		521116	ANY	21
DM1	65,226 (00FECA)	Low Fuel		96	17	21
DM1	65,226 (00FECA)	Engine Oil Level		98	1	21
DM1	65,226 (00FECA)	Stop Engine		1111	1	21
DM1	65,226 (00FECA)	Reduced Engine Power		521241	11	21

DM1	65,226 (00FECA)	High Coolant Temp		110	0,15	21
DM1	65,226 (00FECA)	Change engine Oil NOW		521242	16	21
DM1	65,226 (00FECA)	Change engine Oil SOON		521243	15	21
DM1	65,226 (00FECA)	ABS		563	ANY	0B
DM1	65,226 (00FECA)	Service Engine Soon		520992	ANY	21
DM1	65,226 (00FECA)	Service Engine Soon		521144	ANY	21
DM1	65,226 (00FECA)	Service Engine Soon		521232	ANY	21
DM1	65,226 (00FECA)	Service Engine Soon		521134	ANY	21
DM1	65,226 (00FECA)	Service Engine Soon		521277	ANY	21
DM1	65,226 (00FECA)	High Idle		976	ANY	21
DM1	65,226 (00FECA)	Check Tire		929	12,31	33
DM1	65,226 (00FECA)	Check Tire		241	1,16,18	33

## 15. RELATED DOCUMENTS

- SAE J1455 *Joint SAE/TMC Recommended Environmental Practices for Electronic Equipment Design (Heavy-Duty Trucks)*
- SAE J1211 *Recommended Environmental Practices for Electronic Equipment Design*
- SAE J1113/\* *Electromagnetic Compatibility Measurement Procedures and Limits for Vehicle Components*
- SAE J1812 *Function Performance Status Classification for EMC Immunity Testing*
- SAE J2217 *Photometric Guidelines for Instrument Panel Displays that Accommodate Older Drivers*
- SAE J1226 *Electric Speedometer Specification – On Road*
- SAE J1399 *Electric Tachometer Specification*
- SAE J1810 *Electrical Indicating System Specification*
- SAE J1048 *Symbols for Motor Vehicles Controls, Indicators and Tell-Tales*
- SAE J1362 *Graphical Symbols for Operator Controls and Displays on Off-Road Self-Propelled Work Machines*
- LIN *Specification Package Revision 1.2*
- 1037-01 *117mm Gauge Specification*
- 1075-01 *Warning Bank with Air Specification*
- Warning Bank w/o Air Specification*
- 85mm *Gauge Specification*
- FMVSS 106 *Federal Motor Vehicle Safety Standards, Air Brakes*
- FMVSS 101 *Federal Motor Vehicle Safety Standards, Controls and Displays*
- FMVSS 121 *Federal Motor Vehicle Safety Standards*
- FMVSS 302 *Flammability of interior materials*
- SAE J1587 *Electronic Data Exchange Between Microcomputers*
- SAE 1708 *Serial Data Communications Between Microcomputers*
- SAE J1939 *Recommended Practice for Serial Control and Communication Vehicle Network*
- SAE J844 *NONMETALLIC Air Brake System Tub*

## 16. GLOSSARY/ABBREVIATIONS

TBD – To be determined

EEPROM – Electrically Erasable Programmable Read Only Memory

SAE – Society of Automotive Engineers


PGN – Parameter Group Number (J1939)  
SPN – Suspect Parameter Number (J1939)  
FMI – Failure Mode Identifier (J1939)



## 17. APPENDIX A

### 17.1. Cluster Pinout

The cluster has a single, 2 bay keyed connector. The figure below show the connector pin numbering from the wire entry side with the latch on bottom. This numbering can also be found on the connector housing.



CLU Pin	Description	CLU Pin	Description
1	Not Used	19	LEFT TURN
2	Not Used	20	RIGHT TURN
3	OUTSIDE TEMP	21	HIGH BEAM
4	DIMMER	22	HEADLIGHT
5	Not Used	23	ABS
6	IGN	24	PARK BRAKE
7	GND SIGNAL	25	BRAKE FAIL
8	Not Used	26	SEATBELT
9	BATTERY CHARGE	27	SERVICE ENG SOON
10	J1939 +	28	KEY IN IGN
11	J1939 -	29	GRADE BRAKE
12	Not Used	30	Not used
13	Not Used	31	Not Used
14	Not Used	32	Not Used
15	Not used	33	DAYTIME RUNNING LIGHTS
16	OVERDRIVE OFF	34	Not Used
17	REMOTE TRIP	35	GND CHASSIS
18	REMOTE MODE	36	PWR CHASSIS


## 17.2. Mating Connectors

Mating Connectors for the cluster are TYCO mate n lock. The Mating Terminals (Sockets) used with the connector housings are Tyco P/N: 173681-1 (Actia P/N 102146)

### 17.2.1. CONNECTOR 1

16 positions (2 X 8) (Actia P/N 102130)


Tyco US Part Number: 175966-2



### 17.2.2. CONNECTOR 2

20 positions (2 X 10) (Actia P/N 102131)

Tyco US Part Number: 175967-2



**17.3. PWA Configuration**

Terminal	Designation	I/O Assignment	I/O TYPE	Wakeup	Description
1		RAI FUEL-	RES ANALOG		Used in combination with pin 2 for fuel sender input
2	AN0	RAI FUEL+	RES ANALOG		Used in combination with pin 1 for fuel sender input
3	AN5	RAI TEMP	RES ANALOG		Used as resistive analog input for outside temperature sender
4	AN1	VAI DIMMING	VOLT ANALOG		Used as variable voltage analog input for backlight dimmer
5		TOW HAUL	BIN AL		Active Low to be used as needed
6	AN2	VIGN	BIN AH	X	Active high for wakeup
7	GND	GND			Clean ground for communication
8					
9	AN3	CHARGE	BIN AL		Active Low to be used as needed
10	CAN+	J1939+	DATA	X	Data line CAN+ signal
11	CAN-	J1939-	DATA	X	Data line for CAN- signal
12	J1850	J1850	DATA	X	Data line for SAE J1850+ signal
13	P01	FI TACHO	FREQ		Frequency Input for pulsed signal
14	P00	FI SPEED	FREQ		Frequency Input for pulsed signal
15		DOOR	BIN AL		Active Low to be used as needed
16		OVERDRIVE	BIN AL		Active Low to be used as needed
17	P56	TRIP	BIN AH	X	Active high for Trip Switch
18	P57	MODE	BIN AH	X	Active high for Mode Switch
19		LEFT	BIN AH		Active high to be used as needed
20		RIGHT	BIN AH		Active high to be used as needed
21		HIGH	BIN AH		Active high to be used as needed
22		LIGHTS	BIN AH	X	Active high to be used as needed
23	AN7	ABS	BIN AL		Active low to be used as needed
24		PARKBRAKE	BIN AL		Active low to be used as needed
25	AN4	BRAKE FAIL	RES ANALOG		Used as resistive analog input
26		SEAT	BIN AL		Active low to be used as needed
27		SERVICE	BIN AL		Active low to be used as needed
28		KEY	BIN AL		Active low to be used as needed
29		SHIFT	BIN AH		Active low to be used as needed
30		PTO	BIN AL		Active low to be used as needed
31		TIRES	BIN AL		Active low to be used as needed
32		BUZZER EN	BIN AL		Active low to be used as needed
33		DAYLIGHT	BIN AL		Active low to be used as needed
34		AUTOPARK	BIN AH		Active high to be used as needed
35	GND	GND			Chassis Ground
36	VBAT	VBAT			Chassis Power