

# ***SUPER TWO***®

Access Control Panel

Installation and Service Manual



355 Bayview Avenue, Amityville, NY 11701  
Phone: 631-842-9400 Fax: 631-842-9135

A NAPCO SECURITY GROUP COMPANY

### **FCC Warning**

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **NOTE**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which the user will be required to correct the interference at his own expense.

Shielded cables must be used with this unit to ensure compliance with the Class A FCC limits.

### **DISCLAIMER**



Continental Instruments LLC makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Further, Continental Instruments LLC reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Continental Instruments LLC to notify any person of such revision or changes.

Information furnished by Continental Instruments LLC is believed to be accurate and reliable. However, no responsibility is assumed by Continental Instruments LLC for its use; nor for any infringements of other rights of third parties which may result from its use. No license is granted by implications or otherwise under any patent or patent rights of Continental Instruments LLC.

Copyright © 2004 by Continental Instruments LLC. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, or stored in a retrieval system, without the prior written permission of Continental Instruments LLC, 355 Bayview Avenue, Amityville, NY 11701. 631-842-9400

A NAPCO SECURITY GROUP COMPANY

**THE INSTALLATION OF THIS PRODUCT SHOULD BE MADE BY QUALIFIED SERVICE PERSONNEL AND SHOULD CONFORM TO ALL LOCAL CODES.**

	<p><b>CAUTION</b> RISK OF ELECTRIC SHOCK DO NOT OPEN</p>	
<p><b>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK</b></p> <p>DO NOT REMOVE COVERS (OR BACK).</p> <p>NO USER-SERVICEABLE PARTS INSIDE</p> <p>REFER SERVICING TO QUALIFIED SERVICE PERSONNEL</p>		



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated 'dangerous voltage' within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

**WARNING**

This product generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this product in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

**UNPACKING AND INSPECTION**

Unpack carefully. This is an electronic product and should be handled as such. Compare the items received with the packing list with your order.

**BE SURE TO SAVE THE SHIPPING CARTONS AND INSERT PIECES. THEY ARE THE SAFEST MATERIAL IN WHICH TO MAKE FUTURE SHIPMENTS OF THE PRODUCT.**

**WARNING**

**TO REDUCE THE RISK OF FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.**

**MAINTENANCE**


User maintenance of this unit is limited to external cleaning and inspection.

# TABLE OF CONTENTS

DESCRIPTION .....	7
REGULATORY CONSIDERATIONS.....	8
<i>Regulatory Considerations for Super Two Installations</i> .....	8
<i>Specification Explanations</i> .....	8
<i>UL 294 - Safety of Access Control System Units</i> .....	8
<i>Installer Responsibilities (General)</i> .....	8
<i>UL294 Specific</i> .....	8
CONFIGURATION .....	9
<i>Capacities</i> .....	9
<i>Memory Configurations</i> .....	9
EXPANSION BOARDS AND ACCESSORIES .....	10
<i>2 MB Expansion</i> .....	10
<i>Matrix Keypad Option Board CICP1300XYBD</i> .....	10
<i>RS485 and RS232 Two-Channel Auxiliary Communication Board CICP1300AUX</i> .....	10
<i>Network Interface Board CICP1300NETBD</i> .....	10
<i>Battery Backup</i> .....	10
<i>AC Power Supply</i> .....	10
INSTALLATION .....	11
<i>Installation Preparation</i> .....	12
<i>Cabinet Mounting</i> .....	13
<i>Cable Routing</i> .....	14
<i>Incoming Power Conduit Knockout</i> .....	14
<i>Accessory Conduit Knockouts</i> .....	14
<i>Grounding Accessory Drain and Shield Wires</i> .....	14
POWER CONNECTIONS .....	15
<i>AC Power Source Grounding</i> .....	15
<i>VAC Power</i> .....	15
<i>Super Two Circuit Board Layout</i> .....	16
DOOR CONNECTIONS.....	17
<i>Wiegand/Proximity Reader Connections</i> .....	17
<i>Wiegand/Proximity Reader Cable Requirements</i> .....	17
<i>Magnetic Stripe Reader Connection</i> .....	19

<i>Magnetic Stripe Reader Cable Requirements</i> .....	19
KEYPAD CONNECTION .....	20
<i>Wiegand-Output Card and Keypad Readers -</i> .....	20
<i>X-Y Matrix Keypads</i> .....	20
<i>Keypad Cable Requirements</i> .....	20
<i>Door Status Sensor Connection</i> .....	21
<i>Door Status Sensor Cable Requirements</i> .....	21
<i>Request-to-Exit (Bypass) Sensor Connection</i> .....	22
<i>Request-to-Exit Sensor Cable Requirements</i> .....	22
RELAY CONNECTIONS.....	23
<i>Description</i> .....	23
<i>Door Strike Relays</i> .....	23
<i>Auxiliary Relays</i> .....	23
<i>Console Relay</i> .....	23
<i>Relay Characteristics</i> .....	23
<i>Powering Electromagnetic (EM) Locks</i> .....	24
<i>Fire Alarm Control Panel (FACP) Connection</i> .....	24
ACCESSORY POWER.....	25
ALARM CONNECTION .....	26
<i>Supervised Alarms</i> .....	26
<i>Configuring an Alarm in the Supervised Condition</i> .....	26
<i>Alarm Cable Requirements</i> .....	26
<i>Tamper Switch</i> .....	26
<i>RS-232 Communications - Host/Modem Operation</i> .....	27
<i>RS-232 Cable Requirements</i> .....	27
<i>RS-232 Jumper Settings</i> .....	27
<i>Address Setting</i> .....	27
<i>Super Two to Host Computer/Modem Connection</i> .....	27
NETWORKING .....	29
<i>Network Jumper Settings</i> .....	29
<i>Network Cable Requirements</i> .....	29
<i>Network Address Settings</i> .....	29
<i>RS-232 to RS-422 REPEAT Network</i> .....	30
<i>RS-232 to RS-422 REPEAT Jumper Settings</i> .....	30

<i>RS-232 to RS-422 REPEAT Ground and Drain Cables</i> .....	30
<i>RS-232 to RS-422 MULTIDROP Network</i> .....	32
<i>RS-232 to RS-422 MULTIDROP Network Ground and Drain Wires</i> .....	32
<i>RS-232 to RS-422 MULTIDROP Network Jumper Setting</i> .....	32
<i>RS-422 to RS-422 REPEAT Network</i> .....	34
<i>RS-422 to RS-422 REPEAT Network Jumper Settings</i> .....	34
<i>RS-422 to RS-422 REPEAT Network Ground and Drain Cables</i> .....	34
<i>RS-422 to RS-422 MULTIDROP Network</i> .....	36
<i>RS-422 to RS-422 MULTIDROP Network Jumper Settings</i> .....	36
<i>RS-422 to RS-422 MULTIDROP Network Ground and Drain Cables</i> .....	36
JUMPER SETTINGS .....	38
<i>EOL Jumper</i> .....	38
<i>MD/RPT Jumper</i> .....	38
<i>Memory Battery Activation</i> .....	38
TROUBLESHOOTING .....	40
<i>LED Diagnostics</i> .....	40
CIRCUIT PROTECTION .....	41
<i>Super Two Primary Fuse - 120VAC Installations (USA/Canada)</i> .....	41
<i>Super Two Primary Fuse - 230VAC Installations (European Union)</i> .....	41
<i>Super Two Power Supply Fuse</i> .....	42
<i>Super Two Accessory Circuit Protection</i> .....	42
<i>Super Two +5/+12V Reader Circuit Protection</i> .....	42
MAINTENANCE .....	43
<i>Power Supply Replacement</i> .....	43
<i>Backup Battery Replacement</i> .....	43
<i>Memory Coin Cell Replacement</i> .....	43
<i>Clear Memory and Force Download to Panel</i> .....	43
SPECIFICATIONS.....	44
POWER RATINGS .....	45
APPENDIX A.....	46
<i>2 MB MEMORY BOARD INSTALLATION INSTRUCTIONS CICP1300MB2</i> .....	46
APPENDIX B.....	47
<i>NETWORK INTERFACE BOARD INSTALLATION INSTRUCTIONS CICP1300NETBD</i> .....	47



## DESCRIPTION

The Super Two is a fully programmable, self contained, 2-door access control panel that offers users flexibility, expandability, and simplicity. Operating as a stand-alone unit or within a network, each Super Two makes independent access control decisions.

The Super Two accepts Wiegand, Magnetic Stripe, Proximity card readers, and Keypads to control the access functions for a maximum of two individual access points (entrances/exits). Contact Continental Instruments to determine specific readers and keypads supported.

It supports eight supervised alarm devices including door contact sensors, door bypass switches, or other related detection accessories. Five onboard Form C relays support door locking mechanisms, door alarm shunts or handicapped access privileges.

The standard Super Two features a user-programmable, on-board database that supports a maximum of 20,000 card holders. Expansion components enable the Super Two to support up to a maximum 125,000 card holders with 2MB memory expansion.

**NOTE:** Card Capacities can vary due to changes in Firmware, Badge Length and Panel Configuration (Transaction buffer size, Time Schedule Blocks, and Access Groups). Maximum Card Count can be verified by checking Communication Driver (Max Card Count Column).

The Super Two can use an onboard 7AmpHour (AH) backup battery to carry out full access control functions for a period of four hours (assuming typical accessory loads) in the event of an AC power supply loss.

The Super Two power supply automatically switches from 120 VAC/60Hz to 230 VAC/50Hz to meet the requirements

of both North American and the European Union. With built-in overcurrent protection, this Access Control panel meets the requirements for Energy-Limited installations.

In addition, a replaceable lithium battery protects the on-board database and programmed operating instructions from loss for a period of 4 weeks. In the event of a total failure of the AC power supply *and* the backup battery, the Super Two would immediately be ready for full operating capability once a source of operating power is re-established.

For enhanced site access control requirements, multiple Super Two units (a maximum of 63) may be networked together or with other Continental Instruments products including Smarterm, Miniterm, Microterm, Superterm and Turbo Superterm. A Super Two network may be configured to operate in a repeater mode or in a multidrop mode, using the RS-422 communications protocols.

A single host computer may be used to manage and program one Super Two or a fully developed network of Super Two's, saving equipment and installation costs, database entry/deletion procedures, and monitoring individual access usage.

The host computer may communicate with the Super Two network by Dial-up Modem, RS232/RS422 serial communication or by Ethernet using a plug-in Network Interface Adapter.

Changes or upgrades to the Super Two operating software are readily downloadable from the host computer to either one specific Super Two or an entire network of Super Two's, eliminating the need to physically change the EPROM chip inside the unit.

### REGULATORY CONSIDERATIONS

#### Regulatory Considerations for Super Two Installations

The Super Two has been designed to standards that were devised to assure safe and reliable performance. Verification that these objectives have been met was delegated to Underwriters Laboratory (UL), the most established, nationally recognized testing laboratory (NRTL).

#### Specification Explanations

The following section outlines some of the benefits associated with having the Super Two listed to the particular UL specification.

#### UL 294 - Safety of Access Control System Units

- The product survives high voltage power-line and signal line electrical transients.
- Endurance proven by verifying operation of individual access circuits for over 100,000 cycles at the maximum load rating.
- Affords some confidence that the installation will survive physical attack without allowing invalid access to an area.
- Effective backup power and recharge functions that assure four hours of operation with the supplied standby batteries.

#### Installer Responsibilities (General)

For the Super Two to meet the users expectations under any of the previously mentioned UL specifications, the installer has several definite responsibilities, including:

All wiring must conform to all National Electric Code (NEC) specifications, where designated.

All wiring must conform to National Fire Protection Association (NFPA) schedule 70 specifications, where designated. All wiring must conform to any and all local building electrical codes.

#### Furthermore,

The transient protection circuits built into the unit will protect the Super Two and most of the connected equipment *only* when the chassis of the Super Two unit is effectively grounded.

The ratings and limitations declared on the Super Two product labels must not be exceeded.

#### UL294 Specific

Under UL294 specifications, only card readers specifically listed in the UL file, or, which themselves carry the UL294 label, may be used.

There are no special restrictions on which model Host Computer is used or which version of software is installed.



## CONFIGURATION

### Standard Version

#### Capacities

The standard version Super Two provides access control functions for up to two doors and two card readers. Each 5V reader may draw as much as 100mA from the PWR pin of the reader connector, for a total current draw of 200mA per panel. Each 12V reader may draw 200mA from the PWR pin of the reader connector, for a total of 400mA.

Each of the 8 alarm inputs on the main board may be configured as supervised alarms (requiring termination resistors), or standard alarms (requiring plain electrical contacts).

#### Memory Configurations

The standard 512K memory configuration provides resources for downloadable firmware as well as for the cardholder database and a transaction buffer. A 2MB memory expansion board (CICP1300MB2) is available for expansion of card database and transaction buffer space. The 2MB expansion board allows the Super Two to meet the requirements of managing large cardholder populations and provides a total of 2.5MB of RAM.

## CONFIGURATION




Figure 2 - Super Two Components

## Expansion Boards and Accessories

### 2 MB Expansion

The CICP1300MB2 2MB Memory Expansion Board may be added to the Super Two to increase capacity up to 125,000 Card Holders. See the Appendix for the Installation Instructions for this option.

### Matrix Keypad Option Board CICP1300XYBD

The Super Two is compatible with Wiegand Output Reader/Keypad units such as the HID 5355AGK00 or 5355ABK00. These reduce the cost of cabling and installation and are therefore preferred for Card/Keypad Installations. The CICP1300XYBD Expansion Board is available where traditional 3x4 X-Y Matrix Keypad units must be used. See the Appendix for the Installation Instructions for this option.

### RS485 and RS232 Two-Channel Auxiliary Communication Board CICP1300AUX

This optional plug-in board provides RS232 and RS422 interfaces to serial devices such as RFID Readers, PTZ Camera Controllers, Alarm Panels, and Alarm Receivers.

### Network Interface Board CICP1300NETBD

This plug-in board provides direct 10/100 Base-T Ethernet connect capability.

## Battery Backup

During power interruptions, the Super Two normally continues operating for 4 hours via an on-board 7 AmpHour back-up battery.

The backup battery provides DC power for all Super Two access control and alarm monitoring functions. After charging for 48-hours, the battery carries the rated load for four or more hours. A low-voltage battery sensing circuit protects the Super Two by disconnecting the battery from the main circuit before it becomes too deeply discharged.

## AC Power Supply

The power supply provides 12VDC to the on-board power supply. An AC power terminal block and grounding screw provide connection points for the three incoming AC service lines.

The Super Two may be powered by 230VAC/50Hz when used outside North America. No switches and jumpers need to be set, but the supplied IEC127-approved fuse must be used for installations in the European Union.

**NOTE:** The Super Two may be used to power 12 Volt Electromagnetic (EM) Locks as well as standard Access Control Readers and Accessories. Should AC power fail, the internal 12 Volt, 7AH battery will power the panel, readers, locks and accessories for up to four hours, assuming normal operating conditions.

## INSTALLATION

Only qualified service personnel familiar with all local building codes should attempt this installation. Take appropriate safeguards to avoid unintentional operation by employees and maintenance personnel working about the premises.

The installation of each Super Two system should be completed and tested on its own before connecting into a network. Any possible wiring or installation problems are magnified many times by the complexity of the network.




Once an individual panel has been tested and found operating satisfactorily, it can then be safely brought into the network.




The Super Two is normally permanently installed with fixed wiring to meet the National Electrical Code, ANSI/NFPA 70. A Line Cord and Plug are connected to provide convenient product set-up and checkout. If a plug-in mains connection is used, the flexible cord must be clamped as shown in Power Connections , Page 15. The unit must not be plugged into an outlet that is controlled by a switch.

The following warnings are designed for the safety of the Super Two install/service technician and for the continued proper function of the Super Two unit.

### About This Manual

This manual describes the installation of the Super Two Access Control Unit and the specific accessories that connect to it.

<p><b>NOTES:</b></p>	<p>Notes are included with a procedure informing the installer about related material.</p>
<p><b>CAUTION</b></p> 	<p>Cautions indicate that a particular process requires special attention.</p>
<p><b>WARNING</b></p> 	<p>Warnings indicate that a particular process exposes the installer to live circuits or that making wrong connections can lead to equipment failure.</p>
<p><b>CAUTION</b></p> 	<p>Do not place accessory circuit cables in the same conduit sections containing power cables.</p>

<p><b>CAUTION</b></p> 	<p>Prevent the risk of a fire by replacing ALL fuses with the same type and rating. The main fuse protects the power supply circuit against excessive currents and short circuits. Failure of the power supply (other than a blown fuse) fuse usually indicates a fault in a power supply component. There are no user-serviceable parts in the Super Two cabinet. The power supply must be replaced if it fails.</p>
<p><b>WARNING</b></p> 	<p>The lower part of the power supply has exposed terminals and components (see page 10). DO NOT probe the power supply and expose yourself to high voltage and a shock hazard.</p>
<p><b>WARNING</b></p> 	<p>The risk of a serious electrical shock exists if the wiring harness power connector is removed from the Super Two circuit board, but AC power remains live at the AC Input Terminal Block (see Figure 7, page 15).</p>

## INSTALLATION

### Installation Preparation

First, select a mounting location within a secure, limited access area (see Figure 3). Note the type of wall construction that the enclosure will be secured to.

- Determine that adequate space is available for mounting the Super Two cabinet on a wall with no interference from wires, pipes, or other obstructions.
- Proper installation of the Super Two cabinet requires an area of free space measuring:

20 inches high (508mm)  
X  
20 inches wide (508mm)  
X  
4.0 inches deep (101.6mm)

- Confirm that adequate free space exists on both sides of the Super Two cabinet for cabling conduit entering and

exiting the cabinet.

- Determine the directions of the cabling conduit exiting the Super Two cabinet. Confirm sufficient access to ceilings and/or walls before fitting the conduit lengths.
- Knockouts at the back of the unit may be used for "hidden wiring" installations.

**NOTE:** All Super Two signal wiring and accessory power circuits are certified as power limited. The use of conduit is optional for these circuits.




Figure 3 - Super Two Installation Location

### Cabinet Mounting

Inspect the mounting surface around the proposed installation site. The mounting surface must be capable of supporting 14 pounds (6.3Kg) plus any additional weight of the installation hardware.



**CAUTION**  
Use only suitable mounting hardware for the type of wall construction encountered.

1. Determine the Super Two cabinet mounting location.
2. Mark the four mounting holes against the mounting surface using the Super Two cabinet as a template or using the measurements provided in Figure 4.

**NOTE: Mark the small oval portion of the cabinet screw holes (see Figure 5, Detail A and B).**

3. Place the Super Two cabinet out of the way.
4. Drill pilot holes to the required depth and size for the mounting screws.
5. Insert the top two mounting screws into the wall. Leave approximately one quarter of the screw's length protruding from the wall.

**NOTE: Do not tighten screws completely at this time.**

6. Place the Super Two cabinet over the mounting screws.

Secure the Super Two cabinet to the mounting surface using the two lower screws, and then tighten the remaining length of the screws.




Figure 4 - Super Two Cabinet Mounting Hole Dimensions




Figure 5 - Super Two Mounting Screws

### Cable Routing

All associated cabling for the Super Two is divided into two categories:


- **Power Cables and Accessory Relay Devices**  
This category contains all the power cables servicing the Super Two and any accessory relay controlled devices connected to it.
- **Communication Cables**  
This category contains all the communication cabling between the Super Two and all communication devices, all alarm devices, and all card reader devices.



**NOTE:** For proper operation of the Super Two, route EACH category of cabling in SEPARATE conduit (i.e., **DO NOT mix alarm and communication cables in the same conduit as relay and power cables**).

### Incoming Power Conduit Knockout

The Super Two System requires 120VAC, 60 Hz voltage to the AC Input Power Terminal Block (see page 15). The power cabling is delivered to the Super Two through a knockout located on the lower center of the left side cabinet wall (see Figure 6). The 3/4 inch knockout accepts EIA standard conduit connectors.



**NOTE:** All wiring must conform to National Electric Code (NEC), NFPA 70, as well as any local building codes.

### Accessory Conduit Knockouts

All cabling for the Super Two is routed through EIA standard 3/4-inch knockouts located on the left and right sides of the cabinet (see Figure 6). On the top of the enclosure, three-size knockouts are available.

### Grounding Accessory Drain and Shield Wires

Ensure electromagnetic compatibility and reliable performance by keeping all accessory drain and shield wires as short as possible.

All accessory drain and shield wires connect to ground posts mounted along the knockout strips on both sides of the Super Two cabinet (see Figure 6).

The following procedures assure proper installation of all drain and shield wires.

- Carefully remove the cable jacket after the cable enters the Super Two cabinet.
- Place the drain wires under the ground post screw. Trim as needed.
- Verify a good connection and tighten the ground post screw.
- Connect the accessory wires to the appropriate terminal strip on the Super Two circuit board.




Figure 6 - Cabling Conduit Knockouts

## POWER CONNECTIONS

### AC Power Source Grounding

The Super Two main circuit board has built-in surge suppression devices. The surge suppressors require a good earth ground connection to operate effectively.

### AC Power

The incoming AC source voltage connects to the AC Input Power Terminal Block located in the lower middle of the Super Two cabinet (see Figure 7).

Run the AC power wiring through a knockout normally hidden by the insulation cover. Do not place any other wiring in this area.

After the wiring is completed, use a cable-tie to secure the wires to the cable-tie mount (provided) located below the AC Input Power Terminal Block.



**NOTE:** Use of a dedicated, unswitched AC power source results in optimal performance with minimum interference.



### WARNING

Verify that the AC source voltage is switched off at the breaker panel before proceeding with connections.

Table 1 lists the incoming AC source voltage connections to the AC Input Power Terminal Block.

**NOTE:** Knockouts for conduit Fittings are located on the back of the metal housing and can be used if "hidden cable" installation is required.

**IMPORTANT SAFETY REQUIREMENT:** If the enclosure door is removed, the Ground Strap may be unbolting—but MUST be REATTACHED after installation or service is completed.

### Backup Battery Installation

1. Place the backup battery (P/N CI-HE0042) into to the lower right of the cabinet with the terminals on the right side.
2. Push the terminal of the BLACK lead onto the NEGATIVE (Black) Tab of the battery.
3. Push the terminal of the RED lead onto the POSITIVE (Red) Tab of the battery.

**NOTE:** Because of the Low Battery Voltage Disconnect feature, the Super Two will not start to operate until mains (AC) power is connected.

Incoming AC	Wire Color	AC Input Terminal Block
Line	Black	L
Neutral	White	N
Ground	Green	⏏




Figure 7 - AC Input Power Terminal Block

# POWER CONNECTIONS

## Super Two Circuit Board Layout

The Super Two circuit board (see Figure 8) provides wiring terminal strips for external access control devices (card readers, keypads, alarms, etc.).

The following descriptions in this manual reference the Super Two main circuit board, shown below, and use cutaway drawings to identify specific locations on the circuit board.




Figure 8 - Super Two Circuit Board Layout



## DOOR CONNECTIONS

Inputs from Card Readers, Keypad/Card Readers and Door Alarms connect to the Super Two via the two terminal strips on the right of the board labeled RDR1 and RDR2.

### Wiegand/Proximity Reader Connections

Table 2 below lists the connections between the RDR1 and RDR2 terminal strips and the Wiegand/Proximity Readers.

\* Proximity Reader may be powered by either +5VDC or +12VDC, set by jumper.

RDRx Terminal Strip Pin	Function	Wire Color
PWR	+5VDC/+12VDC	Red *
GND	Ground	Black
LED	LED	Brown
D1	Data-1	White
D0	Data-0	Green
*Jumper Selectable. +12VDC Normally preferred for Proximity Readers.		

### Wiegand/Proximity Reader Cable Requirements

Wiegand/Proximity Readers require a 5-conductor cable between the Super Two and the particular unit (see Figure 9).

**Do not use twisted pair cable.**

**NOTE:** Readers may have a maximum current draw of 200mA each at +12VDC, or a total current draw of 200mA if +5VDC Reader Power is selected.

**EXAMPLE:** If two identical +5VDC Readers are connected to one Super Two, each Reader could draw up to 100mA.

Table 3 lists the cable gauge-vs-length requirements for proper operation of the Super Two and a Wiegand/Proximity Reader.

Unit	Distance (maximum)	Wire Gauge
Wiegand Reader	500ft/153m	22AWG Shielded w/drain
Proximity Reader**	500ft/153m	22AWG Shielded w/drain
**500ft/153m maximum for unbuffered Wiegand units.		



**CAUTION**  
Keep all drain and cable shield wires between the Super Two and any Wiegand/Proximity Readers short. Connect drain and cable shield wires to the ground posts located on both sides of Super Two cabinet. **DO NOT** ground drain wires and cable shields at any other point.

# DOOR CONNECTIONS




Figure 9 - Wiegand/Proximity Reader Connection to Super Two Board

### Magnetic Stripe Reader Connection

Magnetic Stripe Readers connect to terminal strips RDR1 and RDR2 (see Figure 10). Terminal strips RDR1 and RDR2 follow the same connection procedures.

Table 4 lists the connections between the RDR1 and RDR2 terminal strips and the Magnetic Stripe Reader.

DRx Terminal Strip Pin	Function
PWR (Red)	+5VDC/12VDC (Red)
GND (Black)	Ground (Black)
LED (Brown)	LED <sup>1</sup> (Yellow)
D1 (White)	Data-1/DAT (Blue)
D0 (Green)	Data-0/CLK (Green)

Note 1: If the Magstripe Reader does not feature an LED indicator, 4-conductor cable may be used.

### Magnetic Stripe Reader Cable Requirements

Magnetic Stripe Readers require a 5-conductor cable between the Super Two and the particular unit (see Figure 10). **Do not use twisted pair cable.**

Table 5 lists the cable gauge-vs-length requirements for proper operation of the Super Two and Magnetic Stripe Readers.

Unit	Distance	Wire Gauge
Magnetic Stripe Reader	(maximum) 500ft/153m	22AWG Shielded w/drain

### CAUTION



Keep all drain wires between the Super Two and Magnetic Stripe Readers short. Connect drain wires to the ground posts located on both sides of Super Two cabinet. **DO NOT** ground drain wires and cable shields at any other point.




Figure 10 - Magnetic Stripe Reader Connection to Super Two Board

**DOOR CONNECTIONS**

**Keypad Connection**

**Wiegand-Output Card and Keypad Readers -**

The preferred connection for “Card and Keypad” installations is the use of a Wiegand – Output Reader/Keypad such as the HID 5355AGK00 or 5355ABK00. These products eliminate the cost of additional wiring, and require no addition Interface Equipment. Compatible equipment produce the following codes for Keypad entries:

0 = 0000	4 = 0100	8 = 1000
1 = 0001	5 = 0101	9 = 0101
2 = 0010	6 = 0110	* = 1010
3 = 0011	7 = 0111	# = 1011

**NOTE:** Wiegand-output Keypads may simply be connected to the Card Reader inputs at DR1 and DR2 for “Keypad Only” connections.

**X-Y Matrix Keypads**

If traditional twelve-position keypads must be used, these may be wired to the optional Super Two X-Y Matrix Keypad Board . Connect the wiring to terminal strips KP1 and KP2 (see Figure 11). Terminal strips KP1 and KP2 follow the same connection procedures.

Table 6 lists the connections between the KP1 and KP2 terminal strips and the keypad.

KPx Terminal Strip		
Pin #	Function	Wire Color
R1	Row 1	Brown
R2	Row 2	Red
R3	Row 3	Orange
R4	Row 4	Yellow
C1	Column 1	Green
C2	Column 2	Blue
C3	Column 3	Violet

**Keypad Cable Requirements**

Keypads require a 22AWG, 7-conductor, stranded, shielded, cable with drain wire between the Super Two and the particular unit (see Figure 11). **Do not use twisted pair cable.**

Table 7 lists the cable gauge-vs-length requirements for proper operation of the Super Two and the Keypad.

Unit	Distance	Wire Gauge
Magnetic Stripe Reader	(maximum) 500ft/153m	22AWG Shielded w/drain

**CAUTION**



**Keep all drain wires short. Connect drain wires to the ground posts located on both sides of Super Two cabinet. DO NOT ground drain wires and cable shields at any other point.**




Figure 11 - Keypad Connection to Super Two Board

### Door Status Sensor Connection

Door Status sensors connect to the Super Two through two terminal strips labeled RDR1 and RDR2 (see Figure 12).

Table 8 lists the connections between the RDR1 and RDR2 terminal strips and the Door Status sensor.

RDRx Terminal Strip Pin	Signal	Door Status Sensor Function
DS	Alarm	Positive
RT	Return	Negative

### Door Status Sensor Cable Requirements

Door Status sensors require a 22AWG, 2-conductor, stranded, shielded, cable with drain wire between the Super Two and the particular unit (see Figure 12).

Table 9 lists the cable gauge-vs-length requirements for proper operation of the Super Two and the Door Status sensor.

NOTES: Refer to page 26, Alarm Connections, to configure Door Status sensors as supervised alarms.

Unit	Distance	Wire Gauge
Door Status Sensor	500ft/153m	22AWG Shielded w/ drain



#### CAUTION

Keep all drain wires short. Connect drain wires to the ground posts located on both sides of Super Two cabinet. DO NOT ground drain wires and cable shields at any other point.




Figure 12 - Door Status Sensor to Super Two Connections. Plain (Unsupervised) Contacts, and Supervised Contacts

## DOOR CONNECTIONS

### Request-to-Exit (Bypass) Sensor Connection

Request-to-Exit sensors (also known as Bypass sensors) work in conjunction with Door Status Sensors to provide complete facility entry and exit control. The Request-to-Exit sensor input connects to the same Super Two terminal strip (RDR1 and RDR2) that the associated Door Status Sensor connects to (see Figure 13).

Table 10 lists the connections between the RDR1 and RDR2 terminal strips and the associated Request-to-Exit sensor.

DRx Terminal Strip Pin #	Signal	Request-to-Exit Sensor Function
REX	Alarm	Positive
RT	Return	Negative

### Request-to-Exit Sensor Cable Requirements

Request-to-Exit sensors require a 22AWG, 2-conductor, stranded, shielded, cable with drain wire between the Super Two and the particular unit (see Figure 13).

Table 11 lists the cable gauge-vs-length requirements for proper operation of the Super Two and the Request-to-Exit sensor.

Unit	Distance (maximum)	Wire Gauge
Request-to-Exit Sensor	500ft/153m	22AWG Shielded w/ drain



#### CAUTION

Keep all drain wires short. Connect drain wires to the ground posts located on both sides of Super Two cabinet. DO NOT ground drain wires and cable shields at any other point.




Figure 13 - Request-to-Exit Sensor to Super Two Connections. Plain (Unsupervised) Contacts, and Supervised Contacts

## RELAY CONNECTIONS

### Description

The Super Two provides five Form C relays to control door strikes, door alarm shunts, console functions, etc.

The relays are divided into three categories: Door Strike Relays, Auxiliary Relays, and Console Relay

### Door Strike Relays

Two relays are designated as door strike relays and work in conjunction with Wiegand/Proximity readers, Magnetic Stripe readers and Keypad to control access at particular door sites.

The door strike relays, labeled STK1 and STK2, are located on the bottom of the Super Two Circuit Board (see Figure 14).

The door strike relay circuits are rated 2A at 28V AC/DC.

### Auxiliary Relays

Two relays are designated as Auxiliary Relays are typically used to control door alarm shunts.

The Auxiliary Relays are user-programmable and may be used for low-voltage control functions.

The Auxiliary Relays outputs, labeled AUX1 and AUX2 are located on the bottom of Super Two Circuit Board (see Figure 14).

### Console Relay

The Console Relay activation may be linked to specific events such as invalid door access, alarm input, and tamper switch input. The console relay is linked to an event through software.

The console relay output is labeled CONSOLE and is located on the far right hand side of the relay terminal strips on the Super Two Circuit Board (see Figure 14).

### Relay Characteristics

The relays on the Super Two Circuit Board all share the following characteristics:

Form C relay with a contact rating of 2A at 28V AC/DC.

The Normally Open (NO), and the Normally Closed (NC) contacts are the default state of non-energized relays.

Metal oxide varistors (MOVs) are placed across the contacts to reduce electrical noise. The MOVs limit any noise caused by the strike coil to 56 volts.

**NOTES:** Installing a 56V MOV at the strike coil further reduces possible noise input.

Additional MOVs are available from Continental Instruments as part number R783R.

Because of this noise, door strike wiring **MUST NOT** be put in the same conduit with other wiring.

Using door strikes with a coil voltage greater than 28VDC or 24VAC requires using external relays that can be driven by Super Two relays.




Figure 14 - Relay Contact and Accessory Power Outputs

## RELAY CONNECTIONS

### Powering Electromagnetic (EM) Locks

Sufficient Battery-Backed 12-Volt DC Power is available to power the Super Two Circuit Board, two Access Control Readers, the Network Interface Adapter, and two modern EM Locks.

After a Power Failure, the installed 7AH Battery can be expected to keep the system operating for two hours (under normal conditions).

If two EM Locks used each consume 400mA or less, operation under backup power can be expected to last four or more hours.

### Fire Alarm Control Panel (FACP) Connection

Emergency Disconnect of the Fail-Safe EM Lock Power can be accomplished as shown for the STK2 Circuit in Figure 15.




Figure 15 - Fire Alarm Control Panel (FACP) Connection



## ACCESSORY POWER

The ACCESSORY POWER terminal strip (labeled 12V OUT) provides battery backed +12VDC power outlets for auxiliary devices. This terminal strip is located in the lower right-hand corner of the Super Two circuit board.

Table 12 lists the ACC. POWER terminal strip pin numbers and their associated functions.

<b>Table 12 - ACCESSORY POWER (12_V) Terminal Strip Functions</b>	
Pin	Function
1	+12
2	GND
3	+12
4	GND
5	+12
6	GND

**NOTE:** +12VDC current draw is limited to a total maximum of 1.60 Amps.



**WARNING**

Observe Positive and Negative wire polarity between accessory devices and the Super Two.

## ALARM CONNECTION

### ALARM CONNECTION

The Super Two has a total of 8 supervised alarm inputs. Four alarm inputs are located on the RDR1 and RDR2 terminal strips, and are used for Request-to-Exit and Door Status sensor functions (see pages 21 and 22).

An additional four accessory alarm inputs are located on the Accessory ALARM terminal strip located on the lower left corner of the Super Two circuit board (see Figures 25 and 26). These alarm inputs may be used for dry contact type inputs (unsupervised) or supervised alarms.

### Supervised Alarms

Supervised alarms provide monitoring of alarm inputs for fault or tamper conditions. Two additional alarm states may be detected by installing two-1K Ohm resistors near the alarm contacts.

In addition to the standard Normal and Abnormal alarm conditions, the supervised alarms report Line Open and Line Short conditions.

- A Line **Open** condition is the result of a cut wire.
- A Line **Short** condition is the result of a short in the alarm wiring.

These fault conditions may be the result of tampering, and indicate the system cannot correctly detect the state of the alarm contacts.

### Configuring an Alarm in the Supervised Condition

- 1) Use two 1K Ohm, 1/4W,  $\pm 5\%$  carbon film resistors per alarm.

- 2) Install R 1 in parallel with the alarm contacts (see Figure 16).
  - 3) Install R2 in series with the alarm input conductor.
- NOTE:** For maximum protection, install the resistors close to the alarm contacts and embed them in epoxy.

Pin	Signal
1	AL 5
2	RT 5
3	AL6
4	RT6
5	AL 7
6	RT7
7	AL8
8	RT8

Table 13 lists the ALARM terminal strip pin numbers and the respective signals.

### Alarm Cable Requirements

Connecting alarm sensors to the Super Two board requires 22 AWG, stranded, shielded, cables with drain wires.



#### CAUTION

Keep all drain wires short. Connect drain wires to the ground posts located on both sides of Super Two cabinet. DO NOT ground drain wires at any other point.

### Tamper Switch

The Super Two cabinet has a built-in tamper switch. The tamper switch is factory wired and requires no adjustment.




Figure 16 - ALARM Terminal Strip - Unsupervised and Supervised Alarm Connections

### RS-232 Communications - Host/Modem Operation

Operating as a stand-alone system, the Super Two communicates with a host computer (directly, through a modem, or through the optional Ethernet Network Interface) through the RS-232 channel.

Proper RS-232 communications requires observing the EIA standard pin definitions of Data Terminal Equipment (DTE) and Data Control Equipment (DCE).

**NOTE:** All RS-232 equipment made by Continental Instruments Corporation, including the Super Two, are configured as DTE devices.

### RS-232 Cable Requirements

RS-232 communication between the Super Two and a host computer/modem require stranded, 3 conductor, 22 AWG cable with shielding and a drain wire. **Do not use twisted pair cable.**

Table 14 displays the cable gauge and length requirements for proper operation of the Super Two and the host computer/modem.

Unit	Distance	Wire Gauge
Host Computer/Modem	50ft (15.2m) (Maximum)	22AWG

**NOTES:** A host computer is typically connected to the RS-232 cable using either a DB9-S or a DB25-S connector.

Modems are typically connected to the RS-232 cable using a DB25-P connector.

### RS-232 Jumper Settings

RS-232 communications between the Super Two and a host computer require setting the MD/RPT and EOL jumpers on the Super Two board. Refer to page 38, EOL and MD/RPT Jumper Settings, for specific information.

**NOTE:** Operating as a stand-alone system, the Super Two must be configured in the REPEAT mode.

### Address Setting

Operating the Super Two on the RS-232 channel requires setting a board address (Address Zero not valid) on the small rotary switches marked ADDRESS (S2 and S3). Refer to page 29, Network Address Settings for specific information.

### Super Two to Host Computer/Modem Connection

Figure 17 shows a direct Super Two-to-host computer connection.

Figure 18 shows a Super Two-to-host computer connection through a modem.

**NOTE:** Set the Modem jumper to the right when using a modem.

- 1) Connect the Transmit pin of the RS-232 device to COMM terminal strip pin number 5 (labeled RxD) (See Figure 18).
- 2) Connect the Receive pin of the RS-232 device to COMM terminal strip pin number 4 (labeled TxD).
- 3) Connect the Ground pin of the RS-232 device to COMM terminal strip pin number 6 (labeled GND).
- 4) Connect the RS-232 cabling drain wire/shield to GROUND at the host computer/modem end of the cable. Do Not connect the drain wire at the Super Two end of the cable.

Table 15 lists the connections between the COMM terminal strip and a host computer.

Signal	Super Two COMM Pin #	Host Computer DB9-S pin
TXD	4	2
RXD	5	3
GND	6	5

Table 16 lists the connections between the Super Two COMM terminal strip and a modem.

Signal	Super Two COMM Pin #	Modem DB25-P
TXD	4	2
RXD	5	3
GND	6	7

# COMMUNICATION CONNECTIONS




Figure 17 - Super Two-to-Host Computer Connection




Figure 18 - Super Two-to-Modem-to-Computer Connection

## Networking

The Super Two can be networked with a maximum of 62 other Super Two units or other Continental Instruments access control devices (Superterm, Turbo Superterm, Smarterm, Miniterm and Microterm).

**NOTE:** Multidrop networks require line drivers if more than 32 Super Two Panels are configured.

The following network configurations are possible:

### RS-232 to RS-422 Networks

- RS-232 to RS-422 REPEAT Networks
- RS-232 to RS-422 MULTIDROP Networks

### RS-422 to RS-422 Networks

- RS-422 to RS-422 REPEAT Networks
- RS-422 to RS-422 MULTIDROP Networks

**NOTES:** If the first Super Two in the network is less than 50 feet (15.2m) from the host computer, the first Super Two in the network may be used to convert the RS-232 polling signal to RS-422 for the remainder of the network.

If the first Super Two in the network is more than 50 feet (15.2m) from the host computer, an RS-422 polling line converter is required (CICE1941).

## Network Jumper Settings

The MD/RPT and EOL jumpers on each Super Two must be set depending on the type of network configuration.

Refer to page 38 for specific information regarding the EOL jumper. Also refer to page 38 for specific information regarding the MD/RPT jumper.

## Network Cable Requirements

Networking multiple Super Two panels requires 4-conductor cable (2-two wire twisted pair), stranded, 22AWG, with shielding, and drain wire.

For REPEAT network configurations, cable length between EACH Super Two is restricted to a maximum length of 4000 feet (1220m).

For MULTIDROP network configurations, total cable length is restricted to a maximum 4000 feet (1220m) between the FIRST Super Two and the LAST Super Two in the network.

## Network Address Settings

Operating the Super Two with a host computer, or in a network, requires that each Super Two (and other devices) have an individual, unique address other than zero.




Figure 19a – Setting Network Address

The BCD Rotary Switches are set with a small screwdriver. There is a click detent for each number. The valid address range is “01” to “63”. (Address “00” is not valid). See "Clear Memory and Force Download to Panel" on page 43.




Figure 19 - Super Two Address Switch (S2 & S3) Location

## COMMUNICATION CONNECTIONS

### RS-232 to RS-422 REPEAT Network

If the first Super Two in the network is less than 50 feet (15.2m) from the host computer, it may be used to convert the RS-232 polling signal from the host to RS-422 for the remainder of the network.

1. Connect the first Super Two to the RS-232 port of the host computer.
2. Connect the remainder of the network using the Super Two's RS-422 ports.

Refer to Figure 20, page 31, for a typical REPEAT mode network connection diagram.

Table 17 lists the required connections for an RS-232 to RS-422 REPEAT network.

### RS-232 to RS-422 REPEAT Jumper Settings

To convert an RS-232 signal to an RS-422 signal, the first Super Two unit in the network must be in REPEAT mode.

Operating a Super Two network in the REPEAT mode requires setting the MD/RPT and EOL jumpers.

Refer to page 38 for information regarding setting the MD/RPT jumper and for information regarding setting the EOL jumper.


### RS-232 to RS-422 REPEAT Ground and Drain Cables

The drain wires for all RS-422 cables in the network must be grounded to the individual Super Two's Cabinet Ground Post (see Figure 20). Ground RS-422 cables at the end closest to the host computer.

**NOTE:** Ground the drain wire for the RS-232 cables at the host computer end of the cable.

**Table 17 - RS-232 to RS-422 REPEAT Network Connections**

Host Computer	Super Two #1	Super Two #2	Super Two 3#	Super Two #4	to next Super Two
	MODE1 Jumper = REPEAT EOL jumper = IN	MODE1 Jumper = REPEAT EOL jumper = IN	MODE1 Jumper = REPEAT EOL jumper = IN	MODE1 Jumper = REPEAT EOL jumper = IN	MODE1 Jumper = REPEAT EOL jumper = IN
Signal	Connector	Connector	Connector	Connector	Connector
RS-232 RXD RS-232 TXD RS-232 GND	TXD RXD GND				
	RT+ RT- RR+ RR-	MR+ MR- MT+ MT-			
		RT+ RT- RR+ RR-	MR+ MR- MT+ MT-		
			RT+ RT- RR+ RR-	MR+ MR- MT+ MT-	>>>> >>>> >>>> >>>>



**First Network Super Two**  
 REPEAT Mode  
 MD/RPT Jumper = RPT pins 2 and 3)  
 EOL Jumper - IN

**Second Network Super Two**  
 REPEAT Mode  
 MD/RPT Jumper = RPT (pins 2 and 3)  
 EOL Jumper = IN

**Third Network Super Two**  
 REPEAT Mode  
 MD/RPT Jumper = RPT (pins 2 and 3)  
 EOL Jumper = IN

Figure 20 - Super Two RS-232 to RS-422 REPEAT Network Connection

## COMMUNICATION CONNECTIONS

### RS-232 to RS-422 MULTIDROP Network

Figure 21 shows the required connections for an RS-232 to RS-422 MULTIDROP network.

- Connect the first Super Two to the RS-232 port of the host computer.
- Connect the remainder of the network using the Super Two's RS-422 ports.

**NOTE:** Thirty-two (32) Super Two panels may be installed in a Multidrop network.

Table 18 lists the required connections for an RS-232 to RS-422 MULTIDROP network.

### RS-232 to RS-422 MULTIDROP Network Ground and Drain Wires

The drain wires for all RS-422 cables in a MULTIDROP network must be connected together (isolated from the cabinet ground) and connected only to the ground post at the FIRST Super Two in the network (the Super Two unit CLOSEST to the host computer).

### RS-232 to RS-422 MULTIDROP Network Jumper Setting

Operating a Super Two network in the MULTIDROP mode requires setting the MD/RPT and EOL jumpers.

Refer to page 38 for information regarding setting the MD/RPT jumper, and for information regarding setting the EOL jumper.

Table 18- RS-232 to RS-422 MULTIDROP Network Connections

Host Computer	Super Two #1	Super Two #2	Super Two 3#	Super Two 4#	Last Super Two
	MD/RPT Jumper=RPT EOL Jumper = IN	MD/RPT Jumper=MD EOL Jumper = OUT	MD/RPT Jumper=MD EOL Jumper = OUT	MD/RPT Jumper=MD EOL Jumper = OUT	MD/RPT Jumper=MD EOL Jumper = IN
<b>Signal</b>	<b>Connector</b>	<b>Connector</b>	<b>Connector</b>	<b>Connector</b>	<b>Connector</b>
RS-232 RXD RS-232 TXD RS-232 GND	TXD RXD GND				
	RT+ RT- RR+ RR-	MR+ MR- MT+ MT-	MR+ MR- MT+ MT-	MR+ MR- MT+ MT-	>>>>MR+ >>>>MR- >>>>MT+ >>>>MT-






Figure 21 - Super Two RS-232 -to- RS-422 MULTIDROP Network Connection

## COMMUNICATION CONNECTIONS

### RS-422 to RS-422 REPEAT Network

If the first Super Two in a network is more than 50 feet (15.2m) from the host computer, the polling line from the host computer must use RS-422 standards.

A Continental Instruments RS-422 Polling Line Converter (P/N CICE1942) may be used at the host computer to convert RS-232 to RS-422.

Figure 22, page 35 shows the required connections for an RS-422-to-RS-422 REPEAT network.

Table 19 lists the necessary connections between:

A host computer and the first Super Two in the network, and

The first Super Two in the network and the remaining Super Two Panels (63 maximum) in a network.

### RS-422 to RS-422 REPEAT Network Jumper Settings

Operating a Super Two network in the REPEAT mode requires setting the MD/RPT jumper and the EOL jumper.

Refer to page 38 for information regarding setting the MD/RPT jumper, and for information regarding setting the EOL jumper.

### RS-422 to RS-422 REPEAT Network Ground and Drain Cables

Ground the drain wires for all RS-422 cables in the network at each individual Super Two in the network.

**Table 19 - RS-422 to RS-422 REPEAT Network Connections**

Host Computer	Super Two #1	Super Two #2	Super Two 3#	Super Two #4	to next Super Two
	MD/RPT Jumper=RPT EOL Jumper =IN	MD/RPT Jumper=RPT EOL Jumper =IN	MD/RPT Jumper=RPT EOL Jumper =IN	MD/RPT Jumper=RPT EOL Jumper =IN	MD/RPT Jumper=RPT EOL Jumper =IN
Polling Line Connector Signal	Connector/Pin	Connector/Pin	Connector/Pin	Connector/Pin	Connector/Pin
RS-422 TXD+ RS-422 TXD- RS-422 RXD+ RS-422 RXD-	MR+ MR- MT+ MT-				
	RT+ RT- RR+ RR-	MR+ MR- MT+ MT-			
		RT+ RT- RR+ RR-	MR+ MR- MT+ MT-		
			RT+ RT- RR+ RR-	MR+ MR- MT+ MT-	>>>> >>>> >>>> >>>>




Figure 22 - Super Two RS-422 to RS-422 REPEAT Network Connection

## COMMUNICATION CONNECTIONS

### RS-422 to RS-422 MULTIDROP Network

Figure 23 shows the required connections for an RS-422-to-RS-422 MULTIDROP network.

Table 20 lists the necessary connections between:

- A host computer and the first Super Two in the network, and
- The first Super Two in the network and the following Super Two Panels in a network.

**NOTE:** Thirty-two (32) Super Two panels may be installed in a Multidrop network.

### RS-422 to RS-422 MULTIDROP Network Jumper Settings

Operating a Super Two network in the MULTIDROP mode requires setting the MD/RPT and EOL jumpers.

Refer to page 38 for information regarding setting the MD/RPT jumper, and for information regarding setting the EOL jumper.

### RS-422 to RS-422 MULTIDROP Network Ground and Drain Cables

Ground the drain wires for all RS-422 cables in the network to the Super Two ground posts.

**NOTE:** Connect all drain wires together starting at the LAST Super Two in the network and working toward the FIRST Super Two in the network.

Connect the drain wire from the FIRST Super Two in the network to the drain wire at the Polling Line Converter (see Figure 23).

Connect the drain wire from the Polling Line Converter to the ground at the rear of the host computer.

**Table 20 - RS-422 to RS-422 MULTIDROP Network Connections**

Host Computer	Super Two #1	Super Two #2	Super Two 3#	Super Two #4	Last Super Two
	MD/RPT Jumper=MD EOL Jumper = OUT	MD/RPT Jumper=MD EOL Jumper = OUT	MD/RPT Jumper=MD EOL Jumper = OUT	MD/RPT Jumper=MD EOL Jumper = OUT	MD/RPT Jumper=MD EOL Jumper = IN
Signal	Connector	Connector	Connector	Connector	Connector
RS-422 TXD+ RS-422 TXD- RS-422 RXD+ RS-422 RXD-	MR+ MR- MT+ MT-	MR+ MR- MT+ MT-	MR+ MR- MT+ MT-	MR+ MR- MT+ MT-	>>>>MR+ >>>>MR- >>>>MT+ >>>>MT-




Figure 23- RS-422 to RS-422 MULTIDROP Network Connection

## JUMPER SETTINGS

### JUMPER SETTINGS

The Super Two circuit board functions with a variety of options. Proper circuit operation requires setting specific jumpers depending on the installed access control accessories, the installed system options, and any network configurations.

#### EOL Jumper

When operating multiple Super Two units in a MULTIDROP RS-422 network, the EOL jumper on the LAST unit in the communication network must be set to the TERMINATED position.

All other Super Two's should have the EOL jumper set to the NOT TERMINATED position.

When operating any Super Two unit in a REPEAT mode (stand-alone or part of a network), set the EOL jumper on EVERY unit to the TERMINATED position.

#### *Super Two TERMINATED*

Set the jumper to contact both pins (1 and 2--reference Figure 23a at right).

#### *Super Two NOT TERMINATED*

Remove the jumper or hang from lower pin as shown in Figure 23a.




Figure 23a- EOL Jumper

#### MD/RPT Jumper

The MD/RPT jumper is used to designate the particular Super Two as an active REPEAT or a passive MULTIDROP network member (see Figure 24).

#### *MULTIDROP Mode*

Use this mode when the Super Two is operating in the MULTIDROP mode as part of an RS-422 Multidrop network.

Set the jumper to contact the center post (pin 2) and the upper post (pin 1).

#### *REPEAT Mode*

Use this mode when the Super Two is operating in the REPEAT mode as a stand-alone system (RS-232) or a part of a REPEAT or MULTIDROP (RS-422) network.

Set the jumper to contact the center post (pin 2) and the lower post (pin 3).

**NOTE:** Stand-alone Super Two Panels must be configured in the REPEAT mode.


#### Memory Battery Activation

The Super Two contains a 3.0 volt Lithium battery (B 1) used to preserve memory in the event of a power failure. Refer to Figure 8 for board layout.

The Super Two is shipped with a paper isolator between the battery and the battery holder to prevent unnecessary drainage.

Remove the paper isolator immediately before powering up the Super Two. If the battery is not activated all user-programmed data will be lost if power is interrupted.


# MEMORY BATTERY ACTIVATION




Replace the Memory Backup Lithium Cell with the following:

- BR1225 3V Lithium Battery**
- Energizer: ECR1225
- I.E.C.: CR-1225
- NEDA: 5020LC
- Panasonic: BR1225
- Renata: CR1225


**NOTE:** When installing the new cell, use a plastic forceps, or handle the cell by its edge to avoid contaminating the conductive surfaces of the device. For battery types, see above.



## MODEM



## MD/RPT JUMPER



## EOL JUMPER




Figure 24- Memory Battery Activation and Jumper Settings

**TROUBLESHOOTING**

**LED Diagnostics**

The Super Two circuit board uses LEDs to indicate the presence of a particular voltage and RS-232 signals. Figure 25 shows the LED position on the Super Two circuit board and the individual LED functions

Table 21 - LED Diagnostic Functions		
Marking	Function	Notes
PWR	AC Power Status	AC Power connected and 12 Volt Power Supply Working
CPU	Processor Power Ind.	5 Volt Power on the PC Board
RD PWR	Reader Power	5 Volt or 12 Volt Reader Power. Brighter when 12 Volt is selected.
OK	Processor Running okay	Flashing "Heartbeat" verifies operation of CPU, Memory, etc.
RX	Receiving Host Signal	Serial Port or Ethernet Port receiving data from the Host Computer
TX	Transmitting to Host	Serial Port or Ethernet Port sending data to the Host Computer




Figure 25 - Super Two Status LED's



### Super Two Primary Fuse - 120VAC Installations (USA/Canada)



A 1 ampere (1.00A) 5x20mm slow-blow, UL approved fuse protects the Super Two primary circuit. The fuse is located on the Service Entrance Terminal Block on the bottom of the Super Two. (see Figure 26). The Fuse Holder is “shocksafe,” and may be carefully removed while the unit is powered.

1. Find the Service Entrance Terminal Block near the Bottom Middle of the enclosure.
2. Grasp the Black Fuse Holder and pull straight out.
3. Replace the fuse with a 1-ampere (1.00A) 5x20mm slow-blow, UL approved fuse.
4. Re-install the fuse holder with the new fuse.

### Super Two Primary Fuse - 230VAC Installations (European Union)



A 1/2 ampere (0.500A) time delay fuse meeting IEC standards protects the Super Two primary circuit. The fuse is located on the Service Entrance Terminal Block on the bottom of the Super Two. (see Figure 26). The Fuse Holder is “shocksafe,” and may be carefully removed while the unit is powered.

1. Find the Service Entrance Terminal Block near the Bottom Middle of the enclosure.
2. Grasp the Black Fuse Holder and pull straight out.
3. Replace the fuse with a 1/2-ampere (0.500A) 5x20mm time-lag, IEC127 approval fuse.
4. Re-install the fuse holder with the new fuse.




Figure 26 - Super Two Primary Fuse Location




Figure 27 - Fuse Holder

## CIRCUIT PROTECTION

### Super Two Power Supply Fuse

A 4-ampere (4A) fast-blow fuse mounted on the lower part of the Power Supply Circuit Board, provides protection to the Power Supply from high-energy surges. If this fuse faults frequently, consider adding a UL-1449-Listed power-line surge protection device.



#### WARNING

Verify that the main AC power to the Super Two cabinet is switched OFF and locked against accidental starting.

- 1) Turn OFF the main circuit breaker controlling power to the Super Two cabinet.
- 2) Pull the insulating fishpaper cover away from the Power Supply.
- 3) Using a non-conducting fuse puller, remove the old fuse (see Figure 29).
- 4) Replace the fuse with a 4-Amp, 250V, fast-blow (not a time-lag) fuse.
- 5) Reset the main circuit breaker.

### Super Two Accessory Circuit Protection



A 0.75 Amp resettable fuse protects the Battery Charger Circuit, and a 3 Amp resettable fuse limits the output to the Accessory Circuits to safe levels. These devices limit the Accessory Current even when the product is operating under backup power from the battery.




Figure 28 - Super Two Power Supply Fuse Location

Under conditions of moderate overloads, the power supply will shut down its output, but periodically power-up briefly to test to determine if the overload is removed. This will be visible because the PWR Lamp will flash on about once per second. Power will be restored immediately upon removal of the overload condition.

### Super Two +5/+12V Reader Circuit Protection

0.25 ampere (0.25A) Resettable Fuses (RT1 and RT2) are used to limit the Reader current for RDR1 and RDR2. These are found near the RDR1 and RDR2 Terminal Blocks. A fault in the Reader Circuit may be indicated by one of these devices becoming warm to the touch.



**NOTE:** A fault in one Reader Circuit will **not** result in the other Reader Circuit losing power.

**NOTE:** Removing the cause of the over-current fault will normally restore power to the affected circuit. If power is not restored after the fault is removed, disconnect the load by removing the RDR1 or RDR2 Terminal Block for about a half-minute. The Resettable Fuse will cool, and allow power to the circuit again when the Terminal Block is plugged onto the PC Board again.




Figure 29 - Power Supply Fuse Location

## MAINTENANCE

### Power Supply Replacement

The following procedure applies after determining that the Super Two Power Supply (P/N MX1106) needs replacing.



#### WARNING

Verify that the AC source voltage is switched off at the breaker panel before proceeding with power supply replacement.

1. Open the Super Two cabinet and locate the 12VDC power supply in the lower left corner of the cabinet. Pull the insulating cover out of the way.
2. Disconnect the lower Molex connector from the power supply (one black and one white).
3. Disconnect the upper 6-pin Molex connector from the power supply.
4. Remove the four 6-32 screws securing the power supply bracket to the Super Two cabinet.
5. Remove the power supply from the Super Two cabinet.
6. Install the new power supply in the reverse order of the removal.

### Backup Battery Replacement



#### WARNING

Verify that the AC source voltage is switched off at the breaker panel before proceeding with backup battery replacement.

1. Open the Super Two cabinet and locate the backup battery (P/N CI-HE0042) secured to the lower right of the cabinet.
2. Disconnect the RED lead from the POSITIVE terminal of the battery.
3. Disconnect the BLACK lead from the NEGATIVE terminal of the battery.
4. Remove the old battery.
5. Install the new battery in the reverse order of the removal.

**NOTE:** Because of the Low Battery Voltage Disconnect feature, the Super Two will not start to operate until mains (AC) power is connected.

### Memory Coin Cell Replacement

The Super Two is normally powered on a 24/7 schedule. If the power is to be removed to the unit for more than a few days, **please re-install the insulating paper under the Cell Clip** to de-activate the Memory Battery.

If power was removed from a Super Two unit for more than four weeks without the Memory Cell protected by the insulating paper, please replace the Memory Coin Cell, as follows:

1. Open the Super Two cabinet and locate the Memory Coin Cell on the upper-middle of the PC Board.
2. Remove the old cell by pressing backward and downward.
3. Replace the Lithium Cell with a Panasonic BR1225, Energizer ECR1225, or equivalent.
4. When installing the new cell, use plastic forceps, or handle the cell by its edge to avoid contaminating the conductive surfaces of the device.

### Clear Memory and Force Download to Panel

1. Note setting of Address switches.
2. Set Address switches to "00".
3. Press and hold the reset (RST) button for at least two seconds.
4. Set Address switches to their original settings.

Panel memory is cleared. The panel will request a new download.

## SPECIFICATIONS

SPECIFICATION	Quantity (8/4-Door)	Comments
Readers	2	Full function on or off line
Anti-Passback		Standard
Access Modes	4	Card Only, Unique PIN only, Card and PIN, Free Access
Ethernet Port	1	Optional, 10/100 Base-T
Serial Port	1	Host computer. 3 with optional auxiliary communications board.
Polling Modes	4	Dial-up (RS-232), RS-422 Multidrop and Repeat
Baud Rates	7	1200, 2400, 4800, 9600, 19.2kbps, 38.4kbps, 57.6 kbps
Keypads	2	Four-bit Wiegand keypad input is standard. Optional 3x4 Matrix Keypad Interface Board available
Relays	5	Form "C", contact rating of 2A @28VDC
Alarms	8	Supervised or non-supervised (host programmable)
LEDs	2	One LED output per door
Tamper Switch	1	Pre-assigned
Reader Types		Wiegand/Proximity, Magnetic Stripe, Proximity and PIN
Supply Voltage		120/230 VAC 60/50Hz
Current Draw		1.0A @ 120VAC; 0.5A@230VAC
Accessory 12V Output	3	1.6A for Readers, Locks, and Accessories. Battery Backed.
Primary Battery Backup (Memory Only)		1 Month nominal at 25°C (field-replaceable)
Battery Backup		Approx. 4-6 hours. (When powering two EM locks rated 600mA each: 2 hours).
Weight		14 lbs. (with 7AH battery installed)
Enclosure Dimensions		15.75"H x 13.85"W x 3.25"D
Temperature Range Operating Storage		32-115°F (0-46°C) 32-149°F (0-65°C)
Relative Humidity		0% to 85% non-condensing
Card Capacity	20,000	Standard, expandable to 125,000
Time Schedules	128	Standard. 255 with CA3000 Host Software Release 2.1
Access Groups	1000	Standard, configurable and expandable with CA3000 Host Software Release 2.1
Holidays	50	Standard. 100 with CA3000 Host Software Release 2.1
Link Programs	64	Standard
Facility Codes	10	Standard
Transaction Buffer	1000	Standard, configurable and expandable

<b>Cables</b>	<b>AWG</b>	<b>Type *</b>	<b>Maximum Length</b>
Alarm Inputs	22 ga	Stranded, shielded, w/drain 2-conductor alarm	500 ft (153m)
Readers: Magnetic Stripe & Wiegand/Proximity	22 ga	Stranded, shielded, w/drain 4 or 5-conductor (5-conductor for readers w/ LEDs)	500 ft 500 ft w/unbuffered Wiegand (153m unbuffered)
Readers: Magnetic Stripe	22 ga	Stranded, shielded, w/drain 4 or 5-conductor (5-conductor for readers w/ LEDs)	500 ft (153m)
Keypad	22 ga	Stranded, shielded w/drain 7-conductor	500 ft (153m)
Polling Line RS-422 (Network)	22 ga	Stranded, shielded, w/drain 2-twisted pair	4000 ft (1220m)
RS-232, Dial-Up (Host Computer)	22 ga	Stranded, shielded, w/drain	50 ft (15m)
Relay Lock Circuits	18 ga	Stranded, shielded, w/drain	500 ft (153m)

\* **NOTE:** DO NOT use twisted pair cables for Reader, Keypad or RS232 connections.

## **POWER RATINGS**

As supplied from the factory, the Super Two contains a Power Supply that operates on 120VAC/60Hz for North America, or 230VAC/50Hz for the European Union.

Continental Instruments recommends using a dedicated, unswitched power outlet to prevent any interference from other equipment that might be connected on the same line.

<b>Voltage</b>	<b>Current (Maximum)</b>
120VAC	1.0 Amperes
230VAC	0.5 Amperes
Accessory Output- 12VDC	1.6 Amperes

**APPENDIX A**  
**2 MB MEMORY BOARD INSTALLATION**  
**INSTRUCTIONS CICP1300MB2**

1. **Remove power from the SUPER TWO®.** Inside the housing, remove the 6-pin Molex connector marked "Power In" located at the lower-right side of the panel. (see Figure A, below). Ensure that all power LED's are off.
2. **Insert paper insulator** under the clip of the Memory Battery to protect the memory board (see Figure B).
3. **Insert the white plastic "Snap" type standoff into the SUPER TWO® main board.** See Figure C. The hole into which you will insert the standoff is located just below and to right of address switches. Insert (push firmly) the small double-pronged end first until the standoff snaps securely into the hole.
4. **Place the 2MB Memory Board on to the main board,** parallel to the top, as shown in Figure D. Align

the standoff hole in the memory board with the standoff installed in step 3. Align all pins of the memory board with the JP2 connector. Press and snap in to secure.



**CAUTION: Before handling the 2MB memory board, use a grounding strap (or touch the Controller PCB metal chassis) to reduce the possibility of static discharge damaging the PCB and the memory board.**

5. **Restore power.** First restore Memory Battery by removing paper insulator (see Figure B). Next reconnect the 6-pin Molex connector marked "Power In". The "OK" LED should blink (at a rate of approximately once every second).

If you must remove the 2MB memory board, remember to push in the locking tab on the "Snap" type standoff before removal. See Figure E.




Figure A: Remove Power.




Figure B: Remove and Restore Memory Battery.




Figure C: "Snap" type standoff.




Figure D: Memory board placed on top of main board. Press in to secure.




Figure E: Push in tab to detach "Snap" type standoff if necessary.

## APPENDIX B

### NETWORK INTERFACE BOARD INSTALLATION INSTRUCTIONS CICP1300NETBD

1. **Remove power from the SUPER TWO®.** Inside the housing, remove the 6-pin Molex connector marked "Power In" located at the lower-right side of the panel. (see Figure A below). Ensure that all power LED's are off.
2. **On the Super Two main board, remove the 4-40 1/4" Phillips pan-head screw from the top left mounting hole.** Into this mounting hole, screw in the 7/16" round MF type standoff hand tight (see Figure B). **HINT:** Before installing the Network Interface Board, make a note of its MAC Address (see Figure C).
3. **Place the Network Interface board on to the main board,** at the upper left corner (parallel to the top), as shown in Figure C. Align the standoff hole in the network interface board with the standoff installed in step 2. Align all pins of the board with the J3 socket and press to insert the pins.
4. **Secure the Network Interface board.** Screw in the 4-40 1/4" Phillips pan-head screw (removed in step 2) into the standoff hole.
5. **Install Flexible shield: (Required for FCC Compliance, allows the use of Unshielded Network Cable).** Install Cable Clamp to the knockout nearest the Network Interface board on left side of metal enclosure. Insert the CAT5 or CAT6 Network UTP cable through the cable clamp, slip the 3-inch flexible shield over the cable, then plug in the CAT5 or CAT6 Network UTP cable into the Network Interface. Slide the shield so the left side is under the clamp, then gently tighten the clamp to secure the cable and shield into place. (see Figure 4 for image of finished installation).  
**NOTE:** Pull shield snugly over Ethernet cable--do not extend shield over jack--install as shown in Figure D).
6. **Restore power.** Reconnect the 6-pin Molex connector marked "Power In". The "OK" lamp should blink (at a rate of approximately once every second). An LED next to the cable socket on the Network Interface will light or blink, indicating a successful connection and/or network activity.




Figure A: Remove Power.




Figure B: 7/16" "Screw-on" type standoff.




Figure C: Network Interface board placed on top of main board. Press in to secure. Location of MAC address is shown




Figure D: Install Flexible Shield over Ethernet Cable

<b>A</b>	
AC Power Source Grounding .....	15
Accessory Circuit Protection .....	42
Accessory Conduit Knockouts.....	14
ACCESSORY POWER.....	25
Accessory Relay Devices .....	14
Alarm Cable Requirements.....	26
ALARM CONNECTION .....	26
APPENDIX A.....	46
APPENDIX B.....	47
Auxiliary Relays .....	23
<b>B</b>	
Backup Battery Replacement.....	43
Battery Backup .....	10
BCD Rotary Switches.....	29
<b>C</b>	
Cabinet Mounting .....	13
Cable Clamp .....	47
Cable Requirements.....	26
Cable Routing.....	14
Capacities .....	9, 44
Card Capacities.....	7, 44
CICP1300AUX .....	10
CICP1300MB2 .....	9, 46
CICP1300NETBD .....	10, 47
CICP1300XYBD.....	10
CIRCUIT PROTECTION.....	41
Clear Memory and Force Download to Panel.....	43
Communication Cables.....	14
Conduit Knockouts .....	14
CONFIGURATION .....	9
Console Relay.....	23
<b>D</b>	
DESCRIPTION .....	7
DISCLAIMER.....	2
DOOR CONNECTIONS.....	17
Door Status Sensor Cable Requirements .....	21
Door Status Sensor Connection .....	21
Door Strike Relays.....	23
downloadable firmware .....	9
Drain and Shield Wires.....	14
<b>E</b>	
Electromagnetic (EM) Locks.....	10, 24
EOL Jumper.....	38
EOL jumpers.....	29
Ethernet .....	10
EXPANSION BOARDS AND ACCESSORIES.....	10

<b>F</b>	
FCC Warning .....	2
Fire Alarm Control Panel (FACP) Connection.....	24
Flexible shield .....	47
Force Download to Panel .....	43
Form C relays .....	23
Fuse	
Power Supply Fuse .....	42
<b>G</b>	
Grounding.....	15
Grounding Accessory Drain and Shield Wires.....	14
<b>H</b>	
HID 5355AGK00 .....	10
Host/Modem Operation .....	27
<b>I</b>	
IEC127 .....	10
IMPORTANT SAFEGUARDS.....	3
Incoming Power Conduit Knockout .....	14
INSTALLATION .....	11
Installation Preparation.....	12
<b>J</b>	
JUMPER SETTINGS .....	38
Jumpers	
EOL Jumper.....	38
MD/RPT Jumper.....	38
<b>K</b>	
Keypad Cable Requirements .....	20
KEYPAD CONNECTION .....	20
Keypad Option Board .....	10
Knockouts.....	14
<b>L</b>	
LED Diagnostics .....	40
line drivers.....	29
Lithium Cell .....	39
<b>M</b>	
Magnetic Stripe Reader Cable Requirements.....	19
Magnetic Stripe Reader Connection.....	19
MAINTENANCE.....	43
Matrix Keypad Option Board.....	10
MD/RPT Jumper .....	38
MD/RPT jumpers .....	29
Memory Battery Activation.....	38
MEMORY BOARD INSTALLATION	
INSTRUCTIONS.....	46
Memory Coin Cell Replacement .....	43



Memory Configurations.....	9
memory expansion board.....	9
Metal oxide varistors .....	23
mounting.....	12
MOVs .....	23
MULTIDROP Networks .....	29

## N

Network Address Settings .....	29
Network Interface Board.....	10
NETWORK INTERFACE BOARD INSTALLATION INSTRUCTIONS .....	47
Network UTP cable.....	47
NETWORKING .....	29

## P

Power Cables and Accessory Relay Devices.....	14
POWER CONNECTIONS .....	15
power interruptions .....	10
POWER RATINGS .....	45
Power Supply Fuse .....	42
Power Supply Replacement.....	43
PTZ Camera Controllers .....	10

## R

Reader Circuit Protection .....	42
REGULATORY CONSIDERATIONS.....	8
Relay Characteristics .....	23
RELAY CONNECTIONS.....	23
REPEAT Networks.....	29
Request-to-Exit (Bypass) Sensor Connection.....	22
Request-to-Exit Sensor Cable Requirements.....	22
RFID Readers .....	10
RS232.....	10
RS-232 Cable Requirements.....	27
RS-232 Communications.....	27
RS-232 Jumper Settings .....	27
RS-232 to RS-422 MULTIDROP Network.....	32
RS-232 to RS-422 MULTIDROP Network Ground and Drain Wires .....	32
RS-232 to RS-422 MULTIDROP Network Jumper Setting .....	32
RS-232 to RS-422 Networks .....	29
RS-232 to RS-422 REPEAT Ground and Drain Cables.....	30
RS-232 to RS-422 REPEAT Jumper Settings .....	30
RS-232 to RS-422 REPEAT Network.....	30
RS-422 to RS-422 MULTIDROP Network.....	36
RS-422 to RS-422 MULTIDROP Network Ground and Drain Cables.....	36
RS-422 to RS-422 MULTIDROP Network Jumper Settings .....	36
RS-422 to RS-422 Networks .....	29
RS-422 to RS-422 REPEAT Network.....	34

RS-422 to RS-422 REPEAT Network Ground and Drain Cables.....	34
RS-422 to RS-422 REPEAT Network Jumper Settings .....	34
RS485 .....	10

## S

Setting Network Address.....	29
SPECIFICATIONS .....	44
Super Two Circuit Board Layout .....	16
Super Two Primary Fuse - 120VAC Installations (USA/Canada).....	41
Super Two Primary Fuse - 230VAC Installations (European Union) .....	41
Supervised Alarms.....	26

## T

Tamper Switch .....	26
transaction buffer.....	9
TROUBLESHOOTING .....	40
Two-Channel Auxiliary Communication Board.....	10

## U

UL 294.....	8
-------------	---

## V

VAC Power .....	15
-----------------	----

## W

Wiegand Output Reader/Keypad.....	10
Wiegand/Proximity Reader Cable Requirements .....	17
Wiegand/Proximity Reader Connections.....	17
Wiegand-Output Card and Keypad Readers.....	20

## X

X-Y Matrix Keypads .....	20
--------------------------	----

# NOTES

# NOTES



355 Bayview Avenue, Amityville, NY 11701  
Phone: 631-842-9400 Fax: 631-842-9135

A NAPCO SECURITY GROUP COMPANY