



SERVICE MANUAL

Valor[™] 3000 SCALES



Ohaus Corporation 19A Chapin Road, P.O. Box 2033, Pine Brook, NJ 07058-2033 (973) 377-9000



SERVICE MANUAL

Valor™ 3000 SCALES

The information contained in this manual is believed to be accurate at the time of publication, but Ohaus Corporation assumes no liability arising from the use or misuse of this material. Reproduction of this material is strictly prohibited.

Material in this manual is subject to change.

© Copyright 2009 Ohaus Corporation, all rights reserved.
TM Registered trademark of Ohaus Corporation.

TABLE OF CONTENTS

	Page No.
CHAPTER 1 GETTING STARTED	
1.1 Introduction	1-1
1.2 Service Facilities	1-1
1.3 Tools and Test Equipment Required	1-1
1.4 Specifications.....	1-2
1.5 Scale Operation	1-4
1.5.1 Overview of the Controls.....	1-4
1.5.2 Overview of the Display Indicators	1-5
1.5.3 Power On.....	1-5
1.5.4 Power Off.....	1-5
1.5.5 Menu Setup	1-5
1.6 Legal For Trade (LFT).....	1-6
1.6.1 LFT Setup Procedure.....	1-6
1.7 Menu Structure	1-7
CHAPTER 2 TROUBLESHOOTING	
2.1 Troubleshooting	2-1
2.2 Diagnostic Guide.....	2-1
2.2.1 Diagnosis.....	2-1
CHAPTER 3 MAINTENANCE PROCEDURES	
3.1 Preventive Maintenance.....	3-1
3.1.1 Preventive Maintenance Checklist	3-1
3.2 Opening the Scale.....	3-1
3.2.1 Opening Valor 3000 Standard and Washable Models	3-2
3.3 Replacing the Load Cell	3-3
3.4 Replacing the Printed Circuit Board and Display	3-4
3.5 Replacing the Housing Seals	3-5
3.6 Replacing the Function Label.....	3-6
3.7 Replacing the Plastic Insert.....	3-6
CHAPTER 4 TESTING	
4.1. Testing.....	4-1
4.1.1 Test Masses Required	4-1
4.2 Operational Test	4-1
4.3 Segment Display Test.....	4-1
4.4 Load Cell Test Using RAMP.....	4-1
4.5 Performance Tests.....	4-2
4.5.1 Precision Test.....	4-2
4.5.2 Repeatability Test	4-3
4.5.3 Linearity Test	4-5
4.5.4 Off-Center Load Test	4-5
4.5.5 Adjusting Off Center Load.....	4-6
CHAPTER 5 DRAWINGS AND PARTS LISTS	
5-1 Valor 3000 Xtreme Scales: Housing & Internal Parts	5-2
5-2 Valor 3000 Xtreme W Scales: Housing & Internal Parts	5-4

TABLE OF CONTENTS

Appendix A STANDARD CALIBRATION		Page No.
A.1	Calibration.....	A-1
Appendix B THE SERVICE MENU		
B.1	Entering the Service Menu	B-1
B.2	Ramp	B-1
B.3	Linear Calibration	B-2
B.4	Span Calibration	B-3
B.5	Geographical Adjustment Factor (GEO).....	B-4
B.6	Expanded Readability (E.PAnd)	B-5
APPENDIX C SOFTWARE SERVICE TOOL INSTRUCTIONS		
C.1	Hardware and Software Setup	C-1
C.2	Configuring the Scale (after replacing the PCB or Load Cell)	C-4
APPENDIX D GEOGRAPHICAL ADJUSTMENT VALUES		
TABLE D-1. Geographical Adjustment Values.....		D-1

LIST OF TABLES

TABLE NO.	TITLE	Page No.
1-1	Specifications	1-2
1-2	Capacity and Readability	1-3
1-3	Functions of Display Controls	1-4
1-4	Display Indicators	1-5
1-5	Valor 3000 Menu Structure	1-7
2-1	Diagnostic Guide	2-2
4-1	Calibration Mass Values	1-2
4-2	Tolerances.....	4-2
4-3	Repeatability Worksheet.....	4-4
4-4	Linearity Test Masses.....	4-5
5-1	Valor 3000 Xtreme Scales: Housing & Internal Parts	5-3
5-2	Valor 3000 Xtreme W Scales: Housing & Internal Parts.....	5-5
D-1.	Geographical Adjustment Values.....	D-1

LIST OF ILLUSTRATIONS

FIGURE NO.	TITLE	
1-1	Power Connection and Seal	1-4
1-2	Valor 3000 Xtreme & Xtreme W Displays	1-4
1-3	Valor 3000 Display Indicators	1-5
1-4	LFT/Cal Lock Switch.....	1-6
3-1	Scale Bottom	3-2
3-2	Technique for separating Top and Bottom Housing on Valor 3000	3-2
3-3	Red lock between battery compartments	3-3
3-4	Printed Circuit Board and Display	3-4
3-5	Bottom of Valor 3000 Xtreme W, with Battery Cover on.....	3-5
3-6	Seal washer for Weighing Plate	3-5
3-7	Seal washer on left-rear of PCB.....	3-5
3-8	Plastic Insert and Function Label	3-6
3-9	Plastic Insert, viewed from inside Top Housing.....	3-6
4-1	Segment Display	4-1
4-2	Scale drawing of Valor 3000 Load Cell and Weighing Pan	4-6

TABLE OF CONTENTS

TABLE NO.	TITLE	Page No.
5-1	Valor 3000 Xtreme Scales: Housing & Internal Parts	5-2
5-2	Valor 3000 Xtreme W Scales: Housing & Internal Parts.....	5-4
C-1	RS232 Interface connected to Service Interface, connected to the PCB.....	C-1
C-2	Service Interface fits into the RS232 Interface	C-1
C-3	Com Port Configuration screen with correct settings.....	C-2
C-4	Config Tool's Test Command screen	C-2
C-5	The Config Tool's Configuration Screen	C-3

TABLE OF CONTENTS

1.1 INTRODUCTION

This service manual contains the information needed to perform routine maintenance and service on the Ohaus Valor 3000 Series scales. Familiarity with the scale's Instruction Manual is assumed. The contents of this manual are contained in five chapters:

Chapter 1 Getting Started – Contains information on service facilities, tools, specifications, and the mechanical and electronic functions of the scale.

Chapter 2 Troubleshooting – Contains a diagnostic guide and error code table.

Chapter 3 Maintenance Procedures – Contains preventive maintenance procedures and disassembly, repair and replacement procedures.

Chapter 4 Testing – Contains a list of required test masses, an operational test, segment display test, performance tests and adjustments.

Chapter 5 Drawings and Parts Lists – Contains exploded views of Valor 3000 scales identifying all serviceable components.

Appendix A Standard Calibration – Explains procedures for Standard Calibration, performed prior to using a scale, and after service.

Appendix B Service Calibration – Describes the Service Menu and sub-menus, which allow authorized service personnel to perform factory Linearity and Span calibrations (no pre-set limits), take Ramp readings, adjust the GEO Factor, and use E.P.And to set the readability to 1/10th of the standard readability.





Appendix C Software Service Tool Instructions – Used to re-configure the scale after replacing a Printed Circuit Board or Load Cell.

Appendix D Geographical Adjustment Values – The chart of scale settings for every geographical latitude away from the equator (in degrees and minutes) and every elevation above sea level (in meters or feet).

1.2 SERVICE FACILITIES

To service a scale, the service area should meet the following requirements:

- Should be temperature controlled and meet scale specifications for temperature environmental requirements.
- Must be free of vibrations such as fork lift trucks close by, large motors, air currents or drafts from air conditioning/heating ducts, open windows, people walking by, fans, etc.
- Area must be clean and free of excessive dust.
- Work surface must be stable and level.
- Scale must not be exposed to direct sunlight or radiating heat sources.
- Use an approved Electro-Static Device.



1.3 TOOLS AND TEST EQUIPMENT REQUIRED

1. Common hand tools are sufficient to disassemble the Valor 3000 scales.
2. RS2323 Interface Connector – PN 71147376 or 72206287
3. Communications Service Interface – PN 72203450

1.4 SPECIFICATIONS

Complete specifications for the Ohaus Valor 3000 Scales are listed in Table 1-1. When a scale has been serviced, it must meet the specifications listed in the table. Before servicing the scale, determine what specifications are not met.

TABLE 1-1. SPECIFICATIONS

Model	V31XH202	V31XH2	V31X3	V31X6	V31XW301	V31XW3/ V31X3N	V31XW6/ V31X3N
Capacity	200	2000	3000	6000	300	3000	6000
Repeatability (g)	0.01	0.1	1		0.2	1	2
Linearity (g) (+/-)	0.01	0.1	1		0.2	1	2
Weighing Units	g, kg, lb, oz, lb:oz						
Application Modes	Weigh, Percent weighing, Specific Gravity, Fluid Ounces						
Tare range	To capacity by subtraction						
Stabilization Time	≤3 seconds						
Power Requirements	9 VDC 500 mA AC adaptor (supplied) or 4 C (LR14) batteries (not supplied)						
Calibration	Digital with external weight						
Display Type	6-digit 7-segment LCD with white LED backlight						
Display Size	15 mm / 0.6" digits						
Keypad	3-button overlay						
OIML Class	-	-	-	-	III	III	III
Ingress Protection	-	-	-	-	IP65	IP65*	IP65*
Pan Size (mm / in)	120/4.7	146 x 158 / 5.7 x 6.2					
Net Weight (kg / lb)	1.2/2.6	1.3/2.9			1.4/3.1		
Shipping Weight (kg/lb)	2.6/5.7	2.7/6			2.8/6.2		

* Models V31X3N and V31X6N are not rated IP65.

1.4 SPECIFICATIONS

TABLE 1-2. CAPACITY AND READABILITY

Units	Non-Washable Models				LFT SWITCH	Washable Models		
	V31XH202	V31XH2	V31X3	V31X6		V31XW301	V31XW3/ V31X3N	V31XW6/ V31X6N
g	NA	NA	NA	NA	ON	300.0 x 0.2	3000 x 1	6000 x 2
	200.00 x 0.01	2000.0 x 0.1	3000 x 1	6000 x 1	OFF	300.0 x 0.1	3000.0 x 0.5	6000 x 1
kg	NA	NA	NA	NA	ON	0.3000 x 0.0002	3.000 x 0.001	6.000 x 0.002
	0.20000 x 0.00001	2.0000 x 0.0001	3.000 x 0.001	6.000 x 0.001	OFF	0.3000 x 0.0001	3.0000 x 0.0005	6.000 x 0.001
oz	NA	NA	NA	NA	ON	10.58 x 0.01	105.80 x 0.05	211.6 x 0.1
	7.0550 x 0.0005	70.550 x 0.005	105.80 x 0.05	211.65 x 0.05	OFF	10.585 x 0.005	105.80 x 0.02	211.60 x 0.05
lb	NA	NA	NA	NA	ON	0.6615 x 0.0005	6.615 x 0.005	13.225 x 0.005
	0.44090 x 0.00005	4.4090 x 0.0005	6.615 x 0.005	13.230 x 0.005	OFF	0.6615 x 0.0005	6.615 x 0.002	13.225 x 0.005
Lb:oz	NA	NA	NA	NA	ON	NA	6 lb : 9.80 oz x 0.05 oz	13 lb: 3.6 oz x 0.1 oz
	NA	4lb: 6.55oz x 0.01oz	6 lb : 9.80 oz x 0.05oz	13lb: 3.65oz x 0.05oz	OFF	NA	6 lb : 9.80 oz x 0.02 oz	13 lb: 3.60 oz x 0.05 oz
oz (fra)	NA	NA	NA	NA	ON	10 ½ oz x 1 / 8	105 ½ oz x 1 / 8	211 ½ oz x 1 / 8
	7 x 1/8	70½ oz x 1/8	105½ oz x 1/8	211½ oz x 1/8	OFF	10½ oz x 1/8	105½ oz x 1/8	211½ oz x 1/8
lb:oz (fra)	NA	NA	NA	NA	ON	N A	6lb : 9½ oz x 1/8oz	13 lb : 3½ oz x 1/8oz
	N A	4lb : 6 ½ oz x 1/8 oz	6lb : 9 ½ oz x 1/8oz	13 lb : 3 ½oz x 1/8oz	OFF	N A	6lb : 9 ½ oz x 1/8oz	13 lb : 3½ oz x 1/8oz
fl	NA	NA	NA	NA	ON	10.14 x 0.01	101.45 x 0.05	202.9 x 0.1
	6.7630 x 0.0005	67.630 x 0.005	101.45 x 0.05	202.90 x 0.05	OFF	10.140 x 0.005	101.44 x 0.02	202.90 x 0.05

1.5 SCALE OPERATION

This section contains information on the basic operation of the scale.

The included AC adapter may be used to power the scale when battery power is not available. Remove the rubber seal in the bottom. Store it in the location provided. (See Figure 1-1. Connect the AC adaptor plug to the input jack.




Figure 1-1. Power Connection and Seal.

1.5.1 OVERVIEW OF THE CONTROLS




Figure 1-2. Valor 3000 Xtreme & Xtreme W Displays.

TABLE 1-3. FUNCTIONS OF DISPLAY CONTROLS

Button	Action	Functions
O/T On/Off	Short Press (when off) Short Press (when on) Long Press	Turns scale on Sets display to zero Tares weight of item on pan Turns scale off
MODE/UNIT Menu	Short Press Long Press Short Press (Menu mode):	Steps through active units and modes Enters Menu "No" (toggles through available settings)
ENTER Cal	Short Press Long Press Short Press (Menu)	Stores 100% reference in % mode Stores reference sample in SG mode Initiates span calibration process "Yes" (selects/accepts displayed setting)

1.5.2 OVERVIEW OF THE DISPLAY INDICATORS




Figure 1-3. Valor 3000 Display Indicators.

TABLE 1-4. DISPLAY INDICATORS

No.	Function
1	Indicates that the measured value has become stable.
2	Standard 7-segment numeric characters, used for displaying weight values.
3	Symbols for weighing modes, include: FL – Fluid Ounces % - Percent (of referenced weight), S – Specific Gravity kg – Kilograms, lb:oz – Pounds & Ounces

1.5.3 Power ON

With power applied, press **O/T On/Off**. After segment display and software revision number, there is a countdown (-4-, -3-, -2-, -1-), and then * **0.00 oz** (standard weighing mode).

If the scale is set for LFT (Legal For Trade – available on XW and NTEP “N” models), **LFT** flashes briefly after the software revision number and before the countdown. (To reverse the LFT setting, see Section 1.7.)

Allow time for the scale to stabilize after moving it from an area which is at a different temperature than the area where it is to be operated. Allow one hour for each 5°F (2.7°C) temperature change before using the scale. After temperature stabilization, allow an additional 20 minutes after turning the scale on, for the scale electronics to stabilize.

When the scale is first turned on, the factory default is to weigh in grams and tare items without setting the menus.

1.5.4 Power OFF

To turn the scale OFF, press and hold **>O/T<** until the display indicates **OFF**, then release.

1.5.5 Menu Setup

Programmable features of the Valor 3000 scales are contained in menus which are accessed through the Display Panel's control switches. The Menu Structure is described in Section 1.8. (For more detail on using the menus, see the Instruction Manual.)

Note: If the scale is set for LFT (on XW and NTEP models), the Unit and Calibration menus are not accessible, and the following Setup submenus are not accessible: Stability, AST, Filter, Power On Unit, and Global Reset. To gain access to these submenus, see the next section.

1.6 LEGAL FOR TRADE (LFT)

When the scale is set for LFT (on XW and NTEP models), the following menu settings cannot be accessed/changed: Calibration, Unit, Stability, AST, Filter, Power On Unit, and Global Reset.

To regain access to the locked menu settings, remove the small rectangular LFT/Calibration Lock Switch cover on the bottom of the scale. (See Figure 1-4.) Use a small flathead screw driver to move the CAL switch to the left (closer to the “L” in “CAL”), which turns LFT off.

After the LFT/CAL Lock setting has been turned off, the scale must be inspected in accordance with local weights and measures regulations before it can be used in LFT mode again. Local authorities may apply seals on the three screws indicated in Figure 1-4.




Figure 1-4. LFT/Cal Lock Switch.


1.6.1 LFT SETUP PROCEDURE

4. Set the Geographical Adjustment Factor (GEO) according to the location where the scale is to be used. (See Appendix D. Possible values are from 1 to 31.) The setting is in the Service Menu: press **O/T/Off** and **MODE/UNIT/Menu** simultaneously during power on. Press **No** three times until GEO appears, then press **Yes**. Then continuously press **No** until the desired number appears. Press **Yes**, then **No** until END appears. Press **Yes** to return to weighing mode.
5. Access the Setup menu (Press and hold **MODE/UNIT/Menu** until SETUP appears. Press **Yes** to enter the displayed menu, or **No** to advance to the next menu, etc.) Set the following:
 - Auto Zero Tracking (AZT) = 0.5d
 - Stability (Stab) = 1d
 - Units as per local LFT requirements
6. Perform an accurate calibration. (See Appendix A.)
7. Turn the Scale off **and disconnect** the AC power connection.
8. Open the rectangular LFT/Calibration Lock Switch Cover on the bottom of the scale.
9. Move the switch to the right (closer to the “C” in “CAL”), which turns LFT on.
10. Reinstall the LFT/Calibration Lock Switch Cover.
11. Reconnect the AC power, press **O/T/On/Off** to turn on the scale. During power on, the display sequence will now include: “LFT.” This message confirms the proper setting of the LFT mode and the hardware lock switch.

1.7 Menu Structure

Programmable features of the Valor 3000 are contained in menus which are accessed through the Display Panel's control switches. The menu structure is illustrated below. (For more detail on using the menus, see the Instruction Manual.)

TABLE 1-5. VALOR 3000 MENU STRUCTURE

<p>SETUP (Press and hold MODE/UNIT/<i>Menu</i> until SETUP appears. Press Yes.)</p> <p>Stability Automatic Zero Tracking (AZT) Filter Backlight Auto Off Power On Unit Global Reset Legal For Trade* End Setup</p>		<p>UNIT (appears after pressing Yes to end SETUP menu. Press Yes.)</p> <p>g Kg Oz Lb Lb:Oz FL % S (Specific Gravity) End Units</p>
<p>CALIBRATION (Press and hold ENTER/<i>Cal</i> until CAL appears and calibration begins.)</p> <p>See Appendixes A & B for more details.</p>		

*Legal For Trade is included only in models V31XW301, V31XW3, V31XW6, V31XW3N, and V31XW6N.

2.1 TROUBLESHOOTING

This section of the manual contains troubleshooting information. Information is contained to isolate specific problems using Table 2-1, Diagnostic Guide. Follow all directions step by step. Make certain that the work area is clean. Handle scale components with care. Use appropriate Electro-Static Device.

2.2 DIAGNOSTIC GUIDE

Table 2-1 is a Diagnostic Guide designed to help locate the problem area quickly and easily. The probable causes are listed with the most common cause first. If the first remedy does not fix the problem, proceed to the next remedy. Before attempting to repair the scale, read all chapters of this manual to be familiar with the scale components and operation.

2.2.1 Diagnosis

1. Isolate and identify the symptom
2. Refer to Table 2-1, Diagnostic Guide and locate the symptom.
3. Follow the suggested remedies in the order they appear.
4. Perform the indicated checks, or see the appropriate section of the manual.
5. Repair or replace the defective section of the scale.

NOTE:

If more than one symptom is observed, approach one area at a time, and remember that the symptoms may be interrelated.

If a problem arises that is not covered in this manual, contact Ohaus Corporation for further information.

CHAPTER 2 DIAGNOSTIC GUIDE

2.2.1 Diagnosis

TABLE 2-1. DIAGNOSTIC GUIDE

Symptom	Possible Cause	Remedy
Cannot turn on	No power to scale	Verify connections and voltage.
Poor accuracy	Improper calibration Unstable environment	Perform calibration • Move scale to suitable location
Cannot calibrate	Unstable environment Incorrect calibration weight	Move the scale to suitable location Use correct calibration weight
Cannot access mode	Mode not enabled	Enter menu and enable mode
Cannot access unit	Unit not enabled	Enter menu and enable unit
Err 8.1	Pan has load during power on Zero has drifted Load Cell is damaged	Remove weight from pan and re-zero. In Service Menu, run RAMP to check Load Cell. Then calibrate. Replace Load Cell.
Err 8.2	Pan was removed prior to power on Zero has shifted Load Cell is damaged	Install pan and re-zero. In Service Menu, run RAMP to check Load Cell. Then calibrate. Replace Load Cell.
OVER	Weight on pan exceeds capacity	Remove weight from the pan
UNDER	Pan was removed during weighing	Re-install pan
Err 9	New PCB installed. Factory calibration data corrupted	Configure scale – see Appendix C. Perform service calibration
REF Err	Reference Weight is too small	Use larger sample
LOWrEF	Reference Weight is too low for accurate percent weighing.	Continue to weigh with less accurate results
Menus are locked out: Cal, Stab, AZT, Filter, Power On Unit or Global Reset	Scale is set for LFT.	Turn LFT off. (See Section 1.7.)

3.1 PREVENTIVE MAINTENANCE

Ohaus scales are precision instruments and should be carefully handled, stored in a clean, dry, dust-free area, and cleaned periodically. Follow these precautionary steps:

- When a scale has had chemicals or liquids spilled on it, all exterior surfaces should be cleaned as soon as possible with warm water on a damp cloth.
- Do not leave a mass on the scale when the scale is not in use.
- Allow time for the scale to stabilize after moving it from an area which is at a different temperature than the area where it is to be operated. Allow one hour for each 5°F (2.7°C) temperature change before using the scale. After temperature stabilization, allow an additional 20 minutes after turning the scale on, for the scale electronics to stabilize.

3.1.1 Preventive Maintenance Checklist

The scale should be inspected and checked regularly, as follows:

1. Remove the Pan and Sub Pan to inspect and clean the area beneath the Pan.
2. Clean the outside of the scale using a damp cloth with warm water.



CAUTION

DO NOT USE CHEMICAL CLEANERS OR SOLVENTS OF ANY TYPE.
SOME CLEANERS ARE ABRASIVE AND MAY AFFECT THE SCALE'S FINISH.

3. Check the Power Cord for broken or damaged insulation.
4. If using batteries and the scale malfunctions, first replace the batteries to see if this resolves the problem. The Valor 3000 takes four "C" (LR 14) batteries.
5. Make a visual inspection for faulty connectors, wiring, and loose hardware.

3.2 OPENING THE SCALE

Opening the Valor 3000 scale varies slightly according to the specific model, as detailed below. Use these procedures in order to replace the Load Cell, the Printed Circuit Board and/or LCD Display.

3.2.1 Opening Valor 3000 Standard and Washable Models

Common hand tools are sufficient to disassemble the Valor 3000 scales. Turn the scale off and unplug the power cord before you begin.

1. Remove the Weighing Pan: pry off the seal tab, remove the screw and washer securing the Pan Support, and lift off the Pan Support.
2. Remove the Load Cell Seal and Ring. (XW models only.) (See Figure 3-1.) Start by lifting the outer edge, then gently lift to pull the O-ring and seal from the center.
3. Remove the screws holding the Housing in place. (See Figure 3-2.) The screw on the left side may have a tamper-evident seal, used in Legal For Trade application. (See Section 1.8 for more details.)

Screws that secure the Housing
(each with a seal washer inside)




Figure 3-2. Scale Bottom, Valor 3000XW.

4. Replace a screw (without tightening it) in the hole closest to the back end of the scale. Use a thumb-sized coin to press the screw while holding the leveling feet on either side. The Top Housing should come off. (See Figure 3-3.)



Figure 3-1. Proper way to lift off Seal.



Note: If separating the Top and Bottom Housing is difficult, because of the seal gasket between them, *do not apply pressure to the top of the Load Cell* while holding the Housing, to release it from the Bottom Plate.




Figure 3-3. Technique for separating Top and Bottom Housing on Valor 3000.

3.3 Replacing the Load Cell

The Load Cell may need to be replaced because of scale instability, or because the scale does not calibrate or repeat, or because it is physically broken or displays an error code.

1. Open the scale – see Section 3.2.1.
2. Disconnect the cable connecting the PCB to the Load Cell.
 - On XW models it is a flat ribbon cable. Gently pry up the collar holding the cable. Use a flat head screwdriver to move the collar to the up position on both sides. The cable will then lift out.
 - On non-XW models, it is a four-wire cable affixed to the PCB with a white tab pin receptacle. It is easiest to lift out the tab if the PCB is first removed. (See Section 3.4 below.)
3. To release the Load Cell, turn the scale over, holding the Load Cell by hand, and remove the six screws inside the two Battery Compartments.
4. Turn the scale back on its feet and gently lift off the Load Cell.
5. If the Load Cell is malfunctioning, replace it.
6. Before installing the replacement Load Cell, check that the red Shipping Lock on the plastic panel between the Battery Compartments is in the unlocked position.
7. Carefully position the Load Cell so the black plastic tab at the rear fits into the brass Up/down Stop, and the screw holes in the steel plate align with their counterparts in the two Battery Compartments.
8. Turn the scale over. Insert and tighten the screws.
9. When installing the new Load Cell, insert the cable connecting it to the PCB. Reverse the procedure in Step 1 above.
10. To assemble the Housing, follow the steps in Section 3.2.1 in reverse order.
11. Configure the Scale. (See Appendix C.)




Figure 3-4. Red lock between battery compartments.

Note: There is no need to disassemble the Load Cell. It is supplied as an assembled unit. (See Chapter 5 for parts lists.)

3.4 Replacing the Printed Circuit Board and Display

1. Open the scale – see Section 3.2.1.
1. Disconnect the cable from the PCB to the Load Cell. Follow the procedure in Section 3.3.
2. Remove the four screws that hold the PCB in place.
3. Lift the PCB up from the Housing. Insert the replacement PCB.
4. Follow these steps in reverse order to install the new PCB.
5. Turn the scale on. **Err 9** will appear. This is normal.
6. Configure the Scale. (See Appendix C.)




Figure 3-5. Printed Circuit Board and Display.

Note: The PCB and the LCD Display are supplied as a single unit. However, if only the LCD Display needs replacement, it can be separated from the PCB by removing the two screws in the bottom of the PCB, and unsoldering the 24 fine lead-wires connecting it to the PCB. When installing the new LCD Display, carefully feed the lead-wires through their holes, then insert the two screws, and finally solder the 24 lead-wires.

3.5 Replacing the Housing Seals

1. Open scale following instructions in Section 3.2.1. Note the condition of the Load Cell Seal and Ring, which may also need to be replaced.
2. Remove the leveling feet and the two screws that secure the Legal-For-Trade (LFT) switch cover. (See Figure 3-6)
3. Remove the screws holding the Bottom Plate. Then lift off the Bottom Plate. (See Figure 3-6)
4. Carefully position the Bottom Plate Seal to align with the matching holes on the Bottom Plate. Then mount the Bottom Plate on the Bottom Housing, and insert and tighten the six small screws that hold it.
5. Re-install the leveling feet, and then mount the Bottom Plate Gasket.




Figure 3-6. Bottom of Valor 3000 Xtreme W.




Figure 3-7. Bottom Plate Gasket and Seal.

6. Turn the scale over and replace the seal washers in the holes of the screws that hold the Top Housing in place. (See Figure 3-2.)
7. There is a seal-washer to the left of the PCB, inserted beneath a screw and steel washer on the left-rear of the PCB. (See Chapter 5 for the Housing Seal Kit.)




Figure 3-8. Seal washer on left-rear of PCB.

8. Mount the Top Housing, careful to clear the Bottom Plate Gasket on all sides. Then insert all screws.
6. Install the new seal on the Pan Support. Insert it through the hole shown in Figure 3-9.




Figure 3-9. Seal washer for Weighing Plate

3.6 Replacing the Function Label

The Function Label may need to be replaced. (See Chapter 5 for parts information.) Use a broad blade, such as a wide X-Acto knife, to remove the label. Clean the glue residue from the Housing surface. Then carefully place the new label where the old one was. (See Figure 3-8.)




Figure 3-8. Plastic Insert and Function Label.

3.7 Replacing the Plastic Insert

The Plastic Insert also may need to be replaced. (See Chapter 5 for parts information.) Break the tabs off the inside of the Plastic Insert to remove it. Then place the new Insert where the old one was. (See Figure 3-9.)




Figure 3-9. Plastic Insert, viewed from inside Top Housing.

4.1 TESTING

Before and after servicing a Valor 3000 scale, an operational test and various performance tests should be made to confirm that the scale meets specifications. Turn the scale on and allow it to warm up for at least one hour before performing these tests.



NOTE:

Make sure the test area is free from drafts and that the scale rests on a level and vibration-free surface.

4.1.1 TEST MASSES REQUIRED

The masses required to test the Ohaus Valor 3000 scales must meet the requirements of ASTM Class 4 or OIML F2 Tolerance. The mass values are listed in Table 4-1.

TABLE 4-1. CALIBRATION MASS VALUES

MODELS							
	V31XH202	V31XH2	V31X3	V31X6	V31XW301	V31XW3	V31XW6
Calibration Weights	200g	2 kg	3 kg	6 kg	300 g	3 kg	6 kg

4.2 Operational Test

1. Connect a functioning Power Adapter to the scale power receptacle located on the bottom of the scale, or install 4 “C” (LR 14) batteries.
2. Plug the Power Cord into a suitable power source.

4.3 Segment Display Test

Turn the scale on, and ensure that all segments are enabled and displayed briefly. This is a Segment Display Test. (See Figure 4-1.)




Figure 4-1. Segment Display

4.4 Load Cell Test Using RAMP

To test the Load Cell using RAMP, see Appendix B.

4.5 Performance Tests

Accurate performance of the Valor 3000 scales is determined by a series of four performance tests. The displayed readings are compared with the tolerances listed in Tables 4-2 and 4-3. Tolerance values are expressed in counts. A one-count difference is shown in the last digit on the scale display.

TABLE 4-2. TOLERANCES

Model	V31XH202	V31XH2	V31X3	V31X6	V31XW301	V31XW3/ V31X3N	V31XW6/ V31X3N
Precision	±1	±1	±1	±1	±2	±1	±2
Repeatability	1	1	1	1	2	1	2
Linearity	±1	±1	±1	±1	±2	±1	±2

NOTE:

The following performance tests are used to evaluate scale operation before and after repairs. The scale must meet the requirements specified in each test as well as the specifications listed in Table 4-1. Before proceeding with the following tests, the scale should be calibrated. (See Appendix A.)

4.5.1 Precision Test

The Precision Test measures the Standard Deviation of a set of similar weight readings, which should match the specification for each model, listed in Tolerance Table 4-2.

1. Power on the balance. The reading on the display should be 0g.
2. Select a mass weighing near the maximum capacity of the balance, and place it on the center of the Pan. Observe and record the reading.
3. Remove the mass. The reading should return to 0g ± the tolerance in Table 4-2.
4. Repeat this test three times. The readings should be within tolerances. If so, the balance passes the Precision Test.
5. If the deviation for any set of readings (using the same mass placed on the center of the Pan) is greater than the tolerance listed in Table 4-2, the balance does not meet the precision specification. Inspect and correct the following areas:
 - Check for mechanical obstructions. Any foreign object touching any part of the moving assemblies will cause a balance to fail the Precision Test. Inspect and correct as necessary.
 - If the scale does not meet specifications, move it to a suitable location, ensure that it is level, and try again. If it still does not meet specifications, perform a service calibration, and try again. (See Appendix B for Service Calibration.)
 - If the scale does not pass this test, the Load Cell may need to be replaced.

4.5.2 Repeatability Test

Repeatability is the Standard Deviation of a set of similar weight readings.

Requirements:

- To perform this test a single mass must be used for all readings.
- The test mass should be approximately $\frac{1}{2}$ of the capacity of the instrument.
- Wear gloves when handling the mass.

Before starting a repeatability test, set up the instrument as follows:

Set Up:

Enter the menu and adjust and record the following settings:

- A. Set the Stability setting to its lowest setting.
- B. Set the Filter level to medium or the center of its range.
- C. Set the AZT (Auto Zero Tracking) to .5d or its lowest setting. Do not turn it off.
- D. Set the instrument to display the same units as the performance specifications.
(Usually kg, g, or mg)

Record Settings:

Stability Setting =	_____
Filter Level Setting =	_____
Auto Zero Tracking Setting =	_____
Displayed Units =	_____
Mass Used =	_____

TEST PROCEDURE:

1. Zero the instrument.
2. Using a test mass approximately half the capacity of the instrument, place the mass on the center of platform. Record the reading on the worksheet provided.
3. Remove the mass from the platform.
4. Repeat this test starting at Step 1 until you record a total of ten readings

Fill in the worksheet (Table 4-3) with the ten (10) readings.

4.5.2 Repeatability Test

TABLE 4-3. REPEATABILITY WORKSHEET

n	Reading	Delta = Reading – Mean	Delta x Delta
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
n = number of Reading Mean = Sum of readings / 10 Delta = Reading – Mean Standard Deviation = Square Root of (sum of (Delta x Delta) / 9)			

5. Add the ten readings and divide the total by 10 to find the Mean (average).

6. Mean = (Reading 1 + Reading 2 + Reading 3 + Reading 4 + Reading 5

7. + Reading 6 + Reading 7 + Reading 8 + Reading 9 + Reading 10) / 10

Mean = _____

6. Calculate the Delta for each reading and record in the work sheet.

Delta = Reading – Mean

7. Calculate the Delta x Delta for each reading and record in worksheet.

8. Add the ten Delta x Delta values and divide by 9

9. Calculate the Standard Deviation by applying the square root of the result from step 8.

Standard Deviation = _____

Note: If the balance does not meet specifications, move it to a suitable location, ensure that it is level, and try again. If it still does not meet specifications, perform a service calibration, and try again. (See Appendix B for Service Calibration.)

4.5.3 Linearity Test

This test is used to determine the linearity of the unit throughout its operating range. The masses used to perform this test can be utility masses.



NOTE:

The scale must pass the Precision and Repeatability Tests, and be calibrated before the Linearity Test may be performed.

TABLE 4-4. LINEARITY TEST MASSES

Capacity (g)	200 x 0.01	2000 x 0.1	3000 x 1	6000 x 1	300 x 0.2 IP	3000 x 1 IP	6000 x 2 IP
Reference Wt.	50	500	750	1500	75	750	1500
Load 1	50	500	750	1500	75	750	1500
Load 2	100	1000	1500	3000	150	1500	3000
Load 3	150	1500	2250	4500	225	2250	4500

NOTE:

All masses are nominal values. Be certain to use the same reference mass throughout the procedure.

1. Place the test mass on the Scale, record the weight and remove.
2. Place Load 1 on the Scale and press TARE.
3. Place the test mass on the Scale, record the weight and remove.
4. Place Load 2 on the Scale and press TARE.
5. Place the test mass on the Scale, record the weight and remove.
6. Place Load 3 on the Scale and press TARE.
7. Place the test mass on the Scale and record the weight.
8. The difference in the weights of the test mass should be within the tolerance in Table 4-1. If not, calibrate (see Appendix A.1) and repeat the test.
9. If the Scale remains out of tolerance, the Load Cell may need to be replaced.

4.5.4 Off-Center Load Test

The Off-Center Load Test is used to determine whether displayed weight values are affected by moving the sample to different areas of the Pan.

1. Place half of the scale's capacity in the center of the Pan.
2. Note the reading.
3. Move the mass halfway (between the center and the edge) to the front of the Pan. Note any differences in the displayed weight reading.
4. Repeat the test for the back, left, and right position of the Pan.
5. Maximum allowable change in displayed weight readings for each of the four positions can be found in Specifications Tables (Chapter 1). If this maximum is exceeded, follow procedures in Section 4.5.5, Adjusting Off Center Load.

4.5.5 Adjusting Off Center Load

If the Off Center Load (OCL) is excessive, perform adjustment as follows:




Figure 4-2. Scale drawing of Valor 3000 Load Cell and Weighing Pan.

1. Place the test weight in the center of the Weighing Pan.
2. Tare the balance.
3. Move the weight to point A and record the reading.
4. Move the weight to point B and record the reading.
5. Move the weight to point C and record the reading.
6. Move the weight to point D and record the reading.
7. If the reading at point A is negative, file at points 1 and 4 AT AN ANGLE.
8. If the reading at point B is negative, file at points 1 and 2 STRAIGHT ACROSS.
9. If the reading at point C is negative, file at points 2 and 3 AT AN ANGLE.
10. If the reading at point D is negative, file at points 3 and 4 STRAIGHT ACROSS.



Note: It is not recommended that you try to adjust more than –5 counts if the beam has been filed already. If the beam has not been filed previously, you can adjust –10 counts. Remember, when filing you are weakening the beam. File a little at a time.

This section of the manual contains exploded views for the Valor 3000 series scales. The exploded view drawings are designed to identify the parts which can be serviced on the scale in the field.

NOTE:

In all cases where a part is replaced, the scale must be thoroughly checked after the replacement is made. The scale **MUST** meet the parameters of all applicable specifications in this manual.

If further technical information is needed, please contact your local Ohaus distributor, or:

Ohaus Corporation, www.ohaus.com
19A Chapin Road
P.O. Box 2033
Pine Brook, NJ 07058-2033 USA

Tel: 973-377-9000
Fax: 973-593-0359

In the United States call toll free, 800-526-0659 between 8:00 a.m. and 6:00 p.m. EST.

5.1 VALOR 3000 XTREME SCALES: HOUSING & INTERNAL PARTS




Figure 5-1. Valor 3000 Xtreme Scales: Housing & Internal Parts.

5.1 VALOR 3000 XTREME SCALES: HOUSING & INTERNAL PARTS

TABLE 5-1. VALOR 3000 XTREME SCALES: HOUSING & INTERNAL PARTS

Drawing Item	Description
1a	Pan, Square, 146mm x 158mm
2a	Pan Support Square
1b	Pan, Round, 120mm
2b	Pan Support Round
3	Plastic insert Non-IP
4	Function Label, without Level
5	Housing, Top, Ex IP Model, No Labels
6	Load Cell
7	Housing, Bottom
8	Seal Kit, Housing
10	Housing, Bottom Plate, No LFT
11	Feet, 4, Adjustable
12	Battery Cover, Seal and Screws
13	PCB, Main, Low Resolution
14	LCD with Backlight
15	Seal, AC Adapter
16	Hardware Kit
80	Adapter

5.2 VALOR 3000 XTREME W SCALES: HOUSING & INTERNAL PARTS




Figure 5-5. Valor 3000 Xtreme W Scales: Housing & Internal Parts.

5.2 VALOR 3000 XTREME W SCALES: HOUSING & INTERNAL PARTS
TABLE 5-5. VALOR 3000 XTREME W SCALES: HOUSING & INTERNAL PARTS

Drawing Item	Description
1	Pan, Square, 146mm x 158mm
2	Pan Support Square
3	Load Cell Seal Kit, IP Models
4	Function Label, Level
5	Housing, Top, IP Models, No Labels
6	Load Cell, 6000g
7	Housing, Bottom
8	Seal Kit, Housing
10	Housing, Bottom Plate, LFT
11	Feet, 4, Adjustable
12	Battery Cover, Seal and Screws
13	PCB, Main, OIML
14	LCD with Backlight
15	Seal, AC Adapter
16	Hardware Kit
17	Seal Kit, LFT
18	Level, Bubble
80	Adapter, US, 120V

APPENDIX A. STANDARD CALIBRATION

A.1 CALIBRATION

Note: This menu is locked out in Legal For Trade applications. To regain access, see Section 1.6.

Standard calibration should be performed prior to using a scale, and after service. See Section 4.2 for Calibration Masses required for each model.

**Note:**

Be careful not to touch the scale or the table while calibration is in progress, as it will cause the process to fail.

1. Press and hold the **ENTER/Cal** button until **.C.A.L.** appears.
2. Press **Yes**. **CAL** appears, followed by a flashing **-C-** while a zero reading is stored.
3. The specified calibration weight value appears. Place the weight on the pan. The display shows **-C-** while the reading is stored.
4. When calibration is complete, the display shows **done**, and then returns to the previous application mode and scale is ready for use.

NOTE: If calibration fails, ensure that the test area is free from drafts and the surface the scale rests on is level and free of vibrations. Then try to calibrate again. If it continues to fail, there may be an internal problem. To resolve internal problems, follow procedures in Chapter 3.

APPENDIX B. THE SERVICE MENU

This section describes the Service Menu and sub-menus, which allow authorized service personnel to perform factory Linearity and Span calibrations (no pre-set limits).

B.1 Entering the Service Menu

Turn the scale off.

Enter the Service Menu by pressing and holding **O/T/On/ Off** and **MODE/UNIT/Menu** together until **RAMP** appears.


Press **Yes** to select **Ramp**.



B.2 Ramp

The ramp display shows the percentage of use of the A to D circuit, that is, of the temperature-compensated duty cycle. The actual value is not as important as how it changes. It should increase as the weight on the scale is increased. The ramp display should remain constant without fluctuations.

If you press **Yes** to select **Ramp**, a number appears. It should be constant. Add masses from minimum to maximum capacity. The reading will increase, but should not fluctuate. The example at right is with no weight on the Pan. It will vary with other scales.



To exit the ramp function, press **No**.
The scale advances to the **Linear** calibration menu.
Press **Yes** to perform Linear Calibration.
(See next page.)



Note:

Be careful not to touch the scale or the table while calibration is in progress, as it will cause the process to fail.


B.3 Linear Calibration

Linear calibration automatically follows Ramp. To start from the Service Menu, press and hold **O/T/On/Off** and **MODE/UNIT/Menu** together. As the scale powers up, **RAMP** appears. Press **No** to bypass Ramp.

When **Linear** appears, press **Yes**.



The display shows **-C-** while the scale acquires the zero value.



After the zero value is acquired, the display shows the first calibration point value.
Place the indicated weight on the Pan, and press **Yes**.



If the target weight is not placed on the pan within 10 seconds, error **CAL E** is displayed for 3 seconds and the menu returns to **LIN**.




Pressing **Yes** after placing the prompted weight accepts the linearity mid-point weight. The display shows **-C-** while the scale acquires the weight reading.
After the mid-point value is acquired, the display shows the second calibration point value.



If the target weight is not placed on the pan within 10 seconds, error **CAL E** is displayed for 3 seconds and the menu returns to **LIN**.



Pressing **Yes** after placing the prompted weight accepts the linearity full-capacity weight. The display shows **-C-** while the scale acquires the weight reading.



After the full-capacity value is acquired, the display shows **done** for 2 seconds and returns to **LIN**.



Press **No** to move to **Span** calibration. Then press **Yes**.



B.4 Span Calibration

Span calibration from the service menu allows you to set a new zero and maximum setting. This is distinct from user level span calibration, which allows a user to adjust the zero and maximum setting within the range established by the service menu span setting.

Span calibration automatically follows Linear calibration. To start from the Service Menu, press and hold **OT/On/Off** and **MODE/UNIT/Menu** together. As the scale powers up, **RAMP** appears. Press **No** to bypass Ramp. **Lin** appears. Press **No**.

SPAN appears. Press **Yes**.

The display shows **-L-** while the scale acquires the zero value.

The specified maximum mass weight flashes. Place the indicated weight in the center of the Pan.

If the target weight is not placed on the pan within 10 seconds, error **CAL E** appears for 3 seconds and the menu returns to **SPAN**. Start again.

Pressing **Yes** after placing the prompted weight accepts the span weight shown on the display. The display then shows **-C-** while the scale acquires the span value.

After the span value is acquired, the display shows **done** for 2 seconds and returns to **SPAN**. Press **No** to advance to the next option (**Geo**). (To exit the Service Menu, press **No** until **End** appears. Then press **Yes**.)

NOTE: If calibration fails, ensure that the test area is free from drafts and the surface the scale rests on is level and free of vibrations. Then try to calibrate again. If it continues to fail, there may be an internal problem. To resolve internal problems, follow procedures in Chapter 3.

B.5 Geographical Adjustment Factor (GEO)

The Geo Factor adjustment allows entry of values from 0 to 31 and is used to compensate for slight variations in gravity at different geographical locations around the world.

This feature allows authorized personnel to accurately calibrate the scale at a location other than the location where the scale is to be used. Prior to calibration, the Geo Factor is set to correspond to the geographical location where the calibration is being performed. Following calibration, the Geo Factor is changed to match the location where the scale is to be used. If required, the scale may also be sealed according to the required approval regulations.




NOTE

Only an authorized manufacturer's representative or certified verification personnel should make these changes. Changing the Geo Factor alters the calibration values.

In the Service Menu, press **No** when the display reads **SPAN**. **GEO** appears.

Press **Yes** to edit the GEO setting.
The current setting is the first to be shown.
NOTE: Factory setting for GEO is 13 in general and 19 for Europe



Press **No** until the desired setting appears.
Values from 1 to 31 are available. See Appendix D to determine the correct value.
Press **Yes** to accept the value shown on the display. The menu returns to **GEO**



B.6 Expanded Readability (E.PAnd)

E.PAnd sets the readability to $1/10^{\text{th}}$ of the standard readability. (That is, if standard readability is .01, with **E.PAND** on it would be .001.) Normally **E.PAND** is off. Once it is set on, it will be on until the scale is switched off. When the scale is switched off **E.PAnd** is automatically set to off.

In the Service Menu, press **No** when the display reads **GEO**. **E.PAND** appears.

Press **Yes** to enter the **E.PAND** setting menu. **E.PAND** appears again. Press **Yes** to turn it on. **ON** appears. Pressing **Yes** again accepts the setting. Pressing **No** causes **OFF** to appear. In either case, **E.PAND** appears again. Press **Yes** to change the setting.

A rectangular box containing the text "E.PAND" in a stylized, italicized, monospace font.

To accept a chosen setting (either **ON** or **OFF**) press **No** when **E.PAND** appears. **End** appears. If you selected **ON** to activate **E.PAND** mode, the scale will remain in high resolution (readability) until it is turned off.

A rectangular box containing the text "End" in a stylized, italicized, monospace font.

When the scale is switched off **E.PAnd** is automatically set to off.

APPENDIX C. SOFTWARE SERVICE TOOL INSTRUCTIONS

The Software Service Tool (Part Number 80252509) is required when either a main PC Board or a Load Cell is replaced in a Valor 3000 scale. It is used to re-configure the scale to its original parameters in the case of a PCB replacement, or new parameters in the case of a Load Cell replacement.

C.1 Hardware and Software Setup

1. First, check that the scale's **A-Off** feature, under the **SETUP** menu, is set to **OFF**. If this setting is left **ON**, the scale will shut off during configuration.
2. To connect the scale to a personal computer, use the hardware interface:
 - RS232 Interface and Cable (PN 71147376 or 72206287)
 - A Communications Service Interface (PN 72203450) that attaches to the RS232 Interface
3. Plug the cable into the PC's RS232 port.




Figure C-1. RS232 Interface connected to Service Interface, connected to the scale's PCB, circuit board side up.




Figure C-2. Service Interface fits into the RS232 Interface with the gap on the left side when the label side is up on the RS232 Interface.

4. Install the software on a Personal Computer running Microsoft Windows NT 4.0 or later, or Microsoft Windows 98 or later.
5. Run the program Service Tool. (See next page.)

C.1 Hardware and Software Setup *continued*

6. Open **Configtool.exe** and click **Check Scale**.




Figure C-3. First screen of Configtool.exe.

7. Click **COM port** for Communication setup.




Figure C-4. Com Port Configuration screen with correct settings.

8. The communications parameters should appear mid-screen. Correct values are:

Baud = 2400

ByteSize = 7

Parity = None

If the settings do not match, click the arrow next to the parameter and select the correct value. (See Figure C-4.)

C.1 Hardware and Software Setup *continued*

9. Click the **Test Command** tab to test the communications. (See Figure C-4.)




Figure C-5. Config Tool's Test Command screen.

- Enter a "P" command. The scale should respond with a weight value (*e.g.*, 0.02g).
- Enter a "V" command. The response should be the software version (*e.g.*, Sr: 1.03).

C.2 Configuring the Scale (after replacing the PCB or Load Cell)

1. When communications are reliable, return to the Config tab. Press the **Read** button (E) and the data will be read from the scale.
2. If the PC Board has been replaced, the scale needs to be configured. To configure the scale, enter its serial number in the blank (C), then click **Scale** in the **Serial Number** box (A), and click **OK** (D). When the **OK** button highlights again, click **Update** (F). Turn the scale off and then back on to save the data.




Figure C-6. The Config Tool's Configuration Screen.

3. If the Load Cell was replaced, follow the same procedure as above, but enter the Load Cell serial number, and click **Load Cell** (B) in the **Serial Number** box.
4. The bar (G) is a graphical measure of the Load Cell output currently being used.
5. Turn the scale off, perform a Service Calibration (see Appendix B), followed by Operational and Performance tests (Chapter 4).

APPENDIX D. GEOGRAPHICAL ADJUSTMENT VALUES

TABLE D-1. GEOGRAPHICAL ADJUSTMENT VALUES.

	Elevation above sea level in meters										
Geographical latitude away from the equator (North or South), in degrees and minutes.	0 325	325 650	650 975	975 1300	1300 1625	1625 1950	1950 2275	2275 2600	2600 2925	2925 3250	3250 3575
	Elevation above sea level in feet										
	0 1060	1060 2130	2130 3200	3200 4260	4260 5330	5330 6400	6400 7460	7460 8530	8530 9600	9600 10660	10660 11730
0°00' - 5°46'	5	4	4	3	3	2	2	1	1	0	0
5°46' - 9°52'	5	5	4	4	3	3	2	2	1	1	0
9°52' - 12°44'	6	5	5	4	4	3	3	2	2	1	1
12°44' - 15°06'	6	6	5	5	4	4	3	3	2	2	1
15°06' - 17°10'	7	6	6	5	5	4	4	3	3	2	2
17°10' - 19°02'	7	7	6	6	5	5	4	4	3	3	2
19°02' - 20°45'	8	7	7	6	6	5	5	4	4	3	3
20°45' - 22°22'	8	8	7	7	6	6	5	5	4	4	3
22°22' - 23°54'	9	8	8	7	7	6	6	5	5	4	4
23°54' - 25°21'	9	9	8	8	7	7	6	6	5	5	4
25°21' - 26°45'	10	9	9	8	8	7	7	6	6	5	5
26°45' - 28°06'	10	10	9	9	8	8	7	7	6	6	5
28°06' - 29°25'	11	10	10	9	9	8	8	7	7	6	6
29°25' - 30°41'	11	11	10	10	9	9	8	8	7	7	6
30°41' - 31°56'	12	11	11	10	10	9	9	8	8	7	7
31°56' - 33°09'	12	12	11	11	10	10	9	9	8	8	7
33°09' - 34°21'	13	12	12	11	11	10	10	9	9	8	8
34°21' - 35°31'	13	13	12	12	11	11	10	10	9	9	8
35°31' - 36°41'	14	13	13	12	12	11	11	10	10	9	9
36°41' - 37°50'	14	14	13	13	12	12	11	11	10	10	9
37°50' - 38°58'	15	14	14	13	13	12	12	11	11	10	10
38°58' - 40°05'	15	15	14	14	13	13	12	12	11	11	10
40°05' - 41°12'	16	15	15	14	14	13	13	12	12	11	11
41°12' - 42°19'	16	16	15	15	14	14	13	13	12	12	11
42°19' - 43°26'	17	16	16	15	15	14	14	13	13	12	12
43°26' - 44°32'	17	17	16	16	15	15	14	14	13	13	12
44°32' - 45°38'	18	17	17	16	16	15	15	14	14	13	13
45°38' - 46°45'	18	18	17	17	16	16	15	15	14	14	13
46°45' - 47°51'	19	18	18	17	17	16	16	15	15	14	14
47°51' - 48°58'	19	19	18	18	17	17	16	16	15	15	14
48°58' - 50°06'	20	19	19	18	18	17	17	16	16	15	15
50°06' - 51°13'	20	20	19	19	18	18	17	17	16	16	15
51°13' - 52°22'	21	20	20	19	19	18	18	17	17	16	16
52°22' - 53°31'	21	21	20	20	19	19	18	18	17	17	16
53°31' - 54°41'	22	21	21	20	20	19	19	18	18	17	17
54°41' - 55°52'	22	22	21	21	20	20	19	19	18	18	17

APPENDIX D GEOGRAPHICAL ADJUSTMENT VALUES

TABLE D-1. GEOGRAPHICAL ADJUSTMENT VALUES.

	Elevation above sea level in meters										
Geographical latitude away from the equator (North or South), in degrees and minutes.	0 325	325 650	650 975	975 1300	1300 1625	1625 1950	1950 2275	2275 2600	2600 2925	2925 3250	3250 3575
	Elevation above sea level in feet										
	0 1060	1060 2130	2130 3200	3200 4260	4260 5330	5330 6400	6400 7460	7460 8530	8530 9600	9600 10660	10660 11730
55°52' - 57°04'	23	22	22	21	21	20	20	19	19	18	18
57°04' - 58°17'	23	23	22	22	21	21	20	20	19	19	18
58°17' - 59°32'	24	23	23	22	22	21	21	20	20	19	19
59°32' - 60°49'	24	24	23	23	22	22	21	21	20	20	19
60°49' - 62°09'	25	24	24	23	23	22	22	21	21	20	20
62°09' - 63°30'	25	25	24	24	23	23	22	22	21	21	20
63°30' - 64°55'	26	25	25	24	24	23	23	22	22	21	21
64°55' - 66°24'	26	26	25	25	24	24	23	23	22	22	21
66°24' - 67°57'	27	26	26	25	25	24	24	23	23	22	22
67°57' - 69°35'	27	27	26	26	25	25	24	24	23	23	22
69°35' - 71°21'	28	27	27	26	26	25	25	24	24	23	23
71°21' - 73°16'	28	28	27	27	26	26	25	25	24	24	23
73°16' - 75°24'	29	28	28	27	27	26	26	25	25	24	24
75°24' - 77°52'	29	29	28	28	27	27	26	26	25	25	24
77°52' - 80°56'	30	29	29	28	28	27	27	26	26	25	25
80°56' - 85°45'	30	30	29	29	28	28	27	27	26	26	25
85°45' - 90°00'	31	30	30	29	29	28	28	27	27	26	26



P/N 80152591 SERVICE MANUAL: Valor 3000 SERIES SCALES