

MAINTENANCE MANUAL

AXM SERIES

CONTENTS

1. INTRODUCTION

2. SPECIFICATIONS

2.1 SYSTEM BLOCK DIAGRAM

2.2 PHYSICAL LAYOUT OF ELECTRICAL CONNECTION

2.3 GENERAL SPECIFICATIONS

3. INITIAL SETUP

3.1 INTERNAL FUNCTIONS AND SETTING METHODS

3.2 CALIBRATION

3.3 DISABLE CALIBRATION AND INTERNAL FUNCTIONS SETTING WITH JUMPER SW. (JP1)

3.4 OFFSET AND SPAN VALUE DATA

4. TROUBLE SHOOTING

4.1 TROUBLE SHOOTING LOOP

4.2 PARTS AND COMPONENTS TROUBLE SHOOTING

5. ELECTRICAL CIRCUITRY

5.1 SCHEMATICS

5.2 PCB LAYOUT

6. BILL OF MATERIAL

7. APPENDIX

OCT 2009 REV 2

1. INTRODUCTION

The AXM series is designed and programmed according to the OIML R-76 Class III requirements.

This scale is sealed to prevent unauthorized access to internal parts. Ender users should be advised not to undertake any trouble shooting except those listed on the operation manual.

This maintenance manual contains of certain information that may result in fraudulent use. Do not release any part of this manual to any end users or un-authorized persons.

The internal mini jumper should be so set to prevent un-authorized settings or alternations.

Should a load cell has been replaced, make sure that the protection devices are properly set.


After servicing, it is necessary to go through all tests and procedures to ensure the scale meets all the meteorological and approval requirements.

Here are some features of the AXM series

1. Designed to meet OIML-R76 class III requirements.
2. Zero Indicator.
3. Net Indicator.
4. Negative Value Indicator.
5. Auto Tare Function.
6. Power on Zero Function.
7. Manual Zero Function.
8. Extended Display Function.
9. Auto Power Saving Function.
10. Metric/Avoirdupois Conversion Function.
11. Low battery warning signal.
12. 2 points Calibration.
13. Mini jumper to prevent end-user calibration.
14. Optional EL backlights.
15. Optional RS232C interface.
16. Optional Rear Display
17. Built-in rechargeable battery operated.
18. Battery operating time: 200 hours plus after charged.

2. SPECIFICATION

2.1 SYSTEM BLOCK DIAGRAM




Description:

When a mass is placed on the platform, the load of the article is applied to the load cell inside it.

The resistance to the excitation current in the strain gauge will then change and the analog output signal varies.


It is amplified and digitized continuously by the A/D converter into a digital signal. Subsequently, the resulting count is processed and managed by the CPU. The CPU refers to the instructions from the keyboard, and then conveys the output data to LCD driver, which formats the data into readout on the display panels.

2.2 PHYSICAL LAYOUT OF ELECTRICAL CONNECTION



2.3 GENERAL SPECIFICATION

2.3.1 Overall View



2.3.2 Dimension:

Platter size : 250 x 215mm

Overall size : 250(W) x 285(D) x 105(H)mm

2.3.3 Model Specifications

Model Number	Capacity (Max)	Division (e)
AXM-1500	1500g	0.5g
AXM-3000	3000g	1g
AXM-6000	6000g	2g
AXM-15K	15kg	0.005kg
AXM-30K	30kg	0.01kg
SOFTWARE NUMBER	CE019	
Approval Class	III	
Maximum Tare Range	1/3 Max -1e	
Power on Zero Range	±10% Max	
Manual Zero Range	±2% Max	
Min. Load	20e	
Operation Environment	0°~40°C (32°~104°F), Non-condensed. R.H. ≤85%	
Power Consumption	0.5W (when charged)	

2.3.4 Main Components Used

Microprocessors: SM8958

Crystal Oscillator: 11.0592MHz

Display Device: WTN Liquid Crystal Display

2.3.5 Analog Specification

- The maximum number of verification scale intervals will be:
 $n \leq 3000$ for class **III** instruments
- Power supply of 5 V DC;
- 16 bits serial digital output;
- Excitation power supply for the load cell is 5 V DC;
- Input impedance of the load cell is 350 Ω ;
- The analog data processing unit is built in a closed metal box.

3. INITIAL SETUP

3.1 INTERNAL FUNCTIONS AND SETTING METHODS

INTERNAL FUNCTION TABLE

Function	Symbol	Description
1	F1	Span value reading
2	F2	Full display segment check
3	F3	Scale configuration
4	F4	Auto power off setting
9	F9	Auto tare setting
19	F19	1/30000 Verification Mode**
20	F20	Gravity Compensation-place of calibration**
21	F21	Gravity Compensation-place to be used**

HOW TO ENTER THE REQUIRED FUNCTION MODE

- Turn scale off.
- Press and hold TARE, then turn scale on. Scale display F.1
- Press TARE until the required function number appears.
- Press MODE
- Press MODE until the required setting appears.
- Press TARE to confirm.
- Repeat step c to f for other function setting, or
- Press ON/ZERO to save settings and return to normal operation.

F1 Span Value Reading

- Simply enter F1 to read the A/D counts.
- Press ON/ZERO to clear the A/D counts, apply test mass onto platter, the span value of test mass will be displayed.

F2 Full Display Segment Check

When function is entered, scale will firstly display the software version, and then displays all segments later.
Check and make sure that no segments are missed.

F3 Scale Configuration

- Enter F3, scale displays the offset value.
- Press and hold MODE, available scale capacity and min. division appears.

SELECT DISPLAY RESOLUTION

- Press and hold MODE to change the display resolution.

SELECT WEIGHT UNITS

- when desired display resolution is selected, press MODE

to select weight units.

--To employ all (metric and pound/oz) weight units, press MODE until 'g'(kg), 'lb' indicators appear.

--To disable 'lb' weight unit, press MODE until 'g'(kg) indicator appears only.

SELECT SCALE CAPACITY

e. Press MODE to select the capacity, Press TARE to save setting.

f. Re-calibration will be required after scale capacity changed.

F4 Auto Power Off Setting

Two modes are available: (Default=4_OFF)

Press MODE until desired setting appear, press TARE to save setting.

0_OFF = Auto Power Off function is disabled.

4_OFF = Scale will automatically turns it off after 4 minutes unused.

F9 Auto Tare Setting

Two modes are available: (Default=TrOFF)

TrOFF = Auto tare function is disabled.

Tr_on = Scale will automatically tare off the initial weight that places on the platter.

F19~F21 Reserved

3.2 CALIBRATION

Dealer Calibration Procedures:

1. Turn scale off.
2. Press and hold TARE, then turn scale on.
3. Scale displays F1
4. Press MODE
5. Scale displays offset value
6. Press and hold MODE, Scale displays YES.
7. Scale will self calibrate zero point before proceed to the first point calibration.
8. After zero point calibration is done, scale displays LOAD XXXX or XXXX
9. Load calibration load as request.
10. Wait until scale displays LOAD XXXX(second point).
11. Load calibration load as request or press MODE to abandon second point calibration, wait until scale displays DONE.
12. Calibration completed and scale is ready for operation.

Auto Calibration Procedures:

1. Turn scale off.
2. Press and hold MODE, then turn scale on.
3. Scale displays CAL.?
4. Press MODE again, Scale displays YES.
5. Scale will self calibrate zero point before proceed to the first point calibration.
6. After zero point calibration is done, scale displays LOAD XXXX or XXXX
7. Load calibration load as request.
8. Wait until scale displays LOAD XXXX(second point).
9. Load calibration load as request or press MODE to abandon second point calibration, wait until scale displays DONE.
10. Calibration completed and scale is ready for operation.

Note : Auto calibration can only be performed when the span value is within +/-10% tolerance of dealer calibration.

3.3 DISABLE CALIBRATION AND INTERNAL FUNCTIONS SETTING WITH JUMPER SW. (JP1)

The JP1 is used to control calibration and internal functions setting(F1 and F3). move this jumper to CAL-LOCK position to disable calibration and internal functions setting.

CAUTION:

IF THE SCALE WILL BE SOLD TO AN APPLICATION THAT IS LEGAL FOR TRADE. IT IS HIGHLY RECOMMEND SETTING THE JUMPER TO CAL-LOCK POSITION TO DISABLE THE CALIBRATION AND INTERNAL FUNCTION SETTING.

3.4 OFFSET AND SPAN VALUE DATA**OFFSET AND SPAN VALUE DATA TABLE**

Offset Value (Thousand)	Span Value(Thousand)	Offset Control	Span Control(Ohm) R9
10~14	30~60 at 33% of Max.	R1, R2	150

READING OFFSET VALUE

- 1 Turn scale off
- 2 Remove all load from platter
- 3 Enter F3 and read the offset value

READING SPAN VALUE

- 1 Turn scale off
- 2 Remove all load from platter
- 3 Enter F1
- 4 Press ZERO
- 5 Apply load to platter. Span value according to load applied will be displayed.

HOW TO ADJUST OFFSET VALUE

In case the offset value is out of range, change the resistors R1,R2 to obtain correct offset value.

HOW TO ADJUST SPAN VALUE


The span value is controlled by the resistor locating at R9, standard resistor value of R9 is listed on the above table. If the required span value is not attained, then change R9 resistor according to either case below:

Span value too low: Decrease the resistance of R9.

Span value too high: Increase the resistance of R9.

4. TROUBLE SHOOTING

4.1 TROUBLE SHOOTING LOOP



Description:

- 1) Power source: Rechargeable Battery 6V/4Ah or AC adaptor(9V, 500mA)
- 2) How Battery is charged completely?
The charging voltage is regulated by Q1 (C1061) and ZD1 (8.2V) for about 7 volts.
The charging current will go down automatically when voltage reached.
Q2 (C945) and R1 (1.2R, 1/2W) provide Over-Current protection.
- 3) +5V power drives digital circuit system.
U6 (AIC 1722-5.0) is a 5volts Voltage Regulator.
- 4) +5V power drives analog circuit system.
U4 (NS2950A) is a 5volts Voltage Regulator.
- 4) Auto-off:
If the scale is set with 4_off or even under LO-BAT situation, after fixed time interval, CPU will release a low potential signal to draw down Q2, then Q1 cuts off, the scale will be shut down immediately.
- 5) Low Power Detection:
The Q6(A733) is designed to detect the power level. When battery power is less than 5.5V, the collector pole will become high potential, then CPU will instruct LCD display to show LO-BAT symbol.

4.2.1.2 Input voltage: 5.5V or higher

Check and recharge battery if voltage is less than 5.5V.

4.2.1.3 System voltage (Vcc): 5V +/- 10%

Check that the system voltage is within 5V +/- 10%

- a) less than 4.5V, the CPU may not work properly.
- b) more than 6V, ghost will appear on LCD.

4.2.2 Platform Stopper Checking

The platform device shall not touch anything around itself during operation. Check that the platform is not contacted with the upper (no load) and/or lower (with load) stopper.

4.2.3 LCD Display Checking

4.2.3.1 Check that it is soldered and connected properly between LCD and driver IC (PCF8576), driver IC (PCF8576) and CPU.

4.2.3.2 Check whether LCD is broken.

4.2.4 CPU Checking

4.2.4.1 Check that all pins are seated properly into the socket.

4.2.4.2 Check that the Crystal Oscillator works.

4.2.4.3 Check the RESET is normally low.

4.2.5 A/D Unit Checking

4.2.5.1 Check that the +5V powers are correctly fed to the A/D unit.

4.2.5.2 Check that the signal output of loadcell is normal.


4.2.5.3 Check OP. Amplifiers & A/D Converter (AD7705).


When no error is found with the above checking procedures, the trouble can be caused on the load cell or the PCB itself. Replace a new one could be better to identify the defective.


In this way, the readout of weight would be varied because of the output voltage of load cell and different span value, so re-calibration is required after this replacement.

5. ELECTRICAL CIRCUITRY


5.1 SCHEMATICS









5.2 PCB LAYOUT




AXM-10-1 TOP LAYER




AXM-10-1 BOTTOM LAYER




AXM-10-1 TOP OVERLAY




AXM-10-1 BOTTOM OVERLAY




AXM-40-1 TOP LAYER



AXM-40-1 BOTTOM LAYER



AXM-40-1 TOP OVERLAY



AXM-40-1 BOTTOM OVERLAY

6. BILL OF MATERIAL

STRUCTURE

Parts No.	Description	Specification	Qty	Remark
E1AXM000010	P.C.B. KIT	AXM-10-1 MAIN BOARD	1	
E1AXM001000	P.C.B. KIT	AXM-40-1 REAR BOARD	1	
E1GSP010000	P.C.B. KIT	GM-20-1 POWER BOARD	1	
A0002030***	LOAD CELL	C2G1	1	
	AXM-1500	C2G1-3kg		
	AXM-3000	C2G1-6kg		
	AXM-6000	C2G1-10kg		
	AXM-15K	C2G1-20kg		
	AXM-30K	C2G1-35kg		
A6010230950	ADAPTOR	230V/ 9V 500mA	1	
C1GW0000000	PANEL PC	GW SERIES, 135.5*45.5*0.8mm	1	
C1AXM030000	OVERLAY	AXM SERIES	1	
C1AXM030999	REAR PANEL	AXM SERIES, REAR DISPLAY	1	
A1205010210	BATTERY WIRE	21cm (BLACK)	1	
A1205010212	BATTERY WIRE	21cm (RED)	1	
A1600060400	RECHARGEABLE BATTERY	GP4-6 6V 4AH	1	
A5001000301	CABLE TIE	CV-120S	3	
A5005000090	BUBBLE LEVEL	D14 (Dia. 14mm)	1	
F0009000032	S/S PLATE(NO.32)	XM SERIES, 220*185*0.5mm	1	
F0003GSP100	ALUMINUM L/C SUPPORT	GSP SERIES (C2X1 L/C)	1	UPPER
F0003GSP101	ALUMINUM L/C SUPPORT	GSP SERIES (C2X1 L/C)	1	UNDER
G0001GSP000	PLASTIC CABINET, UNDER	GSP SERIES (GRAY)	1	
G0001GM0000	PLASTIC CABINET, UPPER	GM SERIES(WHITE)	1	
G0002GSP000	PLASTIC PLATTER	GSP SERIES	1	
G0004GSP000	RUBBER PAD	CFR-190603 (GSP SERIES)	4	
G0004MP0001	ADJUSTABLE FEET	M SERIES	4	
G0009EM0002	BATTERY CAP	EM SERIES(GRAY)	1	
Y0007GEC000	PACKING MATERIAL	GEC SERIES	1	
Z7GEC000000	DUST COVER	G SERIES	1	
A1007000002	FERRITE CORE	TR-14.1*6.28*28.6mm	1	
A1007000001	FERRITE CORE	TR-16*9*28mm	1	LOADCELL
A1007000011	FERRITE CORE	19*6.5*32(CLAMP TYPE)	2	POWER,RS-232 TO MAIN BOARD

AXM-10-X MAINBOARD

E0AXM000010	P.C.B.	AXM-10-1	1	
A0102000289	L.C.D.	UTN-G289JV-W	1	LCD1
A0201089582	I.C.	SM8958C25P	1	U5
A0202093461	I.C.	93C46	1	U7
A0207017225	VOLTAGE REGULATOR I.C.	AIC1722-50CZT	1	U6
A0208085760	I.C.	PCF8576CT	1	U8
A0300000040	I.C. SOCKET	40 PIN	1	U5
A0401007330	TRANSISTOR	A733	1	Q6
A0401009450	TRANSISTOR	2SC945	2	Q2, 7
A0401015150	TRANSISTOR	2SA1515R(2SB1116K,A950Y)	2	Q1, 8
A0501004148	DIODE	1N4148	1	D2
A0701106017	CAPACITOR (EC)	10uF/25V(SS TYPE)	2	C23, 37
A0701107016	CAPACITOR (EC)	100uF/16V	2	C39, 51
A0701226017	CAPACITOR (EC)	22 μ F/16V (SS TYPE)	2	C24, 38
A0701477016	CAPACITOR (EC)	470uF/16V	1	C18
A0730104050	CAPACITOR (MLC)	104Z	9	C25, 27, 28, 32~34, 49~50, 52
A0740030050	CERAMIC CAPACITOR (CC)	30pf/50V(30)	2	C42, 43
A0740101050	CERAMIC CAPACITOR (CC)	100pf/50V(101)	7	C19~22, 29, 30, 48
A0740102050	CERAMIC CAPACITOR (CC)	1000PF/50V(102)	1	C26
A0804041503	METAL FILM RESISTOR	150K Ω 1/4W	1	R48
A0804045003	METAL FILM RESISTOR	500K Ω 1/4W	1	R49
A0805041101	CARBON FILM RESISTOR	100 Ω 1/4W	2	R17, 18
A0805041102	CARBON FILM RESISTOR	1K Ω 1/4W	2	R26, 28
A0805041103	CARBON FILM RESISTOR	10K Ω 1/4W	9	R19, 20, 22~24, 27, 29, 30, 43
A0805041153	CARBON FILM RESISTOR	15K Ω 1/4W	1	R21
A0805041223	CARBON FILM RESISTOR	22K Ω 1/4W	2	R47, 50
A0805041272	CARBON FILM RESISTOR	2.7K Ω 1/4W	2	R44, 51
A0805041472	CARBON FILM RESISTOR	4.7K Ω 1/4W	2	R25, 45
A0805041473	CARBON FILM RESISTOR	47K Ω 1/4W	1	R46
A0802010305	RESISTOR NETWORK	10K Ω 5 PIN	2	NR8, 9
A0901011040	CONNECTOR	4 PIN WAFER 90°	1	J2
A0907020300	CONNECTOR (PIN PLUG)	2 x 15 PIN 180°	1	J4
A0910000070	CONNECTOR (FPC)	7 PIN 180°	1	J5
A0910100130	SOCKET STRIPS	SIP 1*13(FEMALE)	1	LCD1
A0910100140	SOCKET STRIPS	SIP 1*14(FEMALE)	1	LCD1
A0907010030	CONNECTOR	1 * 3 PIN 180°	1	JP2
A0910111020	MINI JUMPER	PITCH 2.54	1	JP2

A1100211059	CRYSTAL	11.0592MHZ	1	X1
A1500000004	BUZZER	OB0-15210	1	BZ1

A/D SECTION

A0203077050	I.C.	AD7705AN	1	U3
A0206000072	I.C	OP177	2	U1-2
A0207029500	VOLTAGE REGULATOR I.C.	AS2950AW	1	U4
A0702226016	CAPACITOR (TC)	22uF/16V(226)	1	C10
A0713105063	POLYESTER FILM CAPACITOR(MEF)	1uF/63V (105)	1	C7
A0730104050	CAPACITOR (MLC)	104Z	10	C1-6, C8-9, C16-17
A0740047050	CERAMIC CAPACITOR (CC)	47pf/50V(47)	2	C11-12
A0740101050	CERAMIC CAPACITOR (CC)	100pf/50V(101)	3	C13-15
A0803041002	METAL FILM RESISTOR	10K Ω 1/4W	2	R7-8
A0803041501	METAL FILM RESISTOR	1.5K Ω 1/4W	1	R12
A0803043001	METAL FILM RESISTOR	3K Ω 1/4W	1	R11
A0803041500	METAL FILM RESISTOR	150 Ω 1/4W	1	R9 (SPAN)
A0804044701	METAL FILM RESISTOR	4.7K Ω 1/4W	4	R3-6
A0805041101	CARBON FILM RESISTOR	100 Ω 1/4W	3	R10, R13-14
A0805041103	CARBON FILM RESISTOR	10K Ω 1/4W	1	R16
A0805041561	CARBON FILM RESISTOR	560 Ω 1/4W	1	R15
A1008000001	EMI FILTER	DSS-306-55Y5S471M100	3	EMI1-3
A1100249152	CRYSTAL	4.9152MHZ	1	X2
F0015000012	PROTECTION BOX	7705-52-1 (UPPER)	1	
F0015000013	PROTECTION BOX	7705-52-1 (UNDER)	1	
Z0010000305	SCREW	M3*6	2	

AXM-40-1 REAR BOARD

E0AXM001000	P.C.B.	AXM-40-1	1	
A0102000289	L.C.D.	UTN-G289JV-W	1	LCD1
A0910100130	SOCKET STRIPS	SIP 1*13(FEMALE)	1	LCD1
A0910100140	SOCKET STRIPS	SIP 1*14(FEMALE)	1	LCD1
A0907020300	CONNECTOR (PIN PLUG)	2 x 15 PIN 180°	1	J1
A0701107016	CAPACITOR (EC)	100uF/16V	1	C1
A0730104050	CAPACITOR (MLC)	104Z	1	C2
A0805041102	CARBON FILM RESISTOR	1K Ω 1/4W	1	R1
A1203300400	FLAT CABLE	30PIN 40CM	1	J1


BACK LIGHT OPTION

A14000000006	BACK LIGHT	130.0*44mm	1	EL1
A1401005000	BACK LIGHT INVERTER	5V / 90c m ²	1	IN1

RS232 OPTION

E1GEC100000	P.C.B. KIT	RS232C-1B1 RS232 BOARD	1	
A0901010040	CONNECTOR	4 PIN WAFER	1	J3
A1007000002	FERRITE CORE	TR-14.1*6.28*28.6mm	1	
A1202040401	WIRE ARRAY	4PIN 40cm, SINGLE HOUSING	1	

7. APPENDIX



ITEM	PART NAME	DESCRIPTION	QTY
1	PLASTIC CABINET, UPPER	GM SERIES(WHITE)	1
2	PLASTIC CABINET, UNDER	GSP SERIES (GRAY)	1
3	ALUMINUM L/C SUPPORT(UPPER)	GSP SERIES (C2X1 L/C)	1
4	ALUMINUM L/C SUPPORT(UNDER)	GSP SERIES (C2X1 L/C)	1
5	PLASTIC PLATTER	GSP SERIES	1
6	ADJUSTABLE FEET	M SERIES	4
7	BATTERY CAP	EM SERIES(GRAY)	1
8	OVERLAY	AXM SERIES	1
9	REAR PANEL	AXM SERIES, REAR DISPLAY	1
10	LOAD CELL	C2G1	1
	LOAD CELL	C2G1	
	AXM-1500	C2G1-3kg	
	AXM-3000	C2G1-6kg	
	AXM-6000	C2G1-10kg	
	AXM-15K	C2G1-20kg	
	AXM-30K	C2G1-35kg	
11	RUBBER PAD	CFR-190603 (GSP SERIES)	4
12	PANEL PC	GW SERIES, 135.5*45.5*0.8mm	1
13	RECHARGEABLE BATTERY	GP4-6 6V 4AH	1
14	S/S PLATE (NO.32)	XM SERIES, 220*185*0.5mm	1
15	P.C.B. KIT	AXM-10-1 MAIN BOARD	1
16	P.C.B. KIT	AXM-40-1 REAR BOARD	1
17	P.C.B. KIT	GM-20-1 POWER BOARD	1
18	FLAT CABLE	30PIN 40CM	1
19	WIRE ARRAY	4PIN 40cm, SINGLE HOUSING	1
20	BUBBLE LEVEL	D14 (Dia. 14mm)	1
21	MEMBRANE K/B	XM SERIES(OIML)	1

APPROVED NO.		REV.
DRAWING NO.: AXM0-M-01-A		1
DWG. NAME	AXM SERIES SEALING DIAGRAM	

AXM SERIES SEALING DIAGRAM

SEALING POSITION

